

Quality Factor (Q)

The *quality factor* (Q) of a *resonator* may be defined as the *resonance frequency* divided by the *resonator bandwidth*:

$$Q \triangleq \frac{\text{ResonanceFrequency}}{\text{Bandwidth}}$$

where the resonance frequency and bandwidth must be given in the same units (*e.g.*, Hz). The *resonance frequency* is typically defined as the frequency at which the *peak gain* occurs. The *bandwidth* is typically defined as the *3dB-bandwidth*, *i.e.*, the bandwidth between the -3dB points (half-power-gain points) straddling the resonance frequency. A nearly equivalent definition of Q from mechanics is the *amplitude gain at resonance*.

We define Q in the context of *continuous-time* resonators, so that the *transfer function* $H(s)$ is the *Laplace transform* of the *continuous impulse-response* $h(t)$, $t \in \mathbb{R}$ (instead of the z transform of the discrete-time impulse-response $h(n)$, $n = 0, 1, 2, \dots$). An introduction to Laplace-transform analysis appears in [Appendix D](#).

The concept of Q is routinely generalized to apply to any *spectral magnitude peak* for which the peak bandwidth can meaningfully be defined. For example, the fourth-order [Moog VCF](#) lowpass [filter](#) may have a "*corner resonance*" for which Q may be defined as the Q of the two-pole resonator causing the corner boost. More generally, there may be any number of physical resonators combining to create a single magnitude-peak in the *frequency response*, and the Q can still be defined clearly as peak-magnitude frequency divided by 3dB-bandwidth. At the other extreme, a spectral peak may involve *no resonators at all* when the impulse response is finite in duration. Thus, the most practical definition of Q for modern usage is *peak frequency divided by peak bandwidth*. However, because the term itself refers to the quality of a simple second-order *resonator* made using a capacitor and [inductor](#), we will keep the historical definition and generalize as needed.

Subsections

- [Q of a Complex Resonator](#)
- [Q of a Real Second-Order Resonator](#)
 - [Critical Damping and Related Terms](#)
- [Damping Ratio](#)
- [Decay Time is Q Periods](#)
- [Q as Energy Stored over Energy Dissipated](#)

[Next](#) | [Prev](#) | [Up](#) | [Top](#) | [Index](#) | [JOS Index](#) | [JOS Pubs](#) | [JOS Home](#) | [Search](#)

[\[How to cite this work\]](#) [\[Order a printed hardcopy\]](#) [\[Comment on this page via email\]](#)

“Introduction to Digital Filters with Audio Applications”, by Julius O. Smith III, (September 2007 Edition)

Copyright © 2024-09-03 by Julius O. Smith III

Center for Computer Research in Music and Acoustics (CCRMA), Stanford University

