

ELECTRONICS

FOURTH EDITION

BARRON'S GUARANTEE:

This book will improve
your grades in 30 days
or you can return it
to Barron's for
a full refund.

Your Key to Electronics

by Rex Miller and
Mark R. Miller

If you want to learn
electronics...

If you want to
understand it

The Easy Way...

If you want to raise
your grades...

Read this book!

It was written for you.

THE EASY WAY

ELECTRONICS



FOURTH EDITION

Rex Miller

Professor Emeritus, State University College
Buffalo, New York

Mark R. Miller

Chair and Associate Professor, Texas A & M University-Kingsville
Kingsville, Texas



© Copyright 2002, 1995, 1988, 1984 by Barron's Educational Series Inc.

All rights reserved.

No part of this book may be reproduced in any form, by photostat, microfilm, xerography, or any other means, or incorporated into any information retrieval system, electronic or mechanical, without the written permission of the copyright owner.

All inquiries should be addressed to:

Barron's Educational Series, Inc.

250 Wireless Boulevard

Hauppauge, New York 11788

<http://www.barronseduc.com>

Library of Congress Catalog Card No. 2002016321

International Standard Book No. 0-7641-1981-8

Library of Congress Cataloging-in-Publication Data

Miller, Rex

Electronics the easy way / Rex Miller, Mark R. Miller. — 4th ed.

p. cm.

Includes index.

ISBN 0-7641-1981-8

I. Electronics. II. Miller, Mark R. III. Title.

TK7816 .M53 2002

621.381—dc21

2002016321

PRINTED IN THE UNITED STATES OF AMERICA

10 9 8 7 6 5 4 3 2 1

CONTENTS

Preface vi

1 Careers

- Electrical Engineering 1
- Newer Employment Opportunities 2
- The Integrated Circuit 3
- Electronics Engineer 3
- Electric Utilities 4
- The Telephone Industry 5
- TV, Radio, and Appliance Repair 6
- The Broadcast Industry 8
- Summary 9
- Review Questions 9

2 Introduction to Electronics

- Basic Atomic Structure 10
- Electric Energy 13
- Voltage and Current 15
- Power 16
- Resistance 18
- Ohm's Law 21
- Circuits 22
- Summary 29
- Review Questions 30

3 Inductance, Capacitance, and Alternating Current

- Inductance 31
- Alternating Current 35
- Transformers 38
- Inductive Reactance 40
- Capacitors 42
- Capacitive Reactance 49
- Summary 51
- Review Questions 52

4 Resonance

- Resistance, Capacitance, and Inductance 54
- Finding a Vector Sum 56
- Finding the Impedance of an RL Circuit 56
- Impedance in an RC Circuit 58
- Series RCL Circuit 59
- Phase Angle 61
- Power Factor 63
- Series Resonance 64
- Parallel Resonance 67
- Series Resonance Versus Parallel Resonance 70
- Summary 72
- Review Questions 73

5 Changing Alternating Current to Direct Current

- Selenium Rectifiers 75
- Solid State Rectifiers 76
- Power Supply Rectifiers 78
- Filters 83
- Voltage Multipliers 88
- Summary 90
- Review Questions 92

6 Semiconductors

- A Bit of History 93
- Diodes and How They Work 93
- Semiconductor Diodes 98
- Biasing the Junction Diode 101
- The Point Contact Diode 104
- Zener Diodes 105
- Tunnel Diodes 107
- The Silicon Controlled Rectifier 109
- Transistors 110
- Integrated Circuits 117
- Summary 119
- Review Questions 122

7 Electrical Power

- Three-Phase Power 124
- Single-Phase Power 127
- Summary 136
- Review Questions 136

8 Audio Amplifiers

- Distortion 138
- Classes of Operation 140
- Transistor Amplifiers 144
- Integrated Circuits 145
- Operational Amplifiers 146
- Summary 150
- Review Questions 151

9 Other Types of Amplifiers

- Tuned Circuit Coupling 152
- Voltage Amplifiers 153
- Power Amplifiers 154
- Feedback in Amplifiers 154
- Integrated Circuits 156
- Operational Amplifiers 157
- Differential Amplifiers 160
- Field Effect Transistors 161
- Common FET Configurations 164
- Gallium-Arsenide FET 165
- Infrared Emitting Diodes 166
- Silicon Photo Detectors 167
- Summary 168
- Review Questions 169

10 Stereo Equipment

- Nature of Sound 170
- Microphones 172
- Turntables and Record Changers 179
- Tape Recorders 183
- Compact Disc 187
- Digital Audio Tape 194
- Preamplifiers 196
- Power Amplifiers 196
- Comparison of Power Amplifiers 198
- Speakers 200
- Speaker Enclosures 204
- Crossover Networks 206
- Summary 208
- Review Questions 209

11 Oscillators

- Conditions Needed for Oscillations 211
- Feedback 213
- Oscillator Output 214
- Crystals 214
- Transistor Oscillators 215
- Newer Oscillator Circuits 222
- Microwaves 224
- Summary 230
- Review Questions 231

12 Modulation and Demodulation

- Modulation 232
- AM Radiotelephone Transmitter 233
- Amplitude Modulation 233
- Frequency Modulation 234
- Phase Modulation 237
- Detectors or Demodulators 238
- Quadrature Detection 245
- Other Types of Modulation 246
- Tone Modulation 247
- Frequency Shift Keying 247
- Pulse Modulation 249
- Pulse Width Modulation 250
- Pulse-Position Modulation 251
- Summary 251
- Review Questions 252

13 Transmitters, Transmission Lines, and Antennas

- Continuous Wave Transmitter 253
- Amplitude-Modulated Transmitters 253
- Frequency-Modulated Transmitters 256
- Transmission Lines 258
- Antennas 261
- Summary 268
- Review Questions 269

14 Receivers

- Antennas 270
- Transmission Lines 270
- Amplitude-Modulated Receivers 273
- AM Radio on a Chip 280
- Frequency-Modulated Receivers 281
- FM Stereo 286
- FM Radio on a Chip 289
- Other FM Users 290
- Summary 291
- Review Questions 292

15 Television

- Camera Tubes 293
- TV Transmitter 297
- Color Television 301
- LCD Television Pictures 308
- High Definition Television 311
- TV Receiver Antennas 311
- Summary 313
- Review Questions 314

16 Lasers and Fiber Optics

- Types of Lasers 316
- Fiber Optics 319
- Fiber Optics Communications System 322
- Uses for Fiber Optics 324
- Summary 325
- Review Questions 325

17 Radar and Microwaves

- Principles of Operation for Radar 326
- Required Elements of a Pulse System 331
- Power Requirements of a Pulse System 333
- Waveguides and Cavity Resonators 334
- Radar Antennas 337
- Wave Propagation into Space 338
- Uses of Radar 339
- Radar Detector 339
- Microwave Ovens 342
- Summary 344
- Review Questions 345

18 Computers

- History 346
- Types of Computers 347
- Computer Circuits 348
- Truth Table 349
- Microprocessors, Personal Computers, and Special-Purpose Computers 354
- Microprocessors 355
- How the Microprocessor Works 357
- Communicating with the Microprocessor 358
- The Special-Purpose Computer at Work 359
- Summary 360
- Review Questions 361

19 Applications of Electronics

- The Phase-Locked Loop 362
- Cable Television 364
- Satellite Television 365
- Global Positioning System 368
- Robotics 369
- Videotape 380
- The Compact Disc 380
- DVD 382
- Space Manufacturing 383
- Tape Scan Systems 383
- Home Video Systems 384
- Summary 386
- Review Questions 387

20 Cellular Phones, Pagers, Faxes, and Printers

- Cellular Telephone System 389
- Pagers 394
- Facsimiles (Faxes) 395
- Inkjet Printers 400
- Laser and LED Printers 401
- Summary 402
- Review Questions 403

21 Electronics in the Future

- Fiber Optics 405
- Digital Processing 405
- Automobile Electronics 406
- Communications 406
- Home Appliances 406
- Medical Electronics 406
- CCD Television Cameras 406
- The Internet 408
- Summary 409

Glossary 410**Answers to Review Questions 419****Appendix: Electronics Jobs 437**

- Jobs Directly Related to the Production of Semiconductors 437
- Jobs Directly Related to the Printed Circuit Boards 444
- Other Electronics Jobs 455

Index 465

Resistors marked with the color code are available in hundreds of size and wattage rating combinations. Wattage rating refers to the wattage or power consumed by the resistor.

Ohm's Law

A German physicist by the name of Georg Ohm discovered the relationship between voltage, current, and resistance in 1827. He found that in any circuit where the only opposition to the flow of electrons is resistance, there is a relationship between the values of voltage, current, and resistance. The strength or intensity of the current is directly proportional to the voltage and inversely proportional to the resistance.

It is easier to work with Ohm's law when it is expressed in a formula. In the formula, E represents emf, or voltage; I is the current, or the intensity of electron flow; R stands for resistance. The formula is $E = I \times R$. It is used to find the emf (voltage) when the current and the resistance are known.

To find the current, when the voltage and resistance are known, use

$$I = \frac{E}{R}$$

To find the resistance, when the voltage and current are known, use

$$R = \frac{E}{I}$$

Using Ohm's Law

Ohm's law is very useful in electrical and electronics work. You will need it often to determine the missing value. In order to make it easy to remember the formula take a look at Figure 2-7. Here the formulas are arrived at by placing your finger on the unknown and the other two will have their relationship displayed.

The best way to become accustomed to solving problems is to start with something simple, such as:

1. If the voltage is given as 100 V and the resistance is 25 Ω , it is a simple problem and a practical application of Ohm's law to find the current in the circuit. Use

$$I = \frac{E}{R}$$

Substituting the values in the formula,

$$I = \frac{100}{25}$$

means 100 is divided by 25 to produce 4 A for the current.

2. If the current is given as 2 A (you may read it on an ammeter in the circuit), and the voltage (read from the voltmeter) is 100 V, it is easy to find the resistance. Use




Figure 6-30. A. Symbols for FET transistors. B. MOS (metal-oxide semiconductor) transistor. C. An FET transistor in a circuit configuration.

Integrated Circuits

The integrated circuit (IC) is a single, monolithic chip made of semiconductor material. It was first designed and developed in 1958 a short time after the transistor was introduced and made available for experimentation. J. S. Kilby was responsible for the fabrication of the first IC, or integrated circuit. He was able to make both active and passive circuit elements become part of the chip by using diffusion and deposition techniques. Shortly after his success, Robert Noyce made a complete circuit on a single chip. This led the way to the modern, inexpensive IC.

Transistors, diodes, resistors, and capacitors can now be deposited on a chip. Diodes can be made in many groups to do different things. Photolithography, a combination of photographic and printing techniques, has been used to make the complete circuit. This type of printing has made it possible to produce some very sophisticated ICs with very high reliability.

Figure 6-31 shows how an IC has the resistor, capacitor, diode, and transistor etched on its surface and turned into a complete circuit on a flat surface which can be easily packaged and protected. Figure 6-31A shows how a resistor is placed on the chip. The resistor is made in the form of a thin filament of conductive material. Contacts are made. It is insulated by a reverse-biased junction. It is possible to create a few ohms (Ω) or up to 20,000 Ω on ICs.

Figure 6-31B shows how a low-loss capacitor is formed. This is done by depositing a thin insulating layer of silicon dioxide on a conducting region. It is then given a metallized layer to form the second plate. It is possible to reverse-bias a diode to form a capacitor with up to 50 picofarads (pF) of capacitance. Note how capacitors require more space on the chip than resistors. The transistors and diodes require less space. They are connected




Figure 8-13. Common-collector transistor amplifier with current flow and voltage waveforms.

Common Base

Note the connections made to the base, emitter, and collector of the transistor in Figure 8-11. Current flow through the NPN transistor is indicated by the arrows. About 95 percent of the emitter current reaches the collector. In practical circuits the flow is 92 to 98 percent. Here we use 95 as a compromise; the remainder (5 percent) flows through the base.

Input and output waveforms represent the voltage of the signal. Input signal from the generator is applied in series with the bias (battery) between the base and emitter. The output signal appears across the collector load resistor R_1 . The output signal has the same shape and phase as the input except that it is amplified.

Common Emitter

The common-emitter circuit is shown in Figure 8-12. Again, the arrows indicate the current flow and its direction. The input signal of the common-emitter amplifier is 180° out of phase with the output signal that appears across R_1 .

Common Collector

The common-collector circuit is shown in Figure 8-13. This is a particularly useful type of circuit when it comes to impedance matching. It does not amplify, but acts as an impedance-matching device. Note that the signal is not reversed but is the same phase as the input. This can be visualized easily if you note that the output signal is taken from the emitter resistor R_1 .

Table 8-1 will aid you in summarizing the characteristics of the various types of transistor amplifier circuits.

Integrated Circuits

Chips, ICs, integrated circuits all mean the same thing. The integrated circuit is just what its name says: It is a circuit. This circuit can contain the resistances, capacitances, and inductances as well as the transistors and diodes. All this can be contained in a small chip which is so tiny that it is difficult to see with the unaided eye (see Figure 8-14).




Figure 9-15. Three differential amplifiers connected in cascade.

Field Effect Transistors

The field effect transistor (FET) has high input impedance compared with the low input impedance of the bipolar transistor. The FET operates on low dc supply voltages. This type of transistor is used in many consumer devices inasmuch as it is lightweight, rugged, and very small in size.

The FET has three terminals with slightly different names from those encountered with transistors. It has a gate (G), drain (D), and source (S). The drain could be called the anode and the source called the cathode, with the gate being the current controlling connection (see Figure 9-16).

FETs can be classified as to two major types: junction FET (JFET) and metal oxide semiconductor (MOSFET). Sometimes the MOSFET is also referred to as the insulated gate FET (IGFET). The JFET is further classified according to the type of material that makes up its *channel*. The channel is either P-type or N-type material. However, the MOSFET is classified according to its *mode* of operation — that could be either depletion mode or the enhancement mode. Figure 9-17 shows the schematic for MOSFETs.




Figure 9-16. Single gate FET circuit configuration.

Chapter 14

RECEIVERS

The other half of the radio frequency (RF) communications consists of a receiver. The transmitted wave is of very little use unless it is received and decoded to present the information, music, or speech as intended. This is where the receiver does its half of the job in a communications system.

Antennas

Antennas have already been mentioned and discussed in transmitters. The reciprocity principle can be applied here since the transmitting antenna can also be used as a receiving antenna. When a transmitted wave passes a receiving antenna, it induces a current in the antenna as a result of electromagnetic induction. This current varies with the frequency of the wave. This weak current can then be amplified and processed to produce the intelligence it contains.

A number of different stages are designed for various purposes in a receiver. It is the intent of this chapter to cover the stages and how they operate to produce the output in the form of speech, music, or other intelligence.

Requirements for receiving antennas are much less severe than those for a transmitter. If you are not using the same antenna that the transmitter used, you can use some rather simple ones for receivers since they use very low signal strengths. Antennas for receivers may include a straight piece of wire, coils of wire, or basic dipoles. They can also be a little more complicated when it comes to bringing in very weak signals from long distances. The parabolic reflector in the form of a receiving dish is used in satellite communications and in home reception of satellite television.

A stacked array, or dish, can become more directional and enable the operation of a receiver on very weak signals (see Figure 14-1). Figure 14-2 is a loop antenna used for simple amplitude modulation (AM) reception on the broadcast band, i.e., 535 to 1605 kilohertz (kHz). A dipole for frequency modulation (FM) enhances reception if the signal is weak or if stereo is to be picked up. A stereo signal requires a stronger signal fed into the amplifier than the mono FM signal. Figure 14-3 shows an FM dipole antenna that aids in bringing in weaker stations. In most instances, point-to-point communications on FM need a stacked array.

Transmission Lines

Getting the signal from the antenna is no problem in most small portable AM receivers or in FM sets that operate on local stations, but the signal from the antenna to the receiver,

BARRON'S

ELECTRONICS

FOURTH EDITION

**ALL THE
ESSENTIALS
IN ONE CLEAR
VOLUME**

**by Rex Miller and
Mark R. Miller**

THE EASY WAY

- A clear and easy approach to understanding electronics
- Reviews basic principles of electricity and electronics
- Describes many careers open in the field
- Covers recent developments in electronics

- Semiconductors
- Audio amplifiers and stereo equipment
- Oscillators
- Lasers and fiber optics
- Computer hardware
- and much more

ISBN 0-7641-1981-8 5 1495 >
EAN  
9 780764 119811
\$14.95 Canada \$21.00
www.barronseduc.com