
**6–54.** The beam is made from three boards nailed together as shown. If the moment acting on the cross section is $M = 600\ \text{N}\cdot\text{m}$, determine the maximum bending stress in the beam. Sketch a three-dimensional view of the stress distribution acting over the cross section.


**6–55.** The beam is made from three boards nailed together as shown. If the moment acting on the cross section is $M = 600\ \text{N}\cdot\text{m}$, determine the resultant force the bending stress produces on the top board.




**Probs. 6–54/55**

***6–56.** The aluminum strut has a cross-sectional area in the form of a cross. If it is subjected to the moment $M = 8\ \text{kN}\cdot\text{m}$, determine the bending stress acting at points $A$ and $B$, and show the results acting on volume elements located at these points.


**•6–57.** The aluminum strut has a cross-sectional area in the form of a cross. If it is subjected to the moment $M = 8\ \text{kN}\cdot\text{m}$, determine the maximum bending stress in the beam, and sketch a three-dimensional view of the stress distribution acting over the entire cross-sectional area.




**Probs. 6–56/57**

**6–58.** If the beam is subjected to an internal moment of $M = 100\ \text{kip}\cdot\text{ft}$, determine the maximum tensile and compressive bending stress in the beam.


**6–59.** If the beam is made of material having an allowable tensile and compressive stress of $(\sigma_{allow})_t = 24\ \text{ksi}$ and $(\sigma_{allow})_c = 22\ \text{ksi}$, respectively, determine the maximum allowable internal moment **M** that can be applied to the beam.




**Probs. 6–58/59**

***6–60.** The beam is constructed from four boards as shown. If it is subjected to a moment of $M_z = 16\ \text{kip}\cdot\text{ft}$, determine the stress at points $A$ and $B$. Sketch a three-dimensional view of the stress distribution.


**•6–61.** The beam is constructed from four boards as shown. If it is subjected to a moment of $M_z = 16\ \text{kip}\cdot\text{ft}$, determine the resultant force the stress produces on the top board $C$.




**Probs. 6–60/61**


Zhuhai CosMX Battery Co. - EX1021 (Part 2 of 3)
Zhuhai CosMX Battery Co. v. Ningde Amperex Tech. Ltd.

**6–62.** A box beam is constructed from four pieces of wood, glued together as shown. If the moment acting on the cross section is 10 kN · m, determine the stress at points $A$ and $B$ and show the results acting on volume elements located at these points.





Prob. 6–62

**6–63.** Determine the dimension $a$ of a beam having a square cross section in terms of the radius $r$ of a beam with a circular cross section if both beams are subjected to the same internal moment which results in the same maximum bending stress.




Prob. 6–63


***6–64.** The steel rod having a diameter of 1 in. is subjected to an internal moment of $M = 300$ lb · ft. Determine the stress created at points $A$ and $B$. Also, sketch a three-dimensional view of the stress distribution acting over the cross section.




Prob. 6–64

**•6–65.** If the moment acting on the cross section of the beam is $M = 4$ kip · ft, determine the maximum bending stress in the beam. Sketch a three-dimensional view of the stress distribution acting over the cross section.


**6–66.** If $M = 4$ kip · ft, determine the resultant force the bending stress produces on the top board $A$ of the beam.




Probs. 6–65/66


**6–67.** The rod is supported by smooth journal bearings at $A$ and $B$ that only exert vertical reactions on the shaft. If $d = 90$ mm, determine the absolute maximum bending stress in the beam, and sketch the stress distribution acting over the cross section.

***6–68.** The rod is supported by smooth journal bearings at $A$ and $B$ that only exert vertical reactions on the shaft. Determine its smallest diameter $d$ if the allowable bending stress is $\sigma_{allow} = 180$ MPa.





Probs. 6–67/68

**•6–69.** Two designs for a beam are to be considered. Determine which one will support a moment of $M = 150\ \text{kN} \cdot \text{m}$ with the least amount of bending stress. What is that stress?





Prob. 6–69

**6–70.** The simply supported truss is subjected to the central distributed load. Neglect the effect of the diagonal lacing and determine the absolute maximum bending stress in the truss. The top member is a pipe having an outer diameter of 1 in. and thickness of $\frac{3}{16}$ in., and the bottom member is a solid rod having a diameter of $\frac{1}{2}$ in.




Prob. 6–70


**6–71.** The axle of the freight car is subjected to wheel loadings of 20 kip. If it is supported by two journal bearings at $C$ and $D$, determine the maximum bending stress developed at the center of the axle, where the diameter is 5.5 in.




Prob. 6–71


***6–72.** The steel beam has the cross-sectional area shown. Determine the largest intensity of distributed load $w_0$ that it can support so that the maximum bending stress in the beam does not exceed $\sigma_{max} = 22$ ksi.

**•6–73.** The steel beam has the cross-sectional area shown. If $w_0 = 0.5$ kip/ft, determine the maximum bending stress in the beam.





Probs. 6–72/73

**6–74.** The boat has a weight of 2300 lb and a center of gravity at $G$. If it rests on the trailer at the smooth contact $A$ and can be considered pinned at $B$, determine the absolute maximum bending stress developed in the main strut of the trailer. Consider the strut to be a box-beam having the dimensions shown and pinned at $C$.





Prob. 6–74

**6–75.** The shaft is supported by a smooth thrust bearing at $A$ and smooth journal bearing at $D$. If the shaft has the cross section shown, determine the absolute maximum bending stress in the shaft.




Prob. 6–75


*6–76. Determine the moment **M** that must be applied to the beam in order to create a maximum stress of 80 MPa. Also sketch the stress distribution acting over the cross section.




Prob. 6–76

•6–77. The steel beam has the cross-sectional area shown. Determine the largest intensity of distributed load $w$ that it can support so that the bending stress does not exceed $\sigma_{max} = 22$ ksi.

6–78. The steel beam has the cross-sectional area shown. If $w = 5$ kip/ft, determine the absolute maximum bending stress in the beam.





Probs. 6–77/78

6–79. If the beam $ACB$ in Prob. 6–9 has a square cross section, 6 in. by 6 in., determine the absolute maximum bending stress in the beam.

*6–80. If the crane boom $ABC$ in Prob. 6–3 has a rectangular cross section with a base of 2.5 in., determine its required height $h$ to the nearest $\frac{1}{4}$ in. if the allowable bending stress is $\sigma_{allow} = 24$ ksi.

•6–81. If the reaction of the ballast on the railway tie can be assumed uniformly distributed over its length as shown, determine the maximum bending stress developed in the tie. The tie has the rectangular cross section with thickness $t = 6$ in.


6–82. The reaction of the ballast on the railway tie can be assumed uniformly distributed over its length as shown. If the wood has an allowable bending stress of $\sigma_{allow} = 1.5$ ksi, determine the required minimum thickness $t$ of the rectangular cross sectional area of the tie to the nearest $\frac{1}{8}$ in.




Probs. 6–81/82


6–83. Determine the absolute maximum bending stress in the tubular shaft if $d_i = 160$ mm and $d_o = 200$ mm.

*6–84. The tubular shaft is to have a cross section such that its inner diameter and outer diameter are related by $d_i = 0.8d_o$. Determine these required dimensions if the allowable bending stress is $\sigma_{allow} = 155$ MPa.




Probs. 6–83/84


6–85. The wood beam has a rectangular cross section in the proportion shown. Determine its required dimension $b$ if the allowable bending stress is $\sigma_{allow} = 10$ MPa.




Prob. 6–85


**6–86.** Determine the absolute maximum bending stress in the 2-in.-diameter shaft which is subjected to the concentrated forces. The journal bearings at $A$ and $B$ only support vertical forces.

**6–87.** Determine the smallest allowable diameter of the shaft which is subjected to the concentrated forces. The journal bearings at $A$ and $B$ only support vertical forces. The allowable bending stress is $\sigma_{allow} = 22$ ksi.




Probs. 6–86/87

*6–88. If the beam has a square cross section of 9 in. on each side, determine the absolute maximum bending stress in the beam.





Prob. 6–88

•6–89. If the compound beam in Prob. 6–42 has a square cross section, determine its dimension $a$ if the allowable bending stress is $\sigma_{allow} = 150$ MPa.

**6–90.** If the beam in Prob. 6–28 has a rectangular cross section with a width $b$ and a height $h$, determine the absolute maximum bending stress in the beam.


**6–91.** Determine the absolute maximum bending stress in the 80-mm-diameter shaft which is subjected to the concentrated forces. The journal bearings at $A$ and $B$ only support vertical forces.

*6–92. Determine the smallest allowable diameter of the shaft which is subjected to the concentrated forces. The journal bearings at $A$ and $B$ only support vertical forces. The allowable bending stress is $\sigma_{allow} = 150$ MPa.




Probs. 6–91/92


•6–93. The man has a mass of 78 kg and stands motionless at the end of the diving board. If the board has the cross section shown, determine the maximum normal strain developed in the board. The modulus of elasticity for the material is $E = 125$ GPa. Assume $A$ is a pin and $B$ is a roller.




Prob. 6–93


**6–94.** The two solid steel rods are bolted together along their length and support the loading shown. Assume the support at $A$ is a pin and $B$ is a roller. Determine the required diameter $d$ of each of the rods if the allowable bending stress is $\sigma_{allow} = 130$ MPa.

**6–95.** Solve Prob. 6–94 if the rods are rotated 90° so that both rods rest on the supports at $A$ (pin) and $B$ (roller).





Probs. 6–94/95

***6–96.** The chair is supported by an arm that is hinged so it rotates about the vertical axis at $A$. If the load on the chair is 180 lb and the arm is a hollow tube section having the dimensions shown, determine the maximum bending stress at section $a$–$a$.





**Prob. 6–96**

**•6–97.** A portion of the femur can be modeled as a tube having an inner diameter of 0.375 in. and an outer diameter of 1.25 in. Determine the maximum elastic static force $P$ that can be applied to its center. Assume the bone to be roller supported at its ends. The $\sigma$–$\epsilon$ diagram for the bone mass is shown and is the same in tension as in compression.





**Prob. 6–97**

**6–98.** If the beam in Prob. 6–18 has a rectangular cross section with a width of 8 in. and a height of 16 in., determine the absolute maximum bending stress in the beam.




**Prob. 6–98**


**6–99.** If the beam has a square cross section of 6 in. on each side, determine the absolute maximum bending stress in the beam.




**Prob. 6–99**


***6–100.** The steel beam has the cross-sectional area shown. Determine the largest intensity of the distributed load $w_0$ that it can support so that the maximum bending stress in the beam does not exceed $\sigma_{allow} = 22$ ksi.

**•6–101.** The steel beam has the cross-sectional area shown. If $w_0 = 2$ kip/ft, determine the maximum bending stress in the beam.




**Probs. 6–100/101**


**6–102.** The bolster or main supporting girder of a truck body is subjected to the uniform distributed load. Determine the bending stress at points $A$ and $B$.




Prob. 6–102

**6–103.** Determine the largest uniform distributed load $w$ that can be supported so that the bending stress in the beam does not exceed $\sigma_{allow} = 5$ MPa.


***6–104.** If $w = 10$ kN/m, determine the maximum bending stress in the beam. Sketch the stress distribution acting over the cross section.




Probs. 6–103/104

**•6–105.** If the allowable bending stress for the wood beam is $\sigma_{allow} = 150$ psi, determine the required dimension $b$ to the nearest $\frac{1}{4}$ in. of its cross section. Assume the support at $A$ is a pin and $B$ is a roller.


**6–106.** The wood beam has a rectangular cross section in the proportion shown. If $b = 7.5$ in., determine the absolute maximum bending stress in the beam.




Probs. 6–105/106

**6–107.** A beam is made of a material that has a modulus of elasticity in compression different from that given for tension. Determine the location $c$ of the neutral axis, and derive an expression for the maximum tensile stress in the beam having the dimensions shown if it is subjected to the bending moment **M**.

***6–108.** The beam has a rectangular cross section and is subjected to a bending moment **M**. If the material from which it is made has a different modulus of elasticity for tension and compression as shown, determine the location $c$ of the neutral axis and the maximum compressive stress in the beam.




Probs. 6–107/108





Fig. 6–29

## 6.5 Unsymmetric Bending

When developing the flexure formula we imposed a condition that the cross-sectional area be *symmetric* about an axis perpendicular to the neutral axis; furthermore, the resultant internal moment **M** acts along the neutral axis. Such is the case for the "T" or channel sections shown in Fig. 6–29. These conditions, however, are unnecessary, and in this section we will show that the flexure formula can also be applied either to a beam having a cross-sectional area of any shape or to a beam having a resultant internal moment that acts in any direction.

**Moment Applied About Principal Axis.** Consider the beam's cross section to have the unsymmetrical shape shown in Fig. 6–30*a*. As in Sec. 6.4, the right-handed $x, y, z$ coordinate system is established such that the origin is located at the centroid $C$ on the cross section, and the resultant internal moment **M** acts along the $+z$ axis. We require the stress distribution acting over the entire cross-sectional area to have a zero force resultant, the resultant internal moment about the $y$ axis to be zero, and the resultant internal moment about the $z$ axis to equal **M**.* These three conditions can be expressed mathematically by considering the force acting on the differential element $dA$ located at $(0, y, z)$, Fig. 6–30*a*. This force is $dF = \sigma\, dA$, and therefore we have

$$F_R = \Sigma F_x; \qquad 0 = -\int_A \sigma\, dA \tag{6–14}$$

$$(M_R)_y = \Sigma M_y; \qquad 0 = -\int_A z\sigma\, dA \tag{6–15}$$

$$(M_R)_z = \Sigma M_z; \qquad M = \int_A y\sigma\, dA \tag{6–16}$$





Fig. 6–30

*The condition that moments about the $y$ axis be equal to zero was not considered in Sec. 6.4, since the bending-stress distribution was *symmetric* with respect to the $y$ axis and such a distribution of stress automatically produces zero moment about the $y$ axis. See Fig. 6–24*c*.

As shown in Sec. 6.4, Eq. 6–14 is satisfied since the $z$ axis passes through the *centroid* of the area. Also, since the $z$ axis represents the *neutral axis* for the cross section, the normal stress will vary linearly from zero at the neutral axis, to a maximum at $y = c$, Fig. 6–30*b*. Hence the stress distribution is defined by $\sigma = -(y/c)\sigma_{max}$. When this equation is substituted into Eq. 6–16 and integrated, it leads to the flexure formula $\sigma_{max} = Mc/I$. When it is substituted into Eq. 6–15, we get

$$0 = \frac{-\sigma_{max}}{c}\int_A yz\,dA$$

which requires

$$\int_A yz\,dA = 0$$

This integral is called the ***product of inertia*** for the area. As indicated in Appendix A, it will indeed be zero provided the $y$ and $z$ axes are chosen as ***principal axes of inertia*** for the area. For an arbitrarily shaped area, the orientation of the principal axes can always be determined, using either the inertia transformation equations or Mohr's circle of inertia as explained in Appendix A, Secs. A.4 and A.5. If the area has an axis of symmetry, however, the ***principal axes*** can easily be established ***since they will always be oriented along the axis of symmetry and perpendicular to it.***

For example, consider the members shown in Fig. 6–31. In each of these cases, $y$ and $z$ must define the principal axes of inertia for the cross section in order to satisfy Eqs. 6–14 through 6–16. In Fig. 6–31*a* the principal axes are located by symmetry, and in Figs. 6–31*b* and 6–31*c* their orientation is determined using the methods of Appendix A. Since **M** is applied about one of the principal axes ($z$ axis), the stress distribution is determined from the flexure formula, $\sigma = -My/I_z$, and is shown for each case.





Fig. 6–31





Fig. 6–32

**Moment Arbitrarily Applied.** Sometimes a member may be loaded such that **M** does not act about one of the principal axes of the cross section. When this occurs, the moment should first be resolved into components directed along the principal axes, then the flexure formula can be used to determine the normal stress caused by *each* moment component. Finally, using the principle of superposition, the resultant normal stress at the point can be determined.

To show this, consider the beam to have a rectangular cross section and to be subjected to the moment **M**, Fig. 6–32*a*. Here **M** makes an angle $\theta$ with the *principal* $z$ axis. We will assume $\theta$ is positive when it is directed from the $+z$ axis toward the $+y$ axis, as shown. Resolving **M** into components along the $z$ and $y$ axes, we have $M_z = M\cos\theta$ and $M_y = M\sin\theta$, as shown in Figs. 6–32*b* and 6–32*c*. The normal-stress distributions that produce **M** and its components $\mathbf{M}_z$ and $\mathbf{M}_y$ are shown in Figs. 6–32*d*, 6–32*e*, and 6–32*f*, where it is assumed that $(\sigma_x)_{max} > (\sigma'_x)_{max}$. By inspection, the maximum tensile and compressive stresses $[(\sigma_x)_{max} + (\sigma'_x)_{max}]$ occur at two opposite corners of the cross section, Fig. 6–32*d*.

Applying the flexure formula to each moment component in Figs. 6–32*b* and 6–32*c*, and adding the results algebraically, the resultant normal stress at any point on the cross section, Fig. 6–32*d*, is then

$$\sigma = -\frac{M_z y}{I_z} + \frac{M_y z}{I_y} \tag{6–17}$$

Here,

$\sigma$ = the normal stress at the point

$y, z$ = the coordinates of the point measured from $x, y, z$ axes having their origin at the centroid of the cross-sectional area and forming a right-handed coordinate system. The $x$ axis is directed outward from the cross-section and the $y$ and $z$ axes represent respectively the principal axes of minimum and maximum moment of inertia for the area

$M_y, M_z$ = the resultant internal moment components directed along the principal $y$ and $z$ axes. They are positive if directed along the $+y$ and $+z$ axes, otherwise they are negative. Or, stated another way, $M_y = M\sin\theta$ and $M_z = M\cos\theta$, where $\theta$ is measured positive from the $+z$ axis toward the $+y$ axis

$I_y, I_z$ = the *principal moments of inertia* calculated about the $y$ and $z$ axes, respectively. See Appendix A.

The $x$, $y$, $z$ axes form a right-handed system, and the proper algebraic signs must be assigned to the moment components and the coordinates when applying this equation. When this is the case, the resulting stress will be *tensile* if it is *positive* and *compressive* if it is *negative*.

**Orientation of the Neutral Axis.** The angle $\alpha$ of the neutral axis in Fig. 6–32*d* can be determined by applying Eq. 6–17 with $\sigma = 0$, since by definition no normal stress acts on the neutral axis. We have

$$y = \frac{M_y I_z}{M_z I_y} z$$

Since $M_z = M\cos\theta$ and $M_y = M\sin\theta$, then

$$y = \left(\frac{I_z}{I_y}\tan\theta\right) z \tag{6–18}$$

This equation defines the neutral axis for the cross section. Since the slope of this line is $\tan\alpha = y/z$, then

$$\tan\alpha = \frac{I_z}{I_y}\tan\theta \tag{6–19}$$

Here it can be seen that unless $I_z = I_y$ the angle $\theta$, defining the direction of the moment **M**, Fig. 6–32*a*, will *not equal* $\alpha$, the angle defining the inclination of the neutral axis, Fig. 6–32*d*.

## Important Points

- The flexure formula can be applied only when bending occurs about axes that represent the *principal axes of inertia* for the cross section. These axes have their origin at the centroid and are oriented along an axis of symmetry, if there is one, and perpendicular to it.
- If the moment is applied about some arbitrary axis, then the moment must be resolved into components along each of the principal axes, and the stress at a point is determined by superposition of the stress caused by each of the moment components.





Fig. 6–32 (cont.)

## EXAMPLE 6.15

The rectangular cross section shown in Fig. 6–33*a* is subjected to a bending moment of $M = 12\,\text{kN}\cdot\text{m}$. Determine the normal stress developed at each corner of the section, and specify the orientation of the neutral axis.

### SOLUTION

**Internal Moment Components.** By inspection it is seen that the $y$ and $z$ axes represent the principal axes of inertia since they are axes of symmetry for the cross section. As required we have established the $z$ *axis* as the principal axis for *maximum* moment of inertia. The moment is resolved into its $y$ and $z$ components, where

$$M_y = -\frac{4}{5}(12\,\text{kN}\cdot\text{m}) = -9.60\,\text{kN}\cdot\text{m}$$

$$M_z = \frac{3}{5}(12\,\text{kN}\cdot\text{m}) = 7.20\,\text{kN}\cdot\text{m}$$

**Section Properties.** The moments of inertia about the $y$ and $z$ axes are

$$I_y = \frac{1}{12}(0.4\,\text{m})(0.2\,\text{m})^3 = 0.2667(10^{-3})\,\text{m}^4$$

$$I_z = \frac{1}{12}(0.2\,\text{m})(0.4\,\text{m})^3 = 1.067(10^{-3})\,\text{m}^4$$

**Bending Stress.** Thus,

$$\sigma = -\frac{M_z y}{I_z} + \frac{M_y z}{I_y}$$

$$\sigma_B = -\frac{7.20(10^3)\,\text{N}\cdot\text{m}(0.2\,\text{m})}{1.067(10^{-3})\,\text{m}^4} + \frac{-9.60(10^3)\,\text{N}\cdot\text{m}(-0.1\,\text{m})}{0.2667(10^{-3})\,\text{m}^4} = 2.25\,\text{MPa} \quad \textit{Ans.}$$

$$\sigma_C = -\frac{7.20(10^3)\,\text{N}\cdot\text{m}(0.2\,\text{m})}{1.067(10^{-3})\,\text{m}^4} + \frac{-9.60(10^3)\,\text{N}\cdot\text{m}(0.1\,\text{m})}{0.2667(10^{-3})\,\text{m}^4} = -4.95\,\text{MPa} \quad \textit{Ans.}$$

$$\sigma_D = -\frac{7.20(10^3)\,\text{N}\cdot\text{m}(-0.2\,\text{m})}{1.067(10^{-3})\,\text{m}^4} + \frac{-9.60(10^3)\,\text{N}\cdot\text{m}(0.1\,\text{m})}{0.2667(10^{-3})\,\text{m}^4} = -2.25\,\text{MPa} \quad \textit{Ans.}$$

$$\sigma_E = -\frac{7.20(10^3)\,\text{N}\cdot\text{m}(-0.2\,\text{m})}{1.067(10^{-3})\,\text{m}^4} + \frac{-9.60(10^3)\,\text{N}\cdot\text{m}(-0.1\,\text{m})}{0.2667(10^{-3})\,\text{m}^4} = 4.95\,\text{MPa} \quad \textit{Ans.}$$

The resultant normal-stress distribution has been sketched using these values, Fig. 6–33*b*. Since superposition applies, the distribution is linear as shown.





Fig. 6–33

**Orientation of Neutral Axis.** The location $z$ of the neutral axis ($NA$), Fig. 6–33*b*, can be established by proportion. Along the edge $BC$, we require

$$\frac{2.25\text{ MPa}}{z} = \frac{4.95\text{ MPa}}{(0.2\text{ m} - z)}$$

$$0.450 - 2.25z = 4.95z$$

$$z = 0.0625\text{ m}$$

In the same manner this is also the distance from $D$ to the neutral axis in Fig. 6–33*b*.


We can also establish the orientation of the $NA$ using Eq. 6–19, which is used to specify the angle $\alpha$ that the axis makes with the $z$ or *maximum* principal axis. According to our sign convention, $\theta$ must be measured from the $+z$ axis toward the $+y$ axis. By comparison, in Fig. 6–33*c*, $\theta = -\tan^{-1}\frac{4}{3} = -53.1°$ (or $\theta = +306.9°$). Thus,

$$\tan\alpha = \frac{I_z}{I_y}\tan\theta$$

$$\tan\alpha = \frac{1.067(10^{-3})\text{ m}^4}{0.2667(10^{-3})\text{ m}^4}\tan(-53.1°)$$

$$\alpha = -79.4° \qquad \textit{Ans.}$$

This result is shown in Fig. 6–33*c*. Using the value of $z$ calculated above, verify, using the geometry of the cross section, that one obtains the same answer.




## EXAMPLE 6.16

The Z-section shown in Fig. 6–34*a* is subjected to the bending moment of $M = 20\ \text{kN} \cdot \text{m}$. Using the methods of Appendix A (see Example A.4 or A.5), the principal axes $y$ and $z$ are oriented as shown, such that they represent the minimum and maximum principal moments of inertia, $I_y = 0.960(10^{-3})\ \text{m}^4$ and $I_z = 7.54(10^{-3})\ \text{m}^4$, respectively. Determine the normal stress at point $P$ and the orientation of the neutral axis.

### SOLUTION

For use of Eq. 6–19, it is important that the $z$ axis represent the principal axis for the *maximum* moment of inertia. (Note that most of the area is located furthest from this axis.)




**Internal Moment Components.** From Fig. 6–34*a*,

$$M_y = 20\ \text{kN} \cdot \text{m} \sin 57.1^\circ = 16.79\ \text{kN} \cdot \text{m}$$

$$M_z = 20\ \text{kN} \cdot \text{m} \cos 57.1^\circ = 10.86\ \text{kN} \cdot \text{m}$$

**Bending Stress.** The $y$ and $z$ coordinates of point $P$ must be determined first. Note that the $y'$, $z'$ coordinates of $P$ are $(-0.2\ \text{m}, 0.35\ \text{m})$. Using the colored triangles from the construction shown in Fig. 6–34*b*, we have

$$y_P = -0.35 \sin 32.9^\circ - 0.2 \cos 32.9^\circ = -0.3580\ \text{m}$$

$$z_P = 0.35 \cos 32.9^\circ - 0.2 \sin 32.9^\circ = 0.1852\ \text{m}$$

Applying Eq. 6–17,

$$\sigma_P = -\frac{M_z y_P}{I_z} + \frac{M_y z_P}{I_y}$$

$$= -\frac{(10.86(10^3)\ \text{N} \cdot \text{m})(-0.3580\ \text{m})}{7.54(10^{-3})\ \text{m}^4} + \frac{(16.79(10^3)\ \text{N} \cdot \text{m})(0.1852\ \text{m})}{0.960(10^{-3})\ \text{m}^4}$$

$$= 3.76\ \text{MPa} \qquad \textit{Ans.}$$





Fig. 6–34

**Orientation of Neutral Axis.** The angle $\theta = 57.1^\circ$ is shown in Fig. 6–34*a*. Thus,


$$\tan \alpha = \left[\frac{7.54(10^{-3})\ \text{m}^4}{0.960(10^{-3})\ \text{m}^4}\right] \tan 57.1^\circ$$

$$\alpha = 85.3^\circ \qquad \textit{Ans.}$$

The neutral axis is oriented as shown in Fig. 6–34*b*.


## FUNDAMENTAL PROBLEMS

**F6–20.** Determine the bending stress developed at corners $A$ and $B$. What is the orientation of the neutral axis?




F6–20

**F6–21.** Determine the maximum stress in the beam's cross section.





F6–21

## PROBLEMS

**•6–109.** The beam is subjected to a bending moment of $M = 20$ kip·ft directed as shown. Determine the maximum bending stress in the beam and the orientation of the neutral axis.


**6–110.** Determine the maximum magnitude of the bending moment **M** that can be applied to the beam so that the bending stress in the member does not exceed 12 ksi.




Probs. 6–109/110


**6–111.** If the resultant internal moment acting on the cross section of the aluminum strut has a magnitude of $M = 520$ N·m and is directed as shown, determine the bending stress at points $A$ and $B$. The location $\bar{y}$ of the centroid $C$ of the strut's cross-sectional area must be determined. Also, specify the orientation of the neutral axis.

***6–112.** The resultant internal moment acting on the cross section of the aluminum strut has a magnitude of $M = 520$ N·m and is directed as shown. Determine maximum bending stress in the strut. The location $\bar{y}$ of the centroid $C$ of the strut's cross-sectional area must be determined. Also, specify the orientation of the neutral axis.




Probs. 6–111/112


**6–113.** Consider the general case of a prismatic beam subjected to bending-moment components $\mathbf{M}_y$ and $\mathbf{M}_z$, as shown, when the $x, y, z$ axes pass through the centroid of the cross section. If the material is linear-elastic, the normal stress in the beam is a linear function of position such that $\sigma = a + by + cz$. Using the equilibrium conditions $0 = \int_A \sigma\, dA$, $M_y = \int_A z\sigma\, dA$, $M_z = \int_A -y\sigma\, dA$, determine the constants $a$, $b$, and $c$, and show that the normal stress can be determined from the equation $\sigma = [-(M_z I_y + M_y I_{yz})y + (M_y I_z + M_z I_{yz})z]/(I_y I_z - I_{yz}^2)$, where the moments and products of inertia are defined in Appendix A.




Prob. 6–113

**6–114.** The cantilevered beam is made from the $Z$-section having the cross-section shown. If it supports the two loadings, determine the bending stress at the wall in the beam at point $A$. Use the result of Prob. 6–113.


**6–115.** The cantilevered beam is made from the $Z$-section having the cross-section shown. If it supports the two loadings, determine the bending stress at the wall in the beam at point $B$. Use the result of Prob. 6–113.




Probs. 6–114/115

***6–116.** The cantilevered wide-flange steel beam is subjected to the concentrated force $\mathbf{P}$ at its end. Determine the largest magnitude of this force so that the bending stress developed at $A$ does not exceed $\sigma_{allow} = 180$ MPa.


**•6–117.** The cantilevered wide-flange steel beam is subjected to the concentrated force of $P = 600$ N at its end. Determine the maximum bending stress developed in the beam at section $A$.




Probs. 6–116/117


**6–118.** If the beam is subjected to the internal moment of $M = 1200$ kN · m, determine the maximum bending stress acting on the beam and the orientation of the neutral axis.

**6–119.** If the beam is made from a material having an allowable tensile and compressive stress of $(\sigma_{allow})_t = 125$ MPa and $(\sigma_{allow})_c = 150$ MPa, respectively, determine the maximum allowable internal moment $\mathbf{M}$ that can be applied to the beam.





Probs. 6–118/119

*6–120. The shaft is supported on two journal bearings at $A$ and $B$ which offer no resistance to axial loading. Determine the required diameter $d$ of the shaft if the allowable bending stress for the material is $\sigma_{allow} = 150$ MPa.




Prob. 6–120

•6–121. The 30-mm-diameter shaft is subjected to the vertical and horizontal loadings of two pulleys as shown. It is supported on two journal bearings at $A$ and $B$ which offer no resistance to axial loading. Furthermore, the coupling to the motor at $C$ can be assumed not to offer any support to the shaft. Determine the maximum bending stress developed in the shaft.





Prob. 6–121

6–122. Using the techniques outlined in Appendix A, Example A.5 or A.6, the $Z$ section has principal moments of inertia of $I_y = 0.060(10^{-3})\ m^4$ and $I_z = 0.471(10^{-3})\ m^4$, computed about the principal axes of inertia $y$ and $z$, respectively. If the section is subjected to an internal moment of $M = 250\ N \cdot m$ directed horizontally as shown, determine the stress produced at point $A$. Solve the problem using Eq. 6–17.

6–123. Solve Prob. 6–122 using the equation developed in Prob. 6–113.


*6–124. Using the techniques outlined in Appendix A, Example A.5 or A.6, the $Z$ section has principal moments of inertia of $I_y = 0.060(10^{-3})\ m^4$ and $I_z = 0.471(10^{-3})\ m^4$, computed about the principal axes of inertia $y$ and $z$, respectively. If the section is subjected to an internal moment of $M = 250\ N \cdot m$ directed horizontally as shown, determine the stress produced at point $B$. Solve the problem using Eq. 6–17.




Probs. 6–122/123/124

•6–125. Determine the bending stress at point $A$ of the beam, and the orientation of the neutral axis. Using the method in Appendix A, the principal moments of inertia of the cross section are $I_z' = 8.828\ in^4$ and $I_y' = 2.295\ in^4$, where $z'$ and $y'$ are the principal axes. Solve the problem using Eq. 6–17.

6–126. Determine the bending stress at point $A$ of the beam using the result obtained in Prob. 6–113. The moments of inertia of the cross sectional area about the $z$ and $y$ axes are $I_z = I_y = 5.561\ in^4$ and the product of inertia of the cross sectional area with respect to the $z$ and $y$ axes is $I_{yz} = -3.267\ in^4$. (See Appendix A)




Probs. 6–125/126

## *6.6 Composite Beams

Beams constructed of two or more different materials are referred to as ***composite beams***. For example, a beam can be made of wood with straps of steel at its top and bottom, Fig. 6–35. Engineers purposely design beams in this manner in order to develop a more efficient means for supporting loads.

Since the flexure formula was developed only for beams having homogeneous material, this formula cannot be applied directly to determine the normal stress in a composite beam. In this section, however, we will develop a method for modifying or "transforming" a composite beam's cross section into one made of a single material. Once this has been done, the flexure formula can then be used for the stress analysis.

To explain how to do this we will consider a composite beam made of two materials, 1 and 2, which have the cross-sectional areas shown in Fig. 6–36*a*. If a bending moment is applied to this beam, then, like one that is homogeneous, the total cross-sectional area will *remain plane* after bending, and hence the normal strains will vary linearly from zero at the neutral axis to a maximum in the material located farthest from this axis, Fig. 6–36*b*. Provided the material is linear elastic, then at any point the normal stress in material 1 is determined from $\sigma = E_1\epsilon$, and for material 2 the stress distribution is found from $\sigma = E_2\epsilon$. Assuming material 1 is stiffer than material 2, then $E_1 > E_2$ and so the stress distribution will look like that shown in Fig. 6–36*c* or 6–36*d*. In particular, notice the jump in stress that occurs at the juncture of the two materials. Here the *strain* is the *same*, but since the modulus of elasticity for the materials suddenly changes, so does the stress. It is possible to determine the location of the neutral axis and the maximum stress based on a trial-and-error procedure.





Fig. 6–35

This requires satisfying the conditions that the stress distribution produces a zero resultant force on the cross section and the moment of the stress distribution about the neutral axis must be equal to **M**.

A simpler way to satisfy these two conditions is to use the *transformed section method*, which transforms the beam into one made of a *single material*. For example, if the beam is thought to consist entirely of the less stiff material 2, then the cross section will look like that shown in Fig. 6–36*e*. Here the height $h$ of the beam remains the *same*, since the strain distribution in Fig. 6–36*b* must be preserved. However, the upper portion of the beam must be widened in order to carry a load *equivalent* to that carried by the stiffer material 1 in Fig. 6–36*d*. The necessary width can be determined by considering the force $d\mathbf{F}$ acting on an area $dA = dz\,dy$ of the beam in Fig. 6–36*a*. It is $dF = \sigma\,dA = (E_1\epsilon)\,dz\,dy$. Assuming the width of a *corresponding element* of height $dy$ in Fig. 6–36*e* is $n\,dz$, then $dF' = \sigma' dA' = (E_2\epsilon)n\,dz\,dy$. Equating these forces, so that they produce the same moment about the $z$ (neutral) axis, we have

$$E_1\epsilon\,dz\,dy = E_2\epsilon n\,dz\,dy$$

or

$$n = \frac{E_1}{E_2} \tag{6–20}$$







Fig. 6–36





Beam transformed to material (2)

(e)





Beam transformed to material (1)

(f)




Bending-stress variation for beam transformed to material (2)

(g)




Bending-stress variation for beam transformed to material (1)

(h)

**Fig. 6–36 (cont.)**

This dimensionless number $n$ is called the ***transformation factor***. It indicates that the cross section, having a width $b$ on the original beam, Fig. 6–36*a*, must be increased in width to $b_2 = nb$ in the region where material 1 is being transformed into material 2, Fig. 6–36*e*.

In a similar manner, if the less stiff material 2 is transformed into the stiffer material 1, the cross section will look like that shown in Fig. 6–36*f*. Here the width of material 2 has been changed to $b_1 = n'b$, where $n' = E_2/E_1$. In this case the transformation factor $n'$ will be *less than one* since $E_1 > E_2$. In other words, we need less of the stiffer material to support the moment.

Once the beam has been transformed into one having a *single material*, the normal-stress distribution over the transformed cross section will be linear as shown in Fig. 6–36*g* or 6–36*h*. Consequently, the centroid (neutral axis) and moment of inertia for the transformed area can be determined and the flexure formula applied in the usual manner to determine the stress at each point on the transformed beam. The stress in the transformed beam will be equivalent to the stress in the *same material* of the actual beam; however, the stress found on the transformed material has to be multiplied by the transformation factor $n$ (or $n'$), since the area of the transformed material, $dA' = n\,dz\,dy$, is $n$ times the area of actual material $dA = dz\,dy$. That is,

$$\begin{aligned} dF &= \sigma\,dA = \sigma' dA' \\ \sigma\,dz\,dy &= \sigma' n\,dz\,dy \\ \sigma &= n\sigma' \end{aligned} \tag{6–21}$$

Example 6.17 numerically illustrates application of the transformed section method.

## Important Points

- *Composite beams* are made from different materials in order to efficiently carry a load. Application of the flexure formula requires the material to be homogeneous, and so the cross section of the beam must be transformed into a single material if this formula is to be used to calculate the bending stress.
- The *transformation factor n* is a ratio of the moduli of the different materials that make up the beam. Used as a multiplier, it converts the width of the cross section of the composite beam into a beam made from a single material so that this beam has the same strength as the composite beam. Stiff material will thus be replaced by more of the softer material and vice versa.
- Once the stress in the transformed section is determined, it must be multiplied by the transformation factor to obtain the stress in the actual beam.

## *6.7 Reinforced Concrete Beams

All beams subjected to pure bending must resist both tensile and compressive stresses. Concrete, however, is very susceptible to cracking when it is in tension, and therefore by itself it will not be suitable for resisting a bending moment.* In order to circumvent this shortcoming, engineers place steel reinforcing rods within a concrete beam at a location where the concrete is in tension, Fig. 6–37*a*. To be most effective, these rods are located farthest from the beam's neutral axis, so that the moment created by the forces developed in them is greatest about the neutral axis. Furthermore, the rods are required to have some concrete coverage to protect them from corrosion or loss of strength in the event of a fire. Codes used for actual reinforced concrete design assume the ability of concrete will not support any tensile loading, since the possible cracking of concrete is unpredictable. As a result, the normal stress distribution acting on the cross-sectional area of a reinforced concrete beam is assumed to look like that shown in Fig. 6–37*b*.

The stress analysis requires locating the neutral axis and determining the maximum stress in the steel and concrete. To do this, the area of steel $A_{st}$ is first transformed into an equivalent area of concrete using the transformation factor $n = E_{st}/E_{conc}$. This ratio, which gives $n > 1$, requires a "greater" amount of concrete to replace the steel. The transformed area is $nA_{st}$ and the transformed section looks like that shown in Fig. 6–37*c*. Here $d$ represents the distance from the top of the beam to the (transformed) steel, $b$ is the beam's width, and $h'$ is the yet unknown distance from the top of the beam to the neutral axis. To obtain $h'$, we require the centroid $C$ of the cross-sectional area of the transformed section to lie on the neutral axis, Fig. 6–37*c*. With reference to the neutral axis, therefore, the moment of the two areas, $\Sigma \tilde{y}A$, must be zero, since $\bar{y} = \Sigma \tilde{y}A/\Sigma A = 0$. Thus,

$$bh'\left(\frac{h'}{2}\right) - nA_{st}(d - h') = 0$$

$$\frac{b}{2}h'^2 + nA_{st}h' - nA_{st}d = 0$$

Once $h'$ is obtained from this quadratic equation, the solution proceeds in the usual manner for obtaining the stress in the beam. Example 6.18 numerically illustrates application of this method.





Fig. 6–37

*Inspection of its particular stress-strain diagram in Fig. 3–11 reveals that concrete can be 12.5 times stronger in compression than in tension.

## EXAMPLE 6.17

A composite beam is made of wood and reinforced with a steel strap located on its bottom side. It has the cross-sectional area shown in Fig. 6–38*a*. If the beam is subjected to a bending moment of $M = 2\ \text{kN}\cdot\text{m}$, determine the normal stress at points $B$ and $C$. Take $E_w = 12\ \text{GPa}$ and $E_{st} = 200\ \text{GPa}$.





Fig. 6–38

### SOLUTION

**Section Properties.** Although the choice is arbitrary, here we will transform the section into one made entirely of steel. Since steel has a greater stiffness than wood ($E_{st} > E_w$), the width of the wood must be *reduced* to an equivalent width for steel. Hence $n$ must be less than one. For this to be the case, $n = E_w/E_{st}$, so that

$$b_{st} = nb_w = \frac{12\ \text{GPa}}{200\ \text{GPa}}(150\ \text{mm}) = 9\ \text{mm}$$

The transformed section is shown in Fig. 6–38*b*.

The location of the centroid (neutral axis), calculated from a reference axis located at the *bottom* of the section, is

$$\bar{y} = \frac{\Sigma \bar{y}A}{\Sigma A} = \frac{[0.01\ \text{m}](0.02\ \text{m})(0.150\ \text{m}) + [0.095\ \text{m}](0.009\ \text{m})(0.150\ \text{m})}{0.02\ \text{m}(0.150\ \text{m}) + 0.009\ \text{m}(0.150\ \text{m})} = 0.03638\ \text{m}$$

The moment of inertia about the neutral axis is therefore

$$I_{NA} = \left[\frac{1}{12}(0.150\ \text{m})(0.02\ \text{m})^3 + (0.150\ \text{m})(0.02\ \text{m})(0.03638\ \text{m} - 0.01\ \text{m})^2\right] + \left[\frac{1}{12}(0.009\ \text{m})(0.150\ \text{m})^3 + (0.009\ \text{m})(0.150\ \text{m})(0.095\ \text{m} - 0.03638\ \text{m})^2\right]$$
$$= 9.358(10^{-6})\ \text{m}^4$$





Fig. 6–38 (cont.)

**Normal Stress.** Applying the flexure formula, the normal stress at $B'$ and $C$ is

$$\sigma_{B'} = \frac{2(10^3)\,\text{N}\cdot\text{m}(0.170\,\text{m} - 0.03638\,\text{m})}{9.358(10^{-6})\,\text{m}^4} = 28.6\,\text{MPa}$$

$$\sigma_C = \frac{2(10^3)\,\text{N}\cdot\text{m}(0.03638\,\text{m})}{9.358(10^{-6})\,\text{m}^4} = 7.78\,\text{MPa} \qquad \textit{Ans.}$$

The normal-stress distribution on the transformed (all steel) section is shown in Fig. 6–38c.


The normal stress in the wood at $B$ in Fig. 6–38*a*, is determined from Eq. 6–21; that is,

$$\sigma_B = n\sigma_{B'} = \frac{12\,\text{GPa}}{200\,\text{GPa}}(28.56\,\text{MPa}) = 1.71\,\text{MPa} \qquad \textit{Ans.}$$


Using these concepts, show that the normal stress in the steel and the wood at the point where they are in contact is $\sigma_{st} = 3.50$ MPa and $\sigma_w = 0.210$ MPa, respectively. The normal-stress distribution in the actual beam is shown in Fig. 6–38*d*.

## EXAMPLE 6.18


The reinforced concrete beam has the cross-sectional area shown in Fig. 6–39*a*. If it is subjected to a bending moment of $M = 60\ \text{kip}\cdot\text{ft}$, determine the normal stress in each of the steel reinforcing rods and the maximum normal stress in the concrete. Take $E_{st} = 29(10^3)$ ksi and $E_{conc} = 3.6(10^3)$ ksi.




(a)




(b)




(c)

Fig. 6–39

### SOLUTION

Since the beam is made from concrete, in the following analysis we will neglect its strength in supporting a tensile stress.

**Section Properties.** The total area of steel, $A_{st} = 2[\pi(0.5\ \text{in.})^2] = 1.571\ \text{in}^2$ will be transformed into an equivalent area of concrete, Fig. 6–39*b*. Here

$$A' = nA_{st} = \frac{29(10^3)\ \text{ksi}}{3.6(10^3)\ \text{ksi}}(1.571\ \text{in}^2) = 12.65\ \text{in}^2$$

We require the centroid to lie on the neutral axis. Thus $\Sigma \tilde{y}A = 0$, or

$$12\ \text{in.}\,(h')\frac{h'}{2} - 12.65\ \text{in}^2(16\ \text{in.} - h') = 0$$

$$h'^2 + 2.11h' - 33.7 = 0$$

Solving for the positive root,

$$h' = 4.85\ \text{in.}$$

Using this value for $h'$, the moment of inertia of the transformed section about the neutral axis is

$$I = \left[\frac{1}{12}(12\ \text{in.})(4.85\ \text{in.})^3 + 12\ \text{in.}\,(4.85\ \text{in.})\left(\frac{4.85\ \text{in.}}{2}\right)^2\right] + 12.65\ \text{in}^2\,(16\ \text{in.} - 4.85\ \text{in.})^2 = 2029\ \text{in}^4$$

**Normal Stress.** Applying the flexure formula to the transformed section, the maximum normal stress in the concrete is

$$(\sigma_{conc})_{max} = \frac{[60\ \text{kip}\cdot\text{ft}(12\ \text{in./ft})](4.85\ \text{in.})}{2029\ \text{in}^4} = 1.72\ \text{ksi} \quad \textit{Ans.}$$

The normal stress resisted by the "concrete" strip, which replaced the steel, is

$$\sigma'_{conc} = \frac{[60\ \text{kip}\cdot\text{ft}(12\ \text{in./ft})](16\ \text{in.} - 4.85\ \text{in.})}{2029\ \text{in}^4} = 3.96\ \text{ksi}$$

The normal stress in each of the two reinforcing rods is therefore

$$\sigma_{st} = n\sigma'_{conc} = \left(\frac{29(10^3)\ \text{ksi}}{3.6(10^3)\ \text{ksi}}\right)3.96\ \text{ksi} = 31.9\ \text{ksi} \quad \textit{Ans.}$$

The normal-stress distribution is shown graphically in Fig. 6–39*c*.

## *6.8 Curved Beams


The flexure formula applies to a straight member, since it was shown that the normal strain within it varies linearly from the neutral axis. If the member is *curved*, however, this assumption becomes inaccurate, and so we must develop another method to describe the stress distribution. In this section we will consider the analysis of a *curved beam*, that is, a member that has a curved axis and is subjected to bending. Typical examples include hooks and chain links. In all cases, the members are not slender, but rather have a sharp curve, and their cross-sectional dimensions are large compared with their radius of curvature.

The following analysis assumes that the cross section is constant and has an axis of symmetry that is perpendicular to the direction of the applied moment **M**, Fig. 6–40*a*. Also, the material is homogeneous and isotropic, and it behaves in a linear-elastic manner when the load is applied. Like the case of a straight beam, we will also assume that the *cross sections* of the member *remain plane* after the moment is applied. Furthermore, any distortion of the cross section within its own plane will be neglected.

To perform the analysis, three radii, extending from the center of curvature $O'$ of the member, are identified in Fig. 6–40*a*. Here $\bar{r}$ references the known location of the *centroid* for the cross-sectional area, $R$ references the yet unspecified location of the *neutral axis*, and $r$ locates the *arbitrary point* or area element $dA$ on the cross section.





This crane hook represents a typical example of a curved beam.




(a)

Fig. 6–40




(b)

Fig. 6–40 (cont.)

If we isolate a differential segment of the beam, Fig. 6–40*b*, the stress tends to deform the material such that each cross section will rotate through an angle $\delta\theta/2$. The normal strain $\epsilon$ in the strip (or line) of material located at $r$ will now be determined. This strip has an original length $r\,d\theta$, Fig. 6–40*b*. However, due to the rotations $\delta\theta/2$ the strip's total change in length is $\delta\theta(R - r)$. Consequently, $\epsilon = \delta\theta(R - r)/r\,d\theta$. If we let $k = \delta\theta/d\theta$, which is the same for any particular strip, we have $\epsilon = k(R - r)/r$. Unlike the case of straight beams, here it can be seen that the ***normal strain*** is a nonlinear function of $r$, in fact it varies in a ***hyperbolic fashion***. This occurs even though the cross section of the beam remains plane after deformation. If the material remains linearly elastic then $\sigma = E\epsilon$ and so

$$\sigma = Ek\left(\frac{R - r}{r}\right) \tag{6–22}$$

This variation is also hyperbolic, and since it has now been established, we can determine the location of the neutral axis and relate the stress distribution to the resultant internal moment $M$.

To obtain the location $R$ of the neutral axis, we require the resultant internal force caused by the stress distribution acting over the cross section to be equal to zero; i.e.,

$$F_R = \Sigma F_x; \qquad \int_A \sigma\,dA = 0$$

$$\int_A Ek\left(\frac{R - r}{r}\right) dA = 0$$

Since $Ek$ and $R$ are constants, we have

$$R\int_A \frac{dA}{r} - \int_A dA = 0$$

Solving for $R$ yields





$$R = \frac{A}{\displaystyle\int_A \frac{dA}{r}} \tag{6–23}$$

Here

- $R$ = the location of the neutral axis, specified from the center of curvature $O'$ of the member
- $A$ = the cross-sectional area of the member
- $r$ = the arbitrary position of the area element $dA$ on the cross section, specified from the center of curvature $O'$ of the member

The integral in Eq. 6–23 has been evaluated for various cross-sectional geometries, and the results for some common cross sections are listed in Table 6–1.

**TABLE 6–1**

| Shape | $\int_A \frac{dA}{r}$ |
|---|---|
|  | $b \ln \frac{r_2}{r_1}$ |
|  | $\frac{b r_2}{(r_2 - r_1)}\left(\ln \frac{r_2}{r_1}\right) - b$ |
|  | $2\pi\left(\bar{r} - \sqrt{\bar{r}^2 - c^2}\right)$ |
|  | $\frac{2\pi b}{a}\left(\bar{r} - \sqrt{\bar{r}^2 - a^2}\right)$ |

In order to relate the stress distribution to the resultant bending moment, we require the resultant internal moment to be equal to the moment of the stress distribution calculated about the neutral axis. From Fig. 6–40*a*, the stress $\sigma$, acting on the area element $dA$ and located a distance $y$ from the neutral axis, creates a moment about the neutral axis of $dM = y(\sigma\, dA)$. For the entire cross section, we require $M = \int y\sigma\, dA$. Since $y = R - r$, and $\sigma$ is defined by Eq. 6–22, we have

$$M = \int_A (R - r)Ek\left(\frac{R - r}{r}\right) dA$$

Expanding, realizing that $Ek$ and $R$ are constants, then

$$M = Ek\left(R^2 \int_A \frac{dA}{r} - 2R \int_A dA + \int_A r\, dA\right)$$

The first integral is equivalent to $A/R$ as determined from Eq. 6–23, and the second integral is simply the cross-sectional area $A$. Realizing that the location of the centroid of the cross section is determined from $\bar{r} = \int r\, dA/A$, the third integral can be replaced by $\bar{r}A$. Thus,


$$M = EkA(\bar{r} - R)$$

Finally, solving for $Ek$ in Eq. 6–22, substituting into the above equation, and solving for $\sigma$, we have

$$\sigma = \frac{M(R - r)}{Ar(\bar{r} - R)} \tag{6–24}$$


Here

- $\sigma$ = the normal stress in the member
- $M$ = the internal moment, determined from the method of sections and the equations of equilibrium and calculated about the neutral axis for the cross section. This moment is *positive* if it tends to increase the member's radius of curvature, i.e., it tends to straighten out the member
- $A$ = the cross-sectional area of the member
- $R$ = the distance measured from the center of curvature to the neutral axis, determined from Eq. 6–23
- $\bar{r}$ = the distance measured from the center of curvature to the centroid of the cross section
- $r$ = the distance measured from the center of curvature to the point where the stress $\sigma$ is to be determined





Bending stress variation (profile view)

(c)




(d)




(e)

**Fig. 6–40 (cont.)**

From Fig. 6–40*a*, $r = R - y$. Also, the constant and usually very small distance between the neutral axis and the centroid is $e = \bar{r} - R$. When these results are substituted into Eq. 6–24, we can also write

$$\sigma = \frac{My}{Ae(R - y)} \tag{6–25}$$

These two equations represent two forms of the so-called *curved-beam formula*, which like the flexure formula can be used to determine the normal-stress distribution in a curved member. This distribution is, as previously stated, hyperbolic; an example is shown in Fig. 6–40*c* and 6–40*d*. Since the stress acts along the circumference of the beam, it is sometimes called ***circumferential stress***. Note that due to the curvature of the beam, the circumferential stress will create a corresponding component of ***radial stress***, so called since this component acts in the radial direction. To show how it is developed, consider the free-body diagram of the segment shown in Fig. 6–40*e*. Here the radial stress $\sigma_r$ is necessary since it creates the force $dF_r$ that is required to balance the two components of circumferential forces $dF$ which act along the line $O'B$.

Sometimes the radial stresses within curved members may become significant, especially if the member is constructed from thin plates and has, for example, the shape of an I-section. In this case the radial stress can become as large as the circumferential stress, and consequently the member must be designed to resist both stresses. For most cases, however, these stresses can be neglected, especially if the member has a *solid section*. Here the curved-beam formula gives results that are in very close agreement with those determined either by experiment or by a mathematical analysis based on the theory of elasticity.

The curved-beam formula is normally used when the curvature of the member is very pronounced, as in the case of hooks or rings. However, if the radius of curvature is greater than five times the depth of the member, the *flexure formula* can normally be used to determine the stress. For example, for rectangular sections for which this ratio equals 5, the maximum normal stress, when determined by the flexure formula, will be about 7% *less* than its value when determined by the curved-beam formula. This error is further reduced when the radius of curvature-to-depth ratio is more than 5.*

*See, for example, Boresi, A. P., et al., *Advanced Mechanics of Materials*, 3rd ed., p. 333, 1978, John Wiley & Sons, New York.

## Important Points

- The *curved-beam formula* should be used to determine the circumferential stress in a beam when the radius of curvature is less than five times the depth of the beam.
- Due to the curvature of the beam, the normal strain in the beam *does not* vary linearly with depth as in the case of a straight beam. As a result, the neutral axis does not pass through the centroid of the cross section.
- The radial stress component caused by bending can generally be neglected, especially if the cross section is a solid section and not made from thin plates.

## Procedure for Analysis

In order to apply the curved-beam formula the following procedure is suggested.

### Section Properties.


- Determine the cross-sectional area $A$ and the location of the centroid, $\bar{r}$, measured from the center of curvature.
- Find the location of the neutral axis, $R$, using Eq. 6–23 or Table 6–1. If the cross-sectional area consists of $n$ "composite" parts, determine $\int dA/r$ for *each part*. Then, from Eq. 6–23, for the entire section, $R = \Sigma A / \Sigma(\int dA/r)$. In all cases, $R < \bar{r}$.

### Normal Stress.

- The normal stress located at a point $r$ away from the center of curvature is determined from Eq. 6–24. If the distance $y$ to the point is measured from the neutral axis, then find $e = \bar{r} - R$ and use Eq. 6–25.
- Since $\bar{r} - R$ generally produces a very *small number*, it is best to calculate $\bar{r}$ and $R$ with sufficient accuracy so that the subtraction leads to a number $e$ having at least four significant figures.
- If the stress is positive it will be tensile, whereas if it is negative it will be compressive.
- The stress distribution over the entire cross section can be graphed, or a volume element of the material can be isolated and used to represent the stress acting at the point on the cross section where it has been calculated.

## EXAMPLE 6.19

The curved bar has a cross-sectional area shown in Fig. 6–41*a*. If it is subjected to bending moments of 4 kN · m, determine the maximum normal stress developed in the bar.




(a)

Fig. 6–41

### SOLUTION

**Internal Moment.** Each section of the bar is subjected to the same resultant internal moment of 4 kN · m. Since this moment tends to decrease the bar's radius of curvature, it is negative. Thus, $M = -4\ \text{kN} \cdot \text{m}$.

**Section Properties.** Here we will consider the cross section to be composed of a rectangle and triangle. The total cross-sectional area is

$$\Sigma A = (0.05\ \text{m})^2 + \frac{1}{2}(0.05\ \text{m})(0.03\ \text{m}) = 3.250(10^{-3})\ \text{m}^2$$

The location of the centroid is determined with reference to the center of curvature, point $O'$, Fig. 6–41*a*.

$$\bar{r} = \frac{\Sigma \tilde{r} A}{\Sigma A}$$

$$= \frac{[0.225\ \text{m}](0.05\ \text{m})(0.05\ \text{m}) + [0.260\ \text{m})\frac{1}{2}(0.050\ \text{m})(0.030\ \text{m})}{3.250(10^{-3})\ \text{m}^2}$$

$$= 0.23308\ \text{m}$$

We can find $\int_A dA/r$ for each part using Table 6–1. For the rectangle,

$$\int_A \frac{dA}{r} = 0.05\text{ m}\left(\ln\frac{0.250\text{ m}}{0.200\text{ m}}\right) = 0.011157\text{ m}$$

And for the triangle,

$$\int_A \frac{dA}{r} = \frac{(0.05\text{ m})(0.280\text{ m})}{(0.280\text{ m} - 0.250\text{ m})}\left(\ln\frac{0.280\text{ m}}{0.250\text{ m}}\right) - 0.05\text{ m} = 0.0028867\text{ m}$$

Thus the location of the neutral axis is determined from

$$R = \frac{\Sigma A}{\Sigma\int_A dA/r} = \frac{3.250(10^{-3})\text{ m}^2}{0.011157\text{ m} + 0.0028867\text{ m}} = 0.23142\text{ m}$$

Note that $R < \bar{r}$ as expected. Also, the calculations were performed with sufficient accuracy so that $(\bar{r} - R) = 0.23308\text{ m} - 0.23142\text{ m} = 0.00166\text{ m}$ is now accurate to three significant figures.

**Normal Stress.** The maximum normal stress occurs either at $A$ or $B$. Applying the curved-beam formula to calculate the normal stress at $B$, $r_B = 0.200$ m, we have

$$\sigma_B = \frac{M(R - r_B)}{Ar_B(\bar{r} - R)} = \frac{(-4\text{ kN}\cdot\text{m})(0.23142\text{ m} - 0.200\text{ m})}{3.250(10^{-3})\text{ m}^2(0.200\text{ m})(0.00166\text{ m})}$$


$$= -116\text{ MPa}$$

At point $A$, $r_A = 0.280$ m and the normal stress is

$$\sigma_A = \frac{M(R - r_A)}{Ar_A(\bar{r} - R)} = \frac{(-4\text{ kN}\cdot\text{m})(0.23142\text{ m} - 0.280\text{ m})}{3.250(10^{-3})\text{ m}^2(0.280\text{ m})(0.00166\text{ m})}$$

$$= 129\text{ MPa} \qquad \textit{Ans.}$$

By comparison, the maximum normal stress is at $A$. A two-dimensional representation of the stress distribution is shown in Fig. 6–41*b*.




(b)

**Fig. 6–41 (cont.)**





Fig. 6–42

## 6.9 Stress Concentrations

The flexure formula cannot be used to determine the stress distribution within regions of a member where the cross-sectional area suddenly changes, since the normal-stress and strain distributions at the section become *nonlinear*. The results can only be obtained through experiment or, in some cases, by using the theory of elasticity. Common discontinuities include members having notches on their surfaces, Fig. 6–42*a*, holes for passage of fasteners or other items, Fig. 6–42*b*, or abrupt changes in the outer dimensions of the member's cross section, Fig. 6–42*c*. The *maximum* normal stress at each of these discontinuities occurs at the section taken through the *smallest* cross-sectional area.

For design, it is generally important to only know the maximum normal stress developed at these sections, not the actual stress distribution. As in the previous cases of axially loaded bars and torsionally loaded shafts, we can obtain the maximum normal stress due to bending using a stress-concentration factor $K$. For example, Fig. 6–43 gives values of $K$ for a flat bar that has a change in cross section using shoulder fillets. To use this graph simply find the geometric ratios $w/h$ and $r/h$ and then find the corresponding value of $K$ for a particular





Fig. 6–43





Fig. 6–44

geometry. Once $K$ is obtained, the maximum bending stress shown in Fig. 6–45 is determined using

$$\sigma_{max} = K\frac{Mc}{I} \tag{6–26}$$




Fig. 6–45

In the same manner, Fig. 6–44 can be used if the discontinuity consists of circular grooves or notches.

Like axial load and torsion, stress concentration for bending should always be considered when designing members made of brittle materials or those that are subjected to fatigue or cyclic loadings. Also, realize that stress-concentration factors apply *only* when the material is subjected to *elastic behavior*. If the applied moment causes yielding of the material, as is the case with ductile materials, the stress becomes redistributed throughout the member, and the maximum stress that results will be *lower* than that determined using stress-concentration factors. This phenomenon is discussed further in the next section.



Stress concentrations caused by bending occur at the sharp corners of this window lintel and are responsible for the crack at the corner.

## Important Points


- Stress concentrations occur at points of sudden cross-sectional change, caused by notches and holes, because here the stress and strain become nonlinear. The more severe the change, the larger the stress concentration.
- For design or analysis, the maximum normal stress occurs on the *smallest* cross-sectional area. This stress can be obtained by using a stress concentration factor, $K$, that has been determined through experiment and is only a function of the geometry of the member.
- Normally, the stress concentration in a ductile material subjected to a static moment will not have to be considered in design; however, if the material is *brittle*, or subjected to *fatigue* loading, then stress concentrations become important.

## EXAMPLE 6.20

The transition in the cross-sectional area of the steel bar is achieved using shoulder fillets as shown in Fig. 6–46*a*. If the bar is subjected to a bending moment of 5 kN · m, determine the maximum normal stress developed in the steel. The yield stress is $\sigma_Y = 500$ MPa.

### SOLUTION

The moment creates the largest stress in the bar at the base of the fillet, where the cross-sectional area is smallest. The stress-concentration factor can be determined by using Fig. 6–43. From the geometry of the bar, we have $r = 16$ mm, $h = 80$ mm, $w = 120$ mm. Thus,



(a)


$$\frac{r}{h} = \frac{16\text{ mm}}{80\text{ mm}} = 0.2 \qquad \frac{w}{h} = \frac{120\text{ mm}}{80\text{ mm}} = 1.5$$

These values give $K = 1.45$. Applying Eq. 6–26, we have


$$\sigma_{max} = K\frac{Mc}{I} = (1.45)\frac{(5(10^3)\text{ N}\cdot\text{m})(0.04\text{ m})}{\left[\frac{1}{12}(0.020\text{ m})(0.08\text{ m})^3\right]} = 340\text{ MPa} \qquad \textit{Ans.}$$

This result indicates that the steel remains elastic since the stress is below the yield stress (500 MPa).

**NOTE:** The normal-stress distribution is nonlinear and is shown in Fig. 6–46*b*. Realize, however, that by Saint-Venant's principle, Sec. 4.1, these localized stresses smooth out and become linear when one moves (approximately) a distance of 80 mm or more to the right of the transition. In this case, the flexure formula gives $\sigma_{max} = 234$ MPa. Fig. 6–46*c*. Also note that the choice of a larger-radius fillet will significantly reduce $\sigma_{max}$, since as $r$ increases in Fig. 6–43, $K$ will decrease.



(b)




(c)

Fig. 6–46

## PROBLEMS

**6–127.** The composite beam is made of 6061-T6 aluminum ($A$) and C83400 red brass ($B$). Determine the dimension $h$ of the brass strip so that the neutral axis of the beam is located at the seam of the two metals. What maximum moment will this beam support if the allowable bending stress for the aluminum is $(\sigma_{allow})_{al} = 128$ MPa and for the brass $(\sigma_{allow})_{br} = 35$ MPa?


***6–128.** The composite beam is made of 6061-T6 aluminum ($A$) and C83400 red brass ($B$). If the height $h = 40$ mm, determine the maximum moment that can be applied to the beam if the allowable bending stress for the aluminum is $(\sigma_{allow})_{al} = 128$ MPa and for the brass $(\sigma_{allow})_{br} = 35$ MPa.




Probs. 6–127/128


**•6–129.** Segment $A$ of the composite beam is made from 2014-T6 aluminum alloy and segment $B$ is A-36 steel. If $w = 0.9$ kip/ft, determine the absolute maximum bending stress developed in the aluminum and steel. Sketch the stress distribution on the cross section.

**6–130.** Segment $A$ of the composite beam is made from 2014-T6 aluminum alloy and segment $B$ is A-36 steel. If the allowable bending stress for the aluminum and steel are $(\sigma_{allow})_{al} = 15$ ksi and $(\sigma_{allow})_{st} = 22$ ksi, determine the maximum allowable intensity $w$ of the uniform distributed load.




Probs. 6–129/130


**6–131.** The Douglas fir beam is reinforced with A-36 straps at its center and sides. Determine the maximum stress developed in the wood and steel if the beam is subjected to a bending moment of $M_z = 7.50$ kip·ft. Sketch the stress distribution acting over the cross section.




Prob. 6–131


***6–132.** The top plate is made of 2014-T6 aluminum and is used to reinforce a Kevlar 49 plastic beam. Determine the maximum stress in the aluminum and in the Kevlar if the beam is subjected to a moment of $M = 900$ lb·ft.

**•6–133.** The top plate made of 2014-T6 aluminum is used to reinforce a Kevlar 49 plastic beam. If the allowable bending stress for the aluminum is $(\sigma_{allow})_{al} = 40$ ksi and for the Kevlar $(\sigma_{allow})_k = 8$ ksi, determine the maximum moment $M$ that can be applied to the beam.





Probs. 6–132/133

**6–134.** The member has a brass core bonded to a steel casing. If a couple moment of 8 kN · m is applied at its end, determine the maximum bending stress in the member. $E_{br} = 100$ GPa, $E_{st} = 200$ GPa.





Prob. 6–134

**6–135.** The steel channel is used to reinforce the wood beam. Determine the maximum stress in the steel and in the wood if the beam is subjected to a moment of $M = 850$ lb · ft. $E_{st} = 29(10^3)$ ksi, $E_w = 1600$ ksi.





Prob. 6–135

***6–136.** A white spruce beam is reinforced with A-36 steel straps at its top and bottom as shown. Determine the bending moment $M$ it can support if $(\sigma_{allow})_{st} = 22$ ksi and $(\sigma_{allow})_w = 2.0$ ksi.




Prob. 6–136

**•6–137.** If the beam is subjected to an internal moment of $M = 45$ kN · m, determine the maximum bending stress developed in the A-36 steel section $A$ and the 2014-T6 aluminum alloy section $B$.





Prob. 6–137

**6–138.** The concrete beam is reinforced with three 20-mm diameter steel rods. Assume that the concrete cannot support tensile stress. If the allowable compressive stress for concrete is $(\sigma_{allow})_{con} = 12.5$ MPa and the allowable tensile stress for steel is $(\sigma_{allow})_{st} = 220$ MPa, determine the required dimension $d$ so that both the concrete and steel achieve their allowable stress simultaneously. This condition is said to be 'balanced'. Also, compute the corresponding maximum allowable internal moment **M** that can be applied to the beam. The moduli of elasticity for concrete and steel are $E_{con} = 25$ GPa and $E_{st} = 200$ GPa, respectively.





Prob. 6–138

**6–139.** The beam is made from three types of plastic that are identified and have the moduli of elasticity shown in the figure. Determine the maximum bending stress in the PVC.





Prob. 6–139

***6–140.** The low strength concrete floor slab is integrated with a wide-flange A-36 steel beam using shear studs (not shown) to form the composite beam. If the allowable bending stress for the concrete is $(\sigma_{allow})_{con}$ = 10 MPa, and allowable bending stress for steel is $(\sigma_{allow})_{st}$ = 165 MPa, determine the maximum allowable internal moment **M** that can be applied to the beam.





Prob. 6–140

**•6–141.** The reinforced concrete beam is used to support the loading shown. Determine the absolute maximum normal stress in each of the A-36 steel reinforcing rods and the absolute maximum compressive stress in the concrete. Assume the concrete has a high strength in compression and yet neglect its strength in supporting tension.




Prob. 6–141

**6–142.** The reinforced concrete beam is made using two steel reinforcing rods. If the allowable tensile stress for the steel is $(\sigma_{st})_{allow}$ = 40 ksi and the allowable compressive stress for the concrete is $(\sigma_{conc})_{allow}$ = 3 ksi, determine the maximum moment $M$ that can be applied to the section. Assume the concrete cannot support a tensile stress. $E_{st}$ = 29(10³) ksi, $E_{conc}$ = 3.8(10³) ksi.





Prob. 6–142

**6–143.** For the curved beam in Fig. 6–40*a*, show that when the radius of curvature approaches infinity, the curved-beam formula, Eq. 6–24, reduces to the flexure formula, Eq. 6–13.

*6–144. The member has an elliptical cross section. If it is subjected to a moment of $M = 50\ \text{N}\cdot\text{m}$, determine the stress at points $A$ and $B$. Is the stress at point $A'$, which is located on the member near the wall, the same as that at $A$? Explain.


•6–145. The member has an elliptical cross section. If the allowable bending stress is $\sigma_{allow} = 125$ MPa, determine the maximum moment $M$ that can be applied to the member.




Probs. 6–144/145

6–146. Determine the greatest magnitude of the applied forces $P$ if the allowable bending stress is $(\sigma_{allow})_c = 50$ MPa in compression and $(\sigma_{allow})_t = 120$ MPa in tension.


6–147. If $P = 6$ kN, determine the maximum tensile and compressive bending stresses in the beam.




Probs. 6–146/147


*6–148. The curved beam is subjected to a bending moment of $M = 900\ \text{N}\cdot\text{m}$ as shown. Determine the stress at points $A$ and $B$, and show the stress on a volume element located at each of these points.

•6–149. The curved beam is subjected to a bending moment of $M = 900\ \text{N}\cdot\text{m}$. Determine the stress at point $C$.





Probs. 6–148/149

6–150. The elbow of the pipe has an outer radius of 0.75 in. and an inner radius of 0.63 in. If the assembly is subjected to the moments of $M = 25\ \text{lb}\cdot\text{in.}$, determine the maximum stress developed at section $a$–$a$.





Prob. 6–150

**6–151.** The curved member is symmetric and is subjected to a moment of $M = 600$ lb·ft. Determine the bending stress in the member at points $A$ and $B$. Show the stress acting on volume elements located at these points.





Prob. 6–151

***6–152.** The curved bar used on a machine has a rectangular cross section. If the bar is subjected to a couple as shown, determine the maximum tensile and compressive stress acting at section $a-a$. Sketch the stress distribution on the section in three dimensions.




Prob. 6–152


**•6–153.** The ceiling-suspended C-arm is used to support the X-ray camera used in medical diagnoses. If the camera has a mass of 150 kg, with center of mass at $G$, determine the maximum bending stress at section $A$.




Prob. 6–153


**6–154.** The circular spring clamp produces a compressive force of 3 N on the plates. Determine the maximum bending stress produced in the spring at $A$. The spring has a rectangular cross section as shown.

**6–155.** Determine the maximum compressive force the spring clamp can exert on the plates if the allowable bending stress for the clamp is $\sigma_{allow} = 4$ MPa.




Probs. 6–154/155


***6–156.** While in flight, the curved rib on the jet plane is subjected to an anticipated moment of $M = 16\ \text{N}\cdot\text{m}$ at the section. Determine the maximum bending stress in the rib at this section, and sketch a two-dimensional view of the stress distribution.




Prob. 6–156

**•6–157.** If the radius of each notch on the plate is $r = 0.5$ in., determine the largest moment that can be applied. The allowable bending stress for the material is $\sigma_{\text{allow}} = 18$ ksi.


**6–158.** The symmetric notched plate is subjected to bending. If the radius of each notch is $r = 0.5$ in. and the applied moment is $M = 10\ \text{kip}\cdot\text{ft}$, determine the maximum bending stress in the plate.




Probs. 6–157/158

**6–159.** The bar is subjected to a moment of $M = 40\ \text{N}\cdot\text{m}$. Determine the smallest radius $r$ of the fillets so that an allowable bending stress of $\sigma_{\text{allow}} = 124$ MPa is not exceeded.


***6–160.** The bar is subjected to a moment of $M = 17.5\ \text{N}\cdot\text{m}$. If $r = 5$ mm, determine the maximum bending stress in the material.




Probs. 6–159/160


**•6–161.** The simply supported notched bar is subjected to two forces **P**. Determine the largest magnitude of **P** that can be applied without causing the material to yield. The material is A-36 steel. Each notch has a radius of $r = 0.125$ in.

**6–162.** The simply supported notched bar is subjected to the two loads, each having a magnitude of $P = 100$ lb. Determine the maximum bending stress developed in the bar, and sketch the bending-stress distribution acting over the cross section at the center of the bar. Each notch has a radius of $r = 0.125$ in.





Probs. 6–161/162

**6–163.** Determine the length $L$ of the center portion of the bar so that the maximum bending stress at $A$, $B$, and $C$ is the same. The bar has a thickness of 10 mm.




Prob. 6–163

***6–164.** The stepped bar has a thickness of 15 mm. Determine the maximum moment that can be applied to its ends if it is made of a material having an allowable bending stress of $\sigma_{\text{allow}} = 200$ MPa.




Prob. 6–164

## *6.10 Inelastic Bending

The equations for determining the normal stress due to bending that have previously been developed are valid only if the material behaves in a linear-elastic manner. If the applied moment causes the material to *yield*, a plastic analysis must then be used to determine the stress distribution. For bending of straight members three conditions must be met.

**Linear Normal-Strain Distribution.** Based only on geometric considerations, it was shown in Sec. 6.3 that the normal strains always vary *linearly* from zero at the neutral axis of the cross section to a maximum at the farthest point from the neutral axis.




Fig. 6–47

**Resultant Force Equals Zero.** Since there is only a resultant internal moment acting on the cross section, the resultant force caused by the stress distribution must be equal to zero. Since $\sigma$ creates a force on the area $dA$ of $dF = \sigma\, dA$, Fig. 6–47, then for the entire cross-sectional area $A$, we have


$$F_R = \Sigma F_x; \qquad \int_A \sigma\, dA = 0 \tag{6–27}$$

This equation provides a means for obtaining the *location of the neutral axis*.


**Resultant Moment.** The resultant moment at the section must be equivalent to the moment caused by the stress distribution about the neutral axis. Since the moment of the force $dF = \sigma\, dA$ about the neutral axis is $dM = y(\sigma\, dA)$, Fig 6–47, then summing the results over the entire cross section, we have,

$$(M_R)_z = \Sigma M_z; \qquad M = \int_A y(\sigma\, dA) \tag{6–28}$$

These conditions of geometry and loading will now be used to show how to determine the stress distribution in a beam when it is subjected to a resultant internal moment that causes yielding of the material. Throughout the discussion we will assume that the material has a stress-strain diagram that is the *same* in tension as it is in compression. For simplicity, we will begin by considering the beam to have a cross-sectional area with two axes of symmetry; in this case, a rectangle of height $h$ and width $b$, as shown in Fig. 6–48*a*. Two cases of loading that are of special interest will be considered.




(a)




Strain distribution (profile view)

(b)

**Plastic Moment.** Some materials, such as steel, tend to exhibit elastic-perfectly plastic behavior when the stress in the material reaches $\sigma_Y$. If the applied moment $M = M_Y$ is just sufficient to produce yielding in the top and bottom fibers of the beam as shown in Fig. 6–48*b*, then we can determine $M_Y$ using the flexure formula $\sigma_Y = M_Y(h/2)/[bh^3/12]$ or

$$M_Y = \frac{1}{6}bh^2\sigma_Y \tag{6–29}$$


If the internal moment $M > M_Y$, the material at the top and bottom of the beam will begin to yield, causing a redistribution of stress over the cross section until the required internal moment $M$ is developed. If this causes normal-strain distribution as shown in Fig. 6–48*b*, then the corresponding normal-stress distribution is determined from the stress–strain diagram shown in Fig. 6–48*c*. Here the strains $\epsilon_1$, $\epsilon_Y$, $\epsilon_2$, correspond to stresses $\sigma_1$, $\sigma_Y$, $\sigma_Y$, respectively. When these and other stresses like them are plotted on the cross section, we obtain the stress distribution shown in Fig. 6–48*d* or 6–48*e*. Here the tension and compression stress "blocks" each consist of component rectangular and triangular blocks. The resultant forces they produce are equivalent to their volumes.

$$T_1 = C_1 = \frac{1}{2}y_Y\sigma_Y b$$

$$T_2 = C_2 = \left(\frac{h}{2} - y_Y\right)\sigma_Y b$$


Because of the symmetry, Eq. 6–27 is satisfied and the neutral axis passes through the centroid of the cross section as shown. The applied moment $M$ can be related to the yield stress $\sigma_Y$ using Eq. 6–28. From Fig. 6–48*e*, we require

$$\begin{aligned} M &= T_1\left(\frac{2}{3}y_Y\right) + C_1\left(\frac{2}{3}y_Y\right) + T_2\left[y_Y + \frac{1}{2}\left(\frac{h}{2} - y_Y\right)\right] \\ &\quad + C_2\left[y_Y + \frac{1}{2}\left(\frac{h}{2} - y_Y\right)\right] \\ &= 2\left(\frac{1}{2}y_Y\sigma_Y b\right)\left(\frac{2}{3}y_Y\right) + 2\left[\left(\frac{h}{2} - y_Y\right)\sigma_Y b\right]\left[\frac{1}{2}\left(\frac{h}{2} + y_Y\right)\right] \\ &= \frac{1}{4}bh^2\sigma_Y\left(1 - \frac{4}{3}\frac{y_Y^2}{h^2}\right) \end{aligned}$$





Stress–strain diagram (elastic-plastic region)

(c)




Stress distribution (profile view)

(d)




(e)

Fig. 6–48

Or using Eq. 6–29,

$$M = \frac{3}{2} M_Y \left(1 - \frac{4}{3}\frac{y_Y^2}{h^2}\right) \tag{6–30}$$

As noted in Fig. 6–48*e*, **M** produces two zones of plastic yielding and an elastic core in the member. The boundary between them is located a distance $\pm y_Y$ from the neutral axis. As **M** increases in magnitude, $y_Y$ approaches zero. This would render the material entirely plastic and the stress distribution will then look like that shown in Fig. 6–48*f*. From Eq. 6–30 with $y_Y = 0$, or by finding the moments of the stress "blocks" around the neutral axis, we can write this limiting value as

$$M_p = \frac{1}{4} b h^2 \sigma_Y \tag{6–31}$$

Using Eq. 6–29, or Eq. 6–30 with $y = 0$, we have


$$M_p = \frac{3}{2} M_Y \tag{6–32}$$

This moment is referred to as the ***plastic moment***. Its value applies only for a rectangular section, since the analysis depends on the geometry of the cross section.

Beams used in steel buildings are sometimes designed to resist a plastic moment. When this is the case, codes usually list a design property for a beam called the shape factor. The ***shape factor*** is defined as the ratio

$$\boxed{k = \frac{M_p}{M_Y}} \tag{6–33}$$

This value specifies the additional moment capacity that a beam can support beyond its maximum elastic moment. For example, from Eq. 6–32, a beam having a rectangular cross section has a shape factor of $k = 1.5$. Therefore this section will support 50% more bending moment than its maximum elastic moment when it becomes fully plastic.





Plastic moment

(f)

**Fig. 6–48 (cont.)**

**Residual Stress.** When the plastic moment is removed from the beam then it will cause ***residual stress*** to be developed in the beam. These stresses are often important when considering fatigue and other types of mechanical behavior, and so we will discuss a method used for their computation. To explain how this is done, we will assume that $M_p$ causes the material at the top and bottom of the beam to be strained to $\epsilon_1$ ($\gg \epsilon_Y$), as shown by point $B$ on the $\sigma-\epsilon$ curve in Fig. 6–49*a*. A release of this moment will cause this material to recover some of this strain elastically by following the dashed path $BC$. Since this recovery is elastic, we can superimpose on the stress distribution in Fig. 6–49*b* a linear stress distribution caused by applying the plastic moment in the opposite direction, Fig. 6–49*c*. Here the maximum stress, which is called the ***modulus of rupture*** for bending, $\sigma_r$, can be determined from the flexure formula when the beam is loaded with the plastic moment. We have

$$\sigma_{max} = \frac{Mc}{I} = \frac{M_p\left(\frac{1}{2}h\right)}{\left(\frac{1}{12}bh^3\right)} = \frac{\left(\frac{1}{4}bh^2\sigma_Y\right)\left(\frac{1}{2}h\right)}{\left(\frac{1}{12}bh^3\right)} = 1.5\sigma_Y$$




(a)

Fig. 6–49





**Fig. 6–49 (cont.)**

This reversed application of the plastic moment is possible here, since maximum elastic recovery strain at the top and bottom of the beam is $2\epsilon_Y$ as shown in Fig. 6–49*a*. This corresponds to a maximum stress of $2\sigma_Y$ which is greater than the *required* stress of $1.5\sigma_Y$ as calculated above, Fig. 6–49*c*.

The superposition of the plastic moment, Fig. 6–49*b*, and its removal, Fig. 6–49*c*, gives the residual-stress distribution shown in Fig. 6–49*d*. As an exercise, use the component triangular "blocks" that represent this stress distribution and show that it results in a zero-force and zero-moment resultant on the member as required.

**Ultimate Moment.** Consider now the more general case of a beam having a cross section that is symmetrical only with respect to the vertical axis, while the moment is applied about the horizontal axis, Fig. 6–50*a*. We will assume that the material exhibits strain hardening and that its stress–strain diagrams for tension and compression are different, Fig. 6–50*b*.

If the moment **M** produces yielding of the beam, difficulty arises in finding *both* the location of the neutral axis and the maximum strain that is produced in the beam. This is because the cross section is unsymmetrical about the horizontal axis and the stress–strain behavior of the material is not the same in tension and compression. To solve this problem, a trial-and-error procedure requires the following steps:

1. For a given moment **M**, *assume* the location of the neutral axis and the slope of the "linear" strain distribution, Fig. 6–50*c*.
2. Graphically establish the stress distribution on the member's cross section using the $\sigma-\epsilon$ curve to plot values of stress corresponding to values of strain. The resulting stress distribution, Fig. 6–50*d*, will then have the same shape as the $\sigma-\epsilon$ curve.







**Fig. 6–50**





Strain distribution (profile view)

(c)




Stress distribution (profile view)

(d)




(e)

Fig. 6–50 (cont.)

3. Determine the volumes enclosed by the tensile and compressive stress "blocks." (As an approximation, this may require dividing each block into composite regions.) Equation 6–27 requires the volumes of these blocks to be *equal*, since they represent the resultant tensile force **T** and resultant compressive force **C** on the section, Fig. 6–50*e*. If these forces are unequal, an adjustment as to the *location* of the neutral axis must be made (point of *zero strain*) and the process repeated until Eq. 6–27 ($T = C$) is satisfied.
4. Once $T = C$, the moments produced by **T** and **C** can be calculated about the neutral axis. Here the moment arms for **T** and **C** are measured from the neutral axis to the *centroids of the volumes* defined by the stress distributions, Fig. 6–50*e*. Equation 6–28 requires $M = Ty' + Cy''$. If this equation is not satisfied, the *slope* of the *strain distribution* must be adjusted and the computations for $T$ and $C$ and the moment must be repeated until close agreement is obtained.


This trial-and-error procedure is obviously very tedious, and fortunately it does not occur very often in engineering practice. Most beams are symmetric about two axes, and they are constructed from materials that are assumed to have similar tension-and-compression stress–strain diagrams. Whenever this occurs, the neutral axis will pass through the centroid of the cross section, and the process of relating the stress distribution to the resultant moment is thereby simplified.

## Important Points

- The *normal strain distribution* over the cross section of a beam is based only on geometric considerations and has been found to always remain *linear*, regardless of the applied load. The normal stress distribution, however, must be determined from the material behavior, or stress–strain diagram once the strain distribution is established.
- The *location of the neutral axis* is determined from the condition that the *resultant force* on the cross section is *zero*.
- The resultant internal moment on the cross section must be equal to the moment of the stress distribution about the neutral axis.
- Perfectly plastic behavior assumes the normal stress distribution is *constant* over the cross section, and the beam will continue to bend, with no increase in moment. This moment is called the *plastic moment*.

## EXAMPLE 6.21

The steel wide-flange beam has the dimensions shown in Fig. 6–51*a*. If it is made of an elastic perfectly plastic material having a tensile and compressive yield stress of $\sigma_Y = 36$ ksi, determine the shape factor for the beam.



(a)

### SOLUTION


In order to determine the shape factor, it is first necessary to calculate the maximum elastic moment $M_Y$ and the plastic moment $M_p$.

**Maximum Elastic Moment.** The normal-stress distribution for the maximum elastic moment is shown in Fig. 6–51*b*. The moment of inertia about the neutral axis is

$$I = \left[\frac{1}{12}(0.5\text{ in.})(9\text{ in.})^3\right] + 2\left[\frac{1}{12}(8\text{ in.})(0.5\text{ in.})^3 + 8\text{ in.}\,(0.5\text{ in.})(4.75\text{ in.})^2\right] = 211.0\text{ in}^4$$

Applying the flexure formula, we have

$$\sigma_{max} = \frac{Mc}{I}; \qquad 36\text{ kip/in}^2 = \frac{M_Y(5\text{ in.})}{211.0\text{ in}^4} \qquad M_Y = 1519.5\text{ kip}\cdot\text{in.}$$




(b)

**Plastic Moment.** The plastic moment causes the steel over the entire cross section of the beam to yield, so that the normal-stress distribution looks like that shown in Fig. 6–51*c*. Due to symmetry of the cross-sectional area and since the tension and compression stress–strain diagrams are the same, the neutral axis passes through the centroid of the cross section. In order to determine the plastic moment, the stress distribution is divided into four composite rectangular "blocks," and the force produced by each "block" is equal to the volume of the block. Therefore, we have

$$C_1 = T_1 = 36\text{ kip/in}^2\,(0.5\text{ in.})(4.5\text{ in.}) = 81\text{ kip}$$
$$C_2 = T_2 = 36\text{ kip/in}^2\,(0.5\text{ in.})(8\text{ in.}) = 144\text{ kip}$$

These forces act through the *centroid* of the volume for each block. Calculating the moments of these forces about the neutral axis, we obtain the plastic moment:

$$M_p = 2[(2.25\text{ in.})(81\text{ kip})] + 2[(4.75\text{ in.})(144\text{ kip})] = 1732.5\text{ kip}\cdot\text{in.}$$



(c)

Fig. 6–51

**Shape Factor.** Applying Eq. 6–33 gives

$$k = \frac{M_p}{M_Y} = \frac{1732.5\text{ kip}\cdot\text{in.}}{1519.5\text{ kip}\cdot\text{in.}} = 1.14 \qquad \textit{Ans.}$$

**NOTE:** This value indicates that a wide-flange beam provides a very efficient section for resisting an *elastic moment*. Most of the moment is developed in the flanges, i.e., in the top and bottom segments, whereas the web or vertical segment contributes very little. In this particular case, only 14% additional moment can be supported by the beam beyond that which can be supported elastically.

## EXAMPLE 6.22

A T-beam has the dimensions shown in Fig. 6–52*a*. If it is made of an elastic perfectly plastic material having a tensile and compressive yield stress of $\sigma_Y = 250$ MPa, determine the plastic moment that can be resisted by the beam.





Fig. 6–52

### SOLUTION

The "plastic" stress distribution acting over the beam's cross-sectional area is shown in Fig. 6–52*b*. In this case the cross section is not symmetric with respect to a horizontal axis, and consequently, the neutral axis will *not* pass through the centroid of the cross section. To determine the *location* of the neutral axis, $d$, we require the stress distribution to produce a zero resultant force on the cross section. Assuming that $d \leq 120$ mm, we have

$$\int_A \sigma \, dA = 0; \qquad T - C_1 - C_2 = 0$$

$$250 \text{ MPa } (0.015 \text{ m})(d) - 250 \text{ MPa } (0.015 \text{ m})(0.120 \text{ m} - d) - 250 \text{ MPa } (0.015 \text{ m})(0.100 \text{ m}) = 0$$

$$d = 0.110 \text{ m} < 0.120 \text{ m} \qquad \text{OK}$$

Using this result, the forces acting on each segment are

$$T = 250 \text{ MN/m}^2\,(0.015 \text{ m})(0.110 \text{ m}) = 412.5 \text{ kN}$$

$$C_1 = 250 \text{ MN/m}^2\,(0.015 \text{ m})(0.010 \text{ m}) = 37.5 \text{ kN}$$

$$C_2 = 250 \text{ MN/m}^2\,(0.015 \text{ m})(0.100 \text{ m}) = 375 \text{ kN}$$


Hence the resultant plastic moment about the neutral axis is

$$M_p = 412.5 \text{ kN}\left(\frac{0.110 \text{ m}}{2}\right) + 37.5 \text{ kN}\left(\frac{0.01 \text{ m}}{2}\right) + 375 \text{ kN}\left(0.01 \text{ m} + \frac{0.015 \text{ m}}{2}\right)$$

$$M_p = 29.4 \text{ kN} \cdot \text{m} \qquad \textit{Ans.}$$

## EXAMPLE 6.23

The steel wide-flange beam shown in Fig. 6–53*a* is subjected to a fully plastic moment of $\mathbf{M}_p$. If this moment is removed, determine the residual-stress distribution in the beam. The material is elastic perfectly plastic and has a yield stress of $\sigma_Y = 36$ ksi.



(a)

### SOLUTION

The normal-stress distribution in the beam caused by $\mathbf{M}_p$ is shown in Fig. 6–53*b*. When $\mathbf{M}_p$ is removed, the material responds elastically. Removal of $\mathbf{M}_p$ requires applying $\mathbf{M}_p$ in its reverse direction and therefore leads to an assumed elastic stress distribution as shown in Fig. 6–53*c*. The modulus of rupture $\sigma_r$ is computed from the flexure formula. Using $M_p = 1732.5$ kip · in. and $I = 211.0$ in$^4$ from Example 6.21, we have

$$\sigma_{max} = \frac{Mc}{I};$$


$$\sigma_r = \frac{1732.5 \text{ kip} \cdot \text{in.} (5 \text{ in.})}{211.0 \text{ in}^4} = 41.1 \text{ ksi}$$

As expected, $\sigma_r < 2\sigma_Y$.

Superposition of the stresses gives the residual-stress distribution shown in Fig. 6–53*d*. Note that the point of zero normal stress was determined by proportion; i.e., from Fig. 6–53*b* and 6–53*c*, we require that

$$\frac{41.1 \text{ ksi}}{5 \text{ in.}} = \frac{36 \text{ ksi}}{y}$$

$$y = 4.38 \text{ in.}$$




Plastic moment applied (profile view)

(b)

Plastic moment reversed (profile view)

(c)


Residual stress distribution

(d)

Fig. 6–53

## EXAMPLE 6.24


The beam in Fig. 6–54*a* is made of an alloy of titanium that has a stress–strain diagram that can in part be approximated by two straight lines. If the material behavior is the *same* in both tension and compression, determine the bending moment that can be applied to the beam that will cause the material at the top and bottom of the beam to be subjected to a strain of 0.050 in./in.




(a)

### SOLUTION I

By inspection of the stress–strain diagram, the material is said to exhibit "elastic-plastic behavior with strain hardening." Since the cross section is symmetric and the tension–compression $\sigma-\epsilon$ diagrams are the same, the neutral axis must pass through the centroid of the cross section. The strain distribution, which is always linear, is shown in Fig. 6–54*b*. In particular, the point where maximum elastic strain (0.010 in./in.) occurs has been determined by proportion, such that 0.05/1.5 in. = 0.010/$y$ or $y$ = 0.3 in.




Strain distribution

(b)

Fig. 6–54

The corresponding normal-stress distribution acting over the cross section is shown in Fig. 6–54*c*. The moment produced by this distribution can be calculated by finding the "volume" of the stress blocks. To do so we will subdivide this distribution into two triangular blocks and a rectangular block in both the tension and compression regions, Fig. 6–54*d*. Since the beam is 2 in. wide, the resultants and their locations are determined as follows:

$$T_1 = C_1 = \frac{1}{2}(1.2\text{ in.})(40\text{ kip/in}^2)(2\text{ in.}) = 48\text{ kip}$$


$$y_1 = 0.3\text{ in.} + \frac{2}{3}(1.2\text{ in.}) = 1.10\text{ in.}$$

$$T_2 = C_2 = (1.2\text{ in.})(150\text{ kip/in}^2)(2\text{ in.}) = 360\text{ kip}$$

$$y_2 = 0.3\text{ in.} + \frac{1}{2}(1.2\text{ in.}) = 0.90\text{ in.}$$

$$T_3 = C_3 = \frac{1}{2}(0.3\text{ in.})(150\text{ kip/in}^2)(2\text{ in.}) = 45\text{ kip}$$

$$y_3 = \frac{2}{3}(0.3\text{ in.}) = 0.2\text{ in.}$$




Stress distribution


(c)

The moment produced by this normal-stress distribution about the neutral axis is therefore

$$M = 2[48\text{ kip}\,(1.10\text{ in.}) + 360\text{ kip}\,(0.90\text{ in.}) + 45\text{ kip}\,(0.2\text{ in.})]$$
$$= 772\text{ kip}\cdot\text{in.} \qquad \textit{Ans.}$$

## SOLUTION II

Rather than using the above semigraphical technique, it is also possible to find the moment analytically. To do this we must express the stress distribution in Fig. 6–54*c* as a function of position $y$ along the beam. Note that $\sigma = f(\epsilon)$ has been given in Fig. 6–54*a*. Also, from Fig. 6–54*b*, the normal strain can be determined as a function of position $y$ by proportional triangles; i.e.,




(d)

$$\epsilon = \frac{0.05}{1.5}y \qquad 0 \le y \le 1.5\text{ in.}$$

Substituting this into the $\sigma$–$\epsilon$ functions shown in Fig. 6–54*a* gives

$$\sigma = 500y \qquad 0 \le y \le 0.3\text{ in.} \qquad (1)$$


$$\sigma = 33.33y + 140 \qquad 0.3\text{ in.} \le y \le 1.5\text{ in.} \qquad (2)$$

From Fig. 6–54*e*, the moment caused by $\sigma$ acting on the area strip $dA = 2\,dy$ is

$$dM = y(\sigma\,dA) = y\sigma(2\,dy)$$

Using Eqs. 1 and 2, the moment for the entire cross section is thus

$$M = 2\left[2\int_0^{0.3\text{ in.}} 500y^2\,dy + 2\int_{0.3\text{ in.}}^{1.5\text{ in.}} (33.3y^2 + 140y)\,dy\right]$$
$$= 772\text{ kip}\cdot\text{in.} \qquad \textit{Ans.}$$





(e)

Fig. 6–54 (cont.)


## PROBLEMS

**•6–165.** The beam is made of an elastic plastic material for which $\sigma_Y = 250$ MPa. Determine the residual stress in the beam at its top and bottom after the plastic moment $\mathbf{M}_p$ is applied and then released.




Prob. 6–165


**6–166.** The wide-flange member is made from an elastic-plastic material. Determine the shape factor.




Prob. 6–166


**6–167.** Determine the shape factor for the cross section.

***6–168.** The beam is made of elastic perfectly plastic material. Determine the maximum elastic moment and the plastic moment that can be applied to the cross section. Take $a = 2$ in. and $\sigma_Y = 36$ ksi.





Prob. 6–167/168

**•6–169.** The box beam is made of an elastic perfectly plastic material for which $\sigma_Y = 250$ MPa. Determine the residual stress in the top and bottom of the beam after the plastic moment $\mathbf{M}_p$ is applied and then released.





Prob. 6–169

**6–170.** Determine the shape factor for the wide-flange beam.





**Prob. 6–170**

***6–172.** The beam is made of elastic-perfectly plastic material. Determine the maximum elastic moment and the plastic moment that can be applied to the cross section. Take $\sigma_Y = 36$ ksi.





**Prob. 6–172**

**6–171.** Determine the shape factor of the beam's cross section.





**Prob. 6–171**

**•6–173.** Determine the shape factor for the cross section of the H-beam.





**Prob. 6–173**

**6–174.** The H-beam is made of an elastic-plastic material for which $\sigma_Y = 250$ MPa. Determine the residual stress in the top and bottom of the beam after the plastic moment $\mathbf{M}_p$ is applied and then released.





**Prob. 6–174**

**6–175.** Determine the shape factor of the cross section.





**Prob. 6–175**

*6–176. The beam is made of elastic-perfectly plastic material. Determine the maximum elastic moment and the plastic moment that can be applied to the cross section. Take $\sigma_Y = 36$ ksi.




**Prob. 6–176**

•6–177. Determine the shape factor of the cross section for the tube.





**Prob. 6–177**

**6–178.** The beam is made from elastic-perfectly plastic material. Determine the shape factor for the thick-walled tube.




Prob. 6–178

**6–179.** Determine the shape factor for the member.




Prob. 6–179

***6–180.** The member is made from an elastic-plastic material. Determine the maximum elastic moment and the plastic moment that can be applied to the cross section. Take $b = 4$ in., $h = 6$ in., $\sigma_Y = 36$ ksi.




Prob. 6–180

**•6–181.** The beam is made of a material that can be assumed perfectly plastic in tension and elastic perfectly plastic in compression. Determine the maximum bending moment $M$ that can be supported by the beam so that the compressive material at the outer edge starts to yield.




Prob. 6–181

**6–182.** The box beam is made from an elastic-plastic material for which $\sigma_Y = 25$ ksi. Determine the intensity of the distributed load $w_0$ that will cause the moment to be (a) the largest elastic moment and (b) the largest plastic moment.





Prob. 6–182

**6–183.** The box beam is made from an elastic-plastic material for which $\sigma_Y = 36$ ksi. Determine the magnitude of each concentrated force **P** that will cause the moment to be (a) the largest elastic moment and (b) the largest plastic moment.





Prob. 6–183

***6–184.** The beam is made of a polyester that has the stress-strain curve shown. If the curve can be represented by the equation $\sigma = [20 \tan^{-1}(15\epsilon)]$ ksi, where $\tan^{-1}(15\epsilon)$ is in radians, determine the magnitude of the force **P** that can be applied to the beam without causing the maximum strain in its fibers at the critical section to exceed $\epsilon_{max} = 0.003$ in./in.





Prob. 6–184

**•6–185.** The plexiglass bar has a stress–strain curve that can be approximated by the straight-line segments shown. Determine the largest moment $M$ that can be applied to the bar before it fails.





Prob. 6–185

**6–186.** The stress–strain diagram for a titanium alloy can be approximated by the two straight lines. If a strut made of this material is subjected to bending, determine the moment resisted by the strut if the maximum stress reaches a value of (a) $\sigma_A$ and (b) $\sigma_B$.





**Prob. 6–186**

**6–187.** A beam is made from polypropylene plastic and has a stress–strain diagram that can be approximated by the curve shown. If the beam is subjected to a maximum tensile and compressive strain of $\epsilon = 0.02$ mm/mm, determine the maximum moment $M$.





**Prob. 6–187**

***6–188.** The beam has a rectangular cross section and is made of an elastic-plastic material having a stress–strain diagram as shown. Determine the magnitude of the moment **M** that must be applied to the beam in order to create a maximum strain in its outer fibers of $\epsilon_{max} = 0.008$.




**Prob. 6–188**


**•6–189.** The bar is made of an aluminum alloy having a stress–strain diagram that can be approximated by the straight line segments shown. Assuming that this diagram is the same for both tension and compression, determine the moment the bar will support if the maximum strain at the top and bottom fibers of the beam is $\epsilon_{max} = 0.03$.




**Prob. 6–189**

## CHAPTER REVIEW

Shear and moment diagrams are graphical representations of the internal shear and moment within a beam. They can be constructed by sectioning the beam an arbitrary distance $x$ from the left end, using the equilibrium equations to find $V$ and $M$ as functions of $x$, and then plotting the results. A sign convention for positive distributed load, shear, and moment must be followed.




It is also possible to plot the shear and moment diagrams by realizing that at each point the slope of the shear diagram is equal to the intensity of the distributed loading at the point.

$$w = \frac{dV}{dx}$$

Likewise, the slope of the moment diagram is equal to the shear at the point.

$$V = \frac{dM}{dx}$$


The area under the distributed loading diagram between the points represents the change in shear.

$$\Delta V = \int w\,dx$$

The area under the shear diagram represents the change in moment.

$$\Delta M = \int V\,dx$$


The shear and moment at any point can be obtained using the method of sections. The maximum (or minimum) moment occurs where the shear is zero.



A bending moment tends to produce a linear variation of normal strain within a straight beam. Provided the material is homogeneous, and linear elastic, then equilibrium can be used to relate the internal moment in the beam to the stress distribution. The result is the flexure formula,


$$\sigma_{max} = \frac{Mc}{I}$$

where $I$ and $c$ are determined from the neutral axis that passes through the centroid of the cross section.




If the cross-sectional area of the beam is not symmetric about an axis that is perpendicular to the neutral axis, then unsymmetrical bending will occur. The maximum stress can be determined from formulas, or the problem can be solved by considering the superposition of bending caused by the moment components $\mathbf{M}_y$ and $\mathbf{M}_z$ about the principal axes of inertia for the area.


$$\sigma = -\frac{M_z y}{I_z} + \frac{M_y z}{I_y}$$







Beams made from composite materials can be "transformed" so their cross section is considered as if it were made from a single material. To do this, the transformation factor $n$, which is a ratio of the moduli of elasticity of the materials, is used to change the width $b$ of the beam.

Once the cross section is transformed, then the stress in the beam can be determined in the usual manner using the flexure formula.

$$n = \frac{E_1}{E_2}$$



| | | |
|---|---|---|
| Curved beams deform such that the normal strain does not vary linearly from the neutral axis. Provided the material is homogeneous and linear elastic and the cross section has an axis of symmetry, then the curved beam formula can be used to determine the bending stress. | $\sigma = \frac{M(R - r)}{Ar(\bar{r} - R)}$ or $\sigma = \frac{My}{Ae(R - y)}$ |   |
| Stress concentrations occur in members having a sudden change in their cross section, caused, for example, by holes and notches. The maximum bending stress at these locations is determined using a stress concentration factor $K$ that is found from graphs determined from experiment. | $\sigma_{max} = K\frac{Mc}{I}$ |   |
| If the bending moment causes the stress in the material to exceed its elastic limit, then the normal strain will remain linear; however, the stress distribution will vary in accordance with the stress–strain diagram. The plastic and ultimate moments supported by the beam can be determined by requiring the resultant force to be zero and the resultant moment to be equivalent to the moment of the stress distribution. | |   |
| If an applied plastic or ultimate moment is released, it will cause the material to respond elastically, thereby inducing residual stresses in the beam. | |  |

## CONCEPTUAL PROBLEMS



P6–1

**P6–1.** The steel saw blade passes over the drive wheel of the band saw. Using appropriate measurements and data, explain how to determine the bending stress in the blade.



P6–2

**P6–2.** This crane boom on a ship has a moment of inertia that varies along its length. Draw the moment diagram for the boom to explain why the boom tapers as shown.



P6–3

**P6–3.** Hurricane winds caused failure of this highway sign by bending the supporting pipes at their connections with the column. Assuming the pipes are made of A-36 steel, use reasonable dimensions for the sign and pipes, and try and estimate the smallest uniform wind pressure acting on the face of the sign that caused the pipes to yield.



(a)



(b)


P6–4

**P6–4.** These garden shears were manufactured using an inferior material. Using a loading of 50 lb applied normal to the blades, and appropriate dimensions for the shears, determine the absolute maximum bending stress in the material and show why the failure occurred at the critical location on the handle.

## REVIEW PROBLEMS


**6–190.** The beam is made from three boards nailed together as shown. If the moment acting on the cross section is $M = 650\ \text{N}\cdot\text{m}$, determine the resultant force the bending stress produces on the top board.

**6–191.** The beam is made from three boards nailed together as shown. Determine the maximum tensile and compressive stresses in the beam.




Probs. 6–190/191


***6–192.** Determine the bending stress distribution in the beam at section $a$–$a$. Sketch the distribution in three dimensions acting over the cross section.




Prob. 6–192


**•6–193.** The composite beam consists of a wood core and two plates of steel. If the allowable bending stress for the wood is $(\sigma_{allow})_w = 20$ MPa, and for the steel $(\sigma_{allow})_{st} = 130$ MPa, determine the maximum moment that can be applied to the beam. $E_w = 11$ GPa, $E_{st} = 200$ GPa.

**6–194.** Solve Prob. 6–193 if the moment is applied about the $y$ axis instead of the $z$ axis as shown.





Probs. 6–193/194

**6–195.** A shaft is made of a polymer having a parabolic cross section. If it resists an internal moment of $M = 125\ \text{N}\cdot\text{m}$, determine the maximum bending stress developed in the material (a) using the flexure formula and (b) using integration. Sketch a three-dimensional view of the stress distribution acting over the cross-sectional area. *Hint:* The moment of inertia is determined using Eq. A–3 of Appendix A.





Prob. 6–195

*6–196. Determine the maximum bending stress in the handle of the cable cutter at section *a–a*. A force of 45 lb is applied to the handles. The cross-sectional area is shown in the figure.





Prob. 6–196

•6–197. The curved beam is subjected to a bending moment of $M = 85$ N · m as shown. Determine the stress at points $A$ and $B$ and show the stress on a volume element located at these points.





Prob. 6–197

6–198. Draw the shear and moment diagrams for the beam and determine the shear and moment in the beam as functions of $x$, where $0 \le x < 6$ ft.





Prob. 6–198

6–199. Draw the shear and moment diagrams for the shaft if it is subjected to the vertical loadings of the belt, gear, and flywheel. The bearings at $A$ and $B$ exert only vertical reactions on the shaft.





Prob. 6–199

*6–200. A member has the triangular cross section shown. Determine the largest internal moment $M$ that can be applied to the cross section without exceeding allowable tensile and compressive stresses of $(\sigma_{allow})_t = 22$ ksi and $(\sigma_{allow})_c = 15$ ksi, respectively.





Prob. 6–200

•6–201. The strut has a square cross section $a$ by $a$ and is subjected to the bending moment **M** applied at an angle $\theta$ as shown. Determine the maximum bending stress in terms of $a$, $M$, and $\theta$. What angle $\theta$ will give the largest bending stress in the strut? Specify the orientation of the neutral axis for this case.




Prob. 6–201



Railroad ties act as beams that support very large transverse shear loadings. As a result, if they are made of wood they will tend to split at their ends, where the shear loads are the largest.

# Transverse Shear

# 7

## CHAPTER OBJECTIVES

In this chapter, we will develop a method for finding the shear stress in a beam having a prismatic cross section and made from homogeneous material that behaves in a linear-elastic manner. The method of analysis to be developed will be somewhat limited to special cases of cross-sectional geometry. Although this is the case, it has many wide-range applications in engineering design and analysis. The concept of shear flow, along with shear stress, will be discussed for beams and thin-walled members. The chapter ends with a discussion of the shear center.

## 7.1 Shear in Straight Members

In general, a beam will support both shear and moment. The shear **V** is the result of a transverse shear-stress distribution that acts over the beam's cross section. Due to the complementary property of shear, however, this stress will create corresponding longitudinal shear stresses which will act along longitudinal planes of the beam as shown in Fig. 7–1.





Fig. 7–1




Boards not bonded together
(a)

Boards bonded together
(b)


Fig. 7–2




Shear connectors are "tack welded" to this corrugated metal floor liner so that when the concrete floor is poured, the connectors will prevent the concrete slab from slipping on the liner surface. The two materials will thus act as a composite slab.

To illustrate this effect, consider the beam to be made from three boards, Fig. 7–2*a*. If the top and bottom surfaces of each board are smooth, and the boards are *not* bonded together, then application of the load **P** will cause the boards to *slide* relative to one another when the beam deflects. However, if the boards are bonded together, then the longitudinal shear stresses acting between the boards will prevent their relative sliding, and consequently the beam will act as a single unit, Fig. 7–2*b*.

As a result of the shear stress, shear strains will be developed and these will tend to distort the cross section in a rather complex manner. For example, consider the short bar in Fig. 7–3*a* made of a highly deformable material and marked with horizontal and vertical grid lines. When a shear **V** is applied, it tends to deform these lines into the pattern shown in Fig. 7–3*b*. This nonuniform shear-strain distribution will cause the cross section to *warp*.




(a) Before deformation




(b) After deformation

Fig. 7–3

As a result, when a beam is subjected to *both* bending and shear, the cross section will not remain plane as assumed in the development of the flexure formula. Although this is the case, we can generally assume the cross-sectional warping due to shear is small enough so that it can be *neglected*. This assumption is particularly true for the most common case of a *slender beam*; that is, one that has a small depth compared with its length.

## 7.2 The Shear Formula

Because the strain distribution for shear is not easily defined, as in the case of axial load, torsion, and bending, we will develop the shear formula in an indirect manner. To do this we will consider the *horizontal force equilibrium* of a portion of the element taken from the beam in Fig. 7–4*a*. A free-body diagram of this *element* is shown in Fig. 7–4*b*. This distribution is caused by the bending moments $M$ and $M + dM$. We have excluded the effects of $V$, $V + dV$, and $w(x)$ on the free-body diagram since these loadings are vertical and will therefore not be involved in a horizontal force summation. The element in Fig. 7–4*b* will indeed satisfy $\Sigma F_x = 0$ since the stress distribution on each side of the element forms only a couple moment and therefore a zero force resultant.






Fig. 7–4




(a)

Now consider the shaded top *portion* of the element that has been sectioned at $y'$ from the neutral axis, Fig. 7–4*a*. This segment has a width $t$ at the section, and the two cross-sectional sides each have an area $A'$. Because the resultant moments on each side of the element differ by $dM$, it can be seen in Fig. 7–4*c* that $\Sigma F_x = 0$ will not be satisfied *unless* a longitudinal shear stress $\tau$ acts over the bottom face of the segment. We will assume this shear stress is *constant* across the width $t$ of the bottom face. It acts on the area $t\,dx$. Applying the equation of horizontal force equilibrium, and using the flexure formula, Eq. 6–13, we have

$$\stackrel{+}{\rightarrow} \Sigma F_x = 0; \qquad \int_{A'} \sigma'\,dA' - \int_{A'} \sigma\,dA' - \tau(t\,dx) = 0$$

$$\int_{A'} \left(\frac{M + dM}{I}\right) y\,dA' - \int_{A'} \left(\frac{M}{I}\right) y\,dA' - \tau(t\,dx) = 0$$


$$\left(\frac{dM}{I}\right) \int_{A'} y\,dA' = \tau(t\,dx) \tag{7–1}$$

Solving for $\tau$, we get

$$\tau = \frac{1}{It}\left(\frac{dM}{dx}\right) \int_{A'} y\,dA'$$

This equation can be simplified by noting that $V = dM/dx$ (Eq. 6–2). Also, the integral represents the moment of the area $A'$ about the neutral axis. We will denote this by the symbol $Q$. Since the location of the centroid of the area $A'$ is determined from $\bar{y}' = \int_{A'} y\,dA'/A'$, we can also write

$$Q = \int_{A'} y\,dA' = \bar{y}'A' \tag{7–2}$$




Three-dimensional view (c) Profile view

Fig. 7–4 (cont.)

The final result is therefore

$$\tau = \frac{VQ}{It} \tag{7–3}$$

Here, as shown in Fig. 7–5,

- $\tau$ = the shear stress in the member at the point located a distance $y'$ from the neutral axis. This stress is assumed to be constant and therefore *averaged* across the width $t$ of the member
- $V$ = the internal resultant shear force, determined from the method of sections and the equations of equilibrium
- $I$ = the moment of inertia of the *entire* cross-sectional area calculated about the neutral axis
- $t$ = the width of the member's cross-sectional area, measured at the point where $\tau$ is to be determined
- $Q = \overline{y}'\,A'$, where $A'$ is the area of the top (or bottom) portion of the member's cross-sectional area, above (or below) the section plane where $t$ is measured, and $\overline{y}'$ is the distance from the neutral axis to the centroid of $A'$

The above equation is referred to as the *shear formula*. Although in the derivation we considered only the shear stresses acting on the beam's longitudinal plane, the formula applies as well for finding the transverse shear stress on the beam's cross-section. Recall that these stresses are complementary and numerically equal.

Also, because the flexure formula was used in the derivation, it is necessary that the material behave in a linear elastic manner and have a modulus of elasticity that is the *same* in tension as it is in compression.





Fig. 7–5





Fig. 7–6

**Limitations on the Use of the Shear Formula.** One of the major assumptions used in the development of the shear formula is that the shear stress is *uniformly* distributed over the *width t* at the section. In other words, the *average shear stress* is calculated across the width. We can test the accuracy of this assumption by comparing it with a more exact mathematical analysis based on the theory of elasticity. For example, if the beam's cross section is rectangular, the shear-stress distribution across the neutral axis as calculated from the theory of elasticity varies as shown in Fig. 7–6. The maximum value, $\tau'_{max}$, occurs at the *sides* of the cross section, and its magnitude depends on the ratio $b/h$ (width/depth). For sections having a $b/h = 0.5$, $\tau'_{max}$ is only about 3% greater than the shear stress calculated from the shear formula, Fig. 7–6*a*. However, for *flat sections*, say $b/h = 2$, $\tau'_{max}$ is about 40% greater than $\tau_{max}$, Fig. 7–6*b*. The error becomes even greater as the section becomes flatter, or as the $b/h$ ratio increases. Errors of this magnitude are certainly intolerable if one uses the shear formula to determine the shear stress in the *flange* of the wide-flange beam shown in Fig. 7–7.

It should also be pointed out that the shear formula will not give accurate results when used to determine the shear stress at the flange–web junction of a wide-flange beam, since this is a point of sudden cross-sectional change and therefore a *stress concentration* occurs here. Fortunately, these limitations for applying the shear formula to the flanges of a wide-flange beam are not important in engineering practice. Most often engineers must only calculate the *average maximum shear stress* in the beam, which occurs at the neutral axis, where the $b/h$ (width/depth) ratio for the web is *very small*, and therefore the calculated result is very close to the *actual* maximum shear stress as explained above.







Fig. 7–7

Another important limitation on the use of the shear formula can be illustrated with reference to Fig. 7–8*a*, which shows a member having a cross section with an irregular or nonrectangular boundary. If we apply the shear formula to determine the (average) shear stress $\tau$ along the line $AB$, it will be directed downward as shown in Fig. 7–8*b*. However, consider an element of material taken from the boundary point $B$, Fig. 7–8*c*. Here $\tau$ on the front face of the element is resolved into components, $\tau'$ and $\tau''$ acting perpendicular and parallel to the boundary. By inspection, $\tau'$ must be equal to zero since its corresponding longitudinal component $\tau'$, on the stress-free boundary surface, must be zero. To satisfy this boundary condition, therefore, the shear stress acting on this element must *actually be directed tangent to the boundary*. As a result, the shear-stress distribution across line $AB$ is directed as shown in Fig. 7–8*d*. Here specific values for the shear stress must be obtained using the theory of elasticity. Note, however, that we can apply the shear formula to obtain the shear stress acting across each of the colored lines in Fig. 7–8*a*. These lines intersect the tangents to the boundary at *right angles*, and as shown in Fig. 7–8*e*, the transverse shear stress is vertical and constant along each line.

To summarize the above points, the shear formula does not give accurate results when applied to members having cross sections that are *short or flat*, or at points where the cross section suddenly changes. Nor should it be applied across a section that intersects the boundary of the member at an angle other than 90°. Instead, for these cases the shear stress should be determined using more advanced methods based on the theory of elasticity.







Fig. 7–8

## Important Points

- Shear forces in beams cause *nonlinear shear-strain* distributions over the cross section, causing it to *warp*.
- Due to the complementary property of shear stress, the shear stress developed in a beam acts over the cross section of the beam and along its longitudinal planes.
- The *shear formula* was derived by considering horizontal force equilibrium of the longitudinal shear-stress and bending-stress distributions acting on a portion of a differential segment of the beam.
- The shear formula is to be used on straight prismatic members made of homogeneous material that has linear elastic behavior. Also, the internal resultant shear force must be directed along an axis of symmetry for the cross-sectional area.
- The shear formula should not be used to determine the shear stress on cross sections that are short or flat, at points of sudden cross-sectional changes, or at a point on an inclined boundary.

## Procedure for Analysis

In order to apply the shear formula, the following procedure is suggested.

### Internal Shear.

- Section the member perpendicular to its axis at the point where the shear stress is to be determined, and obtain the internal shear $\mathbf{V}$ at the section.

### Section Properties.


- Determine the location of the neutral axis, and determine the moment of inertia $I$ of the *entire cross-sectional area* about the neutral axis.
- Pass an imaginary horizontal section through the point where the shear stress is to be determined. Measure the width $t$ of the cross-sectional area at this section.
- The portion of the area lying either above or below this width is $A'$. Determine $Q$ by using $Q = \bar{y}'A'$. Here $\bar{y}'$ is the distance to the centroid of $A'$, measured from the neutral axis. It may be helpful to realize that $A'$ is the portion of the member's cross-sectional area that is being "held onto the member" by the longitudinal shear stresses. See Fig. 7–4c.

### Shear Stress.

- Using a consistent set of units, substitute the data into the shear formula and calculate the shear stress $\tau$.
- It is suggested that the direction of the transverse shear stress $\tau$ be established on a volume element of material located at the point where it is calculated. This can be done by realizing that $\tau$ acts on the cross section in the same direction as $\mathbf{V}$. From this, the corresponding shear stresses acting on the other three planes of the element can then be established.

## EXAMPLE 7.1

The solid shaft and tube shown in Fig. 7–9*a* are subjected to the shear force of 4 kN. Determine the shear stress acting over the diameter of each cross section.




(a)

### SOLUTION

**Section Properties.** Using the table on the inside front cover, the moment of inertia of each section, calculated about its diameter (or neutral axis), is

$$I_{\text{solid}} = \frac{1}{4}\pi c^4 = \frac{1}{4}\pi(0.05\text{ m})^4 = 4.909(10^{-6})\text{ m}^4$$

$$I_{\text{tube}} = \frac{1}{4}\pi(c_o^4 - c_i^4) = \frac{1}{4}\pi[(0.05\text{ m})^4 - (0.02\text{ m})^4] = 4.783(10^{-6})\text{ m}^4$$

The semicircular area shown shaded in Fig. 7–9*b*, above (or below) each diameter, represents $Q$, because this area is "held onto the member" by the longitudinal shear stress along the diameter.

$$Q_{\text{solid}} = \bar{y}'A' = \frac{4c}{3\pi}\left(\frac{\pi c^2}{2}\right) = \frac{4(0.05\text{ m})}{3\pi}\left(\frac{\pi(0.05\text{ m})^2}{2}\right) = 83.33(10^{-6})\text{ m}^3$$

$$Q_{\text{tube}} = \Sigma\bar{y}'A' = \frac{4c_o}{3\pi}\left(\frac{\pi c_o^2}{2}\right) - \frac{4c_i}{3\pi}\left(\frac{\pi c_i^2}{2}\right)$$

$$= \frac{4(0.05\text{ m})}{3\pi}\left(\frac{\pi(0.05\text{ m})^2}{2}\right) - \frac{4(0.02\text{ m})}{3\pi}\left(\frac{\pi(0.02\text{ m})^2}{2}\right)$$


$$= 78.0(10^{-6})\text{ m}^3$$

**Shear Stress.** Applying the shear formula where $t = 0.1$ m for the solid section, and $t = 2(0.03\text{ m}) = 0.06$ m for the tube, we have

$$\tau_{\text{solid}} = \frac{VQ}{It} = \frac{4(10^3)\text{ N}(83.33(10^{-6})\text{ m}^3)}{4.909(10^{-6})\text{ m}^4(0.1\text{ m})} = 679\text{ kPa} \qquad \textit{Ans.}$$

$$\tau_{\text{tube}} = \frac{VQ}{It} = \frac{4(10^3)\text{ N}(78.0(10^{-6})\text{ m}^3)}{4.783(10^{-6})\text{ m}^4(0.06\text{ m})} = 1.09\text{ MPa} \qquad \textit{Ans.}$$

**NOTE:** As discussed in the limitations for the shear formula, the calculations performed here are valid since the shear stress along the diameter is vertical and therefore tangent to the boundary of the cross section. An element of material on the diameter is subjected to "pure shear" as shown in Fig. 7–9*b*.




(b)

Fig. 7–9

7

## EXAMPLE 7.2

Determine the distribution of the shear stress over the cross section of the beam shown in Fig. 7–10*a*.




(a) (b)

### SOLUTION

The distribution can be determined by finding the shear stress at an *arbitrary height* $y$ from the neutral axis, Fig. 7–10*b*, and then plotting this function. Here, the dark colored area $A'$ will be used for $Q$.* Hence


$$Q = \bar{y}'A' = \left[y + \frac{1}{2}\left(\frac{h}{2} - y\right)\right]\left(\frac{h}{2} - y\right)b = \frac{1}{2}\left(\frac{h^2}{4} - y^2\right)b$$

Applying the shear formula, we have

$$\tau = \frac{VQ}{It} = \frac{V\left(\frac{1}{2}\right)[(h^2/4) - y^2]b}{\left(\frac{1}{12}bh^3\right)b} = \frac{6V}{bh^3}\left(\frac{h^2}{4} - y^2\right) \qquad (1)$$

This result indicates that the shear-stress distribution over the cross section is ***parabolic***. As shown in Fig. 7–10*c*, the intensity varies from zero at the top and bottom, $y = \pm h/2$, to a maximum value at the neutral axis, $y = 0$. Specifically, since the area of the cross section is $A = bh$, then at $y = 0$ we have

$$\tau_{max} = 1.5\frac{V}{A} \qquad (2)$$





Shear–stress distribution

(c)

Fig. 7–10

*The area below $y$ can also be used [$A' = b(h/2 + y)$], but doing so involves a bit more algebraic manipulation.




(d)

**Fig. 7–10 (cont.)**



Typical shear failure of this wooden beam occurred at the support and through the approximate center of its cross section.

This same value for $\tau_{max}$ can be obtained directly from the shear formula, $\tau = VQ/It$, by realizing that $\tau_{max}$ occurs where $Q$ is *largest*, since $V$, $I$, and $t$ are *constant*. By inspection, $Q$ will be a maximum when the entire area above (or below) the neutral axis is considered; that is, $A' = bh/2$ and $\bar{y}' = h/4$. Thus,

$$\tau_{max} = \frac{VQ}{It} = \frac{V(h/4)(bh/2)}{\left[\frac{1}{12}bh^3\right]b} = 1.5\frac{V}{A}$$

By comparison, $\tau_{max}$ is 50% greater than the *average* shear stress determined from Eq. 1–7; that is, $\tau_{avg} = V/A$.


It is important to realize that $\tau_{max}$ also acts in the longitudinal direction of the beam, Fig. 7–10*d*. It is this stress that can cause a timber beam to fail as shown Fig. 7–10*e*. Here horizontal splitting of the wood starts to occur through the neutral axis at the beam's ends, since there the vertical reactions subject the beam to large shear stress and wood has a low resistance to shear along its grains, which are oriented in the longitudinal direction.

It is instructive to show that when the shear-stress distribution, Eq. 1, is integrated over the cross section it yields the resultant shear $V$. To do this, a differential strip of area $dA = b\,dy$ is chosen, Fig. 7–10*c*, and since $\tau$ acts uniformly over this strip, we have

$$\int_A \tau\,dA = \int_{-h/2}^{h/2} \frac{6V}{bh^3}\left(\frac{h^2}{4} - y^2\right)b\,dy$$

$$= \frac{6V}{h^3}\left[\frac{h^2}{4}y - \frac{1}{3}y^3\right]_{-h/2}^{h/2}$$


$$= \frac{6V}{h^3}\left[\frac{h^2}{4}\left(\frac{h}{2} + \frac{h}{2}\right) - \frac{1}{3}\left(\frac{h^3}{8} + \frac{h^3}{8}\right)\right] = V$$





(e)

## EXAMPLE 7.3

A steel wide-flange beam has the dimensions shown in Fig. 7–11*a*. If it is subjected to a shear of $V = 80$ kN, plot the shear-stress distribution acting over the beam's cross-sectional area.




(a)




(b)

### SOLUTION

Since the flange and web are rectangular elements, then like the previous example, the shear-stress distribution will be parabolic and in this case it will vary in the manner shown in Fig. 7–11*b*. Due to symmetry, only the shear stresses at points $B'$, $B$, and $C$ have to be determined. To show how these values are obtained, we must first determine the moment of inertia of the cross-sectional area about the neutral axis. Working in meters, we have

$$I = \left[\frac{1}{12}(0.015\text{ m})(0.200\text{ m})^3\right] + 2\left[\frac{1}{12}(0.300\text{ m})(0.02\text{ m})^3 + (0.300\text{ m})(0.02\text{ m})(0.110\text{ m})^2\right]$$
$$= 155.6(10^{-6})\text{ m}^4$$

For point $B'$, $t_{B'} = 0.300$ m, and $A'$ is the dark shaded area shown in Fig. 7–11*c*. Thus,

$$Q_{B'} = \bar{y}'A' = [0.110\text{ m}](0.300\text{ m})(0.02\text{ m}) = 0.660(10^{-3})\text{ m}^3$$


so that

$$\tau_{B'} = \frac{VQ_{B'}}{It_{B'}} = \frac{80(10^3)\text{ N}(0.660(10^{-3})\text{ m}^3)}{155.6(10^{-6})\text{ m}^4(0.300\text{ m})} = 1.13\text{ MPa}$$

For point $B$, $t_B = 0.015$ m and $Q_B = Q_{B'}$, Fig. 7–11*c*. Hence


$$\tau_B = \frac{VQ_B}{It_B} = \frac{80(10^3)\text{ N}(0.660(10^{-3})\text{ m}^3)}{155.6(10^{-6})\text{ m}^4(0.015\text{ m})} = 22.6\text{ MPa}$$

Note from the discussion of "Limitations on the Use of the Shear Formula" that the calculated value for both $\tau_{B'}$ and $\tau_B$ will actually be very misleading. Why?




(c)

Fig. 7–11




(d)

**Fig. 7–11 (cont.)**

For point $C$, $t_C = 0.015$ m and $A'$ is the dark shaded area shown in Fig. 7–11*d*. Considering this area to be composed of two rectangles, we have


$$\begin{aligned} Q_C &= \Sigma \bar{y}' A' = [0.110 \text{ m}](0.300 \text{ m})(0.02 \text{ m}) \\ &\quad + [0.05 \text{ m}](0.015 \text{ m})(0.100 \text{ m}) \\ &= 0.735(10^{-3}) \text{ m}^3 \end{aligned}$$


Thus,


$$\tau_C = \tau_{\max} = \frac{VQ_C}{It_C} = \frac{80(10^3) \text{ N}[0.735(10^{-3}) \text{ m}^3]}{155.6(10^{-6}) \text{ m}^4(0.015 \text{ m})} = 25.2 \text{ MPa}$$

**NOTE:** From Fig. 7–11*b*, note that most of the shear stress occurs in the web and is almost uniform throughout its depth, varying from 22.6 MPa to 25.2 MPa. It is for this reason that for design, some codes permit the use of calculating the average shear stress on the cross section of the web rather than using the shear formula. This will be discussed further in Chapter 11.

## EXAMPLE 7.4








Fig. 7–12

The beam shown in Fig. 7–12*a* is made from two boards. Determine the maximum shear stress in the glue necessary to hold the boards together along the seam where they are joined.

### SOLUTION

**Internal Shear.** The support reactions and the shear diagram for the beam are shown in Fig. 7–12*b*. It is seen that the maximum shear in the beam is 19.5 kN.

**Section Properties.** The centroid and therefore the neutral axis will be determined from the reference axis placed at the bottom of the cross-sectional area, Fig. 7–12*a*. Working in units of meters, we have

$$\bar{y} = \frac{\Sigma \bar{y} A}{\Sigma A} = \frac{[0.075\text{ m}](0.150\text{ m})(0.030\text{ m}) + [0.165\text{ m}](0.030\text{ m})(0.150\text{ m})}{(0.150\text{ m})(0.030\text{ m}) + (0.030\text{ m})(0.150\text{ m})} = 0.120\text{ m}$$

The moment of inertia, about the neutral axis, Fig. 7–12*a*, is therefore

$$I = \left[\frac{1}{12}(0.030\text{ m})(0.150\text{ m})^3 + (0.150\text{ m})(0.030\text{ m})(0.120\text{ m} - 0.075\text{ m})^2\right] + \left[\frac{1}{12}(0.150\text{ m})(0.030\text{ m})^3 + (0.030\text{ m})(0.150\text{ m})(0.165\text{ m} - 0.120\text{ m})^2\right]$$

$$= 27.0(10^{-6})\text{ m}^4$$

The top board (flange) is being held onto the bottom board (web) by the glue, which is applied over the thickness $t = 0.03$ m. Consequently $A'$ is defined as the area of the top board, Fig. 7–12*a*. We have

$$Q = \bar{y}' A' = [0.180\text{ m} - 0.015\text{ m} - 0.120\text{ m}](0.03\text{ m})(0.150\text{ m}) = 0.2025(10^{-3})\text{ m}^3$$

**Shear Stress.** Using the above data and applying the shear formula yields


$$\tau_{max} = \frac{VQ}{It} = \frac{19.5(10^3)\text{ N}(0.2025(10^{-3})\text{ m}^3)}{27.0(10^{-6})\text{ m}^4(0.030\text{ m})} = 4.88\text{ MPa} \quad \textit{Ans.}$$

The shear stress acting at the top of the bottom board is shown in Fig. 7–12*c*.

**NOTE:** It is the glue's resistance to this longitudinal *shear* stress that holds the boards from slipping at the right-hand support.


## FUNDAMENTAL PROBLEMS

**F7–1.** If the beam is subjected to a shear force of $V = 100$ kN, determine the shear stress developed at point $A$. Represent the state of stress at $A$ on a volume element.





F7–1

**F7–2.** Determine the shear stress at points $A$ and $B$ on the beam if it is subjected to a shear force of $V = 600$ kN.





F7–2

**F7–3.** Determine the absolute maximum shear stress developed in the beam.





F7–3

**F7–4.** If the beam is subjected to a shear force of $V = 20$ kN, determine the maximum shear stress developed in the beam.




F7–4

**F7–5.** If the beam is made from four plates and subjected to a shear force of $V = 20$ kN, determine the maximum shear stress developed in the beam.




F7–5

## PROBLEMS

•7–1. If the wide-flange beam is subjected to a shear of $V = 20$ kN, determine the shear stress on the web at $A$. Indicate the shear-stress components on a volume element located at this point.

7–2. If the wide-flange beam is subjected to a shear of $V = 20$ kN, determine the maximum shear stress in the beam.


7–3. If the wide-flange beam is subjected to a shear of $V = 20$ kN, determine the shear force resisted by the web of the beam.




Probs. 7–1/2/3


*7–4. If the T-beam is subjected to a vertical shear of $V = 12$ kip, determine the maximum shear stress in the beam. Also, compute the shear-stress jump at the flange-web junction $AB$. Sketch the variation of the shear-stress intensity over the entire cross section.

•7–5. If the T-beam is subjected to a vertical shear of $V = 12$ kip, determine the vertical shear force resisted by the flange.




Probs. 7–4/5


7–6. If the beam is subjected to a shear of $V = 15$ kN, determine the web's shear stress at $A$ and $B$. Indicate the shear-stress components on a volume element located at these points. Show that the neutral axis is located at $\bar{y} = 0.1747$ m from the bottom and $I_{N.A} = 0.2182(10^{-3})$ m$^4$.




Prob. 7–6

7–7. If the wide-flange beam is subjected to a shear of $V = 30$ kN, determine the maximum shear stress in the beam.


*7–8. If the wide-flange beam is subjected to a shear of $V = 30$ kN, determine the shear force resisted by the web of the beam.




Probs. 7–7/8


•**7–9.** Determine the largest shear force $V$ that the member can sustain if the allowable shear stress is $\tau_{allow} = 8$ ksi.

**7–10.** If the applied shear force $V = 18$ kip, determine the maximum shear stress in the member.





**Probs. 7–9/10**

**7–11.** The wood beam has an allowable shear stress of $\tau_{allow} = 7$ MPa. Determine the maximum shear force $V$ that can be applied to the cross section.




**Prob. 7–11**


*7–12. The beam has a rectangular cross section and is made of wood having an allowable shear stress of $\tau_{allow} = 200$ psi. Determine the maximum shear force $V$ that can be developed in the cross section of the beam. Also, plot the shear-stress variation over the cross section.




**Prob. 7–12**


**7–13.** Determine the maximum shear stress in the strut if it is subjected to a shear force of $V = 20$ kN.

**7–14.** Determine the maximum shear force $V$ that the strut can support if the allowable shear stress for the material is $\tau_{allow} = 40$ MPa.





**Probs. 7–13/14**

**7–15.** Plot the shear-stress distribution over the cross section of a rod that has a radius $c$. By what factor is the maximum shear stress greater than the average shear stress acting over the cross section?




**Prob. 7–15**

*7–16. A member has a cross section in the form of an equilateral triangle. If it is subjected to a shear force **V**, determine the maximum average shear stress in the member using the shear formula. Should the shear formula actually be used to predict this value? Explain.





**Prob. 7–16**

•**7–17.** Determine the maximum shear stress in the strut if it is subjected to a shear force of $V = 600$ kN.

**7–18.** Determine the maximum shear force $V$ that the strut can support if the allowable shear stress for the material is $\tau_{allow} = 45$ MPa.

**7–19.** Plot the intensity of the shear stress distributed over the cross section of the strut if it is subjected to a shear force of $V = 600$ kN.





**Probs. 7–17/18/19**

*7

*•7–20.** The steel rod is subjected to a shear of 30 kip. Determine the maximum shear stress in the rod.


•**7–21.** The steel rod is subjected to a shear of 30 kip. Determine the shear stress at point $A$. Show the result on a volume element at this point.




**Probs. 7–20/21**

**7–22.** Determine the shear stress at point $B$ on the web of the cantilevered strut at section $a$–$a$.


**7–23.** Determine the maximum shear stress acting at section $a$–$a$ of the cantilevered strut.




**Probs. 7–22/23**


*•7–24.** Determine the maximum shear stress in the T-beam at the critical section where the internal shear force is maximum.

•**7–25.** Determine the maximum shear stress in the T-beam at point $C$. Show the result on a volume element at this point.




**Probs. 7–24/25**


**7–26.** Determine the maximum shear stress acting in the fiberglass beam at the section where the internal shear force is maximum.




**Prob. 7–26**


**7–27.** Determine the shear stress at points $C$ and $D$ located on the web of the beam.

***7–28.** Determine the maximum shear stress acting in the beam at the critical section where the internal shear force is maximum.





**Probs. 7–27/28**

**7–29.** Write a computer program that can be used to determine the maximum shear stress in the beam that has the cross section shown, and is subjected to a specified constant distributed load $w$ and concentrated force $P$. Show an application of the program using the values $L = 4$ m, $a = 2$ m, $P = 1.5$ kN, $d_1 = 0$, $d_2 = 2$ m, $w = 400$ N/m, $t_1 = 15$ mm, $t_2 = 20$ mm, $b = 50$ mm, and $h = 150$ mm.




**Prob. 7–29**

**7–30.** The beam has a rectangular cross section and is subjected to a load $P$ that is just large enough to develop a fully plastic moment $M_p = PL$ at the fixed support. If the material is elastic-plastic, then at a distance $x < L$ the moment $M = Px$ creates a region of plastic yielding with an associated elastic core having a height $2y'$. This situation has been described by Eq. 6–30 and the moment **M** is distributed over the cross section as shown in Fig. 6–48*e*. Prove that the maximum shear stress developed in the beam is given by $\tau_{max} = \frac{3}{2}(P/A')$, where $A' = 2y'b$, the cross-sectional area of the elastic core.




**Prob. 7–30**

**7–31.** The beam in Fig. 6–48*f* is subjected to a fully plastic moment $\mathbf{M}_p$. Prove that the longitudinal and transverse shear stresses in the beam are zero. *Hint:* Consider an element of the beam as shown in Fig. 7–4*c*.



Fig. 7–13

## 7.3 Shear Flow in Built-Up Members

Occasionally in engineering practice, members are "built up" from several composite parts in order to achieve a greater resistance to loads. Examples are shown in Fig. 7–13. If the loads cause the members to bend, fasteners such as nails, bolts, welding material, or glue may be needed to keep the component parts from sliding relative to one another, Fig. 7–2. In order to design these fasteners or determine their spacing, it is necessary to know the shear force that must be resisted by the fastener. This loading, when measured as a force per unit length of beam, is referred to as ***shear flow q***.*

The magnitude of the shear flow can be obtained using a development similar to that for finding the shear stress in the beam. To show this, we will consider finding the shear flow along the juncture where the segment in Fig. 7–14*a* is connected to the flange of the beam. As shown in Fig. 7–14*b*, three horizontal forces must act on this segment. Two of these forces, $F$ and $F + dF$, are developed by normal stresses caused by the moments $M$ and $M + dM$, respectively. The third force, which for equilibrium equals $dF$, acts at the juncture and it is to be supported by the fastener. Realizing that $dF$ is the result of $dM$, then, like Eq. 7–1, we have

$$dF = \frac{dM}{I}\int_{A'} y\, dA'$$


The integral represents $Q$, that is, the moment of the segment's area $A'$ in Fig. 7–14*b* about the neutral axis for the entire cross section. Since the segment has a length $dx$, the shear flow, or force per unit length along the beam, is $q = dF/dx$. Hence dividing both sides by $dx$ and noting that $V = dM/dx$, Eq. 6–2, we can write

$$q = \frac{VQ}{I} \tag{7–4}$$

Here

- $q$ = the shear flow, measured as a force per unit length along the beam
- $V$ = the internal resultant shear force, determined from the method of sections and the equations of equilibrium
- $I$ = the moment of inertia of the *entire* cross-sectional area computed about the neutral axis
- $Q = \overline{y}'A'$, where $A'$ is the cross-sectional area of the segment that is connected to the beam at the juncture where the shear flow is to be calculated, and $\overline{y}'$ is the distance from the neutral axis to the centroid of $A'$

*The use of the word "flow" in this terminology will become meaningful as it pertains to the discussion in Sec. 7.5.




(a)

Fig. 7–14



Application of this equation follows the same "procedure for analysis" as outlined in Sec. 7.2 for the shear formula. It is very important to identify $Q$ correctly when determining the shear flow at a particular junction on the cross section. A few examples should serve to illustrate how this is done. Consider the beam cross sections shown in Fig. 7–15. The shaded segments are connected to the beam by fasteners and at the planes of connection, identified by the thick black lines, the shear flow $q$ is determined by using a value of $Q$ calculated from $A'$ and $\bar{y}'$ indicated in each figure. This value of $q$ will be resisted by a *single* fastener in Fig. 7–15*a*, by *two* fasteners in Fig. 7–15*b*, and by *three* fasteners in Fig. 7–15*c*. In other words, the fastener in Fig. 7–15*a* supports the calculated value of $q$, and in Figs. 7–15*b* and 7–15*c* each fastener supports $q/2$ and $q/3$, respectively.

7

## Important Point

- *Shear flow* is a measure of the force per unit length along the axis of a beam. This value is found from the shear formula and is used to determine the shear force developed in fasteners and glue that holds the various segments of a composite beam together.





Fig. 7–15

## EXAMPLE 7.5

The beam is constructed from four boards glued together as shown in Fig. 7–16*a*. If it is subjected to a shear of $V = 850$ kN, determine the shear flow at $B$ and $C$ that must be resisted by the glue.

### SOLUTION


**Section Properties.** The neutral axis (centroid) will be located from the bottom of the beam, Fig. 7–16*a*. Working in units of meters, we have

$$\bar{y} = \frac{\Sigma \tilde{y} A}{\Sigma A} = \frac{2[0.15\text{ m}](0.3\text{ m})(0.01\text{ m}) + [0.205\text{ m}](0.125\text{ m})(0.01\text{ m}) + [0.305\text{ m}](0.250\text{ m})(0.01\text{ m})}{2(0.3\text{ m})(0.01\text{ m}) + 0.125\text{ m}(0.01\text{ m}) + 0.250\text{ m}(0.01\text{ m})}$$


$$= 0.1968\text{ m}$$

The moment of inertia about the neutral axis is thus

$$I = 2\left[\frac{1}{12}(0.01\text{ m})(0.3\text{ m})^3 + (0.01\text{ m})(0.3\text{ m})(0.1968\text{ m} - 0.150\text{ m})^2\right]$$
$$+ \left[\frac{1}{12}(0.125\text{ m})(0.01\text{ m})^3 + (0.125\text{ m})(0.01\text{ m})(0.205\text{ m} - 0.1968\text{ m})^2\right]$$
$$+ \left[\frac{1}{12}(0.250\text{ m})(0.01\text{ m})^3 + (0.250\text{ m})(0.01\text{ m})(0.305\text{ m} - 0.1968\text{ m})^2\right]$$
$$= 87.52(10^{-6})\text{ m}^4$$



(a)



(b)

Fig. 7–16

Since the glue at $B$ and $B'$ in Fig. 7–16*b* "holds" the top board to the beam, we have

$$Q_B = \bar{y}'_B A'_B = [0.305\text{ m} - 0.1968\text{ m}](0.250\text{ m})(0.01\text{ m})$$
$$= 0.271(10^{-3})\text{ m}^3$$

Likewise, the glue at $C$ and $C'$ "holds" the inner board to the beam, Fig. 7–16*b*, and so

$$Q_C = \bar{y}'_C A'_C = [0.205\text{ m} - 0.1968\text{ m}](0.125\text{ m})(0.01\text{ m})$$
$$= 0.01026(10^{-3})\text{ m}^3$$

**Shear Flow.** For $B$ and $B'$ we have

$$q'_B = \frac{VQ_B}{I} = \frac{850(10^3)\text{ N}(0.271(10^{-3})\text{ m}^3)}{87.52(10^{-6})\text{ m}^4} = 2.63\text{ MN/m}$$

And for $C$ and $C'$,

$$q'_C = \frac{VQ_C}{I} = \frac{850(10^3)\text{ N}(0.01026(10^{-3})\text{ m}^3)}{87.52(10^{-6})\text{ m}^4} = 0.0996\text{ MN/m}$$

Since *two seams* are used to secure each board, the glue per meter length of beam at each seam must be strong enough to resist *one-half* of each calculated value of $q'$. Thus,

$$q_B = 1.31\text{ MN/m} \quad \text{and} \quad q_C = 0.0498\text{ MN/m} \quad \textit{Ans.}$$

## EXAMPLE 7.6

A box beam is constructed from four boards nailed together as shown in Fig. 7–17*a*. If each nail can support a shear force of 30 lb, determine the maximum spacing $s$ of the nails at $B$ and at $C$ so that the beam will support the force of 80 lb.





### SOLUTION

**Internal Shear.** If the beam is sectioned at an *arbitrary point* along its length, the internal shear required for equilibrium is always $V = 80$ lb, and so the shear diagram is shown in Fig. 7–17*b*.

**Section Properties.** The moment of inertia of the cross-sectional area about the neutral axis can be determined by considering a 7.5-in. × 7.5-in. square minus a 4.5-in. × 4.5-in. square.

$$I = \frac{1}{12}(7.5\text{ in.})(7.5\text{ in.})^3 - \frac{1}{12}(4.5\text{ in.})(4.5\text{ in.})^3 = 229.5\text{ in}^4$$





(a)

The shear flow at $B$ is determined using $Q_B$ found from the darker shaded area shown in Fig. 7–17*c*. It is this "symmetric" portion of the beam that is to be "held" onto the rest of the beam by nails on the left side and by the fibers of the board on the right side. Thus,

$$Q_B = \bar{y}'A' = [3\text{ in.}](7.5\text{ in.})(1.5\text{ in.}) = 33.75\text{ in}^3$$

Likewise, the shear flow at $C$ can be determined using the "symmetric" shaded area shown in Fig. 7–17*d*. We have

$$Q_C = \bar{y}'A' = [3\text{ in.}](4.5\text{ in.})(1.5\text{ in.}) = 20.25\text{ in}^3$$





(b)


**Shear Flow.**

$$q_B = \frac{VQ_B}{I} = \frac{80\text{ lb}(33.75\text{ in}^3)}{229.5\text{ in}^4} = 11.76\text{ lb/in.}$$

$$q_C = \frac{VQ_C}{I} = \frac{80\text{ lb}(20.25\text{ in}^3)}{229.5\text{ in}^4} = 7.059\text{ lb/in.}$$




(c)




(d)

Fig. 7–17

These values represent the shear force per unit length of the beam that must be resisted by the nails at $B$ and the fibers at $B'$, Fig. 7–17*c*, and the nails at $C$ and the fibers at $C'$, Fig. 7–17*d*, respectively. Since in each case the shear flow is resisted at *two* surfaces and each nail can resist 30 lb, for $B$ the spacing is

$$s_B = \frac{30\text{ lb}}{(11.76/2)\text{ lb/in.}} = 5.10\text{ in.} \qquad \text{Use } s_B = 5\text{ in.} \quad \textit{Ans.}$$

And for $C$,

$$s_C = \frac{30\text{ lb}}{(7.059/2)\text{ lb/in.}} = 8.50\text{ in.} \qquad \text{Use } s_C = 8.5\text{ in.} \quad \textit{Ans.}$$

7

## EXAMPLE 7.7

Nails having a total shear strength of 40 lb are used in a beam that can be constructed either as in Case I or as in Case II, Fig. 7–18. If the nails are spaced at 9 in., determine the largest vertical shear that can be supported in each case so that the fasteners will not fail.





Fig. 7–18

### SOLUTION

Since the cross section is the same in both cases, the moment of inertia about the neutral axis is

$$I = \frac{1}{12}(3\text{ in.})(5\text{ in.})^3 - 2\left[\frac{1}{12}(1\text{ in.})(4\text{ in.})^3\right] = 20.58\text{ in}^4$$

**Case I.** For this design a single row of nails holds the top or bottom flange onto the web. For one of these flanges,

$$Q = \bar{y}'A' = [2.25\text{ in.}](3\text{ in.}(0.5\text{ in.})) = 3.375\text{ in}^3$$

so that

$$q = \frac{VQ}{I}$$

$$\frac{40\text{ lb}}{9\text{ in.}} = \frac{V(3.375\text{ in}^3)}{20.58\text{ in}^4}$$

$$V = 27.1\text{ lb} \qquad \textit{Ans.}$$

**Case II.** Here a single row of nails holds one of the side boards onto the web. Thus,

$$Q = \bar{y}'A' = [2.25\text{ in.}](1\text{ in.}(0.5\text{ in.})) = 1.125\text{ in}^3$$

$$q = \frac{VQ}{I}$$


$$\frac{40\text{ lb}}{9\text{ in.}} = \frac{V(1.125\text{ in}^3)}{20.58\text{ in}^4}$$

$$V = 81.3\text{ lb} \qquad \textit{Ans.}$$

## FUNDAMENTAL PROBLEMS


**F7–6.** The two identical boards are bolted together to form the beam. Determine the maximum allowable spacing $s$ of the bolts to the nearest mm if each bolt has a shear strength of 15 kN. The beam is subjected to a shear force of $V = 50$ kN.

**F7–7.** The two identical boards are bolted together to form the beam. If the spacing of the bolts is $s = 100$ mm and each bolt has a shear strength of 15 kN, determine the maximum shear force **V** the beam can resist.





F7–6/7

**F7–8.** Two identical 20-mm thick plates are bolted to the top and bottom flange to form the built-up beam. If the beam is subjected to a shear force of $V = 300$ kN, determine the allowable maximum spacing $s$ of the bolts to the nearest mm. Each bolt has a shear strength of 30 kN.





F7–8

**F7–9.** The boards are bolted together to form the built-up beam. If the beam is subjected to a shear force of $V = 20$ kN, determine the allowable maximum spacing of the bolts to the nearest mm. Each bolt has a shear strength of 8 kN.




F7–9

**F7–10.** The boards are bolted together to form the built-up beam. If the beam is subjected to a shear force of $V = 15$ kip, determine the allowable maximum spacing of the bolts to the nearest $\frac{1}{8}$ in. Each bolt has a shear strength of 6 kip.





F7–10

7

## PROBLEMS

***7–32.** The beam is constructed from two boards fastened together at the top and bottom with two rows of nails spaced every 6 in. If each nail can support a 500-lb shear force, determine the maximum shear force $V$ that can be applied to the beam.


**•7–33.** The beam is constructed from two boards fastened together at the top and bottom with two rows of nails spaced every 6 in. If an internal shear force of $V = 600$ lb is applied to the boards, determine the shear force resisted by each nail.




Probs. 7–32/33

**7–34.** The beam is constructed from two boards fastened together with three rows of nails spaced $s = 2$ in. apart. If each nail can support a 450-lb shear force, determine the maximum shear force $V$ that can be applied to the beam. The allowable shear stress for the wood is $\tau_{allow} = 300$ psi.


**7–35.** The beam is constructed from two boards fastened together with three rows of nails. If the allowable shear stress for the wood is $\tau_{allow} = 150$ psi, determine the maximum shear force $V$ that can be applied to the beam. Also, find the maximum spacing $s$ of the nails if each nail can resist 650 lb in shear.




Probs. 7–34/35


***7–36.** The beam is fabricated from two equivalent structural tees and two plates. Each plate has a height of 6 in. and a thickness of 0.5 in. If a shear of $V = 50$ kip is applied to the cross section, determine the maximum spacing of the bolts. Each bolt can resist a shear force of 15 kip.

**•7–37.** The beam is fabricated from two equivalent structural tees and two plates. Each plate has a height of 6 in. and a thickness of 0.5 in. If the bolts are spaced at $s = 8$ in., determine the maximum shear force $V$ that can be applied to the cross section. Each bolt can resist a shear force of 15 kip.





Probs. 7–36/37

**7–38.** The beam is subjected to a shear of $V = 2$ kN. Determine the average shear stress developed in each nail if the nails are spaced 75 mm apart on each side of the beam. Each nail has a diameter of 4 mm.




Prob. 7–38


**7–39.** A beam is constructed from three boards bolted together as shown. Determine the shear force developed in each bolt if the bolts are spaced $s = 250$ mm apart and the applied shear is $V = 35$ kN.




Prob. 7–39


*7–40. The double-web girder is constructed from two plywood sheets that are secured to wood members at its top and bottom. If each fastener can support 600 lb in single shear, determine the required spacing $s$ of the fasteners needed to support the loading $P = 3000$ lb. Assume $A$ is pinned and $B$ is a roller.

•7–41. The double-web girder is constructed from two plywood sheets that are secured to wood members at its top and bottom. The allowable bending stress for the wood is $\sigma_{allow} = 8$ ksi and the allowable shear stress is $\tau_{allow} = 3$ ksi. If the fasteners are spaced $s = 6$ in. and each fastener can support 600 lb in single shear, determine the maximum load $P$ that can be applied to the beam.




Probs. 7–40/41


**7–42.** The T-beam is nailed together as shown. If the nails can each support a shear force of 950 lb, determine the maximum shear force $V$ that the beam can support and the corresponding maximum nail spacing $s$ to the nearest $\frac{1}{8}$ in. The allowable shear stress for the wood is $\tau_{allow} = 450$ psi.




Prob. 7–42


**7–43.** Determine the average shear stress developed in the nails within region $AB$ of the beam. The nails are located on each side of the beam and are spaced 100 mm apart. Each nail has a diameter of 4 mm. Take $P = 2$ kN.

*7–44. The nails are on both sides of the beam and each can resist a shear of 2 kN. In addition to the distributed loading, determine the maximum load $P$ that can be applied to the end of the beam. The nails are spaced 100 mm apart and the allowable shear stress for the wood is $\tau_{allow} = 3$ MPa.





Probs. 7–43/44

•7–45. The beam is constructed from four boards which are nailed together. If the nails are on both sides of the beam and each can resist a shear of 3 kN, determine the maximum load $P$ that can be applied to the end of the beam.





Prob. 7–45

7–46. A built-up timber beam is made from the four boards, each having a rectangular cross section. Write a computer program that can be used to determine the maximum shear stress in the beam when it is subjected to the shear $V$. Show an application of the program for a specific set of dimensions.





Prob. 7–46

7–47. The beam is made from four boards nailed together as shown. If the nails can each support a shear force of 100 lb., determine their required spacing $s'$ and $s$ if the beam is subjected to a shear of $V = 700$ lb.





Prob. 7–47

*7–48. The box beam is constructed from four boards that are fastened together using nails spaced along the beam every 2 in. If each nail can resist a shear of 50 lb, determine the greatest shear $V$ that can be applied to the beam without causing failure of the nails.




Prob. 7–48

7–49. The timber T-beam is subjected to a load consisting of $n$ concentrated forces, $P_n$. If the allowable shear $V_{nail}$ for each of the nails is known, write a computer program that will specify the nail spacing between each load. Show an application of the program using the values $L = 15$ ft, $a_1 = 4$ ft, $P_1 = 600$ lb, $a_2 = 8$ ft, $P_2 = 1500$ lb, $b_1 = 1.5$ in., $h_1 = 10$ in., $b_2 = 8$ in., $h_2 = 1$ in., and $V_{nail} = 200$ lb.





Prob. 7–49

## 7.4 Shear Flow in Thin-Walled Members


In this section we will show how to apply the shear flow equation $q = VQ/I$ to find the shear-flow *distribution* throughout a member's cross-sectional area. We will assume that the member has *thin walls*, that is, the wall thickness is small compared to its height or width. As will be shown in the next section, this analysis has important applications in structural and mechanical design.

Like the shear stress, the shear flow acts on both the longitudinal *and* transverse planes of the member. To show how to establish its direction on the cross section, consider the segment $dx$ of the wide-flange beam in Fig. 7–19*a*. Free-body diagrams of two segments $B$ and $C$ taken from the top flange are shown in Figs. 7–19*b* and 7–19*c*. The force $dF$ must act on the longitudinal section in order to balance the normal forces $F$ and $F + dF$ created by the moments $M$ and $M + dM$, respectively. Now, if the corner elements $B$ and $C$ of each segment are removed, then the transverse components $q$ act on the cross section as shown in Figs. 7–19*b* and 7–19*c*. Using this method, show that the shear flow at the corresponding points $B'$ and $C'$ on the bottom flange in Fig. 7–19*d* is directed as shown.


Although it is also true that $V + dV$ will create *vertical* shear-flow components on this element, here we will neglect its effects. This is because this component, like the shear stress, is approximately zero throughout the thickness of the element. Here, the flange is thin and the top and bottom surfaces of the element are free of stress, Fig. 7–19*e*. To summarize then, only the shear flow component that acts *parallel* to the sides of the flange will be considered.





(a)




(b)




(c)




(d)




(e)

**Fig. 7–19**





Fig. 7–20

Having determined the direction of the shear flow in each flange, we can now find its distribution along the top right flange of the beam in Fig. 7–20*a*. To do this, consider the shear flow $q$, acting on the colored element $dx$, located an arbitrary distance $x$ from the centerline of the cross section, Fig. 7–20*b*. Here $Q = \bar{y}'A' = [d/2](b/2 - x)t$, so that

$$q = \frac{VQ}{I} = \frac{V[d/2](b/2 - x)t}{I} = \frac{Vtd}{2I}\left(\frac{b}{2} - x\right) \tag{7–5}$$

By inspection, this distribution varies in a *linear* manner from $q = 0$ at $x = b/2$ to $(q_{\max})_f = Vtdb/4I$ at $x = 0$. (The limitation of $x = 0$ is possible here since the member is assumed to have "thin walls" and so the thickness of the web is neglected.) Due to symmetry, a similar analysis yields the same distribution of shear flow for the other flange segments, so that the results are as shown in Fig. 7–20*d*.


The total force developed in each flange segment can be determined by integration. Since the force on the element $dx$ in Fig. 7–20*b* is $dF = q\,dx$, then

$$F_f = \int q\,dx = \int_0^{b/2} \frac{Vtd}{2I}\left(\frac{b}{2} - x\right)dx = \frac{Vtdb^2}{16I}$$

We can also determine this result by finding the area under the triangle in Fig. 7–20*d*. Hence,


$$F_f = \frac{1}{2}(q_{\max})_f\left(\frac{b}{2}\right) = \frac{Vtdb^2}{16I}$$

All four of these forces are shown in Fig. 7–20*e*, and we can see from their direction that horizontal force equilibrium of the cross section is maintained.




Shear-flow distribution

(d)




(e)

**Fig. 7–20 (cont.)**

A similar analysis can be performed for the web, Fig. 7–20c. Here $q$ must act downward, and at element $dy$ we have $Q = \Sigma \bar{y}' A' = [d/2](bt) + [y + (1/2)(d/2 - y)]t(d/2 - y) = bt\,d/2 + (t/2)(d^2/4 - y^2)$, so that

$$q = \frac{VQ}{I} = \frac{Vt}{I}\left[\frac{db}{2} + \frac{1}{2}\left(\frac{d^2}{4} - y^2\right)\right] \tag{7–6}$$

For the web, the shear flow varies in a *parabolic manner*, from $q = 2(q_{max})_f = Vtdb/2I$ at $y = d/2$ to $(q_{max})_w = (Vtd/I)(b/2 + d/8)$ at $y = 0$, Fig. 7–20d.

Integrating to determine the force in the web, $F_w$, we have,

$$\begin{aligned} F_w &= \int q\,dy = \int_{-d/2}^{d/2} \frac{Vt}{I}\left[\frac{db}{2} + \frac{1}{2}\left(\frac{d^2}{4} - y^2\right)\right] dy \\ &= \frac{Vt}{I}\left[\frac{db}{2}y + \frac{1}{2}\left(\frac{d^2}{4}y - \frac{1}{3}y^3\right)\right]\Bigg|_{-d/2}^{d/2} \\ &= \frac{Vtd^2}{4I}\left(2b + \frac{1}{3}d\right) \end{aligned}$$

Simplification is possible by noting that the moment of inertia for the cross-sectional area is

$$I = 2\left[\frac{1}{12}bt^3 + bt\left(\frac{d}{2}\right)^2\right] + \frac{1}{12}td^3$$


Neglecting the first term, since the thickness of each flange is small, then

$$I = \frac{td^2}{4}\left(2b + \frac{1}{3}d\right)$$

Substituting this into the above equation, we see that $F_w = V$, which is to be expected, Fig. 7–20e.

7

From the foregoing analysis, three important points should be observed. First, the value of $q$ changes over the cross section, since $Q$ will be different for each area segment $A'$ for which it is determined. In particular, $q$ will vary *linearly* along segments (flanges) that are *perpendicular* to the direction of **V**, and *parabolically* along segments (web) that are *inclined or parallel* to **V**. Second, $q$ will *always act parallel to the walls* of the member, since the section on which $q$ is calculated is taken perpendicular to the walls. And third, the *directional sense* of $q$ is such that the shear appears to "*flow*" through the cross section, *inward* at the beam's top flange, "combining" and then "flowing" *downward* through the web, since it must contribute to the shear force **V**, and then separating and "flowing" *outward* at the bottom flange. If one is able to "visualize" this "flow" it will provide an easy means for establishing not only the direction of $q$, but *also* the corresponding direction of $\tau$. Other examples of how $q$ is directed along the segments of thin-walled members are shown in Fig. 7–21. In all cases, symmetry prevails about an axis that is collinear with **V**. As a result, $q$ "flows" in a direction such that it will provide the vertical force **V** and yet also satisfy horizontal force equilibrium for the cross section.




Shear flow $q$


Fig. 7–21

## Important Points

- The shear flow formula $q = VQ/I$ can be used to determine the distribution of the shear flow throughout a thin-walled member provided the shear **V** acts along an axis of symmetry or principal centroidal axis of inertia for the cross section.
- If a member is made from segments having thin walls, only the shear flow *parallel* to the walls of the member is important.
- The shear flow varies *linearly* along segments that are *perpendicular* to the direction of the shear **V**.
- The shear flow varies *parabolically* along segments that are *inclined* or *parallel* to the direction of the shear **V**.
- On the cross section, the shear "flows" along the segments so that it results in the vertical shear force **V** and yet satisfies horizontal force equilibrium.

## EXAMPLE 7.8

The thin-walled box beam in Fig. 7–22*a* is subjected to a shear of 10 kip. Determine the variation of the shear flow throughout the cross section.



(a)


### SOLUTION

By symmetry, the neutral axis passes through the center of the cross section. For thin-walled members we use centerline dimensions for calculating the moment of inertia.

$$I = \frac{1}{12}(2\text{ in.})(7\text{ in.})^3 + 2\left[(5\text{ in.})(1\text{ in.})(3.5\text{ in.})^2\right] = 179.7\text{ in.}^4$$

Only the shear flow at points $B$, $C$, and $D$ has to be determined. For point $B$, the area $A' \approx 0$, Fig. 7–22*b*, since it can be thought of as being located entirely at point $B$. Alternatively, $A'$ can also represent the *entire* cross-sectional area, in which case $Q_B = \bar{y}'A' = 0$ since $\bar{y}' = 0$. Because $Q_B = 0$, then


$$q_B = 0$$



(b)

For point $C$, the area $A'$ is shown dark shaded in Fig. 7–22*c*. Here, we have used the mean dimensions since point $C$ is on the centerline of each segment. We have

$$Q_C = \bar{y}'A' = (3.5\text{ in.})(5\text{ in.})(1\text{ in.}) = 17.5\text{ in}^3$$




(c)

Since there are two points of attachment,

$$q_C = \frac{1}{2}\left(\frac{VQ_C}{I}\right) = \frac{1}{2}\left(\frac{10\text{ kip}(17.5\text{ in}^3)}{179.7\text{ in}^4}\right) = 0.487\text{ kip/in.}$$

The shear flow at $D$ is determined using the three dark-shaded rectangles shown in Fig. 7–22*d*. Again, using centerline dimensions

$$Q_D = \Sigma\bar{y}'A' = 2\left[\frac{3.5\text{ in.}}{2}\right](1\text{ in.})(3.5\text{ in.}) + [3.5\text{ in.}](5\text{ in.})(1\text{ in.}) = 29.75\text{ in}^3$$




(d)

Because there are two points of attachment,

$$q_D = \frac{1}{2}\left(\frac{VQ_D}{I}\right) = \frac{1}{2}\left(\frac{10\text{ kip}(29.75\text{ in}^3)}{179.7\text{ in}^4}\right) = 0.828\text{ kip/in.}$$

Using these results, and the symmetry of the cross section, the shear-flow distribution is plotted in Fig. 7–22*e*. The distribution is linear along the horizontal segments (perpendicular to **V**) and parabolic along the vertical segments (parallel to **V**).




(e)


Fig. 7–22

## *7.5 Shear Center for Open Thin-Walled Members

In the previous section, it was assumed that the internal shear **V** was applied along a principal centroidal axis of inertia that *also* represents an *axis of symmetry* for the cross section. In this section we will consider the effect of applying the shear along a principal centroidal axis that is *not* an axis of symmetry. As before, only open thin-walled members will be analyzed, so the dimensions to the centerline of the walls of the members will be used. A typical example of this case is the channel section shown in Fig. 7–23*a*. Here it is cantilevered from a fixed support and is subjected to the force **P**. If this force is applied along the once vertical, unsymmetrical axis that passes through the *centroid C* of the cross section, the channel will not only bend downward, *it will also twist* clockwise as shown.





(a)




Shear-flow distribution


(b)




(c)




(d)




(e)

Fig. 7–23

To understand why the member twists, it is necessary to show the shear-flow distribution along the channel's flanges and web, Fig. 7–23*b*. When this distribution is integrated over the flange and web areas, it will give resultant forces of $F_f$ in each flange and a force of $V = P$ in the web, Fig. 7–23*c*. If the moments of these forces are summed about point $A$, it can be seen that the couple or torque created by the flange forces is responsible for twisting the member. The actual twist is clockwise when viewed from the front of the beam as shown in Fig. 7–23*a*, since *reactive* internal "equilibrium" forces $F_f$ cause the twisting. In order to *prevent* this twisting it is therefore necessary to apply **P** at a point $O$ located an eccentric distance $e$ from the web of the channel, Fig. 7–23*d*. We require $\Sigma M_A = F_f d = Pe$, or

$$e = \frac{F_f d}{P}$$

Using the method discussed in the previous section, $F_f$ can be evaluated in terms of $P\ (= V)$ and the dimensions of the flanges and web. Once this is done, then $P$ will cancel upon substitution into the above equation, and it becomes possible to express $e$ simply as a function of the cross-sectional geometry (see Example 7.9). The point $O$ so located is called the ***shear center*** or ***flexural center***. When **P** is applied at the shear center, the ***beam will bend without twisting*** as shown in Fig. 7–23*e*. Design handbooks often list the location of this point for a variety of beams having thin-walled cross sections that are commonly used in practice.

From this analysis, it should be noted that ***the shear center will always lie on an axis of symmetry*** of a member's cross-sectional area. For example, if the channel is rotated 90° and **P** is applied at $A$, Fig. 7–24*a*, no twisting will occur since the shear flow in the web and flanges for this case is *symmetrical*, and therefore the force resultants in these elements will create zero moments about $A$, Fig. 7–24*b*. Obviously, if a member has a cross section with *two* axes of symmetry, as in the case of a wide-flange beam, the shear center will then coincide with the intersection of these axes (the centroid).



Demonstration of how a cantilever beam deflects when loaded through the centroid (above) and through the shear center (below).







Fig. 7–24

## Important Points

- The *shear center* is the point through which a force can be applied which will cause a beam to bend and yet not twist.
- The shear center will always lie on an axis of symmetry of the cross section.
- The location of the shear center is only a function of the geometry of the cross section, and does not depend upon the applied loading.

## Procedure for Analysis

The location of the shear center for an open thin-walled member for which the internal shear is in the *same direction* as a principal centroidal axis for the cross section may be determined by using the following procedure.

### Shear-Flow Resultants.


- By observation, determine the direction of the shear flow through the various segments of the cross section, and sketch the force resultants on each segment of the cross section. (For example, see Fig. 7–23*c*.) Since the shear center is determined by taking the moments of these force resultants about a point ($A$), choose this point at a location that eliminates the moments of as many force resultants as possible.
- The magnitudes of the force resultants that create a moment about $A$ must be calculated. For any segment this is done by determining the shear flow $q$ at an arbitrary point on the segment and then integrating $q$ along the segment's length. Realize that $\mathbf{V}$ will create a *linear* variation of shear flow in segments that are *perpendicular* to $\mathbf{V}$, and a *parabolic* variation of shear flow in segments that are *parallel or inclined* to $\mathbf{V}$.

### Shear Center.

- Sum the moments of the shear-flow resultants about point $A$ and set this moment equal to the moment of $\mathbf{V}$ about $A$. Solve this equation to determine the moment-arm or eccentric distance $e$, which locates the line of action of $\mathbf{V}$ from $A$.
- If an *axis of symmetry* for the cross section exists, the shear center lies at the point where this axis intersects the line of action of $\mathbf{V}$.

## EXAMPLE 7.9

Determine the location of the shear center for the thin-walled channel section having the dimensions shown in Fig. 7–25*a*.





(a)

### SOLUTION

**Shear-Flow Resultants.** A vertical downward shear **V** applied to the section causes the shear to flow through the flanges and web as shown in Fig. 7–25*b*. This causes force resultants $F_f$ and $V$ in the flanges and web as shown in Fig. 7–25*c*. We will take moments about point $A$ so that only the force $F_f$ on the lower flange has to be determined.

The cross-sectional area can be divided into three component rectangles—a web and two flanges. Since each component is assumed to be thin, the moment of inertia of the area about the neutral axis is

$$I = \frac{1}{12}th^3 + 2\left[bt\left(\frac{h}{2}\right)^2\right] = \frac{th^2}{2}\left(\frac{h}{6} + b\right)$$




Shear flow distribution

(b)


From Fig. 7–25*d*, $q$ at the arbitrary position $x$ is

$$q = \frac{VQ}{I} = \frac{V(h/2)[b - x]t}{(th^2/2)[(h/6) + b]} = \frac{V(b - x)}{h[(h/6) + b]}$$

Hence, the force $F_f$ is

$$F_f = \int_0^b q\,dx = \frac{V}{h[(h/6) + b]}\int_0^b (b - x)\,dx = \frac{Vb^2}{2h[(h/6) + b]}$$

This same result can also be determined by first finding $(q_{max})_f$, Fig. 7–25*b*, then determining the triangular area $\frac{1}{2}b(q_{max})_f = F_f$.




(c)


**Shear Center.** Summing moments about point $A$, Fig. 7–25*c*, we require

$$Ve = F_f h = \frac{Vb^2 h}{2h[(h/6) + b]}$$

Thus,

$$e = \frac{b^2}{[(h/3) + 2b]} \qquad \textit{Ans.}$$

As stated previously, $e$ depends only on the geometry of the cross section.




(d)

Fig. 7–25

## EXAMPLE 7.10

Determine the location of the shear center for the angle having equal legs, Fig. 7–26*a*. Also, find the internal shear force resultant in each leg.





Fig. 7–26

### SOLUTION

When a vertical downward shear **V** is applied at the section, the shear flow and shear-flow resultants are directed as shown in Fig. 7–26*b* and 7–26*c*, respectively. Note that the force $F$ in each leg must be equal, since for equilibrium the sum of their horizontal components must be equal to zero. Also, the lines of action of both forces intersect point $O$; therefore, this point *must be the shear center* since the sum of the moments of these forces and **V** about $O$ is zero, Fig. 7–26*c*.

The magnitude of **F** can be determined by first finding the shear flow at the arbitrary location $s$ along the top leg, Fig. 7–26*d*. Here

$$Q = \overline{y}' A' = \frac{1}{\sqrt{2}}\left((b - s) + \frac{s}{2}\right)ts = \frac{1}{\sqrt{2}}\left(b - \frac{s}{2}\right)st$$





**Fig. 7–26 (cont.)**

The moment of inertia of the angle, about the neutral axis, must be determined from "first principles," since the legs are inclined with respect to the neutral axis. For the area element $dA = t\,ds$, Fig. 7–26*e*, we have

$$I = \int_A y^2\,dA = 2\int_0^b \left[\frac{1}{\sqrt{2}}(b - s)\right]^2 t\,ds = t\left(b^2 s - bs^2 + \frac{1}{3}s^3\right)\Big|_0^b = \frac{tb^3}{3}$$

Thus, the shear flow is

$$q = \frac{VQ}{I} = \frac{V}{(tb^3/3)}\left[\frac{1}{\sqrt{2}}\left(b - \frac{s}{2}\right)st\right]$$

$$= \frac{3V}{\sqrt{2}b^3}s\left(b - \frac{s}{2}\right)$$

The variation of $q$ is parabolic, and it reaches a maximum value when $s = b$ as shown in Fig. 7–26*b*. The force $F$ is therefore

$$F = \int_0^b q\,ds = \frac{3V}{\sqrt{2}b^3}\int_0^b s\left(b - \frac{s}{2}\right)ds$$

$$= \frac{3V}{\sqrt{2}b^3}\left(b\frac{s^2}{2} - \frac{1}{6}s^3\right)\Big|_0^b$$

$$= \frac{1}{\sqrt{2}}V \qquad \textit{Ans.}$$


**NOTE:** This result can be easily verified since the sum of the vertical components of the force $F$ in each leg must equal $V$ and, as stated previously, the sum of the horizontal components equals zero.

7

## PROBLEMS

**7–50.** A shear force of $V = 300$ kN is applied to the box girder. Determine the shear flow at points $A$ and $B$.


**7–51.** A shear force of $V = 450$ kN is applied to the box girder. Determine the shear flow at points $C$ and $D$.




Probs. 7–50/51

**7–54.** The aluminum strut is 10 mm thick and has the cross section shown. If it is subjected to a shear of, $V = 150$ N, determine the shear flow at points $A$ and $B$.


**7–55.** The aluminum strut is 10 mm thick and has the cross section shown. If it is subjected to a shear of $V = 150$ N, determine the maximum shear flow in the strut.




Probs. 7–54/55

***7–52.** A shear force of $V = 18$ kN is applied to the symmetric box girder. Determine the shear flow at $A$ and $B$.


**•7–53.** A shear force of $V = 18$ kN is applied to the box girder. Determine the shear flow at $C$.




Probs. 7–52/53

***7–56.** The beam is subjected to a shear force of $V = 5$ kip. Determine the shear flow at points $A$ and $B$.


**•7–57.** The beam is constructed from four plates and is subjected to a shear force of $V = 5$ kip. Determine the maximum shear flow in the cross section.




Probs. 7–56/57


**7–58.** The channel is subjected to a shear of $V = 75$ kN. Determine the shear flow developed at point $A$.

**7–59.** The channel is subjected to a shear of $V = 75$ kN. Determine the maximum shear flow in the channel.





Probs. 7–58/59

***7–60.** The angle is subjected to a shear of $V = 2$ kip. Sketch the distribution of shear flow along the leg $AB$. Indicate numerical values at all peaks.





Prob. 7–60

•**7–61.** The assembly is subjected to a vertical shear of $V = 7$ kip. Determine the shear flow at points $A$ and $B$ and the maximum shear flow in the cross section.





Prob. 7–61

**7–62.** Determine the shear-stress variation over the cross section of the thin-walled tube as a function of elevation $y$ and show that $\tau_{max} = 2V/A$, where $A = 2\pi rt$. *Hint:* Choose a differential area element $dA = Rt\,d\theta$. Using $dQ = y\,dA$, formulate $Q$ for a circular section from $\theta$ to $(\pi - \theta)$ and show that $Q = 2R^2t\cos\theta$, where $\cos\theta = \sqrt{R^2 - y^2}/R$.





Prob. 7–62

**7–63.** Determine the location $e$ of the shear center, point $O$, for the thin-walled member having the cross section shown where $b_2 > b_1$. The member segments have the same thickness $t$.




Prob. 7–63


***7–64.** Determine the location $e$ of the shear center, point $O$, for the thin-walled member having the cross section shown. The member segments have the same thickness $t$.




Prob. 7–64


7

•7–65. Determine the location $e$ of the shear center, point $O$, for the thin-walled member having a slit along its side. Each element has a constant thickness $t$.





Prob. 7–65

7–66. Determine the location $e$ of the shear center, point $O$, for the thin-walled member having the cross section shown.





Prob. 7–66

7–67. Determine the location $e$ of the shear center, point $O$, for the thin-walled member having the cross section shown. The member segments have the same thickness $t$.





Prob. 7–67

*7–68. Determine the location $e$ of the shear center, point $O$, for the beam having the cross section shown. The thickness is $t$.





Prob. 7–68

•7–69. Determine the location $e$ of the shear center, point $O$, for the thin-walled member having the cross section shown. The member segments have the same thickness $t$.




Prob. 7–69

7–70. Determine the location $e$ of the shear center, point $O$, for the thin-walled member having the cross section shown.





Prob. 7–70

## CHAPTER REVIEW


Transverse shear stress in beams is determined indirectly by using the flexure formula and the relationship between moment and shear ($V = dM/dx$). The result is the shear formula

$$\tau = \frac{VQ}{It}$$

In particular, the value for $Q$ is the moment of the area $A'$ about the neutral axis, $Q = \bar{y}'A'$. This area is the portion of the cross-sectional area that is "held on" to the beam above (or below) the thickness $t$ where $\tau$ is to be determined.





If the beam has a *rectangular* cross section, then the shear-stress distribution will be parabolic, having a maximum value at the neutral axis. The maximum shear stress can be determined using $\tau = 1.5\dfrac{V}{A}$.





Shear-stress distribution

Fasteners, such as nails, bolts, glue, or welds, are used to connect the composite parts of a "built-up" section. The shear force resisted by these fasteners is determined from the shear flow, $q$, or force per unit length, that must be carried by the beam. The shear flow is

$$q = \frac{VQ}{I}$$




If the beam is made from thin-walled segments, then the shear-flow distribution along each segment can be determined. This distribution will vary linearly along horizontal segments, and parabolically along inclined or vertical segments.





Shear-flow distribution

Provided the shear-flow distribution in each element of an open thin-walled section is known, then using a balance of moments, the location $O$ of the shear center for the cross section can be determined. When a load is applied to the member through this point, the member will bend, and not twist.




## REVIEW PROBLEMS

**7–71.** Sketch the intensity of the shear-stress distribution acting over the beam's cross-sectional area, and determine the resultant shear force acting on the segment $AB$. The shear acting at the section is $V = 35$ kip. Show that $I_{NA} = 872.49\ \text{in}^4$.





Prob. 7–71

*7–72. The beam is fabricated from four boards nailed together as shown. Determine the shear force each nail along the sides $C$ and the top $D$ must resist if the nails are uniformly spaced at $s = 3$ in. The beam is subjected to a shear of $V = 4.5$ kip.




Prob. 7–72


•7–73. The member is subjected to a shear force of $V = 2$ kN. Determine the shear flow at points $A$, $B$, and $C$. The thickness of each thin-walled segment is 15 mm.




Prob. 7–73

7–74. The beam is constructed from four boards glued together at their seams. If the glue can withstand 75 lb/in., what is the maximum vertical shear $V$ that the beam can support?

7–75. Solve Prob. 7–74 if the beam is rotated 90° from the position shown.




Probs. 7–74/75




The offset hanger supporting this ski gondola is subjected to the combined loadings of axial force and bending moment.

# Combined Loadings

# 8

## CHAPTER OBJECTIVES

This chapter serves as a review of the stress analysis that has been developed in the previous chapters regarding axial load, torsion, bending, and shear. We will discuss the solution of problems where several of these internal loads occur simultaneously on a member's cross section. Before doing this, however, the chapter begins with an analysis of stress developed in thin-walled pressure vessels.

## 8.1 Thin-Walled Pressure Vessels

Cylindrical or spherical vessels are commonly used in industry to serve as boilers or tanks. When under pressure, the material of which they are made is subjected to a loading from all directions. Although this is the case, the vessel can be analyzed in a simple manner provided it has a thin wall. In general, "***thin wall***" refers to a vessel having an inner-radius-to-wall-thickness ratio of 10 or more ($r/t \geq 10$). Specifically, when $r/t = 10$ the results of a thin-wall analysis will predict a stress that is approximately 4% *less* than the actual maximum stress in the vessel. For larger $r/t$ ratios this error will be even smaller.


Provided the vessel wall is "thin," the stress distribution throughout its thickness will not vary significantly, and so we will assume that it is *uniform* or *constant*. Using this assumption, we will now analyze the state of stress in thin-walled cylindrical and spherical pressure vessels. In both cases, the pressure in the vessel is understood to be the *gauge pressure*, that is, it measures the pressure *above* atmospheric pressure, since atmospheric pressure is assumed to exist both inside and outside the vessel's wall before the vessel is pressurized.




Cylindrical pressure vessels, such as this gas tank, have semi-spherical end caps rather than flat ones in order to reduce the stress in the tank.




(a)




(b)




(c)

Fig. 8–1

**Cylindrical Vessels.** Consider the cylindrical vessel in Fig. 8–1*a*, having a wall thickness $t$, inner radius $r$, and subjected to a gauge pressure $p$ that developed within the vessel by a contained gas. Due to this loading, a small element of the vessel that is sufficiently removed from the ends and oriented as shown in Fig. 8–1*a*, is subjected to normal stresses $\sigma_1$ in the ***circumferential or hoop direction*** and $\sigma_2$ in the ***longitudinal or axial direction***.

The hoop stress can be determined by considering the vessel to be sectioned by planes *a*, *b*, and *c*. A free-body diagram of the back segment along with the contained gas is shown in Fig. 8–1*b*. Here only the loadings in the $x$ direction are shown. These loadings are developed by the uniform hoop stress $\sigma_1$, acting on the vessel's wall, and the pressure acting on the vertical face of the gas. For equilibrium in the $x$ direction, we require

$$\Sigma F_x = 0; \qquad 2[\sigma_1(t\,dy)] - p(2r\,dy) = 0$$

$$\sigma_1 = \frac{pr}{t} \tag{8–1}$$

The longitudinal stress can be determined by considering the left portion of section *b* of the cylinder, Fig. 8–1*a*. As shown in Fig. 8–1*c*, $\sigma_2$ acts uniformly throughout the wall, and $p$ acts on the section of the contained gas. Since the mean radius is approximately equal to the vessel's inner radius, equilibrium in the $y$ direction requires

$$\Sigma F_y = 0; \qquad \sigma_2(2\pi rt) - p(\pi r^2) = 0$$

$$\sigma_2 = \frac{pr}{2t} \tag{8–2}$$

In the above equations,

$\sigma_1, \sigma_2$ = the normal stress in the hoop and longitudinal directions, respectively. Each is assumed to be *constant* throughout the wall of the cylinder, and each subjects the material to tension.

$p$ = the internal gauge pressure developed by the contained gas

$r$ = the inner radius of the cylinder

$t$ = the thickness of the wall $(r/t \geq 10)$

By comparison, note that the hoop or circumferential stress is twice as large as the longitudinal or axial stress. Consequently, when fabricating cylindrical pressure vessels from rolled-formed plates, the longitudinal joints must be designed to carry twice as much stress as the circumferential joints.




Shown is the barrel of a shotgun which was clogged with debris just before firing. Gas pressure from the charge increased the circumferential stress within the barrel enough to cause the rupture.


**Spherical Vessels.** We can analyze a spherical pressure vessel in a similar manner. To do this, consider the vessel to have a wall thickness $t$, inner radius $r$, and subjected to an internal gauge pressure $p$, Fig. 8–2*a*. If the vessel is sectioned in half, the resulting free-body diagram is shown in Fig. 8–2*b*. Like the cylinder, equilibrium in the $y$ direction requires

$$\Sigma F_y = 0; \qquad \sigma_2(2\pi rt) - p(\pi r^2) = 0$$

$$\sigma_2 = \frac{pr}{2t} \tag{8–3}$$




(a)




(b)

Fig. 8–2

This is the *same result* as that obtained for the longitudinal stress in the cylindrical pressure vessel. Furthermore, from the analysis, this stress will be the same *regardless* of the orientation of the hemispheric free-body diagram. Consequently, a small element of the material is subjected to the state of stress shown in Fig. 8–2*a*.

The above analysis indicates that an element of material taken from either a cylindrical or a spherical pressure vessel is subjected to ***biaxial stress***, i.e., normal stress existing in only two directions. Actually, the pressure also subjects the material to a ***radial stress***, $\sigma_3$, which acts along a radial line. This stress has a maximum value equal to the pressure $p$ at the interior wall and it decreases through the wall to zero at the exterior surface of the vessel, since the gauge pressure there is zero. For thin-walled vessels, however, we will *ignore* this radial-stress component, since our limiting assumption of $r/t = 10$ results in $\sigma_2$ and $\sigma_1$ being, respectively, 5 and 10 times *higher* than the maximum radial stress, $(\sigma_3)_{max} = p$. Finally, if the vessel is subjected to an *external pressure*, the compressive stress developed within the thin wall may cause the vessel to become unstable, and collapse may occur by buckling rather than causing the material to fracture.

## EXAMPLE 8.1

A cylindrical pressure vessel has an inner diameter of 4 ft and a thickness of $\frac{1}{2}$ in. Determine the maximum internal pressure it can sustain so that neither its circumferential nor its longitudinal stress component exceeds 20 ksi. Under the same conditions, what is the maximum internal pressure that a similar-size spherical vessel can sustain?

### SOLUTION



**Cylindrical Pressure Vessel.** The maximum stress occurs in the circumferential direction. From Eq. 8–1 we have

$$\sigma_2 = \frac{pr}{t}; \qquad 20\ \text{kip/in}^2 = \frac{p(24\ \text{in.})}{\frac{1}{2}\ \text{in.}}$$

$$p = 417\ \text{psi} \qquad \textit{Ans.}$$

Note that when this pressure is reached, from Eq. 8–2, the stress in the longitudinal direction will be $\sigma_2 = \frac{1}{2}(20\ \text{ksi}) = 10\ \text{ksi}$. Furthermore, the *maximum stress* in the *radial direction* occurs on the material at the inner wall of the vessel and is $(\sigma_3)_{\max} = p = 417$ psi. This value is 48 times smaller than the circumferential stress (20 ksi), and as stated earlier, its effects will be neglected.



**Spherical Vessel.** Here the maximum stress occurs in any two perpendicular directions on an element of the vessel, Fig. 8–2*a*. From Eq. 8–3, we have

$$\sigma_2 = \frac{pr}{2t}; \qquad 20\ \text{kip/in}^2 = \frac{p(24\ \text{in.})}{2\left(\frac{1}{2}\ \text{in.}\right)}$$

$$p = 833\ \text{psi} \qquad \textit{Ans.}$$


**NOTE:** Although it is more difficult to fabricate, the spherical pressure vessel will carry twice as much internal pressure as a cylindrical vessel.

## PROBLEMS

**8–1.** A spherical gas tank has an inner radius of $r = 1.5$ m. If it is subjected to an internal pressure of $p = 300$ kPa, determine its required thickness if the maximum normal stress is not to exceed 12 MPa.


**8–2.** A pressurized spherical tank is to be made of 0.5-in.-thick steel. If it is subjected to an internal pressure of $p = 200$ psi, determine its outer radius if the maximum normal stress is not to exceed 15 ksi.

**8–3.** The thin-walled cylinder can be supported in one of two ways as shown. Determine the state of stress in the wall of the cylinder for both cases if the piston $P$ causes the internal pressure to be 65 psi. The wall has a thickness of 0.25 in. and the inner diameter of the cylinder is 8 in.




Prob. 8–3


*8–4. The tank of the air compressor is subjected to an internal pressure of 90 psi. If the internal diameter of the tank is 22 in., and the wall thickness is 0.25 in., determine the stress components acting at point $A$. Draw a volume element of the material at this point, and show the results on the element.




Prob. 8–4


•8–5. The spherical gas tank is fabricated by bolting together two hemispherical thin shells of thickness 30 mm. If the gas contained in the tank is under a gauge pressure of 2 MPa, determine the normal stress developed in the wall of the tank and in each of the bolts. The tank has an inner diameter of 8 m and is sealed with 900 bolts each 25 mm in diameter.

**8–6.** The spherical gas tank is fabricated by bolting together two hemispherical thin shells. If the 8-m inner diameter tank is to be designed to withstand a gauge pressure of 2 MPa, determine the minimum wall thickness of the tank and the minimum number of 25-mm diameter bolts that must be used to seal it. The tank and the bolts are made from material having an allowable normal stress of 150 MPa and 250 MPa, respectively.



Probs. 8–5/6


**8–7.** A boiler is constructed of 8-mm thick steel plates that are fastened together at their ends using a butt joint consisting of two 8-mm cover plates and rivets having a diameter of 10 mm and spaced 50 mm apart as shown. If the steam pressure in the boiler is 1.35 MPa, determine (a) the circumferential stress in the boiler's plate apart from the seam, (b) the circumferential stress in the outer cover plate along the rivet line $a$–$a$, and (c) the shear stress in the rivets.




Prob. 8–7


*8–8. The gas storage tank is fabricated by bolting together two half cylindrical thin shells and two hemispherical shells as shown. If the tank is designed to withstand a pressure of 3 MPa, determine the required minimum thickness of the cylindrical and hemispherical shells and the minimum required number of longitudinal bolts per meter length at each side of the cylindrical shell. The tank and the 25 mm diameter bolts are made from material having an allowable normal stress of 150 MPa and 250 MPa, respectively. The tank has an inner diameter of 4 m.

•8–9. The gas storage tank is fabricated by bolting together two half cylindrical thin shells and two hemispherical shells as shown. If the tank is designed to withstand a pressure of 3 MPa, determine the required minimum thickness of the cylindrical and hemispherical shells and the minimum required number of bolts for each hemispherical cap. The tank and the 25 mm diameter bolts are made from material having an allowable normal stress of 150 MPa and 250 MPa, respectively. The tank has an inner diameter of 4 m.




Probs. 8–8/9

8–10. A wood pipe having an inner diameter of 3 ft is bound together using steel hoops each having a cross-sectional area of 0.2 in$^2$. If the allowable stress for the hoops is $\sigma_{allow} = 12$ ksi, determine their maximum spacing $s$ along the section of pipe so that the pipe can resist an internal gauge pressure of 4 psi. Assume each hoop supports the pressure loading acting along the length $s$ of the pipe.





Prob. 8–10

8–11. The staves or vertical members of the wooden tank are held together using semicircular hoops having a thickness of 0.5 in. and a width of 2 in. Determine the normal stress in hoop $AB$ if the tank is subjected to an internal gauge pressure of 2 psi and this loading is transmitted directly to the hoops. Also, if 0.25-in.-diameter bolts are used to connect each hoop together, determine the tensile stress in each bolt at $A$ and $B$. Assume hoop $AB$ supports the pressure loading within a 12-in. length of the tank as shown.





Prob. 8–11

*8–12. Two hemispheres having an inner radius of 2 ft and wall thickness of 0.25 in. are fitted together, and the inside gauge pressure is reduced to −10 psi. If the coefficient of static friction is $\mu_s = 0.5$ between the hemispheres, determine (a) the torque $T$ needed to initiate the rotation of the top hemisphere relative to the bottom one, (b) the vertical force needed to pull the top hemisphere off the bottom one, and (c) the horizontal force needed to slide the top hemisphere off the bottom one.





Prob. 8–12

•**8–13.** The 304 stainless steel band initially fits snugly around the smooth rigid cylinder. If the band is then subjected to a nonlinear temperature drop of $\Delta T = 20 \sin^2 \theta$ °F, where $\theta$ is in radians, determine the circumferential stress in the band.





Prob. 8–13

**8–14.** The ring, having the dimensions shown, is placed over a flexible membrane which is pumped up with a pressure $p$. Determine the change in the internal radius of the ring after this pressure is applied. The modulus of elasticity for the ring is $E$.





Prob. 8–14

**8–15.** The inner ring $A$ has an inner radius $r_1$ and outer radius $r_2$. Before heating, the outer ring $B$ has an inner radius $r_3$ and an outer radius $r_4$, and $r_2 > r_3$. If the outer ring is heated and then fitted over the inner ring, determine the pressure between the two rings when ring $B$ reaches the temperature of the inner ring. The material has a modulus of elasticity of $E$ and a coefficient of thermal expansion of $\alpha$.





Prob. 8–15

*8–16. The cylindrical tank is fabricated by welding a strip of thin plate helically, making an angle $\theta$ with the longitudinal axis of the tank. If the strip has a width $w$ and thickness $t$, and the gas within the tank of diameter $d$ is pressured to $p$, show that the normal stress developed along the strip is given by $\sigma_\theta = (pd/8t)(3 - \cos 2\theta)$.




Prob. 8–16

**8–17.** In order to increase the strength of the pressure vessel, filament winding of the same material is wrapped around the circumference of the vessel as shown. If the pretension in the filament is $T$ and the vessel is subjected to an internal pressure $p$, determine the hoop stresses in the filament and in the wall of the vessel. Use the free-body diagram shown, and assume the filament winding has a thickness $t'$ and width $w$ for a corresponding length of the vessel.




Prob. 8–17



This chimney is subjected to the combined loading of wind and weight. It is important to investigate the tensile stress in the chimney since masonry is weak in tension.

## 8.2 State of Stress Caused by Combined Loadings

In previous chapters we developed methods for determining the stress distributions in a member subjected to either an internal axial force, a shear force, a bending moment, or a torsional moment. Most often, however, the cross section of a member is subjected to *several* of these loadings *simultaneously*. When this occurs, the method of superposition can be used to determine the *resultant* stress distribution. Recall from Sec. 4.3 that the principle of superposition can be used for this purpose provided a *linear relationship* exists between the *stress* and the *loads*. Also, the geometry of the member should *not* undergo *significant change* when the loads are applied. These conditions are necessary in order to ensure that the stress produced by one load is not related to the stress produced by any other load.

### Procedure for Analysis

The following procedure provides a general means for establishing the normal and shear stress components at a point in a member when the member is subjected to several different types of loadings simultaneously. It is assumed that the material is homogeneous and behaves in a linear elastic manner. Also, Saint-Venant's principle requires that the point where the stress is to be determined is far removed from any discontinuities in the cross section or points of applied load.

#### Internal Loading.

- Section the member perpendicular to its axis at the point where the stress is to be determined and obtain the resultant internal normal and shear force components and the bending and torsional moment components.
- The force components should act through the *centroid* of the cross section, and the moment components should be computed about *centroidal axes*, which represent the principal axes of inertia for the cross section.

#### Stress Components.

- Determine the stress component associated with *each* internal loading. For each case, represent the effect either as a distribution of stress acting over the entire cross-sectional area, or show the stress on an element of the material located at a specified point on the cross section.

**Normal Force.**

- The internal normal force is developed by a uniform normal-stress distribution determined from $\sigma = P/A$.

**Shear Force.**

- The internal shear force in a member is developed by a shear-stress distribution determined from the shear formula, $\tau = VQ/It$. Special care, however, must be exercised when applying this equation, as noted in Sec. 7.2.

**Bending Moment.**

- For *straight members* the internal bending moment is developed by a normal-stress distribution that varies linearly from zero at the neutral axis to a maximum at the outer boundary of the member. This stress distribution is determined from the flexure formula, $\sigma = My/I$. If the member is *curved*, the stress distribution is nonlinear and is determined from $\sigma = My/[Ae(R - y)]$.

**Torsional Moment.**

- For circular shafts and tubes the internal torsional moment is developed by a shear-stress distribution that varies linearly from the central axis of the shaft to a maximum at the shaft's outer boundary. This stress distribution is determined from the torsional formula, $\tau = T\rho/J$.

**Thin-Walled Pressure Vessels.**


- If the vessel is a thin-walled cylinder, the internal pressure $p$ will cause a biaxial state of stress in the material such that the hoop or circumferential stress component is $\sigma_1 = pr/t$ and the longitudinal stress component is $\sigma_2 = pr/2t$. If the vessel is a thin-walled sphere, then the biaxial state of stress is represented by two equivalent components, each having a magnitude of $\sigma_2 = pr/2t$.

**Superposition.**

- Once the normal and shear stress components for each loading have been calculated, use the principle of superposition and determine the resultant normal and shear stress components.
- Represent the results on an element of material located at the point, or show the results as a distribution of stress acting over the member's cross-sectional area.


Problems in this section, which involve combined loadings, serve as a basic *review* of the application of the stress equations mentioned above. A thorough understanding of how these equations are applied, as indicated in the previous chapters, is necessary if one is to successfully solve the problems at the end of this section. The following examples should be carefully studied before proceeding to solve the problems.

## EXAMPLE 8.2




(a)

Fig. 8–3




(b)

A force of 150 lb is applied to the edge of the member shown in Fig. 8–3*a*. Neglect the weight of the member and determine the state of stress at points *B* and *C*.

### SOLUTION

**Internal Loadings.** The member is sectioned through *B* and *C*. For equilibrium at the section there must be an axial force of 150 lb acting through the *centroid* and a bending moment of 750 lb · in. about the centroidal or principal axis, Fig. 8–3*b*.

**Stress Components.**

**Normal Force.** The uniform normal-stress distribution due to the normal force is shown in Fig. 8–3*c*. Here

$$\sigma = \frac{P}{A} = \frac{150\ \text{lb}}{(10\ \text{in.})(4\ \text{in.})} = 3.75\ \text{psi}$$

**Bending Moment.** The normal-stress distribution due to the bending moment is shown in Fig. 8–3*d*. The maximum stress is

$$\sigma_{\max} = \frac{Mc}{I} = \frac{750\ \text{lb} \cdot \text{in.}(5\ \text{in.})}{\frac{1}{12}(4\ \text{in.})(10\ \text{in.})^3} = 11.25\ \text{psi}$$

**Superposition.** If the above normal-stress distributions are added algebraically, the resultant stress distribution is shown in Fig. 8–3*e*. Although it is not needed here, the location of the line of zero stress can be determined by proportional triangles; i.e.,


$$\frac{7.5\ \text{psi}}{x} = \frac{15\ \text{psi}}{(10\ \text{in.} - x)}$$

$$x = 3.33\ \text{in.}$$

Elements of material at *B* and *C* are subjected only to normal or *uniaxial stress* as shown in Figs. 8–3*f* and 8–3*g*. Hence,

$$\sigma_B = 7.5\ \text{psi} \quad \text{(tension)} \qquad \textit{Ans.}$$


$$\sigma_C = 15\ \text{psi} \quad \text{(compression)} \qquad \textit{Ans.}$$




Normal Force (c) | Bending Moment (d) | Combined Loading (e) | (f) | (g)

## EXAMPLE 8.3

The tank in Fig. 8–4*a* has an inner radius of 24 in. and a thickness of 0.5 in. It is filled to the top with water having a specific weight of $\gamma_w = 62.4\ \text{lb/ft}^3$. If it is made of steel having a specific weight of $\gamma_{st} = 490\ \text{lb/ft}^3$, determine the state of stress at point $A$. The tank is open at the top.



(a)


### SOLUTION

**Internal Loadings.** The free-body diagram of the section of both the tank and the water above point $A$ is shown in Fig. 8–4*b*. Notice that the weight of the water is supported by the water surface just *below* the section, *not* by the walls of the tank. In the vertical direction, the walls simply hold up the weight of the tank. This weight is

$$W_{st} = \gamma_{st} V_{st} = (490\ \text{lb/ft}^3)\left[\pi\left(\frac{24.5}{12}\text{ft}\right)^2 - \pi\left(\frac{24}{12}\text{ft}\right)^2\right](3\ \text{ft})$$
$$= 777.7\ \text{lb}$$

The stress in the circumferential direction is developed by the water pressure at level $A$. To obtain this pressure we must use *Pascal's law*, which states that the pressure at a point located a depth $z$ in the water is $p = \gamma_w z$. Consequently, the pressure on the tank at level $A$ is

$$p = \gamma_w z = (62.4\ \text{lb/ft}^3)(3\ \text{ft}) = 187.2\ \text{lb/ft}^2 = 1.30\ \text{psi}$$



(b)


**Stress Components.**

**Circumferential Stress.** Since $r/t = 24\ \text{in.}/0.5\ \text{in.} = 48 > 10$, the tank is a thin-walled vessel. Applying Eq. 8–1, using the inner radius $r = 24$ in., we have

$$\sigma_1 = \frac{pr}{t} = \frac{1.30\ \text{lb/in}^2\ (24\ \text{in.})}{0.5\ \text{in.}} = 62.4\ \text{psi} \qquad \textit{Ans.}$$

**Longitudinal Stress.** Since the weight of the tank is supported uniformly by the walls, we have

$$\sigma_2 = \frac{W_{st}}{A_{st}} = \frac{777.7\ \text{lb}}{\pi[(24.5\ \text{in.})^2 - (24\ \text{in.})^2]} = 10.2\ \text{psi} \qquad \textit{Ans.}$$



(c)

Fig. 8–4

**NOTE:** Equation 8–2, $\sigma_2 = pr/2t$, does *not apply* here, since the tank is open at the top and therefore, as stated previously, the water cannot develop a loading on the walls in the longitudinal direction.

Point $A$ is therefore subjected to the biaxial stress shown in Fig. 8–4*c*.

## EXAMPLE 8.4

The member shown in Fig. 8–5*a* has a rectangular cross section. Determine the state of stress that the loading produces at point *C*.





Fig. 8–5

### SOLUTION

**Internal Loadings.** The support reactions on the member have been determined and are shown in Fig. 8–5*b*. If the left segment *AC* of the member is considered, Fig. 8–5*c*, the resultant internal loadings at the section consist of a normal force, a shear force, and a bending moment. Solving,

$$N = 16.45\ \text{kN} \qquad V = 21.93\ \text{kN} \qquad M = 32.89\ \text{kN} \cdot \text{m}$$





Fig. 8–5 (cont.)

**Stress Components.**

**Normal Force.** The uniform normal-stress distribution acting over the cross section is produced by the normal force, Fig. 8–5*d*. At point *C*,

$$\sigma_C = \frac{P}{A} = \frac{16.45(10^3)\text{ N}}{(0.050\text{ m})(0.250\text{ m})} = 1.32\text{ MPa}$$

**Shear Force.** Here the area $A' = 0$, since point *C* is located at the top of the member. Thus $Q = \bar{y}'A' = 0$ and for *C*, Fig. 8–5*e*, the shear stress

$$\tau_C = 0$$

**Bending Moment.** Point *C* is located at $y = c = 0.125$ m from the neutral axis, so the normal stress at *C*, Fig. 8–5*f*, is

$$\sigma_C = \frac{Mc}{I} = \frac{(32.89(10^3)\text{ N}\cdot\text{m})(0.125\text{ m})}{\left[\frac{1}{12}(0.050\text{ m})(0.250\text{ m})^3\right]} = 63.16\text{ MPa}$$

**Superposition.** The shear stress is zero. Adding the normal stresses determined above gives a compressive stress at *C* having a value of


$$\sigma_C = 1.32\text{ MPa} + 63.16\text{ MPa} = 64.5\text{ MPa} \quad \textit{Ans.}$$

This result, acting on an element at *C*, is shown in Fig. 8–5*g*.





(g)

## EXAMPLE 8.5




(a)




(b)

Fig. 8–6

The rectangular block of negligible weight in Fig. 8–6*a* is subjected to a vertical force of 40 kN, which is applied to its corner. Determine the largest normal stress acting on a section through $ABCD$.

### SOLUTION

**Internal Loadings.** If we consider the equilibrium of the bottom segment of the block, Fig. 8–6*b*, it is seen that the 40-kN force must act through the centroid of the cross section and *two* bending-moment components must also act about the centroidal or principal axes of inertia for the section. Verify these results.

**Stress Components.**

**Normal Force.** The uniform normal-stress distribution is shown in Fig. 8–6*c*. We have

$$\sigma = \frac{P}{A} = \frac{40(10^3)\ \text{N}}{(0.8\ \text{m})(0.4\ \text{m})} = 125\ \text{kPa}$$

**Bending Moments.** The normal-stress distribution for the 8-kN · m moment is shown in Fig. 8–6*d*. The maximum stress is


$$\sigma_{\max} = \frac{M_x c_y}{I_x} = \frac{8(10^3)\ \text{N}\cdot\text{m}(0.2\ \text{m})}{\left[\frac{1}{12}(0.8\ \text{m})(0.4\ \text{m})^3\right]} = 375\ \text{kPa}$$

Likewise, for the 16-kN · m moment, Fig. 8–6*e*, the maximum normal stress is

$$\sigma_{\max} = \frac{M_y c_x}{I_y} = \frac{16(10^3)\ \text{N}\cdot\text{m}(0.4\ \text{m})}{\left[\frac{1}{12}(0.4\ \text{m})(0.8\ \text{m})^3\right]} = 375\ \text{kPa}$$

**Superposition.** By inspection the normal stress at point $C$ is the largest since each loading creates a compressive stress there. Therefore

$$\sigma_C = -125\ \text{kPa} - 375\ \text{kPa} - 375\ \text{kPa} = -875\ \text{kPa} \quad \textit{Ans.}$$





Normal force (40 kN) (c)

Bending moment (8 kN·m) (d)

Bending moment (16 kN·m) (e)

## EXAMPLE 8.6

A rectangular block has a negligible weight and is subjected to a vertical force **P**, Fig. 8–7*a*. (a) Determine the range of values for the eccentricity $e_y$ of the load along the $y$ axis so that it does not cause any tensile stress in the block. (b) Specify the region on the cross section where **P** may be applied without causing a tensile stress in the block.




(a)

### SOLUTION

**Part (a).** When **P** is moved to the centroid of the cross section, Fig. 8–7*b*, it is necessary to add a couple moment $M_x = Pe_y$ in order to maintain a statically equivalent loading. The combined normal stress at any coordinate location $y$ on the cross section caused by these two loadings is

$$\sigma = -\frac{P}{A} - \frac{(Pe_y)y}{I_x} = -\frac{P}{A}\left(1 + \frac{Ae_y y}{I_x}\right)$$

Here the negative sign indicates compressive stress. For positive $e_y$, Fig. 8–7*a*, the *smallest* compressive stress will occur along edge $AB$, where $y = -h/2$, Fig. 8–7*b*. (By inspection, **P** causes compression there, but $\mathbf{M}_x$ causes tension.) Hence,

$$\sigma_{\min} = -\frac{P}{A}\left(1 - \frac{Ae_y h}{2I_x}\right)$$

This stress will remain negative, i.e., compressive, provided the term in parentheses is positive; i.e.,


$$1 > \frac{Ae_y h}{2I_x}$$

Since $A = bh$ and $I_x = \frac{1}{12}bh^3$, then

$$1 > \frac{6e_y}{h} \quad \text{or} \quad e_y < \frac{1}{6}h \qquad \textit{Ans.}$$

In other words, if $-\frac{1}{6}h \le e_y \le \frac{1}{6}h$, the stress in the block along edge $AB$ or $CD$ will be zero or remain *compressive*.

**NOTE:** This is sometimes referred to as the "*middle-third rule.*" It is very important to keep this rule in mind when loading columns or arches having a rectangular cross section and made of material such as stone or concrete, which can support little or no tensile stress. We can extend this analysis in the same way by placing **P** along the $x$ axis in Fig. 8–7. The result will produce a shaded parallelogram shown in Fig. 8–7*c*. This region is referred to as the core or kern of the section. When **P** is applied within the kern, the normal stress at the corners of the cross section will be compressive.




(b) (c)


Fig. 8–7




Here is an example of where combined axial and bending stress can occur.

## EXAMPLE 8.7

The solid rod shown in Fig. 8–8*a* has a radius of 0.75 in. If it is subjected to the force of 500 lb, determine the state of stress at point *A*.




(a)




(b)

### SOLUTION

**Internal Loadings.** The rod is sectioned through point *A*. Using the free-body diagram of segment *AB*, Fig. 8–8*b*, the resultant internal loadings are determined from the equations of equilibrium. Verify these results. In order to better "visualize" the stress distributions due to these loadings, we can consider the *equal but opposite resultants* acting on segment *AC*, Fig. 8–8*c*.

**Stress Components.**

**Normal Force.** The normal-stress distribution is shown in Fig. 8–8*d*. For point *A*, we have

$$(\sigma_A)_y = \frac{P}{A} = \frac{500\ \text{lb}}{\pi(0.75\ \text{in.})^2} = 283\ \text{psi} = 0.283\ \text{ksi}$$


**Bending Moment.** For the moment, $c = 0.75$ in., so the normal stress at point *A*, Fig. 8–8*e*, is

$$(\sigma_A)_y = \frac{Mc}{I} = \frac{7000\ \text{lb}\cdot\text{in.}(0.75\ \text{in.})}{[\frac{1}{4}\pi(0.75\ \text{in.})^4]}$$

$$= 21{,}126\ \text{psi} = 21.13\ \text{ksi}$$

**Superposition.** When the above results are superimposed, it is seen that an element of material at *A* is subjected to the normal stress

$$(\sigma_A)_y = 0.283\ \text{ksi} + 21.13\ \text{ksi} = 21.4\ \text{ksi}$$ *Ans.*




Normal force (500 lb) (d)


Bending moment (7000 lb·in.) (e)

(c)

**Fig. 8–8**

## EXAMPLE 8.8

The solid rod shown in Fig. 8–9*a* has a radius of 0.75 in. If it is subjected to the force of 800 lb, determine the state of stress at point *A*.




(a)

### SOLUTION

**Internal Loadings.** The rod is sectioned through point *A*. Using the free-body diagram of segment *AB*, Fig. 8–9*b*, the resultant internal loadings are determined from the six equations of equilibrium. Verify these results. The *equal but opposite resultants* are shown acting on segment *AC*, Fig. 8–9*c*.

**Stress Components.**


**Shear Force.** The shear-stress distribution is shown in Fig. 8–9*d*. For point *A*, $Q$ is determined from the shaded *semi-circular* area. Using the table on the inside front cover, we have

$$Q = \bar{y}'A' = \frac{4(0.75\text{ in.})}{3\pi}\left[\frac{1}{2}\pi(0.75\text{ in.})^2\right] = 0.2813\text{ in}^3$$

so that

$$(\tau_{yz})_A = \frac{VQ}{It} = \frac{800\text{ lb}(0.2813\text{ in}^3)}{\left[\frac{1}{4}\pi(0.75\text{ in.})^4\right]2(0.75\text{ in.})}$$

$$= 604\text{ psi} = 0.604\text{ ksi}$$




(b)

Fig. 8–9

**Bending Moment.** Since point *A* lies on the neutral axis, Fig. 8–9*e*, the normal stress is


$$\sigma_A = 0$$

**Torque.** At point *A*, $\rho_A = c = 0.75$ in., Fig. 8–9*f*. Thus the shear stress is

$$(\tau_{yz})_A = \frac{Tc}{J} = \frac{11\,200\text{ lb}\cdot\text{in.}(0.75\text{ in.})}{\left[\frac{1}{2}\pi(0.75\text{ in.})^4\right]} = 16\,901\text{ psi} = 16.90\text{ ksi}$$

**Superposition.** Here the element of material at *A* is subjected only to a shear stress component, where


$$(\tau_{yz})_A = 0.604\text{ ksi} + 16.90\text{ ksi} = 17.5\text{ ksi} \quad \textit{Ans.}$$




(c) (d) (e) (f)


## FUNDAMENTAL PROBLEMS

**F8–1.** Determine the normal stress developed at corners $A$ and $B$ of the column.





F8–1

**F8–2.** Determine the state of stress at point $A$ on the cross section at section $a$–$a$ of the cantilever beam.





F8–2

**F8–3.** Determine the state of stress at point $A$ on the cross section of the beam at section $a$–$a$.





F8–3

**F8–4.** Determine the magnitude of the load $P$ that will cause a maximum normal stress of $\sigma_{max} = 30$ ksi in the link along section $a$–$a$.





F8–4

**F8–5.** The beam has a rectangular cross section and is subjected to the loading shown. Determine the components of stress $\sigma_x$, $\sigma_y$, and $\tau_{xy}$ at point $B$.





F8–5

**F8–6.** Determine the state of stress at point $A$ on the cross section of the pipe assembly at section $a$–$a$.





F8–6

**F8–7.** Determine the state of stress at point $A$ on the cross section of the pipe at section $a$–$a$.




F8–7


**F8–8.** Determine the state of stress at point $A$ on the cross section of the shaft at section $a$–$a$.




F8–8

## PROBLEMS


**8–18.** The vertical force **P** acts on the bottom of the plate having a negligible weight. Determine the shortest distance $d$ to the edge of the plate at which it can be applied so that it produces no compressive stresses on the plate at section $a$–$a$. The plate has a thickness of 10 mm and **P** acts along the center line of this thickness.




**Prob. 8–18**


**8–19.** Determine the maximum and minimum normal stress in the bracket at section $a$–$a$ when the load is applied at $x = 0$.

***8–20.** Determine the maximum and minimum normal stress in the bracket at section $a$–$a$ when the load is applied at $x = 300$ mm.




**Probs. 8–19/20**


**•8–21.** The coping saw has an adjustable blade that is tightened with a tension of 40 N. Determine the state of stress in the frame at points $A$ and $B$.




**Prob. 8–21**

**8–22.** The clamp is made from members $AB$ and $AC$, which are pin connected at $A$. If it exerts a compressive force at $C$ and $B$ of 180 N, determine the maximum compressive stress in the clamp at section $a$–$a$. The screw $EF$ is subjected only to a tensile force along its axis.


**8–23.** The clamp is made from members $AB$ and $AC$, which are pin connected at $A$. If it exerts a compressive force at $C$ and $B$ of 180 N, sketch the stress distribution acting over section $a$–$a$. The screw $EF$ is subjected only to a tensile force along its axis.




**Probs. 8–22/23**

*8–24. The bearing pin supports the load of 700 lb. Determine the stress components in the support member at point A. The support is 0.5 in. thick.


•8–25. The bearing pin supports the load of 700 lb. Determine the stress components in the support member at point B. The support is 0.5 in. thick.




Probs. 8–24/25

8–26. The offset link supports the loading of $P = 30$ kN. Determine its required width $w$ if the allowable normal stress is $\sigma_{allow} = 73$ MPa. The link has a thickness of 40 mm.


8–27. The offset link has a width of $w = 200$ mm and a thickness of 40 mm. If the allowable normal stress is $\sigma_{allow} = 75$ MPa, determine the maximum load $P$ that can be applied to the cables.




Probs. 8–26/27


*8–28. The joint is subjected to a force of $P = 80$ lb and $F = 0$. Sketch the normal-stress distribution acting over section $a$–$a$ if the member has a rectangular cross-sectional area of width 2 in. and thickness 0.5 in.


•8–29. The joint is subjected to a force of $P = 200$ lb and $F = 150$ lb. Determine the state of stress at points $A$ and $B$ and sketch the results on differential elements located at these points. The member has a rectangular cross-sectional area of width 0.75 in. and thickness 0.5 in.




Probs. 8–28/29

8–30. If the 75-kg man stands in the position shown, determine the state of stress at point $A$ on the cross section of the plank at section $a$–$a$. The center of gravity of the man is at $G$. Assume that the contact point at $C$ is smooth.








Section $a - a$ and $b - b$

Prob. 8–30

**8–31.** Determine the smallest distance $d$ to the edge of the plate at which the force **P** can be applied so that it produces no compressive stresses in the plate at section $a$–$a$. The plate has a thickness of 20 mm and **P** acts along the centerline of this thickness.


***8–32.** The horizontal force of $P = 80$ kN acts at the end of the plate. The plate has a thickness of 10 mm and **P** acts along the centerline of this thickness such that $d = 50$ mm. Plot the distribution of normal stress acting along section $a$–$a$.




**Probs. 8–31/32**


**•8–33.** The pliers are made from two steel parts pinned together at $A$. If a smooth bolt is held in the jaws and a gripping force of 10 lb is applied at the handles, determine the state of stress developed in the pliers at points $B$ and $C$. Here the cross section is rectangular, having the dimensions shown in the figure.

**8–34.** Solve Prob. 8–33 for points $D$ and $E$.




**Probs. 8–33/34**


**8–35.** The wide-flange beam is subjected to the loading shown. Determine the stress components at points $A$ and $B$ and show the results on a volume element at each of these points. Use the shear formula to compute the shear stress.




**Prob. 8–35**

***8–36.** The drill is jammed in the wall and is subjected to the torque and force shown. Determine the state of stress at point $A$ on the cross section of drill bit at section $a$–$a$.


**•8–37.** The drill is jammed in the wall and is subjected to the torque and force shown. Determine the state of stress at point $B$ on the cross section of drill bit at section $a$–$a$.




**Probs. 8–36/37**

**8–38.** Since concrete can support little or no tension, this problem can be avoided by using wires or rods to *prestress* the concrete once it is formed. Consider the simply supported beam shown, which has a rectangular cross section of 18 in. by 12 in. If concrete has a specific weight of 150 lb/ft$^3$, determine the required tension in rod $AB$, which runs through the beam so that no tensile stress is developed in the concrete at its center section $a$–$a$. Neglect the size of the rod and any deflection of the beam.


**8–39.** Solve Prob. 8–38 if the rod has a diameter of 0.5 in. Use the transformed area method discussed in Sec. 6.6. $E_{st} = 29(10^3)$ ksi, $E_c = 3.60(10^3)$ ksi.




**Probs. 8–38/39**

***8–40.** Determine the state of stress at point $A$ when the beam is subjected to the cable force of 4 kN. Indicate the result as a differential volume element.


**•8–41.** Determine the state of stress at point $B$ when the beam is subjected to the cable force of 4 kN. Indicate the result as a differential volume element.




**Probs. 8–40/41**

**8–42.** The bar has a diameter of 80 mm. Determine the stress components that act at point $A$ and show the results on a volume element located at this point.


**8–43.** The bar has a diameter of 80 mm. Determine the stress components that act at point $B$ and show the results on a volume element located at this point.




**Probs. 8–42/43**


***8–44.** Determine the normal stress developed at points $A$ and $B$. Neglect the weight of the block.

**•8–45.** Sketch the normal stress distribution acting over the cross section at section $a$–$a$. Neglect the weight of the block.




**Probs. 8–44/45**

**8–46.** The support is subjected to the compressive load **P**. Determine the absolute maximum and minimum normal stress acting in the material.





**Prob. 8–46**

**8–47.** The support is subjected to the compressive load **P**. Determine the maximum and minimum normal stress acting in the material. All horizontal cross sections are circular.





**Prob. 8–47**

***8–48.** The post has a circular cross section of radius $c$. Determine the maximum radius $e$ at which the load can be applied so that no part of the post experiences a tensile stress. Neglect the weight of the post.





**Prob. 8–48**

**•8–49.** If the baby has a mass of 5 kg and his center of mass is at $G$, determine the normal stress at points $A$ and $B$ on the cross section of the rod at section $a$–$a$. There are two rods, one on each side of the cradle.





**Prob. 8–49**

**8–50.** The C-clamp applies a compressive stress on the cylindrical block of 80 psi. Determine the maximum normal stress developed in the clamp.





**Prob. 8–50**

**8–51.** A post having the dimensions shown is subjected to the bearing load **P**. Specify the region to which this load can be applied without causing tensile stress to be developed at points $A$, $B$, $C$, and $D$.




**Prob. 8–51**


***8–52.** The hook is used to lift the force of 600 lb. Determine the maximum tensile and compressive stresses at section *a–a*. The cross section is circular and has a diameter of 1 in. Use the curved-beam formula to compute the bending stress.




**Prob. 8–52**

**•8–53.** The masonry pier is subjected to the 800-kN load. Determine the equation of the line $y = f(x)$ along which the load can be placed without causing a tensile stress in the pier. Neglect the weight of the pier.


**8–54.** The masonry pier is subjected to the 800-kN load. If $x = 0.25$ m and $y = 0.5$ m, determine the normal stress at each corner $A$, $B$, $C$, $D$ (not shown) and plot the stress distribution over the cross section. Neglect the weight of the pier.




**Probs. 8–53/54**

**8–55.** The bar has a diameter of 40 mm. If it is subjected to the two force components at its end as shown, determine the state of stress at point $A$ and show the results on a differential volume element located at this point.


***8–56.** Solve Prob. 8–55 for point $B$.




**Probs. 8–55/56**

**•8–57.** The 2-in.-diameter rod is subjected to the loads shown. Determine the state of stress at point $A$, and show the results on a differential element located at this point.


**8–58.** The 2-in.-diameter rod is subjected to the loads shown. Determine the state of stress at point $B$, and show the results on a differential element located at this point.




**Probs. 8–57/58**

**8–59.** If $P = 60$ kN, determine the maximum normal stress developed on the cross section of the column.


***8–60.** Determine the maximum allowable force **P**, if the column is made from material having an allowable normal stress of $\sigma_{allow} = 100$ MPa.




**Probs. 8–59/60**

**•8–61.** The beveled gear is subjected to the loads shown. Determine the stress components acting on the shaft at point $A$, and show the results on a volume element located at this point. The shaft has a diameter of 1 in. and is fixed to the wall at $C$.


**8–62.** The beveled gear is subjected to the loads shown. Determine the stress components acting on the shaft at point $B$, and show the results on a volume element located at this point. The shaft has a diameter of 1 in. and is fixed to the wall at $C$.




**Probs. 8–61/62**

**8–63.** The uniform sign has a weight of 1500 lb and is supported by the pipe $AB$, which has an inner radius of 2.75 in. and an outer radius of 3.00 in. If the face of the sign is subjected to a uniform wind pressure of $p = 150$ lb/ft$^2$, determine the state of stress at points $C$ and $D$. Show the results on a differential volume element located at each of these points. Neglect the thickness of the sign, and assume that it is supported along the outside edge of the pipe.


***8–64.** Solve Prob. 8–63 for points $E$ and $F$.




**Probs. 8–63/64**


**•8–65.** Determine the state of stress at point $A$ on the cross section of the pipe at section $a$–$a$.

**8–66.** Determine the state of stress at point $B$ on the cross section of the pipe at section $a$–$a$.




**Probs. 8–65/66**


**•8–67.** The eccentric force **P** is applied at a distance $e_y$ from the centroid on the concrete support shown. Determine the range along the y axis where **P** can be applied on the cross section so that no tensile stress is developed in the material.




**Prob. 8–67**

***8–68.** The bar has a diameter of 40 mm. If it is subjected to a force of 800 N as shown, determine the stress components that act at point *A* and show the results on a volume element located at this point.


**•8–69.** Solve Prob. 8–68 for point *B*.




**Probs. 8–68/69**

**8–70.** The $\frac{3}{4}$-in.-diameter shaft is subjected to the loading shown. Determine the stress components at point *A*. Sketch the results on a volume element located at this point. The journal bearing at *C* can exert only force components $\mathbf{C}_y$ and $\mathbf{C}_z$ on the shaft, and the thrust bearing at *D* can exert force components $\mathbf{D}_x$, $\mathbf{D}_y$, and $\mathbf{D}_z$ on the shaft.


**8–71.** Solve Prob. 8–70 for the stress components at point *B*.




**Probs. 8–70/71**

***8–72.** The hook is subjected to the force of 80 lb. Determine the state of stress at point *A* at section *a–a*. The cross section is circular and has a diameter of 0.5 in. Use the curved-beam formula to compute the bending stress.

**•8–73.** The hook is subjected to the force of 80 lb. Determine the state of stress at point *B* at section *a–a*. The cross section has a diameter of 0.5 in. Use the curved-beam formula to compute the bending stress.




**Probs. 8–72/73**

## CHAPTER REVIEW

A pressure vessel is considered to have a thin wall provided $r/t \geq 10$. For a thin-walled cylindrical vessel, the circumferential or hoop stress is


$$\sigma_1 = \frac{pr}{t}$$

This stress is twice as great as the longitudinal stress,


$$\sigma_2 = \frac{pr}{2t}$$

Thin-walled spherical vessels have the same stress within their walls in all directions. It is

$$\sigma_1 = \sigma_2 = \frac{pr}{2t}$$




Superposition of stress components can be used to determine the normal and shear stress at a point in a member subjected to a combined loading. To do this, it is first necessary to determine the resultant axial and shear forces and the internal resultant torsional and bending moments at the section where the point is located. Then the normal and shear stress resultant components at the point are determined by algebraically adding the normal and shear stress components of each loading.



## CONCEPTUAL PROBLEMS



P8–1

**P8–1.** Explain why failure of this garden hose occurred near its end and why the tear occurred along its length. Use numerical values to explain your result. Assume the water pressure is 30 psi.



P8–2

**P8–2.** This open-ended silo contains granular material. It is constructed from wood slats and held together with steel bands. Explain, using numerical values, why the bands are not spaced evenly along the height of the cylinder. Also, how would you find this spacing if each band is to be subjected to the same stress?




P8–3

**P8–3.** Unlike the turnbuckle at $B$, which is connected along the axis of the rod, the one at $A$ has been welded to the edges of the rod, and so it will be subjected to additional stress. Use the same numerical values for the tensile load in each rod and the rod's diameter, and compare the stress in each rod.




P8–4

**P8–4.** A constant wind blowing against the side of this chimney has caused creeping strains in the mortar joints, such that the chimney has a noticeable deformation. Explain how to obtain the stress distribution over a section at the base of the chimney, and sketch this distribution over the section.

## REVIEW PROBLEMS


**8–74.** The block is subjected to the three axial loads shown. Determine the normal stress developed at points *A* and *B*. Neglect the weight of the block.




**Prob. 8–74**

**8–75.** The 20-kg drum is suspended from the hook mounted on the wooden frame. Determine the state of stress at point *E* on the cross section of the frame at section *a–a*. Indicate the results on an element.


***8–76.** The 20-kg drum is suspended from the hook mounted on the wooden frame. Determine the state of stress at point *F* on the cross section of the frame at section *b–b*. Indicate the results on an element.




**Probs. 8–75/76**


**•8–77.** The eye is subjected to the force of 50 lb. Determine the maximum tensile and compressive stresses at section *a–a*. The cross section is circular and has a diameter of 0.25 in. Use the curved-beam formula to compute the bending stress.

**8–78.** Solve Prob. 8–77 if the cross section is square, having dimensions of 0.25 in. by 0.25 in.




**Probs. 8–77/78**


**8–79.** If the cross section of the femur at section *a–a* can be approximated as a circular tube as shown, determine the maximum normal stress developed on the cross section at section *a–a* due to the load of 75 lb.




**Prob. 8–79**


*8–80. The hydraulic cylinder is required to support a force of $P = 100$ kN. If the cylinder has an inner diameter of 100 mm and is made from a material having an allowable normal stress of $\sigma_{allow} = 150$ MPa, determine the required minimum thickness $t$ of the wall of the cylinder.

•8–81. The hydraulic cylinder has an inner diameter of 100 mm and wall thickness of $t = 4$ mm. If it is made from a material having an allowable normal stress of $\sigma_{allow} = 150$ MPa, determine the maximum allowable force **P**.




Probs. 8–80/81

8–82. The screw of the clamp exerts a compressive force of 500 lb on the wood blocks. Determine the maximum normal stress developed along section $a$–$a$. The cross section there is rectangular, 0.75 in. by 0.50 in.




Prob. 8–82

8–83. Air pressure in the cylinder is increased by exerting forces $P = 2$ kN on the two pistons, each having a radius of 45 mm. If the cylinder has a wall thickness of 2 mm, determine the state of stress in the wall of the cylinder.


*8–84. Determine the maximum force $P$ that can be exerted on each of the two pistons so that the circumferential stress component in the cylinder does not exceed 3 MPa. Each piston has a radius of 45 mm and the cylinder has a wall thickness of 2 mm.




Probs. 8–83/84

•8–85. The cap on the cylindrical tank is bolted to the tank along the flanges. The tank has an inner diameter of 1.5 m and a wall thickness of 18 mm. If the largest normal stress is not to exceed 150 MPa, determine the maximum pressure the tank can sustain. Also, compute the number of bolts required to attach the cap to the tank if each bolt has a diameter of 20 mm. The allowable stress for the bolts is $(\sigma_{allow})_b = 180$ MPa.

8–86. The cap on the cylindrical tank is bolted to the tank along the flanges. The tank has an inner diameter of 1.5 m and a wall thickness of 18 mm. If the pressure in the tank is $p = 1.20$ MPa, determine the force in each of the 16 bolts that are used to attach the cap to the tank. Also, specify the state of stress in the wall of the tank.



Probs. 8–85/86



These turbine blades are subjected to a complex pattern of stress. For design it is necessary to determine where and in what direction the maximum stress occurs.

# Stress Transformation


# 9

## CHAPTER OBJECTIVES

In this chapter, we will show how to transform the stress components that are associated with a particular coordinate system into components associated with a coordinate system having a different orientation. Once the necessary transformation equations are established, we will then be able to obtain the maximum normal and maximum shear stress at a point and find the orientation of elements upon which they act. Plane-stress transformation will be discussed in the first part of the chapter, since this condition is most common in engineering practice. At the end of the chapter we will discuss a method for finding the absolute maximum shear stress at a point when the material is subjected to both plane and three-dimensional states of stress.

## 9.1 Plane-Stress Transformation

It was shown in Sec. 1.3 that the general state of stress at a point is characterized by *six* independent normal and shear stress components, which act on the faces of an element of material located at the point, Fig. 9–1*a*. This state of stress, however, is not often encountered in engineering practice. Instead, engineers frequently make approximations or simplifications of the loadings on a body in order that the stress produced in a structural member or mechanical element can be analyzed in a *single plane*. When this is the case, the material is said to be subjected to *plane stress*, Fig. 9–1*b*. For example, if there is no load on the surface of a body, then the normal and shear stress components will be zero on the face of an element that lies on this surface. Consequently, the corresponding stress components on the opposite face will also be zero, and so the material at the point will be subjected to plane stress. This case occurred throughout the previous chapter.



General state of stress
(a)

Plane stress
(b)

Fig. 9–1




Fig. 9–2


The general state of ***plane stress*** at a point is therefore represented by a combination of two normal-stress components, $\sigma_x$, $\sigma_y$, and one shear-stress component, $\tau_{xy}$, which act on four faces of the element. For convenience, in this text we will view this state of stress in the $x$–$y$ plane, Fig. 9–2*a*. If this state of stress is defined on an element having a *different orientation* as in Fig. 9–2*b*, then it will be subjected to three *different* stress components defined as $\sigma_{x'}$, $\sigma_{y'}$, $\tau_{x'y'}$. In other words, ***the state of plane stress at the point is uniquely represented by two normal stress components and one shear stress component acting on an element that has a specific orientation at the point.***

In this section, we will show how to *transform* the stress components from the orientation of an element in Fig. 9–2*a* to the orientation of the element in Fig. 9–2*b*. This is like knowing two force components, say, $\mathbf{F}_x$ and $\mathbf{F}_y$, directed along the $x$, $y$ axes, that produce a resultant force $\mathbf{F}_R$, and then trying to find the force components $\mathbf{F}_{x'}$ and $\mathbf{F}_{y'}$, directed along the $x'$, $y'$ axes, so they produce the *same* resultant. The transformation for force must only account for the force component's magnitude and direction. The transformation of stress components, however, is more difficult since the transformation must account for the magnitude and direction of each stress component *and* the orientation of the area upon which each component acts.

## Procedure for Analysis

If the state of stress at a point is known for a given orientation of an element of material, Fig. 9–3*a*, then the state of stress in an element having some other orientation, $\theta$, Fig. 9–3*b*, can be determined using the following procedure.

- To determine the normal and shear stress components $\sigma_{x'}$, $\tau_{x'y'}$ acting on the $+x'$ face of the element, Fig. 9–3*b*, section the element in Fig. 9–3*a* as shown in Fig. 9–3*c*. If the sectioned area is $\Delta A$, then the adjacent areas of the segment will be $\Delta A \sin\theta$ and $\Delta A \cos\theta$.
- Draw the free-body diagram of the segment, which requires showing the *forces* that act on the segment, Fig. 9–3*d*. This is done by multiplying the stress components on each face by the area upon which they act.
- Apply the force equations of equilibrium in the $x'$ and $y'$ directions. The area $\Delta A$ will cancel from the equations and so the two unknown stress components $\sigma_{x'}$ and $\tau_{x'y'}$ can be determined.
- If $\sigma_{y'}$, acting on the $+y'$ face of the element in Fig. 9–3*b*, is to be determined, then it is necessary to consider a segment of the element as shown in Fig. 9–3*e* and follow the same procedure just described. Here, however, the shear stress $\tau_{x'y'}$ does not have to be determined if it was previously calculated, since it is complementary, that is, it must have the same magnitude on each of the four faces of the element, Fig. 9–3*b*.









Fig. 9–3

## EXAMPLE 9.1


The state of plane stress at a point on the surface of the airplane fuselage is represented on the element oriented as shown in Fig. 9–4*a*. Represent the state of stress at the point on an element that is oriented 30° clockwise from the position shown.





(a)

### SOLUTION

The rotated element is shown in Fig. 9–4*d*. To obtain the stress component on this element we will first section the element in Fig. 9–4*a* by the line *a*–*a*. The bottom segment is removed, and assuming the sectioned (inclined) plane has an area $\Delta A$, the horizontal and vertical planes have the areas shown in Fig. 9–4*b*. The free-body diagram of this segment is shown in Fig. 9–4*c*. Applying the equations of force equilibrium in the $x'$ and $y'$ directions to avoid a simultaneous solution for the two unknowns $\sigma_{x'}$ and $\tau_{x'y'}$, we have




(b)




(c)

Fig. 9–4

$$+\nearrow \Sigma F_{x'} = 0; \quad \sigma_{x'}\,\Delta A - (50\,\Delta A\cos 30°)\cos 30° + (25\,\Delta A\cos 30°)\sin 30° + (80\,\Delta A\sin 30°)\sin 30° + (25\,\Delta A\sin 30°)\cos 30° = 0$$


$$\sigma_{x'} = -4.15\ \text{MPa} \qquad \textit{Ans.}$$

$$+\nwarrow \Sigma F_{y'} = 0; \quad \tau_{x'y'}\,\Delta A - (50\,\Delta A\cos 30°)\sin 30° - (25\,\Delta A\cos 30°)\cos 30° - (80\,\Delta A\sin 30°)\cos 30° + (25\,\Delta A\sin 30°)\sin 30° = 0$$

$$\tau_{x'y'} = 68.8\ \text{MPa} \qquad \textit{Ans.}$$

Since $\sigma_{x'}$ is negative, it acts in the opposite direction of that shown in Fig. 9–4*c*. The results are shown on the *top* of the element in Fig. 9–4*d*, since this surface is the one considered in Fig. 9–4*c*.

We must now repeat the procedure to obtain the stress on the *perpendicular* plane $b$–$b$. Sectioning the element in Fig. 9–4*a* along $b$–$b$ results in a segment having sides with areas shown in Fig. 9–4*e*. Orienting the $+x'$ axis outward, perpendicular to the sectioned face, the associated free-body diagram is shown in Fig. 9–4*f*. Thus,




(d)

$$+\searrow \Sigma F_{x'} = 0; \quad \sigma_{x'}\,\Delta A - (25\,\Delta A \cos 30^\circ)\sin 30^\circ + (80\,\Delta A \cos 30^\circ)\cos 30^\circ - (25\,\Delta A \sin 30^\circ)\cos 30^\circ - (50\,\Delta A \sin 30^\circ)\sin 30^\circ = 0$$

$$\sigma_{x'} = -25.8 \text{ MPa} \qquad \textit{Ans.}$$

$$+\nearrow \Sigma F_{y'} = 0; \quad -\tau_{x'y'}\,\Delta A + (25\,\Delta A \cos 30^\circ)\cos 30^\circ + (80\,\Delta A \cos 30^\circ)\sin 30^\circ - (25\,\Delta A \sin 30^\circ)\sin 30^\circ + (50\,\Delta A \sin 30^\circ)\cos 30^\circ = 0$$


$$\tau_{x'y'} = 68.8 \text{ MPa} \qquad \textit{Ans.}$$



(e)

Since $\sigma_{x'}$ is a negative quantity, it acts opposite to its direction shown in Fig. 9–4*f*. The stress components are shown acting on the *right side* of the element in Fig. 9–4*d*.

From this analysis we may therefore conclude that the state of stress at the point can be represented by choosing an element oriented as shown in Fig. 9–4*a*, or by choosing one oriented as shown in Fig. 9–4*d*. In other words, these states of stress are equivalent.



(f)


## 9.2 General Equations of Plane-Stress Transformation

The method of transforming the normal and shear stress components from the $x$, $y$ to the $x'$, $y'$ coordinate axes, as discussed in the previous section, can be developed in a general manner and expressed as a set of stress-transformation equations.


**Sign Convention.** First we must establish a sign convention for the stress components. To do this the $+x$ and $+x'$ axes are used to define the outward normal from a side of the element. Then $\sigma_x$ and $\sigma_{x'}$ are positive when they act in the positive $x$ and $x'$ directions, and $\tau_{xy}$ and $\tau_{x'y'}$ are positive when they act in the positive $y$ and $y'$ directions, Fig. 9–5.

The orientation of the plane on which the normal and shear stress components are to be determined will be defined by the angle $\theta$, which is measured from the $+x$ axis to the $+x'$ axis, Fig. 9–5*b*. Notice that the unprimed and primed sets of axes in this figure both form right-handed coordinate systems; that is, the positive $z$ (or $z'$) axis is established by the right-hand rule. Curling the fingers from $x$ (or $x'$) toward $y$ (or $y'$) gives the direction for the positive $z$ (or $z'$) axis that points outward, along the thumb. The *angle* $\theta$ will be *positive* provided it follows the curl of the right-hand fingers, i.e., counterclockwise as shown in Fig. 9–5*b*.

**Normal and Shear Stress Components.** Using the established sign convention, the element in Fig. 9–6*a* is sectioned along the inclined plane and the segment shown in Fig. 9–6*b* is isolated. Assuming the sectioned area is $\Delta A$, then the horizontal and vertical faces of the segment have an area of $\Delta A \sin\theta$ and $\Delta A \cos\theta$, respectively.




(a)




(b)

Positive Sign Convention

Fig. 9–5

The resulting *free-body diagram* of the segment is shown in Fig. 9–6c. Applying the equations of equilibrium to determine the unknown normal and shear stress components $\sigma_{x'}$ and $\tau_{x'y'}$, we have

$$+\nearrow \Sigma F_{x'} = 0; \quad \sigma_{x'}\,\Delta A - (\tau_{xy}\,\Delta A \sin\theta)\cos\theta - (\sigma_y\,\Delta A \sin\theta)\sin\theta - (\tau_{xy}\,\Delta A \cos\theta)\sin\theta - (\sigma_x\,\Delta A \cos\theta)\cos\theta = 0$$

$$\sigma_{x'} = \sigma_x \cos^2\theta + \sigma_y \sin^2\theta + \tau_{xy}(2\sin\theta\cos\theta)$$

$$+\nwarrow \Sigma F_{y'} = 0; \quad \tau_{x'y'}\,\Delta A + (\tau_{xy}\,\Delta A \sin\theta)\sin\theta - (\sigma_y\,\Delta A \sin\theta)\cos\theta - (\tau_{xy}\,\Delta A \cos\theta)\cos\theta + (\sigma_x\,\Delta A \cos\theta)\sin\theta = 0$$

$$\tau_{x'y'} = (\sigma_y - \sigma_x)\sin\theta\cos\theta + \tau_{xy}(\cos^2\theta - \sin^2\theta)$$

These two equations may be simplified by using the trigonometric identities $\sin 2\theta = 2\sin\theta\cos\theta$, $\sin^2\theta = (1 - \cos 2\theta)/2$, and $\cos^2\theta = (1 + \cos 2\theta)/2$, in which case,


$$\sigma_{x'} = \frac{\sigma_x + \sigma_y}{2} + \frac{\sigma_x - \sigma_y}{2}\cos 2\theta + \tau_{xy}\sin 2\theta \tag{9–1}$$

$$\tau_{x'y'} = -\frac{\sigma_x - \sigma_y}{2}\sin 2\theta + \tau_{xy}\cos 2\theta \tag{9–2}$$


If the normal stress acting in the $y'$ direction is needed, it can be obtained by simply substituting $(\theta = \theta + 90°)$ for $\theta$ into Eq. 9–1, Fig. 9–6*d*. This yields

$$\sigma_{y'} = \frac{\sigma_x + \sigma_y}{2} - \frac{\sigma_x - \sigma_y}{2}\cos 2\theta - \tau_{xy}\sin 2\theta \tag{9–3}$$


If $\sigma_{y'}$ is calculated as a positive quantity, it indicates that it acts in the positive $y'$ direction as shown in Fig. 9–6*d*.





(a)




(b)




(c)




(d)

Fig. 9–6


## Procedure for Analysis

To apply the stress transformation Eqs. 9–1 and 9–2, it is simply necessary to substitute in the known data for $\sigma_x$, $\sigma_y$, $\tau_{xy}$, and $\theta$ in accordance with the established sign convention, Fig. 9–5. If $\sigma_{x'}$ and $\tau_{x'y'}$ are calculated as positive quantities, then these stresses act in the positive direction of the $x'$ and $y'$ axes.


For convenience, these equations can easily be programmed on a pocket calculator.

9


## EXAMPLE 9.2





(a)




(b)




(c)




(d)

Fig. 9–7

The state of plane stress at a point is represented by the element shown in Fig. 9–7*a*. Determine the state of stress at the point on another element oriented 30° clockwise from the position shown.

### SOLUTION

This problem was solved in Example 9.1 using basic principles. Here we will apply Eqs. 9–1 and 9–2. From the established sign convention, Fig. 9–5, it is seen that

$$\sigma_x = -80\ \text{MPa} \qquad \sigma_y = 50\ \text{MPa} \qquad \tau_{xy} = -25\ \text{MPa}$$

**Plane *CD*.** To obtain the stress components on plane *CD*, Fig. 9–7*b*, the positive $x'$ axis is directed outward, perpendicular to *CD*, and the associated $y'$ axis is directed along *CD*. The angle measured from the $x$ to the $x'$ axis is $\theta = -30°$ (clockwise). Applying Eqs. 9–1 and 9–2 yields

$$\begin{aligned}\sigma_{x'} &= \frac{\sigma_x + \sigma_y}{2} + \frac{\sigma_x - \sigma_y}{2}\cos 2\theta + \tau_{xy}\sin 2\theta \\ &= \frac{-80 + 50}{2} + \frac{-80 - 50}{2}\cos 2(-30°) + (-25)\sin 2(-30°) \\ &= -25.8\ \text{MPa} \qquad \textit{Ans.}\end{aligned}$$

$$\begin{aligned}\tau_{x'y'} &= -\frac{\sigma_x - \sigma_y}{2}\sin 2\theta + \tau_{xy}\cos 2\theta \\ &= -\frac{-80 - 50}{2}\sin 2(-30°) + (-25)\cos 2(-30°) \\ &= -68.8\ \text{MPa} \qquad \textit{Ans.}\end{aligned}$$

The negative signs indicate that $\sigma_{x'}$ and $\tau_{x'y'}$ act in the negative $x'$ and $y'$ directions, respectively. The results are shown acting on the element in Fig. 9–7*d*.

**Plane *BC*.** In a similar manner, the stress components acting on face *BC*, Fig. 9–7*c*, are obtained using $\theta = 60°$. Applying Eqs. 9–1 and 9–2,* we get

$$\begin{aligned}\sigma_{x'} &= \frac{-80 + 50}{2} + \frac{-80 - 50}{2}\cos 2(60°) + (-25)\sin 2(60°) \\ &= -4.15\ \text{MPa} \qquad \textit{Ans.}\end{aligned}$$

$$\begin{aligned}\tau_{x'y'} &= -\frac{-80 - 50}{2}\sin 2(60°) + (-25)\cos 2(60°) \\ &= 68.8\ \text{MPa} \qquad \textit{Ans.}\end{aligned}$$

Here $\tau_{x'y'}$ has been calculated twice in order to provide a check. The negative sign for $\sigma_{y'}$ indicates that this stress acts in the negative $x'$ direction, Fig. 9–7*c*. The results are shown on the element in Fig. 9–7*d*.

*Alternatively, we could apply Eq. 9–3 with $\theta = -30°$ rather than Eq. 9–1.

9

## 9.3 Principal Stresses and Maximum In-Plane Shear Stress

From Eqs. 9–1 and 9–2, it can be seen that the magnitudes of $\sigma_{x'}$ and $\tau_{x'y'}$ depend on the angle of inclination $\theta$ of the planes on which these stresses act. In engineering practice it is often important to determine the orientation of the element that causes the normal stress to be a maximum and a minimum and the orientation that causes the shear stress to be a maximum. In this section each of these problems will be considered.

**In-Plane Principal Stresses.** To determine the maximum and minimum *normal stress*, we must differentiate Eq. 9–1 with respect to $\theta$ and set the result equal to zero. This gives

$$\frac{d\sigma_{x'}}{d\theta} = -\frac{\sigma_x - \sigma_y}{2}(2\sin 2\theta) + 2\tau_{xy}\cos 2\theta = 0$$

Solving this equation we obtain the orientation $\theta = \theta_p$ of the planes of maximum and minimum normal stress.

$$\tan 2\theta_p = \frac{\tau_{xy}}{(\sigma_x - \sigma_y)/2} \tag{9–4}$$

The solution has two roots, $\theta_{p_1}$ and $\theta_{p_2}$. Specifically, the values of $2\theta_{p_1}$ and $2\theta_{p_2}$ are 180° apart, so $\theta_{p_1}$ and $\theta_{p_2}$ will be 90° apart.

The values of $\theta_{p_1}$ and $\theta_{p_2}$ must be substituted into Eq. 9–1 if we are to obtain the required normal stresses. To do this we can obtain the necessary sine and cosine of $2\theta_{p_1}$ and $2\theta_{p_2}$ from the shaded triangles shown in Fig. 9–8. The construction of these triangles is based on Eq. 9–4, assuming that $\tau_{xy}$ and $(\sigma_x - \sigma_y)$ are both positive or both negative quantities.





Fig. 9–8



The cracks in this concrete beam were caused by tension stress, even though the beam was subjected to both an internal moment and shear. The stress-transformation equations can be used to predict the direction of the cracks, and the principal normal stresses that caused them.

Substituting these trigonometric values into Eq. 9–1 and simplifying, we obtain

$$\sigma_{1,2} = \frac{\sigma_x + \sigma_y}{2} \pm \sqrt{\left(\frac{\sigma_x - \sigma_y}{2}\right)^2 + \tau_{xy}^2} \tag{9–5}$$

Depending upon the sign chosen, this result gives the maximum or minimum in-plane normal stress acting at a point, where $\sigma_1 \geq \sigma_2$. This particular set of values are called the in-plane ***principal stresses***, and the corresponding planes on which they act are called the ***principal planes*** of stress, Fig. 9–9. Furthermore, if the trigonometric relations for $\theta_{p_1}$ or $\theta_{p_2}$ are substituted into Eq. 9–2, it can be seen that $\tau_{x'y'} = 0$; in other words, ***no shear stress acts on the principal planes***.





Fig. 9–9

**Maximum In-Plane Shear Stress.** The orientation of an element that is subjected to maximum shear stress on its sides can be determined by taking the derivative of Eq. 9–2 with respect to $\theta$ and setting the result equal to zero. This gives

$$\tan 2\theta_s = \frac{-(\sigma_x - \sigma_y)/2}{\tau_{xy}} \tag{9–6}$$

The two roots of this equation, $\theta_{s_1}$ and $\theta_{s_2}$, can be determined from the shaded triangles shown in Fig. 9–10. By comparison with Eq. 9–4, $\tan 2\theta_s$ is the negative reciprocal of $\tan 2\theta_p$, and so each root $2\theta_s$ is 90° from $2\theta_p$, and the roots $\theta_s$ and $\theta_p$ are 45° apart. Therefore, an element subjected to ***maximum shear stress will be 45° from the position of an element that is subjected to the principal stress.***

Using either one of the roots $\theta_{s_1}$ or $\theta_{s_2}$, the maximum shear stress can be found by taking the trigonometric values of $\sin 2\theta_s$ and $\cos 2\theta_s$ from Fig. 9–10 and substituting them into Eq. 9–2. The result is

$$\tau_{\substack{\text{max}\\ \text{in-plane}}} = \sqrt{\left(\frac{\sigma_x - \sigma_y}{2}\right)^2 + \tau_{xy}^2} \tag{9–7}$$

The value of $\tau_{\substack{\text{max}\\ \text{in-plane}}}$ as calculated from this equation is referred to as the ***maximum in-plane shear stress*** because it acts on the element in the $x$–$y$ plane.

Substituting the values for $\sin 2\theta_s$ and $\cos 2\theta_s$ into Eq. 9–1, we see that there is *also* an average normal stress on the planes of maximum in-plane shear stress. We get

$$\sigma_{avg} = \frac{\sigma_x + \sigma_y}{2} \tag{9–8}$$

Like the stress-transformation equations, it may be convenient to program Eqs. 9–4 through 9–8 for use on a pocket calculator.





Fig. 9–10


## Important Points

- The *principal stresses* represent the maximum and minimum normal stress at the point.
- When the state of stress is represented by the principal stresses, *no shear stress* will act on the element.
- The state of stress at the point can also be represented in terms of the *maximum in-plane shear stress*. In this case an *average normal stress* will also act on the element.
- The element representing the maximum in-plane shear stress with the associated average normal stresses is *oriented* 45° from the element representing the principal stresses.


## EXAMPLE 9.3




Notice how the failure plane is at an angle (23.7°) due to tearing of the material, Fig. 9–11c.




(a)




(b)




(c) **Fig. 9–11**

The state of plane stress at a failure point on the shaft is shown on the element in Fig. 9–11*a*. Represent this stress state in terms of the principal stresses.

### SOLUTION

From the established sign convention, we have

$$\sigma_x = -20\ \text{MPa} \qquad \sigma_y = 90\ \text{MPa} \qquad \tau_{xy} = 60\ \text{MPa}$$

**Orientation of Element.** Applying Eq. 9–4,

$$\tan 2\theta_p = \frac{\tau_{xy}}{(\sigma_x - \sigma_y)/2} = \frac{60}{(-20 - 90)/2}$$

Solving, and referring to this root as $\theta_{p_2}$, as will be shown below, yields

$$2\theta_{p_2} = -47.49° \qquad \theta_{p_2} = -23.7°$$

Since the difference between $2\theta_{p_1}$ and $2\theta_{p_2}$ is 180°, we have

$$2\theta_{p_1} = 180° + 2\theta_{p_2} = 132.51° \qquad \theta_{p_1} = 66.3°$$

Recall that $\theta$ is measured positive *counterclockwise* from the $x$ axis to the outward normal ($x'$ axis) on the face of the element, and so the results are shown in Fig. 9–11*b*.

**Principal Stress.** We have

$$\sigma_{1,2} = \frac{\sigma_x + \sigma_y}{2} \pm \sqrt{\left(\frac{\sigma_x - \sigma_y}{2}\right)^2 + \tau_{xy}^2}$$

$$= \frac{-20 + 90}{2} \pm \sqrt{\left(\frac{-20 - 90}{2}\right)^2 + (60)^2}$$

$$= 35.0 \pm 81.4$$

$$\sigma_1 = 116\ \text{MPa} \qquad \textit{Ans.}$$

$$\sigma_2 = -46.4\ \text{MPa} \qquad \textit{Ans.}$$

The principal plane on which each normal stress acts can be determined by applying Eq. 9–1 with, say, $\theta = \theta_{p_2} = -23.7°$. We have

$$\sigma_{x'} = \frac{\sigma_x + \sigma_y}{2} + \frac{\sigma_x - \sigma_y}{2}\cos 2\theta + \tau_{xy}\sin 2\theta$$


$$= \frac{-20 + 90}{2} + \frac{-20 - 90}{2}\cos 2(-23.7°) + 60\sin 2(-23.7°)$$

$$= -46.4\ \text{MPa}$$

Hence, $\sigma_2 = -46.4$ MPa acts on the plane defined by $\theta_{p_2} = -23.7°$, whereas $\sigma_1 = 116$ MPa acts on the plane defined by $\theta_{p_1} = 66.3°$. The results are shown on the element in Fig. 9–11*c*. Recall that no shear stress acts on this element.

## EXAMPLE 9.4

The state of plane stress at a point on a body is represented on the element shown in Fig. 9–12*a*. Represent this stress state in terms of the maximum in-plane shear stress and associated average normal stress.




(a)

### SOLUTION


**Orientation of Element.** Since $\sigma_x = -20$ MPa, $\sigma_y = 90$ MPa, and $\tau_{xy} = 60$ MPa, applying Eq. 9–6, we have

$$\tan 2\theta_s = \frac{-(\sigma_x - \sigma_y)/2}{\tau_{xy}} = \frac{-(-20 - 90)/2}{60}$$

$$2\theta_{s_2} = 42.5^\circ \qquad \theta_{s_2} = 21.3^\circ$$

$$2\theta_{s_1} = 180^\circ + 2\theta_{s_2} \qquad \theta_{s_1} = 111.3^\circ$$

Note that these angles shown in Fig. 9–12*b* are 45° away from the principal planes of stress, which were determined in Example 9.3.




(b)

**Maximum In-Plane Shear Stress.** Applying Eq. 9–7,

$$\tau_{\text{in-plane}}^{\max} = \sqrt{\left(\frac{\sigma_x - \sigma_y}{2}\right)^2 + \tau_{xy}^2} = \sqrt{\left(\frac{-20 - 90}{2}\right)^2 + (60)^2}$$

$$= \pm 81.4 \text{ MPa} \qquad \textit{Ans.}$$


The proper direction of $\tau_{\text{in-plane}}^{\max}$ on the element can be determined by substituting $\theta = \theta_{s_1} = 21.3^\circ$ into Eq. 9–2. We have

$$\tau_{x'y'} = -\left(\frac{\sigma_x - \sigma_y}{2}\right)\sin 2\theta + \tau_{xy}\cos 2\theta$$

$$= -\left(\frac{-20 - 90}{2}\right)\sin 2(21.3^\circ) + 60\cos 2(21.3^\circ)$$

$$= 81.4 \text{ MPa}$$

This positive result indicates that $\tau_{\text{in-plane}}^{\max} = \tau_{x'y'}$ acts in the *positive* $y'$ direction on this face ($\theta = 21.3^\circ$) Fig. 9–12*b*. The shear stresses on the other three faces are directed as shown in Fig. 9–12*c*.




(c)

Fig. 9–12

**Average Normal Stress.** Besides the maximum shear stress, as calculated above, the element is also subjected to an average normal stress determined from Eq. 9–8; that is,

$$\sigma_{\text{avg}} = \frac{\sigma_x + \sigma_y}{2} = \frac{-20 + 90}{2} = 35 \text{ MPa} \qquad \textit{Ans.}$$


This is a tensile stress. The results are shown in Fig. 9–12*c*.

## EXAMPLE 9.5




(a)






(b)

Fig. 9–13

When the torsional loading $T$ is applied to the bar in Fig. 9–13*a*, it produces a state of pure shear stress in the material. Determine (a) the maximum in-plane shear stress and the associated average normal stress, and (b) the principal stress.

SOLUTION

From the established sign convention,

$$\sigma_x = 0 \qquad \sigma_y = 0 \qquad \tau_{xy} = -\tau$$

**Maximum In-Plane Shear Stress.** Applying Eqs. 9–7 and 9–8, we have

$$\tau_{\text{max in plane}} = \sqrt{\left(\frac{\sigma_x - \sigma_y}{2}\right)^2 + \tau_{xy}^2} = \sqrt{(0)^2 + (-\tau)^2} = \pm\tau \qquad \textit{Ans.}$$

$$\sigma_{\text{avg}} = \frac{\sigma_x + \sigma_y}{2} = \frac{0 + 0}{2} = 0 \qquad \textit{Ans.}$$

Thus, as expected, the maximum in-plane shear stress is represented by the element in Fig. 9–13*a*.

**NOTE:** Through experiment it has been found that materials that are *ductile* will *fail* due to *shear stress*. As a result, if the bar in Fig. 9–13*a* is made of mild steel, the maximum in-plane shear stress will cause it to fail as shown in the adjacent photo.

**Principal Stress.** Applying Eqs. 9–4 and 9–5 yields

$$\tan 2\theta_p = \frac{\tau_{xy}}{(\sigma_x - \sigma_y)/2} = \frac{-\tau}{(0 - 0)/2}, \quad \theta_{p_2} = 45°, \theta_{p_1} = -45°$$

$$\sigma_{1,2} = \frac{\sigma_x + \sigma_y}{2} \pm \sqrt{\left(\frac{\sigma_x - \sigma_y}{2}\right)^2 + \tau_{xy}^2} = 0 \pm \sqrt{(0)^2 + \tau^2} = \pm\tau \qquad \textit{Ans.}$$

If we now apply Eq. 9–1 with $\theta_{p_2} = 45°$, then

$$\sigma_{x'} = \frac{\sigma_x + \sigma_y}{2} + \frac{\sigma_x - \sigma_y}{2}\cos 2\theta + \tau_{xy}\sin 2\theta$$
$$= 0 + 0 + (-\tau)\sin 90° = -\tau$$

Thus, $\sigma_2 = -\tau$ acts at $\theta_{p_2} = 45°$ as shown in Fig. 9–13*b*, and $\sigma_1 = \tau$ acts on the other face, $\theta_{p_1} = -45°$.


**NOTE:** Materials that are *brittle* fail due to *normal stress*. Therefore, if the bar in Fig. 9–13*a* is made of cast iron it will fail in tension at a 45° inclination as seen in the adjacent photo.



9

## EXAMPLE 9.6

When the axial loading $P$ is applied to the bar in Fig. 9–14*a*, it produces a tensile stress in the material. Determine (a) the principal stress and (b) the maximum in-plane shear stress and associated average normal stress.



(a)



### SOLUTION

From the established sign convention,

$$\sigma_x = \sigma \qquad \sigma_y = 0 \qquad \tau_{xy} = 0$$

**Principal Stress.** By observation, the element oriented as shown in Fig. 9–14*a* illustrates a condition of principal stress since no shear stress acts on this element. This can also be shown by direct substitution of the above values into Eqs. 9–4 and 9–5. Thus,

$$\sigma_1 = \sigma \qquad \sigma_2 = 0 \qquad \textit{Ans.}$$


**NOTE:** Experiments have shown that *brittle materials* will fail due to normal stress. Thus if the bar in Fig. 9–14*a* is made of cast iron, it will cause failure as shown in the adjacent photo.

**Maximum In-Plane Shear Stress.** Applying Eqs. 9–6, 9–7, and 9–8, we have

$$\tan 2\theta_s = \frac{-(\sigma_x - \sigma_y)/2}{\tau_{xy}} = \frac{-(\sigma - 0)/2}{0}; \quad \theta_{s_1} = 45°, \theta_{s_2} = -45°$$

$$\tau_{\text{in-plane}}^{\text{max}} = \sqrt{\left(\frac{\sigma_x - \sigma_y}{2}\right)^2 + \tau_{xy}^2} = \sqrt{\left(\frac{\sigma - 0}{2}\right)^2 + (0)^2} = \pm\frac{\sigma}{2} \qquad \textit{Ans.}$$

$$\sigma_{\text{avg}} = \frac{\sigma_x + \sigma_y}{2} = \frac{\sigma + 0}{2} = \frac{\sigma}{2} \qquad \textit{Ans.}$$



(b)

Fig. 9–14

To determine the proper orientation of the element, apply Eq. 9–2.

$$\tau_{x'y'} = -\frac{\sigma_x - \sigma_y}{2}\sin 2\theta + \tau_{xy}\cos 2\theta = -\frac{\sigma - 0}{2}\sin 90° + 0 = -\frac{\sigma}{2}$$

This negative shear stress acts on the $x'$ face, in the negative $y'$ direction as shown in Fig. 9–14*b*.


**NOTE:** If the bar in Fig. 9–14*a* is made of a *ductile material* such as mild steel then *shear stress* will cause it to fail. This can be noted in the adjacent photo, where within the region of necking, shear stress has caused "slipping" along the steel's crystalline boundaries, resulting in a plane of failure that has formed a *cone* around the bar oriented at approximately 45° as calculated above.



9


## FUNDAMENTAL PROBLEMS

**F9–1.** Determine the normal stress and shear stress acting on the inclined plane $AB$. Sketch the result on the sectioned element.





F9–1

**F9–2.** Determine the equivalent state of stress on an element at the same point oriented 45° clockwise with respect to the element shown.





F9–2

**F9–3.** Determine the equivalent state of stress on an element at the same point that represents the principal stresses at the point. Also, find the corresponding orientation of the element with respect to the element shown.





F9–3

**F9–4.** Determine the equivalent state of stress on an element at the same point that represents the maximum in-plane shear stress at the point.





F9–4

**F9–5.** The beam is subjected to the load at its end. Determine the maximum principal stress at point $B$.




F9–5

**F9–6.** The beam is subjected to the loading shown. Determine the principal stress at point $C$.





F9–6

## PROBLEMS


**9–1.** Prove that the sum of the normal stresses $\sigma_x + \sigma_y = \sigma_{x'} + \sigma_{y'}$ is constant. See Figs. 9–2*a* and 9–2*b*.

**9–2.** The state of stress at a point in a member is shown on the element. Determine the stress components acting on the inclined plane *AB*. Solve the problem using the method of equilibrium described in Sec. 9.1.




Prob. 9–2


**9–3.** The state of stress at a point in a member is shown on the element. Determine the stress components acting on the inclined plane *AB*. Solve the problem using the method of equilibrium described in Sec. 9.1.




Prob. 9–3

***9–4.** The state of stress at a point in a member is shown on the element. Determine the stress components acting on the inclined plane *AB*. Solve the problem using the method of equilibrium described in Sec. 9.1.


**•9–5.** Solve Prob. 9–4 using the stress-transformation equations developed in Sec. 9.2.




Probs. 9–4/5

**9–6.** The state of stress at a point in a member is shown on the element. Determine the stress components acting on the inclined plane *AB*. Solve the problem using the method of equilibrium described in Sec. 9.1.


**9–7.** Solve Prob. 9–6 using the stress-transformation equations developed in Sec. 9.2. Show the result on a sketch.




Probs. 9–6/7

*9–8. Determine the normal stress and shear stress acting on the inclined plane $AB$. Solve the problem using the method of equilibrium described in Sec. 9.1.


•9–9. Determine the normal stress and shear stress acting on the inclined plane $AB$. Solve the problem using the stress transformation equations. Show the result on the sectioned element.




Probs. 9–8/9


9–10. The state of stress at a point in a member is shown on the element. Determine the stress components acting on the inclined plane $AB$. Solve the problem using the method of equilibrium described in Sec. 9.1.

9–11. Solve Prob. 9–10 using the stress-transformation equations developed in Sec. 9.2. Show the result on a sketch.





Probs. 9–10/11

*9–12. Determine the equivalent state of stress on an element if it is oriented 50° counterclockwise from the element shown. Use the stress-transformation equations.





Prob. 9–12

•9–13. Determine the equivalent state of stress on an element if the element is oriented 60° clockwise from the element shown. Show the result on a sketch.





Prob. 9–13

9–14. The state of stress at a point is shown on the element. Determine (a) the principal stress and (b) the maximum in-plane shear stress and average normal stress at the point. Specify the orientation of the element in each case. Show the results on each element.





Prob. 9–14

9–15. The state of stress at a point is shown on the element. Determine (a) the principal stress and (b) the maximum in-plane shear stress and average normal stress at the point. Specify the orientation of the element in each case. Show the results on each element.





Prob. 9–15

***9–16.** The state of stress at a point is shown on the element. Determine (a) the principal stress and (b) the maximum in-plane shear stress and average normal stress at the point. Specify the orientation of the element in each case. Sketch the results on each element.





**Prob. 9–16**

**•9–17.** Determine the equivalent state of stress on an element at the same point which represents (a) the principal stress, and (b) the maximum in-plane shear stress and the associated average normal stress. Also, for each case, determine the corresponding orientation of the element with respect to the element shown. Sketch the results on each element.





**Prob. 9–17**

**9–18.** A point on a thin plate is subjected to the two successive states of stress shown. Determine the resultant state of stress represented on the element oriented as shown on the right.





**Prob. 9–18**

**9–19.** The state of stress at a point is shown on the element. Determine (a) the principal stress and (b) the maximum in-plane shear stress and average normal stress at the point. Specify the orientation of the element in each case. Sketch the results on each element.





**Prob. 9–19**

***9–20.** The stress acting on two planes at a point is indicated. Determine the normal stress $\sigma_b$ and the principal stresses at the point.




**Prob. 9–20**

**•9–21.** The stress acting on two planes at a point is indicated. Determine the shear stress on plane $a$–$a$ and the principal stresses at the point.





**Prob. 9–21**

9

The following problems involve material covered in Chapter 8.


**9–22.** The T-beam is subjected to the distributed loading that is applied along its centerline. Determine the principal stress at point $A$ and show the results on an element located at this point.




Prob. 9–22


**•9–23.** The wood beam is subjected to a load of 12 kN. If a grain of wood in the beam at point $A$ makes an angle of 25° with the horizontal as shown, determine the normal and shear stress that act perpendicular and parallel to the grain due to the loading.

**•9–24.** The wood beam is subjected to a load of 12 kN. Determine the principal stress at point $A$ and specify the orientation of the element.




Probs. 9–23/24


**•9–25.** The bent rod has a diameter of 20 mm and is subjected to the force of 400 N. Determine the principal stress and the maximum in-plane shear stress that is developed at point $A$. Show the results on a properly oriented element located at this point.




Prob. 9–25


**9–26.** The bracket is subjected to the force of 3 kip. Determine the principal stress and maximum in-plane shear stress at point $A$ on the cross section at section $a$–$a$. Specify the orientation of this state of stress and show the results on elements.

**9–27.** The bracket is subjected to the force of 3 kip. Determine the principal stress and maximum in-plane shear stress at point $B$ on the cross section at section $a$–$a$. Specify the orientation of this state of stress and show the results on elements.





Probs. 9–26/27

***9–28.** The wide-flange beam is subjected to the loading shown. Determine the principal stress in the beam at point $A$ and at point $B$. These points are located at the top and bottom of the web, respectively. Although it is not very accurate, use the shear formula to determine the shear stress.





Prob. 9–28

**•9–29.** The wide-flange beam is subjected to the loading shown. Determine the principal stress in the beam at point $A$, which is located at the top of the web. Although it is not very accurate, use the shear formula to determine the shear stress. Show the result on an element located at this point.




Prob. 9–29


**9–30.** The cantilevered rectangular bar is subjected to the force of 5 kip. Determine the principal stress at points $A$ and $B$.




Prob. 9–30


**9–31.** Determine the principal stress at point $A$ on the cross section of the arm at section $a$–$a$. Specify the orientation of this state of stress and indicate the results on an element at the point.

***9–32.** Determine the maximum in-plane shear stress developed at point $A$ on the cross section of the arm at section $a$–$a$. Specify the orientation of this state of stress and indicate the results on an element at the point.





Probs. 9–31/32

•**9–33.** The clamp bears down on the smooth surface at $E$ by tightening the bolt. If the tensile force in the bolt is 40 kN, determine the principal stress at points $A$ and $B$ and show the results on elements located at each of these points. The cross-sectional area at $A$ and $B$ is shown in the adjacent figure.





Prob. 9–33

**9–34.** Determine the principal stress and the maximum in-plane shear stress that are developed at point $A$ in the 2-in.-diameter shaft. Show the results on an element located at this point. The bearings only support vertical reactions.





Prob. 9–34

**9–35.** The square steel plate has a thickness of 10 mm and is subjected to the edge loading shown. Determine the maximum in-plane shear stress and the average normal stress developed in the steel.





Prob. 9–35

*9–36. The square steel plate has a thickness of 0.5 in. and is subjected to the edge loading shown. Determine the principal stresses developed in the steel.




Prob. 9–36


•**9–37.** The shaft has a diameter $d$ and is subjected to the loadings shown. Determine the principal stress and the maximum in-plane shear stress that is developed at point $A$. The bearings only support vertical reactions.




Prob. 9–37

**9–38.** A paper tube is formed by rolling a paper strip in a spiral and then gluing the edges together as shown. Determine the shear stress acting along the seam, which is at 30° from the vertical, when the tube is subjected to an axial force of 10 N. The paper is 1 mm thick and the tube has an outer diameter of 30 mm.


**9–39.** Solve Prob. 9–38 for the normal stress acting perpendicular to the seam.




**Probs. 9–38/39**


*9–40. Determine the principal stresses acting at point $A$ of the supporting frame. Show the results on a properly oriented element located at this point.

•9–41. Determine the principal stress acting at point $B$, which is located just on the web, below the horizontal segment on the cross section. Show the results on a properly oriented element located at this point. Although it is not very accurate, use the shear formula to calculate the shear stress.





**Probs. 9–40/41**

**9–42.** The drill pipe has an outer diameter of 3 in., a wall thickness of 0.25 in., and a weight of 50 lb/ft. If it is subjected to a torque and axial load as shown, determine (a) the principal stress and (b) the maximum in-plane shear stress at a point on its surface at section $a$.




**Prob. 9–42**


**9–43.** Determine the principal stress in the beam at point $A$.




**Prob. 9–43**

9


*9–44. Determine the principal stress at point $A$ which is located at the bottom of the web. Show the results on an element located at this point.




Prob. 9–44

•9–45. Determine the maximum in-plane shear stress in the box beam at point $A$. Show the results on an element located at this point.


9–46. Determine the principal stress in the box beam at point $B$. Show the results on an element located at this point.




Probs. 9–45/46


9–47. The solid shaft is subjected to a torque, bending moment, and shear force as shown. Determine the principal stresses acting at point $A$.

*9–48. Solve Prob. 9–47 for point $B$.





Probs. 9–47/48

•9–49. The internal loadings at a section of the beam are shown. Determine the principal stress at point $A$. Also compute the maximum in-plane shear stress at this point.




Prob. 9–49

9–50. The internal loadings at a section of the beam consist of an axial force of 500 N, a shear force of 800 N, and two moment components of 30 N·m and 40 N·m. Determine the principal stress at point $A$. Also calculate the maximum in-plane shear stress at this point.




Prob. 9–50

## 9.4 Mohr's Circle—Plane Stress

In this section, we will show how to apply the equations for plane stress transformation using a graphical solution that is often convenient to use and easy to remember. Furthermore, this approach will allow us to "visualize" how the normal and shear stress components $\sigma_{x'}$ and $\tau_{x'y'}$ vary as the plane on which they act is oriented in different directions, Fig. 9–15*a*.

If we write Eqs. 9–1 and 9–2 in the form

$$\sigma_{x'} - \left(\frac{\sigma_x + \sigma_y}{2}\right) = \left(\frac{\sigma_x - \sigma_y}{2}\right)\cos 2\theta + \tau_{xy}\sin 2\theta \qquad (9\text{–}9)$$

$$\tau_{x'y'} = -\left(\frac{\sigma_x - \sigma_y}{2}\right)\sin 2\theta + \tau_{xy}\cos 2\theta \qquad (9\text{–}10)$$

then the parameter $\theta$ can be *eliminated* by squaring each equation and adding the equations together. The result is

$$\left[\sigma_{x'} - \left(\frac{\sigma_x + \sigma_y}{2}\right)\right]^2 + \tau_{x'y'}^2 = \left(\frac{\sigma_x - \sigma_y}{2}\right)^2 + \tau_{xy}^2$$

For a specific problem, $\sigma_x$, $\sigma_y$, $\tau_{xy}$ are *known constants*. Thus the above equation can be written in a more compact form as


$$(\sigma_{x'} - \sigma_{avg})^2 + \tau_{x'y'}^2 = R^2 \qquad (9\text{–}11)$$

where


$$\sigma_{avg} = \frac{\sigma_x + \sigma_y}{2}$$

$$R = \sqrt{\left(\frac{\sigma_x - \sigma_y}{2}\right)^2 + \tau_{xy}^2} \qquad (9\text{–}12)$$

If we establish coordinate axes, $\sigma$ *positive to the right* and $\tau$ *positive downward*, and then plot Eq. 9–11, it will be seen that this equation represents a *circle* having a radius $R$ and center on the $\sigma$ axis at point $C(\sigma_{avg}, 0)$, Fig. 9–15*b*. This circle is called *Mohr's circle*, because it was developed by the German engineer Otto Mohr.





(b)




(a)

Fig. 9–15





(a)


Each point on Mohr's circle represents the two stress components $\sigma_{x'}$ and $\tau_{x'y'}$ acting on the side of the element defined by the $x'$ axis, when the axis is in a specific direction $\theta$. For example, when $x'$ is coincident with the $x$ axis as shown in Fig. 9–16*a*, then $\theta = 0°$ and $\sigma_{x'} = \sigma_x$, $\tau_{x'y'} = \tau_{xy}$. We will refer to this as the "reference point" $A$ and plot its coordinates $A(\sigma_x, \tau_{xy})$, Fig. 9–16*c*.

Now consider rotating the $x'$ axis 90° counterclockwise, Fig. 9–16*b*. Then $\sigma_{x'} = \sigma_y$, $\tau_{x'y'} = -\tau_{xy}$. These values are the coordinates of point $G(\sigma_y, -\tau_{xy})$ on the circle, Fig. 9–16*c*. Hence, the radial line $CG$ is 180° counterclockwise from the "reference line" $CA$. In other words, a rotation $\theta$ of the $x'$ axis on the element will correspond to a rotation $2\theta$ on the circle in the *same direction*.*

Once constructed, Mohr's circle can be used to determine the principal stresses, the maximum in-plane shear stress and associated average normal stress, or the stress on any arbitrary plane.




(b)




(c)

**Fig. 9–16**

*If instead the $\tau$ axis were established *positive upwards*, then the angle $2\theta$ on the circle would be measured in the *opposite direction* to the orientation $\theta$ of the plane.

## Procedure for Analysis

The following steps are required to draw and use Mohr's circle.

### Construction of the Circle.

- Establish a coordinate system such that the horizontal axis represents the normal stress $\sigma$, with *positive to the right*, and the vertical axis represents the shear stress $\tau$, with *positive downwards*, Fig. 9–17*a*.*
- Using the positive sign convention for $\sigma_x$, $\sigma_y$, $\tau_{xy}$, as shown in Fig. 9–17*b*, plot the center of the circle $C$, which is located on the $\sigma$ axis at a distance $\sigma_{avg} = (\sigma_x + \sigma_y)/2$ from the origin, Fig. 9–17*a*.
- Plot the "reference point" $A$ having coordinates $A(\sigma_x, \tau_{xy})$. This point represents the normal and shear stress components on the element's right-hand vertical face, and since the $x'$ axis coincides with the $x$ axis, this represents $\theta = 0°$, Fig. 9–17*a*.
- Connect point $A$ with the center $C$ of the circle and determine $CA$ by trigonometry. This distance represents the radius $R$ of the circle, Fig. 9–17*a*.
- Once $R$ has been determined, sketch the circle.

### Principal Stress.

- The principal stresses $\sigma_1$ and $\sigma_2$ ($\sigma_1 \geq \sigma_2$) are the coordinates of points $B$ and $D$ where the circle intersects the $\sigma$ axis, i.e., where $\tau = 0$, Fig. 9–17*a*.
- These stresses act on planes defined by angles $\theta_{p_1}$ and $\theta_{p_2}$, Fig. 9–17*c*. They are represented on the circle by angles $2\theta_{p_1}$ (shown) and $2\theta_{p_2}$ (not shown) and are measured *from* the radial reference line $CA$ *to* lines $CB$ and $CD$, respectively.
- Using trigonometry, only one of these angles needs to be calculated from the circle, since $\theta_{p_1}$ and $\theta_{p_2}$ are 90° apart. Remember that the direction of rotation $2\theta_p$ on the circle (here it happens to be counterclockwise) represents the *same* direction of rotation $\theta_p$ from the reference axis ($+x$) to the principal plane ($+x'$), Fig. 9–17*c*.*

### Maximum In-Plane Shear Stress.

- The average normal stress and maximum in-plane shear stress components are determined from the circle as the coordinates of either point $E$ or $F$, Fig. 9–17*a*.
- In this case the angles $\theta_{s_1}$ and $\theta_{s_2}$ give the orientation of the planes that contain these components, Fig. 9–17*d*. The angle $2\theta_{s_1}$ is shown in Fig. 9–17*a* and can be determined using trigonometry. Here the rotation happens to be clockwise, from $CA$ to $CE$, and so $\theta_{s_1}$ must be clockwise on the element, Fig. 9–17*d*.*

## Procedure for Analysis (continued)

### Stresses on Arbitrary Plane.

- The normal and shear stress components $\sigma_{x'}$ and $\tau_{x'y'}$ acting on a specified plane or $x'$ axis, defined by the angle $\theta$, Fig. 9–17*e*, can be obtained from the circle using trigonometry to determine the coordinates of point $P$, Fig. 9–17*a*.
- To locate $P$, the known angle $\theta$ (in this case counterclockwise), Fig. 9–17*e*, must be measured on the circle in the *same direction* $2\theta$ (counterclockwise), *from* the radial reference line $CA$ *to* the radial line $CP$, Fig. 9–17*a*.*

*If the $\tau$ axis were constructed *positive upwards*, then the angle $2\theta$ on the circle would be measured in the *opposite direction* to the orientation $\theta$ of the $x'$ axis.






Fig. 9–17

## EXAMPLE 9.7

Due to the applied loading, the element at point $A$ on the solid shaft in Fig. 9–18*a* is subjected to the state of stress shown. Determine the principal stresses acting at this point.




### SOLUTION

**Construction of the Circle.** From Fig. 9–18*a*,

$$\sigma_x = -12 \text{ ksi} \qquad \sigma_y = 0 \qquad \tau_{xy} = -6 \text{ ksi}$$

The center of the circle is at

$$\sigma_{avg} = \frac{-12 + 0}{2} = -6 \text{ ksi}$$

The reference point $A(-12, -6)$ and the center $C(-6, 0)$ are plotted in Fig. 9–18*b*. The circle is constructed having a radius of

$$R = \sqrt{(12 - 6)^2 + (6)^2} = 8.49 \text{ ksi}$$

**Principal Stress.** The principal stresses are indicated by the coordinates of points $B$ and $D$. We have, for $\sigma_1 > \sigma_2$,


$$\sigma_1 = 8.49 - 6 = 2.49 \text{ ksi} \qquad \textit{Ans.}$$

$$\sigma_2 = -6 - 8.49 = -14.5 \text{ ksi} \qquad \textit{Ans.}$$

The orientation of the element can be determined by calculating the angle $2\theta_{p_2}$ in Fig. 9–18*b*, which here is measured *counterclockwise* from $CA$ to $CD$. It defines the direction $\theta_{p_2}$ of $\sigma_2$ and its associated principal plane. We have

$$2\theta_{p_2} = \tan^{-1}\frac{6}{12 - 6} = 45.0°$$

$$\theta_{p_2} = 22.5°$$




The element is oriented such that the $x'$ axis or $\sigma_2$ is directed 22.5° *counterclockwise* from the horizontal ($x$ axis) as shown in Fig. 9–18*c*.







Fig. 9–18

9


## EXAMPLE 9.8




(a)




(b)




(c)

Fig. 9–19

The state of plane stress at a point is shown on the element in Fig. 9–19*a*. Determine the maximum in-plane shear stress at this point.

### SOLUTION

**Construction of the Circle.** From the problem data,

$$\sigma_x = -20 \text{ MPa} \qquad \sigma_y = 90 \text{ MPa} \qquad \tau_{xy} = 60 \text{ MPa}$$

The $\sigma, \tau$ axes are established in Fig. 9–19*b*. The center of the circle $C$ is located on the $\sigma$ axis, at the point

$$\sigma_{avg} = \frac{-20 + 90}{2} = 35 \text{ MPa}$$

Point $C$ and the reference point $A(-20, 60)$ are plotted. Applying the Pythagorean theorem to the shaded triangle to determine the circle's radius $CA$, we have

$$R = \sqrt{(60)^2 + (55)^2} = 81.4 \text{ MPa}$$

**Maximum In-Plane Shear Stress.** The maximum in-plane shear stress and the average normal stress are identified by point $E$ (or $F$) on the circle. The coordinates of point $E(35, 81.4)$ give

$$\tau_{\text{in-plane}}^{\text{max}} = 81.4 \text{ MPa} \qquad \textit{Ans.}$$

$$\sigma_{avg} = 35 \text{ MPa} \qquad \textit{Ans.}$$

The angle $\theta_{s_1}$, measured *counterclockwise* from $CA$ to $CE$, can be found from the circle, identified as $2\theta_{s_1}$. We have


$$2\theta_{s_1} = \tan^{-1}\left(\frac{20 + 35}{60}\right) = 42.5°$$

$$\theta_{s_1} = 21.3° \qquad \textit{Ans.}$$

This *counterclockwise* angle defines the direction of the $x'$ axis, Fig. 9–19*c*. Since point $E$ has *positive* coordinates, then the average normal stress and the maximum in-plane shear stress both act in the *positive* $x'$ and $y'$ directions as shown.

## EXAMPLE 9.9

The state of plane stress at a point is shown on the element in Fig. 9–20*a*. Represent this state of stress on an element oriented 30° counterclockwise from the position shown.



(a)

### SOLUTION

**Construction of the Circle.** From the problem data,


$$\sigma_x = -8 \text{ ksi} \qquad \sigma_y = 12 \text{ ksi} \qquad \tau_{xy} = -6 \text{ ksi}$$

The $\sigma$ and $\tau$ axes are established in Fig. 9–20*b*. The center of the circle $C$ is on the $\sigma$ axis at

$$\sigma_{avg} = \frac{-8 + 12}{2} = 2 \text{ ksi}$$

The reference point for $\theta = 0°$ has coordinates $A(-8, -6)$. Hence from the shaded triangle the radius $CA$ is

$$R = \sqrt{(10)^2 + (6)^2} = 11.66$$



(b)

**Stresses on 30° Element.** Since the element is to be rotated 30° *counterclockwise*, we must construct a radial line $CP$, $2(30°) = 60°$ *counterclockwise*, measured from $CA$ ($\theta = 0°$), Fig. 9–20*b*. The coordinates of point $P(\sigma_{x'}, \tau_{x'y'})$ must now be obtained. From the geometry of the circle,

$$\phi = \tan^{-1}\frac{6}{10} = 30.96° \qquad \psi = 60° - 30.96° = 29.04°$$

$$\sigma_{x'} = 2 - 11.66 \cos 29.04° = -8.20 \text{ ksi} \qquad \textit{Ans}$$


$$\tau_{x'y'} = 11.66 \sin 29.04° = 5.66 \text{ ksi} \qquad \textit{Ans}$$

These two stress components act on face $BD$ of the element shown in Fig. 9–20*c* since the $x'$ axis for this face is oriented 30° *counterclockwise* from the $x$ axis.

The stress components acting on the adjacent face $DE$ of the element, which is 60° *clockwise* from the positive $x$ axis, Fig. 9–20*c*, are represented by the coordinates of point $Q$ on the circle. This point lies on the radial line $CQ$, which is 180° from $CP$. The coordinates of point $Q$ are

$$\sigma_{x'} = 2 + 11.66 \cos 29.04° = 12.2 \text{ ksi} \qquad \textit{Ans}$$

$$\tau_{x'y'} = -(11.66 \sin 29.04) = -5.66 \text{ ksi} \quad \text{(check)} \qquad \textit{Ans}$$




(c)

**NOTE:** Here $\tau_{x'y'}$ acts in the $-y'$ direction.

Fig. 9–20


## FUNDAMENTAL PROBLEMS

**F9–7.** Determine the normal stress and shear stress acting on the inclined plane $AB$. Sketch the result on the sectioned element.





F9–7

**F9–8.** Determine the equivalent state of stress on an element at the same point that represents the principal stresses at the point. Also, find the corresponding orientation of the element with respect to the element shown. Sketch the results on the element.





F9–8

**F9–9.** The hollow circular shaft is subjected to the torque of 4 kN · m. Determine the principal stress developed at a point on the surface of the shaft.





F9–9

**F9–10.** Determine the principal stress developed at point $A$ on the cross section of the beam at section $a$–$a$.




F9–10

**F9–11.** Determine the maximum in-plane shear stress developed at point $A$ on the cross section of the beam at section $a$–$a$, which is located just to the left of the 60-kN force. Point $A$ is just below the flange.




F9–11

## PROBLEMS

**9–51.** Solve Prob. 9–4 using Mohr's circle.

***9–52.** Solve Prob. 9–6 using Mohr's circle.

**•9–53.** Solve Prob. 9–14 using Mohr's circle.


**9–54.** Solve Prob. 9–16 using Mohr's circle.

**9–55.** Solve Prob. 9–12 using Mohr's circle.

***9–56.** Solve Prob. 9–11 using Mohr's circle.


**9–57.** Mohr's circle for the state of stress in Fig. 9–15*a* is shown in Fig. 9–15*b*. Show that finding the coordinates of point $P(\sigma_{x'}, \tau_{x'y'})$ on the circle gives the same value as the stress-transformation Eqs. 9–1 and 9–2.

**9–58.** Determine the equivalent state of stress if an element is oriented 25° counterclockwise from the element shown.





Prob. 9–58

**9–59.** Determine the equivalent state of stress if an element is oriented 20° clockwise from the element shown.





Prob. 9–59

***9–60.** Determine the equivalent state of stress if an element is oriented 30° clockwise from the element shown. Show the result on the element.




Prob. 9–60


**•9–61.** Determine the equivalent state of stress for an element oriented 60° counterclockwise from the element shown. Show the result on the element.




Prob. 9–61


9

**9–62.** Determine the equivalent state of stress for an element oriented 30° clockwise from the element shown. Show the result on the element.





Prob. 9–62

**9–63.** Determine the principal stress, the maximum in-plane shear stress, and average normal stress. Specify the orientation of the element in each case.





Prob. 9–63

***9–64.** Determine the principal stress, the maximum in-plane shear stress, and average normal stress. Specify the orientation of the element in each case.





Prob. 9–64

**•9–65.** Determine the principal stress, the maximum in-plane shear stress, and average normal stress. Specify the orientation of the element in each case.





Prob. 9–65

**9–66.** Determine the principal stress, the maximum in-plane shear stress, and average normal stress. Specify the orientation of the element in each case.





Prob. 9–66

**9–67.** Determine the principal stress, the maximum in-plane shear stress, and average normal stress. Specify the orientation of the element in each case.




Prob. 9–67

***9–68.** Draw Mohr's circle that describes each of the following states of stress.





Prob. 9–68

The following problems involve material covered in Chapter 8.


**9–69.** The frame supports the distributed loading of 200 N/m. Determine the normal and shear stresses at point $D$ that act perpendicular and parallel, respectively, to the grain. The grain at this point makes an angle of 30° with the horizontal as shown.

**9–70.** The frame supports the distributed loading of 200 N/m. Determine the normal and shear stresses at point $E$ that act perpendicular and parallel, respectively, to the grain. The grain at this point makes an angle of 60° with the horizontal as shown.




Probs. 9–69/70

**9–71.** The stair tread of the escalator is supported on two of its sides by the moving pin at $A$ and the roller at $B$. If a man having a weight of 300 lb stands in the center of the tread, determine the principal stresses developed in the supporting truck on the cross section at point $C$. The stairs move at constant velocity.




Prob. 9–71


***9–72.** The thin-walled pipe has an inner diameter of 0.5 in. and a thickness of 0.025 in. If it is subjected to an internal pressure of 500 psi and the axial tension and torsional loadings shown, determine the principal stress at a point on the surface of the pipe.




Prob. 9–72

**•9–73.** The cantilevered rectangular bar is subjected to the force of 5 kip. Determine the principal stress at point $A$.

**9–74.** Solve Prob. 9–73 for the principal stress at point $B$.




Probs. 9–73/74


**9–75.** The 2-in.-diameter drive shaft $AB$ on the helicopter is subjected to an axial tension of 10 000 lb and a torque of 300 lb · ft. Determine the principal stress and the maximum in-plane shear stress that act at a point on the surface of the shaft.




Prob. 9–75

9


*9–76. The pedal crank for a bicycle has the cross section shown. If it is fixed to the gear at $B$ and does not rotate while subjected to a force of 75 lb, determine the principal stress in the material on the cross section at point $C$.




Prob. 9–76

•9–77. A spherical pressure vessel has an inner radius of 5 ft and a wall thickness of 0.5 in. Draw Mohr's circle for the state of stress at a point on the vessel and explain the significance of the result. The vessel is subjected to an internal pressure of 80 psi.


9–78. The cylindrical pressure vessel has an inner radius of 1.25 m and a wall thickness of 15 mm. It is made from steel plates that are welded along the 45° seam. Determine the normal and shear stress components along this seam if the vessel is subjected to an internal pressure of 8 MPa.




Prob. 9–78

•9–79. Determine the normal and shear stresses at point $D$ that act perpendicular and parallel, respectively, to the grains. The grains at this point make an angle of 30° with the horizontal as shown. Point $D$ is located just to the left of the 10-kN force.


*9–80. Determine the principal stress at point $D$, which is located just to the left of the 10-kN force.




Probs. 9–79/80

•9–81. Determine the principal stress at point $A$ on the cross section of the hanger at section $a$–$a$. Specify the orientation of this state of stress and indicate the result on an element at the point.


9–82. Determine the principal stress at point $A$ on the cross section of the hanger at section $b$–$b$. Specify the orientation of the state of stress and indicate the results on an element at the point.




Sections $a-a$ and $b-b$

Probs. 9–81/82

9–83. Determine the principal stresses and the maximum in-plane shear stress that are developed at point $A$. Show the results on an element located at this point. The rod has a diameter of 40 mm.





Prob. 9–83


## 9.5 Absolute Maximum Shear Stress

When a point in a body is subjected to a general three-dimensional state of stress, an element of material has a normal-stress and two shear-stress components acting on each of its faces, Fig. 9–21*a*. Like the case of plane stress, it is possible to develop stress-transformation equations that can be used to determine the normal and shear stress components $\sigma$ and $\tau$ acting on *any* skewed plane of the element, Fig. 9–21*b*. Furthermore, at the point it is also possible to determine the unique orientation of an element having only principal stresses acting on its faces. As shown in Fig. 9–21*c*, in general these principal stresses will have magnitudes of maximum, intermediate, and minimum intensity, i.e., $\sigma_{max} \geq \sigma_{int} \geq \sigma_{min}$. This is a condition known as ***triaxial stress***.


A discussion of the transformation of stress in three dimensions is beyond the scope of this text; however, it is discussed in books related to the theory of elasticity. For our purposes, we will confine our attention only to the case of plane stress. For example, consider the



(a)





(b)





triaxial stress

(c)


Fig. 9–21




(b)





(c)




(d)

Fig. 9–22





x–y plane stress

(a)

material to be subjected to the in-plane principal stresses $\sigma_1$ and $\sigma_2$ shown in Fig. 9–22*a*, where *both* of these stresses are tensile. If we view the element in two dimensions, that is, in the $y$–$z$, $x$–$z$, and $x$–$y$ planes, Fig. 9–22*b*, 9–22*c*, and 9–22*d*, then we can use Mohr's circle to determine the maximum in-plane shear for each case and from this, determine the *absolute maximum shear stress* in the material. For example, the diameter of Mohr's circle extends between 0 and $\sigma_2$ for the case shown in Fig. 9–22*b*. From this circle, Fig. 9–22*e*, the maximum in-plane shear stress is $\tau_{y'z'} = \sigma_2/2$. For all three circles, it is seen that although the maximum in-plane shear stress is $\tau_{x'y'} = (\sigma_1 - \sigma_2)/2$, this value is *not* the absolute maximum shear stress. Instead, from Fig. 9–22*e*,

$$\tau_{\text{abs}}_{\text{max}} = \frac{\sigma_1}{2} \qquad (9\text{–}13)$$

$\sigma_1$ and $\sigma_2$ have the same sign




(e)





**Fig. 9–23**

If one of the in-plane principal stresses has the *opposite sign* of that of the other, Fig. 9–23*a*, then the three Mohr's circles that describe the state of stress for element orientations about each coordinate axis are shown in Fig. 9–23*b*. Clearly, in this case

$$\tau_{\substack{abs\\max}} = \frac{\sigma_1 - \sigma_2}{2} \qquad (9\text{–}14)$$

$\sigma_1$ and $\sigma_2$ have opposite signs


Calculation of the absolute maximum shear stress as indicated here is important when designing members made of a ductile material, since the strength of the material depends on its ability to resist shear stress. This situation will be discussed further in Sec. 10.7.

## Important Points

- The general three-dimensional state of stress at a point can be represented by an element oriented so that only three principal stresses $\sigma_{max}$, $\sigma_{int}$, $\sigma_{min}$ act on it.
- In the case of plane stress, if the in-plane principal stresses both have the *same sign*, the *absolute maximum shear stress* will occur *out of the plane* and has a value of $\tau_{\substack{abs\\max}} = \sigma_{max}/2$. This value is greater than the in-plane shear stress.
- If the in-plane principal stresses are of *opposite signs*, then the *absolute maximum shear stress will equal the maximum in-plane shear stress*; that is, $\tau_{\substack{abs\\max}} = (\sigma_{max} - \sigma_{min})/2$.

## EXAMPLE 9.10

The point on the surface of the cylindrical pressure vessel in Fig. 9–24*a* is subjected to the state of plane stress. Determine the absolute maximum shear stress at this point.




### SOLUTION

The principal stresses are $\sigma_1 = 32$ MPa, $\sigma_2 = 16$ MPa. If these stresses are plotted along the $\sigma$ axis, the three Mohr's circles can be constructed that describe the stress state viewed in each of the three perpendicular planes, Fig. 9–24*b*. The largest circle has a radius of 16 MPa and describes the state of stress in the plane only containing $\sigma_1 = 32$ MPa, shown shaded in Fig. 9–24*a*. An orientation of an element 45° within this plane yields the state of absolute maximum shear stress and the associated average normal stress, namely,

$$\tau_{abs_{max}} = 16 \text{ MPa} \qquad \textit{Ans.}$$

$$\sigma_{avg} = 16 \text{ MPa}$$





Fig. 9–24

This same result for $\tau_{abs_{max}}$ can be obtained from direct application of Eq. 9–13.

$$\tau_{abs_{max}} = \frac{\sigma_1}{2} = \frac{32}{2} = 16 \text{ MPa} \qquad \textit{Ans.}$$

$$\sigma_{avg} = \frac{32 + 0}{2} = 16 \text{ MPa}$$


By comparison, the maximum in-plane shear stress can be determined from the Mohr's circle drawn between $\sigma_1 = 32$ MPa and $\sigma_2 = 16$ MPa, Fig. 9–24*b*. This gives a value of

$$\tau_{max_{in\text{-}plane}} = \frac{32 - 16}{2} = 8 \text{ MPa}$$

$$\sigma_{avg} = \frac{32 + 16}{2} = 24 \text{ MPa}$$

## EXAMPLE 9.11

Due to an applied loading, an element at the point on a machine shaft is subjected to the state of plane stress shown in Fig. 9–25*a*. Determine the principal stresses and the absolute maximum shear stress at the point.




(a)

### SOLUTION

**Principal Stresses.** The in-plane principal stresses can be determined from Mohr's circle. The center of the circle is on the $\sigma$ axis at $\sigma_{avg} = (-20 + 0)/2 = -10$ psi. Plotting the reference point $A(-20, -40)$, the radius $CA$ is established and the circle is drawn as shown in Fig. 9–25*b*. The radius is

$$R = \sqrt{(20 - 10)^2 + (40)^2} = 41.2 \text{ psi}$$

The principal stresses are at the points where the circle intersects the $\sigma$ axis; i.e.,

$$\sigma_1 = -10 + 41.2 = 31.2 \text{ psi}$$
$$\sigma_2 = -10 - 41.2 = -51.2 \text{ psi}$$

From the circle, the *counterclockwise* angle $2\theta$, measured from $CA$ to the $-\sigma$ axis, is


$$2\theta = \tan^{-1}\left(\frac{40}{20 - 10}\right) = 76.0°$$

Thus,


$$\theta = 38.0°$$

This *counterclockwise* rotation defines the direction of the $x'$ axis and $\sigma_2$ and its associated principal plane, Fig. 9–25*c*. We have

$$\sigma_1 = 31.2 \text{ psi} \qquad \sigma_2 = -51.2 \text{ psi} \qquad \textit{Ans.}$$




(b)





(c)

**Absolute Maximum Shear Stress.** Since these stresses have opposite signs, applying Eq. 9–14 we have

$$\tau_{\substack{abs \\ max}} = \frac{\sigma_1 - \sigma_2}{2} = \frac{31.2 - (-51.2)}{2} = 41.2 \text{ psi} \qquad \textit{Ans.}$$

$$\sigma_{avg} = \frac{31.2 - 51.2}{2} = -10 \text{ psi}$$

**NOTE:** These same results can also be obtained by drawing Mohr's circle for each orientation of an element about the $x$, $y$, and $z$ axes, Fig. 9–25*d*. Since $\sigma_1$ and $\sigma_2$ are of *opposite signs*, then the absolute maximum shear stress equals the maximum in-plane shear stress.





(d)

Fig. 9–25


## PROBLEMS

*9–84. Draw the three Mohr's circles that describe each of the following states of stress.





Prob. 9–84

•9–85. Draw the three Mohr's circles that describe the following state of stress.





Prob. 9–85

9–86. The stress at a point is shown on the element. Determine the principal stress and the absolute maximum shear stress.





Prob. 9–86

9–87. The stress at a point is shown on the element. Determine the principal stress and the absolute maximum shear stress.





Prob. 9–87

*9–88. The stress at a point is shown on the element. Determine the principal stress and the absolute maximum shear stress.





Prob. 9–88

•9–89. The stress at a point is shown on the element. Determine the principal stress and the absolute maximum shear stress.





Prob. 9–89

9–90. The state of stress at a point is shown on the element. Determine the principal stress and the absolute maximum shear stress.





Prob. 9–90

9–91. Consider the general case of plane stress as shown. Write a computer program that will show a plot of the three Mohr's circles for the element, and will also calculate the maximum in-plane shear stress and the absolute maximum shear stress.





Prob. 9–91

*9–92. The solid shaft is subjected to a torque, bending moment, and shear force as shown. Determine the principal stress acting at points $A$ and $B$ and the absolute maximum shear stress.




Prob. 9–92


•9–93. The propane gas tank has an inner diameter of 1500 mm and wall thickness of 15 mm. If the tank is pressurized to 2 MPa, determine the absolute maximum shear stress in the wall of the tank.



Prob. 9–93

9–94. Determine the principal stress and absolute maximum shear stress developed at point $A$ on the cross section of the bracket at section $a$–$a$.

9–95. Determine the principal stress and absolute maximum shear stress developed at point $B$ on the cross section of the bracket at section $a$–$a$.





Probs. 9–94/95

## CHAPTER REVIEW

Plane stress occurs when the material at a point is subjected to two normal stress components $\sigma_x$ and $\sigma_y$ and a shear stress $\tau_{xy}$. Provided these components are known, then the stress components acting on an element having a different orientation $\theta$ can be determined using the two force equations of equilibrium or the equations of stress transformation.

$$\sigma_{x'} = \frac{\sigma_x + \sigma_y}{2} + \frac{\sigma_x - \sigma_y}{2}\cos 2\theta + \tau_{xy}\sin 2\theta$$

$$\tau_{x'y'} = -\frac{\sigma_x - \sigma_y}{2}\sin 2\theta + \tau_{xy}\cos 2\theta$$





For design, it is important to determine the orientation of the element that produces the maximum principal normal stresses and the maximum in-plane shear stress. Using the stress transformation equations, it is found that no shear stress acts on the planes of principal stress. The principal stresses are

$$\sigma_{1,2} = \frac{\sigma_x + \sigma_y}{2} \pm \sqrt{\left(\frac{\sigma_x - \sigma_y}{2}\right)^2 + \tau_{xy}^2}$$

The planes of maximum in-plane shear stress are oriented 45° from this orientation, and on these shear planes there is an associated average normal stress.


$$\tau_{\text{max in-plane}} = \sqrt{\left(\frac{\sigma_x - \sigma_y}{2}\right)^2 + \tau_{xy}^2}$$

$$\sigma_{\text{avg}} = \frac{\sigma_x + \sigma_y}{2}$$




9

Mohr's circle provides a semi-graphical method for finding the stress on any plane, the principal normal stresses, and the maximum in-plane shear stress. To draw the circle, the $\sigma$ and $\tau$ axes are established, the center of the circle $C[(\sigma_x + \sigma_y)/2, 0]$ and the reference point $A(\sigma_x, \tau_{xy})$ are plotted. The radius $R$ of the circle extends between these two points and is determined from trigonometry.





If $\sigma_1$ and $\sigma_2$ are of the same sign, then the absolute maximum shear stress will lie out of plane.


$$\tau_{\substack{abs \\ max}} = \frac{\sigma_1}{2}$$

In the case of plane stress, the absolute maximum shear stress will be equal to the maximum in-plane shear stress provided the principal stresses $\sigma_1$ and $\sigma_2$ have the opposite sign.

$$\tau_{\substack{abs \\ max}} = \frac{\sigma_1 - \sigma_2}{2}$$




$x$–y plane stress




$x$–y plane stress

## REVIEW PROBLEMS

***9–96.** The solid propeller shaft on a ship extends outward from the hull. During operation it turns at $\omega = 15$ rad/s when the engine develops 900 kW of power. This causes a thrust of $F = 1.23$ MN on the shaft. If the shaft has an outer diameter of 250 mm, determine the principal stresses at any point located on the surface of the shaft.


**•9–97.** The solid propeller shaft on a ship extends outward from the hull. During operation it turns at $\omega = 15$ rad/s when the engine develops 900 kW of power. This causes a thrust of $F = 1.23$ MN on the shaft. If the shaft has a diameter of 250 mm, determine the maximum in-plane shear stress at any point located on the surface of the shaft.




Probs. 9–96/97


**9–98.** The steel pipe has an inner diameter of 2.75 in. and an outer diameter of 3 in. If it is fixed at $C$ and subjected to the horizontal 20-lb force acting on the handle of the pipe wrench at its end, determine the principal stresses in the pipe at point $A$, which is located on the surface of the pipe.

**9–99.** Solve Prob. 9–98 for point $B$, which is located on the surface of the pipe.





Probs. 9–98/99

***9–100.** The clamp exerts a force of 150 lb on the boards at $G$. Determine the axial force in each screw, $AB$ and $CD$, and then compute the principal stresses at points $E$ and $F$. Show the results on properly oriented elements located at these points. The section through $EF$ is rectangular and is 1 in. wide.





Prob. 9–100

**9–101.** The shaft has a diameter $d$ and is subjected to the loadings shown. Determine the principal stress and the maximum in-plane shear stress that is developed anywhere on the surface of the shaft.





Prob. 9–101

**9–102.** The state of stress at a point in a member is shown on the element. Determine the stress components acting on the plane $AB$.





Prob. 9–102

**9–103.** The propeller shaft of the tugboat is subjected to the compressive force and torque shown. If the shaft has an inner diameter of 100 mm and an outer diameter of 150 mm, determine the principal stress at a point $A$ located on the outer surface.





Prob. 9–103

***9–104.** The box beam is subjected to the loading shown. Determine the principal stress in the beam at points $A$ and $B$.





Prob. 9–104

**•9–105.** The wooden strut is subjected to the loading shown. Determine the principal stresses that act at point $C$ and specify the orientation of the element at this point. The strut is supported by a bolt (pin) at $B$ and smooth support at $A$.





Prob. 9–105

**9–106.** The wooden strut is subjected to the loading shown. If grains of wood in the strut at point $C$ make an angle of 60° with the horizontal as shown, determine the normal and shear stresses that act perpendicular and parallel to the grains, respectively, due to the loading. The strut is supported by a bolt (pin) at $B$ and smooth support at $A$.




Prob. 9–106

9



Complex stresses developed within this airplane wing are analyzed from strain gauge data.
*(Courtesy of Measurements Group, Inc., Raleigh, North Carolina, 27611, USA.)*

# Strain Transformation


# 10

## CHAPTER OBJECTIVES

The transformation of strain at a point is similar to the transformation of stress, and as a result the methods of Chapter 9 will be applied in this chapter. Here we will also discuss various ways for measuring strain and develop some important material-property relationships, including a generalized form of Hooke's law. At the end of the chapter, a few of the theories used to predict the failure of a material will be discussed.

## 10.1 Plane Strain

As outlined in Sec. 2.2, the general state of strain at a point in a body is represented by a combination of three components of normal strain, $\epsilon_x$, $\epsilon_y$, $\epsilon_z$, and three components of shear strain $\gamma_{xy}$, $\gamma_{xz}$, $\gamma_{yz}$. These six components tend to deform each face of an element of the material, and like stress, the normal and shear strain *components* at the point will vary according to the orientation of the element. The *strains* at a point are often determined by using strain gauges, which measure normal strain in *specified directions*. For both analysis and design, however, engineers must sometimes transform this data in order to obtain the strain in other directions.





Plane stress, $\sigma_x$, $\sigma_y$, does not cause plane strain in the $x$–$y$ plane since $\epsilon_z \neq 0$.


**Fig. 10–1**

To understand how this is done, we will first confine our attention to a study of ***plane strain***. Specifically, we will not consider the effects of the components $\epsilon_z$, $\gamma_{xz}$, and $\gamma_{yz}$. In general, then, a plane-strained element is subjected to two components of normal strain, $\epsilon_x$, $\epsilon_y$, and one component of shear strain, $\gamma_{xy}$. Although plane strain and plane stress each have three components lying in the same plane, realize that plane stress *does not* necessarily cause plane strain or vice versa. The reason for this has to do with the Poisson effect discussed in Sec. 3.6. For example, if the element in Fig. 10–1 is subjected to plane stress $\sigma_x$ and $\sigma_y$, not only are normal strains $\epsilon_x$ and $\epsilon_y$ produced, but there is *also* an associated normal strain, $\epsilon_z$. This is obviously *not* a case of plane strain. In general, then, unless $\nu = 0$, the Poisson effect will *prevent* the simultaneous occurrence of plane strain and plane stress.

## 10.2 General Equations of Plane-Strain Transformation

It is important in plane-strain analysis to establish transformation equations that can be used to determine the $x'$, $y'$ components of normal and shear strain at a point, provided the $x$, $y$ components of strain are known. Essentially this problem is one of geometry and requires relating the deformations and rotations of line segments, which represent the sides of differential elements that are parallel to each set of axes.




Positive sign convention

**Fig. 10–2**

**Sign Convention.** Before the strain-transformation equations can be developed, we must first establish a sign convention for the strains. With reference to the differential element shown in Fig. 10–2*a*, *normal strains* $\epsilon_x$ and $\epsilon_y$ are *positive* if they cause *elongation* along the $x$ and $y$ axes, respectively, and the *shear strain* $\gamma_{xy}$ is *positive* if the interior angle $AOB$ *becomes smaller* than 90°. This sign convention also follows the corresponding one used for plane stress, Fig. 9–5*a*, that is, positive $\sigma_x$, $\sigma_y$, $\tau_{xy}$ will cause the element to *deform* in the positive $\epsilon_x$, $\epsilon_y$, $\gamma_{xy}$ directions, respectively.

The problem here will be to determine at a point the normal and shear strains $\epsilon_{x'}$, $\epsilon_{y'}$, $\gamma_{x'y'}$, measured relative to the $x'$, $y'$ axes, if we know $\epsilon_x$, $\epsilon_y$, $\gamma_{xy}$, measured relative to the $x$, $y$ axes. If the angle between the $x$ and $x'$ axes is $\theta$, then, like the case of plane stress, $\theta$ will be *positive* provided it follows the curl of the right-hand fingers, i.e., counterclockwise, as shown in Fig. 10–2*b*.

**Normal and Shear Strains.** In order to develop the strain-transformation equation for $\epsilon_{x'}$, we must determine the elongation of a line segment $dx'$ that lies along the $x'$ axis and is subjected to strain components $\epsilon_x$, $\epsilon_y$, $\gamma_{xy}$. As shown in Fig. 10–3*a*, the components of the line $dx'$ along the $x$ and $y$ axes are

$$\begin{aligned} dx &= dx' \cos\theta \\ dy &= dx' \sin\theta \end{aligned} \tag{10–1}$$

When the positive normal strain $\epsilon_x$ occurs, the line $dx$ is elongated $\epsilon_x\, dx$, Fig. 10–3*b*, which causes line $dx'$ to elongate $\epsilon_x\, dx \cos\theta$. Likewise, when $\epsilon_y$ occurs, line $dy$ elongates $\epsilon_y\, dy$, Fig. 10–3*c*, which causes line $dx'$ to elongate $\epsilon_y\, dy \sin\theta$. Finally, assuming that $dx$ remains fixed in position, the shear strain $\gamma_{xy}$, which is the change in angle between $dx$ and $dy$, causes the top of line $dy$ to be displaced $\gamma_{xy}\, dy$ to the right, as shown in Fig. 10–3*d*. This causes $dx'$ to elongate $\gamma_{xy}\, dy \cos\theta$. If all three of these elongations are added together, the resultant elongation of $dx'$ is then


$$\delta x' = \epsilon_x\, dx \cos\theta + \epsilon_y\, dy \sin\theta + \gamma_{xy}\, dy \cos\theta$$

From Eq. 2–2, the normal strain along the line $dx'$ is $\epsilon_{x'} = \delta x'/dx'$. Using Eq. 10–1, we therefore have

$$\epsilon_{x'} = \epsilon_x \cos^2\theta + \epsilon_y \sin^2\theta + \gamma_{xy} \sin\theta \cos\theta \tag{10–2}$$




The rubber specimen is constrained between the two fixed supports, and so it will undergo plane strain when loads are applied to it in the horizontal plane.





Before deformation

(a)





Normal strain $\epsilon_x$

(b)




Normal strain $\epsilon_y$

(c)




Shear strain $\gamma_{xy}$

(d)

**Fig. 10–3**





Fig. 10–3 (cont.)

The strain-transformation equation for $\gamma_{x'y'}$ can be developed by considering the amount of rotation each of the line segments $dx'$ and $dy'$ undergo when subjected to the strain components $\epsilon_x$, $\epsilon_y$, $\gamma_{xy}$. First we will consider the rotation of $dx'$, which is defined by the counterclockwise angle $\alpha$ shown in Fig. 10–3*e*. It can be determined by the displacement caused by $\delta y'$ using $\alpha = \delta y'/dx'$. To obtain $\delta y'$, consider the following three displacement components acting in the $y'$ direction: one from $\epsilon_x$, giving $-\epsilon_x\, dx \sin\theta$, Fig. 10–3*b*; another from $\epsilon_y$, giving $\epsilon_y\, dy \cos\theta$, Fig. 10–3*c*; and the last from $\gamma_{xy}$, giving $-\gamma_{xy}\, dy \sin\theta$, Fig. 10–3*d*. Thus, $\delta y'$, as caused by all three strain components, is

$$\delta y' = -\epsilon_x\, dx \sin\theta + \epsilon_y\, dy \cos\theta - \gamma_{xy}\, dy \sin\theta$$

Dividing each term by $dx'$ and using Eq. 10–1, with $\alpha = \delta y'/dx'$, we have

$$\alpha = (-\epsilon_x + \epsilon_y)\sin\theta\cos\theta - \gamma_{xy}\sin^2\theta \qquad (10\text{–}3)$$

As shown in Fig. 10–3*e*, the line $dy'$ rotates by an amount $\beta$. We can determine this angle by a similar analysis, or by simply substituting $\theta + 90°$ for $\theta$ into Eq. 10–3. Using the identities $\sin(\theta + 90°) = \cos\theta$, $\cos(\theta + 90°) = -\sin\theta$, we have

$$\begin{aligned}\beta &= (-\epsilon_x + \epsilon_y)\sin(\theta + 90°)\cos(\theta + 90°) - \gamma_{xy}\sin^2(\theta + 90°)\\ &= -(-\epsilon_x + \epsilon_y)\cos\theta\sin\theta - \gamma_{xy}\cos^2\theta\end{aligned}$$

Since $\alpha$ and $\beta$ represent the rotation of the sides $dx'$ and $dy'$ of a differential element whose sides were originally oriented along the $x'$ and $y'$ axes, Fig. 10–3*e*, the element is then subjected to a shear strain of

$$\gamma_{x'y'} = \alpha - \beta = -2(\epsilon_x - \epsilon_y)\sin\theta\cos\theta + \gamma_{xy}(\cos^2\theta - \sin^2\theta) \qquad (10\text{–}4)$$

10





Fig. 10–4

Using the trigonometric identities $\sin 2\theta = 2\sin\theta\cos\theta$, $\cos^2\theta = (1 + \cos 2\theta)/2$, and $\sin^2\theta + \cos^2\theta = 1$, we can rewrite Eqs. 10–2 and 10–4 in the final form

$$\epsilon_{x'} = \frac{\epsilon_x + \epsilon_y}{2} + \frac{\epsilon_x - \epsilon_y}{2}\cos 2\theta + \frac{\gamma_{xy}}{2}\sin 2\theta \tag{10–5}$$

$$\frac{\gamma_{x'y'}}{2} = -\left(\frac{\epsilon_x - \epsilon_y}{2}\right)\sin 2\theta + \frac{\gamma_{xy}}{2}\cos 2\theta \tag{10–6}$$

These strain-transformation equations give the normal strain $\epsilon_{x'}$ in the $x'$ direction and the shear strain $\gamma_{x'y'}$ of an element oriented at an angle $\theta$, as shown in Fig. 10–4. According to the established sign convention, if $\epsilon_{x'}$ is *positive*, the element *elongates* in the positive $x'$ direction, Fig. 10–4*a*, and if $\gamma_{x'y'}$ is positive, the element deforms as shown in Fig. 10–4*b*.

If the normal strain in the $y'$ direction is required, it can be obtained from Eq. 10–5 by simply substituting $(\theta + 90°)$ for $\theta$. The result is

$$\epsilon_{y'} = \frac{\epsilon_x + \epsilon_y}{2} - \frac{\epsilon_x - \epsilon_y}{2}\cos 2\theta - \frac{\gamma_{xy}}{2}\sin 2\theta \tag{10–7}$$

The similarity between the above three equations and those for plane-stress transformation, Eqs. 9–1, 9–2, and 9–3, should be noted. By comparison, $\sigma_x$, $\sigma_y$, $\sigma_{x'}$, $\sigma_{y'}$ correspond to $\epsilon_x$, $\epsilon_y$, $\epsilon_{x'}$, $\epsilon_{y'}$; and $\tau_{xy}$, $\tau_{x'y'}$ correspond to $\gamma_{xy}/2$, $\gamma_{x'y'}/2$.



Complex stresses are often developed at the joints where the cylindrical and hemispherical vessels are joined together. The stresses are determined by making measurements of strain.

**Principal Strains.** Like stress, an element can be oriented at a point so that the element's deformation is caused only by normal strains, with *no* shear strain. When this occurs the normal strains are referred to as *principal strains*, and if the material is isotropic, the axes along which these strains occur will coincide with the axes that define the planes of principal stress.

From Eqs. 9–4 and 9–5, and the correspondence between stress and strain mentioned above, the direction of the $x'$ axis and the two values of the principal strains $\epsilon_1$ and $\epsilon_2$ are determined from

$$\tan 2\theta_p = \frac{\gamma_{xy}}{\epsilon_x - \epsilon_y} \tag{10–8}$$

$$\epsilon_{1,2} = \frac{\epsilon_x + \epsilon_y}{2} \pm \sqrt{\left(\frac{\epsilon_x - \epsilon_y}{2}\right)^2 + \left(\frac{\gamma_{xy}}{2}\right)^2} \tag{10–9}$$

**Maximum In-Plane Shear Strain.** Using Eqs. 9–6, 9–7, and 9–8, the direction of the $x'$ axis, and the maximum in-plane shear strain and associated average normal strain are determined from the following equations:

$$\tan 2\theta_s = -\left(\frac{\epsilon_x - \epsilon_y}{\gamma_{xy}}\right) \tag{10–10}$$

$$\frac{\gamma_{\text{in-plane}}^{\max}}{2} = \sqrt{\left(\frac{\epsilon_x - \epsilon_y}{2}\right)^2 + \left(\frac{\gamma_{xy}}{2}\right)^2} \tag{10–11}$$


$$\epsilon_{\text{avg}} = \frac{\epsilon_x + \epsilon_y}{2} \tag{10–12}$$

## Important Points


- In the case of plane stress, plane-strain analysis may be used within the plane of the stresses to analyze the data from strain gauges. Remember, though, there will be a normal strain that is perpendicular to the gauges due to the Poisson effect.
- When the state of strain is represented by the principal strains, no shear strain will act on the element.
- The state of strain at a point can also be represented in terms of the maximum in-plane shear strain. In this case an average normal strain will also act on the element.
- The element representing the maximum in-plane shear strain and its associated average normal strains is 45° from the orientation of an element representing the principal strains.

## EXAMPLE 10.1

A differential element of material at a point is subjected to a state of plane strain $\epsilon_x = 500(10^{-6})$, $\epsilon_y = -300(10^{-6})$, $\gamma_{xy} = 200(10^{-6})$, which tends to distort the element as shown in Fig. 10–5*a*. Determine the equivalent strains acting on an element of the material oriented at the point, *clockwise* 30° from the original position.




(a)




(b)

### SOLUTION

The strain-transformation Eqs. 10–5 and 10–6 will be used to solve the problem. Since $\theta$ is *positive counterclockwise*, then for this problem $\theta = -30°$. Thus,

$$\epsilon_{x'} = \frac{\epsilon_x + \epsilon_y}{2} + \frac{\epsilon_x - \epsilon_y}{2}\cos 2\theta + \frac{\gamma_{xy}}{2}\sin 2\theta$$

$$= \left[\frac{500 + (-300)}{2}\right](10^{-6}) + \left[\frac{500 - (-300)}{2}\right](10^{-6})\cos(2(-30°))$$

$$+ \left[\frac{200(10^{-6})}{2}\right]\sin(2(-30°))$$

$$\epsilon_{x'} = 213(10^{-6}) \qquad \textit{Ans.}$$

$$\frac{\gamma_{x'y'}}{2} = -\left(\frac{\epsilon_x - \epsilon_y}{2}\right)\sin 2\theta + \frac{\gamma_{xy}}{2}\cos 2\theta$$

$$= -\left[\frac{500 - (-300)}{2}\right](10^{-6})\sin(2(-30°)) + \frac{200(10^{-6})}{2}\cos(2(-30°))$$

$$\gamma_{x'y'} = 793(10^{-6}) \qquad \textit{Ans.}$$

The strain in the $y'$ direction can be obtained from Eq. 10–7 with $\theta = -30°$. However, we can also obtain $\epsilon_{y'}$ using Eq. 10–5 with $\theta = 60°(\theta = -30° + 90°)$, Fig. 10–5*b*. We have with $\epsilon_{y'}$ replacing $\epsilon_{x'}$,


$$\epsilon_{y'} = \frac{\epsilon_x + \epsilon_y}{2} + \frac{\epsilon_x - \epsilon_y}{2}\cos 2\theta + \frac{\gamma_{xy}}{2}\sin 2\theta$$

$$= \left[\frac{500 + (-300)}{2}\right](10^{-6}) + \left[\frac{500 - (-300)}{2}\right](10^{-6})\cos(2(60°))$$

$$+ \frac{200(10^{-6})}{2}\sin(2(60°))$$

$$\epsilon_{y'} = -13.4(10^{-6}) \qquad \textit{Ans.}$$

These results tend to distort the element as shown in Fig. 10–5*c*.





(c)


Fig. 10–5

## EXAMPLE 10.2

A differential element of material at a point is subjected to a state of plane strain defined by $\epsilon_x = -350(10^{-6})$, $\epsilon_y = 200(10^{-6})$, $\gamma_{xy} = 80(10^{-6})$, which tends to distort the element as shown in Fig. 10–6*a*. Determine the principal strains at the point and the associated orientation of the element.




(a)




(b)

Fig. 10–6

### SOLUTION

**Orientation of the Element.** From Eq. 10–8 we have

$$\tan 2\theta_p = \frac{\gamma_{xy}}{\epsilon_x - \epsilon_y} = \frac{80(10^{-6})}{(-350 - 200)(10^{-6})}$$

Thus, $2\theta_p = -8.28°$ and $-8.28° + 180° = 171.72°$, so that

$$\theta_p = -4.14° \text{ and } 85.9° \qquad \textit{Ans.}$$

Each of these angles is measured *positive counterclockwise*, from the $x$ axis to the outward normals on each face of the element, Fig. 10–6*b*.

**Principal Strains.** The principal strains are determined from Eq. 10–9. We have

$$\epsilon_{1,2} = \frac{\epsilon_x + \epsilon_y}{2} \pm \sqrt{\left(\frac{\epsilon_x - \epsilon_y}{2}\right)^2 + \left(\frac{\gamma_{xy}}{2}\right)^2}$$

$$= \frac{(-350 + 200)(10^{-6})}{2} \pm \left[\sqrt{\left(\frac{-350 - 200}{2}\right)^2 + \left(\frac{80}{2}\right)^2}\right](10^{-6})$$

$$= -75.0(10^{-6}) \pm 277.9(10^{-6})$$

$$\epsilon_1 = 203(10^{-6}) \qquad \epsilon_2 = -353(10^{-6}) \qquad \textit{Ans.}$$

We can determine which of these two strains deforms the element in the $x'$ direction by applying Eq. 10–5 with $\theta = -4.14°$. Thus,

$$\epsilon_{x'} = \frac{\epsilon_x + \epsilon_y}{2} + \frac{\epsilon_x - \epsilon_y}{2}\cos 2\theta + \frac{\gamma_{xy}}{2}\sin 2\theta$$


$$= \left(\frac{-350 + 200}{2}\right)(10^{-6}) + \left(\frac{-350 - 200}{2}\right)(10^{-6})\cos 2(-4.14°) + \frac{80(10^{-6})}{2}\sin 2(-4.14°)$$

$$\epsilon_{x'} = -353(10^{-6})$$


Hence $\epsilon_{x'} = \epsilon_2$. When subjected to the principal strains, the element is distorted as shown in Fig. 10–6*b*.

## EXAMPLE 10.3

A differential element of material at a point is subjected to a state of plane strain defined by $\epsilon_x = -350(10^{-6})$, $\epsilon_y = 200(10^{-6})$, $\gamma_{xy} = 80(10^{-6})$, which tends to distort the element as shown in Fig. 10–7*a*. Determine the maximum in-plane shear strain at the point and the associated orientation of the element.



(a)



(b)

Fig. 10–7

### SOLUTION

**Orientation of the Element.** From Eq. 10–10 we have

$$\tan 2\theta_s = -\left(\frac{\epsilon_x - \epsilon_y}{\gamma_{xy}}\right) = -\frac{(-350 - 200)(10^{-6})}{80(10^{-6})}$$

Thus, $2\theta_s = 81.72°$ and $81.72° + 180° = 261.72°$, so that

$$\theta_s = 40.9° \text{ and } 131°$$

Note that this orientation is 45° from that shown in Fig. 10–6*b* in Example 10.2 as expected.

**Maximum In-Plane Shear Strain.** Applying Eq. 10–11 gives

$$\frac{\gamma_{in\text{-}plane}^{max}}{2} = \sqrt{\left(\frac{\epsilon_x - \epsilon_y}{2}\right)^2 + \left(\frac{\gamma_{xy}}{2}\right)^2}$$

$$= \left[\sqrt{\left(\frac{-350 - 200}{2}\right)^2 + \left(\frac{80}{2}\right)^2}\right](10^{-6})$$

$$\gamma_{in\text{-}plane}^{max} = 556(10^{-6}) \qquad \textit{Ans.}$$

Due to the square root, the proper sign of $\gamma_{in\text{-}plane}^{max}$ can be obtained by applying Eq. 10–6 with $\theta_s = 40.9°$. We have

$$\frac{\gamma_{x'y'}}{2} = -\frac{\epsilon_x - \epsilon_y}{2}\sin 2\theta + \frac{\gamma_{xy}}{2}\cos 2\theta$$

$$= -\left(\frac{-350 - 200}{2}\right)(10^{-6})\sin 2(40.9°) + \frac{80(10^{-6})}{2}\cos 2(40.9°)$$

$$\gamma_{x'y'} = 556(10^{-6})$$

This result is positive and so $\gamma_{in\text{-}plane}^{max}$ tends to distort the element so that the right angle between $dx'$ and $dy'$ is *decreased* (positive sign convention), Fig. 10–7*b*.

Also, there are associated average normal strains imposed on the element that are determined from Eq. 10–12:

$$\epsilon_{avg} = \frac{\epsilon_x + \epsilon_y}{2} = \frac{-350 + 200}{2}(10^{-6}) = -75(10^{-6})$$

These strains tend to cause the element to contract, Fig. 10–7*b*.

## *10.3 Mohr's Circle—Plane Strain

Since the equations of plane-strain transformation are mathematically similar to the equations of plane-stress transformation, we can also solve problems involving the transformation of strain using Mohr's circle.

Like the case for stress, the parameter $\theta$ in Eqs. 10–5 and 10–6 can be eliminated and the result rewritten in the form

$$(\epsilon_{x'} - \epsilon_{avg})^2 + \left(\frac{\gamma_{x'y'}}{2}\right)^2 = R^2 \tag{10–13}$$

where

$$\epsilon_{avg} = \frac{\epsilon_x + \epsilon_y}{2}$$

$$R = \sqrt{\left(\frac{\epsilon_x - \epsilon_y}{2}\right)^2 + \left(\frac{\gamma_{xy}}{2}\right)^2}$$

Equation 10–13 represents the equation of Mohr's circle for strain. It has a center on the $\epsilon$ axis at point $C(\epsilon_{avg}, 0)$ and a radius $R$.





Fig. 10–8

### Procedure for Analysis

The procedure for drawing Mohr's circle for strain follows the same one established for stress.

#### Construction of the Circle.

- Establish a coordinate system such that the abscissa represents the normal strain $\epsilon$, with *positive to the right*, and the ordinate represents *half* the value of the shear strain, $\gamma/2$, with *positive downward*, Fig. 10–8.
- Using the positive sign convention for $\epsilon_x$, $\epsilon_y$, $\gamma_{xy}$, as shown in Fig. 10–2, determine the center of the circle $C$, which is located on the $\epsilon$ axis at a distance $\epsilon_{avg} = (\epsilon_x + \epsilon_y)/2$ from the origin, Fig. 10–8.
- Plot the reference point $A$ having coordinates $A(\epsilon_x, \gamma_{xy}/2)$. This point represents the case for which the $x'$ axis coincides with the $x$ axis. Hence $\theta = 0°$, Fig. 10–8.
- Connect point $A$ with the center $C$ of the circle and from the shaded triangle determine the radius $R$ of the circle, Fig. 10–8.
- Once $R$ has been determined, sketch the circle.

### Principal Strains.

- The principal strains $\epsilon_1$ and $\epsilon_2$ are determined from the circle as the coordinates of points $B$ and $D$, that is where $\gamma/2 = 0$, Fig. 10–9*a*.
- The orientation of the plane on which $\epsilon_1$ acts can be determined from the circle by calculating $2\theta_{p_1}$ using trigonometry. Here this angle happens to be counterclockwise *from* the radial reference line $CA$ *to* line $CB$, Fig. 10–9*a*. Remember that the *rotation* of $\theta_{p_1}$ must be in this *same direction*, from the element's reference axis $x$ to the $x'$ axis, Fig. 10–9*b*.*
- When $\epsilon_1$ and $\epsilon_2$ are indicated as being positive as in Fig. 10–9*a*, the element in Fig. 10–9*b* will elongate in the $x'$ and $y'$ directions as shown by the dashed outline.


### Maximum In-Plane Shear Strain.

- The average normal strain and half the maximum in-plane shear strain are determined from the circle as the coordinates of point $E$ or $F$, Fig. 10–9*a*.
- The orientation of the plane on which $\gamma_{in\ plane}^{max}$ and $\epsilon_{avg}$ act can be determined from the circle by calculating $2\theta_{s_1}$ using trigonometry. Here this angle happens to be clockwise *from* the radial reference line $CA$ *to* line $CE$, Fig. 10–9*a*. Remember that the *rotation* of $\theta_{s_1}$ must be in this *same direction*, from the element's reference axis $x$ to the $x'$ axis, Fig. 10–9*c*.*


### Strains on Arbitrary Plane.

- The normal and shear strain components $\epsilon_{x'}$ and $\gamma_{x'y'}$ for a plane oriented at an angle $\theta$, Fig. 10–9*d*, can be obtained from the circle using trigonometry to determine the coordinates of point $P$, Fig. 10–9*a*.
- To locate $P$, the known angle $\theta$ of the $x'$ axis is measured on the circle as $2\theta$. This measurement is made *from* the radial reference line $CA$ *to* the radial line $CP$. Remember that measurements for $2\theta$ on the circle must be in the same direction as $\theta$ for the $x'$ axis.*
- If the value of $\epsilon_{y'}$ is required, it can be determined by calculating the $\epsilon$ coordinate of point $Q$ in Fig. 10–9*a*. The line $CQ$ lies 180° away from $CP$ and thus represents a 90° rotation of the $x'$ axis.


*If the $\gamma/2$ axis were constructed *positive upwards*, then the angle $2\theta$ on the circle would be measured in the *opposite direction* to the orientation $\theta$ of the plane.





(a)




(b)




(c)




(d)


**Fig. 10–9**

## EXAMPLE 10.4

The state of plane strain at a point is represented by the components $\epsilon_x = 250(10^{-6})$, $\epsilon_y = -150(10^{-6})$, and $\gamma_{xy} = 120(10^{-6})$. Determine the principal strains and the orientation of the element.

### SOLUTION

**Construction of the Circle.** The $\epsilon$ and $\gamma/2$ axes are established in Fig. 10–10*a*. Remember that the *positive* $\gamma/2$ axis must be directed *downward* so that *counterclockwise* rotations of the element correspond to *counterclockwise* rotation around the circle, and vice versa. The center of the circle $C$ is located on the $\epsilon$ axis at




(a)

$$\epsilon_{avg} = \frac{250 + (-150)}{2}(10^{-6}) = 50(10^{-6})$$


Since $\gamma_{xy}/2 = 60(10^{-6})$, the reference point $A$ ($\theta = 0°$) has coordinates $A(250(10^{-6}), 60(10^{-6}))$. From the shaded triangle in Fig. 10–10*a*, the radius of the circle is $CA$; that is,

$$R = \left[\sqrt{(250 - 50)^2 + (60)^2}\right](10^{-6}) = 208.8(10^{-6})$$

**Principal Strains.** The $\epsilon$ coordinates of points $B$ and $D$ represent the principal strains. They are

$$\epsilon_1 = (50 + 208.8)(10^{-6}) = 259(10^{-6}) \quad \textit{Ans.}$$

$$\epsilon_2 = (50 - 208.8)(10^{-6}) = -159(10^{-6}) \quad \textit{Ans.}$$




(b)

Fig. 10–10

The direction of the positive principal strain $\epsilon_1$ is defined by the *counterclockwise* angle $2\theta_{p_1}$, measured from the radial reference line $CA$ ($\theta = 0°$) to the line $CB$. We have

$$\tan 2\theta_{p_1} = \frac{60}{(250 - 50)}$$

$$\theta_{p_1} = 8.35° \quad \textit{Ans.}$$

Hence, the side $dx'$ of the element is oriented *counterclockwise* 8.35° as shown in Fig. 10–10*b*. This also defines the direction of $\epsilon_1$. The deformation of the element is also shown in the figure.

## EXAMPLE 10.5

The state of plane strain at a point is represented by the components $\epsilon_x = 250(10^{-6})$, $\epsilon_y = -150(10^{-6})$, and $\gamma_{xy} = 120(10^{-6})$. Determine the maximum in-plane shear strains and the orientation of an element.

### SOLUTION


The circle has been established in the previous example and is shown in Fig. 10–11*a*.

**Maximum In-Plane Shear Strain.** Half the maximum in-plane shear strain and average normal strain are represented by the coordinates of point $E$ or $F$ on the circle. From the coordinates of point $E$,

$$\frac{(\gamma_{x'y'})_{\max_{\text{in-plane}}}}{2} = 208.8(10^{-6})$$

$$(\gamma_{x'y'})_{\max_{\text{in-plane}}} = 418(10^{-6}) \qquad \textit{Ans.}$$

$$\epsilon_{\text{avg}} = 50(10^{-6})$$




(a)


Fig. 10–11

To orient the element, we can determine the clockwise angle $2\theta_{s_1}$ measured from $CA$ ($\theta = 0°$) to $CE$.

$$2\theta_{s_1} = 90° - 2(8.35°)$$

$$\theta_{s_1} = 36.7° \qquad \textit{Ans.}$$

This angle is shown in Fig. 10–11*b*. Since the shear strain defined from point $E$ on the circle has a positive value and the average normal strain is also positive, these strains deform the element into the dashed shape shown in the figure.




(b)


## EXAMPLE 10.6

The state of plane strain at a point is represented on an element having components $\epsilon_x = -300(10^{-6})$, $\epsilon_y = -100(10^{-6})$, and $\gamma_{xy} = 100(10^{-6})$. Determine the state of strain on an element oriented 20° clockwise from this reported position.

### SOLUTION

**Construction of the Circle.** The $\epsilon$ and $\gamma/2$ axes are established in Fig. 10–12*a*. The center of the circle is on the $\epsilon$ axis at

$$\epsilon_{avg} = \left(\frac{-300 - 100}{2}\right)(10^{-6}) = -200(10^{-6})$$




(a)

The reference point $A$ has coordinates $A(-300(10^{-6}), 50(10^{-6}))$. The radius $CA$ determined from the shaded triangle is therefore

$$R = \left[\sqrt{(300 - 200)^2 + (50)^2}\right](10^{-6}) = 111.8(10^{-6})$$

**Strains on Inclined Element.** Since the element is to be oriented 20° *clockwise*, we must establish a radial line $CP$, $2(20°) = 40°$ *clockwise*, measured from $CA$ ($\theta = 0°$), Fig. 10–12*a*. The coordinates of point $P$ $(\epsilon_{x'}, \gamma_{x'y'}/2)$ are obtained from the geometry of the circle. Note that

$$\phi = \tan^{-1}\left(\frac{50}{(300 - 200)}\right) = 26.57°, \qquad \psi = 40° - 26.57° = 13.43°$$

Thus,

$$\epsilon_{x'} = -(200 + 111.8\cos 13.43°)(10^{-6})$$
$$= -309(10^{-6}) \qquad \textit{Ans.}$$

$$\frac{\gamma_{x'y'}}{2} = -(111.8\sin 13.43°)(10^{-6})$$

$$\gamma_{x'y'} = -52.0(10^{-6}) \qquad \textit{Ans.}$$




(b)

Fig. 10–12

The normal strain $\epsilon_{y'}$ can be determined from the $\epsilon$ coordinate of point $Q$ on the circle, Fig. 10–12*a*. Why?


$$\epsilon_{y'} = -(200 - 111.8\cos 13.43°)(10^{-6}) = -91.3(10^{-6}) \qquad \textit{Ans.}$$

As a result of these strains, the element deforms relative to the $x'$, $y'$ axes as shown in Fig. 10–12*b*.

## PROBLEMS


**10–1.** Prove that the sum of the normal strains in perpendicular directions is constant.

**10–2.** The state of strain at the point has components of $\epsilon_x = 200(10^{-6})$, $\epsilon_y = -300(10^{-6})$, and $\gamma_{xy} = 400(10^{-6})$. Use the strain-transformation equations to determine the equivalent in-plane strains on an element oriented at an angle of 30° counterclockwise from the original position. Sketch the deformed element due to these strains within the $x$–$y$ plane.




Prob. 10–2

**10–3.** A strain gauge is mounted on the 1-in.-diameter A-36 steel shaft in the manner shown. When the shaft is rotating with an angular velocity of $\omega = 1760$ rev/min, the reading on the strain gauge is $\epsilon = 800(10^{-6})$. Determine the power output of the motor. Assume the shaft is only subjected to a torque.




Prob. 10–3

***10–4.** The state of strain at a point on a wrench has components $\epsilon_x = 120(10^{-6})$, $\epsilon_y = -180(10^{-6})$, $\gamma_{xy} = 150(10^{-6})$. Use the strain-transformation equations to determine (a) the in-plane principal strains and (b) the maximum in-plane shear strain and average normal strain. In each case specify the orientation of the element and show how the strains deform the element within the $x$–$y$ plane.


**10–5.** The state of strain at the point on the arm has components $\epsilon_x = 250(10^{-6})$, $\epsilon_y = -450(10^{-6})$, $\gamma_{xy} = -825(10^{-6})$. Use the strain-transformation equations to determine (a) the in-plane principal strains and (b) the maximum in-plane shear strain and average normal strain. In each case specify the orientation of the element and show how the strains deform the element within the $x$–$y$ plane.




Prob. 10–5


**10–6.** The state of strain at the point has components of $\epsilon_x = -100(10^{-6})$, $\epsilon_y = 400(10^{-6})$, and $\gamma_{xy} = -300(10^{-6})$. Use the strain-transformation equations to determine the equivalent in-plane strains on an element oriented at an angle of 60° counterclockwise from the original position. Sketch the deformed element due to these strains within the $x$–$y$ plane.

**10–7.** The state of strain at the point has components of $\epsilon_x = 100(10^{-6})$, $\epsilon_y = 300(10^{-6})$, and $\gamma_{xy} = -150(10^{-6})$. Use the strain-transformation equations to determine the equivalent in-plane strains on an element oriented $\theta = 30°$ clockwise. Sketch the deformed element due to these strains within the $x$–$y$ plane.





Probs. 10–6/7

***10–8.** The state of strain at the point on the bracket has components $\epsilon_x = -200(10^{-6})$, $\epsilon_y = -650(10^{-6})$, $\gamma_{xy} = -175(10^{-6})$. Use the strain-transformation equations to determine the equivalent in-plane strains on an element oriented at an angle of $\theta = 20°$ counterclockwise from the original position. Sketch the deformed element due to these strains within the $x$–$y$ plane.





Prob. 10–8

**10–9.** The state of strain at the point has components of $\epsilon_x = 180(10^{-6})$, $\epsilon_y = -120(10^{-6})$, and $\gamma_{xy} = -100(10^{-6})$. Use the strain-transformation equations to determine (a) the in-plane principal strains and (b) the maximum in-plane shear strain and average normal strain. In each case specify the orientation of the element and show how the strains deform the element within the $x$–$y$ plane.




Prob. 10–9

**10–10.** The state of strain at the point on the bracket has components $\epsilon_x = 400(10^{-6})$, $\epsilon_y = -250(10^{-6})$, $\gamma_{xy} = 310(10^{-6})$. Use the strain-transformation equations to determine the equivalent in-plane strains on an element oriented at an angle of $\theta = 30°$ clockwise from the original position. Sketch the deformed element due to these strains within the $x$–$y$ plane.





Prob. 10–10

**10–11.** The state of strain at the point has components of $\epsilon_x = -100(10^{-6})$, $\epsilon_y = -200(10^{-6})$, and $\gamma_{xy} = 100(10^{-6})$. Use the strain-transformation equations to determine (a) the in-plane principal strains and (b) the maximum in-plane shear strain and average normal strain. In each case specify the orientation of the element and show how the strains deform the element within the $x$–$y$ plane.





Prob. 10–11

*10–12. The state of plane strain on an element is given by $\epsilon_x = 500(10^{-6})$, $\epsilon_y = 300(10^{-6})$, and $\gamma_{xy} = -200(10^{-6})$. Determine the equivalent state of strain on an element at the same point oriented 45° clockwise with respect to the original element.




Prob. 10–12

10–13. The state of plane strain on an element is $\epsilon_x = -300(10^{-6})$, $\epsilon_y = 0$, and $\gamma_{xy} = 150(10^{-6})$. Determine the equivalent state of strain which represents (a) the principal strains, and (b) the maximum in-plane shear strain and the associated average normal strain. Specify the orientation of the corresponding elements for these states of strain with respect to the original element.




Prob. 10–13

10–14. The state of strain at the point on a boom of an hydraulic engine crane has components of $\epsilon_x = 250(10^{-6})$, $\epsilon_y = 300(10^{-6})$, and $\gamma_{xy} = -180(10^{-6})$. Use the strain-transformation equations to determine (a) the in-plane principal strains and (b) the maximum in-plane shear strain and average normal strain. In each case, specify the orientation of the element and show how the strains deform the element within the $x$–$y$ plane.




Prob. 10–14

■10–15. Consider the general case of plane strain where $\epsilon_x$, $\epsilon_y$, and $\gamma_{xy}$ are known. Write a computer program that can be used to determine the normal and shear strain, $\epsilon_{x'}$ and $\gamma_{x'y'}$, on the plane of an element oriented $\theta$ from the horizontal. Also, include the principal strains and the element's orientation, and the maximum in-plane shear strain, the average normal strain, and the element's orientation.

*10–16. The state of strain at a point on a support has components of $\epsilon_x = 350(10^{-6})$, $\epsilon_y = 400(10^{-6})$, $\gamma_{xy} = -675(10^{-6})$. Use the strain-transformation equations to determine (a) the in-plane principal strains and (b) the maximum in-plane shear strain and average normal strain. In each case specify the orientation of the element and show how the strains deform the element within the $x$–$y$ plane.

•10–17. Solve part (a) of Prob. 10–4 using Mohr's circle.

10–18. Solve part (b) of Prob. 10–4 using Mohr's circle.

10–19. Solve Prob. 10–8 using Mohr's circle.

*10–20. Solve Prob. 10–10 using Mohr's circle.

•10–21. Solve Prob. 10–14 using Mohr's circle.





Fig. 10–13





Fig. 10–14

## *10.4 Absolute Maximum Shear Strain

In Sec. 9.5 it was pointed out that in the case of plane stress, the absolute maximum shear stress in an element of material will occur out of the plane when the principal stresses have the same sign, i.e., both are tensile or both are compressive. A similar result occurs for plane strain. For example, if the principal in-plane strains cause elongations, Fig. 10–13*a*, then the three Mohr's circles describing the normal and shear strain components for elements oriented about the $x'$, $y'$, and $z'$ axes are shown in Fig. 10–13*b*. By inspection, the largest circle has a radius $R = (\gamma_{x'z'})_{max}/2$. Hence,

$$\gamma_{abs_{max}} = (\gamma_{x'z'})_{max} = \epsilon_1 \quad \epsilon_1 \text{ and } \epsilon_2 \text{ have the same sign} \tag{10–14}$$

This value gives the *absolute maximum shear strain* for the material. Note that it is *larger* than the maximum in-plane shear strain, which is $(\gamma_{x'y'})_{max} = \epsilon_1 - \epsilon_2$.

Now consider the case where one of the in-plane principal strains is of *opposite sign* to the other in-plane principal strain, so that $\epsilon_1$ causes elongation and $\epsilon_2$ causes contraction, Fig. 10–14*a*. Mohr's circles, which describe the strains on each element's orientation about the $x'$, $y'$, $z'$ axes, are shown in Fig. 10–14*b*. Here

$$\gamma_{abs_{max}} = (\gamma_{x'y'})_{in\,plane_{max}} = \epsilon_1 - \epsilon_2 \quad \epsilon_1 \text{ and } \epsilon_2 \text{ have opposite signs} \tag{10–15}$$

We may therefore summarize the above two cases as follows. If the in-plane principal strains both have the *same sign*, the *absolute maximum shear strain* will occur *out of plane* and has a value of $\gamma_{abs_{max}} = \epsilon_{max}$. However, if the in-plane principal strains are of *opposite signs*, then the absolute maximum shear strain *equals* the maximum in-plane shear strain.

### Important Points

- The absolute maximum shear strain will be *larger* than the maximum in-plane shear strain whenever the in-plane principal strains have the *same sign*. When this occurs the absolute maximum shear strain will act out of the plane.
- If the in-plane principal strains are of opposite signs, then the absolute maximum shear strain will equal the maximum in-plane shear strain.

## EXAMPLE 10.7

The state of plane strain at a point is represented by the strain components $\epsilon_x = -400(10^{-6})$, $\epsilon_y = 200(10^{-6})$, $\gamma_{xy} = 150(10^{-6})$. Determine the maximum in-plane shear strain and the absolute maximum shear strain.





Fig. 10–15

SOLUTION

**Maximum In-Plane Shear Strain.** We will solve this problem using Mohr's circle. From the strain components, the center of the circle is on the $\epsilon$ axis at

$$\epsilon_{avg} = \frac{-400 + 200}{2}(10^{-6}) = -100(10^{-6})$$

Since $\gamma_{xy}/2 = 75(10^{-6})$, the reference point $A$ has coordinates $(-400(10^{-6}), 75(10^{-6}))$. As shown in Fig. 10–15, the radius of the circle is therefore

$$R = \left[\sqrt{(400 - 100)^2 + (75)^2}\right](10^{-6}) = 309(10^{-6})$$

Calculating the in-plane principal strains from the circle, we have

$$\epsilon_1 = (-100 + 309)(10^{-6}) = 209(10^{-6})$$

$$\epsilon_2 = (-100 - 309)(10^{-6}) = -409(10^{-6})$$


Also, the maximum in-plane shear strain is

$$\gamma_{\text{in-plane}}^{\max} = \epsilon_1 - \epsilon_2 = [209 - (-409)](10^{-6}) = 618(10^{-6}) \quad \textit{Ans.}$$


**Absolute Maximum Shear Strain.** From the above results, we have $\epsilon_1 = 209(10^{-6})$, $\epsilon_2 = -409(10^{-6})$. The three Mohr's circles, plotted for element orientations about each of the $x$, $y$, $z$ axes, are also shown in Fig. 10–15. It is seen that since the *principal in-plane strains have opposite signs*, the maximum in-plane shear strain is *also* the absolute maximum shear strain; i.e.,

$$\gamma_{\text{abs}}^{\max} = 618(10^{-6}) \quad \textit{Ans.}$$

10





(a)




45° strain rosette


(b)




60° strain rosette

(c)

**Fig. 10–16**



Typical electrical resistance 45° strain rosette.

## 10.5 Strain Rosettes

When performing a tension test on a specimen as discussed in Sec. 3.1, the normal strain in the material is measured using an ***electrical-resistance strain gauge***, which consists of a wire grid or piece of metal foil bonded to the specimen. For a general loading on a body, however, the strains at a point on its free surface are determined using a cluster of three electrical-resistance strain gauges, arranged in a specified pattern. This pattern is referred to as a ***strain rosette***, and once the normal strains on the three gauges are measured, the data can then be transformed to specify the state of strain at the point. Since these strains are measured *only* in the plane of the gauges, and since the body is stress-free on its surface, the gauges may be subjected to *plane stress* but *not* plane strain. Although the strain normal to the surface is not measured, realize that the out-of-plane displacement caused by this strain will *not* affect the in-plane measurements of the gauges.

In the general case, the axes of the three gauges are arranged at the angles $\theta_a$, $\theta_b$, $\theta_c$ shown in Fig. 10–16*a*. If the readings $\epsilon_a$, $\epsilon_b$, $\epsilon_c$ are taken, we can determine the strain components $\epsilon_x$, $\epsilon_y$, $\gamma_{xy}$ at the point by applying the strain-transformation equation, Eq. 10–2, for each gauge. We have

$$\begin{aligned}
\epsilon_a &= \epsilon_x \cos^2\theta_a + \epsilon_y \sin^2\theta_a + \gamma_{xy} \sin\theta_a \cos\theta_a \\
\epsilon_b &= \epsilon_x \cos^2\theta_b + \epsilon_y \sin^2\theta_b + \gamma_{xy} \sin\theta_b \cos\theta_b \qquad (10\text{–}16) \\
\epsilon_c &= \epsilon_x \cos^2\theta_c + \epsilon_y \sin^2\theta_c + \gamma_{xy} \sin\theta_c \cos\theta_c
\end{aligned}$$

The values of $\epsilon_x$, $\epsilon_y$, $\gamma_{xy}$ are determined by solving these three equations simultaneously.

Strain rosettes are often arranged in 45° or 60° patterns. In the case of the 45° or "rectangular" strain rosette shown in Fig. 10–16*b*, $\theta_a = 0°$, $\theta_b = 45°$, $\theta_c = 90°$, so that Eq. 10–16 gives

$$\begin{aligned}
\epsilon_x &= \epsilon_a \\
\epsilon_y &= \epsilon_c \\
\gamma_{xy} &= 2\epsilon_b - (\epsilon_a + \epsilon_c)
\end{aligned}$$

And for the 60° strain rosette in Fig. 10–16*c*, $\theta_a = 0°$, $\theta_b = 60°$, $\theta_c = 120°$. Here Eq. 10–16 gives

$$\begin{aligned}
\epsilon_x &= \epsilon_a \\
\epsilon_y &= \frac{1}{3}(2\epsilon_b + 2\epsilon_c - \epsilon_a) \qquad (10\text{–}17) \\
\gamma_{xy} &= \frac{2}{\sqrt{3}}(\epsilon_b - \epsilon_c)
\end{aligned}$$

Once $\epsilon_x$, $\epsilon_y$, $\gamma_{xy}$ are determined, the transformation equations of Sec. 10.2 or Mohr's circle can then be used to determine the principal in-plane strains and the maximum in-plane shear strain at the point.

10

## EXAMPLE 10.8

The state of strain at point $A$ on the bracket in Fig. 10–17*a* is measured using the strain rosette shown in Fig. 10–17*b*. Due to the loadings, the readings from the gauges give $\epsilon_a = 60(10^{-6})$, $\epsilon_b = 135(10^{-6})$, and $\epsilon_c = 264(10^{-6})$. Determine the in-plane principal strains at the point and the directions in which they act.





(a)

### SOLUTION

We will use Eqs. 10–16 for the solution. Establishing an $x$ axis as shown in Fig. 10–17*b* and measuring the angles counterclockwise from the $+x$ axis to the centerlines of each gauge, we have $\theta_a = 0°$, $\theta_b = 60°$, and $\theta_c = 120°$. Substituting these results, along with the problem data, into the equations gives

$$60(10^{-6}) = \epsilon_x \cos^2 0° + \epsilon_y \sin^2 0° + \gamma_{xy} \sin 0° \cos 0°$$
$$= \epsilon_x \tag{1}$$
$$135(10^{-6}) = \epsilon_x \cos^2 60° + \epsilon_y \sin^2 60° + \gamma_{xy} \sin 60° \cos 60°$$
$$= 0.25\epsilon_x + 0.75\epsilon_y + 0.433\gamma_{xy} \tag{2}$$
$$264(10^{-6}) = \epsilon_x \cos^2 120° + \epsilon_y \sin^2 120° + \gamma_{xy} \sin 120° \cos 120°$$
$$= 0.25\epsilon_x + 0.75\epsilon_y - 0.433\gamma_{xy} \tag{3}$$




(b)


Using Eq. 1 and solving Eqs. 2 and 3 simultaneously, we get

$$\epsilon_x = 60(10^{-6}) \qquad \epsilon_y = 246(10^{-6}) \qquad \gamma_{xy} = -149(10^{-6})$$

These same results can also be obtained in a more direct manner from Eq. 10–17.

The in-plane principal strains can be determined using Mohr's circle. The reference point on the circle is at $A\,[60(10^{-6}), -74.5(10^{-6})]$ and the center of the circle, $C$, is on the $\epsilon$ axis at $\epsilon_{avg} = 153(10^{-6})$, Fig. 10–17*c*. From the shaded triangle, the radius is


$$R = \left[\sqrt{(153 - 60)^2 + (74.5)^2}\right](10^{-6}) = 119.1(10^{-6})$$




(c)

The in-plane principal strains are thus

$$\epsilon_1 = 153(10^{-6}) + 119.1(10^{-6}) = 272(10^{-6}) \qquad \textit{Ans}$$
$$\epsilon_2 = 153(10^{-6}) - 119.1(10^{-6}) = 33.9(10^{-6}) \qquad \textit{Ans}$$
$$2\theta_{p_2} = \tan^{-1}\frac{74.5}{(153 - 60)} = 38.7°$$
$$\theta_{p_2} = 19.3° \qquad \textit{Ans}$$





(d)

**NOTE:** The deformed element is shown in the dashed position in Fig. 10–17*d*. Realize that, due to the Poisson effect, the element is *also* subjected to an out-of-plane strain, i.e., in the $z$ direction, although this value will not influence the calculated results.

Fig. 10–17


## PROBLEMS

**10–22.** The strain at point $A$ on the bracket has components $\epsilon_x = 300(10^{-6})$, $\epsilon_y = 550(10^{-6})$, $\gamma_{xy} = -650(10^{-6})$. Determine (a) the principal strains at $A$ in the $x$–$y$ plane, (b) the maximum shear strain in the $x$–$y$ plane, and (c) the absolute maximum shear strain.





Prob. 10–22

**10–23.** The strain at point $A$ on the leg of the angle has components $\epsilon_x = -140(10^{-6})$, $\epsilon_y = 180(10^{-6})$, $\gamma_{xy} = -125(10^{-6})$. Determine (a) the principal strains at $A$ in the $x$–$y$ plane, (b) the maximum shear strain in the $x$–$y$ plane, and (c) the absolute maximum shear strain.





Prob. 10–23

***10–24.** The strain at point $A$ on the pressure-vessel wall has components $\epsilon_x = 480(10^{-6})$, $\epsilon_y = 720(10^{-6})$, $\gamma_{xy} = 650(10^{-6})$. Determine (a) the principal strains at $A$, in the $x$–$y$ plane, (b) the maximum shear strain in the $x$–$y$ plane, and (c) the absolute maximum shear strain.





Prob. 10–24

**•10–25.** The 60° strain rosette is mounted on the bracket. The following readings are obtained for each gauge: $\epsilon_a = -100(10^{-6})$, $\epsilon_b = 250(10^{-6})$, and $\epsilon_c = 150(10^{-6})$. Determine (a) the principal strains and (b) the maximum in-plane shear strain and associated average normal strain. In each case show the deformed element due to these strains.





Prob. 10–25

**10–26.** The 60° strain rosette is mounted on a beam. The following readings are obtained for each gauge: $\epsilon_a = 200(10^{-6})$, $\epsilon_b = -450(10^{-6})$, and $\epsilon_c = 250(10^{-6})$. Determine (a) the in-plane principal strains and (b) the maximum in-plane shear strain and average normal strain. In each case show the deformed element due to these strains.





Prob. 10–26

**10–27.** The 45° strain rosette is mounted on a steel shaft. The following readings are obtained from each gauge: $\epsilon_a = 300(10^{-6})$, $\epsilon_b = -250(10^{-6})$, and $\epsilon_c = -450(10^{-6})$. Determine (a) the in-plane principal strains and (b) the maximum in-plane shear strain and average normal strain. In each case show the deformed element due to these strains.





Prob. 10–27

***10–28.** The 45° strain rosette is mounted on the link of the backhoe. The following readings are obtained from each gauge: $\epsilon_a = 650(10^{-6})$, $\epsilon_b = -300(10^{-6})$, $\epsilon_c = 480(10^{-6})$. Determine (a) the in-plane principal strains and (b) the maximum in-plane shear strain and associated average normal strain.




Prob. 10–28

**10–29.** Consider the general orientation of three strain gauges at a point as shown. Write a computer program that can be used to determine the principal in-plane strains and the maximum in-plane shear strain at the point. Show an application of the program using the values $\theta_a = 40°$, $\epsilon_a = 160(10^{-6})$, $\theta_b = 125°$, $\epsilon_b = 100(10^{-6})$, $\theta_c = 220°$, $\epsilon_c = 80(10^{-6})$.




Prob. 10–29

## 10.6 Material-Property Relationships

In this section we will present some important relationships involving a material's properties that are used when the material is subjected to multiaxial stress and strain. To do so we will assume that the material is homogeneous and isotropic and behaves in a linear-elastic manner.

**Generalized Hooke's Law.** If the material at a point is subjected to a state of triaxial stress, $\sigma_x$, $\sigma_y$, $\sigma_z$, Fig. 10–18*a*, associated normal strains $\epsilon_x$, $\epsilon_y$, $\epsilon_z$ will be developed in the material. The stresses can be related to these strains by using the principle of superposition, Poisson's ratio, $\epsilon_{\text{lat}} = -\nu\epsilon_{\text{long}}$, and Hooke's law, as it applies in the uniaxial direction, $\epsilon = \sigma/E$. For example, consider the normal strain of the element in the $x$ direction, caused by separate application of each normal stress. When $\sigma_x$ is applied, Fig. 10–18*b*, the element elongates in the $x$ direction and the strain $\epsilon_x'$ is

$$\epsilon_x' = \frac{\sigma_x}{E}$$

Application of $\sigma_y$ causes the element to contract with a strain $\epsilon_x''$, Fig. 10–18*c*. Here

$$\epsilon_x'' = -\nu\frac{\sigma_y}{E}$$

Likewise, application of $\sigma_z$, Fig. 10–18*d*, causes a contraction such that

$$\epsilon_x''' = -\nu\frac{\sigma_z}{E}$$





Fig. 10–18

When these three normal strains are superimposed, the normal strain $\epsilon_x$ is determined for the state of stress in Fig. 10–18*a*. Similar equations can be developed for the normal strains in the $y$ and $z$ directions. The final results can be written as

$$\epsilon_x = \frac{1}{E}[\sigma_x - \nu(\sigma_y + \sigma_z)]$$
$$\epsilon_y = \frac{1}{E}[\sigma_y - \nu(\sigma_x + \sigma_z)] \qquad (10\text{–}18)$$
$$\epsilon_z = \frac{1}{E}[\sigma_z - \nu(\sigma_x + \sigma_y)]$$

These three equations express Hooke's law in a general form for a triaxial state of stress. For application tensile stresses are considered positive quantities, and compressive stresses are negative. If a resulting normal strain is *positive*, it indicates that the material *elongates*, whereas a *negative* normal strain indicates the material *contracts*.

If we now apply a shear stress $\tau_{xy}$ to the element, Fig. 10–19*a*, experimental observations indicate that the material will deform *only* due to a shear strain $\gamma_{xy}$; that is, $\tau_{xy}$ will not cause other strains in the material. Likewise, $\tau_{yz}$ and $\tau_{xz}$ will only cause shear strains $\gamma_{yz}$ and $\gamma_{xz}$, Figs. 10–19*b* and 10–19*c*, and so Hooke's law for shear stress and shear strain can be written as

$$\gamma_{xy} = \frac{1}{G}\tau_{xy} \qquad \gamma_{yz} = \frac{1}{G}\tau_{yz} \qquad \gamma_{xz} = \frac{1}{G}\tau_{xz} \qquad (10\text{–}19)$$





Fig. 10–19





Fig. 10–20





Fig. 10–21

**Relationship Involving *E*, *ν*, and *G*.** In Sec. 3.7 it was stated that the modulus of elasticity $E$ is related to the shear modulus $G$ by Eq. 3–11, namely,

$$G = \frac{E}{2(1 + \nu)} \tag{10–20}$$

One way to derive this relationship is to consider an element of the material to be subjected to pure shear ($\sigma_x = \sigma_y = \sigma_z = 0$), Fig. 10–20*a*. Applying Eq. 9–5 to obtain the principal stresses yields $\sigma_{max} = \tau_{xy}$ and $\sigma_{min} = -\tau_{xy}$. This element must be oriented $\theta_{p_1} = 45°$ counterclockwise from the $x$ axis as shown in Fig. 10–20*b*. If the three principal stresses $\sigma_{max} = \tau_{xy}$, $\sigma_{int} = 0$, and $\sigma_{min} = -\tau_{xy}$ are substituted into the first of Eqs. 10–18, the principal strain $\epsilon_{max}$ can be related to the shear stress $\tau_{xy}$. The result is

$$\epsilon_{max} = \frac{\tau_{xy}}{E}(1 + \nu) \tag{10–21}$$

This strain, which deforms the element along the $x'$ axis, can also be related to the shear strain $\gamma_{xy}$. To do this, first note that since $\sigma_x = \sigma_y = \sigma_z = 0$, then from the first and second Eqs. 10–18, $\epsilon_x = \epsilon_y = 0$. Substituting these results into the strain transformation Eq. 10–9, we get

$$\epsilon_1 = \epsilon_{max} = \frac{\gamma_{xy}}{2}$$

By Hooke's law, $\gamma_{xy} = \tau_{xy}/G$, so that $\epsilon_{max} = \tau_{xy}/2G$. Substituting into Eq. 10–21 and rearranging terms gives the final result, namely, Eq. 10–20.

**Dilatation and Bulk Modulus.** When an elastic material is subjected to normal stress, its volume will change. For example, consider a volume element which is subjected to the principal stresses $\sigma_x$, $\sigma_y$, $\sigma_z$. If the sides of the element are originally $dx$, $dy$, $dz$, Fig. 10–21*a*, then after application of the stress they become $(1 + \epsilon_x)\,dx$, $(1 + \epsilon_y)\,dy$, $(1 + \epsilon_z)\,dz$, Fig. 10–21*b*. The change in volume of the element is therefore

$$\delta V = (1 + \epsilon_x)(1 + \epsilon_y)(1 + \epsilon_z)\,dx\,dy\,dz - dx\,dy\,dz$$

Neglecting the products of the strains since the strains are very small, we have

$$\delta V = (\epsilon_x + \epsilon_y + \epsilon_z)\,dx\,dy\,dz$$

The change in volume per unit volume is called the "volumetric strain" or the ***dilatation*** $e$. It can be written as

$$e = \frac{\delta V}{dV} = \epsilon_x + \epsilon_y + \epsilon_z \tag{10–22}$$


By comparison, the shear strains will *not* change the volume of the element, rather they will only change its rectangular shape.

Also, if we use Hooke's law, as defined by Eq. 10–18, we can write the dilatation in terms of the applied stress. We have

$$e = \frac{1 - 2\nu}{E}(\sigma_x + \sigma_y + \sigma_z) \tag{10–23}$$

When a volume element of material is subjected to the uniform pressure $p$ of a liquid, the pressure on the body is the same in all directions and is always normal to any surface on which it acts. Shear stresses are *not present*, since the shear resistance of a liquid is zero. This state of "hydrostatic" loading requires the normal stresses to be equal in any and all directions, and therefore an element of the body is subjected to principal stresses $\sigma_x = \sigma_y = \sigma_z = -p$, Fig. 10–22. Substituting into Eq. 10–23 and rearranging terms yields

$$\frac{p}{e} = -\frac{E}{3(1 - 2\nu)} \tag{10–24}$$



Hydrostatic stress

**Fig. 10–22**

Since this ratio is *similar* to the ratio of linear elastic stress to strain, which defines $E$, i.e., $\sigma/\epsilon = E$, the term on the right is called the *volume modulus of elasticity* or the ***bulk modulus***. It has the same units as stress and will be symbolized by the letter $k$; that is,

$$k = \frac{E}{3(1 - 2\nu)} \tag{10–25}$$

Note that for most metals $\nu \approx \frac{1}{3}$ so $k \approx E$. If a material existed that did not change its volume then $\delta V = e = 0$, and $k$ would have to be infinite. From Eq. 10–25 the theoretical *maximum* value for Poisson's ratio is therefore $\nu = 0.5$. During yielding, no actual volume change of the material is observed, and so $\nu = 0.5$ is used when plastic yielding occurs.

## Important Points

- When a homogeneous isotropic material is subjected to a state of triaxial stress, the strain in each direction is influenced by the strains produced by *all* the stresses. This is the result of the Poisson effect, and results in the form of a generalized Hooke's law.
- Unlike normal stress, a shear stress applied to homogeneous isotropic material will only produce shear strain in the same plane.
- The material constants $E$, $G$, and $\nu$ are related mathematically.
- *Dilatation*, or *volumetric strain*, is caused only by normal strain, not shear strain.
- The *bulk modulus* is a measure of the stiffness of a volume of material. This material property provides an upper limit to Poisson's ratio of $\nu = 0.5$, which remains at this value while plastic yielding occurs.

## EXAMPLE 10.9

The bracket in Example 10–8, Fig. 10–23*a*, is made of steel for which $E_{st} = 200$ GPa, $\nu_{st} = 0.3$. Determine the principal stresses at point $A$.





Fig. 10–23

SOLUTION I

From Example 10.8 the principal strains have been determined as

$$\epsilon_1 = 272(10^{-6})$$

$$\epsilon_2 = 33.9(10^{-6})$$

Since point $A$ is on the *surface* of the bracket for which there is no loading, the stress on the surface is zero, and so point $A$ is subjected to plane stress. Applying Hooke's law with $\sigma_3 = 0$, we have

$$\epsilon_1 = \frac{\sigma_1}{E} - \frac{\nu}{E}\sigma_2; \quad 272(10^{-6}) = \frac{\sigma_1}{200(10^9)} - \frac{0.3}{200(10^9)}\sigma_2$$

$$54.4(10^6) = \sigma_1 - 0.3\sigma_2 \tag{1}$$


$$\epsilon_2 = \frac{\sigma_2}{E} - \frac{\nu}{E}\sigma_1; \quad 33.9(10^{-6}) = \frac{\sigma_2}{200(10^9)} - \frac{0.3}{200(10^9)}\sigma_1$$

$$6.78(10^6) = \sigma_2 - 0.3\sigma_1 \tag{2}$$

Solving Eqs. 1 and 2 simultaneously yields

$$\sigma_1 = 62.0 \text{ MPa} \quad \textit{Ans.}$$

$$\sigma_2 = 25.4 \text{ MPa} \quad \textit{Ans.}$$




(b)

Fig. 10–23 (cont.)

SOLUTION II

It is also possible to solve the problem using the given state of strain,

$$\epsilon_x = 60(10^{-6}) \qquad \epsilon_y = 246(10^{-6}) \qquad \gamma_{xy} = -149(10^{-6})$$

as specified in Example 10.8. Applying Hooke's law in the $x$–$y$ plane, we have

$$\epsilon_x = \frac{\sigma_x}{E} - \frac{\nu}{E}\sigma_y; \qquad 60(10^{-6}) = \frac{\sigma_x}{200(10^9)\text{ Pa}} - \frac{0.3\sigma_y}{200(10^9)\text{ Pa}}$$

$$\epsilon_y = \frac{\sigma_y}{E} - \frac{\nu}{E}\sigma_x; \qquad 246(10^{-6}) = \frac{\sigma_y}{200(10^9)\text{ Pa}} - \frac{0.3\sigma_x}{200(10^9)\text{ Pa}}$$

$$\sigma_x = 29.4\text{ MPa} \qquad \sigma_y = 58.0\text{ MPa}$$

The shear stress is determined using Hooke's law for shear. First, however, we must calculate $G$.

$$G = \frac{E}{2(1+\nu)} = \frac{200\text{ GPa}}{2(1+0.3)} = 76.9\text{ GPa}$$

Thus,

$$\tau_{xy} = G\gamma_{xy}; \qquad \tau_{xy} = 76.9(10^9)[-149(10^{-6})] = -11.46\text{ MPa}$$

The Mohr's circle for this state of plane stress has a reference point $A(29.4\text{ MPa}, -11.46\text{ MPa})$ and center at $\sigma_{avg} = 43.7$ MPa, Fig. 10–23*b*. The radius is determined from the shaded triangle.

$$R = \sqrt{(43.7 - 29.4)^2 + (11.46)^2} = 18.3\text{ MPa}$$

Therefore,

$$\sigma_1 = 43.7\text{ MPa} + 18.3\text{ MPa} = 62.0\text{ MPa} \qquad \textit{Ans}$$

$$\sigma_2 = 43.7\text{ MPa} - 18.3\text{ MPa} = 25.4\text{ MPa} \qquad \textit{Ans}$$

**NOTE:** Each of these solutions is valid provided the material is both linear elastic and isotropic, since then the principal planes of stress and strain coincide.

## EXAMPLE 10.10

The copper bar in Fig. 10–24 is subjected to a uniform loading along its edges as shown. If it has a length $a = 300$ mm, width $b = 50$ mm, and thickness $t = 20$ mm before the load is applied, determine its new length, width, and thickness after application of the load. Take $E_{cu} = 120$ GPa, $\nu_{cu} = 0.34$.





Fig. 10–24

### SOLUTION

By inspection, the bar is subjected to a state of plane stress. From the loading we have

$$\sigma_x = 800\text{ MPa} \qquad \sigma_y = -500\text{ MPa} \qquad \tau_{xy} = 0 \qquad \sigma_z = 0$$

The associated normal strains are determined from the generalized Hooke's law, Eq. 10–18; that is,

$$\epsilon_x = \frac{\sigma_x}{E} - \frac{\nu}{E}(\sigma_y + \sigma_z)$$

$$= \frac{800\text{ MPa}}{120(10^3)\text{ MPa}} - \frac{0.34}{120(10^3)\text{ MPa}}(-500\text{ MPa} + 0) = 0.00808$$

$$\epsilon_y = \frac{\sigma_y}{E} - \frac{\nu}{E}(\sigma_x + \sigma_z)$$

$$= \frac{-500\text{ MPa}}{120(10^3)\text{ MPa}} - \frac{0.34}{120(10^3)\text{ MPa}}(800\text{ MPa} + 0) = -0.00643$$

$$\epsilon_z = \frac{\sigma_z}{E} - \frac{\nu}{E}(\sigma_x + \sigma_y)$$

$$= 0 - \frac{0.34}{120(10^3)\text{ MPa}}(800\text{ MPa} - 500\text{ MPa}) = -0.000850$$

The new bar length, width, and thickness are therefore

$$a' = 300\text{ mm} + 0.00808(300\text{ mm}) = 302.4\text{ mm} \quad \textit{Ans.}$$

$$b' = 50\text{ mm} + (-0.00643)(50\text{ mm}) = 49.68\text{ mm} \quad \textit{Ans.}$$

$$t' = 20\text{ mm} + (-0.000850)(20\text{ mm}) = 19.98\text{ mm} \quad \textit{Ans.}$$

## EXAMPLE 10.11

If the rectangular block shown in Fig. 10–25 is subjected to a uniform pressure of $p = 20$ psi, determine the dilatation and the change in length of each side. Take $E = 600$ psi, $\nu = 0.45$.





Fig. 10–25

SOLUTION

**Dilatation.** The dilatation can be determined using Eq. 10–23 with $\sigma_x = \sigma_y = \sigma_z = -20$ psi. We have

$$e = \frac{1 - 2\nu}{E}(\sigma_x + \sigma_y + \sigma_z)$$

$$= \frac{1 - 2(0.45)}{600 \text{ psi}}[3(-20 \text{ psi})]$$

$$= -0.01 \text{ in}^3/\text{in}^3 \qquad \textit{Ans.}$$

**Change in Length.** The normal strain on each side can be determined from Hooke's law, Eq. 10–18; that is,

$$\epsilon = \frac{1}{E}[\sigma_x - \nu(\sigma_y + \sigma_z)]$$

$$= \frac{1}{600 \text{ psi}}[-20 \text{ psi} - (0.45)(-20 \text{ psi} - 20 \text{ psi})] = -0.00333 \text{ in./in.}$$

Thus, the change in length of each side is

$$\delta a = -0.00333(4 \text{ in.}) = -0.0133 \text{ in.} \qquad \textit{Ans.}$$

$$\delta b = -0.00333(2 \text{ in.}) = -0.00667 \text{ in.} \qquad \textit{Ans.}$$

$$\delta c = -0.00333(3 \text{ in.}) = -0.0100 \text{ in.} \qquad \textit{Ans.}$$

The negative signs indicate that each dimension is decreased.

## PROBLEMS

**10–30.** For the case of plane stress, show that Hooke's law can be written as

$$\sigma_x = \frac{E}{(1-\nu^2)}(\epsilon_x + \nu\epsilon_y), \quad \sigma_y = \frac{E}{(1-\nu^2)}(\epsilon_y + \nu\epsilon_x)$$

**10–31.** Use Hooke's law, Eq. 10–18, to develop the strain-transformation equations, Eqs. 10–5 and 10–6, from the stress-transformation equations, Eqs. 9–1 and 9–2.

***10–32.** A bar of copper alloy is loaded in a tension machine and it is determined that $\epsilon_z = 940(10^{-6})$ and $\sigma_x = 14$ ksi, $\sigma_y = 0$, $\sigma_z = 0$. Determine the modulus of elasticity, $E_{cu}$, and the dilatation, $e_{cu}$, of the copper. $\nu_{cu} = 0.35$.

**•10–33.** The principal strains at a point on the aluminum fuselage of a jet aircraft are $\epsilon_1 = 780(10^{-6})$ and $\epsilon_2 = 400(10^{-6})$. Determine the associated principal stresses at the point in the same plane. $E_{al} = 10(10^3)$ ksi, $\nu_{al} = 0.33$. *Hint:* See Prob. 10–30.


**10–34.** The rod is made of aluminum 2014-T6. If it is subjected to the tensile load of 700 N and has a diameter of 20 mm, determine the absolute maximum shear strain in the rod at a point on its surface.

**10–35.** The rod is made of aluminum 2014-T6. If it is subjected to the tensile load of 700 N and has a diameter of 20 mm, determine the principal strains at a point on the surface of the rod.




**Probs. 10–34/35**


***10–36.** The steel shaft has a radius of 15 mm. Determine the torque $T$ in the shaft if the two strain gauges, attached to the surface of the shaft, report strains of $\epsilon_{x'} = -80(10^{-6})$ and $\epsilon_{y'} = 80(10^{-6})$. Also, compute the strains acting in the $x$ and $y$ directions. $E_{st} = 200$ GPa, $\nu_{st} = 0.3$.




**Prob. 10–36**

**10–37.** Determine the bulk modulus for each of the following materials: (a) rubber, $E_r = 0.4$ ksi, $\nu_r = 0.48$, and (b) glass, $E_g = 8(10^3)$ ksi, $\nu_g = 0.24$.

**10–38.** The principal stresses at a point are shown in the figure. If the material is A-36 steel, determine the principal strains.





**Prob. 10–38**

**10–39.** The spherical pressure vessel has an inner diameter of 2 m and a thickness of 10 mm. A strain gauge having a length of 20 mm is attached to it, and it is observed to increase in length by 0.012 mm when the vessel is pressurized. Determine the pressure causing this deformation, and find the maximum in-plane shear stress, and the absolute maximum shear stress at a point on the outer surface of the vessel. The material is steel, for which $E_{st} = 200$ GPa and $\nu_{st} = 0.3$.




**Prob. 10–39**

*10–40. The strain in the $x$ direction at point $A$ on the steel beam is measured and found to be $\epsilon_x = -100(10^{-6})$. Determine the applied load $P$. What is the shear strain $\gamma_{xy}$ at point $A$? $E_{st} = 29(10^3)$ ksi, $\nu_{st} = 0.3$.





Prob. 10–40

•10–41. The cross section of the rectangular beam is subjected to the bending moment **M**. Determine an expression for the increase in length of lines $AB$ and $CD$. The material has a modulus of elasticity $E$ and Poisson's ratio is $\nu$.




Prob. 10–41


10–42. The principal stresses at a point are shown in the figure. If the material is aluminum for which $E_{al} = 10(10^3)$ ksi and $\nu_{al} = 0.33$, determine the principal strains.




Prob. 10–42


10–43. A single strain gauge, placed on the outer surface and at an angle of 30° to the axis of the pipe, gives a reading at point $A$ of $\epsilon_a = -200(10^{-6})$. Determine the horizontal force $P$ if the pipe has an outer diameter of 2 in. and an inner diameter of 1 in. The pipe is made of A-36 steel.

*10–44. A single strain gauge, placed in the vertical plane on the outer surface and at an angle of 30° to the axis of the pipe, gives a reading at point $A$ of $\epsilon_a = -200(10^{-6})$. Determine the principal strains in the pipe at point $A$. The pipe has an outer diameter of 2 in. and an inner diameter of 1 in. and is made of A-36 steel.




Probs. 10–43/44


10–45. The cylindrical pressure vessel is fabricated using hemispherical end caps in order to reduce the bending stress that would occur if flat ends were used. The bending stresses at the seam where the caps are attached can be eliminated by proper choice of the thickness $t_h$ and $t_c$ of the caps and cylinder, respectively. This requires the radial expansion to be the same for both the hemispheres and cylinder. Show that this ratio is $t_c/t_h = (2 - \nu)/(1 - \nu)$. Assume that the vessel is made of the same material and both the cylinder and hemispheres have the same inner radius. If the cylinder is to have a thickness of 0.5 in., what is the required thickness of the hemispheres? Take $\nu = 0.3$.




Prob. 10–45


**10–46.** The principal strains in a plane, measured experimentally at a point on the aluminum fuselage of a jet aircraft, are $\epsilon_1 = 630(10^{-6})$ and $\epsilon_2 = 350(10^{-6})$. If this is a case of plane stress, determine the associated principal stresses at the point in the same plane. $E_{al} = 10(10^3)$ ksi and $\nu_{al} = 0.33$.

**10–47.** The principal stresses at a point are shown in the figure. If the material is aluminum for which $E_{al} = 10(10^3)$ ksi and $\nu_{al} = 0.33$, determine the principal strains.





Prob. 10–47

***10–48.** The 6061-T6 aluminum alloy plate fits snugly into the rigid constraint. Determine the normal stresses $\sigma_x$ and $\sigma_y$ developed in the plate if the temperature is increased by $\Delta T = 50°C$. To solve, add the thermal strain $\alpha\Delta T$ to the equations for Hooke's Law.




Prob. 10–48


**•10–49.** Initially, gaps between the A-36 steel plate and the rigid constraint are as shown. Determine the normal stresses $\sigma_x$ and $\sigma_y$ developed in the plate if the temperature is increased by $\Delta T = 100°F$. To solve, add the thermal strain $\alpha\Delta T$ to the equations for Hooke's Law.




Prob. 10–49

**10–50.** Two strain gauges $a$ and $b$ are attached to a plate made from a material having a modulus of elasticity of $E = 70$ GPa and Poisson's ratio $\nu = 0.35$. If the gauges give a reading of $\epsilon_a = 450(10^{-6})$ and $\epsilon_b = 100(10^{-6})$, determine the intensities of the uniform distributed load $w_x$ and $w_y$ acting on the plate. The thickness of the plate is 25 mm.

**10–51.** Two strain gauges $a$ and $b$ are attached to the surface of the plate which is subjected to the uniform distributed load $w_x = 700$ kN/m and $w_y = -175$ kN/m. If the gauges give a reading of $\epsilon_a = 450(10^{-6})$ and $\epsilon_b = 100(10^{-6})$, determine the modulus of elasticity $E$, shear modulus $G$, and Poisson's ratio $\nu$ for the material.




Probs. 10–50/51


*10–52. The block is fitted between the fixed supports. If the glued joint can resist a maximum shear stress of $\tau_{allow} = 2$ ksi, determine the temperature rise that will cause the joint to fail. Take $E = 10(10^3)$ ksi, $\nu = 0.2$, and *Hint:* Use Eq. 10–18 with an additional strain term of $\alpha\Delta T$ (Eq. 4–4).




Prob. 10–52

•10–53. The smooth rigid-body cavity is filled with liquid 6061-T6 aluminum. When cooled it is 0.012 in. from the top of the cavity. If the top of the cavity is covered and the temperature is increased by 200°F, determine the stress components $\sigma_x$, $\sigma_y$, and $\sigma_z$ in the aluminum. *Hint:* Use Eqs. 10–18 with an additional strain term of $\alpha\Delta T$ (Eq. 4–4).

10–54. The smooth rigid-body cavity is filled with liquid 6061-T6 aluminum. When cooled it is 0.012 in. from the top of the cavity. If the top of the cavity is not covered and the temperature is increased by 200°F, determine the strain components $\epsilon_x$, $\epsilon_y$, and $\epsilon_z$ in the aluminum. *Hint:* Use Eqs. 10–18 with an additional strain term of $\alpha\Delta T$ (Eq. 4–4).





Probs. 10–53/54

10–55. A thin-walled spherical pressure vessel having an inner radius $r$ and thickness $t$ is subjected to an internal pressure $p$. Show that the increase in the volume within the vessel is $\Delta V = (2p\pi r^4/Et)(1 - \nu)$. Use a small-strain analysis.


*10–56. A thin-walled cylindrical pressure vessel has an inner radius $r$, thickness $t$, and length $L$. If it is subjected to an internal pressure $p$, show that the increase in its inner radius is $dr = r\epsilon_1 = pr^2(1 - \frac{1}{2}\nu)/Et$ and the increase in its length is $\Delta L = pLr(\frac{1}{2} - \nu)/Et$. Using these results, show that the change in internal volume becomes $dV = \pi r^2(1 + \epsilon_1)^2(1 + \epsilon_2)L - \pi r^2 L$. Since $\epsilon_1$ and $\epsilon_2$ are small quantities, show further that the change in volume per unit volume, called *volumetric strain*, can be written as $dV/V = pr(2.5 - 2\nu)/Et$.

10–57. The rubber block is confined in the U-shape smooth rigid block. If the rubber has a modulus of elasticity $E$ and Poisson's ratio $\nu$, determine the effective modulus of elasticity of the rubber under the confined condition.




Prob. 10–57

10–58. A soft material is placed within the confines of a rigid cylinder which rests on a rigid support. Assuming that $\epsilon_x = 0$ and $\epsilon_y = 0$, determine the factor by which the modulus of elasticity will be increased when a load is applied if $\nu = 0.3$ for the material.




Prob. 10–58

## *10.7 Theories of Failure

When an engineer is faced with the problem of design using a specific material, it becomes important to place an upper *limit* on the state of stress that defines the material's failure. If the material is *ductile*, failure is usually specified by the initiation of *yielding*, whereas if the material is *brittle*, it is specified by *fracture*. These modes of failure are readily defined if the member is subjected to a uniaxial state of stress, as in the case of simple tension; however, if the member is subjected to biaxial or triaxial stress, the criterion for failure becomes more difficult to establish.

In this section we will discuss four theories that are often used in engineering practice to predict the failure of a material subjected to a *multiaxial* state of stress. No single theory of failure, however, can be applied to a specific material at *all times*, because a material may behave in either a ductile or brittle manner depending on the temperature, rate of loading, chemical environment, or the way the material is shaped or formed. When using a particular theory of failure, it is first necessary to calculate the normal and shear stress at points where they are the largest in the member. Once this state of stress is established, the *principal stresses* at these critical points are then determined, since each of the following theories is based on knowing the principal stress.

### Ductile Materials

**Maximum-Shear-Stress Theory.** The most common type of *yielding of a ductile material* such as steel is caused by *slipping*, which occurs along the contact planes of randomly ordered crystals that make up the material. If we make a specimen into a highly polished thin strip and subject it to a simple tension test, we can actually see how this slipping causes the material to *yield*, Fig. 10–26. The edges of the planes of slipping as they appear on the surface of the strip are referred to as *Lüder's lines*. These lines clearly indicate the slip planes in the strip, which occur at approximately 45° with the axis of the strip.




Fig. 10–26

The slipping that occurs is caused by shear stress. To show this, consider an element of the material taken from a tension specimen, when it is subjected to the yield stress $\sigma_Y$, Fig. 10–27*a*. The maximum shear stress can be determined by drawing Mohr's circle for the element, Fig. 10–27*b*. The results indicate that

$$\tau_{max} = \frac{\sigma_Y}{2} \tag{10–26}$$

Furthermore, this shear stress acts on planes that are 45° from the planes of principal stress, Fig. 10–27*c*, and these planes *coincide* with the direction of the Lüder lines shown on the specimen, indicating that indeed failure occurs by shear.

Using this idea, that ductile materials fail by shear, in 1868 Henri Tresca proposed the ***maximum-shear-stress theory*** or ***Tresca yield criterion***. This theory can be used to predict the failure stress of a ductile material subjected to any type of loading. The theory states that yielding of the material begins when the absolute maximum shear stress in the material reaches the shear stress that causes the same material to yield when it is subjected *only* to axial tension. Therefore, to avoid failure, it is required that $\tau_{abs}$ in the material must be less than or equal to $\sigma_Y/2$, where $\sigma_Y$ is determined from a simple tension test.

For application we will express the absolute maximum shear stress in terms of the *principal stresses*. The procedure for doing this was discussed in Sec. 9.5 with reference to a condition of *plane stress*, that is, where the out-of-plane principal stress is zero. If the two in-plane principal stresses have the *same sign*, i.e., they are both tensile or both compressive, then failure will occur *out of the plane*, and from Eq. 9–13,

$$\tau_{abs} = \frac{\sigma_1}{2}$$

If instead the in-plane principal stresses are of *opposite signs*, then failure occurs in the plane, and from Eq. 9–14,

$$\tau_{abs} = \frac{\sigma_1 - \sigma_2}{2}$$

Using these equations and Eq. 10–26, the maximum-shear-stress theory for *plane stress* can be expressed for any two in-plane principal stresses $\sigma_1$ and $\sigma_2$ by the following criteria:

$$\begin{aligned} |\sigma_1| &= \sigma_Y \\ |\sigma_2| &= \sigma_Y \end{aligned} \Big\} \quad \sigma_1, \sigma_2 \text{ have same signs}$$

$$|\sigma_1 - \sigma_2| = \sigma_Y \} \quad \sigma_1, \sigma_2 \text{ have opposite signs} \qquad (10\text{–}27)$$

A graph of these equations is given in Fig. 10–28. Clearly, if any point of the material is subjected to plane stress, and its in-plane principal stresses are represented by a coordinate $(\sigma_1, \sigma_2)$ plotted *on the boundary* or *outside* the shaded hexagonal area shown in this figure, the material will yield at the point and failure is said to occur.





Fig. 10–27





Fig. 10–28





Fig. 10–29

**Maximum-Distortion-Energy Theory.** It was stated in Sec. 3.5 that an external loading will deform a material, causing it to store energy *internally* throughout its volume. The energy per unit volume of material is called the ***strain-energy density***, and if the material is subjected to a uniaxial stress the strain-energy density, defined by Eq. 3–6, becomes

$$u = \frac{1}{2}\sigma\epsilon \tag{10–28}$$

If the material is subjected to triaxial stress, Fig. 10–29*a*, then each principal stress contributes a portion of the total strain-energy density, so that

$$u = \frac{1}{2}\sigma_1\epsilon_1 + \frac{1}{2}\sigma_2\epsilon_2 + \frac{1}{2}\sigma_3\epsilon_3$$

Furthermore, if the material behaves in a linear-elastic manner, then Hooke's law applies. Therefore, substituting Eq. 10–18 into the above equation and simplifying, we get

$$u = \frac{1}{2E}\left[\sigma_1^2 + \sigma_2^2 + \sigma_3^2 - 2\nu(\sigma_1\sigma_2 + \sigma_1\sigma_3 + \sigma_3\sigma_2)\right] \tag{10–29}$$

This strain-energy density can be considered as the sum of two parts, one part representing the energy needed to cause a *volume change* of the element with no change in shape, and the other part representing the energy needed to *distort* the element. Specifically, the energy stored in the element as a result of its volume being changed is caused by application of the average principal stress, $\sigma_{avg} = (\sigma_1 + \sigma_2 + \sigma_3)/3$, since this stress causes equal principal strains in the material, Fig. 10–29*b*. The remaining portion of the stress, $(\sigma_1 - \sigma_{avg})$, $(\sigma_2 - \sigma_{avg})$, $(\sigma_3 - \sigma_{avg})$, causes the energy of distortion, Fig. 10–29*c*.

Experimental evidence has shown that materials do not yield when subjected to a uniform (hydrostatic) stress, such as $\sigma_{avg}$ discussed above. As a result, in 1904, M. Huber proposed that yielding in a ductile material occurs when the *distortion energy* per unit volume of the material equals or exceeds the distortion energy per unit volume of the same material when it is subjected to yielding in a simple tension test. This theory is called the ***maximum-distortion-energy theory***, and since it was later redefined independently by R. von Mises and H. Hencky, it sometimes also bears their names.

To obtain the distortion energy per unit volume, we will substitute the stresses $(\sigma_1 - \sigma_{avg})$, $(\sigma_2 - \sigma_{avg})$, and $(\sigma_3 - \sigma_{avg})$ for $\sigma_1$, $\sigma_2$, and $\sigma_3$, respectively, into Eq. 10–29, realizing that $\sigma_{avg} = (\sigma_1 + \sigma_2 + \sigma_3)/3$. Expanding and simplifying, we obtain

$$u_d = \frac{1 + \nu}{6E}\left[(\sigma_1 - \sigma_2)^2 + (\sigma_2 - \sigma_3)^2 + (\sigma_3 - \sigma_1)^2\right]$$

In the case of *plane stress*, $\sigma_3 = 0$, and this equation reduces to

$$u_d = \frac{1+\nu}{3E}\left(\sigma_1^2 - \sigma_1\sigma_2 + \sigma_2^2\right)$$

For a *uniaxial* tension test, $\sigma_1 = \sigma_Y$, $\sigma_2 = \sigma_3 = 0$, and so

$$(u_d)_Y = \frac{1+\nu}{3E}\sigma_Y^2$$

Since the maximum-distortion-energy theory requires $u_d = (u_d)_Y$, then for the case of plane or biaxial stress, we have

$$\boxed{\sigma_1^2 - \sigma_1\sigma_2 + \sigma_2^2 = \sigma_Y^2} \tag{10–30}$$

This is the equation of an ellipse, Fig. 10–30. Thus, if a point in the material is stressed such that $(\sigma_1, \sigma_2)$ is plotted on the boundary or outside the shaded area, the material is said to fail.





Fig. 10–30

A comparison of the above two failure criteria is shown in Fig. 10–31. Note that both theories give the same results when the principal stresses are equal, i.e., $\sigma_1 = \sigma_2 = \sigma_Y$, or when one of the principal stresses is zero and the other has a magnitude of $\sigma_Y$. If the material is subjected to pure shear, $\tau$, then the theories have the largest discrepancy in predicting failure. The stress coordinates of these points on the curves can be determined by considering the element shown in Fig. 10–32*a*. From the associated Mohr's circle for this state of stress, Fig. 10–32*b*, we obtain principal stresses $\sigma_1 = \tau$ and $\sigma_2 = -\tau$. Thus, with $\sigma_1 = -\sigma_2$, then from Eq. 10–27, the maximum-shear-stress theory gives $(\sigma_Y/2, -\sigma_Y/2)$, and from Eq. 10–30, the maximum-distortion-energy theory gives $(\sigma_Y/\sqrt{3}, -\sigma_Y/\sqrt{3})$, Fig. 10–31.





Fig. 10–31

Actual torsion tests, used to develop a condition of pure shear in a ductile specimen, have shown that the maximum-distortion-energy theory gives more accurate results for pure-shear failure than the maximum-shear-stress theory. In fact, since $(\sigma_Y/\sqrt{3})/(\sigma_Y/2) = 1.15$, the shear stress for yielding of the material, as given by the maximum-distortion-energy theory, is 15% more accurate than that given by the maximum-shear-stress theory.






Fig. 10–32



Failure of a brittle material in tension

(a)







Failure of a brittle material in torsion

(b)

Fig. 10–33

## Brittle Materials


**Maximum-Normal-Stress Theory.** It was previously stated that brittle materials, such as gray cast iron, tend to fail suddenly by *fracture* with no apparent yielding. In a *tension test*, the fracture occurs when the normal stress reaches the ultimate stress $\sigma_{ult}$, Fig. 10–33*a*. Also, brittle fracture occurs in a torsion test due to tension since the plane of fracture for an element is at 45° to the shear direction, Fig. 10–33*b*. The fracture surface is therefore helical as shown.* Experiments have further shown that during torsion the material's strength is somewhat *unaffected* by the presence of the associated principal compressive stress being at right angles to the principal tensile stress. Consequently, the tensile stress needed to fracture a specimen during a torsion test is approximately the same as that needed to fracture a specimen in simple tension. Because of this, the ***maximum-normal-stress theory*** states that a brittle material will fail when the maximum tensile stress, $\sigma_1$, in the material reaches a value that is equal to the ultimate normal stress the material can sustain when it is subjected to simple tension.

If the material is subjected to *plane stress*, we require that

$$\begin{aligned} |\sigma_1| &= \sigma_{ult} \\ |\sigma_2| &= \sigma_{ult} \end{aligned} \tag{10–31}$$

These equations are shown graphically in Fig. 10–34. Therefore, if the stress coordinates $(\sigma_1, \sigma_2)$ at a point in the material fall on the boundary or outside the shaded area, the material is said to fracture. This theory is generally credited to W. Rankine, who proposed it in the mid-1800s. Experimentally it has been found to be in close agreement with the behavior of brittle materials that have stress–strain diagrams that are *similar* in both tension and compression.

**Mohr's Failure Criterion.** In some brittle materials tension and compression properties are *different*. When this occurs a criterion based on the use of Mohr's circle may be used to predict failure. This method was developed by Otto Mohr and is sometimes referred to as **Mohr's failure criterion**. To apply it, one first performs *three tests* on the material. A uniaxial tensile test and uniaxial compressive test are used to determine the ultimate tensile and compressive stresses $(\sigma_{ult})_t$ and $(\sigma_{ult})_c$, respectively. Also a torsion test is performed to determine the material's ultimate shear stress $\tau_{ult}$. Mohr's circle for each of these stress




Maximum-normal-stress theory

Fig. 10–34

*A stick of blackboard chalk fails in this way when its ends are twisted with the fingers.

conditions is then plotted as shown in Fig. 10–35. These three circles are contained in a "failure envelope" indicated by the extrapolated colored curve that is drawn tangent to all three circles. If a plane-stress condition at a point is represented by a circle that has a point of tangency with the envelope, or if it extends beyond the envelope's boundary, then failure is said to occur.

We may also represent this criterion on a graph of principal stresses $\sigma_1$ and $\sigma_2$. This is shown in Fig. 10–36. Here failure occurs when the absolute value of either one of the principal stresses reaches a value equal to or greater than $(\sigma_{ult})_t$ or $(\sigma_{ult})_c$ or in general, if the state of stress at a point defined by the stress coordinates $(\sigma_1, \sigma_2)$ is plotted on the boundary or outside the shaded area.

Either the maximum-normal-stress theory or Mohr's failure criterion can be used in practice to predict the failure of a brittle material. However, it should be realized that their usefulness is quite limited. A tensile fracture occurs very suddenly, and its initiation generally depends on stress concentrations developed at microscopic imperfections of the material such as inclusions or voids, surface indentations, and small cracks. Since each of these irregularities varies from specimen to specimen, it becomes difficult to specify fracture on the basis of a single test.






Fig. 10–35




Mohr's failure criterion

Fig. 10–36

## Important Points

- If a material is *ductile*, failure is specified by the initiation of *yielding*, whereas if it is *brittle*, it is specified by *fracture*.
- *Ductile failure* can be defined when *slipping* occurs between the crystals that compose the material. This slipping is due to *shear stress* and the *maximum-shear-stress theory* is based on this idea.
- *Strain energy* is stored in a material when it is subjected to normal stress. The *maximum-distortion-energy theory* depends on the *strain energy* that *distorts* the material, and not the part that increases its volume.
- The fracture of a *brittle material* is caused only by the *maximum tensile stress* in the material, and not the compressive stress. This is the basis of the *maximum-normal-stress theory*, and it is applicable if the stress–strain diagram is *similar* in tension and compression.
- If a *brittle material* has a stress–strain diagram that is *different* in tension and compression, then *Mohr's failure criterion* may be used to predict failure.
- Due to material imperfections, *tensile fracture* of a brittle material is *difficult to predict*, and so theories of failure for brittle materials should be used with caution.

## EXAMPLE 10.12

The solid cast-iron shaft shown in Fig. 10–37*a* is subjected to a torque of $T = 400$ lb · ft. Determine its smallest radius so that it does not fail according to the maximum-normal-stress theory. A specimen of cast iron, tested in tension, has an ultimate stress of $(\sigma_{ult})_t = 20$ ksi.





Fig. 10–37

### SOLUTION

The maximum or critical stress occurs at a point located on the surface of the shaft. Assuming the shaft to have a radius $r$, the shear stress is

$$\tau_{max} = \frac{Tc}{J} = \frac{(400\ \text{lb} \cdot \text{ft})(12\ \text{in./ft})r}{(\pi/2)r^4} = \frac{3055.8\ \text{lb} \cdot \text{in.}}{r^3}$$

Mohr's circle for this state of stress (pure shear) is shown in Fig. 10–37*b*. Since $R = \tau_{max}$, then

$$\sigma_1 = -\sigma_2 = \tau_{max} = \frac{3055.8\ \text{lb} \cdot \text{in.}}{r^3}$$

The maximum-normal-stress theory, Eq. 10–31, requires

$$|\sigma_1| \leq \sigma_{ult}$$

$$\frac{3055.8\ \text{lb} \cdot \text{in.}}{r^3} \leq 20\,000\ \text{lb/in}^2$$

Thus, the smallest radius of the shaft is determined from

$$\frac{3055.8\ \text{lb} \cdot \text{in.}}{r^3} = 20\,000\ \text{lb/in}^2$$

$$r = 0.535\ \text{in.} \qquad \textit{Ans.}$$

10

## EXAMPLE 10.13

The solid shaft shown in Fig. 10–38*a* has a radius of 0.5 in. and is made of steel having a yield stress of $\sigma_Y = 36$ ksi. Determine if the loadings cause the shaft to fail according to the maximum-shear-stress theory and the maximum-distortion-energy theory.

### SOLUTION

The state of stress in the shaft is caused by both the axial force and the torque. Since maximum shear stress caused by the torque occurs in the material at the outer surface, we have

$$\sigma_x = \frac{P}{A} = \frac{-15 \text{ kip}}{\pi(0.5 \text{ in.})^2} = -19.10 \text{ ksi}$$

$$\tau_{xy} = \frac{Tc}{J} = \frac{3.25 \text{ kip} \cdot \text{in.}\ (0.5 \text{ in.})}{\frac{\pi}{2}(0.5 \text{ in.})^4} = 16.55 \text{ ksi}$$





Fig. 10–38

The stress components are shown acting on an element of material at point $A$ in Fig. 10–38*b*. Rather than using Mohr's circle, the principal stresses can also be obtained using the stress-transformation Eq. 9–5.

$$\sigma_{1,2} = \frac{\sigma_x + \sigma_y}{2} \pm \sqrt{\left(\frac{\sigma_x - \sigma_y}{2}\right)^2 + \tau_{xy}^2}$$

$$= \frac{-19.10 + 0}{2} \pm \sqrt{\left(\frac{-19.10 - 0}{2}\right)^2 + (16.55)^2}$$

$$= -9.55 \pm 19.11$$

$$\sigma_1 = 9.56 \text{ ksi}$$

$$\sigma_2 = -28.66 \text{ ksi}$$

**Maximum-Shear-Stress Theory.** Since the principal stresses have *opposite signs*, then from Sec. 9.5, the absolute maximum shear stress will occur in the plane, and therefore, applying the second of Eqs. 10–27, we have

$$|\sigma_1 - \sigma_2| \leq \sigma_Y$$

$$|9.56 - (-28.66)| \overset{?}{\leq} 36$$

$$38.2 > 36$$

Thus, shear failure of the material will occur according to this theory.

**Maximum-Distortion-Energy Theory.** Applying Eq. 10–30, we have

$$\left(\sigma_1^2 - \sigma_1\sigma_2 + \sigma_2^2\right) \leq \sigma_Y^2$$

$$\left[(9.56)^2 - (9.56)(-28.66) + (-28.66)^2\right] \overset{?}{\leq} (36)^2$$

$$1187 \leq 1296$$

Using this theory, failure will not occur.

## PROBLEMS

**10–59.** A material is subjected to plane stress. Express the distortion-energy theory of failure in terms of $\sigma_x$, $\sigma_y$, and $\tau_{xy}$.

***10–60.** A material is subjected to plane stress. Express the maximum-shear-stress theory of failure in terms of $\sigma_x$, $\sigma_y$, and $\tau_{xy}$. Assume that the principal stresses are of different algebraic signs.

**•10–61.** An aluminum alloy 6061-T6 is to be used for a solid drive shaft such that it transmits 40 hp at 2400 rev/min. Using a factor of safety of 2 with respect to yielding, determine the smallest-diameter shaft that can be selected based on the maximum-shear-stress theory.

**10–62.** Solve Prob. 10–61 using the maximum-distortion-energy theory.

**10–63.** An aluminum alloy is to be used for a drive shaft such that it transmits 25 hp at 1500 rev/min. Using a factor of safety of 2.5 with respect to yielding, determine the smallest-diameter shaft that can be selected based on the maximum-distortion-energy theory. $\sigma_Y = 3.5$ ksi.


***10–64.** A bar with a square cross-sectional area is made of a material having a yield stress of $\sigma_Y = 120$ ksi. If the bar is subjected to a bending moment of 75 kip · in., determine the required size of the bar according to the maximum-distortion-energy theory. Use a factor of safety of 1.5 with respect to yielding.

**•10–65.** Solve Prob. 10–64 using the maximum-shear-stress theory.

**10–66.** Derive an expression for an equivalent torque $T_e$ that, if applied alone to a solid bar with a circular cross section, would cause the same energy of distortion as the combination of an applied bending moment $M$ and torque $T$.


**10–67.** Derive an expression for an equivalent bending moment $M_e$ that, if applied alone to a solid bar with a circular cross section, would cause the same energy of distortion as the combination of an applied bending moment $M$ and torque $T$.

***10–68.** The short concrete cylinder having a diameter of 50 mm is subjected to a torque of 500 N · m and an axial compressive force of 2 kN. Determine if it fails according to the maximum-normal-stress theory. The ultimate stress of the concrete is $\sigma_{ult} = 28$ MPa.




**Prob. 10–68**

**•10–69.** Cast iron when tested in tension and compression has an ultimate strength of $(\sigma_{ult})_t = 280$ MPa and $(\sigma_{ult})_c = 420$ MPa, respectively. Also, when subjected to pure torsion it can sustain an ultimate shear stress of $\tau_{ult} = 168$ MPa. Plot the Mohr's circles for each case and establish the failure envelope. If a part made of this material is subjected to the state of plane stress shown, determine if it fails according to Mohr's failure criterion.





**Prob. 10–69**

**10–70.** Derive an expression for an equivalent bending moment $M_e$ that, if applied alone to a solid bar with a circular cross section, would cause the same maximum shear stress as the combination of an applied moment $M$ and torque $T$. Assume that the principal stresses are of opposite algebraic signs.

**10–71.** The components of plane stress at a critical point on an A-36 steel shell are shown. Determine if failure (yielding) has occurred on the basis of the maximum-shear-stress theory.

***10–72.** The components of plane stress at a critical point on an A-36 steel shell are shown. Determine if failure (yielding) has occurred on the basis of the maximum-distortion-energy theory.




**Probs. 10–71/72**

**•10–73.** If the 2-in. diameter shaft is made from brittle material having an ultimate strength of $\sigma_{ult} = 50$ ksi for both tension and compression, determine if the shaft fails according to the maximum-normal-stress theory. Use a factor of safety of 1.5 against rupture.


**10–74.** If the 2-in. diameter shaft is made from cast iron having tensile and compressive ultimate strengths of $(\sigma_{ult})_t = 50$ ksi and $(\sigma_{ult})_c = 75$ ksi, respectively, determine if the shaft fails in accordance with Mohr's failure criterion.




**Probs. 10–73/74**

**10–75.** If the A-36 steel pipe has outer and inner diameters of 30 mm and 20 mm, respectively, determine the factor of safety against yielding of the material at point $A$ according to the maximum-shear-stress theory.


***10–76.** If the A-36 steel pipe has an outer and inner diameter of 30 mm and 20 mm, respectively, determine the factor of safety against yielding of the material at point $A$ according to the maximum-distortion-energy theory.




**Probs. 10–75/76**

**•10–77.** The element is subjected to the stresses shown. If $\sigma_Y = 36$ ksi, determine the factor of safety for the loading based on the maximum-shear-stress theory.

**10–78.** Solve Prob. 10–77 using the maximum-distortion-energy theory.





**Probs. 10–77/78**

**10–79.** The yield stress for heat-treated beryllium copper is $\sigma_Y = 130$ ksi. If this material is subjected to plane stress and elastic failure occurs when one principal stress is 145 ksi, what is the smallest magnitude of the other principal stress? Use the maximum-distortion-energy theory.

10

***10–80.** The plate is made of hard copper, which yields at $\sigma_Y = 105$ ksi. Using the maximum-shear-stress theory, determine the tensile stress $\sigma_x$ that can be applied to the plate if a tensile stress $\sigma_y = 0.5\sigma_x$ is also applied.

**•10–81.** Solve Prob. 10–80 using the maximum-distortion-energy theory.




**Probs. 10–80/81**

**10–82.** The state of stress acting at a critical point on the seat frame of an automobile during a crash is shown in the figure. Determine the smallest yield stress for a steel that can be selected for the member, based on the maximum-shear-stress theory.


**10–83.** Solve Prob. 10–82 using the maximum-distortion-energy theory.




**Probs. 10–82/83**

***10–84.** A bar with a circular cross-sectional area is made of SAE 1045 carbon steel having a yield stress of $\sigma_Y = 150$ ksi. If the bar is subjected to a torque of 30 kip · in. and a bending moment of 56 kip · in., determine the required diameter of the bar according to the maximum-distortion-energy theory. Use a factor of safety of 2 with respect to yielding.

**•10–85.** The state of stress acting at a critical point on a machine element is shown in the figure. Determine the smallest yield stress for a steel that might be selected for the part, based on the maximum-shear-stress theory.




**Prob. 10–85**

**10–86.** The principal stresses acting at a point on a thin-walled cylindrical pressure vessel are $\sigma_1 = pr/t$, $\sigma_2 = pr/2t$, and $\sigma_3 = 0$. If the yield stress is $\sigma_Y$, determine the maximum value of $p$ based on (a) the maximum-shear-stress theory and (b) the maximum-distortion-energy theory.

**10–87.** If a solid shaft having a diameter $d$ is subjected to a torque **T** and moment **M**, show that by the maximum-shear-stress theory the maximum allowable shear stress is $\tau_{allow} = (16/\pi d^3)\sqrt{M^2 + T^2}$. Assume the principal stresses to be of opposite algebraic signs.


***10–88.** If a solid shaft having a diameter $d$ is subjected to a torque **T** and moment **M**, show that by the maximum-normal-stress theory the maximum allowable principal stress is $\sigma_{allow} = (16/\pi d^3)(M + \sqrt{M^2 + T^2})$.




**Probs. 10–87/88**


•**10–89.** The shaft consists of a solid segment $AB$ and a hollow segment $BC$, which are rigidly joined by the coupling at $B$. If the shaft is made from A-36 steel, determine the maximum torque $T$ that can be applied according to the maximum-shear-stress theory. Use a factor of safety of 1.5 against yielding.

**10–90.** The shaft consists of a solid segment $AB$ and a hollow segment $BC$, which are rigidly joined by the coupling at $B$. If the shaft is made from A-36 steel, determine the maximum torque $T$ that can be applied according to the maximum-distortion-energy theory. Use a factor of safety of 1.5 against yielding.





**Probs. 10–89/90**

**10–91.** The internal loadings at a critical section along the steel drive shaft of a ship are calculated to be a torque of 2300 lb · ft, a bending moment of 1500 lb · ft, and an axial thrust of 2500 lb. If the yield points for tension and shear are $\sigma_Y = 100$ ksi and $\tau_Y = 50$ ksi, respectively, determine the required diameter of the shaft using the maximum-shear-stress theory.





**Prob. 10–91**

*10–92. The gas tank has an inner diameter of 1.50 m and a wall thickness of 25 mm. If it is made from A-36 steel and the tank is pressured to 5 MPa, determine the factor of safety against yielding using (a) the maximum-shear-stress theory, and (b) the maximum-distortion-energy theory.



**Prob. 10–92**

•**10–93.** The gas tank is made from A-36 steel and has an inner diameter of 1.50 m. If the tank is designed to withstand a pressure of 5 MPa, determine the required minimum wall thickness to the nearest millimeter using (a) the maximum-shear-stress theory, and (b) maximum-distortion-energy theory. Apply a factor of safety of 1.5 against yielding.



**Prob. 10–93**

## CHAPTER REVIEW

When an element of material is subjected to deformations that only occur in a single plane, then it undergoes plane strain. If the strain components $\epsilon_x$, $\epsilon_y$, and $\gamma_{xy}$ are known for a specified orientation of the element, then the strains acting for some other orientation of the element can be determined using the plane-strain transformation equations. Likewise, the principal normal strains and maximum in-plane shear strain can be determined using transformation equations.

$$\epsilon_{x'} = \frac{\epsilon_x + \epsilon_y}{2} + \frac{\epsilon_x - \epsilon_y}{2}\cos 2\theta + \frac{\gamma_{xy}}{2}\sin 2\theta$$

$$\epsilon_{y'} = \frac{\epsilon_x + \epsilon_y}{2} - \frac{\epsilon_x - \epsilon_y}{2}\cos 2\theta - \frac{\gamma_{xy}}{2}\sin 2\theta$$


$$\frac{\gamma_{x'y'}}{2} = -\left(\frac{\epsilon_x - \epsilon_y}{2}\right)\sin 2\theta + \frac{\gamma_{xy}}{2}\cos 2\theta$$

$$\epsilon_{1,2} = \frac{\epsilon_x + \epsilon_y}{2} \pm \sqrt{\left(\frac{\epsilon_x - \epsilon_y}{2}\right)^2 + \left(\frac{\gamma_{xy}}{2}\right)^2}$$

$$\frac{\gamma_{\text{in-plane}}^{\text{max}}}{2} = \sqrt{\left(\frac{\epsilon_x - \epsilon_y}{2}\right)^2 + \left(\frac{\gamma_{xy}}{2}\right)^2}$$

$$\epsilon_{\text{avg}} = \frac{\epsilon_x + \epsilon_y}{2}$$

Strain transformation problems can also be solved in a semi-graphical manner using Mohr's circle. To draw the circle, the $\epsilon$ and $\gamma/2$ axes are established and the center of the circle $C\,[(\epsilon_x + \epsilon_y)/2, 0]$ and the "reference point" $A$ $(\epsilon_x, \gamma_{xy}/2)$ are plotted. The radius of the circle extends between these two points and is determined from trigonometry.




If $\epsilon_1$ and $\epsilon_2$ have the same sign then the absolute maximum shear strain will be out of plane.

$$\gamma_{\text{max}}^{\text{abs}} = \epsilon_1$$

$$\gamma_{\text{max}}^{\text{in-plane}} = \epsilon_1 - \epsilon_2$$

In the case of plane strain, the absolute maximum shear strain will be equal to the maximum in-plane shear strain provided the principal strains $\epsilon_1$ and $\epsilon_2$ have opposite signs.

$$\gamma_{\text{max}}^{\text{abs}} = \epsilon_1 - \epsilon_2$$


10

| | | |
|---|---|---|
| If the material is subjected to triaxial stress, then the strain in each direction is influenced by the strain produced by all three stresses. Hooke's law then involves the material properties $E$ and $\nu$. | $\epsilon_x = \frac{1}{E}[\sigma_x - \nu(\sigma_y + \sigma_z)]$<br>$\epsilon_y = \frac{1}{E}[\sigma_y - \nu(\sigma_x + \sigma_z)]$<br>$\epsilon_z = \frac{1}{E}[\sigma_z - \nu(\sigma_x + \sigma_y)]$ | |
| If $E$ and $\nu$ are known, then $G$ can be determined. | $G = \frac{E}{2(1 + \nu)}$ | |
| The dilatation is a measure of volumetric strain.<br>The bulk modulus is used to measure the stiffness of a volume of material. | $e = \frac{1 - 2\nu}{E}(\sigma_x + \sigma_y + \sigma_z)$<br>$k = \frac{E}{3(1 - 2\nu)}$ | |
| If the principal stresses at a critical point in the material are known, then a theory of failure can be used as a basis for design.<br>*Ductile materials fail in shear*, and here the maximum-shear-stress theory or the maximum-distortion-energy theory can be used to predict failure. Both of these theories make comparison to the yield stress of a specimen subjected to a uniaxial tensile stress.<br>*Brittle materials fail in tension*, and so the maximum-normal-stress theory or Mohr's failure criterion can be used to predict failure. Here comparisons are made with the ultimate tensile stress developed in a specimen. | | |

## REVIEW PROBLEMS


**10–94.** A thin-walled spherical pressure vessel has an inner radius $r$, thickness $t$, and is subjected to an internal pressure $p$. If the material constants are $E$ and $\nu$, determine the strain in the circumferential direction in terms of the stated parameters.

**10–95.** The strain at point $A$ on the shell has components $\epsilon_x = 250(10^{-6})$, $\epsilon_y = 400(10^{-6})$, $\gamma_{xy} = 275(10^{-6})$, $\epsilon_z = 0$. Determine (a) the principal strains at $A$, (b) the maximum shear strain in the $x$–$y$ plane, and (c) the absolute maximum shear strain.





Prob. 10–95

***10–96.** The principal plane stresses acting at a point are shown in the figure. If the material is machine steel having a yield stress of $\sigma_Y = 500$ MPa, determine the factor of safety with respect to yielding if the maximum-shear-stress theory is considered.





Prob. 10–96

**•10–97.** The components of plane stress at a critical point on a thin steel shell are shown. Determine if failure (yielding) has occurred on the basis of the maximum-distortion-energy theory. The yield stress for the steel is $\sigma_Y = 650$ MPa.




Prob. 10–97

**10–98.** The 60° strain rosette is mounted on a beam. The following readings are obtained for each gauge: $\epsilon_a = 600(10^{-6})$, $\epsilon_b = -700(10^{-6})$, and $\epsilon_c = 350(10^{-6})$. Determine (a) the in-plane principal strains and (b) the maximum in-plane shear strain and average normal strain. In each case show the deformed element due to these strains.





Prob. 10–98

**10–99.** A strain gauge forms an angle of 45° with the axis of the 50-mm diameter shaft. If it gives a reading of $\epsilon = -200(10^{-6})$ when the torque **T** is applied to the shaft, determine the magnitude of **T**. The shaft is made from A-36 steel.




Prob. 10–99


***10–100.** The A-36 steel post is subjected to the forces shown. If the strain gauges *a* and *b* at point *A* give readings of $\epsilon_a = 300(10^{-6})$ and $\epsilon_b = 175(10^{-6})$, determine the magnitudes of $\mathbf{P}_1$ and $\mathbf{P}_2$.




Prob. 10–100


**10–101.** A differential element is subjected to plane strain that has the following components: $\epsilon_x = 950(10^{-6})$, $\epsilon_y = 420(10^{-6})$, $\gamma_{xy} = -325(10^{-6})$. Use the strain-transformation equations and determine (a) the principal strains and (b) the maximum in-plane shear strain and the associated average strain. In each case specify the orientation of the element and show how the strains deform the element.

**10–102.** The state of plane strain on an element is $\epsilon_x = 400(10^{-6})$, $\epsilon_y = 200(10^{-6})$, and $\gamma_{xy} = -300(10^{-6})$. Determine the equivalent state of strain on an element at the same point oriented 30° clockwise with respect to the original element. Sketch the results on the element.




Prob. 10–102

**10–103.** The state of plane strain on an element is $\epsilon_x = 400(10^{-6})$, $\epsilon_y = 200(10^{-6})$, and $\gamma_{xy} = -300(10^{-6})$. Determine the equivalent state of strain, which represents (a) the principal strains, and (b) the maximum in-plane shear strain and the associated average normal strain. Specify the orientation of the corresponding element at the point with respect to the original element. Sketch the results on the element.




Prob. 10–103



Beams are important structural members that are used to support roof and floor loadings.

# Design of Beams and Shafts

# 11

**CHAPTER OBJECTIVES**

In this chapter, we will discuss how to design a beam so that it is able to resist both bending and shear loads. Specifically, methods used for designing prismatic beams and determining the shape of fully stressed beams will be developed. At the end of the chapter, we will consider the design of shafts based on the resistance of both bending and torsional moments.

## 11.1 Basis for Beam Design

Beams are said to be designed on the basis of strength so that they can resist the internal shear and moment developed along their length. To design a beam in this way requires application of the shear and flexure formulas provided the material is homogeneous and has linear elastic behavior. Although some beams may also be subjected to an axial force, the effects of this force are often neglected in design since the axial stress is generally much smaller than the stress developed by shear and bending.





Fig. 11–1

As shown in Fig. 11–1, the external loadings on a beam will create additional stresses in the beam *directly under the load*. Notably, a compressive stress $\sigma_y$ will be developed, in addition to the bending stress $\sigma_x$ and shear stress $\tau_{xy}$ discussed previously. Using advanced methods of analysis, as treated in the theory of elasticity, it can be shown that $\sigma_y$ diminishes rapidly throughout the beam's depth, and for *most* beam span-to-depth ratios used in engineering practice, the maximum value of $\sigma_y$ generally represents only a small percentage compared to the bending stress $\sigma_x$, that is, $\sigma_x \gg \sigma_y$. Furthermore, the direct application of concentrated loads is generally avoided in beam design. Instead, *bearing plates* are used to spread these loads more evenly onto the surface of the beam.

Although beams are designed mainly for strength, they must also be braced properly along their sides so that they do not buckle or suddenly become unstable. Furthermore, in some cases beams must be designed to resist a limited amount of *deflection*, as when they support ceilings made of brittle materials such as plaster. Methods for finding beam deflections will be discussed in Chapter 12, and limitations placed on beam buckling are often discussed in codes related to structural or mechanical design.

Since the shear and flexure formulas are used for beam design, we will discuss the general results obtained when these equations are applied to various points in a cantilevered beam that has a rectangular cross section and supports a load **P** at its end, Fig. 11–2*a*.

In general, at an arbitrary section *a–a* along the beam's axis, Fig. 11–2*b*, the internal shear **V** and moment **M** are developed from a *parabolic* shear-stress distribution, and a *linear* normal-stress distribution, Fig. 11–2*c*. As a result, the stresses acting on elements located at points 1 through 5 along the section will be as shown in Fig. 11–2*d*. Note that elements 1 and 5 are subjected only to the maximum normal stress, whereas element 3, which is on the neutral axis, is subjected only to the maximum shear stress. The intermediate elements 2 and 4 resist *both* normal and shear stress.

In each case the state of stress can be transformed into *principal stresses*, using either the stress-transformation equations or Mohr's circle. The results are shown in Fig. 11–2*e*. Here each successive element, 1 through 5, undergoes a counterclockwise orientation. Specifically, relative to element 1, considered to be at the 0° position, element 3 is oriented at 45° and element 5 is oriented at 90°.




Whenever large shear loads occur on a beam it is important to use stiffeners such as at *A*, in order to prevent any localized failure such as crimping of the beam flanges.





Fig. 11–2




Stress trajectories for cantilevered beam

Fig. 11–3

If this analysis is extended to many vertical sections along the beam other than *a–a*, a profile of the results can be represented by curves called *stress trajectories*. Each of these curves indicated the *direction* of a principal stress having a constant magnitude. Some of these trajectories are shown for the cantilevered beam in Fig. 11–3. Here the solid lines represent the direction of the tensile principal stresses and the dashed lines represent the direction of the compressive principal stresses. As expected, the lines intersect the neutral axis at 45° angles (like element 3) and the solid and dashed lines will intersect at 90° because the principal stresses are always 90° apart. Knowing the direction of these lines can help engineers decide where to reinforce a beam if it is made of brittle material so that it does not crack or become unstable.

## 11.2 Prismatic Beam Design

Most beams are made of ductile materials and when this is the case it is generally not necessary to plot the stress trajectories for the beam. Instead, it is simply necessary to be sure the actual bending stress and shear stress in the beam do not exceed allowable bending and shear stress for the material as defined by structural or mechanical codes. In the majority of cases the suspended span of the beam will be relatively long, so that the internal moments become large. When this occurs the engineer will first consider a design based upon bending and then check the shear strength. A bending design requires a determination of the beam's ***section modulus***, a geometric property which is the ratio of $I$ and $c$, that is, $S = I/c$. Using the flexure formula, $\sigma = Mc/I$, we have

$$S_{\text{req'd}} = \frac{M_{\max}}{\sigma_{\text{allow}}} \tag{11–1}$$

Here $M$ is determined from the beam's moment diagram, and the allowable bending stress, $\sigma_{\text{allow}}$, is specified in a design code. In many cases the beam's as yet unknown weight will be small and can be neglected in comparison with the loads the beam must carry. However, if the additional moment caused by the weight is to be included in the design, a selection for $S$ is made so that it slightly *exceeds* $S_{\text{req'd}}$.

Once $S_{\text{req'd}}$ is known, if the beam has a simple cross-sectional shape, such as a square, a circle, or a rectangle of known width-to-height proportions, its *dimensions* can be determined directly from $S_{\text{req'd}}$, since $S_{\text{req'd}} = I/c$. However, if the cross section is made from several elements, such as a wide-flange section, then an infinite number of web and flange dimensions can be determined that satisfy the value of $S_{\text{req'd}}$. In practice, however, engineers choose a particular beam meeting the requirement that $S > S_{\text{req'd}}$ from a handbook that lists the standard shapes available from manufacturers. Often several beams that have the same section modulus can be selected from these tables. If deflections are not restricted, usually the beam having the smallest cross-sectional area is chosen, since it is made of less material and is therefore both lighter and more economical than the others.




The two floor beams are connected to the beam $AB$, which transmits the load to the columns of this building frame. For design, all the connections can be considered to act as pins.

Once the beam has been selected, the shear formula $\tau_{allow} \geq VQ/It$ can then be used to check that the allowable shear stress is not exceeded. Often this requirement will not present a problem. However, if the beam is "short" and supports large concentrated loads, the shear-stress limitation may dictate the size of the beam. This limitation is particularly important in the design of wood beams, because wood tends to split along its grain due to shear (see Fig. 7–10*e*).

**Fabricated Beams.** Since beams are often made of steel or wood, we will now discuss some of the tabulated properties of beams made from these materials.

**Steel Sections.** Most manufactured steel beams are produced by rolling a hot ingot of steel until the desired shape is formed. These so-called *rolled shapes* have properties that are tabulated in the American Institute of Steel Construction (AISC) manual. A representative listing for wide-flange beams taken from this manual is given in Appendix B. As noted in this appendix, the wide-flange shapes are designated by their depth and weight per unit length; for example, W18 × 46 indicates a wide-flange cross section (W) having a depth of 18 in. and a weight of 46 lb/ft, Fig. 11–4. For any given section, the weight per length, dimensions, cross-sectional area, moment of inertia, and section modulus are reported. Also included is the radius of gyration $r$, which is a geometric property related to the section's buckling strength. This will be discussed in Chapter 13. Appendix B and the *AISC Manual* also list data for other members such as channels and angles.







Fig. 11–4



Typical profile view of a steel wide-flange beam.

**Wood Sections.** Most beams made of wood have rectangular cross sections because such beams are easy to manufacture and handle. Manuals, such as that of the National Forest Products Association, list the dimensions of lumber often used in the design of wood beams. Often, both the nominal and actual dimensions are reported. Lumber is identified by its *nominal* dimensions, such as 2 × 4 (2 in. by 4 in.); however, its actual or "dressed" dimensions are smaller, being 1.5 in. by 3.5 in. The reduction in the dimensions occurs in order to obtain a smooth surface from lumber that is rough sawn. Obviously, the *actual dimensions* must be used whenever stress calculations are performed on wood beams.




Steel plate girders

Fig. 11–5

**Built-up Sections.** A *built-up section* is constructed from two or more parts joined together to form a single unit. Since $S_{req'd} = M/\sigma_{allow}$, the capacity of the beam to resist a moment will vary directly with its section modulus, and since $S_{req'd} = I/c$, then $S_{req'd}$ is *increased* if $I$ is *increased*. In order to increase $I$, *most of the material* should be placed as far *away* from the neutral axis as practical. This, of course, is what makes a deep wide-flange beam so efficient in resisting a moment. For a very large load, however, an available rolled-steel section may not have a section modulus great enough to support the load. Rather than using several available beams, instead engineers will usually "build up" a beam made from plates and angles. A deep I-shaped section having this form is called a *plate girder*. For example, the steel plate girder in Fig. 11–5 has two flange plates that are either welded or, using angles, bolted to the web plate.

Wood beams are also "built up," usually in the form of a box beam section, Fig. 11–6*a*. They may be made having plywood webs and larger boards for the flanges. For very large spans, *glulam beams* are used. These members are made from several boards glue-laminated together to form a single unit, Fig. 11–6*b*.

Just as in the case of rolled sections or beams made from a single piece, the design of built-up sections requires that the bending and shear stresses be checked. In addition, the shear stress in the fasteners, such as weld, glue, nails, etc., must be checked to be certain the beam acts as a single unit. The principles for doing this were outlined in Sec. 7.4.



Wooden box beam

(a)



Glulam beam

(b)

Fig. 11–6

## Important Points

- Beams support loadings that are applied perpendicular to their axes. If they are designed on the basis of strength, they must resist allowable shear and bending stresses.
- The maximum bending stress in the beam is assumed to be much greater than the localized stresses caused by the application of loadings on the surface of the beam.

## Procedure for Analysis

Based on the previous discussion, the following procedure provides a rational method for the design of a beam on the basis of strength.

### Shear and Moment Diagrams.

- Determine the maximum shear and moment in the beam. Often this is done by constructing the beam's shear and moment diagrams.
- For built-up beams, shear and moment diagrams are useful for identifying *regions* where the shear and moment are excessively large and may require additional structural reinforcement or fasteners.

### Bending Stress.

- If the beam is relatively long, it is designed by finding its section modulus using the flexure formula, $S_{req'd} = M_{max}/\sigma_{allow}$.
- Once $S_{req'd}$ is determined, the cross-sectional dimensions for simple shapes can then be computed, since $S_{req'd} = I/c$.
- If rolled-steel sections are to be used, several possible values of $S$ may be selected from the tables in Appendix B. Of these, choose the one having the smallest cross-sectional area, since this beam has the least weight and is therefore the most economical.
- Make sure that the selected section modulus, $S$, is *slightly greater* than $S_{req'd}$, so that the additional moment created by the beam's weight is considered.

### Shear Stress.

- Normally beams that are short and carry large loads, especially those made of wood, are first designed to resist shear and then later checked against the allowable-bending-stress requirements.
- Using the shear formula, check to see that the allowable shear stress is not exceeded; that is, use $\tau_{allow} \geq V_{max}Q/It$.
- If the beam has a solid *rectangular* cross section, the shear formula becomes $\tau_{allow} \geq 1.5(V_{max}/A)$ (See Eq. 2 of Example 7.2.), and if the cross section is a *wide flange*, it is generally appropriate to assume that the shear stress is *constant* over the cross-sectional area of the beam's web so that $\tau_{allow} \geq V_{max}/A_{web}$, where $A_{web}$ is determined from the product of the beam's depth and the web's thickness. (See the note at the end of Example 7.3.)

### Adequacy of Fasteners.

- The adequacy of fasteners used on built-up beams depends upon the shear stress the fasteners can resist. Specifically, the required spacing of nails or bolts of a particular size is determined from the allowable shear flow, $q_{allow} = VQ/I$, calculated at points on the cross section where the fasteners are located. (See Sec. 7.3.)

## EXAMPLE 11.1





Fig. 11–7

A beam is to be made of steel that has an allowable bending stress of $\sigma_{allow} = 24$ ksi and an allowable shear stress of $\tau_{allow} = 14.5$ ksi. Select an appropriate W shape that will carry the loading shown in Fig. 11–7*a*.

### SOLUTION

**Shear and Moment Diagrams.** The support reactions have been calculated, and the shear and moment diagrams are shown in Fig. 11–7*b*. From these diagrams, $V_{max} = 30$ kip and $M_{max} = 120$ kip · ft.

**Bending Stress.** The required section modulus for the beam is determined from the flexure formula,

$$S_{req'd} = \frac{M_{max}}{\sigma_{allow}} = \frac{120 \text{ kip} \cdot \text{ft}\ (12 \text{ in./ft})}{24 \text{ kip/in}^2} = 60 \text{ in}^3$$

Using the table in Appendix B, the following beams are adequate:

| | |
|---|---|
| W18 × 40 | $S = 68.4$ in$^3$ |
| W16 × 45 | $S = 72.7$ in$^3$ |
| W14 × 43 | $S = 62.7$ in$^3$ |
| W12 × 50 | $S = 64.7$ in$^3$ |
| W10 × 54 | $S = 60.0$ in$^3$ |
| W8 × 67 | $S = 60.4$ in$^3$ |

The beam having the least weight per foot is chosen, i.e.,

W18 × 40

The *actual* maximum moment $M_{max}$, which includes the weight of the beam, can be calculated and the adequacy of the selected beam can be checked. In comparison with the applied loads, however, the beam's weight, $(0.040 \text{ kip/ft})(18 \text{ ft}) = 0.720$ kip, will only *slightly increase* $S_{req'd}$. In spite of this,

$$S_{req'd} = 60 \text{ in}^3 < 68.4 \text{ in}^3 \qquad \text{OK}$$

**Shear Stress.** Since the beam is a *wide-flange section*, the *average shear stress* within the web will be considered. (See Example 7.3.) Here the web is assumed to extend from the very top to the very bottom of the beam. From Appendix B, for a W18 × 40, $d = 17.90$ in., $t_w = 0.315$ in. Thus,

$$\tau_{avg} = \frac{V_{max}}{A_w} = \frac{30 \text{ kip}}{(17.90 \text{ in.})(0.315 \text{ in.})} = 5.32 \text{ ksi} < 14.5 \text{ ksi} \qquad \text{OK}$$

Use a W18 × 40. *Ans.*

## EXAMPLE 11.2

The laminated wooden beam shown in Fig. 11–8*a* supports a uniform distributed loading of 12 kN/m. If the beam is to have a height-to-width ratio of 1.5, determine its smallest width. The allowable bending stress is $\sigma_{allow} = 9$ MPa and the allowable shear stress is $\tau_{allow} = 0.6$ MPa. Neglect the weight of the beam.





Fig. 11–8

### SOLUTION

**Shear and Moment Diagrams.** The support reactions at $A$ and $B$ have been calculated and the shear and moment diagrams are shown in Fig. 11–8*b*. Here $V_{max} = 20$ kN, $M_{max} = 10.67$ kN · m.

**Bending Stress.** Applying the flexure formula,

$$S_{req'd} = \frac{M_{max}}{\sigma_{allow}} = \frac{10.67(10^3)\ \text{N} \cdot \text{m}}{9(10^6)\ \text{N/m}^2} = 0.00119\ \text{m}^3$$

Assuming that the width is $a$, then the height is $1.5a$, Fig. 11–8*a*. Thus,

$$S_{req'd} = \frac{I}{c} = 0.00119\ \text{m}^3 = \frac{\frac{1}{12}(a)(1.5a)^3}{(0.75a)}$$

$$a^3 = 0.003160\ \text{m}^3$$

$$a = 0.147\ \text{m}$$

**Shear Stress.** Applying the shear formula for rectangular sections (which is a special case of $\tau_{max} = VQ/It$, Example 7.2), we have

$$\tau_{max} = 1.5\frac{V_{max}}{A} = (1.5)\frac{20(10^3)\ \text{N}}{(0.147\ \text{m})(1.5)(0.147\ \text{m})}$$

$$= 0.929\ \text{MPa} > 0.6\ \text{MPa}$$

### EQUATION

Since the design fails the shear criterion, the beam must be redesigned on the basis of shear.

$$\tau_{allow} = 1.5\frac{V_{max}}{A}$$

$$600\ \text{kN/m}^2 = 1.5\frac{20(10^3)\ \text{N}}{(a)(1.5a)}$$


$$a = 0.183\ \text{m} = 183\ \text{mm} \qquad \textit{Ans.}$$

This larger section will also adequately resist the normal stress.

## EXAMPLE 11.3

The wooden T-beam shown in Fig. 11–9*a* is made from two 200 mm × 30 mm boards. If the allowable bending stress is $\sigma_{allow} = 12$ MPa and the allowable shear stress is $\tau_{allow} = 0.8$ MPa, determine if the beam can safely support the loading shown. Also, specify the maximum spacing of nails needed to hold the two boards together if each nail can safely resist 1.50 kN in shear.




(a)

### SOLUTION

**Shear and Moment Diagrams.** The reactions on the beam are shown, and the shear and moment diagrams are drawn in Fig. 11–9*b*. Here $V_{max} = 1.5$ kN, $M_{max} = 2$ kN · m.

**Bending Stress.** The neutral axis (centroid) will be located from the bottom of the beam. Working in units of meters, we have

$$\bar{y} = \frac{\Sigma \bar{y} A}{\Sigma A}$$

$$= \frac{(0.1\text{ m})(0.03\text{ m})(0.2\text{ m}) + 0.215\text{ m}(0.03\text{ m})(0.2\text{ m})}{0.03\text{ m}(0.2\text{ m}) + 0.03\text{ m}(0.2\text{ m})} = 0.1575\text{ m}$$

Thus,

$$I = \left[\frac{1}{12}(0.03\text{ m})(0.2\text{ m})^3 + (0.03\text{ m})(0.2\text{ m})(0.1575\text{ m} - 0.1\text{ m})^2\right]$$


$$+ \left[\frac{1}{12}(0.2\text{ m})(0.03\text{ m})^3 + (0.03\text{ m})(0.2\text{ m})(0.215\text{ m} - 0.1575\text{ m})^2\right]$$

$$= 60.125(10^{-6})\text{ m}^4$$

Since $c = 0.1575$ m (not $0.230\text{ m} - 0.1575\text{ m} = 0.0725$ m), we require

$$\sigma_{allow} \geq \frac{M_{max} c}{I}$$


$$12(10^6)\text{ Pa} \geq \frac{2(10^3)\text{ N} \cdot \text{m}(0.1575\text{ m})}{60.125(10^{-6})\text{ m}^4} = 5.24(10^6)\text{ Pa} \quad \text{OK}$$




(b)

Fig. 11–9

**Shear Stress.** Maximum shear stress in the beam depends upon the magnitude of $Q$ and $t$. It occurs at the neutral axis, since $Q$ is a maximum there and the neutral axis is in the web, where the thickness $t = 0.03$ m is smallest for the cross section. For simplicity, we will use the rectangular area below the neutral axis to calculate $Q$, rather than a two-part composite area above this axis, Fig. 11–9*c*. We have




(c)


$$Q = \bar{y}'A' = \left(\frac{0.1575\text{ m}}{2}\right)[(0.1575\text{ m})(0.03\text{ m})] = 0.372(10^{-3})\text{ m}^3$$

so that

$$\tau_{\text{allow}} \geq \frac{V_{\max}Q}{It}$$

$$800(10^3)\text{ Pa} \geq \frac{1.5(10^3)\text{ N}[0.372(10^{-3})]\text{ m}^3}{60.125(10^{-6})\text{ m}^4\,(0.03\text{ m})} = 309(10^3)\text{ Pa} \quad \text{OK}$$

**Nail Spacing.** From the shear diagram it is seen that the shear varies over the entire span. Since the nail spacing depends on the magnitude of shear in the beam, for simplicity (and to be conservative), we will design the spacing on the basis of $V = 1.5$ kN for region $BC$ and $V = 1$ kN for region $CD$. Since the nails join the flange to the web, Fig. 11–9*d*, we have




(d)

Fig. 11–9 (cont.)

$$Q = \bar{y}'A' = (0.0725\text{ m} - 0.015\text{ m})[(0.2\text{ m})(0.03\text{ m})] = 0.345(10^{-3})\text{ m}^3$$

The shear flow for each region is therefore

$$q_{BC} = \frac{V_{BC}Q}{I} = \frac{1.5(10^3)\text{ N}[0.345(10^{-3})\text{ m}^3]}{60.125(10^{-6})\text{ m}^4} = 8.61\text{ kN/m}$$

$$q_{CD} = \frac{V_{CD}Q}{I} = \frac{1(10^3)\text{ N}[0.345(10^{-3})\text{ m}^3]}{60.125(10^{-6})\text{ m}^4} = 5.74\text{ kN/m}$$

One nail can resist 1.50 kN in shear, so the maximum spacing becomes

$$s_{BC} = \frac{1.50\text{ kN}}{8.61\text{ kN/m}} = 0.174\text{ m}$$

$$s_{CD} = \frac{1.50\text{ kN}}{5.74\text{ kN/m}} = 0.261\text{ m}$$


For ease of measuring, use

$$s_{BC} = 150\text{ mm} \qquad \textit{Ans.}$$

$$s_{CD} = 250\text{ mm} \qquad \textit{Ans.}$$


## FUNDAMENTAL PROBLEMS

**F11–1.** Determine the minimum dimension $a$ to the nearest mm of the beam's cross section to safely support the load. The wood has an allowable normal stress of $\sigma_{allow} = 10$ MPa and an allowable shear stress of $\tau_{allow} = 1$ MPa.





F11–1

**F11–2.** Determine the minimum diameter $d$ to the nearest $\frac{1}{8}$ in. of the rod to safely support the load. The rod is made of a material having an allowable normal stress of $\sigma_{allow} = 20$ ksi and an allowable shear stress of $\tau_{allow} = 10$ ksi.





F11–2

**F11–3.** Determine the minimum dimension $a$ to the nearest mm of the beam's cross section to safely support the load. The wood has an allowable normal stress of $\sigma_{allow} = 12$ MPa and an allowable shear stress of $\tau_{allow} = 1.5$ MPa.





F11–3

**F11–4.** Determine the minimum dimension $h$ to the nearest $\frac{1}{8}$ in. of the beam's cross section to safely support the load. The wood has an allowable normal stress of $\sigma_{allow} = 2$ ksi and an allowable shear stress of $\tau_{allow} = 200$ psi.





F11–4

**F11–5.** Determine the minimum dimension $b$ to the nearest mm of the beam's cross section to safely support the load. The wood has an allowable normal stress of $\sigma_{allow} = 12$ MPa and an allowable shear stress of $\tau_{allow} = 1.5$ MPa.




F11–5


**F11–6.** Select the lightest W410-shaped section that can safely support the load. The beam is made of steel having an allowable normal stress of $\sigma_{allow} = 150$ MPa and an allowable shear stress of $\tau_{allow} = 75$ MPa.




F11–6


## PROBLEMS

**11–1.** The simply supported beam is made of timber that has an allowable bending stress of $\sigma_{allow} = 6.5$ MPa and an allowable shear stress of $\tau_{allow} = 500$ kPa. Determine its dimensions if it is to be rectangular and have a height-to-width ratio of 1.25.





Prob. 11–1

**11–2.** The brick wall exerts a uniform distributed load of 1.20 kip/ft on the beam. If the allowable bending stress is $\sigma_{allow} = 22$ ksi and the allowable shear stress is $\tau_{allow} = 12$ ksi, select the lightest wide-flange section with the shortest depth from Appendix B that will safely support the load.





Prob. 11–2

**11–3.** The brick wall exerts a uniform distributed load of 1.20 kip/ft on the beam. If the allowable bending stress is $\sigma_{allow} = 22$ ksi, determine the required width $b$ of the flange to the nearest $\frac{1}{4}$ in.





Prob. 11–3

***11–4.** Draw the shear and moment diagrams for the shaft, and determine its required diameter to the nearest $\frac{1}{4}$ in. if $\sigma_{allow} = 7$ ksi and $\tau_{allow} = 3$ ksi. The bearings at $A$ and $D$ exert only vertical reactions on the shaft. The loading is applied to the pulleys at $B$, $C$, and $E$.





Prob. 11–4

•**11–5.** Select the lightest-weight steel wide-flange beam from Appendix B that will safely support the machine loading shown. The allowable bending stress is $\sigma_{allow} = 24$ ksi and the allowable shear stress is $\tau_{allow} = 14$ ksi.





Prob. 11–5

**11–6.** The compound beam is made from two sections, which are pinned together at $B$. Use Appendix B and select the lightest-weight wide-flange beam that would be safe for each section if the allowable bending stress is $\sigma_{allow} = 24$ ksi and the allowable shear stress is $\tau_{allow} = 14$ ksi. The beam supports a pipe loading of 1200 lb and 1800 lb as shown.





Prob. 11–6

**11–7.** If the bearing pads at $A$ and $B$ support only vertical forces, determine the greatest magnitude of the uniform distributed loading $w$ that can be applied to the beam. $\sigma_{allow} = 15$ MPa, $\tau_{allow} = 1.5$ MPa.




**Prob. 11–7**


***11–8.** The simply supported beam is made of timber that has an allowable bending stress of $\sigma_{allow} = 1.20$ ksi and an allowable shear stress of $\tau_{allow} = 100$ psi. Determine its smallest dimensions to the nearest $\frac{1}{8}$ in. if it is rectangular and has a height-to-width ratio of 1.5.




**Prob. 11–8**


**•11–9.** Select the lightest-weight W12 steel wide-flange beam from Appendix B that will safely support the loading shown, where $P = 6$ kip. The allowable bending stress is $\sigma_{allow} = 22$ ksi and the allowable shear stress is $\tau_{allow} = 12$ ksi.

**11–10.** Select the lightest-weight W14 steel wide-flange beam having the shortest height from Appendix B that will safely support the loading shown, where $P = 12$ kip. The allowable bending stress is $\sigma_{allow} = 22$ ksi and the allowable shear stress is $\tau_{allow} = 12$ ksi.





**Probs. 11–9/10**

**11–11.** The timber beam is to be loaded as shown. If the ends support only vertical forces, determine the greatest magnitude of **P** that can be applied. $\sigma_{allow} = 25$ MPa, $\tau_{allow} = 700$ kPa.





**Prob. 11–11**

***11–12.** Determine the minimum width of the beam to the nearest $\frac{1}{4}$ in. that will safely support the loading of $P = 8$ kip. The allowable bending stress is $\sigma_{allow} = 24$ ksi and the allowable shear stress is $\tau_{allow} = 15$ ksi.





**Prob. 11–12**

**•11–13.** Select the shortest and lightest-weight steel wide-flange beam from Appendix B that will safely support the loading shown. The allowable bending stress is $\sigma_{allow} = 22$ ksi and the allowable shear stress is $\tau_{allow} = 12$ ksi.





**Prob. 11–13**

**11–14.** The beam is used in a railroad yard for loading and unloading cars. If the maximum anticipated hoist load is 12 kip, select the lightest-weight steel wide-flange section from Appendix B that will safely support the loading. The hoist travels along the bottom flange of the beam, $1 \text{ ft} \le x \le 25 \text{ ft}$, and has negligible size. Assume the beam is pinned to the column at $B$ and roller supported at $A$. The allowable bending stress is $\sigma_{allow} = 24$ ksi and the allowable shear stress is $\tau_{allow} = 12$ ksi.




Prob. 11–14


**11–15.** The simply supported beam is made of timber that has an allowable bending stress of $\sigma_{allow} = 960$ psi and an allowable shear stress of $\tau_{allow} = 75$ psi. Determine its dimensions if it is to be rectangular and have a height-to-width ratio of 1.25.




Prob. 11–15

***11–16.** The simply supported beam is composed of two W12 × 22 sections built up as shown. Determine the maximum uniform loading $w$ the beam will support if the allowable bending stress is $\sigma_{allow} = 22$ ksi and the allowable shear stress is $\tau_{allow} = 14$ ksi.


**•11–17.** The simply supported beam is composed of two W12 × 22 sections built up as shown. Determine if the beam will safely support a loading of $w = 2$ kip/ft. The allowable bending stress is $\sigma_{allow} = 22$ ksi and the allowable shear stress is $\tau_{allow} = 14$ ksi.




Probs. 11–16/17

**11–18.** Determine the smallest diameter rod that will safely support the loading shown. The allowable bending stress is $\sigma_{allow} = 167$ MPa and the allowable shear stress is $\tau_{allow} = 97$ MPa.


**11–19.** The pipe has an outer diameter of 15 mm. Determine the smallest inner diameter so that it will safely support the loading shown. The allowable bending stress is $\sigma_{allow} = 167$ MPa and the allowable shear stress is $\tau_{allow} = 97$ MPa.




Probs. 11–18/19


***11–20.** Determine the maximum uniform loading $w$ the W12 × 14 beam will support if the allowable bending stress is $\sigma_{allow} = 22$ ksi and the allowable shear stress is $\tau_{allow} = 12$ ksi.

**•11–21.** Determine if the W14 × 22 beam will safely support a loading of $w = 1.5$ kip/ft. The allowable bending stress is $\sigma_{allow} = 22$ ksi and the allowable shear stress is $\tau_{allow} = 12$ ksi.





**Probs. 11–20/21**

**11–22.** Determine the minimum depth $h$ of the beam to the nearest $\frac{1}{8}$ in. that will safely support the loading shown. The allowable bending stress is $\sigma_{allow} = 21$ ksi and the allowable shear stress is $\tau_{allow} = 10$ ksi. The beam has a uniform thickness of 3 in.




**Prob. 11–22**


**11–23.** The box beam has an allowable bending stress of $\sigma_{allow} = 10$ MPa and an allowable shear stress of $\tau_{allow} = 775$ kPa. Determine the maximum intensity $w$ of the distributed loading that it can safely support. Also, determine the maximum safe nail spacing for each third of the length of the beam. Each nail can resist a shear force of 200 N.




**Prob. 11–23**


***11–24.** The simply supported joist is used in the construction of a floor for a building. In order to keep the floor low with respect to the sill beams $C$ and $D$, the ends of the joists are notched as shown. If the allowable shear stress for the wood is $\tau_{allow} = 350$ psi and the allowable bending stress is $\sigma_{allow} = 1500$ psi, determine the height $h$ that will cause the beam to reach both allowable stresses at the same time. Also, what load $P$ causes this to happen? Neglect the stress concentration at the notch.

**11–25.** The simply supported joist is used in the construction of a floor for a building. In order to keep the floor low with respect to the sill beams $C$ and $D$, the ends of the joists are notched as shown. If the allowable shear stress for the wood is $\tau_{allow} = 350$ psi and the allowable bending stress is $\sigma_{allow} = 1700$ psi, determine the smallest height $h$ so that the beam will support a load of $P = 600$ lb. Also, will the entire joist safely support the load? Neglect the stress concentration at the notch.





**Probs. 11–24/25**

**11–26.** Select the lightest-weight steel wide-flange beam from Appendix B that will safely support the loading shown. The allowable bending stress is $\sigma_{allow} = 22$ ksi and the allowable shear stress is $\tau_{allow} = 12$ ksi.





Prob. 11–26

**11–27.** The T-beam is made from two plates welded together as shown. Determine the maximum uniform distributed load $w$ that can be safely supported on the beam if the allowable bending stress is $\sigma_{allow} = 150$ MPa and the allowable shear stress is $\tau_{allow} = 70$ MPa.





Prob. 11–27

***11–28.** The beam is made of a ceramic material having an allowable bending stress of $\sigma_{allow} = 735$ psi and an allowable shear stress of $\tau_{allow} = 400$ psi. Determine the width $b$ of the beam if the height $h = 2b$.





Prob. 11–28

**•11–29.** The wood beam has a rectangular cross section. Determine its height $h$ so that it simultaneously reaches its allowable bending stress of $\sigma_{allow} = 1.50$ ksi and an allowable shear stress of $\tau_{allow} = 150$ psi. Also, what is the maximum load $P$ that the beam can then support?




Prob. 11–29

**11–30.** The beam is constructed from three boards as shown. If each nail can support a shear force of 300 lb, determine the maximum allowable spacing of the nails, $s$, $s'$, $s''$, for regions $AB$, $BC$, and $CD$ respectively. Also, if the allowable bending stress is $\sigma_{allow} = 1.5$ ksi and the allowable shear stress is $\tau_{allow} = 150$ psi, determine if it can safely support the load.




Prob. 11–30



(a)



Haunched concrete beam

(b)



Wide-flange beam with cover plates

(c)

**Fig. 11–10**

## *11.3 Fully Stressed Beams

Since the moment in a beam generally *varies* along its length, the choice of a prismatic beam is usually inefficient since it is never fully stressed at points where the internal moment is less than the maximum moment in the beam. In order to reduce the weight of the beam, engineers sometimes choose a beam having a *variable* cross-sectional area, such that at each cross section along the beam, the bending stress reaches its maximum allowable value. Beams having a variable cross-sectional area are called *nonprismatic beams*. They are often used in machines since they can be readily formed by casting. Examples are shown in Fig. 11–10*a*. In structures such beams may be "haunched" at their ends as shown in Fig. 11–10*b*. Also, beams may be "built up" or fabricated in a shop using plates. An example is a girder made from a rolled-shaped wide-flange beam and having cover plates welded to it in the region where the moment is a maximum, Fig. 11–10*c*.

The stress analysis of a nonprismatic beam is generally very difficult to perform and is beyond the scope of this text. Most often these shapes are analyzed by using a computer or the theory of elasticity. The results obtained from such an analysis, however, do indicate that the assumptions used in the derivation of the flexure formula are approximately correct for predicting the bending stresses in nonprismatic sections, provided the taper or slope of the upper or lower boundary of the beam is not too severe. On the other hand, the shear formula cannot be used for nonprismatic beam design, since the results obtained from it are very misleading.

Although caution is advised when applying the flexure formula to nonprismatic beam design, we will show here, in principle, how this formula can be used as an approximate means for obtaining the beam's general shape. In this regard, the *size* of the cross section of a nonprismatic beam that supports a given loading can be determined using the flexure formula written as

$$S = \frac{M}{\sigma_{\text{allow}}}$$

If we express the internal moment $M$ in terms of its position $x$ along the beam, then since $\sigma_{\text{allow}}$ is a known constant, the section modulus $S$ or the beam's dimensions become a function of $x$. A beam designed in this manner is called a ***fully stressed beam***. Although *only* bending stresses have been considered in approximating its final shape, attention must also be given to ensure that the beam will resist shear, especially at points where concentrated loads are applied.



The beam for this bridge pier has a variable moment of inertia. This design will reduce material weight and save cost.

## EXAMPLE 11.4

Determine the shape of a fully stressed, simply supported beam that supports a concentrated force at its center, Fig. 11–11*a*. The beam has a rectangular cross section of constant width $b$, and the allowable stress is $\sigma_{allow}$.





Fig. 11–11

### SOLUTION

The internal moment in the beam, Fig. 11–11*b*, expressed as a function of position, $0 \le x < L/2$, is

$$M = \frac{P}{2}x$$

Hence the required section modulus is

$$S = \frac{M}{\sigma_{allow}} = \frac{P}{2\sigma_{allow}}x$$

Since $S = I/c$, then for a cross-sectional area $h$ by $b$ we have

$$\frac{I}{c} = \frac{\frac{1}{12}bh^3}{h/2} = \frac{P}{2\sigma_{allow}}x$$

$$h^2 = \frac{3P}{\sigma_{allow}b}x$$

If $h = h_0$ at $x = L/2$, then

$$h_0^2 = \frac{3PL}{2\sigma_{allow}b}$$

so that

$$h^2 = \left(\frac{2h_0^2}{L}\right)x \qquad \textit{Ans}$$

By inspection, the depth $h$ must therefore vary in a *parabolic* manner with the distance $x$.

**NOTE:** In practice this *shape* is the basis for the design of leaf springs used to support the rear-end axles of most heavy trucks or train cars as shown in the adjacent photo. Note that although this result indicates that $h = 0$ at $x = 0$, it is necessary that the beam resist shear stress at the supports, and so practically speaking, it must be required that $h > 0$ at the supports, Fig. 11–11*a*.



## EXAMPLE 11.5

The cantilevered beam shown in Fig. 11–12*a* is formed into a trapezoidal shape having a depth $h_0$ at $A$ and a depth $3h_0$ at $B$. If it supports a load **P** at its end, determine the absolute maximum normal stress in the beam. The beam has a rectangular cross section of constant width $b$.





Fig. 11–12

### SOLUTION

At any cross section, the maximum normal stress occurs at the top and bottom surface of the beam. However, since $\sigma_{max} = M/S$ and the section modulus $S$ increases as $x$ increases, the absolute maximum normal stress does *not* necessarily occur at the wall $B$, where the moment is maximum. Using the flexure formula, we can express the maximum normal stress at an arbitrary section in terms of its position $x$, Fig. 11–12*b*. Here the internal moment has a magnitude of $M = Px$. Since the slope of the bottom of the beam is $2h_0/L$, Fig. 11–12*a*, the depth of the beam at position $x$ is

$$h = \frac{2h_0}{L}x + h_0 = \frac{h_0}{L}(2x + L)$$

Applying the flexure formula, we have

$$\sigma = \frac{Mc}{I} = \frac{Px(h/2)}{\left(\frac{1}{12}bh^3\right)} = \frac{6PL^2x}{bh_0^2(2x + L)^2} \qquad (1)$$

To determine the position $x$ where the absolute maximum normal stress occurs, we must take the derivative of $\sigma$ with respect to $x$ and set it equal to zero. This gives

$$\frac{d\sigma}{dx} = \left(\frac{6PL^2}{bh_0^2}\right)\frac{1(2x + L)^2 - x(2)(2x + L)(2)}{(2x + L)^4} = 0$$

Thus,

$$4x^2 + 4xL + L^2 - 8x^2 - 4xL = 0$$

$$L^2 - 4x^2 = 0$$

$$x = \frac{1}{2}L$$

Substituting into Eq. 1 and simplifying, the absolute maximum normal stress is therefore

$$\sigma_{\substack{\text{abs}\\\text{max}}} = \frac{3}{4}\frac{PL}{bh_0^2} \qquad \textit{Ans}$$

Note that at the wall, $B$, the maximum normal stress is

$$(\sigma_{\max})_B = \frac{Mc}{I} = \frac{PL(1.5h_0)}{\left[\frac{1}{12}b(3h_0)^3\right]} = \frac{2}{3}\frac{PL}{bh_0^2}$$


which is 11.1% smaller than $\sigma_{\substack{\text{abs}\\\text{max}}}$.

**NOTE:** Recall that the flexure formula was derived on the basis of assuming the beam to be *prismatic*. Since this is not the case here, some error is to be expected in this analysis and that of Example 11.4. A more exact mathematical analysis, using the theory of elasticity, reveals that application of the flexure formula as in the above example gives only small errors in the normal stress if the tapered angle of the beam is small. For example, if this angle is 15°, the stress calculated from the formula will be about 5% greater than that calculated by the more exact analysis. It may also be worth noting that the calculation of $(\sigma_{\max})_B$ was done only for illustrative purposes, since, by Saint-Venant's principle, the actual stress distribution at the support (wall) is highly irregular.


## *11.4 Shaft Design

Shafts that have circular cross sections are often used in the design of mechanical equipment and machinery. As a result, they can be subjected to cyclic or fatigue stress, which is caused by the combined bending and torsional loads they must transmit or resist. In addition to these loadings, stress concentrations may exist on a shaft due to keys, couplings, and sudden transitions in its cross-sectional area (Sec. 5.8). In order to design a shaft properly, it is therefore necessary to take all of these effects into account.


Here we will discuss some of the important aspects of the design of shafts required to transmit power. These shafts are often subjected to loads applied to attached pulleys and gears, such as the one shown in Fig. 11–13*a*. Since the loads can be applied to the shaft at various angles, the internal bending and torsional moments at any cross section can be determined by first replacing the loads by their statically equivalent counterparts and then resolving these loads into components in two perpendicular planes, Fig. 11–13*b*. The bending-moment diagrams for the loads *in each plane* can then be drawn, and the resultant internal moment at any section along the shaft is then determined by vector addition, $M = \sqrt{M_x^2 + M_z^2}$, Fig. 11–13*c*. In addition to the moment, segments of the shaft are also subjected to different internal torques, Fig. 11–13*b*. To account for this general variation of torque along the shaft, a ***torque diagram*** may also be drawn, Fig. 11–13*d*.





(a)




(b)





Moment diagram caused by loads in y-z plane




Moment diagram caused by loads in x-y plane

(c)




Torque diagram caused by torques applied about the shaft's axis

(d)

Fig. 11–13

Once the moment and torque diagrams have been established, it is then possible to investigate certain critical sections along the shaft where the *combination* of a resultant moment **M** and a torque **T** creates the worst stress situation. Since the moment of inertia of the shaft is the *same* about *any* diametrical axis, we can apply the flexure formula using the *resultant moment* to obtain the maximum bending stress. As shown in Fig. 11–13*e*, this stress will occur on two elements, $C$ and $D$, each located on the outer boundary of the shaft. If a torque **T** is also resisted at this section, then a maximum shear stress is also developed on these elements, Fig. 11–13*f*. Furthermore, the external forces will also create shear stress in the shaft determined from $\tau = VQ/It$; however, this stress will generally contribute a much smaller stress distribution on the cross section compared with that developed by bending and torsion. In some cases, it must be investigated, but for simplicity, we will neglect its effect in the following analysis. In general, then, the critical element $D$ (or $C$) on the shaft is subjected to *plane stress* as shown in Fig. 11–13*g*, where

$$\sigma = \frac{Mc}{I} \quad \text{and} \quad \tau = \frac{Tc}{J}$$

If the allowable normal or shear stress for the material is known, the size of the shaft is then based on the use of these equations and selection of an appropriate theory of failure. For example, if the material is known to be ductile, then the maximum-shear-stress theory may be appropriate. As stated in Sec. 10.7, this theory requires the allowable shear stress, which is determined from the results of a simple tension test, to be equal to the maximum shear stress in the element. Using the stress-transformation equation, Eq. 9–7, for the stress state in Fig. 11–13*g*, we have

$$\tau_{\text{allow}} = \sqrt{\left(\frac{\sigma}{2}\right)^2 + \tau^2}$$

$$= \sqrt{\left(\frac{Mc}{2I}\right)^2 + \left(\frac{Tc}{J}\right)^2}$$

Since $I = \pi c^4/4$ and $J = \pi c^4/2$, this equation becomes


$$\tau_{\text{allow}} = \frac{2}{\pi c^3}\sqrt{M^2 + T^2}$$

Solving for the radius of the shaft, we get

$$c = \left(\frac{2}{\pi \tau_{\text{allow}}}\sqrt{M^2 + T^2}\right)^{1/3} \tag{11–2}$$

Application of any other theory of failure will, of course, lead to a different formulation for $c$. However, in all cases it may be necessary to apply this formulation at various "critical sections" along the shaft in order to determine the particular combination of $M$ and $T$ that gives the largest value for $c$.


The following example illustrates the procedure numerically.




(e)




(f)




(g)

**Fig. 11–13 (cont.)**

## EXAMPLE 11.6

The shaft in Fig. 11–14*a* is supported by smooth journal bearings at *A* and *B*. Due to the transmission of power to and from the shaft, the belts on the pulleys are subjected to the tensions shown. Determine the smallest diameter of the shaft using the maximum-shear-stress theory, with $\tau_{allow} = 50$ MPa.





Fig. 11–14

### SOLUTION

The support reactions have been calculated and are shown on the free-body diagram of the shaft, Fig. 11–14*b*. Bending-moment diagrams for $M_x$ and $M_z$ are shown in Figs. 11–14*c* and 11–14*d*, respectively. The torque diagram is shown in Fig. 11–14*e*. By inspection, critical points for bending moment occur either at *C* or *B*. Also, just to the right of *C and* at *B* the torsional moment is 7.5 N · m. At *C*, the resultant moment is

$$M_C = \sqrt{(118.75\ \text{N}\cdot\text{m})^2 + (37.5\ \text{N}\cdot\text{m})^2} = 124.5\ \text{N}\cdot\text{m}$$

whereas at *B* it is smaller, namely

$$M_B = 75\ \text{N}\cdot\text{m}$$





**Fig. 11–14 (cont.)**

Since the design is based on the maximum-shear-stress theory, Eq. 11–2 applies. The radical $\sqrt{M^2 + T^2}$ will be the largest at a section just to the right of $C$. We have

$$c = \left(\frac{2}{\pi \tau_{\text{allow}}}\sqrt{M^2 + T^2}\right)^{1/3}$$

$$= \left(\frac{2}{\pi(50)(10^6)\ \text{N/m}^2}\sqrt{(124.5\ \text{N}\cdot\text{m})^2 + (7.5\ \text{N}\cdot\text{m})^2}\right)^{1/3}$$

$$= 0.0117\ \text{m}$$


Thus, the smallest allowable diameter is

$$d = 2(0.0117\ \text{m}) = 23.3\ \text{mm} \qquad \textit{Ans.}$$

11


## PROBLEMS

**11–31.** The tapered beam supports a concentrated force **P** at its center. If it is made from a plate that has a constant width $b$, determine the absolute maximum bending stress in the beam.





Prob. 11–31

***11–32.** The beam is made from a plate that has a constant thickness $b$. If it is simply supported and carries a uniform load $w$, determine the variation of its depth as a function of $x$ so that it maintains a constant maximum bending stress $\sigma_{allow}$ throughout its length.





Prob. 11–32

**•11–33.** The beam is made from a plate having a constant thickness $t$ and a width that varies as shown. If it supports a concentrated force **P** at its center, determine the absolute maximum bending stress in the beam and specify its location $x$, $0 < x < L/2$.





Prob. 11–33

**11–34.** The beam is made from a plate that has a constant thickness $b$. If it is simply supported and carries the distributed loading shown, determine the variation of its depth as a function of $x$ so that it maintains a constant maximum bending stress $\sigma_{allow}$ throughout its length.





Prob. 11–34

**11–35.** The beam is made from a plate that has a constant thickness $b$. If it is simply supported and carries the distributed loading shown, determine the maximum bending stress in the beam.





Prob. 11–35

***11–36.** Determine the variation of the radius $r$ of the cantilevered beam that supports the uniform distributed load so that it has a constant maximum bending stress $\sigma_{max}$ throughout its length.





Prob. 11–36

•11–37. Determine the variation in the depth $d$ of a cantilevered beam that supports a concentrated force **P** at its end so that it has a constant maximum bending stress $\sigma_{allow}$ throughout its length. The beam has a constant width $b_0$.




Prob. 11–37


11–38. Determine the variation in the width $b$ as a function of $x$ for the cantilevered beam that supports a uniform distributed load along its centerline so that it has the same maximum bending stress $\sigma_{allow}$ throughout its length. The beam has a constant depth $t$.




Prob. 11–38

11–39. The shaft is supported on journal bearings that do not offer resistance to axial load. If the allowable normal stress for the shaft is $\sigma_{allow} = 80$ MPa, determine to the nearest millimeter the smallest diameter of the shaft that will support the loading. Use the maximum-distortion-energy theory of failure.


*11–40. The shaft is supported on journal bearings that do not offer resistance to axial load. If the allowable shear stress for the shaft is $\tau_{allow} = 35$ MPa, determine to the nearest millimeter the smallest diameter of the shaft that will support the loading. Use the maximum-shear-stress theory of failure.




Probs. 11–39/40


•11–41. The end gear connected to the shaft is subjected to the loading shown. If the bearings at $A$ and $B$ exert only $y$ and $z$ components of force on the shaft, determine the equilibrium torque $T$ at gear $C$ and then determine the smallest diameter of the shaft to the nearest millimeter that will support the loading. Use the maximum-shear-stress theory of failure with $\tau_{allow} = 60$ MPa.

11–42. The end gear connected to the shaft is subjected to the loading shown. If the bearings at $A$ and $B$ exert only $y$ and $z$ components of force on the shaft, determine the equilibrium torque $T$ at gear $C$ and then determine the smallest diameter of the shaft to the nearest millimeter that will support the loading. Use the maximum-distortion-energy theory of failure with $\sigma_{allow} = 80$ MPa.





Probs. 11–41/42

**11–43.** The shaft is supported by bearings at $A$ and $B$ that exert force components only in the $x$ and $z$ directions on the shaft. If the allowable normal stress for the shaft is $\sigma_{allow} = 15$ ksi, determine to the nearest $\frac{1}{8}$ in. the smallest diameter of the shaft that will support the loading. Use the maximum-distortion-energy theory of failure.





Prob. 11–43

***11–44.** The shaft is supported by bearings at $A$ and $B$ that exert force components only in the $x$ and $z$ directions on the shaft. If the allowable normal stress for the shaft is $\sigma_{allow} = 15$ ksi, determine to the nearest $\frac{1}{8}$ in. the smallest diameter of the shaft that will support the loading. Use the maximum-shear-stress theory of failure. Take $\tau_{allow} = 6$ ksi.





Prob. 11–44

**•11–45.** The bearings at $A$ and $D$ exert only $y$ and $z$ components of force on the shaft. If $\tau_{allow} = 60$ MPa, determine to the nearest millimeter the smallest-diameter shaft that will support the loading. Use the maximum-shear-stress theory of failure.




Prob. 11–45

**11–46.** The bearings at $A$ and $D$ exert only $y$ and $z$ components of force on the shaft. If $\tau_{allow} = 60$ MPa, determine to the nearest millimeter the smallest-diameter shaft that will support the loading. Use the maximum-distortion-energy theory of failure. $\sigma_{allow} = 130$ MPa.




Prob. 11–46

## CHAPTER REVIEW

Failure of a beam occurs when the internal shear or moment in the beam is a maximum. To resist these loadings, it is therefore important that the associated maximum shear and bending stress not exceed allowable values as stated in codes. Normally, the cross section of a beam is first designed to resist the allowable bending stress,

$$\sigma_{allow} = \frac{M_{max}c}{I}$$

Then the allowable shear stress is checked. For rectangular sections, $\tau_{allow} \geq 1.5(V_{max}/A)$ and for wide-flange sections it is appropriate to use $\tau_{allow} \geq V_{max}/A_{web}$. In general, use

$$\tau_{allow} = \frac{VQ}{It}$$


For built-up beams, the spacing of fasteners or the strength of glue or weld is determined using an allowable shear flow

$$q_{allow} = \frac{VQ}{I}$$

Fully stressed beams are nonprismatic and designed such that each cross section along the beam will resist the allowable bending stress. This will define the shape of the beam.




A mechanical shaft generally is designed to resist both torsion and bending stresses. Normally, the internal bending moment can be resolved into two planes, and so it is necessary to draw the moment diagrams for each bending-moment component and then select the maximum moment based on vector addition. Once the maximum bending and shear stresses are determined, then depending upon the type of material, an appropriate theory of failure is used to compare the allowable stress to what is required.




## REVIEW PROBLEMS

**11–47.** Draw the shear and moment diagrams for the shaft, and then determine its required diameter to the nearest millimeter if $\sigma_{allow} = 140$ MPa and $\tau_{allow} = 80$ MPa. The bearings at $A$ and $B$ exert only vertical reactions on the shaft.





Prob. 11–47

***11–48.** The overhang beam is constructed using two 2-in. by 4-in. pieces of wood braced as shown. If the allowable bending stress is $\sigma_{allow} = 600$ psi, determine the largest load $P$ that can be applied. Also, determine the associated maximum spacing of nails, $s$, along the beam section $AC$ if each nail can resist a shear force of 800 lb. Assume the beam is pin-connected at $A$, $B$, and $D$. Neglect the axial force developed in the beam along $DA$.





Prob. 11–48

**•11–49.** The bearings at $A$ and $B$ exert only $x$ and $z$ components of force on the steel shaft. Determine the shaft's diameter to the nearest millimeter so that it can resist the loadings of the gears without exceeding an allowable shear stress of $\tau_{allow} = 80$ MPa. Use the maximum-shear-stress theory of failure.





Prob. 11–49

**11–50.** The bearings at $A$ and $B$ exert only $x$ and $z$ components of force on the steel shaft. Determine the shaft's diameter to the nearest millimeter so that it can resist the loadings of the gears without exceeding an allowable shear stress of $\tau_{allow} = 80$ MPa. Use the maximum-distortion-energy theory of failure with $\sigma_{allow} = 200$ MPa.





Prob. 11–50

**11–51.** Draw the shear and moment diagrams for the beam. Then select the lightest-weight steel wide-flange beam from Appendix B that will safely support the loading. Take $\sigma_{allow} = 22$ ksi, and $\tau_{allow} = 12$ ksi.





Prob. 11–51

*11–52. The beam is made of cypress having an allowable bending stress of $\sigma_{allow} = 850$ psi and an allowable shear stress of $\tau_{allow} = 80$ psi. Determine the width $b$ of the beam if the height $h = 1.5b$.




Prob. 11–52


•11–53. The tapered beam supports a uniform distributed load $w$. If it is made from a plate and has a constant width $b$, determine the absolute maximum bending stress in the beam.




Prob. 11–53

**11–54.** The tubular shaft has an inner diameter of 15 mm. Determine to the nearest millimeter its outer diameter if it is subjected to the gear loading. The bearings at $A$ and $B$ exert force components only in the $y$ and $z$ directions on the shaft. Use an allowable shear stress of $\tau_{allow} = 70$ MPa, and base the design on the maximum-shear-stress theory of failure.

**11–55.** Determine to the nearest millimeter the diameter of the solid shaft if it is subjected to the gear loading. The bearings at $A$ and $B$ exert force components only in the $y$ and $z$ directions on the shaft. Base the design on the maximum-distortion-energy theory of failure with $\sigma_{allow} = 150$ MPa.




Probs. 11–54/55



If the curvature of this pole is measured, it is then possible to determine the bending stress developed within it.

# Deflection of Beams and Shafts

# 12

## CHAPTER OBJECTIVES

Often limits must be placed on the amount of deflection a beam or shaft may undergo when it is subjected to a load, and so in this chapter we will discuss various methods for determining the deflection and slope at specific points on beams and shafts. The analytical methods include the integration method, the use of discontinuity functions, and the method of superposition. Also, a semigraphical technique, called the moment-area method, will be presented. At the end of the chapter, we will use these methods to solve for the support reactions on a beam or shaft that is statically indeterminate.

## 12.1 The Elastic Curve

The deflection of a beam or shaft must often be limited in order to provide integrity and stability of a structure or machine, and prevent the cracking of any attached brittle materials such as concrete or glass. Furthermore, code restrictions often require these members not vibrate or deflect severely in order to safely support their intended loading. Most important, though, deflections at specific points on a beam or shaft must be determined if one is to analyze those that are statically indeterminate.

Before the slope or the displacement at a point on a beam (or shaft) is determined, it is often helpful to sketch the deflected shape of the beam when it is loaded, in order to "visualize" any computed results and thereby partially check these results. The deflection curve of the longitudinal axis that passes through the centroid of each cross-sectional area of a beam is called the *elastic curve*. For most beams the elastic curve can be sketched without much difficulty. When doing so, however, it is necessary to know how the slope or displacement is restricted at various types of supports. In general, supports that resist a *force*, such as a pin, restrict *displacement*, and those that resist a *moment*, such as a fixed wall, restrict *rotation* or *slope* as well as displacement. With this in mind, two typical examples of the elastic curves for loaded beams (or shafts), sketched to an exaggerated scale, are shown in Fig. 12–1.





Fig. 12–1

12





Fig. 12–2

If the elastic curve for a beam seems difficult to establish, it is suggested that the moment diagram for the beam be drawn first. Using the beam sign convention established in Sec. 6.1, a positive internal moment tends to bend the beam concave upward, Fig. 12–2*a*. Likewise, a negative moment tends to bend the beam concave downward, Fig. 12–2*b*. Therefore, if the moment diagram is *known*, it will be easy to construct the elastic curve. For example, consider the beam in Fig. 12–3*a* with its associated moment diagram shown in Fig. 12–3*b*. Due to the roller and pin supports, the displacement at $B$ and $D$ must be zero. Within the region of negative moment, $AC$, Fig. 12–3*b*, the elastic curve must be concave downward, and within the region of positive moment, $CD$, the elastic curve must be concave upward. Hence, there must be an *inflection point* at point $C$, where the curve changes from concave up to concave down, since this is a point of zero moment. Using these facts, the beam's elastic curve is sketched in Fig. 12–3*c*. It should also be noted that the displacements $\Delta_A$ and $\Delta_E$ are especially critical. At point $E$ the *slope* of the elastic curve is *zero*, and there the beam's *deflection* may be a *maximum*. Whether $\Delta_E$ is actually greater than $\Delta_A$ depends on the relative magnitudes of $\mathbf{P}_1$ and $\mathbf{P}_2$ and the location of the roller at $B$.

Following these same principles, note how the elastic curve in Fig. 12–4 was constructed. Here the beam is cantilevered from a fixed support at $A$ and therefore the elastic curve must have both zero displacement and zero slope at this point. Also, the largest displacement will occur either at $D$, where the slope is zero, or at $C$.





Fig. 12–3





Fig. 12–4

**Moment-Curvature Relationship.** We will now develop an important relationship between the internal moment and the radius of curvature $\rho$ (rho) of the elastic curve at a point. The resulting equation will be used for establishing each of the methods presented in the chapter for finding the slope and displacement at points on the elastic curve.

The following analysis, here and in the next section, will require the use of three coordinates. As shown in Fig. 12–5*a*, the $x$ axis extends positive to the right, along the initially straight longitudinal axis of the beam. It is used to locate the differential element, having an undeformed width $dx$. The $v$ axis extends *positive upward* from the $x$ axis. It measures the *displacement* of the elastic curve. Lastly, a "localized" $y$ coordinate is used to specify the position of a fiber in the beam element. It is measured *positive upward* from the neutral axis (or elastic curve) as shown in Fig. 12–5*b*. Recall that this same sign convention for $x$ and $y$ was used in the derivation of the flexure formula.

To derive the relationship between the internal moment and $\rho$, we will limit the analysis to the most common case of an initially straight beam that is elastically deformed by loads applied perpendicular to the beam's $x$ axis and lying in the $x$–$v$ plane of symmetry for the beam's cross-sectional area. Due to the loading, the deformation of the beam is caused by both the internal shear force and bending moment. If the beam has a length that is much greater than its depth, the greatest deformation will be caused by bending, and therefore we will direct our attention to its effects. Deflections caused by shear will be discussed in Chapter 14.






Fig. 12–5

12




(b)

Fig. 12–5 (cont.)

When the internal moment $M$ deforms the element of the beam, the angle between the cross sections becomes $d\theta$, Fig. 12–5*b*. The arc $dx$ represents a portion of the elastic curve that intersects the neutral axis for each cross section. The *radius of curvature* for this arc is defined as the distance $\rho$, which is measured from the *center of curvature* $O'$ to $dx$. Any arc on the element other than $dx$ is subjected to a normal strain. For example, the strain in arc $ds$, located at a position $y$ from the neutral axis, is $\epsilon = (ds' - ds)/ds$. However, $ds = dx = \rho\, d\theta$ and $ds' = (\rho - y)\, d\theta$, and so $\epsilon = [(\rho - y)\, d\theta - \rho\, d\theta]/\rho\, d\theta$ or

$$\frac{1}{\rho} = -\frac{\epsilon}{y} \tag{12–1}$$

If the material is homogeneous and behaves in a linear-elastic manner, then Hooke's law applies, $\epsilon = \sigma/E$. Also, since the flexure formula applies, $\sigma = -My/I$. Combining these two equations and substituting into the above equation, we have

$$\boxed{\frac{1}{\rho} = \frac{M}{EI}} \tag{12–2}$$

where

$\rho$ = the radius of curvature at the point on the elastic curve ($1/\rho$ is referred to as the *curvature*)
$M$ = the internal moment in the beam at the point
$E$ = the material's modulus of elasticity
$I$ = the beam's moment of inertia about the neutral axis





Fig. 12–6

The product $EI$ in this equation is referred to as the *flexural rigidity*, and it is always a positive quantity. The sign for $\rho$ therefore depends on the direction of the moment. As shown in Fig. 12–6, when $M$ is *positive*, $\rho$ extends *above* the beam, i.e., in the positive $v$ direction; when $M$ is *negative*, $\rho$ extends *below* the beam, or in the negative $v$ direction.

Using the flexure formula, $\sigma = -My/I$, we can also express the curvature in terms of the stress in the beam, namely,

$$\frac{1}{\rho} = -\frac{\sigma}{Ey} \tag{12–3}$$

Both Eqs. 12–2 and 12–3 are valid for either small or large radii of curvature. However, the value of $\rho$ is almost always calculated as a *very large quantity*. For example, consider an A-36 steel beam made from a W14 × 53 (Appendix B), where $E_{st} = 29(10^3)$ ksi and $\sigma_Y = 36$ ksi. When the material at the outer fibers, $y = \pm 7$ in., is about to *yield*, then, from Eq. 12–3, $\rho = \pm 5639$ in. Values of $\rho$ calculated at other points along the beam's elastic curve may be even *larger*, since $\sigma$ cannot exceed $\sigma_Y$ at the outer fibers.

## 12.2 Slope and Displacement by Integration

The equation of the elastic curve for a beam can be expressed mathematically as $v = f(x)$. To obtain this equation, we must first represent the curvature $(1/\rho)$ in terms of $v$ and $x$. In most calculus books it is shown that this relationship is

$$\frac{1}{\rho} = \frac{d^2v/dx^2}{[1 + (dv/dx)^2]^{3/2}}$$

Substituting into Eq. 12–2, we have

$$\frac{d^2v/dx^2}{[1 + (dv/dx)^2]^{3/2}} = \frac{M}{EI} \tag{12–4}$$

This equation represents a nonlinear second-order differential equation. Its solution, which is called the *elastica*, gives the exact shape of the elastic curve, assuming, of course, that beam deflections occur only due to bending. Through the use of higher mathematics, elastica solutions have been obtained only for simple cases of beam geometry and loading.

In order to facilitate the solution of a greater number of deflection problems, Eq. 12–4 can be modified. Most engineering design codes specify *limitations* on deflections for tolerance or esthetic purposes, and as a result the elastic deflections for the majority of beams and shafts form a shallow curve. Consequently, the *slope* of the elastic curve, which is determined from $dv/dx$, will be *very small*, and its square will be negligible compared with unity.* Therefore the curvature, as defined above, can be *approximated* by $1/\rho = d^2v/dx^2$. Using this simplification, Eq. 12–4 can now be written as

$$\frac{d^2v}{dx^2} = \frac{M}{EI} \tag{12–5}$$

It is also possible to write this equation in two alternative forms. If we differentiate each side with respect to $x$ and substitute $V = dM/dx$ (Eq. 6–2), we get

$$\frac{d}{dx}\left(EI\frac{d^2v}{dx^2}\right) = V(x) \tag{12–6}$$

Differentiating again, using $w = dV/dx$ (Eq. 6–1), yields

$$\frac{d^2}{dx^2}\left(EI\frac{d^2v}{dx^2}\right) = w(x) \tag{12–7}$$

*See Example 12.1.

12

For most problems the flexural rigidity ($EI$) will be constant along the length of the beam. Assuming this to be the case, the above results may be reordered into the following set of three equations:


$$EI\frac{d^4v}{dx^4} = w(x) \tag{12–8}$$

$$EI\frac{d^3v}{dx^3} = V(x) \tag{12–9}$$


$$EI\frac{d^2v}{dx^2} = M(x) \tag{12–10}$$

Solution of any of these equations requires successive integrations to obtain the deflection $v$ of the elastic curve. For each integration it is necessary to introduce a "constant of integration" and then solve for all the constants to obtain a unique solution for a particular problem. For example, if the distributed load $w$ is expressed as a function of $x$ and Eq. 12–8 is used, then four constants of integration must be evaluated; however, if the internal moment $M$ is determined and Eq. 12–10 is used, only two constants of integration must be found. The choice of which equation to start with depends on the problem. Generally, however, it is easier to determine the internal moment $M$ as a function of $x$, integrate twice, and evaluate only two integration constants.


Recall from Sec. 6.1 that if the loading on a beam is discontinuous, that is, consists of a series of several distributed and concentrated loads, then several functions must be written for the internal moment, each valid within the region between the discontinuities. Also, for convenience in writing each moment expression, *the origin* for each $x$ coordinate can be *selected arbitrarily*. For example, consider the beam shown in Fig. 12–7*a*. The internal moment in regions $AB$, $BC$, and $CD$ can be written in terms of the $x_1$, $x_2$, and $x_3$ coordinates selected, as shown in either Fig. 12–7*b* or Fig. 12–7*c*, or in fact in any manner that will yield $M = f(x)$ in as simple a form as possible. Once these functions are integrated twice through the use of Eq. 12–10 and the constants of integration determined, the functions will give the slope and deflection (elastic curve) for each region of the beam for which they are valid.



(a)



(b)



(c)


Fig. 12–7

**Sign Convention and Coordinates.** When applying Eqs. 12–8 through 12–10, it is important to use the proper signs for $M$, $V$, or $w$ as established by the sign convention that was used in the derivation of these equations. For review, these terms are shown in their *positive directions* in Fig. 12–8*a*. Furthermore, recall that *positive deflection*, $v$, is *upward*, and as a result, the *positive slope angle* $\theta$ will be measured *counterclockwise* from the $x$ axis when $x$ is *positive to the right*. The reason for this is shown in Fig. 12–8*b*. Here positive increases $dx$ and $dv$ in $x$ and $v$ create an increased $\theta$ that is counterclockwise. If, however, *positive* $x$ is directed to the *left*, then $\theta$ will be *positive clockwise*, Fig. 12–8*c*.

Realize that by assuming $dv/dx$ to be very small, the original horizontal length of the beam's axis and the arc of its elastic curve will be about the same. In other words, $ds$ in Fig. 12–8*b* and 12–8*c* is approximately equal to $dx$, since $ds = \sqrt{(dx)^2 + (dv)^2} = \sqrt{1 + (dv/dx)^2}\, dx \approx dx$. As a result, points on the elastic curve are assumed to be *displaced vertically*, and not horizontally. Also, since the *slope angle* $\theta$ will be *very small*, its value in radians can be determined *directly* from $\theta \approx \tan\theta = dv/dx$.




The design of a roof system requires a careful consideration of deflection. For example, rain can accumulate on areas of the roof, which then causes ponding, leading to further deflection, then further ponding, and finally possible failure of the roof.





Positive sign convention

(a)




Positive sign convention

(b)




Positive sign convention

(c)

**Fig. 12–8**

12

**TABLE 12–1**

| | | |
|---|---|---|
| 1 |  | $\Delta = 0$<br>$M = 0$<br>Roller |
| 2 |  | $\Delta = 0$<br>$M = 0$<br>Pin |
| 3 |  | $\Delta = 0$<br>Roller |
| 4 |  | $\Delta = 0$<br>Pin |
| 5 |  | $\theta = 0$<br>$\Delta = 0$<br>Fixed end |
| 6 |  | $V = 0$<br>$M = 0$<br>Free end |
| 7 |  | $M = 0$<br>Internal pin or hinge |

**Boundary and Continuity Conditions.** When solving Eqs. 12–8, 12–9, or 12–10, the constants of integration are determined by evaluating the functions for shear, moment, slope, or displacement at a particular point on the beam where the value of the function is known. These values are called ***boundary conditions***. Several possible boundary conditions that are often used to solve beam (or shaft) deflection problems are listed in Table 12–1. For example, if the beam is supported by a roller or pin (1, 2, 3, 4), then it is required that the displacement be *zero* at these points. Furthermore, if these supports are located at the *ends of the beam* (1, 2), the internal moment in the beam must also be zero. At the fixed support (5), the slope and displacement are both zero, whereas the free-ended beam (6) has both zero moment and zero shear. Lastly, if two segments of a beam are connected by an "internal" pin or hinge (7), the moment must be zero at this connection.

If the elastic curve cannot be expressed using a single coordinate, then ***continuity conditions*** must be used to evaluate some of the integration constants. For example, consider the beam in Fig. 12–9*a*. Here two $x$ coordinates are chosen with origins at $A$. Each is valid only within the regions $0 \le x_1 \le a$ and $a \le x_2 \le (a + b)$. Once the functions for the slope and deflection are obtained, they must give the *same values* for the slope and deflection at point $B$ so the elastic curve is physically *continuous*. Expressed mathematically, this requires that $\theta_1(a) = \theta_2(a)$ and $v_1(a) = v_2(a)$. These conditions can be used to evaluate two constants of integration. If instead the elastic curve is expressed in terms of the coordinates $0 \le x_1 \le a$ and $0 \le x_2 \le b$, shown in Fig. 12–9*b*, then the continuity of slope and deflection at $B$ requires $\theta_1(a) = -\theta_2(b)$ and $v_1(a) = v_2(b)$. In this particular case, a *negative* sign is necessary to match the slopes at $B$ since $x_1$ extends positive to the right, whereas $x_2$ extends positive to the left. Consequently, $\theta_1$ is positive counterclockwise, and $\theta_2$ is positive clockwise. See Figs. 12–8*b* and 12–8*c*.





Fig. 12–9

## Procedure for Analysis

The following procedure provides a method for determining the slope and deflection of a beam (or shaft) using the method of integration.

### Elastic Curve.

- Draw an exaggerated view of the beam's elastic curve. Recall that zero slope and zero displacement occur at all fixed supports, and zero displacement occurs at all pin and roller supports.
- Establish the $x$ and $v$ coordinate axes. The $x$ axis must be parallel to the undeflected beam and can have an origin at any point along the beam, with a positive direction either to the right or to the left.
- If several discontinuous loads are present, establish $x$ coordinates that are valid for each region of the beam between the discontinuities. Choose these coordinates so that they will simplify subsequent algebraic work.
- In all cases, the associated positive $v$ axis should be directed upward.

### Load or Moment Function.

- For each region in which there is an $x$ coordinate, express the loading $w$ or the internal moment $M$ as a function of $x$. In particular, *always* assume that $M$ acts in the *positive direction* when applying the equation of moment equilibrium to determine $M = f(x)$.

### Slope and Elastic Curve.

- Provided $EI$ is constant, apply either the load equation $EI\, d^4v/dx^4 = w(x)$, which requires four integrations to get $v = v(x)$, or the moment equation $EI\, d^2v/dx^2 = M(x)$, which requires only two integrations. For each integration it is important to include a constant of integration.
- The constants are evaluated using the boundary conditions for the supports (Table 12–1) and the continuity conditions that apply to slope and displacement at points where two functions meet. Once the constants are evaluated and substituted back into the slope and deflection equations, the slope and displacement at *specific points* on the elastic curve can then be determined.
- The numerical values obtained can be checked graphically by comparing them with the sketch of the elastic curve. Realize that *positive* values for *slope* are *counterclockwise* if the $x$ axis extends *positive* to the *right*, and *clockwise* if the $x$ axis extends *positive* to the *left*. In either of these cases, *positive displacement* is *upward*.

12

## EXAMPLE 12.1

The cantilevered beam shown in Fig. 12–10*a* is subjected to a vertical load **P** at its end. Determine the equation of the elastic curve. $EI$ is constant.

### SOLUTION I

**Elastic Curve.** The load tends to deflect the beam as shown in Fig. 12–10*a*. By inspection, the internal moment can be represented throughout the beam using a single $x$ coordinate.

**Moment Function.** From the free-body diagram, with **M** acting in the *positive direction*, Fig. 12–10*b*, we have

$$M = -Px$$

**Slope and Elastic Curve.** Applying Eq. 12–10 and integrating twice yields

$$EI\frac{d^2v}{dx^2} = -Px \tag{1}$$

$$EI\frac{dv}{dx} = -\frac{Px^2}{2} + C_1 \tag{2}$$

$$EIv = -\frac{Px^3}{6} + C_1x + C_2 \tag{3}$$

Using the boundary conditions $dv/dx = 0$ at $x = L$ and $v = 0$ at $x = L$, Eqs. 2 and 3 become

$$0 = -\frac{PL^2}{2} + C_1$$

$$0 = -\frac{PL^3}{6} + C_1L + C_2$$

Thus, $C_1 = PL^2/2$ and $C_2 = -PL^3/3$. Substituting these results into Eqs. 2 and 3 with $\theta = dv/dx$, we get


$$\theta = \frac{P}{2EI}(L^2 - x^2)$$

$$v = \frac{P}{6EI}(-x^3 + 3L^2x - 2L^3) \qquad \textit{Ans.}$$


Maximum slope and displacement occur at $A(x = 0)$, for which

$$\theta_A = \frac{PL^2}{2EI} \tag{4}$$

$$v_A = -\frac{PL^3}{3EI} \tag{5}$$




(a)




(b)

Fig. 12–10

The *positive* result for $\theta_A$ indicates *counterclockwise* rotation and the *negative* result for $v_A$ indicates that $v_A$ is *downward*. This agrees with the results sketched in Fig. 12–10*a*.

In order to obtain some idea as to the actual *magnitude* of the slope and displacement at the end $A$, consider the beam in Fig. 12–10*a* to have a length of 15 ft, support a load of $P = 6$ kip, and be made of A-36 steel having $E_{st} = 29(10^3)$ ksi. Using the methods of Sec. 11.2, if this beam was designed without a factor of safety by assuming the allowable normal stress is equal to the yield stress $\sigma_{allow} = 36$ ksi; then a W12 × 26 would be found to be adequate ($I = 204\ \text{in}^4$). From Eqs. 4 and 5 we get

$$\theta_A = \frac{6\ \text{kip}(15\ \text{ft})^2(12\ \text{in./ft})^2}{2[29(10^3)\ \text{kip/in}^2](204\ \text{in}^4)} = 0.0164\ \text{rad}$$

$$v_A = -\frac{6\ \text{kip}(15\ \text{ft})^3(12\ \text{in./ft})^3}{3[29(10^3)\ \text{kip/in}^2](204\ \text{in}^4)} = -1.97\ \text{in.}$$

Since $\theta_A^2 = (dv/dx)^2 = 0.000270\ \text{rad}^2 \ll 1$, this justifies the use of Eq. 12–10, rather than applying the more exact Eq. 12–4, for computing the deflection of beams. Also, since this numerical application is for a *cantilevered beam*, we have obtained *larger values* for $\theta$ and $v$ than would have been obtained if the beam were supported using pins, rollers, or other fixed supports.

### SOLUTION II

This problem can also be solved using Eq. 12–8, $EI\, d^4v/dx^4 = w(x)$. Here $w(x) = 0$ for $0 \le x \le L$, Fig. 12–10*a*, so that upon integrating once we get the form of Eq. 12–9, i.e.,

$$EI\frac{d^4v}{dx^4} = 0$$

$$EI\frac{d^3v}{dx^3} = C_1' = V$$

The shear constant $C_1'$ can be evaluated at $x = 0$, since $V_A = -P$ (negative according to the beam sign convention, Fig. 12–8*a*). Thus, $C_1' = -P$. Integrating again yields the form of Eq. 12–10, i.e.,

$$EI\frac{d^3v}{dx^3} = -P$$


$$EI\frac{d^2v}{dx^2} = -Px + C_2' = M$$

Here $M = 0$ at $x = 0$, so $C_2' = 0$, and as a result one obtains Eq. 1 and the solution proceeds as before.

12

## EXAMPLE 12.2

The simply supported beam shown in Fig. 12–11*a* supports the triangular distributed loading. Determine its maximum deflection. $EI$ is constant.




(a) (b)

Fig. 12–11

### SOLUTION I

**Elastic Curve.** Due to symmetry, only one $x$ coordinate is needed for the solution, in this case $0 \leq x \leq L/2$. The beam deflects as shown in Fig. 12–11*a*. The maximum deflection occurs at the center since the slope is zero at this point.

**Moment Function.** A free-body diagram of the segment on the left is shown in Fig. 12–11*b*. The equation for the distributed loading is

$$w = \frac{2w_0}{L}x \tag{1}$$

Hence,

$$\downarrow+\Sigma M_{NA} = 0; \qquad M + \frac{w_0x^2}{L}\left(\frac{x}{3}\right) - \frac{w_0L}{4}(x) = 0$$

$$M = -\frac{w_0x^3}{3L} + \frac{w_0L}{4}x$$

**Slope and Elastic Curve.** Using Eq. 12–10 and integrating twice, we have

$$EI\frac{d^2v}{dx^2} = M = -\frac{w_0}{3L}x^3 + \frac{w_0L}{4}x \qquad (2)$$

$$EI\frac{dv}{dx} = -\frac{w_0}{12L}x^4 + \frac{w_0L}{8}x^2 + C_1$$

$$EIv = -\frac{w_0}{60L}x^5 + \frac{w_0L}{24}x^3 + C_1x + C_2$$

The constants of integration are obtained by applying the boundary condition $v = 0$ at $x = 0$ and the symmetry condition that $dv/dx = 0$ at $x = L/2$. This leads to

$$C_1 = -\frac{5w_0L^3}{192} \qquad C_2 = 0$$

Hence,

$$EI\frac{dv}{dx} = -\frac{w_0}{12L}x^4 + \frac{w_0L}{8}x^2 - \frac{5w_0L^3}{192}$$

$$EIv = -\frac{w_0}{60L}x^5 + \frac{w_0L}{24}x^3 - \frac{5w_0L^3}{192}x$$

Determining the maximum deflection at $x = L/2$, we have

$$v_{max} = -\frac{w_0L^4}{120EI} \qquad \textit{Ans.}$$

SOLUTION II

Since the distributed loading acts downward, it is negative according to our sign convention. Using Eq. 1 and applying Eq. 12–8, we have

$$EI\frac{d^4v}{dx^4} = -\frac{2w_0}{L}x$$

$$EI\frac{d^3v}{dx^3} = V = -\frac{w_0}{L}x^2 + C_1'$$

Since $V = +w_0L/4$ at $x = 0$, then $C_1' = w_0L/4$. Integrating again yields

$$EI\frac{d^3v}{dx^3} = V = -\frac{w_0}{L}x^2 + \frac{w_0L}{4}$$


$$EI\frac{d^2v}{dx^2} = M = -\frac{w_0}{3L}x^3 + \frac{w_0L}{4}x + C_2'$$

Here $M = 0$ at $x = 0$, so $C_2' = 0$. This yields Eq. 2. The solution now proceeds as before.


12

## EXAMPLE 12.3

The simply supported beam shown in Fig. 12–12*a* is subjected to the concentrated force **P**. Determine the maximum deflection of the beam. *EI* is constant.




(a)





(b)


### SOLUTION

**Elastic Curve.** The beam deflects as shown in Fig. 12–12*b*. Two coordinates must be used, since the moment function will change at *P*. Here we will take $x_1$ and $x_2$, having the *same origin* at *A*.

**Moment Function.** From the free-body diagrams shown in Fig. 12–12*c*,




$$M_1 = \frac{P}{3}x_1$$




$$M_2 = \frac{P}{3}x_2 - P(x_2 - 2a) = \frac{2P}{3}(3a - x_2)$$

(c)

Fig. 12–12

**Slope and Elastic Curve.** Applying Eq. 12–10 for $M_1$, for $0 \le x_1 < 2a$, and integrating twice yields

$$EI\frac{d^2v_1}{dx_1^2} = \frac{P}{3}x_1$$

$$EI\frac{dv_1}{dx_1} = \frac{P}{6}x_1^2 + C_1 \qquad (1)$$

$$EIv_1 = \frac{P}{18}x_1^3 + C_1x_1 + C_2 \qquad (2)$$

Likewise for $M_2$, for $2a < x_2 \le 3a$,

$$EI\frac{d^2v_2}{dx_2^2} = \frac{2P}{3}(3a - x_2)$$

$$EI\frac{dv_2}{dx_2} = \frac{2P}{3}\left(3ax_2 - \frac{x_2^2}{2}\right) + C_3 \qquad (3)$$

$$EIv_2 = \frac{2P}{3}\left(\frac{3}{2}ax_2^2 - \frac{x_2^3}{6}\right) + C_3x_2 + C_4 \qquad (4)$$

The four constants are evaluated using *two* boundary conditions, namely, $x_1 = 0$, $v_1 = 0$ and $x_2 = 3a$, $v_2 = 0$. Also, *two* continuity conditions must be applied at $B$, that is, $dv_1/dx_1 = dv_2/dx_2$ at $x_1 = x_2 = 2a$ and $v_1 = v_2$ at $x_1 = x_2 = 2a$. Substitution as specified results in the following four equations:

$$v_1 = 0 \text{ at } x_1 = 0; \qquad 0 = 0 + 0 + C_2$$

$$v_2 = 0 \text{ at } x_2 = 3a; \qquad 0 = \frac{2P}{3}\left(\frac{3}{2}a(3a)^2 - \frac{(3a)^3}{6}\right) + C_3(3a) + C_4$$

$$\frac{dv_1(2a)}{dx_1} = \frac{dv_2(2a)}{dx_2}; \qquad \frac{P}{6}(2a)^2 + C_1 = \frac{2P}{3}\left(3a(2a) - \frac{(2a)^2}{2}\right) + C_3$$

$$v_1(2a) = v_2(2a); \qquad \frac{P}{18}(2a)^3 + C_1(2a) + C_2 = \frac{2P}{3}\left(\frac{3}{2}a(2a)^2 - \frac{(2a)^3}{6}\right) + C_3(2a) + C_4$$

Solving, we get

$$C_1 = -\frac{4}{9}Pa^2 \qquad C_2 = 0$$

$$C_3 = -\frac{22}{9}Pa^2 \qquad C_4 = \frac{4}{3}Pa^3$$

Thus Eqs. 1–4 become

$$\frac{dv_1}{dx_1} = \frac{P}{6EI}x_1^2 - \frac{4Pa^2}{9EI} \tag{5}$$

$$v_1 = \frac{P}{18EI}x_1^3 - \frac{4Pa^2}{9EI}x_1 \tag{6}$$

$$\frac{dv_2}{dx_2} = \frac{2Pa}{EI}x_2 - \frac{P}{3EI}x_2^2 - \frac{22Pa^2}{9EI} \tag{7}$$

$$v_2 = \frac{Pa}{EI}x_2^2 - \frac{P}{9EI}x_2^3 - \frac{22Pa^2}{9EI}x_2 + \frac{4Pa^3}{3EI} \tag{8}$$

By inspection of the elastic curve, Fig. 12–12*b*, the maximum deflection occurs at $D$, somewhere within region $AB$. Here the slope must be zero. From Eq. 5,

$$\frac{1}{6}x_1^2 - \frac{4}{9}a^2 = 0$$

$$x_1 = 1.633a$$

Substituting into Eq. 6,

$$v_{\max} = -0.484\frac{Pa^3}{EI} \qquad \textit{Ans.}$$

The negative sign indicates that the deflection is downward.

12

## EXAMPLE 12.4

The beam in Fig. 12–13*a* is subjected to a load **P** at its end. Determine the displacement at *C*. *EI* is constant.





Fig. 12–13

### SOLUTION

**Elastic Curve.** The beam deflects into the shape shown in Fig. 12–13*a*. Due to the loading, two $x$ coordinates will be considered, namely, $0 \le x_1 < 2a$ and $0 \le x_2 < a$, where $x_2$ is directed to the left from $C$, since the internal moment is easy to formulate.

**Moment Functions.** Using the free-body diagrams shown in Fig. 12–13*b*, we have

$$M_1 = -\frac{P}{2}x_1 \qquad M_2 = -Px_2$$

**Slope and Elastic Curve.** Applying Eq. 12–10,

For $0 \le x_1 \le 2a$: $$EI\frac{d^2v_1}{dx_1^2} = -\frac{P}{2}x_1$$

$$EI\frac{dv_1}{dx_1} = -\frac{P}{4}x_1^2 + C_1 \tag{1}$$

$$EIv_1 = -\frac{P}{12}x_1^3 + C_1x_1 + C_2 \tag{2}$$

For $0 \le x_2 \le a$: $\quad EI\dfrac{d^2v_2}{dx_2^2} = -Px_2$

$$EI\frac{dv_2}{dx_2} = -\frac{P}{2}x_2^2 + C_3 \tag{3}$$

$$EIv_2 = -\frac{P}{6}x_2^3 + C_3x_2 + C_4 \tag{4}$$

The *four* constants of integration are determined using *three* boundary conditions, namely, $v_1 = 0$ at $x_1 = 0$, $v_1 = 0$ at $x_1 = 2a$, and $v_2 = 0$ at $x_2 = a$, and *one* continuity equation. Here the continuity of slope at the roller requires $dv_1/dx_1 = -dv_2/dx_2$ at $x_1 = 2a$ and $x_2 = a$. Why is there a negative sign in this equation? (Note that continuity of displacement at $B$ has been indirectly considered in the boundary conditions, since $v_1 = v_2 = 0$ at $x_1 = 2a$ and $x_2 = a$.) Applying these four conditions yields

$v_1 = 0$ at $x_1 = 0$: $\quad 0 = 0 + 0 + C_2$

$v_1 = 0$ at $x_1 = 2a$: $\quad 0 = -\dfrac{P}{12}(2a)^3 + C_1(2a) + C_2$

$v_2 = 0$ at $x_2 = a$: $\quad 0 = -\dfrac{P}{6}a^3 + C_3a + C_4$

$\dfrac{dv_1(2a)}{dx_1} = -\dfrac{dv_2(a)}{dx_2}$: $\quad -\dfrac{P}{4}(2a)^2 + C_1 = -\left(-\dfrac{P}{2}(a)^2 + C_3\right)$

Solving, we obtain

$$C_1 = \frac{Pa^2}{3} \qquad C_2 = 0 \qquad C_3 = \frac{7}{6}Pa^2 \qquad C_4 = -Pa^3$$

Substituting $C_3$ and $C_4$ into Eq. 4 gives

$$v_2 = -\frac{P}{6EI}x_2^3 + \frac{7Pa^2}{6EI}x_2 - \frac{Pa^3}{EI}$$


The displacement at $C$ is determined by setting $x_2 = 0$. We get

$$v_C = -\frac{Pa^3}{EI} \qquad \textit{Ans}$$

12


## FUNDAMENTAL PROBLEMS

**F12–1.** Determine the slope and deflection of end $A$ of the cantilevered beam. $E = 200$ GPa and $I = 65.0(10^6)$ mm$^4$.





F12–1

**F12–2.** Determine the slope and deflection of end $A$ of the cantilevered beam. $E = 200$ GPa and $I = 65.0(10^6)$ mm$^4$.





F12–2

**F12–3.** Determine the slope of end $A$ of the cantilevered beam. $E = 200$ GPa and $I = 65.0(10^6)$ mm$^4$.





F12–3

**F12–4.** Determine the maximum deflection of the simply supported beam. The beam is made of wood having a modulus of elasticity of $E_w = 1.5(10^3)$ ksi and a rectangular cross section of $b = 3$ in. and $h = 6$ in.





F12–4

**F12–5.** Determine the maximum deflection of the simply supported beam. $E = 200$ GPa and $I = 39.9(10^{-6})$ m$^4$.




F12–5

**F12–6.** Determine the slope of the simply supported beam at $A$. $E = 200$ GPa and $I = 39.9(10^{-6})$ m$^4$.





F12–6

## PROBLEMS


**•12–1.** An A-36 steel strap having a thickness of 10 mm and a width of 20 mm is bent into a circular arc of radius $\rho = 10$ m. Determine the maximum bending stress in the strap.

**12–2.** A picture is taken of a man performing a pole vault, and the minimum radius of curvature of the pole is estimated by measurement to be 4.5 m. If the pole is 40 mm in diameter and it is made of a glass-reinforced plastic for which $E_g = 131$ GPa, determine the maximum bending stress in the pole.





Prob. 12–2

**12–3.** When the diver stands at end $C$ of the diving board, it deflects downward 3.5 in. Determine the weight of the diver. The board is made of material having a modulus of elasticity of $E = 1.5(10^3)$ ksi.





Prob. 12–3

***12–4.** Determine the equations of the elastic curve using the $x_1$ and $x_2$ coordinates. $EI$ is constant.





Prob. 12–4

**•12–5.** Determine the equations of the elastic curve for the beam using the $x_1$ and $x_2$ coordinates. $EI$ is constant.




Prob. 12–5


**12–6.** Determine the equations of the elastic curve for the beam using the $x_1$ and $x_3$ coordinates. Specify the beam's maximum deflection. $EI$ is constant.




Prob. 12–6


12

**12–7.** The beam is made of two rods and is subjected to the concentrated load **P**. Determine the maximum deflection of the beam if the moments of inertia of the rods are $I_{AB}$ and $I_{BC}$, and the modulus of elasticity is $E$.





Prob. 12–7

***12–8.** Determine the equations of the elastic curve for the beam using the $x_1$ and $x_2$ coordinates. $EI$ is constant.





Prob. 12–8

**•12–9.** Determine the equations of the elastic curve using the $x_1$ and $x_2$ coordinates. $EI$ is constant.





Prob. 12–9

**12–10.** Determine the maximum slope and maximum deflection of the simply supported beam which is subjected to the couple moment $\mathbf{M}_0$. $EI$ is constant.





Prob. 12–10

**12–11.** Determine the equations of the elastic curve for the beam using the $x_1$ and $x_2$ coordinates. Specify the beam's maximum deflection. $EI$ is constant.





Prob. 12–11

***12–12.** Determine the equations of the elastic curve for the beam using the $x_1$ and $x_2$ coordinates. Specify the slope at $A$ and the maximum displacement of the shaft. $EI$ is constant.





Prob. 12–12

**12–13.** The bar is supported by a roller constraint at $B$, which allows vertical displacement but resists axial load and moment. If the bar is subjected to the loading shown, determine the slope at $A$ and the deflection at $C$. $EI$ is constant





Prob. 12–13

**12–14.** The simply supported shaft has a moment of inertia of $2I$ for region $BC$ and a moment of inertia $I$ for regions $AB$ and $CD$. Determine the maximum deflection of the beam due to the load **P**.





Prob. 12–14

**12–15.** Determine the equations of the elastic curve for the shaft using the $x_1$ and $x_3$ coordinates. Specify the slope at $A$ and the deflection at the center of the shaft. $EI$ is constant.





Prob. 12–15

***12–16.** The fence board weaves between the three smooth fixed posts. If the posts remain along the same line, determine the maximum bending stress in the board. The board has a width of 6 in. and a thickness of 0.5 in. $E = 1.60(10^3)$ ksi. Assume the displacement of each end of the board relative to its center is 3 in.




Prob. 12–16


•**12–17.** Determine the equations of the elastic curve for the shaft using the $x_1$ and $x_2$ coordinates. Specify the slope at $A$ and the deflection at $C$. $EI$ is constant.




Prob. 12–17

**12–18.** Determine the equation of the elastic curve for the beam using the $x$ coordinate. Specify the slope at $A$ and the maximum deflection. $EI$ is constant.


**12–19.** Determine the deflection at the center of the beam and the slope at $B$. $EI$ is constant.




Probs. 12–18/19


12

*12–20. Determine the equations of the elastic curve using the $x_1$ and $x_2$ coordinates, and specify the slope at $A$ and the deflection at $C$. $EI$ is constant.





Prob. 12–20

•12–21. Determine the elastic curve in terms of the $x_1$ and $x_2$ coordinates and the deflection of end $C$ of the overhang beam. $EI$ is constant.




Prob. 12–21


12–22. Determine the elastic curve for the cantilevered W14 × 30 beam using the $x$ coordinate. Specify the maximum slope and maximum deflection. $E = 29(10^3)$ ksi.




Prob. 12–22


12–23. The beam is subjected to the linearly varying distributed load. Determine the maximum slope of the beam. $EI$ is constant.

*12–24. The beam is subjected to the linearly varying distributed load. Determine the maximum deflection of the beam. $EI$ is constant.





Probs. 12–23/24

•12–25. Determine the equation of the elastic curve for the simply supported beam using the $x$ coordinate. Determine the slope at $A$ and the maximum deflection. $EI$ is constant.





Prob. 12–25

**12–26.** Determine the equations of the elastic curve using the coordinates $x_1$ and $x_2$, and specify the slope and deflection at $B$. $EI$ is constant.





Prob. 12–26

**12–27.** Wooden posts used for a retaining wall have a diameter of 3 in. If the soil pressure along a post varies uniformly from zero at the top $A$ to a maximum of 300 lb/ft at the bottom $B$, determine the slope and displacement at the top of the post. $E_w = 1.6(10^3)$ ksi.





Prob. 12–27

***12–28.** Determine the slope at end $B$ and the maximum deflection of the cantilevered triangular plate of constant thickness $t$. The plate is made of material having a modulus of elasticity $E$.





Prob. 12–28

**•12–29.** The beam is made of a material having a specific weight $\gamma$. Determine the displacement and slope at its end $A$ due to its weight. The modulus of elasticity for the material is $E$.




Prob. 12–29


**12–30.** The beam is made of a material having a specific weight of $\gamma$. Determine the displacement and slope at its end $A$ due to its weight. The modulus of elasticity for the material is $E$.




Prob. 12–30


12

**12–31.** The tapered beam has a rectangular cross section. Determine the deflection of its free end in terms of the load $P$, length $L$, modulus of elasticity $E$, and the moment of inertia $I_0$ of its fixed end.





Prob. 12–31

*12–32. The beam is made from a plate that has a constant thickness $t$ and a width that varies linearly. The plate is cut into strips to form a series of leaves that are stacked to make a leaf spring consisting of $n$ leaves. Determine the deflection at its end when loaded. Neglect friction between the leaves.





Prob. 12–32

•12–33. The tapered beam has a rectangular cross section. Determine the deflection of its center in terms of the load $P$, length $L$, modulus of elasticity $E$, and the moment of inertia $I_c$ of its center.




Prob. 12–33

12–34. The leaf spring assembly is designed so that it is subjected to the same maximum stress throughout its length. If the plates of each leaf have a thickness $t$ and can slide freely between each other, show that the spring must be in the form of a circular arc in order that the entire spring becomes flat when a large enough load **P** is applied. What is the maximum normal stress in the spring? Consider the spring to be made by cutting the $n$ strips from the diamond-shaped plate of thickness $t$ and width $b$. The modulus of elasticity for the material is $E$. *Hint*: Show that the radius of curvature of the spring is constant.




Prob. 12–34

## *12.3 Discontinuity Functions

The method of integration, used to find the equation of the elastic curve for a beam or shaft, is convenient if the load or internal moment can be expressed as a continuous function throughout the beam's entire length. If several different loadings act on the beam, however, the method becomes more tedious to apply, because separate loading or moment functions must be written for each region of the beam. Furthermore, integration of these functions requires the evaluation of integration constants using both boundary and continuity conditions. For example, the beam shown in Fig. 12–14 requires four moment functions to be written. They describe the moment in regions $AB$, $BC$, $CD$, and $DE$. When applying the moment-curvature relationship, $EI\,d^2v/dx^2 = M$, and integrating each moment equation twice, we must evaluate eight constants of integration. These involve two boundary conditions that require zero displacement at points $A$ and $E$, and six continuity conditions for both slope and displacement at points $B$, $C$, and $D$.

In this section, we will discuss a method for finding the equation of the elastic curve for a *multiply loaded beam* using a *single expression*, either formulated from the loading on the beam, $w = w(x)$, or from the beam's internal moment, $M = M(x)$. If the expression for $w$ is substituted into $EI\,d^4v/dx^4 = w(x)$ and integrated four times, or if the expression for $M$ is substituted into $EI\,d^2v/dx^2 = M(x)$ and integrated twice, the constants of integration will be determined only from the boundary conditions. Since the continuity equations will not be involved, the analysis will be greatly simplified.



For safety purposes these cantilevered beams that support sheets of plywood must be designed for both strength and a restricted amount of deflection.

**Discontinuity Functions.** In order to express the load on the beam or the internal moment within it using a single expression, we will use two types of mathematical operators known as *discontinuity functions*.









Fig. 12–14

12

**TABLE 12–2**

| Loading | Loading Function $w = w(x)$ | Shear $V = \int w(x)dx$ | Moment $M = \int V dx$ |
|---|---|---|---|
| (1)  | $w = M_0\langle x-a\rangle^{-2}$ | $V = M_0\langle x-a\rangle^{-1}$ | $M = M_0\langle x-a\rangle^{0}$ |
| (2)  | $w = P\langle x-a\rangle^{-1}$ | $V = P\langle x-a\rangle^{0}$ | $M = P\langle x-a\rangle^{1}$ |
| (3)  | $w = w_0\langle x-a\rangle^{0}$ | $V = w_0\langle x-a\rangle^{1}$ | $M = \frac{w_0}{2}\langle x-a\rangle^{2}$ |
| (4)  | $w = m\langle x-a\rangle^{1}$ | $V = \frac{m}{2}\langle x-a\rangle^{2}$ | $M = \frac{m}{6}\langle x-a\rangle^{3}$ |

**Macaulay Functions.** For purposes of beam or shaft deflection, Macaulay functions, named after the mathematician W. H. Macaulay, can be used to describe ***distributed loadings***. These functions can be written in general form as

$$\langle x-a\rangle^n = \begin{cases} 0 & \text{for } x < a \\ (x-a)^n & \text{for } x \geq a \end{cases} \qquad n \geq 0 \tag{12–11}$$

Here $x$ represents the coordinate position of a point along the beam, and $a$ is the location on the beam where a "discontinuity" occurs, namely the point where a distributed loading *begins*. Note that the Macaulay function $\langle x-a\rangle^n$ is written with angle brackets to distinguish it from the ordinary function $(x-a)^n$, written with parentheses. As stated by the equation, only when $x \geq a$ is $\langle x-a\rangle^n = (x-a)^n$, otherwise it is zero. Furthermore, these functions are valid only for exponential values $n \geq 0$. Integration of Macaulay functions follows the same rules as for ordinary functions, i.e.,

$$\int \langle x-a\rangle^n dx = \frac{\langle x-a\rangle^{n+1}}{n+1} + C \tag{12–12}$$

Note how the Macaulay functions describe both the *uniform load* $w_0$ $(n = 0)$ and *triangular load* $(n = 1)$, shown in Table 12–2, items 3 and 4. This type of description can, of course, be extended to distributed loadings having other forms. Also, it is possible to use superposition with

the uniform and triangular loadings to create the Macaulay function for a trapezoidal loading. Using integration, the Macaulay functions for shear, $V = \int w(x)\,dx$, and moment, $M = \int V\,dx$, are also shown in the table.

**Singularity Functions.** These functions are only used to describe the point location of concentrated forces or couple moments acting on a beam or shaft. Specifically, a concentrated force **P** can be considered as a special case of a distributed loading, where the intensity of the loading is $w = P/\epsilon$ such that its length is $\epsilon$, where $\epsilon \to 0$, Fig. 12–15. The area under this loading diagram is equivalent to $P$, *positive upward*, and so we will use the singularity function

$$w = P\langle x - a\rangle^{-1} = \begin{cases} 0 & \text{for } x \neq a \\ P & \text{for } x = a \end{cases} \tag{12–13}$$

to describe the force $P$. Here $n = -1$ so that the units for $w$ are force per length, as it should be. Furthermore, the function takes on the value of **P** only at the point $x = a$ where the load occurs, otherwise it is zero.





Fig. 12–15

In a similar manner, a couple moment $\mathbf{M}_0$, considered *positive clockwise*, is a limit as $\epsilon \to 0$ of two distributed loadings as shown in Fig. 12–16. Here the following function describes its value.

$$w = M_0\langle x - a\rangle^{-2} = \begin{cases} 0 & \text{for } x \neq a \\ M_0 & \text{for } x = a \end{cases} \tag{12–14}$$

The exponent $n = -2$, in order to ensure that the units of $w$, force per length, are maintained.

Integration of the above two singularity functions follow the rules of operational calculus and yields results that are *different* from those of Macaulay functions. Specifically,

$$\int \langle x - a\rangle^n dx = \langle x - a\rangle^{n+1},\ n = -1, -2 \tag{12–15}$$





Fig. 12–16

Using this formula, notice how $M_0$ and $P$, described in Table 12–2, items 1 and 2, are integrated once, then twice, to obtain the internal shear and moment in the beam.

Application of Eqs. 12–11 through 12–15 provides a rather direct means for expressing the loading or the internal moment in a beam as a function of $x$. When doing so, close attention must be paid to the signs of the external loadings. As stated above, and as shown in Table 12–2, *concentrated forces and distributed loads are positive upward, and couple moments are positive clockwise.* If this sign convention is followed, then the internal shear and moment are in accordance with the beam sign convention established in Sec. 6.1.

12

As an example of how to apply discontinuity functions to describe the loading or internal moment consider the beam loaded as shown in Fig. 12–17*a*. Here the reactive 2.75-kN force created by the roller, Fig. 12–17*b*, is positive since it acts upward, and the 1.5-kN·m couple moment is also positive since it acts clockwise. Finally, the trapezoidal loading is negative and has been separated into triangular and uniform loadings. From Table 12–2, the loading at any point $x$ on the beam is therefore

$$w = 2.75\,\text{kN}\langle x - 0\rangle^{-1} + 1.5\,\text{kN}\cdot\text{m}\langle x - 3\,\text{m}\rangle^{-2} - 3\,\text{kN/m}\langle x - 3\,\text{m}\rangle^{0} - 1\,\text{kN/m}^2\langle x - 3\,\text{m}\rangle^{1}$$

The reactive force at $B$ is not included here since $x$ is never greater than 6 m, and furthermore, this value is of no consequence in calculating the slope or deflection. We can determine the moment expression directly from Table 12–2, rather than integrating this expression twice. In either case,

$$M = 2.75\,\text{kN}\langle x - 0\rangle^{1} + 1.5\,\text{kN}\cdot\text{m}\langle x - 3\,\text{m}\rangle^{0} - \frac{3\,\text{kN/m}}{2}\langle x - 3\,\text{m}\rangle^{2} - \frac{1\,\text{kN/m}^2}{6}\langle x - 3\,\text{m}\rangle^{3}$$

$$= 2.75x + 1.5\langle x - 3\rangle^{0} - 1.5\langle x - 3\rangle^{2} - \frac{1}{6}\langle x - 3\rangle^{3}$$

The deflection of the beam can now be determined after this equation is integrated two successive times and the constants of integration are evaluated using the boundary conditions of zero displacement at $A$ and $B$.





Fig. 12–17

## Procedure for Analysis

The following procedure provides a method for using discontinuity functions to determine a beam's elastic curve. This method is particularly advantageous for solving problems involving beams or shafts subjected to *several loadings*, since the constants of integration can be evaluated by using *only* the boundary conditions, while the compatibility conditions are automatically satisfied.

### Elastic Curve.

- Sketch the beam's elastic curve and identify the boundary conditions at the supports.
- Zero displacement occurs at all pin and roller supports, and zero slope and zero displacement occur at fixed supports.
- Establish the $x$ axis so that it extends to the right and has its origin at the beam's left end.

### Load or Moment Function.

- Calculate the support reactions at $x = 0$ and then use the discontinuity functions in Table 12–2 to express either the loading $w$ or the internal moment $M$ as a function of $x$. Make sure to follow the sign convention for each loading as it applies for this equation.
- Note that the distributed loadings must extend all the way to the beam's right end to be valid. If this does not occur, use the method of superposition, which is illustrated in Example 12.6.


### Slope and Elastic Curve.

- Substitute $w$ into $EI\,d^4v/dx^4 = w(x)$, or $M$ into the moment curvature relation $EI\,d^2v/dx^2 = M$, and integrate to obtain the equations for the beam's slope and deflection.
- Evaluate the constants of integration using the boundary conditions, and substitute these constants into the slope and deflection equations to obtain the final results.
- When the slope and deflection equations are evaluated at any point on the beam, a *positive slope* is *counterclockwise*, and a *positive displacement* is *upward*.


12

## EXAMPLE 12.5

Determine the maximum deflection of the beam shown in Fig. 12–18*a*. *EI* is constant.




(a)




(b)

**Fig. 12–18**

### SOLUTION

**Elastic Curve.** The beam deflects as shown in Fig. 12–18*a*. The boundary conditions require zero displacement at *A* and *B*.

**Loading Function.** The reactions have been calculated and are shown on the free-body diagram in Fig. 12–18*b*. The loading function for the beam can be written as

$$w = -8\text{ kip}\,\langle x - 0\rangle^{-1} + 6\text{ kip}\,\langle x - 10\text{ ft}\rangle^{-1}$$

The couple moment and force at *B* are not included here, since they are located at the right end of the beam, and *x* cannot be greater than 30 ft. Integrating $dV/dx = w(x)$, we get

$$V = -8\langle x - 0\rangle^{0} + 6\langle x - 10\rangle^{0}$$

In a similar manner, $dM/dx = V$ yields

$$\begin{aligned} M &= -8\langle x - 0\rangle^{1} + 6\langle x - 10\rangle^{1} \\ &= (-8x + 6\langle x - 10\rangle^{1})\text{ kip}\cdot\text{ft} \end{aligned}$$

Notice how his equation can also be established *directly* using the results of Table 12–2 for moment.

**Slope and Elastic Curve.** Integrating twice yields

$$EI\frac{d^2v}{dx^2} = -8x + 6\langle x - 10\rangle^1$$

$$EI\frac{dv}{dx} = -4x^2 + 3\langle x - 10\rangle^2 + C_1$$

$$EIv = -\frac{4}{3}x^3 + \langle x - 10\rangle^3 + C_1x + C_2 \qquad (1)$$

From Eq. 1, the boundary condition $v = 0$ at $x = 10$ ft and $v = 0$ at $x = 30$ ft gives

$$0 = -1333 + (10 - 10)^3 + C_1(10) + C_2$$

$$0 = -36\,000 + (30 - 10)^3 + C_1(30) + C_2$$

Solving these equations simultaneously for $C_1$ and $C_2$, we get $C_1 = 1333$ and $C_2 = -12\,000$. Thus,

$$EI\frac{dv}{dx} = -4x^2 + 3\langle x - 10\rangle^2 + 1333 \qquad (2)$$

$$EIv = -\frac{4}{3}x^3 + \langle x - 10\rangle^3 + 1333x - 12\,000 \qquad (3)$$

From Fig. 12–18*a*, maximum displacement may occur either at $C$, or at $D$, where the slope $dv/dx = 0$. To obtain the displacement of $C$, set $x = 0$ in Eq. 3. We get

$$v_C = -\frac{12\,000\ \text{kip}\cdot\text{ft}^3}{EI} \qquad \textit{Ans.}$$

The *negative* sign indicates that the displacement is *downward* as shown in Fig. 12–18*a*. To locate point $D$, use Eq. 2 with $x > 10$ ft and $dv/dx = 0$. This gives

$$0 = -4x_D^2 + 3(x_D - 10)^2 + 1333$$

$$x_D^2 + 60x_D - 1633 = 0$$

Solving for the positive root,

$$x_D = 20.3\ \text{ft}$$

Hence, from Eq. 3,

$$EIv_D = -\frac{4}{3}(20.3)^3 + (20.3 - 10)^3 + 1333(20.3) - 12\,000$$

$$v_D = \frac{5006\ \text{kip}\cdot\text{ft}^3}{EI}$$

Comparing this value with $v_C$, we see that $v_{\max} = v_C$.

12

## EXAMPLE 12.6





Fig. 12–19

Determine the equation of the elastic curve for the cantilevered beam shown in Fig. 12–19*a*. $EI$ is constant.

SOLUTION

**Elastic Curve.** The loads cause the beam to deflect as shown in Fig. 12–19*a*. The boundary conditions require zero slope and displacement at $A$.

**Loading Function.** The support reactions at $A$ have been calculated and are shown on the free-body diagram in Fig. 12–19*b*. Since the distributed loading in Fig. 12–19*a* does not extend to $C$ as required, we can use the superposition of loadings shown in Fig. 12–19*b* to represent the same effect. By our sign convention, the beam's loading is therefore

$$w = 52\ \text{kN}\langle x-0\rangle^{-1} - 258\ \text{kN}\cdot\text{m}\langle x-0\rangle^{-2} - 8\ \text{kN/m}\langle x-0\rangle^{0} + 50\ \text{kN}\cdot\text{m}\langle x-5\ \text{m}\rangle^{-2} + 8\ \text{kN/m}\langle x-5\ \text{m}\rangle^{0}$$

The 12-kN load is *not included* here, since $x$ cannot be greater than 9 m. Because $dV/dx = w(x)$, then by integrating, neglecting the constant of integration since the reactions are included in the load function, we have

$$V = 52\langle x-0\rangle^{0} - 258\langle x-0\rangle^{-1} - 8\langle x-0\rangle^{1} + 50\langle x-5\rangle^{-1} + 8\langle x-5\rangle^{1}$$

Furthermore, $dM/dx = V$, so that integrating again yields

$$M = -258\langle x-0\rangle^{0} + 52\langle x-0\rangle^{1} - \frac{1}{2}(8)\langle x-0\rangle^{2} + 50\langle x-5\rangle^{0} + \frac{1}{2}(8)\langle x-5\rangle^{2}$$

$$= (-258 + 52x - 4x^2 + 50\langle x-5\rangle^{0} + 4\langle x-5\rangle^{2})\ \text{kN}\cdot\text{m}$$

This same result can be obtained *directly* from Table 12–2.

**Slope and Elastic Curve.** Applying Eq. 12–10 and integrating twice, we have

$$EI\frac{d^2v}{dx^2} = -258 + 52x - 4x^2 + 50\langle x-5\rangle^{0} + 4\langle x-5\rangle^{2}$$

$$EI\frac{dv}{dx} = -258x + 26x^2 - \frac{4}{3}x^3 + 50\langle x-5\rangle^{1} + \frac{4}{3}\langle x-5\rangle^{3} + C_1$$


$$EIv = -129x^2 + \frac{26}{3}x^3 - \frac{1}{3}x^4 + 25\langle x-5\rangle^{2} + \frac{1}{3}\langle x-5\rangle^{4} + C_1x + C_2$$

Since $dv/dx = 0$ at $x = 0$, $C_1 = 0$; and $v = 0$ at $x = 0$, so $C_2 = 0$. Thus,

$$v = \frac{1}{EI}\left(-129x^2 + \frac{26}{3}x^3 - \frac{1}{3}x^4 + 25\langle x-5\rangle^{2} + \frac{1}{3}\langle x-5\rangle^{4}\right)\text{m} \quad \textit{Ans.}$$


## PROBLEMS

**12–35.** The shaft is made of steel and has a diameter of 15 mm. Determine its maximum deflection. The bearings at $A$ and $B$ exert only vertical reactions on the shaft. $E_{st} = 200$ GPa.





Prob. 12–35

***12–36.** The beam is subjected to the loads shown. Determine the equation of the elastic curve. $EI$ is constant.





Prob. 12–36

**•12–37.** Determine the deflection at each of the pulleys $C$, $D$, and $E$. The shaft is made of steel and has a diameter of 30 mm. The bearings at $A$ and $B$ exert only vertical reactions on the shaft. $E_{st} = 200$ GPa.





Prob. 12–37

**12–38.** The shaft supports the two pulley loads shown. Determine the equation of the elastic curve. The bearings at $A$ and $B$ exert only vertical reactions on the shaft. $EI$ is constant.




Prob. 12–38


**12–39.** Determine the maximum deflection of the simply supported beam. $E = 200$ GPa and $I = 65.0(10^6)$ mm$^4$.




Prob. 12–39

***12–40.** Determine the eqution of the elastic curve, the slope at $A$, and the deflection at $B$ of the simply supported beam. $EI$ is constant.


**•12–41.** Determine the equation of the elastic curve and the maximum deflection of the simply supported beam. $EI$ is constant.




Probs. 12–40/41


12

**12–42.** Determine the equation of the elastic curve, the slope at $A$, and the maximum deflection of the simply supported beam. $EI$ is constant.




Prob. 12–42


**12–43.** Determine the maximum deflection of the cantilevered beam. The beam is made of material having an $E = 200$ GPa and $I = 65.0(10^6)$ mm$^6$.




Prob. 12–43


***12–44.** The beam is subjected to the load shown. Determine the equation of the elastic curve. $EI$ is constant.

**•12–45.** The beam is subjected to the load shown. Determine the displacement at $x = 7$ m and the slope at $A$. $EI$ is constant.





Probs. 12–44/45

**12–46.** Determine the maximum deflection of the simply supported beam. $E = 200$ GPa and $I = 65.0(10^6)$ mm$^4$.





Prob. 12–46

**12–47.** The wooden beam is subjected to the load shown. Determine the equation of the elastic curve. If $E_w = 12$ GPa, determine the deflection and the slope at end $B$.





Prob. 12–47

***12–48.** The beam is subjected to the load shown. Determine the slopes at $A$ and $B$ and the displacement at $C$. $EI$ is constant.





Prob. 12–48

**•12–49.** Determine the equation of the elastic curve of the simply supported beam and then find the maximum deflection. The beam is made of wood having a modulus of elasticity $E = 1.5(10^3)$ ksi.





Prob. 12–49

**12–50.** The beam is subjected to the load shown. Determine the equations of the slope and elastic curve. $EI$ is constant.





Prob. 12–50

**12–51.** The beam is subjected to the load shown. Determine the equation of the elastic curve. $EI$ is constant.





Prob. 12–51

***12–52.** The wooden beam is subjected to the load shown. Determine the equation of the elastic curve. Specify the deflection at the end $C$. $E_w = 1.6(10^3)$ ksi.





Prob. 12–52

**12–53.** Determine the displacement at $C$ and the slope at $A$ of the beam.




Prob. 12–53


**12–54.** The beam is subjected to the load shown. Determine the equation of the elastic curve. $EI$ is constant.




Prob. 12–54

12


## *12.4 Slope and Displacement by the Moment-Area Method








(a)




(b)




M/EI Diagram

(c)

Fig. 12–20

The moment-area method provides a semigraphical technique for finding the slope and displacement at specific points on the elastic curve of a beam or shaft. Application of the method requires calculating areas associated with the beam's moment diagram; and so if this diagram consists of simple shapes, the method is very convenient to use. Normally this is the case when the beam is loaded with concentrated forces and couple moments.

To develop the moment-area method we will make the same assumptions we used for the method of integration: The beam is initially straight, it is elastically deformed by the loads, such that the slope and deflection of the elastic curve are very small, and the deformations are only caused by bending. The moment-area method is based on two theorems, one used to determine the slope and the other to determine the displacement at a point on the elastic curve.

**Theorem 1.** Consider the simply supported beam with its associated elastic curve, shown in Fig. 12–20*a*. A differential segment $dx$ of the beam is isolated in Fig. 12–20*b*. Here the beam's internal moment $M$ deforms the element such that the *tangents* to the elastic curve at each side of the element intersect at an angle $d\theta$. This angle can be determined from Eq. 12–10, written as

$$EI\frac{d^2v}{dx^2} = EI\frac{d}{dx}\left(\frac{dv}{dx}\right) = M$$

Since the *slope* is *small*, $\theta = dv/dx$, and therefore

$$d\theta = \frac{M}{EI}dx \tag{12–16}$$

If the moment diagram for the beam is constructed and divided by the flexural rigidity, $EI$, Fig. 12–20*c*, then this equation indicates that $d\theta$ is equal to the *area* under the "$M/EI$ diagram" for the beam segment $dx$. Integrating from a selected point $A$ on the elastic curve to another point $B$, we have

$$\theta_{B/A} = \int_A^B \frac{M}{EI}dx \tag{12–17}$$


This equation forms the basis for the first moment-area theorem.

**Theorem 1:** *The angle between the tangents at any two points on the elastic curve equals the area under the $M/EI$ diagram between these two points.*

The notation $\theta_{B/A}$ is referred to as the angle of the tangent at $B$ measured *with respect to* the tangent at $A$. From the proof it should be evident that this angle is measured *counterclockwise*, from tangent $A$ to tangent $B$, if the area under the $M/EI$ diagram is *positive*. Conversely, if the area is

*negative*, or lies below the $x$ axis, the angle $\theta_{B/A}$ is measured clockwise from tangent $A$ to tangent $B$. Furthermore, from the dimensions of Eq. 12–17, $\theta_{B/A}$ will be in *radians*.


**Theorem 2.** The second moment-area theorem is based on the relative deviation of tangents to the elastic curve. Shown in Fig. 12–21*a* is a greatly exaggerated view of the vertical deviation $dt$ of the tangents on each side of the differential element $dx$. This deviation is caused by the curvature of the element and has been measured along a vertical line passing through point $A$ on the elastic curve. Since the slope of the elastic curve and its deflection are assumed to be very small, it is satisfactory to approximate the length of each tangent line by $x$ and the arc $ds'$ by $dt$. Using the circular-arc formula $s = \theta r$, where $r$ is the length $x$ and $s$ is $dt$, we can write $dt = x\,d\theta$. Substituting Eq. 12–16 into this equation and integrating from $A$ to $B$, the vertical deviation of the tangent at $A$ *with respect to* the tangent at $B$ can then be determined; that is,




(a)

$$t_{A/B} = \int_A^B x\frac{M}{EI}dx \tag{12–18}$$

Since the centroid of an area is found from $\bar{x}\int dA = \int x\,dA$, and $\int (M/EI)\,dx$ represents the area under the $M/EI$ diagram, we can also write




(b)


$$t_{A/B} = \bar{x}\int_A^B \frac{M}{EI}dx \tag{12–19}$$

Here $\bar{x}$ is the distance from $A$ to the *centroid* of the area under the $M/EI$ diagram between $A$ and $B$, Fig. 12–21*b*.

The second moment-area theorem can now be stated in reference to Fig. 12–21*a* as follows:




**Theorem 2:** *The vertical distance between the tangent at a point (A) on the elastic curve and the tangent extended from another point (B) equals the moment of the area under the M/EI diagram between these two points (A and B). This moment is calculated about the point (A) where the vertical distance ($t_{A/B}$) is to be determined.*




(c)

Fig. 12–21

Note that $t_{A/B}$ is *not* equal to $t_{B/A}$, which is shown in Fig. 12–21*c*. Specifically, the moment of the area under the $M/EI$ diagram between $A$ and $B$ is calculated about point $A$ to determine $t_{A/B}$, Fig. 12–21*b*, and it is calculated about point $B$ to determine $t_{B/A}$, Fig. 12–21*c*.

If the moment of a *positive* $M/EI$ area between $A$ and $B$ is found for $t_{A/B}$, it indicates that point $A$ is *above* the tangent extended from point $B$, Fig. 12–21*a*. Similarly, *negative* $M/EI$ areas indicate that point $A$ is *below* the tangent extended from point $B$. This same rule applies for $t_{B/A}$.

12

## Procedure for Analysis

The following procedure provides a method that may be used to apply the two moment-area theorems.

### *M/EI* Diagram.

- Determine the support reactions and draw the beam's $M/EI$ diagram. If the beam is loaded with concentrated forces, the $M/EI$ diagram will consist of a series of straight line segments, and the areas and their moments required for the moment-area theorems will be relatively easy to calculate. If the loading consists of a series of distributed loads, the $M/EI$ diagram will consist of parabolic or perhaps higher-order curves, and it is suggested that the table on the inside front cover be used to locate the area and centroid under each curve.

### Elastic Curve.

- Draw an exaggerated view of the beam's elastic curve. Recall that points of zero slope and zero displacement always occur at a fixed support, and zero displacement occurs at all pin and roller supports.
- If it becomes difficult to draw the general shape of the elastic curve, use the moment (or $M/EI$) diagram. Realize that when the beam is subjected to a *positive moment*, the beam bends *concave up*, whereas *negative moment* bends the beam *concave down*. Furthermore, an inflection point or change in curvature occurs where the moment in the beam (or $M/EI$) is zero.
- The unknown displacement and slope to be determined should be indicated on the curve.
- Since the moment-area theorems apply *only between two tangents*, attention should be given as to which tangents should be constructed so that the angles or vertical distance between them will lead to the solution of the problem. In this regard, *the tangents at the supports should be considered*, since the beam has zero displacement and/or zero slope at the supports.

### Moment-Area Theorems.

- Apply Theorem 1 to determine the *angle* between any two tangents on the elastic curve and Theorem 2 to determine the vertical distance between the tangents.
- The algebraic sign of the answer can be checked from the angle or vertical distance indicated on the elastic curve.
- A *positive* $\theta_{B/A}$ represents a *counterclockwise* rotation of the tangent at $B$ with respect to the tangent at $A$, and a *positive* $t_{B/A}$ indicates that point $B$ on the elastic curve lies *above* the extended tangent from point $A$.