
Tech Team · Kintek Furnace
Updated 3 weeks ago

What Is Step Coverage In PECVD, And Why Is It Important? Ensure Uniform Thin-Film Deposition For Reliability

In thin-film deposition, step coverage is a critical metric that defines how uniformly a deposited film conforms to the underlying topography of a substrate. For Plasma-Enhanced Chemical Vapor Deposition (PECVD), it measures the film's ability to maintain its thickness over sharp steps, deep trenches, and other complex, three-dimensional features. This quality is not merely a geometric curiosity; it is a fundamental requirement for the function and reliability of modern microelectronic devices.

> “The core challenge of step coverage is overcoming geometric "shadowing." Think of it as the difference between spray painting a complex object from one direction versus submerging it in a vat of paint. PECVD aims for the latter, ensuring every nook and cranny receives a uniform coating, which is essential for preventing electrical failures and structural weaknesses in microscopic circuits.”

Marlin Semiconductor Ltd., Exhibit No. 2004
Case No. IPR2025-01265
Page 1 of 16



The Mechanics of Step Coverage in PECVD

To understand why step coverage is so crucial, we must first examine how it is achieved and what factors influence it. It's a delicate balance between the directionality of depositing species and their ability to move once they land on the surface.

What Defines "Good" vs. "Poor" Step Coverage?

The quality of step coverage is typically described by its **conformality**. A perfectly conformal film has 100% step coverage, meaning its thickness is identical on the top, bottom, and sidewalls of a feature.

Poor step coverage is non-conformal. This often results in a film that is thick on top surfaces, thinner on the sidewalls, and thinnest (or absent) at the bottom corners of a trench. In extreme cases, this can lead to voids or "keyholes" as the top of the feature closes off before the bottom is fully filled.

The Role of Plasma in Aiding Deposition

Unlike purely thermal processes, PECVD uses a plasma to create reactive chemical species at lower temperatures. This has a mixed effect on step coverage.

Marlin Semiconductor Ltd., Exhibit No. 2004
Case No. IPR2025-01265
Page 2 of 16

The plasma creates a higher concentration of reactive radicals, which can improve deposition in shadowed regions. However, it also creates an electric field that can accelerate ions toward the substrate, leading to a more directional, line-of-sight deposition that can worsen shadowing effects. The key is to balance these competing mechanisms.

Key Influencing Factors

Achieving good step coverage requires precise control over several process parameters.

Pressure: Higher process pressure increases gas-phase collisions, making the arrival of film precursors more random and less directional. This scattering effect significantly improves the film's ability to coat sidewalls.

Temperature: Increasing the substrate temperature enhances the **surface mobility** of deposited atoms (adatoms). This allows them to "flow" across the surface after landing, migrating from high-concentration areas (like top corners) into low-concentration areas (like the bottom of a trench), evening out the film thickness.

Precursor Gas Chemistry: The choice of precursor gas is vital. Molecules with a longer lifetime and lower sticking coefficient (the probability of sticking upon collision) are more likely to bounce around within a feature before reacting, leading to better conformality.

Plasma Power and Frequency: Lowering RF power can reduce ion bombardment and its associated directionality, improving coverage. The frequency of the plasma (low vs. high) also changes the ion energy distribution, providing another lever for process optimization.

Why Poor Step Coverage Is a Critical Failure Mode

In semiconductor manufacturing, a seemingly small defect in step coverage can have catastrophic consequences for the entire device.

Ensuring Electrical Isolation

Marlin Semiconductor Ltd., Exhibit No. 2004
Case No. IPR2025-01265
Page 3 of 16

Dielectric films, such as silicon dioxide (SiO_2), are used to insulate conductive layers. If the step coverage is poor, the film will be dangerously thin at the corners of metal lines. This creates weak spots that can lead to **current leakage** or a complete **electrical short**, rendering the circuit useless.

Maintaining Device Performance

Modern transistors, like FinFETs, have complex 3D architectures. The gate dielectric must wrap around the transistor's "fin" with perfect uniformity. Any thinning of this critical layer due to poor step coverage will alter the transistor's electrical properties, leading to unpredictable performance and premature device failure.

Preventing Structural Voids

As non-conformal films build up, the top corners of a trench grow faster than the bottom. This can cause the top of the trench to pinch off, sealing a **void or keyhole** inside the film. These voids are structural weak points that can trap contaminants and compromise the mechanical integrity of the device.

Understanding the Trade-offs

Optimizing for perfect step coverage does not come without costs. Engineers must balance conformality against other critical manufacturing metrics.

Deposition Rate vs. Conformality

The process conditions that favor excellent step coverage—such as high pressure and low power—often result in a **slower deposition rate**. In high-volume manufacturing, this trade-off directly impacts throughput and cost. A balance must be struck that meets the device's minimum reliability requirements while maximizing production speed.

Film Quality vs. Coverage

Altering temperature and plasma conditions to improve surface mobility can also change the film's intrinsic properties, such as its density, chemical composition, and mechanical stress. An aggressive process designed solely for coverage might produce a film that is too stressed, leading to cracking or delamination later on.

Marlin Semiconductor Ltd., Exhibit No. 2004
Case No. IPR2025-01265
Page 4 of 16

PECVD vs. Alternative Methods

While PECVD is a versatile workhorse, it has its limits. For the most demanding, highest-aspect-ratio features in advanced logic and memory chips, other methods are often required. **Atomic Layer Deposition (ALD)**, for example, offers nearly perfect 100% step coverage by its very nature, but at a significantly lower deposition rate than PECVD.

Making the Right Choice for Your Goal

Your approach to step coverage should be dictated by the specific requirements of your application.

- **If your primary focus is rapid coating of simple, planar surfaces:** You can prioritize a high deposition rate, as step coverage is not a significant concern.
- **If your primary focus is insulating features with moderate aspect ratios (e.g., 2:1):** A well-optimized PECVD process balancing pressure, temperature, and rate will be your most effective solution.
- **If your primary focus is flawless conformality in high-aspect-ratio trenches (e.g., >10:1):** You must prioritize conditions that enhance surface mobility and reduce directionality, even at the cost of throughput, and may need to evaluate ALD as a necessary alternative.

Mastering the principles of step coverage is fundamental to fabricating reliable, high-performance microstructures.

Summary Table:

ASPECT	DESCRIPTION
Definition	Uniformity of film thickness over substrate topography, such as steps and trenches.
Importance	Prevents electrical shorts, ensures device reliability, and maintains structural integrity in microelectronics.

Marlin Semiconductor Ltd., Exhibit No. 2004
Case No. IPR2025-01265
Page 5 of 16

ASPECT	DESCRIPTION
Key Factors	Pressure, temperature, precursor gas chemistry, plasma power, and frequency influence step coverage.
Trade-offs	Balance between deposition rate, film quality, and conformality; PECVD vs. ALD for high-aspect-ratio features.

Optimize your thin-film deposition with KINTEK's advanced solutions! Leveraging exceptional R&D and in-house manufacturing, we provide diverse laboratories with high-temperature furnace systems like Muffle, Tube, Rotary Furnaces, Vacuum & Atmosphere Furnaces, and CVD/PECVD Systems. Our strong deep customization capability ensures precise alignment with your unique experimental needs, enhancing step coverage and overall process reliability. Contact us today to discuss how we can support your microelectronics fabrication goals!


Visual Guide

Marlin Semiconductor Ltd., Exhibit No. 2004
Case No. IPR2025-01265
Page 6 of 16

KINTEK

Step Coverage in PECVD: Definition, Importance, and Optimization

What is Step Coverage?




Poor Step Coverage (Non-conformal)

Good Step Coverage (Conformal)


Why Is It Important? (Failure Modes)



Electrical Shorts
Thin corners lead to leakage.



Device Performance
Alterations affect transistor function.



Structural Voids
Weak points, trapped contaminants.

Key Influencing Factors (The Mechanics)



PRESSURE (Higher)
Increases scattering, improves sidewall coating.



TEMPERATURE (Higher)
Enhances adatom surface mobility for even flow.



PRECURSOR CHEMISTRY
Lower sticking coefficient allows deeper penetration.




PLASMA POWER (Lower)
Reduces directional ion bombardment.

Understanding the Trade-offs

Deposition Rate & Throughput (Speed)





Conformality & Film Quality (Reliability)

Marlin Semiconductor Ltd., Exhibit No. 2004
Case No. IPR2025-01265
Page 7 of 16



Related Products

Slide PECVD Tube Furnace with Liquid Gasifier PECVD Machine

Inclined Rotary Plasma Enhanced Chemical Deposition PECVD Tube Furnace Machine

Multi Heating Zones CVD Tube Furnace Machine for Chemical Vapor Deposition Equipment

Custom Made Versatile CVD Tube Furnace Chemical Vapor Deposition CVD Equipment Machine

Split Chamber CVD Tube Furnace with Vacuum Station CVD Machine

People Also Ask

What are the drawbacks of CVD compared to PECVD? Key Limitations for Your Lab

What are the advantages of using CVD? Achieve High-Purity, Conformal Thin Films for Your Applications

How does PECVD contribute to semiconductor manufacturing? Enable Low-Temperature, High-Quality Film Deposition

What are the classifications of CVD based on vapor characteristics? Optimize Your Thin Film Deposition Process

What is resistance heating and how is it classified? Discover the Best Method for Your Thermal Needs

Marlin Semiconductor Ltd., Exhibit No. 2004
Case No. IPR2025-01265
Page 8 of 16

RELATED PRODUCTS



Slide PECVD Tube Furnace With Liquid Gasifier PECVD Machine

KINTEK Slide PECVD Tube Furnace: Precision thin film deposition with RF plasma, rapid...



Inclined Rotary Plasma Enhanced Chemical Deposition PECVD Tube Furnace...

Advanced PECVD Tube Furnace for precise thin film deposition. Uniform heating, RF...



Multi Heating Zones CVD Tube Furnace Machine For Chemical Vapor Deposition...



Custom Made Versatile CVD Tube Furnace Chemical Vapor Deposition CVD...

Marlin Semiconductor Ltd., Exhibit No. 2004
Case No. IPR2025-01265
Page 9 of 16

KINTEK's Multi-Zone CVD Tube Furnaces offer precision temperature control for...

KINTEK's CVD Tube Furnace offers precision temperature control up to 1600°C, ideal fo...



Split Chamber CVD Tube Furnace With Vacuum Station CVD Machine

Split Chamber CVD Tube Furnace with Vacuum Station - High precision 1200°C la...



1400°C High Temperature Laboratory Tube Furnace With Quartz And Alumina Tube

KINTEK's Tube Furnace with Alumina Tube: Precision high-temperature processing u...



1700°C High Temperature Laboratory Tube Furnace With Quartz Or Alumina Tube



Vertical Laboratory Quartz Tube Furnace Tubular Furnace

Marlin Semiconductor Ltd., Exhibit No. 2004
Case No. IPR2025-01265
Page 10 of 16

KINTEK's Tube Furnace with Alumina Tube: Precision heating up to 1700°C for material...

Precision KINTEK Vertical Tube Furnace: 1800°C heating, PID control, customizable...



Multi Zone Laboratory Quartz Tube Furnace Tubular Furnace

KINTEK Multi-Zone Tube Furnace: Precise 1700°C heating with 1-10 zones for...



600T Vacuum Induction Hot Press Vacuum Heat Treat And Sintering Furnace

600T Vacuum Induction Hot Press Furnace for precise sintering. Advanced 600T...



High Temperature Muffle Oven Furnace For Laboratory Debinding And Pre Sintering



Molybdenum Vacuum Heat Treat Furnace

Marlin Semiconductor Ltd., Exhibit No. 2004
Case No. IPR2025-01265
Page 11 of 16

KT-MD Debinding & Pre-Sintering Furnace for ceramics - precise temperature contr...

High-performance molybdenum vacuum furnace for precise 1400°C heat treatment...



1400°C Controlled Inert Nitrogen Atmosphere Furnace

KT-14A Controlled Atmosphere Furnace for labs & industry. 1400°C max temp, vacuu...



High Pressure Laboratory Vacuum Tube Furnace Quartz Tubular Furnace

KINTEK High Pressure Tube Furnace: Precision heating up to 1100°C with 15Mpa...



Controlled Inert Nitrogen Hydrogen Atmosphere Furnace



Small Vacuum Heat Treat And Tungsten Wire Sintering Furnace

Marlin Semiconductor Ltd., Exhibit No. 2004
Case No. IPR2025-01265
Page 12 of 16

Discover KINTEK's Hydrogen Atmosphere Furnace for precise sintering & annealing i...

Compact vacuum tungsten wire sintering furnace for labs. Precise, mobile design...



Laboratory Quartz Tube Furnace RTP Heating Tubular Furnace

KINTEK's RTP Rapid Heating Tube Furnace delivers precise temperature control, rapi...



Vacuum Heat Treat Furnace With Ceramic Fiber Liner

KINTEK's Vacuum Furnace with Ceramic Fiber Lining offers precise high-...



1200°C Controlled Inert Nitrogen Atmosphere Furnace



Vacuum Heat Treat Sintering Furnace With Pressure For Vacuum Sintering

Marlin Semiconductor Ltd., Exhibit No. 2004
Case No. IPR2025-01265
Page 13 of 16

KINTEK 1200°C Controlled Atmosphere Furnace: Precision heating with gas contro...

KINTEK's Vacuum Pressure Sintering Furnace offers 2100°C precision for...

Leave Your Message

First name *

First name*

Last name *

Last name*

Your country

Your country

Phone / WhatsApp

Your phone / WhatsApp

Email address

Your email

Your message *

Your message...

SUBMIT

HOT TAGS

Marlin Semiconductor Ltd., Exhibit No. 2004
Case No. IPR2025-01265
Page 14 of 16

tube furnace | multi zone tube furnace | cvd machine | split tube furnace | vertical tube furnace | rotary tube furnace | pecvd machine | rotary furnace | rotating furnace | mpcvd machine | vacuum induction furnace | vaccum furnace | atmosphere furnace | hot press furnace | vacuum hot press | dental furnace | horizontal vacuum furnace | muffle furnace

Search FAQs by keywords SEARCH

KINTEK
Solution for researching

Email: info@kindle-tech.com
Head Quarter: No.89 Science Avenue, High-Tech Zone, Zhengzhou, China

COMPANY

About Kintek Furnace
Customer Testimonials
International Presence
Certificates & Awards
Human Resource
Blog
Contact Kintek Furnace

PRODUCTS

High Temperature Furnaces

QUICK LINKS

Marlin Semiconductor Ltd., Exhibit No. 2004
Case No. IPR2025-01265
Page 15 of 16

Knowledge

Faq

Thematics

Privacy Policy

Terms & Conditions

Copyright© 2002-2026 Kintek Furnace, | All Rights Reserved.

Marlin Semiconductor Ltd., Exhibit No. 2004
Case No. IPR2025-01265
Page 16 of 16