



Standard Features

				
Fill augers are available for both seedcart and empty the seed hopper when changing seed varieties.	Soil deflectors deflect soil from the seedcart and empty the seed hopper ensuring seed coverage.	Row markers are available for the front row (discs). The front row markers attach to welded on toolbar mountings and feature breakaway protectors for protection from obstructions are encountered.	Row markers are available for the front row (discs). The front row markers attach to welded on toolbar mountings and feature breakaway protectors for protection from obstructions are encountered.	Row markers are available for the front row (discs). The front row markers attach to welded on toolbar mountings and feature breakaway protectors for protection from obstructions are encountered.

Optional Features

				
When no till conditions demand, concrete balles blocks and sulcase weight brackets ensure proper penetration of row units.	Mechanical Drive Wheel Lift automatically disengages seed flow when toolbar is raised, both when in use and rows and when in transport.	Seed Hopper Agitator may be required if inoculant or other seed additives cause seed to bridge.	Seed Hopper Agitator may be required if inoculant or other seed additives cause seed to bridge.	Seed Hopper Agitator may be required if inoculant or other seed additives cause seed to bridge.

Standard features and options subject to change without notice by Hiniker Company.