# ETSI TS 125 331 V7.0.0 (2006-03)

*Technical Specification*

## Universal Mobile Telecommunications System (UMTS); Radio Resource Control (RRC) protocol specification (3GPP TS 25.331 version 7.0.0 Release 7)



Reference
RTS/TSGR-0225331v700

Keywords
UMTS

***ETSI***

650 Route des Lucioles
F-06921 Sophia Antipolis Cedex - FRANCE

Tel.: +33 4 92 94 42 00 Fax: +33 4 93 65 47 16

Siret N° 348 623 562 00017 - NAF 742 C
Association à but non lucratif enregistrée à la
Sous-Préfecture de Grasse (06) N° 7803/88

***Important notice***

Individual copies of the present document can be downloaded from:
http://www.etsi.org

The present document may be made available in more than one electronic version or in print. In any case of existing or perceived difference in contents between such versions, the reference version is the Portable Document Format (PDF). In case of dispute, the reference shall be the printing on ETSI printers of the PDF version kept on a specific network drive within ETSI Secretariat.

Users of the present document should be aware that the document may be subject to revision or change of status. Information on the current status of this and other ETSI documents is available at
http://portal.etsi.org/tb/status/status.asp

If you find errors in the present document, please send your comment to one of the following services:
http://portal.etsi.org/chaircor/ETSI_support.asp

***Copyright Notification***

No part may be reproduced except as authorized by written permission.
The copyright and the foregoing restriction extend to reproduction in all media.

© European Telecommunications Standards Institute 2006.
All rights reserved.

**DECT**™, **PLUGTESTS**™ and **UMTS**™ are Trade Marks of ETSI registered for the benefit of its Members.
**TIPHON**™ and the **TIPHON logo** are Trade Marks currently being registered by ETSI for the benefit of its Members.
**3GPP**™ is a Trade Mark of ETSI registered for the benefit of its Members and of the 3GPP Organizational Partners.

# Intellectual Property Rights

IPRs essential or potentially essential to the present document may have been declared to ETSI. The information pertaining to these essential IPRs, if any, is publicly available for **ETSI members and non-members**, and can be found in ETSI SR 000 314: *"Intellectual Property Rights (IPRs); Essential, or potentially Essential, IPRs notified to ETSI in respect of ETSI standards"*, which is available from the ETSI Secretariat. Latest updates are available on the ETSI Web server (http://webapp.etsi.org/IPR/home.asp).

Pursuant to the ETSI IPR Policy, no investigation, including IPR searches, has been carried out by ETSI. No guarantee can be given as to the existence of other IPRs not referenced in ETSI SR 000 314 (or the updates on the ETSI Web server) which are, or may be, or may become, essential to the present document.

# Foreword

This Technical Specification (TS) has been produced by ETSI 3rd Generation Partnership Project (3GPP).

The present document may refer to technical specifications or reports using their 3GPP identities, UMTS identities or GSM identities. These should be interpreted as being references to the corresponding ETSI deliverables.

The cross reference between GSM, UMTS, 3GPP and ETSI identities can be found under http://webapp.etsi.org/key/queryform.asp .

# Contents

Intellectual Property Rights ..... 2
Foreword ..... 2
Foreword ..... 29
1 Scope ..... 30
2 References ..... 30
3 Definitions and abbreviations ..... 32
3.1 Definitions ..... 32
3.2 Abbreviations ..... 33
4 General ..... 35
4.1 Overview of the specification ..... 35
4.2 RRC Layer Model ..... 36
4.3 Protocol specification principles ..... 39
5 RRC Functions and Services provided to upper layers ..... 39
5.1 RRC Functions ..... 39
5.2 RRC Services provided to upper layers ..... 40
5.3 Primitives between RRC and upper layers ..... 40
6 Services expected from lower layers ..... 40
6.1 Services expected from Layer 2 ..... 40
6.2 Services expected from Layer 1 ..... 40
6.3 Signalling Radio Bearers ..... 40
7 Protocol states ..... 41
7.1 Overview of RRC States and State Transitions including GSM ..... 41
7.2 Processes in UE modes/states ..... 42
7.2.1 UE Idle mode ..... 42
7.2.2 UTRA RRC Connected mode ..... 42
7.2.2.1 URA_PCH or CELL_PCH state ..... 42
7.2.2.2 CELL_FACH state ..... 43
7.2.2.3 CELL_DCH state ..... 43
8 RRC procedures ..... 44
8.1 RRC Connection Management Procedures ..... 45
8.1.1 Broadcast of system information ..... 45
8.1.1.1 General ..... 45
8.1.1.1.1 System information structure ..... 45
8.1.1.1.2 System information blocks ..... 46
8.1.1.1.3 Segmentation and concatenation of system information blocks ..... 50
8.1.1.1.4 Re-assembly of segments ..... 51
8.1.1.1.5 Scheduling of system information ..... 52
8.1.1.2 Initiation ..... 52
8.1.1.3 Reception of SYSTEM INFORMATION messages by the UE ..... 52
8.1.1.4 Void ..... 53
8.1.1.5 Actions upon reception of the Master Information Block and Scheduling Block(s) ..... 53
8.1.1.6 Actions upon reception of system information blocks ..... 56
8.1.1.6.1 System Information Block type 1 ..... 57
8.1.1.6.2 System Information Block type 2 ..... 58
8.1.1.6.3 System Information Block type 3 ..... 58
8.1.1.6.4 System Information Block type 4 ..... 60
8.1.1.6.5 System Information Block type 5 and 5bis ..... 60
8.1.1.6.6 System Information Block type 6 ..... 62
8.1.1.6.7 System Information Block type 7 ..... 63
8.1.1.6.8 Void ..... 63
8.1.1.6.9 Void ..... 63

8.1.1.6.10 Void ..... 63
8.1.1.6.11 System Information Block type 11 ..... 63
8.1.1.6.12 System Information Block type 12 ..... 64
8.1.1.6.13 System Information Block type 13 ..... 66
8.1.1.6.14 System Information Block type 14 ..... 66
8.1.1.6.15 System Information Block type 15 ..... 66
8.1.1.6.16 System Information Block type 16 ..... 68
8.1.1.6.17 System Information Block type 17 ..... 69
8.1.1.6.18 System Information Block type 18 ..... 69
8.1.1.7 Modification of system information ..... 70
8.1.1.7.1 Modification of system information blocks using a value tag ..... 70
8.1.1.7.2 Synchronised modification of system information blocks ..... 70
8.1.1.7.3 Actions upon system information change ..... 70
8.1.1.7.4 Actions upon expiry of a system information expiry timer ..... 71
8.1.2 Paging ..... 71
8.1.2.1 General ..... 71
8.1.2.2 Initiation ..... 72
8.1.2.3 Reception of a PAGING TYPE 1 message by the UE ..... 72
8.1.3 RRC connection establishment ..... 74
8.1.3.1 General ..... 74
8.1.3.2 Initiation ..... 74
8.1.3.3 RRC CONNECTION REQUEST message contents to set ..... 75
8.1.3.4 Reception of an RRC CONNECTION REQUEST message by the UTRAN ..... 75
8.1.3.5 Cell re-selection, T300 or T318 timeout ..... 76
8.1.3.5a Abortion of RRC connection establishment ..... 77
8.1.3.6 Reception of an RRC CONNECTION SETUP message by the UE ..... 77
8.1.3.7 Physical channel failure or cell re-selection ..... 79
8.1.3.8 Invalid RRC CONNECTION SETUP message, unsupported configuration or invalid configuration ..... 80
8.1.3.9 Reception of an RRC CONNECTION REJECT message by the UE ..... 81
8.1.3.10 Invalid RRC CONNECTION REJECT message ..... 83
8.1.4 RRC connection release ..... 84
8.1.4.1 General ..... 84
8.1.4.2 Initiation ..... 84
8.1.4.3 Reception of an RRC CONNECTION RELEASE message by the UE ..... 84
8.1.4.4 Invalid RRC CONNECTION RELEASE message ..... 86
8.1.4.5 Cell re-selection or radio link failure ..... 86
8.1.4.6 Expiry of timer T308, unacknowledged mode transmission ..... 87
8.1.4.7 Void ..... 87
8.1.4.8 Reception of an RRC CONNECTION RELEASE COMPLETE message by UTRAN ..... 88
8.1.4.9 Unsuccessful transmission of the RRC CONNECTION RELEASE COMPLETE message, acknowledged mode transmission ..... 88
8.1.4.10 Detection of loss of dedicated physical channel by UTRAN in CELL_DCH state ..... 88
8.1.4.11 Failure to receive RRC CONNECTION RELEASE COMPLETE message by UTRAN ..... 88
8.1.4a RRC connection release requested by upper layers ..... 88
8.1.4a.1 General ..... 88
8.1.4a.2 Initiation ..... 88
8.1.5 Void ..... 89
8.1.6 Transmission of UE capability information ..... 89
8.1.6.1 General ..... 89
8.1.6.2 Initiation ..... 89
8.1.6.3 Reception of a UE CAPABILITY INFORMATION message by the UTRAN ..... 90
8.1.6.4 Reception of the UE CAPABILITY INFORMATION CONFIRM message by the UE ..... 90
8.1.6.5 Invalid UE CAPABILITY INFORMATION CONFIRM message ..... 90
8.1.6.6 T304 timeout ..... 91
8.1.7 UE capability enquiry ..... 91
8.1.7.1 General ..... 91
8.1.7.2 Initiation ..... 91
8.1.7.3 Reception of a UE CAPABILITY ENQUIRY message by the UE ..... 92
8.1.7.4 Invalid UE CAPABILITY ENQUIRY message ..... 92
8.1.8 Initial Direct transfer ..... 92
8.1.8.1 General ..... 92

8.1.8.2 Initiation of Initial direct transfer procedure in the UE ..... 92
8.1.8.2a RLC re-establishment or inter-RAT change ..... 94
8.1.8.2ab Inter-RAT handover from UTRAN to GERAN *Iu mode* ..... 94
8.1.8.2b Abortion of signalling connection establishment ..... 95
8.1.8.3 Reception of INITIAL DIRECT TRANSFER message by the UTRAN ..... 95
8.1.9 Downlink Direct transfer ..... 95
8.1.9.1 General ..... 95
8.1.9.2 Initiation of downlink direct transfer procedure in the UTRAN ..... 95
8.1.9.3 Reception of a DOWNLINK DIRECT TRANSFER message by the UE ..... 96
8.1.9.3a No signalling connection exists ..... 96
8.1.9.4 Invalid DOWNLINK DIRECT TRANSFER message ..... 96
8.1.10 Uplink Direct transfer ..... 97
8.1.10.1 General ..... 97
8.1.10.2 Initiation of uplink direct transfer procedure in the UE ..... 97
8.1.10.2a RLC re-establishment or inter-RAT change ..... 98
8.1.10.2b Inter-RAT handover from UTRAN to GERAN *Iu mode* ..... 98
8.1.10.3 Reception of UPLINK DIRECT TRANSFER message by the UTRAN ..... 98
8.1.11 UE dedicated paging ..... 98
8.1.11.1 General ..... 98
8.1.11.2 Initiation ..... 98
8.1.11.3 Reception of a PAGING TYPE 2 message by the UE ..... 99
8.1.11.4 Invalid PAGING TYPE 2 message ..... 99
8.1.12 Security mode control ..... 99
8.1.12.1 General ..... 100
8.1.12.2 Initiation ..... 100
8.1.12.2.1 Ciphering configuration change ..... 100
8.1.12.2.2 Integrity protection configuration change ..... 101
8.1.12.3 Reception of SECURITY MODE COMMAND message by the UE ..... 103
8.1.12.3.1 New ciphering and integrity protection keys ..... 107
8.1.12.4 Void ..... 108
8.1.12.4a Incompatible simultaneous security reconfiguration ..... 108
8.1.12.4b Cell update procedure during security reconfiguration ..... 109
8.1.12.4c Invalid configuration ..... 110
8.1.12.5 Reception of SECURITY MODE COMPLETE message by the UTRAN ..... 110
8.1.12.6 Invalid SECURITY MODE COMMAND message ..... 112
8.1.13 Signalling connection release procedure ..... 113
8.1.13.1 General ..... 113
8.1.13.2 Initiation of SIGNALLING CONNECTION RELEASE by the UTRAN ..... 113
8.1.13.3 Reception of SIGNALLING CONNECTION RELEASE by the UE ..... 113
8.1.13.4 Invalid SIGNALLING CONNECTION RELEASE message ..... 113
8.1.13.5 Invalid configuration ..... 114
8.1.14 Signalling connection release indication procedure ..... 114
8.1.14.1 General ..... 114
8.1.14.2 Initiation ..... 114
8.1.14.2a RLC re-establishment or inter-RAT change ..... 115
8.1.14.3 Reception of SIGNALLING CONNECTION RELEASE INDICATION by the UTRAN ..... 115
8.1.15 Counter check procedure ..... 115
8.1.15.1 General ..... 115
8.1.15.2 Initiation ..... 116
8.1.15.3 Reception of a COUNTER CHECK message by the UE ..... 116
8.1.15.4 Reception of the COUNTER CHECK RESPONSE message by UTRAN ..... 117
8.1.15.5 Cell re-selection ..... 117
8.1.15.6 Invalid COUNTER CHECK message ..... 117
8.1.16 Inter RAT handover information transfer ..... 117
8.1.16.1 General ..... 117
8.1.16.2 Initiation ..... 117
8.1.16.3 INTER RAT HANDOVER INFO message contents to set ..... 118
8.2 Radio Bearer control procedures ..... 119
8.2.1 Radio bearer establishment ..... 119
8.2.2 Reconfiguration procedures ..... 119
8.2.2.1 General ..... 121
8.2.2.2 Initiation ..... 122

8.2.2.2a Initiation of handover from GERAN *Iu mode* ..... 123
8.2.2.3 Reception of RADIO BEARER SETUP or RADIO BEARER RECONFIGURATION or RADIO BEARER RELEASE or TRANSPORT CHANNEL RECONFIGURATION or PHYSICAL CHANNEL RECONFIGURATION message by the UE ..... 124
8.2.2.3a Reception of RADIO BEARER RECONFIGURATION message by the UE performing handover from GERAN *Iu mode* ..... 133
8.2.2.4 Transmission of a response message by the UE, normal case ..... 134
8.2.2.5 Reception of a response message by the UTRAN, normal case ..... 136
8.2.2.5a Rejection by the UE ..... 137
8.2.2.6 Unsupported configuration in the UE ..... 138
8.2.2.7 Physical channel failure ..... 138
8.2.2.8 Cell re-selection ..... 139
8.2.2.9 Transmission of a response message by the UE, failure case ..... 139
8.2.2.10 Reception of a response message by the UTRAN, failure case ..... 140
8.2.2.11 Invalid configuration ..... 140
8.2.2.12 Incompatible simultaneous reconfiguration ..... 141
8.2.2.12a Incompatible simultaneous security reconfiguration ..... 141
8.2.2.12b Cell update procedure during security reconfiguration ..... 141
8.2.2.13 Invalid received message ..... 142
8.2.2.14 Radio link failure ..... 142
8.2.3 Radio bearer release ..... 143
8.2.4 Transport channel reconfiguration ..... 144
8.2.5 Transport format combination control ..... 144
8.2.5.1 General ..... 144
8.2.5.2 Initiation ..... 144
8.2.5.3 Reception of a TRANSPORT FORMAT COMBINATION CONTROL message by the UE ..... 144
8.2.5.4 Invalid configuration ..... 146
8.2.5.5 Invalid TRANSPORT FORMAT COMBINATION CONTROL message ..... 146
8.2.6 Physical channel reconfiguration ..... 147
8.2.7 Physical Shared Channel Allocation [TDD only] ..... 147
8.2.7.1 General ..... 147
8.2.7.2 Initiation ..... 147
8.2.7.3 Reception of a PHYSICAL SHARED CHANNEL ALLOCATION message by the UE ..... 147
8.2.7.4 Invalid PHYSICAL SHARED CHANNEL ALLOCATION message ..... 149
8.2.8 PUSCH capacity request [TDD only] ..... 150
8.2.8.1 General ..... 150
8.2.8.2 Initiation ..... 150
8.2.8.3 PUSCH CAPACITY REQUEST message contents to set ..... 151
8.2.8.4 Reception of a PUSCH CAPACITY REQUEST message by the UTRAN ..... 152
8.2.8.5 T310 expiry ..... 152
8.2.9 Void ..... 152
8.2.10 Uplink Physical Channel Control [TDD only] ..... 152
8.2.10.1 General ..... 152
8.2.10.2 Initiation ..... 152
8.2.10.3 Reception of UPLINK PHYSICAL CHANNEL CONTROL message by the UE ..... 153
8.2.10.4 Invalid UPLINK PHYSICAL CHANNEL CONTROL message ..... 153
8.2.11 Physical channel reconfiguration failure ..... 154
8.2.11.1 General ..... 154
8.2.11.2 Runtime error due to overlapping compressed mode configurations ..... 154
8.2.11.3 Void ..... 154
8.3 RRC connection mobility procedures ..... 155
8.3.1 Cell and URA update procedures ..... 155
8.3.1.1 General ..... 157
8.3.1.2 Initiation ..... 158
8.3.1.3 CELL UPDATE / URA UPDATE message contents to set ..... 162
8.3.1.4 T305 expiry and the UE detects "out of service area" ..... 164
8.3.1.4.1 Re-entering "in service area" ..... 164
8.3.1.4.2 Expiry of timer T307 ..... 165
8.3.1.5 Reception of an CELL UPDATE/URA UPDATE message by the UTRAN ..... 165
8.3.1.6 Reception of the CELL UPDATE CONFIRM/URA UPDATE CONFIRM message by the UE ..... 166
8.3.1.7 Transmission of a response message to UTRAN ..... 172
8.3.1.7a Physical channel failure ..... 175

8.3.1.8 Unsupported configuration by the UE ..... 176
8.3.1.9 Invalid configuration ..... 177
8.3.1.9a Incompatible simultaneous reconfiguration ..... 179
8.3.1.9b Security reconfiguration during Cell update procedure ..... 180
8.3.1.10 Confirmation error of URA ID list ..... 180
8.3.1.11 Invalid CELL UPDATE CONFIRM/URA UPDATE CONFIRM message ..... 181
8.3.1.12 T302 expiry or cell reselection ..... 182
8.3.1.13 T314 expiry ..... 184
8.3.1.14 T315 expiry ..... 185
8.3.1.15 Reception of the UTRAN MOBILITY INFORMATION CONFIRM message by the UTRAN ..... 186
8.3.2 URA update ..... 186
8.3.3 UTRAN mobility information ..... 186
8.3.3.1 General ..... 186
8.3.3.2 Initiation ..... 187
8.3.3.3 Reception of UTRAN MOBILITY INFORMATION message by the UE ..... 187
8.3.3.4 Reception of an UTRAN MOBILITY INFORMATION CONFIRM message by the UTRAN ..... 190
8.3.3.5 Cell re-selection ..... 190
8.3.3.5a Incompatible simultaneous security reconfiguration ..... 191
8.3.3.6 Invalid UTRAN MOBILITY INFORMATION message ..... 191
8.3.4 Active set update ..... 191
8.3.4.1 General ..... 192
8.3.4.2 Initiation ..... 192
8.3.4.3 Reception of an ACTIVE SET UPDATE message by the UE ..... 193
8.3.4.4 Unsupported configuration in the UE ..... 194
8.3.4.5 Invalid configuration ..... 195
8.3.4.5a Void ..... 195
8.3.4.5b Incompatible simultaneous reconfiguration ..... 195
8.3.4.6 Reception of the ACTIVE SET UPDATE COMPLETE message by the UTRAN ..... 196
8.3.4.7 Reception of the ACTIVE SET UPDATE FAILURE message by the UTRAN ..... 196
8.3.4.8 Invalid ACTIVE SET UPDATE message ..... 196
8.3.4.9 Reception of an ACTIVE SET UPDATE message in wrong state ..... 196
8.3.5 Hard handover ..... 197
8.3.5.1 Timing re-initialised hard handover ..... 197
8.3.5.1.1 General ..... 197
8.3.5.1.2 Initiation ..... 197
8.3.5.2 Timing-maintained hard handover ..... 198
8.3.5.2.1 General ..... 198
8.3.5.2.2 Initiation ..... 198
8.3.6 Inter-RAT handover to UTRAN ..... 199
8.3.6.1 General ..... 199
8.3.6.2 Initiation ..... 199
8.3.6.3 Reception of HANDOVER TO UTRAN COMMAND message by the UE ..... 200
8.3.6.4 Invalid Handover to UTRAN command message ..... 203
8.3.6.4a Unsupported configuration in HANDOVER TO UTRAN COMMAND message ..... 203
8.3.6.5 UE fails to perform handover ..... 203
8.3.6.6 Reception of message HANDOVER TO UTRAN COMPLETE by the UTRAN ..... 204
8.3.7 Inter-RAT handover from UTRAN ..... 204
8.3.7.1 General ..... 204
8.3.7.2 Initiation ..... 204
8.3.7.3 Reception of a HANDOVER FROM UTRAN COMMAND message by the UE ..... 205
8.3.7.4 Successful completion of the inter-RAT handover ..... 206
8.3.7.5 UE fails to complete requested handover ..... 206
8.3.7.6 Invalid HANDOVER FROM UTRAN COMMAND message ..... 207
8.3.7.7 Reception of an HANDOVER FROM UTRAN FAILURE message by UTRAN ..... 208
8.3.7.8 Unsupported configuration in HANDOVER FROM UTRAN COMMAND message ..... 208
8.3.7.8a Reception of HANDOVER FROM UTRAN COMMAND message by UE in CELL_FACH ..... 208
8.3.8 Inter-RAT cell reselection to UTRAN ..... 209
8.3.8.1 General ..... 209
8.3.8.2 Initiation ..... 209
8.3.8.2a Initiation of inter-RAT cell reselection from GERAN *Iu mode* ..... 209
8.3.8.3 UE fails to complete an inter-RAT cell reselection ..... 210
8.3.8.3a UE fails to complete an inter-RAT cell reselection from GERAN *Iu mode* ..... 210

8.3.9 Inter-RAT cell reselection from UTRAN ..... 210
8.3.9.1 General ..... 210
8.3.9.2 Initiation ..... 210
8.3.9.2a Initiation of inter-RAT cell reselection to GERAN *Iu mode* ..... 211
8.3.9.3 Successful cell reselection ..... 211
8.3.9.4 UE fails to complete an inter-RAT cell reselection ..... 211
8.3.10 Inter-RAT cell change order to UTRAN ..... 211
8.3.10.1 General ..... 211
8.3.10.2 Initiation ..... 211
8.3.10.3 UE fails to complete an inter-RAT cell change order ..... 212
8.3.11 Inter-RAT cell change order from UTRAN ..... 212
8.3.11.1 General ..... 212
8.3.11.2 Initiation ..... 212
8.3.11.3 Reception of an CELL CHANGE ORDER FROM UTRAN message by the UE ..... 212
8.3.11.4 Successful completion of the cell change order ..... 213
8.3.11.5 Expiry of timer T309 or UE fails to complete requested cell change order ..... 214
8.3.11.6 Unsupported configuration in CELL CHANGE ORDER FROM UTRAN message ..... 215
8.3.11.7 Invalid CELL CHANGE ORDER FROM UTRAN message ..... 215
8.4 Measurement procedures ..... 216
8.4.0 Measurement related definitions ..... 216
8.4.1 Measurement control ..... 217
8.4.1.1 General ..... 218
8.4.1.2 Initiation ..... 218
8.4.1.3 Reception of MEASUREMENT CONTROL by the UE ..... 218
8.4.1.4 Unsupported measurement in the UE ..... 224
8.4.1.4a Configuration Incomplete ..... 224
8.4.1.5 Invalid MEASUREMENT CONTROL message ..... 224
8.4.1.6 Measurements after transition from CELL_DCH to CELL_FACH/CELL_PCH/URA_PCH state ..... 225
8.4.1.6.1 Intra-frequency measurement ..... 225
8.4.1.6.2 Inter-frequency measurement ..... 225
8.4.1.6.3 Inter-RAT measurement ..... 226
8.4.1.6.4 Quality measurement ..... 226
8.4.1.6.5 UE internal measurement ..... 226
8.4.1.6.6 Traffic volume measurement ..... 226
8.4.1.6.7 UE positioning measurement ..... 227
8.4.1.6a Actions in CELL_FACH/CELL_PCH/URA/PCH state upon cell re-selection ..... 229
8.4.1.7 Measurements after transition from CELL_FACH to CELL_DCH state ..... 229
8.4.1.7.1 Intra-frequency measurement ..... 229
8.4.1.7.2 Inter-frequency measurement ..... 229
8.4.1.7.3 Inter-RAT measurement ..... 229
8.4.1.7.4 Traffic volume measurement ..... 229
8.4.1.7.5 UE positioning measurement ..... 230
8.4.1.8 Measurements after transition from idle mode to CELL_DCH state ..... 231
8.4.1.8.1 Intra-frequency measurement ..... 231
8.4.1.8.2 Inter-frequency measurement ..... 231
8.4.1.8.3 Inter-RAT measurement ..... 231
8.4.1.8.4 Traffic volume measurement ..... 231
8.4.1.8.5 UE positioning measurement ..... 231
8.4.1.9 Measurements after transition from idle mode to CELL_FACH state ..... 231
8.4.1.9.1 Intra-frequency measurement ..... 232
8.4.1.9.2 Inter-frequency measurement ..... 232
8.4.1.9.3 Inter-RAT measurement ..... 232
8.4.1.9.4 Traffic volume measurement ..... 232
8.4.1.9.5 UE positioning measurement ..... 232
8.4.1.9a Measurements after transition from connected mode to idle mode ..... 232
8.4.1.9a.1 Intra-frequency measurement ..... 233
8.4.1.9a.2 Inter-frequency measurement ..... 233
8.4.1.9a.3 Inter-RAT measurement ..... 233
8.4.1.9a.4 UE positioning measurement ..... 233
8.4.1.9b Measurements after transition from CELL_FACH to CELL_PCH/URA_PCH ..... 233
8.4.1.9b.1 Traffic volume measurement ..... 233
8.4.1.9b.2 UE positioning measurement ..... 233

8.4.1.9c Measurements after transition from CELL_PCH/URA_PCH to CELL_FACH ....234
8.4.1.9c.1 Traffic volume measurement ....234
8.4.1.9c.2 UE positioning measurement ....234
8.4.1.10 Changes in measurement objects ....234
8.4.1.10.1 Traffic volume measurement ....234
8.4.1.10.2 Quality measurement ....235
8.4.1.10.3 Intra-frequency, Inter-frequency and Inter-RAT measurements ....235
8.4.2 Measurement report ....236
8.4.2.1 General ....236
8.4.2.2 Initiation ....236
8.4.3 Assistance Data Delivery ....237
8.4.3.1 General ....237
8.4.3.2 Initiation ....237
8.4.3.3 Reception of ASSISTANCE DATA DELIVERY message by the UE ....238
8.4.3.4 Invalid ASSISTANCE DATA DELIVERY message ....238
8.5 General procedures ....238
8.5.1 Selection of initial UE identity ....238
8.5.2 Actions when entering idle mode from connected mode ....239
8.5.3 Open loop power control upon establishment of DPCCH ....240
8.5.4 Physical channel establishment criteria ....240
8.5.5 Actions in "out of service area" and "in service area" ....240
8.5.5.1 Detection of "out of service" area ....241
8.5.5.1.1 Actions following detection of "out of service" area in URA_PCH or CELL_PCH state ....241
8.5.5.1.2 Actions following detection of "out of service" area in CELL_FACH state ....241
8.5.5.1.3 Actions following detection of "out of service" area on transition from CELL_DCH to URA_PCH or CELL_PCH ....241
8.5.5.1.4 Actions following detection of "out of service" area on transition from CELL_DCH to CELL_FACH ....241
8.5.5.2 Detection of "in service" area ....242
8.5.5.2.1 Actions following Re-entry into "in service area" in URA_PCH or CELL_PCH state ....242
8.5.5.2.2 Actions following re-entry into "in service area" in CELL_FACH state ....242
8.5.5.3 T316 expiry ....242
8.5.5.4 T317 expiry ....242
8.5.6 Radio link failure criteria and actions upon radio link failure ....243
8.5.7 Open loop power control ....243
8.5.8 Maintenance of Hyper Frame Numbers ....247
8.5.9 START value calculation ....248
8.5.10 Integrity protection ....248
8.5.10.1 Integrity protection in downlink ....249
8.5.10.2 Integrity protection in uplink ....250
8.5.10.3 Calculation of message authentication code ....251
8.5.11 FACH measurement occasion calculation ....251
8.5.12 Establishment of Access Service Classes ....252
8.5.13 Mapping of Access Classes to Access Service Classes ....253
8.5.14 PLMN Type Selection ....253
8.5.14a Neighbour cells list narrowing for cell reselection ....253
8.5.15 CFN calculation ....253
8.5.15.1 Initialisation for CELL_DCH state after state transition ....253
8.5.15.2 Initialisation in CELL_DCH state at hard handover ....254
8.5.15.3 Initialisation for CELL_FACH ....254
8.5.15.4 Initialisation after intersystem handover to UTRAN ....254
8.5.15.5 Initialisation for MTCH and/or MSCH carried on S-CCPCH that may be soft combined ....254
8.5.16 Configuration of CTCH occasions ....255
8.5.17 PRACH selection ....255
8.5.18 Selection of RACH TTI ....256
8.5.18.1 FDD ....256
8.5.18.2 1.28 Mcps TDD ....257
8.5.19 Secondary CCPCH selection ....257
8.5.19a Secondary CCPCH and FACH selection for MCCH reception ....258
8.5.20 Unsupported configuration ....258
8.5.21 Actions related to Radio Bearer mapping ....259
8.5.22 Actions when entering another RAT from connected mode ....263

8.5.23 Measured results on RACH ..... 263
8.5.24 Change of PLMN while in RRC connected mode ..... 265
8.5.25 Actions related to HS_DSCH_RECEPTION variable ..... 265
8.5.26 Service prioritisation ..... 267
8.5.27 MBMS frequency selection ..... 267
8.5.28 Actions related to E_DCH_TRANSMISSION variable ..... 268
8.6 Generic actions on receipt and absence of an information element ..... 269
8.6.1 CN information elements ..... 269
8.6.1.1 Void ..... 269
8.6.1.2 CN information info ..... 269
8.6.1.3 Signalling connection release indication ..... 270
8.6.2 UTRAN mobility information elements ..... 270
8.6.2.1 URA identity ..... 270
8.6.2.2 Mapping info ..... 271
8.6.3 UE information elements ..... 271
8.6.3.1 Activation time ..... 271
8.6.3.1a CN domain specific DRX cycle length coefficient ..... 272
8.6.3.1b H-RNTI ..... 272
8.6.3.2 UTRAN DRX Cycle length coefficient ..... 273
8.6.3.3 Generic state transition rules depending on received information elements ..... 273
8.6.3.4 Ciphering mode info ..... 274
8.6.3.5 Integrity protection mode info ..... 277
8.6.3.5.1 Initialisation of Integrity Protection ..... 277
8.6.3.5.2 Integrity Protection Re-configuration for SRNS Relocation and handover from GERAN Iu mode ..... 278
8.6.3.5.3 Integrity Protection modification in case of new keys or initialisation of signalling connection ..... 279
8.6.3.6 Void ..... 280
8.6.3.7 Void ..... 280
8.6.3.8 Integrity check info ..... 280
8.6.3.9 New C-RNTI ..... 280
8.6.3.9a New DSCH-RNTI ..... 280
8.6.3.10 New U-RNTI ..... 281
8.6.3.11 RRC transaction identifier ..... 281
8.6.3.12 Capability Update Requirement ..... 284
8.6.3.13 Group release information ..... 285
8.6.3.14 New E-RNTI ..... 286
8.6.4 Radio bearer information elements ..... 286
8.6.4.1 Signalling RB information to setup list ..... 286
8.6.4.2 RAB information for setup ..... 287
8.6.4.2a RAB information to reconfigure ..... 288
8.6.4.3 RB information to setup ..... 288
8.6.4.4 RB information to be affected ..... 290
8.6.4.4a RB information to change list ..... 290
8.6.4.5 RB information to reconfigure ..... 291
8.6.4.6 RB information to release ..... 291
8.6.4.7 RB with PDCP information ..... 292
8.6.4.8 RB mapping info ..... 292
8.6.4.9 RLC Info ..... 295
8.6.4.10 PDCP Info ..... 297
8.6.4.11 PDCP SN Info ..... 298
8.6.4.12 NAS Synchronisation Indicator ..... 298
8.6.4.13 PDCP context relocation info ..... 298
8.6.4.14 RLC Info MBMS ..... 299
8.6.5 Transport channel information elements ..... 299
8.6.5.1 Transport Format Set ..... 299
8.6.5.2 Transport format combination set ..... 300
8.6.5.3 Transport format combination subset ..... 302
8.6.5.4 DCH quality target ..... 304
8.6.5.5 Added or Reconfigured UL TrCH information ..... 304
8.6.5.5a Added or reconfigured MAC-d flow ..... 304
8.6.5.6 Added or Reconfigured DL TrCH information ..... 305
8.6.5.6a Void ..... 306

8.6.5.6b HARQ Info....306
8.6.5.7 Deleted UL TrCH information....306
8.6.5.8 Deleted DL TrCH information....307
8.6.5.9 UL Transport channel information common for all transport channels....307
8.6.5.10 DL Transport channel information common for all transport channels....307
8.6.5.11 Void....308
8.6.5.12 TFCS Reconfiguration/Addition Information....308
8.6.5.12a Additional RACH TFCS for CCCH....309
8.6.5.13 TFCS Removal Information....309
8.6.5.14 Void....309
8.6.5.15 TFCS Explicit Configuration....309
8.6.5.16 E-DCH Transmission Time Interval....309
8.6.5.17 HARQ Info for E-DCH....310
8.6.5.18 Added or reconfigured E-DCH MAC-d flow....310
8.6.6 Physical channel information elements....311
8.6.6.1 Frequency info....311
8.6.6.2 Void....311
8.6.6.2a PNBSCH allocation....311
8.6.6.3 Void....312
8.6.6.3a Downlink information per radio link list....312
8.6.6.4 Downlink information for each radio link....313
8.6.6.5 Void....314
8.6.6.6 Uplink DPCH info....315
8.6.6.7 Void....315
8.6.6.8 Maximum allowed UL TX power....315
8.6.6.9 Void....316
8.6.6.10 Void....316
8.6.6.11 Uplink DPCH power control info....316
8.6.6.12 Secondary CPICH info....317
8.6.6.13 Primary CPICH usage for channel estimation....317
8.6.6.14 DPCH frame offset....317
8.6.6.15 DPCH Compressed mode info....319
8.6.6.16 Repetition period, Repetition length, Offset (TDD only)....322
8.6.6.17 Primary CCPCH info....323
8.6.6.18 Primary CPICH info....323
8.6.6.19 Void....323
8.6.6.20 Void....323
8.6.6.21 Void....323
8.6.6.22 Secondary Scrambling Code, Code Number....323
8.6.6.23 PDSCH Power Control info....324
8.6.6.24 Tx Diversity Mode....324
8.6.6.25 Void....325
8.6.6.26 UL Timing Advance Control (TDD only)....325
8.6.6.26a Uplink synchronisation parameters (TDD only)....326
8.6.6.27 Downlink information common for all radio links....326
8.6.6.28 Downlink DPCH info common for all radio links....326
8.6.6.28a Downlink F-DPCH info common for all radio links....328
8.6.6.29 ASC setting....328
8.6.6.30 SRB delay, PC preamble (FDD only)....330
8.6.6.31 Void....330
8.6.6.32 Void....330
8.6.6.33 HS-SCCH Info....330
8.6.6.34 Measurement Feedback Info....331
8.6.6.35 DPC Mode....331
8.6.6.36 Downlink HS-PDSCH Information....331
8.6.6.37 E-DCH Info....332
8.6.7 Measurement information elements....332
8.6.7.1 Measurement validity....332
8.6.7.2 Filter coefficient....333
8.6.7.3 Intra-frequency/Inter-frequency/Inter-RAT cell info list....334
8.6.7.4 Intra-frequency measurement quantity....340
8.6.7.5 Inter-RAT measurement quantity....340

8.6.7.6 Inter-RAT reporting quantity ....341
8.6.7.7 Cell Reporting Quantities ....342
8.6.7.8 Periodical Reporting Criteria ....342
8.6.7.9 Reporting Cell Status ....343
8.6.7.10 Traffic Volume Measurement ....344
8.6.7.11 Traffic Volume Measurement Reporting Criteria ....344
8.6.7.12 FACH measurement occasion info ....344
8.6.7.13 Measurement Reporting Mode ....345
8.6.7.14 Inter-frequency measurement ....345
8.6.7.15 Inter-RAT measurement ....346
8.6.7.16 Intra-frequency measurement ....347
8.6.7.17 Quality measurement ....347
8.6.7.18 UE internal measurement ....347
8.6.7.18a Void ....348
8.6.7.19 UE positioning ....348
8.6.7.19.0 UE positioning reporting criteria ....348
8.6.7.19.1 UE positioning reporting quantity ....348
8.6.7.19.1a UE positioning reporting for UE assisted methods ....349
8.6.7.19.1b UE positioning reporting for UE based methods ....351
8.6.7.19.2 UE positioning OTDOA assistance data for UE-assisted ....352
8.6.7.19.2a UE positioning OTDOA assistance data for UE-based ....353
8.6.7.19.3 UE positioning GPS assistance data ....354
8.6.7.19.4 UE positioning Ciphering info ....358
8.6.7.19.5 UE positioning Error ....359
8.6.7.19.6 Void ....359
8.6.7.20 Void ....359
8.6.7.21 Intra-frequency reporting quantity for RACH reporting ....359
8.6.7.22 Additional Measurement List ....360
8.6.8 Void ....361
8.6.9 MBMS specific information elements ....361
8.6.9.1 Continue MCCH Reading ....361
8.6.9.1a MBMS dynamic persistence level ....361
8.6.9.2 MBMS PL Service Restriction Information ....361
8.6.9.3 MBMS L1 combining schedule ....361
8.6.9.3a MBMS Number of neighbour cells ....361
8.6.9.4 MBMS Preferred frequency information ....361
8.6.9.4a Void ....362
8.6.9.4b MBMS p-t-m activation time ....362
8.6.9.5 MBMS RB list released to change transfer mode ....362
8.6.9.6 MBMS Required UE action ....363
8.6.9.6a MBMS re- acquire MCCH ....364
8.6.9.7 MBMS Service transmissions info list ....364
8.6.9.8 MBMS Short transmission ID ....364
8.6.9.9 MBMS Transmission identity ....364
8.6.9.9a MBMS transmission time difference ....365
8.6.9.9b MCCH configuration information ....365
8.6.9.10 Next scheduling period ....365
8.7 MBMS specific procedures ....366
8.7.1 Reception of MBMS control information ....366
8.7.1.1 General ....366
8.7.1.2 Initiation ....367
8.7.1.3 UE requirements on reading of MCCH information ....367
8.7.1.4 UE requirements on reading of MSCH information ....368
8.7.2 MCCH acquisition ....368
8.7.2.1 General ....368
8.7.2.2 Initiation ....368
8.7.2.3 MCCH information to be acquired by the UE ....368
8.7.2.4 Reception of the MBMS MODIFIED SERVICES INFORMATION and the MBMS UNMODIFIED SERVICES INFORMATION by the UE ....369
8.7.2.5 Reception of the other MBMS messages by the UE ....369
8.7.3 MBMS Notification ....369
8.7.3.1 General ....370

8.7.3.2 Initiation ..... 370
8.7.3.3 Receiving the MBMS Notification information ..... 370
8.7.3.3.1 Reception via MCCH ..... 370
8.7.3.3.2 Void ..... 371
8.7.3.3.3 Reception via DCCH ..... 371
8.7.3.4 UE action upon receiving MBMS MODIFIED SERVICES INFORMATION message ..... 371
8.7.3.5 UE fails to receive MBMS Notification information ..... 372
8.7.4 MBMS counting ..... 372
8.7.4.1 General ..... 372
8.7.4.2 Initiation ..... 373
8.7.4.3 Reception of the MBMS ACCESS INFORMATION ..... 373
8.7.4.4 Termination of the MBMS counting procedure ..... 374
8.7.4.5 Failure of the counting response procedure ..... 374
8.7.5 MBMS p-t-m radio bearer configuration ..... 374
8.7.5.1 General ..... 375
8.7.5.2 Initiation ..... 375
8.7.5.3 Reception of the MBMS Current Cell PTM RB information ..... 375
8.7.5.4 Reception of the MBMS Neighbouring Cell PTM RB information ..... 375
8.7.6 MBMS modification request ..... 376
8.7.6.1 General ..... 376
8.7.6.2 Initiation ..... 376
8.7.6.3 Reception of a MBMS MODIFICATION REQUEST message by the UTRAN ..... 376
8.7.7 MBMS service scheduling ..... 376
8.7.7.1 General ..... 377
8.7.7.2 Initiation ..... 377
8.7.7.3 Reception of the MBMS scheduling information ..... 377

9 Handling of unknown, unforeseen and erroneous protocol data ..... 377
9.1 General ..... 377
9.2 ASN.1 violation or encoding error ..... 377
9.3 Unknown or unforeseen message type ..... 378
9.3a Unsolicited received message ..... 378
9.3b Unexpected critical message extension ..... 379
9.4 Unknown or unforeseen information element value, mandatory information element ..... 379
9.5 Conditional information element error ..... 380
9.6 Unknown or unforeseen information element value, conditional information element ..... 380
9.7 Unknown or unforeseen information element value, optional information element ..... 381
9.8 Unexpected non-critical message extension ..... 381
9.9 Handling of errors in nested information elements ..... 382

10 Message and information element functional definition and content ..... 382
10.1 General ..... 382
10.1.1 Protocol extensions ..... 383
10.1.1.1 Non-critical extensions ..... 385
10.1.1.1.1 Extension of an information element with additional values or choices ..... 385
10.1.1.1.2 Extension of a message with additional information elements ..... 386
10.1.1.2 Critical extensions ..... 386
10.1.1.2.1 Extension of an information element with additional values or choices ..... 386
10.1.1.2.2 Extension of a message with additional information elements ..... 386
10.2 Radio Resource Control messages ..... 386
10.2.1 ACTIVE SET UPDATE ..... 386
10.2.2 ACTIVE SET UPDATE COMPLETE ..... 387
10.2.3 ACTIVE SET UPDATE FAILURE ..... 388
10.2.4 ASSISTANCE DATA DELIVERY ..... 388
10.2.5 CELL CHANGE ORDER FROM UTRAN ..... 389
10.2.6 CELL CHANGE ORDER FROM UTRAN FAILURE ..... 390
10.2.7 CELL UPDATE ..... 390
10.2.8 CELL UPDATE CONFIRM ..... 392
10.2.9 COUNTER CHECK ..... 395
10.2.10 COUNTER CHECK RESPONSE ..... 396
10.2.11 DOWNLINK DIRECT TRANSFER ..... 396
10.2.12 Void ..... 397

10.2.13 Void ..... 397
10.2.14 Void ..... 397
10.2.15 HANDOVER FROM UTRAN COMMAND ..... 397
10.2.16 HANDOVER FROM UTRAN FAILURE ..... 399
10.2.16a HANDOVER TO UTRAN COMMAND ..... 400
10.2.16b HANDOVER TO UTRAN COMPLETE ..... 403
10.2.16c INITIAL DIRECT TRANSFER ..... 404
10.2.16d INTER RAT HANDOVER INFO ..... 405
10.2.16e MBMS Access Information ..... 405
10.2.16f MBMS Common p-t-m rb Information ..... 406
10.2.16g MBMS Current Cell p-t-m rb Information ..... 408
10.2.16h MBMS General Information ..... 410
10.2.16i MBMS Modification request ..... 411
10.2.16j MBMS Modified services Information ..... 412
10.2.16k MBMS Neighbouring Cell p-t-m rb Information ..... 414
10.2.16L MBMS Scheduling Information ..... 417
10.2.16m MBMS Unmodified services Information ..... 417
10.2.17 MEASUREMENT CONTROL ..... 418
10.2.18 MEASUREMENT CONTROL FAILURE ..... 419
10.2.19 MEASUREMENT REPORT ..... 421
10.2.20 PAGING TYPE 1 ..... 421
10.2.21 PAGING TYPE 2 ..... 422
10.2.22 PHYSICAL CHANNEL RECONFIGURATION ..... 422
10.2.23 PHYSICAL CHANNEL RECONFIGURATION COMPLETE ..... 424
10.2.24 PHYSICAL CHANNEL RECONFIGURATION FAILURE ..... 425
10.2.25 PHYSICAL SHARED CHANNEL ALLOCATION ..... 426
10.2.26 PUSCH CAPACITY REQUEST ..... 427
10.2.27 RADIO BEARER RECONFIGURATION ..... 428
10.2.28 RADIO BEARER RECONFIGURATION COMPLETE ..... 432
10.2.29 RADIO BEARER RECONFIGURATION FAILURE ..... 433
10.2.30 RADIO BEARER RELEASE ..... 433
10.2.31 RADIO BEARER RELEASE COMPLETE ..... 436
10.2.32 RADIO BEARER RELEASE FAILURE ..... 438
10.2.33 RADIO BEARER SETUP ..... 438
10.2.34 RADIO BEARER SETUP COMPLETE ..... 442
10.2.35 RADIO BEARER SETUP FAILURE ..... 444
10.2.36 RRC CONNECTION REJECT ..... 444
10.2.37 RRC CONNECTION RELEASE ..... 445
10.2.38 RRC CONNECTION RELEASE COMPLETE ..... 446
10.2.39 RRC CONNECTION REQUEST ..... 446
10.2.40 RRC CONNECTION SETUP ..... 448
10.2.41 RRC CONNECTION SETUP COMPLETE ..... 450
10.2.41a RRC FAILURE INFO ..... 451
10.2.42 RRC STATUS ..... 451
10.2.43 SECURITY MODE COMMAND ..... 452
10.2.44 SECURITY MODE COMPLETE ..... 453
10.2.45 SECURITY MODE FAILURE ..... 453
10.2.46 SIGNALLING CONNECTION RELEASE ..... 454
10.2.47 SIGNALLING CONNECTION RELEASE INDICATION ..... 454
10.2.48 SYSTEM INFORMATION ..... 454
10.2.48.1 First Segment ..... 456
10.2.48.2 First Segment (short) ..... 456
10.2.48.3 Subsequent Segment ..... 457
10.2.48.4 Last Segment ..... 457
10.2.48.5 Last Segment (short) ..... 457
10.2.48.6 Complete SIB ..... 457
10.2.48.7 Complete SIB (short) ..... 458
10.2.48.8 System Information Blocks ..... 458
10.2.48.8.1 Master Information Block ..... 459
10.2.48.8.2 Scheduling Block 1 ..... 459
10.2.48.8.3 Scheduling Block 2 ..... 459
10.2.48.8.4 System Information Block type 1 ..... 460

10.2.48.8.5 System Information Block type 2 ..... 460
10.2.48.8.6 System Information Block type 3 ..... 460
10.2.48.8.7 System Information Block type 4 ..... 462
10.2.48.8.8 System Information Block type 5 and 5bis ..... 462
10.2.48.8.9 System Information Block type 6 ..... 465
10.2.48.8.10 System Information Block type 7 ..... 466
10.2.48.8.11 Void ..... 466
10.2.48.8.12 Void ..... 466
10.2.48.8.13 Void ..... 467
10.2.48.8.14 System Information Block type 11 ..... 467
10.2.48.8.15 System Information Block type 12 ..... 467
10.2.48.8.16 System Information Block type 13 ..... 467
10.2.48.8.16.1 System Information Block type 13.1 ..... 468
10.2.48.8.16.2 System Information Block type 13.2 ..... 468
10.2.48.8.16.3 System Information Block type 13.3 ..... 468
10.2.48.8.16.4 System Information Block type 13.4 ..... 469
10.2.48.8.17 System Information Block type 14 ..... 469
10.2.48.8.18 System Information Block type 15 ..... 469
10.2.48.8.18.1 System Information Block type 15.1 ..... 470
10.2.48.8.18.2 System Information Block type 15.2 ..... 470
10.2.48.8.18.3 System Information Block type 15.3 ..... 470
10.2.48.8.18.4 System Information Block type 15.4 ..... 471
10.2.48.8.19 System Information Block type 16 ..... 472
10.2.48.8.20 System Information Block type 17 ..... 472
10.2.48.8.21 System Information Block type 18 ..... 473
10.2.49 SYSTEM INFORMATION CHANGE INDICATION ..... 473
10.2.50 TRANSPORT CHANNEL RECONFIGURATION ..... 473
10.2.51 TRANSPORT CHANNEL RECONFIGURATION COMPLETE ..... 476
10.2.52 TRANSPORT CHANNEL RECONFIGURATION FAILURE ..... 477
10.2.53 TRANSPORT FORMAT COMBINATION CONTROL ..... 477
10.2.54 TRANSPORT FORMAT COMBINATION CONTROL FAILURE ..... 478
10.2.55 UE CAPABILITY ENQUIRY ..... 479
10.2.56 UE CAPABILITY INFORMATION ..... 479
10.2.57 UE CAPABILITY INFORMATION CONFIRM ..... 480
10.2.58 UPLINK DIRECT TRANSFER ..... 480
10.2.59 UPLINK PHYSICAL CHANNEL CONTROL ..... 481
10.2.60 URA UPDATE ..... 483
10.2.61 URA UPDATE CONFIRM ..... 483
10.2.62 UTRAN MOBILITY INFORMATION ..... 484
10.2.63 UTRAN MOBILITY INFORMATION CONFIRM ..... 486
10.2.64 UTRAN MOBILITY INFORMATION FAILURE ..... 486
10.3 Information element functional definitions ..... 487
10.3.1 CN Information elements ..... 487
10.3.1.1 CN domain identity ..... 487
10.3.1.2 CN Domain System Information ..... 487
10.3.1.3 CN Information info ..... 488
10.3.1.3a CN Information info full ..... 488
10.3.1.3b Domain Specific Access Restriction ..... 489
10.3.1.3c Domain Specific Access Restriction Parameters ..... 489
10.3.1.4 IMEI ..... 489
10.3.1.5 IMSI (GSM-MAP) ..... 489
10.3.1.6 Intra Domain NAS Node Selector ..... 490
10.3.1.7 Location Area Identification ..... 491
10.3.1.7a Multiple PLMN List ..... 492
10.3.1.8 NAS message ..... 492
10.3.1.9 NAS system information (GSM-MAP) ..... 492
10.3.1.10 Paging record type identifier ..... 492
10.3.1.11 PLMN identity ..... 493
10.3.1.11a PLMN identity with Optional MCC ..... 493
10.3.1.12 PLMN Type ..... 493
10.3.1.13 P-TMSI (GSM-MAP) ..... 493
10.3.1.14 RAB identity ..... 494

10.3.1.15 Routing Area Code....494
10.3.1.16 Routing Area Identification....494
10.3.1.17 TMSI (GSM-MAP)....495
10.3.2 UTRAN mobility Information elements....495
10.3.2.1 Cell Access Restriction....495
10.3.2.2 Cell identity....495
10.3.2.3 Cell selection and re-selection info for SIB3/4....496
10.3.2.4 Cell selection and re-selection info for SIB11/12....500
10.3.2.5 Mapping Info....501
10.3.2.6 URA identity....502
10.3.3 UE Information elements....503
10.3.3.1 Activation time....503
10.3.3.2 Capability Update Requirement....503
10.3.3.3 Cell update cause....503
10.3.3.4 Ciphering Algorithm....504
10.3.3.5 Ciphering mode info....504
10.3.3.6 CN domain specific DRX cycle length coefficient....504
10.3.3.7 Void....505
10.3.3.8 C-RNTI....505
10.3.3.9 Void....505
10.3.3.9a DSCH-RNTI....505
10.3.3.10 Void....505
10.3.3.10a E-RNTI....505
10.3.3.11 Establishment cause....506
10.3.3.12 Expiration Time Factor....507
10.3.3.13 Failure cause....507
10.3.3.14 Failure cause and error information....507
10.3.3.14o Group release information....508
10.3.3.14a H-RNTI....508
10.3.3.15 Initial UE identity....508
10.3.3.16 Integrity check info....509
10.3.3.17 Integrity protection activation info....509
10.3.3.18 Integrity protection Algorithm....510
10.3.3.19 Integrity protection mode info....510
10.3.3.19a Void....510
10.3.3.20 Void....511
10.3.3.21 Measurement capability....511
10.3.3.21a Measurement capability extension....513
10.3.3.22 Paging cause....516
10.3.3.23 Paging record....516
10.3.3.24 PDCP capability....517
10.3.3.25 Physical channel capability....518
10.3.3.26 Protocol error cause....521
10.3.3.27 Protocol error indicator....522
10.3.3.28 RB timer indicator....522
10.3.3.29 Redirection info....522
10.3.3.30 Re-establishment timer....522
10.3.3.31 Rejection cause....523
10.3.3.32 Release cause....523
10.3.3.32a RF Capability Compressed....524
10.3.3.33 RF capability FDD....524
10.3.3.33a RF capability FDD extension....525
10.3.3.33b RF capability TDD....525
10.3.3.33c RF capability TDD 1.28 Mcps....525
10.3.3.34 RLC capability....525
10.3.3.35 RLC re-establish indicator....525
10.3.3.35o RRC connection release information....526
10.3.3.35a RRC State Indicator....526
10.3.3.36 RRC transaction identifier....526
10.3.3.37 Security capability....527
10.3.3.38 START....527
10.3.3.39 Void....527

10.3.3.40 Transport channel capability ..... 527
10.3.3.41 UE multi-mode/multi-RAT capability ..... 529
10.3.3.42 UE radio access capability ..... 529
10.3.3.42o UE radio access capability compressed ..... 531
10.3.3.42oa UE radio access capability comp 2 ..... 531
10.3.3.42a UE radio access capability extension ..... 532
10.3.3.42b UE security information ..... 532
10.3.3.42c UE security information2 ..... 532
10.3.3.43 UE Timers and Constants in connected mode ..... 533
10.3.3.44 UE Timers and Constants in idle mode ..... 534
10.3.3.45 UE positioning capability ..... 535
10.3.3.46 URA update cause ..... 536
10.3.3.47 U-RNTI ..... 536
10.3.3.47a U-RNTI group ..... 536
10.3.3.48 U-RNTI Short ..... 536
10.3.3.49 UTRAN DRX cycle length coefficient ..... 537
10.3.3.50 Wait time ..... 537
10.3.3.51 UE Specific Behaviour Information 1 idle ..... 537
10.3.3.52 UE Specific Behaviour Information 1 interRAT ..... 537
10.3.4 Radio Bearer Information elements ..... 537
10.3.4.0 Default configuration identity ..... 537
10.3.4.1 Downlink RLC STATUS info ..... 538
10.3.4.1a PDCP context relocation info ..... 538
10.3.4.2 PDCP info ..... 539
10.3.4.2a PDCP ROHC target mode ..... 541
10.3.4.3 PDCP SN info ..... 541
10.3.4.4 Polling info ..... 542
10.3.4.5 Predefined configuration identity ..... 542
10.3.4.5a Predefined configuration status information ..... 542
10.3.4.5b Predefined configuration status information compressed ..... 543
10.3.4.6 Predefined configuration value tag ..... 543
10.3.4.7 Predefined RB configuration ..... 544
10.3.4.8 RAB info ..... 544
10.3.4.9 RAB info Post ..... 545
10.3.4.10 RAB information for setup ..... 545
10.3.4.11 RAB information to reconfigure ..... 545
10.3.4.12 NAS Synchronization indicator ..... 545
10.3.4.13 RB activation time info ..... 546
10.3.4.14 RB COUNT-C MSB information ..... 546
10.3.4.15 RB COUNT-C information ..... 546
10.3.4.16 RB identity ..... 546
10.3.4.17 RB information to be affected ..... 547
10.3.4.18 RB information to reconfigure ..... 547
10.3.4.19 RB information to release ..... 547
10.3.4.20 RB information to setup ..... 547
10.3.4.21 RB mapping info ..... 548
10.3.4.22 RB with PDCP information ..... 551
10.3.4.23 RLC info ..... 551
10.3.4.23a RLC info MBMS ..... 553
10.3.4.24 Signalling RB information to setup ..... 553
10.3.4.25 Transmission RLC Discard ..... 553
10.3.4.26 UM Duplication Avoidance and Reordering info ..... 555
10.3.4.27 UM Out of sequence delivery info ..... 555
10.3.5 Transport CH Information elements ..... 555
10.3.5.1 Added or Reconfigured DL TrCH information ..... 555
10.3.5.1a Added or reconfigured MAC-d flow ..... 556
10.3.5.1b Added or reconfigured E-DCH MAC-d flow ..... 557
10.3.5.2 Added or Reconfigured UL TrCH information ..... 559
10.3.5.2a Additional Dynamic Transport Format Information for CCCH ..... 559
10.3.5.2b Additional RACH TFCS for CCCH ..... 559
10.3.5.3 Void ..... 560
10.3.5.4 Deleted DL TrCH information ..... 560

10.3.5.5 Deleted UL TrCH information ..... 560
10.3.5.6 DL Transport channel information common for all transport channels ..... 561
10.3.5.7 Void ..... 561
10.3.5.7a HARQ Info ..... 562
10.3.5.7b Void ..... 562
10.3.5.7c MAC-d Flow Identity ..... 562
10.3.5.7d HARQ Info for E-DCH ..... 562
10.3.5.7e E-DCH MAC-d Flow Identity ..... 563
10.3.5.8 Power Offset Information ..... 563
10.3.5.9 Predefined TrCH configuration ..... 564
10.3.5.10 Quality Target ..... 564
10.3.5.11 Semi-static Transport Format Information ..... 564
10.3.5.12 Void ..... 565
10.3.5.13 TFCS Explicit Configuration ..... 565
10.3.5.14 Void ..... 565
10.3.5.15 TFCS Reconfiguration/Addition Information ..... 566
10.3.5.16 TFCS Removal Information ..... 567
10.3.5.17 Void ..... 567
10.3.5.18 Transport channel identity ..... 567
10.3.5.19 Transport Format Combination (TFC) ..... 567
10.3.5.20 Transport Format Combination Set ..... 567
10.3.5.21 Transport Format Combination Set Identity ..... 567
10.3.5.22 Transport Format Combination Subset ..... 568
10.3.5.23 Transport Format Set ..... 568
10.3.5.24 UL Transport channel information common for all transport channels ..... 570
10.3.6 Physical CH Information elements ..... 571
10.3.6.1 AC-to-ASC mapping ..... 571
10.3.6.2 AICH Info ..... 572
10.3.6.3 AICH Power offset ..... 572
10.3.6.4 Allocation period info ..... 572
10.3.6.5 Alpha ..... 572
10.3.6.6 ASC setting ..... 572
10.3.6.7 Void ..... 574
10.3.6.8 CCTrCH power control info ..... 575
10.3.6.8a Cell and Channel Identity info ..... 575
10.3.6.9 Cell parameters Id ..... 575
10.3.6.10 Common timeslot info ..... 575
10.3.6.11 Constant value ..... 576
10.3.6.11a Constant value TDD ..... 576
10.3.6.12 Void ..... 576
10.3.6.13 Void ..... 576
10.3.6.14 Void ..... 576
10.3.6.15 Void ..... 576
10.3.6.16 Default DPCH Offset Value ..... 577
10.3.6.17 Downlink channelisation codes ..... 577
10.3.6.17a Downlink channelisation codes VHCR ..... 577
10.3.6.18 Downlink DPCH info common for all RL ..... 578
10.3.6.19 Downlink DPCH info common for all RL Post ..... 580
10.3.6.20 Downlink DPCH info common for all RL Pre ..... 580
10.3.6.21 Downlink DPCH info for each RL ..... 580
10.3.6.22 Downlink DPCH info for each RL Post ..... 583
10.3.6.23 Downlink DPCH power control information ..... 584
10.3.6.23oa Downlink F-DPCH info common for all RL ..... 584
10.3.6.23ob Downlink F-DPCH info for each RL ..... 584
10.3.6.23a Downlink HS-PDSCH Information ..... 585
10.3.6.24 Downlink information common for all radio links ..... 585
10.3.6.25 Downlink information common for all radio links Post ..... 586
10.3.6.26 Downlink information common for all radio links Pre ..... 587
10.3.6.27 Downlink information for each radio link ..... 587
10.3.6.28 Downlink information for each radio link Post ..... 587
10.3.6.29 Void ..... 588
10.3.6.30 Void ..... 588

10.3.6.31 Downlink rate matching restriction information ....588
10.3.6.32 Downlink Timeslots and Codes ....588
10.3.6.32a Downlink Timeslots and Codes VHCR ....589
10.3.6.33 DPCH compressed mode info ....590
10.3.6.34 DPCH Compressed Mode Status Info ....593
10.3.6.35 Dynamic persistence level ....594
10.3.6.35a FPACH info ....594
10.3.6.35b Frequency band indicator ....594
10.3.6.35c Frequency band indicator 2 ....594
10.3.6.36 Frequency info ....595
10.3.6.36oo HS-PDSCH Midamble Configuration ....595
10.3.6.36o HS-PDSCH Timeslot Configuration ....595
10.3.6.36oa HS-PDSCH Timeslot Configuration VHCR ....596
10.3.6.36a HS-SCCH Info ....598
10.3.6.36b HS-SICH Power Control Info ....601
10.3.6.37 Individual timeslot info ....601
10.3.6.38 Individual Timeslot interference ....602
10.3.6.39 Maximum allowed UL TX power ....602
10.3.6.40 Void ....602
10.3.6.40a Measurement Feedback Info ....602
10.3.6.41 Midamble shift and burst type ....602
10.3.6.42 PDSCH Capacity Allocation info ....604
10.3.6.43 Void ....604
10.3.6.44 PDSCH info ....604
10.3.6.45 PDSCH Power Control info ....605
10.3.6.46 PDSCH system information ....605
10.3.6.47 Void ....606
10.3.6.48 Persistence scaling factors ....606
10.3.6.49 PICH Info ....606
10.3.6.50 PICH Power offset ....608
10.3.6.50a PLCCH Info ....608
10.3.6.51 PRACH Channelisation Code List ....608
10.3.6.51a PRACH Channelisation Code 1.28 Mcps TDD ....608
10.3.6.51b PRACH Channelisation Code List VHCR ....609
10.3.6.52 PRACH info (for RACH) ....609
10.3.6.53 PRACH partitioning ....611
10.3.6.54 PRACH power offset ....611
10.3.6.55 PRACH system information list ....612
10.3.6.56 Predefined PhyCH configuration ....613
10.3.6.57 Primary CCPCH info ....613
10.3.6.58 Primary CCPCH info post ....614
10.3.6.59 Primary CCPCH TX Power ....615
10.3.6.60 Primary CPICH info ....615
10.3.6.61 Primary CPICH Tx power ....615
10.3.6.62 Primary CPICH usage for channel estimation ....615
10.3.6.63 PUSCH info ....615
10.3.6.63a PUSCH info VHCR ....616
10.3.6.64 PUSCH Capacity Allocation info ....617
10.3.6.65 PUSCH power control info ....617
10.3.6.66 PUSCH system information ....618
10.3.6.66a PUSCH system information VHCR ....618
10.3.6.67 RACH transmission parameters ....619
10.3.6.68 Radio link addition information ....619
10.3.6.69 Radio link removal information ....620
10.3.6.69a E-DCH reconfiguration information ....620
10.3.6.70 Void ....622
10.3.6.70a SCTD indicator ....622
10.3.6.71 Secondary CCPCH info ....623
10.3.6.71a Secondary CCPCH info MBMS ....624
10.3.6.72 Secondary CCPCH system information ....625
10.3.6.72a Secondary CCPCH system information MBMS ....626
10.3.6.73 Secondary CPICH info ....626

10.3.6.74 Secondary scrambling code....626
10.3.6.74a Serving HS-DSCH cell information....627
10.3.6.75 SFN Time info....627
10.3.6.75a Special Burst Scheduling....627
10.3.6.76 Void....627
10.3.6.77 Void....627
10.3.6.78 STTD indicator....627
10.3.6.78a SYNC_UL info....628
10.3.6.79 TDD open loop power control....628
10.3.6.80 TFC Control duration....629
10.3.6.81 Void....629
10.3.6.82 TGPSI....629
10.3.6.83 Time info....630
10.3.6.84 Timeslot number....630
10.3.6.85 TPC combination index....630
10.3.6.85a TSTD indicator....630
10.3.6.86 TX Diversity Mode....630
10.3.6.87 UL interference....631
10.3.6.87a UL interference TDD....631
10.3.6.88 Uplink DPCH info....632
10.3.6.89 Uplink DPCH info Post....634
10.3.6.90 Uplink DPCH info Pre....634
10.3.6.91 Uplink DPCH power control info....635
10.3.6.92 Uplink DPCH power control info Post....636
10.3.6.93 Uplink DPCH power control info Pre....637
10.3.6.94 Uplink Timeslots and Codes....638
10.3.6.94a Uplink Timeslots and Codes LCR....639
10.3.6.94b Uplink Timeslots and Codes VHCR....640
10.3.6.95 Uplink Timing Advance....641
10.3.6.95a Uplink Timing Advance VHCR....641
10.3.6.96 Uplink Timing Advance Control....641
10.3.6.97 E-DCH Info....644
10.3.6.98 E-DPCCH Info....645
10.3.6.99 E-DPDCH Info....646
10.3.6.100 E-AGCH Info....646
10.3.6.101 E-HICH Info....647
10.3.6.102 E-RGCH Info....647
10.3.7 Measurement Information elements....647
10.3.7.1 Additional measurements list....647
10.3.7.2 Cell info....648
10.3.7.3 Cell measured results....649
10.3.7.4 Cell measurement event results....650
10.3.7.5 Cell reporting quantities....650
10.3.7.6 Cell synchronisation information....651
10.3.7.7 Event results....651
10.3.7.8 FACH measurement occasion info....652
10.3.7.9 Filter coefficient....653
10.3.7.10 HCS Cell re-selection information....653
10.3.7.11 HCS neighbouring cell information....653
10.3.7.12 HCS Serving cell information....654
10.3.7.13 Inter-frequency cell info list....654
10.3.7.14 Inter-frequency event identity....655
10.3.7.15 Inter-frequency measured results list....655
10.3.7.16 Inter-frequency measurement....655
10.3.7.17 Inter-frequency measurement event results....656
10.3.7.18 Inter-frequency measurement quantity....656
10.3.7.19 Inter-frequency measurement reporting criteria....657
10.3.7.20 Inter-frequency measurement system information....660
10.3.7.20a Inter-frequency RACH reporting information....660
10.3.7.21 Inter-frequency reporting quantity....660
10.3.7.22 Inter-frequency SET UPDATE....661
10.3.7.23 Inter-RAT cell info list....661

10.3.7.24 Inter-RAT event identity ..... 662
10.3.7.25 Inter-RAT info ..... 662
10.3.7.26 Inter-RAT measured results list ..... 663
10.3.7.27 Inter-RAT measurement ..... 664
10.3.7.28 Inter-RAT measurement event results ..... 664
10.3.7.29 Inter-RAT measurement quantity ..... 665
10.3.7.30 Inter-RAT measurement reporting criteria ..... 665
10.3.7.31 Inter-RAT measurement system information ..... 666
10.3.7.32 Inter-RAT reporting quantity ..... 666
10.3.7.33 Intra-frequency cell info list ..... 666
10.3.7.34 Intra-frequency event identity ..... 667
10.3.7.35 Intra-frequency measured results list ..... 668
10.3.7.36 Intra-frequency measurement ..... 668
10.3.7.37 Intra-frequency measurement event results ..... 668
10.3.7.38 Intra-frequency measurement quantity ..... 669
10.3.7.39 Intra-frequency measurement reporting criteria ..... 669
10.3.7.40 Intra-frequency measurement system information ..... 673
10.3.7.41 Intra-frequency reporting quantity ..... 673
10.3.7.42 Intra-frequency reporting quantity for RACH reporting ..... 673
10.3.7.43 Maximum number of reported cells on RACH ..... 674
10.3.7.43a MBMS preferred frequency information ..... 675
10.3.7.44 Measured results ..... 675
10.3.7.45 Measured results on RACH ..... 676
10.3.7.46 Measurement Command ..... 678
10.3.7.47 Measurement control system information ..... 678
10.3.7.48 Measurement Identity ..... 679
10.3.7.49 Measurement reporting mode ..... 679
10.3.7.50 Measurement Type ..... 679
10.3.7.51 Measurement validity ..... 680
10.3.7.52 Void ..... 680
10.3.7.53 Periodical reporting criteria ..... 680
10.3.7.53aa Periodical reporting info-1b ..... 680
10.3.7.53a PLMN identities of neighbour cells ..... 680
10.3.7.54 Primary CCPCH RSCP info ..... 681
10.3.7.54a Qhcs ..... 681
10.3.7.55 Quality measured results list ..... 683
10.3.7.56 Quality measurement ..... 684
10.3.7.57 Quality measurement event results ..... 684
10.3.7.58 Quality measurement reporting criteria ..... 684
10.3.7.59 Quality reporting quantity ..... 685
10.3.7.60 Reference time difference to cell ..... 685
10.3.7.61 Reporting Cell Status ..... 685
10.3.7.62 Reporting information for state CELL_DCH ..... 688
10.3.7.63 SFN-SFN observed time difference ..... 688
10.3.7.64 Time to trigger ..... 688
10.3.7.65 Timeslot ISCP info ..... 688
10.3.7.66 Traffic volume event identity ..... 689
10.3.7.67 Traffic volume measured results list ..... 689
10.3.7.68 Traffic volume measurement ..... 690
10.3.7.69 Traffic volume measurement event results ..... 690
10.3.7.70 Traffic volume measurement object ..... 691
10.3.7.71 Traffic volume measurement quantity ..... 691
10.3.7.72 Traffic volume measurement reporting criteria ..... 692
10.3.7.73 Traffic volume measurement system information ..... 693
10.3.7.74 Traffic volume reporting quantity ..... 693
10.3.7.75 UE internal event identity ..... 693
10.3.7.76 UE internal measured results ..... 694
10.3.7.77 UE internal measurement ..... 695
10.3.7.78 UE internal measurement event results ..... 695
10.3.7.79 UE internal measurement quantity ..... 695
10.3.7.80 UE internal measurement reporting criteria ..... 696
10.3.7.81 Void ..... 697

10.3.7.82 UE Internal reporting quantity ....697
10.3.7.83 UE Rx-Tx time difference type 1 ....697
10.3.7.84 UE Rx-Tx time difference type 2 ....698
10.3.7.85 UE Transmitted Power info ....698
10.3.7.86 UE positioning Ciphering info ....698
10.3.7.87 UE positioning Error ....699
10.3.7.88 UE positioning GPS acquisition assistance ....699
10.3.7.88a UE positioning GPS Additional Assistance Data Request ....701
10.3.7.89 UE positioning GPS almanac ....702
10.3.7.90 UE positioning GPS assistance data ....702
10.3.7.90a Void ....703
10.3.7.91 UE positioning GPS DGPS corrections ....703
10.3.7.91a UE positioning GPS Ephemeris and Clock Correction parameters ....704
10.3.7.92 UE positioning GPS ionospheric model ....706
10.3.7.93 UE positioning GPS measured results ....706
10.3.7.94 UE positioning GPS navigation model ....707
10.3.7.95 UE positioning GPS real-time integrity ....708
10.3.7.95a Void ....708
10.3.7.96 UE positioning GPS reference time ....708
10.3.7.97 UE positioning GPS UTC model ....709
10.3.7.98 UE positioning IPDL parameters ....709
10.3.7.99 UE positioning measured results ....710
10.3.7.100 UE positioning measurement ....710
10.3.7.101 UE positioning measurement event results ....711
10.3.7.102 Void ....711
10.3.7.103 UE positioning OTDOA assistance data for UE-assisted ....712
10.3.7.103a UE positioning OTDOA assistance data for UE-based ....712
10.3.7.104 Void ....712
10.3.7.105 UE positioning OTDOA measured results ....712
10.3.7.106 UE positioning OTDOA neighbour cell info ....713
10.3.7.106a UE positioning OTDOA neighbour cell info for UE-based ....715
10.3.7.107 UE positioning OTDOA quality ....715
10.3.7.108 UE positioning OTDOA reference cell info ....716
10.3.7.108a UE positioning OTDOA reference cell info for UE-based ....717
10.3.7.109 UE positioning position estimate info ....718
10.3.7.109a UE positioning Relative Time Difference quality ....719
10.3.7.110 UE positioning reporting criteria ....719
10.3.7.111 UE positioning reporting quantity ....720
10.3.7.112 $T_{ADV}$ info ....721
10.3.8 Other Information elements ....722
10.3.8.1 BCCH modification info ....722
10.3.8.2 BSIC ....722
10.3.8.3 CBS DRX Level 1 information ....722
10.3.8.4 Cell Value tag ....722
10.3.8.4a Ellipsoid point ....723
10.3.8.4b Ellipsoid point with Altitude ....723
10.3.8.4c Ellipsoid point with Altitude and uncertainty ellipsoid ....723
10.3.8.4d Ellipsoid point with uncertainty Circle ....724
10.3.8.4e Ellipsoid point with uncertainty Ellipse ....725
10.3.8.4f GERAN system information ....725
10.3.8.4g GSM Target Cell Info ....725
10.3.8.4h Horizontal Velocity ....726
10.3.8.4i Horizontal with Vertical Velocity ....726
10.3.8.4j Horizontal Velocity with Uncertainty ....727
10.3.8.4k Horizontal with Vertical Velocity and Uncertainty ....727
10.3.8.5 Inter-RAT change failure ....728
10.3.8.6 Inter-RAT handover failure ....728
10.3.8.7 Inter-RAT UE radio access capability ....729
10.3.8.8 Void ....730
10.3.8.8a Inter-RAT UE security capability ....731
10.3.8.9 MIB Value tag ....731

10.3.8.10 PLMN Value tag ..... 731
10.3.8.10a PNBSCH allocation ..... 731
10.3.8.11 Predefined configuration identity and value tag ..... 731
10.3.8.12 Protocol error information ..... 732
10.3.8.13 References to other system information blocks ..... 732
10.3.8.14 References to other system information blocks and scheduling blocks ..... 732
10.3.8.15 Rplmn information ..... 732
10.3.8.16 Scheduling information ..... 733
10.3.8.17 SEG COUNT ..... 734
10.3.8.18 Segment index ..... 734
10.3.8.18a SIB and SB type ..... 735
10.3.8.19 SIB data fixed ..... 735
10.3.8.20 SIB data variable ..... 735
10.3.8.20a SIB occurrence identity ..... 736
10.3.8.20b SIB occurrence identity and value tag ..... 736
10.3.8.20c SIB occurrence value tag ..... 736
10.3.8.21 SIB type ..... 736
10.3.8.22 SIB type SIBs only ..... 737
10.3.9 ANSI-41 Information elements ..... 738
10.3.9.1 ANSI-41 Core Network Information ..... 738
10.3.9.2 ANSI-41 Global Service Redirection information ..... 738
10.3.9.3 ANSI-41 NAS parameter ..... 738
10.3.9.4 ANSI-41 NAS system information ..... 739
10.3.9.5 ANSI-41 Private Neighbour List information ..... 739
10.3.9.6 ANSI-41 RAND information ..... 739
10.3.9.7 ANSI-41 User Zone Identification information ..... 739
10.3.9.8 MIN_P_REV ..... 739
10.3.9.9 NID ..... 740
10.3.9.10 P_REV ..... 740
10.3.9.11 SID ..... 740
10.3.9a MBMS Information elements ..... 740
10.3.9a.1 MBMS Common CCTrCH identity ..... 740
10.3.9a.2 MBMS Common PhyCh identity ..... 741
10.3.9a.3 MBMS Common RB identity ..... 741
10.3.9a.4 MBMS Common TrCh identity ..... 741
10.3.9a.5 MBMS Current cell S-CCPCH identity ..... 741
10.3.9a.6 Void ..... 741
10.3.9a.7 MBMS L1 combining schedule ..... 742
10.3.9a.7o MBMS p-t-m activation time ..... 742
10.3.9a.7a MBMS p-t-m RB information ..... 743
10.3.9a.8 MBMS Service identity ..... 744
10.3.9a.8a MBMS Service ID ..... 744
10.3.9a.9 MBMS Session identity ..... 745
10.3.9a.10 MBMS Short transmission identity ..... 745
10.3.9a.10a MBMS Soft Combining Timing Offset ..... 745
10.3.9a.11 MBMS specific timers and counters ..... 746
10.3.9a.12 MBMS Transmission identity ..... 746
10.3.9a.13 MCCH configuration information ..... 746
10.3.9a.14 MICH configuration information ..... 748
10.3.9a.15 MICH Power offset ..... 749
10.3.9a.16 MSCH configuration information ..... 749
10.3.10 Multiplicity values and type constraint values ..... 750

11 Message and Information element abstract syntax (with ASN.1) ..... 753

11 Message and Information element abstract syntax (with ASN.1) ..... 753
11.1 General message structure ..... 753
11.2 PDU definitions ..... 757
11.3 Information element definitions ..... 837
11.4 Constant definitions ..... 1007
11.5 RRC information between network nodes ..... 1009

12 Message transfer syntax ..... 1025

12.1 Structure of encoded RRC messages ..... 1026
12.1.1 Basic production ..... 1026
12.1.2 Extension ..... 1026
12.1.3 Padding ..... 1026
12.2 ECN link module for RRC ..... 1028
12.3 ECN modules for RRC ..... 1029
12.4 RRC messages encoded otherwise ..... 1029
12.4.1 Messages using tabular encoding specification ..... 1029
12.4.1.1 TRANSPORT FORMAT COMBINATION CONTROL using transparent DCCH ..... 1030
12.4.1.1.1 TRANSPORT FORMAT COMBINATION CONTROL, 3 bit format ..... 1030
12.4.1.1.2 Void ..... 1030
12.4.1.1.3 Void ..... 1030

13 Protocol timers, counters, other parameters and default configurations ..... 1031
13.1 Timers for UE ..... 1031
13.2 Counters for UE ..... 1032
13.3 UE constants and parameters ..... 1033
13.4 UE variables ..... 1033
13.4.ob AM_RLC_ERROR_PENDING_RB234 ..... 1033
13.4.oc AM_RLC_ERROR_PENDING_RB5_AND_UP ..... 1033
13.4.0 CELL_INFO_LIST ..... 1033
13.4.00 Void ..... 1034
13.4.0a CELL_UPDATE_STARTED ..... 1034
13.4.1 CIPHERING_STATUS ..... 1035
13.4.2 Void ..... 1035
13.4.2a CONFIGURATION_INCOMPLETE ..... 1035
13.4.3 C_RNTI ..... 1035
13.4.3o DSAC_PARAM ..... 1036
13.4.3a DSCH_RNTI ..... 1036
13.4.4 Void ..... 1036
13.4.4o E_DCH_TRANSMISSION ..... 1036
13.4.4a E_RNTI ..... 1037
13.4.5 ESTABLISHED_RABS ..... 1037
13.4.5a ESTABLISHED_SIGNALLING_CONNECTIONS ..... 1038
13.4.6 ESTABLISHMENT_CAUSE ..... 1038
13.4.7 FAILURE_CAUSE ..... 1038
13.4.8 FAILURE_INDICATOR ..... 1038
13.4.8o H_RNTI ..... 1039
13.4.8oo HS_DSCH_RECEPTION ..... 1039
13.4.8a INCOMPATIBLE_SECURITY_RECONFIGURATION ..... 1039
13.4.9 INITIAL_UE_IDENTITY ..... 1040
13.4.9a INTEGRITY_PROTECTION_ACTIVATION_INFO ..... 1040
13.4.10 INTEGRITY_PROTECTION_INFO ..... 1040
13.4.10a INTER_RAT_HANDOVER_INFO_TRANSFERRED ..... 1041
13.4.11 INVALID_CONFIGURATION ..... 1043
13.4.11a LATEST_CONFIGURED_CN_DOMAIN ..... 1043
13.4.11b LATEST_CONFIGURED_SRB_DELAY_AND_PC_PREAMBLE ..... 1043
13.4.11c MBMS_ACTIVATED_services ..... 1043
13.4.11d MBMS_PREV_FREQUENCY_INFO ..... 1044
13.4.12 MEASUREMENT_IDENTITY ..... 1044
13.4.13 Void ..... 1044
13.4.14 ORDERED_RECONFIGURATION ..... 1045
13.4.14a PDCP_ROHC_TARGET_MODE ..... 1045
13.4.15 PDCP_SN_INFO ..... 1045
13.4.15a PHYSICAL_SHARED_CHANNEL_CONFIGURATION ..... 1045
13.4.16 PROTOCOL_ERROR_INDICATOR ..... 1046
13.4.17 PROTOCOL_ERROR_INFORMATION ..... 1046
13.4.18 PROTOCOL_ERROR_REJECT ..... 1046
13.4.19 RB_TIMER_INDICATOR ..... 1047
13.4.20 RB_UPLINK_CIPHERING_ACTIVATION_TIME_INFO ..... 1047
13.4.20a SECURITY_MODIFICATION ..... 1047
13.4.21 Void ..... 1047

13.4.22 START_THRESHOLD ..... 1047
13.4.23 START_VALUE_TO_TRANSMIT ..... 1048
13.4.24 TFC_SUBSET ..... 1048
13.4.25 TGPS_IDENTITY ..... 1049
13.4.26 TGSN_REPORTED ..... 1050
13.4.26a TIMERS_AND_CONSTANTS ..... 1050
13.4.27 TRANSACTIONS ..... 1050
13.4.27a TRIGGERED_1A_EVENT ..... 1051
13.4.27b TRIGGERED_1B_EVENT ..... 1051
13.4.27c TRIGGERED_1C_EVENT ..... 1052
13.4.27d BEST_CELL_1D_EVENT ..... 1052
13.4.27e TRIGGERED_1E_EVENT ..... 1053
13.4.27f TRIGGERED_1F_EVENT ..... 1053
13.4.27f1 TRIGGERED_1G_EVENT ..... 1053
13.4.27f2 TRIGGERED_1H_EVENT ..... 1054
13.4.27f3 TRIGGERED_1I_EVENT ..... 1054
13.4.27f4 BEST_FREQUENCY_2A_EVENT ..... 1054
13.4.27f5 TRIGGERED_2B_EVENT ..... 1054
13.4.27f6 TRIGGERED_2C_EVENT ..... 1055
13.4.27f7 TRIGGERED_2D_EVENT ..... 1055
13.4.27f8 TRIGGERED_2E_EVENT ..... 1055
13.4.27f9 TRIGGERED_2F_EVENT ..... 1055
13.4.27f10 TRIGGERED_3A_EVENT ..... 1055
13.4.27f11 TRIGGERED_3B_EVENT ..... 1056
13.4.27f12 TRIGGERED_3C_EVENT ..... 1056
13.4.27f13 BEST_CELL_3D_EVENT ..... 1057
13.4.27f21 TRIGGERED_1J_EVENT ..... 1058
13.4.27g UE_CAPABILITY_REQUESTED ..... 1058
13.4.28 UE_CAPABILITY_TRANSFERRED ..... 1059
13.4.28a UE_POSITIONING_GPS_DATA ..... 1060
13.4.28b UE_POSITIONING_OTDOA_DATA_UE_ASSISTED ..... 1061
13.4.28c UE_POSITIONING_OTDOA_DATA_UE_BASED ..... 1062
13.4.29 UNSUPPORTED_CONFIGURATION ..... 1062
13.4.30 URA_IDENTITY ..... 1062
13.4.31 U_RNTI ..... 1062
13.4.32 VALUE_TAG ..... 1063
13.5 UE RRC Procedure Performance ..... 1064
13.5.1 Definitions ..... 1064
13.5.2 RRC procedure performance values ..... 1065
13.6 RB information parameters for signalling radio bearer RB 0 ..... 1070
13.6a RB information parameters for SHCCH ..... 1070
13.6b RB information parameters for BCCH mapped to FACH ..... 1070
13.6c RB information parameters for PCCH mapped to PCH ..... 1071
13.6d Parameters for BCCH mapped to BCH ..... 1071
13.7 Parameter values for default radio configurations ..... 1071

14 Specific functions ..... 1124
14.1 Intra-frequency measurements ..... 1124
14.1.1 Intra-frequency measurement quantities ..... 1124
14.1.2 Intra-frequency reporting events for FDD ..... 1124
14.1.2.1 Reporting event 1A: A Primary CPICH enters the reporting range ..... 1125
14.1.2.2 Reporting event 1B: A primary CPICH leaves the reporting range ..... 1127
14.1.2.3 Reporting event 1C: A non-active primary CPICH becomes better than an active primary CPICH 1129
14.1.2.4 Reporting event 1D: Change of best cell ..... 1132
14.1.2.5 Reporting event 1E: A Primary CPICH becomes better than an absolute threshold ..... 1134
14.1.2.6 Reporting event 1F: A Primary CPICH becomes worse than an absolute threshold ..... 1136
14.1.2.7 Reporting event 1J: A non-active E-DCH but active DCH primary CPICH becomes better than an active E-DCH primary CPICH ..... 1138
14.1.3 Intra-frequency reporting events for TDD ..... 1140
14.1.3.1 Reporting event 1G: Change of best cell (TDD) ..... 1140
14.1.3.2 Reporting event 1H: Timeslot ISCP below a certain threshold (TDD) ..... 1142
14.1.3.3 Reporting event 1I: Timeslot ISCP above a certain threshold (TDD) ..... 1143

14.1.4 Event-triggered periodic intra-frequency measurement reports (informative) ....1144
14.1.4.1 Cell addition failure (FDD only) ....1144
14.1.4.1a Cell removal failure (FDD only) ....1145
14.1.4.2 Cell replacement failure (FDD only) ....1146
14.1.5 Mechanisms available for modifying intra-frequency measurement reporting behaviour (informative) ....1146
14.1.5.1 Hysteresis ....1146
14.1.5.2 Time-to-trigger ....1147
14.1.5.3 Cell individual offsets ....1148
14.1.5.4 Forbid a Primary CPICH to affect the reporting range (FDD only) ....1149
14.1.6 Report quantities in intra-frequency measurements ....1150
14.2 Inter-frequency measurements ....1151
14.2.0a Inter-frequency measurement quantities ....1151
14.2.0b Frequency quality estimate ....1151
14.2.0b.1 FDD cells ....1151
14.2.0b.2 TDD cells ....1152
14.2.0c Inter-frequency reporting quantities ....1152
14.2.1 Inter-frequency reporting events ....1153
14.2.1.1 Event 2a: Change of best frequency. ....1153
14.2.1.2 Event 2b: The estimated quality of the currently used frequency is below a certain threshold **and** the estimated quality of a non-used frequency is above a certain threshold. ....1154
14.2.1.3 Event 2c: The estimated quality of a non-used frequency is above a certain threshold ....1155
14.2.1.4 Event 2d: The estimated quality of the currently used frequency is below a certain threshold ....1156
14.2.1.5 Event 2e: The estimated quality of a non-used frequency is below a certain threshold ....1157
14.2.1.6 Event 2 f: The estimated quality of the currently used frequency is above a certain threshold ....1158
14.3 Inter-RAT measurements ....1159
14.3.0a Inter-RAT measurement quantities ....1159
14.3.0b Frequency quality estimate of the UTRAN frequency ....1160
14.3.0c Inter-RAT reporting quantities ....1160
14.3.1 Inter-RAT reporting events ....1160
14.3.1.1 Event 3a: The estimated quality of the currently used UTRAN frequency is below a certain threshold **and** the estimated quality of the other system is above a certain threshold. ....1161
14.3.1.2 Event 3b: The estimated quality of other system is below a certain threshold ....1163
14.3.1.3 Event 3c: The estimated quality of other system is above a certain threshold ....1164
14.3.1.4 Event 3d: Change of best cell in other system ....1165
14.3.2 GSM measurements in compressed mode ....1167
14.3.2.1 GSM RSSI measurements ....1167
14.3.2.2 Initial BSIC identification ....1167
14.3.2.3 BSIC re-confirmation ....1167
14.4 Traffic Volume Measurements ....1167
14.4.1 Traffic Volume Measurement Quantity ....1167
14.4.2 Traffic Volume reporting triggers ....1168
14.4.2.1 Reporting event 4 A: Transport Channel Traffic Volume becomes larger than an absolute threshold ....1172
14.4.2.2 Reporting event 4 B: Transport Channel Traffic Volume becomes smaller than an absolute threshold ....1172
14.4.3 Traffic volume reporting mechanisms ....1173
14.4.3.1 Pending time after trigger ....1173
14.4.3.2 Time-to-trigger ....1173
14.4.4 Interruption of user data transmission ....1174
14.5 Quality Measurements ....1174
14.5.1 Quality reporting measurement quantities ....1174
14.5.2 Quality reporting events ....1174
14.5.2.1 Reporting event 5A: A predefined number of bad CRCs is exceeded ....1174
14.6 UE internal measurements ....1175
14.6.1 UE internal measurement quantities ....1175
14.6.2 UE internal measurement reporting events ....1175
14.6.2.1 Reporting event 6A: The UE Tx power becomes larger than an absolute threshold ....1175
14.6.2.2 Reporting event 6B: The UE Tx power becomes less than an absolute threshold ....1176
14.6.2.3 Reporting event 6C: The UE Tx power reaches its minimum value ....1177
14.6.2.4 Reporting event 6D: The UE Tx power reaches its maximum value ....1178
14.6.2.5 Reporting event 6E: The UE RSSI reaches the UE's dynamic receiver range ....1179

14.6.2.6 Reporting event 6F (FDD): The UE Rx-Tx time difference for a RL included in the active set becomes larger than an absolute threshold ..... 1179
14.6.2.6a Reporting event 6F (1.28 Mcps TDD): The time difference indicated by $T_{ADV}$ becomes larger than an absolute threshold ..... 1180
14.6.2.7 Reporting event 6G: The UE Rx-Tx time difference for a RL included in the active set becomes less than an absolute threshold ..... 1180
14.7 UE positioning measurements ..... 1181
14.7.1 UE positioning measurement quantities ..... 1181
14.7.2 Void ..... 1181
14.7.3 UE positioning reporting events ..... 1181
14.7.3.1 Reporting Event 7a: The UE position changes more than an absolute threshold ..... 1181
14.7.3.2 Reporting Event 7b: SFN-SFN measurement changes more than an absolute threshold ..... 1182
14.7.3.3 Reporting Event 7c: GPS time and SFN time have drifted apart more than an absolute threshold ..... 1182
14.8 Void ..... 1183
14.9 Downlink power control ..... 1183
14.9.1 Generalities ..... 1183
14.9.2 Downlink power control in compressed mode ..... 1183
14.10 Calculated Transport Format Combination ..... 1184
14.10.1 Default TFCS for MBMS ..... 1184
14.10.1.1 S-CCPCH configuration including a FACH carrying MSCH ..... 1184
14.10.1.2 S-CCPCH configuration not including a FACH carrying MSCH ..... 1184
14.11 UE autonomous update of virtual active set on non-used frequency (FDD only) ..... 1185
14.11.1 Initial virtual active set ..... 1185
14.11.2 Virtual active set update during an inter-frequency measurement ..... 1186
14.12 Provision and reception of RRC information between network nodes ..... 1187
14.12.0 General ..... 1187
14.12.0a General error handling for RRC messages exchanged between network nodes ..... 1188
14.12.1 RRC Information to target RNC ..... 1189
14.12.2 RRC information, target RNC to source RNC ..... 1189
14.12.3 Void ..... 1191
14.12.4 RRC messages exchanged between network nodes ..... 1191
14.12.4.0 HANDOVER TO UTRAN COMMAND ..... 1191
14.12.4.0a INTER RAT HANDOVER INFO ..... 1191
14.12.4.1 INTER RAT HANDOVER INFO WITH INTER RAT CAPABILITIES ..... 1191
14.12.4.2 SRNS RELOCATION INFO ..... 1192
14.12.4.3 Void ..... 1205
14.12.4.4 RFC 3095 CONTEXT INFO ..... 1205
14.13 Void ..... 1208
14.14 Void ..... 1208

**Annex A (informative): USIM parameters ..... 1209**
A.1 Introduction ..... 1209
A.2 Ciphering information ..... 1209
A.3 Frequency information ..... 1209
A.4 Multiplicity values and type constraint values ..... 1210

**Annex B (informative): Description of RRC state transitions ..... 1211**
B.1 RRC states and state transitions including GSM ..... 1211
B.2 Transition from Idle Mode to UTRA RRC Connected Mode ..... 1211
B.2.1 Transitions for Emergency Calls ..... 1211
B.3 UTRA RRC Connected Mode States and Transitions ..... 1211
B.3.1 CELL_DCH state ..... 1211
B.3.1.1 Transition from CELL_DCH to Idle Mode ..... 1212
B.3.1.2 Transition from CELL_DCH to CELL_FACH state ..... 1212
B.3.1.3 Transition from CELL_DCH to CELL_PCH state ..... 1212
B.3.1.4 Transition from CELL_DCH to URA_PCH state ..... 1212
B.3.1.5 Radio Resource Allocation tasks (CELL_DCH) ..... 1212
B.3.1.6 RRC Connection mobility tasks (CELL_DCH) ..... 1213
B.3.1.7 UE Measurements (CELL_DCH) ..... 1213
B.3.1.8 Acquisition of system information (CELL_DCH) ..... 1213
B.3.2 CELL_FACH state ..... 1213
B.3.2.1 Transition from CELL_FACH to CELL_DCH state ..... 1213

B.3.2.2 Transition from CELL_FACH to CELL_PCH state ..... 1213
B.3.2.3 Transition from CELL_FACH to Idle Mode ..... 1213
B.3.2.4 Transition from CELL_FACH to URA_PCH State ..... 1213
B.3.2.5 Radio Resource Allocation Tasks (CELL_FACH) ..... 1214
B.3.2.6 RRC Connection mobility tasks (CELL_FACH) ..... 1214
B.3.2.7 UE Measurements (CELL_FACH) ..... 1214
B.3.2.8 Transfer and update of system information (CELL_FACH) ..... 1214
B.3.3 CELL_PCH state ..... 1215
B.3.3.1 Transition from CELL_PCH to CELL_FACH state ..... 1215
B.3.3.2 Radio Resource Allocation Tasks (CELL_PCH) ..... 1215
B.3.3.3 RRC Connection mobility tasks (CELL_PCH) ..... 1215
B.3.3.4 UE Measurements (CELL_PCH) ..... 1215
B.3.3.5 Transfer and update of system information (CELL_PCH) ..... 1215
B.3.4 URA_PCH State ..... 1216
B.3.4.1 Transition from URA_PCH State to CELL_FACH State (URA_PCH) ..... 1216
B.3.4.2 Radio Resource Allocation Tasks (URA_PCH) ..... 1216
B.3.4.3 RRC Connection mobility tasks (URA_PCH) ..... 1216
B.3.4.4 UE Measurements (URA_PCH) ..... 1216
B.3.4.5 Transfer and update of system information (URA_PCH) ..... 1217
B.3.5 States and Transitions for Cell Reselection in URA_PCH, CELL_PCH, and CELL_FACH ..... 1217
B.4 Inter-RAT handover with CS domain services ..... 1217
B.5 Inter-RAT handover with PS domain services ..... 1218
B.6 Inter-RAT handover with simultaneous PS and CS domain services ..... 1218
B.6.1 Inter-RAT handover UTRAN to GSM / BSS ..... 1218
B.6.2 Inter-RAT handover GSM / BSS to UTRAN ..... 1218

**Annex C (informative): Description for the Compressed Coding of Pre-defined configurations included in the INTER RAT HANDOVER INFO message ..... 1219**
C.1 Definitions ..... 1219
C.2 Examples of the methodology ..... 1219

**Annex D (Normative): Implementation of Domain Specific Access Control (DSAC) in UEs of 3GPP Release 5 ..... 1222**

**Annex E (informative): Change history ..... 1223**

History ..... 1251

# Foreword

This Technical Specification has been produced by the 3rd Generation Partnership Project (3GPP).

The contents of the present document are subject to continuing work within the TSG and may change following formal TSG approval. Should the TSG modify the contents of the present document, it will be re-released by the TSG with an identifying change of release date and an increase in version number as follows:

Version x.y.z

where:

- x the first digit:
  - 1 presented to TSG for information;
  - 2 presented to TSG for approval;
  - 3 or greater indicates TSG approved document under change control.
- y the second digit is incremented for all changes of substance, i.e. technical enhancements, corrections, updates, etc.
- z the third digit is incremented when editorial only changes have been incorporated in the document.

# 1 Scope

The present document specifies the Radio Resource Control protocol for the UE-UTRAN radio interface.

The scope of the present document also includes:

- the information to be transported in a transparent container between source RNC and target RNC in connection with SRNC relocation;
- the information to be transported in a transparent container between a target RNC and another system.

# 2 References

The following documents contain provisions which, through reference in this text, constitute provisions of the present document.

- References are either specific (identified by date of publication, edition number, version number, etc.) or non-specific.
- For a specific reference, subsequent revisions do not apply.
- For a non-specific reference, the latest version applies. In the case of a reference to a 3GPP document (including a GSM document), a non-specific reference implicitly refers to the latest version of that document *in the same Release as the present document*.

[1] 3GPP TR 21.905: "Vocabulary for 3GPP Specifications".

[2] 3GPP TS 25.301: "Radio Interface Protocol Architecture".

[3] 3GPP TS 25.303: "Interlayer Procedures in Connected Mode".

[4] 3GPP TS 25.304: "UE Procedures in Idle Mode and Procedures for Cell Reselection in Connected Mode".

[5] 3GPP TS 24.008: "Mobile radio interface layer 3 specification; Core Network Protocols; Stage 3".

[6] 3GPP TS 25.103: "RF parameters in support of RRM".

[7] 3GPP TS 25.215: "Physical layer – Measurements (FDD)".

[8] 3GPP TS 25.225: "Physical layer – Measurements (TDD)".

[9] 3GPP TS 25.401: "UTRAN overall description".

[10] 3GPP TS 25.402: "Synchronization in UTRAN; Stage 2".

[11] 3GPP TS 23.003: "Numbering, addressing and identification".

[12] ICD-GPS-200: "Navstar GPS Space Segment/Navigation User Interface".

[13] RTCM-SC104: "RTCM Recommended Standards for Differential GNSS Service (v.2.2)".

[14] 3GPP TR 25.921: "Guidelines and principles for protocol description and error handling".

[15] 3GPP TS 25.321: "Medium Access Control (MAC) protocol specification".

[16] 3GPP TS 25.322: "Radio Link Control (RLC) protocol specification".

[17] 3GPP TS 24.007: "Mobile radio interface signalling layer 3; General aspects".

[18] 3GPP TS 25.305: "Stage 2 Functional Specification of UE Positioning in UTRAN".

[19] 3GPP TS 25.133: "Requirements for Support of Radio Resource Management (FDD)".

[20] 3GPP TS 25.123: "Requirements for Support of Radio Resource Management (TDD)".

[21] 3GPP TS 25.101: "UE Radio Transmission and Reception (FDD)".

[22] 3GPP TS 25.102: "UE Radio Transmission and Reception (TDD)".

[23] 3GPP TS 23.060: "General Packet Radio Service (GPRS); Service description; Stage 2".

[24] 3GPP TS 23.032: "Universal Geographical Area Description (GAD)".

[25] 3GPP TS 23.122: "Non-Access-Stratum functions related to Mobile Station (MS) in idle mode".

[26] 3GPP TS 25.211: "Physical channels and mapping of transport channels onto physical channels (FDD)".

[27] 3GPP TS 25.212: "Multiplexing and channel coding (FDD)".

[28] 3GPP TS 25.213: "Spreading and modulation (FDD)".

[29] 3GPP TS 25.214: "Physical layer procedures (FDD)".

[30] 3GPP TS 25.221: "Physical channels and mapping of transport channels onto physical channels (TDD)".

[31] 3GPP TS 25.222: "Multiplexing and channel coding (TDD)".

[32] 3GPP TS 25.223: "Spreading and modulation (TDD)".

[33] 3GPP TS 25.224: "Physical Layer Procedures (TDD)".

[34] 3GPP TS 25.302: "Services provided by the physical layer ".

[35] 3GPP TS 25.306 "UE Radio Access Capabilities".

[36] 3GPP TS 25.323: "Packet Data Convergence Protocol (PDCP) Specification".

[37] 3GPP TS 25.324: "Broadcast/Multicast Control BMC".

[38] 3GPP TR 25.922: "Radio resource management strategies".

[39] 3GPP TR 25.925: "Radio interface for broadcast/multicast services".

[40] 3GPP TS 33.102: "3G Security; Security Architecture".

[41] 3GPP TS 34.108: "Common Test Environments for User Equipment (UE) Conformance Testing".

[42] 3GPP TS 34.123-2: "User Equipment (UE) conformance specification; Part 2: Implementation Conformance Statement (ICS) proforma specification".

[43] 3GPP TS 44.018: "Mobile radio interface layer 3 specification; Radio Resource Control Protocol".

[44] 3GPP TS 44.060: "General Packet Radio Service (GPRS); Mobile Station (MS) - Base Station System (BSS) interface; Radio Link Control/Medium Access Control (RLC/MAC) protocol".

[45] 3GPP TS 45.005: "Radio transmission and reception".

[46] 3GPP TS 45.008: "Radio subsystem link control".

[47] ITU-T Recommendation X.680 (07/2002) "Information Technology - Abstract Syntax Notation One (ASN.1): Specification of basic notation".

[48] ITU-T Recommendation X.681 (07/2002) "Information Technology - Abstract Syntax Notation One (ASN.1): Information object specification".

[49] ITU-T Recommendation X.691 (07/2002) "Information technology - ASN.1 encoding rules: Specification of Packed Encoding Rules (PER)".

[50] 3GPP TS 31.102: "Characteristics of the USIM Application".

[51] 3GPP TS 25.308: "High Speed Downlink Packet Access (HSDPA): Overall Description; Stage 2".

[52] IANA ROHC profile identifier definition (http://www.iana.org/assignments/rohc-pro-ids).

[53] 3GPP TS 44.118: "Mobile radio interface layer 3 specification; Radio Resource Control Protocol, Iu Mode".

[54] 3GPP TS 23.246: "Multimedia Broadcast Multicast Service; Architecture and Functional Description".

[55] 3GPP TS 25.346: " Introduction of the Multimedia Broadcast Multicast Service (MBMS) in the Radio Access Network (Stage-2)".

[56] 3GPP TR 25.992: "Multimedia Broadcast Multicast Service (MBMS); UTRAN/GERAN Requirements".

[57] 3GPP TS 25.413: "UTRAN Iu Interface RANAP Signalling".

[58] 3GPP TS 25.309: "FDD Enhanced Uplink; Overall Description; Stage 2".

# 3 Definitions and abbreviations

## 3.1 Definitions

For the purposes of the present document, the terms and definitions given in [1] apply, together as:

**Data Description Indicator (DDI)**: MAC-e header field used to identify the logical channel, MAC-d flow and the size of the MAC-d PDUs concatenated into a MAC-es PDU.

**E-DCH active set:** The set of cells which carry the E-DCH for one UE. Only radio links for which an E-HICH configuration is stored are considered part of the E-DCH active set.

**HARQ profile:** One HARQ profile consists of a power offset attribute and maximum number of transmissions.

MBMS activated services: the MBMS multicast services the UE has joined as well as the broadcast services the UE is interested in.

MCCH acquisition: the procedure for acquiring all MCCH information relevant for the UE ie. includes reception of the RB information for the UE"s MBMS activated services.

MBMS controlling cell: the cell from which the UE receives MCCH.

MBMS notification: a notification provided by UTRAN indicating a change in the provision of one or more MBMS services.

MBMS transmission: a possibly repeated session of an MBMS service. An MBMS transmission is uniquely identified by the combination of the MBMS service identity and the MBMS session identity.

**Primary Absolute Grant**: Absolute Grant received with the primary E-RNTI.

**Secondary Absolute Grant**: Absolute Grant received with the secondary E-RNTI.

**Serving E-DCH cell:** Cell from which the UE receives Absolute Grants from the Node-B scheduler. A UE has one Serving E-DCH cell.

**Serving E-DCH RLS or Serving RLS:** Set of cells which contains at least the Serving E-DCH cell and from which the UE can receive and combine one Relative Grant. The UE has only one Serving E-DCH RLS.

**Non-serving E-DCH RL or Non-serving RL:** Cell which belongs to the E-DCH active set but does not belong to the Serving E-DCH RLS and from which the UE can receive one Relative Grant. The UE can have zero, one or several Non-serving E-DCH RL(s).

## 3.2 Abbreviations

For the purposes of the present document, the following abbreviations apply:

| | |
|---|---|
| ACK | Acknowledgement |
| AG | Absolute Grant |
| AICH | Acquisition Indicator CHannel |
| AM | Acknowledged Mode |
| AS | Access Stratum |
| ASC | Access Service Class |
| ASN.1 | Abstract Syntax Notation.1 |
| BCCH | Broadcast Control Channel |
| BCFE | Broadcast Control Functional Entity |
| BER | Bit Error Rate |
| BLER | BLock Error Rate |
| BSS | Base Station Sub-system |
| CCCH | Common Control Channel |
| CCPCH | Common Control Physical CHannel |
| CH | Conditional on history |
| CM | Connection Management |
| CN | Core Network |
| C-RNTI | Cell RNTI |
| CTCH | Common Traffic CHannel |
| CTFC | Calculated Transport Format Combination |
| CV | Conditional on value |
| DCA | Dynamic Channel Allocation |
| DCCH | Dedicated Control Channel |
| DCFE | Dedicated Control Functional Entity |
| DCH | Dedicated Channel |
| DC-SAP | Dedicated Control SAP |
| DDI | Data Description Indicator |
| DGPS | Differential Global Positioning System |
| DL | Downlink |
| DSCH | Downlink Shared Channel |
| DTCH | Dedicated Traffic Channel |
| E-AGCH | E-DCH Absolute Grant Channel |
| E-DCH | Enhanced uplink DCH |
| E-DPCCH | E-DCH Dedicated Physical Control Channel |
| E-DPDCH | E-DCH Dedicated Physical Data Channel |
| E-HICH | E-DCH HARQ Acknowledgement Indicator Channel |
| E-RGCH | E-DCH Relative Grant Channel |
| E-RNTI | E-DCH RNTI |
| E-TFCI | E-DCH Transport Format Combination Indicator |
| FACH | Forward Access Channel |
| FDD | Frequency Division Duplex |
| F-DPCH | Fractional DPCH |
| GC-SAP | General Control SAP |
| GERAN | GSM/EDGE Radio Access Network |
| GRA | GERAN Registration Area |
| G-RNTI | GERAN Radio Network Temporary Identity |
| HARQ | Hybrid Automatic Repeat Request |
| HCS | Hierarchical Cell Structure |
| HFN | Hyper Frame Number |
| H-RNTI | HS-DSCH RNTI |
| HS-DSCH | High Speed Downlink Shared Channel |
| ID | Identifier |
| IDNNS | Intra Domain NAS Node Selector |
| IE | Information element |
| IETF | Internet Engineering Task Force |
| IMEI | International Mobile Equipment Identity |
| IMSI | International Mobile Subscriber Identity |

| | |
|---|---|
| IP | Internet Protocol |
| ISCP | Interference on Signal Code Power |
| L1 | Layer 1 |
| L2 | Layer 2 |
| L3 | Layer 3 |
| LAI | Location Area Identity |
| MAC | Media Access Control |
| MBMS | Multimedia Broadcast Multicast Service |
| MCC | Mobile Country Code |
| MCCH | MBMS point-to-multipoint Control Channel |
| MD | Mandatory default |
| MICH | MBMS notification Indicator Channel |
| MM | Mobility Management |
| MNC | Mobile Network Code |
| MP | Mandatory present |
| MTCH | MBMS point-to-multipoint Traffic Channel |
| MSCH | MBMS point-to-multipoint Scheduling Channel |
| NACC | Network Assisted Cell Change |
| NAS | Non Access Stratum |
| Nt-SAP | Notification SAP |
| NW | Network |
| OP | Optional |
| PCCH | Paging Control Channel |
| PCH | Paging Channel |
| PDCP | Packet Data Convergence Protocol |
| PDSCH | Physical Downlink Shared Channel |
| PDU | Protocol Data Unit |
| PLMN | Public Land Mobile Network |
| PNFE | Paging and Notification Control Functional Entity |
| PRACH | Physical Random Access CHannel |
| PSI | Packet System Information |
| p-t-m | Point-to-Multipoint |
| P-TMSI | Packet Temporary Mobile Subscriber Identity |
| p-t-p | Point-to-Point |
| PUSCH | Physical Uplink Shared Channel |
| QoS | Quality of Service |
| RAB | Radio access bearer |
| RACH | Random Access CHannel |
| RAI | Routing Area Identity |
| RAT | Radio Access Technology |
| RB | Radio Bearer |
| RFE | Routing Functional Entity |
| RG | Relative Grant |
| RL | Radio Link |
| RLC | Radio Link Control |
| RLS | Radio Link Set |
| RNC | Radio Network Controller |
| RNTI | Radio Network Temporary Identifier |
| RRC | Radio Resource Control |
| RSCP | Received Signal Code Power |
| RSN | Retransmission Sequence Number |
| RSSI | Received Signal Strength Indicator |
| SAP | Service Access Point |
| SCFE | Shared Control Function Entity |
| SCTD | Space Code Transmit Diversity |
| SCTO | Soft Combining Timing Offset (MBMS) |
| SF | Spreading Factor |
| SG | Serving grant |
| SHCCH | Shared Control Channel |
| SI | System Information |
| SIR | Signal to Interference Ratio |
| S-RNTI | SRNC - RNTI |

| | |
|---|---|
| TDD | Time Division Duplex |
| TF | Transport Format |
| TFCS | Transport Format Combination Set |
| TFS | Transport Format Set |
| TM | Transparent Mode |
| TME | Transfer Mode Entity |
| TMSI | Temporary Mobile Subscriber Identity |
| Tr | Transparent |
| TSN | Transmission Sequence Number |
| Tx | Transmission |
| UE | User Equipment |
| UL | Uplink |
| UM | Unacknowledged Mode |
| URA | UTRAN Registration Area |
| U-RNTI | UTRAN-RNTI |
| USCH | Uplink Shared Channel |
| UTRAN | Universal Terrestrial Radio Access Network |

# 4 General

If not specified differently, descriptions are relevant for both FDD and TDD. Descriptions for TDD only are relevant for both 1.28 Mcps TDD and 3.84 Mcps TDD and 7.68 Mcps TDD if not specified differently.

## 4.1 Overview of the specification

This specification is organised as follows:

- subclause 4.2 contains the description of the model of the RRC protocol layer;
- clause 5 lists the RRC functions and the services provided to upper layers;
- clause 6 lists the services expected from the lower layers and specifies the radio bearers available for usage by the RRC messages;
- clause 7 specifies the UE states for the Access Stratum, and also specifies the processes running in the UE in the respective states;
- clause 8 specifies RRC procedures, including UE state transitions;
- clause 9 specifies the procedures for the handling of unknown, unforeseen, and erroneous protocol data by the receiving entity;
- clause 10 describes the message in a Tabular format; these messages descriptions are referenced in clause 8;
- clause 11 specifies the encoding of the messages of the RRC protocol. This is based on the Tabular description in clause 10.
- clause 12 specifies the transfer syntax for RRC PDUs derived from the encoding definition;
- clause 13 lists the protocol timers, counters, constants and variables to be used by the UE;
- clause 14 specifies some of the processes applicable in UTRA RRC connected mode e.g. measurement processes, and also the RRC information to be transferred between network nodes. Note that not all the processes applicable in UTRA RRC connected mode are specified here i.e. some UTRA RRC connected mode processes are described in [4] e.g. cell re-selection;
- Annex A contains recommendations about the network parameters to be stored on the USIM;
- Annex B contains informative Stage 2 description of the RRC protocol states and state transitions.

The following figure summarises the mapping of UE states, including states in GSM, to the appropriate UTRA and GSM specifications that specify the UE behaviour.




**Figure 4.1-1: Mapping of UE state to 3GPP Specifications**

## 4.2 RRC Layer Model

The functional entities of the RRC layer are described below:

- Routing of higher layer messages to different MM/CM entities (UE side) or different core network domains (UTRAN side) is handled by the Routing Function Entity (**RFE**).

- Broadcast functions are handled in the broadcast control function entity (**BCFE**). The BCFE is used to deliver the RRC services, which are required at the GC-SAP. The BCFE can use the lower layer services provided by the Tr-SAP and UM-SAP.

- Paging of UEs that do not have an RRC connection is controlled by the paging and notification control function entity (**PNFE**). The PNFE is used to deliver the RRC services that are required at the Nt-SAP. The PNFE can use the lower layer services provided by the Tr-SAP and UM-SAP.

- The Dedicated Control Function Entity (**DCFE**) handles all functions specific to one UE. The DCFE is used to deliver the RRC services that are required at the DC-SAP and can use lower layer services of UM/AM-SAP and Tr-SAP depending on the message to be sent and on the current UE service state.

- In TDD mode, the DCFE is assisted by the Shared Control Function Entity (SCFE) location in the C-RNC, which controls the allocation of the PDSCH and PUSCH using lower layers services of UM-SAP and Tr-SAP.

- The Transfer Mode Entity (TME) handles the mapping between the different entities inside the RRC layer and the SAPs provided by RLC.

NOTE 1: Logical information exchange is necessary also between the RRC sublayer functional entities. Most of that is implementation dependent and not necessary to present in detail in a specification.

Figure 4.2-1 shows the RRC model for the UE and Figure 4.2-2 and Figure 4.2-3 show the RRC model for the UTRAN.

NOTE 2: The figure shows only the types of SAPs that are used. Multiple instances of Tr-SAP, UM-SAP and AM-SAP are possible. Especially, different functional entities usually use different instances of SAP types.




**Figure 4.2-1: UE side model of RRC**




**Figure 4.2-2: UTRAN side RRC model (DS-MAP system)**




**Figure 4.2-3: UTRAN side RRC model (DS-41 System)**

## 4.3 Protocol specification principles

This protocol specification is based on the applicable general guidelines given in [14].

In this specification, a notation of variables is used. The variables are defined in subclause 13.4. Variables are typically used to represent a status or a result of an action, such as reception of an information element in a message, which is used to specify a behaviour somewhere else in the specification, such as when setting the value of an information element in a transmitted message. The variables only serve the purpose of specifying the protocol, and do not therefore impose any particular implementation.

When specifying the UE behaviour at reception of messages, the behaviour that is tied to reception or non-reception of individual information elements, and in some cases combinations of information elements, is specified in one location (subclause 8.6).

# 5 RRC Functions and Services provided to upper layers

## 5.1 RRC Functions

The RRC performs the functions listed below. A more detailed description of these functions is provided in [2]:

- Broadcast of information related to the non-access stratum (Core Network);
- Broadcast of information related to the access stratum;
- Establishment, maintenance and release of an RRC connection between the UE and UTRAN;
- Establishment, reconfiguration and release p-t-p of Radio Bearers;
- Establishment, reconfiguration and release of p-t-m Radio Bearers;
- Assignment, reconfiguration and release of radio resources for the RRC connection;
- RRC connection mobility functions;
- Control of requested QoS;
- UE measurement reporting and control of the reporting;
- Outer loop power control;
- Control of ciphering;
- Slow DCA (TDD mode);
- Paging;
- Initial cell selection and cell re-selection;
- Arbitration of radio resources on uplink DCH;
- RRC message integrity protection;
- Timing advance (TDD mode);
- CBS control;
- MBMS control.

## 5.2 RRC Services provided to upper layers

The RRC offers the following services to upper layers, a description and primitives of these services are provided in [2] and [17].

- General Control;
- Notification;
- Dedicated control.

The RRC layer provides the UE-UTRAN portion of signalling connections to the upper layers to support the exchange of upper layer's information flow. The signalling connection is used between the user equipment and the core network to transfer upper layer information. For each core network domain, at most one signalling connection may exist at the same time. The RRC layer maps the signalling connections for one UE on a single RRC connection. For the upper layer data transfer on signalling connections, the RRC layer supports the discrimination between two different classes, named "High priority" (corresponding to "SAPI 0" for a GSM-MAP based core network) and "Low priority" (corresponding to "SAPI 3" for a GSM-MAP based core network).

## 5.3 Primitives between RRC and upper layers

The primitives between RRC and the upper layers are described in [17].

# 6 Services expected from lower layers

## 6.1 Services expected from Layer 2

The services provided by layer 2 are described in [2], [15] and [16].

## 6.2 Services expected from Layer 1

The services provided by layer 1 are described in [2].

## 6.3 Signalling Radio Bearers

The Radio Bearers (RB) available for transmission of RRC messages are defined as "signalling radio bearers" and are specified in the following. The UE and UTRAN shall select the signalling radio bearers for RRC messages using RLC-TM, RLC-UM or RLC-AM on the DCCH and CCCH, according to the following:

- Signalling radio bearer RB0 shall be used for all messages sent on the CCCH (UL: RLC-TM, DL: RLC-UM).
- Signalling radio bearer RB1 shall be used for all messages sent on the DCCH, when using RLC unacknowledged mode (RLC-UM).
- Signalling radio bearer RB2 shall be used for all messages sent on the DCCH, when using RLC acknowledged mode (RLC-AM), except for the RRC messages carrying higher layer (NAS) signalling.
- Signalling radio bearer RB3 and optionally Signalling radio bearer RB4 shall be used for the RRC messages carrying higher layer (NAS) signalling and sent on the DCCH in RLC acknowledged mode (RLC-AM), as specified in subclauses 8.1.8., 8.1.9 and 8.1.10.
- Additionally, RBs whose identities shall be set between 5 and 32 may be used as signalling radio bearer for the RRC messages on the DCCH sent in RLC transparent mode (RLC-TM).
- RRC messages on the SHCCH are mapped either on RACH or on the USCH in the uplink using TM and either on FACH or on the DSCH using RLC-UM. These messages are only specified for TDD mode.

- RRC messages on the MCCH are mapped on FACH using RLC-UM. The transport channel configuration for MCCH is indicated on BCCH. For this signalling radio bearer no identity is applied.
- RRC messages on the MSCH are mapped on FACH using RLC-UM. The transport channel configuration for MSCH is indicated on MCCH. For this signalling radio bearer no identity is applied.

The Radio Bearer configuration for signalling radio bearer RB0, SHCCH, BCCH on FACH, PCCH on PCH and BCCH mapped to BCH are specified in subclauses 13.6, 13.6a, 13.6b and 13.6c.

Ciphering is never applied to signalling radio bearer RB0 or signalling radio bearers using RLC TM.

# 7 Protocol states

## 7.1 Overview of RRC States and State Transitions including GSM

Figure 7.1-1 shows the RRC states in UTRA RRC Connected Mode, including transitions between UTRA RRC connected mode and GSM connected mode for CS domain services, and between UTRA RRC connected mode and GSM/GPRS packet modes for PS domain services. It also shows the transitions between Idle Mode and UTRA RRC Connected Mode and furthermore the transitions within UTRA RRC connected mode.




NOTE: 1: The indicated division within Idle Mode is only included for clarification and shall not be interpreted as states.

**Figure 7.1-1: RRC States and State Transitions including GSM**

The RRC connection is defined as a point-to-point bi-directional connection between RRC peer entities in the UE and the UTRAN characterised by the allocation of a U-RNTI. A UE has either zero or one RRC connection.

If NAS informs AS about a new selected PLMN, registered PLMN or equivalent PLMN list while being in connected mode, the UE shall perform the actions according to subclause 8.5.24.

NOTE: The state transitions are specified in clause 8.

# 7.2 Processes in UE modes/states

NOTE: This subclause specifies what processes shall be active in the UE in the different RRC modes/states. The related procedures and the conditions on which they are triggered are specified either in clause 8 or elsewhere in the relevant process definition.

## 7.2.1 UE Idle mode

UE processes that are active in UE Idle mode are specified in [4].

The UE shall perform a periodic search for higher priority PLMNs as specified in [25].

## 7.2.2 UTRA RRC Connected mode

In this specification unless otherwise mentioned "connected mode" shall refer to "UTRA RRC connected mode".

### 7.2.2.1 URA_PCH or CELL_PCH state

In the URA_PCH or CELL_PCH state the UE shall perform the following actions:

NOTE: Neither DCCH nor DTCH are available in these states.

1> if the UE is "in service area":

2> maintain up-to-date system information as broadcast by the serving cell as specified in the subclause 8.1.1;

2> perform cell reselection process as specified in [4];

2> perform a periodic search for higher priority PLMNs as specified in [25];

NOTE: If the DRX cycle length is 80ms, then a search for higher priority PLMNs may not identify all the available PLMNs due to the paging occasion on the current serving cell coinciding with the MIB of the cell of interest.

2> monitor the paging occasions and PICH monitoring occasions determined according to subclauses 8.6.3.1a and 8.6.3.2 and receive paging information on the PCH mapped on the S-CCPCH selected by the UE according to the procedure in subclause 8.5.19;

2> act on RRC messages received on PCCH and BCCH;

2> perform measurements process according to measurement control information as specified in subclause 8.4 and in subclause 14.4;

2> maintain up-to-date BMC data if it supports Cell Broadcast Service (CBS) as specified in [37];

2> act on RRC messages received on MCCH if it supports MBMS and has activated an MBMS service as specified in subclause 8.7;

2> run timer T305 for periodical URA update if the UE is in URA_PCH or for periodical cell update if the UE is in CELL_PCH.

1> if the UE is "out of service area":

2> perform cell selection process as specified in [4];

2> run timer T316;

2> run timer T305 or T307;

2> if the cell selection process fails to find a suitable cell after a complete scan of all RATs and all frequency bands supported by the UE, the UE shall after a minimum of TimerOutOfService time (default value 30 s) of being "out of service area":

3> indicate all available PLMNs to NAS to enable the selection of a new PLMN;

3> if an acceptable cell is found then the UE shall camp on that cell to obtain limited service as defined in [4] and, perform actions according to subclause 8.5.24;

3> else if no acceptable cell is found, the UE shall continue looking for an acceptable cell as defined in [4].

#### 7.2.2.2 CELL_FACH state

In the CELL_FACH state the UE shall perform the following actions:

NOTE: DCCH and, if configured, DTCH are available in this state.

1> if the UE is "in service area":

2> maintain up-to-date system information as broadcast by the serving cell as specified in subclause 8.1.1;

2> perform cell reselection process as specified in [4];

2> perform measurements process according to measurement control information as specified in subclause 8.4 and in subclause 14.4;

2> run timer T305 (periodical cell update);

2> select and configure the RB multiplexing options applicable for the transport channels to be used in this RRC state;

2> listen to all FACH transport channels mapped on the S-CCPCH selected by the UE according to the procedure in subclause 8.5.19;

2> act on RRC messages received on BCCH, CCCH and DCCH;

2> act on RRC messages received on MCCH if it supports MBMS and has activated an MBMS service as specified in subclause 8.7;

2> act on RRC messages received on, if available, SHCCH (TDD only).

1> if the UE is "out of service area":

2> perform cell selection process as specified in [4];

2> run timers T305 (periodical cell update), and T317 (cell update when re-entering "in service") or T307 (transition to Idle mode), if started;

2> run timers T314 and/or T315, if started;

2> if the cell selection process fails to find a suitable cell after a complete scan of all RATs and all frequency bands supported by the UE, the UE shall after a minimum of TimerOutOfService time (default value 30 seconds) of being "out of service area":

3> indicate all available PLMNs to NAS to enable the selection of a new PLMN;

3> if an acceptable cell is found then the UE shall camp on that cell to obtain limited service as defined in [4] and perform actions according to subclause 8.5.24;

3> else if no acceptable cell is found, the UE shall continue looking for an acceptable cell as defined in [4].

#### 7.2.2.3 CELL_DCH state

In the CELL_DCH state the UE shall perform the following actions:

NOTE: DCCH and, if configured, DTCH are available in this state.

1> read the system information as specified in subclause 8.1.1 (for UEs in TDD mode);

1> perform measurements process according to measurement control information as specified in subclause 8.4 and in clause 14;

1> select and configure the RB multiplexing options applicable for the transport channels to be used in this RRC state;

1> act on RRC messages received on DCCH;

1> act on RRC messages received on BCCH (applicable only to UEs with certain capabilities and in FDD mode);

1> act on RRC messages received on MCCH if it supports MBMS and has activated an MBMS service as specified in subclause 8.7 (applicable only to UEs supporting MBMS with certain capabilities);

1> act on RRC messages received on BCCH (TDD only) and, if available, SHCCH (TDD only).

NOTE: If any of the above procedures results in different HS-DSCH and E-DCH serving cells, the UE behaviour is unspecified.

# 8 RRC procedures

The UE shall be able to process several simultaneous RRC procedures. After the reception of a message which invoked a procedure, the UE shall be prepared to receive and act on another message which may invoke a second procedure. Whether this second invocation of a procedure (transaction) is accepted or rejected by the UE is specified in the subclauses of this clause, and in particular in subclause 8.6.3.11 (RRC transaction identifier).

On receiving a message the UE shall:

1> check that the message is addressed to the UE (e.g. by checking the IE "Initial UE identity" or the IE "U-RNTI" for messages on CCCH);

1> discard the messages addressed to other UEs.

and then the UE shall:

1> apply integrity check as appropriate;

1> proceed with error handling as specified in clause 9;

1> act upon the IE "RRC transaction identifier";

1> continue with the procedure as specified in the relevant subclause.

NOTE: Due to an error in the Release '99 ASN.1, a Release '99 UE is unable to determine which UE is addressed by a downlink CCCH message corresponding to a protocol version later than Release '99. As a result, the Release '99 UE will not be able to return a protocol error according to subclause 9.3a. Therefore, the UTRAN should only send a Release '99 message version towards UEs that have indicated conformance to Release '99 in the IE "Access stratum release indicator".

The RRC entity in the UE shall consider PDUs to have been transmitted when they are submitted to the lower layers. If the RRC entity in the UE submits a message for transmission using AM RLC, it shall consider the message successfully transmitted when UTRAN reception of all relevant PDUs is acknowledged by RLC. In the UE, timers are started when the PDUs are sent on the radio interface in the case of the transmission using the CCCH.

# 8.1 RRC Connection Management Procedures

## 8.1.1 Broadcast of system information




**Figure 8.1.1-1: Broadcast of system information**




**Figure 8.1.1-2: Notification of system information modification for UEs in idle mode, CELL_PCH state and URA_PCH state**




**Figure 8.1.1-3: Notification of system information modification for UEs in CELL_FACH and CELL_DCH(TDD only) state**

### 8.1.1.1 General

The purpose of this procedure is to broadcast system information from the UTRAN to UEs in a cell.

#### 8.1.1.1.1 System information structure

The system information elements are broadcast in *system information blocks*. A system information block groups together system information elements of the same nature. Different system information blocks may have different characteristics, e.g. regarding their repetition rate and the requirements on UEs to re-read the system information blocks.

The system information is organised as a tree. A *master information block* gives references and scheduling information to a number of system information blocks in a cell. The system information blocks contain the actual system information. The master information block may optionally also contain reference and scheduling information to one or two *scheduling blocks*, which give references and scheduling information for additional system information blocks. Scheduling information for a system information block may only be included in either the master information block or one of the scheduling blocks.

For all system information blocks except System Information Block types 15.2, 15.3 and 16, the content is the same in each occurrence for system information blocks using value tag. System Information Block types 15.2, 15.3 and 16 may occur more than once with different content. In this case scheduling information is provided for each such occurrence of the system information block. System information blocks that do not use value tag may have different content for each occurrence.

#### 8.1.1.1.2 System information blocks

Table 8.1.1 specifies all system information blocks and their characteristics.

The *area scope column* in table 8.1.1 specifies the area where a system information block's value tag is valid. If the area scope is *cell*, the UE shall consider the system information block to be valid only in the cell in which it was read. If system information blocks have been previously stored for this cell, the UE shall check whether the value tag for the system information block in the entered cell is different compared to the stored value tag. If the area scope is *PLMN* or *Equivalent PLMN*, the UE shall check the value tag for the system information block when a new cell is selected. If the value tag for the system information block in the new cell is different compared to the value tag for the system information block stored in the UE, the UE shall re-read the system information block. If the area scope is *PLMN*, the UE shall consider the system information block to be valid only within the PLMN in which it was read. If the area scope is *Equivalent PLMN*, the UE shall consider the system information block to be valid within the PLMN in which it was received and all PLMNs which are indicated by higher layers to be equivalent.

For System information block types 15.2, 15.3 and 16, which may have multiple occurrences, each occurrence has its own independent value tag. The UE- shall re-read a particular occurrence if the value tag of this occurrence has changed compared to that stored in the UE.

The *UE mode/state column when block is valid* in Table 8.1.1 specifies in which UE mode or UE state the IEs in a system information block shall be regarded as valid by the UE. In other words, the indicated system information block becomes invalid upon change to a mode/state that is not included in this column. System Information Block Type 16 remains also valid upon transition to or from GSM/GPRS. In some cases, the states are inserted in brackets to indicate that the validity is dependent on the broadcast of the associated System Information Blocks by the network as explained in the relevant procedure subclause.

The *UE mode/state column when block is read* in Table 8.1.1 specifies in which UE mode or UE state the IEs in a system information block may be read by the UE. The UE shall have the necessary information prior to execution of any procedure requiring information to be obtained from the appropriate system information block. The requirements on the UE in terms of when to read the system information may therefore be derived from the procedure specifications that specify which IEs are required in the different UE modes/states in conjunction with the different performance requirements that are specified.

The UE shall:

1> if System Information Block type 11 is referenced in the master information block or in the scheduling blocks:

2> if System Information Block type 12 is not referenced in the master information block or in the scheduling blocks , or broadcast of System Information Block type 12 is not indicated in System Information Block type 11:

3> have read and acted upon System Information Block type 11 in a cell when the UE transmits an RRC message on RACH.

2> else:

3> have read and acted upon System Information Block type 11 in a cell before the UE transmits the RRC CONNECTION REQUEST message.

3> have read and acted upon both System Information Block type 11 and System Information Block type 12 in a cell when:

4> the UE transmits an RRC message on RACH in RRC connected mode; or

4> the UE *receives a message commanding to enter Cell_DCH state.*

NOTE 1: There are a number of system information blocks that include the same IEs while the UE mode/state in which the information is valid differs. This approach is intended to allows the use of different IE values in different UE mode/states.

NOTE 2: System Information Block Type 16 is also obtained by a UE while in GSM/GPRS. The details of this are not within the scope of this specification.

The *Scheduling information* column in table 8.1.1 specifies the position and repetition period for the System Information Block.

The *modification of system information* column in table 8.1.1 specifies the update mechanisms applicable for a certain system information block. For system information blocks with a value tag, the UE shall update the information according to subclause 8.1.1.7.1 or 8.1.1.7.2. For system information blocks with an expiration timer, the UE shall, when the timer expires, perform an update of the information according to subclause 8.1.1.7.4.

**Table 8.1.1: Specification of system information block characteristics**

| System information block | Area scope | UE mode/state when block is valid | UE mode/state when block is read | Scheduling information | Modification of system information | Additional comment |
|---|---|---|---|---|---|---|
| Master information block | Cell | Idle mode, CELL_FACH, CELL_PCH, URA_PCH, CELL_DCH (TDD only) | Idle mode, CELL_FACH, CELL_PCH, URA_PCH, CELL_DCH (TDD only) | SIB_POS = 0 SIB_REP = 8 (FDD) SIB_REP = 8, 16, 32 (TDD) SIB_OFF=2 | Value tag | |
| Scheduling block 1 | Cell | Idle mode, CELL_FACH, CELL_PCH, URA_PCH, CELL_DCH (TDD only) | Idle mode, CELL_FACH, CELL_PCH, URA_PCH, CELL_DCH (TDD only) | Specified by the IE "Scheduling information" in MIB | Value tag | |
| Scheduling block 2 | Cell | Idle mode, CELL_FACH, CELL_PCH, URA_PCH, CELL_DCH (TDD only) | Idle mode, CELL_FACH, CELL_PCH, URA_PCH, CELL_DCH (TDD only) | Specified by the IE "Scheduling information" in MIB | Value tag | |
| System information block type 1 | PLMN | Idle mode CELL_FACH, CELL_PCH, URA_PCH, CELL_DCH | Idle, CELL_FACH, CELL_PCH, URA_PCH | Specified by the IE "Scheduling information" | Value tag | |
| System information block type 2 | Cell | URA_PCH | URA_PCH | Specified by the IE "Scheduling information" | Value tag | |
| System information block type 3 | Cell | Idle mode, (CELL_FACH, CELL_PCH, URA_PCH) | Idle mode, (CELL_FACH, CELL_PCH, URA_PCH) | Specified by the IE "Scheduling information" | Value tag | |
| System information block type 4 | Cell | CELL_FACH, CELL_PCH, URA_PCH | CELL_FACH, CELL_PCH, URA_PCH | Specified by the IE "Scheduling information" | Value tag | If System information block type 4 is not broadcast in a cell, the connected mode UE shall apply information in System information block type 3 in connected mode. |
| System information block type 5 and 5bis | Cell | Idle mode, (CELL_FACH, CELL_PCH, URA_PCH, CELL_DCH (TDD only)) | Idle mode, (CELL_FACH, CELL_PCH, URA_PCH, CELL_DCH (TDD only)) | Specified by the IE "Scheduling information" | Value tag | System information block type 5bis is sent instead of system information block type 5 in networks that use Band IV. |

| System information block | Area scope | UE mode/state when block is valid | UE mode/state when block is read | Scheduling information | Modification of system information | Additional comment |
|---|---|---|---|---|---|---|
| System information block type 6 | Cell | CELL_FACH, CELL_PCH, URA_PCH, CELL_DCH (TDD only) | CELL_FACH, CELL_PCH, URA_PCH, CELL_DCH (TDD only) | Specified by the IE "Scheduling information" | Value tag | If system information block type 6 is not broadcast in a cell, the connected mode UE shall read System information block type 5.<br><br>If some of the optional IEs are not included in System information block type 6, the UE shall read the corresponding IEs in System information block type 5<br><br>In TDD mode system information block 6 shall only be read in CELL_DCH if required for open loop power control as specified in subclause 8.5.7 and/or if shared transport channels are assigned to the UE. If in these cases system information block type 6 is not broadcast the UE shall read system information block type 5. |
| System information block type 7 | Cell | Idle mode, CELL_FACH, CELL_PCH, URA_PCH, CELL_DCH (TDD only) | Idle mode, CELL_FACH, CELL_PCH, URA_PCH, CELL_DCH (TDD only) | Specified by the IE "Scheduling information" | Expiration timer = MAX(32 , SIB_REP * ExpirationTimeFactor) | In TDD mode system information block type 7 shall only be read in CELL_DCH if shared transport channels are assigned to the UE. |
| System information block type 11 | Cell | Idle mode (CELL_FACH, CELL_PCH, URA_PCH, CELL_DCH) | Idle mode (CELL_FACH, CELL_PCH, URA_PCH) | Specified by the IE "Scheduling information" | Value tag | |
| System information block type 12 | Cell | CELL_FACH, CELL_PCH, URA_PCH, CELL_DCH | Idle mode, CELL_FACH, CELL_PCH, URA_PCH | Specified by the IE "Scheduling information" | Value tag | If system information block type 12 is not broadcast in a cell, the connected mode UE shall read System information block type 11.<br>If some of the optional IEs are not included in System information block type 12, the UE shall read the corresponding IEs in System information block type 11. |
| System information block type 13 | Cell | Idle Mode, CELL_FACH, CELL_PCH, URA_PCH | Idle Mode, CELL_FACH, CELL_PCH, URA_PCH | Specified by the IE "Scheduling information" | Value tag | |

| System information block | Area scope | UE mode/state when block is valid | UE mode/state when block is read | Scheduling information | Modification of system information | Additional comment |
|---|---|---|---|---|---|---|
| System information block type 13.1 | Cell | Idle Mode, CELL_FACH, CELL_PCH, URA_PCH | Idle Mode, CELL_FACH, CELL_PCH, URA_PCH | Specified by the IE "Scheduling information" | Value tag | |
| System information block type 13.2 | Cell | Idle Mode, CELL_FACH, CELL_PCH, URA_PCH | Idle Mode, CELL_FACH, CELL_PCH, URA_PCH | Specified by the IE "Scheduling information" | Value tag | |
| System information block type 13.3 | Cell | Idle Mode, CELL_FACH, CELL_PCH, URA_PCH | Idle Mode, CELL_FACH, CELL_PCH, URA_PCH | Specified by the IE "Scheduling information" | Value tag | |
| System information block type 13.4 | Cell | Idle Mode, CELL_FACH, CELL_PCH, URA_PCH | Idle Mode, CELL_FACH, CELL_PCH, URA_PCH | Specified by the IE "Scheduling information" | Value tag | |
| System information block type 14 | Cell | Idle Mode, CELL_FACH, CELL_PCH, URA_PCH, CELL_DCH | Idle Mode, CELL_FACH, CELL_PCH, URA_PCH, CELL_DCH | Specified by the IE "Scheduling information" | Expiration timer = MAX(32 , SIB_REP * ExpirationTimeFactor) | This system information block is used in 3.84 Mcps TDD and 7.68 Mcps TDD mode only. System information block type 14 shall only be read in CELL_DCH if required for open loop power control as specified in subclause 8.5.7. |
| System information block type 15 | Cell | Idle Mode, CELL_FACH, CELL_PCH, URA_PCH | Idle Mode, CELL_FACH, CELL_PCH, URA_PCH | Specified by the IE "Scheduling information" | Value tag | |
| System information block type 15.1 | Cell | Idle Mode, CELL_FACH, CELL_PCH, URA_PCH | Idle Mode, CELL_FACH, CELL_PCH, URA_PCH | Specified by the IE "Scheduling information" | Value tag | |
| System information block type 15.2 | Cell | Idle Mode, CELL_FACH, CELL_PCH, URA_PCH | Idle Mode, CELL_FACH, CELL_PCH, URA_PCH | Specified by the IE "Scheduling information" | Value tag | For this system information block there may be multiple occurrences |
| System information block type 15.3 | PLMN | Idle Mode, CELL_FACH, CELL_PCH, URA_PCH | Idle Mode, CELL_FACH, CELL_PCH, URA_PCH | Specified by the IE "Scheduling information" | Value tag | For this system information block there may be multiple occurrences |
| System information block type 15.4 | Cell | Idle Mode, CELL_FACH, CELL_PCH, URA_PCH | Idle Mode, CELL_FACH, CELL_PCH, URA_PCH | Specified by the IE "Scheduling information" | Value tag | |
| System information block type 15.5 | Cell | Idle Mode, CELL_FACH, CELL_PCH, URA_PCH | Idle Mode, CELL_FACH, CELL_PCH, URA_PCH | Specified by the IE "Scheduling information" | Value tag | |
| System information block type 16 | Equivalent PLMN | Idle Mode, CELL_FACH, CELL_PCH, URA_PCH, CELL_DCH | Idle Mode, CELL_FACH, CELL_PCH, URA_PCH | Specified by the IE "Scheduling information" | Value tag | For this system information block there may be multiple occurrences. This system information block is also valid while in GSM/GPRS. |

| System information block | Area scope | UE mode/state when block is valid | UE mode/state when block is read | Scheduling information | Modification of system information | Additional comment |
|---|---|---|---|---|---|---|
| System information block type 17 | Cell | CELL_FACH, CELL_PCH, URA_PCH, CELL_DCH | CELL_FACH, CELL_PCH, URA_PCH, CELL_DCH | Specified by the IE "Scheduling information" | Expiration timer = SIB_REP | This system information block is used in TDD mode only. System information block type 17 shall only be read if shared transport channels are assigned to the UE. |
| System Information Block type 18 | Cell | Idle mode, CELL_FACH, CELL_PCH, URA_PCH, CELL_DCH | Idle mode, CELL_FACH, CELL_PCH, URA_PCH | Specified by the IE "Scheduling information" | Value tag | |

#### 8.1.1.1.3 Segmentation and concatenation of system information blocks

A generic SYSTEM INFORMATION message is used to convey the system information blocks on the BCCH. A given BCCH may be mapped onto either a BCH or a FACH transport channel according to subclause 8.1.1.1.2. The size of the SYSTEM INFORMATION message shall fit the size of a BCH or a FACH transport block.

The RRC layer in UTRAN performs segmentation and concatenation of encoded system information blocks. If the encoded system information block is larger than the size of a SYSTEM INFORMATION message, it will be segmented and transmitted in several messages. If the encoded system information block is smaller than a SYSTEM INFORMATION message, UTRAN may concatenate several system information blocks, or the first segment or the last segment into the same message as specified in the remainder of this clause.

Four different segment types are defined:

- First segment;
- Subsequent segment;
- Last segment;
- Complete.

Each of the types - *First*, *Subsequent* and *Last segment* - is used to transfer segments of a master information block, scheduling block or a system information block. The segment type, *Complete,* is used to transfer a complete master information block, complete scheduling block or a complete system information block.

Each segment consists of a header and a data field. The data field carries the encoded system information elements. The header contains the following parameters:

- The number of segments in the system information block (SEG_COUNT). This parameter is only included in the header if the segment type is "First segment".
- SIB type. The SIB type uniquely identifies the master information block, scheduling block or a system information block.
- Segment index. This parameter is only included in the header if the segment type is "Subsequent segment" or "Last segment".

UTRAN may combine one or several segments of variable length in the same SYSTEM INFORMATION message. The following combinations are allowed:

1. No segment;
2. First segment;
3. Subsequent segment;

4. Last segment;
5. Last segment + First segment;
6. Last segment + one or several Complete;
7. Last segment + one or several Complete + First segment;
8. One or several Complete;
9. One or several Complete + First segment;
10. One Complete of size 215 to 226;
11. Last segment of size 215 to 222.

The "No segment" combination is used when there is no master information block, scheduling block or system information block scheduled for a specific BCH transport block.

UEs are not required to support the reception of multiple occurrences of the same system information block type within one SYSTEM INFORMATION message.

NOTE: Since the SIB type is the same for each occurrence of the system information block, the UE does not know the order in which the occurrences, scheduled for this SYSTEM INFORMATION message, appear. Therefore, the UE is unable to determine which scheduling information, e.g., value tag relates to which occurrence of the system information block.

#### 8.1.1.1.4 Re-assembly of segments

The RRC layer in the UE shall perform re-assembly of segments. All segments belonging to the same master information block, scheduling block or system information block shall be assembled in ascending order with respect to the segment index. When all segments of the master information block, scheduling block or a system information block have been received, the UE shall perform decoding of the complete master information block, scheduling block or system information block. For System Information Block types 15.2, 15.3 and 16, which may have multiple occurrences, each occurrence shall be re-assembled independently.

The UE shall discard system information blocks of which segments were missing, of which segments were received out of sequence and/or for which duplicate segments were received. The only valid sequence is an ascending one with the sequence starting with the First Segment of the associated System Information Block.

If the UE receives a Subsequent segment or Last segment where the index in IE "Segment index" is equal to or larger than the number of segments stated in IE "SEG_COUNT" in the scheduling information for that scheduling block or system information block:

1> the UE may:

2> read all the segments to create a system information block as defined by the scheduling information read by the UE;

2> store the content of the system information block with a value tag set to the value NULL; and

2> consider the content of the scheduling block or system information block as valid:

3> until it receives the same type of scheduling block or system information block in a position according to its scheduling information; or

3> at most for 6 hours after reception.

1> and the UE shall:

2> re-read scheduling information for that scheduling block or system information block.

If the UE receives a Subsequent segment or Last segment where the index in IE "Segment index" is equal to or larger than the number of segments stated in IE "SEG_COUNT" in the First segment, the UE shall

1> discard all segments for that master information block, scheduling block or system information block; and

1> re-read the scheduling information for that system information block;

1> then re-read all segments for that system information block.

#### 8.1.1.1.5 Scheduling of system information

Scheduling of system information blocks is performed by the RRC layer in UTRAN. If segmentation is used, it should be possible to schedule each segment separately.

To allow the mixing of system information blocks with short repetition period and system information blocks with segmentation over many frames, UTRAN may multiplex segments from different system information blocks. Multiplexing and de-multiplexing is performed by the RRC layer.

The scheduling of each system information block broadcast on a BCH transport channel is defined by the following parameters:

- the number of segments (SEG_COUNT);
- the repetition period (SIB_REP). The same value applies to all segments;
- the position (phase) of the first segment within one cycle of the Cell System Frame Number (SIB_POS(0)). Since system information blocks are repeated with period SIB_REP, the value of SIB_POS(i), i = 0, 1, 2, … SEG_COUNT-1 must be less than SIB_REP for all segments;
- the offset of the subsequent segments in ascending index order (SIB_OFF(i), i = 1, 2, … SEG_COUNT-1) The position of the subsequent segments is calculated using the following: SIB_POS(i) = SIB_POS(i-1) + SIB_OFF(i).

The scheduling is based on the Cell System Frame Number (SFN). The SFN of a frame at which a particular segment, *i*, with i = 0, 1, 2, … SEG_COUNT-1 of a system information block occurs, fulfils the following relation:

$$SFN \bmod SIB_REP = SIB_POS(i)$$

In FDD and TDD the scheduling of the master information block is fixed as defined in table 8.1.1. For TDD, UTRAN may apply one of the values allowed for the master information block's repetition period. The value that UTRAN is using in TDD is not signalled; UEs have to determine it by trial and error.

### 8.1.1.2 Initiation

The system information is continuously broadcast on a regular basis in accordance with the scheduling defined for each system information block.

### 8.1.1.3 Reception of SYSTEM INFORMATION messages by the UE

The UE shall read SYSTEM INFORMATION messages broadcast on a BCH transport channel in idle mode and in the connected mode in states CELL_FACH, CELL_PCH, URA_PCH and CELL_DCH (TDD only). In addition, UEs in FDD mode which support simultaneous reception of one SCCPCH and one DPCH shall read system information on a FACH transport channel when in CELL_DCH state.

In idle mode and connected mode different combinations of system information blocks are valid. The UE shall acquire the system information blocks that are needed according to table 8.1.1.

The UE may store system information blocks with *cell*, *PLMN* or *Equivalent PLMN* area scope (including their value tag if applicable) for different cells and different PLMNs, to be used if the UE returns to these cells.

The UE shall consider all stored system information blocks as invalid after it has been switched off. Some information obtained from system information may be stored by the UE or in the USIM for use in a stored information cell selection.

When selecting a new cell the UE shall consider all current system information blocks with area scope cell to be invalid. If the UE has stored valid system information blocks for the newly selected cell, the UE may set those as current system information blocks.

After selecting a new cell and this cell broadcasts an IE "PLMN Identity" in the MIB which is different from the IE "PLMN Identity" broadcast in the MIB in the previously selected cell, the UE shall consider all current system information blocks with area scope *PLMN* to be invalid. If the UE has previously stored valid system information blocks for the selected cell of the new PLMN, the UE may set those as current system information blocks.

When NAS informs AS about a new selected PLMN, the UE shall consider all stored system information blocks with area scope *Equivalent PLMN* to be invalid.

#### 8.1.1.4 Void

#### 8.1.1.5 Actions upon reception of the Master Information Block and Scheduling Block(s)

When selecting a new cell, the UE shall read the master information block. The UE may use the pre-defined scheduling information to locate the master information block in the cell.

Upon reception of the master information block, the UE shall:

1> if the IE "Multiple PLMN List" is not present in the Master Information Block:

2> consider the IE "PLMN identity" in the Master Information Block as the PLMN identity of the cell.

1> else:

2> consider the PLMN identities in the IE "Multiple PLMN List" as the PLMN identities of the cell;

2> when reading the "Multiple PLMN List", read all the PLMN identities in the list as follows:

3> if the IE "MIB PLMN Identity" is set to TRUE:

4> read the "PLMN identity" IE in the MIB and consider it as a part of the "Multiple PLMN List".

3> if the IE "MIB PLMN Identity" is set to FALSE:

4> not consider the "PLMN identity" IE in the MIB as a part of the "Multiple PLMN List";

4> not consider the IE "PLMN identity" in the MIB as a PLMN identity of the cell;

4> not forward the PLMN in the IE "PLMN identity" of the MIB to upper layers.

3> if the MCC is not present when reading a IE "PLMN identity with Optional MCC" in the IE "Multiple PLMN List":

4> set the MCC of this PLMN identity equal to the MCC of the closest preceding "PLMN identity with Optional MCC" in the "Multiple PLMN List" that includes an MCC;

4> or, if no such "PLMN identity with Optional MCC" exists, the UE shall set the MCC of this PLMN identity to the MCC of the "PLMN identity" IE in the Master Information Block irrespective of the value of the IE "MIB PLMN Identity".

1> if the UE is operating in "ANSI-41 mode" and the IE "PLMN Type" has the value "ANSI-41" or "GSM-MAP and ANSI-41":

2> store the ANSI-41 Information elements contained in the master information block and perform initial process for ANSI-41.

1> compare the value tag in the master information block with the value tag stored for this cell and this PLMN in the variable VALUE_TAG;

1> if the value tags differ, or if no IEs for the master information block are stored:

2> store the value tag into the variable VALUE_TAG for the master information block;

2> read and store scheduling information included in the master information block.

1> if the value tags are the same the UE may use stored system information blocks and scheduling blocks using value tag that were stored for this cell and this PLMN as valid system information.

For all system information blocks or scheduling blocks that are supported by the UE referenced in the master information block or the scheduling blocks, the UE shall perform the following actions:

1> for all system information blocks with area scope "PLMN" or "Equivalent PLMN" that use value tags:

2> compare the value tag read in scheduling information for that system information block with the value stored within the variable VALUE_TAG for that system information block;

2> if the value tags differ, or if no IEs for the corresponding system information block are stored:

3> store the value tag read in scheduling information for that system information block into the variable VALUE_TAG;

3> read and store the IEs of that system information block.

2> if the value tags are the same the UE may use stored system information blocks using value tag that were stored in this PLMN as valid system information.

1> for all system information blocks or scheduling blocks with area scope cell that use value tags:

2> compare the value tag read in scheduling information for that system information block or scheduling block with the value stored within the variable VALUE_TAG for that system information block or scheduling block;

2> if the value tags differ, or if no IEs for the corresponding system information block or scheduling block are stored:

3> store the value tag read in scheduling information for that system information block or scheduling block into the variable VALUE_TAG;

3> read and store the IEs of that system information block or scheduling block.

2> if the value tags are the same the UE may use stored system information blocks using value tags that were stored for this cell and this PLMN as valid system information.

1> for system information blocks which may have multiple occurrences:

2> compare the value tag and the configuration or multiple occurrence identity for the occurrence of the system information blocks read in scheduling information with the value tag and configuration or multiple occurrence identity stored within the variable VALUE_TAG:

3> if the value tags differ, or if no IEs from the occurrence with that configuration or multiple occurrence identity of the system information block are stored:

4> store the value tag read in scheduling information for that system information block and the occurrence with that configuration or multiple occurrence identity into the variable VALUE_TAG;

4> read and store the IEs of that system information block.

3> if the value tags and the configuration or multiple occurrence identity are identical to those stored, the UE may use stored occurrences of system information blocks that were stored for this cell and this PLMN as valid system information.

For system information blocks, not supported by the UE, but referenced either in the master information block or in the scheduling blocks, the UE may:

1> skip reading this system information block;

1> skip monitoring changes to this system information block.

If the UE:

1> receives a scheduling block at a position different from its position according to the scheduling information for the scheduling block; or

1> receives a scheduling block for which scheduling information has not been received:

the UE may:

1> store the content of the scheduling block with a value tag set to the value NULL; and

1> consider the content of the scheduling block as valid until it receives the same type of scheduling block in a position according to its scheduling information or at most for 6 hours after reception.

If the UE does not find a scheduling block in a position where it should be according to its scheduling information, but a transport block with correct CRC was found at that position, the UE shall:

1> read the scheduling information for this scheduling block.

If the UE does not find the master information block in a position fulfilling:

$$SFN \bmod 32 = 0$$

but a transport block with correct CRC was found at that position), the UE shall:

1> consider the master information block as not found; and

1> consider the cell to be barred according to [4]; and

1> consider the barred cell as using the value "allowed" in the IE "Intra-frequency cell re-selection indicator", and the maximum value in the IE "$T_{barred}$".

NOTE: This permits a different repetition for the MIB in later versions for FDD. In TDD it allows for a variable SIB_REP in this and future releases.

If system information block type 1 is not scheduled on BCH, and system information block type 13 is not scheduled on BCH, the UE shall:

1> consider the cell to be barred according to [4]; and

1> consider the barred cell as using the value "allowed" in the IE "Intra-frequency cell re-selection indicator", and the maximum value in the IE "$T_{barred}$".

If the UE only supports GSM-MAP but finds a cell that broadcasts System Information Block type 13 but not System Information Block type 1, the UE shall:

1> consider the cell barred.

If:

- system information block type 1 is not scheduled on BCH; and
- the UE is operating in "GSM-MAP mode"; and
- the IE "PLMN type" in the Master Information Block has the value "GSM-MAP" or "GSM-MAP and ANSI-41":

the UE shall:

1> indicate to upper layers that no CN system information is available.

If in idle mode and System Information Block type 3 is not scheduled on BCH, the UE shall:

1> consider the cell to be barred according to [4]; and

1> consider the barred cell as using the value "allowed" in the IE "Intra-frequency cell re-selection indicator", and the maximum value in the IE "$T_{barred}$".

If in connected mode and System Information Block type 3 is not scheduled on BCH, and System Information Block type 4 is not scheduled on BCH, the UE shall:

1> consider the cell to be barred according to [4]; and

1> consider the barred cell as using the value "allowed" in the IE "Intra-frequency cell re-selection indicator", and the maximum value in the IE "$T_{barred}$".

If in idle mode and neither System Information Block type 5 nor type 5bis is scheduled on BCH, or System Information Block type 5 or type 5bis is scheduled but IE "AICH info" (FDD) or IE "PICH info" is not present, the UE shall:

1> consider the cell to be barred according to [4]; and

1> consider the barred cell as using the value "allowed" in the IE "Intra-frequency cell re-selection indicator", and the maximum value in the IE "$T_{barred}$".

If in connected mode and neither System Information Block type 5 nor type 5bis is scheduled on BCH, and System Information Block type 6 is not scheduled on BCH, or any of System Information Block type 5, type 5bis or type 6 is scheduled but IE "AICH info" (FDD) or IE "PICH info" is not present, the UE shall:

1> consider the cell to be barred according to [4]; and

1> consider the barred cell as using the value "allowed" in the IE "Intra-frequency cell re-selection indicator", and the maximum value in the IE "$T_{barred}$".

If System Information Block type 7 is not scheduled on BCH, the UE shall:

1> consider the cell to be barred according to [4]; and

1> consider the barred cell as using the value "allowed" in the IE "Intra-frequency cell re-selection indicator", and the maximum value in the IE "$T_{barred}$".

In 3.84 Mcps TDD and 7.68 Mcps TDD, if System Information Block type 14 is not scheduled on BCH, the UE shall:

1> consider the cell to be barred according to [4]; and

1> consider the barred cell as using the value "allowed" in the IE "Intra-frequency cell re-selection indicator", and the maximum value in the IE "$T_{barred}$".

#### 8.1.1.6 Actions upon reception of system information blocks

The UE may use the scheduling information included within the master information block and the scheduling blocks to locate each system information block to be acquired.

The UE should only expect one occurrence of the scheduling information for a system information block in the master information block and any of the scheduling blocks except for System Information Block type 16, System Information Block type 15.2 and System Information Block type 15.3, which may have multiple occurrences. However, to enable future introduction of new system information blocks, the UE shall also be able to receive system information blocks other than the ones indicated within the scheduling information. The UE may ignore contents of such system information block.

If the UE:

1> receives a system information block in a position according to the scheduling information for the system information block; and

1> this system information block uses a value tag; or

1> this system information block uses a value tag and configuration or multiple occurrence identity:

the UE shall:

1> store the content of the system information block together with the value of its value tag or the values of configuration and multiple occurrence identity and the associated value tag in the scheduling information for the system information block; and

1> consider the content of the system information block valid until, if used, the value tag in the scheduling information for the system information block is changed or at most for 6 hours after reception.

If the UE:

1> receives a system information block in a position according to the scheduling information for the system information block; and

1> this system information block does not use a value tag according to the system information block type:

the UE shall:

1> store the content of the system information block; and

1> start an expiration timer using a value as defined in Table 8.1.1 for that system information block type; and

1> consider the content of the system information block valid until, the expiration timer expires.

If the UE:

1> receives a system information block at a position different from its position according to the scheduling information for the system information block; or

1> receives a system information block for which scheduling information has not been received; and

1> this system information block uses a value tag:

the UE may:

1> store the content of the system information block with a value tag set to the value NULL; and

1> consider the content of the system information block as valid until it receives the same type of system information block in a position according to its scheduling information or at most for 6 hours after reception.

If the UE:

1> receives a system information block with multiple occurrences at a position different from its position according to the scheduling information for the system information block; or

1> receives a system information block with multiple occurrences for which scheduling information has not been received; and

1> this system information block uses a value tag and configuration or multiple occurrence identity:

the UE shall:

1> ignore this information.

If the UE does not find a system information block in a position where it should be according to its scheduling information, but a transport block with correct CRC was found at that position, the UE shall read the scheduling information for this system information block.

The UE shall act upon all received information elements as specified in subclause 8.6 unless specified otherwise in the following subclauses.

#### 8.1.1.6.1 System Information Block type 1

The UE should store all relevant IEs included in this system information block if the UE is operating in "GSM-MAP mode" and the IE "PLMN type" in the Master Information Block has the value "GSM-MAP" or "GSM-MAP and ANSI-41". The UE shall also:

1> check that the cell, according to information included in IE "CN common GSM-MAP NAS system information", is suitable [4];

1> if in connected mode:

2> not forward the content of the IE "CN common GSM-MAP NAS system information" to upper layers.

1> if in idle mode:

2> forward the content of the IE "CN common GSM-MAP NAS system information" to upper layers.

1> for the IE "CN domain system information list":

2> for each IE "CN domain system information" that is present:

3> check that the cell, according to information included in IE "CN domain specific NAS system information", is suitable [4];

3> if in connected mode:

4> not forward the content of the IE "CN domain specific NAS system information" to upper layers.

3> if in idle mode:

4> forward the content of the IE "CN domain specific NAS system information" and the IE "CN domain identity" to upper layers;

4> use the IE "CN domain specific DRX cycle length coefficient" to calculate frame number for the Paging Occasions as specified in [4];

4> store the value of the IE "CN domain specific DRX cycle length coefficient" for use in connected mode.

2> if an IE "CN domain system information" is not present for a particular CN domain:

3> if in idle mode:

4> indicate to upper layers that no CN system information is available for that CN domain.

1> if the UE has not yet entered UTRA RRC connected mode:

2> store the values of the IE "UE Timers and constants in connected mode" in the variable TIMERS_AND_CONSTANTS.

1> use the values stored in the variable TIMERS_AND_CONSTANTS for the relevant timers and constants.

#### 8.1.1.6.2 System Information Block type 2

If in connected mode the UE should store all relevant IEs included in this system information block. The UE shall:

1> if in state URA_PCH, start to perform URA updates using the information in the IE "URA identity".

If in idle mode, the UE shall not use the values of the IEs in this system information block.

#### 8.1.1.6.3 System Information Block type 3

The UE should store all relevant IEs included in this system information block. The UE shall:

1> if in connected mode, and System Information Block 4 is indicated as used in the cell:

2> read and act on information sent in that block.

With respect to Domain Specific Access Control, the UE shall:

1> if the IE "Multiple PLMN List" is not included in the Master Information Block:

2> apply the domain specific access restrictions as indicated by the IE "Domain Specific Access Restriction Parameters For PLMN Of MIB".

1> else:

2> if the PLMN specified by the IE "PLMN Identity" of the Master Information Block is chosen by the UE:

3> apply the domain specific access restrictions as indicated by the IE "Domain Specific Access Restriction Parameters For PLMN Of MIB".

2> else, if N-th (N=1..5) PLMN in the IE "Multiple PLMNs" contained in the IE "Multiple PLMN List" is chosen by the UE:

3> if the IE "Domain Specific Access Restriction List" of the IE "Domain Specific Access Restriction For Shared Network" is indicated:

4> if the IE "Domain Specific Access Restriction Parameters For OperatorN" is indicated:

5> apply the domain specific access restrictions as indicated by the IE "Domain Specific Access Restriction Parameters For OperatorN".

3> else, if the IE "Domain Specific Access Restriction Parameters For All" of the IE "Domain Specific Access Restriction For Shared Network" is indicated:

4> apply the domain specific access restrictions as indicated by the IE "Domain Specific Access Restriction Parameters For All".

The UE shall apply the following handling with respect to any Access Class Barring information:

1> if in idle mode and any Access Class Barring information is indicated:

2> if no Domain Specific Access Restriction Parameters are included in System Information Block Type 3, the UE shall:

3> act on the IE "Access Class Barred list" when initiating RRC Connection establishment as specified in [4].

2> if the Domain Specific Access Restriction Parameters to be applied are included in System Information Block Type 3 the UE shall:

3> act on the IE "Domain Specific Access Class Barred List" if indicated in the IE "CS Domain Specific Access Restriction" when initiating RRC Connection establishment to send an INITIAL DIRECT TRANSFER message to the CS domain, as specified in [4];

3> act on the IE "Domain Specific Access Class Barred List" if indicated in the IE "PS Domain Specific Access Restriction" when initiating RRC Connection establishment to send an INITIAL DIRECT TRANSFER message to the PS domain, as specified in [4];

3> upon transition to UTRA RRC connected, the UE shall:

4> store that Domain Specific Access Restriction Parameters to the variable "DSAC_PARAM" and maintain the variable until it is cleared, the PLMN chosen by the UE is changed or the RRC connection is released;

4> act on the stored IE "Domain Specific Access Class Barred List" if indicated in the IE "CS Domain Specific Access Restriction" when initiating an INITIAL DIRECT TRANSFER message to the CS domain, as specified in [4];

4> act on the stored IE "Domain Specific Access Class Barred List" if indicated in the IE "PS Domain Specific Access Restriction" when initiating an INITIAL DIRECT TRANSFER message to the PS domain, as specified in [4];

1> if in connected mode:

2> if no Access Class Barring information is indicated:

3> if the variable "DSAC_PARAM" is set, the UE shall

4> clear the variable "DSAC_PARAM";

4> act as if no Access Class is barred.

2> else if the Domain Specific Access Restriction Parameters to be applied is not included in System Information Block Type 3:

3> if the variable "DSAC_PARAM" is set, the UE shall:

4> clear the variable "DSAC_PARAM";

4> act as if no Access Class is barred.

2> else if the Domain Specific Access Restriction Parameters to be applied are included in the System Information Block Type 3:

3> if the variable "DSAC_PARAM is not set, the UE shall:

4> store that Domain Specific Access Restriction Parameters to the variable "DSAC_PARAM" and maintain the variable until it is cleared, the PLMN chosen by the UE is changed or the RRC connection is released;

4> act on the stored IE "Domain Specific Access Class Barred List" if indicated in the IE "CS Domain Specific Access Restriction" when initiating an INITIAL DIRECT TRANSFER message to the CS, as specified in [4];

4> act on the stored IE "Domain Specific Access Class Barred List" if indicated in the IE "PS Domain Specific Access Restriction" when initiating an INITIAL DIRECT TRANSFER message to the PS domain, as specified in [4].

3> else (the access class barring information is stored) UE shall:

4> update the variable "DSAC_PARAM" with that Domain Specific Access Restriction Parameters;

4> act on the updated IE "Domain Specific Access Class Barred List" if indicated in the IE "CS Domain Specific Access Restriction" when initiating an INITIAL DIRECT TRANSFER message to the CS domain, as specified in [4];

4> act on the updated IE "Domain Specific Access Class Barred List" if indicated in the IE "PS Domain Specific Access Restriction" when initiating an INITIAL DIRECT TRANSFER message to the PS domain, as specified in [4].

#### 8.1.1.6.4 System Information Block type 4

If in connected mode, the UE should store all relevant IEs included in this system information block. The UE shall:

1> if in connected mode:

2> read and act on information sent in this block;

2> read the System Information Block Type 3 for any Access Class Barring information and act on that information as described in subclause 8.1.1.6.3.

If in idle mode, the UE shall not use the values of the IEs included in this system information block.

#### 8.1.1.6.5 System Information Block type 5 and 5bis

The UE should store all relevant IEs included in this system information block. The UE shall:

1> if the IE "Frequency band indicator" is included and if the frequency band indicated in the IE is not part of the frequency bands supported in the UE radio access capability; or

1> if the IE "Frequency band indicator 2" is included and if the frequency band indicated in the IE is not part of the frequency bands supported in the UE radio access capability; or

1> if the IE "Frequency band indicator" is included and set to "extension indicator", and the UE does not support any of the frequency bands that can be indicated by the IE "Frequency band indicator 2" (i.e., Band VIII or beyond); or

1> if the IE "Frequency band indicator" is not included in System Information Block type 5, the DL frequency is in between 2110MHz-2170MHz, and Band I is not part of the frequency bands supported by the UE in the UE radio access capability, or

1> if the IE "Frequency band indicator" is not included in System Information Block type 5, the DL frequency is in between 1805MHz-1880MHz, and Band III is not part of the frequency bands supported by the UE in the UE radio access capability:

2> consider the cell to be barred according to [4]; and

2> consider the barred cell as using the value "not allowed" in the IE "Intra-frequency cell re-selection indicator", and the maximum value in the IE "$T_{barred}$".

1> if the cell belongs to any frequency band equal to Band IV or greater and neither the IE "Frequency band indicator" nor the IE "Frequency band indicator 2" are included in System Information Block type 5 or in System Information Block type 5bis:

2> the UE behaviour is not specified.

1> if in connected mode, and System Information Block type 6 is indicated as used in the cell:

2> read and act on information sent in System Information Block type 6.

1> replace the TFS of the RACH with the one stored in the UE if any;

1> let the physical channel(s) of type PRACH given by the IE(s) "PRACH info" be the default in uplink for the PRACH if UE is in CELL_FACH state;

1> start to receive the physical channel of type AICH using the parameters given by the IE "AICH info" (FDD only) when given allocated PRACH is used;

1> if the IE "Additional Dynamic Transport Format Information for CCCH" is included for the selected PRACH:

2> use this transport format for transmission of the CCCH.

1> else:

2> use the first instance of the list of transport formats as in the IE "RACH TFS" for the used RACH received in the IE "PRACH system information list" when using the CCCH.

1> replace the TFS of the FACH/PCH with the one stored in the UE if any;

1> select a Secondary CCPCH as specified in [4] and in subclause 8.5.19, and start to receive the physical channel of type PICH associated with the PCH carried by the selected Secondary CCPCH using the parameters given by the IE "PICH info" if UE is in Idle mode or in CELL_PCH or URA_PCH state;

1> start to monitor its paging occasions on the selected PICH if UE is in Idle mode or in CELL_PCH or URA_PCH state;

1> start to receive the selected physical channel of type Secondary CCPCH using the parameters given by the IE(s) "Secondary CCPCH info" if UE is in CELL_FACH state;

1> in 3.84 Mcps TDD and 7.68 Mcps TDD:

2> use the IE "TDD open loop power control" as defined in subclause 8.5.7 when allocated PRACH is used.

1> in TDD:

2> if the IE "PDSCH system information" and/or the IE "PUSCH system information" is included:

3> store each of the configurations given there with the associated identity given in the IE "PDSCH Identity" and/or "PUSCH Identity" respectively. For every configuration, for which the IE "SFN Time info" is included, the information shall be stored for the duration given there.

If a UE is a 12 kbps class UE according to [35] and the UE has a lower capability than required to support all transport channel configurations mapped on a specific Secondary CCPCH, the UE shall at a certain time instant still be able to decode those transport channels mapped on this Secondary CCPCH that do match the capability supported by the UE. The UE shall use the TFCI bits for that Secondary CCPCH, to distinguish a transport channel configuration that is supported by the UE from a transport channel configuration that is not supported by the UE.

In particular if the UE is a 12 kbps class UE according to [35] and it does not support the processing requirement at a given point in time for a Secondary CCPCH, it shall still be able to decode the same Secondary CCPCH when the

processing requirement is consistent with the UE capability. Or if the UE does not support the number of TFs or the coding of a certain transport channel on a Secondary CCPCH, it shall still be able to decode other transport channels mapped on the same Secondary CCPCH that is consistent with what is supported by the UE.

The UE shall:

1> if the IE "Secondary CCPCH system information MBMS" is included:

2> apply the Secondary CCPCH and FACH indicated by the IE "FACH carrying MCCH" for receiving MCCH.

1> otherwise, if the IE "Secondary CCPCH system information" includes the IE "MCCH configuration information":

2> apply the Secondary CCPCH and FACH indicated by the IE 'MCCH configuration information' for receiving MCCH.

#### 8.1.1.6.6 System Information Block type 6

If in connected mode, the UE should store all relevant IEs included in this system information block. The UE shall:

1> if the IE "Frequency band indicator" is included:

2> if the frequency band indicated in the IE is not part of the frequency bands supported in the UE radio access capability; or

2> if the IE "Frequency band indicator 2" is included and if the frequency band indicated in the IE is not part of the frequency bands supported in the UE radio access capability; or

2> if the IE "Frequency band indicator" is included and set to "extension indicator", and the UE does not support any of the frequency bands that can be indicated by the IE "Frequency band indicator 2" (i.e., Band VIII or beyond):

3> consider the cell to be barred according to [4]; and

3> consider the barred cell as using the value "not allowed" in the IE "Intra-frequency cell re-selection indicator", and the maximum value in the IE "$T_{barred}$".

1> replace the TFS of the RACH with the one stored in the UE if any;

1> let the physical channel(s) of type PRACH given by the IE(s) "PRACH info" be the default in uplink if UE is in CELL_FACH state. If the IE "PRACH info" is not included, the UE shall read the corresponding IE(s) in System Information Block type 5 and use that information to configure the PRACH;

1> start to receive the physical channel of type AICH using the parameters given by the IE "AICH info" when associated PRACH is used. If the IE "AICH info" is not included, the UE shall read the corresponding IE in System Information Block type 5 and use that information (FDD only);

1> if the IE "Additional Dynamic Transport Format Information for CCCH" is included for the selected PRACH:

2> use this transport format for transmission of the CCCH (FDD only).

1> else:

2> use the first instance of the list of transport formats as in the IE "RACH TFS" for the used RACH received in the IE "PRACH system information list" when using the CCCH (FDD only).

1> replace the TFS of the FACH/PCH with the one stored in the UE if any;

1> select a Secondary CCPCH as specified in [4] and in subclause 8.5.19, and start to receive the physical channel of type PICH associated with the PCH carried by the selected Secondary CCPCH using the parameters given by the IE "PICH info" if the UE is in CELL_PCH or URA_PCH state. If the IE "PICH info" is not included, the UE shall read the corresponding IE in System Information Block type 5 and use that information;

1> start to monitor its paging occasions on the selected PICH if the UE is in CELL_PCH or URA_PCH state;

1> start to receive the selected physical channel of type Secondary CCPCH using the parameters given by the IE(s) "Secondary CCPCH info" if the UE is in CELL_FACH state. If the IE "Secondary CCPCH info" is not included, the UE shall read the corresponding IE(s) in System Information Block type 5 and use that information;

1> in 3.84 Mcps TDD and 7.68 Mcps TDD: use the IE "TDD open loop power control" as defined in subclause 8.5.7;

1> in TDD: if the IE "PDSCH system information" and/or the IE "PUSCH system information" is included, store each of the configurations given there with the associated identity given in the IE "PDSCH Identity" and/or "PUSCH Identity" respectively. For every configuration, for which the IE "SFN Time info" is included, the information shall be stored for the duration given there.

If in idle mode, the UE shall not use the values of the IEs in this system information block.

If a UE is a 12 kbps class UE according to [35] and the UE has a lower capability than required to support all transport channel configurations mapped on a specific Secondary CCPCH, the UE shall at a certain time instant still be able to decode those transport channels mapped on this Secondary CCPCH that do match the capability supported by the UE. The UE shall use the TFCI bits for that Secondary CCPCH, to distinguish a transport channel configuration that is supported by the UE from a transport channel configuration that is not supported by the UE.

In particular if the UE is a 12 kbps class UE according to [35] and it does not support the processing requirement at a given point in time for a Secondary CCPCH, it shall still be able to decode the same Secondary CCPCH when the processing requirement is consistent with the UE capability. Or if the UE does not support the number of TFs or the coding of a certain transport channel on a Secondary CCPCH, it shall still be able to decode other transport channels mapped on the same Secondary CCPCH that is consistent with what is supported by the UE.

#### 8.1.1.6.7 System Information Block type 7

The UE should store all relevant IEs included in this system information block.

#### 8.1.1.6.8 Void

#### 8.1.1.6.9 Void

#### 8.1.1.6.10 Void

#### 8.1.1.6.11 System Information Block type 11

The UE should store all relevant IEs included in this system information block. The UE shall:

1> if in idle mode:

2> clear the variable MEASUREMENT_IDENTITY.

1> if IE "FACH measurement occasion info" is included:

2> act as specified in subclause 8.6.7.

1> else:

2> may perform inter-frequency/inter-RAT measurements or inter-frequency/inter-RAT cell re-selection evaluation, if the UE capabilities permit such measurements while simultaneously receiving the S-CCPCH of the serving cell.

1> clear the variable CELL_INFO_LIST;

1> act upon the received IE "Intra-frequency cell info list"/"Inter-frequency cell info list"/"Inter-RAT cell info list" as described in subclause 8.6.7.3;

1> if the IE "Inter-frequency RACH reporting information" is included in the system information block:

2> read the IE and use that information for the inter-frequency measurements as specified in subclause 8.5.23.

1> if in idle mode; or

1> if in connected mode and if System Information Block type 12 is not broadcast in the cell:

2> if no intra-frequency measurement stored in the variable MEASUREMENT_IDENTITY was set up or modified through a MEASUREMENT CONTROL message:

3> if included, store the IE "Intra-frequency reporting quantity" and the IE "Intra-frequency measurement reporting criteria" or "Periodical reporting criteria" in order to activate reporting when state CELL_DCH is entered in the variable MEASUREMENT_IDENTITY. The IE "Cells for measurement" is absent for this measurement. The IE "Measurement Validity" is absent for this measurement after a state transition to CELL_DCH;

1> if in connected mode and if System Information Block type 12 is not broadcast in the cell:

2> read the IE "Traffic volume measurement information";

2> if no traffic volume measurement with the measurement identity indicated in the IE "Traffic volume measurement system information" was set up or modified through a MEASUREMENT CONTROL message:

3> update the variable MEASUREMENT_IDENTITY with the measurement information received in that IE.

1> if the IE "Cell selection and reselection info" is not included for a new neighbouring cell in the IE "intra-frequency cell info list", the IE "inter-frequency cell info list" or the IE "inter-RAT cell info list" in System Information Block type 11:

2> use the default values specified for the IE "Cell selection and reselection info" for that cell except for the IE "HCS neighbouring cell information".

1> if the IE "Use of HCS" is set to "used", indicating that HCS is used, do the following:

2> if IE "HCS neighbouring cell information" is not included for the first new cell in the IE "Intra-frequency cell info list", the IE "Inter-frequency cell info list" or the IE "Inter-RAT cell info list" in System Information Block type 11:

3> use the default values specified for the IE "HCS neighbouring cell information" for that cell.

2> if IE "HCS neighbouring cell information" is not included for any other new cell in the IE "Intra-frequency cell info list", the IE "Inter-frequency cell info list" or the IE "Inter-RAT cell info list" in System Information Block type 11:

3> for that cell use the same parameter values as used for the preceding cell in the same cell info list in System Information Block type 11.

1> if the value of the IE "Cell selection and reselection quality measure" is different from the value of the IE "Cell selection and reselection quality measure" obtained from System Information Block type 3 or System Information Block type 4:

2> use the value of the IE from this System Information Block and ignore the value obtained from System Information Block type 3 or System Information Block type 4.

1> if in connected mode, and System Information Block type 12 is indicated as used in the cell:

2> read and act on information sent in System Information Block type 12 as indicated in subclause 8.1.1.6.12.

#### 8.1.1.6.12 System Information Block type 12

If in connected mode, the UE should store all relevant IEs included in this system information block. The UE shall:

1> after reception of System Information Block type 11:

2> update the variable MEASUREMENT_IDENTITY with the measurement information in the received IEs unless specified otherwise.

1> if IE "FACH measurement occasion info" is included:

2> act as specified in subclause 8.6.7.

1> else:

2> may perform inter-frequency/inter-RAT measurements or inter-frequency/inter-RAT cell re-selection evaluation, if the UE capabilities permit such measurements while simultaneously receiving the S-CCPCH of the serving cell.

1> act upon the received IE "Intra-frequency cell info list"/"Inter-frequency cell info list"/"Inter-RAT cell info list" as described in subclause 8.6.7.3;

1> if any of the IEs "Intra-frequency measurement quantity", "Intra-frequency reporting quantity for RACH reporting", "Maximum number of reported cells on RACH" or "Reporting information for state CELL_DCH" are not included in the system information block:

2> read the corresponding IE(s) in system information block type 11 and use that information for the intra-frequency measurement.

1> if the IE "Inter-frequency RACH reporting information" is included in this system information block or in System Information Block type 11:

2> if the IE is not included in the system information block, read the corresponding IE(s) in System Information Block type 11;

2> use the received information for the inter-frequency measurements as specified in subclause 8.5.23.

1> if included in this system information block or in System Information Block type 11:

2> if no intra-frequency measurement in the variable MEASUREMENT_IDENTITY was set up or modified through a MEASUREMENT CONTROL message:

3> store the IE "Intra-frequency reporting quantity" and the IE "Intra-frequency measurement reporting criteria" or "Periodical reporting criteria" in order to activate reporting when state CELL_DCH is entered in the variable MEASUREMENT_IDENTITY. The IE "Cells for measurement" is absent for this measurement. The IE "Measurement Validity" is absent for this measurement after a state transition to CELL_DCH;

1> if the IE "Traffic volume measurement system information" is not included in this system information block:

2> read the corresponding IE in System Information Block type 11.

1> if the IE "Traffic volume measurement system information" was received either in this system information block or in System Information Block type 11:

2> if no traffic volume measurement with the measurement identity indicated in the IE "Traffic volume measurement system information" was set up or modified through a MEASUREMENT CONTROL message:

3> update the variable MEASUREMENT_IDENTITY with the measurement information received in that IE.

1> if in CELL_FACH state:

2> start or continue the traffic volume measurements stored in the variable MEASUREMENT_IDENTITY that are valid in CELL_FACH state.

1> if the IE "Cell selection and reselection info" is not included for a new neighbouring cell in the IE "Intra-frequency cell info list", the IE "Inter-frequency cell info list" or the IE "Inter-RAT cell info list" in System Information Block type 12:

2> use the default values specified for the IE "Cell selection and reselection info" for that cell except for the IE "HCS neighbouring cell information".

1> if the IE "Use of HCS" is set to "used", indicating that HCS is used, do the following:

2> if IE "HCS neighbouring cell information" is not included for the first new cell in the IE "Intra-frequency cell info list", the IE "Inter-frequency cell info list" or the IE "Inter-RAT cell info list" in System Information Block type 12:

3> use the default values specified for the IE "HCS neighbouring cell information" for that cell.

2> if IE "HCS neighbouring cell information" is not included for any other new cell in the IE "Intra-frequency cell info list", the IE "Inter-frequency cell info list" or the IE "Inter-RAT cell info list" in System Information Block type 12:

3> for that cell use the same parameter values as used for the preceding cell in the same cell info list in System Information Block type 12.

1> if the value of the IE "Cell selection and reselection quality measure" is different from the value of the IE "Cell selection and reselection quality measure" obtained from System Information Block type 3 or System Information Block type 4:

2> use the value of the IE from this System Information Block and ignore the value obtained from System Information Block type 3 or System Information Block type 4.

If in idle mode, the UE shall not use the values of the IEs in this system information block.

#### 8.1.1.6.13 System Information Block type 13

If in idle or connected mode, the UE should store all relevant IEs included in this system information block except for the IEs "CN domain specific DRX cycle length coefficient", "UE timers and constants in idle mode" and "Capability update requirement" which shall be stored only in the idle mode case. The UE shall read System Information Block type 13 and the associated System Information Block types 13.1, 13.2, 13.3 and 13.4 only when the UE is operating in "ANSI-41 mode" and the IE "PLMN type" in the Master Information Block has the value "ANSI-41" or "GSM-MAP and ANSI-41". The UE shall also:

1> forward the content of the IE "CN domain specific NAS system information" to the non-access stratum entity indicated by the IE "CN domain identity";

1> use the IE "CN domain specific DRX cycle length coefficient" to calculate frame number for the Paging Occasions and Page indicator as specified in [4].

Refer to TIA/EIA/IS-2000.5-A for actions on information contained in System Information Block types 13.1, 13.2, 13.3 and 13.4.

#### 8.1.1.6.14 System Information Block type 14

This system information block type is used only in 3.84 Mcps TDD and 7.68 Mcps TDD.

The UE should store all relevant IEs included in this system information block. The UE shall:

1> use the IE "UL Timeslot Interference" to calculate PRACH, DPCH and PUSCH transmit power for TDD uplink open loop power control as defined in subclause 8.5.7.

#### 8.1.1.6.15 System Information Block type 15

If the UE is in idle or connected mode, and supports GPS location services it should store all relevant IEs included in this system information block. The UE shall:

1> if the IE "GPS Data ciphering info" is included:

1> act as specified in the subclause 8.6.7.19.4.- act upon the received IE "Reference position" as specified in subclause 8.6.7.19.3.8;

1> act upon the received IE "GPS reference time" as specified in subclause 8.6.7.19.3.7;

1> if IE "Satellite information" is included:

2> act upon this list of bad satellites as specified in subclause 8.6.7.19.3.6.

NOTE: For efficiency purposes, the UTRAN should broadcast System Information Block type 15 if it is broadcasting System Information Block type 15.2.

#### 8.1.1.6.15.1 System Information Block type 15.1

The UE should store all the relevant IEs included in this system information block in variable UE_POSITIONING_GPS_DATA. The UE shall:

1> act on "DGPS information" in the IE "DGPS Corrections" in a similar manner as specified in [13] except that the scale factors for PRC and RRC are different;

1> act upon the received IE " UE Positioning GPS DGPS corrections" as specified in subclause 8.6.7.19.3.3.

In this version of the specification, the UE shall:

1> ignore the following IEs: "Delta PRC2", "Delta RRC2", "Delta PRC3" and "Delta RRC3".

#### 8.1.1.6.15.2 System Information Block type 15.2

For System Information Block type 15.2 multiple occurrences may be used; one occurrence for one satellite. To identify the different occurrences, the scheduling information for System Information Block type 15.2 includes IE "SIB occurrence identity and value tag". The UE should store all the relevant IEs included in this system information block in variable UE_POSITIONING_GPS_DATA. The UE shall:

1> compare for each occurrence the value tag of the stored occurrence, if any, with the occurrence value tag included in the IE "SIB occurrence identity and value tag" for the occurrence of the System Information Block with the same occurrence identity;

1> in case the UE has no SIB occurrence stored with the same identity or in case the occurrence value tag is different:

2> store the occurrence information together with its identity and value tag for later use.

1> in case an occurrence with the same identity but different value tag was stored:

2> overwrite this one with the new occurrence read via system information for later use.

1> interpret IE "Transmission TOW" as a very coarse estimate of the current time, i.e., the approximate GPS time-of-week when the message is broadcast;

1> interpret IE "SatID" as the satellite ID of the data from which this message was obtained;

1> act upon the received IEs "Sat ID" and "GPS Ephemeris and Clock Corrections Parameter" as specified in subclause 8.6.7.19.3.4.

The IE "Transmission TOW" may be different each time a particular SIB occurrence is transmitted. The UTRAN should not increment the value tag of the SIB occurrence if the IE "Transmission TOW" is the only IE that is changed.

The UE may not need to receive all occurrences before it can use the information from any one occurrence.

#### 8.1.1.6.15.3 System Information Block type 15.3

For System Information Block type 15.3 multiple occurrences may be used; one occurrence for each set of satellite data. To identify the different occurrences, the scheduling information for System Information Block type 15.3 includes IE "SIB occurrence identity and value tag". The UE should store all the relevant IEs included in this system information block in variable UE_POSITIONING_GPS_DATA. The UE shall:

1> compare for each occurrence the value tag of the stored occurrence, if any, with the occurrence value tag included in the IE "SIB occurrence identity and value tag" for the occurrence of the System Information Block with the same occurrence identity;

1> in case the UE has no SIB occurrence stored with the same identity or in case the occurrence value tag is different:

2> store the occurrence information together with its identity and value tag for later use.

1> in case an occurrence with the same identity but different value tag was stored:

2> overwrite this one with the new occurrence read via system information for later use.

1> interpret IE "Transmission TOW" as a very coarse estimate of the current time, i.e., the approximate GPS time-of-week when the message is broadcast;

1> if the IE "GPS Almanac and Satellite Health" is included:

2> interpret IE "SatMask" as the satellites that contain the pages being broadcast in this message;

2> interpret IE "LSB TOW" as the least significant 8 bits of the TOW ([12]);

2> act upon the received IE "GPS Almanac and Satellite Health" as specified in subclause 8.6.7.19.3.2.

1> if the IE "GPS ionospheric model" is included:

2> act upon the received IE "GPS ionospheric model" as specified in subclause 8.6.7.19.3.5.

1> if the IE "GPS UTC model" is included:

2> act upon the received IE "GPS UTC model" as specified in subclause 8.6.7.19.3.9.

The IE "Transmission TOW" may be different each time a particular SIB occurrence is transmitted. The UTRAN should not increment the value tag of the SIB occurrence if the IE "Transmission TOW" is the only IE that is changed. One SIB occurrence value tag is assigned to the table of subclause 10.2.48.8.18.3.

The UE may not need to receive all occurrences before it can use the information for any one occurrence.

#### 8.1.1.6.15.4 System Information Block type 15.4

If the UE is in idle mode or connected mode, the UE shall:

1> if the IE "OTDOA Data ciphering info" is included:

2> act as specified in subclause 8.6.7.19.4.

If the UE is in connected mode, the UE shall:

1> act as specified in subclause 8.6.7.19.2.

#### 8.1.1.6.15.5 System Information Block type 15.5

If the UE is in idle or connected mode, the UE shall:

1> if the UE supports UE-based OTDOA positioning:

2> act as specified in subclause 8.6.7.19.2a.

### 8.1.1.6.16 System Information Block type 16

For System Information Block type 16 multiple occurrences may be used; one occurrence for each predefined configuration. To identify the different predefined configurations, the scheduling information for System Information Block type 16 includes IE "Predefined configuration identity and value tag".

The UE should store all relevant IEs included in this system information block. The UE shall:

1> compare for each predefined configuration the value tag of the stored predefined configuration with the preconfiguration value tag included in the IE "Predefined configuration identity and value tag" for the occurrence of the System Information Block with the same predefined configuration identity;

1> in case the UE has no predefined configuration stored with the same identity:

2> store the predefined configuration information together with its identity and value tag for later use e.g. during handover to UTRAN.

1> in case a predefined configuration with the same identity but different value tag was stored:

2> overwrite this one with the new configuration read via system information for later use e.g. during handover to UTRAN.

The above handling applies regardless of whether the previously stored predefined configuration information has been obtained via UTRA or via another RAT.

The UE is not required to complete reading of all occurrences of System Information Block type 16 before initiating RRC connection establishment.

The UE is not required to store more than maxPredefConfig preconfigurations even in the case of multiple equivalent PLMNs.

#### 8.1.1.6.17 System Information Block type 17

This system information block type is used only for TDD.

If in connected mode, the UE should store all relevant IEs included in this system information block. The UE shall:

1> if the IE "PDSCH system information" and/or the IE "PUSCH system information" is included, store each of the configurations given there with the associated identity given in the IE "PDSCH Identity" and/or "PUSCH Identity" respectively. This information shall become invalid after the time specified by the repetition period (SIB_REP) for this system information block.

If in idle mode, the UE shall not use the values of the IEs in this system information block.

#### 8.1.1.6.18 System Information Block type 18

If the System Information Block type 18 is present, a UE shall obtain knowledge of the PLMN identity of the neighbour cells to be considered for cell reselection, and shall behave as specified in this subclause and in subclause 8.5.14a.

The UE should store all the relevant IEs included in this system information block.

A UE in idle mode shall act according to the following rules:

1> any PLMN list of a given type (IEs "PLMNs of intra-frequency cells list", "PLMNs of inter-frequency cells list", "PLMNs of inter-RAT cell lists") included in the IE "Idle mode PLMN identities" is paired with the list of cells of the same type derived from System Information Block type 11;

1> the PLMN identity located at a given rank in the PLMN list is that of the cell with the same ranking in the paired list of cells, the cells being considered in the increasing order of their associated identities ("Intra-frequency cell id", "Inter-frequency cell id", "Inter-RAT cell id");

1> if no identity is indicated for the first PLMN in a list, the UE shall assume that the neighbouring cell broadcasts the same PLMN configuration (i.e. IE "PLMN Identity" and IE "Multiple PLMN List") as the current cell;

1> if no identity is indicated for another entry in the list, the UE shall assume that the neighbouring cell broadcasts the same PLMN configuration (i.e. IE "PLMN Identity" and IE "Multiple PLMN List") as the previous cell in the list;

1> if the number of identities in a PLMN list exceeds the number of neighbour cells in the paired list (if any), the extra PLMN identities are considered as unnecessary and ignored;

1> if the number of identities in a PLMN list (if any) is lower than the number of neighbour cells in the paired list, the missing PLMN identities are replaced by the PLMN configuration for the last cell in the list.

A UE in connected mode shall act in the same manner as a UE in idle mode with the following modifications:

1> the PLMN lists to be considered are the ones included, when present, in the IE "Connected mode PLMN identities"; otherwise, the UE shall use, in place of any missing list, the corresponding one in the IE "Idle mode PLMN identities";

1> the paired lists of cells are the ones derived from System Information Block type 11, and System Information Block type 12 if present.

### 8.1.1.7 Modification of system information

For System Information Block type 15.2, 15.3 and 16 that may have multiple occurrences, the UE shall handle each occurrence independently as specified in the previous; that is each occurrence is handled as a separate system information block.

NOTE: It should be noted that for the proper operation of the BCCH Modification Information sent on a PCH, the System Information should not be changed more frequently than can be accommodated by mobile stations operating at the maximum DRX cycle length supported by the UTRAN.

#### 8.1.1.7.1 Modification of system information blocks using a value tag

Upon modifications of system information blocks using value tags, UTRAN should notify the new value tag for the master information block in the IE "BCCH modification info", transmitted in the following way:

1> to reach UEs in idle mode, CELL_PCH state and URA_PCH state, the IE "BCCH modification info" is contained in a PAGING TYPE 1 message transmitted on the PCCH in all paging occasions in the cell;

1> to reach UEs in CELL_FACH state or TDD UEs in CELL_DCH with S-CCPCH assigned, the IE "BCCH modification info" is contained in a SYSTEM INFORMATION CHANGE INDICATION message transmitted on the BCCH mapped on at least one FACH on every Secondary CCPCH in the cell.

Upon reception of a PAGING TYPE 1 message or a SYSTEM INFORMATION CHANGE INDICATION message containing the IE "BCCH modification info" containing the IE "MIB value tag" but not containing the IE "BCCH modification time", the UE shall perform actions as specified in subclause 8.1.1.7.3.

If the IE "BCCH modification time" is included the UE shall perform actions as specified in subclause 8.1.1.7.2.

#### 8.1.1.7.2 Synchronised modification of system information blocks

For modification of some system information elements, e.g. reconfiguration of the channels, it is important for the UE to know exactly when a change occurs. In such cases, the UTRAN should notify the SFN when the change will occur as well as the new value tag for the master information block in the IE "BCCH modification info" transmitted in the following way:

1> To reach UEs in idle mode, CELL_PCH state and URA_PCH state, the IE "BCCH modification info" is contained in a PAGING TYPE 1 message transmitted on the PCCH in all paging occasions in the cell;

1> To reach UEs in CELL_FACH state, the IE "BCCH modification info" is contained in a SYSTEM INFORMATION CHANGE INDICATION message transmitted on the BCCH mapped on at least one FACH on every Secondary CCPCH in the cell.

Upon reception of a PAGING TYPE 1 message or a SYSTEM INFORMATION CHANGE INDICATION message containing the IE "BCCH modification info" containing the IE "MIB value tag" and containing the IE "BCCH modification time", the UE shall:

1> perform the actions as specified in subclause 8.1.1.7.3 at the time, indicated in the IE "BCCH Modification Info".

#### 8.1.1.7.3 Actions upon system information change

The UE shall:

1> compare the value of IE "MIB value tag" in the IE "BCCH modification info" with the value tag stored for the master information block in variable VALUE_TAG.

1> if the value tags differ:

2> read the master information block on BCH;

2> if the value tag of the master information block in the system information is the same as the value in IE "MIB value tag" in "BCCH modification info" but different from the value tag stored in the variable VALUE_TAG:

3> perform actions as specified in subclause 8.1.1.5.

2> if the value tag of the master information block in the system information is the same as the value tag stored in the variable VALUE_TAG:

3> for the next occurrence of the master information block:

4> perform actions as specified in subclause 8.1.1.7.3 again.

2> if the value tag of the master information block in the system information is different from the value tag stored in the variable VALUE_TAG, and is different from the value in IE "MIB value tag" in "BCCH modification info":

3> perform actions as specified in subclause 8.1.1.5;

3> if (VTCI-VTMIB) mod 8 < 4, where VTCI is the value tag in the IE "MIB value tag" in "BCCH modification info" and VTMIB is the value tag of the master information block in the system information:

4> for the next occurrence of the master information block:

5> perform actions as specified in subclause 8.1.1.7.3 again.

#### 8.1.1.7.4 Actions upon expiry of a system information expiry timer

When the expiry timer of a system information block not using a value tag expires

the UE shall:

1> consider the content of the system information block invalid;

1> re-acquire the system information block again before the content can be used;

In FDD for system information blocks other than System Information Block type 7, or in states other than CELL_FACH, or in TDD for system information blocks other than System Information Block type 14, or in states other than CELL_FACH or CELL_DCH the UE may:

1> postpone reading the system information block until the content is needed.

In FDD for System Information Block type 7, while in state CELL_FACH, and in TDD for System Information Block type 14, while in state CELL_FACH or CELL DCH the UE shall always keep an up to date version of the relevant IEs, unless this is not possible because system information can not be received due to bad radio conditions.

## 8.1.2 Paging




**Figure 8.1.2-1: Paging**

### 8.1.2.1 General

This procedure is used to transmit paging information to selected UEs in idle mode, CELL_PCH or URA_PCH state using the paging control channel (PCCH). Upper layers in the network may request paging, to e.g. establish a signalling

connection. UTRAN may initiate paging for UEs in CELL_PCH or URA_PCH state to trigger a cell update procedure. In addition, UTRAN may initiate paging for UEs in idle mode, CELL_PCH and URA_PCH state to trigger reading of updated system information. UTRAN may also initiate paging for UEs in CELL_PCH and URA_PCH state to release the RRC connection.

#### 8.1.2.2 Initiation

UTRAN initiates the paging procedure by transmitting a PAGING TYPE 1 message on an appropriate paging occasion on the PCCH.

UTRAN may repeat transmission of a PAGING TYPE 1 message to a UE in several paging occasions to increase the probability of proper reception of a page.

UTRAN may page several UEs in the same paging occasion by including one IE "Paging record" for each UE in the PAGING TYPE 1 message.

For CN originated paging, UTRAN should set the IE "Paging cause" to the cause for paging received from upper layers. If no cause for paging is received from upper layers, UTRAN should set the value "Terminating – cause unknown".

UTRAN may also indicate that system information has been updated, by including the value tag of the master information block in the IE "BCCH modification info" in the PAGING TYPE 1 message. In this case, UTRAN may omit the IEs "Paging record".

#### 8.1.2.3 Reception of a PAGING TYPE 1 message by the UE

A UE in idle mode, CELL_PCH state or URA_PCH state shall receive the paging information for all its monitored paging occasions. For a UE in idle mode, the paging occasions are specified in [4] and depend on the IE "CN domain specific DRX cycle length coefficient", as specified in subclause 8.6.3.1a. For a UE in CELL_PCH state or URA_PCH state, the paging occasions depend also on the IE "UTRAN DRX cycle length coefficient" and the IE "RRC State Indicator", as specified in subclauses 8.6.3.2 and 8.6.3.3 respectively.

When the UE receives a PAGING TYPE 1 message, it shall perform the actions as specified below.

If the UE is in idle mode, for each occurrence of the IE "Paging record" included in the message the UE shall:

1> if the IE "Used paging identity" is a CN identity:

2> compare the IE "UE identity" with all of its allocated CN UE identities:

2> if one match is found:

3> indicate reception of paging; and

3> forward the IE "CN domain identity", the IE "UE identity" and the IE "Paging cause" to the upper layers.

1> otherwise:

2> ignore that paging record.

If the UE is in connected mode, for each occurrence of the IE "Paging record" included in the message the UE shall:

1> if the IE "Used paging identity" is a UTRAN single UE identity and if this U-RNTI is the same as the U-RNTI allocated to the UE stored in the UE variable U_RNTI:

2> if the optional IE "CN originated page to connected mode UE" is included:

3> indicate reception of paging; and

3> forward the IE "CN domain identity", the IE "Paging cause" and the IE "Paging record type identifier" to the upper layers.

2> if the IE "Release indicator" in the IE "RRC connection release information" has the value "Release":

3> release all its radio resources;

3> indicate the release of the established signalling connections (as stored in the variable ESTABLISHED_SIGNALLING_CONNECTIONS) and established radio access bearers (as stored in the variable ESTABLISHED_RABS) to the upper layers;

3> clear the variable ESTABLISHED_SIGNALLING_CONNECTIONS;

3> clear the variable ESTABLISHED_RABS;

3> pass the value of the IE "Release cause" received in the IE "Release information" to upper layers;

3> enter idle mode;

3> perform the actions specified in subclause 8.5.2 when entering idle mode;

3> and the procedure ends.

2> otherwise:

3> perform a cell update procedure with cause "paging response" as specified in subclause 8.3.1.2.

2> ignore any other remaining IE "Paging record" that may be present in the message.

1> if the IE "Used paging identity" is a UTRAN group identity and there is a group identity match according to subclause 8.6.3.13:

2> if the IE "Release indicator" in the IE "RRC connection release information" has the value "Release":

3> release all its radio resources;

3> indicate the release of the established signalling connections (as stored in the variable ESTABLISHED_SIGNALLING_CONNECTIONS) and established radio access bearers (as stored in the variable ESTABLISHED_RABS) to the upper layers;

3> clear the variable ESTABLISHED_SIGNALLING_CONNECTIONS;

3> clear the variable ESTABLISHED_RABS;

3> pass the value of the IE "Release cause" received in the IE 'Release information' to upper layers;

3> enter idle mode;

3> perform the actions specified in subclause 8.5.2 when entering idle mode;

3> and the procedure ends.

2> otherwise:

3> perform a cell update procedure with cause "paging response" as specified in subclause 8.3.1.2.

2> ignore any other remaining IE "Paging record" that may be present in the message.

1> otherwise:

2> ignore that paging record.

If the IE "BCCH modification info" is included, any UE in idle mode, CELL_PCH or URA_PCH state shall perform the actions as specified in subclause 8.1.1 in addition to any actions caused by the IE "Paging record" occurrences in the message as specified above.

## 8.1.3 RRC connection establishment




**Figure 8.1.3-1: RRC Connection Establishment, network accepts RRC connection**




**Figure 8.1.3-2: RRC Connection Establishment, network rejects RRC connection**

### 8.1.3.1 General

The purpose of this procedure is to establish an RRC connection.

### 8.1.3.2 Initiation

The UE shall initiate the procedure when upper layers in the UE requests the establishment of a signalling connection and the UE is in idle mode (no RRC connection exists), as specified in subclause 8.1.8.

Upon initiation of the procedure, the UE shall:

1> set the variable PROTOCOL_ERROR_INDICATOR to FALSE;

1> if the USIM is present:

2> set the value of "THRESHOLD" in the variable "START_THRESHOLD" to the 20 MSBs of the value stored in the USIM [50] for the maximum value of START for each CN Domain.

1> if the SIM is present:

2> set the value of "THRESHOLD" in the variable "START_THRESHOLD" to the default value in [40] for each CN Domain.

1> set the IE "Initial UE identity" in the variable INITIAL_UE_IDENTITY according to subclause 8.5.1;

1> set the contents of the RRC CONNECTION REQUEST message according to subclause 8.1.3.3;

1> set CFN in relation to SFN of current cell according to subclause 8.5.15;

1> perform the mapping of the Access Class to an Access Service Class as specified in subclause 8.5.13, and apply the given Access Service Class when accessing the RACH;

1> submit the RRC CONNECTION REQUEST message for transmission on the uplink CCCH;

1> set counter V300 to 1; and

1> if the variable ESTABLISHMENT_CAUSE is set to "MBMS reception":

2> when the MAC layer indicates success or failure to transmit the message:

3> if the MAC layer indicates failure:

4> enter idle mode;

4> consider the procedure to be unsuccessful;

4> perform other actions when entering idle mode from connected mode as specified in subclause 8.5.2;

4> the procedure ends.

3> else:

3> start timer T318;

3> apply value 0 for counter N300 regardless of the value included in IE "UE Timers and Constants in idle mode";

1> otherwise:

2> start timer T300 when the MAC layer indicates success or failure to transmit the message.

1> select a Secondary CCPCH according to [4];

1> start receiving all FACH transport channels mapped on the selected Secondary CCPCH.

### 8.1.3.3 RRC CONNECTION REQUEST message contents to set

The UE shall, in the transmitted RRC CONNECTION REQUEST message:

1> set the IE "Establishment cause" to the value of the variable ESTABLISHMENT_CAUSE;

1> set the IE "Initial UE identity" to the value of the variable INITIAL_UE_IDENTITY;

1> set the IE "Protocol error indicator" to the value of the variable PROTOCOL_ERROR_INDICATOR; and

1> include the IE "Predefined configuration status information" and set this IE to true if the UE has all pre-configurations stored with the same value tag as broadcast in the cell in which the RRC connection establishment is initiated.

1> if the UE is attempting to establish the signalling connection to PS-domain:

2> include the IE "Domain Indicator" and set it to "PS domain".

1> else if the UE is attempting to establish the signalling connection to CS domain:

2> include the IE "Domain Indicator" and set it to "CS domain".

1> if the UE only supports HS-DSCH but not E-DCH:

2> include the IE "UE capability indication" and set it to the "HS-DSCH" value.

1> if the UE supports HS-DSCH and E-DCH:

2> include the IE "UE capability indication" and set it to the "HS-DSCH+E-DCH" value.

The UE shall not include the IE "UE Specific Behaviour Information 1 idle".

### 8.1.3.4 Reception of an RRC CONNECTION REQUEST message by the UTRAN

Upon receiving an RRC CONNECTION REQUEST message, UTRAN should either:

1> accept the request and use a predefined or default radio configuration, in which case it should:

2> include the following information in the RRC CONNECTION SETUP message:

3> the IE "Predefined configuration identity", to indicate which pre-defined configuration of RB and, transport channel parameters shall be used; or

3> the IE "Default configuration mode" and IE "Default configuration identity", to indicate which default configuration of RB and transport channel parameters shall be used;

3> PhyCH information elements.

2> submit the RRC CONNECTION SETUP message to the lower layers for transmission on the downlink CCCH.

NOTE 1: UTRAN should only apply a predefined radio configuration in case it orders the UE to enter CELL_DCH. This is because the predefined configuration information included in System Information Block 16 mandatorily includes information only required in CELL_DCH state.

1> accept the request without using a predefined or default radio configuration, in which case it should:

2> include in the RRC CONNECTION SETUP message the complete set of RB, TrCH and PhyCH information elements to be used;

2> submit the RRC CONNECTION SETUP message to the lower layers for transmission on the downlink CCCH;

NOTE 2: In R'99, the RRC CONNECTION SETUP message always includes the IEs "Added or Reconfigured TrCH information list", both for uplink and downlink transport channels, even if UTRAN orders the UE to move to CELL_FACH and hence need not configure any transport channels. In these cases, UTRAN may include a configuration that adds little to the encoded message size e.g. a DCH with a single zero size transport format. At a later stage, UTRAN may either remove or reconfigure this configuration.

1> submit an RRC CONNECTION REJECT message on the downlink CCCH. In the RRC CONNECTION REJECT message, the UTRAN may direct the UE to another UTRA carrier or to another system. After the RRC CONNECTION REJECT message has been sent, all context information for the UE may be deleted in UTRAN.

### 8.1.3.5 Cell re-selection, T300 or T318 timeout

1> if the UE has not yet received an RRC CONNECTION SETUP message with the value of the IE "Initial UE identity" equal to the value of the variable INITIAL_UE_IDENTITY; and

1> if cell re-selection or expiry of timer T300 or timer T318 occurs:

the UE shall:

1> check the value of V300; and

2> if V300 is equal to or smaller than N300:

3> if cell re-selection occurred:

4> set CFN in relation to SFN of current cell according to subclause 8.5.15.

3> set the IEs in the RRC CONNECTION REQUEST message according to subclause 8.1.3.3;

3> perform the mapping of the Access Class to an Access Service Class as specified in subclause 8.5.13; and

3> apply the given Access Service Class when accessing the RACH;

3> submit a new RRC CONNECTION REQUEST message to lower layers for transmission on the uplink CCCH;

3> increment counter V300;

3> restart timer T300 when the MAC layer indicates success or failure to transmit the message.

2> if V300 is greater than N300:

3> enter idle mode.

3> consider the procedure to be unsuccessful;

3> Other actions the UE shall perform when entering idle mode from connected mode are specified in subclause 8.5.2;

3> the procedure ends.

### 8.1.3.5a Abortion of RRC connection establishment

If the UE has not yet entered UTRA RRC Connected mode and the RRC connection establishment is to be aborted as specified in subclause 8.1.8, the UE shall:

1> consider the procedure to be unsuccessful;

1> perform the actions when entering idle mode as specified in subclause 8.5.2.

The procedure ends.

### 8.1.3.6 Reception of an RRC CONNECTION SETUP message by the UE

The UE shall compare the value of the IE "Initial UE identity" in the received RRC CONNECTION SETUP message with the value of the variable INITIAL_UE_IDENTITY.

If the values are different, the UE shall:

1> ignore the rest of the message.

If the values are identical, the UE shall:

2> if IE "Specification mode" is set to "Preconfiguration" and IE "Preconfiguration mode" is set to "Predefined configuration":

3> initiate the radio bearer and transport channel configuration in accordance with the predefined parameters identified by the IE "Predefined configuration identity" with the following exception;

4> ignore the IE "RB to setup list" and the IE "Re- establishment timer".

NOTE: IE above IEs are mandatory to include in IE 'Predefined RB configuration' that is included in System Information Block 16 but should be ignored since it is not possible to establish a RAB during RRC connection establishment.

3> initiate the physical channels in accordance with the received physical channel information elements;

2> if IE "Specification mode" is set to "Preconfiguration" and IE "Preconfiguration mode" is set to "Default configuration":

3> initiate the radio bearer and transport channel configuration in accordance with the default parameters identified by the IE "Default configuration mode" and IE "Default configuration identity" with the following exception:

4> ignore the radio bearers other than signalling radio bearers.

3> initiate the physical channels in accordance with the received physical channel information elements.

NOTE: IE "Default configuration mode" specifies whether the FDD or TDD version of the default configuration shall be used.

2> if IE "Specification mode" is set to "Complete specification":

3> initiate the radio bearer, transport channel and physical channel configuration in accordance with the received radio bearer, transport channel and physical channel information elements.

1> clear the variable ESTABLISHMENT_CAUSE;

1> stop timer T300 or T318, whichever one is running, and act upon all received information elements as specified in subclause 8.6, unless specified otherwise in the following:

2> if the UE, according to subclause 8.6.3.3, will be in the CELL_FACH state at the conclusion of this procedure:

3> if the IE "Frequency info" is included:

4> select a suitable UTRA cell according to [4] on that frequency.

3> enter UTRA RRC connected mode;

3> select PRACH according to subclause 8.5.17;

3> select Secondary CCPCH according to subclause 8.5.19;

3> ignore the IE "UTRAN DRX cycle length coefficient" and stop using DRX.

1> if the UE, according to subclause 8.6.3.3, will be in the CELL_DCH state at the conclusion of this procedure:

2> perform the physical layer synchronisation procedure A as specified in [29] (FDD only);

2> enter UTRA RRC connected mode.

1> submit an RRC CONNECTION SETUP COMPLETE message to the lower layers on the uplink DCCH after successful state transition per subclause 8.6.3.3, with the contents set as specified below:

2> set the IE "RRC transaction identifier" to:

3> the value of "RRC transaction identifier" in the entry for the RRC CONNECTION SETUP message in the table "Accepted transactions" in the variable TRANSACTIONS; and

3> clear that entry.

2> if the USIM or SIM is present:

3> set the "START" for each CN domain in the IE "START list" in the RRC CONNECTION SETUP COMPLETE message with the corresponding START value that is stored in the USIM [50] if present, or as stored in the UE if the SIM is present; and then

3> set the START value stored in the USIM [50] if present, and as stored in the UE if the SIM is present for any CN domain to the value "THRESHOLD" of the variable START_THRESHOLD.

2> if neither the USIM nor SIM is present:

3> set the "START" for each CN domain in the IE "START list" in the RRC CONNECTION SETUP COMPLETE message to zero;

3> set the value of "THRESHOLD" in the variable "START_THRESHOLD" to the default value [40].

2> retrieve its UTRA UE radio access capability information elements from variable UE_CAPABILITY_REQUESTED; and then

2> include this in IE "UE radio access capability" and IE "UE radio access capability extension", provided this IE is included in variable UE_CAPABILITY_REQUESTED;

2> retrieve its inter-RAT-specific UE radio access capability information elements from variable UE_CAPABILITY_REQUESTED; and then

2> include this in IE "UE system specific capability".

When the RRC CONNECTION SETUP COMPLETE message has been submitted to lower layers for transmission the UE shall:

1> if the UE has entered CELL_FACH state:

2> start timer T305 using its initial value if periodical update has been configured by T305 in the IE "UE Timers and constants in connected mode" set to any other value than "infinity" in the variable TIMERS_AND_CONSTANTS.

1> store the contents of the variable UE_CAPABILITY_REQUESTED in the variable UE_CAPABILITY_TRANSFERRED;

1> initialise variables upon entering UTRA RRC connected mode as specified in subclause 13.4;

1> consider the procedure to be successful;

And the procedure ends.

### 8.1.3.7 Physical channel failure or cell re-selection

1> If the UE failed to establish, per subclause 8.5.4, the physical channel(s) indicated in the RRC CONNECTION SETUP message; or

1> if the UE performs cell re-selection; or

1> if the UE will be in the CELL_FACH state at the conclusion of this procedure; and

1> if the received RRC CONNECTION SETUP message included the IE "Frequency info" and the UE could not find a suitable UTRA cell on that frequency but it could find a suitable UTRA cell on another frequency; or

1> if the received RRC CONNECTION SETUP message included the IE "Primary CPICH info" (for FDD) or "Primary CCPCH info" (for TDD), and the UE selected another cell than indicated by this IE; or

1> if the contents of the variable C_RNTI is empty;

1> after having received an RRC CONNECTION SETUP message with the value of the IE "Initial UE identity" equal to the value of the variable INITIAL_UE_IDENTITY; and

1> before the RRC CONNECTION SETUP COMPLETE message is delivered to lower layers for transmission:

the UE shall:

1> clear the entry for the RRC CONNECTION SETUP message in the table "Accepted transactions" in the variable TRANSACTIONS;

1> check the value of V300, and:

2> if V300 is equal to or smaller than N300:

3> set CFN in relation to SFN of current cell according to subclause 8.5.15;

3> set the IEs in the RRC CONNECTION REQUEST message according to subclause 8.1.3.3;

3> perform the mapping of the Access Class to an Access Service Class as specified in subclause 8.5.13, and apply the given Access Service Class when accessing the RACH;

3> submit a new RRC CONNECTION REQUEST message to the lower layers for transmission on the uplink CCCH;

3> increment counter V300; and

3> restart timer T300 when the MAC layer indicates success or failure in transmitting the message.

2> if V300 is greater than N300:

3> enter idle mode;

3> perform the actions specified in subclause 8.5.2 when entering idle mode from connected mode;

3> consider the RRC establishment procedure to be unsuccessful;

3> the procedure ends.

### 8.1.3.8 Invalid RRC CONNECTION SETUP message, unsupported configuration or invalid configuration

If the UTRAN instructs the UE to use a configuration, which it does not support e.g., the message includes a pre-defined configuration that the UE has not stored and/or if the received message causes the variable UNSUPPORTED_CONFIGURATION or the variable INVALID_CONFIGURATION to be set to TRUE the UE shall perform procedure specific error handling as specified in this subclause.

If the UE receives an RRC CONNECTION SETUP message which contains an IE "Initial UE identity" with a value which is identical to the value of the variable INITIAL_UE_IDENTITY, but the RRC CONNECTION SETUP message contains a protocol error causing the variable PROTOCOL_ERROR_REJECT to be set to TRUE according to clause 9, the UE shall perform procedure specific error handling as follows. The UE shall:

1> stop timer T300 or T318, whichever one is running; and

1> clear the entry for the RRC CONNECTION SETUP message in the table "Rejected transactions" in the variable TRANSACTIONS and proceed as below.

If the UE receives an RRC CONNECTION SETUP message which contains an IE "Initial UE identity" with a value which is identical to the value of the variable INITIAL_UE_IDENTITY:

1> if the RRC CONNECTION SETUP message contained a configuration the UE does not support; and/or

1> if the variable UNSUPPORTED_CONFIGURATION becomes set to TRUE due to the received RRC CONNECTION SETUP message; and/or

1> if the variable INVALID_CONFIGURATION becomes set to TRUE due to the received RRC CONNECTION SETUP message:

the UE shall:

1> stop timer T300 or T318, whichever one is running; and

1> clear the entry for the RRC CONNECTION SETUP message in the table "Accepted transactions" in the variable TRANSACTIONS and proceed as below.

If V300 is equal to or smaller than N300, the UE shall:

1> set the variable PROTOCOL_ERROR_INDICATOR to TRUE;

1> set the IEs in the RRC CONNECTION REQUEST message according to subclause 8.1.3.3;

1> perform the mapping of the Access Class to an Access Service Class as specified in subclause 8.5.13; and

1> apply the given Access Service Class when accessing the RACH;

1> submit a new RRC CONNECTION REQUEST message to the lower layers for transmission on the uplink CCCH;

1> increment counter V300; and

1> restart timer T300 when the MAC layer indicates success or failure in transmitting the message.

If V300 is greater than N300, the UE shall:

1> enter idle mode;

1> perform the actions specified in subclause 8.5.2 when entering idle mode from connected mode;

1> consider the RRC establishment procedure to be unsuccessful;

1> the procedure ends.

### 8.1.3.9 Reception of an RRC CONNECTION REJECT message by the UE

When the UE receives an RRC CONNECTION REJECT message on the downlink CCCH, it shall compare the value of the IE "Initial UE identity" in the received RRC CONNECTION REJECT message with the value of the variable INITIAL_UE_IDENTITY:

If the values are different, the UE shall ignore the rest of the message;

If the values are identical, the UE shall:

1> stop timer T300 or T318, whichever one is running; and

1> clear the entry for the RRC CONNECTION REJECT message in the table "Accepted transactions" in the variable TRANSACTIONS;

1> if the UE has disabled cell reselection to a UTRA carrier due to an earlier RRC CONNECTION REJECT message, the UE shall resume cell reselection to that UTRA carrier;

1> if the IE "wait time" <> '0'; and

1> if the IE "frequency info" is present and:

2> if V300 is equal to or smaller than N300:

3> select a suitable UTRA cell according to [4] on that frequency;

3> after having selected and camped on a suitable cell on the designated UTRA carrier:

4> set CFN in relation to SFN of current cell according to subclause 8.5.15;

4> set the contents of the RRC CONNECTION REQUEST message according to subclause 8.1.3.3;

4> perform the mapping of the Access Class to an Access Service Class as specified in subclause 8.5.13, and apply the given Access Service Class when accessing the RACH;

4> transmit an RRC CONNECTION REQUEST message on the uplink CCCH;

4> reset counter V300;

4> start timer T300 when the MAC layer indicates success or failure in transmitting the message;

4> disable cell reselection to original UTRA carrier until the time stated in the IE "wait time" has elapsed or until the RRC connection establishment procedure ends, whichever occurs first;

3> if no suitable cell on the designated UTRA carrier is found:

4> wait for at least the time stated in the IE "wait time";

4> set CFN in relation to SFN of current cell according to subclause 8.5.15;

4> set the IEs in the RRC CONNECTION REQUEST message according to subclause 8.1.3.3;

4> perform the mapping of the Access Class to an Access Service Class as specified in subclause 8.5.13, and apply the given Access Service Class when accessing the RACH;

4> then submit a new RRC CONNECTION REQUEST message to the lower layers for transmission on the uplink CCCH of the original serving cell;

4> increment counter V300;

4> restart timer T300 when the MAC layer indicates success or failure to transmit the message;

2> if V300 is greater than N300:

3> enter idle mode;

3> perform the actions specified in subclause 8.5.2 when entering idle mode from connected mode;

3> consider the RRC establishment procedure to be unsuccessful;

3> the procedure ends.

1> if the IE "inter-RAT info" is present:

2> if the IE "wait time" = '0':

3> the UE behaviour is not specified.

2> if V300 is equal to or smaller than N300:

3> if the IE "GSM target cell info" is present:

4> attempt to camp on a suitable cell of the list of cells indicated for that RAT;

4> if the UE selects and camps on one of the cells indicated for that RAT:

5> disable cell reselection to the original RAT until the time stated in the IE "wait time" has elapsed.

4> if the UE cannot find any suitable cell from the indicated ones within 10s, the UE is allowed to camp on any suitable cell on that RAT.

3> if the IE "GSM target cell info" is not present:

4> select a suitable cell in the designated RAT;

4> after having selected and camped on a suitable cell on the designated RAT:

5> disable cell reselection to the original RAT until the time stated in the IE "wait time" has elapsed or until the UE successfully establishes a connection on the designated RAT, whichever occurs first.

3> if no suitable cell in the designated RAT is found:

4> wait at least the time stated in the IE "wait time";

4> set CFN in relation to SFN of current cell according to subclause 8.5.15;

4> set the IEs in the RRC CONNECTION REQUEST message according to subclause 8.1.3.2.

4> perform the mapping of the Access Class to an Access Service Class as specified in subclause 8.5.13, and apply the given Access Service Class when accessing the RACH;

4> then submit a new RRC CONNECTION REQUEST message to the lower layers for transmission on the uplink CCCH;

4> increment counter V300;

4> restart timer T300 when the MAC layer indicates success or failure to transmit the message;

2> if V300 is greater than N300:

3> enter idle mode;

3> perform the actions specified in subclause 8.5.2 when entering idle mode from connected mode;

3> consider the RRC establishment procedure to be unsuccessful;

3> the procedure ends.

1> if the IE "wait time" <> '0'; and

1> if neither the IEs "frequency info" nor "inter-RAT info" are present:

2> if V300 is equal to or smaller than N300:

3> wait at least the time stated in the IE "wait time";

3> set the IEs in the RRC CONNECTION REQUEST message according to subclause 8.1.3.2;

3> perform the mapping of the Access Class to an Access Service Class as specified in subclause 8.5.13, and apply the given Access Service Class when accessing the RACH;

3> submit a new RRC CONNECTION REQUEST message to the lower layers for transmission on the uplink CCCH;

3> increment counter V300;

3> restart timer T300 when the MAC layer indicates success or failure to transmit the message;

2> if V300 is greater than N300:

3> enter idle mode;

3> perform the actions specified in subclause 8.5.2 when entering idle mode from connected mode;

3> consider the RRC establishment procedure to be unsuccessful;

3> the procedure ends.

1> if the IE "wait time" = '0':

2> enter idle mode;

2> perform the actions specified in subclause 8.5.2 when entering idle mode from connected mode;

2> consider the RRC establishment procedure to be unsuccessful;

2> the procedure ends.

### 8.1.3.10 Invalid RRC CONNECTION REJECT message

If the UE receives an RRC CONNECTION REJECT message which contains an IE "Initial UE identity" with a value which is identical to the value of the IE "Initial UE identity" in the most recent RRC CONNECTION REQUEST message sent by the UE; but the RRC CONNECTION REJECT message contains a protocol error causing the variable PROTOCOL_ERROR_REJECT to be set to TRUE according to clause 9, the UE shall perform procedure specific error handling as follows:

The UE shall:

1> stop timer T300 or T318, whichever one is running; and

1> clear the entry for the RRC CONNECTION REJECT message in the table "Rejected transactions" in the variable TRANSACTIONS;

1> if V300 is equal to or smaller than N300:

2> set the variable PROTOCOL_ERROR_INDICATOR to TRUE;

2> set the IEs in the RRC CONNECTION REQUEST message according to subclause 8.1.3.3;

2> perform the mapping of the Access Class to an Access Service Class as specified in subclause 8.5.13, and apply the given Access Service Class when accessing the RACH;

2> submit a new RRC CONNECTION REQUEST message to the lower layers for transmission on the uplink CCCH;

2> increment counter V300;

2> restart timer T300 when the MAC layer indicates success or failure to transmit the message.

1> if V300 is greater than N300:

2> enter idle mode;

2> perform the actions specified in subclause 8.5.2 when entering idle mode from connected mode;

2> consider the procedure to be successful;

2> the procedure ends.

## 8.1.4 RRC connection release




**Figure 8.1.4-1: RRC Connection Release procedure on the DCCH**

**Figure 8.1.4-2: RRC Connection Release procedure on the CCCH**

### 8.1.4.1 General

The purpose of this procedure is to release the RRC connection including all radio bearers and all signalling radio bearers between the UE and the UTRAN. By doing so, all established signalling connections will be released.

### 8.1.4.2 Initiation

When the UE is in state CELL_DCH or CELL_FACH, the UTRAN may at anytime initiate an RRC connection release by transmitting an RRC CONNECTION RELEASE message using UM RLC.

When UTRAN transmits an RRC CONNECTION RELEASE message the downlink DCCH should be used, if available. If the downlink DCCH is not available in UTRAN and the UE is in CELL_FACH state, the downlink CCCH may be used.

UTRAN may transmit several RRC CONNECTION RELEASE messages to increase the probability of proper reception of the message by the UE. In such a case, the RRC SN for these repeated messages should be the same. The number of repeated messages and the interval between the messages is a network option.

### 8.1.4.3 Reception of an RRC CONNECTION RELEASE message by the UE

The UE shall receive and act on an RRC CONNECTION RELEASE message in states CELL_DCH and CELL_FACH. Furthermore this procedure can interrupt any ongoing procedures with the UE in the above listed states.

When the UE receives the first RRC CONNECTION RELEASE message; and

1> if the message is received on the CCCH, and IE "U-RNTI" is present and has the same value as the variable U_RNTI; or

1> if the message is received on DCCH:

the UE shall perform the RRC connection release procedure as specified below.

When the UE receives the first RRC CONNECTION RELEASE message; and

1> if the message is received on the CCCH, the IE "UTRAN group identity" is present and there is a group identity match according to subclause 8.6.3.13:

the UE shall perform the RRC connection release procedure as specified below.

The UE shall:

1> in state CELL_DCH:

2> initialise the counter V308 to zero;

2> set the IE "RRC transaction identifier" in the RRC CONNECTION RELEASE COMPLETE message to the value of "RRC transaction identifier" in the entry for the RRC CONNECTION RELEASE message in the table "Accepted transactions" in the variable TRANSACTIONS;

2> submit an RRC CONNECTION RELEASE COMPLETE message to the lower layers for transmission using UM RLC on the DCCH to the UTRAN;

2> if the IE "Rplmn information" is present:

3> the UE may:

4> store the IE on the ME together with the PLMN id for which it applies;

3> the UE may then:

4> utilise this information, typically indicating where a number of BCCH frequency ranges of a RAT may be expected to be found, during subsequent Rplmn selections of the indicated PLMN.

2> start timer T308 when the RRC CONNECTION RELEASE COMPLETE message is sent on the radio interface.

1> in state CELL_FACH:

2> if the RRC CONNECTION RELEASE message was received on the DCCH:

3> set the IE "RRC transaction identifier" in the RRC CONNECTION RELEASE COMPLETE message to the value of "RRC transaction identifier" in the entry for the RRC CONNECTION RELEASE message in the table "Accepted transactions" in the variable TRANSACTIONS;

3> submit an RRC CONNECTION RELEASE COMPLETE message to the lower layers for transmission using AM RLC on the DCCH to the UTRAN.

3> when the successful transmission of the RRC CONNECTION RELEASE COMPLETE message has been confirmed by the lower layers:

4> release all its radio resources; and

4> indicate the release of the established signalling connections (as stored in the variable ESTABLISHED_SIGNALLING_CONNECTIONS) and established radio access bearers (as stored in the variable ESTABLISHED_RABS) to upper layers; and

4> clear any entry for the RRC CONNECTION RELEASE message in the tables "Accepted transactions" and "Rejected transactions" in the variable TRANSACTIONS;

4> clear the variable ESTABLISHED_SIGNALLING_CONNECTIONS;

4> clear the variable ESTABLISHED_RABS;

4> pass the value of the IE "Release cause" received in the RRC CONNECTION RELEASE message to upper layers;

4> enter idle mode;

4> perform the actions specified in subclause 8.5.2 when entering idle mode.

3> and the procedure ends.

2> if the RRC CONNECTION RELEASE message was received on the CCCH:

3> release all its radio resources;

3> indicate the release of the established signalling connections (as stored in the variable ESTABLISHED_SIGNALLING_CONNECTIONS) and established radio access bearers (as stored in the variable ESTABLISHED_RABS) to the upper layers;

3> clear any entry for the RRC CONNECTION RELEASE message in the tables "Accepted transactions" and "Rejected transactions" in the variable TRANSACTIONS;

3> clear the variable ESTABLISHED_SIGNALLING_CONNECTIONS;

3> clear the variable ESTABLISHED_RABS;

3> pass the value of the IE "Release cause" received in the RRC CONNECTION RELEASE message to upper layers;

3> enter idle mode;

3> perform the actions specified in subclause 8.5.2 when entering idle mode;

3> and the procedure ends.

#### 8.1.4.4 Invalid RRC CONNECTION RELEASE message

If the RRC CONNECTION RELEASE message contains a protocol error causing the variable PROTOCOL_ERROR_REJECT to be set to TRUE according to clause 9, and if the "protocol error cause" in PROTOCOL_ERROR_INFORMATION is set to any cause value except "ASN.1 violation or encoding error", the UE shall perform procedure specific error handling as follows:

The UE shall:

1> ignore any IE(s) causing the error but treat the rest of the RRC CONNECTION RELEASE message as normal according to subclause 8.1.4.3, with an addition of the following actions:

2> if the RRC CONNECTION RELEASE message was received on the DCCH:

3> set the IE "RRC transaction identifier" in the RRC CONNECTION RELEASE COMPLETE message to the value of "RRC transaction identifier" in the entry for the RRC CONNECTION RELEASE message in the table "Rejected transactions" in the variable TRANSACTIONS;

3> include the IE "Error indication" in the RRC CONNECTION RELEASE COMPLETE message with:

4> the IE "Failure cause" set to the cause value "Protocol error"; and

4> the IE "Protocol error information" set to the value of the variable PROTOCOL_ERROR_INFORMATION.

#### 8.1.4.5 Cell re-selection or radio link failure

If the UE performs cell re-selection or the radio link failure criteria in subclause 8.5.6 are met at any time during the RRC connection release procedure and the UE has not yet entered idle mode, the UE shall:

1> if cell re-selection occurred (CELL_FACH state):

2> perform a cell update procedure according to subclause 8.3.1 using the cause "Cell reselection".

1> if radio link failure occurred (CELL_DCH state):

2> release all its radio resources;

2> indicate the release of the established signalling connections (as stored in the variable ESTABLISHED_SIGNALLING_CONNECTIONS) and established radio access bearers (as stored in the variable ESTABLISHED_RABS) to upper layers;

2> clear the variable ESTABLISHED_SIGNALLING_CONNECTIONS;

2> clear the variable ESTABLISHED_RABS;

2> enter idle mode;

2> perform the actions specified in subclause 8.5.2 when entering idle mode;

2> and the procedure ends.

### 8.1.4.6 Expiry of timer T308, unacknowledged mode transmission

When in state CELL_DCH and the timer T308 expires, the UE shall:

1> increment V308 by one;

1> if V308 is equal to or smaller than N308:

2> prior to retransmitting the RRC CONNECTION RELEASE COMPLETE message:

3> if the IE "Status" in the variable INTEGRITY_PROTECTION_INFO has the value "Started":

4> include the same IEs as in the last unsuccessful attempt of this message, except for the IE "Integrity check info", which is set as specified in subclause 8.5.10.

3> else:

4> include the same IEs as in the last unsuccessful attempt of this message.

2> set the IE "RRC transaction identifier" in the RRC CONNECTION RELEASE COMPLETE message retransmitted below to the value of "RRC transaction identifier" in the entry for the RRC CONNECTION RELEASE message in the table "Accepted transactions" in the variable TRANSACTIONS;

2> send the RRC CONNECTION RELEASE COMPLETE message on signalling radio bearer RB1;

2> start timer T308 when the RRC CONNECTION RELEASE COMPLETE message is sent on the radio interface.

1> if V308 is greater than N308:

2> release all its radio resources;

2> indicate the release of the established signalling connections (as stored in the variable ESTABLISHED_SIGNALLING_CONNECTIONS) and established radio access bearers (as stored in the variable ESTABLISHED_RABS) to upper layers;

2> clear any entry for the RRC CONNECTION RELEASE message in the tables "Accepted transactions" and "Rejected transactions" in the variable TRANSACTIONS;

2> clear the variable ESTABLISHED_SIGNALLING_CONNECTIONS;

2> clear the variable ESTABLISHED_RABS;

2> enter idle mode;

2> perform the actions specified in subclause 8.5.2 when entering idle mode;

2> and the procedure ends.

### 8.1.4.7 Void

#### 8.1.4.8 Reception of an RRC CONNECTION RELEASE COMPLETE message by UTRAN

When UTRAN receives an RRC CONNECTION RELEASE COMPLETE message from the UE, it should:

1> release all UE dedicated resources and the procedure ends on the UTRAN side.

#### 8.1.4.9 Unsuccessful transmission of the RRC CONNECTION RELEASE COMPLETE message, acknowledged mode transmission

When acknowledged mode was used and RLC does not succeed in transmitting the RRC CONNECTION RELEASE COMPLETE message, the UE shall:

1> release all its radio resources;

1> indicate the release of the established signalling connections (as stored in the variable ESTABLISHED_SIGNALLING_CONNECTIONS) and established radio access bearers (as stored in the variable ESTABLISHED_RABS) to upper layers;

1> clear the variable ESTABLISHED_SIGNALLING_CONNECTIONS;

1> clear the variable ESTABLISHED_RABS;

1> enter idle mode;

1> perform the actions specified in subclause 8.5.2 when entering idle mode;

1> and the procedure ends.

#### 8.1.4.10 Detection of loss of dedicated physical channel by UTRAN in CELL_DCH state

If the release is performed from the state CELL_DCH, and UTRAN detects loss of the dedicated physical channel according to subclause 8.5.6, UTRAN may release all UE dedicated resources, even if no RRC CONNECTION RELEASE COMPLETE message has been received.

#### 8.1.4.11 Failure to receive RRC CONNECTION RELEASE COMPLETE message by UTRAN

If UTRAN does not receive any RRC CONNECTION RELEASE COMPLETE message, it should release all UE dedicated resources.

### 8.1.4a RRC connection release requested by upper layers

#### 8.1.4a.1 General

The purpose of this procedure is to release the RRC connection and bar the current cell or cells. The procedure is requested by upper layers when they determine that the network has failed an authentication check [5].

#### 8.1.4a.2 Initiation

If the upper layers request the release of the RRC connection, the UE shall:

1> release all its radio resources;

1> enter idle mode;

1> perform other actions when entering idle mode from connected mode as specified in subclause 8.5.2;

1> if the UE was in CELL_DCH state prior to entering idle mode:

2> consider all cells that were in the active set prior to entering idle mode to be barred according to [4]; and

2> consider the barred cells as using the value "allowed" in the IE "Intra-frequency cell re-selection indicator", and the maximum value in the IE "$T_{barred}$".

1> if the UE was in CELL_FACH or CELL_PCH or URA_PCH state prior to entering idle mode:

2> consider the cell on which the UE was camped prior to entering idle mode to be barred according to [4]; and

2> consider the barred cell as using the value "allowed" in the IE "Intra-frequency cell re-selection indicator", and the maximum value in the IE "$T_{barred}$".

## 8.1.5 Void

## 8.1.6 Transmission of UE capability information




**Figure 8.1.6-1: Transmission of UE capability information, normal flow**

### 8.1.6.1 General

The UE capability update procedure is used by the UE to convey UE specific capability information to the UTRAN.

### 8.1.6.2 Initiation

The UE shall initiate the UE capability update procedure in the following situations:

1> the UE receives a UE CAPABILITY ENQUIRY message from the UTRAN;

1> while in connected mode the UE capabilities change compared to those stored in the variable UE_CAPABILITY_TRANSFERRED.

If the UE CAPABILITY INFORMATION message is sent in response to a UE CAPABILITY ENQUIRY message, the UE shall:

1> include the IE "RRC transaction identifier"; and

1> set it to the value of "RRC transaction identifier" in the entry for the UE CAPABILITY ENQUIRY message in the table "Accepted transactions" in the variable TRANSACTIONS;

1> for the UE capabilities defined prior to REL-6:

2> retrieve its UTRA UE radio access capability information elements from variable UE_CAPABILITY_REQUESTED; and

2> include this in IE "UE radio access capability" and in IE "UE radio access capability extension", provided this IE is included in variable UE_CAPABILITY_REQUESTED;

2> retrieve its inter-RAT-specific UE radio access capability information elements from variable UE_CAPABILITY_REQUESTED; and

2> include this in IE "UE system specific capability".

1> for the UE capabilities defined in REL-6 or later:

2> include the information elements associated with the capabilities included in the variable UE_CAPABILITY_REQUESTED and the variable UE_CAPABILITY_TRANSFERRED.

If the UE CAPABILITY INFORMATION message is sent because one or more of the UE capabilities change compared to those stored in the variable UE_CAPABILITY_TRANSFERRED while in connected state, the UE shall:

1> for the UE capabilities defined prior to REL-6, include the information elements associated with the capabilities that have changed in the UE CAPABILITY INFORMATION message; and

1> for the UE capabilities defined in REL-6 or later, include the information elements associated with the capabilities included in the variable UE_CAPABILITY_TRANSFERRED.

If the UE is in CELL_PCH or URA_PCH state, it shall first perform a cell update procedure using the cause "uplink data transmission", see subclause 8.3.1.

The UE RRC shall submit the UE CAPABILITY INFORMATION message to the lower layers for transmission on the uplink DCCH using AM RLC. When the message has been delivered to lower layers for transmission the UE RRC shall start timer T304 and set counter V304 to 1.

### 8.1.6.3 Reception of a UE CAPABILITY INFORMATION message by the UTRAN

Upon reception of a UE CAPABILITY INFORMATION message, the UTRAN should transmit a UE CAPABILITY INFORMATION CONFIRM message on the downlink DCCH using UM or AM RLC. After the UE CAPABILITY INFORMATION CONFIRM message has been submitted to the lower layers for transmission, the procedure is complete.

### 8.1.6.4 Reception of the UE CAPABILITY INFORMATION CONFIRM message by the UE

Upon reception of a UE CAPABILITY INFORMATION CONFIRM message, the UE shall:

1> stop timer T304;

1> if there is an entry for the UE CAPABILITY ENQUIRY message is present in the table "Accepted transactions" in the variable TRANSACTIONS:

2> clear that entry.

1> update its variable UE_CAPABILITY_TRANSFERRED with the UE capabilities it has last transmitted to the UTRAN during the current RRC connection;

1> clear the variable UE_CAPABILITY_REQUESTED;

1> and the procedure ends.

### 8.1.6.5 Invalid UE CAPABILITY INFORMATION CONFIRM message

If the UE receives a UE CAPABILITY INFORMATION CONFIRM message, which contains a protocol error causing the variable PROTOCOL_ERROR_REJECT to be set to TRUE according to clause 9, the UE shall perform procedure specific error handling as follows:

1> stop timer T304;

1> transmit an RRC STATUS message on the uplink DCCH using AM RLC;

1> include the IE "Identification of received message"; and

1> set the IE "Received message type" to UE CAPABILITY INFORMATION CONFIRM; and

1> set the IE "RRC transaction identifier" to the value of "RRC transaction identifier" in the entry for the UE CAPABILITY INFORMATION CONFIRM message in the table "Rejected transactions" in the variable TRANSACTIONS; and

1> clear that entry;

1> include the IE "Protocol error information" with contents set to the value of the variable PROTOCOL_ERROR_INFORMATION;

1> when the RRC STATUS message has been submitted to lower layers for transmission:

2> restart timer T304 and continue with any ongoing procedures or processes as if the invalid UE CAPABILITY INFORMATION CONFIRM message has not been received.

#### 8.1.6.6 T304 timeout

Upon expiry of timer T304, the UE shall check the value of V304 and:

1> if V304 is smaller than or equal to N304:

2> prior to retransmitting the UE CAPABILITY INFORMATION message:

3> if the IE "Status" in the variable INTEGRITY_PROTECTION_INFO has the value "Started":

4> include the same IEs as in the last unsuccessful attempt of this message, except for the IE "Integrity check info", which is set as specified in subclause 8.5.10.

3> else:

4> include the same IEs as in the last unsuccessful attempt of this message.

2> send the UE CAPABILITY INFORMATION message on signalling radio bearer RB2;

2> restart timer T304;

2> increment counter V304.

1> if V304 is greater than N304:

2> initiate the Cell update procedure as specified in subclause 8.3.1, using the cause "Radio link failure".

### 8.1.7 UE capability enquiry

**Figure 8.1.7-1: UE capability enquiry procedure, normal flow**

#### 8.1.7.1 General

The UE capability enquiry can be used to request the UE to transmit its capability information related to any radio access network that is supported by the UE.

#### 8.1.7.2 Initiation

The UE capability enquiry procedure is initiated by the UTRAN by transmitting a UE CAPABILITY ENQUIRY message on the DCCH using UM or AM RLC.

#### 8.1.7.3 Reception of a UE CAPABILITY ENQUIRY message by the UE

Upon reception of a UE CAPABILITY ENQUIRY message, the UE shall act on the received information elements as specified in subclause 8.6 and initiate the transmission of UE capability information procedure, which is specified in subclause 8.1.6.

#### 8.1.7.4 Invalid UE CAPABILITY ENQUIRY message

If the UE receives a UE CAPABILITY ENQUIRY message, which contains a protocol error causing the variable PROTOCOL_ERROR_REJECT to be set to TRUE according to clause 9, the UE shall perform procedure specific error handling as follows:

1> transmit an RRC STATUS message on the uplink DCCH using AM RLC;

1> include the IE "Identification of received message"; and

1> set the IE "Received message type" to UE CAPABILITY ENQUIRY; and

1> set the IE "RRC transaction identifier" to the value of "RRC transaction identifier" in the entry for the UE CAPABILITY ENQUIRY message in the table "Rejected transactions" in the variable TRANSACTIONS; and

1> clear that entry;

1> include the IE "Protocol error information" with contents set to the value of the variable PROTOCOL_ERROR_INFORMATION;

1> when the RRC STATUS message has been submitted to lower layers for transmission:

2> continue with the ongoing processes and procedures as if the invalid UE CAPABILITY ENQUIRY message has not been received.

### 8.1.8 Initial Direct transfer

**Figure 8.1.8-1: Initial Direct transfer in the uplink, normal flow**

#### 8.1.8.1 General

The initial direct transfer procedure is used in the uplink to establish a signalling connection. It is also used to carry an initial upper layer (NAS) message over the radio interface.

#### 8.1.8.2 Initiation of Initial direct transfer procedure in the UE

In the UE, the initial direct transfer procedure shall be initiated, when the upper layers request establishment of a signalling connection. This request also includes a request for the transfer of a NAS message.

Upon initiation of the initial direct transfer procedure the UE shall:

1> set the variable ESTABLISHMENT_CAUSE to the cause for establishment indicated by upper layers.

Upon initiation of the initial direct transfer procedure when the UE is in idle mode, the UE shall:

1> perform an RRC connection establishment procedure, according to subclause 8.1.3;

NOTE: If an RRC connection establishment is ongoing, this procedure continues unchanged, i.e. it is not interrupted.

1> if the RRC connection establishment procedure was not successful:

2> if the establishment cause for the failed RRC connection establishment was set to "MBMS reception" and a different cause value is stored in the variable "ESTABLISHMENT_CAUSE":

3> UE-AS (RRC) initiates a new RRC connection establishment procedure, using the establishment cause as contained in the variable ESTABLISHMENT_CAUSE.

2> otherwise:

3> indicate failure to establish the signalling connection to upper layers and end the procedure.

1> when the RRC connection establishment procedure is completed successfully:

2> continue with the initial direct transfer procedure as below.

Upon initiation of the initial direct transfer procedure when the UE is in CELL_PCH or URA_PCH state, the UE shall:

1> perform a cell update procedure, according to subclause 8.3.1, using the cause "uplink data transmission";

1> when the cell update procedure completed successfully:

2> continue with the initial direct transfer procedure as below.

The UE shall, in the INITIAL DIRECT TRANSFER message:

1> set the IE "NAS message" as received from upper layers; and

1> set the IE "CN domain identity" as indicated by the upper layers; and

1> set the IE "Intra Domain NAS Node Selector" as follows:

2> derive the IE "Intra Domain NAS Node Selector" from TMSI/PMTSI, IMSI, or IMEI; and

2> provide the coding of the IE "Intra Domain NAS Node Selector" according to the following priorities:

1. derive the routing parameter for IDNNS from TMSI (CS domain) or PTMSI (PS domain) whenever a valid TMSI/PTMSI is available;

2. base the routing parameter for IDNNS on IMSI when no valid TMSI/PTMSI is available;

3. base the routing parameter for IDNNS on IMEI only if no (U)SIM is inserted in the UE.

1> if the UE, on the existing RRC connection, has received a dedicated RRC message containing the IE "Primary PLMN Identity" in the IE "CN Information Info":

2> set the IE "PLMN identity" in the INITIAL DIRECT TRANSFER message to the latest PLMN information received via dedicated RRC signalling. If NAS has indicated the PLMN towards which a signalling connection is requested, and this PLMN is not in agreement with the latest PLMN information received via dedicated RRC signalling, then the initial direct transfer procedure shall be aborted, and NAS shall be informed.

1> if the UE, on the existing RRC connection, has not received a dedicated RRC message containing the IE "CN Information Info" , and if the IE "Multiple PLMN List" was broadcast in the cell where the current RRC connection was established:

2> set the IE "PLMN identity" in the INITIAL DIRECT TRANSFER message to the PLMN chosen by higher layers [5, 25] amongst the PLMNs in the IE "Multiple PLMN List" broadcast in the cell where the RRC connection was established.

1> if the IE "Activated service list" within variable MBMS_ACTIVATED_SERVICES includes one or more MBMS services with the IE "Service type" set to "Multicast" and;

1> if the IE "CN domain identity" as indicated by the upper layers is set to "CS domain" and;

1> if the variable ESTABLISHED_SIGNALLING_CONNECTIONS does not include the CN domain identity 'PS domain':

2> include the IE "MBMS joined information";

2> include the IE "P-TMSI" within the IE "MBMS joined information" if a valid PTMSI is available.

1> if the variable ESTABLISHMENT_CAUSE_ is initialised:

2> set the IE "Establishment cause" to the value of the variable ESTABLISHMENT_CAUSE;

2> clear the variable ESTABLISHMENT_CAUSE.

1> calculate the START according to subclause 8.5.9 for the CN domain as set in the IE "CN Domain Identity"; and

1> include the calculated START value for that CN domain in the IE "START".

The UE shall:

1> transmit the INITIAL DIRECT TRANSFER message on the uplink DCCH using AM RLC on signalling radio bearer RB3;

1> when the INITIAL DIRECT TRANSFER message has been submitted to lower layers for transmission:

2> confirm the establishment of a signalling connection to upper layers; and

2> add the signalling connection with the identity indicated by the IE "CN domain identity" in the variable ESTABLISHED_SIGNALLING_CONNECTIONS.

1> when the successful delivery of the INITIAL DIRECT TRANSFER message has been confirmed by RLC:

2> the procedure ends.

When not stated otherwise elsewhere, the UE may also initiate the initial direct transfer procedure when another procedure is ongoing, and in that case the state of the latter procedure shall not be affected.

A new signalling connection request may be received from upper layers during transition to idle mode. In those cases, from the time of the indication of release to upper layers until the UE has entered idle mode, any such upper layer request to establish a new signalling connection shall be queued. This request shall be processed after the UE has entered idle mode.

#### 8.1.8.2a RLC re-establishment or inter-RAT change

If a re-establishment of the transmitting side of the RLC entity on signalling radio bearer RB3 occurs before the successful delivery of the INITIAL DIRECT TRANSFER message has been confirmed by RLC, the UE shall:

1> retransmit the INITIAL DIRECT TRANSFER message on the uplink DCCH using AM RLC on signalling radio bearer RB3.

If an Inter-RAT handover from UTRAN procedure occurs before the successful delivery of the INITIAL DIRECT TRANSFER message has been confirmed by RLC, for messages with the IE "CN domain identity" set to "CS domain", the UE shall:

1> retransmit the NAS message as specified in subclause 8.3.7.4.

#### 8.1.8.2ab Inter-RAT handover from UTRAN to GERAN *Iu mode*

If an Inter-RAT handover from UTRAN to GERAN *Iu mode* occurs before the successful delivery of the INITIAL DIRECT TRANSFER message has been confirmed by RLC, for messages for all CN domains, the UE shall:

1> retransmit the NAS message as specified in subclause 8.3.7.4.

#### 8.1.8.2b Abortion of signalling connection establishment

If the UE receives a request from upper layers to release (abort) the signalling connection for the CN domain for which the initial direct transfer procedure is ongoing, the UE shall:

1> if the UE has not yet entered UTRA RRC connected mode:

2> abort the RRC connection establishment procedure as specified in subclause 8.1.3;

the procedure ends.

#### 8.1.8.3 Reception of INITIAL DIRECT TRANSFER message by the UTRAN

On reception of the INITIAL DIRECT TRANSFER message the NAS message should be routed using the IE "CN Domain Identity". UTRAN may also use the IE "Intra Domain NAS Node Selector" and the IE "PLMN identity" for routing among the CN nodes for the addressed CN domain.

If no signalling connection exists towards the chosen node, then a signalling connection is established.

When the UTRAN receives an INITIAL DIRECT TRANSFER message, it shall not affect the state of any other ongoing RRC procedures, when not stated otherwise elsewhere.

The UTRAN should:

1> set the START value for the CN domain indicated in the IE "CN domain identity" to the value of the IE "START".

### 8.1.9 Downlink Direct transfer

**Figure 8.1.9-1: Downlink Direct transfer, normal flow**

#### 8.1.9.1 General

The downlink direct transfer procedure is used in the downlink direction to carry upper layer (NAS) messages over the radio interface.

#### 8.1.9.2 Initiation of downlink direct transfer procedure in the UTRAN

In the UTRAN, the direct transfer procedure is initiated when the upper layers request the transfer of a NAS message after the initial signalling connection is established. The UTRAN may also initiate the downlink direct transfer procedure when another RRC procedure is ongoing, and in that case the state of the latter procedure shall not be affected. The UTRAN shall transmit the DOWNLINK DIRECT TRANSFER message on the downlink DCCH using AM RLC on signalling radio bearer RB3 or signalling radio bearer RB4. The UTRAN should:

1> if upper layers indicate "low priority" for this message:

2> select signalling radio bearer RB4, if available. Specifically, for a GSM-MAP based CN, signalling radio bearer RB4 should, if available, be selected when "SAPI 3" is requested;

2> select signalling radio bearer RB3 when signalling radio bearer RB4 is not available.

1> if upper layers indicate "high priority" for this message:

2> select signalling radio bearer RB3. Specifically, for a GSM-MAP based CN, signalling radio bearer RB3 should be selected when "SAPI 0" is requested.

The UTRAN sets the IE "CN Domain Identity" to indicate, which CN domain the NAS message is originated from.

### 8.1.9.3 Reception of a DOWNLINK DIRECT TRANSFER message by the UE

Upon reception of the DOWNLINK DIRECT TRANSFER message, the UE RRC shall, using the IE "CN Domain Identity", route the contents of the IE "NAS message" and the value of the IE"CN Domain Identity" to upper layers.

The UE shall clear the entry for the DOWNLINK DIRECT TRANSFER message in the table "Accepted transactions" in the variable TRANSACTIONS.

When the UE receives a DOWNLINK DIRECT TRANSFER message, it shall not affect the state of any other ongoing RRC procedures when not stated otherwise elsewhere.

### 8.1.9.3a No signalling connection exists

If the UE receives a DOWNLINK DIRECT TRANSFER message, and the signalling connection identified with the IE "CN domain identity" does not exist according to the variable ESTABLISHED_SIGNALLING_CONNECTIONS, the UE shall:

1> ignore the content of the DOWNLINK DIRECT TRANSFER message;

1> transmit an RRC STATUS message on the uplink DCCH using AM RLC;

1> include the IE "Identification of received message"; and

1> set the IE "Received message type" to DOWNLINK DIRECT TRANSFER; and

1> set the IE "RRC transaction identifier" to the value of "RRC transaction identifier" in the entry for the DOWNLINK DIRECT TRANSFER message in the table "Accepted transactions" in the variable TRANSACTIONS; and

1> clear that entry;

1> include the IE "Protocol error information" with the IE "Protocol error cause" set to "Message not compatible with receiver state".

When the RRC STATUS message has been submitted to lower layers for transmission, the UE shall:

1> continue with any ongoing processes and procedures as if the DOWNLINK DIRECT TRANSFER message has not been received.

### 8.1.9.4 Invalid DOWNLINK DIRECT TRANSFER message

If the UE receives a DOWNLINK DIRECT TRANSFER message, which contains a protocol error causing the variable PROTOCOL_ERROR_REJECT to be set to TRUE according to clause 9, the UE shall perform procedure specific error handling as follows:

1> transmit an RRC STATUS message on the uplink DCCH using AM RLC;

1> include the IE "Identification of received message"; and

1> set the IE "Received message type" to DOWNLINK DIRECT TRANSFER; and

1> set the IE "RRC transaction identifier" to the value of "RRC transaction identifier" in the entry for the DOWNLINK DIRECT TRANSFER message in the table "Rejected transactions" in the variable TRANSACTIONS; and

1> clear that entry;

1> include the IE "Protocol error information" with contents set to the value of the variable PROTOCOL_ERROR_INFORMATION.

When the RRC STATUS message has been submitted to lower layers for transmission, the UE shall:

1> continue with any ongoing processes and procedures as if the invalid DOWNLINK DIRECT TRANSFER message has not been received.

## 8.1.10 Uplink Direct transfer

**Figure 8.1.10-1: Uplink Direct transfer, normal flow**

### 8.1.10.1 General

The uplink direct transfer procedure is used in the uplink direction to carry all subsequent upper layer (NAS) messages over the radio interface belonging to a signalling connection.

### 8.1.10.2 Initiation of uplink direct transfer procedure in the UE

In the UE, the uplink direct transfer procedure shall be initiated when the upper layers request a transfer of a NAS message on an existing signalling connection. When not stated otherwise elsewhere, the UE may initiate the uplink direct transfer procedure when another procedure is ongoing, and in that case the state of the latter procedure shall not be affected.

Upon initiation of the uplink direct transfer procedure in CELL_PCH or URA_PCH state, the UE shall:

1> perform a cell update procedure, according to subclause 8.3.1, using the cause "uplink data transmission";

1> when the cell update procedure has been completed successfully:

2> continue with the uplink direct transfer procedure as below.

The UE shall transmit the UPLINK DIRECT TRANSFER message on the uplink DCCH using AM RLC on signalling radio bearer RB3 or signalling radio bearer RB4. The UE shall:

1> if upper layers indicate "low priority" for this message:

2> select signalling radio bearer RB4, if available. Specifically, for a GSM-MAP based CN, signalling radio bearer RB4 shall, if available, be selected when "SAPI 3" is requested;

2> select signalling radio bearer RB3 when signalling radio bearer RB4 is not available;

1> if upper layers indicate "high priority" for this message:

2> select signalling radio bearer RB3. Specifically, for a GSM-MAP based CN, signalling radio bearer RB3 shall be selected when "SAPI 0" is requested.

The UE shall set the IE "NAS message" as received from upper layers and set the IE "CN domain identity" as indicated by the upper layers.

When the successful delivery of the UPLINK DIRECT TRANSFER message has been confirmed by RLC the procedure ends.

### 8.1.10.2a RLC re-establishment or inter-RAT change

If signalling radio bearer RB n (where n equals to 3 or 4) was used when transmitting the UPLINK DIRECT TRANSFER message and a re-establishment of the transmitting side of the RLC entity on the same signalling radio bearer RB n occurs before the successful delivery of the UPLINK DIRECT TRANSFER message has been confirmed by RLC, the UE shall:

1> retransmit the UPLINK DIRECT TRANSFER message on the uplink DCCH using AM RLC on signalling radio bearer RB n.

If an Inter-RAT handover from UTRAN procedure occurs before the successful delivery of the UPLINK DIRECT TRANSFER message has been confirmed by RLC, for messages with the IE "CN domain identity" set to "CS domain", the UE shall:

1> retransmit the NAS message as specified in subclause 8.3.7.4.

### 8.1.10.2b Inter-RAT handover from UTRAN to GERAN *Iu mode*

If an Inter-RAT handover from UTRAN to GERAN *Iu mode* occurs before the successful delivery of the UPLINK DIRECT TRANSFER message has been confirmed by RLC, for messages for all CN domains, the UE shall:

1> retransmit the NAS message as specified in subclause 8.3.7.4.

### 8.1.10.3 Reception of UPLINK DIRECT TRANSFER message by the UTRAN

On reception of the UPLINK DIRECT TRANSFER message the NAS message should be routed using the value indicated in the IE "CN domain identity".

When the UTRAN receives an UPLINK DIRECT TRANSFER message, it shall not affect the state of any other ongoing RRC procedures, when not stated otherwise elsewhere.

## 8.1.11 UE dedicated paging




**Figure 8.1.11-1: UE dedicated paging**

### 8.1.11.1 General

This procedure is used to transmit dedicated paging information to one UE in connected mode in CELL_DCH or CELL_FACH state. Upper layers in the network may request initiation of paging.

### 8.1.11.2 Initiation

For a UE in CELL_DCH or CELL_FACH state, UTRAN initiates the procedure by transmitting a PAGING TYPE 2 message on the DCCH using AM RLC. When not stated otherwise elsewhere, the UTRAN may initiate the UE dedicated paging procedure also when another RRC procedure is ongoing, and in that case the state of the latter procedure shall not be affected.

UTRAN should set the IE "Paging cause" to the cause for paging received from upper layers. If no cause for paging is received from upper layers, UTRAN should set the value "Terminating – cause unknown".

### 8.1.11.3 Reception of a PAGING TYPE 2 message by the UE

When the UE receives a PAGING TYPE 2 message, it shall not affect the state of any other ongoing RRC procedures, when not stated otherwise elsewhere.

The UE shall:

1> indicate reception of paging; and

1> forward the IE "Paging cause" and the IE "Paging record type identifier" to upper layers.

The UE shall:

1> clear the entry for the PAGING TYPE 2 message in the table "Accepted transactions" in the variable TRANSACTIONS.

### 8.1.11.4 Invalid PAGING TYPE 2 message

If the UE receives a PAGING TYPE 2 message, which contains a protocol error causing the variable PROTOCOL_ERROR_REJECT to be set to TRUE according to clause 9, the UE shall perform procedure specific error handling as follows:

1> transmit an RRC STATUS message on the uplink DCCH using AM RLC;

1> include the IE "Identification of received message"; and

1> set the IE "Received message type" to PAGING TYPE 2; and

1> set the IE "RRC transaction identifier" to the value of "RRC transaction identifier" in the entry for the PAGING TYPE 2 message in the table "Rejected transactions" in the variable TRANSACTIONS; and

1> clear that entry;

1> include the IE "Protocol error information" with contents set to the value of the variable PROTOCOL_ERROR_INFORMATION;

1> when the RRC STATUS message has been submitted to lower layers for transmission:

2> continue with any ongoing processes and procedures as if the invalid PAGING TYPE 2 message has not been received.

## 8.1.12 Security mode control




**Figure 8.1.12-1: Security mode control procedure**

### 8.1.12.1 General

The purpose of this procedure is to trigger the start of ciphering or to command the restart of the ciphering with a new ciphering configuration, for the radio bearers of one CN domain and for all signalling radio bearers.

It is also used to start integrity protection or to modify the integrity protection configuration for all signalling radio bearers.

### 8.1.12.2 Initiation

#### 8.1.12.2.1 Ciphering configuration change

To start/restart ciphering, UTRAN sends a SECURITY MODE COMMAND message on the downlink DCCH in AM RLC using the most recent ciphering configuration. If no such ciphering configuration exists then the SECURITY MODE COMMAND is not ciphered. UTRAN should not transmit a SECURITY MODE COMMAND to signal a change in ciphering algorithm.

When configuring ciphering, UTRAN should ensure that the UE needs to store at most two different ciphering configurations (keyset and algorithm) per CN domain, in total over all radio bearers at any given time. For signalling radio bearers the total number of ciphering configurations that need to be stored is at most three. Prior to sending the SECURITY MODE COMMAND, for the CN domain indicated in the IE "CN domain identity" in the SECURITY MODE COMMAND, UTRAN should:

1> suspend all radio bearers using RLC-AM or RLC-UM and all signalling radio bearers using RLC-AM or RLC-UM, except the signalling radio bearer used to send the SECURITY MODE COMMAND message on the downlink DCCH in RLC-AM, and except signalling radio bearer RB0, according to the following:

2> not transmit RLC PDUs with sequence number greater than or equal to the number in IE "Radio bearer downlink ciphering activation time info" on all suspended radio bearers and all suspended signalling radio bearers.

1> set, for the signalling radio bearer used to send the SECURITY MODE COMMAND, the "RLC sequence number" in IE "Radio bearer downlink ciphering activation time info" in the IE "Ciphering mode info", at which time the new ciphering configuration shall be applied;

NOTE: The UTRAN should avoid the situation that the UE is aware of more than one pending downlink ciphering activation times for SRB2. In such a case the UE behaviour is unspecified.

1> if a transparent mode radio bearer for this CN domain exists:

2> include the IE "Ciphering activation time for DPCH" in IE "Ciphering mode info", at which time the new ciphering configuration shall be applied and specify a CFN value for this IE that is a multiple of 8 frames (CFN mod 8 = 0).

NOTE: UTRAN should chose the value for the IE "Ciphering activation time for DPCH" such that the new ciphering configuration will occur after all the pending ciphering activation times have been reached for the transparent mode radio bearers of this CN domain.

1> consider a ciphering activation time in downlink to be pending until the RLC sequence number of the next RLC PDU to be transmitted for the first time is equal to or larger than the selected activation time;

1> set, for each suspended radio bearer and signalling radio bearer that has no pending ciphering activation time set by a previous security mode control procedure, an "RLC sequence number" in IE "Radio bearer downlink ciphering activation time info" in the IE "Ciphering mode info", at which time the new ciphering configuration shall be applied;

1> set, for each suspended radio bearer and signalling radio bearer that has a pending ciphering activation time set by a previous security mode control procedure, the "RLC sequence number" in IE "Radio bearer downlink ciphering activation time info" in the IE "Ciphering mode info" to the value used in the previous security mode control procedure, at which time the latest ciphering configuration shall be applied;

1> if Integrity protection has already been started for the UE:

2> if for the CN domain indicated in the IE "CN domain identity" in the SECURITY MODE COMMAND, a new security key set (new ciphering and integrity protection keys) has been received from upper layers since the transmission of the last SECURITY MODE COMMAND message for that CN domain:

3> include the IE "Integrity protection mode info" in the SECURITY MODE COMMAND.

2> if the IE "CN domain identity" in the SECURITY MODE COMMAND is different from the IE "CN domain identity" that was sent in the previous SECURITY MODE COMMAND message to the UE:

3> include the IE "Integrity protection mode info" in the SECURITY MODE COMMAND.

1> transmit the SECURITY MODE COMMAND message on RB2;

1> prohibit the transmission of RRC messages on RB2.

#### 8.1.12.2.2 Integrity protection configuration change

To start or modify integrity protection, UTRAN sends a SECURITY MODE COMMAND message on the downlink DCCH in AM RLC using the new integrity protection configuration. UTRAN should not "modify" integrity protection for a CN domain to which a SECURITY MODE COMMAND configuring integrity protection has been previously sent for an ongoing signalling connection unless the application of new integrity keys needs to be signalled to the UE. UTRAN should not transmit a SECURITY MODE COMMAND to signal a change in integrity protection algorithm.

In case of Inter-RAT handover to UTRAN, after the reception of the HANDOVER TO UTRAN COMPLETE message and a key set is received, UTRAN should transmit a SECURITY MODE COMMAND message containing IE "Integrity protection mode info" in order to initiate integrity protection with the integrity key of the key set used in the other RAT (see subclause 8.3.6.3).

When configuring Integrity protection, UTRAN should:

1> ensure that the UE needs to store at most three different Integrity protection configurations (keysets) at any given time. This includes the total number of Integrity protection configurations for all signalling radio bearers;

1> if Ciphering has already been started for the UE for the CN domain to be set in the IE "CN domain identity" in the SECURITY MODE COMMAND:

2> if for the CN domain indicated in the IE "CN domain identity" in the SECURITY MODE COMMAND, a new security key set (new ciphering and integrity protection keys) has been received from upper layers since the transmission of the last SECURITY MODE COMMAND message for that CN domain:

3> include the IE "Ciphering mode info" in the SECURITY MODE COMMAND.

1> if Ciphering has already been configured for the UE for a CN domain different from the CN domain to be set in the IE "CN domain identity" in the SECURITY MODE COMMAND:

2> include the IE "Ciphering mode info" in the SECURITY MODE COMMAND.

Prior to sending the SECURITY MODE COMMAND, for the CN domain indicated in the IE "CN domain identity" in the SECURITY MODE COMMAND, UTRAN should:

1> if this is the first SECURITY MODE COMMAND sent for this RRC connection:

2> if new keys have been received:

3> initialise the hyper frame numbers as follows:

4> set all bits of the hyper frame numbers of the COUNT-I values for all signalling radio bearers to zero.

2> else (if new keys have not been received):

3> use the value "START" in the most recently received IE "START list" or IE "START" that belongs to the CN domain indicated in the IE "CN domain identity" to initialise all hyper frame numbers of COUNT-I for all the signalling radio bearers by:

4> setting the 20 most significant bits of the hyper frame numbers for all signalling radio bearers to the value "START" in the most recently received IE "START list" or IE "START" for that CN domain;

4> setting the remaining bits of the hyper frame numbers equal to zero.

1> else (this is not the first SECURITY MODE COMMAND sent for this RRC connection):

2> if new keys have been received:

3> initialise the hyper frame number for COUNT-I for RB2 as follows:

4> set all bits of the HFN of the COUNT-I value for RB2 to zero.

2> if new keys have not been received:

3> initialise the hyper frame number for COUNT-I for RB2 as follows:

4> set the 20 most significant bits of the HFN of the downlink and uplink COUNT-I to the value of the most recently received IE "START" or IE "START list" for the CN domain to be set in the IE "CN Domain Identity";

4> set the remaining bits of the HFN of the downlink and uplink COUNT-I to zero.

1> if the IE "Integrity protection mode command" has the value "Start":

2> prohibit the transmission of signalling messages with any RRC SN on all signalling radio bearers, except RB2;

2> set the FRESH value in the IE "Integrity protection initialisation number", included in the IE "Integrity protection mode info".

1> if the IE "Integrity protection mode command" has the value "Modify":

2> for each signalling radio bearer RBn, except RB2:

3> prohibit the transmission of signalling messages with RRC SN greater or equal to the RRC sequence number in entry for signalling radio bearer n in the "RRC message sequence number list" in the IE "Downlink integrity protection activation info", included in the IE "Integrity protection mode info".

2> consider an integrity protection activation time in downlink to be pending until the selected activation time is equal to the next RRC sequence number to be used, which means that the last RRC message using the old integrity protection configuration has been submitted to lower layers;

2> set, for each signalling radio bearer RBn, that has no pending integrity protection activation time set by a previous security mode control procedure, an RRC sequence number in entry for signalling radio bearer n in the "RRC message sequence number list" in the IE "Downlink integrity protection activation info", included in the IE "Integrity protection mode info", at which time the new integrity protection configuration shall be applied;

2> set, for each signalling radio bearer RBn, that has a pending integrity protection activation time set by a previous security mode control procedure, the RRC sequence number in entry for signalling radio bearer n in the "RRC message sequence number list" in the IE "Downlink integrity protection activation info", included in the IE "Integrity protection mode info", to the value used in the previous security mode control procedure, at which time the latest integrity protection configuration shall be applied.

1> transmit the SECURITY MODE COMMAND message on RB2 using the new integrity protection configuration.

NOTE1: In the case of re-initialisation of Integrity Protection at HFN wrap around, the network should take into account the UE actions as described in subclauses 8.5.10.1 and 8.5.10.2.

NOTE2: After the SECURITY MODE COMMAND message is transmitted, the network should ensure that it can revert back to old integrity protection until it receives the SECURITY MODE COMPLETE message, to take into account the UE actions when security mode control procedure is unsuccessful. The network should also be aware that the UE may revert to old configuration when waiting for the acknowledgement from L2 for the SECURITY MODE COMPLETE message, and act accordingly.

NOTE3: In the case of the first SECURITY MODE COMMAND message following an SRNS relocation, the network should set the IE "Downlink integrity protection activation info" for SRB3 and SRB4 to at least "the current downlink RRC sequence number +2". As a consequence, at least the first message sent on SRB3 and SRB4 by the Target RNC will use the old integrity protection configuration.

### 8.1.12.3 Reception of SECURITY MODE COMMAND message by the UE

Upon reception of the SECURITY MODE COMMAND message, the UE shall:

1> if neither IE "Ciphering mode info" nor IE "Integrity protection mode info" is included in the SECURITY MODE COMMAND:

2> set the variable INVALID_CONFIGURATION to TRUE.

1> if the IE "Security capability" is the same as indicated by variable UE_CAPABILITY_TRANSFERRED, and the IE "GSM security capability" (if included in the SECURITY MODE COMMAND) is the same as indicated by the variable UE_CAPABILITY_TRANSFERRED:

2> set the variable LATEST_CONFIGURED_CN_DOMAIN equal to the IE "CN domain identity";

2> set the IE "Status" in the variable SECURITY_MODIFICATION for the CN domain indicated in the IE "CN domain identity" in the received SECURITY MODE COMMAND to the value "Affected";

2> set the IE "Status" in the variable SECURITY_MODIFICATION for all CN domains other than the CN domain indicated in the IE "CN domain identity" to "Not affected";

2> set the IE "RRC transaction identifier" in the SECURITY MODE COMPLETE message to the value of "RRC transaction identifier" in the entry for the SECURITY MODE COMMAND message in the table "Accepted transactions" in the variable TRANSACTIONS; and

2> clear that entry;

2> if the SECURITY MODE COMMAND message contained the IE "Ciphering mode info":

3> perform the actions as specified in subclause 8.6.3.4.

2> if the SECURITY MODE COMMAND message contained the IE "Integrity protection mode info":

3> perform the actions as specified in subclause 8.6.3.5.

1> prior to sending the SECURITY MODE COMPLETE message:

2> use the old ciphering configuration for this message;

2> if the SECURITY MODE COMMAND message contained the IE "Ciphering mode info":

3> include and set the IE "Radio bearer uplink ciphering activation time info" to the value of the variable RB_UPLINK_CIPHERING_ACTIVATION_TIME_INFO;

3> for each radio bearer and signalling radio bearer that belongs to the CN domain as indicated in the variable LATEST_CONFIGURED_CN_DOMAIN:

4> start or continue incrementing the COUNT-C values for all RLC-AM and RLC-UM signalling radio bearers at the ciphering activation time as specified in the procedure;

4> start or continue incrementing the COUNT-C values common for all transparent mode radio bearers for this CN domain at the ciphering activation time as specified in the procedure;

4> continue incrementing the COUNT-C values for all RLC-AM and RLC-UM radio bearers.

3> if no new security key set (new ciphering and integrity protection keys) has been received from the upper layers [40] for the CN domain as indicated in the variable LATEST_CONFIGURED_CN_DOMAIN:

4> for ciphering on signalling radio bearers using RLC-AM and RLC-UM in the downlink, at the RLC sequence number indicated in IE "Radio bearer downlink ciphering activation time info" in the IE

"Ciphering mode info" included in the SECURITY MODE COMMAND, for each signalling radio bearer:

5> set the 20 most significant bits of the HFN component of the downlink COUNT-C to the value "START" in the most recently transmitted IE "START list" or IE "START", at the reception of the SECURITY MODE COMMAND, that belongs to the CN domain as indicated in the variable LATEST_CONFIGURED_CN_DOMAIN;

5> set the remaining bits of the hyper frame numbers to zero.

3> if new keys have been received:

4> perform the actions in subclause 8.1.12.3.1.

2> if the SECURITY MODE COMMAND message contained the IE "Integrity protection mode info":

3> include and set the IE "Uplink integrity protection activation info" to the value of the variable INTEGRITY_PROTECTION_ACTIVATION_INFO for each signalling radio bearer;

3> if no new security key set (new ciphering and integrity protection keys) has been received from the upper layers [40] for the CN domain as indicated in the variable LATEST_CONFIGURED_CN_DOMAIN, for RB2:

4> in the downlink, for the received SECURITY MODE COMMAND message:

5> set the 20 most significant bits of the IE "Downlink RRC HFN" in the variable INTEGRITY_PROTECTION_INFO of the downlink COUNT-I to the value "START" in the most recently transmitted IE "START list" or IE "START", at the reception of the SECURITY MODE COMMAND, that belongs to the CN domain as indicated in the variable LATEST_CONFIGURED_CN_DOMAIN;

5> set the remaining bits of the IE "Downlink RRC HFN" to zero.

4> in the uplink, for the transmitted response message, SECURITY MODE COMPLETE:

5> set the 20 most significant bits of the IE "Uplink RRC HFN" in the variable INTEGRITY_PROTECTION_INFO of the uplink COUNT-I to the value "START" in the most recently transmitted IE "START list" or IE "START", at the reception of the SECURITY MODE COMMAND, that belongs to the CN domain as indicated in the variable LATEST_CONFIGURED_CN_DOMAIN;

5> set the remaining bits of the IE "Uplink RRC HFN" to zero.

3> if no new security key set (new ciphering and integrity protection keys) has been received from the upper layers [40] for the CN domain indicated in the variable LATEST_CONFIGURED_CN_DOMAIN, for each signalling radio bearer other than RB2:

4> if the IE "Integrity protection mode command" has the value "start":

5> in the downlink, for this signalling radio bearer:

6> set the 20 most significant bits of IE "Downlink RRC HFN" in the variable INTEGRITY_PROTECTION_INFO of the downlink COUNT-I to the value START transmitted in the most recently transmitted IE "START list" or IE "START", at the reception of the SECURITY MODE COMMAND, that belongs to the CN domain as indicated in the variable LATEST_CONFIGURED_CN_DOMAIN;

6> set the remaining bits of the IE "Downlink RRC HFN" in the variable INTEGRITY_PROTECTION_INFO of the downlink COUNT-I to zero;

4> else:

5> in the downlink, for the first message for which the RRC sequence number in a received RRC message for this signalling radio bearer is equal to or greater than the activation time as indicated in IE "Downlink integrity protection activation info" as included in the IE "Integrity protection mode info", for this signalling radio bearer:

6> set the 20 most significant bits of the IE "Downlink RRC HFN" in the variable INTEGRITY_PROTECTION_INFO of the downlink COUNT-I to the value "START" in the most recently transmitted IE "START list" or IE "START", at the reception of the SECURITY MODE COMMAND, that belongs to the CN domain as indicated in the variable LATEST_CONFIGURED_CN_DOMAIN;

6> set the remaining bits of the IE "Downlink RRC HFN" to zero.

3> if new keys have been received:

4> perform the actions in subclause 8.1.12.3.1.

2> start applying the new integrity protection configuration in the uplink for signalling radio bearer RB2 from and including the transmitted SECURITY MODE COMPLETE message;

2> transmit the SECURITY MODE COMPLETE message on RB2;

2> if the SECURITY MODE COMMAND message contained the IE "Ciphering mode info":

3> prohibit the transmission of RRC messages on RB2.

NOTE: After submission of the SECURITY MODE COMPLETE message to the lower layers, the UE should accept messages received in the DL which require the new security configuration to be applied on them. If the received message is successfully integrity checked, the UE should not discard the message due to lack of completion of the security procedure, caused by the successful delivery of the SECURITY MODE COMPLETE not having yet been confirmed by lower layers, unless the security configuration to be applied has been aborted and the message received requires integrity protection [5].

1> when the successful delivery of the SECURITY MODE COMPLETE message has been confirmed by RLC:

2> if the SECURITY MODE COMMAND message contained the IE "Ciphering mode info":

3> if no new security key set (new ciphering and integrity protection keys) has been received from the upper layers [40] for the CN domain as indicated in the variable LATEST_CONFIGURED_CN_DOMAIN:

4> for ciphering on signalling radio bearers using RLC-AM and RLC-UM in the uplink, at the RLC sequence number indicated in IE "Radio bearer uplink ciphering activation time info" included in the SECURITY MODE COMPLETE, for each signalling radio bearer:

5> set the 20 most significant bits of the HFN component of the uplink COUNT-C to the value "START" in the most recently transmitted IE "START list" or IE "START", at the reception of the SECURITY MODE COMMAND, that belongs to the CN domain as indicated in the variable LATEST_CONFIGURED_CN_DOMAIN;

5> set the remaining bits of the hyper frame numbers to zero.

3> if new keys have been received:

4> perform the actions in subclause 8.1.12.3.1.

3> resume data transmission on any suspended radio bearer and signalling radio bearer mapped on RLC-AM or RLC-UM;

3> allow the transmission of RRC messages on RB2;

3> set the IE "Reconfiguration" in the variable CIPHERING_STATUS to FALSE; and

3> clear the variable RB_UPLINK_CIPHERING_ACTIVATION_TIME_INFO.

2> if the SECURITY MODE COMMAND message contained the IE "Integrity protection mode info":

3> if no new security key set (new ciphering and integrity protection keys) has been received from the upper layers [40] for the CN domain indicated in the variable LATEST_CONFIGURED_CN_DOMAIN, for each signalling radio bearer other than RB2:

4> if the IE "Integrity protection mode command" has the value "start":

5> in the uplink, for this signalling radio bearer:

6> set the 20 most significant bits of IE "Uplink RRC HFN" in the variable INTEGRITY_PROTECTION_INFO of the uplink COUNT-I to the value START transmitted in the most recently transmitted IE "START list" or IE "START", at the reception of the SECURITY MODE COMMAND, that belongs to the CN domain as indicated in the variable LATEST_CONFIGURED_CN_DOMAIN;

6> set the remaining bits of the IE "Uplink RRC HFN" in the variable INTEGRITY_PROTECTION_INFO of the uplink COUNT-I to zero.

4> else:

5> in the uplink, for the first transmitted RRC message for this signalling radio bearer with RRC sequence number equal to the activation time as indicated in IE "Uplink integrity protection activation info" included in the transmitted SECURITY MODE COMPLETE, for this signalling radio bearer:

6> set the 20 most significant bits of the IE "Uplink RRC HFN" in the variable INTEGRITY_PROTECTION_INFO of the uplink COUNT-I to the value "START" in the most recently transmitted IE "START list" or IE "START", at the reception of the SECURITY MODE COMMAND, that belongs to the CN domain as indicated in the variable LATEST_CONFIGURED_CN_DOMAIN;

6> set the remaining bits of the IE "Uplink RRC HFN" to zero.

3> if new keys have been received:

4> perform the actions in subclause 8.1.12.3.1.

3> allow the transmission of RRC messages on all signalling radio bearers with any RRC SN;

3> set "Uplink RRC Message sequence number" for signalling radio bearer RB0 in the variable INTEGRITY_PROTECTION_INFO to a value such that next RRC message to be sent on uplink RB0 will use the new integrity protection configuration and the "RRC Message sequence number" in the IE "Integrity check info" in the next RRC message will equal to the activation time for RB0 as indicated in IE "Uplink integrity protection activation info" included in the transmitted SECURITY MODE COMPLETE;

3> set the IE "Reconfiguration" in the variable INTEGRITY_PROTECTION_INFO to FALSE; and

3> clear the variable INTEGRITY_PROTECTION_ACTIVATION_INFO.

2> clear the variable SECURITY_MODIFICATION;

2> notify upper layers upon change of the security configuration;

2> and the procedure ends.

1> if the IE "Security capability" is not the same as indicated by the variable UE_CAPABILITY_TRANSFERRED, or the IE "GSM security capability" (if included in the SECURITY MODE COMMAND) is not the same as indicated by the variable UE_CAPABILITY_TRANSFERRED, or if the IE "GSM security capability" is not included in the SECURITY MODE COMMAND and is included in the variable UE_CAPABILITY_TRANSFERRED:

2> release all its radio resources;

2> indicate the release of the established signalling connections (as stored in the variable ESTABLISHED_SIGNALLING_CONNECTIONS) and established radio access bearers (as stored in the variable ESTABLISHED_RABS) to upper layers;

2> clear the variable ESTABLISHED_SIGNALLING_CONNECTIONS;

2> clear the variable ESTABLISHED_RABS;

2> clear the variable SECURITY_MODIFICATION;

2> enter idle mode;

2> perform actions when entering idle mode as specified in subclause 8.5.2;

2> and the procedure ends.

#### 8.1.12.3.1 New ciphering and integrity protection keys

NOTE: The actions in this subclause are to be performed only if the new keys were received for an ongoing RRC connection while in UTRA.

If a new security key set (new ciphering and integrity protection keys) has been received from the upper layers [40] for the CN domain as indicated in the variable LATEST_CONFIGURED_CN_DOMAIN, the UE shall:

1> set the START value for the CN domain indicated in the variable LATEST_CONFIGURED_CN_DOMAIN to zero;

1> if the SECURITY MODE COMMAND message contained the IE "Integrity protection mode info":

2> for integrity protection in the downlink on each signalling radio bearer except RB2:

3> if IE "Integrity protection mode command" has the value "start":

4> for the first received message on this signalling radio bearer:

5> start using the new integrity key;

5> for this signalling radio bearer:

6> set the IE "Downlink RRC HFN" in the variable INTEGRITY_PROTECTION_INFO of the downlink COUNT-I to zero.

3> else:

4> for the first message for which the RRC sequence number in a received RRC message for this signalling radio bearer is equal to or greater than the activation time as indicated in IE "Downlink integrity protection activation info" as included in the IE "Integrity protection mode info":

5> start using the new integrity key;

5> for this signalling radio bearer:

6> set the IE "Downlink RRC HFN" in the variable INTEGRITY_PROTECTION_INFO of the downlink COUNT-I to zero.

2> for integrity protection in the uplink on each signalling radio bearer except RB2:

3> for the first message for which the RRC sequence number in a to be transmitted RRC message for this signalling radio bearer is equal to the activation time as indicated in IE "Uplink integrity protection activation info" included in the transmitted SECURITY MODE COMPLETE message:

4> start using the new integrity key;

4> for this signalling radio bearer:

5> set the IE "Uplink RRC HFN" in the variable INTEGRITY_PROTECTION_INFO of the uplink COUNT-I to zero.

2> for integrity protection in the downlink on signalling radio bearer RB2:

3> at the received SECURITY MODECOMMAND:

4> start using the new integrity key;

4> set the IE "Downlink RRC HFN" in the variable INTEGRITY_PROTECTION_INFO of the downlink COUNT-I to zero.

2> for integrity protection in the uplink on signalling radio bearer RB2 :

3> at the transmitted SECURITY MODE COMPLETE:

4> start using the new integrity key;

4> set the IE "Uplink RRC HFN" in the variable INTEGRITY_PROTECTION_INFO of the uplink COUNT-I to zero.

1> if the SECURITY MODE COMMAND message contained the IE "Ciphering mode info":

2> for each signalling radio bearer and for each radio bearer for the CN domain indicated in the variable LATEST_CONFIGURED_CN_DOMAIN:

3> if the IE "Status" in the variable CIPHERING_STATUS has the value "Started" for this CN domain, then for ciphering on radio bearers using RLC-TM:

4> at the CFN as indicated in the IE "Ciphering activation time for DPCH" in the IE "Ciphering mode info":

5> start using the new key in uplink and downlink;

5> set the HFN component of the COUNT-C to zero.

3> if the IE "Status" in the variable CIPHERING_STATUS has the value "Started" for this CN domain, then for ciphering on radio bearers and signalling radio bearers using RLC-AM and RLC-UM:

4> in the downlink, at the RLC sequence number indicated in IE "Radio bearer downlink ciphering activation time info" in the IE "Ciphering mode info":

5> start using the new key;

5> set the HFN component of the downlink COUNT-C to zero.

4> in the uplink, at the RLC sequence number indicated in IE "Radio bearer uplink ciphering activation time info":

5> start using the new key;

5> set the HFN component of the uplink COUNT-C to zero.

1> consider the value of the latest transmitted START value to be zero.

### 8.1.12.4 Void

### 8.1.12.4a Incompatible simultaneous security reconfiguration

If the variable INCOMPATIBLE_SECURITY_RECONFIGURATION becomes set to TRUE of the received SECURITY MODE COMMAND message, the UE shall:

1> transmit a SECURITY MODE FAILURE message on the uplink DCCH using AM RLC, using the ciphering and integrity protection configurations prior to the reception of this SECURITY MODE COMMAND;

1> set the IE "RRC transaction identifier" in the SECURITY MODE FAILURE message to the value of "RRC transaction identifier" in the entry for the SECURITY MODE COMMAND message in the table "Accepted transactions" in the variable TRANSACTIONS; and

1> clear that entry;

1> set the IE "failure cause" to the cause value "incompatible simultaneous reconfiguration";

1> when the response message has been submitted to lower layers for transmission:

2> set the variable INCOMPATIBLE_SECURITY_RECONFIGURATION to FALSE;

2> continue with any ongoing processes and procedures as if the invalid SECURITY MODE COMMAND message has not been received;

2> only accept a message on SRB 2, with a COUNT-I that:

3> is higher than the COUNT-I used prior to receiving the SECURITY MODE COMMAND message incremented by one; and

3> does not take into account the HFN from the received SECURITY MODE COMMAND message.

2> and the procedure ends.

### 8.1.12.4b Cell update procedure during security reconfiguration

If:

- a cell update procedure according to subclause 8.3.1 is initiated; and
- the received SECURITY MODE COMMAND message causes either,
  - the IE "Reconfiguration" in the variable CIPHERING_STATUS to be set to TRUE; and/or
  - the IE "Reconfiguration" in the variable INTEGRITY_PROTECTION_INFO to be set to TRUE:

the UE shall:

1> abort the ongoing integrity and/or ciphering reconfiguration;

1> resume data transmission on any suspended radio bearer and signalling radio bearer mapped on RLC-AM or RLC-UM;

1> allow the transmission of RRC messages on all signalling radio bearers with any RRC SN;

1> when the CELL UPDATE message has been submitted to lower layers for transmission:

2> if the SECURITY MODE COMMAND message contained the IE "Ciphering mode info":

3> set the IE "Reconfiguration" in the variable CIPHERING_STATUS to FALSE; and

3> clear the variable RB_UPLINK_CIPHERING_ACTIVATION_TIME_INFO;

2> if the SECURITY MODE COMMAND message contained the IE "Integrity protection mode info":

3> set the IE "Reconfiguration" in the variable INTEGRITY_PROTECTION_INFO to FALSE; and

3> clear the variable INTEGRITY_PROTECTION_ACTIVATION_INFO.

2> continue with any ongoing processes and procedures as if the SECURITY MODE COMMAND message has not been received;

2> only accept a message on SRB 2, with a COUNT-I that:

3> is higher than the COUNT-I used prior to receiving the SECURITY MODE COMMAND message incremented by one; and

3> does not take into account the HFN from the received SECURITY MODE COMMAND message.

2> if the UE has already submitted the SECURITY MODE COMPLETE message, use a COUNT-I value for transmission of the next message on SRB2 as stated below:

3> take the COUNT-I used prior to the transmission of the SECURITY MODE COMPLETE message;

3> increment that COUNT-I with 2;

3> apply that COUNT-I on the next message to transmit.

2> clear the variable SECURITY_MODIFICATION;

2> the procedure ends.

### 8.1.12.4c Invalid configuration

If the variable INVALID_CONFIGURATION is set to TRUE due to the received SECURITY MODE COMMAND message, the UE shall:

1> transmit a SECURITY MODE FAILURE message on the DCCH using AM RLC after setting the IEs as specified below:

2> set the IE "RRC transaction identifier" in the SECURITY MODE FAILURE message to the value of "RRC transaction identifier" in the entry for the SECURITY MODE COMMAND message in the table "Accepted transactions" in the variable TRANSACTIONS; and

2> clear that entry;

2> set the IE "failure cause" to the cause value "invalid configuration".

1> when the response message has been submitted to lower layers for transmission:

2> set the variable INVALID_CONFIGURATION to FALSE;

2> set the IE "Reconfiguration" in the variable CIPHERING_STATUS to FALSE;

2> continue with any ongoing processes and procedures as if the invalid SECURITY MODE COMMAND message has not been received;

2> only accept a message on SRB 2, with a COUNT-I that:

3> is higher than the COUNT-I used prior to receiving the SECURITY MODE COMMAND message incremented by one; and

3> does not take into account the HFN from the received SECURITY MODE COMMAND message.

2> and the procedure ends.

### 8.1.12.5 Reception of SECURITY MODE COMPLETE message by the UTRAN

UTRAN should apply integrity protection on the received SECURITY MODE COMPLETE message and all subsequent messages with the new integrity protection configuration, if changed. When UTRAN has received a SECURITY MODE COMPLETE message and the integrity protection has successfully been applied, UTRAN should:

1> if the IE "Ciphering mode info" was included in the SECURITY MODE COMMAND message:

2> if new keys were received for the CN domain set in the IE "CN Domain Identity" in the SECURITY MODE COMMAND:

3> set, at the downlink and uplink activation time, all the bits of the hyper frame numbers of the downlink and uplink COUNT-C values respectively for all radio bearers for this CN domain and all signalling radio bearers to zero.

2> else (if new keys were not received):

3> use, at the downlink and uplink activation time, the value "START" in the most recently received IE "START list" or IE "START" that belongs to the CN domain as indicated in the IE "CN domain identity" to initialise all hyper frame numbers of the downlink and uplink COUNT-C values respectively for all the signalling radio bearers as follows:

4> set the 20 most significant bits of the hyper frame numbers of the COUNT-C for all signalling radio bearers to the value "START" in the most recently received IE "START list" or IE "START" for that CN domain;

4> set the remaining bits of the hyper frame numbers equal to zero.

1> if the IE "Integrity protection mode info" was included in the SECURITY MODE COMMAND message:

2> if this was not the first SECURITY MODE COMMAND message for this RRC connection:

3> if new keys have been received for the CN domain set in the IE "CN Domain Identity" included in the transmitted SECURITY MODE COMMAND message:

4> initialise, at the downlink and uplink activation time, all hyper frame numbers of the downlink and uplink COUNT-I values respectively for all the signalling radio bearers other than RB2 as follows:

5> set all bits of the hyper frame numbers of the uplink and downlink COUNT-I to zero.

3> if no new keys have been received for the CN domain set in the IE "CN Domain Identity" included in the transmitted SECURITY MODE COMMAND message:

4> use, at the downlink and uplink activation time, the value "START" in the most recently received IE "START list" or IE "START" that belongs to the CN domain as indicated in the IE "CN domain identity" to initialise all hyper frame numbers of the downlink and uplink COUNT-I values respectively for all the signalling radio bearers other than RB2 as follows:

5> set the 20 most significant bits of the hyper frame numbers of the downlink and uplink COUNT-I respectively for all signalling radio bearers to the value "START" in the most recently received IE "START list" or IE "START" for that CN domain;

5> set the remaining bits of the hyper frame numbers equal to zero.

1> send an indication to upper layers that the new security configuration has been activated;

1> resume, in the downlink, all suspended radio bearers and all signalling radio bearers;

1> allow the transmission of RRC messages on all signalling radio bearers with any RRC SN;

1> if the IE "Integrity protection mode command" included in the SECURITY MODE COMMAND had the value "Start":

2> start applying integrity protection in the downlink for all signalling radio bearers.

1> if the IE "Integrity protection mode command" included in the SECURITY MODE COMMAND had the value "Modify":

2> start applying the new integrity protection configuration in the downlink at the RRC sequence number, for each signalling radio bearers RBn, except for signalling radio bearer RB2, indicated by the entry for signalling radio bearer n in the "RRC message sequence number list" in the IE "Downlink integrity protection activation info";

2> continue applying the new integrity configuration for signalling radio bearer RB2;

2> apply the new integrity protection configuration on the received signalling messages with RRC SN greater than or equal to the number associated with the signalling radio bearer in IE "Uplink integrity protection activation info".

1> apply the old ciphering configuration for the transmission of RLC PDUs with RLC sequence number less than the number indicated in the IE "Radio bearer downlink ciphering activation time info" included in the IE "Ciphering mode info";

1> apply the new ciphering configuration for the transmission of RLC PDUs with RLC sequence number greater than or equal to the number indicated in IE "Radio bearer downlink ciphering activation time info" included in the IE "Ciphering mode info";

1> apply the old integrity protection configuration on the received signalling messages with RRC SN smaller than the number associated with the signalling radio bearer in IE "Uplink integrity protection activation info";

1> for radio bearers using RLC-AM or RLC-UM:

2> use the old ciphering configuration for received RLC PDUs with RLC sequence number less than the RLC sequence number indicated in the IE "Radio bearer uplink ciphering activation time info" sent by the UE;

2> use the new ciphering configuration for received RLC PDUs with RLC sequence number greater than or equal to the RLC sequence number indicated in the IE "Radio bearer uplink ciphering activation time info" sent by the UE;

2> if an RLC reset or re-establishment of the transmitting side of an RLC entity occurs after the SECURITY MODE COMPLETE message has been received by UTRAN before the downlink activation time for the new ciphering configuration has been reached, ignore the activation time and apply the new ciphering configuration in downlink immediately after the RLC reset or RLC re-establishment;

2> if an RLC reset or re-establishment of the receiving side of an RLC entity occurs after the SECURITY MODE COMPLETE message has been received by UTRAN before the uplink activation time for the new ciphering configuration has been reached, ignore the activation time and apply the new ciphering configuration in uplink immediately after the RLC reset or RLC re-establishment.

1> for radio bearers using RLC-TM:

2> use the old ciphering configuration for the received RLC PDUs before the CFN as indicated in the IE "Ciphering activation time for DPCH" in the IE "Ciphering mode info" as included in the SECURITY MODE COMMAND;

2> use the new ciphering configuration for the received RLC PDUs at the CFN as indicated in the IE "Ciphering activation time for DPCH" in the IE "Ciphering mode info" as included in the SECURITY MODE COMMAND.

1> and the procedure ends.

### 8.1.12.6 Invalid SECURITY MODE COMMAND message

If the SECURITY MODE COMMAND message contains a protocol error causing the variable PROTOCOL_ERROR_REJECT to be set to TRUE according to clause 9, the UE shall perform procedure specific error handling as follows:

1> transmit a SECURITY MODE FAILURE message on the uplink DCCH using AM RLC;

1> set the IE "RRC transaction identifier" in the SECURITY MODE FAILURE message to the value of "RRC transaction identifier" in the entry for the SECURITY MODE COMMAND message in the table "Rejected transactions" in the variable TRANSACTIONS; and

1> clear that entry;

1> set the IE "failure cause" to the cause value "protocol error";

1> include the IE "Protocol error information" with contents set to the value of the variable PROTOCOL_ERROR_INFORMATION;

1> when the response message has been submitted to lower layers for transmission:

2> continue with any ongoing processes and procedures as if the invalid SECURITY MODE COMMAND message has not been received;

2> only accept a message on SRB 2, with a COUNT-I that:

3> is higher than the COUNT-I used prior to receiving the SECURITY MODE COMMAND message incremented by one; and

3> does not take into account the HFN from the received SECURITY MODE COMMAND message.

2> and the procedure ends.

## 8.1.13 Signalling connection release procedure

**Figure 8.1.13-1: Signalling connection release procedure, normal case**

### 8.1.13.1 General

The signalling connection release procedure is used to notify to the UE that one of its ongoing signalling connections has been released. The procedure does not initiate the release of the RRC connection.

### 8.1.13.2 Initiation of SIGNALLING CONNECTION RELEASE by the UTRAN

To initiate the procedure, the UTRAN transmits a SIGNALLING CONNECTION RELEASE message on DCCH using AM RLC.

### 8.1.13.3 Reception of SIGNALLING CONNECTION RELEASE by the UE

Upon reception of a SIGNALLING CONNECTION RELEASE message, the UE shall:

1> indicate the release of the signalling connection and pass the value of the IE "CN domain identity" to upper layers;

1> remove the signalling connection with the identity indicated by the IE "CN domain identity" from the variable ESTABLISHED_SIGNALLING_CONNECTIONS;

1> clear the entry for the SIGNALLING CONNECTION RELEASE message in the table "Accepted transactions" in the variable TRANSACTIONS;

1> the procedure ends.

### 8.1.13.4 Invalid SIGNALLING CONNECTION RELEASE message

If the UE receives a SIGNALLING CONNECTION RELEASE message, which contains a protocol error causing the variable PROTOCOL_ERROR_REJECT to be set to TRUE according to clause 9, the UE shall perform procedure specific error handling as follows:

1> include the IE "Identification of received message"; and

2> set the IE "Received message type" to SIGNALLING CONNECTION RELEASE;

2> set the IE "RRC transaction identifier" to the value of "RRC transaction identifier" in the entry for the SIGNALLING CONNECTION RELEASE message in the table "Rejected transactions" in the variable TRANSACTIONS; and

2> clear that entry.

1> include the IE "Protocol error information" with contents set to the value of the variable PROTOCOL_ERROR_INFORMATION;

1> transmit an RRC STATUS message on the uplink DCCH using AM RLC

1> when the RRC STATUS message has been submitted to lower layers for transmission:

2> continue with any ongoing processes and procedures as if the invalid SIGNALLING CONNECTION RELEASE message has not been received.

### 8.1.13.5 Invalid configuration

If radio access bearers for the CN domain indicated by the IE "CN domain identity" exist in the variable ESTABLISHED_RABS, the UE shall:

1> transmit an RRC STATUS message on the uplink DCCH using AM RLC;

1> include the IE "Identification of received message"; and

1> set the IE "Received message type" to SIGNALLING CONNECTION RELEASE; and

1> set the IE "RRC transaction identifier" to the value of "RRC transaction identifier" in the entry for the SIGNALLING CONNECTION RELEASE message in the table "Accepted transactions" in the variable TRANSACTIONS and clear that entry;

1> include the IE "Protocol error information" with contents set to the value "Message not compatible with receiver state";

1> when the RRC STATUS message has been submitted to lower layers for transmission:

2> continue with any ongoing processes and procedures as if the invalid SIGNALLING CONNECTION RELEASE message has not been received.

## 8.1.14 Signalling connection release indication procedure

**Figure 8.1.14-1: Signalling connection release indication procedure, normal case**

### 8.1.14.1 General

The signalling connection release indication procedure is used by the UE to indicate to the UTRAN that one of its signalling connections has been released. The procedure may in turn initiate the RRC connection release procedure.

### 8.1.14.2 Initiation

The UE shall, on receiving a request to release (abort) the signalling connection from upper layers for a specific CN domain:

1> if a signalling connection in the variable ESTABLISHED_SIGNALLING_CONNECTIONS for the specific CN domain identified with the IE "CN domain identity" exists:

2> initiate the signalling connection release indication procedure.

1> otherwise:

2> abort any ongoing establishment of signalling connection for that specific CN domain as specified in 8.1.3.5a.

Upon initiation of the signalling connection release indication procedure in CELL_PCH or URA_PCH state, the UE shall:

1> perform a cell update procedure, according to subclause 8.3.1, using the cause "uplink data transmission";

1> when the cell update procedure completed successfully:

2> continue with the signalling connection release indication procedure as below.

The UE shall:

1> set the IE "CN Domain Identity" to the value indicated by the upper layers. The value of the IE indicates the CN domain whose associated signalling connection the upper layers are indicating to be released;

1> remove the signalling connection with the identity indicated by upper layers from the variable ESTABLISHED_SIGNALLING_CONNECTIONS;

1> transmit a SIGNALLING CONNECTION RELEASE INDICATION message on DCCH using AM RLC.

When the successful delivery of the SIGNALLING CONNECTION RELEASE INDICATION message has been confirmed by RLC the procedure ends.

#### 8.1.14.2a RLC re-establishment or inter-RAT change

If a re-establishment of the transmitting side of the RLC entity on signalling radio bearer RB2 occurs before the successful delivery of the SIGNALLING CONNECTION RELEASE INDICATION message has been confirmed by RLC, the UE shall:

1> retransmit the SIGNALLING CONNECTION RELEASE INDICATION message on the uplink DCCH using AM RLC on signalling radio bearer RB2.

If an Inter-RAT handover from UTRAN procedure occurs before the successful delivery of the SIGNALLING CONNECTION RELEASE INDICATION message has been confirmed by RLC, the UE shall:

1> abort the signalling connection while in the new RAT.

#### 8.1.14.3 Reception of SIGNALLING CONNECTION RELEASE INDICATION by the UTRAN

Upon reception of a SIGNALLING CONNECTION RELEASE INDICATION message, the UTRAN requests the release of the signalling connection from upper layers. Upper layers may then initiate the release of the signalling connection.

### 8.1.15 Counter check procedure




**Figure 8.1.15-1: Counter check procedure**

#### 8.1.15.1 General

The counter check procedure is used by the UTRAN to perform a local authentication. The purpose of the procedure is to check that the amount of data sent in both directions (uplink and downlink) over the duration of the RRC connection is identical at the UTRAN and at the UE (to detect a possible intruder – a 'man-in-the-middle' – from operating).

This procedure is only applicable to radio bearers, and only to radio bearers using RLC-AM or RLC-UM. It should be noted that this requires that the COUNT-C values for each UL and DL radio bearers using RLC-AM or RLC-UM continue to be incremented even if ciphering is not used. This procedure is not applicable to signalling radio bearers.

### 8.1.15.2 Initiation

The UTRAN monitors the COUNT-C value associated with each radio bearer using UM or AM RLC. The procedure is triggered whenever any of these values reaches a critical checking value. The granularity of these checking values and the values themselves are defined to the UTRAN by the visited network. The UTRAN initiates the procedure by sending a COUNTER CHECK message on the downlink DCCH.

### 8.1.15.3 Reception of a COUNTER CHECK message by the UE

When the UE receives a COUNTER CHECK message it shall compare the COUNT-C MSB values received in the IE "RB COUNT-C MSB information" in the COUNTER CHECK message to the COUNT-C MSB values of the corresponding radio bearers.

The UE shall:

1> set the IE "RRC transaction identifier" in the COUNTER CHECK RESPONSE message to the value of "RRC transaction identifier" in the entry for the COUNTER CHECK message in the table "Accepted transactions" in the variable TRANSACTIONS; and

1> clear that entry.

If:

- there is one or more radio bearer(s) using UM or AM RLC mode stored in the variable ESTABLISHED_RABS, which is (are) not included in the IE "RB COUNT-C MSB information"; or
- there is one or more radio bearer(s) included in the IE "RB COUNT-C MSB information", which is (are) not stored in the variable ESTABLISHED_RABS; or
- for any radio bearer (excluding signalling radio bearers) using UM or AM RLC mode stored in the variable ESTABLISHED_RABS and included in the IE "RB COUNT-C MSB information" with COUNT-C MSB values different from the MSB part of the COUNT-C values in the UE:

the UE shall:

1> include these radio bearers in the IE "RB COUNT-C information" in the COUNTER CHECK RESPONSE message. For any RB which is included in the IE "RB COUNT-C MSB information" in the COUNTER CHECK message but not stored in the variable ESTABLISHED_RABS in the UE, the MSB part of COUNT-C values in the COUNTER CHECK RESPONSE message shall be set identical to COUNT-C-MSB values in the COUNTER CHECK message. The LSB part shall be filled with zeroes.

The UE shall:

1> if no COUNT-C exists for a radio bearer for a given direction (uplink or downlink) because:

2> it is a uni-directional radio bearer configured only for the other direction (downlink or uplink respectively); or

2> it has been configured to RLC-TM mode in one direction (uplink or downlink) and RLC-UM in the other (downlink or uplink respectively):

3> set the COUNT-C in the IE "RB COUNT-C information" in the COUNTER CHECK RESPONSE message, to any value.

1> submit a COUNTER CHECK RESPONSE message to lower layers for transmission on the uplink DCCH using AM RLC.

When the COUNTER CHECK RESPONSE message has been submitted to lower layers for transmission the procedure ends.

### 8.1.15.4 Reception of the COUNTER CHECK RESPONSE message by UTRAN

If the UTRAN receives a COUNTER CHECK RESPONSE message that does not contain any COUNT-C values, the procedure ends.

If the UTRAN receives a COUNTER CHECK RESPONSE message that contains one or several COUNT-C values the UTRAN may release the RRC connection.

### 8.1.15.5 Cell re-selection

If the UE performs cell re-selection anytime during this procedure it shall, without interrupting the procedure:

1> initiate the cell update procedure according to subclause 8.3.1.

### 8.1.15.6 Invalid COUNTER CHECK message

If the UE receives a COUNTER CHECK message, which contains a protocol error causing the variable PROTOCOL_ERROR_REJECT to be set to TRUE according to clause 9, the UE shall perform procedure specific error handling as follows. The UE shall:

1> transmit an RRC STATUS message on the uplink DCCH using AM RLC;

1> include the IE "Identification of received message"; and

1> set the IE "Received message type" to COUNTER CHECK; and

1> set the IE "RRC transaction identifier" to the value of "RRC transaction identifier" in the entry for the UE COUNTER CHECK message in the table "Rejected transactions" in the variable TRANSACTIONS; and

1> clear that entry;

1> include the IE "Protocol error information" with contents set to the value of the variable PROTOCOL_ERROR_INFORMATION;

1> when the RRC STATUS message has been submitted to lower layers for transmission:

2> continue with any ongoing processes and procedures as if the invalid COUNTER CHECK message has not been received.

## 8.1.16 Inter RAT handover information transfer

**Figure 8.1.16-1: Inter RAT handover information transfer, normal flow**

### 8.1.16.1 General

The inter RAT handover information transfer procedure is used by the UE to convey RRC information needed for inter RAT handover to UTRAN.

### 8.1.16.2 Initiation

If:

- a radio access technology other than UTRA, e.g. GSM, using radio access technology-specific procedures, orders the UE to provide the INTER RAT HANDOVER INFO message; or

- a radio access technology other than UTRA, e.g. GSM, using radio access technology-specific procedures, configures the UE to send the INTER RAT HANDOVER INFO message upon system specific conditions not involving an explicit order e.g. early classmark sending upon entering connected mode; or

- while in connected mode using another radio access technology, the inter RAT handover info changes compared to what has previously been sent via the other radio access technology:

the UE shall:

1> initiate the inter RAT handover information transfer procedure.

To determine if the inter RAT handover info has changed compared to what has previously been sent, the UE shall:

1> store the information last sent in the variable INTER_RAT_HANDOVER_INFO_TRANSFERRED;

1> if this variable has not yet been set:

2> not initiate the inter RAT handover information transfer procedure due to change of inter RAT handover info.

NOTE: Currently neither the UE security information nor the predefined configuration status information change while in connected mode using GSM radio access technology.

### 8.1.16.3 INTER RAT HANDOVER INFO message contents to set

The UE shall:

1> include the IE "UE security information", and the IE "UE security information2" if supported by the UE; and

1> not include the IE "UE Specific Behaviour Information 1 interRAT".

1> in case support for the compressed version of the inter RAT handover info is indicated via the other radio access technology:

2> include of the following IEs the IE that after encoding has the smallest size: IE "Predefined configuration status information compressed" or the IE "Predefined configuration status information";

2> include the IE "UE radio access capability compressed".

1> else:

2> include the IE "Predefined configuration status information";

2> include the IE "UE capability container", containing the IE "UE radio access capability" and the IE "UE radio access capability extension", in accordance with the following:

3> if the UE supports multiple UTRA FDD Frequency Bands; or

3> if the UE supports a single UTRA FDD Frequency Band different from Band I [21]:

4> include the IE "UE radio access capability", excluding IEs "RF capability FDD" and "Measurement capability";

4> include the IE "UE radio access capability extension", including the IEs "RF capability FDD extension" and the "Measurement capability extension" associated with each supported UTRA FDD frequency band indicated in the IE "Frequency band".

3> else:

4> include the IE "UE radio access capability", including the IEs "RF capability FDD" and "Measurement capability" associated with the Band I [21];

4> include the IE "UE radio access capability extension", including the IEs "RF capability FDD extension" and the "Measurement capability extension" associated with each supported UTRA FDD frequency band indicated in the IE "Frequency band".

1> include the IE "UE radio access capability comp 2";

1> initiate the transfer of the INTER RAT HANDOVER INFO message via the other radio access technology, using radio access technology-specific procedures;

1> store the following in the variable INTER_RAT_HANDOVER_INFO_TRANSFERRED if they were included in the INTER RAT HANDOVER INFO message:

2> the IE "Predefined configuration status information";

2> the IE "Predefined configuration status information compressed";

2> the IE "UE security information";

2> the IE "UE radio access capability";

2> the IE "UE radio access capability extension"; and

2> the IE "UE radio access capability compressed";

2> if the IE "UE radio access capability compressed" were included in the INTER RAT HANDOVER INFO message:

3> set the IE "Security Capability" to the mandatory R99 algorithms.

1> and the procedure ends.

# 8.2 Radio Bearer control procedures

## 8.2.1 Radio bearer establishment

See subclause 8.2.2 Reconfiguration procedures.

## 8.2.2 Reconfiguration procedures




**Figure 8.2.2-1: Radio Bearer Establishment, normal case**




**Figure 8.2.2-2: Radio Bearer Establishment, failure case**




**Figure 8.2.2-3: Radio bearer reconfiguration, normal flow**




**Figure 8.2.2-4: Radio bearer reconfiguration, failure case**




**Figure 8.2.2-5: Radio Bearer Release, normal case**




**Figure 8.2.2-6: Radio Bearer Release, failure case**




**Figure 8.2.2-7: Transport channel reconfiguration, normal flow**




**Figure 8.2.2-8: Transport channel reconfiguration, failure case**




**Figure 8.2.2-9: Physical channel reconfiguration, normal flow**




**Figure 8.2.2-10: Physical channel reconfiguration, failure case**

### 8.2.2.1 General

Reconfiguration procedures include the following procedures:

- the radio bearer establishment procedure;
- radio bearer reconfiguration procedure;

- the radio bearer release procedure;
- the transport channel reconfiguration procedure; and
- the physical channel reconfiguration procedure.

The radio bearer establishment procedure is used to establish new radio bearer(s).

The radio bearer reconfiguration procedure is used to reconfigure parameters for a radio bearer.

The radio bearer release procedure is used to release radio bearer(s).

The transport channel reconfiguration procedure is used to reconfigure transport channel parameters.

The physical channel reconfiguration procedure is used to establish, reconfigure and release physical channels.

While performing any of the above procedures, these procedures may perform a hard handover (subclause 8.3.5) and/or an HS-DSCH cell change and/or a serving E-DCH cell change. The reconfiguration procedures are also used to change the feedback configuration for HS-DSCH.

#### 8.2.2.2 Initiation

To initiate any one of the reconfiguration procedures, UTRAN should:

1> configure new radio links in any new physical channel configuration;

1> start transmission and reception on the new radio links;

1> for a radio bearer establishment procedure:

2> transmit a RADIO BEARER SETUP message on the downlink DCCH using AM or UM RLC;

2> if signalling radio bearer RB4 is setup with this procedure and signalling radio bearers RB1-RB3 were already established prior to the procedure:

3> if the variable "LATEST_CONFIGURED_CN_DOMAIN" has been initialised:

4> connect any radio bearers setup by the same message as signalling radio bearer RB4 to the CN domain indicated in the variable "LATEST CONFIGURED CN DOMAIN".

1> for a radio bearer reconfiguration procedure:

2> transmit a RADIO BEARER RECONFIGURATION message on the downlink DCCH using AM or UM RLC.

1> for a radio bearer release procedure:

2> transmit a RADIO BEARER RELEASE message on the downlink DCCH using AM or UM RLC.

1> for a transport channel reconfiguration procedure:

2> transmit a TRANSPORT CHANNEL RECONFIGURATION message on the downlink DCCH using AM or UM RLC.

1> for a physical channel reconfiguration procedure:

2> transmit a PHYSICAL CHANNEL RECONFIGURATION message on the downlink DCCH using AM or UM RLC.

1> if the reconfiguration procedure is simultaneous with SRNS relocation procedure:

2> if the transmitted message is a RADIO BEARER RECONFIGURATION:

3> include the IE "New U-RNTI".

2> else:

3> include the IE "Downlink counter synchronisation info".

2> if ciphering and/or integrity protection are activated:

3> include new ciphering and/or integrity protection configuration information to be used after reconfiguration.

2> use the downlink DCCH using AM RLC.

1> if transport channels are added, reconfigured or deleted in uplink and/or downlink:

2> set TFCS according to the new transport channel(s).

1> if transport channels are added or deleted in uplink and/or downlink, and RB Mapping Info applicable to the new configuration has not been previously provided to the UE, the UTRAN should:

2> send the RB Mapping Info for the new configuration.

In the Radio Bearer Reconfiguration procedure UTRAN may indicate that uplink transmission shall be stopped or continued on certain radio bearers. Uplink transmission on a signalling radio bearer used by the RRC signalling (signalling radio bearer RB1 or signalling radio bearer RB2) should not be stopped.

NOTE 1: The Release '99 RADIO BEARER RECONFIGURATION message always includes the IE "RB information to reconfigure", even if UTRAN does not require the reconfiguration of any RB. In these cases, UTRAN may include only the IE "RB identity" within the IE "RB information to reconfigure".

NOTE 2: The Release '99 RADIO BEARER RECONFIGURATION message always includes the IE "Downlink information per radio link list", even if UTRAN does not require the reconfiguration of any RL. In these cases, UTRAN may re-send the currently assigned values for the mandatory IEs included within the IE "Downlink information per radio link list ".

NOTE 3: The Release '99 RADIO BEARER RECONFIGURATION message always includes the IE "Primary CPICH Info" (FDD) or IE "Primary CCPCH Info" (TDD) within IE "Downlink information per radio link list". This implies that in case UTRAN applies the RADIO BEARER RECONFIGURATION message to move the UE to CELL_FACH state, it has to indicate a cell. However, UTRAN may indicate any cell; the UE anyhow performs cell selection and notifies UTRAN if it selects another cell than indicated by UTRAN.

If the IE "Activation Time" is included, UTRAN should set it to a value taking the UE performance requirements into account.

UTRAN should take the UE capabilities into account when setting the new configuration.

If the message is used to initiate a transition from CELL_DCH to CELL_FACH state, the UTRAN may assign a C-RNTI to be used in that cell by the UE.

### 8.2.2.2a Initiation of handover from GERAN *Iu mode*

To initiate the handover from GERAN *Iu mode,* UTRAN should:

1> provide a RADIO BEARER RECONFIGURATION message to be encapsulated in INTERSYSTEM HANDOVER TO UTRAN COMMAND message, sent on the downlink SRB2 in GERAN *Iu mode*, as specified in [53].

1> in case UTRAN decides to use a predefined or default radio configuration that is stored in the UE, it should include the following information in the RADIO BEARER RECONFIGURATION message:

- PhyCH information elements; and
- either:
  - the IE "Predefined configuration identity", to indicate which pre-defined configuration of RB, transport channel and physical channel parameters shall be used; or
  - the IE "Default configuration mode" and IE "Default configuration identity", to indicate which default configuration of RB, transport channel and physical channel parameters shall be used.

### 8.2.2.3 Reception of RADIO BEARER SETUP or RADIO BEARER RECONFIGURATION or RADIO BEARER RELEASE or TRANSPORT CHANNEL RECONFIGURATION or PHYSICAL CHANNEL RECONFIGURATION message by the UE

The UE shall:

1> be able to receive any of the following messages:

2> RADIO BEARER SETUP message; or

2> RADIO BEARER RECONFIGURATION message; or

2> RADIO BEARER RELEASE message; or

2> TRANSPORT CHANNEL RECONFIGURATION message; or

2> PHYSICAL CHANNEL RECONFIGURATION message;

1> be able to perform a hard handover and apply physical layer synchronisation procedure A as specified in [29], even if no prior UE measurements have been performed on the target cell and/or frequency.

In case the reconfiguration procedure is used to remove all existing RL(s) in the active set while new RL(s) are established the UE shall:

1> if the UE has a pending "TGPS reconfiguration CFN" at the activation time received in the reconfiguration message and the reconfiguration requests a timing re-initialised hard handover (see subclause 8.3.5.1), the UE may:

2> abort the pending CM activation;

2> set the CM_PATTERN_ACTIVATION_ABORTED to TRUE.

1> otherwise:

2> set the CM_PATTERN_ACTIVATION_ABORTED to FALSE.

If the UE receives:

- a RADIO BEARER SETUP message; or
- a RADIO BEARER RECONFIGURATION message; or
- a RADIO BEARER RELEASE message; or
- a TRANSPORT CHANNEL RECONFIGURATION message; or
- a PHYSICAL CHANNEL RECONFIGURATION message:

it shall:

1> set the variable ORDERED_RECONFIGURATION to TRUE;

1> if the UE will enter the CELL_DCH state from any state other than CELL_DCH state at the conclusion of this procedure:

2> perform the physical layer synchronisation procedure A as specified in [29] (FDD only).

1> act upon all received information elements as specified in subclause 8.6, unless specified in the following and perform the actions below.

The UE may:

1> maintain a list of the set of cells to which the UE has Radio Links if the IE "Cell ID" is present.

The UE may first release the physical channel configuration used at reception of the reconfiguration message. The UE shall then:

1> enter a state according to subclause 8.6.3.3.

In case the UE receives a RADIO BEARER RECONFIGURATION message including the IE "RB information to reconfigure" that only includes the IE "RB identity", the UE shall:

1> handle the message as if IE "RB information to reconfigure" was absent.

NOTE: The ASN.1 "r3" version of the RADIO BEARER RECONFIGURATION message always includes the IE "RB information to reconfigure". UTRAN has to include it even if it does not require the reconfiguration of any RB.

In case the UE receives a RADIO BEARER RECONFIGURATION message with the IE "Specification mode" set to "Preconfiguration" while the message is not sent through GERAN *Iu mode,* the UE behaviour is unspecified.

In case the UE receives a RADIO BEARER SETUP message with the IE "Specification mode" set to "Preconfiguration" while the message is sent through GERAN *Iu mode,* the UE behaviour is unspecified.

In case the UE receives a RADIO BEARER SETUP message with the IE "Specification mode" set to "Preconfiguration" while the message is not sent through GERAN *Iu mode,* the UE shall:

1> perform the actions related to the IE 'RB information to change list' as specified in subclause 8.6.4.4;

1> for radio bearers included in the default configuration identified by the IE "Default configuration mode" and the IE "Default configuration identity" which value is not included in an IE 'IE 'Re-map to default RB' within the IE "RB information to change list":

2> establish the radio bearer and transport channel configuration in accordance with the default parameters identified by the IE "Default configuration mode" and the IE "Default configuration identity";

2> if no physical channel information elements are included in the message:

3> initiate the physical channels in accordance with the default parameters identified by the IE "Default configuration mode".

2> otherwise:

3> initiate the physical channels in accordance with the received physical channel information elements;

1> construct the Transport format combination set, including all possible combinations of the following, in order of increasing CTFC value:

2> the transport format combinations of the transport channels included in the default configuration as specified for the corresponding default configuration; and

2> the transport format combinations of the other remaining transport channels as specified by the transport format combination set used upon receiving the message.

1> apply the signalled gain factor information for the TFC indicated by the IE "Reference TFC" and compute the gain factor for all other TFCs using this reference, in accordance with in [29];

1> act upon all received information elements, including the ones identified by the the IE "Default configuration mode" and IE "Default configuration identity", as specified in subclause 8.6, unless specified in the following and perform the actions below.

NOTE 2: The IE "Default configuration mode" specifies whether the FDD or TDD version of the default configuration shall be used.

If after state transition the UE enters CELL_DCH state, the UE shall, after the state transition:

1> in FDD; or

1> in TDD when "Primary CCPCH Info" is included indicating a new target cell and "New C-RNTI" is not specified:

2> remove any C-RNTI from MAC;

2> clear the variable C_RNTI.

If after state transition the UE leaves CELL_DCH state, the UE shall, after the state transition:

1> if any IEs releated to HS-DSCH are stored in the UE:

2> clear any stored IE "Downlink HS-PDSCH information";

2> determine the value for the HS_DSCH_RECEPTION variable and take the corresponding actions as described in subclause 8.5.25.

1> if any IEs related to E-DCH are stored in the UE:

2> clear any stored IE "E-DCH info";

2> determine the value for the E_DCH_TRANSMISSION variable and take the corresponding actions as described in subclause 8.5.28.

If the UE was in CELL_DCH state upon reception of the reconfiguration message and remains in CELL_DCH state, the UE shall:

1> if the IE "Uplink DPCH Info" is absent, not change its current UL Physical channel configuration;

1> in TDD:

2> if "Primary CCPCH Info" is included indicating a new target cell and "New C-RNTI" is not specified:

3> remove any C-RNTI from MAC;

3> clear the variable C_RNTI.

2> if "Primary CCPCH Info" is included indicating a new target cell and "New H-RNTI" is not specified:

3> remove any H-RNTI from MAC;

3> clear the variable H_RNTI;

3> determine the value for the HS_DSCH_RECEPTION variable and take the corresponding actions as described in subclause 8.5.25.

1> if "DPCH frame offset" is included for one or more RLs in the active set, and the reconfiguration procedure does not request a timing reinitialized hard handover (see subclause 8.3.5.1):

2> use its value to determine the beginning of the DPCH or F-DPCH frame in accordance with the following:

3> if the received IE "DPCH frame offset" is across the value range border compared to the DPCH or F-DPCH frame offset currently used by the UE:

4> consider it to be a request to adjust the timing with 256 chips across the frame border (e.g. if the UE receives value 0 while the value currently used is 38144 consider this as a request to adjust the timing with +256 chips).

3> if after taking into account value range borders, the received IE "DPCH frame offset" corresponds to a request to adjust the timing with a step exceeding 256 chips:

4> set the variable INVALID_CONFIGURATION to TRUE.

3> and the procedure ends.

2> adjust the radio link timing accordingly.

If after state transition the UE enters CELL_FACH state, the UE shall, after the state transition:

1> if the IE "Frequency info" is included in the received reconfiguration message:

2> select a suitable UTRA cell according to [4] on that frequency;

2> if the UE finds a suitable UTRA cell on that frequency:

3> if the received reconfiguration message included the IE "Primary CPICH info" (for FDD) or "Primary CCPCH info" (for TDD), and the UE selects another cell than indicated by this IE or the received reconfiguration message did not include the IE "Primary CPICH info" (for FDD) or "Primary CCPCH info" (for TDD):

4> initiate a cell update procedure according to subclause 8.3.1 using the cause "Cell reselection";

4> when the cell update procedure completed successfully:

5> if the UE is in CELL_PCH or URA_PCH state, initiate a cell update procedure according to subclause 8.3.1 using the cause "Uplink data transmission" and proceed as below.

2> else, if the UE can not find a suitable UTRA cell on that frequency but it finds a suitable UTRA cell on another frequency:

3> initiate a cell update procedure according to subclause 8.3.1 using the cause "Cell reselection";

3> when the cell update procedure completed successfully:

4> if the UE is in CELL_PCH or URA_PCH state, initiate a cell update procedure according to subclause 8.3.1 using the cause "Uplink data transmission" and proceed as below.

1> if the IE "Frequency info" is not included in the received reconfiguration message:

2> select a suitable UTRA cell according to [4];

2> if the UE finds a suitable UTRA cell on the current frequency:

3> if the received reconfiguration message included the IE "Primary CPICH info" (for FDD) or "Primary CCPCH info" (for TDD), and the UE selects another cell than indicated by this IE or the received reconfiguration message did not include the IE "Primary CPICH info" (for FDD) or "Primary CCPCH info" (for TDD):

4> initiate a cell update procedure according to subclause 8.3.1 using the cause "Cell reselection";

4> when the cell update procedure completed successfully:

5> if the UE is in CELL_PCH or URA_PCH state, initiate a cell update procedure according to subclause 8.3.1 using the cause "Uplink data transmission" and proceed as below.

2> else, if the UE can not find a suitable UTRA cell on the current frequency but it finds a suitable UTRA cell on another frequency:

3> initiate a cell update procedure according to subclause 8.3.1 using the cause "Cell reselection";

3> when the cell update procedure completed successfully:

4> if the UE is in CELL_PCH or URA_PCH state, initiate a cell update procedure according to subclause 8.3.1 using the cause "Uplink data transmission" and proceed as below.

1> start timer T305 using its initial value if timer T305 is not running and if periodical update has been configured by T305 in the IE "UE Timers and constants in connected mode" set to any other value than "infinity" in the variable TIMERS_AND_CONSTANTS;

1> select PRACH according to subclause 8.5.17;

1> select Secondary CCPCH according to subclause 8.5.19;

1> use the transport format set given in system information;

1> if the IE "UTRAN DRX cycle length coefficient" is included in the same message:

2> ignore that IE and stop using DRX.

1> if the contents of the variable C_RNTI is empty:

2> perform a cell update procedure according to subclause 8.3.1 using the cause "Cell reselection";

2> when the cell update procedure completed successfully:

3> if the UE is in CELL_PCH or URA_PCH state:

4> initiate a cell update procedure according to subclause 8.3.1 using the cause "Uplink data transmission";

4> proceed as below.

If the UE was in CELL_FACH state upon reception of the reconfiguration message and remains in CELL_FACH state, the UE shall:

1> if the IE "Frequency info" is included in the received reconfiguration message:

2> select a suitable UTRA cell according to [4] on that frequency;

2> if the UE finds a suitable UTRA cell on that frequency:

3> if the received reconfiguration message included the IE "Primary CPICH info" (for FDD) or "Primary CCPCH info" (for TDD), and the UE selected another cell than indicated by this IE or the received reconfiguration message did not include the IE "Primary CPICH info" (for FDD) or "Primary CCPCH info" (for TDD):

4> initiate a cell update procedure according to subclause 8.3.1 using the cause "cell reselection";

4> when the cell update procedure completed successfully:

5> if the UE is in CELL_PCH or URA_PCH state, initiate a cell update procedure according to subclause 8.3.1 using the cause "Uplink data transmission" and proceed as below.

2> else, if the UE can not find a suitable UTRA cell on that frequency but it finds a suitable UTRA cell on another frequency:

3> initiate a cell update procedure according to subclause 8.3.1 using the cause "Cell reselection";

3> when the cell update procedure completed successfully:

4> if the UE is in CELL_PCH or URA_PCH state, initiate a cell update procedure according to subclause 8.3.1 using the cause "Uplink data transmission" and proceed as below.

1> if the IE "Frequency info" is not included in the received reconfiguration message:

2> if the IE "Primary CPICH info" (for FDD) or "Primary CCPCH info" (for TDD) is included the UE shall either:

3> ignore the content of the IE "Primary CPICH info" (for FDD) or "Primary CCPCH info" (for TDD) and proceed as below;

2> or:

3> if the received reconfiguration message included the IE "Primary CPICH info" (for FDD) or "Primary CPCH info" (for TDD), and it is different from the current cell:

4> initiate a cell update procedure according to subclause 8.3.1 using the cause "Cell reselection";

4> when the cell update procedure completed successfully:

5> if the UE is in CELL_PCH or URA_PCH state, initiate a cell update procedure according to subclause 8.3.1 using the cause "Uplink data transmission" and proceed as below.

If after state transition the UE leaves CELL_FACH state, the UE shall:

1> stop timer T305.

If after state transition the UE enters CELL_PCH or URA_PCH state, the UE shall:

1> if the IE "UTRAN DRX cycle length coefficient" is not included in the same message:

2> set the variable INVALID_CONFIGURATION to TRUE.

The UE shall transmit a response message as specified in subclause 8.2.2.4, setting the information elements as specified below. The UE shall:

1> if the received reconfiguration message included the IE "Downlink counter synchronisation info"; or

1> if the received reconfiguration message is a RADIO BEARER RECONFIGURATION and the IE "New U-RNTI" is included:

2> if the variable PDCP_SN_INFO is empty:

3> configure the corresponding RLC entity for all AM and UM radio bearers and AM and UM signalling radio bearers except RB2 to "stop".

2> else:

3> configure the RLC entity for signalling radio bearers RB1, RB3 and RB4 to "stop";

3> configure the RLC entity for UM and AM radio bearers for which the IE "PDCP SN Info" is not included to "stop".

2> re-establish the RLC entity for RB2;

2> for the downlink and the uplink, apply the ciphering configuration as follows:

3> if the received re-configuation message included the IE "Ciphering Mode Info":

4> use the ciphering configuration in the received message when transmitting the response message.

3> if the ciphering configuration for RB2 from a previously received SECURITY MODE COMMAND has not yet been applied because the activation times not having been reached:

4> if the previous SECURITY MODE COMMAND was received due to new keys being received:

5> consider the new ciphering configuration to include the received new keys;

5> initialise the HFN component of the uplink COUNT-C and downlink COUNT-C of SRB2 as indicated in subclause 8.1.12.3.1.

4> if the ciphering configuration for RB2 from a previously received SECURITY MODE COMMAND has not yet been applied because of the corresponding activation times not having been reached and the previous SECURITY MODE COMMAND caused a change in LATEST_CONFIGURED_CN_DOMAIN:

5> consider the new ciphering configuration to include the keys associated with the LATEST_CONFIGURED_CN_DOMAIN;

5> initialise the HFN component of the uplink COUNT-C and downlink COUNT-C of SRB2 to the most recently transmitted IE "START list" or IE "START" for the LATEST_CONFIGURED_CN_DOMAIN at the reception of the previous SECURITY MODE COMMAND.

4> apply the new ciphering configuration immediately following RLC re-establishment.

3> else:

4> continue using the current ciphering configuration.

2> set the new uplink and downlink HFN component of COUNT-C of RB2 to MAX(uplink HFN component of COUNT-C of RB2, downlink HFN component of COUNT-C of RB2);

2> increment by one the downlink and uplink values of the HFN of COUNT-C for RB2;

2> calculate the START value according to subclause 8.5.9;

2> include the calculated START values for each CN domain in the IE "START list" in the IE "Uplink counter synchronisation info".

1> if the received reconfiguration message did not include the IE "Downlink counter synchronisation info":

2> if the variable START_VALUE_TO_TRANSMIT is set:

3> include and set the IE "START" to the value of that variable.

2> if the variable START_VALUE_TO_TRANSMIT is not set and the IE "New U-RNTI" is included:

3> calculate the START value according to subclause 8.5.9;

3> include the calculated START values for each CN domain in the IE "START list" in the IE "Uplink counter synchronisation info".

2> if the received reconfiguration message caused a change in the RLC size for any RB using RLC-AM:

3> calculate the START value according to subclause 8.5.9;

3> include the calculated START values for the CN domain associated with the corresponding RB identity in the IE "START list" in the IE "Uplink counter synchronisation info".

1> if the received reconfiguration message contained the IE "Ciphering mode info" or contained the IE "Integrity protection mode info":

2> set the IE "Status" in the variable SECURITY_MODIFICATION for all the CN domains in the variable SECURITY_MODIFICATION to "Affected".

1> if the received reconfiguration message contained the IE "Ciphering mode info":

2> if the reconfiguration message is not used to perform SRNS relocation with change of ciphering algorithm:

3> the UE behaviour is not specified.

2> if the message is used to perform a timing re-initialised hard handover:

3> if IE "Ciphering activation time for DPCH" is included:

4> the UE behaviour is not specified.

2> else:

3> if the reconfiguration message is used to setup radio bearer(s) using RLC-TM; or

3> if radio bearer(s) using RLC-TM already exist:

4> if IE "Ciphering activation time for DPCH" is not included:

5> the UE behaviour is not specified.

1> if the received reconfiguration message did not contain the IE "Ciphering activation time for DPCH" in IE "Ciphering mode info":

2> if prior to this procedure there exist no transparent mode RLC radio bearers:

3> if, at the conclusion of this procedure, the UE will be in CELL_DCH state; and

3> if, at the conclusion of this procedure, at least one transparent mode RLC radio bearer exists:

4> include the IE "COUNT-C activation time" and specify a CFN value for this IE that is a multiple of 8 frames (CFN mod 8 = 0) and lies at least 200 frames ahead of the CFN in which the response message is first transmitted.

NOTE: UTRAN should not include the IE "Ciphering mode info" in any reconfiguration message unless it is also used to perform an SRNS relocation with change of ciphering algorithm.

1> set the IE "RRC transaction identifier" to the value of "RRC transaction identifier" in the entry for the received message in the table "Accepted transactions" in the variable TRANSACTIONS; and

1> clear that entry;

1> if the variable PDCP_SN_INFO is not empty:

2> include the IE "RB with PDCP information list" and set it to the value of the variable PDCP_SN_INFO.

1> in TDD, if the procedure is used to perform a handover to a cell where timing advance is enabled, and the UE can calculate the timing advance value in the new cell (i.e. in a synchronous TDD network):

2> set the IE "Uplink Timing Advance" according to subclause 8.6.6.26.

1> if the IE "Integrity protection mode info" was present in the received reconfiguration message:

2> start applying the new integrity protection configuration in the uplink for signalling radio bearer RB2 from and including the transmitted response message.

If after state transition the UE enters URA_PCH state, the UE shall, after the state transition and transmission of the response message:

1> if the IE "Frequency info" is included in the received reconfiguration message:

2> select a suitable UTRA cell according to [4] on that frequency.

2> if the UE can not find a suitable UTRA cell on that frequency but it finds a suitable UTRA cell on another frequency:

3> proceed as below.

1> if the IE "Frequency info" is not included in the received reconfiguration message:

2> select a suitable UTRA cell according to [4].

1> prohibit periodical status transmission in RLC;

1> remove any C-RNTI from MAC;

1> clear the variable C_RNTI;

1> start timer T305 using its initial value if timer T305 is not running and if periodical update has been configured by T305 in the IE "UE Timers and constants in connected mode" set to any other value than "infinity" in the variable TIMERS_AND_CONSTANTS;

1> select Secondary CCPCH according to subclause 8.5.19;

1> if the IE "UTRAN DRX cycle length coefficient" is included in the same message:

2> use the value in the IE "UTRAN DRX Cycle length coefficient" for calculating Paging occasion and PICH Monitoring Occasion as specified in subclause 8.6.3.2.

1> if the criteria for URA update caused by "URA reselection" according to subclause 8.3.1 are fulfilled after cell selection:

2> initiate a URA update procedure according to subclause 8.3.1 using the cause "URA reselection";

2> when the URA update procedure is successfully completed:

3> the procedure ends.

If after state transition the UE enters CELL_PCH state from CELL_DCH state, the UE shall, after the state transition and transmission of the response message:

1> if the IE "Frequency info" is included in the received reconfiguration message:

2> select a suitable UTRA cell according to [4] on that frequency.

2> if the UE finds a suitable UTRA cell on that frequency:

3> if the received reconfiguration message included the IE "Primary CPICH info" (for FDD) or "Primary CCPCH info" (for TDD), and the UE selects another cell than indicated by this IE or the received reconfiguration message did not include the IE "Primary CPICH info" (for FDD) or "Primary CCPCH info" (for TDD):

4> initiate a cell update procedure according to subclause 8.3.1 using the cause "Cell reselection";

4> proceed as below.

2> else, if the UE can not find a suitable UTRA cell on that frequency but it finds a suitable UTRA cell on another frequency:

3> initiate a cell update procedure according to subclause 8.3.1 using the cause "Cell reselection";

3> proceed as below.

1> if the IE "Frequency info" is not included in the received reconfiguration message:

2> select a suitable UTRA cell according to [4].

2> if the UE finds a suitable UTRA cell on the current frequency:

3> if the received reconfiguration message included the IE "Primary CPICH info" (for FDD) or "Primary CCPCH info" (for TDD), and the UE selects another cell than indicated by this IE or the received reconfiguration message did not include the IE "Primary CPICH info" (for FDD) or "Primary CCPCH info" (for TDD):

4> initiate a cell update procedure according to subclause 8.3.1 using the cause "Cell reselection";

4> proceed as below.

2> else, if the UE can not find a suitable UTRA cell on the current frequency but it finds a suitable UTRA cell on another frequency:

3> initiate a cell update procedure according to subclause 8.3.1 using the cause "Cell reselection";

3> proceed as below.

1> prohibit periodical status transmission in RLC;

1> remove any C-RNTI from MAC;

1> clear the variable C_RNTI;

1> start timer T305 using its initial value if timer T305 is not running and if periodical update has been configured by T305 in the IE "UE Timers and constants in connected mode" set to any other value than "infinity" in the variable TIMERS_AND_CONSTANTS;

1> select Secondary CCPCH according to subclause 8.5.19;

1> if the IE "UTRAN DRX cycle length coefficient" is included in the same message:

2> use the value in the IE "UTRAN DRX Cycle length coefficient" for calculating Paging occasion and PICH Monitoring Occasion as specified in subclause 8.6.3.2.

1> the procedure ends.

If after state transition the UE enters CELL_PCH state from CELL_FACH state, the UE shall, after the state transition and transmission of the response message:

1> if the IE "Frequency info" is included in the received reconfiguration message:

2> select a suitable UTRA cell according to [4] on that frequency.

2> if the UE finds a suitable UTRA cell on that frequency:

3> if the received reconfiguration message included the IE "Primary CPICH info" (for FDD) or "Primary CCPCH info" (for TDD), and the UE selected another cell than indicated by this IE or the received reconfiguration message did not include the IE "Primary CPICH info" (for FDD) or "Primary CCPCH info" (for TDD):

4> initiate a cell update procedure according to subclause 8.3.1 using the cause "cell reselection";

4> proceed as below.

2> else, if the UE can not find a suitable UTRA cell on that frequency but it finds a suitable UTRA cell on another frequency:

3> initiate a cell update procedure according to subclause 8.3.1 using the cause "Cell reselection";

3> proceed as below.

1> if the IE "Frequency info" is not included in the received reconfiguration message:

2> if the IE "Primary CPICH info" (for FDD) or "Primary CCPCH info" (for TDD) is included the UE shall either:

3> ignore the content of the IE "Primary CPICH info" (for FDD) or "Primary CCPCH info" (for TDD) and proceed as below;

2> or:

3> if the received reconfiguration message included the IE "Primary CPICH info" (for FDD) or "Primary CPCH info" (for TDD), and it is different from the current cell:

4> initiate a cell update procedure according to subclause 8.3.1 using the cause "Cell reselection";

4> proceed as below.

1> prohibit periodical status transmission in RLC;

1> remove any C-RNTI from MAC;

1> clear the variable C_RNTI;

1> start timer T305 using its initial value if timer T305 is not running and if periodical update has been configured by T305 in the IE "UE Timers and constants in connected mode" set to any other value than "infinity" in the variable TIMERS_AND_CONSTANTS;

1> select Secondary CCPCH according to subclause 8.5.19;

1> if the IE "UTRAN DRX cycle length coefficient" is included in the same message:

2> use the value in the IE "UTRAN DRX Cycle length coefficient" for calculating Paging occasion and PICH Monitoring Occasion as specified in subclause 8.6.3.2.

1> the procedure ends.

#### 8.2.2.3a Reception of RADIO BEARER RECONFIGURATION message by the UE performing handover from GERAN *Iu mode*

If the UE is performing handover from GERAN *Iu mode*, the UE shall, in addition to the actions in 8.2.2.3:

1> if the IE "Specification mode" is set to "Preconfiguration" and the IE "Preconfiguration mode" is set to "Predefined configuration":

2> initiate the radio bearer and transport channel configuration in accordance with the predefined parameters identified by the IE "Predefined configuration identity";

2> initiate the physical channels in accordance with the predefined parameters identified by the IE "Predefined radio configuration identity" and the received physical channel information elements;

2> store information about the established radio access bearers and radio bearers according to the IE "Predefined configuration identity"; and

1> if the IE "Specification mode" is set to "Preconfiguration" and the IE "Preconfiguration mode" is set to "Default configuration":

2> initiate the radio bearer and transport channel configuration in accordance with the default parameters identified by the IE "Default configuration mode" and the IE "Default configuration identity";

2> initiate the physical channels in accordance with the default parameters identified by the IE "Default configuration mode" and IE "Default configuration identity" and the received physical channel information elements;

NOTE: The IE "Default configuration mode" specifies whether the FDD or TDD version of the default configuration shall be used.

1> if IE "Specification mode" is set to "Complete specification":

2> initiate the radio bearer, transport channel and physical channel configuration in accordance with the received radio bearer, transport channel and physical channel information elements.

1> perform an open loop estimation to determine the UL transmission power according to subclause 8.5.3;

1> set the following variables equal to the corresponding variables in GERAN *Iu mode:*

CIPHERING_STATUS

ESTABLISHED_RABS

ESTABLISHED_SIGNALLING_CONNECTIONS

INTEGRITY_PROTECTION_INFO

INTER_RAT_HANDOVER_INFO_TRANSFERRED

LATEST_CONFIGURED_CN_DOMAIN

START_THRESHOLD

UE_CAPABILITY_TRANSFERRED.

1> set the new uplink and downlink HFN of RB2 to $MSB_{20}$(MAX(uplink HFN of RB2, downlink HFN of RB2));

NOTE: $MSB_{20}$() operation provides the HFN mapping from GERAN *Iu mode* to UTRAN. In GERAN *Iu mode* the length of HFN component of the COUNT-C of RB2 is longer than 20 bits.

1> initialise the variable TIMERS_AND_CONSTANTS to the default values and start to use those timer and constants values.

#### 8.2.2.4 Transmission of a response message by the UE, normal case

In case the procedure was triggered by reception of a RADIO BEARER SETUP message, the UE shall:

1> transmit a RADIO BEARER SETUP COMPLETE as response message on the uplink DCCH using AM RLC.

In case the procedure was triggered by reception of a RADIO BEARER RECONFIGURATION message, the UE shall:

1> transmit a RADIO BEARER RECONFIGURATION COMPLETE as response message on the uplink DCCH using AM RLC.

In case the procedure was triggered by reception of a RADIO BEARER RELEASE message, the UE shall:

1> transmit a RADIO BEARER RELEASE COMPLETE as response message on the uplink DCCH using AM RLC.

In case the procedure was triggered by reception of a TRANSPORT CHANNEL RECONFIGURATION message, the UE shall:

1> transmit a TRANSPORT CHANNEL RECONFIGURATION COMPLETE as response message on the uplink DCCH using AM RLC.

In case the procedure was triggered by reception of a PHYSICAL CHANNEL RECONFIGURATION message, the UE shall:

1> transmit a PHYSICAL CHANNEL RECONFIGURATION COMPLETE as response message on the uplink DCCH using AM RLC.

If the new state is CELL_DCH or CELL_FACH, the response message shall be transmitted using the new configuration after the state transition, and the UE shall:

1> if the IE "Downlink counter synchronisation info" was included in the reconfiguration message; or

1> if the received reconfiguration message is a RADIO BEARER RECONFIGURATION and the IE "New U-RNTI" is included:

2> when RLC has confirmed the successful transmission of the response message:

3> if the variable PDCP_SN_INFO is empty:

4> configure the RLC entity for all AM and UM radio bearers and AM and UM signalling radio bearers except RB2 to "continue".

3> else:

4> configure the RLC entity for signalling radio bearers RB1, RB3 and RB4 to "continue";

4> configure the RLC entity for UM and AM radio bearers for which the IE "PDCP SN Info" is not included to "continue".

3> re-establish all AM and UM RLC entities with RB identities larger than 4 and set the first 20 bits of all the HFN component of the respective COUNT-C values to the START value included in the response message for the corresponding CN domain;

3> re-establish the RLC entities with RB identities 1, 3 and 4 and set the first 20 bits of all the HFN component of the respective COUNT-C values to the START value included in the response message for the CN domain stored in the variable LATEST_CONFIGURED_CN_DOMAIN;

3> set the remaining bits of the HFN component of COUNT-C values of all UM RLC entities to zero;

3> if the IE "PDCP context relocation info" is not present:

4> re-initialise the PDCP header compression entities of each radio bearer in the variable ESTABLISHED_RABS as specified in [36].

3> if the IE "PDCP context relocation info" is present:

4> perform the actions as specified in subclause 8.6.4.13.

1> if the variable PDCP_SN_INFO is empty:

2> if the received reconfiguration message contained the IE "Ciphering mode info":

3> when RLC has confirmed the successful transmission of the response message:

4> notify upper layers upon change of the security configuration;

4> perform the actions below.

2> if the received reconfiguration message did not contain the IE "Ciphering mode info":

3> when RLC has been requested to transmit the response message:

4> perform the actions below.

1> if the variable PDCP_SN_INFO is non-empty:

2> when RLC has confirmed the successful transmission of the response message:

3> for each radio bearer in the variable PDCP_SN_INFO:

4> if the IE "RB started" in the variable ESTABLISHED_RABS is set to "started":

5> configure the RLC entity for that radio bearer to "continue".

3> perform the actions below.

If the new state is CELL_PCH or URA_PCH, the response message shall be transmitted using the old configuration before the state transition, but the new C-RNTI shall be used if the IE "New C-RNTI" was included in the received reconfiguration message, and the UE shall:

1> when RLC has confirmed the successful transmission of the response message:

2> for each radio bearer in the variable PDCP_SN_INFO:

3> if the IE "RB started" in the variable ESTABLISHED_RABS is set to "started":

4> configure the RLC entity for that radio bearer to "continue".

2> enter the new state (CELL_PCH or URA_PCH, respectively);

2> perform the actions below.

The UE shall:

1> set the variable ORDERED_RECONFIGURATION to FALSE;

1> if the received reconfiguration message contained the IE "Ciphering mode info":

2> resume data transmission on any suspended radio bearer and signalling radio bearer mapped on RLC-AM or RLC-UM;

2> set the IE "Reconfiguration" in the variable CIPHERING_STATUS to FALSE; and

2> clear the variable RB_UPLINK_CIPHERING_ACTIVATION_TIME_INFO.

1> if the received reconfiguration message contained the IE "Integrity protection mode info":

2> allow the transmission of RRC messages on all signalling radio bearers with any RRC SN;

2> set "Uplink RRC Message sequence number" for signalling radio bearer RB0 in the variable INTEGRITY_PROTECTION_INFO to a value such that next RRC message to be sent on uplink RB0 will use the new integrity protection configuration;

2> set the IE "Reconfiguration" in the variable INTEGRITY_PROTECTION_INFO to FALSE; and

2> clear the variable INTEGRITY_PROTECTION_ACTIVATION_INFO.

1> clear the variable PDCP_SN_INFO;

1> clear the variable START_VALUE_TO_TRANSMIT;

1> clear the variable SECURITY_MODIFICATION.

### 8.2.2.5 Reception of a response message by the UTRAN, normal case

When UTRAN has received

- the RADIO BEARER SETUP COMPLETE message; or
- the RADIO BEARER RECONFIGURATION COMPLETE message; or
- the RADIO BEARER RELEASE COMPLETE message; or
- the TRANSPORT CHANNEL RECONFIGURATION COMPLETE message; or

- the PHYSICAL CHANNEL RECONFIGURATION COMPLETE message.

UTRAN may:

1> delete the old configuration.

If the procedure caused the UE to leave the CELL_FACH state, UTRAN may:

1> delete the C-RNTI of the UE.

If the IE "UL Timing Advance" is included in TDD, UTRAN should:

1> evaluate the timing advance value that the UE has to use in the new cell after handover.

If the IE "START" or the IE "START list " is included, UTRAN should:

1> set the START value for each CN domain with the corresponding values as received in this response message;

1> consequently, then use the START values to initialise the hyper frame numbers, in the same way as specified for the UE in subclause 8.2.2.3, for any new radio bearers that are established.

If UTRAN has ordered a ciphering reconfiguration by including the IE "Ciphering mode info", UTRAN should:

1> for radio bearers using RLC-AM or RLC-UM:

2> on the receiving side of an RLC entity apply the new ciphering configuration in uplink immediately;

2> on the transmitting side of an RLC entity apply the new ciphering configuration in downlink immediately.

1> for radio bearers using RLC-TM:

2> begin incrementing the COUNT-C at the CFN only as indicated in:

3> the IE "Ciphering activation time for DPCH" in the IE "Ciphering mode info", if included in the message that triggered the radio bearer control procedure; or

3> the IE "COUNT-C activation time", if included in the response message for this procedure.

1> and the procedure ends on the UTRAN side.

### 8.2.2.5a Rejection by the UE

If the UTRAN establishes one or more p-t-p radio bearer(s) for the transmission of a session of an MBMS service, identified by the IE "MBMS Session identity", for which upper layers indicate that it has already been received correctly, the UE shall:

1> transmit a failure response as specified in subclause 8.2.2.9, setting the information elements as specified below:

2> include the IE "RRC transaction identifier";

2> set it to the value of "RRC transaction identifier" in the entry for the received message in the table "Accepted transactions" in the variable TRANSACTIONS;

2> clear that entry; and

2> set the IE "failure cause" to "MBMS session already received correctly".

1> set the variable UNSUPPORTED_CONFIGURATION to FALSE;

1> continue with any ongoing processes and procedures as if the reconfiguration message was not received.

1> the procedure ends.

If the UTRAN establishes one or more p-t-p radio bearer(s) for the transmission of a session of an MBMS service, which will inhibit reception of one or more MBMS services which according to upper layers are of higher priority, the UE may:

1> transmit a failure response as specified in subclause 8.2.2.9, setting the information elements as specified below:

2> include the IE "RRC transaction identifier";

2> set it to the value of "RRC transaction identifier" in the entry for the received message in the table "Accepted transactions" in the variable TRANSACTIONS;

2> clear that entry; and

2> set the IE "failure cause" to "Lower priority MBMS service".

1> set the variable UNSUPPORTED_CONFIGURATION to FALSE;

1> continue with any ongoing processes and procedures as if the reconfiguration message was not received.

1> the procedure ends.

### 8.2.2.6 Unsupported configuration in the UE

If the UTRAN instructs the UE to use a configuration, which it does not support and/or if the received message causes the variable UNSUPPORTED_CONFIGURATION to be set to TRUE, the UE shall:

1> transmit a failure response as specified in subclause 8.2.2.9, setting the information elements as specified below:

2> include the IE "RRC transaction identifier"; and

2> set it to the value of "RRC transaction identifier" in the entry for the received message in the table "Accepted transactions" in the variable TRANSACTIONS; and

2> clear that entry;

2> set the IE "failure cause" to "configuration unsupported".

1> set the variable UNSUPPORTED_CONFIGURATION to FALSE;

1> continue with any ongoing processes and procedures as if the reconfiguration message was not received.

The procedure ends.

### 8.2.2.7 Physical channel failure

If the received message caused the UE to be in CELL_DCH state and the UE according to subclause 8.5.4 failed to establish the dedicated physical channel(s) indicated in the received message or for 3.84 Mcps TDD or 7.68 Mcps TDD failed to establish the physical channel(s) indicated in the received message to which DCCH(s) are mapped the UE shall:

1> if the CM_PATTERN_ACTIVATION_ABORTED flag is not set to TRUE:

2> revert to the configuration prior to the reception of the message (old configuration), including any HS-DSCH and E-DCH configuration if existing;

2> if the UE was in Cell DCH state prior to the reconfiguration:

3> perform the physical layer synchronisation procedure A as specified in [29] (FDD only);

3> apply power control preamble according to [26] during the number of frames indicated in the IE "PC preamble" in the variable LATEST_CONFIGURED_SRB_DELAY_AND_PC_PREAMBLE; and

3> then not send any data on signalling radio bearers RB0 to RB4 during the number of frames indicated in the IE "SRB delay" in the variable LATEST_CONFIGURED_SRB_DELAY_AND_PC_PREAMBLE or while the physical channel is not considered established;.

1> if the CM_PATTERN_ACTIVATION_ABORTED flag is set to TRUE or if the old configuration includes dedicated physical channels (CELL_DCH state) and the UE is unable to revert to the old configuration:

2> initiate a cell update procedure according to subclause 8.3.1, using the cause "radio link failure";

2> after the cell update procedure has completed successfully:

3> proceed as below.

1> if the old configuration does not include dedicated physical channels (CELL_FACH state):

2> select a suitable UTRA cell according to [4];

2> if the UE selects another cell than the cell the UE camped on upon reception of the reconfiguration message:

3> initiate a cell update procedure according to subclause 8.3.1, using the cause "Cell reselection";

3> after the cell update procedure has completed successfully:

4> proceed as below.

1> transmit a failure response message as specified in subclause 8.2.2.9, setting the information elements as specified below:

2> include the IE "RRC transaction identifier"; and

2> set it to the value of "RRC transaction identifier" in the entry for the received message in the table "Accepted transactions" in the variable TRANSACTIONS; and

2> clear that entry;

2> set the IE "failure cause" to "physical channel failure".

1> set the variable ORDERED_RECONFIGURATION to FALSE;

1> continue with any ongoing processes and procedures as if the reconfiguration message was not received.

The procedure ends.

### 8.2.2.8 Cell re-selection

If the UE performs cell re-selection during the reconfiguration procedure, the UE shall:

1> initiate a cell update procedure, as specified in subclause 8.3.1;

1> continue with the reconfiguration procedure.

NOTE: After the completion of the cell update procedure and completion of the reconfiguration procedure within the UE, the UE will move to the RRC state as indicated in the reconfiguration message.

### 8.2.2.9 Transmission of a response message by the UE, failure case

The UE shall:

1> in case of reception of a RADIO BEARER SETUP message:

2> if the radio bearer establishment procedure affects several radio bearers:

3> (may) include the identities of the radio bearers for which the procedure would have been successful into the RADIO BEARER SETUP FAILURE message.

2> transmit a RADIO BEARER SETUP FAILURE as response message on the DCCH using AM RLC.

1> in case of reception of a RADIO BEARER RECONFIGURATION message:

2> if the radio bearer reconfiguration procedure affects several radio bearers:

3> (may) include the identities of the radio bearers for which the procedure would have been successful into the RADIO BEARER RECONFIGURATION FAILURE message.

2> transmit a RADIO BEARER RECONFIGURATION FAILURE as response message on the DCCH using AM RLC.

1> in case of reception of a RADIO BEARER RECONFIGURATION message encapsulated in INTERSYSTEM HANDOVER TO UTRAN COMMAND message in GERAN *Iu mode*:

2> perform the actions as specified in [53].

1> in case of reception of a RADIO BEARER RELEASE message:

2> if the radio bearer release procedure affects several radio bearers:

3> (may) include the identities of the radio bearers for which the procedure would have been successful into the RADIO BEARER RELEASE FAILURE message.

2> transmit a RADIO BEARER RELEASE FAILURE as response message on the DCCH using AM RLC.

1> in case of reception of a TRANSPORT CHANNEL RECONFIGURATION message:

2> transmit a TRANSPORT CHANNEL RECONFIGURATION FAILURE as response message on the DCCH using AM RLC.

1> in case of reception of a PHYSICAL CHANNEL RECONFIGURATION message:

2> transmit a PHYSICAL CHANNEL RECONFIGURATION FAILURE as response message on the DCCH using AM RLC.

1> when the response message has been submitted to lower layers for transmission:

2> continue with any ongoing processes and procedures as if no reconfiguration attempt had occurred.

### 8.2.2.10 Reception of a response message by the UTRAN, failure case

When the UTRAN has received:

- the RADIO BEARER SETUP FAILURE message; or
- the RADIO BEARER RECONFIGURATION FAILURE message; or
- the RADIO BEARER RELEASE FAILURE message; or
- the TRANSPORT CHANNEL RECONFIGURATION FAILURE message; or
- the PHYSICAL CHANNEL RECONFIGURATION FAILURE message:

the UTRAN may restore the old and delete the new configuration. Upper layers should be notified of the failure.

The procedure ends on the UTRAN side.

### 8.2.2.11 Invalid configuration

If the variable INVALID_CONFIGURATION is set to TRUE the UE shall:

1> keep the configuration existing before the reception of the message;

1> transmit a failure response message as specified in subclause 8.2.2.9, setting the information elements as specified below:

2> include the IE "RRC transaction identifier"; and

3> set it to the value of "RRC transaction identifier" in the entry for the received message in the table "Accepted transactions" in the variable TRANSACTIONS; and

3> clear that entry.

2> set the IE "failure cause" to "invalid configuration".

1> set the variable INVALID_CONFIGURATION to FALSE;

1> continue with any ongoing processes and procedures as if the reconfiguration message was not received.

The procedure ends.

### 8.2.2.12 Incompatible simultaneous reconfiguration

If the table "Rejected transactions" in the variable TRANSACTIONS is set due to the received message and the variable PROTOCOL_ERROR_REJECT is set to FALSE, the UE shall:

1> not apply the configuration contained in the received reconfiguration message;

1> transmit a failure response message as specified in subclause 8.2.2.9, setting the information elements as specified below:

2> include the IE "RRC transaction identifier"; and

2> set it to the value of "RRC transaction identifier" in the entry for the received message in the table "Rejected transactions" in the variable TRANSACTIONS; and

2> clear that entry;

2> set the IE "failure cause" to "incompatible simultaneous reconfiguration".

1> continue with any ongoing processes and procedures as if the reconfiguration message was not received.

The procedure ends.

### 8.2.2.12a Incompatible simultaneous security reconfiguration

If the variable INCOMPATIBLE_SECURITY_RECONFIGURATION is set to TRUE due to the received reconfiguration message, the UE shall:

1> transmit a failure response message as specified in subclause 8.2.2.9, setting the information elements as specified below:

2> include the IE "RRC transaction identifier"; and

2> set it to the value of "RRC transaction identifier" in the entry for the received message in the table "Accepted transactions" in the variable TRANSACTIONS; and

2> clear that entry;

2> set the IE "failure cause" to the cause value "incompatible simultaneous reconfiguration".

1> set the variable INCOMPATIBLE_SECURITY_RECONFIGURATION to FALSE;

1> continue with any ongoing processes and procedures as if the reconfiguration message was not received.

The procedure ends.

### 8.2.2.12b Cell update procedure during security reconfiguration

If:

- a cell update procedure according to subclause 8.3.1 is initiated; and
- the received reconfiguration message causes either:
  - the IE "Reconfiguration" in the variable CIPHERING_STATUS to be set to TRUE; and/or
  - the IE "Reconfiguration" in the variable INTEGRITY_PROTECTION_INFO to be set to TRUE:

the UE shall:

1> release all radio resources;

1> indicate the release of the established signalling connections (as stored in the variable ESTABLISHED_SIGNALLING_CONNECTIONS) and established radio access bearers (as stored in the variable ESTABLISHED_RABS) to upper layers; and

1> clear any entry for the RRC CONNECTION RELEASE message in the tables "Accepted transactions" and "Rejected transactions" in the variable TRANSACTIONS;

1> clear the variable ESTABLISHED_SIGNALLING_CONNECTIONS;

1> clear the variable ESTABLISHED_RABS;

1> if the received reconfiguration message contained the IE "Ciphering mode info":

2> set the IE "Reconfiguration" in the variable CIPHERING_STATUS to FALSE; and

2> clear the variable RB_UPLINK_CIPHERING_ACTIVATION_TIME_INFO;

2> clear the variable SECURITY_MODIFICATION.

1> if the received reconfiguration message contained the IE "Integrity protection mode info":

2> set the IE "Reconfiguration" in the variable INTEGRITY_PROTECTION_INFO to FALSE; and

2> clear the variable INTEGRITY_PROTECTION_ACTIVATION_INFO.

1> enter idle mode;

1> perform the actions specified in subclause 8.5.2 when entering idle mode;

1> and the procedure ends.

NOTE: UTRAN should use RB Control messages to perform an SRNS relocation only in case of state transitions from CELL_DCH to CELL_DCH.

### 8.2.2.13 Invalid received message

If the received reconfiguration message contains a protocol error causing the variable PROTOCOL_ERROR_REJECT to be set to TRUE according to clause 9, the UE shall perform procedure specific error handling as follows. The UE shall:

1> transmit a failure response message as specified in subclause 8.2.2.9, setting the information elements as specified below:

2> include the IE "RRC transaction identifier"; and

2> set it to the value of "RRC transaction identifier" in the entry for the received message in the table "Rejected transactions" in the variable TRANSACTIONS; and

2> clear that entry;

2> set the IE "failure cause" to the cause value "protocol error";

2> include the IE "Protocol error information" with contents set to the value of the variable PROTOCOL_ERROR_INFORMATION.

The procedure ends.

### 8.2.2.14 Radio link failure

If the criteria for radio link failure are met in the old configuration during the reconfiguration procedure as specified in subclause 8.5.6, the UE shall:

1> if UE would have entered CELL_PCH or URA_PCH as a result of this reconfiguration procedure and UE has already submitted a response message to lower layers:

2> act as if the reconfiguration message was not received;

2> initiate a cell update procedure according to subclause 8.3.1, using the cause "radio link failure";

2> the procedure ends.

NOTE: UTRAN should consider the reconfiguration procedure as unsuccessful in this case even if a success response message had been received.

1> if the UE would have remained in CELL_DCH state as a result of this reconfiguration procedure:

2> initiate a cell update procedure according to subclause 8.3.1, using the cause "radio link failure";

2> after the cell update procedure has completed successfully:

3> transmit a failure response message as specified in subclause 8.2.2.9, setting the information elements as specified below:

4> include the IE "RRC transaction identifier"; and

4> set it to the value of "RRC transaction identifier" in the entry for the received message in the table "Accepted transactions" in the variable TRANSACTIONS; and

4> clear that entry;

4> set the IE "failure cause" to "physical channel failure".

3> act as if the reconfiguration message was not received;

3> the procedure ends.

If the criteria for radio link failure are met in the new configuration during the reconfiguration procedure (i.e. while UE is waiting for RLC acknowledgement for a response message.) as specified in subclause 8.5.6, the UE shall:

1> if the received reconfiguration causes either:

- the IE "Reconfiguration" in the variable CIPHERING_STATUS to be set to TRUE; and/or

- the IE "Reconfiguration" in the variable INTEGRITY_PROTECTION_INFO to be set to TRUE:

2> perform the actions specified in subclause 8.2.2.12b.

1> else, the UE should:

2> release all its radio resources;

2> indicate the release of the established signalling connections (as stored in the variable ESTABLISHED_SIGNALLING_CONNECTIONS) and established radio access bearers (as stored in the variable ESTABLISHED_RABS) to upper layers;

2> clear any entry for the RRC CONNECTION RELEASE message in the tables "Accepted transactions" and "Rejected transactions" in the variable TRANSACTIONS;

2> clear the variable ESTABLISHED_SIGNALLING_CONNECTIONS;

2> clear the variable ESTABLISHED_RABS;

2> enter idle mode;

2> perform the actions specified in subclause 8.5.2 when entering idle mode; and

2> the procedure ends.

### 8.2.3 Radio bearer release

See subclause 8.2.2 (Reconfiguration procedures).

## 8.2.4 Transport channel reconfiguration

See subclause 8.2.2 (Reconfiguration procedures).

## 8.2.5 Transport format combination control

**Figure 8.2.5-1: Transport format combination control, normal flow**




**Figure 8.2.5-2: Transport format combination control, failure case**

### 8.2.5.1 General

The transport format combination control procedure is used to control the allowed uplink transport format combinations within the transport format combination set.

### 8.2.5.2 Initiation

To initiate the transport format combination control procedure, the UTRAN transmits the TRANSPORT FORMAT COMBINATION CONTROL message on the downlink DCCH using AM, UM or TM RLC. When not stated otherwise elsewhere, the UTRAN may initiate the transport format combination control procedure also when another procedure is ongoing, and in that case the state of the latter procedure shall not be affected.

To change the sub-set of allowed transport format combinations, the UTRAN should:

1> set the allowed TFCs in the IE "Transport Format Combination subset" ("TFC subset"). The UTRAN may specify the duration for which a new TFC sub-set applies by using the IE "TFC Control duration" and independently may specify the time at which a new TFC sub-set shall be applied using the IE "Activation time for TFC subset".

To remove completely the previous restrictions of allowed transport format combinations, the UTRAN should:

1> set the IE "full transport format combination set " in the IE "TFC subset".

### 8.2.5.3 Reception of a TRANSPORT FORMAT COMBINATION CONTROL message by the UE

If the TRANSPORT FORMAT COMBINATION CONTROL message was received on AM RLC or UM RLC, the UE shall:

1> act upon all received information elements as specified in 8.6, unless specified otherwise in the following;

1> perform the actions for the transport format combination subset specified in the IE "DPCH/PUSCH TFCS in uplink" according to subclause 8.6.5.3;

1> if the variable INVALID_CONFIGURATION is set to FALSE:

2> if the IE "TFC Control duration" is included in the message:

3> store the value of the IE "TFC Control duration" in the IE "Duration" in the variable TFC_SUBSET;

3> set the IE "Current TFC subset" (for the CCTrCH indicated by the IE "TFCS Id" in case of TDD) in the variable TFC_SUBSET to the value of the IE "Transport format combination subset";

3> at the CFN indicated by IE "Activation time for TFC subset" apply the transport format combination subset in the IE "Current TFC subset" stored in the variable TFC_SUBSET for the number of (10 ms) frames specified in the IE "Duration";

3> at the end of the time period defined by the IE "Duration"in the variable TFC_SUBSET:

4> if the IE "Current TFC subset" (for the CCTrCH indicated by the IE "TFCS Id" in case of TDD) in the variable TFC_SUBSET has not subsequently been changed by another message:

5> set the value of the IE "Current TFC subset" to the value of the IE "Default TFC subset" in the variable TFC_SUBSET;

5> clear the IE "Duration" in the variable TFC_SUBSET;

5> apply the transport format combination subset in the IE "Current TFC subset" stored in the variable TFC_SUBSET;

2> if the IE "TFC Control duration" is not included in the message:

3> clear the value of the IE "Duration" in the variable TFC_SUBSET;

3> set both the IE "Current TFC subset" and the IE "Default TFC subset" ( for the CCTrCH indicated by the IE "TFCS Id" in case of TDD) in the variable TFC_SUBSET to the value of the IE "Transport format combination subset";

3> at the CFN indicated by the IE "Activation time for TFC subset" apply the transport format combination subset in the IE "Current TFC subset" stored in the variable TFC_SUBSET.

If the TRANSPORT FORMAT COMBINATION CONTROL message was received on TM RLC, the UE shall:

1> if the IE "TFC subset identity" identifies one of the TFC subsets stored in the IE "TFC subset list" in the variable TFC_SUBSET:

2> perform the actions as specified in subclause 8.6.5.3;

2> if the variable INVALID_CONFIGURATION is set to FALSE:

3> in the variable TFC_SUBSET, set the IE "Current TFC subset" and the IE "default TFC subset" to the value of the IE "TFC subset" in "TFC subset list" which is identified by the IE "TFC subset identity";

3> clear the IE "Duration" in the variable TFC_SUBSET;

3> apply the transport format combination subset in the IE "Current TFC subset" stored in the variable TFC_SUBSET.

1> if the IE "TFC subset identity" is greater than the maximum number of TFC subsets stored in the IE "TFC subset list" in the variable TFC_SUBSET:

2> set the variable INVALID_CONFIGURATION to TRUE.

NOTE: The UTRAN should only send the TRANSPORT FORMAT COMBINATION CONTROL message on TM RLC in order to control the rate of TM RBs (for example, carrying multi-rate AMR or WB-AMR) otherwise the UE behaviour is not specified.

The UE shall:

1> clear the entry for the TRANSPORT FORMAT COMBINATION CONTROL message in the table "Accepted transactions" in the variable TRANSACTIONS;

1> and the procedure ends.

### 8.2.5.4 Invalid configuration

If the variable INVALID_CONFIGURATION is set to TRUE due to the received TRANSPORT FORMAT COMBINATION CONTROL message the UE shall:

1> if the TRANSPORT FORMAT COMBINATION CONTROL message was received on AM RLC:

2> keep the TFC subset existing before the TRANSPORT FORMAT COMBINATION CONTROL message was received;

2> transmit a TRANSPORT FORMAT COMBINATION CONTROL FAILURE message on the DCCH using AM RLC;

2> set the IE "RRC transaction identifier" in the TRANSPORT FORMAT COMBINATION CONTROL FAILURE message to the value of "RRC transaction identifier" in the entry for the TRANSPORT FORMAT COMBINATION CONTROL message in the table "Accepted transactions" in the variable TRANSACTIONS; and

2> clear that entry;

2> set the IE "failure cause" to "invalid configuration";

2> when the TRANSPORT FORMAT COMBINATION CONTROL FAILURE message has been submitted to lower layers for transmission the procedure ends.

1> if the TRANSPORT FORMAT COMBINATION CONTROL message was received on UM RLC or TM RLC:

2> ignore the TRANSPORT FORMAT COMBINATION CONTROL message;

2> clear the entry for the TRANSPORT FORMAT COMBINATION CONTROL message in the table "Accepted transactions" in the variable TRANSACTIONS.

### 8.2.5.5 Invalid TRANSPORT FORMAT COMBINATION CONTROL message

If the TRANSPORT FORMAT COMBINATION CONTROL message was received on AM RLC or UM RLC and contains a protocol error causing the variable PROTOCOL_ERROR_REJECT to be set to TRUE according to clause 9, the UE shall perform procedure specific error handling as follows. The UE shall:

1> transmit a TRANSPORT FORMAT COMBINATION CONTROL FAILURE message on the uplink DCCH using AM RLC setting the information elements as specified below:

2> set the IE "RRC transaction identifier" in the TRANSPORT FORMAT COMBINATION CONTROL FAILURE message to the value of "RRC transaction identifier" in the entry for the TRANSPORT FORMAT COMBINATION CONTROL message in the table "Rejected transactions" in the variable TRANSACTIONS; and

2> clear that entry;

2> set the IE "failure cause" to the cause value "protocol error";

2> include the IE "Protocol error information" with contents set to the value of the variable PROTOCOL_ERROR_INFORMATION.

1> when the TRANSPORT FORMAT COMBINATION CONTROL FAILURE message has been submitted to lower layers for transmission:

2> continue with any ongoing processes and procedures as if the invalid TRANSPORT FORMAT COMBINATION CONTROL message has not been received;

2> and the procedure ends.

If the TRANSPORT FORMAT COMBINATION CONTROL message was received on TM RLC and contains a protocol error causing the variable PROTOCOL_ERROR_REJECT to be set to TRUE according to clause 9, the UE shall perform procedure specific error handling as follows. The UE shall:

1> ignore the invalid TRANSPORT FORMAT COMBINATION CONTROL message as if it has not been received;

1> the procedure ends.

## 8.2.6 Physical channel reconfiguration

See subclause 8.2.2 Reconfiguration procedures.

## 8.2.7 Physical Shared Channel Allocation [TDD only]

**Figure 8.2.7-1: Physical Shared Channel Allocation**

### 8.2.7.1 General

The purpose of this procedure is to allocate radio resources to USCH and/or DSCH transport channels in TDD mode, for use by a UE. This procedure can also be used to indicate to the UE, that a PUSCH allocation is pending, in order to prevent further capacity requests from the UE.

UEs are not required to receive FACH and DSCH simultaneously, i.e. if resources are allocated to DSCH the FACH reception may be suspended.

### 8.2.7.2 Initiation

To initiate the Physical Shared Channel Allocation procedure, the UTRAN sends the "PHYSICAL SHARED CHANNEL ALLOCATION" message on the downlink SHCCH or on the downlink DCCH using UM RLC. The DSCH-RNTI shall be included for UE identification, if the message is sent on the SHCCH.

### 8.2.7.3 Reception of a PHYSICAL SHARED CHANNEL ALLOCATION message by the UE

Upon reception of a "PHYSICAL SHARED CHANNEL ALLOCATION" message, if the message is received on the downlink SHCCH the UE shall:

1> check the DSCH-RNTI to see if the UE is addressed by the message;

1> if the UE is addressed by the message, or if the message is received on the downlink DCCH:

2> perform the following actions.

1> otherwise:

2> ignore the message.

1> act upon all received information elements as specified in subclause 8.6, unless specified otherwise in the following:

1> if the IE "ISCP Timeslot list" is included:

2> store the timeslot numbers given there for future Timeslot ISCP measurements and reports in the variable PHYSICAL_SHARED_CHANNEL_CONFIGURATION.

1> if the IE "PDSCH capacity allocation info" is included:

2> configure the physical resources used for the downlink CCTrCH given by the IE "TFCS ID" according to the following:

3> if the CHOICE "Configuration" has the value "Old configuration":

4> if the UE has stored a PDSCH configuration in the variable PHYSICAL_SHARED_CHANNEL_CONFIGURATION with the identity given by the IE "PDSCH Identity":

5> configure the physical resources according to that configuration.

4> otherwise:

5> ignore the IE "PDSCH capacity allocation info".

3> if the CHOICE "Configuration" has the value "New configuration":

4> configure the physical resources according to the information given in IE "PDSCH Info". If IE "Common timeslot info" or IE "PDSCH timeslots and codes" IE are not present in IE "PDSCH Info":

5> reuse the configuration stored in the variable PHYSICAL_SHARED_CHANNEL_CONFIGURATION for this CCTrCH.

4> if the IE "PDSCH Identity" is included:

5> store the new configuration in the variable PHYSICAL_SHARED_CHANNEL_CONFIGURATION using that identity.

2> start using the new configuration at the CFN specified by the IE "Allocation activation time", and use that for the duration given by the IE "Allocation duration";

2> if the IE "Confirm request" has the value "Confirm PDSCH" and IE "PDSCH Identity" is included in IE "PDSCH capacity allocation info":

3> initiate the PUSCH CAPACITY REQUEST procedure as described in subclause 8.2.8.

1> if the IE "PUSCH capacity allocation info" is included:

2> stop the timer T310, if running;

2> if the CHOICE "PUSCH allocation" has the value "PUSCH allocation pending":

3> start the timer T311.

2> if the CHOICE "PUSCH allocation" has the value "PUSCH allocation assignment":

3> stop the timer T311, if running;

3> configure the physical resources used for the uplink CCTrCH given by the IE "TFCS ID" according to the following:

4> if the CHOICE "Configuration" has the value "Old configuration":

5> if the UE has stored a PUSCH configuration with the identity given by the IE "PUSCH Identity" in the variable PHYSICAL_SHARED_CHANNEL_CONFIGURATION:

6> configure the physical resources according to that configuration.

5> otherwise:

6> ignore the IE "PUSCH capacity allocation info".

4> if the CHOICE "Configuration" has the value "New configuration", the UE shall:

5> configure the physical resources according to the information given in IE "PUSCH Info". If IE "Common timeslot info" or IE "PUSCH timeslots and codes" is not present in IE "PUSCH Info":

6> reuse the configuration stored in the variable PHYSICAL_SHARED_CHANNEL_CONFIGURATION for this CCTrCH.

5> if the IE "PUSCH Identity" is included:

6> store the new configuration in the variable PHYSICAL_SHARED_CHANNEL_CONFIGURATION using that identity.

3> if the IE "PUSCH power control info" is present in this message and includes the parameter "UL target SIR" for 3.84 Mcps TDD or 7.68 Mcps TDD, or the parameters "$PRX_{PUSCHdes}$" and "Beacon PL Est. " and "TPC Step Size" for 1.28 Mcps TDD, or the parameters are stored in the variable PHYSICAL SHARED CHANNEL CONFIGURATION for this CCTrCH:

4> start using the new configuration at the CFN specified by the IE "Allocation activation time", and use that for the duration given by the IE "Allocation duration".

3> otherwise:

4> ignore the IE "PUSCH capacity allocation info".

3> if the IE "PUSCH power control info" is present in this message and includes the parameter "UL target SIR" for 3.84 Mcps TDD or 7.68 Mcps TDD, or the parameters "$PRX_{PUSCHdes}$" and/or "Beacon PL Est. " and/or "TPC Step Size" for 1.28 Mcps TDD:

4> replace the parameters "UL target SIR" or "$PRX_{PUSCHdes}$" or "TPC Step Size" stored in the variable PHYSICAL SHARED CHANNEL CONFIGURATION for this CCTrCH with the signalled values.

3> if the IE "Traffic volume report request " is included:

4> initiate the PUSCH CAPACITY REQUEST procedure as described in subclause 8.2.8 at the time indicated by the IE "Traffic volume report request".

3> if the IE "Confirm request" has the value "Confirm PUSCH" and IE "PUSCH Identity" is included in IE "PUSCH capacity allocation info":

4> initiate the PUSCH CAPACITY REQUEST procedure as described in subclause 8.2.8.

3> determine the TFCS subset and hence the TFCI values which are possible given the PUSCH allocation for that CCTrCH;

3> configure the MAC-c/sh in the UE with this TFCS restriction if necessary;

3> transmit USCH Transport Block Sets as required, within the TFCS limits given by the PUSCH allocation.

NOTE: If the UE has just entered a new cell and System Information Block Type 6 has not yet been scheduled, PUSCH/PDSCH information should be specified in the allocation message.

The UE shall:

1> clear the entry for the PHYSICAL SHARED CHANNEL ALLOCATION message in the table "Accepted transactions" in the variable TRANSACTIONS;

1> and the procedure ends.

### 8.2.7.4 Invalid PHYSICAL SHARED CHANNEL ALLOCATION message

If the UE receives a PHYSICAL SHARED CHANNEL ALLOCATION message, which contains a protocol error causing the variable PROTOCOL_ERROR_REJECT to be set to TRUE according to clause 9, the UE shall perform procedure specific error handling as follows. The UE shall:

1> ignore the invalid PHYSICAL SHARED CHANNEL ALLOCATION message;

1> submit the PUSCH CAPACITY REQUEST message for transmission on the uplink SHCCH, setting the information elements in the message as specified in subclause 8.2.8.3;

1> reset counter V310;

1> start timer T310;

1> proceed as described in subclause 8.2.8.

## 8.2.8 PUSCH capacity request [TDD only]




**Figure 8.2.8-1: PUSCH Capacity request procedure**

### 8.2.8.1 General

With this procedure, the UE transmits its request for PUSCH resources to the UTRAN. In the normal case, the UTRAN responds with a PHYSICAL SHARED CHANNEL ALLOCATION message, which either allocates the requested PUSCH resources, and/or allocates a PDSCH resource, or may just serve as an acknowledgement, indicating that PUSCH allocation is pending.

This procedure can also be used to acknowledge the reception of a PHYSICAL SHARED CHANNEL ALLOCATION message, or to indicate a protocol error in that message.

With the PUSCH CAPACITY REQUEST message, the UE can request capacity for one or more USCH.

### 8.2.8.2 Initiation

This procedure is initiated:

1> in the CELL_FACH or CELL_DCH state;

1> and when at least one RB using USCH has been established;

1> and when the UE sees the requirement to request physical resources (PUSCH) for an USCH channel or there is the need to reply to a PHYSICAL SHARED CHANNEL ALLOCATION message as described in clause 8.2.7 (i.e. to confirm the reception of a message, if requested to do so, or to indicate a protocol error).

The procedure can be initiated if:

- Timer T311 is not running.
- The timer T310 (capacity request repetition timer) is not running.

The UE shall:

1> set the IEs in the PUSCH CAPACITY REQUEST message according to subclause 8.2.8.3;

1> if the procedure is triggered to reply to a previous PHYSICAL SHARED CHANNEL ALLOCATION message by the IE "Confirm request" set to "Confirm PUSCH" and the IE "PUSCH capacity allocation info" is not present:

2> transmit the PUSCH CAPACITY REQUEST message on RACH.

1> else:

2> transmit the PUSCH CAPACITY REQUEST message on the uplink SHCCH.

1> set counter V310 to 1;

1> start timer T310.

### 8.2.8.3 PUSCH CAPACITY REQUEST message contents to set

With one PUSCH CAPACITY REQUEST message, capacity for one or more USCH can be requested. It shall include these information elements:

1> DSCH-RNTI to be used as UE identity if the message is sent on RACH;

1> Traffic volume measured results for each radio bearer satisfying the reporting criteria as specified in the MEASUREMENT CONTROL procedure (if no radio bearer satisfies the reporting criteria, traffic volume measured results shall not be included). These results shall include:

2> Radio Bearer ID of the Radio Bearer being reported;

2> RLC buffer payload for these radio bearers, as specified by the MEASUREMENT CONTROL procedure.

The UE shall:

1> if the initiation of the procedure is triggered by the IE "Traffic volume report request" in a previously received PHYSICAL SHARED CHANNEL ALLOCATION message:

2> report the traffic volume measurement result for the radio bearer mapped on USCH transport channel specified in the received message. These results shall include:

3> Radio Bearer ID of the Radio Bearer being reported;

3> RLC buffer payload for this radio bearer.

1> if the initiation of the procedure is triggered by the IE "Confirm request" set to "Confirm PDSCH" in a previously received PHYSICAL SHARED CHANNEL ALLOCATION message and the IE "PUSCH capacity allocation info" is present in this message:

2> set the CHOICE "Allocation confirmation" to "PDSCH Confirmation" with the value given in the IE "PDSCH Identity" stored in the variable PHYSICAL_SHARED_CHANNEL_CONFIGURATION.

1> if the initiation of the procedure is triggered by the IE "Confirm request" set to "Confirm PUSCH" in a previously received PHYSICAL SHARED CHANNEL ALLOCATION message:

2> set the CHOICE "Allocation confirmation" to "PUSCH Confirmation" with the value given in the IE "PUSCH Identity" stored in the variable PHYSICAL_SHARED_CHANNEL_CONFIGURATION.

1> if the variable PROTOCOL_ERROR_REJECT is set to TRUE:

2> include the IE "RRC transaction identifier" in the response message transmitted below; and

2> set it to the value of "RRC transaction identifier" in the entry for the PHYSICAL SHARED CHANNEL ALLOCATION message in the table "Rejected transactions" in the variable TRANSACTIONS; and

2> clear that entry;

2> set the IE "protocol error indicator" to TRUE;

2> include the IE "Protocol error information" with contents set to the value of the variable PROTOCOL_ERROR_INFORMATION.

1> if the value of the variable PROTOCOL_ERROR_ REJECT is FALSE:

2> set the IE "Protocol error indicator" to FALSE.

As an option, the message may include IE "Timeslot ISCP" and IE "Primary CCPCH RSCP".

The timeslots for which "Timeslot ISCP" may be reported shall have been configured with a previous PHYSICAL SHARED CHANNEL ALLOCATION message and stored in the variable PHYSICAL_SHARED_CHANNEL_CONFIGURATION.

"Primary CCPCH RSCP" is reported when requested with a previous PHYSICAL SHARED CHANNEL ALLOCATION message.

#### 8.2.8.4 Reception of a PUSCH CAPACITY REQUEST message by the UTRAN

Upon receiving a PUSCH CAPACITY REQUEST message with traffic volume measurement included for at least one radio bearer, the UTRAN should initiate the PHYSICAL SHARED CHANNEL ALLOCATION procedure, either for allocating PUSCH or PDSCH resources as required, or just as an acknowledgement, indicating a pending PUSCH allocation, as described in subclause 8.2.7.

#### 8.2.8.5 T310 expiry

Upon expiry of timer T310, the UE shall:

1> if V310 is smaller than N310:

2> transmit a new PUSCH CAPACITY REQUEST message on the Uplink SHCCH;

2> restart timer T310;

2> increment counter V310;

2> set the IEs in the PUSCH CAPACITY REQUEST message as specified in subclause 8.2.8.3.

1> if V310 is greater than or equal to N310:

2> the procedure ends.

### 8.2.9 Void

### 8.2.10 Uplink Physical Channel Control [TDD only]

**Figure 8.2.10-1: Uplink Physical Channel Control**

#### 8.2.10.1 General

The uplink physical channel control procedure is used in TDD to control the uplink outer loop power control and timing advance running in the UE.

#### 8.2.10.2 Initiation

The UTRAN initiates the procedure by transmitting the UPLINK PHYSICAL CHANNEL CONTROL message on the downlink DCCH using AM or UM RLC in order to update parameters for uplink open loop power control in the UE for

one CCTrCH or to inform the UE about a new timing advance value to be applied. Especially, uplink interference information measured by the UTRAN can be included for the uplink timeslots used for the CCTrCH.

### 8.2.10.3 Reception of UPLINK PHYSICAL CHANNEL CONTROL message by the UE

Upon reception of the UPLINK PHYSICAL CHANNEL CONTROL message, the UE shall:

1> act upon all received information elements as specified in subclause 8.6.

In 1.28 Mcps TDD, if the IE "Uplink DPCH Power Control Info" is transmitted, this information shall be taken into account by the UE for uplink open loop power control and for uplink closed loop power control as described in subclause 8.6.6.11.

In 3.84 Mcps TDD or 7.68 Mcps TDD, if the IEs "Uplink DPCH Power Control Info", "PRACH Constant Value", "PUSCH Constant Value", "HS-SICH Power Control Info", "Alpha" or IE group "list of UL Timeslot Interference" are transmitted, this information shall be taken into account by the UE for uplink open loop power control as specified in subclause 8.5.7. If the UE is capable of using IPDLs for UE positioning, the IE "IPDL-Alpha" shall be used instead of the IE "Alpha". If the IE "IPDL-Alpha" parameter is not present, the UE shall use IE "Alpha".

If the IE Special Burst Scheduling is transmitted the UE shall:

1> use the new value for the "Special Burst Generation Period".

The UE shall:

1> clear the entry for the UPLINK PHYSICAL CHANNEL CONTROL message in the table "Accepted transactions" in the variable TRANSACTIONS;

1> and the procedure ends.

### 8.2.10.4 Invalid UPLINK PHYSICAL CHANNEL CONTROL message

If the UE receives a UPLINK PHYSICAL CHANNEL CONTROL message, which contains a protocol error causing the variable PROTOCOL_ERROR_REJECT to be set to TRUE according to clause 9, the UE shall perform procedure specific error handling as follows. The UE shall:

1> transmit an RRC STATUS message on the uplink DCCH using AM RLC, setting the information elements as specified below:

2> include the IE "Identification of received message"; and

2> set the IE "Received message type" to UPLINK PHYSICAL CHANNEL CONTROL; and

2> set the IE "RRC transaction identifier" to the value of "RRC transaction identifier" in the entry for the UPLINK PHYSICAL CHANNEL CONTROL message in the table "Rejected transactions" in the variable TRANSACTIONS; and

2> clear that entry;

2> include the IE "Protocol error information" with contents set to the value of the variable PROTOCOL_ERROR_INFORMATION.

1> when the RRC STATUS message has been submitted to lower layers for transmission:

2> continue with any ongoing processes and procedures as if the invalid UPLINK PHYSICAL CHANNEL CONTROL message has not been received.

## 8.2.11 Physical channel reconfiguration failure




**Figure 8.2.11-1: Physical channel reconfiguration failure in case of runtime configuration error**

### 8.2.11.1 General

The physical channel reconfiguration failure procedure is used to indicate to the network a runtime configuration error in the UE.

### 8.2.11.2 Runtime error due to overlapping compressed mode configurations

When the UE has received from the UTRAN the configurations of several compressed mode transmission gap pattern sequences, and if several of these patterns are to be simultaneously active, the UE shall check to see if these simultaneously active transmission gap pattern sequences create transmission gaps in the same frame. An illegal overlap is created if two or more transmission gap pattern sequences create transmission gaps in the same frame, irrespective of the gaps are created in uplink or downlink.

If the parallel transmission gap pattern sequences create an illegal overlap, the UE shall:

1> delete the overlapping transmission gap pattern sequence configuration stored in the variable TGPS_IDENTITY, which is associated with the highest value of IE "TGPSI";

1> transmit a PHYSICAL CHANNEL RECONFIGURATION FAILURE message on the DCCH using AM RLC, setting the information elements as specified below:

2> not include the IE "RRC transaction identifier";

2> set the cause value in IE "failure cause" to value "compressed mode runtime error".

1> terminate the inter-frequency and/or inter-RAT measurements corresponding to the deleted transmission gap pattern sequence;

1> when the PHYSICAL CHANNEL RECONFIGURATION FAILURE message has been submitted to lower layers for transmission:

2> the procedure ends.

### 8.2.11.3 Void

# 8.3 RRC connection mobility procedures

## 8.3.1 Cell and URA update procedures




**Figure 8.3.1-1: Cell update procedure, basic flow**




**Figure 8.3.1-2: Cell update procedure with update of UTRAN mobility information**




**Figure 8.3.1-3: Cell update procedure with physical channel reconfiguration**




**Figure 8.3.1-4: Cell update procedure with transport channel reconfiguration**




**Figure 8.3.1-5: Cell update procedure with radio bearer release**




**Figure 8.3.1-6: Cell update procedure with radio bearer reconfiguration**




**Figure 8.3.1-7: Cell update procedure, failure case**




**Figure 8.3.1-8: URA update procedure, basic flow**




**Figure 8.3.1-9: URA update procedure with update of UTRAN mobility information**




**Figure 8.3.1-10: URA update procedure, failure case**

### 8.3.1.1 General

The URA update and cell update procedures serve several main purposes:

- to notify UTRAN after re-entering service area in the URA_PCH or CELL_PCH state;
- to notify UTRAN of an RLC unrecoverable error [16] on an AM RLC entity;
- to be used as a supervision mechanism in the CELL_FACH, CELL_PCH, or URA_PCH state by means of periodical update.

In addition, the URA update procedure also serves the following purpose:

- to retrieve a new URA identity after cell re-selection to a cell not belonging to the current URA assigned to the UE in URA_PCH state.

In addition, the cell update procedure also serves the following purposes:

- to update UTRAN with the current cell the UE is camping on after cell reselection;
- to act on a radio link failure in the CELL_DCH state;
- to act on the transmission failure of the UE CAPABILITY INFORMATION message;
- when triggered in the URA_PCH or CELL_PCH state, to notify UTRAN of a transition to the CELL_FACH state due to the reception of UTRAN originated paging or due to a request to transmit uplink data;
- to count the number of UEs in URA_PCH , CELL_PCH and CELL_FACH that are interested to receive an MBMS transmission;
- when triggered in the URA_PCH , CELL_PCH and CELL_FACH state, to notify UTRAN of the UEs interest to receive an MBMS service;
- to request the MBMS P-T-P RB setup by the UE in CELL_PCH or URA_PCH state.

The URA update and cell update procedures may:

1> include an update of mobility related information in the UE;

1> cause a state transition from the CELL_FACH state to the CELL_DCH, CELL_PCH or URA_PCH states or idle mode.

The cell update procedure may also include:

- a re-establish of AM RLC entities;
- a radio bearer release, radio bearer reconfiguration, transport channel reconfiguration or physical channel reconfiguration.

#### 8.3.1.2 Initiation

A UE shall initiate the cell update procedure in the following cases:

1> Uplink data transmission:

2> if the UE is in URA_PCH or CELL_PCH state; and

2> if the UE has uplink RLC data PDU or uplink RLC control PDU on RB1 or upwards to transmit:

3> perform cell update using the cause "uplink data transmission".

1> Paging response:

2> if the criteria for performing cell update with the cause specified above in the current subclause are not met; and

2> if the UE in URA_PCH or CELL_PCH state, receives a PAGING TYPE 1 message fulfilling the conditions for initiating a cell update procedure specified in subclause 8.1.2.3:

3> perform cell update using the cause "paging response".

1> Radio link failure:

2> if none of the criteria for performing cell update with the causes specified above in the current subclause is met:

3> if the UE is in CELL_DCH state and the criteria for radio link failure are met as specified in subclause 8.5.6; or

3> if the transmission of the UE CAPABILITY INFORMATION message fails as specified in subclause 8.1.6.6:

4> perform cell update using the cause "radio link failure".

1> Re-entering service area:

2> if none of the criteria for performing cell update with the causes specified above in the current subclause is met; and

2> if the UE is in CELL_FACH or CELL_PCH state; and

2> if the UE has been out of service area and re-enters service area before T307 or T317 expires:

3> perform cell update using the cause "re-entering service area".

1> RLC unrecoverable error:

2> if none of the criteria for performing cell update with the causes specified above in the current subclause is met; and

2> if the UE detects RLC unrecoverable error [16] in an AM RLC entity:

3> perform cell update using the cause "RLC unrecoverable error".

1> Cell reselection:

2> if none of the criteria for performing cell update with the causes specified above in the current subclause is met:

3> if the UE is in CELL_FACH or CELL_PCH state and the UE performs cell re-selection; or

3> if the UE is in CELL_FACH state and the variable C_RNTI is empty:

4> perform cell update using the cause "cell reselection".

1> Periodical cell update:

2> if none of the criteria for performing cell update with the causes specified above in the current subclause is met; and

2> if the UE is in CELL_FACH or CELL_PCH state; and

2> if the timer T305 expires; and

2> if the criteria for "in service area" as specified in subclause 8.5.5.2 are fulfilled; and

2> if periodic updating has been configured by T305 in the IE "UE Timers and constants in connected mode" set to any other value than "infinity":

3> perform cell update using the cause "periodical cell update".

1> MBMS reception:

2> if the UE is in URA_PCH, Cell_PCH or Cell_FACH state; and

2> if the UE should perform cell update for MBMS counting as specified in subclause 8.7.4:

3> perform cell update using the cause "MBMS reception".

1> MBMS ptp RB request:

2> if the UE is in URA_PCH or Cell_PCH state; and

2> if the UE should perform cell update for MBMS ptp radio bearer request as specified in 8.6.9.6 :

3> perform cell update using the cause "MBMS ptp RB request".

A UE in URA_PCH state shall initiate the URA update procedure in the following cases:

1> URA reselection:

2> if the UE detects that the current URA assigned to the UE, stored in the variable URA_IDENTITY, is not present in the list of URA identities in system information block type 2; or

2> if the list of URA identities in system information block type 2 is empty; or

2> if the system information block type 2 can not be found:

3> perform URA update using the cause "change of URA".

1> Periodic URA update:

2> if the criteria for performing URA update with the causes as specified above in the current subclause are not met; and

2> if the timer T305 expires; and

2> if periodic updating has been configured by T305 in the IE "UE Timers and constants in connected mode" set to any other value than "infinity":

3> perform URA update using the cause "periodic URA update".

When initiating the URA update or cell update procedure, the UE shall:

1> stop timer T305;

1> if the UE is in CELL_DCH state:

2> in the variable RB_TIMER_INDICATOR, set the IE "T314 expired" and the IE "T315 expired" to FALSE;

2> if the stored values of the timer T314 and timer T315 are both equal to zero; or

2> if the stored value of the timer T314 is equal to zero and there are no radio bearers associated with any radio access bearers for which in the variable ESTABLISHED_RABS the value of the IE "Re-establishment timer" is set to "useT315":

3> release all its radio resources;

3> indicate release (abort) of the established signalling connections (as stored in the variable ESTABLISHED_SIGNALLING_CONNECTIONS) and established radio access bearers (as stored in the variable ESTABLISHED_RABS) to upper layers;

3> clear the variable ESTABLISHED_SIGNALLING_CONNECTIONS;

3> clear the variable ESTABLISHED_RABS;

3> enter idle mode;

3> perform other actions when entering idle mode from connected mode as specified in subclause 8.5.2;

3> and the procedure ends.

2> if the stored value of the timer T314 is equal to zero:

3> release all radio bearers, associated with any radio access bearers for which in the variable ESTABLISHED_RABS the value of the IE "Re-establishment timer" is set to "useT314";

3> in the variable RB_TIMER_INDICATOR set the IE "T314 expired" to TRUE.

2> if the stored value of the timer T315 is equal to zero:

3> release all radio bearers associated with any radio access bearers for which in the variable ESTABLISHED_RABS the value of the IE "Re-establishment timer" is set to "useT315";

3> in the variable RB_TIMER_INDICATOR set the IE "T315 expired" to TRUE.

2> if the stored value of the timer T314 is greater than zero:

3> if there are radio bearers associated with any radio access bearers for which in the variable ESTABLISHED_RABS the value of the IE "Re-establishment timer" is set to "useT314":

4> start timer T314.

3> if there are no radio bearers associated with any radio access bearers for which in the variable ESTABLISHED_RABS the value of the IE "Re-establishment timer" is set to "useT314" or "useT315":

4> start timer T314.

2> if the stored value of the timer T315 is greater than zero:

3> if there are radio bearers associated with any radio access bearers for which in the variable ESTABLISHED_RABS the value of the IE "Re-establishment timer" is set to "useT315":

4> start timer T315.

2> for the released radio bearer(s):

3> delete the information about the radio bearer from the variable ESTABLISHED_RABS;

3> when all radio bearers belonging to the same radio access bearer have been released:

4> indicate local end release of the radio access bearer to upper layers using the CN domain identity together with the RAB identity stored in the variable ESTABLISHED_RABS;

4> delete all information about the radio access bearer from the variable ESTABLISHED_RABS.

2> move to CELL_FACH state;

2> select a suitable UTRA cell on the current frequency according to [4];

2> select PRACH according to subclause 8.5.17;

2> select Secondary CCPCH according to subclause 8.5.19;

2> use the transport format set given in system information as specified in subclause 8.6.5.1;

2> set the variable ORDERED_RECONFIGURATION to FALSE.

1> set the variables PROTOCOL_ERROR_INDICATOR, FAILURE_INDICATOR, UNSUPPORTED_CONFIGURATION and INVALID_CONFIGURATION to FALSE;

1> set the variable CELL_UPDATE_STARTED to TRUE;

1> if any IEs releated to HS-DSCHare stored in the UE:

2> clear any stored IE "Downlink HS-PDSCH information";

2> determine the value for the HS_DSCH_RECEPTION variable and take the corresponding actions as described in subclause 8.5.25.

1> if any IEs related to E-DCHare stored in the UE:

2> clear any stored IE "E-DCH info";

2> determine the value for the E_DCH_TRANSMISSION variable and take the corresponding actions as described in subclause 8.5.28.

1> if the UE is not already in CELL_FACH state:

2> move to CELL_FACH state;

2> select PRACH according to subclause 8.5.17;

2> select Secondary CCPCH according to subclause 8.5.19;

2> use the transport format set given in system information as specified in subclause 8.6.5.1.

1> if the UE performs cell re-selection:

2> clear the variable C_RNTI; and

2> stop using that C_RNTI just cleared from the variable C_RNTI in MAC.

1> set CFN in relation to SFN of current cell according to subclause 8.5.15;

1> in case of a cell update procedure:

2> set the contents of the CELL UPDATE message according to subclause 8.3.1.3;

2> submit the CELL UPDATE message for transmission on the uplink CCCH.

1> in case of a URA update procedure:

2> set the contents of the URA UPDATE message according to subclause 8.3.1.3;

2> submit the URA UPDATE message for transmission on the uplink CCCH.

1> set counter V302 to 1;

1> start timer T302 when the MAC layer indicates success or failure in transmitting the message.

### 8.3.1.3 CELL UPDATE / URA UPDATE message contents to set

In case of cell update procedure the UE shall transmit a CELL UPDATE message.

In case of URA update procedure the UE shall transmit a URA UPDATE message.

The UE shall set the IEs in the CELL UPDATE message as follows:

1> set the IE "Cell update cause" corresponding to the cause specified in subclause 8.3.1.2 that is valid when the CELL UPDATE message is submitted to lower layers for transmission;

NOTE: During the time period starting from when a cell update procedure is initiated by the UE until when the procedure ends, additional CELL UPDATE messages may be transmitted by the UE with different causes.

1> if the IE "Cell update cause" is set to "uplink data transmission" and if an event triggered traffic volume measurement has been configured:

2> if the TCTV is larger than the threshold in the IE "Reporting threshold" for a traffic volume measurement stored in the MEASUREMENT_IDENTITY variable and that traffic volume measurement has "measurement identity" equal to 4, "Traffic volume event identity" equal to "4a", "Measurement validity" equal to "all states" or "all states except CELL_DCH":

3> set the IE "Traffic volume indicator" to TRUE.

2> else:

3> set the IE "Traffic volume indicator" to FALSE.

1> set the IE "U-RNTI" to the value of the variable U_RNTI;

1> if the value of the variable PROTOCOL_ERROR_INDICATOR is TRUE:

2> include the IE "RRC transaction identifier"; and

3> set it to the value of "RRC transaction identifier" in the entry for the CELL UPDATE CONFIRM message in the table "Rejected transactions" in the variable TRANSACTIONS.

2> include and set the IE "failure cause" to the cause value "protocol error";

2> set the IE "Protocol error information" set to the value of the variable PROTOCOL_ERROR_INFORMATION.

1> if the value of the variable FAILURE_INDICATOR is TRUE:

2> include the IE "RRC transaction identifier"; and

3> set it to the value of "RRC transaction identifier" in the entry for the CELL UPDATE CONFIRM message in the table "Accepted transactions" in the variable TRANSACTIONS.

2> include and set the IE "failure cause" to the value of the variable FAILURE_CAUSE.

1> for each CN domain for which an entry exists in the variable ESTABLISHED_SIGNALLING_CONNECTIONS or which is indicated in the variable "LATEST CONFIGURED CN DOMAIN":

2> include the START value calculated according to subclause 8.5.9.

1> if an unrecoverable error [16] in any of the AM RLC entities for the signalling radio bearers RB2, RB3 or RB4 is detected:

2> set the IE "AM_RLC error indication (RB2, RB3 or RB4)" to TRUE;

2> set the variable AM_RLC_ERROR_PENDING_RB234 to TRUE.

1> otherwise:

2> if the value of the variable AM_RLC_ERROR_PENDING_RB234 is TRUE:

3> set the IE "AM_RLC error indication (RB2, RB3 or RB4)" to TRUE.

2> otherwise:

3> set the IE "AM_RLC error indication (RB2, RB3 or RB4)" to FALSE.

1> if an unrecoverable error [16] in any of the AM RLC entities for the RB5 or upward is detected:

2> set the IE "AM_RLC error indication (RB>4)" to TRUE;

2> set the variable AM_RLC_ERROR_PENDING_RB5_AND_UP to TRUE.

1> otherwise:

2> if the value of the variable AM_RLC_ERROR_PENDING_RB5_AND_UP is TRUE:

3> set the IE "AM_RLC error indication (RB>4)" to TRUE.

2> otherwise:

3> set the IE "AM_RLC error indication (RB>4)" to FALSE.

1> set the IE "RB Timer indicator" to the value of the variable RB_TIMER_INDICATOR;

1> if the variable ESTABLISHMENT_CAUSE is initialised:

2> include the IE "Establishment cause" and set it to the value of the variable ESTABLISHMENT_CAUSE.

1> if the variable ORDERED_RECONFIGURATION is set to TRUE:

2> include the IE "Reconfiguration Status Indicator" and set it to TRUE.

1> if the IE "Cell update cause" is set to "radio link failure" and the UE has submitted a reconfiguration response message to RLC and the UE has not received the RLC acknowledgement for the response message:

2> include the IE "Reconfiguration Status Indicator" and set it to TRUE.

The UE shall set the IEs in the URA UPDATE message as follows:

1> set the IE "U-RNTI" to the value of the variable U_RNTI;

1> set the IE "URA update cause" corresponding to which cause as specified in subclause 8.3.1.2 that is valid when the URA UPDATE message is submitted to lower layers for transmission;

NOTE: During the time period starting from when a URA update procedure is initiated by the UE until when the procedure ends, additional URA UPDATE messages may be transmitted by the UE with different causes, depending on which causes are valid for the respective URA UPDATE message.

1> if the value of the variable PROTOCOL_ERROR_INDICATOR is TRUE:

2 > include the IE "RRC transaction identifier"; and

3> set it to the value of "RRC transaction identifier" in the entry for the URA UPDATE CONFIRM message in the table "Rejected transactions" in the variable TRANSACTIONS.

2> set the IE "Protocol error indicator" to TRUE;

2> include the IE "Protocol error information" set to the value of the variable PROTOCOL_ERROR_INFORMATION.

1> if the value of the variable PROTOCOL_ERROR_INDICATOR is FALSE:

2> if the value of the variable INVALID_CONFIGURATION is TRUE:

3> include the IE "RRC transaction identifier"; and

3> set it to the value of "RRC transaction identifier" in the entry for the URA UPDATE CONFIRM message in the table "Accepted transactions" in the variable TRANSACTIONS;

3> set the IE "Protocol error indicator" to TRUE;

3> include the IE "Protocol error information" set to "Information element value not comprehended".

2> if the value of the variable INVALID_CONFIGURATION is FALSE:

3> set the IE "Protocol error indicator" to FALSE.

#### 8.3.1.4 T305 expiry and the UE detects "out of service area"

When the T305 expires and the UE detects that it is "out of service area" as specified in subclause 8.5.5.1, the UE shall

1> start timer T307;

1> act according to subclause 7.2.2.

##### 8.3.1.4.1 Re-entering "in service area"

If the UE detects "in service area" according to subclause 8.5.5.2 and timer T307 or T317 is running, the UE shall:

1> check the value of V302; and

1> if V302 is equal to or smaller than N302:

2> in case of a cell update procedure:

3> set the contents of the CELL UPDATE message according to subclause 8.3.1.3;

3> submit the CELL UPDATE message for transmission on the uplink CCCH.

2> in case of a URA update procedure:

3> set the contents of the URA UPDATE message according to subclause 8.3.1.3;

3> submit the URA UPDATE message for transmission on the uplink CCCH.

2> increment counter V302;

2> restart timer T302 when the MAC layer indicates success or failure to transmit the message.

1> if V302 is greater than N302:

2> clear the variable RB_UPLINK_CIPHERING_ACTIVATION_TIME_INFO;

2> clear the variable INTEGRITY_PROTECTION_ACTIVATION_INFO;

2> in case of a cell update procedure:

3> clear the entry for the CELL UPDATE CONFIRM message in the table "Rejected transactions" in the variable TRANSACTIONS.

2> in case of a URA update procedure:

3> clear the entry for the URA UPDATE CONFIRM message in the table "Rejected transactions" in the variable TRANSACTIONS.

2> release all its radio resources;

2> indicate release (abort) of the established signalling connections (as stored in the variable ESTABLISHED_SIGNALLING_CONNECTIONS) and established radio access bearers (as stored in the variable ESTABLISHED_RABS) to upper layers;

2> clear the variable ESTABLISHED_SIGNALLING_CONNECTIONS;

2> clear the variable ESTABLISHED_RABS;

2> enter idle mode;

2> perform other actions when entering idle mode from connected mode as specified in subclause 8.5.2;

2> and the procedure ends.

#### 8.3.1.4.2 Expiry of timer T307

When the T307 expires, the UE shall:

1> move to idle mode;

1> release all dedicated resources;

1> indicate release (abort) of the established signalling connections (as stored in the variable ESTABLISHED_SIGNALLING_CONNECTIONS) and established radio access bearers (as stored in the variable ESTABLISHED_RABS) to upper layers;

1> clear the variable ESTABLISHED_SIGNALLING_CONNECTIONS;

1> clear the variable ESTABLISHED_RABS;

1> perform other actions when entering idle mode from connected mode as specified in subclause 8.5.2;

1> and the procedure ends.

### 8.3.1.5 Reception of an CELL UPDATE/URA UPDATE message by the UTRAN

When the UTRAN receives a CELL UPDATE/URA UPDATE message, the UTRAN should:

1> in case the procedure was triggered by reception of a CELL UPDATE:

2> if SRNS relocation was performed:

3> transmit a CELL UPDATE CONFIRM message on the downlink DCCH.

2> otherwise:

3> update the START value for each CN domain as maintained in UTRAN (refer to subclause 8.5.9) with "START" in the IE "START list" for the CN domain as indicated by "CN domain identity" in the IE "START list";

3> transmit a CELL UPDATE CONFIRM message on the downlink DCCH or optionally on the CCCH but only if ciphering is not required; and

3> optionally set the IE "RLC re-establish indicator (RB2, RB3 and RB4)" and/or the IE "RLC re-establish indicator (RB5 and upwards)" to TRUE to request a RLC re-establishment in the UE, in which case the corresponding RLC entities should also be re-established in UTRAN; or

1> in case the procedure was triggered by reception of a URA UPDATE:

2> if SRNS relocation was performed:

3> transmit a URA UPDATE CONFIRM message on the downlink DCCH.

2> otherwise:

3> transmit a URA UPDATE CONFIRM message on the downlink CCCH or DCCH.

2> include the IE "URA identity" in the URA UPDATE CONFIRM message in a cell where multiple URA identifiers are broadcast; or

1> initiate an RRC connection release procedure (see subclause 8.1.4) by transmitting an RRC CONNECTION RELEASE message on the downlink CCCH. In particular UTRAN should:

2> if the CELL UPDATE message was sent because of an unrecoverable error in RB2, RB3 or RB4:

3> initiate an RRC connection release procedure (subclause 8.1.4) by transmitting an RRC CONNECTION RELEASE message on the downlink CCCH.

UTRAN may transmit several CELL UPDATE CONFIRM/URA UPDATE CONFIRM messages to increase the probability of proper reception of the message by the UE. In such a case, the RRC SN for these repeated messages should be the same.

#### 8.3.1.6 Reception of the CELL UPDATE CONFIRM/URA UPDATE CONFIRM message by the UE

When the UE receives a CELL UPDATE CONFIRM/URA UPDATE CONFIRM message; and

- if the message is received on the CCCH, and IE "U-RNTI" is present and has the same value as the variable U_RNTI; or
- if the message is received on DCCH:

the UE may:

1> maintain a list of the set of cells to which the UE has Radio Links if the IE "Cell ID" is present.

the UE shall:

1> stop timer T302;

1> in case of a cell update procedure and the CELL UPDATE CONFIRM message:

2> includes "RB information elements"; and/or

2> includes "Transport channel information elements"; and/or

2> includes "Physical channel information elements"; and

2> if the variable ORDERED_RECONFIGURATION is set to FALSE:

3> set the variable ORDERED_RECONFIGURATION to TRUE.

1> act upon all received information elements as specified in subclause 8.6, unless specified otherwise in the following:

2> if the IE "Frequency info" is included in the message:

3> if the IE "RRC State Indicator" is set to the value "CELL_FACH" or "CELL_PCH" or URA_PCH":

4> select a suitable UTRA cell according to [4] on that frequency;

4> if the UE finds a suitable UTRA cell on that frequency:

5> if the received CELL UPDATE CONFIRM message included the IE "Primary CPICH info" (for FDD) or "Primary CCPCH info" (for TDD), and the UE selects another cell than indicated by this IE or the received CELL UPDATE CONFIRM message did not include the IE "Primary CPICH info" (for FDD) or "Primary CCPCH info" (for TDD):

6> act as specified in subclause 8.3.1.12.

4> else, if the UE can not find a suitable UTRA cell on the indicated frequency but it finds a suitable UTRA cell on another frequency:

5> act as specified in subclause 8.3.1.12.

3> if the IE "RRC State Indicator" is set to the value "CELL_DCH":

4> act on the IE "Frequency info" as specified in subclause 8.6.6.1.

2> use the transport channel(s) applicable for the physical channel types that is used; and

2> if the IE "TFS" is neither included nor previously stored in the UE for that transport channel(s):

3> use the TFS given in system information.

2> if none of the TFS stored is compatible with the physical channel:

3> delete the stored TFS;

3> use the TFS given in system information.

2> if the IE "RLC re-establish indicator (RB2, RB3 and RB4)" in the CELL UPDATE CONFIRM message is set to TRUE:

3> re-establish the RLC entities for signalling radio bearer RB2, signalling radio bearer RB3 and signalling radio bearer RB4 (if established);

3> if the value of the IE "Status" in the variable CIPHERING_STATUS of the CN domain stored in the variable LATEST_CONFIGURED_CN_DOMAIN is set to "Started":

4> set the HFN component of the respective COUNT-C values for AM RLC entities with RB identity 2,RB identity 3 and RB identity 4 (if established) equal to the START value included in the latest transmitted CELL UPDATE message for the CN domain stored in the variable LATEST_CONFIGURED_CN_DOMAIN.

2> if the IE "RLC re-establish indicator (RB5 and upwards)" in the CELL UPDATE CONFIRM message is set to TRUE:

3> for radio bearers with RB identity 5 and upwards:

4> re-establish the AM RLC entities;

4> if the value of the IE "Status" in the variable CIPHERING_STATUS of the CN domain as indicated in the IE "CN domain identity" in the IE "RAB info" in the variable ESTABLISHED_RABS is set to "Started":

5> set the HFN component of the respective COUNT-C values for AM RLC entities equal to the START value included in this CELL UPDATE message for the CN domain as indicated in the IE "CN domain identity" in the IE "RAB info" in the variable ESTABLISHED_RABS.

NOTE: UE actions, in case IE "Downlink counter synchronisation info" is included and either IE "RLC re-establish indicator (RB2, RB3 and RB4)" or IE "RLC re-establish indicator (RB5 and upwards)" are set to TRUE, are not defined.

1> if the CELL UPDATE CONFIRM / URA UPDATE CONFIRM message contained the IE "Ciphering mode info" or contained the IE "Integrity protection mode info":

2> set the IE "Status" in the variable SECURITY_MODIFICATION for all the CN domains in the variable SECURITY_MODIFICATION to "Affected".

1> if the variable ESTABLISHMENT_CAUSE is set:

2> clear the variable ESTABLISHMENT_CAUSE.

1> enter a state according to subclause 8.6.3.3 applied on the CELL UPDATE CONFIRM / URA UPDATE CONFIRM message.

If the UE after state transition enters CELL_DCH state, it shall:

1> perform the physical layer synchronisation procedure A as specified in [29] (FDD only);

1> not prohibit periodical status transmission in RLC.

If the UE after state transition remains in CELL_FACH state, it shall

1> start the timer T305 using its initial value if timer T305 is not running and periodical cell update has been configured by T305 in the IE "UE Timers and constants in connected mode" set to any other value than "infinity";

1> select PRACH according to subclause 8.5.17;

1> select Secondary CCPCH according to subclause 8.5.19;

1> not prohibit periodical status transmission in RLC;

1> if the IE "UTRAN DRX cycle length coefficient" is included in the same message:

2> ignore that IE and stop using DRX.

If the UE after state transition enters URA_PCH or CELL_PCH state, it shall:

1> prohibit periodical status transmission in RLC;

1> clear the variable C_RNTI;

1> stop using that C_RNTI just cleared from the variable C_RNTI in MAC;

1> start the timer T305 using its initial value if timer T305 is not running and periodical update has been configured by T305 in the IE "UE Timers and constants in connected mode" set to any other value than "infinity";

1> select Secondary CCPCH according to subclause 8.5.19;

1> if the IE "UTRAN DRX cycle length coefficient" is included in the same message:

2> use the value in the IE "UTRAN DRX Cycle length coefficient" for calculating Paging Occasion and PICH Monitoring Occasion as specified in subclause 8.6.3.2.

NOTE: In the case of a cell update procedure during an ongoing reconfiguration procedure moving the UE into CELL_PCH/URA_PCH then the value of the IE "UTRAN DRX Cycle length coefficient" sent in the CELL UPDATE CONFIRM message should be the same as the value sent in the reconfiguration message.

1> if the IE "UTRAN DRX cycle length coefficient" is not included in the same message:

2> set the variable INVALID_CONFIGURATION to TRUE.

If the UE after the state transition remains in CELL_FACH state; and

1> the contents of the variable C_RNTI are empty:

it shall check the value of V302; and:

1> if V302 is equal to or smaller than N302:

2> if, caused by the received CELL UPDATE CONFIRM or URA UPDATE CONFIRM message:

3> the IE "Reconfiguration" in the variable CIPHERING_STATUS is set to TRUE; and/or

3> the IE "Reconfiguration" in the variable INTEGRITY_PROTECTION_INFO is set to TRUE:

4> abort the ongoing integrity and/or ciphering reconfiguration;

4> if the received CELL UPDATE CONFIRM or URA UPDATE CONFIRM message contained the IE "Ciphering mode info":

5> set the IE "Reconfiguration" in the variable CIPHERING_STATUS to FALSE; and

5> clear the variable RB_UPLINK_CIPHERING_ACTIVATION_TIME_INFO.

4> if the received CELL UPDATE CONFIRM or URA UPDATE CONFIRM message contained the IE "Integrity protection mode info":

5> set the IE "Reconfiguration" in the variable INTEGRITY_PROTECTION_INFO to FALSE; and

5> clear the variable INTEGRITY_PROTECTION_ACTIVATION_INFO.

2> in case of a URA update procedure:

3> stop the URA update procedure;

3> clear any entry for the URA UPDATE CONFIRM message in the table "Accepted transactions" in the variable TRANSACTIONS; and

3> continue with a cell update procedure.

2> set the contents of the CELL UPDATE message according to subclause 8.3.1.3, except for the IE "Cell update cause" which shall be set to "cell reselection";

2> submit the CELL UPDATE message for transmission on the uplink CCCH;

2> increment counter V302;

2> restart timer T302 when the MAC layer indicates success or failure to transmit the message.

1> if V302 is greater than N302:

2> clear the variable RB_UPLINK_CIPHERING_ACTIVATION_TIME_INFO;

2> clear the variable INTEGRITY_PROTECTION_ACTIVATION_INFO;

2> in case of a cell update procedure:

3> clear the entry for the CELL UPDATE CONFIRM message in the table "Rejected transactions" in the variable TRANSACTIONS.

2> in case of a URA update procedure:

3> clear the entry for the URA UPDATE CONFIRM message in the table "Rejected transactions" in the variable TRANSACTIONS.

2> release all its radio resources;

2> indicate release (abort) of the established signalling connections (as stored in the variable ESTABLISHED_SIGNALLING_CONNECTIONS) and established radio access bearers (as stored in the variable ESTABLISHED_RABS) to upper layers;

2> clear the variable ESTABLISHED_SIGNALLING_CONNECTIONS;

2> clear the variable ESTABLISHED_RABS;

2> enter idle mode;

2> other actions the UE shall perform when entering idle mode from connected mode are specified in subclause 8.5.2;

2> and the procedure ends.

If the UE after the state transition remains in CELL_FACH state; and

- a C-RNTI is stored in the variable C_RNTI;

or

- the UE after the state transition moves to another state than the CELL_FACH state:

the UE shall:

1> in case cell reselection interrupted an ongoing cell update procedure and a CELL UPDATE CONFIRM/URA UPDATE CONFIRM was received with the IE "Downlink counter synchronisation info" present and the response to which was not submitted to the lower layers due to the cell re-selection:

2> include the IE "START list" in the response message transmitted according to subclause 8.3.1.7;

2> if the CELL UPDATE CONFIRM/URA UPDATE CONFIRM, the response to which was not delivered to the lower layers, due to the cell re-selection, included the IE "RB with PDCP information list":

3> include the IE "RB with PDCP information list" in the response message transmitted according to subclause 8.3.1.7.

1> in case of a cell update procedure:

2> set the IE "RRC transaction identifier" in any response message transmitted below to the value of "RRC transaction identifier" in the entry for the CELL UPDATE CONFIRM message in the table "Accepted transactions" in the variable TRANSACTIONS; and

2> clear that entry.

1> in case of a URA update procedure:

2> set the IE "RRC transaction identifier" in any response message transmitted below to the value of "RRC transaction identifier" in the entry for the URA UPDATE CONFIRM message in the table "Accepted transactions" in the variable TRANSACTIONS; and

2> clear that entry;

1> if the variable PDCP_SN_INFO is non-empty:

2> include the IE "RB with PDCP information list" in any response message transmitted below and set it to the value of the variable PDCP_SN_INFO.

1> if the received CELL UPDATE CONFIRM or URA UPDATE CONFIRM message included the IE "Downlink counter synchronisation info":

2> if the variable PDCP_SN_INFO is empty:

3> configure the corresponding RLC entity for all AM and UM radio bearers and AM and UM signalling radio bearers except RB2 to "stop".

2> else:

3> configure the RLC entity for signalling radio bearers RB1, RB3 and RB4 to "stop";

3> configure the RLC entity for UM and AM radio bearers for which the IE "PDCP SN Info" is not included to "stop".

2> re-establish the RLC entity for RB2;

2> for the downlink and the uplink, apply the ciphering configuration as follows:

3> if the received re-configuation message included the IE "Ciphering Mode Info":

4> use the ciphering configuration in the received message when transmitting the response message.

3> if the ciphering configuration for RB2 from a previously received SECURITY MODE COMMAND has not yet been applied because the activation times not having been reached:

4> if the previous SECURITY MODE COMMAND was received due to new keys being received:

5> consider the new ciphering configuration to include the received new keys;

5> initialise the HFN component of the uplink COUNT-C and downlink COUNT-C of SRB2 as indicated in subclause 8.1.12.3.1.

4> if the ciphering configuration for RB2 from a previously received SECURITY MODE COMMAND has not yet been applied because of the corresponding activation times not having been reached and the previous SECURITY MODE COMMAND caused a change in LATEST_CONFIGURED_CN_DOMAIN:

5> consider the new ciphering configuration to include the keys associated with the LATEST_CONFIGURED_CN_DOMAIN;

5> initialise the HFN component of the uplink COUNT-C and downlink COUNT-C of SRB2 to the most recently transmitted IE "START list" or IE "START" for the LATEST_CONFIGURED_CN_DOMAIN at the reception of the previous SECURITY MODE COMMAND.

4> apply the new ciphering configuration immediately following RLC re-establishment.

3> else:

4> continue using the current ciphering configuration.

2> set the new uplink and downlink HFN component of the COUNT-C of RB2 to MAX(uplink HFN component of the COUNT-C of RB2, downlink HFN component of the COUNT-C of RB2);

2> increment by one the downlink and uplink values of the HFN component of the COUNT-C for RB2;

2> calculate the START value according to subclause 8.5.9;

2> include the calculated START values for each CN domain in the IE "START list" in the IE "Uplink counter synchronisation info" in any response message transmitted below.

1> transmit a response message as specified in subclause 8.3.1.7;

1> if the IE "Integrity protection mode info" was present in the CELL UPDATE CONFIRM or URA UPDATE CONFIRM message:

2> start applying the new integrity protection configuration in the uplink for signalling radio bearer RB2 from and including the transmitted response message.

1> if the variable ORDERED_RECONFIGURATION is set to TRUE caused by the received CELL UPDATE CONFIRM message in case of a cell update procedure:

2> set the variable ORDERED_RECONFIGURATION to FALSE.

1> clear the variable PDCP_SN_INFO;

1> when the response message transmitted per subclause 8.3.1.7 to the UTRAN has been confirmed by RLC:

2> if the CELL UPDATE CONFIRM / URA UPDATE CONFIRM message contained the IE "Ciphering mode info":

3> resume data transmission on any suspended radio bearer and signalling radio bearer mapped on RLC-AM or RLC-UM;

3> set the IE "Reconfiguration" in the variable CIPHERING_STATUS to FALSE; and

3> clear the variable RB_UPLINK_CIPHERING_ACTIVATION_TIME_INFO.

2> if the CELL UPDATE CONFIRM / URA UPDATE CONFIRM message contained the IE "Integrity protection mode info":

3> set "Uplink RRC Message sequence number" for signalling radio bearer RB0 in the variable INTEGRITY_PROTECTION_INFO to a value such that next RRC message to be sent on uplink RB0 will use the new integrity protection configuration;

3> allow the transmission of RRC messages on all signalling radio bearers with any RRC SN;

3> set the IE "Reconfiguration" in the variable INTEGRITY_PROTECTION_INFO to FALSE.

2> clear the variable INTEGRITY_PROTECTION_ACTIVATION_INFO.

1> in case of a cell update procedure:

2> clear the entry for the CELL UPDATE CONFIRM message in the table "Rejected transactions" in the variable TRANSACTIONS.

1> in case of a URA update procedure:

2> clear the entry for the URA UPDATE CONFIRM message in the table "Rejected transactions" in the variable TRANSACTIONS.

1> set the variable CELL_UPDATE_STARTED to FALSE;

1> if the variable AM_RLC_ERROR_PENDING_RB234 is set to TRUE:

2> set the variable AM_RLC_ERROR_PENDING_RB234 to FALSE.

1> if the variable AM_RLC_ERROR_PENDING_RB5_AND_UP is set to TRUE:

2> set the variable AM_RLC_ERROR_PENDING_RB5_AND_UP to FALSE.

1> clear the variable SECURITY_MODIFICATION.

1> stop timers T314 and/or T315 if they are running.

The procedure ends.

### 8.3.1.7 Transmission of a response message to UTRAN

If the CELL UPDATE CONFIRM message:

- includes the IE "RB information to release list":

the UE shall:

1> transmit a RADIO BEARER RELEASE COMPLETE as response message using AM RLC.

If the CELL UPDATE CONFIRM message:

- does not include the IE "RB information to release list"; and
- includes the IE "RB information to reconfigure list"; or
- includes the IE "RB information to be affected list":

the UE shall:

1> transmit a RADIO BEARER RECONFIGURATION COMPLETE as response message using AM RLC.

If the CELL UPDATE CONFIRM message:

- does not include the IE "RB information to release list", nor the IE "RB information to reconfigure list", nor the IE "RB information to be affected list"; and
- includes "Transport channel information elements":

the UE shall:

1> transmit a TRANSPORT CHANNEL RECONFIGURATION COMPLETE as response message using AM RLC.

If the CELL UPDATE CONFIRM message:

- does not include the IE "RB information to release list", nor the IE "RB information to reconfigure list", nor the IE "RB information to be affected list"; and
- does not include "Transport channel information elements"; and
- includes "Physical channel information elements":

the UE shall:

1> transmit a PHYSICAL CHANNEL RECONFIGURATION COMPLETE as response message using AM RLC.

If the CELL UPDATE CONFIRM message:

- does not include the IE "RB information to release list", nor the IE "RB information to reconfigure list", nor the IE "RB information to be affected list"; and
- does not include "Transport channel information elements"; and

- does not include "Physical channel information elements"; and
- includes "CN information elements"; or
- includes the IE "Ciphering mode info"; or
- includes the IE "Integrity protection mode info"; or
- includes the IE "New C-RNTI"; or
- includes the IE "New U-RNTI"; or
- includes the IE "Downlink counter synchronisation info" and the IE "New U-RNTI":

NOTE: In the case of a cell update procedure during an ongoing reconfiguration procedure moving the UE into CELL_PCH/URA_PCH the CELL UPDATE CONFIRM message should include the IE "New C-RNTI".

the UE shall:

1> transmit a UTRAN MOBILITY INFORMATION CONFIRM as response message using AM RLC.

If the CELL UPDATE CONFIRM message:

- does not include "RB information elements"; and
- does not include "Transport channel information elements"; and
- does not include "Physical channel information elements"; and
- does not include "CN information elements"; and
- does not include the IE "Ciphering mode info"; and
- does not include the IE "Integrity protection mode info"; and
- does not include the IE "New C-RNTI"; and
- does not include the IE "New U-RNTI":

the UE shall:

1> transmit no response message.

If the URA UPDATE CONFIRM message:

- includes "CN information elements"; or
- includes the IE "Ciphering mode info"; or
- includes the IE "Integrity protection mode info"; or
- includes any one or both of the IEs "New C-RNTI" and "New U-RNTI"; or
- includes the IE "Downlink counter synchronisation info" and the IE "New U-RNTI":

the UE shall:

1> transmit a UTRAN MOBILITY INFORMATION CONFIRM as response message using AM RLC.

If the URA UPDATE CONFIRM message:

- does not include "CN information elements"; and
- does not include the IE "Ciphering mode info"; and
- does not include the IE "Integrity protection mode info"; and
- does not include the IE "New U-RNTI"; and

- does not include the IE "New C-RNTI":

the UE shall:

1> transmit no response message.

If the new state is CELL_DCH or CELL_FACH, the response message shall be transmitted using the new configuration after the state transition., and the UE shall:

1> if the IE "Downlink counter synchronisation info" was included in the received CELL UPDATE CONFIRM or URA UPDATE CONFIRM message:

2> when RLC has confirmed the successful transmission of the response message:

3> if the variable PDCP_SN_INFO is empty:

4> configure the RLC entity for all AM and UM radio bearers and AM and UM signalling radio bearers except RB2 to "continue".

3> else:

4> configure the RLC entity for signalling radio bearers RB1, RB3 and RB4 to "continue";

4> configure the RLC entity for UM and AM radio bearers for which the IE " PDCP SN Info" is not included to "continue".

3> re-establish all AM and UM RLC entities with RB identities larger than 4 and set the first 20 bits of all the HFN component of the respective COUNT-C values to the START value included in the response message for the corresponding CN domain;

3> re-establish the RLC entities with RB identities 1, 3 and 4 and set the first 20 bits of all the HFN component of the respective COUNT-C values to the START value included in the response message for the CN domain stored in the variable LATEST_CONFIGURED_CN_DOMAIN;

3> set the remaining bits of the HFN component of the COUNT-C values of all UM RLC entities to zero;

3> if the IE "PDCP context relocation info" is not present:

> re-initialise the PDCP header compression entities of each radio bearer in the variable ESTABLISHED_RABS as specified in [36].

3> if the IE "PDCP context relocation info" is present:

4> perform the actions as specified in subclause 8.6.4.13.

1> if the variable PDCP_SN_INFO is empty:

2> if the CELL UPDATE CONFIRM or URA UPDATE CONFIRM message contained the IE "Ciphering mode info":

3> when RLC has confirmed the successful transmission of the response message:

4> continue with the remainder of the procedure.

2> if the CELL UPDATE CONFIRM or URA UPDATE CONFIRM message did not contain the IE "Ciphering mode info":

3> when RLC has been requested to transmit the response message,

4> continue with the remainder of the procedure.

1> if the variable PDCP_SN_INFO is non-empty:

2> when RLC has confirmed the successful transmission of the response message:

3> for each radio bearer in the variable PDCP_SN_INFO:

4> if the IE "RB started" in the variable ESTABLISHED_RABS is set to "started":

5> configure the RLC entity for that radio bearer to "continue".

3> continue with the remainder of the procedure.

If the new state is CELL_PCH or URA_PCH, the response message shall be transmitted in CELL_FACH state, and the UE shall:

1> when RLC has confirmed the successful transmission of the response message:

2> if the IE "Downlink counter synchronisation info" was included in the received CELL UPDATE CONFIRM or URA UPDATE CONFIRM message:

3> re-establish all AM and UM RLC entities with RB identities larger than 4 and set the first 20 bits of all the HFN component of the respective COUNT-C values to the START value included in the response message for the corresponding CN domain;

3> re-establish the RLC entities with RB identities 1, 3 and 4 and set the first 20 bits of all the HFN component of the respective COUNT-C values to the START value included in the response message for the CN domain stored in the variable LATEST_CONFIGURED_CN_DOMAIN;

3> set the remaining bits of the HFN component of the COUNT-C values of all UM RLC entities to zero;

3> re-initialise the PDCP header compression entities of each radio bearer in the variable ESTABLISHED_RABS as specified in [36].

2> for each radio bearer in the variable PDCP_SN_INFO:

3> if the IE "RB started" in the variable ESTABLISHED_RABS is set to "started":

4> configure the RLC entity for that radio bearer to "continue".

2> enter the new state (CELL_PCH or URA_PCH, respectively).

1> continue with the remainder of the procedure.

### 8.3.1.7a Physical channel failure

If the received CELL UPDATE CONFIRM message would cause the UE to transit to CELL_DCH state:

1> if the UE failed to establish the physical channel(s) indicated in the received CELL UPDATE CONFIRM message according to the criteria defined in subclause 8.5.4 are not fulfilled;

1> if the received CELL UPDATE CONFIRM message does not contain dedicated physical channels; or

1> for 3.84 Mcps TDD or 7.68 Mcps TDD, if the received CELL UPDATE CONFIRM does not contain physical channels to which DCCH(s) are mapped:

the UE shall:

1> if, caused by the received CELL UPDATE CONFIRM message

2> the IE "Reconfiguration" in the variable CIPHERING_STATUS is set to TRUE; and/or

2> the IE "Reconfiguration" in the variable INTEGRITY_PROTECTION_INFO is set to TRUE:

3> abort the ongoing integrity and/or ciphering reconfiguration;

3> if the received CELL UPDATE CONFIRM message contained the IE "Ciphering mode info":

4> set the IE "Reconfiguration" in the variable CIPHERING_STATUS to FALSE; and

4> clear the variable RB_UPLINK_CIPHERING_ACTIVATION_TIME_INFO.

3> if the received CELL UPDATE CONFIRM message contained the IE "Integrity protection mode info":

4> set the IE "Reconfiguration" in the variable INTEGRITY_PROTECTION_INFO to FALSE; and

4> clear the variable INTEGRITY_PROTECTION_ACTIVATION_INFO.

1> if the variable ORDERED_RECONFIGURATION is set to TRUE caused by the received CELL UPDATE CONFIRM message:

2> set the IE "failure cause" to "physical channel failure";

2> set the variable ORDERED_RECONFIGURATION to FALSE.

1> if V302 is equal to or smaller than N302:

2> select a suitable UTRA cell according to [4];

2> set the contents of the CELL UPDATE message according to subclause 8.3.1.3, except for the IE "Cell update cause" which shall be set to "Radio link failure";

2> submit the CELL UPDATE message for transmission on the uplink CCCH;

2> increment counter V302;

2> restart timer T302 when the MAC layer indicates success or failure to transmit the message.

1> if V302 is greater than N302:

2> clear the variable RB_UPLINK_CIPHERING_ACTIVATION_TIME_INFO;

2> clear the variable INTEGRITY_PROTECTION_ACTIVATION_INFO;

2> in case of a cell update procedure:

3> clear the entry for the CELL UPDATE CONFIRM message in the table "Rejected transactions" in the variable TRANSACTIONS.

2> release all its radio resources;

2> indicate release (abort) of the established signalling connections (as stored in the variable ESTABLISHED_SIGNALLING_CONNECTIONS) and established radio access bearers (as stored in the variable ESTABLISHED_RABS) to upper layers;

2> clear the variable ESTABLISHED_SIGNALLING_CONNECTIONS;

2> clear the variable ESTABLISHED_RABS;

2> set the variable CELL_UPDATE_STARTED to FALSE;

2> enter idle mode.

### 8.3.1.8 Unsupported configuration by the UE

If the UE does not support the configuration in the CELL UPDATE CONFIRM message and/or the variable UNSUPPORTED_CONFIGURATION is set to TRUE, the UE shall:

1> if V302 is equal to or smaller than N302, the UE shall:

2> if, caused by the received CELL UPDATE CONFIRM message

3> the IE "Reconfiguration" in the variable CIPHERING_STATUS is set to TRUE; and/or

3> the IE "Reconfiguration" in the variable INTEGRITY_PROTECTION_INFO is set to TRUE:

4> abort the ongoing integrity and/or ciphering reconfiguration;

4> if the received CELL UPDATE CONFIRM message contained the IE "Ciphering mode info":

5> set the IE "Reconfiguration" in the variable CIPHERING_STATUS to FALSE; and

5> clear the variable RB_UPLINK_CIPHERING_ACTIVATION_TIME_INFO.

4> if the received CELL UPDATE CONFIRM message contained the IE "Integrity protection mode info":

5> set the IE "Reconfiguration" in the variable INTEGRITY_PROTECTION_INFO to FALSE; and

5> clear the variable INTEGRITY_PROTECTION_ACTIVATION_INFO.

2> if the variable ORDERED_RECONFIGURATION is set to TRUE due to the received CELL UPDATE CONFIRM message in case of a cell update procedure:

3> set the variable ORDERED_RECONFIGURATION to FALSE.

2> set the variable FAILURE_INDICATOR to TRUE;

2> set the variable FAILURE_CAUSE to "Unsupported configuration";

2> set the content of the CELL UPDATE message according to subclause 8.3.1.3;

2> submit the CELL UPDATE message for transmission on the uplink CCCH;

2> increment counter V302;

2> restart timer T302 when the MAC layer indicates success or failure to transmit the message.

1> if V302 is greater than N302, the UE shall:

2> clear the variable RB_UPLINK_CIPHERING_ACTIVATION_TIME_INFO;

2> clear the variable INTEGRITY_PROTECTION_ACTIVATION_INFO;

2> clear the variable PDCP_SN_INFO;

2> clear the entry for the CELL UPDATE CONFIRM message in the table "Rejected transactions" in the variable TRANSACTIONS;

2> release all its radio resources;

2> indicate release (abort) of the established signalling connections (as stored in the variable ESTABLISHED_SIGNALLING_CONNECTIONS) and established radio access bearers (as stored in the variable ESTABLISHED_RABS) to upper layers;

2> clear the variable ESTABLISHED_SIGNALLING_CONNECTIONS;

2> clear the variable ESTABLISHED_RABS;

2> set the variable CELL_UPDATE_STARTED to FALSE;

2> enter idle mode;

2> Other actions the UE shall perform when entering idle mode from connected mode are specified in subclause 8.5.2;

2> and the procedure ends.

### 8.3.1.9 Invalid configuration

If the variable INVALID_CONFIGURATION is set to TRUE, the UE shall:

1> if V302 is equal to or smaller than N302:

2> if, caused by the received CELL UPDATE CONFIRM or URA UPDATE CONFIRM message

3> the IE "Reconfiguration" in the variable CIPHERING_STATUS is set to TRUE; and/or

3> the IE "Reconfiguration" in the variable INTEGRITY_PROTECTION_INFO is set to TRUE:

4> abort the ongoing integrity and/or ciphering reconfiguration;

4> if the received CELL UPDATE CONFIRM or URA UPDATE CONFIRM message contained the IE "Ciphering mode info":

5> set the IE "Reconfiguration" in the variable CIPHERING_STATUS to FALSE; and

5> clear the variable RB_UPLINK_CIPHERING_ACTIVATION_TIME_INFO.

4> if the received CELL UPDATE CONFIRM or URA UPDATE CONFIRM message contained the IE "Integrity protection mode info";

5> set the IE "Reconfiguration" in the variable INTEGRITY_PROTECTION_INFO to FALSE; and

5> clear the variable INTEGRITY_PROTECTION_ACTIVATION_INFO.

2> if the variable ORDERED_RECONFIGURATION is set to TRUE caused by the received CELL UPDATE CONFIRM message in case of a cell update procedure:

3> set the variable ORDERED_RECONFIGURATION to FALSE.

2> in case of a cell update procedure:

3> set the variable FAILURE_INDICATOR to TRUE;

3> set the variable FAILURE_CAUSE to "Invalid configuration";

3> set the contents of the CELL UPDATE message according to subclause 8.3.1.3;

3> submit the CELL UPDATE message for transmission on the uplink CCCH.

2> in case of a URA update procedure:

3> set the contents of the URA UPDATE message according to subclause 8.3.1.3;

3> submit the URA UPDATE message for transmission on the uplink CCCH.

2> increment counter V302;

2> restart timer T302 when the MAC layer indicates success or failure to transmit the message.

1> if V302 is greater than N302:

2> clear the variable RB_UPLINK_CIPHERING_ACTIVATION_TIME_INFO;

2> clear the variable INTEGRITY_PROTECTION_ACTIVATION_INFO;

2> clear the variable PDCP_SN_INFO;

2> clear the entry for the CELL UPDATE CONFIRM message in the table "Rejected transactions" in the variable TRANSACTIONS;

2> release all its radio resources;

2> indicate release (abort) of the established signalling connections (as stored in the variable ESTABLISHED_SIGNALLING_CONNECTIONS) and established radio access bearers (as stored in the variable ESTABLISHED_RABS) to upper layers;

2> clear the variable ESTABLISHED_SIGNALLING_CONNECTIONS;

2> clear the variable ESTABLISHED_RABS;

2> set the variable CELL_UPDATE_STARTED to FALSE;

2> enter idle mode;

2> Other actions the UE shall perform when entering idle mode from connected mode are specified in subclause 8.5.2;

2> the procedure ends.

### 8.3.1.9a Incompatible simultaneous reconfiguration

In case of a cell update procedure and if the received CELL UPDATE CONFIRM message

- includes the IE "RB information to release list", and/or the IE "RB information to reconfigure list", and/or the IE "RB information to be affected list", and/or
- includes "Transport channel information elements"; and/or
- includes "Physical channel information elements"; and
- the variable ORDERED_RECONFIGURATION is set to TRUE because of an ongoing Reconfiguration procedure;

or

If the variable INCOMPATIBLE_SECURITY_RECONFIGURATION is set to TRUE due to the received CELL UPDATE CONFIRM or URA UPDATE CONFIRM message:

the UE shall:

1> if V302 is equal to or smaller than N302:

2> if, caused by the received CELL UPDATE CONFIRM or URA UPDATE CONFIRM message

3> the IE "Reconfiguration" in the variable CIPHERING_STATUS is set to TRUE; and/or

3> the IE "Reconfiguration" in the variable INTEGRITY_PROTECTION_INFO is set to TRUE:

4> abort the ongoing integrity and/or ciphering reconfiguration;

4> if the received CELL UPDATE CONFIRM or URA UPDATE CONFIRM message contained the IE "Ciphering mode info":

5> set the IE "Reconfiguration" in the variable CIPHERING_STATUS to FALSE; and

5> clear the variable RB_UPLINK_CIPHERING_ACTIVATION_TIME_INFO.

4> if the received CELL UPDATE CONFIRM or URA UPDATE CONFIRM message contained the IE "Integrity protection mode info":

5> set the IE "Reconfiguration" in the variable INTEGRITY_PROTECTION_INFO to FALSE; and

5> clear the variable INTEGRITY_PROTECTION_ACTIVATION_INFO.

2> if the variable ORDERED_RECONFIGURATION is set to TRUE due to the received CELL UPDATE CONFIRM message in case of a cell update procedure:

3> set the variable ORDERED_RECONFIGURATION to FALSE.

2> set the variable FAILURE_INDICATOR to TRUE;

2> set the variable FAILURE_CAUSE to "Incompatible simultaneous reconfiguration";

2> set the content of the CELL UPDATE message according to subclause 8.3.1.3;

2> submit the CELL UPDATE message for transmission on the uplink CCCH;

2> increment counter V302;

2> restart timer T302 when the MAC layer indicates success or failure to transmit the message.

1> if V302 is greater than N302:

2> clear the variable RB_UPLINK_CIPHERING_ACTIVATION_TIME_INFO;

2> clear the variable INTEGRITY_PROTECTION_ACTIVATION_INFO;

2> clear the variable PDCP_SN_INFO;

2> set the variable INCOMPATIBLE_SECURITY_RECONFIGURATION to FALSE;

2> clear the entry for the CELL UPDATE CONFIRM message in the table "Rejected transactions" in the variable TRANSACTIONS;

2> release all its radio resources;

2> indicate release (abort) of the established signalling connections (as stored in the variable ESTABLISHED_SIGNALLING_CONNECTIONS) and established radio access bearers (as stored in the variable ESTABLISHED_RABS) to upper layers;

2> clear the variable ESTABLISHED_SIGNALLING_CONNECTIONS;

2> clear the variable ESTABLISHED_RABS;

2> set the variable CELL_UPDATE_STARTED to FALSE;

2> enter idle mode;

2> Other actions the UE shall perform when entering idle mode from connected mode are specified in subclause 8.5.2;

2> the procedure ends.

### 8.3.1.9b Security reconfiguration during Cell update procedure

If:

- the variable CELL_UPDATE_STARTED is set to TRUE; and
- the UE receives a SECURITY MODE COMMAND message:

the UE shall

1> ignore the received SECURITY MODE COMMAND and continue with any ongoing processes and procedures as if the SECURITY MODE COMMAND message has not been received.

### 8.3.1.10 Confirmation error of URA ID list

If the URA UPDATE CONFIRM message causes a confirmation error of URA identity list as specified in subclause 8.6.2.1 the UE shall:

1> check the value of V302; and

1> if V302 is smaller or equal than N302:

2> if, caused by the received URA UPDATE CONFIRM message

3> the IE "Reconfiguration" in the variable CIPHERING_STATUS is set to TRUE; and/or

3> the IE "Reconfiguration" in the variable INTEGRITY_PROTECTION_INFO is set to TRUE:

4> abort the ongoing integrity and/or ciphering reconfiguration;

4> if the received URA UPDATE CONFIRM message contained the IE "Ciphering mode info":

5> set the IE "Reconfiguration" in the variable CIPHERING_STATUS to FALSE; and

5> clear the variable RB_UPLINK_CIPHERING_ACTIVATION_TIME_INFO.

4> if the received URA UPDATE CONFIRM message contained the IE "Integrity protection mode info"

5> set the IE "Reconfiguration" in the variable INTEGRITY_PROTECTION_INFO to FALSE; and

5> clear the variable INTEGRITY_PROTECTION_ACTIVATION_INFO.

2> set the IEs in the URA UPDATE message according to subclause 8.3.1.3;

2> submit the URA UPDATE message for transmission on the uplink CCCH;

2> increment counter V302;

2> restart timer T302 when the MAC layer indicates success or failure to transmit the message.

1> if V302 is greater than N302:

2> release all its radio resources;

2> clear the variable RB_UPLINK_CIPHERING_ACTIVATION_TIME_INFO;

2> clear the variable INTEGRITY_PROTECTION_ACTIVATION_INFO;

2> clear the variable PDCP_SN_INFO;

2> indicate release (abort) of the established signalling connections (as stored in the variable ESTABLISHED_SIGNALLING_CONNECTIONS) and established radio access bearers (as stored in the variable ESTABLISHED_RABS) to upper layers;

2> clear the variable ESTABLISHED_SIGNALLING_CONNECTIONS;

2> clear the variable ESTABLISHED_RABS;

2> set the variable CELL_UPDATE_STARTED to FALSE;

2> enter idle mode;

2> perform the actions specified in subclause 8.5.2 when entering idle mode from connected mode;

2> the procedure ends.

### 8.3.1.11 Invalid CELL UPDATE CONFIRM/URA UPDATE CONFIRM message

If the UE receives an CELL UPDATE CONFIRM/URA UPDATE CONFIRM message, which contains a protocol error causing the variable PROTOCOL_ERROR_REJECT to be set to TRUE according to clause 9, the UE shall perform procedure specific error handling as follows:

1> If V302 is equal to or smaller than N302, the UE shall:

2> set the variable PROTOCOL_ERROR_INDICATOR to TRUE;

2> in case of a cell update procedure:

3> set the contents of the CELL UPDATE message according to subclause 8.3.1.3;

3> submit the CELL UPDATE message for transmission on the uplink CCCH.

2> in case of a URA update procedure:

3> set the contents of the URA UPDATE message according to subclause 8.3.1.3;

3> submit the URA UPDATE message for transmission on the uplink CCCH.

2> increment counter V302;

2> restart timer T302 when the MAC layer indicates success or failure to transmit the message.

1> if V302 is greater than N302, the UE shall:

2> clear the variable RB_UPLINK_CIPHERING_ACTIVATION_TIME_INFO;

2> in case of a cell update procedure:

3> clear the entry for the CELL UPDATE CONFIRM message in the table "Rejected transactions" in the variable TRANSACTIONS.

2> in case of a URA update procedure:

3> clear the entry for the URA UPDATE CONFIRM message in the table "Rejected transactions" in the variable TRANSACTIONS.

2> indicate release (abort) of the established signalling connections (as stored in the variable ESTABLISHED_SIGNALLING_CONNECTIONS) and established radio access bearers (as stored in the variable ESTABLISHED_RABS) to upper layers;

2> clear the variable ESTABLISHED_SIGNALLING_CONNECTIONS;

2> clear the variable ESTABLISHED_RABS;

2> set the variable CELL_UPDATE_STARTED to FALSE;

2> release all its radio resources;

2> enter idle mode;

2> Other actions the UE shall perform when entering idle mode from connected mode are specified in subclause 8.5.2;

2> the procedure ends.

#### 8.3.1.12 T302 expiry or cell reselection

If any or several of the following conditions are true:

- expiry of timer T302;
- reselection to another UTRA cell (including the previously serving cell) before completion of the cell update or URA update procedure;

the UE shall:

1> stop T302 if it is running;

1> if the UE was in CELL_DCH state prior to the initiation of the procedure; and

2> if timers T314 and T315 have elapsed while T302 was running:

3> enter idle mode.

3> indicate release (abort) of the established signalling connections (as stored in the variable ESTABLISHED_SIGNALLING_CONNECTIONS) and established radio access bearers (as stored in the variable ESTABLISHED_RABS) to upper layers. Other actions the UE shall perform when entering idle mode from connected mode are specified in subclause 8.5.2.

3> and the procedure ends.

2> if timer T314 has elapsed while T302 was running and,

3> if "T314 expired" in the variable RB_TIMER_INDICATOR is set to FALSE and

3> if T315 is still running:

4> release locally all radio bearers which are associated with any radio access bearers for which in the variable ESTABLISHED_RABS the value of the IE "Re-establishment timer" is set to "useT314";

4> indicate release of those radio access bearers to upper layers;

4> delete all information about those radio access bearers from the variable ESTABLISHED_RABS;

4> set "T314 expired" in the variable RB_TIMER_INDICATOR to TRUE.

2> if timer T315 has elapsed while T302 was running and,

3> if "T315 expired" in the variable RB_TIMER_INDICATOR is set to FALSE and,

3> if T314 is still running:

4> release locally all radio bearers which are associated with any radio access bearers for which in the variable ESTABLISHED_RABS the value of the IE "Re-establishment timer" is set to "useT315";

4> indicate release of those radio access bearers to upper layers;

4> delete all information about those radio access bearers from the variable ESTABLISHED_RABS;

4> set "T315 expired" in the variable RB_TIMER_INDICATOR to TRUE.

2> if timers T314 and T315 are not running:

3> enter idle mode;

3> indicate release (abort) of the established signalling connections (as stored in the variable ESTABLISHED_SIGNALLING_CONNECTIONS) and established radio access bearers (as stored in the variable ESTABLISHED_RABS) to upper layers. Other actions the UE shall perform when entering idle mode from connected mode are specified in subclause 8.5.2;

3> and the procedure ends.

1> check whether it is still in "in service area" (see subclause 8.5.5.2);

1> if the variable ORDERED_RECONFIGURATION is set to TRUE caused by the received CELL UPDATE CONFIRM message in case of a cell update procedure:

2> set the variable ORDERED_RECONFIGURATION to FALSE.

1> in case of a cell update procedure:

2> clear any entry for the CELL UPDATE CONFIRM message in the table "Accepted transactions" in the variable TRANSACTIONS.

1> in case of a URA update procedure:

2> clear any entry for the URA UPDATE CONFIRM message in the table "Accepted transactions" in the variable TRANSACTIONS.

If the UE detects "in service area" if it has not entered idle mode, and:

1> if V302 is equal to or smaller than N302, the UE shall:

2> if the UE performed cell re-selection:

3> delete its C-RNTI.

2> in case of a cell update procedure:

3> set the contents of the CELL UPDATE message according to subclauses 8.3.1.3 and 8.5.10;

3> if a CELL UPDATE CONFIRM message was received and caused the IE "Reconfiguration" in the variable CIPHERING_STATUS to be set to TRUE and/or the IE "Reconfiguration" in the variable INTEGRITY_PROTECTION_INFO to be set to TRUE:

4> if the IE "Downlink counter synchronisation info" was included in the received CELL UPDATE CONFIRM message:

5> apply the new security (integrity protection) configuration received in the CELL UPDATE CONFIRM on the CELL UPDATE message.

3> submit the CELL UPDATE message for transmission on the uplink CCCH.

2> in case of a URA update procedure:

3> set the contents of the URA UPDATE message according to subclauses 8.3.1.3 and 8.5.10;

3> if a URA UPDATE CONFIRM message was received and caused the IE "Reconfiguration" in the variable CIPHERING_STATUS to be set to TRUE and/or the IE "Reconfiguration" in the variable INTEGRITY_PROTECTION_INFO is set to TRUE:

4> if the IE "Downlink counter synchronisation info" was included in the received URA UPDATE CONFIRM message:

5> apply the new security (integrity protection) configuration received in the URA UPDATE CONFIRM on the URA UPDATE message.

3> submit the URA UPDATE message for transmission on the uplink CCCH.

2> increment counter V302;

2> restart timer T302 when the MAC layer indicates success or failure to transmit the message.

1> if V302 is greater than N302, the UE shall:

2> clear the variable RB_UPLINK_CIPHERING_ACTIVATION_TIME_INFO;

2> clear the variable INTEGRITY_PROTECTION_ACTIVATION_INFO;

2> clear the variable PDCP_SN_INFO;

2> in case of a cell update procedure:

3> clear the entry for the CELL UPDATE CONFIRM message in the table "Rejected transactions" in the variable TRANSACTIONS.

2> in case of a URA update procedure:

3> clear the entry for the URA UPDATE CONFIRM message in the table "Rejected transactions" in the variable TRANSACTIONS.

2> release all its radio resources;

2> indicate release (abort) of the established signalling connections (as stored in the variable ESTABLISHED_SIGNALLING_CONNECTIONS) and established radio access bearers (as stored in the variable ESTABLISHED_RABS) to upper layers;

2> clear the variable ESTABLISHED_SIGNALLING_CONNECTIONS;

2> clear the variable ESTABLISHED_RABS;

2> set the variable CELL_UPDATE_STARTED to FALSE;

2> enter idle mode;

2> other actions the UE shall perform when entering idle mode from connected mode are specified in subclause 8.5.2;

2> and the procedure ends.

If the UE detects "out of service area", it shall:

1> act according to subclause 7.2.2.

### 8.3.1.13 T314 expiry

Upon expiry of timer T314 the UE shall:

1> if timer T302 is running:

2> continue awaiting response message from UTRAN.

1> if timer T302 is not running and timer T315 is running:

2> set IE "T314 expired" in variable RB_TIMER_INDICATOR to TRUE;

2> release locally all radio bearers which are associated with any radio access bearers for which in the variable ESTABLISHED_RABS the value of the IE "Re-establishment timer" is set to "useT314";

2> indicate release of those radio access bearers to upper layers;

2> delete all information about those radio access bearers from the variable ESTABLISHED_RABS.

1> if timers T302 and T315 are not running:

2> clear the variable RB_UPLINK_CIPHERING_ACTIVATION_TIME_INFO;

2> clear the variable INTEGRITY_PROTECTION_ACTIVATION_INFO;

2> clear the variable PDCP_SN_INFO;

2> clear the entry for the CELL UPDATE CONFIRM message in the table "Rejected transactions" in the variable TRANSACTIONS;

2> release all its radio resources;

2> indicate release (abort) of the established signalling connections (as stored in the variable ESTABLISHED_SIGNALLING_CONNECTIONS) and established radio access bearers (as stored in the variable ESTABLISHED_RABS) to upper layers;

2> clear the variable ESTABLISHED_SIGNALLING_CONNECTIONS;

2> clear the variable ESTABLISHED_RABS;

2> set the variable CELL_UPDATE_STARTED to FALSE;

2> enter idle mode;

2> other actions the UE shall perform when entering idle mode from connected mode are specified in subclause 8.5.2;

2> and the procedure ends.

#### 8.3.1.14 T315 expiry

Upon expiry of timer T315 the UE shall:

1> if timer T302 is running:

2> continue awaiting response message from UTRAN.

1> if timer T302 is not running and timer T314 is running:

2> set IE "T315 expired" in variable RB_TIMER_INDICATOR to TRUE;

2> release locally all radio bearers which are associated with any radio access bearers for which in the variable ESTABLISHED_RABS the value of the IE "Re-establishment timer" is set to "use T315";

2> indicate release of those radio access bearers to upper layers;

2> delete all information about those radio access bearers from the variable ESTABLISHED_RABS.

1> if timers T302 and T314 are not running:

2> clear the variable RB_UPLINK_CIPHERING_ACTIVATION_TIME_INFO;

2> clear the variable INTEGRITY_PROTECTION_ACTIVATION_INFO;

2> clear the variable PDCP_SN_INFO;

2> clear the entry for the CELL UPDATE CONFIRM message in the table "Rejected transactions" in the variable TRANSACTIONS;

2> release all its radio resources;

2> indicate release (abort) of the established signalling connections (as stored in the variable ESTABLISHED_SIGNALLING_CONNECTIONS) and established radio access bearers (as stored in the variable ESTABLISHED_RABS) to upper layers;

2> clear the variable ESTABLISHED_SIGNALLING_CONNECTIONS;

2> clear the variable ESTABLISHED_RABS;

2> set the variable CELL_UPDATE_STARTED to FALSE;

2> enter idle mode;

2> other actions the UE shall perform when entering idle mode from connected mode are specified in subclause 8.5.2;

2> and the procedure ends.

#### 8.3.1.15 Reception of the UTRAN MOBILITY INFORMATION CONFIRM message by the UTRAN

See subclause 8.3.3.4.

### 8.3.2 URA update

See subclause 8.3.1.

### 8.3.3 UTRAN mobility information




**Figure 8.3.3-1: UTRAN mobility information procedure, normal flow**




**Figure 8.3.3-2: UTRAN mobility information procedure, failure case**

#### 8.3.3.1 General

The purpose of this procedure is to allocate any one or a combination of the following to a UE in connected mode:

- a new C-RNTI;

- a new U-RNTI;
- other mobility related information.

### 8.3.3.2 Initiation

To initiate the procedure UTRAN transmits a UTRAN MOBILITY INFORMATION message to the UE on the downlink DCCH using AM or UM RLC. In case of SRNS relocation, the message is sent using UM RLC only.

### 8.3.3.3 Reception of UTRAN MOBILITY INFORMATION message by the UE

When the UE receives a UTRAN MOBILITY INFORMATION message, it shall:

1> act on received information elements as specified in subclause 8.6;

1> if the IE "UE Timers and constants in connected mode" is present:

2> store the values of the IE "UE Timers and constants in connected mode" in the variable TIMERS_AND_CONSTANTS, replacing any previously stored value for each timer and constant; and

2> for each updated timer value:

3> start using the new value next time the timer is started;

NOTE: If a new value of timer T305 is included in the IE "UE Timers and constants in connected mode", and the old value of timer T305 is "infinity", the UE will not use the new value of the timer T305 until the next cell reselection.

2> for each updated constant value:

3> start using the new value directly;

1> if the IE "CN domain specific DRX cycle length coefficient" is present:

2> store the value of the IE "CN domain specific DRX cycle length coefficient" for that CN domain, replacing any previously stored value; and

2> use the value to determine the connected mode paging occasions according to [4].

1> set the IE "RRC transaction identifier" in the UTRAN MOBILITY INFORMATION CONFIRM message to the value of "RRC transaction identifier" in the entry for the UTRAN MOBILITY INFORMATION message in the table "Accepted transactions" in the variable TRANSACTIONS; and

1> clear that entry;

1> if the UTRAN MOBILITY INFORMATION message contained the IE "Ciphering mode info" or contained the IE "Integrity protection mode info":

2> set the IE "Status" in the variable SECURITY_MODIFICATION for all the CN domains in the variable SECURITY_MODIFICATION to "Affected".

1> if the variable PDCP_SN_INFO is non-empty:

2> include the IE "RB with PDCP information list" in the UTRAN MOBILITY INFORMATION CONFIRM message and set it to the value of the variable PDCP_SN_INFO.

1> if the received UTRAN MOBILITY INFORMATION message included the IE "Downlink counter synchronisation info":

2> if the variable PDCP_SN_INFO is empty:

3> configure the corresponding RLC entity for all AM and UM radio bearers and AM and UM signalling radio bearers except RB2 to "stop".

2> else:

3> configure the RLC entity for signalling radio bearers RB1, RB3 and RB4 to "stop";

3> configure the RLC entity for UM and AM radio bearers for which the IE "PDCP SN Info" is not included to "stop".

2> re-establish the RLC entity for RB2;

2> for the downlink and the uplink, apply the ciphering configuration as follows:

3> if the received re-configuation message included the IE "Ciphering Mode Info":

4> use the ciphering configuration in the received message when transmitting the response message.

3> if the ciphering configuration for RB2 from a previously received SECURITY MODE COMMAND has not yet been applied because the activation times not having been reached:

4> if the previous SECURITY MODE COMMAND was received due to new keys being received:

5> consider the new ciphering configuration to include the received new keys;

5> initialise the HFN component of the uplink COUNT-C and downlink COUNT-C of SRB2 as indicated in subclause 8.1.12.3.1.

4> if the ciphering configuration for RB2 from a previously received SECURITY MODE COMMAND has not yet been applied because of the corresponding activation times not having been reached and the previous SECURITY MODE COMMAND caused a change in LATEST_CONFIGURED_CN_DOMAIN:

5> consider the new ciphering configuration to include the keys associated with the LATEST_CONFIGURED_CN_DOMAIN;

5> initialise the HFN component of the uplink COUNT-C and downlink COUNT-C of SRB2 to the most recently transmitted IE "START list" or IE "START" for the LATEST_CONFIGURED_CN_DOMAIN at the reception of the previous SECURITY MODE COMMAND.

4> apply the new ciphering configuration immediately following RLC re-establishment.

3> else:

4> continue using the current ciphering configuration.

2> set the new uplink and downlink HFN component of COUNT-C of RB2 to MAX(uplink HFN component of COUNT-C of RB2, downlink HFN component of COUNT-C of RB2);

2> increment by one the downlink and uplink values of the HFN component of COUNT-C for RB2;

2> calculate the START value according to subclause 8.5.9;

2> include the calculated START values for each CN domain in the IE "START list" in the IE "Uplink counter synchronisation info" in the UTRAN MOBILITY INFORMATION CONFIRM message.

1> transmit a UTRAN MOBILITY INFORMATION CONFIRM message on the uplink DCCH using AM RLC;

1> if the IE "Integrity protection mode info" was present in the UTRAN MOBILITY INFORMATION message:

2> start applying the new integrity protection configuration in the uplink for signalling radio bearer RB2 from and including the transmitted UTRAN MOBILITY INFORMATION CONFIRM message.

1> if the IE "Downlink counter synchronisation info" was included in the received UTRAN MOBILITY INFORMATION message:

2> when RLC has confirmed the successful transmission of the response message:

3> if the variable PDCP_SN_INFO is empty:

4> configure the RLC entity for all AM and UM radio bearers and AM and UM signalling radio bearers except RB2 to "continue".

3> else:

4> configure the RLC entity for signalling radio bearers RB1, RB3 and RB4 to "continue";

4> configure the RLC entity for UM and AM radio bearers for which the IE "PDCP SN Info" is not included to "continue".

3> re-establish all AM and UM RLC entities with RB identities larger than 4 and set the first 20 bits of all the HFN component of the respective COUNT-C values to the START value included in the response message for the corresponding CN domain;

3> re-establish the RLC entities with RB identities 1, 3 and 4 and set the first 20 bits of all the HFN component of the respective COUNT-C values to the START value included in the response message for the CN domain stored in the variable LATEST_CONFIGURED_CN_DOMAIN;

3> set the remaining bits of the HFN component of the COUNT-C values of all UM RLC entities to zero;

3> if the IE "PDCP context relocation info" is not present:

4> re-initialise the PDCP header compression entities of each radio bearer in the variable ESTABLISHED_RABS as specified in [36].

3> if the IE "PDCP context relocation info" is present:

4> perform the actions as specified in subclause 8.6.4.13.

1> if the variable PDCP_SN_INFO is empty; and

2> if the UTRAN MOBILITY INFORMATION message contained the IE "Ciphering mode info":

3> when RLC has confirmed the successful transmission of the UTRAN MOBILITY INFORMATION CONFIRM message:

4> perform the actions below:

2> if the UTRAN MOBILITY INFORMATION message did not contain the IE "Ciphering mode info":

3> when RLC has been requested to transmit the UTRAN MOBILITY INFORMATION CONFIRM message:

4> perform the actions below.

1> if the variable PDCP_SN_INFO is non-empty:

2> when RLC has confirmed the successful transmission of the UTRAN MOBILITY INFORMATION CONFIRM message:

3> for each radio bearer in the variable PDCP_SN_INFO:

4> if the IE "RB started" in the variable ESTABLISHED_RABS is set to "started":

5> configure the RLC entity for that radio bearer to "continue".

3> clear the variable PDCP_SN_INFO; and

3> perform the actions below.

The UE shall:

1> if the UTRAN MOBILITY INFORMATION message contained the IE "Ciphering mode info":

2> resume data transmission on any suspended radio bearer and signalling radio bearer mapped on RLC-AM or RLC-UM;

2> set the IE "Reconfiguration" in the variable CIPHERING_STATUS to FALSE; and

2> clear the variable RB_UPLINK_CIPHERING_ACTIVATION_TIME_INFO.

1> if the UTRAN MOBILITY INFORMATION message contained the IE "Integrity protection mode info":

2> allow the transmission of RRC messages on all signalling radio bearers with any RRC SN;

2> set the IE "Reconfiguration" in the variable INTEGRITY_PROTECTION_INFO to FALSE; and

2> clear the variable INTEGRITY_PROTECTION_ACTIVATION_INFO.

1> clear the variable SECURITY_MODIFICATION.

The procedure ends.

#### 8.3.3.4 Reception of an UTRAN MOBILITY INFORMATION CONFIRM message by the UTRAN

When the network receives UTRAN MOBILITY INFORMATION CONFIRM message, UTRAN may delete any old U-RNTI. The procedure ends.

#### 8.3.3.5 Cell re-selection

If the UE performs cell re-selection, the UE shall:

1> initiate a cell update procedure according to subclause 8.3.1;

1> if the UTRAN MOBILITY INFORMATION message contains the IE "New C-RNTI"; and

1> if the UE has not yet submitted the UTRAN MOBILITY INFORMATION CONFIRM message to lower layers for transmission; and

1> if the IE "Downlink counter synchronisation info" was not included in the received UTRAN MOBILITY INFORMATION message:

2> transmit a UTRAN MOBILITY INFORMATION FAILURE message on the uplink DCCH using AM RLC;

2> set the IE "RRC transaction identifier" in the UTRAN MOBILITY INFORMATION FAILURE message to the value of "RRC transaction identifier" in the entry for the UTRAN MOBILITY INFORMATION message in the table "Accepted transactions" in the variable TRANSACTIONS; and

2> clear that entry.

2> set the IE "failure cause" to the cause value "cell update occurred";

2> when the UTRAN MOBILITY INFORMATION FAILURE message has been submitted to lower layers for transmission:

3> continue with any ongoing processes and procedures as if the invalid UTRAN MOBILITY INFORMATION message has not been received and the procedure ends.

1> otherwise:

2> if a UTRAN MOBILITY INFORMATION message was received and caused the IE "Reconfiguration" in the variable CIPHERING_STATUS to be set to TRUE and/or the IE "Reconfiguration" in the variable INTEGRITY_PROTECTION_INFO to be set to TRUE; and

2> if the IE "Downlink counter synchronisation info" was included in the received UTRAN MOBILITY INFORMATION message:

3> apply the new security (integrity protection) configuration received in the UTRAN MOBILITY INFORMATION message on the CELL UPDATE message to be transmitted.

2> continue the procedure normally.

#### 8.3.3.5a Incompatible simultaneous security reconfiguration

If the variable INCOMPATIBLE_SECURITY_RECONFIGURATION becomes set to TRUE of the received UTRAN MOBILITY INFORMATION message, the UE shall:

1> transmit a UTRAN MOBILITY INFORMATION FAILURE message on the uplink DCCH using AM RLC;

1> set the IE "RRC transaction identifier" in the UTRAN MOBILITY INFORMATION FAILURE message to the value of "RRC transaction identifier" in the entry for the UTRAN MOBILITY INFORMATION message in the table "Accepted transactions" in the variable TRANSACTIONS; and

1> clear that entry;

1> set the IE "failure cause" to the cause value "incompatible simultaneous reconfiguration";

1> when the UTRAN MOBILITY INFORMATION FAILURE message has been delivered to lower layers for transmission:

2> set the variable INCOMPATIBLE_SECURITY_RECONFIGURATION to FALSE;

2> continue with any ongoing processes and procedures as if the UTRAN MOBILITY INFORMATION message has not been received;

2> and the procedure ends.

#### 8.3.3.6 Invalid UTRAN MOBILITY INFORMATION message

If the UTRAN MOBILITY INFORMATION message contains a protocol error causing the variable PROTOCOL_ERROR_REJECT to be set to TRUE according to clause 9, the UE shall perform procedure specific error handling as follows. The UE shall:

1> transmit a UTRAN MOBILITY INFORMATION FAILURE message on the uplink DCCH using AM RLC;

1> set the IE "RRC transaction identifier" in the UTRAN MOBILITY INFORMATION FAILURE message to the value of "RRC transaction identifier" in the entry for the UTRAN MOBILITY INFORMATION message in the table "Rejected transactions" in the variable TRANSACTIONS, and;

1> clear that entry.

1> set the IE "failure cause" to the cause value "protocol error";

1> include the IE "Protocol error information" with contents set to the value of the variable PROTOCOL_ERROR_INFORMATION;

1> when the UTRAN MOBILITY INFORMATION FAILURE message has been submitted to lower layers for transmission:

2> continue with any ongoing processes and procedures as if the invalid UTRAN MOBILITY INFORMATION message has not been received;

2> and the procedure ends.

### 8.3.4 Active set update




**Figure 8.3.4-1: Active Set Update procedure, successful case**




**Figure 8.3.4-2: Active Set Update procedure, failure case**

### 8.3.4.1 General

The purpose of the active set update procedure is to update the active set of the connection between the UE and UTRAN. This procedure shall be used in CELL_DCH state. The UE should keep on using the old RLs while configuring the new RLs. Also the UE should keep the transmitter turned on during the procedure. This procedure is only used in FDD mode.

### 8.3.4.2 Initiation

The procedure is initiated when UTRAN orders a UE in CELL_DCH state, to make the following modifications of the active set of the connection:

a) Radio link addition;

b) Radio link removal;

c) Combined radio link addition and removal;

d) Addition of a radio link to the E-DCH active set;

e) Removal of a radio link from the E-DCH active set.

In case a) and c), UTRAN should:

1> prepare new additional radio link(s) in the UTRAN prior to the command to the UE.

In all cases, UTRAN should:

1> send an ACTIVE SET UPDATE message on downlink DCCH using AM or UM RLC;

1> create active sets that contain at least one common radio link across a DPCH or F-DPCH frame boundary as the result of one or multiple (parallel) active set update procedures.

UTRAN should include the following information:

1> IE "Radio Link Addition Information": Downlink DPCH information and other optional parameters relevant for the radio links to be added along with the IE "Primary CPICH info" used for the reference ID to indicate which radio link to add. This IE is needed in cases a) and c) listed above;

1> IE "Radio Link Removal Information": IE "Primary CPICH info" used for the reference ID to indicate which radio link to remove. This IE is needed in cases b) and c) listed above;

1> IE "E-DCH reconfiguration information": IE "Primary CPICH info" used for the reference ID along with the IE "E-HICH information" to indicate which radio link to add to the E-DCH active set. This IE is needed in case d) above, when the RL added to the E-DCH active set is already in the DCH active set;

1> IE "E-DCH reconfiguration information": IE "Primary CPICH info" used for the reference ID along with the IE "E-HICH release indicator" to indicate which radio link to remove from the E-DCH active set. This IE is needed in case e) above, when the RL removed from the E-DCH active set remains in the DCH active set.

### 8.3.4.3 Reception of an ACTIVE SET UPDATE message by the UE

Upon reception of an ACTIVE SET UPDATE message the UE shall act upon all received information elements as specified in 8.6, unless specified otherwise in the following.

The UE may:

1> maintain a list of the set of cells to which the UE has Radio Links if the IE "Cell ID" is present.

The UE shall:

1> first add the RLs indicated in the IE "Radio Link Addition Information";

1> remove the RLs indicated in the IE "Radio Link Removal Information". If the UE active set is full or becomes full, an RL, which is included in the IE "Radio Link Removal Information" for removal, shall be removed before adding RL, which is included in the IE "Radio Link Addition Information" for addition;

1> perform the physical layer synchronisation procedure B as specified in [29];

1> if the IE "E-HICH information" is included:

2> store this E-HICH configuration for the concerning radio link.

1> if the IE "E-HICH information" is included:

2> store this E-RGCH configuration for the concerning radio link, if included.

1> determine the value for the E_DCH_TRANSMISSION variable and take the corresponding actions as described in subclause 8.5.28;

1> if the radio link currently considered to be the serving HS-DSCH radio link is indicated in the IE "Radio Link Removal Information":

2> no longer consider any radio link as the serving HS-DSCH radio link;

2> determine the value for the HS_DSCH_RECEPTION variable and take the corresponding actions as described in subclause 8.5.25.

1> if "Serving HS-DSCH cell information" IE is present, act on received information elements as specified in subclause 8.6:

2> if the IEs "$\Delta_{ACK}$", "$\Delta_{NACK}$", and "HARQ_preamble_mode" are present, act on the received information elements;

2> if the new H-RNTI and "Primary CPICH info" are included:

3> consider the cell indicated in Primary CPICH as serving HS-DSCH cell and no longer consider any other radio link as serving HS-DSCH cell.

2> if the IE "MAC-hs reset indicator" is included:

3> reset the MAC-hs entity [15].

2> determine the value for the HS_DSCH_RECEPTION variable and take the corresponding actions as described in subclause 8.5.25.

1> if the IE "E-DCH reconfiguration information" is included:

2> if the IE "E-DCH RL Info other cells" is present:

3> if the IE "E-HICH Information" is present:

4> store the E-HICH and E-RGCH information (if present), contained therein, for the indicated radio link.

3> if the IE "E-HICH release indicator" is present:

4> delete the stored E-HICH, E-AGCH and E-RGCH (if any) configurations.

3> if the IE "E-RGCH release indicator" is set present:

4> delete the stored E-RGCH configuration for this RL.

2> if the IE "E-DCH RL Info new serving cell" is present:

3> consider the cell indicated in "Primary CPICH info" as serving E-DCH radio link and no longer consider any other radio link as serving E-DCH radio link;

3> store the E-HICH and E-RGCH information (if present), contained therein, for the new serving E-DCH radio link;

3> if the IE "E-RGCH release indicator" is present:

4> delete the stored E-RGCH configuration for this RL.

3> store the newly received E-AGCH configuration.

2> if the IEs "E-DPCCH/DPCCH power offset" and/or "Reference E-TFCI PO" and/or "Power offset for scheduling info" are present, act on the received information elements.

2> if the serving E-DCH radio link was another radio link than this radio link prior to reception of the message:

3> if the IE "New Primary E-RNTI" is not included:

4> clear the Primary E-RNTI stored in the variable E_RNTI.

3> if the IE "New Secondary E-RNTI" is not included:

4> clear the Secondary E-RNTI stored in the variable E_RNTI.

1> if the radio link currently considered to be the serving E-DCH radio link is indicated in the IE "Radio Link Removal Information":

2> no longer consider any radio link as the serving E-DCH radio link.

1> determine the value for the E_DCH_TRANSMISSION variable and take the corresponding actions as described in subclause 8.5.28.

1> set the IE "RRC transaction identifier" in the ACTIVE SET UPDATE COMPLETE message to the value of "RRC transaction identifier" in the entry for the ACTIVE SET UPDATE message in the table "Accepted transactions" in the variable TRANSACTIONS; and

1> clear that entry;

1> transmit an ACTIVE SET UPDATE COMPLETE message on the uplink DCCH using AM RLC without waiting for the completion of the Physical Layer synchronisation B, as specified in [29];

1> the procedure ends on the UE side.

#### 8.3.4.4 Unsupported configuration in the UE

If UTRAN instructs the UE to use a configuration that it does not support, the UE shall:

1> keep the active set as it was before the ACTIVE SET UPDATE message was received;

1> transmit an ACTIVE SET UPDATE FAILURE message on the DCCH using AM RLC;

1> set the IE "RRC transaction identifier" in the ACTIVE SET UPDATE FAILURE message to the value of "RRC transaction identifier" in the entry for the ACTIVE SET UPDATE message in the table "Accepted transactions" in the variable TRANSACTIONS; and

1> clear that entry;

1> set the IE "failure cause" to "configuration unsupported";

1> when the ACTIVE SET UPDATE FAILURE message has been submitted to lower layers for transmission:

2> the procedure ends on the UE side.

### 8.3.4.5 Invalid configuration

If any of the following conditions are valid:

- a radio link indicated by the IE "Downlink DPCH info for each RL" in the IE "Radio link addition information" has a different spreading factor than the spreading factor for the radio links in the active set that will be established at the time indicated by the IE "Activation time"; and/or
- a radio link in the IE "Radio link addition information" is also present in the IE "Radio Link Removal Information"; and/or
- the IE "Radio Link Removal Information" contains all the radio links which are part of or will be part of the active set at the time indicated by the IE "Activation time"; and/or
- the IE "TX Diversity Mode" is not set to "none" and it indicates a diversity mode that is different from the one currently used (<STTD> or <closed loop mode1>) in all or part of the active set; and/or
- a radio link indicated by the IE "Radio Link Removal Information" does not exist in the active set; and/or
- after the removal of all radio links indicated by the IE "Radio Link Removal Information" and the addition of all radio links indicated by the IE "Radio Link Addition Information" the active set would contain more than the maximum allowed number of radio links; and/or
- after the addition of all radio links indicated by the IE "Radio Link Addition Information" the active set would contain radio links indicated by the IE "Downlink DPCH info for each RL" and radio links indicated by the IE "Downlink F-DPCH info for each RL"; and/or
- the variable INVALID_CONFIGURATION is set to TRUE:

the UE shall:

1> keep the active set as it was before the ACTIVE SET UPDATE message was received;

1> transmit an ACTIVE SET UPDATE FAILURE message on the DCCH using AM RLC;

1> set the IE "RRC transaction identifier" in the ACTIVE SET UPDATE FAILURE message to the value of "RRC transaction identifier" in the entry for the ACTIVE SET UPDATE message in the table "Accepted transactions" in the variable TRANSACTIONS; and

1> clear that entry;

1> set the IE "failure cause" to "Invalid configuration";

1> When the ACTIVE SET UPDATE FAILURE message has been submitted to lower layers for transmission:

2> the procedure ends on the UE side.

If the following condition is valid:

- the active set update procedure results in active sets that do not contain at least one common radio link before and after a DPCH or F-DPCH frame boundary:

the UE behaviour is not specified.

### 8.3.4.5a Void

### 8.3.4.5b Incompatible simultaneous reconfiguration

If the variable ORDERED_RECONFIGURATION is set to TRUE, the UE may:

1> if the activation time for the procedure that has set variable ORDERED_RECONFIGURATION and the activation time for the Active Set Update procedure are within a time window of 5 frames:

2> transmit an ACTIVE SET UPDATE FAILURE message on the uplink DCCH using AM RLC;

2> set the IE "RRC transaction identifier" in the ACTIVE SET UPDATE FAILURE message to the value of "RRC transaction identifier" in the entry for the ACTIVE SET UPDATE message in the table "Accepted transactions" in the variable TRANSACTIONS; and

2> clear that entry;

2> set the IE "failure cause" to the cause value "incompatible simultaneous reconfiguration";

2> when the ACTIVE SET UPDATE FAILURE message has been delivered to lower layers for transmission:

3> continue with any ongoing processes and procedures as if the ACTIVE SET UPDATE message has not been received.

3> and the procedure ends.

#### 8.3.4.6 Reception of the ACTIVE SET UPDATE COMPLETE message by the UTRAN

When the UTRAN has received the ACTIVE SET UPDATE COMPLETE message,

1> the UTRAN may remove radio link(s) that are indicated to remove to the UE in case b) and c); and

1> the procedure ends on the UTRAN side.

#### 8.3.4.7 Reception of the ACTIVE SET UPDATE FAILURE message by the UTRAN

When the UTRAN has received the ACTIVE SET UPDATE FAILURE message, the UTRAN may delete radio links that were included in the IE "Radio Link Addition Information" for addition. The procedure ends on the UTRAN side.

#### 8.3.4.8 Invalid ACTIVE SET UPDATE message

If the ACTIVE SET UPDATE message contains a protocol error causing the variable PROTOCOL_ERROR_REJECT to be set to TRUE according to clause 9, the UE shall perform procedure specific error handling as follows. The UE shall:

1> transmit a ACTIVE SET UPDATE FAILURE message on the uplink DCCH using AM RLC;

1> set the IE "RRC transaction identifier" in the ACTIVE SET UPDATE FAILURE message to the value of "RRC transaction identifier" in the entry for the ACTIVE SET UPDATE message in the table "Rejected transactions" in the variable TRANSACTIONS; and

1> clear that entry;

1> set the IE "failure cause" to the cause value "protocol error";

1> include the IE "Protocol error information" with contents set to the value of the variable PROTOCOL_ERROR_INFORMATION;

1> when the ACTIVE SET UPDATE FAILURE message has been delivered to lower layers for transmission:

2> continue with any ongoing processes and procedures as if the invalid ACTIVE SET UPDATE message has not been received;

2> and the procedure ends.

#### 8.3.4.9 Reception of an ACTIVE SET UPDATE message in wrong state

If the UE is in another state than CELL_DCH state upon reception of the ACTIVE SET UPDATE message, the UE shall perform procedure specific error handling as follows. The UE shall:

1> transmit a ACTIVE SET UPDATE FAILURE message on the uplink DCCH using AM RLC;

1> set the IE "RRC transaction identifier" in the ACTIVE SET UPDATE FAILURE message to the value of "RRC transaction identifier" in the entry for the ACTIVE SET UPDATE message in the table "Accepted transactions" in the variable TRANSACTIONS; and

1> clear that entry;

1> set the IE "failure cause" to the cause value "protocol error";

1> include the IE "Protocol error information" with the IE "Protocol error cause" set to "Message not compatible with receiver state";

1> when the ACTIVE SET UPDATE FAILURE message has been delivered to lower layers for transmission:

2> continue with any ongoing processes and procedures as if the ACTIVE SET UPDATE message has not been received;

2> and the procedure ends.

## 8.3.5 Hard handover

When performing hard handover with change of frequency, the UE shall:

1> stop all intra-frequency and inter-frequency measurement reporting on the cells listed in the variable CELL_INFO_LIST. Each stopped measurement is restarted when a MEASUREMENT CONTROL message is received with the corresponding measurement identity.

### 8.3.5.1 Timing re-initialised hard handover

#### 8.3.5.1.1 General

The purpose of the timing re-initialised hard handover procedure is to remove all the RL(s) in the active set and establish new RL(s) along with a change in the CFN in the UE according to the SFN of the target cell.(see subclause 8.5.15).

NOTE: During the hard-handover procedure, the UE will align the timing of the uplink transmission as specified in [26].

This procedure is initiated when UTRAN does not know the target SFN timing before hard handover.

#### 8.3.5.1.2 Initiation

Timing re-initialised hard handover initiated by the UTRAN is normally performed by using the procedure "Physical channel reconfiguration" (subclause 8.2.6), but may also be performed by using either one of the following procedures:

- "radio bearer establishment" (subclause 8.2.1);
- "Radio bearer reconfiguration" (subclause 8.2.2);
- "Radio bearer release" (subclause 8.2.3); or
- "Transport channel reconfiguration" (subclause 8.2.4).

In this case of a timing re-initialised hard handover, UTRAN should include the IE "Default DPCH Offset Value" and:

1> in FDD mode:

2> set "Default DPCH Offset Value" and "DPCH frame offset" respecting the following relation

$$(\text{Default DPCH Offset Value}) \bmod 38400 = \text{DPCH frame offset}_j$$

3> where *j* indicates the first radio link listed in the message and the IE values used are the Actual Values of the IEs as defined in clause 11.

If the IE "Default DPCH Offset Value" is included, the UE shall:

1> in FDD mode:

2> if the above relation between "Default DPCH Offset Value" and "DPCH frame offset" is not respected:

3> set the variable INVALID_CONFIGURATION to true.

If the IE "Default DPCH Offset Value" is not included, the UE shall:

1> set the variable INVALID_CONFIGURATION to true.

### 8.3.5.2 Timing-maintained hard handover

#### 8.3.5.2.1 General

The purpose of the Timing-maintained hard handover procedure is to remove all the RL(s) in the active set and establish new RL(s) while maintaining the CFN in the UE.

NOTE: During the hard-handover procedure, the UE will align the timing of the uplink transmission as specified in [26].

This procedure can be initiated only if UTRAN knows the target SFN timing before hard handover. The target SFN timing can be known by UTRAN in the following 2 cases:

- UE reads SFN when measuring "Cell synchronisation information" and sends it to the UTRAN in MEASUREMENT REPORT message.
- UTRAN internally knows the time difference between the cells.

#### 8.3.5.2.2 Initiation

Timing-maintained hard handover initiated by the network is normally performed by using the procedure "Physical channel reconfiguration" (subclause 8.2.6), but may also be performed by using either one of the following procedures:

- "radio bearer establishment" (subclause 8.2.1);
- "Radio bearer reconfiguration" (subclause 8.2.2);
- "Radio bearer release" (subclause 8.2.3); or
- "Transport channel reconfiguration" (subclause 8.2.4).

In this case of a timing maintained hard handover procedure the UTRAN should not include the IE "Default DPCH Offset Value".

If the IE "Default DPCH Offset Value" is included, the UE shall:

1> ignore the IE "Default DPCH Offset Value".

## 8.3.6 Inter-RAT handover to UTRAN




**Figure 8.3.6-1: Inter-RAT handover to UTRAN, successful case**

### 8.3.6.1 General

The purpose of the inter-RAT handover procedure is to, under the control of the network, transfer a connection between the UE and another radio access technology (e.g. GSM) to UTRAN.

### 8.3.6.2 Initiation

The procedure is initiated when a radio access technology other than UTRAN, e.g. GSM, using radio access technology-specific procedures, orders the UE to make a handover to UTRAN.

A HANDOVER TO UTRAN COMMAND message is sent to the UE via the radio access technology from which inter-RAT handover is performed.

In case UTRAN decides to uses a predefined or default radio configuration that is stored in the UE, it should include the following information in the HANDOVER TO UTRAN COMMAND message.

- the IE "New U-RNTI" to be assigned;
- the IE "Predefined configuration identity", to indicate which pre-defined configuration of RB, transport channel and physical channel parameters shall be used; or
- the IE "Default configuration mode" and IE "Default configuration identity", to indicate which default configuration of RB, transport channel and physical channel parameters shall be used;
- PhyCH information elements.

NOTE 1: When using a predefined or default configuration during handover to UTRAN, UTRAN can only assign values of IEs "New U-RNTI" and "scrambling code" that are within the special subranges defined exclusively for this procedure. UTRAN may re- assign other values after completion of the handover procedure.

NOTE 2: When using a predefined or default configuration during handover to UTRAN, fewer IEs are signalled; when using this signalling option some parameters e.g. concerning compressed mode, DSCH can not be configured. In this case, the corresponding functionality can not be activated immediately.

NOTE 3: When using a predefined or default configuration, the HANDOVER TO UTRAN COMMAND should not include more than one radio link. If UTRAN includes more than one radio link in the HANDOVER TO UTRAN COMMAND using a predefined or default configuration, the UE behaviour is unspecified.

In case UTRAN does not use a predefined radio configuration that is stored in the UE, it should include the following information in the HANDOVER TO UTRAN COMMAND message.

- the IE "New U-RNTI" to be assigned;
- the complete set of RB, TrCH and PhyCH information elements to be used.

### 8.3.6.3 Reception of HANDOVER TO UTRAN COMMAND message by the UE

The UE shall be able to receive a HANDOVER TO UTRAN COMMAND message and perform an inter-RAT handover, even if no prior UE measurements have been performed on the target UTRAN cell and/or frequency.

The UE shall act upon all received information elements as specified in subclause 8.6, unless specified otherwise in the following.

The UE may:

1> maintain a list of the set of cells to which the UE has Radio Links if the IE "Cell ID" is present.

The UE shall:

1> store a U-RNTI value (32 bits), which is derived by the IEs "SRNC identity" (12 bits) and "S-RNTI 2" (10 bits) included in IE "U-RNTI-short". In order to produce a full size U-RNTI value, a full size "S-RNTI" (20 bits) shall be derived by padding the IE "S-RNTI 2" with 10 zero bits in the most significant positions; and

1> initialise the variable ESTABLISHED_SIGNALLING_CONNECTIONS with the signalling connections that remains after the handover according to the specifications of the source RAT;

1> initialise the variable UE_CAPABILITIES_TRANSFERRED with the UE capabilities that have been transferred to the network up to the point prior to the handover, if any;

1> initialise the variable TIMERS_AND_CONSTANTS to the default values and start to use those timer and constants values;

1> if IE "Specification mode" is set to "Preconfiguration" and IE "Preconfiguration mode" is set to "Predefined configuration":

2> initiate the radio bearer and transport channel configuration in accordance with the predefined parameters identified by the IE "Predefined configuration identity";

2> initiate the physical channels in accordance with the predefined parameters identified by the IE "Predefined radio configuration identity" and the received physical channel information elements;

2> store information about the established radio access bearers and radio bearers according to the IE "Predefined configuration identity"; and

2> set the IE "RAB Info Post" in the variable ESTABLISHED_RABS and the IE "Re-establishment timer" in the IE "RAB Info" in the variable ESTABLISHED_RABS to "useT314".

1> if IE "Specification mode" is set to "Preconfiguration" and IE "Preconfiguration mode" is set to "Default configuration":

2> initiate the radio bearer and transport channel configuration in accordance with the default parameters identified by the IE "Default configuration mode" and IE "Default configuration identity";

2> initiate the physical channels in accordance with the default parameters identified by the IE "Default configuration mode" and IE "Default configuration identity" and the received physical channel information elements;

NOTE: IE "Default configuration mode" specifies whether the FDD or TDD version of the default configuration shall be used.

2> set the IE "RAB Info Post" in the variable ESTABLISHED_RABS and the IE "Re-establishment timer" in the IE "RAB Info" in the variable ESTABLISHED_RABS to "useT314".

1> if IE "Specification mode" is set to "Preconfiguration":

2> use the following values for parameters that are neither signalled within the HANDOVER TO UTRAN COMMAND message nor included within pre-defined or default configuration:

3> 0 dB for the power offset $P_{Pilot\text{-}DPDCH}$ bearer in FDD;

3> calculate the Default DPCH Offset Value using the following formula:

3> in FDD:

Default DPCH Offset Value = (SRNTI 2 mod 600) * 512

3> in TDD:

Default DPCH Offset Value = (SRNTI 2 mod 7)

3> handle the above Default DPCH Offset Value as if an IE with that value was included in the message, as specified in subclause 8.6.6.21.

1> if IE "Specification mode" is set to "Complete specification":

2> initiate the radio bearer, transport channel and physical channel configuration in accordance with the received radio bearer, transport channel and physical channel information elements.

1> perform an open loop estimation to determine the UL transmission power according to subclause 8.5.3;

1> set the IE "START" for each CN domain, in the IE "START list" in the HANDOVER TO UTRAN COMPLETE message equal to the START value for each CN domain stored in the USIM if the USIM is present, or as stored in the UE for each CN domain if the SIM is present;

NOTE: Keys received while in another RAT are not regarded as "new" (i.e.do not trigger the actions in subclause 8.1.12.3.1) in a subsequent security mode control procedure in UTRAN, irrespective of whether the keys are already being used in the other RAT or not. If the UE has received new keys in the other RAT before handover, then the START values in the USIM (sent in the HANDOVER TO UTRAN COMPLETE message and in the INTER_RAT_HANDOVER_INFO sent to the BSS while in the other RAT) will not reflect the receipt of these new keys
If ciphering has been activated in the other RAT, then during the first security mode control procedure following the Inter-RAT handover to UTRAN procedure, UE activates integrity protection using the integrity key of the same key set as used in the other RAT. The term "used key set" denotes the key set that was stored on USIM/SIM at the last successfully completed RRC Security Mode Control (UTRAN), RR Cipher Mode Control procedure or GMM Authentication and Ciphering procedure (GERAN) after entering connected mode in UTRAN or GERAN.
If ciphering has not been activated in the other RAT, then. at a subsequent security mode control procedure in UTRAN, UE activates ciphering and/or integrity protection using the key set stored in the USIM/SIM.

1> set the value of "THRESHOLD" in the variable "START_THRESHOLD" to the 20 MSBs of the value stored in the USIM [50] for the maximum value of START for each CN Domain, or to the default value in [40] if the SIM is present;

1> if ciphering has been activated in the radio access technology from which inter- RAT handover is performed:

2> for the CN domain included in the IE "CN domain identity" which is included in the IE "RAB info" of the IE "RAB information to setup", or the CS domain when these IEs are not present:

3> set the variable LATEST_CONFIGURED_CN_DOMAIN to the value indicated in the IE "CN domain identity", or to the CS domain when this IE is not present;

3> set the 20 MSB of the HFN component of the COUNT-C variable for all radio bearers using RLC-TM and all signalling radio bearers to the "START" value included in the IE "UE security information" in the variable "INTER_RAT_HANDOVER_INFO_TRANSFERRED";

3> set the remaining LSBs of the HFN component of COUNT-C for all radio bearers using RLC-TM and all signalling radio bearers to zero;

3> not increment the HFN component of COUNT-C for radio bearers using RLC-TM, i.e. keep the HFN value fixed without incrementing every CFN cycle;

3> set the CFN component of the COUNT-C variable to the value of the CFN as calculated in subclause 8.5.15;

3> set the IE "Status" in the variable CIPHERING_STATUS to "Started";

3> apply the algorithm according to IE "Ciphering Algorithm" with the ciphering key of the key set used in the other RAT prior to handover and apply ciphering immediately upon reception of the HANDOVER TO UTRAN COMMAND.

NOTE: The term "used key set" denotes the key set that was stored on USIM/SIM at the last successfully completed RRC Security Mode Control (UTRAN) or RR Cipher Mode Control procedures (GERAN) after entering connected mode in UTRAN or GERAN.
If ciphering has been activated in the radio access technology from which inter RAT handover is performed, UTRAN should not include the IE "Ciphering mode info" in the SECURITY MODE COMMAND message that starts Integrity protection.

1> if ciphering has not been activated in the radio access technology from which inter-RAT handover is performed:

2> for the CN domain(s) included in the IE "CN domain identity" which is included in the IE "RAB info" of the IE "RAB information to setup", or the CS domain when these IEs are not present:

3> set the IE "Status" in the variable CIPHERING_STATUS to "Not Started".

If the UE succeeds in establishing the connection to UTRAN, it shall:

1> if CN domain is set to CS domain only indicate to upper layers that no CN system information is available for any domain other than the CS domain;

1> if CN domain is set to PS domain only indicate to upper layers that no CN system information is available for any domain other than the PS domain;

NOTE: After the handover has been completed, the UTRAN should provide the UE with the CN system information of the CN domain to which the UE has no signalling connection as soon as possible, in order not to delay access to that CN domain.

1> if the USIM or SIM is present:

2> set the START value stored in the USIM [50] if present, and as stored in the UE if the SIM is present for any CN domain to the value "THRESHOLD" of the variable START_THRESHOLD.

1> if the IE "Status" in the variable CIPHERING_STATUS of a CN domain is set to "Started" and transparent mode radio bearers have been established by this procedure for that CN domain:

2> include the IE "COUNT-C activation time" in the response message and specify a CFN value for this IE other than the default, "Now", that is a multiple of 8 frames (CFN mod 8 =0) and lies at least 200 frames ahead of the CFN in which the response message is first transmitted;

2> at the CFN value as indicated in the response message in the IE "COUNT-C activation time" for radio bearers using RLC-TM:

3> set the 20 MSB of the HFN component of the COUNT-C variable common for all transparent mode radio bearers of this CN domain to the START value as indicated in the IE "START list" of the response message for the relevant CN domain; and

3> set the remaining LSBs of the HFN component of COUNT-C to zero;

3> increment the HFN component of the COUNT-C variable by one even if the "COUNT-C activation time" is equal to zero;

3> set the CFN component of the COUNT-C to the value of the IE "COUNT-C activation time" of the response message. The HFN component and the CFN component completely initialise the COUNT-C variable;

3> step the COUNT-C variable, as normal, at each CFN value. The HFN component is no longer fixed in value but incremented at each CFN cycle.

1> if the IE "Status" in the variable CIPHERING_STATUS of a CN domain is set to "Not Started" and transparent mode radio bearers have been established by this procedure for that CN domain:

2> initialise the 20 MSB of the HFN component of COUNT-C common for all transparent mode radio bearers of this CN domain with the START value as indicated in the IE "START list" of the response message for the relevant CN domain;

2> set the remaining LSBs of the HFN component of COUNT-C to zero;

2> do not increment the COUNT-C value common for all transparent mode radio bearers for this CN domain.

1> transmit a HANDOVER TO UTRAN COMPLETE message on the uplink DCCH, using, if ciphering has been started, the new ciphering configuration;

1> when the HANDOVER TO UTRAN COMPLETE message has been submitted to lower layers for transmission:

2> enter UTRA RRC connected mode in state CELL_DCH;

2> initialise variables upon entering UTRA RRC connected mode as specified in subclause 13.4;

2> update the variable UE_CAPABILITY_TRANSFERRED with the UE capabilities stored in the variable INTER_RAT_HANDOVER_INFO_TRANSFERRED;

2> for all radio bearers using RLC-AM or RLC-UM:

3> set the 20 MSB of the HFN component of the uplink and downlink COUNT-C variable to the START value indicated in the IE "START list" of the response message for the relevant CN domain; and

3> set the remaining LSBs of the HFN component of COUNT-C to zero;

3> increment the HFN component of the COUNT-C variable by one;

3> start incrementing the COUNT-C values.

1> and the procedure ends.

### 8.3.6.4 Invalid Handover to UTRAN command message

If the UE receives a HANDOVER TO UTRAN COMMAND message, which contains a protocol error causing the variable PROTOCOL_ERROR_REJECT to be set to TRUE according to clause 9, the UE shall perform procedure specific error handling according to the source radio access technology. The UE shall:

1> if allowed by the source RAT:

2> transmit an RRC FAILURE INFO message to the source radio access technology; and

2> include the IE "Protocol error information" with contents set to the value of the variable PROTOCOL_ERROR_INFORMATION;

1> Other details may be provided in the specifications related to the source radio access technology.

NOTE: The other RAT may include the above diagnostics information in a subsequent handover request towards the same RNC.

### 8.3.6.4a Unsupported configuration in HANDOVER TO UTRAN COMMAND message

If the UE does not support the configuration included in the HANDOVER TO UTRAN COMMAND message, e.g., the message includes a pre-defined configuration that the UE has not stored, the UE shall:

1> continue the connection using the other radio access technology; and

1> indicate the failure to the other radio access technology.

### 8.3.6.5 UE fails to perform handover

If the UE does not succeed in establishing the connection to UTRAN, it shall:

1> terminate the procedure including release of the associated resources;

1> resume the connection used before the handover; and

1> indicate the failure to the other radio access technology.

Upon receiving an indication about the failure from the other radio access technology, UTRAN should release the associated resources and the context information concerning this UE.

#### 8.3.6.6 Reception of message HANDOVER TO UTRAN COMPLETE by the UTRAN

Upon receiving a HANDOVER TO UTRAN COMPLETE message, UTRAN should consider the inter-RAT handover procedure as having been completed successfully and indicate this to the Core Network.

### 8.3.7 Inter-RAT handover from UTRAN

**Figure 8.3.7-1: Inter-RAT handover from UTRAN, successful case**




**Figure 8.3.7-2: Inter-RAT handover from UTRAN, failure case**

#### 8.3.7.1 General

The purpose of the inter-RAT handover procedure is to, under the control of the network, transfer a connection between the UE and UTRAN to another radio access technology (e.g. GSM). This procedure may be used in CELL_DCH state. This procedure may be used to perform CS handover which applies when no RABs are established or when the established RABs are only in the CS domain or when the established RABs are in both CS and PS domains. This procedure may be used to perform PS handover which applies when no RABs are established or when the established RABs are only in the PS domain.

#### 8.3.7.2 Initiation

The procedure is initiated when UTRAN orders a UE in CELL_DCH state, to make a handover to a radio access technology other than UTRAN, e.g. GSM.

To initiate the procedure, UTRAN sends a HANDOVER FROM UTRAN COMMAND message.

### 8.3.7.3 Reception of a HANDOVER FROM UTRAN COMMAND message by the UE

The UE shall be able to receive a HANDOVER FROM UTRAN COMMAND message and perform an inter-RAT handover, even if no prior UE measurements have been performed on the target cell.

The UE shall:

1> if the UE has a pending "TGPS reconfiguration CFN" at the activation time received in the HANDOVER FROM UTRAN COMMAND the UE may:

2> abort the pending CM activation;

2> set the CM_PATTERN_ACTIVATION_ABORTED to TRUE.

1> otherwise:

2> set the CM_PATTERN_ACTIVATION_ABORTED to FALSE.

1> establish the connection to the target radio access technology, by using the contents of the IE "Inter-RAT message". This IE contains a message specified in another standard, as indicated by the IE "System type", and carries information about the candidate/ target cell identifier(s) and radio parameters relevant for the target radio access technology. The correspondence between the value of the IE "System type", the standard to apply and the message contained within IE "Inter RAT message" is shown in the following:

| Value of the IE "System type" | Standard to apply | Inter RAT Message |
|---|---|---|
| GSM | GSM TS 04.18, version 8.5.0 or later, or 3GPP TS 44.018<br><br>3GPP TS 44.060, version 6.13.0 or later | HANDOVER COMMAND<br><br>PS HANDOVER COMMAND |
| GERAN Iu | 3GPP TS 44.118 | RADIO BEARER RECONFIGURATION |
| cdma2000 | TIA/EIA/IS-2000 or later, TIA/EIA/IS-833 or later, TIA/EIQ/IS-834 or later | |

1> if the IE "System type" has the value "GSM" or "GERAN Iu":

2> if the IE "Frequency band" has the value "GSM /DCS 1800 band used":

3> set the BAND_INDICATOR [45] to "ARFCN indicates 1800 band".

2> if the IE "Frequency band" has the value " GSM /PCS 1900 band used":

3> set the BAND_INDICATOR [45] to "ARFCN indicates 1900 band".

1> apply the "Inter RAT Message" according to the "standard to apply" in the table above.

1> if the IE "RAB information List" is included in the HANDOVER FROM UTRAN COMMAND message:

2> if the IE "RAB information List" includes one IE "RAB Info" with the IE "CN domain Identity" set to "CS domain":

3> connect upper layer entities corresponding to the indicated CS domain RAB to the radio resources indicated in the inter-RAT message.

2> if the IE "RAB information List" includes one IE "RAB Info" with the IE "CN domain Identity" set to "PS domain":

3> connect upper layer entities corresponding to the indicated PS domain RAB to the radio resources indicated in the inter-RAT message.

3> if the "System type" is "GSM":

4> use the contents of the IE "GERAN system information" as the system information to begin access on the target GERAN cell.

NOTE1: In this version of the specification the maximum number of CS domain RABs which may be included in the IE "RAB information List" is limited to 1.

NOTE2: In handover to GERAN *Iu mode*, the RAB information is included in the RADIO BEARER RECONFIGURATION message specified in [53].

NOTE3: Requirements concerning the establishment of the radio connection towards the other radio access technology and the signalling procedure are outside the scope of this specification.

NOTE4: The UE may ignore the IE "NAS synchronisation indicator" if included in the HANDOVER FROM UTRAN COMMAND message;

NOTE5: The UE behaviour is undefined if the IE "Re-establishment timer" in the IE "RAB info" indicates a timer different from the timer currently configured for this RAB.

NOTE6: The IE "GERAN System Information" is constructed in the same way as in 2G to 2G PS Handover in [44].

#### 8.3.7.4 Successful completion of the inter-RAT handover

Upon successfully completing the handover, UTRAN should:

1> release the radio connection; and

1> remove all context information for the concerned UE.

Upon successfully completing the handover, the UE shall:

1> if inter-RAT handover to GERAN *Iu mode* is performed:

2> perform the actions on reception of the RADIO BEARER RECONFIGURATION message as specified in [53].

1> if inter-RAT handover to GERAN *Iu mode* is performed and if there are any NAS messages for which the successful delivery of the INITIAL DIRECT TRANSFER message or UPLINK DIRECT TRANSFER message on signalling radio bearer RB3 or signalling radio bearer RB4 has not yet been confirmed by RLC; or

1> if inter-RAT handover to other RAT than GERAN *Iu mode* is performed and if there are any NAS messages with the IE "CN domain identity" set to "CS domain" for which the successful delivery of the INITIAL DIRECT TRANSFER message or UPLINK DIRECT TRANSFER message on signalling radio bearer RB3 or signalling radio bearer RB4 that have not yet been confirmed by RLC:

2> retransmit those NAS messages to the network on the newly established radio connection to the target radio access technology.

1> clear or set variables upon leaving UTRA RRC connected mode as specified in subclause 13.4.

NOTE: The release of the UMTS radio resources is initiated from the target RAT.

#### 8.3.7.5 UE fails to complete requested handover

If the UE does not succeed in establishing the connection to the target radio access technology, it shall:

1> revert back to the UTRA configuration;

1> if the CM_PATTERN_ACTIVATION_ABORTED flag is not set to TRUE:

2> establish the UTRA physical channel(s) (including HS-DSCH and E-DCH related channels) used at the time for reception of HANDOVER FROM UTRAN COMMAND;

2> perform the physical layer synchronisation procedure A as specified in [29] (FDD only);

2> apply power control preamble according to [26] during the number of frames indicated in the IE "PC preamble" in the variable LATEST_CONFIGURED_SRB_DELAY_AND_PC_PREAMBLE; and

2> then not send any data on signalling radio bearers RB0 to RB4 during the number of frames indicated in the IE "SRB delay" in the variable LATEST_CONFIGURED_SRB_DELAY_AND_PC_PREAMBLE or while the physical channel is not considered established.

1> if the CM_PATTERN_ACTIVATION_ABORTED flag is set to TRUE or if the UE does not succeed to establish the UTRA physical channel(s):

2> perform a cell update procedure according to subclause 8.3.1 with cause "Radio link failure";

2> when the cell update procedure has completed successfully:

3> proceed as below.

1> transmit the HANDOVER FROM UTRAN FAILURE message setting the information elements as specified below:

2> include the IE "RRC transaction identifier"; and

2> set it to the value of "RRC transaction identifier" in the entry for the HANDOVER FROM UTRAN COMMAND message in the table "Accepted transactions" in the variable TRANSACTIONS; and

2> clear that entry;

2> set the IE "Inter-RAT handover failure" to "physical channel failure".

1> When the HANDOVER FROM UTRAN FAILURE message has been submitted to lower layer for transmission:

2> the procedure ends.

#### 8.3.7.6 Invalid HANDOVER FROM UTRAN COMMAND message

If the IE "Inter-RAT message" received within the HANDOVER FROM UTRAN COMMAND message does not include a valid inter RAT handover message in accordance with the protocol specifications for the target RAT, the UE shall perform procedure specific error handling as follows. The UE shall:

1> set the IE "failure cause" to the cause value "Inter-RAT protocol error";

1> include the IE "Inter-RAT message" in accordance with the specifications applicable to the other RAT;

1> transmit a HANDOVER FROM UTRAN FAILURE message on the uplink DCCH using AM RLC;

1> when the transmission of the HANDOVER FROM UTRAN FAILURE message has been confirmed by RLC:

2> continue with any ongoing processes and procedures as if the invalid HANDOVER FROM UTRAN COMMAND message has not been received;

2> and the procedure ends.

If the HANDOVER FROM UTRAN COMMAND message contains a protocol error causing the variable PROTOCOL_ERROR_REJECT to be set to TRUE according to clause 9, the UE shall perform procedure specific error handling as follows. The UE shall:

1> set the IE "RRC transaction identifier" in the HANDOVER FROM UTRAN FAILURE message to the value of "RRC transaction identifier" in the entry for the HANDOVER FROM UTRAN COMMAND message in the table "Rejected transactions" in the variable TRANSACTIONS; and

1> clear that entry;

1> set the IE "failure cause" to the cause value "protocol error";

1> include the IE "Protocol error information" with contents set to the value of the variable PROTOCOL_ERROR_INFORMATION;

1> transmit a HANDOVER FROM UTRAN FAILURE message on the uplink DCCH using AM RLC;

1> when the HANDOVER FROM UTRAN FAILURE message has been submitted to lower layers for transmission:

2> continue with any ongoing processes and procedures as if the invalid HANDOVER FROM UTRAN COMMAND message has not been received;

2> and the procedure ends.

### 8.3.7.7 Reception of an HANDOVER FROM UTRAN FAILURE message by UTRAN

Upon receiving an HANDOVER FROM UTRAN FAILURE message, UTRAN may initiate the release the resources in the target radio access technology.

### 8.3.7.8 Unsupported configuration in HANDOVER FROM UTRAN COMMAND message

If:

- the UTRAN instructs the UE to perform a non-supported handover scenario; or
- the UTRAN instructs the UE to use a non-supported configuration; or
- the UE does not support PS Handover to GERAN, and the inter-RAT handover to other RAT than GERAN *Iu mode* is performed and the IE "RAB information List" is included in the HANDOVER FROM UTRAN COMMAND message and this IE does not include any IE "RAB Info" with the IE "CN domain Identity" set to "CS domain"; or
- the HANDOVER FROM UTRAN COMMAND message includes the IE "RAB information List" and includes at least one IE "RAB Info" with the IE "CN domain Identity" set to "PS domain", and the IE "GERAN System Information" is not present:

the UE shall:

1> transmit a HANDOVER FROM UTRAN FAILURE message, setting the information elements as specified below:

2> include the IE "RRC transaction identifier"; and

2> set it to the value of "RRC transaction identifier" in the entry for the HANDOVER FROM UTRAN COMMAND message in the table "Accepted transactions" in the variable TRANSACTIONS; and

2> clear that entry;

2> set the IE "Inter-RAT handover failure" to "configuration unacceptable";

2> when the HANDOVER FROM UTRAN FAILURE message has been submitted to lower layers for transmission:

3> resume normal operation as if the invalid HANDOVER FROM UTRAN COMMAND message has not been received;

3> and the procedure ends.

### 8.3.7.8a Reception of HANDOVER FROM UTRAN COMMAND message by UE in CELL_FACH

If the UE receives HANDOVER FROM UTRAN COMMAND while in CELL_FACH, the UE shall:

1> transmit a HANDOVER FROM UTRAN FAILURE message, setting the information elements as specified below:

2> include the IE "RRC transaction identifier"; and

2> set it to the value of "RRC transaction identifier" in the entry for the HANDOVER FROM UTRAN COMMAND message in the table "Accepted transactions" in the variable TRANSACTIONS; and

2> clear that entry;

2> set the IE "Inter-RAT handover failure" to "protocol error", include IE "Protocol error information"; and

2> set the value of IE "Protocol error cause" to "Message not compatible with receiver state";

2> when the HANDOVER FROM UTRAN FAILURE message has been submitted to lower layers for transmission:

3> resume normal operation as if the invalid HANDOVER FROM UTRAN COMMAND message has not been received;

3> and the procedure ends.

## 8.3.8 Inter-RAT cell reselection to UTRAN

### 8.3.8.1 General

The purpose of the inter-RAT cell reselection procedure to UTRAN is to transfer, under the control of the UE and to some extent the source radio access technology, a connection between the UE and another radio access technology (e.g. GSM/GPRS, but not UTRAN) to UTRAN.

### 8.3.8.2 Initiation

When the UE makes an inter-RAT cell reselection to UTRAN according to the criteria specified in [4], it shall initiate this procedure. The inter-RAT cell reselection made by the UE may use system information broadcast from the source radio access technology or UE dedicated information.

If the NAS procedures associated with inter-system change specified in [5] require the establishment of an RRC connection, the UE shall:

1> set the variable ESTABLISHMENT_CAUSE to "Inter-RAT cell reselection";

NOTE: This value of ESTABLISHMENT_CAUSE has priority over the cause requested by upper layers.

1> initiate an RRC connection establishment procedure as specified in subclause 8.1.3;

1> after initiating an RRC connection establishment:

2> release all resources specific to the other radio access technology.

If the NAS procedures associated with inter-system change specified in [5] do not require the establishment of an RRC connection, the UE shall:

1> enter idle mode in the target cell without accessing the cell; and

1> release all resources specific to the other radio access technology.

### 8.3.8.2a Initiation of inter-RAT cell reselection from GERAN *Iu mode*

When the UE performs an inter-RAT cell reselection from GERAN *Iu mode* Cell_Shared state, the UE shall:

1> initiate the cell update procedure as specified for the cell reselection case in CELL_FACH and CELL_PCH states, using the cause "cell reselection"and setting the G-RNTI in the IE "U-RNTI".

When the UE performs an inter-RAT cell reselection from GERAN *Iu mode* GRA_PCH state, the UE shall:

1> compare the GRA identity which the MS had been assigned to in GERAN against the URA identities which are broadcast in the UTRAN cell.

1> If the assigned GRA identity is not present in the list of URA identities that are broadcast in the UTRAN cell:

2> initiate the URA update procedure as specified for the URA reselection case in URA_PCH state, using the cause "change of URA" and setting the G-RNTI in the IE "U-RNTI".

The UE shall:

1> set the following variables equal to the corresponding variables in GERAN *Iu mode:*

CIPHERING_STATUS

ESTABLISHED_RABS

ESTABLISHED_SIGNALLING_CONNECTIONS

INTEGRITY_PROTECTION_INFO

INTER_RAT_HANDOVER_INFO_TRANSFERRED

LATEST_CONFIGURED_CN_DOMAIN

START_THRESHOLD

UE_CAPABILITY_TRANSFERRED.

1> set the new uplink and downlink HFN of RB2 to $MSB_{20}$(MAX(uplink HFN of RB2, downlink HFN of RB2)).

NOTE: $MSB_{20}$() operation provides the HFN mapping from GERAN *Iu mode* to UTRAN. In GERAN *Iu mode* the length of HFN component of the COUNT-C of RB2 is longer than 20 bits.

1> initialise the variable TIMERS_AND_CONSTANTS to the default values and start to use those timer and constants values.

#### 8.3.8.3 UE fails to complete an inter-RAT cell reselection

If the inter-RAT cell reselection fails before the UE has initiated the RRC connection establishment the UE may return back to the other radio access technology.

If the RRC connection establishment fails, the UE shall enter idle mode.

#### 8.3.8.3a UE fails to complete an inter-RAT cell reselection from GERAN *Iu mode*

When the UE performs an inter-RAT cell reselection from GERAN *Iu mode* to UTRAN, and the cell reselection fails:

1> the UE may return back to the GERAN *Iu mode* state from which it initiated the inter-RAT cell reselection.

### 8.3.9 Inter-RAT cell reselection from UTRAN

#### 8.3.9.1 General

The purpose of the inter-RAT cell reselection procedure from UTRAN is to transfer, under the control of the UE and to some extent the UTRAN, a connection between the UE and UTRAN to another radio access technology (e.g. GSM/GPRS).

#### 8.3.9.2 Initiation

This procedure is applicable in states CELL_FACH, CELL_PCH or URA_PCH.

When the UE based on received system information makes a cell reselection to a radio access technology other than UTRAN, e.g. GSM/GPRS, according to the criteria specified in [4], the UE shall:

1> If the NAS procedures associated with inter-system change specified in [5] require the establishment of a connection:

2> initiate the establishment of a connection to the target radio access technology according to its specifications.

#### 8.3.9.2a Initiation of inter-RAT cell reselection to GERAN *Iu mode*

When the UE in CELL_PCH or CELL_FACH state performs an inter-RAT cell reselection to GERAN *Iu mode*, according to the criteria specified in [4], the UE shall:

1> initiate the cell update procedure according to 3GPP TS 44.118 [53], setting the U-RNTI in the IE "G-RNTI".

When the UE in URA_PCH state performs an inter-RAT cell reselection to GERAN *Iu mode*, according to the criteria specified in [4], the UE shall:

1> compare the URA identity which the UE had been assigned to in UTRAN against the GRA identities which are broadcast in the GERAN cell;

1> If the assigned URA identity is not present in the list of GRA identities that are broadcast in the GERAN cell:

2> initiate the GRA update procedure as specified in 3GPP TS 44.118 [53], setting the U-RNTI in the IE "G-RNTI".

#### 8.3.9.3 Successful cell reselection

When the UE has succeeded in reselecting a cell in the target radio access technology, the UE shall:

1> release all UTRAN specific resources.

UTRAN should:

1> release all UE dedicated resources upon indication that the UE has completed a connection establishment to the other radio access technology.

#### 8.3.9.4 UE fails to complete an inter-RAT cell reselection

If the inter-RAT cell reselection fails, the UE shall:

1> resume the connection to UTRAN using the resources used before initiating the inter-RAT cell reselection procedure.

### 8.3.10 Inter-RAT cell change order to UTRAN

#### 8.3.10.1 General

The purpose of the inter-RAT cell change order to UTRAN procedure is to transfer, under the control of the source radio access technology, a connection between the UE and another radio access technology (e.g. GSM/GPRS) to UTRAN.

#### 8.3.10.2 Initiation

The procedure is initiated when a radio access technology other than UTRAN, e.g. GSM/GPRS, using procedures specific for that RAT, orders the UE to change to a UTRAN cell.

NOTE: Within the message used to order the UE to change to a UTRAN cell, the source RAT should specify the identity of the target UTRAN cell as specified in the specifications for that RAT.

The UE shall:

1> set the variable ESTABLISHMENT_CAUSE to "Inter-RAT cell change order";

NOTE: This value of ESTABLISHMENT_CAUSE has priority over the cause requested by upper layers.

1> initiate an RRC connection establishment procedure as specified in subclause 8.1.3.

### 8.3.10.3 UE fails to complete an inter-RAT cell change order

If the inter-RAT cell reselection fails the UE shall return to the other radio access technology and proceed as specified in the appropriate specifications for that RAT.

NOTE 3: The cell change was network ordered. Therefore, failure to change to the target cell should not cause the UE to move to UE- controlled cell selection.

## 8.3.11 Inter-RAT cell change order from UTRAN

**Figure 8.3.11-1: Inter–RAT cell change order from UTRAN**




**Figure 8.3.11-2: Inter-RAT cell change order from UTRAN, failure case**

### 8.3.11.1 General

The purpose of the inter-RAT cell change order procedure is to transfer, under the control of the network, a connection between the UE and UTRAN to another radio access technology (e.g. GSM). This procedure may be used in CELL_DCH and CELL_FACH state. This procedure may be used when no RABs are established or when the established RABs are only from PS domain. This procedure may not be used when there is no PS signalling connection.

### 8.3.11.2 Initiation

The procedure is initiated when UTRAN orders a UE in CELL_DCH or CELL_FACH state, to make a cell change to a radio access technology other than UTRAN, e.g. GSM.

To initiate the procedure, UTRAN sends a CELL CHANGE ORDER FROM UTRAN message.

### 8.3.11.3 Reception of an CELL CHANGE ORDER FROM UTRAN message by the UE

The UE shall be able to receive a CELL CHANGE ORDER FROM UTRAN message and perform a cell change order to another RAT, even if no prior UE measurements have been performed on the target cell.

If the variable ESTABLISHED_SIGNALLING_CONNECTIONS does not include the CN domain identity "PS domain", or if the variable ESTABLISHED_SIGNALLING_CONNECTIONS includes the CN domain identity "CS domain":

1> the UE shall act as if the message was never received.

The UE shall:

1> if the UE has a pending "TGPS reconfiguration CFN" at the activation time received in the CELL CHANGE ORDER FROM UTRAN message the UE may:

2> abort the pending CM activation;

2> set the CM_PATTERN_ACTIVATION_ABORTED to TRUE.

1> otherwise:

2> set the CM_PATTERN_ACTIVATION_ABORTED to FALSE.

1> start timer T309; and

1> establish the connection to the other radio access technology, as specified within IE "Target cell description". This IE specifies the target cell identity, in accordance with the specifications for that other RAT. In case the target cell is a GSM/ GPRS cell, IE "Target cell description" may also include IE "NC mode", which specifies the cell selection mode to be applied in the target cell; and

1> if IE "NC mode" is not included in the CELL CHANGE ORDER FROM UTRAN:

2> retrieve it from the target cell as specified in [43];

2> act upon IE "NC mode" as specified in [43].

1> if the IE "RAB Information List" is included in the CELL CHANGE ORDER FROM UTRAN message:

2> ignore the contents of the IE "RAB Information List".

NOTE: Requirements concerning the establishment of the radio connection towards the other radio access technology and the signalling procedure are outside the scope of this specification. In case of GSM/GPRS proceed according to the procedure Network control cell reselection procedure as specified in [44].

1> if the UE supports UTRAN to GERAN Network Assisted Cell Change, the IE "Geran System Information" is present and the UE is in CELL_DCH state:

2> if according to [44] the IE "GERAN System Information" includes a correct and consistent set of SI or PSI messages:

3> use this information as the system information to begin access on the target GERAN cell.

2> otherwise:

3> ignore the IE "GERAN System Information" and continue the Cell Change Order procedure.

NOTE: The IE "GERAN System Information" is constructed in the same way as in 2G to 2G NACC, i.e. the PSI messages are encoded as such, whereas the SI messages exclude 2 octets of headers, see [44].

### 8.3.11.4 Successful completion of the cell change order

The UE regards the procedure as completed when it has received a successful response from the target RAT, e.g. in case of GSM when it received the response to a (PACKET) CHANNEL REQUEST in the new cell.

Upon successful completion of the cell change order, the UE shall:

1> stop timer T309;

1> clear or set variables upon leaving UTRA RRC connected mode as specified in subclause 13.4.

Upon indication of the UE having successfully completed the cell change order, UTRAN should:

1> release the radio connection; and

1> remove all context information for the concerned UE.

NOTE: The release of the UMTS radio resources is initiated from another RAT.

### 8.3.11.5 Expiry of timer T309 or UE fails to complete requested cell change order

If:

- timer T309 expires prior to the successful establishment of a connection to the target RAT; or
- if the establishment of the connection to the other RAT failed due to other reasons e.g. (random) access failure, rejection due to lack of resources:

the UE shall:

1> if it received the CELL CHANGE ORDER FROM UTRAN message in state CELL_DCH:

2> if the CM_PATTERN_ACTIVATION_ABORTED flag is not set to TRUE:

3> revert back to the UTRA configuration;

3> establish the UTRA physical channel(s) (including HS-DSCH and E-DCH related channels) used at the time for reception of CELL CHANGE ORDER FROM UTRAN.

2> perform the physical layer synchronisation procedure A as specified in [29] (FDD only);

2> apply power control preamble according to [26] during the number of frames indicated in the IE "PC preamble" in the variable LATEST_CONFIGURED_SRB_DELAY_AND_PC_PREAMBLE; and

2> then not send any data on signalling radio bearers RB0 to RB4 during the number of frames indicated in the IE "SRB delay" in the variable LATEST_CONFIGURED_SRB_DELAY_AND_PC_PREAMBLE or while the physical channel is not considered established;

2> if the CM_PATTERN_ACTIVATION_ABORTED flag is set to TRUE or if the UE does not succeed in establishing the UTRA physical channel(s):

3> perform a cell update procedure according to subclause 8.3.1 with cause "Radio link failure";

3> when the cell update procedure has completed successfully:

4> proceed as below.

2> transmit the CELL CHANGE ORDER FROM UTRAN FAILURE message setting the information elements as specified below:

3> include the IE "RRC transaction identifier"; and

3> set it to the value of "RRC transaction identifier" in the entry for the received message in the table "Accepted transactions" in the variable TRANSACTIONS; and

3> clear that entry;

3> set the IE "Inter-RAT change failure" to "physical channel failure".

2> When the CELL CHANGE ORDER FROM UTRAN FAILURE message has been submitted to lower layer for transmission, the procedure ends.

1> if the UE receives the CELL CHANGE ORDER FROM UTRAN message in CELL_FACH state:

2> revert to the cell it was camped on at the reception of the CELL CHANGE ORDER FROM UTRAN message;

2> if the UE is unable to return to this cell:

3> select a suitable UTRA cell according to [4];

3> initiate the cell update procedure according to subclause 8.3.1 using the cause "cell re-selection";

3> when the cell update procedure completed successfully:

4> proceed as below.

2> transmit the CELL CHANGE ORDER FROM UTRAN FAILURE message setting the information elements as specified below:

3> include the IE "RRC transaction identifier"; and

3> set it to the value of "RRC transaction identifier" in the entry for the CELL CHANGE ORDER FROM UTRAN message in the table "Accepted transactions" in the variable TRANSACTIONS; and

3> clear that entry;

3> set the IE "Inter-RAT change failure" to "physical channel failure".

2> When the CELL CHANGE ORDER FROM UTRAN FAILURE message has been submitted to lower layer for transmission:

3> the procedure ends.

### 8.3.11.6 Unsupported configuration in CELL CHANGE ORDER FROM UTRAN message

If the UTRAN instructs the UE to perform a non-supported cell change order scenario or to use a non-supported configuration, the UE shall:

1> transmit a CELL CHANGE ORDER FROM UTRAN FAILURE message, setting the information elements as specified below:

2> include the IE "RRC transaction identifier"; and

2> set it to the value of "RRC transaction identifier" in the entry for the received message in the table "Accepted transactions" in the variable TRANSACTIONS; and

2> clear that entry;

2> set the IE "Inter-RAT change failure" to "configuration unacceptable";

2> when the CELL CHANGE ORDER FROM UTRAN FAILURE message has been submitted to lower layers for transmission:

3> resume normal operation as if the CELL CHANGE ORDER FROM UTRAN message has not been received;

3> and the procedure ends.

### 8.3.11.7 Invalid CELL CHANGE ORDER FROM UTRAN message

If the CELL CHANGE ORDER FROM UTRAN message contains a protocol error causing the variable PROTOCOL_ERROR_REJECT to be set to TRUE according to clause 9, the UE shall perform procedure specific error handling as follows. The UE shall:

1> set the IE "RRC transaction identifier" in the CELL CHANGE ORDER FROM UTRAN FAILURE message to the value of "RRC transaction identifier" in the entry for the CELL CHANGE ORDER FROM UTRAN message in the table "Rejected transactions" in the variable TRANSACTIONS; and

1> clear that entry;

1> set the IE "Inter-RAT change failure" to the cause value "protocol error";

1> include the IE "Protocol error information" with contents set to the value of the variable PROTOCOL_ERROR_INFORMATION;

1> transmit a CELL CHANGE ORDER FROM UTRAN FAILURE message on the uplink DCCH using AM RLC;

1> when the CELL CHANGE ORDER FROM UTRAN FAILURE message has been submitted to lower layers for transmission:

2> resume normal operation as if the invalid CELL CHANGE ORDER FROM UTRAN message has not been received;

2> and the procedure ends.

# 8.4 Measurement procedures

## 8.4.0 Measurement related definitions

UTRAN may control a measurement in the UE either by broadcast of SYSTEM INFORMATION and/or by transmitting a MEASUREMENT CONTROL message.

The following information is used to control the UE measurements and the measurement results reporting:

1. **Measurement identity**: A reference number that should be used by the UTRAN when setting up, modifying or releasing the measurement and by the UE in the measurement report.
2. **Measurement command**: One out of three different measurement commands.
   - Setup: Setup a new measurement.
   - Modify: Modify a previously defined measurement, e.g. to change the reporting criteria.
   - Release: Stop a measurement and clear all information in the UE that are related to that measurement.
3. **Measurement type**: One of the types listed below describing what the UE shall measure.

Presence or absence of the following control information depends on the measurement type

4. **Measurement objects:** The objects on which the UE shall measure measurement quantities, and corresponding object information.
5. **Measurement quantity:** The quantity the UE shall measure on the measurement object. This also includes the filtering of the measurements.
6. **Reporting quantities:** The quantities the UE shall include in the report in addition to the quantities that are mandatory to report for the specific event.
7. **Measurement reporting criteria**: The triggering of the measurement report, e.g. periodical or event-triggered reporting.
8. **Measurement Validity**: Defines in which UE states the measurement is valid.
9. **Measurement reporting mode**: This specifies whether the UE shall transmit the measurement report using AM or UM RLC.
10. **Additional measurement identities**: A list of references to other measurements. When this measurement triggers a measurement report, the UE shall also include the reporting quantities for the measurements referenced by the additional measurement identities.

All these measurement parameters depend on the measurement type and are described in more detail in clause 14.

The different types of measurements are:

- **Intra-frequency measurements**: measurements on downlink physical channels at the same frequency as the active set. A measurement object corresponds to one cell. Detailed description is found in subclause 14.1.
- **Inter-frequency measurements**: measurements on downlink physical channels at frequencies that differ from the frequency of the active set and on downlink physical channels in the active set. A measurement object corresponds to one cell. Detailed description is found in subclause 14.2.
- **Inter-RAT measurements**: measurements on downlink physical channels belonging to another radio access technology than UTRAN, e.g. GSM. A measurement object corresponds to one cell. Detailed description is found in subclause 14.3.

- **Traffic volume measurements**: measurements on uplink traffic volume. A measurement object corresponds to one cell. Detailed description is found in subclause 14.4.

- **Quality measurements**: Measurements of downlink quality parameters, e.g. downlink transport block error rate. A measurement object corresponds to one transport channel in case of BLER. A measurement object corresponds to one timeslot in case of SIR (TDD only). Detailed description is found in subclause 14.5.

- **UE-internal measurements**: Measurements of UE transmission power and UE received signal level. Detailed description is found in subclause 14.6.

- **UE positioning measurements:** Measurements of UE position. Detailed description is found in subclause 14.7.

The UE shall support a number of measurements running in parallel as specified in [19] and [20]. The UE shall also support that each measurement is controlled and reported independently of every other measurement.

Cells that the UE is monitoring are grouped in the UE into three mutually exclusive categories:

1. Cells, which belong to the **active set.** User information is sent from all these cells. In FDD, the cells in the active set are involved in soft handover. In TDD the active set always comprises one cell only. The UE shall only consider active set cells included in the variable CELL_INFO_LIST for measurement; i.e. active set cells not included in the CELL_INFO_LIST shall not be considered in any event evaluation and measurement reporting.

2. Cells, which are not included in the active set, but are included in the CELL_INFO_LIST belong to the **monitored set.**

3. Cells detected by the UE, which are neither in the CELL_INFO_LIST nor in the active set belong to the **detected set.** Reporting of measurements of the detected set is only applicable to intra-frequency measurements made by UEs in CELL_DCH state.

If the IE "Cells for measurement" has been included in a MEASUREMENT CONTROL message, only monitored set cells explicitly indicated for a given intra-frequency (resp. inter-frequency, interRAT) measurement by the IE "Cells for measurement" shall be considered for measurement. If the IE "Cells for measurement" has not been included in a MEASUREMENT CONTROL message, all of the intra-frequency (resp. inter-frequency, inter RAT) cells stored in the variable CELL_INFO_LIST shall be considered for measurement. The IE "Cells for measurement" is not applicable to active set cells or virtual active set cells e.g. when the triggering condition refers to active set cells, the UE shall consider all active set cells in the CELL_INFO_LIST for measurement irrespective if these cells are explicitly indicated by the IE "Cells for measurement".

## 8.4.1 Measurement control

**Figure 8.4.1-1: Measurement Control, normal case**




**Figure 8.4.1-2: Measurement Control, failure case**

#### 8.4.1.1 General

The purpose of the measurement control procedure is to setup, modify or release a measurement in the UE.

#### 8.4.1.2 Initiation

The UTRAN may request a measurement by the UE to be setup, modified or released with a MEASUREMENT CONTROL message, which is transmitted on the downlink DCCH using AM RLC.

The UTRAN should take the UE capabilities into account when a measurement is requested from the UE.

When a new measurement is created, UTRAN should set the IE "Measurement identity" to a value, which is not used for other measurements. UTRAN may use several "Measurement identity" for the same "Measurement type". In case of setting several "Measurement identity" within a same "Measurement type", the measurement object or the list of measurement objects can be set differently for each measurement with different "Measurement identity ".

When a current measurement is modified or released, UTRAN should set the IE "Measurement identity" to the value, which is used for the measurement being modified or released. In case of modifying IEs within a "Measurement identity", it is not needed for UTRAN to indicate the IEs other than modified IEs, and the UE continues to use the current values of the IEs that are not modified. UTRAN should not use "modify" to change the type of measurement stored in the variable MEASUREMENT_IDENTITY for a given measurement identity.

#### 8.4.1.3 Reception of MEASUREMENT CONTROL by the UE

Upon reception of a MEASUREMENT CONTROL message the UE shall perform actions specified in subclause 8.6 unless otherwise specified below.

The UE shall:

1> read the IE "Measurement command";

1> if the IE "Measurement command" has the value "setup":

2> store this measurement in the variable MEASUREMENT_IDENTITY according to the IE "measurement identity", first releasing any previously stored measurement with that identity if that exists;

2> if the measurement type is quality, UE internal, intra-frequency, inter-frequency or inter-RAT:

3> if the UE is in CELL_FACH state:

4> the UE behaviour is not specified.

2> for measurement types "inter-RAT measurement" or "inter-frequency measurement" that require measurements on a frequency other than the actually used frequency:

3> if, according to its measurement capabilities, the UE requires compressed mode to perform that measurement type and after reception of this message a compressed mode pattern sequence with an appropriate measurement purpose is active according to the IE "Current TGPS Status Flag" in UE variable TGPS_IDENTITY; or

3> if, according to its measurement capabilities, the UE does not require compressed mode to perform the measurements on at least one supported band of that measurement type:

4> if the measurement is valid in the current RRC state of the UE:

5> begin measurements according to the stored control information for this measurement identity.

NOTE: The UE is not required to perform measurements on cells for which it needs compressed mode but a suitable compressed mode pattern is not activated.

2> for measurement type "inter-frequency measurement" that requires measurements only on the same frequency as the actually used frequency:

3> if the measurement is valid in the current RRC state of the UE:

4> begin measurements according to the stored control information for this measurement identity.

2> for measurement type "UE positioning measurement":

3> if the UE is in CELL_FACH state:

4> if IE "Positioning Method" is set to "OTDOA":

5> if IE "Method Type" is set to "UE assisted":

6> if IE "UE positioning OTDOA assistance data for UE assisted" is not included:

7> if System Information Block type 15.4 is broadcast:

8> read System Information Block type 15.4.

7> act as specified in subclause 8.6.7.19.2.

5> if IE "Method Type" is set to "UE based":

6> if IE "UE positioning OTDOA assistance data for UE based" is not included:

7> if System Information Block type 15.5 is broadcast:

8> read System Information Block type 15.5.

7> act as specified in subclause 8.6.7.19.2a.

2> for any other measurement type:

3> if the measurement is valid in the current RRC state of the UE:

4> begin measurements according to the stored control information for this measurement identity.

1> if the IE "Measurement command" has the value "modify":

2> for all IEs present in the MEASUREMENT CONTROL message:

3> if a measurement was stored in the variable MEASUREMENT_IDENTITY associated to the identity by the IE "measurement identity":

4> if the measurement type is quality, UE internal, intra-frequency, inter-frequency or inter-RAT:

5> if the UE is in CELL_FACH state:

6> the UE behaviour is not specified.

4> if measurement type is set to "intra-frequency measurement", for any of the optional IEs "Intra-frequency measurement objects list", "Intra-frequency measurement quantity", "Intra-frequency reporting quantity", "Measurement Validity", "report criteria" and "parameters required for each event" (given "report criteria" is set to "intra-frequency measurement reporting criteria") that are present in the MEASUREMENT CONTROL message:

4> if measurement type is set to "inter-frequency measurement", for any of the optional IEs "Inter-frequency measurement quantity", "Inter-frequency reporting quantity", "Measurement Validity", "Inter-frequency set update" and "parameters required for each event" (given "report criteria" is set to either "inter-frequency measurement reporting criteria" or "intra-frequency measurement reporting criteria") that are present in the MEASUREMENT CONTROL message:

4> if measurement type is set to "inter-RAT measurement", for any of the optional IEs "Inter-RAT measurement objects list", "Inter-RAT measurement quantity", and "Inter-RAT reporting quantity" that are present in the MEASUREMENT CONTROL message:

4> if measurement type is set to "UE positioning measurement" and the IE "UE positioning OTDOA assistance data" is present, for any of the optional IEs "UE positioning OTDOA neighbour cell info for UE-assisted", "UE positioning OTDOA reference cell info for UE-assisted", "UE positioning

OTDOA reference cell info for UE-based", "UE positioning OTDOA neighbour cell info for UE-based" and "UE positioning" that are present in the MEASUREMENT CONTROL message:

4> if measurement type is set to "UE positioning measurement" and the IE "UE positioning GPS assistance data" is present, for any of the optional IEs "UE positioning GPS reference time", "UE positioning GPS reference UE position", "UE positioning GPS DGPS corrections", "UE positioning GPS ionospheric model", "UE positioning GPS UTC model", "UE positioning GPS acquisition assistance", "UE positioning GPS real-time integrity" that are present in the MEASUREMENT CONTROL message:

4> if measurement type is set to "traffic volume measurement", for any of the optional IEs "Traffic volume measurement Object", "Traffic volume measurement quantity", "Traffic volume reporting quantity", and"Measurement Validity" that are present in the MEASUREMENT CONTROL message:

4> if measurement type is set to "quality measurement", for the optional IE "Quality reporting quantity" if it is present in the MEASUREMENT CONTROL message:

4> if measurement type is set to "UE internal measurement", for any of the optional IEs "UE internal measurement quantity", and "UE internal reporting quantity" that are present in the MEASUREMENT CONTROL message:

5> replace all instances of the IEs listed above (and all their children) stored in variable MEASUREMENT_IDENTITY associated to the identity indicated by the IE "measurement identity" with the IEs received in the MEASUREMENT CONTROL message;

5> leave all other stored information elements unchanged in the variable MEASUREMENT_IDENTITY.

3> otherwise:

4> set the variable CONFIGURATION_INCOMPLETE to TRUE.

2> if measurement type is set to "inter-frequency measurement":

3> if "report criteria" is set to "intra-frequency measurement reporting criteria" and "reporting criteria" in "inter-frequency measurement quantity" is set to "intra-frequency reporting criteria":

4> leave the currently stored "inter-frequency measurement reporting criteria" within "report criteria" and "inter-frequency reporting criteria" within "inter-frequency measurement quantity" unchanged, and continue to act on the information stored in these variables.

NOTE: If the UTRAN wants to modify the inter-frequency cell info list for an inter-frequency measurement configured with event based reporting without repeating any IEs related to the configured events, one possibility is to set the IE "report criteria" to "intra-frequency measurement reporting criteria", not include the IE "parameters required for each event", and set the IE "reporting criteria" in the IE "inter-frequency measurement quantity" to "intra-frequency reporting criteria".

2> for measurement types "inter-frequency measurement" that require measurements on a frequency other than the actually used frequency, or that require measurements on another RAT:

3> if, according to its measurement capabilities, the UE requires compressed mode to perform that measurement type and after reception of this message a compressed mode pattern sequence with an appropriate measurement purpose is active according to the IE "Current TGPS Status Flag" in UE variable TGPS_IDENTITY; or

3> if, according to its measurement capabilities, the UE does not require compressed mode, on at least one supported band of that measurement type, to perform the measurements:

4> resume the measurements according to the new stored measurement control information.

2> for measurement type "inter-frequency measurement" that requires measurements only on the same frequency as the actually used frequency:

3> if the measurement is valid in the current RRC state of the UE:

4> resume measurements according to the new stored control information for this measurement identity.

2> for any other measurement type:

3> resume the measurements according to the new stored measurement control information.

2> for measurement type "inter-RAT measurement":

3> if "report criteria" is set to "inter-RAT measurement reporting criteria":

4> if the value of "report criteria" stored in the variable MEASUREMENT_IDENTITY associated to the identity indicated by the IE "measurement identity" is not "inter-RAT measurement reporting criteria"; or

4> if the value of "report criteria" stored in the variable MEASUREMENT_IDENTITY associated to the identity indicated by the IE "measurement identity" is "inter-RAT measurement reporting criteria" and if the IE "Parameters required for each event" is present:

5> replace the IE "report criteria" (and all its children) stored in variable MEASUREMENT_IDENTITY associated to the identity indicated by the IE "measurement identity" with the IE "reporting criteria" received in the MEASUREMENT CONTROL message.

3> if "report criteria" is not set to "inter-RAT measurement reporting criteria":

4> replace the IE "reporting criteria" (and all its children) stored in variable MEASUREMENT_IDENTITY associated to the identity indicated by the IE "measurement identity" with the IE "reporting criteria" received in the MEASUREMENT CONTROL message.

2> for measurement type "UE positioning measurement":

3> if "reporting criteria" is set to "UE positioning reporting criteria":

4> if the value of "reporting criteria" stored in the variable MEASUREMENT_IDENTITY associated to the identity indicated by the IE "measurement identity" is not "UE positioning reporting criteria", or;

4> if the value of "reporting criteria" stored in the variable MEASUREMENT_IDENTITY associated to the identity indicated by the IE "measurement identity" is "UE positioning reporting criteria" and if the IE "Parameters required for each event" is present:

5> replace the IE "reporting criteria" (and all its children) stored in variable MEASUREMENT_IDENTITY associated to the identity indicated by the IE "measurement identity" with the IE "report criteria" received in the MEASUREMENT CONTROL message.

3> if "reporting criteria" is not set to "UE positioning reporting criteria":

4> replace the IE "report criteria" (and all its children) stored in variable MEASUREMENT_IDENTITY associated to the identity indicated by the IE "measurement identity" with the IE "report criteria" received in the MEASUREMENT CONTROL message.

2> for measurement type "traffic volume measurement":

3> replace the IE "report criteria" (and all its children) stored in variable MEASUREMENT_IDENTITY associated to the identity indicated by the IE "measurement identity" with the IE "report criteria" received in the MEASUREMENT CONTROL message.

2> for measurement type "quality measurement":

3> replace the IE "report criteria" (and all its children) stored in variable MEASUREMENT_IDENTITY associated to the identity indicated by the IE "measurement identity" with the IE "report criteria" received in the MEASUREMENT CONTROL message;

3> if "report criteria" is set to "quality measurement reporting criteria":

4> if the value of "BLER reporting" in any instance of the IE "Quality reporting quantity" stored in the variable MEASUREMENT_IDENTITY associated to the identity indicated by the IE "measurement identity" with the IE "report criteria" received in the MEASUREMENT CONTROL message is set to TRUE:

5> the UE behaviour is unspecified.

2> for measurement type "UE internal measurement":

3> if "report criteria" is set to "UE internal measurement reporting criteria":

4> if the value of "report criteria" stored in the variable MEASUREMENT_IDENTITY associated to the identity indicated by the IE "measurement identity" is not "UE internal measurement reporting criteria"; or

4> if the value of "report criteria" stored in the variable MEASUREMENT_IDENTITY associated to the identity indicated by the IE "measurement identity" is "UE internal measurement reporting criteria" and if the IE "Parameters sent for each UE internal measurement event" is present:

5> replace the IE "report criteria" (and all its children) stored in variable MEASUREMENT_IDENTITY associated to the identity indicated by the IE "measurement identity" with the IE "report criteria" received in the MEASUREMENT CONTROL message.

3> if "report criteria" is not set to "UE internal measurement reporting criteria":

4> replace the IE "report criteria" (and all its children) stored in variable MEASUREMENT_IDENTITY associated to the identity indicated by the IE "measurement identity" with the IE "report criteria" received in the MEASUREMENT CONTROL message.

1> if the IE "measurement command" has the value "release":

2> terminate the measurement associated with the identity given in the IE "measurement identity";

2> clear all stored measurement control information related associated to this measurement identity in variable MEASUREMENT_IDENTITY.

1> if the IE "DPCH Compressed Mode Status Info" is present:

2> if, as the result of this message, UE will have more than one transmission gap pattern sequence with the same measurement purpose active (according to IEs "TGMP" and "Current TGPS Status Flag" in variable TGPS_IDENTITY):

3> set the variable CONFIGURATION_INCOMPLETE to TRUE.

2> if there is any pending "TGPS reconfiguration CFN" or any pending "TGCFN":

3> the UE behaviour is unspecified.

2> if there is a pending "activation time" for a reconfiguration procedure that included the IE "DPCH Compressed mode info":

3> the UE behaviour is unspecified.

2> if pattern sequence corresponding to IE "TGPSI" is already active (according to "Current TGPS Status Flag") in the variable TGPS_IDENTITY):

3> if the "TGPS Status Flag" in this message is set to "deactivate" for the corresponding pattern sequence:

4> deactivate this pattern sequence at the beginning of the frame indicated by IE "TGPS reconfiguration CFN" received in the message;

4> set the "Current TGPS Status Flag" for this pattern sequence in the variable TGPS_IDENTITY to "inactive" at the frame indicated by IE "TGPS reconfiguration CFN" received in the message.

3> if the "TGPS Status Flag" in this message is set to "activate" for the corresponding pattern sequence:

4> deactivate this pattern sequence at the beginning of the frame indicated by IE "TGPS reconfiguration CFN" received in the message.

NOTE1: The temporary deactivation of pattern sequences for which the status flag is set to "activate" can be used by the network to align the timing of already active patterns with newly activated patterns.

NOTE2: The deactivation of pattern sequences only occurs as a result of RRC messages received by the UE, i.e. the UE does not set the "Current TGPS Status Flag" to "inactive" after the final gap of a finite length pattern sequence.

2> after the time indicated by IE "TGPS reconfiguration CFN" has elapsed:

3> activate the pattern sequence corresponding to each IE "TGPSI" for which the "TGPS status flag" in this message is set to "activate" at the time indicated by IE "TGCFN"; and

3> set the corresponding "Current TGPS status flag" for this pattern sequence in the variable TGPS_IDENTITY to "active"; and

3> begin the inter-frequency and/or inter-RAT measurements corresponding to the pattern sequence measurement purpose of each activated pattern sequence;

3> if the values of IE "TGPS reconfiguration CFN" and IE "TGCFN" are equal:

4> start the concerned pattern sequence immediately at that CFN.

2> not alter pattern sequences stored in variable TGPS_IDENTITY, if the pattern sequence is not identitifed in IE "TGPSI" in the received message.

1> if the UE in CELL_FACH state receives a MEASUREMENT CONTROL message, which indicates the same measurement identity as that stored in the variable MEASUREMENT_IDENTITY:

2> update the stored information with the traffic volume measurement control information in variable MEASUREMENT_IDENTITY; and

2> refrain from updating the traffic volume measurement control information associated with this measurement identity in the variable MEASUREMENT_IDENTITY with the information received in System Information Block type 12 (or System Information Block type 11, according to subclause 8.1.1.6.11) until this measurement is explicitly released with another MEASUREMENT CONTROL message.

1> if the IE "Read SFN indicator" included in the IE "Cell info" of an inter-frequency cell is set to TRUE and the variable UE_CAPABILITY_TRANSFERRED has the DL "Measurement capability" for "FDD measurements" set to TRUE (the UE requires DL compressed mode in order to perform measurements on FDD):

2> set the variable CONFIGURATION_INCOMPLETE to TRUE.

1> clear the entry for the MEASUREMENT CONTROL message in the table "Accepted transactions" in the variable TRANSACTIONS.

The UE may:

1> if the IE "Measurement command" has the value "setup":

2> for measurement type "UE positioning measurement":

3> if the UE is CELL_FACH state:

4> if IE "Positioning Method" is set to "GPS":

5> if IE "UE positioning GPS assistance data" is not included and variable UE_POSITIONING_GPS_DATA is empty:

6> if System Information Block types 15, 15.1, 15.2 and 15.3 are broadcast:

7> read System Information Block types 15, 15.1, 15.2 and 15.3.

6> act as specified in subclause 8.6.7.19.3.

1> and the procedure ends.

### 8.4.1.4 Unsupported measurement in the UE

If UTRAN instructs the UE to perform a measurement that is not supported by the UE, or would cause the maximum number of reporting criteria supported by the UE [19] to be exceeded, the UE shall:

1> retain the measurement configuration that was valid before the MEASUREMENT CONTROL message was received;

1> set the IE "RRC transaction identifier" in the MEASUREMENT CONTROL FAILURE message to the value of "RRC transaction identifier" in the entry for the MEASUREMENT CONTROL message in the table "Accepted transactions" in the variable TRANSACTIONS; and

1> clear that entry.

1> set the cause value in IE "failure cause" to "unsupported measurement";

1> submit the MEASUREMENT CONTROL FAILURE message to lower layers for transmission on the DCCH using AM RLC;

1> continue with any ongoing processes and procedures as if the invalid MEASUREMENT CONTROL message has not been received;

1> and the procedure ends.

### 8.4.1.4a Configuration Incomplete

If the variable CONFIGURATION_INCOMPLETE is set to TRUE, the UE shall:

1> retain the measurement configuration that was valid before the MEASUREMENT CONTROL message was received;

1> set the IE "RRC transaction identifier" in the MEASUREMENT CONTROL FAILURE message to the value of "RRC transaction identifier" in the entry for the MEASUREMENT CONTROL message in the table "Accepted transactions" in the variable TRANSACTIONS and clear that entry;

1> clear the variable CONFIGURATION_INCOMPLETE;

1> set the cause value in IE "failure cause" to "Configuration incomplete";

1> submit the MEASUREMENT CONTROL FAILURE message to lower layers for transmission on the DCCH using AM RLC;

1> continue with any ongoing processes and procedures as if the invalid MEASUREMENT CONTROL message has not been received;

1> and the procedure ends.

### 8.4.1.5 Invalid MEASUREMENT CONTROL message

If the MEASUREMENT CONTROL message contains a protocol error causing the variable PROTOCOL_ERROR_REJECT to be set to TRUE according to clause 9, the UE shall perform procedure specific error handling as follows. The UE shall:

1> set the IE "RRC transaction identifier" in the MEASUREMENT CONTROL FAILURE message to the value of "RRC transaction identifier" in the entry for the MEASUREMENT CONTROL message in the table "Rejected transactions" in the variable TRANSACTIONS; and

1> clear that entry.

1> set the IE "failure cause" to the cause value "protocol error";

1> include the IE "Protocol error information" with contents set to the value of the variable PROTOCOL_ERROR_INFORMATION;

1> submit the MEASUREMENT CONTROL FAILURE message to lower layers for transmission on the DCCH using AM RLC;

1> continue with any ongoing processes and procedures as if the invalid MEASUREMENT CONTROL message has not been received;

1> and the procedure ends.

### 8.4.1.6 Measurements after transition from CELL_DCH to CELL_FACH/CELL_PCH/URA_PCH state

The UE shall apply the following rules for different measurement types after transiting from CELL_DCH to CELL_FACH/CELL_PCH/URA_PCH state:

#### 8.4.1.6.1 Intra-frequency measurement

Upon transition from CELL_DCH to CELL_FACH/CELL_PCH/URA_PCH state, the UE shall:

1> stop intra-frequency type measurement reporting;

1> if the transition is due to a reconfiguration message which included the IE "Primary CPICH info" (for FDD) or "Primary CCPCH info" (for TDD), and the UE selects a cell other than that indicated by this IE on the current frequency (in case the IE "Frequency info" is not received) or other than that indicated by this IE on the frequency indicated by the IE "Frequency info" (when the IE "Frequency info" is included); or

1> if the transition is due to a reconfiguration message which does not include the IE "Primary CPICH info" (for FDD) or "Primary CCPCH info" (for TDD); or

1> if the transition is not due to a reconfiguration message:

2> delete the measurements of type intra-frequency associated with the variable MEASUREMENT_IDENTITY.

1> begin monitoring cells listed in the IE "intra-frequency cell info list" received in System Information Block type 12 (or System Information Block type 11, according to subclause 8.1.1.6.11).

#### 8.4.1.6.2 Inter-frequency measurement

Upon transition from CELL_DCH to CELL_FACH/ CELL_PCH/URA_PCH state, the UE shall:

1> stop the inter-frequency type measurement reporting assigned in a MEASUREMENT CONTROL message;

1> if the transition is due to a reconfiguration message which included the IE "Primary CPICH info" (for FDD) or "Primary CCPCH info" (for TDD), and the UE selects a cell other than that indicated by this IE on the current frequency (in case the IE "Frequency info" is not received) or other than that indicated by this IE on the frequency indicated by the IE "Frequency info" (when the IE "Frequency info" is included); or

1> if the transition is due to a reconfiguration message which does not include the IE "Primary CPICH info" (for FDD) or "Primary CCPCH info" (for TDD); or

1> if the transition is not due to a reconfiguration message:

2> delete the measurements of type inter-frequency associated with the variable MEASUREMENT_IDENTITY and delete the corresponding compressed mode pattern stored in the variable TGPS_IDENTITY.

1> for remaining compressed mode patterns, set the IE "TGPS Status Flag" to "deactivate" and the IE "Current TGPS Status Flag" to "inactive" in the variable TGPS_IDENTITY.

1> begin monitoring cells listed in the IE "inter-frequency cell info list" received in System Information Block type 12 (or System Information Block type 11, according to subclause 8.1.1.6.11);

1> in CELL_FACH state:

2> perform measurements on other frequencies according to the IE "FACH measurement occasion info".

#### 8.4.1.6.3 Inter-RAT measurement

Upon transition from CELL_DCH to CELL_FACH/CELL_PCH/URA_PCH state, the UE shall:

1> stop the inter-RAT type measurement reporting assigned in a MEASUREMENT CONTROL message;

1> delete the measurements of type inter-RAT associated with the variable MEASUREMENT_IDENTITY and delete the corresponding compressed mode pattern stored in the variable TGPS_IDENTITY;

1> begin monitoring cells listed in the IE "inter-RAT cell info list" received in System Information Block type 12 (or System Information Block type 11, according to subclause 8.1.1.6.11);

1> in CELL_FACH state:

2> perform measurements on other systems according to the IE "FACH measurement occasion info".

#### 8.4.1.6.4 Quality measurement

Upon transition from CELL_DCH to CELL_FACH/CELL_PCH/URA_PCH state, the UE shall:

1> stop quality type measurement reporting;

1> delete all measurement control information of measurement type "quality" stored in the variable MEASUREMENT_IDENTITY.

#### 8.4.1.6.5 UE internal measurement

Upon transition from CELL_DCH to CELL_FACH/CELL_PCH/URA_PCH state, the UE shall:

1> stop UE internal measurement type measurement reporting;

1> delete all measurement control information of measurement type "UE internal" stored in the variable MEASUREMENT_IDENTITY.

#### 8.4.1.6.6 Traffic volume measurement

Upon transition from CELL_DCH to CELL_FACH or CELL_PCH or URA_PCH state, the UE shall:

1> retrieve each set of measurement control information of measurement type "traffic volume" stored in the variable MEASUREMENT_IDENTITY; and

2> if the optional IE "measurement validity" for this measurement has not been included:

3> delete the measurement associated with the variable MEASUREMENT_IDENTITY.

2> if the IE "measurement validity" for the measurement has been included, and the IE "UE state" has been assigned to value "CELL_DCH":

3> stop measurement reporting;

3> store the measurement associated with the variable MEASUREMENT_IDENTITY to be used after the next transition to CELL_DCH state.

2> if the IE "measurement validity" for the measurement has been included, and the IE "UE state" has been assigned to value "all states" or "all states except CELL_DCH", and if the state transition is from CELL_DCH to CELL_PCH or URA_PCH state:

3> stop measurement reporting;

3> store the measurement associated with the variable MEASUREMENT_IDENTITY to be used after the next transition to CELL_FACH state.

2> if the IE "measurement validity" for the measurement has been included, and the IE "UE state" has been assigned to value "all states", and if the state transition is from CELL_DCH to CELL_FACH state:

3> continue measurement reporting.

2> if the IE "measurement validity" has been included and the IE "UE state" has been assigned to value "all states except CELL_DCH", and if the state transition is from CELL_DCH to CELL_FACH state:

3> resume this measurement and associated reporting.

1> if no traffic volume type measurement has been assigned to the UE with a MEASUREMENT CONTROL message that is valid in CELL_FACH or CELL_PCH or URA_PCH states (stored in the variable MEASUREMENT_IDENTITY), which has the same identity as the one indicated in the IE "Traffic volume measurement system information":

2> store the measurement control information from the IE "Traffic volume measurement system information" received in System Information Block type 12 (or System Information Block type 11, according to subclause 8.1.1.6.11) in the variable MEASUREMENT_IDENTITY;

2> perform traffic volume measurement reporting according to the assigned information, when in CELL_FACH state.

#### 8.4.1.6.7 UE positioning measurement

Upon transition from CELL_DCH to CELL_FACH and upon transition from CELL_DCH to CELL_PCH or URA_PCH for UE assisted GPS measurements, the UE shall:

1> retrieve each set of measurement control information of measurement type "UE positioning" stored in the variable MEASUREMENT_IDENTITY; and

2> if the optional IE "measurement validity" for this measurement has not been included:

3> delete the measurement associated with the variable MEASUREMENT_IDENTITY.

2> if the IE "measurement validity" for the measurement has been included, and the IE "UE state" has been assigned to value "CELL_DCH":

3> stop measurement reporting;

3> store the measurement associated with the variable MEASUREMENT_IDENTITY to be used after the next transition to CELL_DCH state.

2> if the IE "measurement validity" for the measurement has been included, and the IE "UE state" has been assigned to value "all states":

3> upon transition from CELL_DCH to CELL_PCH or URA_PCH:

4> if the choice in the IE "Reporting Criteria" included the IE "UE Positioning measurement" stored in the variable MEASUREMENT_IDENTITY is set to "UE positioning reporting criteria" and the value of the IE "Measurement interval" included in this IE is less than 64 seconds:

5>use a value of 64 seconds for the measurement interval associated with this measurement while the UE remains in CELL_PCH/URA_PCH.

4> if the choice in the IE "Reporting Criteria" included the IE "UE Positioning measurement" stored in the variable MEASUREMENT_IDENTITY is set to "Periodical Reporting Criteria" and the value of the IE "Reporting interval" included in this IE is less than 64 seconds:

5> use a value of 64 seconds for the reporting interval associated with this measurement while the UE remains in CELL_PCH/URA_PCH.

3> continue measurement reporting according to its UE positioning measurement reporting capability.

2> if the IE "measurement validity" has been included and the IE "UE state" has been assigned to value "all states except CELL_DCH":

3> upon transition from CELL_DCH to CELL_PCH or URA_PCH:

4> if the choice in the IE "Reporting Criteria" included the IE "UE Positioning measurement" stored in the variable MEASUREMENT_IDENTITY is set to "UE positioning reporting criteria" and the value of the IE "Measurement interval " included in this IE is less than 64 seconds:

5> use a value of 64 seconds for the measurement interval associated with this measurement while the UE remains in CELL_PCH/URA_PCH.

4> if the choice in the IE "Reporting Criteria" included the IE "UE Positioning measurement" stored in the variable MEASUREMENT_IDENTITY is set to "Periodical Reporting Criteria" and the value of the IE "Reporting interval" included in this IE is less than 64 seconds:

5> use a value of 64 seconds for the reporting interval associated with this measurement while the UE remains in CELL_PCH/URA_PCH.

3> resume this measurement and associated reporting according to its UE Positioning measurement reporting capability.

1> if the transition is due to a reconfiguration message which included the IE "Primary CPICH info" (for FDD) or "Primary CCPCH info" (for TDD), and the UE selects a cell other than that indicated by this IE; or

1> if the transition is due to a reconfiguration message which does not include the IE "Primary CPICH info" (for FDD) or "Primary CCPCH info" (for TDD); or

1> if the transition is due to a reconfiguration message which included the IE "Frequency info", and the UE selects a cell on another frequency than that indicated by this IE; or

1> if the transition is due to a reconfiguration message which does not include the IE "Frequency info", and the UE can not find a cell on the current frequency, but it selects a cell on another frequency; or

1> if the transition is not due to a reconfiguration message:

2> delete the assistance data included in the variable UE_POSITIONING_OTDOA_DATA_UE_BASED and UE_POSITIONING_OTDOA_DATA_UE_ASSISTED.

1> if the IE "Positioning Methods" stored in the variable MEASUREMENT_IDENTITY is set to "OTDOA" or "OTDOA or GPS":

2> if the IE "Method type" stored in the variable MEASUREMENT_IDENTITY is set to "UE-based" or "UE assisted preferred but UE-based allowed" or "UE-based preferred but UE-assisted allowed":

3> begin monitoring assistance data received in System Information Block type 15.4 and System Information Block type 15.5 according to subclause 8.1.1.6.15.

2> if the IE "Method type" stored in the variable MEASUREMENT_IDENTITY is set to "UE-assisted":

3> begin monitoring assistance data received in System Information Block type 15.4 according to subclause 8.1.1.6.15.

1> if the UE is in CELL_FACH state:

2> if the IE "UE positioning OTDOA neighbour cell list for UE assisted" stored in the variable UE_POSITIONING_OTDOA_DATA_UE_ASSISTED or UE_POSITIONING_OTDOA_DATA_UE_BASED contains neighbour cells on other frequencies than the current frequency:

3> perform measurements on other frequencies according to the IE "FACH measurement occasion info".

The UE may:

1> if the IE "Positioning Methods" stored in the variable MEASUREMENT_IDENTITY is set to "GPS" or "OTDOA or GPS":

2> begin monitoring assistance data received in System Information Block type 15 and/or System Information Block type 15.1 and/or System Information Block type 15.2 and/or System Information Block type 15.3 according to subclause 8.1.1.6.15.

NOTE: In the case that the measurement or reporting intervals are modified to 64 seconds during a transition to CELL_PCH/URA_PCH as described above, the UE retains the previously used values of "Measurement interval" and "Reporting interval" for use after transition out of CELL_PCH/URA_PCH.

#### 8.4.1.6a Actions in CELL_FACH/CELL_PCH/URA/PCH state upon cell re-selection

Upon cell reselection while in CELL_FACH/CELL_PCH/URA/PCH state and the cell reselection has occurred after the measurement control information was stored, the UE shall:

1> delete all measurements of type intra-frequency, inter-frequency, and inter-RAT associated with the variable MEASUREMENT_IDENTITY;

1> delete all compressed mode patterns associated with inter-frequency and inter-RAT measurements stored in the variable TGPS_IDENTITY;

1> delete the traffic volume measurements that have not been set up or modified through a MEASUREMENT CONTROL message.

### 8.4.1.7 Measurements after transition from CELL_FACH to CELL_DCH state

The UE shall apply the following rules for different measurement types after transiting from CELL_FACH to CELL_DCH state:

#### 8.4.1.7.1 Intra-frequency measurement

Upon transition from CELL_FACH to CELL_DCH state:

1> if intra-frequency measurements applicable to CELL_DCH state are stored in the variable MEASUREMENT_IDENTITY:

2> if the cell in which the UE transited from CELL_FACH state is included in the active set for the CELL_DCH state, the UE shall:

3> resume the measurement reporting.

2> otherwise, the UE shall:

3> not resume the measurement reporting. The measurement shall be restarted when a MEASUREMENT CONTROL message is received with the corresponding measurement identity.

#### 8.4.1.7.2 Inter-frequency measurement

Upon transition from CELL_FACH to CELL_DCH state:

1> if inter-frequency measurements applicable to CELL_DCH state are stored in the variable MEASUREMENT_IDENTITY:

2> if the cell in which the UE transited from CELL_FACH state is included in the active set for the CELL_DCH state, the UE shall:

3> resume the measurement reporting.

2> otherwise, the UE shall:

3> not resume the measurement reporting. The measurement shall be restarted when a MEASUREMENT CONTROL message is received with the corresponding measurement identity.

#### 8.4.1.7.3 Inter-RAT measurement

Upon transition from CELL_FACH to CELL_DCH state, the UE shall:

1> stop monitoring the list of cells assigned in the IE "inter-RAT cell info list" in System Information Block type 12 (or System Information Block type 11, according to subclause 8.1.1.6.11).

#### 8.4.1.7.4 Traffic volume measurement

Upon transition from CELL_FACH to CELL_DCH state, the UE shall:

1> retrieve each set of measurement control information of measurement type "traffic volume" stored in the variable MEASUREMENT_IDENTITY;

2> if the optional IE "measurement validity" for this measurement has not been included:

3> delete the measurement associated with the variable MEASUREMENT_IDENTITY.

2> if the IE "measurement validity" for the measurement has been included, and the IE "UE state" has been assigned to value "all states except CELL_DCH":

3> stop measurement reporting; and

3> save the measurement associated with the variable MEASUREMENT_IDENTITY to be used after the next transition to CELL_FACH/CELL_PCH/URA_PCH state.

2> if the IE "measurement validity" for the measurement has been included, and the IE "UE state" has been assigned to value "all states":

3> continue measurement reporting.

2> if the IE "measurement validity" has been included and the IE "UE state" has been assigned to value "CELL_DCH":

3> resume this measurement and associated reporting.

1> if no traffic volume type measurement has been assigned to the UE with a MEASUREMENT CONTROL message that is valid in CELL_DCH and has the same identity as the one indicated in the IE "Traffic volume measurement system information":

2> store the measurement control information from the IE "Traffic volume measurement system information" received in System Information Block type 12 (or System Information Block type 11, according to subclause 8.1.1.6.11) in the variable MEASUREMENT_IDENTITY;

2> begin traffic volume measurement reporting according to the assigned information.

#### 8.4.1.7.5 UE positioning measurement

Upon transition from CELL_FACH to CELL_DCH state, the UE shall:

1> retrieve each set of measurement control information of measurement type "UE positioning" stored in the variable MEASUREMENT_IDENTITY; and

2> if the optional IE "Measurement validity" for this measurement has not been included:

3> delete the measurement associated with the variable MEASUREMENT_IDENTITY.

2> if the IE "measurement validity" for the measurement has been included, and the IE "UE state" has been assigned to value "all states except CELL_DCH":

3> stop measurement reporting; and

3> save the measurement associated with the variable MEASUREMENT_IDENTITY to be used after the next transition to CELL_FACH/CELL_PCH/URA_PCH state.

2> if the IE "measurement validity" for the measurement has been included, and the IE "UE state" has been assigned to value "all states":

3> continue measurement reporting.

2> if the IE "measurement validity" has been included and the IE "UE state" has been assigned to value "CELL_DCH":

3> resume this measurement and associated reporting.

1> stop monitoring assistance data received in System Information Block type 15 or System Information Block type 15.1 or System Information Block type 15.2 or System Information Block type 15.3 or System Information Block type 15.4 or System Information Block 15.5.

### 8.4.1.8 Measurements after transition from idle mode to CELL_DCH state

The UE shall obey the following rules for different measurement types after transiting from idle mode to CELL_DCH state:

#### 8.4.1.8.1 Intra-frequency measurement

Upon transition from idle mode to CELL_DCH state:

1> if intra-frequency measurements applicable to CELL_DCH state are stored in the variable MEASUREMENT_IDENTITY:

2> if the cell in which the UE transited from idle mode is included in the active set for the CELL_DCH state, the UE shall:

3> begin measurement reporting.

2> otherwise, the UE shall:

3> not begin the measurement reporting. The measurement shall be restarted when a MEASUREMENT CONTROL message is received with the corresponding measurement identity.

#### 8.4.1.8.2 Inter-frequency measurement

Upon transition from idle mode to CELL_DCH state, the UE shall:

1> stop monitoring the list of cells assigned in the IE "inter-frequency cell info list" in System Information Block type 12 (or System Information Block type 11, according to subclause 8.1.1.6.11).

#### 8.4.1.8.3 Inter-RAT measurement

Upon transition from idle mode to CELL_DCH state, the UE shall:

1> stop monitoring the list of cells assigned in the IE "inter-RAT cell info list" in System Information Block type 12 (or System Information Block type 11, according to subclause 8.1.1.6.11).

#### 8.4.1.8.4 Traffic volume measurement

Upon transition from idle mode to CELL_DCH state, the UE shall:

1> begin a traffic volume type measurement, assigned in System Information Block type 11 (or System Information Block type 12, according to subclause 8.1.1.6.11).

#### 8.4.1.8.5 UE positioning measurement

Upon transition from idle mode to CELL_DCH state, the UE shall:

1> stop monitoring assistance data received in System Information Block type 15 or System Information Block type 15.1 or System Information Block type 15.2 or System Information Block type 15.3 or System Information Block type 15.4 or System Information Block type 15.5.

### 8.4.1.9 Measurements after transition from idle mode to CELL_FACH state

The UE shall obey the follow rules for different measurement types after transiting from idle mode to CELL_FACH state:

#### 8.4.1.9.1 Intra-frequency measurement

Upon transition from idle mode to CELL_FACH state, the UE shall:

1> begin or continue monitoring cells listed in the IE "intra-frequency cell info list" received in System Information Block type 12 (or System Information Block type 11, according to subclause 8.1.1.6.11).

#### 8.4.1.9.2 Inter-frequency measurement

Upon transition from idle mode to CELL_FACH state, the UE shall:

1> begin or continue monitoring cells listed in the IE "inter-frequency cell info list" received in System Information Block type 12 (or System Information Block type 11, according to subclause 8.1.1.6.11);

1> perform measurements on other frequencies according to the IE "FACH measurement occasion info".

#### 8.4.1.9.3 Inter-RAT measurement

Upon transition from idle mode to CELL_FACH state, the UE shall:

1> begin or continue monitoring cells listed in the IE "inter-RAT cell info list" received in System Information Block type 12 (or System Information Block type 11, according to subclause 8.1.1.6.11);

1> perform measurements on other systems according to the IE "FACH measurement occasion info".

#### 8.4.1.9.4 Traffic volume measurement

Upon transition from idle mode to CELL_FACH state, the UE shall:

1> store the measurement control information from the IE "Traffic volume measurement system information" received in System Information Block type 12 (or System Information Block type 11, according to subclause 8.1.1.6.11) in the variable MEASUREMENT_IDENTITY;

1> begin traffic volume measurement reporting according to the assigned information.

#### 8.4.1.9.5 UE positioning measurement

Upon transition from idle mode to CELL_FACH state, the UE may:

1> begin or continue monitoring assistance data received in System Information Block type 15 or System Information Block type 15.1 or System Information Block type 15.2 or System Information Block type 15.3 or System Information Block type 15.4 or System Information Block type 15.5 according to subclause 8.1.1.6.15;

1> if the IE "UE positioning OTDOA neighbour cell list for UE assisted" stored in the variable UE_POSITIONING_OTDOA_DATA_UE_ASSISTED; or

1> if the IE "UE positioning OTDOA neighbour cell list for UE based" stored in the variable UE_POSITIONING_OTDOA_DATA_UE_BASED contains neighbour cells on other frequencies than the current frequency:

2> perform measurements on other frequencies according to the IE "FACH measurement occasion info".

### 8.4.1.9a Measurements after transition from connected mode to idle mode

Upon transition from connected mode to idle mode the UE shall:

1> stop measurement reporting for all measurements stored in the variable MEASUREMENT_IDENTITY;

1> clear the variable MEASUREMENT_IDENTITY;

1> apply the following rules for different measurement types.

#### 8.4.1.9a.1 Intra-frequency measurement

Upon transition from connected mode to idle mode, the UE shall:

1> stop monitoring intra-frequency cells listed in the IE "intra-frequency cell info list" received in System Information Block type 12 (if System Information Block type 12 is transmitted in the cell, according to subclause 8.1.1.6.11);

1> begin monitoring intra-frequency cells listed in the IE "intra-frequency cell info list" received in System Information Block type 11.

#### 8.4.1.9a.2 Inter-frequency measurement

Upon transition from connected mode to idle mode, the UE shall:

1> stop monitoring inter-frequency cells listed in the IE "inter-frequency cell info list" received in System Information Block type 12 (if System Information Block type 12 is transmitted in the cell, according to subclause 8.1.1.6.11);

1> begin monitoring inter-frequency cells listed in the IE "inter-frequency cell info list" received in System Information Block type 11.

#### 8.4.1.9a.3 Inter-RAT measurement

Upon transition from connected mode to idle mode, the UE shall:

1> stop monitoring inter-RAT cells listed in the IE "inter-RAT cell info list" received in System Information Block type 12 (if System Information Block type 12 is transmitted in the cell, according to 8.1.1.6.11);

1> begin monitoring inter-RAT cells listed in the IE "inter-RAT cell info list" received in System Information Block type 11.

#### 8.4.1.9a.4 UE positioning measurement

Upon transition from connected mode to idle mode, the UE may:

1> begin or continue monitoring assistance data received in System Information Block type 15 or System Information Block type 15.1 or System Information Block type 15.2 or System Information Block type 15.3 or System Information Block type 15.4 or System Information Block type 15.5.

### 8.4.1.9b Measurements after transition from CELL_FACH to CELL_PCH/URA_PCH

#### 8.4.1.9b.1 Traffic volume measurement

Upon transition from CELL_FACH to CELL_PCH or URA_PCH, the UE shall:

1> stop any ongoing traffic volume measurement, and associated traffic volume measurement reporting.

1> store the measurement associated with the variable MEASUREMENT_IDENTITY to be used after the next transition to CELL_FACH state;

1> if no traffic volume type measurement has been assigned to the UE with a MEASUREMENT CONTROL message that is valid in CELL_FACH or CELL_PCH or URA_PCH states (stored in the variable MEASUREMENT_IDENTITY), which has the same identity as the one indicated in the IE "Traffic volume measurement system information":

2> store the measurement control information from the IE "Traffic volume measurement system information" received in System Information Block type 12 (or System Information Block type 11, according to subclause 8.1.1.6.11) in the variable MEASUREMENT_IDENTITY.

#### 8.4.1.9b.2 UE positioning measurement

Upon transition from CELL_FACH to CELL_PCH or URA_PCH, the UE shall:

1> retrieve each set of measurement control information of measurement type "UE positioning" stored in the variable MEASUREMENT_IDENTITY; and

2> if the optional IE "measurement validity" for this measurement has not been included:

3> delete the measurement associated with the variable MEASUREMENT_IDENTITY.

2> if the IE "measurement validity" for the measurement has been included, and the IE "UE state" has been assigned to value "all states" or "all states except CELL_DCH":

3> if the choice in the IE "Reporting Criteria" included in the IE "UE Positioning measurement" stored in the variable MEASUREMENT_IDENTITY is set to "UE positioning reporting criteria" and the value of the IE "Measurement interval" included in this IE is less than 64 seconds:

4> use a value of 64 seconds for the measurement interval associated with this measurement while the UE remains in CELL_PCH/URA_PCH.

3> if the choice in the IE "Reporting Criteria" included in the IE "UE Positioning measurement" stored in the variable MEASUREMENT_IDENTITY is set to "Periodical Reporting Criteria" and the value of the IE "Reporting interval" included in this IE is less than 64 seconds:

4> use a value of 64 seconds for the reporting interval associated with this measurement while the UE remains in CELL_PCH/URA_PCH.

NOTE: In the case that the measurement or reporting intervals are modified to 64 seconds as described above, the UE retains the previously used values of "Measurement interval" and "Reporting interval" for use after transition out of CELL_PCH/URA_PCH.

### 8.4.1.9c Measurements after transition from CELL_PCH/URA_PCH to CELL_FACH

#### 8.4.1.9c.1 Traffic volume measurement

Upon transition from CELL_PCH or URA_PCH to CELL_FACH, the UE shall resume any traffic volume measurement stored in the variable MEASUREMENT_IDENTITY with measurement validity "all states" or "all states except CELL_DCH", and start the associated traffic volume measurement reporting.

#### 8.4.1.9c.2 UE positioning measurement

Upon transition from CELL_PCH or URA_PCH to CELL_FACH, the UE shall continue any UE positioning measurement stored in the variable MEASUREMENT_IDENTITY with measurement validity "all states" or "all states except CELL_DCH", and continue the associated UE positioning measurement reporting.

NOTE: The UE's values of "Measurement interval" in the IE "UE positioning reporting criteria" and "Reporting interval" in the IE "Periodical Reporting Criteria" after this state transition revert to the values stored during the transition to CELL_PCH/URA_PCH (i.e., the 64-second interval specified in subclause 8.4.1.9b.2 is not retained).

### 8.4.1.10 Changes in measurement objects

#### 8.4.1.10.1 Traffic volume measurement

When performing traffic volume event evaluation or reporting related to a certain transport channel, the UE shall consider all RBs which are mapped to the concerning transport channel e.g. if an additional RB is established on a transport channel used for event triggering or reporting, the new RB shall be taken into account.

NOTE: In this subclause, an "existing" uplink transport channel refers to a configured uplink transport channel applicable in the current RRC state.

The UE shall:

1> if the IE "Traffic volume measurement object" is included for this measurement:

2> while a transport channel that is referenced in the IE "Traffic volume measurement object" does not exist:

3> not perform any reporting related to this transport channel.

1> else:

2> report on all existing uplink transport channels; e.g. if an additional transport channel is established while the measurement is ongoing, this new transport channel shall be taken into account in the traffic volume measurement reporting.

For every traffic volume event, the UE shall:

1> if the IE "Uplink transport channel type" is not included in the IE "Traffic volume measurement reporting criteria", or the "Uplink transport channel type" has the value "DCH" or "USCH" and the IE "UL transport channel id" is not included in the IE "Traffic volume measurement reporting criteria":

2> if the IE "Traffic volume measurement object" is not included:

3> take all existing UL transport channels into account for event triggering; e.g. if an additional transport channel is established while the measurement is ongoing, this new transport channel shall be taken into account in the traffic volume event triggering.

2> else:

3> while a transport channel that is referenced in the IE "Traffic Volume Measurement object" does not exist:

4> not take this transport channel identity into account in the traffic volume measurement triggering.

1> else:

2> while a transport channel that is referenced in the IE "Traffic Volume Measurement Reporting Criteria" does not exist:

3> not take this transport channel identity into account in the traffic volume event triggering.

#### 8.4.1.10.2 Quality measurement

While a transport channel that is explicitly referenced with a transport channel identity in the IE "Quality Reporting Quantity" does not exist, the UE shall:

1> not perform any reporting related to this transport channel identity.

If the IE "Quality Reporting Quantity" does not contain any explicit transport channel identities, the UE shall:

1> report the quality of all existing downlink dedicated transport channels;

1> if an additional transport channel is established while the measurement is ongoing:

2> take into account this new transport channel in the quality measurement reporting.

While a transport channel that is explicitly referenced with a transport channel id in the IE "Quality Measurement Reporting Criteria" does not exist, the UE shall:

1> not take this transport channel identity into account in the quality measurement event triggering.

#### 8.4.1.10.3 Intra-frequency, Inter-frequency and Inter-RAT measurements

For measurements which include the IE "Cells for measurement" the UE shall:

1> while an IE "Intra-frequency cell id" or IE "Inter-frequency cell id" or IE "Inter-RAT cell id" in the IE "Cells for measurement" points to a position in the variable CELL_INFO_LIST which is marked as "vacant":

2> not take this position into account for event triggering and reporting.

## 8.4.2 Measurement report

**Figure 8.4.2-1: Measurement report, normal case**

### 8.4.2.1 General

The purpose of the measurement reporting procedure is to transfer measurement results from the UE to UTRAN.

### 8.4.2.2 Initiation

In CELL_DCH state, the UE shall:

1> transmit a MEASUREMENT REPORT message on the uplink DCCH when the reporting criteria stored in variable MEASUREMENT_IDENTITY are met for any ongoing measurements that are being performed in the UE.

In CELL_FACH state, the UE shall:

1> transmit a MEASUREMENT REPORT message on the uplink DCCH when the reporting criteria stored in variable MEASUREMENT_IDENTITY are met for any ongoing traffic volume measurement or UE positioning measurement that is being performed in the UE.

In TDD, if the Radio Bearer associated with the MEASUREMENT_IDENTITY fulfilling the reporting criteria for an ongoing traffic volume measurement is mapped on transport channel of type USCH, the UE shall:

1> initiate the "PUSCH CAPACITY REQUEST" procedure instead of transmitting a MEASUREMENT REPORT (TDD Only).

In CELL_PCH or URA_PCH state, the UE shall:

1> first perform the cell update procedure according to subclause 8.3.1, using the cause "uplink data transmission", in order to transit to CELL_FACH state; and then

1> transmit a MEASUREMENT REPORT message on the uplink DCCH when the reporting criteria stored in variable MEASUREMENT_IDENTITY are fulfilled for any ongoing UE positioning measurement which is being performed in the UE.

The reporting criteria are fulfilled if either:

- a periodic MEASUREMENT REPORT message shall be sent according to the IE "Periodical Reporting Criteria"; or

- an event in stored IE "Measurement reporting criteria" was triggered. Events and triggering of reports for different measurement types are described in detail in clause 14.

For the measurement, which triggered the MEASUREMENT REPORT message, the UE shall:

1> set the IE "measurement identity" to the measurement identity, which is associated with that measurement in variable MEASUREMENT_IDENTITY;

1> set the IE "measured results" to include measurements according to the IE "reporting quantity" of that measurement stored in variable MEASUREMENT_IDENTITY; and

2> if all the reporting quantities are set to "false":

3> not set the IE "measured results".

1> set the IE "Measured results" in the IE "Additional measured results" according to the IE "reporting quantity" for all measurements associated with the measurement identities included in the "Additional measurements list" stored in variable MEASUREMENT_IDENTITY of the measurement that triggered the measurement report; and

2> if one or more additional measured results are to be included:

3> include only the available additional measured results, and sort them in ascending order according to their IE "measurement identity" in the MEASUREMENT REPORT message.

1> if the MEASUREMENT REPORT message was triggered by an event (i.e. not a periodical report):

2> set the IE "Event results" according to the event that triggered the report.

1> if the observed time difference for one or more GSM cells is included in the MEASUREMENT REPORT message:

2> set the IE "GSM OTD reference cell" to the primary CPICH info of the active set cell that was used as reference for the measurement.

1> if the IE Inter-RAT measured results list or the IE Inter-RAT measurement event results is included in the measurement report:

2> if the indication status of the IE "Inter-RAT cell info indication" in the variable CELL_INFO_LIST is marked "present" , include the stored value of the IE "Inter-RAT cell info indication" in the MEASUREMENT REPORT message.

The UE shall:

1> transmit the MEASUREMENT REPORT message on the uplink DCCH using either AM or UM RLC according to the stored IE "measurement reporting mode" associated with the measurement identity that triggered the report.

When the MEASUREMENT REPORT message has been submitted to lower layers for transmission:

1> the procedure ends.

## 8.4.3 Assistance Data Delivery

**Figure 8.4.3-1 Assistance Data Delivery**

### 8.4.3.1 General

The purpose of the assistance data delivery procedure is to transfer UE positioning related assistance data from the UTRAN to the UE.

### 8.4.3.2 Initiation

When requested by the Core Network, the UTRAN may deliver UE positioning related assistance data with a ASSISTANCE DATA DELIVERY message, which is transmitted on the downlink DCCH using AM RLC

#### 8.4.3.3 Reception of ASSISTANCE DATA DELIVERY message by the UE

Upon reception of a ASSISTANCE DATA DELIVERY message the UE shall:

1> if IE "UE positioning OTDOA assistance data for UE-based" is included:

2> act as specified in subclause 8.6.7.19.2a.

1> if IE "UE positioning GPS assistance data" is included:

2> act as specified in subclause 8.6.7.19.3.

#### 8.4.3.4 Invalid ASSISTANCE DATA DELIVERY message

If the UE receives a ASSISTANCE DATA DELIVERY message, which contains a protocol error causing the variable PROTOCOL_ERROR_REJECT to be set to TRUE according to clause 9, the UE shall perform procedure specific error handling as follows. The UE shall:

1> transmit an RRC STATUS message on the uplink DCCH using AM RLC;

1> include the IE "Identification of received message"; and

1> set the IE "Received message type" to ASSISTANCE DATA DELIVERY; and

1> set the IE "RRC transaction identifier" to the value of "RRC transaction identifier" in the entry for the ASSISTANCE DATA DELIVERY message in the table "Rejected transactions" in the variable TRANSACTIONS; and

1> clear that entry;

1> include the IE "Protocol error information" with contents set to the value of the variable PROTOCOL_ERROR_INFORMATION.

1> when the RRC STATUS message has been submitted to lower layers for transmission:

2> continue with any ongoing processes and procedures as if the invalid ASSISTANCE DATA DELIVERY message has not been received.

## 8.5 General procedures

### 8.5.1 Selection of initial UE identity

The purpose of the IE "Initial UE identity" is to provide a unique UE identification at the establishment of an RRC connection. The type of identity shall be selected by the UE according to the following.

If the UE is operating in "GSM-MAP mode", the UE shall choose "UE id type" in the IE "Initial UE identity" with the following priority:

1. TMSI (GSM-MAP): The TMSI (GSM-MAP) shall be chosen if available. The IE "LAI" in the IE "Initial UE identity" shall also be present when TMSI (GSM-MAP) is used, for making it unique.
2. P-TMSI (GSM-MAP): The P-TMSI (GSM-MAP) shall be chosen if available and no TMSI (GSM-MAP) is available. The IE "RAI" in the IE "Initial UE identity" shall in this case also be present when P-TMSI (GSM-MAP) is used, for making it unique.
3. IMSI (GSM-MAP): The IMSI (GSM-MAP) shall be chosen if available and no TMSI (GSM-MAP) or P-TMSI is available.
4. IMEI: The IMEI shall be chosen when none of the above three conditions are fulfilled.

When being used, the IEs "TMSI (GSM-MAP)," "P-TMSI (GSM-MAP)", "IMSI (GSM-MAP)", "LAI" and "RAI" shall be set equal to the values of the corresponding identities stored in the USIM or SIM.

If the UE is operating in "ANSI-41 mode", the UE shall choose "UE id type" in the IE "Initial UE identity" according to the procedure specified in the 3GPP2 document "3GPP2 C.P0004-A".

### 8.5.2 Actions when entering idle mode from connected mode

When entering idle mode from connected mode, the UE shall:

1> clear or set variables upon leaving UTRA RRC connected mode as specified in subclause 13.4;

1> if the RRC CONNECTION RELEASE message was received and the IE "Redirection info" was present therein:

2> attempt to camp on a suitable cell on the indicated UTRA carrier included in the RRC CONNECTION RELEASE message;

2> attempt to camp on a suitable cell of the list of cells for the indicated RAT included in the RRC CONNECTION RELEASE message. If no cells were indicated for that RAT or no suitable cell of the indicated cells for that RAT is found within 10s, attempt to camp on any suitable cell of that RAT; or

2> if no suitable cell is found on the indicated UTRA carrier or RAT camp on any suitable cell.

1> attempt to select a suitable cell to camp on.

When leaving connected mode according to [4], the UE shall:

1> perform cell selection.

While camping on a cell, the UE shall:

1> acquire system information according to the system information procedure in subclause 8.1;

1> perform measurements according to the measurement control procedure specified in subclause 8.4; and

1> if the UE is registered:

2> be prepared to receive paging messages according to the paging procedure in subclause 8.2.

If the UE is operating in "GSM-MAP mode", the UE shall:

1> delete any NAS system information received in connected mode;

1> acquire the NAS system information in system information block type 1; and

1> proceed according to subclause 8.6.1.2.

When entering idle mode, the UE shall:

1> if the USIM is present, for each CN domain:

2> if a new security key set was received for this CN domain but was not used either for integrity protection or ciphering during this RRC connection:

3> set the START value for this domain to zero; and

3> store this START value for this domain in the USIM.

2> else:

3> if the current "START" value, according to subclause 8.5.9 for a CN domain, is greater than or equal to the value "THRESHOLD" of the variable START_THRESHOLD:

4> delete the ciphering and integrity keys that are stored in the USIM for that CN domain;

4> inform the deletion of these keys to upper layers.

3> else:

4> store the current "START" value for this CN domain on the USIM.

NOTE: Prior to storing the "START" value, the UE should calculate this "START" value according to subclause 8.5.9.

1> else:

2> if the SIM is present, for each CN domain:

3> if a new security key set was received for this CN domain but was not used either for integrity protection or ciphering during this RRC connection:

4> set the START value for this domain to zero; and

4> store this START value for this domain in the UE

3> else:

4> if the current "START" value, according to subclause 8.5.9 for this CN domain, is greater than or equal to the value "THRESHOLD" of the variable START_THRESHOLD:

5> delete the Kc key for this CN domain;

5> delete the ciphering and integrity keys that are stored in the UE for that CN domain;

5> set the "START" values for this CN domain to zero and store it the UE;

5> inform the deletion of the key to upper layers.

4> else:

5> store the current "START" value for this CN domain in the UE.

NOTE: Prior to storing the "START" value, the UE should calculate this "START" value according to subclause 8.5.9.

## 8.5.3 Open loop power control upon establishment of DPCCH

This procedure is used in FDD mode only.

When establishing the first DPCCH the UE shall start the UL inner loop power control at a power level according to:

1> DPCCH_Initial_power = DPCCH_Power_offset – CPICH_RSCP

Where

DPCCH_Power_offset shall have the value of IE "DPCCH Power offset" in IE "Uplink DPCH power control info"

The value for the CPICH_RSCP shall be measured by the UE.

## 8.5.4 Physical channel establishment criteria

When a physical dedicated channel establishment is initiated by the UE, the UE shall start a timer T312 and wait for layer 1 to indicate N312 "in sync" indications. On receiving N312 "in sync" indications, the physical channel is considered established and the timer T312 is stopped and reset.

If the timer T312 expires before the physical channel is established, the UE shall consider this as a "physical channel failure".

NOTE: The criteria defined in this subclause only apply in case the UE performs synchronisation procedure A (FDD only).

## 8.5.5 Actions in "out of service area" and "in service area"

This subclause specifies the general actions the UE shall perform when it detects "out of service" or "in service" area. The specific UE behaviour when it detects "out of service" or "in service area" and periodical update has been

configured by T305 in the IE "UE Timers and constants in connected mode" set to any other value than "infinity" is specified in subclause 8.3.1.

#### 8.5.5.1 Detection of "out of service" area

The UE shall detect "out of service" area as defined in [19].

##### 8.5.5.1.1 Actions following detection of "out of service" area in URA_PCH or CELL_PCH state

If the UE detects the "out of service area" and the UE is in URA_PCH or CELL_PCH state it shall perform the following actions:

1> start timer T316;

1> perform processes described in subclause 7.2.2.

##### 8.5.5.1.2 Actions following detection of "out of service" area in CELL_FACH state

If the UE detects the "out of service area" and the UE is in CELL_FACH state it shall perform the following actions. The UE shall:

1> start timer T317 if not already running;

1> perform processes described in subclause 7.2.2.

##### 8.5.5.1.3 Actions following detection of "out of service" area on transition from CELL_DCH to URA_PCH or CELL_PCH

If the UE detects the "out of service area" on transition from CELL_DCH to URA_PCH or CELL_PCH, it shall perform the following actions:

1> start timer T316;

1> start the timer T305 using its initial value if timer T305 is not running and periodical cell update has been configured by T305 in the IE "UE Timers and constants in connected mode" set to any other value than "infinity";

1> perform processes described in subclause 7.2.2.

##### 8.5.5.1.4 Actions following detection of "out of service" area on transition from CELL_DCH to CELL_FACH

If the UE detects the "out of service area" on transition from CELL_DCH to CELL_FACH, it shall perform the following actions:

1> if the transition is triggered by a reconfiguration procedure:

2> start timer T317;

2> start the timer T305 using its initial value if timer T305 is not running and periodical cell update has been configured by T305 in the IE "UE Timers and constants in connected mode" set to any other value than "infinity";

2> perform processes described in subclause 7.2.2.

1> otherwise:

2> perform processes described in subclause 7.2.2.

#### 8.5.5.2 Detection of "in service" area

When a suitable cell is found based on the description in [4], the UE considers it as having detected "in service area".

##### 8.5.5.2.1 Actions following Re-entry into "in service area" in URA_PCH or CELL_PCH state

If the UE re-enters "in service area" before T316 expiry the UE shall perform the following actions. The UE shall:

1> stop T316;

1> if T307 is active:

2> stop T307.

1> if the UE is in CELL_PCH state and the UE is camped on a cell different from the one where service was lost:

2> initiate the cell update procedure using the cause "cell-reselection" as specified in subclause 8.3.1.

1> perform processes described in subclause 7.2.2.

##### 8.5.5.2.2 Actions following re-entry into "in service area" in CELL_FACH state

If the UE detects "in service area" before T317 expiry the UE shall perform the following actions. If no cell update procedure or URA update procedure is ongoing, the UE shall:

1> stop T317;

1> if T307 is active:

2> stop T307.

1> initiate the cell update procedure using as cause "Re-entering service area" as specified in subclause 8.3.1;

1> perform processes described in subclause 7.2.2.

If a cell update procedure or URA update procedure is ongoing, the UE shall:

1> stop T317;

1> perform the actions as specified in 8.3.1.

#### 8.5.5.3 T316 expiry

On T316 expiry the UE shall perform the following actions. The UE shall:

1> if "out of service area" is detected:

2> start timer T317;

2> move to CELL_FACH state;

2> perform processes described in subclause 7.2.2.

1> if "in service area" is detected:

2> initiate the cell update procedure using as cause "Re-entering service area" as specified in subclause 8.3.1;

2> perform processes described in subclause 7.2.2.

#### 8.5.5.4 T317 expiry

T317 shall never expire, i.e. all its values shall be assumed to be "infinity".

If T317 is running:

1> the UE behaviour shall be as specified in subclause 7.2.2.2.

## 8.5.6 Radio link failure criteria and actions upon radio link failure

In CELL_DCH State, after receiving N313 consecutive "out of sync" indications from layer 1 for the established DPCCH or F-DPCH physical channel in FDD, and the physical channels associated with mapped DCCHs in TDD, the UE shall:

1> start timer T313;

1> upon receiving N315 successive "in sync" indications from layer 1 and upon change of UE state:

2> stop and reset timer T313.

1> if T313 expires:

2> consider it as a "Radio link failure".

Periods in time where neither "in sync" nor "out of sync" is reported by layer 1 do not affect the evaluation of the number of consecutive (resp. successive) "in sync" or "out of sync" indications.

When a radio link failure occurs, the UE shall:

1> clear the dedicated physical channel configuration;

1> perform actions as specified for the ongoing procedure;

1> if no procedure is ongoing or no actions are specified for the ongoing procedure:

2> perform a cell update procedure according to subclause 8.3.1 using the cause "radio link failure".

## 8.5.7 Open loop power control

For FDD and prior to PRACH transmission the UE shall:

1> acquire valid versions of the necessary System Information IEs as follows:

2> if the UE has stored valid versions of the IEs "Primary CPICH Tx power" and "Constant value":

3> use the stored content of the IEs.

2> otherwise:

3> read and store the IE "Primary CPICH Tx power" and "Constant value" in System Information Block type 6 (or System Information Block type 5, if System Information Block type 6 is not being broadcast).

2> if the UE has a valid version of the IE "UL interference" stored:

3> use the stored content of the IE "UL interference".

2> otherwise:

3> read and store the IE "UL interference" in System Information Block type 7;

3> if the UE fails to read the IE "UL interference" in System Information Block type 7 due to bad radio conditions, the UE shall use the last stored IE "UL interference".

1> measure the value for the CPICH_RSCP;

1> calculate the power for the first preamble as:

Preamble_Initial_Power = Primary CPICH TX power – CPICH_RSCP + UL interference + Constant Value

Where,

Primary CPICH TX power shall have the value of IE "Primary CPICH Tx power",

UL interference shall have the value of IE "UL interference"; and

Constant Value shall have the value of IE "Constant value".

1> as long as the physical layer is configured for PRACH transmission:

2> continuously recalculate the Preamble_Initial_Power when any of the broadcast parameters used in the above formula changes; and

2> resubmit to the physical layer the new calculated Preamble_Initial_Power.

For 3.84 Mcps TDD or 7.68 Mcps TDD the UE shall:

1> if in the IE "Uplink DPCH Power Control info" the "CHOICE UL OL PC info" has the value "Broadcast UL OL PC info":

2> prior to DPCH transmission the UE shall:

3> acquire valid versions of the necessary System Information IEs as follows:

4> if the UE has stored valid versions of the IEs "Primary CCPCH Tx power" and "DPCH Constant value":

5> use the stored content of the IEs.

4> otherwise:

5> read and store the IE "Primary CCPCH Tx power" and "DPCH Constant value" in System Information Block type 6 (or System Information Block type 5, if System Information Block type 6 is not being broadcast).

3> if the UE has a valid version of the IE "UL interference" for each active UL timeslot stored:

4> use the stored content of the IE "UL interference" for each active UL timeslot.

3> otherwise:

4> read and store the IE "UL Timeslot Interference" for each active UL timeslot in System Information Block type 14;

4> if the UE fails to read the IE "UL Timeslot Interference" for each active UL time slot in System Information Block type 14 due to bad radio conditions, the UE shall use the last stored IE "UL Timeslot interference" for each active UL timeslot.

1> otherwise:

2> acquire Reference Power, Constant Values and $I_{BTS}$ for all active UL timeslots from the IE "Uplink DPCH Power Control info".

1> for PUSCH, PRACH and HS-SICH power control:

2> prior to PUSCH or PRACH transmission the UE shall:

3> acquire valid versions of the necessary System Information IEs as follows:

4> if the UE has stored valid versions of the IEs "Primary CCPCH Tx power" and "PUSCH Constant value" for PUSCH transmissions or "PRACH Constant value" for PRACH transmissions:

5> use the stored content of the IEs.

4> otherwise:

5> read and store the IE "Primary CCPCH Tx power" and "PUSCH Constant value" for PUSCH transmissions or "PRACH Constant value" for PRACH transmissions in System Information Block type 6 (or System Information Block type 5, if System Information Block type 6 is not being broadcast).

3> if the UE has a valid version of the IE "UL interference" for each active UL timeslot stored:

4> use the stored content of the IE "UL interference" for each active UL timeslot.

3> otherwise:

4> read and store the IE "UL Timeslot Interference" for each active UL timeslot in System Information Block type 14;

4> if the UE fails to read the IE "UL Timeslot Interference" for each active UL time slot in System Information Block type 14 due to bad radio conditions, the UE shall use the last stored IE "UL Timeslot interference" for each active UL timeslot.

calculate the UL transmit power according to the following formula for the PRACH continuously while the physical channel is active:

$$P_{PRACH} = L_{PCCPCH} + I_{BTS} + \text{PRACH Constant value},$$

2> 3dB shall be added to RACH Constant Value in the above equation for the case where RACH Spreading Factor = 8;

2> for 7.68 Mcps TDD, 3dB shall be added to RACH Constant Value in the above equation for the case where RACH Spreading Factor = 16.

1> calculate the UL transmit power according to the following formula for the DPCH continuously while the physical channel is active:

$$P_{DPCH} = \alpha L_{PCCPCH} + (1-\alpha)L_0 + I_{BTS} + SIR_{TARGET} + \text{DPCH Constant value}$$

1> calculate the UL transmit power according to the following formula for the PUSCH continuously while the physical channel is active:

$$P_{PUSCH} = \alpha L_{PCCPCH} + (1-\alpha)L_0 + I_{BTS} + SIR_{TARGET} + \text{PUSCH Constant value}$$

1> calculate the initial UL transmit power for HS-SICH according to the following formula:

$$P_{HS\text{-}SICH} = \alpha L_{PCCPCH} + (1-\alpha)L_0 + I_{BTS} + SIR_{TARGET} + \text{HS-SICH Constant value}$$

Where, for all the above equations for 3.84 Mcps TDD or 7.68 Mcps TDD the following apply:

- $P_{PRACH}$, $P_{DPCH}$, $P_{PUSCH}$ and $P_{HS\text{-}SICH}$: Transmitter power level in dBm;
- Pathloss values:
  - $L_{PCCPCH}$: Measurement representing path loss in dB based on beacon channels (the reference transmit power is signalled as the value of the IE "Primary CCPCH Tx Power" on BCH in System Information Block type 6 (or System Information Block type 5, according to subclause 8.1.1.6.5), or individually signalled in the IE" Uplink DPCH Power Control info").
  - $L_0$: Long term average of path loss in dB;
  - If the midamble is used in the evaluation of $L_{PCCPCH}$ and $L_0$, and the Tx diversity scheme used for the P-CCPCH involves the transmission of different midambles from the diversity antennas, the received power of the different midambles from the different antennas shall be combined prior to evaluation of the variables.
- $I_{BTS}$: Interference signal power level at cell's receiver in dBm. $I_{BTS}$ shall have the value of the IE "UL Timeslot Interference" (IE "UL Timeslot Interference" is broadcast on BCH in System Information Block type 14 or individually signalled to each UE in the IE "Uplink DPCH Power Control info" for each active uplink timeslot).
- $\alpha$: $\alpha$ is a weighting parameter, which represents the quality of path loss measurements. $\alpha$ may be a function of the time delay between the uplink time slot and the most recent down link PCCPCH time slot. $\alpha$ is calculated at the UE. $\alpha$ shall be smaller or equal to the value of the IE "Alpha". If the IE "Alpha" is not explicitly signalled to the UE $\alpha$ shall be set to 1. If UE is capable of estimating its position by using the OTDOA IPDL method, the UE shall use the IPDL-$\alpha$ parameter.

- $SIR_{TARGET}$: Target SNR in dB. This value is individually signalled to UEs in IE "UL target SIR" in IE "Uplink DPCH Power Control Info" or in IE "PUSCH Power Control Info" or in IE "HS-SICH Power Control Info".
- PRACH Constant value: PRACH Constant value shall have the value of the IE "PRACH Constant value".
- DPCH Constant value: DPCH Constant value shall have the value of the IE "DPCH Constant value".
- PUSCH Constant value: PUSCH Constant value shall have the value of the IE "PUSCH Constant value".
- HS-SICH Constant value: HS-SICH Constant value shall have the value of the IE "HS-SICH Constant value".
- Values received by dedicated signalling shall take precedence over broadcast values.
- If IPDLs are applied, the UE may increase UL Tx power by the value given in the IE "Max power increase". This power increase is only allowed in the slots between an idle slot and the next beacon slot.

For 1.28 Mcps TDD the UE shall:

1> acquire valid versions of the necessary System Information IEs as follows:

2> if the UE has stored a valid version of the IE "Primary CCPCH Tx Power":

3> use the stored content of the IE.

2> otherwise:

3> read and store the IE "Primary CCPCH Tx Power" from System Information Block type 6 (or System Information Block type 5, if System Information Block type 6 is not being broadcast).

1> calculate the UL transmit power according to the following formula for each UpPCH code transmission:

$$P_{UpPCH} = L_{PCCPCH} + PRX_{UpPCHdes} + (i-1)* Pwr_{ramp}$$

NOTE: When i equals 1, the initial signature power "Signature_Initial_Power" defined in [33] corresponds to $P_{UpPCH}$ with i set to 1.

1> calculate the UL transmit power according to the following formula for each PRACH transmission:

$$P_{PRACH} = L_{PCCPCH} + PRX_{PRACHdes} + (i_{UpPCH}-1) * Pwr_{ramp}$$

1> calculate the initial UL transmit power according to the following formula for the PUSCH. Once the UE receives TPC bits relating to the PUSCH then it transitions to closed loop power control. If successive PUSCH resource allocations are contiguous then no return is made to open loop power control at the beginning of the succeeding resource allocation.

$$P_{USCH} = PRX_{PUSCHdes} + L_{PCCPCH}$$

1> calculate the initial UL transmit power for HS-SICH according to the following formula:

$$P_{HS\text{-}SICH} = PRX_{HS\text{-}SICH} + L_{PCCPCH}$$

1> calculate the initial UL transmit power according to the following formula for the DPCH. Once the UE receives TPC bits relating to the uplink DPCH then it transitions to closed loop power control.

$$P_{DPCH} = PRX_{DPCHdes} + L_{PCCPCH}$$

Where:

- $P_{UpPCH}$, $P_{PRACH}$, $P_{DPCH}$, $P_{HS\text{-}SICH}$ & $P_{USCH}$: Transmitter power level in dBm.
- $L_{PCCPCH}$: Measurement representing path loss in dB (reference transmit power "Primary CCPCH Tx Power" is broadcast on BCH in System Information Block type 5 and System Information Block type 6, or individually signalled to each UE in the IE" Uplink DPCH Power Control info").
- i is the number of transmission attempts on UpPCH, i=1…Max SYNC_UL Transmissions.

- $i_{UpPCH}$ is the final value of i.

- $PRX_{PRACHdes}$: Desired PRACH RX power at the cell's receiver in dBm signalled to the UE by the network in the FPACH response to the UE's successful SYNC_UL transmission.

- $PRX_{UpPCHdes}$: Desired UpPCH RX power at the cell's receiver in dBm. The value is broadcast in "$PRX_{UpPCHdes}$" in IE "SYNC_UL info" on BCH and shall be read on System Information Block type 5 and System Information Block type 6. It can also be signalled directly to the UE in IE "Uplink Timing Advance Control" contained in a protocol message triggering a hard handover or a transition from cell FACH to cell DCH state.

- $PRX_{PUSCHdes}$: Desired PUSCH RX power at the cell's receiver in dBm signalled to the UE in IE "PUSCH Power Control Info".

- $PRX_{DPCHdes}$: Desired DPCH RX power at the cell's receiver in dBm signalled to the UE in IE "Uplink DPCH Info" and IE "Uplink DPCH Power Control Info".

- $Pwr_{ramp}$: The UE shall increase its transmission power by the value of the IE "Power Ramp step" by every UpPCH transmission. Its value is signalled in the IE "SYNC UL info" in System Information Block type 5 and System Information Block type 6 or is signalled to the UE in the IE "Uplink Timing Advance Control" contained in a protocol message triggering a hard handover or a transition from cell FACH state to cell DCH state.

- $PRX_{HS\text{-}SICH}$: Desired HS-SICH RX power at the cell's receiver in dBm signalled to the UE in IE "Downlink HS-PDSCH Information".

- Ack-Nack Power Offset: Difference in the desired RX power between HS-SICH transmissions conveying an acknowledgement and transmissions conveying a negative acknowledgement signalled to the UE in IE "HS-SCCH Info".

## 8.5.8 Maintenance of Hyper Frame Numbers

The MSBs of both the ciphering sequence numbers (COUNT-C) and integrity sequence numbers (COUNT-I), for the ciphering and integrity protection algorithms, respectively [40], are called the Hyper Frame Numbers (HFN).

For integrity protection, the UE shall:

1> maintain COUNT-I as specified in subclause 8.5.10.

The following hyper frame numbers types are defined:

MAC-d HFN:
24 MSB of COUNT-C for data sent over RLC TM

RLC UM HFN:
25 MSB of COUNT-C for data sent over RLC UM

RLC AM HFN:
20 MSB of COUNT-C for data sent over RLC AM

RRC HFN:
28 MSB of COUNT-I

For non-transparent mode RLC signalling radio bearers and radio bearers, the UE shall:

1> maintain one uplink and one downlink COUNT-C per signalling radio bearer and per radio bearer and one uplink and one downlink COUNT-I per signalling radio bearer;

1> increment the RLC UM HFN and RLC AM HFN in uplink and downlink by one each time the RLC sequence number wraps around in uplink and downlink respectively;

1> if the activation time for a new ciphering configuration set by an RRC procedure is equal to zero:

2> apply the configured RLC UM HFN or RLC AM HFN at this activation time, i.e. the configured HFN is not incremented.

NOTE: On the receiver side it may happen that the RLC PDU with sequence number equal to the activation time is lost and the first received PDU after the activation time implies a wrap around of the sequence number compared to the activation time. In this case the configured HFN is incremented by one. This action is taken only when the activation time is set to a RLC PDU sequence number value other than zero.

For all transparent mode RLC signalling radio bearers and radio bearers of each CN domain, the UE shall:

1> maintain one COUNT-C, common for all radio bearers in uplink and downlink;

1> increment the MAC-d HFN by one each time the CFN wraps around;

1> if the activation time for a new ciphering configuration set by an RRC procedure is equal to zero:

2> apply the configured MAC-d HFN at this activation time, i.e. the configured HFN is not incremented.

1> maintain one uplink and one downlink COUNT-I per signalling radio bearer.

NOTE: In this release of the specification there is only an uplink transparent mode COUNT-I, which is used for signalling radio bearer RB0.

COUNT-C and COUNT-I are defined in [40], with the following supplement for COUNT-C: for transparent mode RLC radio bearers with a transmission time interval of x radio frames (x = 2, 4, 8), the MAC PDU is carried by L1 in x consecutive radio frames due to radio frame segmentation. In this case, the CFN of the first radio frame in the TTI shall be used as the CFN component of COUNT-C for ciphering of all data in the TTI [15].

## 8.5.9 START value calculation

In connected mode, if a security mode command procedure has been successfully completed for a CN domain during the current RRC connection, the START value for that CN domain is calculated as:

Let $START_X$ = the START value for CN domain 'X' prior to the calculation below:

$START_X' = MSB_{20}$ ( MAX {COUNT-C, COUNT-I | radio bearers and signalling radio bearers using the most recently configured $CK_X$ and $IK_X$}) + 2.

- if $START_X'$= the maximum value = 1048575 then $START_X = START_X'$;
- if the current $START_X < START_X'$ then $START_X = START_X'$, otherwise $START_X$ is unchanged.

NOTE: Here, "most recently configured" means that if there is more than one key in use for a CN domain, due to non-expiry of the ciphering and/or integrity protection activation time for any signalling radio bearers and/or radio bearers, do not include the COUNT-I/COUNT-C for these signalling radio bearers and/or radio bearers in the calculation of the $START_X'$.

COUNT-C corresponding to non-ciphered radio bearers (i.e. RBs with ciphering status set to "not started") shall not be included in the calculation of the $START_X'$. If a radio bearer is released and the radio bearer was ciphered, the values of the COUNT-C at the time the radio bearer is released shall be taken into account in the calculation of the $START_X'$.

If a security mode command procedure has not been successfully completed for a CN domain during the current RRC connection, the UE shall use the latest transmitted START value for this CN domain.

## 8.5.10 Integrity protection

If the "Status" in the variable INTEGRITY_ PROTECTION_INFO has the value "Started" then the UE shall:

1> perform integrity protection (and integrity checking) on all RRC messages, with the following exceptions:

HANDOVER TO UTRAN COMPLETE

PAGING TYPE 1

PUSCH CAPACITY REQUEST

PHYSICAL SHARED CHANNEL ALLOCATION

RRC CONNECTION REQUEST

RRC CONNECTION SETUP

RRC CONNECTION SETUP COMPLETE

RRC CONNECTION REJECT

RRC CONNECTION RELEASE (CCCH only)

SYSTEM INFORMATION

SYSTEM INFORMATION CHANGE INDICATION

TRANSPORT FORMAT COMBINATION CONTROL (TM DCCH only)

If the "Status" in the variable INTEGRITY_ PROTECTION_INFO has the value "Not started" then integrity protection (and integrity checking) shall not be performed on any RRC message.

For each signalling radio bearer, the UE shall use two RRC hyper frame numbers:

- "Uplink RRC HFN";
- "Downlink RRC HFN".

and two message sequence numbers:

- "Uplink RRC Message sequence number";
- "Downlink RRC Message sequence number".

The above information is stored in the variable INTEGRITY_PROTECTION_INFO per signalling radio bearer (RB0-RB4).

Upon the first activation of integrity protection for an RRC connection, UE and UTRAN initialise the "Uplink RRC Message sequence number" and "Downlink RRC Message sequence number" for all signalling radio bearers as specified in subclauses 8.6.3.5 and 8.5.10.1.

The RRC message sequence number (RRC SN) is incremented for every integrity protected RRC message.

If the IE "Integrity Protection Mode Info" is present in a received message, the UE shall:

1> perform the actions in subclause 8.6.3.5 before proceeding with the integrity check of the received message.

### 8.5.10.1 Integrity protection in downlink

If the UE receives an RRC message on signalling radio bearer with RB identity n, the "Status" in the variable INTEGRITY_ PROTECTION_INFO has the value "Started" and the IE 'Integrity check info' is present the UE shall:

1> check the value of the IE "RRC message sequence number" included in the IE "Integrity check info";

2> if the "Downlink RRC Message sequence number" is not present in the variable INTEGRITY_PROTECTION_INFO:

3> initialise the "Downlink RRC Message sequence number" for signalling radio bearer RBn in the variable INTEGRITY_PROTECTION_INFO with the value of the IE "RRC message sequence number" included in the IE "Integrity check info" of the received message.

2> if the "Downlink RRC Message sequence number" is present in the variable INTEGRITY_PROTECTION_INFO:

3> if the RRC message sequence number is lower than the "Downlink RRC Message sequence number" for signalling radio bearer RBn in the variable INTEGRITY_PROTECTION_INFO:

4> increment "Downlink RRC HFN" for signalling radio bearer RBn in the variable INTEGRITY_PROTECTION_INFO with one.

NOTE: The actions above imply that also for the case the "Downlink RRC HFN" is re-initialised by a security mode control procedure, this "Downlink RRC HFN" value is incremented by one before it is applied for the integrity protection of any received message if the conditions above are fulfilled.

3> if the RRC message sequence number is equal to the "Downlink RRC Message sequence number" for signalling radio bearer RBn in the variable INTEGRITY_PROTECTION_INFO:

4> discard the message.

1> calculate an expected message authentication code in accordance with subclause 8.5.10.3;

1> compare the expected message authentication code with the value of the received IE "message authentication code" contained in the IE "Integrity check info";

2> if the expected message authentication code and the received message authentication code are the same, the integrity check is successful:

3> update the "Downlink RRC Message sequence number" for signalling radio bearer RBn in the variable INTEGRITY_PROTECTION_INFO with the value of the IE "RRC message sequence number" included in the IE "Integrity check info" of the received RRC message.

2> if the calculated expected message authentication code and the received message authentication code differ:

3> act as if the message was not received.

If the UE receives an RRC message on signalling radio bearer with identity 0, 1, or 2, the "Status" in the variable INTEGRITY_ PROTECTION_INFO has the value "Started" and the IE 'Integrity check info' is not present the UE shall:

1> discard the message.

If the UE receives an RRC message on signalling radio bearer with identity 3 or 4, the "Status" in the variable INTEGRITY_PROTECTION_INFO has the value "Started" and the IE 'Integrity check info' is not present:

1> if a security mode command procedure has not been successfully completed during the current RRC connection for the CN domain indicated by IE "CN Domain Identity" in the received message:

2> the UE shall forward the message to upper layer.

1> else:

2> the UE shall discard the message.

UTRAN may transmit several copies of the same message in the downlink to increase the probability of proper reception of the message by the UE. In such a case, the RRC SN for these repeated messages should be the same.

### 8.5.10.2 Integrity protection in uplink

Prior to sending an RRC message using the signalling radio bearer with radio bearer identity n, and the "Status" in the variable INTEGRITY_ PROTECTION_INFO has the value "Started" the UE shall:

1> increment "Uplink RRC Message sequence number" for signalling radio bearer RBn in the variable INTEGRITY_PROTECTION_INFO with 1, even if the message is a retransmission of a previously transmitted message.

1> if the "Uplink RRC Message sequence number" for signalling radio bearer RBn in the variable INTEGRITY_PROTECTION_INFO equals zero:

2> increment "Uplink RRC HFN" for signalling radio bearer RBn in the variable INTEGRITY_PROTECTION_INFO by one.

NOTE 1: The actions above imply that also for the case the "Uplink RRC HFN" is re-initialised by a security mode control procedure, this "Uplink RRC HFN" is incremented before it is applied in the integrity protection of any transmitted message if the conditions above are fulfilled.

NOTE 2: For SRB0, this is also valid in case the Message Sequence Number has been increased by N302 +2 resulting in an MSN which equals 0 (i.e.: SRB0 UL activation time equals 0). Then the uplink RRC HFN is incremented by 1 after it is re-initialized and before it is applied in the integrity protection of any transmitted message.

1> calculate the message authentication code in accordance with subclause 8.5.10.3;

1> replace the "Message authentication code" in the IE "Integrity check info" in the message with the calculated message authentication code;

1> replace the "RRC Message sequence number" in the IE "Integrity check info" in the message with contents set to the new value of the "Uplink RRC Message sequence number" for signalling radio bearer RBn in the variable INTEGRITY_PROTECTION_INFO.

In the response message for the procedure ordering the security reconfiguration, the UE indicates the activation time, for each signalling radio bearer. When the new integrity configuration is to be applied in uplink, UTRAN should start to apply the new integrity protection configuration according to the activation time for each signalling radio bearer (except for the signalling radio bearer which is used to send the message that is reconfiguring the security configuration where the new configuration is to be applied starting from and including reception of the response message).

### 8.5.10.3 Calculation of message authentication code

The UE shall calculate the message authentication code in accordance with [40]. The input parameter MESSAGE [40] for the integrity algorithm shall be constructed by:

1> setting the "Message authentication code" in the IE "Integrity check info" in the message to the value of the IE "RB identity" for the signalling radio bearer;

1> setting the "RRC Message sequence number" in the IE "Integrity check info" in the message to zero;

1> encoding the message;

1> appending RRC padding (if any) as a bit string to the encoded bit string as the least significant bits.

For usage on an RRC message transmitted or received on the radio bearer with identity n, the UE shall:

1> construct the input parameter COUNT-I [40] by appending the following IEs from the IE "Signalling radio bearer specific integrity protection information" for radio bearer n in the variable INTEGRITY_PROTECTION_INFO:

2> for uplink:

3> "Uplink RRC HFN", as the MSB, and "Uplink RRC Message sequence number", as LSB.

2> for downlink:

3> "Downlink RRC HFN", as the MSB, and the IE "RRC message sequence number" included in the IE "Integrity check info", as LSB.

## 8.5.11 FACH measurement occasion calculation

When in CELL_FACH state and when the variable C_RNTI is non-empty the UE in FDD mode shall perform measurements as specified in subclauses 8.4.1.6 and 8.4.1.9 during the frame(s) with the SFN value fulfilling the following equation:

$$SFN \text{ div } N = C_RNTI \bmod M_REP + n * M_REP$$

where

- N is the TTI (in number of 10ms frames) of the FACH having the largest TTI on the SCCPCH selected by the UE according to the procedure in subclause 8.5.19. FACHs that only carry MBMS logical channels (MTCH, MSCH, or MCCH) are excluded from measurement occasion calculations.

- C_RNTI is the C-RNTI value of the UE stored in the variable C_RNTI

- M_REP is the Measurement Occasion cycle length. According to the equation above, a FACH Measurement Occasion of N frames will be repeated every N * M_REP frame, and M_REP = $2^k$.

  where,

  - k is the FACH Measurement occasion cycle length coefficient.
    The value of the FACH Measurement occasion cycle length coefficient is read in system information in "System Information Block type 11" or "System Information Block type 12" in the IE "FACH measurement occasion info".

- n = 0,1,2… as long as SFN is below its maximum value

The UE is allowed to measure on other occasions in case the UE moves "out of service" area or in case it can simultaneously perform the ordered measurements.

A UE in TDD mode shall use the frame(s) with the SFN value fulfilling the above equation for neighbour cells measurements.

NOTE: For FDD, in order to meet the MBMS demodulation performance requirements [21], a UE receiving MBMS PTM may not be able use the entire measurement occasion.

## 8.5.12 Establishment of Access Service Classes

The PRACH resources (i.e. access slots and preamble signatures for FDD), timeslot (with specific frame allocation and channelisation code for 3.84 Mcps TDD and 7.68 Mcps TDD, and SYNC_UL codes (with specific frame allocation) for 1.28 Mcps TDD) may be divided between different Access Service Classes in order to provide different priorities of RACH usage. It is possible for more than one ASC or for all ASCs to be assigned to the same access slot/signature space in FDD or frame allocation/channelisation codes in 3.84 Mcps TDD or 7.68 Mcps TDD, or frame allocation/SYNC_UL codes in 1.28 Mcps TDD.

Access Service Classes shall be numbered in the range $0 \le i \le \text{NumASC} \le 7$ (i.e. the maximum number of ASCs is 8). An ASC is defined by an identifier, *i,* that defines a certain partition of the PRACH resources (SYNC_UL resources in 1.28 Mcps TDD) and an associated persistence value $P_i$. A set of ASC parameters consists of "NumASC+1" such parameters ($i$, $P_i$), $i$ = 0, …, NumASC.

PRACH partitions shall be established using the information element "PRACH partitioning". The persistence values $P_i$ to be associated with each ASC shall be derived from the dynamic persistence level $N$ = 1,…, 8 which is broadcast in System Information Block 7, and the persistence scaling factors $s_i$, broadcast in System Information Block Type 5 and possibly also in System Information Block Type 6, as follows:

$P(N) = 2^{-(N-1)}$

| ASC # *i* | 0 | 1 | 2 | 3 | 4 | 5 | 6 | 7 |
|---|---|---|---|---|---|---|---|---|
| $P_i$ | 1 | P(N) | $s_2$ P(N) | $s_3$ P(N) | $s_4$ P(N) | $s_5$ P(N) | $s_6$P(N) | $s_7$ P(N) |

In addition, MBMS specific persistence values may be provided within the MBMS MODIFIED SERVICES INFORMATION message. The UE behaviour upon receiving upon receiving an MBMS dynamic persistence value is specified in subclause 8.6.9.1a.

Scaling factors $s_i$ are provided optionally for $i$ = 2,…, NumASC, where NumASC+1 is the number of ASCs as defined by PRACH partitioning. If no scaling factors are broadcast, default value 1 shall be used if NumASC ≥ 2.

If $k \ge 1$ scaling factors are broadcast and NumASC ≥ $k$+2 then the last scaling factor $s_{k+1}$ shall be used as default for the ASCs where $i > k+1$.

The set of ASC parameters is provided to MAC with the CMAC-Config-REQ primitive (see [15]), the PRACH partitioning is provided to PHY using the CPHY-RL-Setup-REQ primitive (see [34]).

The ASC enumeration shall be such that it corresponds to the order of priority (ASC 0 = highest priority, ASC 7 = lowest priority). ASC 0 shall be used in case of Emergency Call or for reasons with equivalent priority.

ASCs are numbered according to the order in which the IEs "ASC Setting" appear in the IE "PRACH partitioning", where the first IE "ASC Setting" describes ASC 0, the second IE "ASC Setting" describes ASC 1, etc.

At radio bearer setup/reconfiguration each involved logical channel is assigned a MAC Logical channel Priority (MLP) in the range 1,…,8. When the MAC sublayer is configured for RACH transmission in the UE, these MLP levels shall be employed for ASC selection on MAC.

## 8.5.13 Mapping of Access Classes to Access Service Classes

Access Classes shall only be applied at initial access, i.e. when sending an RRC CONNECTION REQUEST message. A mapping between Access Class (AC) and Access Service Class (ASC) shall be indicated by the information element "AC-to-ASC mapping" in System Information Block type 5. The correspondence between AC and ASC shall be indicated as follows.

| AC | 0 - 9 | 10 | 11 | 12 | 13 | 14 | 15 |
|---|---|---|---|---|---|---|---|
| ASC | 1st IE | 2nd IE | 3rd IE | 4th IE | 5th IE | 6th IE | 7th IE |

In the table, "$n^{th}$ IE" designates an ASC number *i* in the range 0 - 7 to AC. If the ASC indicated by the "$n^{th}$ IE" is undefined, the UE behaviour is unspecified.

For the random access, the parameters implied by the respective ASC shall be employed. In case the UE is member of several ACs it shall select the ASC for the highest AC number. In connected mode, AC shall not be applied.

## 8.5.14 PLMN Type Selection

Depending on UE configuration, the UE is operating in "ANSI-41 mode" or "GSM-MAP mode".

## 8.5.14a Neighbour cells list narrowing for cell reselection

While a UE is camping on a suitable cell, a UE having performed the PLMN identification of the neighbour cells as specified in subclause 8.1.1.6.18 shall narrow the cell list to be used for cell reselection ([4]) to those neighbour cells for which:

The PLMN identity is part of the PLMNs that can make a cell suitable as defined in [4].

## 8.5.15 CFN calculation

The DOFF used in the formulas in this clause concerns the value of IE "Default DPCH Offset Value" received in the message that instructs the UE to enter CELL_DCH state or to perform timing re-initialised hard handover.

Subclause 8.5.15.5 is used in FDD to initialise the CFN for MTCH and/or MSCH if the IE "MBMS Soft Combining Timing Offset" is included for an S-CCPCH in MBMS CURRENT CELL P-T-M RB INFORMATION or MBMS NEIGHBOURING CELL P-T-M RB INFORMATION, and if only MTCH and/or MSCH are on the S-CCPCH. Otherwise, subclauses 8.5.15.1 through 8.5.15.4 are used to intialise the CFN.

### 8.5.15.1 Initialisation for CELL_DCH state after state transition

When the UE receives any of the messages causing the UE to perform a state transition to CELL_DCH, the UE shall set the CFN in relation to the SFN of the first radio link listed in the IE "Downlink information per radio link list" included in that message according to the following formula:

- for FDD:

$$CFN = (SFN - (DOFF \text{ div } 38400)) \bmod 256$$

  where the formula gives the CFN of the downlink DPCH or F-DPCH frame which starts at the same time as or which starts during the PCCPCH frame with the given SFN. DOFF is determined according to subclause 8.6.6.14.

- for TDD:

$$CFN = (SFN - DOFF) \bmod 256.$$

### 8.5.15.2 Initialisation in CELL_DCH state at hard handover

When the UE is in CELL_DCH state and receives any of the messages causing the UE to perform a hard handover, the UE shall check the IE "Timing indication" in that message and:

1> if IE "Timing indication" has the value "initialise" (i.e. timing re-initialised hard handover):

2> read SFN on target cell identified by the first radio link listed in the IE "Downlink information per radio link list" included in that message;

2> set the CFN according to the following formula:

3> for FDD:

$$CFN = (SFN - (DOFF \text{ div } 38400)) \bmod 256$$

where the formula gives the CFN of the downlink DPCH or F-DPCH frame which starts at the same time as or which starts during the PCCPCH frame with the given SFN.

3> for TDD:

$$CFN = (SFN - DOFF) \bmod 256.$$

1> if IE "Timing indication" has the value "maintain" (i.e. timing-maintained hard handover), the UE shall keep CFN with no change due to the hard handover, and only increase CFN (mod 256) by 1 every frame.

### 8.5.15.3 Initialisation for CELL_FACH

Unless the conditions of subclause 8.15.5.5 are met, when the UE performs cell selection, re-selection or changes to CELL_FACH state the UE shall set CFN for all common or shared channels according to:

$$CFN = SFN \bmod 256$$

where the formula gives the CFN of the downlink common or shared channel frame which starts at the same time as or which starts during the PCCPCH frame with the given SFN.

After the initialisation, the CFN in the UE is increased (mod 256) by 1 every frame.

### 8.5.15.4 Initialisation after intersystem handover to UTRAN

Upon inter RAT handover to UTRAN the UE shall, regardless of the value received within IE "Timing indication" (if received):

1> read SFN on target cell and set the CFN according to the following formula:

2> for FDD:

$$CFN = (SFN - (DOFF \text{ div } 38400)) \bmod 256$$

where the formula gives the CFN of the downlink DPCH frame which starts at the same time as or which starts during the PCCPCH frame with the given SFN.

2> for TDD:

$$CFN = (SFN - DOFF) \bmod 256.$$

### 8.5.15.5 Initialisation for MTCH and/or MSCH carried on S-CCPCH that may be soft combined

For FDD, if the IE "MBMS Soft Combining Timing Offset" is included for an S-CCPCH in MBMS CURRENT CELL P-T-M RB INFORMATION or MBMS NEIGHBOURING CELL P-T-M RB INFORMATION, and if only MTCH and/or MSCH are on the S-CCPCH, the UE shall set CFN for the S-CCPCH according to:

$$CFN = (SFN - (SCTO \text{ div } 10ms)) \bmod 256$$

where the formula gives the CFN of the downlink S-CCPCH frame which starts at the same time as or which starts during the PCCPCH frame with the given SFN.

the SCTO used in the formula is the IE "MBMS Soft Combining Timing Offset".

After the initialisation, the CFN in the UE is increased (mod 256) by 1 every frame.

## 8.5.16 Configuration of CTCH occasions

The CTCH, carrying CBS data is mapped onto only one S-CCPCH. If more than one CTCH is defined, the first CTCH that is configured in the list of S-CCPCHs is the one that is used for CBS data. If the UE is in connected mode it shall ignore any CTCH configuration contained in System Information Block type 6 and use the CTCH configuration contained in System Information Block 5.

The CTCH occasions are identified by the first radio frame of the TTI that can contain CTCH data. The CTCH occasions are fixed on the system frame number cycle 0 .. 4095 (i.e. no modulo calculation) and thus repeated cyclically.

The CTCH occasions are determined by a set of parameters.

$M_{TTI}$: number of radio frames within the TTI of the FACH used for CTCH

N: period of CTCH allocation on S-CCPCH, integer number of radio frames,
$M_{TTI} \leq N \leq 256$, where N is a multiple of $M_{TTI}$ (see [27] and [31]).

MaxSFN: maximum system frame number = 4095 (see [10]).

K: CBS frame offset, integer number of radio frames $0 \leq K \leq N-1$ where K is a multiple of $M_{TTI}$ .

The CTCH occasions are calculated as follows:

$$SFN = (K + m\ N),\ m = 0, 1,..., M, \text{ with M chosen that } K+MN \leq MaxSFN.$$

The parameters N and K are broadcast as system information.

If the IE "Period of BMC scheduling messages (P)" is included in system information block type 5 then BMC Schedule Messages are transmitted periodically every P CTCH occasions. One BMC Schedule Message may be segmented across more than one CTCH occasion. The CTCH occasions that contain the start of the BMC Schedule Messages are calculated as follows:

$$SFN = (K + m\ P\ N), \text{ where m is an integer and } 0 \leq SFN \leq MaxSFN$$

If the IE "Period of BMC scheduling messages (P)" is not included in system information block type 5 then BMC Schedule Messages could be transmitted in any CTCH occasion.

## 8.5.17 PRACH selection

For this version of the specification, when a UE selects a cell, the uplink frequency to be used for the initial PRACH transmission shall have a default duplex frequency spacing offset from the downlink frequency that the cell was selected on. The default duplex frequency separation to be used by the UE is specified in [21] for each frequency band (for FDD only).

NOTE: The PRACH selection scheme assumes that all PRACHs configured in System Information Block type 5, System Information Block type 5bis and System Information Block type 6 support all (implicitly or explicitly) configurable RLC sizes of the cell, i.e. at least the transport formats corresponding to a single transport block of each applicable RLC size of the cell must be defined for each PRACH.

The UE shall select a "PRACH system information" according to the following rule. The UE shall:

1> select a "PRACH system information" from the ones indicated in the IE "PRACH system information list" in System Information Block type 5 or in System Information Block type 5bis (applicable in Idle Mode and Connected Mode) or System Information Block type 6 (applicable in Connected Mode only), as follows:

2> if in connected mode and System Information Block type 6 is defined and includes PRACH info:

3> compile a list of candidate PRACHs that consists of the PRACH system information listed in System Information Block 6, in the order of appearance as in System Information Block 6.

2>otherwise:

3> compile a list of candidate PRACHs that consists of the PRACH system information listed in System Information Block 5 or in System Information Block 5bis, in the order of appearance as in System Information Block 5 or in System Information Block 5bis, respectively.

2> in FDD:

3> perform RACH TTI selection as specified in subclause 8.5.18.1.

2> in 1.28 Mcps TDD:

3> perform RACH TTI selection according to subclause 8.5.18.2.

2> remove from the list of candidate PRACHs those PRACHs that have a TTI length different from the selected value;

2> select a PRACH randomly from the list of candidate PRACHs as follows:

"Index of selected PRACH" = floor (rand * K)

where K is equal to the number of candidate PRACH system informations, "rand" is a random number uniformly distributed in the range $0 \leq rand < 1$ and "floor" refers to rounding down to nearest integer. The candidate PRACH system informations shall be indexed from 0 to K-1. The random number generator is left to implementation. The scheme shall be implemented such that one of the available PRACH system informations is randomly selected with uniform probability. At start-up of the random number generator in the UE the seed shall be dependent on the IMSI of the UE or time, thereby avoiding that all UEs select the same RACH;

2> use the TFCS of the selected PRACH when performing TFC selection (see [15]);

2> reselect the PRACH system information when a new cell is selected. RACH reselection may also be performed after each transmission of a Transport Block Set on RACH.

1> for emergency call, the UE is allowed to select any of the available PRACH system informations.

After selecting a PRACH system information, the RRC in the UE shall configure the MAC and the physical layer for the RACH access according to the parameters included in the selected "PRACH system information" IE.

## 8.5.18 Selection of RACH TTI

### 8.5.18.1 FDD

In FDD mode, a RACH may employ either 10 or 20 ms TTI. The supported TTI is indicated as a semi-static parameter of the RACH Transport Format in system information. The UE shall select an appropriate TTI length from the RACHs included in the list of candidate PRACH(s) according to the following rule.

The UE shall:

1> if only RACHs with one particular TTI length are included in the list of candidate PRACH(s):

2> select this TTI length and proceed as specified in subclause 8.5.17.

1> if both PRACHs with 10ms and 20ms TTI lengths are included in the list of candidate PRACH(s):

2> perform TTI selection as follows:

3> when the UE calculates the initial preamble transmit power ("Preamble_Initial_Power") as specified in subclause 8.5.7:

4> select a TF to be employed for calculation of a transmit power margin as follows:

5> from the TFs supported by all candidate PRACHs keep those which correspond to a single transport block of all configured RLC sizes (i.e., in idle mode, the RLC size applicable for RB0, in connected mode, the RLC sizes configured with explicit "RB mapping info"). If more than a single TF remain applicable, the UE may select any of these. Preferably the UE should select the TF which is intended to be used at the next transmission or, if such information is not available, the TF corresponding to the largest configured RLC size.

4> calculate a transmit power margin,

$$\text{Margin} = \{\min(\text{Maximum allowed UL tx power}, \text{P_MAX}) - \max(\text{Preamble_Initial_Power}, \text{Preamble_Initial_Power} + \Delta\text{Pp-m} + 10*\log_{10}(1 + (\beta_d/\beta_c)^2)\}$$

where "Maximum allowed UL tx power" is the maximum allowed uplink transmit power indicated in system information (in dBm), and P_MAX is the maximum RF output power of the UE (dBm). The margin shall be calculated for the gain factors $\beta_d$ and $\beta_c$ of the TF selected in the step above, using 10ms TTI length.

NOTE 1: the expression Preamble_Initial_Power + $\Delta$Pp-m + $10*\log_{10}(1 + (\beta_d/\beta_c)^2)$ represents the total RACH message power if the message would be sent after the initial preamble.

NOTE 2: For all PRACHs with the same TTI the UTRAN should set each of the IEs "Primary CPICH TX power", "Constant value" to the same value, and within these PRACH configurations, the UTRAN should, for all TFs including a single TB, set each of the IEs "Gain Factor $\beta_c$ ", "Gain Factor $\beta_d$" and "Power offset $P_{p\text{-}m}$" to the same value. If these guidelines are not followed, the UE behaviour is unspecified.

3> if the resulting "Margin" value is less than 6 dB:

4> select RACH with 20 ms TTI, and proceed as specified in subclause 8.5.17.

3> otherwise, if the last L1 message transmission on PRACH failed (see [15]):

4> the UE may select RACH with 20ms TTI length and proceed as specified in subclause 8.5.17.

3> otherwise:

4> select RACH with 10ms TTI length and proceed as specified in subclause 8.5.17.

### 8.5.18.2 1.28 Mcps TDD

In 1.28 Mcps TDD, a RACH may be assigned a 5, 10 or 20 ms TTI. If, in one cell, more than one RACH is defined a UE shall select the RACH that is to be used for each transmission according to the following rule:

1> if only RACHs with one particular TTI length are assigned a transport format that is suitable for the transmission of the transport block set:

2> select this RACH's TTI length.

1> if more than one RACHs are assigned a transport format that is suitable for the transmission of the transport block set:

2> select the longest of the TTI lengths of these RACHs.

## 8.5.19 Secondary CCPCH selection

In UTRAN Connected mode, the UE shall select the Secondary CCPCH according to the following rules:

1> in Cell_DCH state:

2> select Secondary CCPCH according to subclause 8.6.6.4.

1> in Cell_FACH state:

2> if System Information Block type 6 is defined and includes one or more SCCPCH that carry a FACH, compile a list of candidate SCCPCH that consists of these SCCPCH, in the order of appearance in System Information Block type 6.

NOTE 1: An SCCPCH carries a FACH if the size of the "FACH/PCH information" list within the IE "Secondary CCPCH system information" exceeds 1 or if the size of this list equals 1 while IE "Secondary CCPCH system information" does not contain an IE "PICH info".

2> otherwise:

3> compile a list of candidate SCCPCH that consists of the SCCPCH(s) included in System Information Block type 5 that carry a FACH, in the order of appearance in System Information Block type 5.

2> select an SCCPCH from the list of candidate SCCPCHs based on U-RNTI as follows:

"Index of selected SCCPCH" = U-RNTI mod K,

where K is equal to the number of candidate SCCPCHs.

1> in Cell_PCH and URA_PCH states:

2> if System Information Block type 6 is defined and includes one or more SCCPCH that carry a PCH, compile a list of candidate SCCPCH that consists of these SCCPCH, in the order of appearance in System Information Block type 6

NOTE 2: An SCCPCH carries a PCH if the IE "Secondary CCPCH system information" contains IE "PICH info"

2> otherwise compile a list of candidate SCCPCH that consists of the SCCPCH(s) included in System Information Block type 5 that that carry a PCH , in the order of appearance in System Information Block type 5

2> select an SCCPCH from the list of candidate SCCPCHs based on U-RNTI as follows:

"Index of selected SCCPCH" = U-RNTI mod K,

where K is equal to the number of candidate SCCPCHs.

The UE shall set the CFN in relation to the SFN of the current cell according to subclause 8.5.15.

The UE shall decode all transport formats on all FACHs multiplexed on the selected S-CCPCH according to its UE capability, as defined in subclauses 8.1.1.6.5 and 8.1.1.6.6, to find blocks adressed to the UE.

## 8.5.19a Secondary CCPCH and FACH selection for MCCH reception

The UE shall select the Secondary CCPCH for acquiring MCCH information according to the following rules:

1> if System Information Block type 5 is defined and includes an S-CCPCH within the IE "Secondary CCPCH system information" including a FACH for which the IE "MCCH configuration information" is included:

2> select that S-CCPCH and FACH for receiving MCCH.

1> otherwise if System Information Block type 5 is defined and includes an SCCPCH within the IE "Secondary CCPCH system information MBMS" for which the IE "FACH carrying MCCH" is included:

2> select that S-CCPCH and FACH for receiving MCCH.

## 8.5.20 Unsupported configuration

The UE should set the variable UNSUPPORTED_CONFIGURATION to TRUE if the received message is not according to the UE capabilities.

### 8.5.21 Actions related to Radio Bearer mapping

When the UE receives the IE "RB mapping info" and/or the IE "Transport format set", when transport channels, MAC-d flows or E-DCH MAC-d flows are added or deleted, when the UE performs a cell reselection or a state transition, or when the UE releases a RB, the UE shall for each of the configured Radio Bearers:

1> upon moving to CELL_FACH state from CELL_DCH state to initiate a cell update procedure and upon subsequent cell reselections until the first successfully completed cell update procedure, perform the actions defined in the remainder of this subclause only for SRB1, SRB2, SRB3 and SRB4;

1> for FDD, select the multiplexing option according to the following:

2> if the UE is in CELL_FACH state:

3> if the RB has a multiplexing option with transport channel type "FACH" for the DL and transport channel type "RACH" for the UL:

4> select this multiplexing option.

2> if the UE is in CELL_DCH state:

3> if the RB has a multiplexing option with transport channel type "DCH + HS-DSCH" for the DL, and both the corresponding DCH transport channel and MAC-d flow are configured, and with transport channel type "E-DCH" for the UL, and the corresponding E-DCH MAC-d flow is configured:

4> select this multiplexing option; else

3> if the RB has a multiplexing option with transport channel type "DCH + HS-DSCH" for the DL, and both the corresponding DCH transport channel and MAC-d flow are configured, and with transport channel type "DCH" for the UL, and the corresponding DCH transport channel is configured:

4> select this multiplexing option; else

3> if the RB has a multiplexing option with transport channel type "DCH + DSCH" for the DL:

4> the UE behaviour is unspecified; else

3> if the RB has a multiplexing option with transport channel type "HS-DSCH" for the DL, and the corresponding MAC-d flow is configured, and with transport channel type "E-DCH" for the UL, and the corresponding E-DCH MAC-d flow is configured:

4> select this multiplexing option; else

3> if the RB has a multiplexing option with transport channel type "HS-DSCH" for the DL, and the corresponding MAC-d flow is configured, and with transport channel type "DCH" for the UL, and the corresponding DCH transport channel is configured:

4> select this multiplexing option; else

3> if the RB has a multiplexing option with transport channel type "DSCH" for the DL:

4> the UE behaviour is unspecified; else

3> if the RB has a multiplexing option with transport channel type "DSCH" for the DL, and the corresponding DSCH transport channel is configured, and with transport channel type "DCH" for the UL, and the corresponding DCH transport channel is configured:

4> select this multiplexing option; else

3> if the RB has a multiplexing option with transport channel type "DCH" for the DL, and the corresponding DCH transport channel is configured, and with transport channel type "E-DCH" for the UL, and the corresponding E-DCH MAC-d flow is configured:

4> select this multiplexing option.

3> if the RB has a multiplexing option with transport channel type "DCH" for the DL, and the corresponding DCH transport channel is configured, and with transport channel type "DCH" for the UL, and the corresponding DCH transport channel is configured:

4> select this multiplexing option.

1> for TDD, select the multiplexing option according to the following:

2> if the UE is in CELL_FACH state:

3> if the RB has the multiplexing options with the transport channel types "FACH" and "DSCH" for the DL, and the corresponding FACH and DSCH transport channels are configured, and with the transport channel types "RACH" and "USCH" for the UL, and the corresponding RACH and USCH transport channels are configured:

4> if both PUSCH and PDSCH are allocated:

5> select the multiplexing option "DSCH" for DL and "USCH" for UL; else

4> if only PUSCH is allocated:

5> select the multiplexing option "FACH" for DL and "USCH" for UL; else

4> if only PDSCH is allocated:

5> select the multiplexing option "DSCH" for DL and "RACH" for UL; else

4> if neither PUSCH nor PDSCH is allocated:

5> select the multiplexing option "FACH" for DL and "RACH" for UL.

3> if the RB has a single multiplexing option with the transport channel type "FACH" for the DL and the transport channel type "RACH" for the UL:

4> select this multiplexing option; else

3> if the RB has a single multiplexing option with the transport channel type "DSCH" for the DL, and the corresponding DSCH tranfsport channel is configured, and with the transport channel type "USCH" for the UL, and the corresponding USCH transport channel is configured:

4> select this multiplexing option; else

2> if the UE is in CELL_DCH state:

3> if the RB has a multiplexing option with transport channel type "DCH + HS-DSCH" for the DL, and both the corresponding DCH transport channel and MAC-d flow are configured, and with transport channel type "DCH" for the UL, and the corresponding DCH transport channel is configured:

4> select this multiplexing option; else

3> if the RB has a multiplexing option with transport channel type "DCH + DSCH" for the DL, and both the corresponding DCH and DSCH transport channels are configured, and with transport channel type "DCH" for the UL, and the corresponding DCH transport channel is configured:

4> select this multiplexing option; else

3> if the RB has a multiplexing option with transport channel type "HS-DSCH" for the DL, and the corresponding MAC-d flow is configured, and with transport channel type "DCH" for the UL, and the corresponding DCH transport channel is configured:

4> select this multiplexing option; else

3> if the RB has a multiplexing option with transport channel type "DCH" for the DL, and the corresponding DCH transport channel is configured, and with transport channel type "DCH" for the UL, and the corresponding DCH transport channel is configured:

4> select this multiplexing option; else

3> if theRB has a multiplexing option with transport channel type "DSCH" for the DL, and the corresponding DSCH transport channel is configured, and with transport channel "USCH" for the UL, and the corresponding USCH transport channel is configured:

4> select this multiplexing option.

1> configure the MAC with the appropriate transport format set (with computed transport block sizes) for the transport channel used by that RB;

1> in case the selected multiplexing option is a multiplexing option on E-DCH:

2> the set of RLC sizes that apply to the logical channel used by that RB consists of all RLC PDU sizes listed in the IE "RLC PDU size list" in the RB mapping info for E-DCH.

1> else:

2> determine the sets of RLC sizes that apply to the logical channels used by that RB, based on the IEs "RLC size list" and/or the IEs "Logical Channel List" included in the applicable "Transport format set" (either the ones received in the same message or the ones stored if none were received);

1> in case the selected multiplexing option is a multiplexing option on RACH:

2> ignore the RLC size indexes that do not correspond to any RLC size within the Transport Format Set stored for RACH.

2> if there is no remaining RLC size index corresponding to an RLC size within the Transport Format Set stored for RACH:

3> set the variable INVALID_CONFIGURATION to TRUE.

1> if RACH is the transport channel to be used on the uplink, if that RB has a multiplexing option on RACH and if it is using AM:

2> apply the largest size amongst the ones derived according to the previous bullet for the RLC size (or RLC sizes in case the RB is realised using two logical channels) for the corresponding RLC entity.

NOTE: The IE "RB mapping info" is only included in the IE "Predefined RB configurations" in system information when used for Inter-RAT handover to UTRAN and there is no AM RLC size change involved in this case.

1> if that RB is using AM and the RLC size applicable to the uplink logical channel transporting data PDUs is different from the one derived from the previously stored configuration; and

1> none of the following conditions is met:

- the RLC size change is caused by a CELL UPDATE CONFIRM and the CELL UPDATE CONFIRM message includes the IE "Downlink counter synchronisation info".
- the RLC size change is caused by a reconfiguration message, and a cell update procedure occurs during the reconfiguration procedure and the CELL UPDATE CONFIRM message includes the IE "Downlink counter synchronisation info".
- the RLC size change is caused by a reconfiguration message, and a cell update procedure occurs during this reconfiguration procedure and the CELL UPDATE CONFIRM message includes the IE "RLC re-establish indicator" being set to TRUE for the corresponding radio bearer.

2> if the RLC size change is caused by a reconfiguration message or a CELL UPDATE CONFIRM; and

2> the IE "one sided RLC re-establishment" is included in that message and is set to TRUE:

3> re-establish the transmitting side of the corresponding RLC entity.

2> else:

3> re-establish the corresponding RLC entity.

2> configure the corresponding RLC entity with the new uplink RLC size;

2> for each AM RLC radio bearer in the CN domain as indicated in the IE "CN domain identity" in the IE "RAB info" in the variable ESTABLISHED_RABS whose RLC size is changed; and

2> for each AM RLC signalling radio bearer in the CN domain as indicated in the IE "CN domain identity" in the variable LATEST_CONFIGURED_CN_DOMAIN whose RLC size is changed:

3> if the IE "Status" in the variable CIPHERING_STATUS of this CN domain is set to "Started":

4> if the information causing the RLC re-establishment was included in system information:

5> set the HFN values for the corresponding RLC entity equal to the value of the IE "START" for this CN domain that will be included in the CELL UPDATE message following cell reselection.

NOTE: Since the UE cannot predict the START value at the time of the next CELL UPDATE transmission in the future, UTRAN should desist from changing the RLC size for a signalling radio bearer within a cell. Other than this case the change in RLC size for a signalling radio bearer is known to the UE when reading system information following cell reselection.

4> if the RLC re-establishment is caused by a CELL UPDATE CONFIRM:

5> if the whole RLC entity was re-established:

6> set the HFN values for the corresponding RLC entity in uplink and downlink equal to the value of the IE "START" included in the latest transmitted CELL UPDATE message for this CN domain.

5> if only the transmitting side of the RLC entity was re-established:

6> set the HFN value for the corresponding RLC entity in the uplink equal to the value of the IE "START" included in the latest transmitted CELL UPDATE message for this CN domain.

4> if the RLC re-establishment is caused by a reconfiguration message:

5> if the whole RLC entity was re-established:

6> set the HFN values for the corresponding RLC entity in uplink and downlink equal to the value of the IE "START" that will be included in the reconfiguration complete message for this CN domain.

5> if only the transmitting side of the RLC entity was re-established:

6> set the HFN value for the corresponding RLC entity in the direction uplink equal to the value of the IE "START" that will be included in the reconfiguration complete message for this CN domain.

NOTE1: If the UTRAN modifies the RLC size for RB2 on any reconfiguration message or Cell Update Confirm message, the UE behaviour is unspecified in this version of the specification.

NOTE2: The UE cannot rely on the configured Transport Formats to determine the RLC sizes to be used in downlink for a particular logical channel. This size can be signalled explicitly in the RLC Info IE.

1> if that RB is using UM:

2> indicate the largest RLC size applicable for uplink to the corresponding RLC entity.

1> configure MAC multiplexing according to the selected multiplexing option (MAC multiplexing shall only be configured for a logical channel if the transport channel it is mapped on according to the selected multiplexing option is the same as the transport channel another logical channel is mapped on according to the multiplexing option selected for it);

1> configure the MAC with the logical channel priorities according to selected multiplexing option;

1> configure the MAC with the set of applicable RLC Sizes for each of the logical channels used for that RB;

1> if there is no multiplexing option applicable for the transport channels and MAC-d flows to be used:

2> set the variable INVALID_CONFIGURATION to TRUE.

1> if there is more than one multiplexing option applicable for the transport channels or MAC-d flows to be used:

2> set the variable INVALID_CONFIGURATION to TRUE.

If upon cell re-selection or upon moving to CELL_FACH state from CELL_DCH state to initiate cell update procedure the UE sets variable INVALID_CONFIGURATION to TRUE as a result of the actions defined in this subclause, the UE should:

1> move to idle mode;

1> release (locally) the established signalling connections (as stored in the variable ESTABLISHED_SIGNALLING_CONNECTIONS) and the established radio access bearers (as stored in the variable ESTABLISHED_RABS) and indicate this to upper layers;

1> perform other actions when entering idle mode from connected mode as specified in subclause 8.5.2.

## 8.5.22 Actions when entering another RAT from connected mode

NOTE: This section does not apply when entering GERAN Iu mode from UTRAN connected mode.

When entering another RAT from connected mode (due to Inter-RAT handover from UTRAN, Inter-RAT cell change order from UTRAN or Inter-RAT cell reselection from UTRAN), after successful completion of the procedure causing the transition to the other RAT, the UE shall:

1> if the USIM is present, for each CN domain:

2> if a new security key set was received for this CN domain but was not used either for integrity protection or ciphering during this RRC connection:

3> set the START value for this domain to zero and;

3> store this START value for this domain in the USIM;

2> else:

3> store the current START value for every CN domain in the USIM [50].

NOTE: Prior to storing the START value, the UE should calculate this START value according to subclause 8.5.9.

1> if the SIM is present, for each CN domain:

2> if a new security key was received for this CN domain but was not used either for integrity protection or ciphering during this RRC connection:

3> set the START value for this domain to zero and;

3> store this START value for this domain in the UE.

2> else:

3> store the current START value for this CN domain in the UE.

NOTE: Prior to storing the START value, the UE should calculate this START value according to subclause 8.5.9.

## 8.5.23 Measured results on RACH

When transmitting an uplink RRC message, the UE shall:

1> if the uplink RRC message is an RRC CONNECTION REQUEST message:

2> if the IE "Intra-frequency reporting quantity for RACH reporting" and the IE "Maximum number of reported cells on RACH" are included in System Information Block type 11:

3> include a measurement report in the IE "Measured results on RACH", as specified in the IE "Intra-frequency reporting quantity for RACH reporting" and the IE "Maximum number of reported cells on RACH" in System Information Block type 11.

2> if the IE "Inter-frequency RACH reporting information" is included in System Information Block type 11:

3> if, at the time the message is to be sent, valid measurements are available; and

3> there is one or more cells for which the quantity, indicated by the IE "Reporting quantity" in the IE "Inter-frequency RACH reporting information', exceeds the threshold specified by the IE "Inter-frequency RACH reporting threshold":

4> include a measurement report in the IE "Measured results on RACH";

4> include the cells for which the quantity, indicated by the IE "Reporting quantity" in the IE "Inter-frequency RACH reporting information', exceeds the threshold specified by the IE "Inter-frequency RACH reporting threshold";

4> set the IE "Inter-frequency cell indication- SIB11" to the following value: Value_Tag MOD 2, with Value_Tag corresponding to the value tag of System Information Block Type 11.

1> for any other uplink RRC message which optionally includes the IE "Measured results on RACH":

2> if the IE "Intra-frequency reporting quantity for RACH reporting" and the IE "Maximum number of reported cells on RACH" are included in System Information Block type 12 (or "System Information Block Type 11", if these IEs are not included in the broadcast "System Information Block Type 12" or "System Information Block Type 12" is not being broadcast).

3> include a measurement report in the IE "Measured results on RACH", as specified in the IE "Intra-frequency reporting quantity for RACH reporting" and the IE "Maximum number of reported cells on RACH" in System Information Block type 12 (or "System Information Block Type 11" if these IEs are not included in the broadcast "System Information Block Type 12" or "System Information Block Type 12" is not being broadcast).

2> if the IE "Inter-frequency RACH reporting information" is included in "System Information Block type 12" (or "System Information Block Type 11" if this IE is not included in the "System Information Block Type 12" or if "System Information Block Type 12" is not being broadcast):

3> if, at the time the message is to be sent, valid measurements are available; and

3> there is one or more cells for which the quantity, indicated by the IE "Reporting quantity" in the IE "Inter-frequency RACH reporting information', exceeds the threshold specified by the IE "Inter-frequency RACH reporting threshold":

4> include a measurement report in the IE "Measured results on RACH";

4> include the cells for which the quantity, indicated by the IE "Reporting quantity" in the IE "Inter-frequency RACH reporting information", exceeds the threshold specified by the IE "Inter-frequency RACH reporting threshold";

4> set the IE "Inter-frequency cell indication- SIB11" to the following value: Value_Tag MOD 2, with Value_Tag corresponding to the value tag of System Information Block Type 11;

4> if "System Information Block Type 12" is being broadcast:

5> set the IE "Inter-frequency cell indication- SIB12" to the following value: Value_Tag MOD 2, with Value_Tag corresponding to the value tag of System Information Block Type 12.

1> include in the IE "Measured results on RACH" all requested reporting quantities for cells for which measurements are reported.

NOTE: The UE only includes measurement results for neighbour cells for which valid measurements are available at the time the message is sent. At cell access following selection or reselection to a cell, the UE may not have had sufficient time to obtain valid measurement results for neighbour cells.

1> for messages transmitted on CCCH, take care that the maximum allowed message size is not exceeded when forming the IE "Measured results on RACH", i.e. limit the number of included neighbour cells or if required omit the IE "Measured results on RACH" altogether. When limiting the number of included neighbouring cells, the number of inter-frequency cells should be limited first i.e. inter-frequency cells should be omitted before limiting the number of intra- frequency cells.

If the IE "Measured results on RACH" is present in the message, the UTRAN should extract the contents to be used for radio resource control.

## 8.5.24 Change of PLMN while in RRC connected mode

If the UE camps on an acceptable cell to obtain limited service while in RRC connected mode the UE shall:

1> keep the RRC connection and its behaviour, while camping on an acceptable cell as if in Idle mode in that PLMN;

1> if the UE re-enters "in service area" in a suitable cell, or cannot maintain limited service (i.e. cannot find any acceptable cell of any PLMN), the UE shall resume its RRC Connected mode behaviour as if it had not camped on any cell whilst being in "out of service area".

The UE shall:

1> if the NAS indicates the selection of a new PLMN resulting from manual- or automatic mode PLMN selection [25] while the UE is in RRC connected mode; or

1> if the UE attempts transmission on an acceptable cell while the UE is in RRC connected mode (i.e. to initiate emergency call), the UE shall:

2> move to idle mode;

2> release all dedicated resources;

2> indicate release (abort) of the established signalling connections (as stored in the variable ESTABLISHED_SIGNALLING_CONNECTIONS) and established radio access bearers (as stored in the variable ESTABLISHED_RABS) to upper layers;

2> clear the variable ESTABLISHED_SIGNALLING_CONNECTIONS;

2> clear the variable ESTABLISHED_RABS; and

2> perform actions specified in subclause 8.5.2 when entering idle mode from connected mode.

NOTE: NAS can inform AS about a new selected PLMN as a result of a PLMN selection (manual- or automatic mode PLMN selection (see [25])), or as a result of network signalling (after inter-RAT handover or inter-PLMN SRNS relocation). Only in the first case (manual- or automatic mode PLMN selection), this will result in an immediate RRC connection release.

## 8.5.25 Actions related to HS_DSCH_RECEPTION variable

The variable HS_DSCH_RECEPTION shall be set to "TRUE" only when all the following conditions are met:

1> for FDD and 1.28 Mcps TDD:

2> the UE is in CELL_DCH state.

1> for 3.84 Mcps TDD or 7.68 Mcps TDD:

2> a dedicated physical channel is allocated to the UE in the uplink.

1> the variable H_RNTI is set;

1> the UE has a stored IE "HS-SCCH info";

1> the UE has a stored IE "HARQ info";

1> for FDD:

2> one of the radio links in the active set is configured as the serving HS-DSCH radio link;

2> the UE has stored the following IEs:

- IE "Measurement Feedback Info";
- IE "Uplink DPCH Power Control Info" including stored $\Delta_{ACK}$, $\Delta_{NACK}$ and Ack-NACK Repetition factor.

1> for 3.84 Mcps TDD or 7.68 Mcps TDD, the UE has stored the IE "HS-PDSCH Timeslot Configuration" and either of the following conditions are met:

2> a dedicated physical channel is allocated to the UE in the downlink;

2> the UE has stored $D_{hs\text{-}sync}$.

1> for 1.28 Mcps TDD, the UE has stored the IE "HS-PDSCH Midamble Configuration" and either of the following conditions are met:

2> a dedicated physical channel is allocated to the UE in the downlink;

2> the UE has stored "PLCCH Info".

1> there is at least one RB mapped to HS-DSCH;

1> at least for one of the RB"s mapped to HS-DSCH, there is at least one MAC-hs queue (including the IE "MAC-d PDU size Info") configured for the concerning MAC-d flow;

NOTE: To enable or disable HS-DSCH reception, the UTRAN has the possibility to add/remove the concerning HS-DSCH related RB mapping options, add/remove the concerning MAC-d flows or, for FDD, add/remove the serving HS-DSCH radio link or, for TDD add/remove H-RNTI upon hard handover.

If any of the above conditions is not met and the variable HS_DSCH_RECEPTION is set to TRUE, the UE shall:

1> set the variable HS_DSCH_RECEPTION to FALSE;

1> stop any HS_SCCH reception procedures;

1> stop any HS-DSCH reception procedures;

1> clear the variable H_RNTI and remove any stored H-RNTI;

1> act as if the IE "MAC-hs reset indicator" is received and set to TRUE;

1> release all HARQ resources;

1> no long consider any radio link to be the HS-DSCH serving radio link;

1> for 3.84 Mcps TDD or 7.68 Mcps TDD, if no downlink DPCH is assigned the UE shall clear the uplink DPCH configuration and initiate the Cell Update procedure according to subclause 8.3.1, cause "radio link failure".

NOTE: If configured for HS-DSCH and not explicitly indicated as being cleared, the UE will have still stored the IEs "HARQ info", "Added or Reconfigured MAC-d flow", "RB mapping Info" and "Downlink HS-PDSCH information".

Whenever the variable HS_DSCH_RECEPTION is set to TRUE, the UE shall:

1> perform HS_SCCH reception procedures according to the stored HS-SCCH configuration as stated in:

2> subclause 8.6.6.33 for the IE "HS-SCCH Info".

1> perform HS-DSCH reception procedures according to the stored HS-PDSCH configuration as stated in:

2> subclause 8.6.3.1b for the IE "H-RNTI";

2> subclause 8.6.5.6b for the IE "HARQ info";

2> subclause 8.6.6.34 for the IE "Measurement Feedback Info".

Whenever the variable HS_DSCH_RECEPTION is set to FALSE, the UE shall:

1> not perform HS_SCCH reception procedures;

1> not perform HS-DSCH reception procedures.

## 8.5.26 Service prioritisation

The UE may perform the Service prioritisation procedure whenever it detects that it becomes incapable of receiving all services it is interested in as well as whenever there are changes concerning the subset of services that it has selected to receive. This may occur upon state transitions, service / session start, service / session stop, service reconfiguration eg. transfer mode change and preferred frequency layer changes.

If the UE detects that it is incapable of receiving all services, the UE may:

1> request upper layers to prioritise the services and to initiate release of non- prioritised services that may cause interruption in the reception of the prioritised services;

1> if reception of the prioritised MBMS service is inhibited by one or more MBMS service(s) provided via a p-t-p radio bearer:

2> request UTRAN to terminate these MBMS service(s) using the MBMS MODIFICATION REQUEST message as specified in subclause 8.7.6.

NOTE: The termination of MBMS services is performed by RRC procedures, while clearing of non- MBMS services is performed by upper layers.

## 8.5.27 MBMS frequency selection

The UE shall perform the MBMS frequency layer selection procedure upon receiving the IE "MBMS Preferred frequency information" or when specified explicitly e.g. as in subclause 8.6.9.2.

The UE shall:

1> consider MBMS services, for which a preferred frequency layer is specified, to be available only on the concerned frequency;

1> consider MBMS services, for which no preferred frequency layer is specified, to be available on all frequencies;

1> consider that UTRAN will provide any non- MBMS services on all frequencies unless specified otherwise, i.e. as specified in subclause 8.6.9.2;

1> if based on the above, the UE detects that it is incapable of receiving all services:

2> perform the Service prioritisation procedure as specified in subclause 8.5.26.

2> after having completed the release of non- prioritised services inhibiting reception of the prioritised service(s), if applicable, select the frequency corresponding with the service(s) prioritised by upper layers.

1> otherwise:

2> if a preferred frequency layer applies for the services included in variable MBMS_ACTIVATED_SERVICES:

3> select that preferred frequency.

2> otherwise:

3> select the currently used frequency.

1> if the selected frequency is different from the currently used frequency:

2> if the UE is in CELL_DCH:

3> request UTRAN to be moved to the preferred frequency by means of the MBMS MODIFICATION REQUEST message as specified in subclause 8.7.6;

3> upon receiving a request to move to the requested preferred frequency, store the frequency information of the frequency on which the UE was operating prior to cell-reselection to the preferred frequency in the variable MBMS_PREV_FREQUENCY_INFORMATION.

2> otherwise:

3> apply the cell-reselection procedure as described in [4], using the received "MBMS Preferred frequency information",

3> if the UE re-selects to a cell on the indicated preferred frequency:

4> if the UE is in CELL_FACH, CELL_PCH or URA_PCH:

5> act according to subclause 8.3.1.2.

4> store the frequency information of the frequency on which the UE was operating prior to cell-reselection to the preferred frequency in the variable MBMS_PREV_FREQUENCY_INFORMATION.

4> apply the MCCH acquisition procedure, as specified in subclause 8.7.2.

## 8.5.28 Actions related to E_DCH_TRANSMISSION variable

The variable E_DCH_TRANSMISSION shall be set to "TRUE" only when all the following conditions are met:

1> the UE is in CELL_DCH state;

1> the variable E_RNTI includes either the Primary E-RNTI or the Secondary E-RNTI or both the Primary and the Secondary E-RNTI;

1> the UE has stored the following IEs:

- IE "E-DCH Transmission Time Interval";
- IE "HARQ info for E-DCH";
- IE "E-DCH info", including the IE "E-DPCCH info" and the IE "E-DPDCH info".
- one of the radio links in the active set is configured as the serving E-DCH radio link, and for this radio link the UTRAN has configured the IE "E-HICH configuration" and the IE "E-AGCH info".

1> there is at least one logical channel mapped to E-DCH for which:

2> the corresponding E-DCH MAC-d flow is configured, i.e. the IEs "E-DCH MAC-d flow power offset" and "E-DCH MAC-d flow maximum number of retransmissions", and the transmission grant type are configured.

If any of the above conditions is not met and the variable E_DCH_TRANSMISSION is set to TRUE, the UE shall:

1> set the variable E_DCH_TRANSMISSION to FALSE;

1> stop any E-AGCH, E-HICH and E-RGCH reception procedures;

1> stop any E-DPCCH and E-DPDCH transmission procedures;

1> clear the variable E_RNTI;

1> act as if the IE "MAC-es/e reset indicator" was received and set to TRUE;

1> release all E-DCH HARQ resources;

1> no longer consider any radio link to be the serving E-DCH radio link.

Whenever the variable E_DCH_TRANSMISSION is set to TRUE, the UE shall:

1> perform E_AGCH reception procedures according to the stored E_AGCH configuration as stated in:

2> subclause 8.6.3.14 for the IE "New Primary E-RNTI" and the IE "New Secondary E-RNTI".

1> perform E-HICH reception procedures for all radio links in the E-DCH active set;

1> perform E-RGCH reception procedures for all radio links in the active set for which an E-RGCH configuration has been provided;

1> perform E-DPCCH transmission procedures according to the stored E-DPCCH configuration as stated in:

2> subclause 8.6.6.37 for the IE "E-DPCCH Info";

1> perform E-DPDCH transmission procedures according to the stored E-DPDCH configuration as stated in:

2> subclause 8.6.5.16 for the IE "E-DCH Transmission Time Interval";

2> subclause 8.6.5.17 for the IE "HARQ info for E-DCH".

2> subclause 8.6.6.37 for the IE "E-DPDCH Info".

1> inclusion of MAC-d PDU's in a MAC-e PDU for logical channels belonging to a MAC-d flow for which the IE "Non-scheduled transmission grant info" is configured shall:

2> obey the scheduling and size restrictions as specified for that MAC-d flow (see subclause 8.6.5.18).

1> inclusion of MAC-d PDU's in a MAC-e PDU for logical channels belonging to a MAC-d flow for which the IE "Scheduled transmission grant info" is configured shall:

2> be performed in accordance with the received scheduling grant on E-AGCH/E-RGCH (see [15]); and

2> obey the scheduling restrictions as specified for scheduled transmissions (see subclause 8.6.6.37).

Whenever the variable E_DCH_TRANSMISSION is set to FALSE, the UE shall:

1> not perform E-AGCH, E-HICH and E-RGCH reception procedures;

1> not perform E-DPCCH and E-DPDCH transmission procedures.

# 8.6 Generic actions on receipt and absence of an information element

## 8.6.1 CN information elements

### 8.6.1.1 Void

### 8.6.1.2 CN information info

If the IE "CN information info" is present in a message, the UE shall:

1> if the IE "Primary PLMN Identity" is present:

2> forward the content of the IE "Primary PLMN identity" to upper layers.

1> else:

2> if the IE "PLMN Identity" is present:

3> forward the content of the IE "PLMN identity" to upper layers.

1> if present, forward the content of the IE "CN common GSM-MAP NAS system information" to upper layers;

1> if the IE "CN domain related information" is present:

2> forward each occurrence of the IE "CN domain specific GSM-MAP NAS system info" together with the IE "CN domain identity" to upper layers.

2> if an IE "CN domain specific GSM-MAP NAS system info" is not present for a particular CN domain:

3> indicate to upper layers that no CN system information is available for that CN domain.

NOTE: If UTRAN at SRNS relocation includes and sets the IE "Primary PLMN identity" to the PLMN identity signalled in RANAP RELOCATION REQUEST [57], the UTRAN should also set the IE "PLMN identity" to the PLMN identity in the IE "PLMN Identity" of the Master Information Block transmitted in the cell(s) used by the UE after completed SRNS relocation.

#### 8.6.1.3 Signalling connection release indication

If the IE "Signalling Connection release indication" is present in a message, the UE shall:

1> if all radio access bearers for the CN domain identified with the value of the IE "Signalling Connection release indication" would have been released in the variable ESTABLISHED_RABS after processing of the received message:

2> indicate release of the signalling connection identified with the value of the IE "Signalling Connection release indication" to the upper layers;

2> remove the signalling connection identified with the value of the IE "Signalling Connection release indication" from the variable ESTABLISHED_SIGNALLING_CONNECTIONS.

1> if radio access bearers for the CN domain identified with the value of the IE "Signalling Connection release indication" would remain in the variable ESTABLISHED_RABS after processing of the received message:

2> set the variable INVALID_CONFIGURATION to TRUE.

### 8.6.2 UTRAN mobility information elements

#### 8.6.2.1 URA identity

The UE shall:

1> if the IE "URA identity" is included in a received message:

2> if the IE "RRC State Indicator" is included and set to "URA_PCH":

3> store this URA identity in the variable URA_IDENTITY;

3> after sending a possible message to UTRAN and entering URA_PCH state as specified elsewhere, read system information block type 2 in the selected cell;

3> if the stored URA identity in the variable URA_IDENTITY is not included in the list of URA identities in System Information Block type 2 in the selected cell, the list of URA identities in system information block type 2 is empty or if the system information block type 2 can not be found, a confirmation error of URA identity list has occurred:

4> if no URA update procedure is ongoing:

5> initiate a URA update procedure after entering URA_PCH state; see subclause 8.3.1.2.

4> if a URA update procedure is ongoing:

5> take actions as specified in subclause 8.3.1.10.

1> if the IE "URA identity" is not included in a received message:

2> if the IE "RRC State Indicator" is included and set to " URA_PCH":

3> after sending a possible message to UTRAN and entering URA_PCH state as specified elsewhere, read System Information Block type 2 in the selected cell;

3> if System Information Block type 2 in the selected cell contains a single URA identity:

4> store this URA identity in the variable URA_IDENTITY.

3> if System Information Block type 2 of the selected cell contains more than one URA identity, the list of URA identities in system information block type 2 is empty or if the system information block type 2 can not be found, a confirmation error of URA identity list has occurred:

4> if no URA update procedure is ongoing:

5> initiate a URA update procedure after entering URA_PCH state, see subclause 8.3.1.2.

4> if a URA update procedure is ongoing:

5> take actions as specified in subclause 8.3.1.10.

#### 8.6.2.2 Mapping info

If the IE "Mapping info" is received, the UE shall in this version of the specification:

1> ignore the contents of this IE.

### 8.6.3 UE information elements

#### 8.6.3.1 Activation time

If the UE receives a message in which presence is needed for the IE "Activation time", and the value is other than the default value "Now", the UE shall:

1> let the "reference CCTrCH" be defined as the CCTrCh that includes any transport channel or is associated with any physical channel which is being added, re-configured or removed, or, in the case of HS-DSCH, the CCTrCh including the associated DCH;

1> if the frame boundary immediately before the frame with the CFN (Connection Frame Number) value indicated by the IE "Activation Time" is at the TTI boundary common to all the transport channels that are multiplexed onto the reference CCTrCh:

2> select that frame boundary as the activation time T.

1> else:

2> select the next TTI boundary, which is common to all the transport channels that are multiplexed onto the reference CCTrCh, after the frame with the CFN (Connection Frame Number) value indicated by the IE "Activation Time", as the activation time T.

1> if the IE "Delay restriction flag" is received and activation time T is more than 128 frames from the CFN at which the message was received:

2> choose an activation time T as soon as possible after reception of the message, respecting the performance requirements in subclause 13.5, which is common to all the transport channels that are multiplexed onto the reference CCTrCh.

NOTE: If the UE receives a message containing the IE "Delay restriction flag" and that message causes a transport channel or physical channel reconfiguration of the reference CCTrCH then the UE behaviour is not specified.

1> at the activation time T:

2> for a physical channel reconfiguration other than an HS-DSCH related reconfiguration, caused by the received message:

3> release the physical channel configuration, which was present before T;

3> initiate the establishment of the physical channel configuration as specified for the physical channel information elements in the received message as specified elsewhere.

2> for an HS-DSCH related reconfiguration in FDD or 1.28 Mcps TDD caused by the received message:

3> select the HS-SCCH subframe boundary immediately before the first HS-SCCH subframe, which entirely falls within the 10 ms frame following T;

3> start using, at that HS-SCCH subframe boundary, the new HS-DSCH configuration in the received message, replacing any old HS-DSCH configuration.

2> for an HS-DSCH related reconfiguration in 3.84 Mcps TDD or 7.68 Mcps TDD caused by the received message:

3> start using, at activation time T, the new HS-DSCH configuration in the received message, replacing any old HS-DSCH configuration.

2> for actions, other than a physical channel reconfiguration, caused by the received message:

3> perform the actions for the information elements in the received message as specified elsewhere.

NOTE: In FDD an "HS-DSCH related reconfiguration" includes, in particular, reconfigurations that need to be time-aligned with the 2ms subframe of the HS-SCCH, HS-PDSCH and/or HS-DPCCH. For example, start and stop of HS-SCCH reception and serving HS-DSCH cell change.

If the UE receives a message in which presence is needed for the IE "Activation time", and the value is the default value "Now", the UE shall:

1> choose an activation time T as soon as possible after the reception of the message, respecting the performance requirements in subclause 13.5;

1> at the activation time T:

2> perform the actions for the information elements in the received message as specified elsewhere.

NOTE: In FDD, if the UE was in idle mode or CELL_FACH state upon reception of the message, regardless of the state the UE enters after reception of the message, and the value of the IE "Activation time" in the received message is different from "Now", the UE behaviour is unspecified. In TDD, if the UE was in idle mode or CELL_FACH state upon reception of the message, the value of the IE "Activation time" in the received message is relative to the CFN associated with the cell from which the message was received.

### 8.6.3.1a CN domain specific DRX cycle length coefficient

The UE updates CN domain specific DRX cycle length coefficient as specified in [4]. The UE shall use it to calculate the CN domain specific DRX cycle length, according to the following:

1> set k to the value of the IE "CN domain specific DRX cycle length coefficient".

1> store the result of MAX($2^k$, PBP), where PBP is the Paging Block Periodicity, as the CN domain specific DRX cycle length for the CN domain indicated by the IE "CN domain identity". For FDD PBP=1.

The UE shall determine its idle mode paging occasions and PICH monitoring occasions for that CN domain, according to [4], based on the stored CN domain specific DRX cycle length, when using DRX in idle mode.

### 8.6.3.1b H-RNTI

If the IE "New H-RNTI" is included and the UE will be in CELL_DCH state after completion of this procedure, the UE shall:

1> store the value in the variable H_RNTI;

1> determine the value for the HS_DSCH_RECEPTION variable and take the corresponding actions as described in subclause 8.5.25.

If the message that triggers the HS_DSCH_RECEPTION variable to change value from FALSE to TRUE does not contain the IE "New H-RNTI":

1> the UE behaviour is not defined.

When the variable HS_DSCH_RECEPTION is set to TRUE the UE shall:

1> use the value of the variable H_RNTI as UE identity in the HS-SCCH reception procedure in the physical layer.

### 8.6.3.2 UTRAN DRX Cycle length coefficient

If the IE "UTRAN DRX cycle length coefficient" is present, the UE shall use it to calculate the UTRAN DRX cycle length, according to the following:

1> set k to the value of the IE "UTRAN DRX cycle length coefficient";

1> store the result of MAX($2^k$,PBP), where PBP is the Paging Block Periodicity, as the DRX cycle length.

The UE shall determine its connected mode paging occasions and PICH monitoring occasions in the same way as for idle mode, according to [4].

The DRX cycle length to use in connected mode is defined in [4].

### 8.6.3.3 Generic state transition rules depending on received information elements

The IE "RRC State Indicator" indicates the state the UE shall enter. The UE shall enter the state indicated by the IE "RRC State Indicator" even if the received message includes other IEs relevant only for states other than indicated by the IE "RRC State Indicator". E.g. if the RRC state indicator is set to CELL_FACH while other IEs provide information about a configuration including dedicated channels, the UE shall enter CELL_FACH state. If however the UE has no information about the configuration corresponding to the state indicated by the IE "RRC State Indicator", it shall consider the requested configuration as invalid.

The UE shall, if the IE "RRC State Indicator" in the received message has the value:

1> "CELL_FACH":

2> enter CELL_FACH state as dictated by the procedure governing the message received.

1> "CELL_DCH":

2> if neither DPCH is assigned in the message nor is the UE in CELL_DCH:

3> set the variable INVALID_CONFIGURATION to TRUE.

2> else:

3> enter CELL_DCH state as dictated by the procedure governing the message received.

1> "CELL_PCH":

2> if the received message is RRC CONNECTION SETUP and IE "RRC State Indicator" is set to CELL_PCH:

3> set the variable INVALID_CONFIGURATION to TRUE.

2> else:

3> enter CELL_PCH state as dictated by the procedure governing the message received.

1> "URA_PCH":

2> if the received message is RRC CONNECTION SETUP and IE "RRC State Indicator" is set to URA_PCH:

3> set the variable INVALID_CONFIGURATION to TRUE.

2> else:

3> enter URA_PCH state as dictated by the procedure governing the message received.

### 8.6.3.4 Ciphering mode info

The IE "Ciphering mode info" defines the new ciphering configuration. At any given time, the UE needs to store at most two different ciphering configurations (keyset and algorithm) per CN domain at any given time in total for all radio bearers and three configurations in total for all signalling radio bearers.

If the IE "Ciphering mode info" is present and if the IE "Reconfiguration" in the variable CIPHERING_STATUS is set to TRUE, the UE shall:

1> ignore this second attempt to change the ciphering configuration; and

1> set the variable INCOMPATIBLE_SECURITY_RECONFIGURATION to TRUE.

If the IE "Ciphering mode info" is present and if the IE "Reconfiguration" in the variable CIPHERING_STATUS is set to FALSE, the UE shall:

1> if none of the IE "Status" in the variable CIPHERING STATUS has the value "Started", and this IE "Ciphering mode info" was included in a message that is not the message SECURITY MODE COMMAND; or

1> if the IE "Ciphering Mode Info" was received in the message SECURITY MODE COMMAND and there does not exist exactly one ciphering activation time in the IE "Radio bearer downlink ciphering activation time info" for each established RLC-AM and RLC-UM radio bearers included in the IE "RB information" in the IE "ESTABLISHED_RABS" for the CN domain as indicated in the variable LATEST_CONFIGURED_CN_DOMAIN; or

1> if the IE "Ciphering Mode Info" was received in the message SECURITY MODE COMMAND and the IE "Ciphering activation time for DPCH" is not included in the message, and there exist radio bearers using RLC-TM according to the IE "RB information" in the IE "ESTABLISHED_RABS" for the CN domain as indicated in the variable LATEST_CONFIGURED_CN_DOMAIN; or

1> if the IE "Ciphering Mode Info" was received in the message SECURITY MODE COMMAND and there does not exist exactly one ciphering activation time in the IE "Radio bearer downlink ciphering activation time info" for each established signalling radio bearer included in the IE "Signalling radio bearer information" in the IE "ESTABLISHED_RABS":

2> ignore this attempt to change the ciphering configuration;

2> set the variable INVALID_CONFIGURATION to TRUE;

2> perform the actions as specified in subclause 8.1.12.4c.

1> set the IE "Reconfiguration" in the variable CIPHERING_STATUS to TRUE;

1> set the IE "Status" in the variable CIPHERING_STATUS of the CN domains for which the IE "Status" of the variable SECURITY_MODIFICATION is set to "Affected" to "Started";

1> apply the new ciphering configuration in the lower layers for all RBs that belong to a CN domain for which the IE "Status" of the variable SECURITY_MODIFICATION is set to "Affected" and all signalling radio bearers:

2> using the ciphering algorithm (UEA [40]) indicated by the IE "Ciphering algorithm" as part of the new ciphering configuration;

2> for each radio bearer that belongs to a CN domain for which the IE "Status" of the variable SECURITY_MODIFICATION is set to "Affected" and all signalling radio bearers:

3> using the value of the IE "RB identity" in the variable ESTABLISHED_RABS minus one as the value of BEARER [40] in the ciphering algorithm.

1> for the downlink and the uplink, apply the new ciphering configuration as follows:

2> if the ciphering configuration for a AM or UM radio bearer or signalling radio bearer from a previously received SECURITY MODE COMMAND has not yet been applied because of the corresponding activation

times not having been reached and the current received message includes the IE "DL Counter Synch Info" or the current received message is a RADIO BEARER RECONFIGURATION message and includes the IE "New U-RNTI":

3> if the previous SECURITY MODE COMMAND was received due to new keys being received:

4> consider the new ciphering configuration to include the received new keys.

3> else if the previous SECURITY MODE COMMAND caused a change in LATEST_CONFIGURED_CN_DOMAIN:

4> consider the new ciphering configuration to include the keys associated with the LATEST_CONFIGURED_CN_DOMAIN.

3> apply the new ciphering configuration in uplink and downlink immediately following RLC re-establishment.

2> if the IE "Ciphering activation time for DPCH" is present in the IE "Ciphering mode info" and the UE was in CELL_DCH state prior to this procedure:

3> for radio bearers using RLC-TM:

4> apply the old ciphering configuration for CFN less than the number indicated in the IE "Ciphering activation time for DPCH";

4> apply the new ciphering configuration for CFN greater than or equal to the number indicated in IE "Ciphering activation time for DPCH".

2> if the IE "Radio bearer downlink ciphering activation time info" is present:

3> apply the following procedure for each radio bearer and signalling radio bearers using RLC-AM or RLC-UM indicated by the IE "RB identity":

4> suspend uplink transmission on the radio bearer or the signalling radio bearer (except for the SRB where the response message is transmitted) according to the following:

5> do not transmit RLC PDUs with sequence number greater than or equal to the uplink activation time, where the uplink activation time is selected according to the rules below.

4> select an "RLC sequence number" at which (activation) time the new ciphering configuration shall be applied in uplink for that radio bearer according to the following:

5> consider a ciphering activation time in uplink to be pending until the RLC sequence number of the next RLC PDU to be transmitted for the first time is equal to or larger than the selected activation time;

5> for each radio bearer and signalling radio bearer that has no pending ciphering activation time in uplink as set by a previous procedure changing the security configuration:

6> set a suitable value that would ensure a minimised delay in the change to the latest ciphering configuration.

5> for each radio bearer and signalling radio bearer that has a pending ciphering activation time in uplink as set by a previous procedure changing the security configuration:

6> for radio bearers and signalling radio bearers except SRB2:

7> set the same value as the pending ciphering activation time.

6> for signalling radio bearer SRB2:

7> set a suitable value that would ensure a minimised delay in the change to the latest ciphering configuration.

4> store the selected "RLC sequence number" for that radio bearer in the entry for the radio bearer in the variable RB_UPLINK_CIPHERING_ACTIVATION_TIME_INFO;

4> switch to the new ciphering configuration according to the following:

5> use the old ciphering configuration for the transmitted and received RLC PDUs with RLC sequence numbers smaller than the corresponding RLC sequence numbers indicated in the IE "Radio bearer uplink ciphering activation time info" sent to UTRAN and in the received IE "Radio bearer downlink ciphering activation time info" received from UTRAN, respectively;

5> use the new ciphering configuration for the transmitted and received RLC PDUs with RLC sequence numbers greater than or equal to the corresponding RLC sequence numbers indicated in the IE "Radio bearer uplink ciphering activation time info" sent to UTRAN and in the received IE "Radio bearer downlink ciphering activation time info" received from UTRAN, respectively;

5> for a radio bearer using RLC-AM, when the RLC sequence number indicated in the IE "Radio bearer downlink ciphering activation time info" falls below the RLC receiving window and the RLC sequence number indicated in the IE "Radio bearer uplink ciphering activation time info" falls below the RLC transmission window, the UE may release the old ciphering configuration for that radio bearer;

5> if an RLC reset or re-establishment of the transmitting side of an RLC entity occurs before the activation time for the new ciphering configuration has been reached in uplink, ignore the activation time and apply the new ciphering configuration in uplink immediately after the RLC reset or RLC re-establishment;

5> if an RLC reset or re-establishment of the receiving side of an RLC entity occurs before the activation time for the new ciphering configuration has been reached in downlink, ignore the activation time and apply the new ciphering configuration in downlink immediately after the RLC reset or RLC re-establishment.

2> if the current received message includes the IE "Downlink counter synchronisation info" or the current received message is a RADIO BEARER RECONFIGURATION message and includes the IE "New U-RNTI":

3> apply the new ciphering configuration in uplink and downlink immediately following RLC re-establishment.

If the IE "Radio bearer downlink ciphering activation time info" was received in another message than SECURITY MODE COMMAND:

1> the UE behaviour is unspecified.

If the IE "Ciphering mode info" is not present, the UE shall:

1> for the downlink and the uplink, apply the ciphering configuration as follows:

2> if the ciphering configuration for a AM or UM radio bearer or signalling radio bearer from a previously received SECURITY MODE COMMAND has not yet been applied because of the corresponding activation times not having been reached and the current received message includes the IE "Downlink counter synchronisation info" or the current received message is a RADIO BEARER RECONFIGURATION message and includes the IE "New U-RNTI":

3> if the previous SECURITY MODE COMMAND was received due to new keys being received:

4> consider the ciphering configuration to include the received new keys.

3> else if the previous SECURITY MODE COMMAND caused a change in LATEST_CONFIGURED_CN_DOMAIN:

4> consider the ciphering configuration to include the keys associated with the LATEST_CONFIGURED_CN_DOMAIN.

3> apply the ciphering configuration in uplink and downlink immediately following RLC re-establishment.

2> else:

3> not change the ciphering configuration.

### 8.6.3.5 Integrity protection mode info

The IE "Integrity protection mode info" defines the new integrity protection configuration. At any given time, the UE needs to store at most three different integrity protection configurations (keysets) in total for all signalling radio bearers for all CN domains.

If the IE "Integrity protection mode info" is present and if the IE "Reconfiguration" in the variable INTEGRITY_PROTECTION_INFO is set to TRUE, the UE shall:

1> ignore this second attempt to change the integrity protection configuration; and

1> set the variable INCOMPATIBLE_SECURITY_RECONFIGURATION to TRUE.

If the IE "Integrity protection mode command" has the value "Start", the IE "Status" in the variable INTEGRITY_PROTECTION_INFO has the value "Not started" and the IE "Integrity protection mode info" was not included in the message SECURITY MODE COMMAND; or

If the IE "Integrity protection mode command" has the value "Start", the IE "Status" in the variable INTEGRITY_PROTECTION_INFO has the value "Not started", the IE "Integrity protection mode info" was included in the message SECURITY MODE COMMAND and the IE "Integrity protection algorithm" is not included; or

If the IE "Integrity protection mode command" has the value "Modify" and the IE "Status" in the variable INTEGRITY_PROTECTION_INFO has the value "Not Started"; or

If the IE "Integrity protection mode command" has the value "Start", the IE "Status" in the variable INTEGRITY_PROTECTION_INFO has the value "Started" and the IE "Integrity protection mode command info" was included in the message SECURITY MODE COMMAND; or

If the IE "Integrity protection mode command" has the value "Modify" and there does not exist exactly one integrity protection activation time in the IE "Downlink integrity protection activation info" for each established signalling radio bearer included in the IE "Signalling radio bearer information" in the IE "ESTABLISHED_RABS"; or

If the IE "Integrity protection mode command" has the value "Modify", the IE "Status" in the variable INTEGRITY_PROTECTION_INFO has the value "Started" and the IE "Integrity protection mode info" was not included in the message SECURITY MODE COMMAND:

the UE shall:

1> ignore this attempt to change the integrity protection configuration; and

1> set the variable INVALID_CONFIGURATION to TRUE.

If the IE "Integrity protection mode info" is not present, the UE shall:

1> not change the integrity protection configuration.

If the IE "Integrity protection mode info" is present and if the IE "Reconfiguration" in the variable INTEGRITY_PROTECTION_INFO is set to FALSE, the UE shall:

1> set the IE "Reconfiguration" in the variable INTEGRITY_PROTECTION_INFO to TRUE;

1> perform the actions in accordance with subclauses 8.6.3.5.1, 8.6.3.5.2 and 8.6.3.5.3.

#### 8.6.3.5.1 Initialisation of Integrity Protection

The UE shall:

1> if the IE "Integrity protection mode command" has the value "start" and the IE "Status" in the variable INTEGRITY_PROTECTION_INFO has the value "Not started", and this IE was included in the message SECURITY MODE COMMAND:

2> initialise the information for all signalling radio bearers in the variable INTEGRITY_PROTECTION_INFO according to the following:

3> set the IE "Uplink RRC Message sequence number" in the variable INTEGRITY_PROTECTION_INFO to zero;

3> do not set the IE "Downlink RRC Message sequence number" in the variable INTEGRITY_PROTECTION_INFO;

3> set the variable INTEGRITY_PROTECTION_ACTIVATION_INFO to zero for each signalling radio bearer in the IE "ESTABLISHED_RABS".

NOTE: The IEs "Integrity protection activation info" and "RRC Message sequence number"included in the IE "Integrity Check Info" in the transmitted message do not have identical values, but integrity protection is applied from the first transmitted message.

2> set the IE "Status" in the variable INTEGRITY_PROTECTION_INFO to the value "Started";

2> perform integrity protection on the received message, applying the new integrity protection configuration, as described in subclause 8.5.10.1 by:

3> using the algorithm (UIA [40]) indicated by the IE "Integrity protection algorithm" contained in the IE "Integrity protection mode info";

3> using the IE "Integrity protection initialisation number", contained in the IE "Integrity protection mode info" as the value of FRESH [40].

2> start applying the new integrity protection configuration in the downlink for each signalling radio bearer in the IE "ESTABLISHED_RABS" except RB2 at the next received RRC message;

2> start applying the new integrity protection configuration in the downlink for signalling radio bearer RB2 from and including the received SECURITY MODE COMMAND message;

2> start applying the new integrity protection configuration in the uplink for signalling radio bearer RB2 from and including the transmitted SECURITY MODE COMPLETE message;

2> start applying the new integrity protection configuration in the uplink for signalling radio bearers other than RB2 at the uplink activation time included in the IE "Uplink integrity protection activation info".

NOTE: After Inter-RAT handover to UTRAN, and ciphering was activated in the other RAT, then during the first security mode control procedure following the handover, UE activates integrity protection using the integrity key of the same key set as used in the other RAT (see.subclause 8.3.6.3).

#### 8.6.3.5.2 Integrity Protection Re-configuration for SRNS Relocation and handover from GERAN Iu mode

The UE shall:

1> if IE "Integrity protection mode command" has the value "start" and the IE "Status" in the variable INTEGRITY_PROTECTION_INFO has the value "Started" and this IE was not included SECURITY MODE COMMAND:

NOTE: This case is used in SRNS relocation and in handover from GERAN *Iu mode*.

2> perform integrity protection on the received message, applying the new integrity protection configuration, as described in subclause 8.5.10.1 by:

3> using the algorithm (UIA [40]) indicated by the IE "Integrity protection algorithm" contained in the IE "Integrity protection mode info";

3> using the IE "Integrity protection initialisation number", contained in the IE "Integrity protection mode info" as the value of FRESH [40].

2> let RBm be the signalling radio bearer where the reconfiguration message was received and let RBn be the signalling radio bearer where the response message is transmitted;

2> prohibit transmission of RRC messages on all signalling radio bearers in the IE "ESTABLISHED_RABS" except on RB0 and the radio bearer where the response message is transmitted;

2> for the downlink, for each signalling radio bearer, if for the signalling radio bearer, a security configuration triggered by a previous SECURITY MODE COMMAND has not yet been applied, due to the activation time for the signalling radio bearer not having been reached:

3> set "Down link RRC Message sequence number" for this signalling radio bearer in the variable INTEGRITY_PROTECTION_INFO to (activation time -1), where the activation time is the corresponding activation time for this signalling radio bearer;

3> if the previous SECURITY MODE COMMAND was received due to new keys being received:

4> consider the new integrity protection configuration to include the received new keys.

3> else if the previous SECURITY MODE COMMAND caused a change in LATEST_CONFIGURED_CN_DOMAIN:

4> consider the new Integrity Protection configuration to include the keys associated with the LATEST_CONFIGURED_CN_DOMAIN associated with the previously received SECURITY MODE COMMAND.

2> start applying the new integrity protection configuration in the downlink for each signalling radio bearer in the IE "ESTABLISHED_RABS" except RBm at the next received RRC message for the corresponding signalling radio bearer;

2> start applying the new integrity protection configuration in the downlink for signalling radio bearer RBm from and including the received configuration message;

2> start applying the new integrity protection configuration in the uplink for signalling radio bearer RBn from and including the transmitted response message;

2> start applying the new integrity protection configuration in the uplink for signalling radio bearers other than RBn from the first message onwards.

#### 8.6.3.5.3 Integrity Protection modification in case of new keys or initialisation of signalling connection

The UE shall:

1> if the IE "Integrity protection mode command" has the value "modify" and the IE "Status" in the variable INTEGRITY_PROTECTION_INFO has the value "Started" and this IE was included in SECURITY MODE COMMAND:

2> store the (oldest currently used) integrity protection configuration until activation times have elapsed for the new integrity protection configuration to be applied on all signalling radio bearers;

2> start applying the new integrity protection configuration in the downlink for each signalling radio bearer n, at the first received message with RRC Sequence number greater than or equal to the RRC sequence number indicated by the entry for signalling radio bearer n in the "RRC message sequence number list" in the IE "Downlink integrity protection activation info", included in the IE "Integrity protection mode info";

2> perform integrity protection on the received message, applying the new integrity protection configuration, as described in subclause 8.5.10.1;

3> if present, use the algorithm indicated by the IE "Integrity protection algorithm" (UIA [40]);

2> set the content of the variable INTEGRITY_PROTECTION_ACTIVATION_INFO according to the following:

3> for each established signalling radio bearer, stored in the variable ESTABLISHED_RABS:

4> select a value of the RRC sequence number at which (activation) time the new integrity protection configuration shall be applied in uplink for that signalling radio bearer according to the following:

5> for each signalling radio bearer except RB0:

6> set the activation time for the new integrity protection configuration to the next RRC SN.

4> for signalling radio bearer RB0:

5> set the value of the included RRC sequence number to greater than or equal to the current value of the RRC sequence number for signalling radio bearer RB0 in the variable INTEGRITY_PROTECTION_INFO, plus the value of the constant N302 plus two.

4> prohibit the transmission of RRC messages on all signalling radio bearers, except for RB2, with RRC SN greater than or equal to the value in the "RRC message sequence number list" for the signalling radio bearer in the IE "Uplink integrity protection activation info" of the variable INTEGRITY_PROTECTION_ACTIVATION_INFO.

2> start applying the new integrity protection configuration in the uplink at the RRC sequence number, for each RBn, except for signalling radio bearer RB2, indicated by the entry for signalling radio bearer n in the "RRC message sequence number list" in the IE "Uplink integrity protection activation info", included in the variable INTEGRITY_PROTECTION_ACTIVATION_INFO;

2> start applying the new integrity protection configuration in the uplink at the RRC sequence number for signalling radio bearer RB2, as specified for the procedure initiating the integrity protection reconfiguration;

2> start applying the new integrity protection configuration in the downlink at the RRC sequence number, for each RBn, except for signalling radio bearer RB2, indicated by the entry for signalling radio bearer n in the "RRC message sequence number list" in the IE "Downlink integrity protection activation info";

NOTE: For signalling radio bearers that have a pending activation time as set for integrity protection by a previous procedure changing the integrity protection configuration, UTRAN should set this value in IE "Downlink integrity protection activation info".

2> start applying the new integrity protection configuration in the downlink at the RRC sequence number for signalling radio bearer RB2, as specified for the procedure initiating the integrity protection reconfiguration.

### 8.6.3.6 Void

### 8.6.3.7 Void

### 8.6.3.8 Integrity check info

If the IE "Integrity check info" is present the UE shall:

1> act as described in subclause 8.5.10.1.

### 8.6.3.9 New C-RNTI

If the IE "New C-RNTI" is included, the UE shall:

1> store the value in the variable C_RNTI, replacing any old stored value;

1> use that C-RNTI when using common transport channels of type RACH and FACH in the current cell.

### 8.6.3.9a New DSCH-RNTI

In TDD if the IE "New DSCH-RNTI" is included, the UE shall:

1> if the UE will be in CELL_DCH or CELL_FACH at the end of the procedure where the received message included this IE:

2> if the UE supports DSCH or USCH as indicated in the IE "Physical Channel Capability" included in the IE "UE Radio Access Capability":

3> store the value in the variable DSCH_RNTI, replacing any old stored value;

3> use that DSCH-RNTI when using SHCCH signalling in the current cell.

### 8.6.3.10 New U-RNTI

If the IE "New U-RNTI" is included in a received message, the UE shall:

1> store the value in the variable U_RNTI, replacing any old stored value.

### 8.6.3.11 RRC transaction identifier

The IE "RRC transaction identifier" may be used, together with the message type, for identification of an invocation of a downlink procedure (transaction). The UE behaviour for accepting or rejecting transactions based on the message type and the IE "RRC transaction identifier" is specified below.

If the IE "RRC transaction identifier" is included in a received message, the UE shall perform the actions below. The UE shall:

If the received message is any of the messages:

- RADIO BEARER SETUP; or
- RADIO BEARER RECONFIGURATION; or
- RADIO BEARER RELEASE; or
- TRANSPORT CHANNEL RECONFIGURATION; or
- PHYSICAL CHANNEL RECONFIGURATION:

the UE shall:

1> if the variable ORDERED_RECONFIGURATION is set to FALSE; and

1> if the variable CELL_UPDATE_STARTED is set to FALSE; and

1> if the received message does not contain a protocol error according to clause 9 and the variable PROTOCOL_ERROR_REJECT is set to FALSE; and

1> if the table "Accepted transactions" in the variable TRANSACTIONS does not contain an entry with an IE "Message Type" set to ACTIVE SET UPDATE:

2> accept the transaction; and

2> store the IE "Message type" and the IE "RRC transaction identifier" of the received message in the table "Accepted transactions" in the variable TRANSACTIONS.

1> else:

2> if the variable ORDERED_RECONFIGURATION is set to TRUE; or

2> if the variable CELL_UPDATE_STARTED is set to TRUE; or

2> if the table "Accepted transactions" in the variable TRANSACTIONS contains an entry with an IE "Message Type" set to ACTIVE SET UPDATE; or

2> if the received message contains a protocol error according to clause 9 causing the variable PROTOCOL_ERROR_REJECT to be set to TRUE:

3> if the IE "RRC transaction identifier" of the received message is identical to the "RRC transaction identifier" stored for the same "Message Type" as the received message in the table "Accepted transactions" in the variable TRANSACTIONS:

4> ignore the transaction; and

4> continue with any ongoing processes and procedures as the message was not received;

4> and end the procedure.

3> else:

4> reject the transaction; and

4> if the IE "Message Type" of the received message is not present in the table "Rejected transactions" in the variable TRANSACTIONS:

5> store the IE "Message type" and the IE "RRC transaction identifier" of the received message in the table "Rejected transactions" in the variable TRANSACTIONS.

Else:

If the received message is any of the messages:

- RRC CONNECTION SETUP; or
- CELL UPDATE CONFIRM; or
- URA UPDATE CONFIRM; or
- UE CAPABILITY ENQUIRY:

the UE shall:

1> if the IE "Message Type" of the received message is not present in the table "Accepted transactions" in the variable TRANSACTIONS:

2> if the received message does not contain a protocol error according to clause 9 and the variable PROTOCOL_ERROR_REJECT is set to FALSE:

3> accept the transaction; and

3> store the IE "Message type" and the IE "RRC transaction identifier" of the received message in the table "Accepted transactions" in the variable TRANSACTIONS.

2> else:

2> if the received message contains a protocol error according to clause 9 causing the variable PROTOCOL_ERROR_REJECT to be set to TRUE:

3> reject the transaction; and

3> if the IE "Message Type" of the received message is not present in the table "Rejected transactions" in the variable TRANSACTIONS:

4> store the IE "Message type" and the IE "RRC transaction identifier" of the received message in the table "Rejected transactions" in the variable TRANSACTIONS.

1> else:

1> if the IE "Message Type" of the received message is present in the table "Accepted transactions" in the variable TRANSACTIONS:

2> if the IE "RRC transaction identifier" of the received message is identical to the "RRC transaction identifier" stored for the "Message Type" in the table "Accepted transactions" in the variable TRANSACTIONS:

3> ignore the transaction; and

3> continue with any ongoing processes and procedures as the message was not received; and

3> end the procedure.

2> else:

2> if the IE "RRC transaction identifier" of the received message is different from the "RRC transaction identifier" stored for the "Message Type" in the table "Accepted transactions" in the variable TRANSACTIONS:

3> if the received message does not contain a protocol error according to clause 9 and the variable PROTOCOL_ERROR_REJECT is set to FALSE:

4> ignore the once accepted transaction and instead accept the new transaction; and

4> store the IE "Message type" and the IE "RRC transaction identifier" of the received message in the table "Accepted transactions" in the variable TRANSACTIONS, replacing the previous entry.

NOTE 1: The UE is expected to process the first RRC CONNECTION SETUP/CELL UPDATE CONFIRM/URA UPDATE COMFIRM message that it receives after transmitting an RRC CONNECTION REQUEST/CELL_UPDATE/URA_UPDATE message. If the UE receives further RRC CONNECTION SETUP/CELL UPDATE CONFIRM/URA UPDATE COMFIRM messages without having transmitted another RRC CONNECTION REQUEST/CELL_UPDATE/URA_UPDATE message, the UE is not required to process these messages.

NOTE 2: If the previously accepted transaction was a CELL UPDATE CONFIRM/URA UPDATE CONFIRM that included the IE "Dowlink counter synchronisation info", rather than ignore the first accepted transaction the UE may continue with the first transaction in the case where a cell re-selection interrupted the on-going procedure causing a cell update procedure to be triggered. In this case the response message acts as an explicit acknowledgement of both the CELL UPDATE CONFIRM/URA UPDATE CONFIRM message signalling an SRNS relocation and the subsequent CELL UPDATE CONFIRM/URA UPDATE CONFIRM.

3> else:

3> if the received message contains a protocol error according to clause 9 causing the variable PROTOCOL_ERROR_REJECT to be set to TRUE:

4> reject the transaction; and

4> if the IE "Message Type" of the received message is not present in the table "Rejected transactions" in the variable TRANSACTIONS:

5> store the IE "Message type" and the IE "RRC transaction identifier" of the received message in the table "Rejected transactions" in the variable TRANSACTIONS.

Else:

If the received message is any of the messages:

- HANDOVER FROM UTRAN COMMAND; or
- CELL CHANGE ORDER FROM UTRAN:

the UE shall:

1> if the variable ORDERED_RECONFIGURATION is set to TRUE;

2> reject the transaction; and

2> if the IE "Message Type" of the received message is not present in the table "Rejected transactions" in the variable TRANSACTIONS:

3> store the IE "Message type" and the IE "RRC transaction identifier" of the received message in the table "Rejected transactions" in the variable TRANSACTIONS.

Else:

If the received message is any other message, the UE shall:

1> if the IE "Message Type" of the received message is not present in the table "Accepted transactions" in the variable TRANSACTIONS:

2> if the received message does not contain a protocol error according to clause 9 and the variable PROTOCOL_ERROR_REJECT is set to FALSE:

3> accept the transaction; and

3> store the IE "Message type" and the IE "RRC transaction identifier" of the received message in the table "Accepted transactions" in the variable TRANSACTIONS.

2> else:

2> if the received message contains a protocol error according to clause 9 causing the variable PROTOCOL_ERROR_REJECT to be set to TRUE:

3> reject the transaction; and

3> store the IE "Message type" and the IE "RRC transaction identifier" of the received message in the table "Rejected transactions" in the variable TRANSACTIONS.

1> else:

1> if the IE "Message Type" of the received message is present in the table "Accepted transactions" in the variable TRANSACTIONS:

2> if the IE "RRC transaction identifier" of the received message is identical to the "RRC transaction identifier" stored in any entry for the "Message Type" in the table "Accepted transactions" in the variable TRANSACTIONS:

3> ignore the transaction; and

3> continue with any ongoing processes and procedures as the message was not received; and

3> end the procedure.

2> else:

2> if the IE "RRC transaction identifier" of the received message is different from the "RRC transaction identifier" stored in all entries for the "Message Type" in the table "Accepted transactions" in the variable TRANSACTIONS:

3> if the received message does not contain a protocol error according to clause 9 and the variable PROTOCOL_ERROR_REJECT is set to FALSE:

4> accept the additional transaction; and

4> store the IE "Message type" and the IE "RRC transaction identifier" of the received message in the table "Accepted transactions" in the variable TRANSACTIONS, in addition to the already existing entries.

3> else:

3> if the received message contains a protocol error according to clause 9 causing the variable PROTOCOL_ERROR_REJECT to be set to TRUE:

4> reject the transaction; and

4> store the IE "Message type" and the IE "RRC transaction identifier" of the received message in the table "Rejected transactions" in the variable TRANSACTIONS.

### 8.6.3.12 Capability Update Requirement

If the IE "Capability Update Requirement" is included the UE shall:

1> if the IE "UE radio access FDD capability update requirement" has the value TRUE:

2> if the UE supports FDD mode:

3> store its UTRA FDD capabilities and its UTRA capabilities common to FDD and TDD in the IE "UE radio access capability" and the IE "UE radio access capability extension" in variable UE_CAPABILITY_REQUESTED as specified below:

4> if the UE supports multiple UTRA FDD Frequency Bands; or

4> if the UE supports a single UTRA FDD Frequency Band different from Band I [21]:

5> store the IE "UE radio access capability", excluding IEs "RF capability FDD" and "Measurement capability";

5> store the IE "UE radio access capability extension", including the IEs "RF capability FDD extension" and the "Measurement capability extension" associated with each supported UTRA FDD frequency band indicated in the IE "Frequency band".

4> else:

5> store the IE "UE radio access capability", including the IEs "RF capability FDD" and "Measurement capability" associated with the Band I [21].

1> if the IE "UE radio access 3.84 Mcps TDD capability update requirement" has the value TRUE:

2> if the UE supports 3.84 Mcps TDD mode:

3> store its UTRAN-specific 3.84 Mcps TDD capabilities and its UTRAN–specific capabilities common to FDD and TDD in the variable UE_CAPABILITY_REQUESTED.

1> if the IE "UE radio access 7.68 Mcps TDD capability update requirement" has the value TRUE:

2> if the UE supports 7.68 Mcps TDD mode:

3> store its UTRAN-specific 7.68 Mcps TDD capabilities and its UTRAN–specific capabilities common to FDD and TDD in the variable UE_CAPABILITY_REQUESTED.

1> if the IE "UE radio access 1.28 Mcps TDD capability update requirement" has the value TRUE:

2> if the UE supports 1.28 Mcps TDD mode:

3> store its UTRAN-specific 1.28 Mcps TDD capabilities and its UTRAN–specific capabilities common to FDD and TDD in the variable UE_CAPABILITY_REQUESTED.

1> if the IE "System specific capability update requirement list" is present:

2> for each of the RAT requested in the IE "UE system specific capability"

3> if the UE supports the listed RAT:

4> include its inter-RAT radio access capabilities for the listed RAT in the IE "UE system specific capability" from the variable UE_CAPABILITY_REQUESTED.

4> if the listed RAT is GSM and PS Handover to GPRS is supported:

5> include the IE "MS Radio Access Capability" in the variable UE_CAPABILITY_REQUESTED;

If the IE " Capability update requirement " is not present, the UE shall:

1> assume the default values as specified in subclause 10.3.3.2 and act in accordance with the above.

### 8.6.3.13 Group release information

The UE shall apply the following procedure to compare the IE "U-RNTI group" with the U-RNTI allocated to the UE stored in the variable U_RNTI.

If the IE "group discriminator" is equal to "All":

1> consider this as a group identity match.

If the IE "group discriminator" is equal to "U-RNTI mask":

1> let N be the value of the IE "U-RNTI bit mask index";

1> if N is equal to b20, b21, … or b31:

2> compare pairs of bits, starting from bit b31 downto, and including, bit N of the "SRNC identity" of the IE "U-RNTI" with the corresponding bits stored in the variable U_RNTI;

2> if all pairs of bits are equal:

3> consider this as a group identity match.

1> if N is equal to b1, b2, … or b19:

2> compare pairs of bits, starting from bit b31 downto, and including, bit b20 of the "SRNC identity" in the IE "U-RNTI" with the corresponding bits of the "SRNC identity" stored in the variable U_RNTI;

2> if all pairs of bits are equal:

3> then compare pairs of bits, starting from bit b19 downto, and including, bit N of the "S-RNTI" in the IE "U-RNTI" with the corresponding bits of the "S-RNTI" stored in the variable U_RNTI;

3> if all pairs of bits are equal:

4> consider this as a group identity match.

#### 8.6.3.14 New E-RNTI

If the IE "New Primary E-RNTI" and/or the IE "New Secondary E-RNTI" are/is included and the UE will be in CELL_DCH state after completion of this procedure, the UE shall:

1> store the new value(s) in the variable E_RNTI;

1> determine the value for the E_DCH_TRANSMISSION variable and take the corresponding actions as described in subclause 8.5.28.

If, after the completion of this procedure, the variable E_DCH_TRANSMISSION is set to FALSE, the UE shall:

1> clear the variable E-RNTI.

When the variable E_DCH_TRANSMISSION is set to TRUE the UE shall:

1> use the value of the Primary E-RNTI and/or Secondary E-RNTI stored in the variable E_RNTI as UE identities in the E-AGCH reception procedure in the physical layer.

### 8.6.4 Radio bearer information elements

#### 8.6.4.1 Signalling RB information to setup list

If the IE "Signalling RB information to setup list" is included the UE shall:

1> use the same START value to initialise the COUNT-C and COUNT-I variables for all the signalling radio bearers in the list;

1> if the IE "Signalling RB information to setup list" was included in the RADIO BEARER SETUP message:

2> if the variable LATEST_CONFIGURED_CN_DOMAIN has been initialised:

3> calculate the START value only once during this procedure according to subclause 8.5.9 for the CN domain indicated in the variable LATEST_CONFIGURED_CN_DOMAIN;

3> store the calculated START value in the variable START_VALUE_TO_TRANSMIT.

1> for each occurrence of the IE "Signalling RB information to setup":

2> use the value of the IE "RB identity" as the identity of the signalling radio bearer to setup;

2> if the signalling radio bearer identified with the IE "RB identity" does not exist in the variable ESTABLISHED_RABS:

3> create a new entry for the signalling radio bearer in the variable ESTABLISHED_RABS.

2> if the IE "Signalling RB information to setup list" was received in a message other than HANDOVER TO UTRAN COMMAND; and

2> if the variable LATEST_CONFIGURED_CN_DOMAIN has been initialised and the value "STATUS" of the variable CIPHERING_STATUS of the CN domain stored in this variable is "Started":

3> if the IE "Uplink RLC mode" or the IE "Downlink RLC mode" either in the IE "RLC info" or referenced by the RB identity in the IE "Same as RB" is set to "AM RLC" or "UM RLC":

4> initialise the 20 MSB of the hyper frame number component of COUNT-C for this signalling radio bearer with the START value in the variable START_VALUE_TO_TRANSMIT;

4> set the remaining LSB of the hyper frame number component of COUNT-C for this signalling radio bearer to zero;

4> start to perform ciphering on this signalling radio bearer, using the value of the IE "RB identity" minus one as the value of BEARER in the ciphering algorithm.

2> if the IE "Signalling RB information to setup list" was received in a message other than HANDOVER TO UTRAN COMMAND; and

2> if the variable LATEST_CONFIGURED_CN_DOMAIN has been initialised and the value "Status" of the variable "INTEGRITY_PROTECTION_INFO" of the CN domain stored in this variable is "Started":

3> initialise the 20 MSB of the hyper frame number component of COUNT-I for this signalling radio bearer with the START value in the variable START_VALUE_TO_TRANSMIT;

3> set the remaining LSB of the hyper frame number component of COUNT-I for this signalling radio bearer to zero;

3> for this signalling radio bearer, set the IE "Uplink RRC Message sequence number" in the variable INTEGRITY_PROTECTION_INFO to zero;

3> start performing integrity protection according to subclauses 8.5.10.1 and 8.5.10.2.

2> perform the actions for the IE "RLC info" as specified in subclause 8.6.4.9, applied for that signalling radio bearer;

2> perform the actions for the IE "RB mapping info" as specified in subclause 8.6.4.8, applied for that signalling radio bearer.

1> apply a default value of the IE "RB identity" equal to 1 for the first IE "Signalling RB information to setup"; and

1> increase the default value by 1 for each occurrence.

NOTE: The UTRAN should only use the default value of the IE "RB identity" within the RRC Connection Setup and Handover to UTRAN Command messages. If the default value of the IE "RB identity" is used in any other message then the UE behaviour is not specified.

### 8.6.4.2 RAB information for setup

If the IE "RAB information for setup" is included, the procedure is used to establish radio bearers belonging to a radio access bearer, and the UE shall:

1> if several IEs "RAB information for setup" are included and the included IEs "CN domain identity" in the IE "RAB info" does not all have the same value:

2> set the variable INVALID_CONFIGURATION to TRUE.

1> if the radio access bearer identified with the IE "RAB info" does not exist in the variable ESTABLISHED_RABS:

2> create a new entry for the radio access bearer in the variable ESTABLISHED_RABS;

2> store the content of the IE "RAB info" in the entry for the radio access bearer in the variable ESTABLISHED_RABS;

2> indicate the establishment of the radio access bearer to the upper layer entity using the IE "CN domain identity", forwarding the content of the IE "RAB identity";

2> if prior to this procedure there exists no transparent mode radio bearer for the CN domain included in the IE "CN domain identity" and at least one transparent mode radio bearer is included in the IE "RB information to setup"; or

2> if at least one RLC-AM or RLC-UM radio bearer is included in the IE "RB information to setup":

3> calculate the START value only once during this procedure (the same START value shall be used on all new radio bearers created for this radio access bearer) according to subclause 8.5.9 for the CN domain as indicated in the IE "CN domain identity" in the IE "RAB info" part of the IE "RAB information to setup";

3> store the calculated START value in the variable START_VALUE_TO_TRANSMIT.

1> for each radio bearer in the IE "RB information to setup":

2> if the radio bearer identified with the IE "RB identity" does not exist in the variable ESTABLISHED_RABS:

3> perform the actions specified in subclause 8.6.4.3;

3> store information about the new radio bearer in the entry for the radio access bearer identified by "RAB info" in the variable ESTABLISHED_RABS;

3> create a new RAB subflow for the radio access bearer;

3> number the RAB subflow in ascending order, assigning the smallest number to the RAB subflow corresponding to the first radio bearer in the list;

3> if the IE "CN domain identity" in the IE "RAB info" is set to "PS domain" and the number of RAB subflows for the radio access bearer is greater than 1:

4> set the variable INVALID_CONFIGURATION to TRUE.

2> if the radio bearer identified with the IE "RB identity" already exists in the variable ESTABLISHED_RABS:

3> set the variable INVALID_CONFIGURATION to TRUE.

### 8.6.4.2a RAB information to reconfigure

If the IE "RAB information to reconfigure" is included then the UE shall:

1> if the entry for the radio access bearer identified by the IE "CN domain identity" together with the IE "RAB Identity" in the variable ESTABLISHED_RABS already exists:

2> perform the action for the IE "NAS Synchronization Indicator", according to subclause 8.6.4.12.

1> else:

2> set the variable INVALID_CONFIGURATION to TRUE.

### 8.6.4.3 RB information to setup

If the IE "RB information to setup" is included, the UE shall apply the following actions on the radio bearer identified with the value of the IE "RB identity". The UE shall:

1> use the same START value to initialise the hyper frame number components of COUNT-C variables for all the new radio bearers to setup;

1> perform the actions for the IE "PDCP info", if present, according to subclause 8.6.4.10, applied for the radio bearer;

1> perform the actions for the IE "RLC info", according to subclause 8.6.4.9, applied for the radio bearer;

1> perform the actions for the IE "RB mapping info", according to subclause 8.6.4.8, applied for the radio bearer;

1> if the IE "Downlink RLC mode" either in the IE "RLC info" or referenced by the RB identity in the IE "Same as RB" is set to "TM RLC":

2> configure delivery of erroneous SDUs in lower layers according to indication from upper layer [5].

1> if the IE "RB information to setup" was received in a message other than HANDOVER TO UTRAN COMMAND; and

1> if the IE "Uplink RLC mode" or the IE "Downlink RLC mode" either in the IE "RLC info" or referenced by the RB identity in the IE "Same as RB" is set to "AM RLC" or "UM RLC":

2> initialise the 20 MSB of the hyper frame number component of COUNT-C for this radio bearer with the START value in the variable START_VALUE_TO_TRANSMIT;

2> set the remaining LSB of the hyper frame number component of COUNT-C for this radio bearer to zero;

2> start incrementing the COUNT-C values.

1> if the IE "RB information to setup" was received in a message other than HANDOVER TO UTRAN COMMAND; and

1> if the IE "Uplink RLC mode" and the IE "Downlink RLC mode" either in the IE "RLC info" or referenced by the RB identity in the IE "Same as RB" is set to "TM RLC":

2> if prior to this procedure there exists no transparent mode radio bearer for the CN domain included in the IE "CN domain identity" in the IE "RAB info" in the variable ESTABLISHED_RABS and at least one transparent mode radio bearer is included in the IE "RB information to setup":

3> if the IE "Status" in the variable CIPHERING_STATUS of the CN domain as indicated in the IE "CN domain identity" in the IE "RAB info" in the variable ESTABLISHED_RABS is set to "Not Started":

4> at the activation time as specified in the IE "Ciphering activation time for DPCH" if included in the IE "Ciphering mode info" in the command message or, if this IE is not included, as specified in the IE "COUNT-C activation time" included in the response message:

5> initialise the 20 most significant bits of the hyper frame number component of COUNT-C common for all transparent mode radio bearers of this CN domain with the START value in the variable START_VALUE_TO_TRANSMIT;

5> set the remaining LSB of the hyper frame number component of COUNT-C to zero;

5> do not increment the COUNT-C value common for all transparent mode radio bearers for this CN domain.

3> if the IE "Status" in the variable CIPHERING_STATUS of the CN domain as indicated in the IE "CN domain identity" in the IE "RAB info" in the variable ESTABLISHED_RABS is set to " Started":

4> at the activation time as specified in the IE "Activation Time" in the RADIO BEARER SETUP message:

5> initialise the 20 most significant bits of the HFN component of COUNT-C common for all transparent mode RLC radio bearer to the value of the latest transmitted START for this CN domain, while not incrementing the value of the HFN component of COUNT-C at each CFN cycle; and

5> set the remaining LSB of the HFN component of COUNT-C to zero;

5> start to perform ciphering on the radio bearer in lower layers while not incrementing the HFN.

4> at the activation time as specified in the IE "Ciphering activation time for DPCH" if included in the IE "Ciphering mode info" in the command message or, if this IE is not included, as specified in the IE "COUNT-C activation time" included in the response message:

5> initialise the 20 most significant bits of the HFN component of COUNT-C common for all transparent mode radio bearers of this CN domain with the START value in the variable START_VALUE_TO_TRANSMIT;

5> set the remaining LSB of the HFN component of COUNT-C to zero;

5> if the received message is used to perform a Timing re-initialised hard handover:

6> increment the HFN component of the COUNT-C variable by one even if the "COUNT-C activation time" is set to zero.

5> start incrementing the COUNT-C value common for all transparent mode radio bearers of this CN domain as normal, at each CFN value, i.e. the HFN component is no longer fixed in value but incremented at each CFN cycle.

2> if prior to this procedure there exists at least one transparent mode radio bearer for the CN domain included in the IE "CN domain identity" in the IE "RAB info" in the variable ESTABLISHED_RABS:

3> if the IE "Status" in the variable CIPHERING_STATUS of the CN domain as indicated in the IE "CN domain identity" in the IE "RAB info" in the variable ESTABLISHED_RABS is set to "Not Started":

4> do not increment the COUNT-C value common for all transparent mode radio bearers for this CN domain.

3> if the IE "Status" in the variable CIPHERING_STATUS of the CN domain as indicated in the IE "CN domain identity" in the IE "RAB info" in the variable ESTABLISHED_RABS is set to "Started":

4> use the COUNT-C value common for all transparent mode radio bearers of this CN domain.

1> if the IE "Status" in the variable CIPHERING_STATUS of the CN domain as indicated in the IE "CN domain identity" in the IE "RAB info" in the variable ESTABLISHED_RABS is set to "Started":

2> start to perform ciphering on the radio bearer in lower layers, using the value of the IE "RB identity" minus one as the value of BEARER in the ciphering algorithm.

NOTE: UTRAN should not use the IE "RB information to setup" to setup radio bearers with RB identity in the range 1-4.

### 8.6.4.4 RB information to be affected

If the IE "RB information to be affected" is included, the UE shall apply the following actions on the radio bearer identified with the value of the IE "RB identity". The UE shall:

1> perform the actions for the IE "RB mapping info", according to subclause 8.6.4.8, applied for the radio bearer.

### 8.6.4.4a RB information to change list

The UE shall apply the following actions:

1> if the IE "RB information to change list" is included:

2> for the radio bearers identified for which the corresponding value of the IE "RB identity" is included in the IE "RB information to change list" and the IE "RB change" is set to "Release":

3> release the radio bearer, as specified in subclause 8.6.4.6.

NOTE: This concerns an existing radio bearer. All radio bearers included in the default configuration are part of the configuration that results after completing the radio bearer establishment procedure.

2> for the radio bearers identified for which the corresponding value of the IE "RB identity" is included in the IE "RB information to change list" and the IE "RB change" is set to "Re- map":

3> of the radio bearer, that is included in the default radio bearer configuration and is identified by the IE "Re-map to default RB":

4> apply the IE "RB mapping info";

4> perform a radio bearer reconfiguration in accordance with subclause 8.6.4.5.

1> for all other radio bearers ie. all the radio bearers in case the IE "RB information to change list" is absent or the radio bearers for which the corresponding value of the IE "RB identity" is not included in the IE "RB information to change list":

2> continue the radio bearers unchanged.

1> for all transport channels on which no radio bearer is mapped:

2> release the transport channel in accordance with subclause 8.6.5.7 or 8.6.5.8

### 8.6.4.5 RB information to reconfigure

If the IE "RB information to reconfigure" is included, the UE shall apply the following actions on the radio bearer identified with the value of the IE "RB identity". The UE shall:

1> perform the actions for the IE "PDCP info", if present, according to subclause 8.6.4.10, applied for the radio bearer;

1> if the IE "RLC info" is present:

2> perform the actions for the IE "RLC info", according to subclause 8.6.4.9, applied for the radio bearer.

1> else:

2> continue using the current RLC configuration for the radio bearer.

1> perform the actions for the IE "RB mapping info", according to subclause 8.6.4.8, applied for the radio bearer;

1> if the IE "Downlink RLC mode" in the IE "RLC info" is set to "TM RLC":

2> configure delivery of erroneous SDUs in lower layers according to indication from upper layer [5].

1> if the IE "PDCP SN info" is included:

2> perform the actions as specified in subclause 8.6.4.11 applied for the radio bearer.

1> if the IE "RB stop/continue" is included; and

2> if the "RB identity" has a value greater than 2; and

3> if the value of the IE "RB stop/continue" is "stop":

4> configure the RLC entity for the radio bearer to stop;

4> set the IE "RB started" in the variable ESTABLISHED_RABS to "stopped" for that radio bearer.

3> if the value of the IE "RB stop/continue" is "continue":

4> configure the RLC entity for the radio bearer to continue;

4> set the IE "RB started" in the variable ESTABLISHED_RABS to "started" for that radio bearer.

2> if the IE "RB identity" is set to a value less than or equal to 2:

3> set the variable INVALID_CONFIGURATION to TRUE.

### 8.6.4.6 RB information to release

If the IE "RB information to release" is included, the UE shall apply the following actions on the radio bearer identified with the value of the IE "RB identity". The UE shall:

1> if the IE "RB identity" is set to a value less than 4:

2> set the variable INVALID_CONFIGURATION to TRUE.

1> if the IE "RB identity" refers to a signalling radio bearer:

2> release the RLC entity for the signalling radio bearer;

2> delete the information about the signalling radio bearer from the variable ESTABLISHED_RABS.

1> if the IE "RB identity" refers to a radio bearer:

2> release the PDCP and RLC entities for that radio bearer;

2> indicate release of the RAB subflow associated with the radio bearer to upper layers;

2> delete the information about the radio bearer from the variable ESTABLISHED_RABS;

2> when all radio bearers belonging to the same radio access bearer have been released:

3> indicate release of the radio access bearer to upper layers providing the "CN domain identity" together with the "RAB identity" stored in the variable ESTABLISHED_RABS;

3> delete all information about the radio access bearer from the variable ESTABLISHED_RABS.

The UE shall:

1> determine the value for the HS_DSCH_RECEPTION variable and take the corresponding actions as described in subclause 8.5.25;

1> determine the value for the E_DCH_TRANSMISSION variable and take the corresponding actions as described in subclause 8.5.28.

### 8.6.4.7 RB with PDCP information

If the IE "RB with PDCP information" is included, the UE shall apply the following actions on the radio bearer identified with the value of the IE "RB identity". The UE shall:

1> for the IE "PDCP SN info":

2> perform the actions as specified in subclause 8.6.4.11.

### 8.6.4.8 RB mapping info

If the IE "RB mapping info" is included, the UE shall:

1> for each multiplexing option of the RB:

2> if a multiplexing option that maps a logical channel corresponding to a TM-RLC entity onto RACH, FACH, USCH, DSCH (only for TDD), HS-DSCH or E-DCH is included:

3> set the variable INVALID_CONFIGURATION to TRUE.

2> if the multiplexing option realises the radio bearer on the uplink (resp. on the downlink) using two logical channels with different values of the IE "Uplink transport channel type" (resp. of the IE "Downlink transport channel type"):

3> set the variable INVALID_CONFIGURATION to TRUE.

2> if that RB is using TM and the IE "Segmentation indication" is set to TRUE and, based on the multiplexing configuration resulting from this message, the logical channel corresponding to it is mapped onto the same transport channel as another logical channel:

3> set the variable INVALID_CONFIGURATION to TRUE.

2> if the transport channel considered in that multiplexing option is different from RACH and if that RB is using AM and the set of RLC sizes applicable to the uplink logical channel transferring data PDUs has more than one element not equal to zero:

3> set the variable INVALID_CONFIGURATION to TRUE.

2> if that RB is using UM or TM and the multiplexing option realises it using two logical channels:

3> set the variable INVALID_CONFIGURATION to TRUE.

2> for each logical channel in that multiplexing option:

3> if the value of the IE "RLC size list" is set to "Explicit list":

4> if a "Transport format set" for the transport channel this logical channel is mapped on in this multiplexing option is included in the same message, and the value (index) of any IE "RLC size index" in the IE "Explicit list" does not correspond to an "RLC size" in the IE transport format set of that transport channel given in the message; or

4> if the transport channel this logical channel is mapped on in this multiplexing option is different from RACH, and if a "Transport format set" for that transport channel is not included in the same message, and the value (index) of any IE "RLC size index" in the IE "Explicit list" does not correspond to an "RLC size" in the stored transport format set of that transport channel; or

4> if a "Transport format set" for the transport channel this logical channel is mapped on in this multiplexing option is included in the same message, and the value of any IE "Logical channel list" in the transport format set is not set to "Configured"; or

4> if a "Transport format set" for the transport channel this logical channel is mapped on in this multiplexing option is not included in the same message, and the value of any IE "Logical channel list" in the stored transport format set of that transport channel is not set to "Configured":

5> set the variable INVALID_CONFIGURATION to TRUE.

3> if the value of the IE "RLC size list" is set to "All":

4> if the transport channel this logical channel is mapped on is RACH; or

4> if a "Transport format set" for the transport channel this logical channel is mapped on in this multiplexing option is included in the same message, and the value of any IE "Logical channel list" in the transport format set is not set to "Configured"; or

4> if a "Transport format set" for the transport channel this logical channel is mapped on in this multiplexing option is not included in the same message, and the value of any IE "Logical channel list" in the stored transport format set of that transport channel is not set to "Configured":

5> set the variable INVALID_CONFIGURATION to TRUE.

3> if the value of the IE "RLC size list" is set to "Configured":

4> if the transport channel this logical channel is mapped on is RACH; or

4> if a "Transport format set" for the transport channel this logical channel is mapped on in this multiplexing option is included in the same message, and for none of the RLC sizes defined for that transport channel in the "Transport format set", the "Logical Channel List" is set to "All" or given as an "Explicit List" which contains this logical channel; or

4> if a "Transport format set" for the transport channel this logical channel is mapped on in this multiplexing option is not included in the same message, and for none of the RLC sizes defined in the transport format set stored for that transport channel, the "Logical Channel List" is set to "All" or given as an "Explicit List" which contains this logical channel:

5> set the variable INVALID_CONFIGURATION to TRUE.

1> if, as a result of the message this IE is included in, several radio bearers can be mapped onto the same transport channel, and the IE "Logical Channel Identity" was not included in the RB mapping info of any of those radio

bearers for a multiplexing option on that transport channel or the same "Logical Channel Identity" was used more than once in the RB mapping info of those radio bearers for the multiplexing options on that transport channel:

2> set the variable INVALID_CONFIGURATION to TRUE.

1> if the "RB mapping info" is considered as valid according to the rules above:

2> delete all previously stored multiplexing options for that radio bearer;

2> store each new multiplexing option for that radio bearer;

2> perform the actions as specified in subclause 8.5.21;

2> determine the value for the HS_DSCH_RECEPTION variable and take the corresponding actions as described in subclause 8.5.25;

2> determine the value for the E_DCH_TRANSMISSION variable and take the corresponding actions as described in subclause 8.5.28.

1> if the IE "Uplink transport channel type" is set to the value "RACH":

2> in FDD:

3> refer the IE "RLC size index" to the RACH Transport Format Set of the first PRACH received in the IE "PRACH system information list" received in System Information Block 5, System Information Block 5bis or System Information Block 6.

2> in TDD:

3> use the first Transport Format of the PRACH of the IE "PRACH system information list" at the position equal to the value in the IE "RLC size index".

In case IE "RLC info" includes IE "Downlink RLC mode" ("DL RLC logical channel info" is mandatory present) but IE "Number of downlink RLC logical channels" is absent in the corresponding IE "RB mapping info", the parameter values are exactly the same as for the corresponding UL logical channels. In case two multiplexing options are specified for the UL, the first options shall be used as default for the DL. As regards the IE "Channel type", the following rule should be applied to derive the DL channel type from the UL channel included in the IE:

| Channel used in UL | DL channel type implied by "same as" |
|---|---|
| DCH | DCH |
| RACH | FACH |
| USCH | DSCH |

If ciphering is applied, UTRAN should not map Transparent Mode RBs of different CN domains on the same transport channel and it should not map transparent mode SRBs and RBs onto the same transport channel. In such cases the UE behaviour is not specified.

For FDD the list of multiplexing options configured in the UE for each RB and SRB should comply with the following rules otherwise the UE behaviour is not specified:

- at most one multiplexing option can contain the combination "FACH" for the DL and "RACH" for the UL;
- at most one multiplexing option can contain the combination "DCH" or "DCH + HS-DSCH" for the DL together with "DCH" for he UL;
- at most one multiplexing option can contain the combination "HS-DSCH" or "DCH + HS-DSCH" for the DL together with "DCH" for the UL;
- at most one multiplexing option can contain the combination "DCH" or "DCH + HS-DSCH" for the DL together with "E-DCH" for the UL; and
- at most one multiplexing option can contain the combination "HS-DSCH" or "DCH + HS-DSCH" for the DL together with "E-DCH" for the UL.

### 8.6.4.9 RLC Info

Upon reception of the IE "RLC Info", the UE shall:

1> if both the IE "Uplink RLC mode" and the IE "Downlink RLC mode" are present in the IE "RLC info":

2> configure the transmitting and receiving RLC entities in the UE for that radio bearer accordingly.

1> else, if the IE "Uplink RLC mode" is present and the IE "Downlink RLC mode" is not present in the IE "RLC info":

2> configure the transmitting RLC entity in the UE for that radio bearer accordingly and keep the configuration existing before the reception of the message for the receiving RLC entity.

1> else, if the IE "Uplink RLC mode" is not present and the IE "Downlink RLC mode" is present in the IE "RLC info":

2> configure the receiving RLC entity in the UE for that radio bearer accordingly and keep the configuration existing before the reception of the message for the transmitting RLC entity.

1> if the IE "Polling info" is present in the IE "RLC info":

2> for each present IE in the IE "Polling info":

3> configure RLC to use the corresponding function according to the value of the IE.

2> for each absent IE in the IE "Polling info":

3> configure RLC to not use the corresponding function.

1> if the IE "Polling info" is absent:

2> configure RLC to not use the polling functionality.

1> if the IE "Downlink RLC STATUS info" is present in the IE "RLC info" (this IE is present for AM RLC):

2> for each present IE in the IE "Downlink RLC STATUS info":

3> configure RLC to use the corresponding function according to value of the IE.

2> for each absent IE in the IE "Downlink RLC STATUS info":

3> configure RLC to not use the corresponding function.

1> if the IE "Transmission RLC discard" is present:

2> configure the discard procedure in RLC according to the IE "Transmission RLC discard"

1> if the IE "Transmission RLC discard" is absent (only possible for TM RLC and UM RLC):

2> do not configure SDU discard in RLC.

1> if the IE "Uplink RLC mode" is present and is set to "UM RLC":

2> if the IE "Alternative E-bit interpretation" is present:

3> configure the uplink RLC entity to use the alternative E-bit interpretation and corresponding LI's.

2> if the IE "Alternative E-bit interpretation" is not present:

3> configure the uplink RLC entity to use the normal E-bit interpretation and corresponding LI's.

1> if the IE "Downlink RLC mode" is present and is set to "AM RLC":

2> if IE "DL RLC PDU size" is not present:

3> determining the downlink RLC PDU size will be handled at RLC level as described in [16], without any configuration from RRC.

NOTE: The case where this mandatory IE is not present is meant to handle the interaction with a network using an earlier release of the specification.

2> else, if the IE "DL RLC PDU size" is present and no downlink RLC PDU size is currently set in the RLC entity:

3> configure the corresponding RLC entity with the downlink RLC PDU size.

2> else, if the IE "DL RLC PDU size" is present and its value is different from the one currently set in the RLC entity:

NOTE: The downlink RLC PDU size set in the RLC entity can either be explicitly configured or, in case no explicit configuration is provided, derived by the first received RLC PDU [16].

3> if the IE "one sided RLC re-establishment" is set to TRUE:

4> re-establish the receiving side of the corresponding RLC entity.

3> else:

4> re-establish the corresponding RLC entity.

3> configure the corresponding RLC entity with the new downlink RLC PDU size;

3> if the UE supports the lossless DL RLC PDU size change and PDCP was configured for that radio bearer with the IE "Support for lossless SRNS relocation or for lossless DL RLC PDU size change" set to TRUE:

4> include the current DL PDCP receive sequence number and the radio bearer identity for that radio bearer in the variable PDCP_SN_INFO.

3> if the IE "Status" in the variable CIPHERING_STATUS of the CN domain as indicated in the IE "CN domain identity" in the IE "RAB info" for this radio bearer is set to "Started":

4> if the RLC re-establishment is caused by a CELL UPDATE CONFIRM:

5> if only the receiving side of the RLC entity was re-established:

6> set the HFN values for the corresponding RLC entity in downlink equal to the value of the IE "START" included in the latest transmitted CELL UPDATE message for this CN domain.

5> if the whole RLC entity was re-established:

6> set the HFN values for the corresponding RLC entity in uplink and downlink equal to the value of the IE "START" included in the latest transmitted CELL UPDATE message for this CN domain.

4> if the RLC re-establishment is caused by a reconfiguration message:

5> if only the receiving side of the RLC entity was re-established:

6> set the HFN values for the corresponding RLC entity in downlink equal to the value of the IE "START" that will be included in the reconfiguration complete message for this CN domain.

5> if the whole RLC entity was re-established:

6> set the HFN values for the corresponding RLC entity in uplink and downlink equal to the value of the IE "START" that will be included in the reconfiguration complete message for this CN domain.

1> if the IE "Downlink RLC mode" is present and is set to "UM RLC":

2> if the IE "DL UM RLC LI size" is not present:

3> configure the corresponding RLC entity with an LI size of 7 bits;

NOTE: The case where this mandatory IE is not present is meant to handle the interaction with a network using an earlier release of the specification.

2> else:

3> configure the corresponding RLC entity with the LI size indicated in the IE "DL UM RLC LI size".

2> if the IE "DL Reception Window Size" is present:

3> if the variable UE_CAPABILITY_TRANSFERRED indicates "Support of HS-PDSCH" as "Supported":

4> configure the corresponding RLC entity to support out-of-sequence reception with the receive window size indicated in the IE.

3> if the variable UE_CAPABILITY_TRANSFERRED indicates "Support of HS-PDSCH" as "Unsupported":

4> the UE behaviour is not specified.

2> else:

3> configure the corresponding RLC entity without out-of-sequence reception.

NOTE: If the "Uplink RLC mode" or the "Downlink RLC mode" of an existing radio bearer is modified by a reconfiguration message, the UE behaviour is unspecified.

2> if the IE "Alternative E-bit interpretation" is present:

3> configure the downlink RLC entity to use the alternative E-bit interpretation and corresponding LI's.

2> if the IE "Alternative E-bit interpretation" is not present:

3> configure the downlink RLC entity to use the normal E-bit interpretation and corresponding LI's.

### 8.6.4.10 PDCP Info

For RFC 3095:

1> the chosen MAX_CID shall not be greater than the value "Maximum number of ROHC context sessions" as indicated in the IE "PDCP Capability";

1> the configuration for the PACKET_SIZES_ALLOWED is FFS.

If IE "PDCP info" is included, the UE shall:

1> if the radio bearer is connected to a CS domain radio access bearer:

2> set the variable INVALID_CONFIGURATION to TRUE.

1> if the IE "PDCP PDU header" is set to the value "absent":

2> if the IE "Support for lossless SRNS relocation or for lossless DL RLC PDU size change" is true:

3> set the variable INVALID_CONFIGURATION to TRUE.

1> if the IE "PDCP PDU header" is set to the value "present":

2> include PDCP headers in both uplink and downlink PDCP PDUs;

2> if the IE "Support for lossless SRNS relocation or for lossless DL RLC PDU size change" is false:

3> if the IE "Header compression information" is absent:

4> set the variable INVALID_CONFIGURATION to TRUE.

1> if the IE "Header compression information" is absent:

2> not use Header compression after the successful completion of this procedure;

2> remove any stored configuration for the IE "Header compression information".

1> if the IE "Header compression information" is present:

2> if the IE "Algorithm Type" is set to "RFC 2507":

3> if the UE capability "Maximum header compression context space", as specified in [35], is exceeded with this configuration:

4> set the variable INVALID_CONFIGURATION to TRUE.

1> configure the PDCP entity for that radio bearer accordingly;

1> configure the RLC entity for that radio bearer according to the value of the IE "Support for lossless SRNS relocation or for lossless DL RLC PDU size change";

1> set the PROFILES parameter, used by inband ROHC profile negotiation, for this PDCP entity for both UL and DL equal to the list of ROHC profiles received in the IE "PDCP info". A UE complying to this version of the protocol shall support ROHC profiles 0x0000 (ROHC uncompressed), 0x0001 (ROHC RTP), 0x0002 (ROHC UDP) and 0x0003 (ROHC ESP) (see [52]).

1> if the IE "PDCP ROHC target mode" is received:

2> set the variable " PDCP_ROHC_TARGET_MODE " to the received value.

1> if the IE "PDCP ROHC target mode" is not received in either of the CELL UPDATE CONFIRM, the RADIO BEARER RECONFIGURATION or the RADIO BEARER SETUP message:

2> delete the variable "PDCD_ROHC_TARGET_MODE" and act according to actions specified in [36].

### 8.6.4.11 PDCP SN Info

If the IE "PDCP SN Info" is included, the UE shall:

1> transfer the sequence number to the PDCP entity for the radio bearer;

1> configure the RLC entity for the radio bearer to stop;

1> include the current PDCP receive sequence number and the radio bearer identity for the radio bearer in the variable PDCP_SN_INFO.

### 8.6.4.12 NAS Synchronisation Indicator

If the IE "NAS Synchronisation Indicator" is present in a message, the UE shall:

1> forward the content to upper layers along with the IE "CN domain identity" of the associated RAB stored in the variable ESTABLISHED_RABS at the CFN indicated in the IE "Activation time" in order to synchronise actions in NAS and AS.

### 8.6.4.13 PDCP context relocation info

If the IE "PDCP context relocation info" is included, the UE shall, for each radio bearer included in this IE:

1> If the IE "Downlink RFC 3095 context relocation indication" is set to TRUE:

2> perform the actions as specified in [36] for all RFC 3095 contexts associated with that radio bearer in the downlink.

1> If the IE "Uplink RFC 3095 context relocation indication" is set to TRUE:

2> perform the actions as specified in [36] for all RFC 3095 contexts associated with that radio bearer in the uplink.

#### 8.6.4.14 RLC Info MBMS

Upon reception of the IE "RLC Info MBMS", the UE shall:

1> configure the receiving RLC entity in the UE for that radio bearer accordingly;

1> configure the corresponding RLC entity with the LI size indicated in the IE "DL UM RLC LI size".

1> if the IE "DL Duplication Avoidance and Reordering info" is present:

2> configure the corresponding RLC entity to use the UM duplication avoidance and reordering functionality.

1> if the IE "DL Out of sequence delivery info" is present:

2> configure the corresponding RLC entity to use the UM out of sequence delivery functionality.

### 8.6.5 Transport channel information elements

#### 8.6.5.1 Transport Format Set

If the IE "Transport format set" is included, the UE shall:

1> if the transport format set is a RACH TFS received in System Information Block type 5 or 6, and CHOICE "Logical Channel List" has a value different from "Configured":

2> ignore that System Information Block.

NOTE: The TFS added by the IE "Additional Dynamic Transport Format Information for CCCH" has no CHOICE "Logical Channel List" and can thus never be considered as different from "Configured".

1> if the transport format set for a downlink transport channel is received in a System Information Block, and CHOICE "Logical Channel List" has a value different from 'ALL':

2> ignore that System Information Block.

1> if the transport format set for a downlink transport channel is received in a message on a DCCH, and CHOICE "Logical Channel List" has a value different from 'ALL':

2> keep the transport format set if this exists for that transport channel;

2> set the variable INVALID_CONFIGURATION to TRUE.

1> if the value of any IE "RB identity" (and "Logical Channel" for RBs using two UL logical channels) in the IE "Logical channel list" does not correspond to a logical channel indicated to be mapped onto this transport channel in any RB multiplexing option (either included in the same message or previously stored and not changed by this message); or

1> if the "Logical Channel List" for any of the RLC sizes defined for that transport channel is set to "Configured" while it is set to "All" or given as an "Explicit List" for any other RLC size; or

1> if the "Logical Channel List" for any of the RLC sizes defined for that transport channel is set to "All" and for any logical channel mapped to this transport channel, the value of the "RLC size list" (either provided in the IE "RB mapping info" if included in the same message, or stored) is not set to "Configured"; or

1> if the "Logical Channel List" for any of the RLC sizes defined for that transport channel is given as an "Explicit List" that contains a logical channel for which the value of the "RLC size list" (either provided in the IE "RB mapping info" if included in the same message, or stored) is not set to "Configured"; or

1> if the "Logical Channel List" for all the RLC sizes defined for that transport channel are given as "Explicit List" and if one of the logical channels mapped onto this transport channel is not included in any of those lists; or

1> if the "Logical Channel List" for the RLC sizes defined for that transport channel is set to "Configured" and for any logical channel mapped onto that transport channel, the value of the "RLC size list" (either provided in the IE "RB mapping info" if included in the same message, or stored) is also set to "Configured"; or

1> if the IE "Transport Format Set" was not received within the IE "PRACH system information list" and if the "Logical Channel List" for the RLC sizes defined for that transport channel is set to "Configured" and for any logical channel mapped onto that transport channel, the "RLC size list" (either provided in the IE "RB mapping info" if included in the same message, or stored ) is given as an "Explicit List" that includes an "RLC size index" that does not correspond to any RLC size in this "Transport Format Set"; or

1> if the IE "Transport Format Set" was not received within the IE "PRACH system information list", and if that RB is using AM and the set of RLC sizes applicable to the logical channel transferring data PDUs has more than one element not equal to zero:

2> keep the transport format set if this exists for that transport channel;

2> set the variable INVALID_CONFIGURATION to TRUE.

1> if the total number of configured transport formats for the transport channel exceeds maxTF:

2> keep the transport format set if this exists for that transport channel;

2> set the variable INVALID_CONFIGURATION to TRUE.

1> if the IE "Transport format set" is considered as valid according to the rules above:

2> remove a previously stored transport format set if this exists for that transport channel;

2> store the transport format set for that transport channel;

2> consider the first instance of the parameter *Number of TBs and TTI List* within the *Dynamic transport format information* to correspond to transport format 0 for this transport channel, the second to transport format 1 and so on;

2> if the IE "Transport format Set" has the choice "Transport channel type" set to "Dedicated transport channel":

3> calculate the transport block size for all transport formats in the TFS using the following

TB size = RLC size + MAC header size if "RLC size" <> 0,
TB size = 0 if "RLC size" = 0,

where:

- MAC header size is calculated according to [15] if MAC multiplexing is used. Otherwise it is 0 bits;
- 'RLC size' reflects the RLC PDU size.

2> if the IE "Transport format Set" has the choice "Transport channel type" set to "Common transport channel":

3> calculate the transport block size for all transport formats in the TFS using the following:

TB size = RLC size.

where:

- 'RLC size' reflects the RLC PDU size.

2> if the IE "Number of Transport blocks" <> 0 and IE "RLC size" = 0, no RLC PDU data exists but only parity bits exist for that transport format;

2> if the IE "Number of Transport blocks" = 0, neither RLC PDU neither data nor parity bits exist for that transport format;

2> perform the actions as specified in subclause 8.5.21.

For configuration restrictions on Blind Transport Format Detection, see [27].

### 8.6.5.2 Transport format combination set

If the IE "Transport format combination set" is included for the uplink, the UE shall for that direction:

1> store the new transport format combination set, or (if this exists) modify a previously stored transport format combination set according to IEs included in IE "Transport format combination set";

1> start to respect those transport format combinations;

1> if IE "Transport format combination subset" is received in this message:

2> perform the actions as specified in subclause 8.6.5.3.

1> if IE "Transport format combination subset" is not received in this message:

2> clear the IE "Duration" in the variable TFC_SUBSET;

2> set both the IE "Current TFC subset" and the IE "Default TFC subset" in the variable TFC_SUBSET to the value indicating "full transport format combination set".

If the IE "Transport format combination set" is included for the downlink, the UE shall for that direction:

1> store the new transport format combination set, or (if this exists) modify a previously stored transport format combination set according to IEs included in IE "Transport format combination set";

1> start to respect those transport format combinations.

If the IE "Transport format combination set" is not included for the uplink and if there is no addition, removal or reconfiguration of transport channels, the UE shall for that direction:

1> use a previously stored transport format combination set if this exists.

If the IE "Transport format combination set" is not included for the downlink and if there is no addition, removal or reconfiguration of transport channels, the UE shall for that direction:

1> use a previously stored transport format combination set if this exists.

If the IE "Transport format combination set" is not included for either the uplink or the downlink and for that direction after the reconfiguration there is one or more DCH; and

1> if no transport format combination set is stored in the UE; or

1> if transport channels are added or removed in the message; or

1> if any transport channel is reconfigured in the message such that the size of the transport format set is changed:

the UE shall:

1> set the variable INVALID_CONFIGURATION to TRUE.

In the uplink TFCS the minimum set of TFCs is the set of TFCs that is needed for the TFC selection algorithm defined in [15] to give a predictable result. Any configured TFCS or TFC subset shall satisfy the requirements as specified by the minimum set. In the definition of the minimum set of TFCs below, only logical channels for which the TFCS or the TFC subset include at least one TFC with non-empty TF for the corresponding transport channel should be considered.

The minimum set of TFCs consists of the following:

1> for each UM logical channel:

2> a TFC with one transport block for this transport channel and empty TFs (see [34]) for all the others. If more than one TFC fulfils these criteria, only the TFC with the lowest number of bits should be included in the minimum set of TFCs.

1> for each AM logical channel:

2> a TFC with a non-empty TF for the corresponding transport channel and empty TFs for all other transport channels, where the non-empty TF includes one transport block with "Configured RLC Size" equal to the RLC PDU size.

1> for each set of "synchronous" TM logical channels (see the definition below) and for each set of SDU sizes associated with it:

2> a TFC with TFs corresponding to any combination of SDU sizes that can be received in a TTI from higher layers on the corresponding transport channels and empty TFs for all other transport channels.

NOTE: In case an adaptive rate codec is used and the TFCS has been restricted by the IE "TFC subset", the minimum set consists of the set of TFCs with TFs corresponding to any combination of SDU sizes that can be received in a TTI respecting the restricted TFCS.

1> for each TM logical channel that is not part of a set of "synchronous" TM logical channels (see the definition below):

2> a TFC with non-empty TFs for the corresponding transport channel, and empty TFs for all other transport channels, where

3> for non-segmented mode TM-RLC logical channels the non-empty TFs include, for the smallest SDU size that can be received in a single TTI from higher layer:

4> a TF with non-zero number of transport blocks with "Configured RLC Size" equal to the corresponding SDU size. If more than one TFC fulfils these criteria, only the TFC with the lowest number of bits in the TFC is included in the minimum set of TFCs.

3> for segmented mode TM-RLC, the non-empty TFs include any TF such that the number of transport blocks multiplied by the "Configured RLC Size" is equal to the smallest SDU size that can be received in a single TTI from higher layer.

1> an "empty" TFC (see [34]).

Furthermore, the UTRAN should ensure that the uplink TFCS and any configured TFC Subset satisfies the following rules:

1> for each TTI length with which at least one transport channel is configured:

2> for each combination of TFs for the transport channels configured with this TTI length included in the TFCS:

3> a TFC with these TFs for the transport channels configured with this TTI length and empty TFs on all transport channels configured with shorter TTI lengths is also included in the TFCS.

For TDD, the TFCS of a CCTrCH should include those of the above combinations, which include a TF with one transport block for a transport channel used in that CCTrCH, and the "empty" TFC should be included in the TFCS of every CCTrCH.

Synchronous TM logical channels are logical channels on which higher layer traffic is generated in a perfectly correlated fashion (e.g. AMR RAB).

NOTE: The "Configured RLC Size" is defined as the transport block size minus the MAC header size.

### 8.6.5.3 Transport format combination subset

When configuring a TFC Subset, the UTRAN should follow the guidelines defined in subclause 8.6.5.2.

If the IE "Transport format combination subset"("TFC subset") is included, the UE shall:

1> if the IE "Minimum allowed Transport format combination index" is included; and

2> if the value of the IE "Minimum allowed Transport format combination index" is greater than the highest TFCI value in the current transport format combination set:

3> consider the TFC subset to be incompatible with the current transport format combination set.

1> if the IE "Allowed transport format combination list" is included; and

2> if the value of any of the IEs "Allowed transport format combination" included in the IE "Allowed transport format combination list" does not match a TFCI value in the current transport format combination set:

3> consider the TFC subset to be incompatible with the current transport format combination set.

1> if the IE "Non-allowed transport format combination list" is included; and

2> if the value of any of the IEs "Non-allowed transport format combination" included in the IE "Non-allowed transport format combination list" does not match a TFCI value in the current transport format combination set:

3> consider the TFC subset to be incompatible with the current transport format combination set.

1> if the IE "Restricted TrCH information" is included:

2> if the value of any of the IEs "Uplink transport channel type" and "Restricted UL TrCH identity" included in the IE "Restricted TrCH information" do not correspond to any of the transport channels for which the current transport format combination set is valid:

3> consider the TFC subset to be incompatible with the current transport format combination set.

2> if the IE "Allowed TFIs" is included; and

3> if the value of each of the IEs "Allowed TFI" included in the IE "Allowed TFIs" corresponds to a transport format for that transport channel within the current transport format combination set:

4> allow all transport format combinations that include these transport formats for the transport channel;

4> restrict all other transport format combinations.

3> else:

4> consider the TFC subset to be incompatible with the current transport format combination set.

2> if the IE "Allowed TFIs" is not included:

3> restrict all transport format combinations where the transport channel has a transport format of non-zero rate.

1> if the UE considers the TFC subset to be incompatible with the current Transport format combination set according to the above:

2> keep any previous restriction of the transport format combination set;

2> set the variable INVALID_CONFIGURATION to TRUE.

1> if the UE does not consider the TFC subset to be incompatible with the current Transport format combination set according to the above:

2> if the IE "Transport format combination subset" is received in a message other than a TRANSPORT FORMAT COMBINATION CONTROL message:

3> set both the IE "Current TFC subset" and the IE "Default TFC subset" in the variable TFC_SUBSET to the IE "Transport format combination subset" (in case of TDD for the uplink CCTrCH specified by the IE "TFCS Id");

3> clear the IE "Duration" in the variable TFC_SUBSET;

3> apply the transport format combination subset in the IE "Current TFC subset" stored in the variable TFC_SUBSET.

1> if the IE "transport format combination subset" indicates the "full transport format combination set":

2> set both the IE "Current TFC subset" and the IE "Default TFC subset" in the variable TFC_SUBSET to the value indicating "full transport format combination set";

2> clear the IE "Duration" in the variable TFC_SUBSET;

2> if the IE "Transport format combination subset" is received in a TRANSPORT FORMAT COMBINATION CONTROL message, then at the CFN indicated by the IE "Activation time for TFC subset" any restriction on transport format combination set is released and the UE may use the full transport format combination set;

2> else:

3> any restriction on transport format combination set is released and the UE may use the full transport format combination set.

### 8.6.5.4 DCH quality target

If the IE "DCH quality target" is included, the UE shall:

1> set, at physical channel establishment, the initial downlink target SIR value based on the received IE "DCH quality target" for the transport channel with respect to all transport formats;

1> adjust the target SIR for the downlink power control to meet the quality target received in the IE "DCH quality target" for the transport channel. The UE shall not compensate for the fact that the required SIR to achieve a target BLER for a particular transport format may be different from the required SIR to achieve the target BLER for another transport format..

NOTE 1: Adjusting the target SIR is possible to do continuously by the UE if a CRC exists in all transport formats in the downlink TFS for a DCH. If a CRC does not exist in all transport formats, the UE can only adjust the target SIR when receiving transport formats containing a CRC and the UE has knowledge about the transport format according to [27].

NOTE 2: If the UTRAN configures a UE to use blind transport format detection and configures a transport channel such that single transport format detection [27] must be used to detect the TF, then it is not possible for the UE to maintain a quality target for that transport channel.

### 8.6.5.5 Added or Reconfigured UL TrCH information

If the IE "Added or Reconfigured UL TrCH information" is included then the UE shall:

1> for the transport channel identified by the IE "UL Transport Channel Identity" and IE "Uplink transport channel type":

2> perform the actions for the IE "Transport Format Set" as specified in subclause 8.6.5.1.

NOTE: The UE stores the UL transport channel configuration until it is explicitly deleted by a message containing the IE "Deleted UL TrCH information" or the UE leaves RRC Connected mode.

If the IE "Added or Reconfigured UL TrCH information" is included and E-DCH is included and there is more than one MAC-d flow carried on E-DCH then the UE shall:

1> apply the values IE "E-DCH Transmission Time Interval" and the field HARQ info to all E-DCH MAC-d flows.

NOTE: In case of multiple E-DCH MAC-d flows, IE "Added or Reconfigured UL TrCH information" is only included once. If the IE "Added or Reconfigured UL TrCH information" is included more than once with the IE "Uplink transport channel type" set to 'E-DCH', the UE behaviour is unspecified.

1> if the choice "UL parameters" is set to 'EDCH':

2> if the IE "HARQ Info" is included:

3> perform the actions specified in subclause 8.6.5.17.

2> if the IE "Added or Reconfigured E-DCH MAC-d Flow list " is included:

3> for each MAC-d flow identified by the IE "Mac-d flow identity":

4> perform the actions as specified in subclause 8.6.5.18.

2> determine the value for the E_DCH_TRANSMISSION variable and take the corresponding actions as described in subclause 8.5.28.

### 8.6.5.5a Added or reconfigured MAC-d flow

If the IE "Added or reconfigured MAC-d flow" is included, the UE shall:

1> if a MAC-hs queue (identified by the IE "MAC-hs queue Id") is included in both the IE "MAC-hs queue to add or reconfigure list" and the IE "MAC-hs queue to delete list":

2> set the variable INVALID_CONFIGURATION to TRUE.

1> for each MAC-hs queue included in the IE "MAC-hs queue to add or reconfigure" list:

2> if the UE has previously stored a mapping between this MAC-hs queue and a MAC-d flow:

3> delete the old mapping.

2> map the MAC-d flow indicated in the current message to this MAC-hs queue;

2> set the release timer for each of the MAC-hs queues in the MAC-hs entity to the value in the corresponding IE "T1";

2> set the MAC-hs receiver window size for each of the MAC-hs queues in the MAC-hs entity to the value in the corresponding IE "MAC-hs window size"; and

2> configure MAC-hs with the mapping between MAC-d PDU sizes index and allowed MAC-d PDU sizes as follows:

3> if a MAC-d PDU size has been stored for a MAC-d PDU size index for the corresponding MAC-hs queue and no mapping is provided in the current message for this MAC-d PDU index:

4> continue to use this mapping.

3> if a MAC-d PDU size has been stored for a MAC-d PDU size index for the corresponding MAC-hs queue and a mapping is provided in the current message for this MAC-d PDU index:

4> configure the MAC-hs entity with the mapping indicated in the current message.

1> for each MAC-hs queue included in the IE "MAC-hs queue to delete" list:

2> delete any information about the MAC-hs queue identified by the IE "MAC-hs queue Id".

1> if the IE "Added or reconfigured MAC-d flow" is considered valid according to the rules above:

2> perform the actions as specified in subclause 8.5.21.

### 8.6.5.6 Added or Reconfigured DL TrCH information

If the IE "Added or Reconfigured DL TrCH information" is included then for the transport channel identified by the IE "DL Transport Channel Identity" the UE shall:

1> if the choice "DL parameters" is set to 'explicit':

2> perform the actions for the IE "Transport Format Set" as specified in subclause 8.6.5.1.

1> if the choice "DL parameters" is set to 'same as uplink':

2> if the IE "UL Transport Channel Identity" indicates an existing or a new UL Transport Channel:

3> store as transport format for this transport channel the transport format associated with the transport channel identified by the IE "UL Transport Channel Identity".

2> else:

3> set the variable INVALID_CONFIGURATION to TRUE.

1> if the choice "DL parameters" is set to 'HSDSCH':

2> if the IE "HARQ Info" is included:

3> perform the actions specified in subclause 8.6.5.6b.

2> if the IE "Added or Reconfigured MAC-d Flow" is included:

3> perform the actions as specified in subclause 8.6.5.5a.

2> determine the value for the HS_DSCH_RECEPTION variable and take the corresponding actions as described in subclause 8.5.25.

1> if the IE "DCH quality target" is included:

2> perform the actions specified in subclause 8.6.5.4.

NOTE: The UE stores the DL transport channel configuration until it is explicitly deleted by a message containing the IE "Deleted DL TrCH information" or the UE leaves RRC connected mode.

### 8.6.5.6a Void

### 8.6.5.6b HARQ Info

If the IE "HARQ Info" is included, the UE shall:

1> store the received configuration;

1> determine the value for the HS_DSCH_RECEPTION variable and take the corresponding actions as described in subclause 8.5.25.

When the variable HS_DSCH_RECEPTION is set to TRUE the UE shall:

1> configure the MAC-hs entity with the number of HARQ processes indicated in IE "Number of Processes";

1> assign to each of these HARQ processes IDs going from 0 to "Number of Processes" – 1;

1> if the IE "Memory Partitioning" is set to 'Implicit':

2> partition the soft memory buffer in the MAC-hs entity equally among the processes configured above. In the event that the division of the soft memory buffer results in a non-Integer value the partition memory size is rounded down to the nearerst Integer value.

1> if the IE "Memory Partitioning" is set to 'Explicit':

2> if the UE capability "Total number of soft channel bits in HS-DSCH", as specified in [35], is exceeded with this configuration:

3> set the variable INVALID_CONFIGURATION to TRUE.

2> else:

3> partition the soft memory buffer in the MAC-hs entity according to the IE "Process memory size" assuming that the order in the list follows the order in the HARQ process IDs.

### 8.6.5.7 Deleted UL TrCH information

If the IE "Deleted UL TrCH information" is included the UE shall:

1> if an Uplink transport channel is requested to be deleted:

2> delete any information about the transport channel identified by the IE "UL TrCH identity" and the IE "Uplink transport channel type".

1> if an E-DCH MAC-d flow is requested to be deleted:

2> delete any information about the E-DCH MAC-d flow identified by the IE "E-DCH MAC-d flow identity";

2> determine the value for the E_DCH_TRANSMISSION variable and take the corresponding actions as described in subclause 8.5.28.

### 8.6.5.8 Deleted DL TrCH information

If the IE "Deleted DL TrCH information" is included the UE shall:

1> if a Downlink transport channel is requested to be deleted:

2> delete any information about the transport channel identified by the IE "DL TrCH identity".

1> if a DL MAC-d flow is requested to be deleted:

2> delete any information about the DL HS-DSCH MAC-d flow identified by the IE "MAC-d Flow Identity", i.e. delete any information about MAC-hs queue(s) mapped onto this MAC-d flow.

2> determine the value for the HS_DSCH_RECEPTION variable and take the corresponding actions as described in subclause 8.5.25.

### 8.6.5.9 UL Transport channel information common for all transport channels

If the IE "UL Transport channel information common for all transport channels" is included the UE shall:

1> perform actions for the IE "TFC subset" as specified in subclause 8.6.5.3;

1> if the IE "PRACH TFCS" is included:

2> set the variable INVALID_CONFIGURATION to TRUE.

1> if the IE has the choice "mode" set to FDD:

2> perform actions for the IE "UL DCH TFCS" as specified in subclause 8.6.5.2.

1> if the IE has the choice "mode" set to TDD:

2> if the IE "Individual UL CCTrCH information" is included:

3> for each TFCS identified by IE "UL TFCS id":

4> perform actions for the IE "UL TFCS" as specified in subclause 8.6.5.2.

1> if the IE "TFC subset list" is included:

2> remove a previously stored TFC subset list if this exists in the IE "TFC subset list" in the variable TFC_SUBSET;

2> store the IE "TFC subset list" in the IE "TFC subset list" in the variable TFC_SUBSET;

2> consider the first instance of the IE "TFC subset" in the IE "TFC subset list" as Transport Format Combination Subset 0 (TFC subset identity = 0), the second instance as Transport Format Combination Subset 1 (TFC subset identity = 1) and so on;

2> if the IE"TFC subset list" contains greater than 8 elements then the UE behaviour is not specified.

NOTE: The UTRAN should not modify the TFC subset list when a temporary restriction of the TFC set is being applied, due to the reception of the IE "TFC Control Duration" in a TRANSPORT FORMAT COMBINATION CONTROL message is still being applied.

### 8.6.5.10 DL Transport channel information common for all transport channels

If the IE "DL Transport channel information common for all transport channels" is included the UE shall:

1> if the IE "SCCPCH TFCS" is included:

2> set the variable INVALID_CONFIGURATION to TRUE.

1> if the IE choice "mode" is set to FDD:

2> if the choice "DL parameters" is set to 'explicit':

3> if the IE "DL DCH TFCS" is included:

4> if the IE "SCCPCH TFCS" is included and the state the UE enters after handling the received information is other than CELL_DCH:

5> ignore the received IE "DL DCH TFCS".

NOTE: the IE "DL Transport channel information common for all transport channels" always includes a DL DCH TFCS configuration, either by including the IE "DL DCH TFCS " or by specifying that the TFCS is the same as in UL. If UTRAN does not require the reconfiguration of the concerned parameters, UTRAN may replace one TFC with the value that is already assigned for this IE.

4> else:

5> perform actions as specified in subclause 8.6.5.2.

1> if the IE choice "mode" is set to TDD:

2> if the IE "Individual DL CCTRCH information" is included:

3> for each DL TFCS identified by the IE "DL TFCS identity":

4> if the IE choice "DL parameters" is set to 'independent':

5> perform actions for the IE "DL TFCS" as specified in subclause 8.6.5.2.

4> if the IE choice "DL parameters" is set to 'same as UL':

5> if the IE "UL DCH TFCS identity" indicates an existing or a new UL TFCS:

6> store for that DL TFCS the TFCS identified by the IE "UL DCH TFCS identity".

5> else:

6> set the variable INVALID_CONFIGURATION to TRUE.

### 8.6.5.11 Void

### 8.6.5.12 TFCS Reconfiguration/Addition Information

If the IE "TFCS Reconfiguration/Addition Information" is included the UE shall:

1> store the TFCs to be reconfigured/added indicated in the IE "CTFC information" as specified below;

1> if the IE "Power offset information" is included:

2> perform actions as specified in [29].

In order to identify the TFCs included in this IE the UE shall calculate the CTFC as specified in subclause 14.10.

1> if the IE "Additional Dynamic Transport Format Information for CCCH" was included in the IE "RACH TFS":

2> ignore for the CTFC calculation any TF added by the IE "Additional Dynamic Transport Format Information for CCCH".

If the IE "TFCS Reconfiguration/Addition Information" is used in case of TFCS "Complete reconfiguration" the UE shall:

1> remove a previously stored transport format combination set if this exists;

1> consider the first instance of the IE "CTFC information" as Transport Format Combination 0 in FDD (TFCI=0) and 1 in TDD (TFCI=1), the second instance as Transport Format Combination 1 in FDD (TFCI=1) and 2 in TDD (TFCI=2) and so on. In TDD the TFCI value = 0 is reserved for physical layer use.

If the IE "TFCS Reconfiguration/Addition Information" is used in case of TFCS "Addition" the UE shall insert the new additional(s) TFC into the first available position(s) in ascending TFCI order in the TFCS.

### 8.6.5.12a Additional RACH TFCS for CCCH

If the IE "Additional RACH TFCS for CCCH " is included the UE shall:

1> if the IE "Power offset information" is included:

2> perform actions as specified in [29].

1> add to the TFCS as calculated in 8.6.5.12 for the corresponding PRACH the TFC which consists of the TF added by the IE "Additional Dynamic Transport Format Information for CCCH" into the next position in ascending order after the highest TFCI value already used.

NOTE: On PRACH only one transport channel can be multiplexed.

### 8.6.5.13 TFCS Removal Information

If the IE "TFCS Removal Information" is included the UE shall:

1> remove the TFC indicated by the IE "TFCI" from the current TFCS, and regard this position (TFCI) in the TFCS as vacant.

### 8.6.5.14 Void

### 8.6.5.15 TFCS Explicit Configuration

If the IE " TFCS Explicit Configuration" is included the UE shall:

1> if the IE choice "TFCS representation" is set to 'complete reconfiguration':

2> perform the actions for the IE "TFCS Reconfiguration/Addition Information" as specified in subclause 8.6.5.12.

1> if the IE choice "TFCS representation" is set to 'addition':

2> perform the actions for the IE "TFCS Reconfiguration/Addition Information" as specified in subclause 8.6.5.12.

1> if the IE choice "TFCS representation" is set to 'removal':

2> perform the actions for the IE "TFCS Removal Information" as specified in subclause 8.6.5.13.

1> if the IE choice "TFCS representation" is set to 'replace':

2> perform first the actions for the IE "TFCS Removal Information" as specified in subclause 8.6.5.13; and then

2> perform the actions for the IE "TFCS Reconfiguration/Addition Information" as specified in subclause 8.6.5.12.

### 8.6.5.16 E-DCH Transmission Time Interval

If the IE "E-DCH Transmission Time Interval" is included, the UE shall:

1> store the received TTI;

1> determine the value for the E_DCH_TRANSMISSION variable and take the corresponding actions as described in subclause 8.5.28.

When the variable E_DCH_TRANSMISSION is set to TRUE the UE shall:

1> apply the TTI as signalled in the IE "E-DCH Transmission Time Interval" on the E-DPDCH.

If the received "E-DCH Transmission Time Interval" is 2 ms and the previously stored TTI was 10 ms:

1> not send any data on E-DPDCH in first 8 TTIs after activation time of new TTI.

### 8.6.5.17 HARQ Info for E-DCH

If the IE "HARQ Info for E-DCH" is included, the UE shall:

1> store the received configuration;

1> determine the value for the E_DCH_TRANSMISSION variable and take the corresponding actions as described in subclause 8.5.28.

When the variable E_DCH_TRANSMISSION is set to TRUE the UE shall:

1> use a redundancy version for each HARQ transmission as configured by the IE "HARQ RV Configuration".

### 8.6.5.18 Added or reconfigured E-DCH MAC-d flow

If the IE "Added or reconfigured E-DCH MAC-d flow" is included, the UE shall:

1> if the IE "E-DCH MAC-d flow power offset" is included:

2> configure the power offset indicated in the IE "E-DCH MAC-d flow power offset" for the E-DCH MAC-d flow identified by the IE "E-DCH MAC-d flow identity".

1> if the IE "E-DCH MAC-d flow maximum number of retransmissions" is included:

2> configure the maximum number of retransmissions indicated in the IE "E-DCH MAC-d flow maximum number of retransmissions" for the E-DCH MAC-d flow identified by the IE "E-DCH MAC-d flow identity".

1> if the IE "E-DCH MAC-d flow multiplexing list" is included:

2> only multiplex MAC-d PDU"s from the E-DCH MAC-d flow indicated in the IE "E-DCH MAC-d flow identity" with MAC-d PDU"s from E-DCH MAC-d flows with which multiplexing in the same MAC-e PDU is allowed in accordance to the IE "E-DCH MAC-d flow multiplexing list".

1> else:

2> if previously the IE "E-DCH MAC-d flow multiplexing list" was already received for this E-DCH MAC-d flow:

3> continue to only multiplex E-DCH PDU"s from the E-DCH MAC-d flow indicated in the IE 'E-DCH MAC-d flow identity' with MAC-d PDU"s from E-DCH MAC-d flows with which multiplexing in the same MAC-e PDU is allowed according to the previously received IE 'E-DCH MAC-d flow multiplexing list'.

2> else (never received the IE "E-DCH MAC-d flow multiplexing list" for this E-DCH MAC-d flow):

3> allow multiplexing of MAC-d PDU"s from the E-DCH MAC-d flow indicated in the IE "E-DCH MAC-d flow identity" with MAC-d PDU"s from any other E-DCH MAC-d flow in the same MAC-e PDU.

1> if the IE "Non-scheduled transmission grant info" is included:

2> if the TTI configured on the E-DCH equals 2ms, and the IE "2ms non-scheduled transmission grant HARQ process allocation" is configured for this MAC-d flow:

3> MAC-d PDU's for logical channels belonging to this MAC-d flow shall only be included in a MAC-e PDU transmitted by HARQ processes allowed by the IE "2ms non-scheduled transmission grant HARQ process allocation", with a total contribution from this MAC-d flow not exceeding the size as signalled by the IE "Max MAC-e PDU contents size".

2> else:

3> MAC-d PDU's for logical channels belonging to this MAC-d flow shall be included in a MAC-e PDU transmitted by any HARQ process, with a total contribution from this MAC-d flow not exceeding the size as signalled by the IE "Max MAC-e PDU contents size".

1> if the IE "Scheduled transmission grant info" is included:

2> transmission of MAC-d PDU's for logical channels belonging to this MAC-d flow shall be in accordance with the received scheduled grant on E-AGCH/E-RGCH (see [15]).

1> perform the actions as specified in subclause 8.5.21;

1> determine the value for the E_DCH_TRANSMISSION variable and take the corresponding actions as described in subclause 8.5.28.

## 8.6.6 Physical channel information elements

This subclause specifies the actions upon reception and/or non-reception of the physical channel information elements. The combination of the values of those information elements included in a given message shall follow the compatibility rules that are specified in the physical layer specifications. In case those rules are not followed, the UE shall set the variable INVALID_CONFIGURATION to TRUE.

### 8.6.6.1 Frequency info

If, after completion of the procedure, the UE will be in CELL_DCH state, the UE shall:

1> if the IE "Frequency info" is included:

2> if the frequency is different from the currently used frequency:

3> store and use the frequency indicated by the IE "Frequency Info";

3> if the received message is used to perform a Timing-maintained hard handover (see subclause 8.3.5.2), and IE "Timing maintained Synchronization indicator" is included:

4> not perform any physical layer synchronisation procedure (FDD only);

3> else:

4> perform the physical layer synchronisation procedure A as specified in [29] (FDD only).

2> if the frequency is the same as the currently used frequency:

3> continue to use the currently used frequency;

3> perform the physical layer synchronisation procedure A as specified in [29] (FDD only).

1> if the IE "Frequency info" is not included and the UE has a currently used frequency:

2> continue to use the currently used frequency;

NOTE If the received message is used to perform a Timing-reinitialised hard handover, and the IE "Frequency Info" is not included, the UE may perform the physical layer synchronisation procedure A as specified in [29] (FDD only).

### 8.6.6.2 Void

### 8.6.6.2a PNBSCH allocation

The UE shall consider the frame numbers fulfilling the following equation as "PRACH blocked frames" as specified in [33].

$$SFN = \lfloor k * \text{Repetition period} \rfloor$$

for an integer k with k {0, 1, 2, 3, 4, ... , value of IE "Number of repetitions per SFN period" - 1}, where:

Repetition period is: 4096 / value of IE "Number of repetitions per SFN period".

The UE shall configure the physical layer for the physical random access procedure accordingly.

### 8.6.6.3 Void

### 8.6.6.3a Downlink information per radio link list

If the IE "Downlink information per radio link list" is included in a received message, the UE shall:

1> if the active set resulting after the reception of the IE "Downlink information per radio link list" would contain radio links indicated by the IE "Downlink DPCH info for each RL" and radio links indicated by the IE "Downlink F-DPCH info for each RL":

2> set the variable INVALID_CONFIGURATION to TRUE.

1> if the message was received in CELL_DCH state and the UE remains in CELL_DCH state according to subclause 8.6.3.3 applied on the received message:

2> for FDD, check whether the radio links included in the IE "Downlink information per radio link list" are part of the current active set considering that a radio link is uniquely identified by the downlink UARFCN and the primary scrambling code;

2> for TDD, check whether the radio links included in the IE "Downlink information per radio link list" are part of the current active set considering that a radio link is uniquely identified by the UARFCN and the primary CCPCH;

2> if all radio links included in the IE "Downlink information per radio link list" are part of the current active set:

3> for radio links part of the current active set, and present in the IE "Downlink information per radio link list":

4> update the downlink physical channel configuration according to the IE "Downlink information for each radio link" as specified in subclause 8.6.6.4.

3> for radio links part of the current active set, and absent in the IE "Downlink information per radio link list":

4> not change its current downlink physical channel configuration;

4> in case the IE "Serving HS-DSCH radio link indicator" is set to 'TRUE' for another radio link, no longer consider any of these absent radio links as serving HS-DSCH radio link;

4> in case the IE "Serving E-DCH radio link indicator" is set to 'TRUE' for another radio link, no longer consider any of these absent radio links as serving E-DCH radio link.

2> if all radio links included in the IE "Downlink information per radio link list" are not part of the current active set:

3> perform a hard handover by replacing all the radio links in the current active set with the radio links in the IE "Downlink information per radio link list", each with a downlink physical channel configuration according to the IE "Downlink information for each radio link" as specified in subclause 8.6.6.4;

3> perform the checks on the value of the IE "Default DPCH Offset Value" as specified in subclause 8.3.5.1.2 or 8.3.5.2.2;

3> act on the IE "Timing indication" and the IE "Default DPCH Offset Value", if included, as specified in subclause 8.5.15.2;

NOTE: UTRAN should not mix radio links which are part of the current active set and radio links which are not part of the current active set in the same IE "Downlink information per radio link list". In such cases the UE behaviour is unspecified.

1> otherwise:

2> if the message was received in CELL_FACH state and the UE would transit to CELL_DCH state according to subclause 8.6.3.3 applied on the received message:

3> establish a downlink physical channel configuration for each of the included radio links according to the IE "Downlink information for each radio link" as specified in subclause 8.6.6.4.

### 8.6.6.4 Downlink information for each radio link

If the IE "Downlink information for each radio link" is included in a received message, the UE shall:

1> if the UE would enter CELL_DCH state according to subclause 8.6.3.3 applied on the received message:

2> if the UE is in TDD mode and shared transport channels are assigned to the UE:

3> start to receive the indicated Secondary CCPCH.

2> if the UE is in TDD mode and no shared transport channels are assigned to the UE:

3> set the variable UNSUPPORTED_CONFIGURATION to TRUE.

2> if the IE "Serving HS-DSCH radio link indicator" is set to 'TRUE':

3> consider this radio link as the serving HS-DSCH radio link and no longer consider any other radio link as serving HS-DSCH radio link.

2> if the IE "Serving E-DCH radio link indicator" is set to 'TRUE':

3> consider this radio link as the serving E-DCH radio link and no longer consider any other radio link as serving E-DCH radio link.

2> if the IE "E-AGCH Info" is included for the serving E-DCH radio link:

3> store the newly received E-AGCH configuration.

NOTE: The UTRAN should always include the IE "E-AGCH info" if the serving E-DCH radio link indicated in the message is another radio link than the serving E-DCH radio link prior to the procedure.

2> if the IE "E-HICH information" is included:

3> store this E-HICH configuration for the concerning radio link.

2> if the IE "E-HICH information" is included or previously stored:

3> store this E-RGCH configuration for the concerning radio link, if included.

2> determine the value for the E_DCH_TRANSMISSION variable and take the corresponding actions as described in subclause 8.5.28.

2> act on the other IEs contained in the IE "Downlink information for each radio link" as specified in subclause 8.6 applied on this radio link.

1> in addition, if the message was received in CELL_DCH state and the UE remains in CELL_DCH state according to subclause 8.6.3.3 applied on the received message:

2> if the IE "Serving HS-DSCH radio link indicator" is set to 'TRUE':

3> consider this radio link as the serving HS-DSCH radio link;

3> if the serving HS-DSCH radio link was another radio link than this radio link prior to reception of the message and the IE "H-RNTI" is not included:

4> clear the variable H_RNTI.

2> if the IE "Serving HS-DSCH radio link indicator" is set to "FALSE" and this radio link was considered the serving HS-DSCH radio link prior to reception of this message:

3> no longer consider this radio link as the serving HS-DSCH radio link.

2> determine the value for the HS_DSCH_RECEPTION variable and take the corresponding actions as described in subclause 8.5.25.

2> if the IE "Serving E-DCH radio link indicator" is set to 'TRUE':

3> consider this radio link as the serving E-DCH radio link;

3> if the serving E-DCH radio link was another radio link than this radio link prior to reception of the message:

4> if the IE "New Primary E-RNTI" is not included:

5> clear the Primary E-RNTI stored in the variable E_RNTI.

4> if the IE "New Secondary E-RNTI" is not included:

5> clear the Secondary E-RNTI stored in the variable E_RNTI.

2> if the IE "Serving E-DCH radio link indicator" is set to "FALSE" and this radio link was considered the serving E-DCH radio link prior to reception of this message:

3> no longer consider this radio link as the serving E-DCH radio link.

2> if the IE "E-HICH release indicator" is present:

3> delete the stored E-HICH, E-AGCH and E-RGCH (if any) configurations.

2> if the IE "E-RGCH release indicator" is present:

3> delete the stored E-RGCH configuration for this RL.

2> determine the value for the E_DCH_TRANSMISSION variable and take the corresponding actions as described in subclause 8.5.28;

2> for each optional IE part of the IE "Downlink information for each radio link" that is not present:

3> do not change its current downlink physical channel configuration corresponding to the IE, which is absent, if not stated otherwise elsewhere.

NOTE: The Release '99 RADIO BEARER RECONFIGURATION message always includes at least one IE "Downlink information for each radio link" containing the mandatory IEs, even if UTRAN does not require the reconfiguration of any radio link.

1> if the UE would enter either the CELL_FACH, CELL_PCH or URA_PCH state according to subclause 8.6.3.3 applied on the received message:

2> if IEs other than the IE "Primary CPICH info" (for FDD) or the IE "Primary CCPCH info" (for TDD) are included in the IE "Downlink information for each radio link":

3> ignore these IEs.

2> act on the other IEs contained in the IE "Downlink information for each radio link" as specified in subclause 8.6 applied on this radio link.

### 8.6.6.5 Void

### 8.6.6.6 Uplink DPCH info

If the IE "Uplink DPCH info" is included, the UE shall:

For FDD:

1> release any active uplink physical channels and activate the given physical channels;

1> if the IE "Number of FBI bits" is not included:

2> use 0 FBI bits in the Uplink DPCH.

1> use an SF equal to or greater than the minimum SF indicated in the IE "Spreading Factor" during uncompressed frames or compressed frames by HL scheduling;

1> use an SF equal to or greater than the minimum SF divided by 2 during compressed frames by SF reduction.

For TDD:

1> release the uplink physical channels associated with any CCTrCH that is removed or reconfigured and activate the physical channels assigned to any CCTrCH that is added or reconfigured;

1> for 3.84 Mcps TDD or 7.68 Mcps TDD use the IE "UL target SIR" specified for each added or reconfigured CCTrCH as described in subclause 8.5.7. For 1.28 Mcps TDD use the value of IE 'UL target SIR' specified for each added or reconfigured CCTrCH for parameter $PRX_{DPCHdes}$ as described in subclause 8.5.7;

1> for 1.28 Mcps TDD:

2> if "PLCCH Info" is included then store PLCCH Info parameters with respect to this uplink DPCH (overwriting parameter values previously stored);

2> if "PLCCH Info" is not included then delete the PLCCH Info stored with respect to this uplink DPCH.

1> use the parameters of the IE "Time info" for each added or reconfigured CCTrCH;

1> if present, use the IE "Uplink Timing Advance Control" as specified in subclause 8.6.6.26.

### 8.6.6.7 Void

### 8.6.6.8 Maximum allowed UL TX power

If the IE "Maximum allowed UL TX power" is included in the Handover to UTRAN Command, in any other dedicated message or in System Information Block type 3 or in System Information Block 4, the UE shall:

1> store and use the value until it is updated.

If the IE "Maximum allowed UL TX power" was not included in any dedicated message, the UE shall:

1> use the value previously stored, when received in an earlier dedicated message, Handover to UTRAN Command message or received in System Information Block type 3 or in System Information Block 4.

For all cases, the UE shall:

1> keep the UE uplink transmit power at or below the indicated power value;

1> if the current UE uplink transmit power is above the indicated power value:

2> decrease the power to a level at or below the power value.

The maximum UE TX power is defined as the lower of the maximum output power of the UE power class and the maximum allowed UL TX power indicated in this IE. The maximum UE TX power shall not be exceeded.

### 8.6.6.9 Void

### 8.6.6.10 Void

### 8.6.6.11 Uplink DPCH power control info

The UE shall:

1> in FDD:

2> if the IE "Uplink DPCH power control info" is included:

3> if a synchronisation procedure A is performed according to [29]:

4> calculate and set an initial uplink transmission power;

4> start inner loop power control as specified in subclause 8.5.3;

4> for the UL inner loop power control:

5> use the parameters specified in the IE.

3> else:

4> ignore the IEs "DPCCH Power offset", "PC Preamble" and "SRB delay";

4> act on the IE "Power control algorithm" and the IE "TPC step size", if included.

3> act on the IEs "$\Delta_{ACK}$", "$\Delta_{NACK}$" and "Ack-Nack repetition factor", if included;

3> use the procedure for transmitting HS-DPCCH preamble and postamble according to [29], if the IE "HARQ_preamble_mode" is set to 1.

1> in 3.84 Mcps TDD or 7.68 Mcps TDD:

2> if the IE "Uplink DPCH power control info" is included:

3> use the parameters specified in the IE for open loop power control as defined in subclause 8.5.7.

2> else:

3> use the current uplink transmission power.

1> in 1.28 Mcps TDD:

2> if the CHOICE UL OL PC info is set to 'Broadcast UL OL PC info':

3> set the variable INVALID_CONFIGURATION to true.

2> if the IE "Uplink DPCH power control info"is included in the UPLINK PHYSICAL CHANNEL CONTROL message:

3> use "Beacon PL Est. " and the TPC step size for the closed loop power control of the CCTrCH identified in the message, replacing the existing value used for the CCTrCH.

3> if the IE " UL target SIR " is included:

4> use this value for parameter $PRX_{DPCHdes}$ for open loop power control of the CCTrCH identified in the message in the case of a transition from closed loop to open loop power control as specified in [33].

2> if the IE "Uplink DPCH power control info" is included in the IE "Uplink DPCH info":

3> use the "Beacon PL Est. " and TPC step size for the closed loop power control of all CCTrCH added or reconfigured by the IE replacing any existing values used for the CCTrCHs;

3> if the IE " UL target SIR " is included ignore the parameter.

1> both in FDD and TDD;

2> if the IE "Uplink DPCH power control info" is not included in a message used to enter CELL_DCH:

3> set the variable INVALID_CONFIGURATION to true.

1> determine the value for the HS_DSCH_RECEPTION variable and take the corresponding actions as described in subclause 8.5.25.

### 8.6.6.12 Secondary CPICH info

If the IE Secondary CPICH info is included, the UE may:

1> use the channelisation code according to IE "channelisation code", with scrambling code according to IE "DL scrambling code" in the IE "Secondary CPICH info", for channel estimation of that radio link;

1> use the pilot bits on DPCCH for channel estimation.

If the IE Secondary CPICH info is not included, the UE shall:

1> not use any previously stored configuration corresponding to the usage of the Secondary CPICH info.

### 8.6.6.13 Primary CPICH usage for channel estimation

If the IE "Primary CPICH usage for channel estimation" is included and has the value "Primary CPICH may be used" the UE:

1> may use the Primary CPICH for channel estimation;

1> may use the pilot bits on DPCCH for channel estimation.

NOTE: If the IE "Primary CPICH usage for channel estimation" has the value "Primary CPICH shall not be used" and the IE "Secondary CPICH info" is not included for that radio link then the UE behaviour is not specified.

If the IE "Primary CPICH usage for channel estimation" is included and has the value "Primary CPICH shall not be used" the UE:

1> shall not use the Primary CPICH for channel estimation;

1> may use the Secondary CPICH for channel estimation;

1> may use the pilot bits on DPCCH for channel estimation.

### 8.6.6.14 DPCH frame offset

If "DPCH frame offset" is included in a message that instructs the UE to enter CELL_DCH state:

1> UTRAN should:

2> if only one Radio Link is included in the message:

3> if the UE is configured for DPCH:

4> set "Default DPCH Offset Value" and "DPCH frame offset" respecting the following relation:

(Default DPCH Offset Value) mod 38400 = DPCH frame offset

- where the IE values used are the Actual Values of the IEs as defined in clause 11.

3> if the UE is configured for F-DPCH:

4> set "Default DPCH Offset Value" and "DPCH frame offset" respecting one of the following relations:

5> (Default DPCH Offset Value) mod 38400 = DPCH frame offset; or

5> (Default DPCH Offset Value+256) mod 38400 = DPCH frame offset,

- where the IE values used are the Actual Values of the IEs as defined in clause 11.

2> if more than one Radio Link are included in the message:

3> if the UE is configured for DPCH:

4> set "Default DPCH Offset Value" and "DPCH frame offset" respecting the following relation:

(Default DPCH Offset Value) mod 38400 = DPCH frame $offset_j$

- where *j* indicates the first radio link listed in the message and the IE values used are the Actual Values of the IEs as defined in clause 11.

3> if the UE is configured for F-DPCH:

4> set "Default DPCH Offset Value" and "DPCH frame $offset_j$" respecting one of the following relations:

5> (Default DPCH Offset Value) mod 38400 = DPCH frame $offset_j$; or

5> (Default DPCH Offset Value+256) mod 38400 = DPCH frame $offset_j$,

- where *j* indicates the first radio link listed in the message and the IE values used are the Actual Values of the IEs as defined in clause 11.

1> The UE shall:

2> if only one Radio Link is included in the message:

3> if the UE is configured for DPCH:

4> if (Default DPCH Offset Value) mod 38400 = DPCH frame offset:

5> set DOFF (see subclause 8.5.15.1) to Default DPCH Offset Value.

4> else:

5> set the variable INVALID_CONFIGURATION to true.

3> if the UE is configured for F-DPCH:

4> if (Default DPCH Offset Value) mod 38400 = DPCH frame offset:

5> set DOFF (see subclause 8.5.15.1) to Default DPCH Offset Value.

4> else if (Default DPCH Offset Value+256) mod 38400 = DPCH frame offset:

5> set DOFF (see subclause 8.5.15.1) to Default DPCH Offset Value + 256.

4> else:

5> set the variable INVALID_CONFIGURATION to true.

2> if more than one Radio Links are included in the message:

3> if the UE is configured for DPCH:

4> if (Default DPCH Offset Value) mod 38400 = DPCH frame $offset_j$,

- where *j* indicates the first radio link listed in the message:

5> set DOFF (see subclause 8.5.15.1) to Default DPCH Offset Value.

4> else:

5> set the variable INVALID_CONFIGURATION to true.

3> if the UE is configured for F-DPCH:

4> if (Default DPCH Offset Value) mod 38400 = DPCH frame $offset_j$,,

- where *j* indicates the first radio link listed in the message:

5> set DOFF (see subclause 8.5.15.1) to Default DPCH Offset Value.

4> else if (Default DPCH Offset Value+256) mod 38400 = DPCH frame $offset_j$ ,

- where *j* indicates the first radio link listed in the message:

5> set DOFF (see subclause 8.5.15.1) to Default DPCH Offset Value + 256.

4> else:

5> set the variable INVALID_CONFIGURATION to true.

If the IE "DPCH frame offset" is included the UE shall:

1> use its value to determine the beginning of the DPCH or F-DPCH frame.

### 8.6.6.15 DPCH Compressed mode info

If the IE "DPCH compressed mode info" is included, and if the IE group "transmission gap pattern sequence configuration parameters" is included, the UE shall for each transmission gap pattern sequence perform the following consistency checks:

1> if the UE, according to its measurement capabilities, and for all supported bands of the UTRA mode or RAT associated with the measurement purpose indicated by IE "TGMP", requires UL compressed mode, and CHOICE 'UL/DL mode' indicates 'DL only':

2> set the variable INVALID_CONFIGURATION to TRUE.

1> if the UE, according to its measurement capabilities, and for all supported bands of the UTRA mode or RAT associated with the measurement purpose indicated by IE "TGMP", requires DL compressed mode, and CHOICE 'UL/DL mode' indicates 'UL only':

2> set the variable INVALID_CONFIGURATION to TRUE.

1> if the UE, according to its measurement capabilities, does not require UL compressed mode for any of supported band of the UTRA mode or RAT associated with the measurement purpose indicated by the IE "TGMP", and CHOICE 'UL/DL mode' indicates 'UL only' or 'UL and DL':

2> set the variable INVALID_CONFIGURATION to TRUE.

1> if the UE, according to its measurement capabilities, does not require DL compressed mode for any supported band of the UTRA mode or RAT associated with the measurement purpose indicated by the IE "TGMP", and CHOICE 'UL/DL mode' indicates 'DL only' or 'UL and DL':

2> set the variable INVALID_CONFIGURATION to TRUE.

1> if UE already has an active transmission gap pattern sequence that, according to IE "TGMP", has the same measurement purpose, and both patterns will be active (according to the IE "Current TGPS Status Flag" in variable TGPS_IDENTITY) after the new configuration has been taken into use:

2> set the variable INVALID_CONFIGURATION to TRUE.

1> if there is any pending "TGPS reconfiguration CFN" or any pending "TGCFN":

2> the UE behaviour is unspecified.

If variable INVALID_CONFIGURATION has value FALSE after UE has performed the checks above, the UE shall:

1> if pattern sequence corresponding to IE "TGPSI" is already active (according to "Current TGPS Status Flag") in the variable TGPS_IDENTITY):

2> if the "TGPS Status Flag" in this message is set to "deactivate" for the corresponding pattern sequence:

3> deactivate this pattern sequence at the beginning of the frame, indicated by IE "Activation time" (see subclause 8.6.3.1) received in this message, when the new configuration received in this message is taken into use.

3> set the "Current TGPS Status Flag" for this pattern sequence in the variable TGPS_IDENTITY to "inactive" at the frame, indicated by IE "Activation time" (see subclause 8.6.3.1) received in this message, when the new configuration received in this message is taken into use.

2> if the "TGPS Status Flag" in this message is set to "activate" for the corresponding pattern sequence:

3> deactivate this pattern sequence at the beginning of the frame, indicated by IE "Activation time"(see subclause 8.6.3.1) received in this message, when the new configuration received in this message is taken into use.

NOTE1: The temporary deactivation of pattern sequences for which the status flag is set to "activate" can be used by the network to align the timing of already active patterns with newly activated patterns.

NOTE2: The deactivation of pattern sequences only occurs as a result of RRC messages received by the UE, i.e. the UE does not set the "Current TGPS Status Flag" to "inactive" after the final gap of a finite length pattern sequence.

1> update each pattern sequence to the variable TGPS_IDENTITY according to the IE "TGPSI";

1> update into the variable TGPS_IDENTITY the configuration information defined by IE group" transmission gap pattern sequence configuration parameters ";

1> if an F-DPCH is configured:

2> not use the IEs "Downlink compressed mode method", "Downlink frame type", "DeltaSIR1", "DeltaSIRafter1", and if included, the IEs "DeltaSIR2", "DeltaSIRafter2".

1> after the instant in which the message is to be executed, as specified in subclause 8.6.3.1:

2> activate the stored pattern sequence corresponding to each IE "TGPSI" for which the "TGPS status flag" in the variable TGPS_IDENTITY is set to "activate" at the time indicated by IE "TGCFN"; and

2> set the "Current TGPS Status Flag" for this pattern sequence in the variable TGPS_IDENTITY to "active".

NOTE1: If the pattern is activated with a message that includes the IE "Activation time", and if the CFN value indicated by the IE "Activation Time" and the CFN value indicated by the TGCFN are included in the same TTI (but not at the TTI boundary) common to all the transport channels that are multiplexed onto the reference CCTrCh (as defined in subclause 8.6.3.1), and if the CFN value indicated by the TGCFN is equal or higher than the CFN value indicated by the IE "Activation Time" (as defined in subclause 8.6.3.1) value, the UE behaviour is not specified.

NOTE2: If the pattern is activated with a message used to perform timing re-initialised hard handover, the UE can start evaluating the activation of the pattern (i.e. compare the value of the CFN in the new configuration with the value of the TGCFN) at any time between the message activation time and the completion of the synchronisation procedure A.

2> if the IE "DPCH compressed mode info" is included in a message used to perform a Hard Handover with change of frequency (see subclause 8.3.5); or

2> if the IE "DPCH compressed mode info" is included in a message used to transfer the UE from Cell_FACH to Cell_DCH, and the cell in which the UE transited from CELL_FACH state is not included in the active set for the CELL_DCH state (see subclause 8.4.1.7.2):

3> not begin the inter-frequency measurement reporting corresponding to the pattern sequence measurement purpose of each activated pattern sequence.

2> else:

3> begin the inter-frequency measurement reporting corresponding to the pattern sequence measurement purpose of each activated pattern sequence.

2> begin the inter-RAT measurement reporting corresponding to the pattern sequence measurement purpose of each activated pattern sequence;

2> if the new configuration is taken into use at the same CFN as indicated by IE "TGCFN":

3> start the concerned pattern sequence immediately at that CFN.

1> monitor if the parallel transmission gap pattern sequences create an illegal overlap, and in case of overlap, take actions as specified in subclause 8.2.11.2.

If the IE "DPCH compressed mode info" is included, and if the IE group "transmission gap pattern sequence configuration parameters" is not included, the UE shall:

1> if, as the result of this message, UE will have more than one transmission gap pattern sequence with the same measurement purpose active (according to IEs "TGMP" and "Current TGPS Status Flag" in variable TGPS_IDENTITY):

2> set the variable CONFIGURATION_INCOMPLETE to TRUE.

1> if there is any pending "TGPS reconfiguration CFN" or any pending "TGCFN":

2> the UE behaviour is unspecified.

1> if pattern sequence corresponding to IE "TGPSI" is already active (according to "Current TGPS Status Flag" in the variable TGPS_IDENTITY):

2> if the "TGPS Status Flag" in this message is set to "deactivate" for the corresponding pattern sequence:

3> deactivate this pattern sequence at the beginning of the frame, indicated by IE "Activation time"(see subclause 8.6.3.1) received in this message, when the new configuration received in this message is taken into use;

3> set the "Current TGPS Status Flag" for this pattern sequence in the variable TGPS_IDENTITY to "inactive" at the frame, indicated by IE "Activation time"(see subclause 8.6.3.1) received in this message, when the new configuration received in this message is taken into use.

2> if the "TGPS Status Flag" in this message is set to "activate" for the corresponding pattern sequence:

3> deactivate this pattern sequence at the beginning of the frame, indicated by IE "Activation time"(see subclause 8.6.3.1) received in this message, when the new configuration received in this message is taken into use.

NOTE1: The temporary deactivation of pattern sequences for which the status flag is set to "activate" can be used by the network to align the timing of already active patterns with newly activated patterns.

NOTE2: The deactivation of pattern sequences only occurs as a result of RRC messages received by the UE, i.e. the UE does not set the "Current TGPS Status Flag" to "inactive" after the final gap of a finite length pattern sequence.

1> after the instant in which the message is to be executed, as specified in subclause 8.6.3.1:

2> activate the stored pattern sequence corresponding to each IE "TGPSI" for which the "TGPS status flag" is set to "activate" at the time indicated by IE "TGCFN"; and

NOTE1: If the pattern is activated with a message that includes the IE "Activation time", and if the CFN value indicated by the IE "Activation Time" and the CFN value indicated by the TGCFN are included in the same TTI (but not at the TTI boundary) common to all the transport channels that are multiplexed onto the reference CCTrCh (as defined in subclause 8.6.3.1), and if the CFN value indicated by the TGCFN is equal or higher than the CFN value indicated by the IE "Activation Time" (as defined in subclause 8.6.3.1) value, the UE behaviour is not specified.

NOTE2: If the pattern is activated with a message used to perform timing re-initialised hard handover, the UE can start evaluating the activation of the pattern (i.e. compare the value of the CFN in the new configuration with the value of the TGCFN) at any time between the message activation time and the completion of the synchronisation procedure A.

2> set the "Current TGPS Status Flag" for this pattern sequence in the variable TGPS_IDENTITY to "active";

2> if the IE "DPCH compressed mode info" is included in a message used to perform a Hard Handover with change of frequency (see subclause 8.3.5); or

2> if the IE "DPCH compressed mode info" is included in a message used to transfer the UE from Cell_FACH to Cell_DCH, and the cell in which the UE transited from CELL_FACH state is not included in the active set for the CELL_DCH state (see subclause 8.4.1.7.2):

3> not begin the inter-frequency measurement reporting corresponding to the pattern sequence measurement purpose of each activated pattern sequence.

2> else:

3> begin the inter-frequency measurement reporting corresponding to the pattern sequence measurement purpose of each activated pattern sequence.

2> begin the inter-RAT measurement reporting corresponding to the pattern sequence measurement purpose of each activated pattern sequence;

2> if the new configuration is taken into use at the same CFN as indicated by IE "TGCFN":

3> start the concerned pattern sequence immediately at that CFN.

For transmission gap pattern sequences stored in variable TGPS_IDENTITY, but not identified in IE "TGPSI" (either due to the absence of the IE "DPCH compressed mode info" in the received message or due to not receiving the corresponding TGPSI value in the IE "DPCH compressed mode info"), the UE shall:

1> if the received message implies a timing re-initialised hard handover (see subclause 8.3.5.1):

2> deactivate such transmission gap pattern sequences at the beginning of the frame, indicated by IE "Activation time" (see subclause 8.6.3.1) received in this message; and

2> set IE "Current TGPS Status Flag" in corresponding UE variable TGPS_IDENTITY to 'inactive'.

1> if the received message not implies a timing re-initialised hard handover (see subclause 8.3.5.1):

2> continue such transmission gap pattern sequence according to IE "Current TGPS Status Flag" in the corresponding UE variable TGPS_IDENTITY.

Uplink and downlink compressed mode methods are described in [27]. For UL "higher layer scheduling" compressed mode method and transport format combination selection, see [15].

### 8.6.6.16 Repetition period, Repetition length, Offset (TDD only)

In case the physical allocations of different channels overlap the following priority rules shall apply for common channels and shall be taken into account by the UE:

1> PICH takes precedence over Primary CCPCH;

1> PICH takes precedence over Secondary CCPCH;

1> MICH takes precedence over Primary CCPCH;

1> MICH takes precedence over Secondary CCPCH;

1> Secondary CCPCH takes precedence over Primary CCPCH.

The frame allocation can be derived by following rules:

If no IE "Offset" is explicitly given, the parameter "Offset" to be used is calculated by the following equation:

Activation time mod Repetition period = Offset.

Frames from CFN $CFN_{off}$ to $CFN_{off}$ + Repetition length - 1 belong to the allocation with $CFN_{off}$ fulfilling the following equation:

$CFN_{off}$ mod Repetition period = Offset.

Repetition length is always a multiple of the largest TTI within the CCTrCH fulfilling the following equation:

(largest TTI within CCTrCH) * X = Repetition Length

Example of usage:




**Figure 8.6.6.16-1: Examples for frame allocations in TDD**

### 8.6.6.17 Primary CCPCH info

If the IE "Primary CCPCH info" is included, the UE shall:

1> use the information elements in this IE.

### 8.6.6.18 Primary CPICH info

If the IE "Primary CPICH info" in FDD is included, the UE shall:

1> use the value of this IE as the primary scrambling code for the downlink radio link.

### 8.6.6.19 Void

### 8.6.6.20 Void

### 8.6.6.21 Void

### 8.6.6.22 Secondary Scrambling Code, Code Number

The following description applies to FDD.

Code Number can be assigned by following rules:

1> When more than one DL DPDCH is assigned per RL, the segmented physical channel shall be mapped on to DL DPDCHs according to [27]. When *p* number of DL DPDCHs are assigned to each RL, the first pair of Secondary Scrambling Code and Code Number corresponds to "*PhCH number 1*", the second to "*PhCH number 2"*, and so on until the *p*th to "*PhCH number p*".

### 8.6.6.23 PDSCH Power Control info

The UE shall:

1> if the IE "PDSCH Power Control info" is included:

2> configure PDSCH power control with the received values.

1> if the IE "PDSCH Power Control info" is not included:

2> continue to use the stored values.

### 8.6.6.24 Tx Diversity Mode

If the IE "Tx Diversity Mode" is included the UE shall:

1> if the value of the IE "Tx Diversity Mode" is STTD:

2> configure the Layer 1 to use the Tx diversity mode indicated in the IE "Tx Diversity Mode" for the radio links for which the IE "Closed loop timing adjustment mode" is included, ignoring the actual value of IE "Closed loop timing adjustment mode".

1> if the value of the IE "Tx Diversity Mode" is closed loop mode 1:

2> configure the Layer 1 to use the Tx diversity mode indicated in the IE "Tx Diversity Mode" for the radio links for which the IE "Closed loop timing adjustment mode" is included, using the actual value of the IE "Closed loop timing adjustment mode".

1> if the value of the IE "Tx Diversity Mode" is "none":

2> configure the Layer 1 not to use Tx diversity for all radio links in the active set.

If the IE "Tx Diversity Mode" is not included, the UE shall:

1> continue to use the already configured Tx diversity mode;

1> in case no Tx diversity mode has been configured:

2> do not apply Tx diversity.

For HS-SCCH, the UE shall:

1> if the DPCH associated with a HS-SCCH is using either open or closed loop transmit diversity on the radio link transmitted from the HS-DSCH serving cell:

2> use STTD for this HS-SCCH;

1> if the F-DPCH associated with an HS-SCCH is using open loop transmit diversity on the radio link transmitted from the HS-DSCH serving cell:

2> use STTD for this HS-SCCH.

1> otherwise:

2> not use Tx diversity for this HS-SCCH.

For E-AGCH, E-RGCH, and E-HICH from the same cell, the UE shall:

1> if the DPCH associated with E-AGCH, E-RGCH, and E-HICH from the same cell is using either open or closed loop transmit diversity on the radio link received from the E-DCH serving cell:

2> use STTD for these E-AGCH, E-RGCH, and E-HICH.

1> if the F-DPCH associated with E-AGCH, E-RGCH, and E-HICH from the same cell is using open loop transmit diversity on the radio link received from the E-DCH serving cell:

2> use STTD for these E-AGCH, E-RGCH, and E-HICH.

1> otherwise:

2> not use Tx diversity for these E-AGCH, E-RGCH, and E-HICH.

### 8.6.6.25 Void

### 8.6.6.26 UL Timing Advance Control (TDD only)

If the IE "UL Timing Advance Control" is present, the UE shall:

1> if the IE "Uplink Timing Advance Control" has the value "disabled":

2> reset timing advance to 0;

2> disable calculated timing advance following handover;

2> in case of handover:

3> start uplink transmissions in the target cell without applying timing advance.

1> if the IE "Uplink Timing Advance Control" has the value "enabled":

2> in 3.84 Mcps TDD or 7.68 Mcps TDD:

3> in case of no cell change:

4> evaluate and apply the timing advance value for uplink transmission as indicated in the IE "Uplink Timing Advance" at the CFN indicated in the IE "Activation Time".

3> in case of cell change:

4> use the IE "Uplink Timing Advance" as $TA_{old}$ and apply $TA_{new}$ for uplink transmission in the target cell at the CFN indicated in the IE "Activation Time" as specified in [33];

4> include the value of the applied timing advance in the IE "Timing Advance" in the COMPLETE message.

2> in 1.28 Mcps TDD:

3> if the IE "Synchronisation parameters" is included:

4> initiate a sequence of UpPCH SYNC_UL code transmissions using a code selected from the set specified and continue until a timing correction is received in the specified FPACH (received for WT sub-frames following the sub-frame in which the transmission was made) or until Max SYNC_UL transmissions have been completed. The power used for each SYNC_UL transmission is as specified in subclause 8.5.7. Each transmission is made in the first sub-frame possible following the end of each FPACH reception interval using the timing specified in [33]. A new code is selected for each transmission. The detection that the FPACH relates to the transmitted SYNC_UL code is described in [33];

4> if a timing correction is received within Max SYNC_UL transmissions the procedure is completed. The assigned uplink resources may then be used, commencing at the first possible TTI boundary or the SFN in which the assignment commences, whichever is the later. The timing of the uplink transmission is described in [33];

4> if no timing correction has been received within Max SYNC_UL transmissions, the synchronisation procedure has failed. If the assigned resources are DCH, the UE should not transmit using these resources and should respond as if a physical channel failure has occurred as specified in subclauses 8.1.3.7 or 8.2.2.7 or 8.3.1.7, or 8.3.6.5. If the assigned resources are USCH then the UE should ignore the USCH allocation.

3> if the IE "Synchronisation parameters" is not included:

4> in case of no cell change:

5> continue to use the current uplink timing.

4> in case of cell change:

5> evaluate and apply the timing correction $TA_{new}$ for uplink transmissions using the procedure as specified in [33].

### 8.6.6.26a Uplink synchronisation parameters (TDD only)

The UE shall apply uplink synchronisation using the values of the IEs "Uplink synchronisation step size" and "Uplink synchronisation frequency" as specified in [33].

### 8.6.6.27 Downlink information common for all radio links

If the IE "Downlink information common for all radio links " is included the UE shall:

1> if the IE "Downlink DPCH info common for all RL" is included:

2> perform actions as specified in subclause 8.6.6.28.

1> if the IE "Downlink F-DPCH info common for all RL" is included:

2> perform actions as specified in subclause 8.6.6.28a.

1> if the IE choice "mode" is set to 'FDD':

2> perform actions for the IE "DPCH compressed mode info" as specified in subclause 8.6.6.15;

2> perform actions for the IE "Tx Diversity mode" as specified in subclause 8.6.6.24.

1> if the IE "MAC-hs reset indicator" is included:

2> if the serving HS-DSCH radio link is the same radio link as prior to the reception of the message:

3> the UE behaviour is unspecified;

2> reset the MAC-hs entity [15].

### 8.6.6.28 Downlink DPCH info common for all radio links

If the IE "Downlink DPCH info common for all RL" is included the UE shall:

1> if:

2> the IE "Downlink DPCH info common for all RL" is included in a reconfiguration message; and

2> the UE was in CELL_DCH state upon reception of the message and remains in CELL_DCH state; and

2> the message is not used to perform a hard handover (as specified in subclause 8.6.6.3a) and the IE "Timing indication" is set to "initialise":

3> the UE behaviour is not specified.

1> if the IE "Downlink DPCH power control information" is included:

2> in the case of FDD:

3> perform actions for the IE "DPC Mode" according to [29].

2> in the case of TDD:

3> perform actions for the IE "TPC Step Size" according to [33].

1> if the IE choice "mode" is set to 'FDD':

2> if the IE "Downlink rate matching restriction information" is included:

3> set the variable INVALID_CONFIGURATION to TRUE.

2> perform actions for the IE "spreading factor";

2> perform actions for the IE "Fixed or Flexible position";

2> perform actions for the IE "TFCI existence";

2> if the IE choice "SF" is set to 256:

3> store the value of the IE "Number of bits for pilot bits".

2> if the IE choice "SF" is set to 128:

3> store the value of the IE "Number of bits for pilot bits".

If the IE "Downlink DPCH info common for all RL" is included in a message used to perform a Timing re-initialised hard handover or the IE "Downlink DPCH info common for all RL" is included in a message other than RB SETUP used to transfer the UE from a state different from Cell_DCH to Cell_DCH, and ciphering is active for any radio bearer using RLC-TM, the UE shall, after having activated the dedicated physical channels indicated by that IE:

1> if any ciphering configuration for a radio bearer using RLC-TM has not been applied, due to that the activation time from a previous procedure has not elapsed:

2> apply the ciphering configuration immediately and consider the activation time from the previous procedure to be elapsed.

1> if the IE "MAC-d HFN initial value" is included in the IE "Downlink DPCH info common for all RL":

2> set the HFN component of COUNT-C for TM-RLC to the value of the IE "MAC-d HFN initial value", while not incrementing the value of the HFN component of COUNT-C at each CFN cycle.

NOTE: The UTRAN should choose a value for the IE "MAC-d HFN initial value" using the COUNT-C value of the RBs using RLC-TM indicated by the Source RNC to the Target RNC in the IE "SRNS Relocation Info" and include some margin in such a way that no values of COUNT-C are repeated after the handover.

1> else:

2> set the 20 MSB of the HFN component of COUNT-C for TM-RLC to the value of the latest transmitted IE "START" or "START List" for this CN domain, while not incrementing the value of the HFN component of COUNT-C at each CFN cycle; and

2> set the remaining LSBs of the HFN component of COUNT-C to zero.

1> start to perform ciphering on the radio bearer in lower layers while not incrementing the HFN;

1> include the IE "COUNT-C activation time" in the response message and specify a CFN value for this IE other than the default, "Now", that is a multiple of 8 frames (CFN mod 8 =0) and lies at least 200 frames ahead of the CFN in which the response message is first transmitted;

1> calculate the START value according to subclause 8.5.9;

1> include the calculated START values for each CN domain in the IE "START list" in the IE "Uplink counter synchronisation info" in the response message;

1> at the CFN value as indicated in the response message in the IE "COUNT-C activation time":

2> set the 20 MSB of the HFN component of the COUNT-C variable common for all transparent mode radio bearers of this CN domain to the START value as indicated in the IE "START list" of the response message for the relevant CN domain; and

2> set the remaining LSBs of the HFN component of COUNT-C to zero;

2> increment the HFN component of the COUNT-C variable by one even if the "COUNT-C activation time" is equal to zero;

2> set the CFN component of the COUNT-C to the value of the IE "COUNT-C activation time" of the response message. The HFN component and the CFN component completely initialise the COUNT-C variable;

2> step the COUNT-C variable, as normal, at each CFN value, i.e. the HFN component is no longer fixed in value but incremented at each CFN cycle.

### 8.6.6.28a Downlink F-DPCH info common for all radio links

If the IE "Downlink F-DPCH info common for all RL" is included the UE shall:

1> if the IE "Downlink F-DPCH info common for all RL" is included in a message used to perform a hard handover:

2> perform actions for the IE "Timing indication" as specified in subclause 8.5.15.2, and subclause 8.3.5.1 or 8.3.5.2.

1> if the IE "Downlink DPCH power control information" is included:

2> perform actions for the IE "DPC Mode" according to [29].

### 8.6.6.29 ASC setting

If the IE "ASC setting" is included, the UE shall:

1> establish the available signatures for this ASC as specified in the following:

2> renumber the list of available signatures specified in the IE "Available signature" included in the IE "PRACH info" from signature index 0 to signature index N-1, where N is the number of available signatures, starting with the lowest available signature number and continuing in sequence, in the order of increasing signature numbers;

2> consider as available signatures for this ASC the signatures included in this renumbered list from the index specified by the IE "Available signature Start Index" to the index specified by the IE "Available signature End Index".

1> establish the available access slot sub-channels for this ASC as specified in the following:

2> if the IE "AICH transmission timing" included in the IE "AICH Info" is set to '0';

3> ignore the leftmost (most significant) bit (bit b3) of the bit string specified by the IE "Assigned Sub-Channel Number";

3> repeat 4 times the 3 rightmost (least significant) bits (bits b2-b0) of the bit string specified by the IE "Assigned Sub-Channel Number" to form a resulting bit string 'b2 b1 b0 b2 b1 b0 b2 b1 b0 b2 b1 b0' of length 12 bits, where the leftmost bit is the most significant.

2> if the IE "AICH transmission timing" included in the IE "AICH Info" is set to '1':

3> repeat 3 times the bit string (bits b3-b0) specified by the IE "Assigned Sub-Channel Number" to form a bit string 'b3 b2 b1 b0 b3 b2 b1 b0 b3 b2 b1 b0' of length 12 bits, where the leftmost bit is the most significant.

2> perform in both cases, for the resulting bit string (that includes the repetitions) bit-wise logical AND operation with the IE "Available Sub Channel number" included in IE "PRACH info (for RACH)";

2> consider as available sub-channels for this ASC the available sub-channels indicated in the resulting bit string, after logical AND operation i.e. each bit set to 1 or 0 indicates availability or non-availability, respectively, of sub-channel number *x*, with *x* from 0 to 11, for the respective ASC.

NOTE 1: In FDD, the list of available signatures is renumbered from signature index 0 to signature index N-1, where N is the number of available signatures, starting with the lowest available signature number and continuing in sequence, in the order of increasing signature numbers.

- List of available signatures: 16 or fewer signatures are available.
- Example: only signatures 0, 5, 10 and 15 are available, then :
- Signature 0 is: available signature index 0
- Signature 5 is: available signature index 1
- Signature 10 is: available signature index 2
- Signature 15 is: available signature index 3

NOTE 2: In 3.84 Mcps TDD, the list of available channelisation codes (defined in PRACH info) is renumbered from channelisation code index 0 to channelisation code index N-1, where N is the number of available channelisation codes, starting with the lowest available channelisation code number and continuing in sequence, in the order of increasing channelisation code numbers

List of available channelisation codes : 8 or less channelisation codes are available.

The i-th bit of the bitmap defined in the IE "Available Channelisation Code indices" defines whether the channelisation code with the available channelisation code index i is to be used for this ASC (bit set means used, bit unset means not used). Only the low N bits shall be used in the bitmap, where N is the number of available channelisation codes defined in PRACH info.

Ex : spreading factor 16, channelisation codes 16/1, 16/2, 16/5, 16/8 are available :

Channelisation code 16/1 is: available channelisation code index 0
Channelisation code 16/2 is: available channelisation code index 1
Channelisation code 16/5 is: available channelisation code index 2
Channelisation code 16/8 is: available channelisation code index 3

Available Channelisation Code indices has the value '00001100' means: Channelisation Codes 16/5 and 16/8 are available for this ASC.

NOTE 2a: In 7.68 Mcps TDD, the list of available channelisation codes (defined in PRACH info) is renumbered from channelisation code index 0 to channelisation code index N-1, where N is the number of available channelisation codes, starting with the lowest available channelisation code number and continuing in sequence, in the order of increasing channelisation code numbers

List of available channelisation codes : 16 or less channelisation codes are available.

The i-th bit of the bitmap defined in the IE "Available Channelisation Code indices" defines whether the channelisation code with the available channelisation code index i is to be used for this ASC (bit set means used, bit unset means not used). Only the low N bits shall be used in the bitmap, where N is the number of available channelisation codes defined in PRACH info.

Ex : spreading factor 32, channelisation codes 32/1, 32/2, 32/5, 32/8 are available :

Channelisation code 32/1 is: available channelisation code index 0
Channelisation code 32/2 is: available channelisation code index 1
Channelisation code 32/5 is: available channelisation code index 2
Channelisation code 32/8 is: available channelisation code index 3

Available Channelisation Code indices has the value '0000000000001100' means: Channelisation Codes 32/5 and 32/8 are available for this ASC.

NOTE 3: In TDD, the subchannel description is found in [33].

NOTE 4: In 1.28 Mcps TDD, the list of available SYNC_UL codes (defined in PRACH info) is numbered from SYNC_UL code index 0 to SYNC_UL code index N-1, where N is the number of available SYNC_UL codes, starting with the lowest available SYNC_UL code number and continuing in sequence, in the order of increasing SYNC_UL code numbers

The i-th bit of the bitmap defined in the IE "Available SYNC_UL codes indices" defines whether the SYNC_UL code with the available SYNC_UL code index i is to be used for this ASC (bit set means used, bit unset means not used). Only the low N bits shall be used in the bitmap, where N is the number of available SYNC_UL codes defined in PRACH info.

- List of available SYNC_UL codes: 8 or fewer SYNC_UL codes are available.

Example: only signatures 0, 5, 6 and 7 are available, then:

- SYNC_UL codes 0 is: available SYNC_UL codes index 0
- SYNC_UL codes 5 is: available SYNC_UL codes index 1
- SYNC_UL codes 6 is: available SYNC_UL codes index 2
- SYNC_UL codes 7 is: available SYNC_UL codes index 3

Available SYNC_UL codes indices has the value '00001100' means: SYNC_UL codes 6 and 7 are available for this ASC.

### 8.6.6.30 SRB delay, PC preamble (FDD only)

When the IE "SRB delay" and IE "PC preamble" is received in a message that results in a configuration of uplink DPCH and synchronisation procedure A is being used as specified in [29], the UE shall:

1> store the received IE "SRB delay" and IE "PC preamble" in the variable LATEST_CONFIGURED_SRB_DELAY_AND_PC_PREAMBLE;

1> apply power control preamble according to [26] during the number of frames indicated in the IE "PC preamble"; and

1> then not send any data on signalling radio bearers RB0 to RB4 during the number of frames indicated in the IE "SRB delay" or while the physical channel is not considered established.

### 8.6.6.31 Void

### 8.6.6.32 Void

### 8.6.6.33 HS-SCCH Info

If the IE "HS-SCCH Info" is included and the UE will be in CELL_DCH state after completion of this procedure, the UE shall:

1> store the received configuration.

1> determine the value for the HS_DSCH_RECEPTION variable and take the corresponding actions as described in subclause 8.5.25.

When the variable HS_DSCH_RECEPTION is set to TRUE the UE shall:

1> in the case of FDD:

2> receive the HS-SCCH(s) according to the IE "HS-SCCH channelisation code" on the serving HS-DSCH radio link applying the scrambling code as received in the IE "DL Scrambling code".

1> in the case of TDD:

2> receive the HS-SCCH(s) according to the IEs "Timeslot Number", "Channelisation Code" and Midamble configuration IEs.

2> transmit the HS-SICH according to the IEs "Timeslot Number", "Channelisation Code" and Midamble configuration IEs.

2> for HS-SCCH power control the UE shall use the "BLER target" signalled in the first occurrence of the "HS-SCCH Set Configuration".

2> in 3.84 Mcps TDD and 7.68 Mcps TDD:

3> use the parameters specified in the IE "HS-SICH power control info" for open loop power control as defined in subclause 8.5.7.

2> in 1.28 Mcps TDD:

3> use the IE " $PRX_{HS-SICH}$ " to calculate and set an initial uplink transmission power;

3> use the IE " TPC step size" upon reception of TPC commands for closed loop power control;

3> use default value of "Uplink synchronisation frequency" and same value of "Uplink synchronisation step size" in "Uplink DPCH info" for HS-SICH upon reception of SS commands for closed loop uplink synchronisation on HS-SICH.

### 8.6.6.34 Measurement Feedback Info

If the IE "Measurement Feedback Info" is included and the UE will be in CELL_DCH state after completion of this procedure, the UE shall:

1> store the received configuration;

1> determine the value for the HS_DSCH_RECEPTION variable and take the corresponding actions as described in subclause 8.5.25.

When the variable HS_DSCH_RECEPTION is set to TRUE the UE shall:

1> use the information for the channel quality indication (CQI) procedure in the physical layer on the serving HS-DSCH radio link.

### 8.6.6.35 DPC Mode

If the IE "DPC Mode" is included, the UE shall:

1> apply the indicated DPC mode according to [29].

If the IE "DPC Mode" is not included, the UE shall:

1> continue with the currently used DPC mode.

### 8.6.6.36 Downlink HS-PDSCH Information

If the IE "Downlink HS-PDSCH Information" is included and the UE would be in CELL_DCH state after completion of this procedure, the UE shall:

1> if the IE "HS-SCCH Info" is included:

2> act as specified in subclause 8.6.6.33.

1> if the IE "Measurement Feedback Info" is included:

2> act as specified in subclause 8.6.6.34.

1> if the IE "HS-DSCH Timeslot Configuration" or "HS-PDSCH Midamble Configuration" is included:

2> store the received configuration;

2> determine the value for the HS_DSCH_RECEPTION variable and take actions as described in subclause 8.5.25.

#### 8.6.6.37 E-DCH Info

If the IE "E-DCH Info" is included and the UE will be in CELL_DCH state after completion of this procedure, the UE shall:

1> if the IE "E-DPCCH Info" is included:

2> store the newly received E-DPCCH configuration.

1> if the IE "E-DPDCH Info" is included:

2> store the newly received E-DPDCH configuration.

NOTE: The UTRAN should ensure the ordering of the E-TFCI table in increasing transmission power, by correct setting of the reference E-TFCI power offsets.

1> if the IE "MAC-es/e reset indicator" is included:

2> reset the MAC-es/e entity [15].

1> determine the value for the E_DCH_TRANSMISSION variable and take the corresponding actions as described in subclause 8.5.28.

When the variable E_DCH_TRANSMISSION is set to TRUE the UE shall:

1> configure the UL E-DPCCH in accordance with the stored IE "E-DPCCH" configuration;

1> configure the MAC with the stored IE "E-DPDCH" configuration and/or the information contained in IE "Scheduled Transmission configuration".

### 8.6.7 Measurement information elements

On reception of measurement information elements the UE shall:

1> store the received information in the variable MEASUREMENT_IDENTITY and CELL_INFO_LIST as specified;

1> perform further actions as specified in subclause 8.6.7 and subclause 8.4, based on the content of the variable MEASUREMENT_IDENTITY.

If a configuration is considered to be invalid the UE may:

1> set the variable CONFIGURATION_INCOMPLETE to TRUE.

#### 8.6.7.1 Measurement validity

If the IE "measurement validity" for a given measurement has not been included in measurement control information, the UE shall delete the measurement associated with the variable MEASUREMENT_IDENTITY after the UE makes a transition to a new state.

If the IE "measurement validity" for this measurement has been included in measurement control information, the UE shall save the measurement associated with the variable MEASUREMENT_IDENTITY. The IE "UE state" defines the scope of resuming the measurement.

If the "UE state" is defined as "all states", the UE shall continue the measurement after making a transition to a new state. This scope is assigned for traffic volume measurement type and UE positioning measurement type. For traffic volume measurement type this scope can only be applied by the UE if the IE " traffic volume measurement object" has been included in measurement control information. If the IE " traffic volume measurement object" has not been included in measurement control information, the UE shall not save the measurement control information in variable MEASUREMENT_IDENTITY, but shall send a MEASUREMENT CONTROL FAILURE message to the UTRAN with failure cause "Configuration incomplete".

If the "UE state" is defined as "all states except CELL_DCH", the UE shall store the measurement to be resumed after a subsequent transition from CELL_DCH state to any of the other states in connected mode. This scope is assigned for traffic volume measurement type or UE positioning measurement type.

If the "UE state" is defined as "CELL_DCH", the UE shall store the measurement to be resumed after a subsequent transition to CELL_DCH state.

If the IE "measurement type" received in a MEASUREMENT CONTROL message is set to "inter-frequency measurement" or "intra-frequency measurement" and the IE "measurement validity" is present and is set to a value other than "CELL_DCH", the UE behaviour is unspecified.

### 8.6.7.2 Filter coefficient

If the IE "Filter coefficient" is received the UE shall, depending on the measurement quantity (see Table 8.6.7.2), apply filtering of the measurements for that measurement quantity according to the formula below. This filtering shall be performed by the UE before UE event evaluation. The UE shall depending on the reporting quantity (see Table 8.6.7.2), also filter the measurements reported in the IE "Measured results". The filtering shall not be performed for the measurements reported in the IE "Measured results on RACH" and for cell-reselection in connected or idle mode.

The filtering shall be performed according to the following formula.

$$F_n = (1-a) \cdot F_{n-1} + a \cdot M_n$$

The variables in the formula are defined as follows:

$F_n$ is the updated filtered measurement result

$F_{n-1}$ is the old filtered measurement result

$M_n$ is the latest received measurement result from physical layer measurements, the unit used for $M_n$ is the same unit as the reported unit in the MEASUREMENT REPORT message or the unit used in the event evaluation.

$a = 1/2^{(k/2)}$, where k is the parameter received in the IE "Filter coefficient".

NOTE: if $k$ is set to 0 that will mean no layer 3 filtering.

In order to initialise the averaging filter, $F_0$ is set to $M_1$ when the first measurement result from the physical layer measurement is received.

The physical layer measurement results are sampled once every measurement period. The measurement period and the accuracy for a certain measurement is defined in [19] and [20].

Table 8.6.7.2 lists for all measurement quantities and reporting quantities if L3-filtering is applicable or not and used L3-filtering type for each measurement quantity.

**Table 8.6.7.2: L3 filtering applicable for each measurement quantity and reporting quantity**

| Measurement- / Reporting quantity | L3-filtering applicable | Linear or logarithmic filtering | Comment |
|---|---|---|---|
| Pathloss | Yes | Log | |
| Cell synchronisation information | No | - | |
| Cell Identity | No | - | |
| Frequency quality estimate | No | - | Although the frequency quality estimate itself is not filtered, the inputs to the frequency quality estimate calculation (CPICH Ec/N0 or CPICH RSCP or P-CCPCH RSCP) are filtered |
| UTRA carrier RSSI | Yes | Log | |
| GSM carrier RSSI | Yes | Log | |
| UE transmitted power | Yes | Log | |
| FDD | | | |

| | | | |
|---|---|---|---|
| > UE Rx-Tx time difference | No | - | |
| > CPICH Ec/N0 | Yes | Log | |
| > CPICH RSCP | Yes | Log | |
| TDD | | | |
| > Primary CCPCH RSCP | Yes | Log | |
| > Proposed TGSN | No | - | |
| > Timeslot ISCP | Yes | Log | |
| > TADV (1.28 Mcps TDD) | No | - | |
| > Applied TA (3.84 Mcps TDD) | No | - | |
| > Applied TA (7.68 Mcps TDD) | No | - | |

The UE shall support 2 different layer 3 filters per measurement type defined in subclause 8.4.0 (i.e. the UE shall be capable to apply at least 2 different L3 filters to intra-frequency measurement results, at least 2 different L3 filters to inter-frequency measurement results, etc.). If a MEASUREMENT CONTROL message is received that would require the UE to configure more than 2 different layer 3 filters, the UE may:

1> set the variable CONFIGURATION_INCOMPLETE to TRUE.

### 8.6.7.3 Intra-frequency/Inter-frequency/Inter-RAT cell info list

If the IE "Intra-frequency cell info list" is received in System Information Block Type 11, the UE shall update the variable CELL_INFO_LIST accordingly and in the following order. The UE shall:

1> if the IE "Intra-frequency cell removal" is received:

2> ignore the IE.

1> if the IE "New Intra-frequency cells" is received, for each cell, and in the same order as the cells appear in the IE:

2> update the variable CELL_INFO_LIST as follows:

3> if the IE "Intra-frequency cell id" is received:

4> store received cell information at this position in the Intra-frequency cell info list in the variable CELL_INFO_LIST, possibly overwriting any existing information in this position; and

4> mark the position "occupied".

3> if the IE "Intra-frequency cell id" is not received:

4> store the received cell information at the first vacant position in ascending order in the Intra-frequency cell info list in the variable CELL_INFO_LIST; and

4> mark the position as "occupied".

If the IE "Intra-frequency cell info list" is received in System Information Block Type 12, the UE shall update the variable CELL_INFO_LIST accordingly and in the following order. The UE shall:

1> if the IE "Intra-frequency cell removal" is received:

2> if it has the value "Remove some intra-frequency cells", at the position indicated by the IE "Intra-frequency cell id":

3> clear the cell information stored in the variable CELL_INFO_LIST; and

3> mark the position "vacant".

2> if it has the value "Remove all intra-frequency cells":

3> for each position referring to an intra-frequency cell in the variable CELL_INFO_LIST:

4> clear the cell information stored in the variable CELL_INFO_LIST; and

4> mark the position "vacant".

2> if it has the value "Remove no intra-frequency cells":

3> leave the variable CELL_INFO_LIST unchanged.

1> if the IE "New Intra-frequency cells" is received, for each cell, and in the same order as the cells appear in the IE:

2> update the variable CELL_INFO_LIST as follows:

3> if the IE "Intra-frequency cell id" is received:

4> store received cell information at this position in the Intra-frequency cell info list in the variable CELL_INFO_LIST, possibly overwriting any existing information in this position; and

4> mark the position "occupied".

3> if the IE "Intra-frequency cell id" is not received:

4> store the received cell information at the first vacant position in ascending order in the Intra-frequency cell info list in the variable CELL_INFO_LIST; and

4> mark the position as "occupied".

If the IE "Intra-frequency cell info list" is received in a MEASUREMENT CONTROL message, the UE shall update the variable CELL_INFO_LIST accordingly and in the following order. The UE shall:

1> if the CHOICE "Intra-frequency cell removal" is received:

2> if it has the value "Remove some intra-frequency cells", at the position indicated by the IE "Intra-frequency cell id":

3> clear the cell information stored in the variable CELL_INFO_LIST; and

3> mark the position "vacant".

2> if it has the value "Remove all intra-frequency cells":

3> for each position referring to an intra-frequency cell in the variable CELL_INFO_LIST:

4> clear the cell information stored in the variable CELL_INFO_LIST; and

4> mark the position "vacant".

2> if it has the value "Remove no intra-frequency cells":

3> leave the variable CELL_INFO_LIST unchanged.

1> if the IE "New Intra-frequency cells" is received, for each cell, and in the same order as the cells appear in the IE:

2> update the variable CELL_INFO_LIST as follows:

3> if the IE "Intra-frequency cell id" is received:

4> store received cell information at this position in the Intra-frequency cell info list in the variable CELL_INFO_LIST, possibly overwriting any existing information in this position; and

4> mark the position "occupied".

3> if the IE "Intra-frequency cell id" is not received:

4> store the received cell information at the first vacant position in ascending order in the Intra-frequency cell info list in the variable CELL_INFO_LIST; and

4> mark the position as "occupied".

1> if the IE "Cells for measurement" is received, in the measurement configured by this message only:

2> consider Intra-frequency cells whose cell information is stored at the position indicated by the IE "Intra-frequency cell id" in the variable CELL_INFO_LIST.

1> if the IE "Cells for measurement" is not received, in the measurement configured by this message:

2> consider all Intra-frequency cells whose cell information is stored in CELL_INFO_LIST.

If the IE "Inter-frequency cell info list" is received in System Information Block Type 11 update the variable CELL_INFO_LIST accordingly and in the following order. The UE shall:

1> if the IE "Inter-frequency cell removal" is received:

2> ignore the IE.

1> if the IE "New Inter-frequency cells" is received, for each cell, and in the same order as the cells appear in the IE:

2> update the variable CELL_INFO_LIST as follows:

3> if the IE "Inter-frequency cell id" is received:

4> store received cell information at this position in the Inter-frequency cell info list in the variable CELL_INFO_LIST, possibly overwriting any existing information in this position; and

4> mark the position "occupied".

3> if the IE "Inter-frequency cell id" is not received:

4> store the received cell information at the first vacant position in ascending order in the Inter-frequency cell info list in the variable CELL_INFO_LIST; and

4> mark the position as "occupied".

If the IE "Inter-frequency cell info list" is received in System Information Block Type 12, the UE shall update the variable CELL_INFO_LIST accordingly and in the following order. The UE shall:

1> if the CHOICE "Inter-frequency cell removal" is received:

2> if it has the value "Remove some inter-frequency cells", at the position indicated by the IE "Inter-frequency cell id":

3> clear the cell information stored in the variable CELL_INFO_LIST; and

3> mark the position "vacant".

2> if it has the value "Remove all inter-frequency cells":

3> for each position referring to an inter-frequency cell in the variable CELL_INFO_LIST:

4> clear the cell information stored in the variable CELL_INFO_LIST; and

4> mark the position "vacant".

2> if it has the value "Remove no inter-frequency cells":

3> leave the variable CELL_INFO_LIST unchanged.

1> if the IE "New Inter-frequency cells" is received, for each cell, and in the same order as the cells appear in the IE:

2> update the variable CELL_INFO_LIST as follows:

3> if the IE "Inter-frequency cell id" is received:

4> store received cell information at this position in the Inter-frequency cell info list in the variable CELL_INFO_LIST, possibly overwriting any existing information in this position; and

4> mark the position "occupied".

3> if the IE "Inter-frequency cell id" is not received:

4> store the received cell information at the first vacant position in ascending order in the Inter-frequency cell info list in the variable CELL_INFO_LIST; and

4> mark the position as "occupied".

If the IE "Inter-frequency cell info list" is received in a MEASUREMENT CONTROL message, the UE shall update the variable CELL_INFO_LIST accordingly and in the following order:

1> if the CHOICE "Inter-frequency cell removal" is received:

2> if it has the value "Remove some inter-frequency cells", at the position indicated by the IE "Inter-frequency cell id":

3> clear the cell information stored in the variable CELL_INFO_LIST; and

3> mark the position "vacant".

2> if it has the value "Remove all inter-frequency cells":

3> for each position referring to an inter-frequency cell in the variable CELL_INFO_LIST:

4> clear the cell information stored in the variable CELL_INFO_LIST; and

4> mark the position "vacant".

2> if it has the value "Remove no inter-frequency cells":

3> leave the variable CELL_INFO_LIST unchanged.

1> if the IE "New Inter-frequency cells" is received, for each cell, and in the same order as the cells appear in the IE:

2> update the variable CELL_INFO_LIST as follows:

3> if the IE "Inter-frequency cell id" is received:

4> store received cell information at this position in the Inter-frequency cell info list in the variable CELL_INFO_LIST, possibly overwriting any existing information in this position; and

4> mark the position "occupied".

3> if the IE "Inter-frequency cell id" is not received:

4> store the received cell information at the first vacant position in ascending order in the Inter-frequency cell info list in the variable CELL_INFO_LIST; and

4> mark the position as "occupied".

1> if the IE "Cells for measurement" is received, in the measurement configured by this message only:

2> consider Inter-frequency cells whose cell information is stored at the position indicated by the IE "Inter-frequency cell id" in the variable CELL_INFO_LIST.

1> if the IE "Cells for measurement" is not received, in the measurement configured by this message:

2> consider all Inter-frequency cells whose cell information is stored in CELL_INFO_LIST.

If the IE "Inter-RAT cell info list" is received in System Information Block Type 11, the UE shall update the variable CELL_INFO_LIST accordingly and in the following order. The UE shall:

1> ignore the IE "Inter-RAT cell removal".

1> if the IE "New Inter-RAT cells" is received, for each cell, and in the same order as the cells appear in the IE:

2> if the IE "Radio Access Technology" is set to "None":

3> ignore the cell.

2> otherwise:

3> update the variable CELL_INFO_LIST as follows:

4> if the IE "Inter-RAT cell id" is received:

5> store received cell information at this position in the Inter-RAT cell info list in the variable CELL_INFO_LIST, possibly overwriting any existing information in this position; and

5> mark the position "occupied".

4> if the IE "Inter-RAT cell id" is not received:

5> store the received cell information at the first vacant position in ascending order in the Inter-RAT cell info list in the variable CELL_INFO_LIST; and

5> mark the position as "occupied".

1> if the IE "Cells for measurement" is received:

2> ignore the IE;

2> set the "Inter-RAT cell info indication" to the value "0" and mark the indication status "present" in the variable CELL_INFO_LIST.

If the IE "Inter-RAT cell info list" is received in System Information Block Type 12, the UE shall update the variable CELL_INFO_LIST accordingly and in the following order. The UE shall:

1> if the IE "Inter-RAT cell removal" is received:

2> if it has the value "Remove some inter-RAT cells", at the position indicated by the IE "Inter-RAT cell id":

3> clear the cell information stored in the variable CELL_INFO_LIST; and

3> mark the position "vacant".

2> if it has the value "Remove all inter-RAT cells":

3> for each position referring to an inter-RAT cell in the variable CELL_INFO_LIST:

4> clear the cell information stored in the variable CELL_INFO_LIST; and

4> mark the position "vacant".

2> if it has the value "Remove no inter-RAT cells":

3> leave the variable CELL_INFO_LIST unchanged.

1> if the IE "New Inter-RAT cells" is received, for each cell, and in the same order as the cells appear in the IE:

2> if the IE "Radio Access Technology" is set to "None":

3> ignore the cell.

2> otherwise:

3> update the variable CELL_INFO_LIST as follows:

4> if the IE "Inter-RAT cell id" is received:

5> store received cell information at this position in the Inter-RAT cell info list in the variable CELL_INFO_LIST, possibly overwriting any existing information in this position; and

5> mark the position "occupied".

4> if the IE "Inter-RAT cell id" is not received:

5> store the received cell information at the first vacant position in ascending order in the Inter-RAT cell info list in the variable CELL_INFO_LIST; and

5> mark the position as "occupied".

1> if the IE "Cells for measurement" is received:

2> ignore the IE;

1> set the "Inter-RAT cell info indication" to the value "0" and mark the indication status "present" in the variable CELL_INFO_LIST.

If the IE "Inter-RAT cell info list" is received in a MEASUREMENT CONTROL message, the UE shall update the variable CELL_INFO_LIST accordingly and in the following order. The UE shall:

1> if the IE "Inter-RAT cell removal" is received:

2> if it has the value "Remove some inter-RAT cells", at the position indicated by the IE "Inter-RAT cell id":

3> clear the cell information stored in the variable CELL_INFO_LIST; and

3> mark the position "vacant".

2> if it has the value "Remove all inter-RAT cells":

3> for each position referring to an inter RAT cell in the variable CELL_INFO_LIST:

4> clear the cell information stored in the variable CELL_INFO_LIST; and

4> mark the position "vacant".

2> if it has the value "Remove no inter-RAT cells":

3> leave the variable CELL_INFO_LIST unchanged.

1> if the IE "New Inter-RAT cells" is received, for each cell, and in the same order as the cells appear in the IE:

2> if the IE "Radio Access Technology" is set to "None":

3> ignore the cell.

2> otherwise:

3> update the variable CELL_INFO_LIST as follows:

4> if the IE "Inter-RAT cell id" is received:

5> store received cell information at this position in the Inter-RAT cell info list in the variable CELL_INFO_LIST, possibly overwriting any existing information in this position; and

5> mark the position "occupied".

4> if the IE "Inter-RAT cell id" is not received:

5> store the received cell information at the first vacant position in ascending order in the Inter-RAT cell info list in the variable CELL_INFO_LIST; and

5> mark the position as "occupied".

1> if the IE "Cells for measurement" is received, in the measurement configured by this message only:

2> consider Inter-RAT cells whose cell information is stored at the position indicated by the IE "Inter-RAT cell id" in the variable CELL_INFO_LIST.

1> if the IE "Cells for measurement" is not received, in the measurement configured by this message:

2> consider all Inter-RAT cells whose cell information is stored in CELL_INFO_LIST.

1> if the IE "Cell selection and re-selection info for SIB11/12" is present:

2> ignore the IE.

1> if the IE "Inter-RAT cell info indication" is present:

2> store the received value of the IE "Inter-RAT cell info indication" and mark the indication status "present" in the variable CELL_INFO_LIST.

1> if the IE "Inter-RAT cell info indication" is not present:

2> clear the "Inter-RAT cell info indication" and mark the indication status "not present" in the variable CELL_INFO_LIST.

### 8.6.7.4 Intra-frequency measurement quantity

If the IE "Intra-frequency measurement quantity" is received in a MEASUREMENT CONTROL message, the UE shall:

1> if the IE "Measurement quantity" is set to "pathloss"; and

1> for any intra-frequency cell indicated by the IE "Cells for measurement", the IE "Primary CPICH Tx power" in FDD or the IE "Primary CCPCH TX Power" in TDD in the intra frequency cell info list in the variable CELL_INFO_LIST is not present:

2> set the variable CONFIGURATION_INCOMPLETE to TRUE.

1> else:

2> configure the measurement quantity accordingly.

### 8.6.7.5 Inter-RAT measurement quantity

If the IE "Inter-RAT measurement quantity" is received in a MEASUREMENT CONTROL message and CHOICE system is GSM, the UE shall:

1> if IE "BSIC verification required" is set to "required", for cells that match any of the BCCH ARFCN and BSIC combinations in the list of inter-RAT cells that the UE has received in IE "Inter-RAT cell info list", and that has a "verified" BSIC:

2> report measurement quantities according to IE "inter-RAT reporting quantity" taking into account the restrictions defined in subclause 8.6.7.6;

2> trigger inter-RAT events according to IE "inter-RAT measurement reporting criteria"; and

2> perform event evaluation for event-triggered reporting after BSIC has been verified for a GSM cell as defined in [19]; and

2> trigger periodical reports according to the given "Reporting interval"; and

2> when a periodical measurement report is triggered, include only BSIC verified GSM cells in the IE "Inter-RAT measured results list"; and

3> indicate verified BSIC for a GSM cell in the IE "Inter-RAT measured results list" as defined in subclause 8.6.7.6.

2> when an event triggered measurement report is triggered, include only BSIC verified GSM cells in the IE "Inter-RAT measured results list"; and

3> indicate verified BSIC for a GSM cell in the IE "Inter-RAT measured results list" as defined in subclause 8.6.7.6.

1> if IE "BSIC verification required" is set to "not required", for cells that match any of the BCCH ARFCN in the list of inter-RAT cells that the UE has received in IE "Inter-RAT cell info list", regardless if the BSIC is "verified" or "non-verified":

2> report measurement quantities according to IE "inter-RAT reporting quantity";

2> trigger inter-RAT events according to IE "inter-RAT measurement reporting criteria";

2> when an event triggered or periodical measurement report is triggered, include GSM cells in the IE "Inter-RAT measured results list" regardless of whether the BSIC of the GSM cell has been verified or not; and

3> for any GSM cell that has not been verified, indicate non-verified BSIC for a GSM cell in the "Inter-RAT measured results list" IE as defined in subclause 8.6.7.6.

3> for any GSM cell that has been verified, indicate verified BSIC for a GSM cell in the "Inter-RAT measured results list" IE as defined in subclause 8.6.7.6.

1> if the IE "Measurement quantity" is set to "pathloss":

2> set the variable CONFIGURATION_INCOMPLETE to TRUE.

NOTE: The requirements for a cell to be considered "verified" or "non-verified" can be found in [19].

### 8.6.7.6 Inter-RAT reporting quantity

If the IE "Inter-RAT reporting quantity" is received by the UE, the UE shall:

1> store the content of the IE to the variable MEASUREMENT_IDENTITY.

If the IE "Inter-RAT measurement quantity" is received and CHOICE system is GSM, the UE shall check each quantity in the GSM choice. The UE shall include measured results in MEASUREMENT REPORT as specified in the IE "Inter-RAT reporting quantity" with the following restrictions:

1> if the UE has not confirmed the BSIC of the measured cell:

2> if no compressed mode pattern sequence specified with measurement purpose "Initial BSIC identification" is active and according to its capabilities the UE requires compressed mode to measure this, the UE is not required to include the "inter-RAT cell id" in the IE "Inter-RAT measured results list", when a MEASUREMENT REPORT is triggered.

1> if the UE has confirmed the BSIC of the measured cell, then:

2> if no compressed mode pattern sequence specified with measurement purpose "Initial BSIC identification" nor "BSIC re-confirmation" is active and according to its capabilities the UE requires compressed mode to measure this, the UE is not required to include the "inter-RAT cell id" in the IE "Inter-RAT measured results", when a MEASUREMENT REPORT is triggered. If no compressed mode pattern sequence with measurement purpose "GSM carrier RSSI measurements" is active and according to its capabilities the UE requires compressed mode to measure this, the UE may include "inter-RAT cell id" in MEASUMENT REPORT without "GSM carrier RSSI" even if it is defined in the IE "Inter-RAT reporting quantity".

1> if the IE "UTRAN estimated quality" is set to "TRUE":

2> ignore that IE.

1> if IE "GSM Carrier RSSI" is set to "TRUE":

2> include optional IE "GSM Carrier RSSI" with a value set to the measured RXLEV to that GSM cell in IE "Inter-RAT measured results list". If no compressed mode pattern sequence specified with measurement purpose "GSM carrier RSSI measurements" is active and according to its capabilities the UE requires compressed mode to measure this, the UE is not required to include the "GSM carrier RSSI" in the IE " Inter-RAT measured results list ", when a MEASUREMENT REPORT is triggered.

1> if the BSIC of reported GSM cell is "verified":

2> set the CHOICE BSIC to "Verified BSIC" and IE "inter-RAT cell id" to the value that GSM cell had in the IE "Inter-RAT cell info list".

1> if the BSIC of reported GSM cell is "non-verified":

2> set the CHOICE BSIC to "Non verified BSIC" and the IE "BCCH ARFCN" to the value of that GSM cells ARFCN.

The requirements for a cell to be considered "verified" or "non-verified" can be found in [19].

### 8.6.7.7 Cell Reporting Quantities

If the IE "Cell Reporting Quantities" is received by the UE, the UE shall store the content of the IE "Cell Reporting Quantities" to the variable MEASUREMENT_IDENTITY.

The UE shall include measured results in MEASUREMENT REPORT as specified in the IE "Cell Reporting Quantities", except for the following cases:

If the IE "Cell Identity" is set to TRUE, the UE shall in this version of the specification:

1> treat the IE as if the IE "Cell Identity" is set to FALSE.

If the IE "Cell synchronisation information reporting indicator" is set to TRUE, the UE shall:

1> include the IE "Cell synchronisation information" in MEASUREMENT REPORT as specified in the IE "Cell Reporting Quantities":

2> if the measurement is performed on another frequency; or

2> if the IE "Read SFN indicator" included in the IE "Cell info" of the measured cell is set to FALSE:

3> the UE may omit the information group "COUNT-C-SFN frame difference" in the IE "Cell synchronisation information".

2> if the measurement is performed on the same frequency and no RLC Transparent Mode COUNT-C exists in the UE:

3> set the IE "COUNT-C-SFN high" to 0.

2> otherwise:

3> include the information group "COUNT-C-SFN frame difference" with IE "COUNT-C-SFN high" set to:

COUNT-C-SFN high = (((SFN - (COUNT-C mod 4096)) mod 4096) div 256) * 256;

3> if RLC Transparent Mode COUNT-Cs exist in both CN domains:

4> use the COUNT-C of CS domain in this measurement.

If the IE "Proposed TGSN Reporting required" is set to TRUE, the UE shall:

1> if compressed mode was used to monitor a TDD cell and the variable TGSN_REPORTED is set to FALSE:

2> report the IE "Proposed TGSN" indicating the TGSN that suits best to the measured cell;

2> set the variable TGSN_REPORTED to TRUE.

1> otherwise

2> omit the IE "Proposed TGSN".

### 8.6.7.8 Periodical Reporting Criteria

If the IE "Periodical Reporting Criteria" is received by the UE, the UE shall:

1> store the contents of the IE "Amount of Reporting" and IE "Reporting interval" in the variable MEASUREMENT_IDENTITY.

For the first MEASUREMENT REPORT message, the UE shall:

1> send the MEASUREMENT REPORT as soon as all requested reporting quantities are available according to the requirements and the measurement capabilities set in [19] and [20] for at least one measurement object stored in the variable MEASUREMENT_IDENTITY, but never later than one reporting interval after measurement initiation.

Following the first MEASUREMENT REPORT message, the UE shall:

1> send a MEASUREMENT REPORT message one reporting interval after the previous MEASUREMENT REPORT message;

The first and subsequent periodic MEASUREMENT REPORT messages shall only include measured results for reporting quantities that are available according to the requirements and the measurement capabilities set in [19] and [20] i.e. if no measured results are available and the measurement type is not UE positioning, the IE "Measured Results" shall not be included in the MEASUREMENT REPORT message. If no measured results are available and the measurement type is UE positioning, the UE shall include the IE "Measured Results" in the MEASUREMENT REPORT message in order to include the IE "UE positioning error" as specified in 8.6.7.19a and 8.6.7.19b.

After the UE has sent a total number of MEASUREMENT REPORT messages, which equal the value indicated in the IE "Amount of reporting", the UE shall:

1> terminate measurement reporting; and

1> delete all measurement information linked with the "Measurement identity" of the ongoing measurement from the variable MEASUREMENT_IDENTITY.

If according to subclause 8.6.7.19.1a or 8.6.7.19.1b, a UE configured with a UE positioning measurement is unable to report the requested measurement results due to missing GPS assistance data and sends a MEASUREMENT REPORT containing the IE "UE positioning error" and the IE "Error reason" is set to "Assistance Data Missing", then this is not counted in the total number of MEASUREMENT REPORT messages sent.

### 8.6.7.9 Reporting Cell Status

If the IE "Reporting Cell Status" is received, the UE shall set the IE "Measured Results" in MEASUREMENT REPORT as follows. The UE shall:

1> for intra-frequency measurement and inter-frequency measurement:

2> include the IE "Cell Measured Results" for cells (excluding cells of another RAT) that satisfy the condition (such as "Report cells within active set") specified in the IE "Reporting Cell Status", in descending order by the measurement quantity.

2> the maximum number of the IE "Cell Measured Results" to be included in the IE "Measured Results" per reported frequency is the number specified in the IE "Reporting Cell Status".

1> for periodic inter-frequency measurement:

2> include in the IE "Inter-frequency measured results list" the measured results for all non-used frequencies.

1> for inter-RAT measurement:

2> include the measurement results for cells of other RAT (e.g., GSM) that satisfy the condition specified in the IE "Reporting Cell Status", in descending order by the measurement quantity.

2> the maximum number of the IE "Measured GSM Cells" to be included in the IE "Measured Results" is the number specified in the IE "Reporting Cell Status".

If the IE "Reporting Cell Status" is not received for intra-frequency, inter-frequency measurement, or inter-RAT measurement, the UE shall:

1> for intra-frequency measurement, inter-frequency measurement and inter-RAT measurement:

2> exclude the IE "Measured Results" in MEASUREMENT REPORT.

NOTE: The IE "Reporting Cell Status" within "Event Criteria List" defines whether "Cell Measured Results" is present for event-based reporting.

The IE "Reporting Cell Status" is not included in System Information Block 11/12 for periodic intra-frequency measurements. In this case the UE shall assume the default values "Report cells within active set and/or monitored set on used frequency " and "6".

### 8.6.7.10 Traffic Volume Measurement

If the IE "Traffic Volume Measurement" is received by the UE, the UE shall:

1> store the content of the IE to the variable MEASUREMENT_IDENTITY.

If IE "Traffic volume measurement" is received by the UE in a MEASUREMENT CONTROL message, where IE "measurement command" has the value "setup", and if the IE "traffic volume reporting quantity" is included, the UE shall:

1> if the parameter "Average of RLC Buffer Payload for each RB" or the parameter "Variance of RLC Buffer payload for each RB" is set to "TRUE":

2> if the IE "Traffic volume measurement quantity" is not included:

3> set the variable CONFIGURATION_INCOMPLETE to TRUE.

2> if the IE "Traffic volume measurement quantity" is included:

3> if the parameter "time interval to take an average or a variance" is not included:

4> set the variable CONFIGURATION_INCOMPLETE to TRUE.

If IE "Traffic volume measurement" is received by the UE in a MEASUREMENT CONTROL message, where IE "measurement command" has the value "setup", but IE "Traffic volume reporting quantity" or is not received, the UE shall:

1> set the variable CONFIGURATION_INCOMPLETE to TRUE.

### 8.6.7.11 Traffic Volume Measurement Reporting Criteria

If the IE "Traffic Volume Measurement Reporting Criteria" is received by the UE, the UE shall:

1> if the IE "Parameters sent for each transport channel" is absent:

2> set the variable PROTOCOL_ERROR_REJECT to TRUE;

2> set the IE "Protocol error cause" in the variable PROTOCOL_ERROR_INFORMATION to "Information element missing".

1> for each IE "Parameters sent for each transport channel":

2> if the IE "Parameters required for each Event" is absent:

3> set the variable CONFIGURATION_INCOMPLETE to TRUE.

### 8.6.7.12 FACH measurement occasion info

IE "FACH measurement occasion info" is used to control UE measurement activities in inter-frequency and inter-RAT cells in CELL_FACH state.

If IE "FACH measurement occasion info" is received, UE shall, when in CELL_FACH state:

1> if IE "FACH Measurement occasion cycle length coefficient" is included:

2> if, according to its measurement capabilities, UE is not able to perform some of the indicated measurements in this IE simultaneously as receiving the SCCPCH of serving cell:

3> perform those measurements during FACH measurement occasions, see subclause 8.5.11.

2> if, according to its measurement capabilities, UE is able to perform some of the indicated measurements in this IE simultaneously as receiving the SCCPCH of serving cell:

3> UE may perform measurements also on other occasions.

2> if, according to its measurement capabilities, UE is able to perform the measurements and indicated in this IE simultaneously as receiving the SCCPCH of serving cell:

3> perform the measurements simultaneously as receiving the SCCPCH of serving cell.

1> if IE "FACH Measurement occasion cycle length coefficient" is not included:

2> perform those indicated measurements indicated in this IE that UE, according to its measurement capabilities, is able to perform simultaneously as receiving the SCCPCH of serving cell.

1> if IE "Inter-frequency FDD measurement indicator" is set to TRUE:

2> perform measurements and evaluate cell re-selection criteria according to [4] on inter-frequency FDD cells listed in IE "Measurement control system information" in "System Information Block type 11" or "System Information Block type 12".

1> if IE "Inter-frequency FDD measurement indicator" is set to FALSE:

2> neither perform measurements nor evaluate cell re-selection criteria on inter-frequency FDD cells.

1> if IE "Inter-frequency TDD measurement indicator" is set to TRUE:

2> perform measurements and evaluate cell re-selection criteria according to [4] on inter-frequency TDD cells listed in IE "Measurement control system information" in "System Information Block type 11" or "System Information Block type 12".

1> if IE "Inter-frequency TDD measurement indicator" is set to FALSE:

2> neither perform measurements nor evaluate cell re-selection criteria on inter-frequency TDD cells.

1> if IE "Inter-RAT measurement indicators" is included:

2> perform measurements and evaluate cell re-selection criteria according to [4] on those cells of listed Inter-RAT types that are present in IE "Measurement control system information" in "System Information Block type 11" or "System Information Block type 12".

### 8.6.7.13 Measurement Reporting Mode

If IE "Measurement Reporting Mode" is received by the UE, the UE shall:

1> store the contents of the IE "Measurement Report Transfer Mode" in the variable MEASUREMENT_IDENTITY;

1> use the indicated RLC mode when sending MEASUREMENT REPORT message(s) related to this measurement;

1> ignore IE "Periodical Reporting / Event Trigger Reporting Mode".

If IE "Measurement Reporting Mode" is not received by the UE in MEASUREMENT CONTROL message, where IE "measurement command" has the value "setup", the UE shall:

1> clear all stored measurement control information related associated to this measurement identity in variable MEASUREMENT_IDENTITY;

1> set the variable CONFIGURATION_INCOMPLETE to TRUE.

### 8.6.7.14 Inter-frequency measurement

If the Inter-frequency cell info list, included in the variable CELL_INFO_LIST, includes a number (M) of frequencies that is larger than the number (N) considered in a UE performance requirement defined in [19] and [20]:

1> the UE shall:

2> meet this performance requirement on the first relevant (N) frequencies, according to the order defined by the position of the frequencies in the Inter-frequency cell info list, included in the variable CELL_INFO_LIST.

1> the UE may:

2> ignore the remaining (M-N) frequencies.

If IE "Inter-frequency measurement" is received by the UE in a MEASUREMENT CONTROL message, where IE "measurement command" has the value "setup", but IE "Inter-frequency measurement quantity", IE "Inter-frequency reporting quantity" or IE "parameters required for each event" (given "CHOICE Report criteria" is set to "inter-frequency measurement reporting criteria") is not received, the UE shall:

1> clear all stored measurement control information related associated to this measurement identity in variable MEASUREMENT_IDENTITY;

1> set the variable CONFIGURATION_INCOMPLETE to TRUE.

If IE "Inter-frequency measurement" is received by the UE in a MEASUREMENT CONTROL message, where IE "measurement command" has the value "modify":

1> if CHOICE "Report criteria" in IE "Inter-frequency measurement" is set to "intra-frequency measurement reporting criteria" and IE "parameters required for each event" is present:

2> the UE behaviour is unspecified.

If IE "Inter-frequency measurement" is received by the UE in a MEASUREMENT CONTROL message, where IE "measurement command" has the value "setup" and CHOICE "Report criteria" in IE "Inter-frequency measurement" is set to "intra-frequency measurement reporting criteria":

1> the UE behaviour is unspecified.

In the case of an inter-frequency measurement for FDD, the UE shall:

1> if IE "Inter-frequency measurement" is received by the UE in a MEASUREMENT CONTROL message, where IE "measurement command" has the value "setup", if an inter-frequency event is configured that is different from event 2d or 2f, and if the IE "Inter-frequency SET UPDATE" is not received in that same message:

2> set the variable CONFIGURATION_INCOMPLETE to TRUE.

If IE "Inter-frequency measurement" is received by the UE in a MEASUREMENT CONTROL message:

1> if CHOICE "Report criteria" is set to "inter-frequency measurement reporting criteria" and CHOICE "reporting criteria" in "inter-frequency measurement quantity" is not set to "inter-frequency reporting criteria"; or

1> if CHOICE "Report criteria" is set to "intra-frequency measurement reporting criteria" and CHOICE "reporting criteria" in "inter-frequency measurement quantity" is not set to "intra-frequency reporting criteria":

2> the UE behaviour is not specified.

If the variable CONFIGURATION_INCOMPLETE is set to TRUE, the UE shall:

1> act as described in subclause 8.4.1.4a.

### 8.6.7.15 Inter-RAT measurement

If the Inter-RAT cell info list, included in the variable CELL_INFO_LIST, includes a number (M) of frequencies that is larger than the number (N) considered in a UE performance requirement defined in [19] and [20]:

1> the UE shall:

2> meet this performance requirement on the first relevant (N) frequencies, according to the order defined by the position of the frequencies in the Inter-RAT cell info list, included in the variable CELL_INFO_LIST.

1> the UE may:

2> ignore the remaining (M-N) frequencies.

If IE "Inter-RAT measurement" is received by the UE in a MEASUREMENT CONTROL message, where IE "measurement command" has the value "setup", but IE "Inter-RAT measurement quantity", IE "Inter-RAT reporting quantity" or "parameters required for each event" (given "CHOICE Report criteria" is set to "inter-RAT measurement reporting criteria") is not received, the UE shall:

1> clear all stored measurement control information related associated to this measurement identity in variable MEASUREMENT_IDENTITY;

1> set the variable CONFIGURATION_INCOMPLETE to TRUE.

### 8.6.7.16 Intra-frequency measurement

If IE "Intra-frequency measurement" is received by the UE in a MEASUREMENT CONTROL message, where IE "measurement command" has the value "setup", but IE "Intra-frequency measurement quantity", IE "Intra-frequency reporting quantity", "CHOICE Report criteria" or "parameters required for each event" (given "CHOICE report criteria" is set to "intra-frequency measurement reporting criteria") is not received, the UE shall:

1> clear all stored measurement control information related associated to this measurement identity in variable MEASUREMENT_IDENTITY;

1> set the variable CONFIGURATION_INCOMPLETE to TRUE.

In case of 1a or 1e event-triggered reporting:

1> if the IE "Intra-frequency measurement quantity" is set to "pathloss", the UE shall:

2> if detected set cells are indicated as possibly triggering the event within the IEs "Triggering condition 2" :

3> set the variable CONFIGURATION_INCOMPLETE to TRUE.

### 8.6.7.17 Quality measurement

If IE "Quality measurement" is received by the UE in a MEASUREMENT CONTROL message, where IE "measurement command" has the value "setup", but IE "Quality reporting quantity" is not received, the UE shall:

1> clear all stored measurement control information related associated to this measurement identity in variable MEASUREMENT_IDENTITY;

1> set the variable CONFIGURATION_INCOMPLETE to TRUE.

If Transport Channel BLER reporting is requested in IE "Quality Reporting Quantity", but no transport channels are explicitly referenced with transport channel identities, the UE shall

1> report BLER for all downlink transport channels, for which Transport Channel BLER is defined and can be requested [7, 8].

If a transport channel, for which Transport Channel BLER is not defined and can not be requested [7, 8], is referenced with a transport channel identity in IE "Quality Reporting Quantity" and/or IE "Quality Measurement Reporting Criteria":

1> the UE behaviour is not specified.

### 8.6.7.18 UE internal measurement

If IE "UE internal measurement" is received by the UE in a MEASUREMENT CONTROL message, where IE "measurement command" has the value "setup", but IE "UE internal measurement quantity", IE "UE internal reporting quantity" or "parameters sent for each UE internal measurement event" (given "CHOICE report criteria" is set to "UE internal measurement reporting criteria") is not received, the UE shall:

1> clear all stored measurement control information related associated to this measurement identity in variable MEASUREMENT_IDENTITY;

1> set the variable CONFIGURATION_INCOMPLETE to TRUE.

### 8.6.7.18a Void

### 8.6.7.19 UE positioning

#### 8.6.7.19.0 UE positioning reporting criteria

If IE "UE positioning reporting criteria" is included, the UE shall:

1> perform the necessary measurements and evaluate the event in the interval indicated in IE "Measurement Interval";

1> if IE "Event ID" is set to "7a" and if IE "Report first fix" is set to TRUE:

2> if the IE "Method Type" included in the variable MEASUREMENT_IDENTITY is set to "UE based":

3> act as specified in subclause 8.6.7.19.1b.

#### 8.6.7.19.1 UE positioning reporting quantity

The UE shall:

1> ignore IE "Multiple Sets";

1> ignore IE "Response Time";

1> if IE "Horizontal Accuracy" and/or IE "Vertical Accuracy" is included:

2> should try to achieve the requested level(s) of positioning accuracy with 67% confidence.

1> if IE "Positioning Methods" is set to "Cell ID":

2> act as specified in subclause 8.6.7.19.1a.

1> if the IE "Method Type" is set to "UE based":

2> act as specified in subclause 8.6.7.19.1b.

1> if the IE "Method Type" is set to "UE assisted":

2> act as specified in subclause 8.6.7.19.1a.

1> if the IE "Method Type" is set to "UE-assisted preferred but UE-based allowed" or "UE-based preferred but UE-assisted allowed":

2> act either according to subclause 8.6.7.19.1a or 8.6.7.19.1b depending on the method type chosen by the UE.

If UE according to its capabilities supports Rx-Tx time difference type 2 measurement and if IE "Positioning Methods" is set to "Cell ID" and the IE "Method Type" is set to "UE-based", the UE shall:

1> set the variable CONFIGURATION_INCOMPLETE to TRUE.

If UE according to its capabilities supports Rx-Tx time difference type 2 measurement and if IE "Positioning Methods" is set to "Cell ID" and the IE "Measurement validity" stored in the variable MEASUREMENT_IDENTITY is other than "CELL_DCH", the UE shall:

1> set the variable CONFIGURATION_INCOMPLETE to TRUE.

The UE shall perform the following consistency check:

1> if UE, according to its capabilities, does not support UE-based OTDOA and if IE "Positioning Methods" is set to "OTDOA" and if IE "Method Type" is set to "UE-based":

2> set the variable CONFIGURATION_INCOMPLETE to TRUE.

1> if UE, according to its capabilities, does not support UE-assisted OTDOA and if IE "Positioning Methods" is set to "OTDOA" and if IE "Method Type" is set to "UE-assisted":

2> set the variable CONFIGURATION_INCOMPLETE to TRUE.

1> if UE, according to its capabilities, does not support UE-based GPS and if IE "Positioning Methods" is set to "GPS" and if IE "Method Type" is set to "UE-based":

2> set the variable CONFIGURATION_INCOMPLETE to TRUE.

1> if UE, according to its capabilities, does not support UE-assisted GPS and if IE "Positioning Methods" is set to "GPS" and if IE "Method Type" is set to "UE-assisted":

2> set the variable CONFIGURATION_INCOMPLETE to TRUE.

1> if UE, according to its capabilities, does not support UE-based positioning and if IE "Positioning Methods" is set to "OTDOAorGPS" and if IE "Method Type" is set to "UE-based":

2> set the variable CONFIGURATION_INCOMPLETE to TRUE.

1> if UE, according to its capabilities, does not support Rx-Tx time difference type 2 measurement and if IE "Positioning Methods" is set to "Cell ID":

2> set the variable CONFIGURATION_INCOMPLETE to TRUE.

1> if UE, according to its capabilities, does not support UE GPS timing of cell frames measurement and if IE "GPS timing of Cell wanted" is set to TRUE:

2> set the variable CONFIGURATION_INCOMPLETE to TRUE.

#### 8.6.7.19.1a UE positioning reporting for UE assisted methods

The UE shall:

1> when a measurement report is triggered:

2> if the UE was able to perform measurements on at least one neighbour cell included in the variable UE_POSITIONING_OTDOA_DATA_UE_ASSISTED in case of OTDOA or one satellite included in the variable UE_POSITIONING_GPS_DATA in case of GPS positioning or one cell from the active set in case of CELL ID:

3> if the IE "Vertical Accuracy" is included:

4> interpret the presence of this IE to indicate that the UTRAN desires to compute a 3-dimensional position estimate.

3> if the IE "Positioning Methods" is set to "GPS":

4> include the IE "UE positioning GPS measured results" in the measurement report and set the contents of the IE as follows:

5> if the UE supports the capability to provide the GPS timing of the cell frames measurement:

6> if the IE "GPS timing of Cell wanted" is set to TRUE:

7> perform the UE GPS timing of cell frames measurement on the serving cell or on one cell of the active set.

7> include the IE "Primary CPICH Info" for FDD or the IE "cell parameters id" for TDD; and

7> include the IE "Reference SFN" and the IE "UE GPS timing of cell frames".

6> if the IE "GPS timing of Cell wanted" is set to FALSE:

7> include the IE "GPS TOW msec" and set it to the GPS TOW when the measurements included in the MEASUREMENT REPORT were valid.

5> if the UE does not support the capability to provide the GPS timing of the cell:

6> include the IE "GPS TOW msec" and set it to the GPS TOW when the measurements included in the MEASUREMENT REPORT were valid.

3> if the IE "Positioning Methods" is set to "OTDOA":

4> include the IE "UE positioning OTDOA measured results " in the measurement report and set the contents of the IE as follows:

5> set IE "SFN" to the SFN when the last measurement was performed;

5> if the UE supports the capability to perform the Rx-Tx time difference type 2 measurement:

6> if the UE is in CELL_DCH state:

7> if the measured value is equal to "1279.9375":

8> set the IE "Rx-Tx time difference type 2" in IE "UE positioning OTDOA measured results" for the reference cell to "1279.8750".

7> otherwise:

8> set the IE "Rx-Tx time difference type 2" in IE "UE positioning OTDOA measured results" for the reference cell to the measured value.

7> include the IE group "Rx-Tx time difference type 2 info" for the reference cell and for each neighbour cell listed in variable UE_POSITIONING_OTDOA_DATA_UE_ASSISTED that belongs to the active set.

5> if the UE does not support the capability to perform the Rx-Tx time difference type 2 measurement:

6> set the IE "Rx-Tx time difference type 2" in IE "UE positioning OTDOA measured results" for the reference cell to value "1279.9375" to indicate that the measurement is not supported.

4> include IE group "Neighbour" for all neighbour cells listed in variable UE_POSITIONING_OTDOA_DATA_UE_ASSISTED on which the SFN-SFN observed time difference type 2 measurement could be performed.

3> if IE "Positioning Methods" in the MEASUREMENT CONTROL message has been assigned to value "OTDOA or GPS":

4> the UE may choose to either act as if IE "Positioning Methods" is set to "GPS" or "OTDOA" depending on the method chosen by the UE.

3> if the IE "Positioning Methods" is set to "CELL ID":

4> if the UE supports the capability to perform the Rx-Tx time difference type 2 measurement; and

4> if the UE is in CELL_DCH state:

5> perform the Rx-Tx time difference type 2 measurement on the cells in the active set; and

5> report the measurement results back to the network in the MEASUREMENT REPORT by using IE "UE positioning OTDOA measured results" including measurements on the cells in the active set; and

5> report Rx-Tx time difference type 2 measurement of the reference cell (as designated by the UE); and

5> for all reported neighbour cells:

6> report Rx-Tx time difference type 2 measurement; and

6> set the IE "SFN-SFN observed time difference type 2" and all IEs within the corresponding IE "UE positioning OTDOA quality" in IE "UE positioning OTDOA measured results" to value "0".

2> if the UE is not able to report the requested measurement results:

3> include IE "UE positioning error" in the MEASUREMENT REPORT and set the contents of this IE as specified in subclause 8.6.7.19.5.

1> if the UE is unable to report the requested measurement results due to missing GPS assistance data:

2> the UE may at anytime send a measurement report containing the IE "UE positioning error" and set the contents of this IE as specified in subclause 8.6.7.19.5.

2> after sending the measurement report, the UE shall not send another measurement report to request the same GPS assistance data for at least 20s. This requirement does not apply after release of the current RRC connection.

### 8.6.7.19.1b UE positioning reporting for UE based methods

The UE shall:

1> when a measurement report is triggered:

2> if the UE has been able to calculate a position after performing measurements on the cells included in the variable UE_POSITIONING_OTDOA_DATA_UE_BASED in case of OTDOA or the UE has been able to calculate a position in case of GPS positioning:

3> include IE "UE positioning Position Estimate Info" in the MEASUREMENT REPORT and set the contents of the IE as follows:

4> if the UE supports the capability to perform the UE GPS timing of cell frames measurement:

5> if the IE "GPS timing of Cell wanted" is set to TRUE:

6> perform the UE GPS timing of cell frames measurement on the serving cell or on one cell of the active set.

6> include the IE "Primary CPICH Info" for FDD or the IE "cell parameters id" for TDD;

6> include the SFN when the position was determined;

6> include the IE "UE GPS timing of cell frames".

5> if the IE "GPS timing of Cell wanted" is set to FALSE:

6> include the IE "GPS TOW msec" and set it to the GPS TOW when the position estimate was valid.

4> if the UE does not support the capability to provide the GPS timing of the cell:

5> include the IE "GPS TOW msec" and set it to the GPS TOW when the position estimate was valid.

4> if IE "Vertical Accuracy" has been included in IE "UE positioning reporting quantity":

5> if the IE "Vertical Accuracy" has been assigned to value "0":

6> if the IE "Horizontal Accuracy" has been assigned a value "0":

7> may include IE "Ellipsoid point with altitude".

6> if the IE "Horizontal Accuracy" has been assigned a value unequal to "0"; and

6> if the UE has been able to calculate a 3-dimensional position

7> include IE "Ellipsoid point with altitude" or IE "Ellipsoid point with altitude and uncertainty ellipsoid" as the position estimate.

6> if the UE has not been able to calculate a 3-dimensional position:

7> may act as if IE "Vertical Accuracy" was not included in IE "UE positioning reporting quantity".

5> if the IE "Vertical Accuracy" has been assigned to a value unequal to "0":

6> if the UE has been able to calculate a 3-dimensional position:

7> include IE "Ellipsoid point with altitude and uncertainty ellipsoid" as the position estimate.

6> if the UE has not been able to calculate a 3-dimensional position:

7> act as if IE "Vertical Accuracy" has not been included in IE "UE positioning reporting quantity".

4> if IE "Vertical Accuracy" has not been included in IE "UE positioning reporting quantity":

5> if IE "Horizontal Accuracy" in IE "UE positioning reporting quantity" has been assigned to value "0":

6> may include IE "Ellipsoid point".

5> if IE "Horizontal Accuracy" in IE "UE positioning reporting quantity" has been assigned to a value unequal to 0:

6> include either IE "Ellipsoid point with uncertainty circle" or IE "Ellipsoid point with uncertainty ellipse" or IE "Ellipsoid point with altitude and uncertainty ellipsoid" as the position estimate.

4> if IE "Velocity Requested" has been included in IE "UE positioning reporting quantity":

5> include IE "Velocity estimate" if supported and available.

2> if the UE was not able to calculate a position:

3> include IE "UE positioning error" in the MEASUREMENT REPORT and set the contents of this IE as specified in subclause 8.6.7.19.5.

1> if the UE is unable to calculate a position due to missing GPS assistance data:

2> the UE may at any time send a measurement report containing the IE "UE positioning error" and set the contents of this IE as specified in subclause 8.6.7.19.5;

2> after sending the measurement report, the UE shall not send another measurement report to request the same GPS assistance data for at least 20s. This requirement does not apply after release of the current RRC connection.

### 8.6.7.19.2 UE positioning OTDOA assistance data for UE-assisted

If IE "UE positioning OTDOA reference cell info for UE-assisted" is received in System Information Block type 15.4 or in the MEASUREMENT CONTROL message, the UE shall update the variable UE_POSITIONING_OTDOA_DATA_UE_ASSISTED accordingly. The UE shall:

1> store received cell information in the UE positioning reference cell info in the variable UE_POSITIONING_OTDOA_DATA_UE_ASSISTED, overwriting any existing information.

If IE "UE positioning OTDOA neighbour cell list for UE-assisted" is received in System Information Block type 15.4 or in the MEASUREMENT CONTROL message, the UE shall update the variable UE_POSITIONING_OTDOA_DATA_UE_ASSISTED accordingly. The UE shall:

1> store received cell information in the neighbour cell info list in the variable UE_POSITIONING_OTDOA_DATA_UE_ASSISTED, overwriting any existing information.

If, according to its capabilities, UE does not support IPDLs and if IE "IPDL parameters" is received for the reference or any of the neighbour cells, the UE shall:

1> ignore this IE.

In 1.28 Mcps TDD, if the IE "IPDL parameters" is received and the UE supports IPDLs, the UE shall:

1> ignore the IE IP_Slot;

1> if the IE "IP_PCCPCH" is set to FALSE:

2> configure the physical layer with IP_Sub to be first subframe according to [33].

1> if the IE "IP_PCCPCH" is set to TRUE:

2> configure the physical layer with IP_Sub to be second subframe according to [33].

1> if the IE "IP_PCCPCH" is absent:

2> configure the physical layer with IP_Sub to use both subframes according to [33].

If IE "SFN offset validity" is set to FALSE, the UE shall:

1> ignore the IE "SFN offset".

If IE "UE positioning measurement" is received in the MEASUREMENT CONTROL message, the UE shall also perform the following consistency checks:

1> if IE "Positioning Methods" is set to "OTDOA":

2> if IE "UE positioning OTDOA reference cell info for UE-assisted" is not included and if UE positioning OTDOA reference cell info for UE-assisted in variable UE_POSITIONING_OTDOA_DATA_UE_ASSISTED is empty:

3> set the variable CONFIGURATION_INCOMPLETE to TRUE.

1> if IE "Positioning Methods" is set to "OTDOA":

2> if IE "UE positioning OTDOA neighbour cell list for UE-assisted" is not included and if less than two neighbour cells are stored in UE positioning OTDOA neighbour cell info list for UE-assisted in variable UE_POSITIONING_OTDOA_DATA_UE_ASSISTED:

3> set the variable CONFIGURATION_INCOMPLETE to TRUE.

#### 8.6.7.19.2a UE positioning OTDOA assistance data for UE-based

The UE shall:

1> if IE "UE positioning OTDOA reference cell info for UE-based" is received in System Information Block type 15.5 or in the MEASUREMENT CONTROL message or in the ASSISTANCE DATA DELIVERY:

2> update the variable UE_POSITIONING_OTDOA_DATA_UE_BASED accordingly;

2> store received cell information in the UE positioning reference cell info for UE-based in the variable UE_POSITIONING_OTDOA_DATA_UE_BASED, overwriting any existing information.

1> if IE "UE positioning OTDOA neighbour cell list for UE-based" is received in System Information Block type 15.5 or in the MEASUREMENT CONTROL message or in the ASSISTANCE DATA DELIVERY:

2> update the variable UE_POSITIONING_OTDOA_DATA_UE_BASED accordingly;

2> store received cell information in the neighbour cell info list for UE-based in the variable UE_POSITIONING_OTDOA_DATA_UE_BASED, overwriting any existing information.

1> if, according to its capabilities, UE does not support IPDLs and if IE "IPDL parameters" is received for the reference or any of the neighbour cells:

2> ignore this IE.

1> in 1.28 Mcps TDD:

2> if the IE "IPDL parameters" is received and the UE supports IPDLs:

3> ignore the IE IP_Slot;

3> if the IE "IP_PCCPCH" is set to FALSE:

4> configure the physical layer with IP_Sub to be first subframe according to [33].

3> if the IE "IP_PCCPCH" is set to TRUE:

4> configure the physical layer with IP_Sub to be second subframe according to [33].

3> if the IE "IP_PCCPCH" is absent:

4> configure the physical layer with IP_Sub to use both subframes according to [33].

1> if IE "SFN offset validity" is set to FALSE:

2> ignore the IE "SFN offset".

1> if IE "UE positioning measurement" is received in the MEASUREMENT CONTROL message:

2> also perform the following consistency checks:

3> if IE "Positioning Methods" is set to "OTDOA":

4> if IE "UE positioning OTDOA reference cell info for UE-based" is not included and if UE positioning OTDOA reference cell info for UE-based in variable UE_POSITIONING_OTDOA_DATA_UE_BASED is empty:

5> set the variable CONFIGURATION_INCOMPLETE to TRUE.

3> if IE "Positioning Methods" is set to "OTDOA":

4> if IE "UE positioning OTDOA neighbour cell list for UE-based" is not included and if less than two neighbour cells are stored in UE positioning OTDOA neighbour cell info list for UE-based in variable UE_POSITIONING_OTDOA_DATA_UE_BASED:

5> set the variable CONFIGURATION_INCOMPLETE to TRUE.

4> if IE "Method Type" is set to "UE based":

5> if IE "UE positioning OTDOA reference cell info for UE-based" is included and if IE "Cell Position" for the reference cell is not included:

6> set the variable CONFIGURATION_INCOMPLETE to TRUE.

5> if the IE "UE positioning OTDOA neighbour cell list for UE-based" is included and if cell position of less than two neighbour cells of the cells included in this IE and stored in variable UE_POSITIONING_OTDOA_DATA_UE_BASED are different and if those cell positions are not different to the one of the reference cell stored in variable UE_POSITIONING_OTDOA_DATA_UE_BASED:

6> set the variable CONFIGURATION_INCOMPLETE to TRUE.

5> if the IE "UE positioning OTDOA neighbouring cell list for UE-based " is included and only two neighbour cells are included or stored in variable UE_POSITIONING_OTDOA_DATA_UE_BASED and if the IE "Round Trip Time" is neither included for the neighbour cells nor for the reference cell info:

6> set the variable CONFIGURATION_INCOMPLETE to TRUE.

#### 8.6.7.19.3 UE positioning GPS assistance data

The UE may receive GPS assistance data in System Information Block types 15, 15.1, 15.2, or 15.3, or in the ASSISTANCE DATA DELIVERY message, or in the MEASUREMENT CONTROL message.

#### 8.6.7.19.3.1 UE positioning GPS acquisition assistance

If the IE "UE positioning GPS acquisition assistance" is included, the UE shall:

1> update the variable UE_POSITIONING_GPS_DATA as follows:

2> delete all information currently stored in the IE "UE positioning GPS acquisition assistance" in the variable UE_POSITIONING_GPS_DATA;

2> store the received acquisition assistance information in the IE "UE positioning GPS acquisition assistance" in the variable UE_POSITIONING_GPS_DATA;

2> store the IE "GPS TOW msec" in the IE "UE positioning GPS acquisition assistance" in variable UE_POSITIONING_GPS_DATA and use it as an estimate of the GPS Time-of-Week at the time of reception of the complete message containing the IE "GPS TOW msec";

NOTE: The UE does not need to apply any compensation on the GPS Time-of-Week.

1> if the IEs "SFN" and "UTRAN GPS timing of cell frames" are included:

2> if the UE is able to utilise these IEs:

3> store these IEs in the IE "UE positioning GPS acquisition assistance " in variable UE_POSITIONING_GPS_DATA;

3> if the IE "Primary CPICH Info" for FDD or IE "cell parameters id" for TDD is not included:

4> if the UE is not in CELL_DCH state:

5> use IEs "SFN" and "UTRAN GPS timing of cell frames" to estimate the relationship between GPS time and radio interface timing of the NODE B transmission in the serving cell.

4> if the UE is in CELL_DCH state:

5> ignore IEs "SFN" and "UTRAN GPS timing of cell frames".

3> if the IE "Primary CPICH Info" for FDD or IE "cell parameters id" for TDD is also included:

4> store this IE in the IE "UE positioning acquisition assistance" in variable UE_POSITIONING_GPS_DATA;

4> use IEs "SFN" and "UTRAN GPS timing of cell frames" to estimate the relationship between GPS time and air-interface timing of the NODE B transmission in the cell indicated by "Primary CPICH info" or "cell parameters id".

#### 8.6.7.19.3.2 UE positioning GPS Almanac

If the IE "UE positioning GPS Almanac" is included, the UE shall:

1> if the IE "SV Global Health" is included:

1> store this IE in the IE in the IE "SV Global Health" in the IE "UE positioning GPS Almanac" in variable UE_POSITIONING_GPS_DATA.

1> for each satellite:

2> store received GPS almanac information at the position indicated by the IE "Sat ID" in the IE "UE positioning GPS Almanac" in the variable UE_POSITIONING_GPS_DATA, possibly overwriting any existing information in this position.

2> interpret IE "Data ID" as the Data ID field contained in the indicated subframe, word 3, most significant 2 bits, as defined by [12];

2> act on the rest of the IEs in a similar manner as specified in [12].

#### 8.6.7.19.3.3 UE positioning D-GPS Corrections

If the IE "UE positioning GPS DGPS corrections" is included, the UE shall:

1> update the variable UE_POSITIONING_GPS_DATA as follows:

2> delete all information currently stored in the IE "UE positioning GPS DGPS corrections" in the variable UE_POSITIONING_GPS_DATA;

2> store the received DGPS corrections in the IE "UE positioning GPS DGPS corrections" in the variable UE_POSITIONING_GPS_DATA.

1> use IE "GPS TOW sec" to determine when the differential corrections were calculated;

1> use IE "Status/Health" to determine the status of the differential corrections.

#### 8.6.7.19.3.3a UE positioning GPS Navigation Model

If the IE "UE positioning GPS Navigation Model" is included, for each satellite, the UE shall:

1> use IE "Satellite Status" to determine if an update of IE "UE positioning GPS Ephemeris and Clock Correction parameters" has been provided for the satellite indicated by the IE "SatID";

1> if an update has been provided for this satellite:

2> act as specified in subclause 8.6.7.19.3.4.

#### 8.6.7.19.3.4 UE positioning GPS Ephemeris and Clock Correction Parameters

If the IE "UE positioning GPS Ephemeris and Clock Correction parameters" is included, for each satellite, the UE shall:

1> update the variable UE_POSITIONING_GPS_DATA as follows:

2> store this IE at the position indicated by the IE "Sat ID" in the IE "UE positioning GPS Navigation Model" in the variable UE_POSITIONING_GPS_DATA, possibly overwriting any existing information in this position.

1> act on these GPS ephemeris and clock correction parameters in a manner similar to that specified in [12].

#### 8.6.7.19.3.5 UE positioning GPS ionospheric model

If IE "UE positioning GPS ionospheric model" is included, the UE shall:

1> store this IE in the IE "UE positioning GPS ionospheric model" in variable UE_POSITIONING_GPS_DATA;

1> act on these GPS ionospheric model parameters in a manner similar to that specified in [12].

#### 8.6.7.19.3.6 UE positioning GPS real-time integrity

If this list of bad satellites is included, the UE shall:

1> update the variable UE_POSITIONING_GPS_DATA as follows:

2> add the Sat IDs that are not yet included in the list of satellites in the IE "UE positioning GPS real time integrity" in the variable UE_POSITIONING_GPS_DATA;

2> remove all Sat IDs in the list of satellites in the IE "UE positioning GPS real time integrity" in the variable UE_POSITIONING_GPS_DATA that are not included in IE UE positioning GPS real time integrity.

1> consider the data associated with the satellites identified in the variable UE_POSITIONING_GPS_DATA as invalid.

#### 8.6.7.19.3.7 UE positioning GPS reference time

If the IE "UE positioning GPS reference time" is included, the UE shall:

1> store the IE "GPS Week" in "UE positioning GPS reference time" in variable UE_POSITIONING_GPS_DATA and use it as the current GPS week;

1> store the IE "GPS TOW msec" in the IE "UE positioning GPS reference time" in variable UE_POSITIONING_GPS_DATA and use it as an estimate of the GPS Time-of-Week at the time of reception of the complete message containing the IE "GPS TOW msec";

NOTE: The UE does not need to apply any compensation on the GPS Time-of-Week.

1> if the IE "SFN" and IE "UTRAN GPS timing of cell frames" are included:

2> if the UE is able to utilise the IEs:

3> store these IEs in the IE "UE positioning GPS reference time" in variable UE_POSITIONING_GPS_DATA;

3> if the IE "Primary CPICH Info" for FDD or IE "cell parameters id" for TDD is not included:

4> if the UE is not in CELL_DCH state:

5> use IEs "SFN" and "UTRAN GPS timing of cell frames" to estimate the relationship between GPS time and air-interface timing of the NODE B transmission in the serving cell.

4> if the UE is in CELL_DCH state:

5> ignore IEs "SFN" and "UTRAN GPS timing of cell frames".

3> if the IE "Primary CPICH Info" for FDD or IE "cell parameters id" for TDD is also included:

4> store this IE in the IE "UE positioning GPS reference time" in variable UE_POSITIONING_GPS_DATA;

4> use IEs "SFN" and "UTRAN GPS timing of cell frames" to estimate the relationship between GPS time and air-interface timing of the NODE B transmission in the cell indicated by "Primary CPICH info" or "cell parameters id".

1> if the IE "SFN-TOW Uncertainty" is included:

2> store this IE in the IE "UE positioning GPS reference time" in variable UE_POSITIONING_GPS_DATA and use it to determine if the relationship between GPS time and air-interface timing of the NODE B transmission is known to within at least 10ms.

1> if the IE "$T_{UTRAN-GPS}$ drift rate" is included:

2> store this IE in the IE "UE positioning GPS reference time" in variable UE_POSITIONING_GPS_DATA; and

2> may use it as an estimate of the drift rate of the NODE B clock relative to GPS time.

1> if the IE "GPS TOW Assist" is included:

2> for each satellite:

3> delete all information currently stored in the IE "GPS TOW Assist" in the IE "UE positioning GPS reference time" in the variable UE_POSITIONING_GPS_DATA;

3> store the received GPS TOW Assist information in the IE "UE positioning GPS reference time" in the variable UE_POSITIONING_GPS_DATA.

#### 8.6.7.19.3.8 UE positioning GPS reference UE position

If the IE "UE positioning GPS reference UE position" is included, the UE shall:

1> store this IE in the IE "UE positioning GPS reference UE position" in variable UE_POSITIONING_GPS_DATA; and

1> use it as a priori knowledge of the approximate location of the UE.

#### 8.6.7.19.3.9 UE positioning UTC model

If the IE "UE positioning GPS UTC model" is included, the UE shall:

1> store this IE in the IE "UE positioning GPS UTC model" in variable UE_POSITIONING_GPS_DATA.

### 8.6.7.19.4 UE positioning Ciphering info

The UE shall:

1> if deciphering information is received from higher layers for deciphering of GPS assistance data broadcast on system information:

2> store the current key in IE "Current deciphering key" in variable UE_POSITIONING_GPS_DATA;

2> store the next key in IE "Next deciphering key" in variable UE_POSITIONING_GPS_DATA;

2> store the ciphering key flag in UE_POSITIONING_GPS_DATA.

1> if deciphering information is received from higher layers for deciphering of OTDOA assistance data broadcast on system information:

2> store the current key in IE "Current deciphering key" in variable UE_POSITIONING_OTDOA_DATA_UE_BASED;

2> store the next key in IE "Next deciphering key" in variable UE_POSITIONING_OTDOA_DATA_UE_BASED;

2> store the ciphering key flag in UE_POSITIONING_OTDOA_DATA_UE_BASED.

1> if the IE "GPS Data ciphering info" is included in System Information Block type 15:

2> select one of the two deciphering keys received and stored it in UE_POSITIONING_GPS_DATA according to the following:

3> if the value of the received IE "Ciphering Key Flag" is the same as the value of the IE "Ciphering Key Flag" stored in the variable UE_POSITIONING_GPS_DATA:

4> select the current deciphering key.

3> if the value of the received IE "Ciphering Key Flag" is different from the value of the IE "Ciphering Key Flag" stored in the variable UE_POSITIONING_GPS_DATA:

4> select the next deciphering key.

2> store the received IE in the variable UE_POSITIONING_GPS_DATA;

2> use the selected deciphering key to decipher the broadcast UE positioning GPS information contained within the System Information Block types 15.1, 15.2 and 15.3.

1> if the IE "OTDOA positioning ciphering info" is included in System Information Block type 15.4:

2> select one of the two deciphering keys and stored it in UE_POSITIONING_OTDOA_DATA_UE_BASED according to the following:

3> if the value of the received IE "Ciphering Key Flag" is the same as the value of the IE "Ciphering Key Flag" stored in the variable UE_POSITIONING_OTDOA_DATA_UE_BASED:

4> select the current deciphering key.

3> if the value of the received IE "Ciphering Key Flag" is different from the value of the IE "Ciphering Key Flag" stored in the variable UE_POSITIONING_OTDOA_DATA_UE_BASED:

4> select the next deciphering key.

2> store the received IE in the variable UE_POSITIONING_OTDOA_DATA_UE_BASED;

2> use the selected deciphering key to decipher the IE "OTDOA assistance data" included in the System Information Block types 15.4.

#### 8.6.7.19.5 UE positioning Error

The UE shall set the contents of the IE "UE positioning Error" as follows:

1> if the IE "Positioning Methods" in IE "UE positioning reporting quantity" has been assigned to value "OTDOA" and no neighbour cells could be received,

2> set IE "Error reason" to "Not Enough OTDOA Cells";

1> if the IE "Positioning Methods" in IE "UE positioning reporting quantity" has been assigned to value "GPS":

2> if there were not enough GPS satellites to be received:

3> set IE "Error reason" to "Not Enough GPS Satellites".

2> if some GPS assistance data was missing:

3> set IE "Error reason" to "Assistance Data Missing"; and

3> if the IE "Additional Assistance Data Request" included in the IE "UE positioning reporting quantity" stored in the variable MEASUREMENT_IDENTITY is set to TRUE:

4> include the IE "GPS Additional Assistance Data Request".

3> if the IE "Additional Assistance Data Request" included in the IE "UE positioning reporting quantity" stored in the variable MEASUREMENT_IDENTITY is set to FALSE:

4> not include the IE "GPS Additional Assistance Data Request", and use the assistance data available for doing a positioning estimate.

2> if the UE was not able to read the SFN of the reference cell included in the IE "UE positioning GPS reference time" or in the IE "UE positioning acquisition assistance":

3> set IE "Error reason" to "Reference Cell Not Serving Cell".

2> if the UE was not able to measure the requested GPS timing of cell frames measurement:

3> set IE "Error reason" to "Not Accomplished GPS Timing Of Cell Frames".

1> if none of the conditions above are fulfilled:

2> set IE "Error reason" to "Undefined Error".

The UE shall not set the IE "Error reason" to "Request Denied By User" or "Not Processed and Timeout".

#### 8.6.7.19.6 Void

### 8.6.7.20 Void

### 8.6.7.21 Intra-frequency reporting quantity for RACH reporting

If the IE "Intra-frequency reporting quantity for RACH reporting" is included, the UE shall:

1> if the IE "SFN-SFN observed time difference reporting indicator" has the value "type 2":

2> act as if the value of the IE "SFN-SFN observed time difference reporting indicator" is "no reporting".

1> if the IE "Reporting quantity" (FDD) or all IEs "Reporting quantity" (TDD) have the value "no report":

2> the UE behaviour is unspecified.

### 8.6.7.22 Additional Measurement List

If the IE "Additional Measurement List" is received in a MEASUREMENT CONTROL message, the UE shall:

1> if the received measurement configuration in this MEASUREMENT CONTROL message, or any measurement referenced in the "Additional Measurement List" do not all have the same validity (for this consistency check the UE shall assume "CELL_DCH" as the measurement validity for measurements of type "inter-RAT", "UE internal", and "quality"):

2> set the variable CONFIGURATION_INCOMPLETE to TRUE.

1> if any of the measurements referenced in the "Additional Measurement List" is an intra-frequency, inter-frequency or inter-RAT measurement, and this measurement is configured with event based reporting:

2> the UE behaviour is not specified.

1> if any of the "intra-frequency", "inter-frequency", "traffic volume" or "UE positioning" measurements referenced in the "Additional Measurement List" has been setup without including the IE "measurement validity":

2> the UE behaviour is not specified.

1> if the result of this MEASUREMENT CONTROL message is such that more than one additional measurement of the same type will be referenced in the IE "Additional Measurement List" in the MEASUREMENT_IDENTITY variable:

2> the UE behaviour is not specified.

1> if the UE has no IE "Additional Measurement List" stored the in variable MEASUREMENT_IDENTITY associated with the identity indicated by the IE "measurement identity":

2> store the received IE "Additional Measurement List" in the variable MEASUREMENT_IDENTITY.

If the IE "Additional Measurement List" is received in a MEASUREMENT CONTROL message with the IE "Measurement command" value set to "modify", and the UE has an IE "Additional Measurement List" stored in the variable MEASUREMENT_IDENTITY associated with the identity indicated by the IE "measurement identity", the UE shall:

1> replace the information stored in "Additional Measurement List" in variable MEASUREMENT_IDENTITY associated to the identity indicated by the IE "measurement identity" with the one received in the MEASUREMENT CONTROL message.

If the IE "Additional Measurement List" is not received in a MEASUREMENT CONTROL message and the IE "Measurement command" has the value "modify" and the UE has an IE "Additional Measurement List" stored in the variable MEASUREMENT_IDENTITY associated with the identity indicated by the IE "measurement identity", the UE shall:

1> leave the IE "Additional Measurement List" stored in the variable MEASUREMENT_IDENTITY associated with the identity indicated by the IE "measurement identity" unchanged.

If, at any time during the life-time of a measurement, any measurement referenced in the Additional Measurement List does not exist, the UE shall:

1> remove this measurement identity from the Additional Measurement List.

NOTE: A measurement referenced in the Additional Measurement List which is updated with a measurement command set to "modify", or replaced with a measurement command set to "setup", continues to exist.

If the measurement configured with the MEASUREMENT CONTROL message triggers a measurement report, the UE shall:

1> also include the reporting quantities for the measurements referenced by the additional measurement identities. The contents of the IE "Additional Measured results" are completely determined by the measurement configuration of the referenced additional measurement.

## 8.6.8 Void

## 8.6.9 MBMS specific information elements

The UE shall perform the generic actions defined in this subclause only for the information elements corresponding with services that are included in variable MBMS_ACTIVATED_SERVICES.

### 8.6.9.1 Continue MCCH Reading

If the "Continue MCCH Reading " is included the UE shall:

1> if the IE "Continue MCCH reading " is set to 'TRUE':

2> continue receiving the MBMS MODIFIED SERVICES INFORMATION from MCCH in the next modification period and act upon it as specified in subclause 8.7.3.4.

### 8.6.9.1a MBMS dynamic persistence level

If the IE "MBMS dynamic persistence level" is included the UE shall:

1> Apply the dynamic persistence level in place of that broadcast in SIB 7 for MBMS related PRACH transmissions that are made within the modification period in which this IE was received.

### 8.6.9.2 MBMS PL Service Restriction Information

The UE shall:

1> if the UE receives a message triggering the reconfiguration procedure, a CELL UPDATE CONFIRM or an MBMS GENERAL INFORMATION message; and

1> if that message does include the IE "MBMS PL Service Restriction Information":

2> consider that UTRAN will not provide any non- MBMS services on the MBMS preferred frequencies.

1> otherwise:

2> consider that UTRAN will provide any non- MBMS services on the MBMS preferred frequencies.

1> perform the MBMS frequency selection procedure as specified in subclause 8.5.27.

### 8.6.9.3 MBMS L1 combining schedule

If the IE "MBMS L1 combining schedule" is included the UE may:

1> apply L1 combining between the concerned neighbouring cell"s S-CCPCH and the corresponding current cell"s S-CCPCH for the periods indicated by this IE.

### 8.6.9.3a MBMS Number of neighbour cells

The UE may:

1> apply the number of neighbour cells to identify if all MBMS NEIGHBOURING CELL P-T-M RB INFORMATION messages have been received from MCCH.

### 8.6.9.4 MBMS Preferred frequency information

If the IE "MBMS Preferred frequency information" is included the UE shall:

1> perform the Preferred frequency layer selection procedure as specified in subclause 8.5.27.

### 8.6.9.4a Void

### 8.6.9.4b MBMS p-t-m activation time

The UE shall:

1> for the services as listed in the IE "MBMS transmission identity" included in the MBMS MODIFIED SERVICES INFORMATION message for which the IE "MBMS required UE action" is set to "Acquire PTM RB info";

1> if the IE "MBMS all unmodified p-t-m services" is included in the MBMS MODIFIED SERVICES INFORMATION message, for the services as listed in the IE "MBMS transmission identity" included in the MBMS UNMODIFIED SERVICES INFORMATION message for which the IE "MBMS required UE action" in the MBMS UNMODIFIED SERVICES INFORMATION message is set to "Acquire PTM RB info":

2> if the IE "MBMS p-t-m activation time" is not included:

3> if available continue using the currently used p-t-m configuration for this service until the end of the modification period;

3> start to use the p-t-m configuration received in this modification period from the next modification period onward.

2> else:

3> for the cell current cell:

4> stop using any old configuration on TTIs that are after or contain the time instant as indicated by the IE "MBMS p-t-m activation time";

4> start using the configuration for the S-CCPCH received for that p-t-m bearer in the same modification period as the IE "MBMS p-t-m activation time" on TTIs that are after or that contain the time instant as indicated by the IE "MBMS p-t-m activation time".

3> for neighbouring cells:

4> for the neighbouring cells for which the IE "MBMS transmission time difference" is included:

5> stop using any old configuration on TTIs corresponding to the TTIs of the cell wherein the UE is reading the MCCH from and where the new p-t-m radio bearer information is valid according to the above;

5> start using the configuration for the S-CCPCH received for that p-t-m bearer in the same modification period as the IE "MBMS p-t-m activation time" on TTIs corresponding to the TTIs of the cell wherein the UE is reading the MCCH from and where the new p-t-m radio bearer information is valid according to the above.

4> for the neighbouring cells for which the IE "MBMS transmission time difference" is not included:

5> stop using any old configuration on TTIs that are after or contain the time instant as indicated by the IE "MBMS p-t-m activation time".

5> start using the configuration for the S-CCPCH received for that p-t-m bearer in the same modification period as the IE "MBMS p-t-m activation time" on TTIs that are after the time instant as indicated by the IE "MBMS p-t-m activation time".

### 8.6.9.5 MBMS RB list released to change transfer mode

If the IE "MBMS RB list released to change transfer mode" is included the UE shall:

1> perform the service prioritisation procedure as specified in subclause 8.5.26, taking into account that the MBMS service(s) for which the radio bearers are released will be provided via p-t-m radio bearer(s).

### 8.6.9.6 MBMS Required UE action

If the IE "MBMS required UE action" is included the UE shall:

1> if the "MBMS required UE action" is set to 'None':

2> take no action with respect to this IE.

1> if the IE "MBMS required UE action" is set to 'Acquire counting info' or set to 'Acquire counting info– PTM RBs unmodified':

2> perform the MBMS counting procedure as specified in subclause 8.7.4;

NOTE: If upper layers indicate that an MBMS transmission has already been received correctly, the UE will continue as if the information about the concerned MBMS transmission was not included in the message. This implies that the UE does not respond to counting for a transmission already received correctly.

1> if the IE "MBMS required UE action" is set to 'Acquire PTM RB info'; or

1> if the IE "MBMS required UE action" is set to 'Acquire counting info– PTM RBs unmodified' and the UE is not receiving a p-t-m RB for the concerned service:

2> continue acquiring the MBMS COMMON P-T-M RB INFORMATION, MBMS CURRENT CELL P-T-M RB INFORMATION and the MBMS NEIGHBOURING CELL P-T-M RB INFORMATION messages without delaying reading of MCCH until the next modification period and without stopping at the end of the modification period, in accordance with subclause 8.7.1.3

2> act upon the MBMS COMMON P-T-M RB INFORMATION, MBMS CURRENT CELL P-T-M RB INFORMATION and the MBMS NEIGHBOURING CELL P-T-M RB INFORMATION message, if received, in accordance with subclause 8.7.5;

1> if the IE "MBMS required UE action" is set to 'Request PTP RB':

2> if the UE is in idle mode:

3> indicate to upper layers that establishment of an RRC connection is required to receive the concerned MBMS service with the establishment cause set to 'MBMS ptp RB request', unless the UE has already requested p-t-p RB establishment in the current modification period.

2> if the UE is in URA_PCH or Cell_PCH states:

3> perform a cell update procedure with cause "MBMS ptp RB request", as specified in subclause 8.3.1.2, unless the UE has already requested p-t-p RB establishment in the current modification period.

2> if the UE is in CELL_DCH:

3> indicate to upper layers that establishment of an PMM connection is required to receive the concerned MBMS service with the establishment cause set to 'MBMS ptp RB request' unless the UE has already established the PMM connection.

1> if the IE "MBMS required UE action" is set to 'Release PTM RB':

2> stop receiving the concerned MBMS service;

2> if the UE is in a state other than CELL_DCH (for FDD) or if the UE is in Idle mode, URA_PCH or CELL_PCH state (for TDD); and

2> if the UE does not decide to receive an MBMS service for which a preferred frequency applies; and

2> if the IE "MBMS dispersion indicator" is set to TRUE; and

2> if the variable MBMS_PREV_FREQUENCY_INFO is not empty:

3> if any frequency in SIB11 or SIB12 has the same frequency stored in the variable MBMS_PREV_FREQUENCY_INFO:

4> select a suitable UTRA cell in that frequency.

4> if no suitable UTRA cell in that frequency is found:

5> select a suitable UTRA cell in another frequency.

3> if no frequency in SIB11 or SIB12 has the same frequency stored in the variable MBMS_PREV_FREQUENCY_INFO.

4> select a frequency randomly among the inter-frequencies indicated in SIB11 or SIB12.

5> select a suitable UTRA cell in the selected frequency

5> if no suitable UTRA cell in the selected frequency is found:

6> select a suitable UTRA cell in another frequency.

3> clear the variable MBMS_PREV_FREQUENCY_INFO.

2> clear all service specific information applicable for the concerned service.

NOTE: The UE is only required to acquire the relevant SIB11 or SIB12, according to what is specified in subclauses 8.1.1.6.11 and 8.1.1.6.12.

### 8.6.9.6a MBMS re- acquire MCCH

If the UE receives the IE " MBMS re- acquire MCCH" with a value set to TRUE, the UE shall:

1> perform the MCCH acquisition procedure as specified in subclause 8.7.2.

### 8.6.9.7 MBMS Service transmissions info list

If the UE receives the IE "MBMS Service transmissions info list", the UE may:

1> discontinue reception of the S-CCPCH on which the IE was received, except for the service transmissions indicated by this IE for the concerned scheduling period.

### 8.6.9.8 MBMS Short transmission ID

If the IE "MBMS short transmission ID" is included the UE shall:

1> if the value of the "MBMS short transmission ID" is less than or equal to the number of services identified by the IE "Modified services list" included in the MBMS MODIFIED SERVICES INFORMATION message acquired in the same modification period as the one in which the "MBMS short transmission ID" is received:

2> consider the "MBMS short transmission ID" to be an index to the list of services contained in the IE "Modified services list" and apply the MBMS service identity specified for this entry.

1> otherwise:

2> compile a list of available MBMS services, as included in the MBMS MODIFIED SERVICES INFORMATION and the MBMS UNMODIFIED SERVICES INFORMATION messages acquired in the same modification period as the one in which the "MBMS short transmission ID" is received:

3> concatenate the services contained in IE "Modified services list" included in the MBMS MODIFIED SERVICES INFORMATION and the services contained in IE "Unmodified services list" included in the MBMS UNMODIFIED SERVICES INFORMATION.

2> consider the 'MBMS short transmission ID' to be the index of the entry in the list of available services and apply the MBMS service identity specified for this entry.

### 8.6.9.9 MBMS Transmission identity

If the IE "MBMS transmission identity" is included the UE shall:

1> if upper layers indicate that the MBMS transmission has already been received correctly:

2> ignore the information about this MBMS transmission i.e. continue as if the information about the concerned MBMS transmission was not included in the message.

1> otherwise:

2> act upon the information about the concerned MBMS transmission as specified elsewhere.

The UE behaviour is unspecified if an MBMS transmission identity appears more than once in the combined list of transmissions i.e. the IE is included more than once in the MBMS MODIFIED SERVICES INFORMATION or in the MBMS UNMODIFIED SERVICES INFORMATION, or once in both message.

### 8.6.9.9a MBMS transmission time difference

The IE "MBMS transmission time difference" indicates the time difference between the transmissions on the current and the neighbour cell i.e. indicating the TTIs that can be L1- combined. The UE shall:

1> derive the parameter Neighbor_Start from the IE MBMS transmission time difference as follows:

MBMS transmission time difference = (Neighbor_Start / Max_TTI_Size) mod 4

where Neighbor_Start is the CFN of the first radio frame in a TTI on the neighbour cell that may be combined with the TTI on the current cell of which the CFN of the first radio frame equals 0 while Max_TTI_Size is the largest TTI size on the S-CCPCHs to be soft combined;

1> in case of partial soft combining, derive the CFN of the first radio frame in a TTI on the neighbour cell that may be combined assuming the same time difference applies.

The maximum delay between S-CCPCH clusters that the UE may combine is set by UE performance requirements.

NOTE: The MBMS transmission time difference is semi-static; it does not vary within or between L1 combining periods nor when full combining is used.

### 8.6.9.9b MCCH configuration information

If the IE "MCCH configuration information" is included the UE shall:

1> Consider an access information period to start from the frame with the SFN value fulfilling the following equation (where *m* is the modification period coefficient and *a* is the access info period coefficient):

$$SFN \bmod 2^{(m-a)} = 0$$

1> Consider a repetition period to start from the frame with the SFN value fulfilling the following equation (where *m* is the modification period coefficient and *r* is the repetition period coefficient):

$$SFN \bmod 2^{(m-r)} = 0$$

1> Consider a modification period to start from the frame with the SFN value fulfilling the following equation (where *m* is the modification period coefficient):

$$SFN \bmod 2^{m} = 0$$

1> configure the RLC entity in the UE used for receiving MCCH in accordance with 8.6.4.9;

1> configure the MAC entity in the UE, used for receiving MCCH, for receiving TCTF field unless the IE 'TCTF presence' is received;

### 8.6.9.10 Next scheduling period

If the IE "Next scheduling period" is included the UE may:

1> discontinue reception of the S-CCPCH on which the IE was received for the number of scheduling periods indicated by this IE.

# 8.7 MBMS specific procedures

## 8.7.1 Reception of MBMS control information

### 8.7.1.1 General

The procedure for receiving MBMS control information is used by a UE to receive information from UTRAN concerning the way it provides MBMS services the UE has joined. The procedure applies to all UEs supporting MBMS, irrespective of its state (idle, URA_PCH, CELL_PCH, CELL_FACH and CELL_DCH).

Most MBMS control information is provided on the MCCH. The information on MCCH is transmitted using a fixed schedule, which is common for all services. MCCH information other than MBMS ACCESS INFORMATION message is transmitted periodically based on a repetition period. This MCCH information is repeated a configurable number of times with exactly the same content; the period in which the content of MCCH information other than MBMS ACCESS INFORMATION message remains unchanged is called the modification period. MBMS ACCESS INFORMATION message may be transmitted more frequently, based on the Access Info period. The transmissions of MBMS ACCESS INFORMATION message within a modification period need not have exactly the same content (the value of some parameters eg. IE 'Access probability factor – Idle' may change). Nevertheless, the transmissions of MBMS ACCESS INFORMATION message within a modification period should concern the same MBMS service(s), although information for a service may be removed eg. upon completion of the counting for that service.

The general principles are illustrated in figure 8.7.1-1, in which different colours indicate potentially different content of the MCCH information.




**Figure 8.7.1-1: Scheduling of MCCH Information**

For services provided via a p-t-m radio bearer scheduling information may be provided on an MSCH mapped on the same S-CCPCH as the p-t-m radio bearer(s). For some of the services provided p-t-m this scheduling information may be provided by signalling an MBMS SCHEDULING INFORMATION message at every scheduling period, while for others the MBMS SCHEDULING INFORMATION message may be signalled less frequently i.e. after a multiple of the scheduling period. In general, the UE is neither required to acquire MSCH information nor to act on it.

In case the UE shall acquire MCCH information that is scheduled at the same time as MSCH information, the reception of the MCCH information shall take precedence.

In order to minimise the time the UE needs to read MCCH upon notification as specified in 8.7.3 to acquire the required information, UTRAN should schedule the MCCH messages in a specific order ie. any message that needs to be read by any UE due to the reception of the MBMS MODIFIED SERVICES INFORMATION message should be scheduled prior to the remaining messages. More specifically, the UE may assume that UTRAN schedules the MCCH messages in the following order:

MBMS MODIFIED SERVICES INFORMATION,

followed by messages that needs to be read by any UE due to the content of the MBMS MODIFIED SERVICES INFORMATION message in the following order: MBMS GENERAL INFORMATION, MBMS COMMON P-T-M RB INFORMATION, MBMS CURRENT CELL P-T-M RB INFORMATION, one or more MBMS NEIGHBOURING CELL P-T-M RB INFORMATION,

MBMS UNMODIFIED SERVICES INFORMATION,

followed by messages that do not need to be read by any UE due to the content of the MBMS MODIFIED SERVICES INFORMATION message in the following order: MBMS GENERAL INFORMATION, MBMS COMMON P-T-M

RB INFORMATION, MBMS CURRENT CELL P-T-M RB INFORMATION, one or more MBMS NEIGHBOURING CELL P-T-M RB INFORMATION

### 8.7.1.2 Initiation

The requirements concerning which MBMS control information the UE shall acquire in the different cases is specified in other subclauses. This section specifies common requirements concerning the reception of MCCH information and MSCH information.

### 8.7.1.3 UE requirements on reading of MCCH information

When requested to acquire MBMS control information other than the MBMS ACCESS INFORMATION message , the UE shall:

1> if requested to start reading MCCH at the next modification period:

2> start reading MCCH at the beginning of the next modification period.

1> otherwise

2> start reading MCCH at the beginning of the next repetition period.

1> if requested to stop reading MCCH at the end of the modification period:

2> continue reading MCCH until the required MBMS control information is received or until the UE detects a TTI in which no MCCH information is transmitted, whichever is first;

2> continue reading MCCH in this manner at every subsequent repetition period, until the information is received correctly or until the end of the modification period.

1> otherwise:

2> continue reading MCCH until the required MBMS control information is received or until the UE detects a TTI in which no MCCH information is transmitted, whichever is first;

2> continue reading MCCH in this manner at every subsequent repetition period, until the information is received correctly.

NOTE 1: The UE may combine information received at different repetition periods within a modification period.

When requested to acquire the MBMS ACCESS INFORMATION message, the UE shall:

1> if requested to start reading MCCH at the next modification period:

2> start reading MCCH at the beginning of the next modification period.

1> otherwise:

2> start reading MCCH at the beginning of the next access info period.

1> continue reading MCCH in this manner at every subsequent access info period, until the message is received correctly or until the end of the modification period.

If the UE is CELL_DCH and has a compressed mode pattern that overlaps with the period in which it needs to read MCCH, the UE may temporarily refrain from receiving MCCH unless it is capable of simultaneous operation. If the UE is CELL_FACH and has a measurement occasion that overlaps with the period in which it needs to read MCCH, the UE may temporarily refrain from receiving MCCH unless it is capable of simultaneous operation. A UE in CELL_FACH may omit performing measurements during a measurement occasion in order to receive MCCH provided that this does not prevent it from fulfilling the measurement performance requirements as specified in [19]. In Idle mode as well as in CELL_PCH and URA_PCH states the UE may temporarily refrain from receiving MCCH if needed to fulfil the measurements performance requirements as specified in [19].

NOTE 2: The UTRAN should endeavour to ensure that for each UE in CELL_FACH the assigned measurement occasions do not overlap constantly with the periodic MCCH transmissions.

If the UE selects to another cell, the UE shall re-establish the RLC entity used for MCCH reception.

#### 8.7.1.4 UE requirements on reading of MSCH information

If the UE supports reception of MSCH, UE shall:

1> if the UE needs to acquire MCCH information that is transmitted at the same time as the MSCH information and the UE does not support simultaneous reception:

2> refrain from reading MSCH.

If the UE supports reception of MSCH, UE should:

1> start reading MSCH at the beginning of the next scheduling period;

1> continue reading MSCH until the required MBMS control information is received or until the UE detects a TTI in which no MSCH information is transmitted, whichever is first.

### 8.7.2 MCCH acquisition




**Figure 8.7.2-1: MCCH acquisition, normal**

#### 8.7.2.1 General

The UE applies the MCCH acquisition procedure to determine the MBMS services available in the cell and to initiate reception of the services that the UE has joined. The procedure applies to all UEs supporting MBMS, irrespective of their state (idle, URA_PCH, CELL_PCH, CELL_FACH and CELL_DCH).

#### 8.7.2.2 Initiation

The UE shall apply the MCCH acquisition procedure upon selecting (eg. upon power on) or re- selecting a cell supporting MBMS, upon change of MBMS controlling cell (eg. due to an active set update or hard handover), upon entering UTRA from another RAT, upon release of a MBMS PTP RB for the purpose of changing transfer mode, upon return from loss of coverage and upon receiving an indication from upper layers that the set of activated services has changed.

#### 8.7.2.3 MCCH information to be acquired by the UE

The UE shall detect the available MBMS services by acquiring the MBMS MODIFIED SERVICES INFORMATION and the MBMS UNMODIFIED SERVICES INFORMATION messages without delaying reading of MCCH until the

next modification period and without stopping at the end of the modification period, in accordance with subclause 8.7.1.3.

The UE shall immediately acquire the MBMS ACCESS INFORMATION and the MBMS GENERAL INFORMATION messages ie. it shall not delay reception of these messages until it has completed the acquisition of the MBMS MODIFIED SERVICES INFORMATION and the MBMS UNMODIFIED SERVICES INFORMATION messages. Likewise, the UE should immediately acquire the MBMS CURRENT CELL P-T-M RB INFORMATION and MBMS NEIGHBOURING CELL P-T-M RB INFORMATION messages.

The UE shall continue acquiring the above messages until it has received a consistent set of MCCH information eg. both the MBMS MODIFIED SERVICES INFORMATION and the MBMS UNMODIFIED SERVICES INFORMATION message should be acquired in the same modification period.

#### 8.7.2.4 Reception of the MBMS MODIFIED SERVICES INFORMATION and the MBMS UNMODIFIED SERVICES INFORMATION by the UE

Upon completing the reception of the MBMS MODIFIED SERVICES INFORMATION and the MBMS UNMODIFIED SERVICES INFORMATION messages, the UE shall

1> act as follows for each of the services included in these messages provided that the service is included in variable MBMS_ACTIVATED_SERVICES and upper layers indicate that the session has not yet been received correctly (referred to as 'applicable services');

1> act upon all received information elements as specified in subclause 8.6, unless specified otherwise in the following;

1> if one or more preferred frequency applies for the applicable services:

2> delay acting upon the "MBMS Preferred frequency information" until receiving the relevant MCCH information i.e. the MBMS GENERAL INFORMATION message;

2> act upon the "MBMS Preferred frequency information" as specified in subclause 8.6.9.4 for the service(s) that upper layers indicate to have highest priority.

1> perform the service prioritisation procedure as specified in subclause 8.5.26;

1> if the UE receives an MBMS service using a p-t-m radio bearer and the received messages do not contain an IE "MBMS required UE action" set to "Acquire PTM RB info" or set to "Acquire counting info– PTM RBs unmodified" for that service then the UE shall:

2> stop receiving the concerned MBMS service and clear all service specific information applicable for the concerned service.

#### 8.7.2.5 Reception of the other MBMS messages by the UE

Upon receiving the MBMS ACCESS INFORMATION message, the UE shall act as specified in subclause 8.7.4.3.

Upon receiving the MBMS GENERAL INFORMATION message, the UE should store all relevant IEs included in this message. The UE shall also:

1> act upon all received information elements as specified in subclause 8.6, unless specified otherwise in the following.

Upon receiving the MBMS CURRENT CELL P-T-M RB INFORMATION and MBMS NEIGHBOURING CELL P-T-M RB INFORMATION messages, the UE shall act as specified in subclauses 8.7.5.3 and subclause 8.7.5.4 respectively.

The procedure ends.

### 8.7.3 MBMS Notification




**Figure 8.7.3-1: MBMS notification on MCCH**




**Figure 8.7.3-2: MBMS notification on DCCH**

### 8.7.3.1 General

The MBMS notification procedure is used by the UE to respond to a notification provided by UTRAN, indicating a change applicable for one or more MBMS services the UE has joined. The procedure applies to all UEs supporting MBMS, irrespective of their state (idle and connected mode: URA_PCH, CELL_PCH, CELL_FACH and CELL_DCH). The actual notification mechanism to be used depends on the UE state.

### 8.7.3.2 Initiation

UTRAN initiates the notification procedure to inform UEs about a change applicable for one or more MBMS services available in a cell. Some types of MBMS service changes e.g. the establishment of a p-t-m radio bearer, involve a modification of MCCH messages other than the MBMS MODIFIED SERVICES INFORMATION message.

NOTE 1: On MCCH, the MBMS MODIFIED SERVICES INFORMATION as well as the MBMS UNMODIFIED SERVICES INFORMATION messages are signalled even if no services are contained in the message.

NOTE 2: A service remains in the MBMS MODIFIED SERVICES INFORMATION message until it enters a 'steady state', upon which it moves to the MBMS UNMODIFIED SERVICES INFORMATION message. In case counting is used, the service remains in the MBMS MODIFIED SERVICES INFORMATION message through the moment UTRAN has decided the transfer mode.

### 8.7.3.3 Receiving the MBMS Notification information

#### 8.7.3.3.1 Reception via MCCH

The UE may:

1> if in idle mode, URA_PCH, CELL_PCH or CELL_FACH state; and

1> if not receiving an MBMS service provided via a p-t-m radio bearer:

2> monitor the MBMS notification Indicator Channel (MICH).

2> if a notification on the MICH for one or more of the MBMS services included in the variable MBMS_ACTIVATED_SERVICES is detected:

3> acquire the MBMS MODIFIED SERVICES INFORMATION message with delaying the reading of MCCH until the next modification period and with stopping at the end of the modification period, in accordance with subclause 8.7.1.3;

3> handle the MBMS MODIFIED SERVICES INFORMATION message as specified in subclause 8.7.3.4.

The UE shall:

1> if in idle mode, URA_PCH, CELL_PCH or CELL_FACH state:

2> if receiving an MBMS service that is provided via a p-t-m radio bearer; or

2> if not receiving an MBMS service that is provided via a p-t-m radio bearer and not monitoring MICH:

3> acquire the MBMS MODIFIED SERVICES INFORMATION message from MCCH at the start of every modification period, in accordance with subclause 8.7.1.3;

3> handle the MBMS MODIFIED SERVICES INFORMATION message as specified in subclause 8.7.3.4.

#### 8.7.3.3.2 Void

#### 8.7.3.3.3 Reception via DCCH

Notification via DCCH is used to notify the UE about the start of a session for which a PL applies, to notify the UE about the establishment of a p-t-m radio bearer and to request a UE in PMM_idle state to establish a PMM connection to enable reception of a service provided via a p-t-p radio bearer.

Upon receiving the MBMS MODIFIED SERVICES INFORMATION message via DCCH, a UE in CELL_DCH shall:

1> handle the MBMS MODIFIED SERVICES INFORMATION message as specified in subclause 8.7.3.4.

### 8.7.3.4 UE action upon receiving MBMS MODIFIED SERVICES INFORMATION message

Upon receiving the MBMS MODIFIED SERVICES INFORMATION message, the UE shall act as follows for each of the services included in this messages provided that the service is included in variable MBMS_ACTIVATED_SERVICES and upper layers indicate that the session has not yet been received correctly (referred to as 'applicable services'):

1> if the IE "MBMS all unmodified p-t-m services" is included in the MBMS MODIFIED SERVICES INFORMATION messages:

2> for all services listed in the message UNMODIFIED SERVICES INFORMATION, provided that the service is included in variable MBMS_ACTIVATED_SERVICES, upper layers indicate that the session has not yet been received correctly (referred to as 'applicable services') and the IE "MBMS required UE action" in the message MBMS UNMODIFIED SERVICES INFORMATION is set to "Acquire PTM RB info":

3> continue acquiring the MBMS UNMODIFIED SERVICES INFORMATION, MBMS COMMON P-T-M RB INFORMATION, MBMS CURRENT CELL P-T-M RB INFORMATION, and the MBMS NEIGHBOURING CELL P-T-M RB INFORMATION messages without delaying reading of MCCH until the next modification period and without stopping at the end of the modification period, in accordance with subclause 8.7.1.3;

3> act upon the MBMS UNMODIFIED SERVICES INFORMATION MBMS COMMON P-T-M RB INFORMATION, MBMS CURRENT CELL P-T-M RB INFORMATION and the MBMS NEIGHBOURING CELL P-T-M RB INFORMATION message, if received, in accordance with subclause 8.7.5.

2> if the UE receives an MBMS service using a p-t-m radio bearer and the messages MBMS UNMODIFIED SERVICES INFORMATION and MBMS MODIFIED SERVICES INFORMATION do not contain an IE "MBMS required action" set to "Acquire PTM RB info" or set to "Acquire counting info – PTM RBs unmodified" for that service then the UE shall:

3> stop receiving the concerned MBMS service and clear all service specific information applicable for the concerned service.

1> act upon all received information elements as specified in subclause 8.6, unless specified otherwise in the following

1> if one or more preferred frequency applies for the applicable services:

2> if the UE is in CELL_FACH state:

3> acquire the MBMS GENERAL INFORMATION message;

3> act as specified in subclause 8.6.9.2 upon the IE "MBMS PL Service Restriction information" for the corresponding preferred frequency, as received in the MBMS GENERAL INFORMATION message.

2> delay acting upon the "MBMS Preferred frequency information" until receiving the relevant MCCH information i.e. the MBMS GENERAL INFORMATION message;

2> act upon the "MBMS Preferred frequency information" as specified in 8.6.9.2 for the service(s) that upper layers indicate to have highest priority.

1> perform the service prioritisation procedure as specified in subclause 8.5.26;

1> if applicable, use a single MBMS MODIFICATION REQUEST to request release of radio bearers corresponding with lower priority MBMS services provided p-t-p and/or to request a move to the preferred frequency as specified in subclause 8.5.26 and subclause 8.6.9.2 respectively;

1> the procedure ends.

### 8.7.3.5 UE fails to receive MBMS Notification information

If the UE fails to receive the MBMS MODIFIED SERVICES INFORMATION message within the current modification period, the UE shall:

1> Acquire the MBMS MODIFIED SERVICES INFORMATION and the MBMS UNMODIFIED SERVICES INFORMATION messages without delaying reading of MCCH until the next modification period and with stopping at the end of that modification period, in accordance with subclause 8.7.1.3;

1> act upon the received MBMS MODIFIED SERVICES INFORMATION and the MBMS UNMODIFIED SERVICES INFORMATION messages as specified in subclause 8.7.2.4.

## 8.7.4 MBMS counting




**Figure 8.7.4-1: MBMS counting, normal**

### 8.7.4.1 General

The MBMS counting procedure is used by the UE to inform UTRAN about its interest to receive an MBMS transmission. The procedure applies to UEs supporting MBMS that are in idle mode or in connected mode. In connected mode the procedure applies to the URA_PCH, Cell_PCH and/ or Cell_FACH states dependent upon the value of the IE "Connected mode counting scope".

### 8.7.4.2 Initiation

The UE initiates the MBMS counting procedure for an MBMS transmission upon receiving an MBMS MODIFIED SERVICES message including IE "MBMS required UE action" with the value set to 'Acquire counting info' or set to "Acquire counting info– PTM RBs unmodified".

### 8.7.4.3 Reception of the MBMS ACCESS INFORMATION

The UE shall acquire the MBMS ACCESS INFORMATION message without delaying reading of MCCH until the next modification period in accordance with subclause 8.7.1.3. If the procedure the UE would apply to respond to counting (Idle mode: RRC connection establishment, connected mode: Cell update) is ongoing, the UE may defer acquiring the MBMS ACCESS INFORMATION message until this procedure has completed.

The UE behaviour upon receiving an MBMS ACCESS INFORMATION message that is contained in more than one TTI is not specified.

Upon receiving the MBMS ACCESS INFORMATION message including one or more MBMS service(s) it has joined, the UE shall for each joined service:

1> if the UE is in idle mode:

2> draw a random number, "rand", uniformly distributed in the range: $0 \leq \text{rand} < 1$

2> if 'rand' is lower than the value indicated by the IE 'Access probability factor-Idle' for the concerned service:

3> indicate to upper layers that establishment of an RRC connection is required to receive the concerned MBMS service, with the establishment cause set to 'MBMS reception';

3> if the above condition applies for more than one service, initiate a single indication to upper layers;

3> if the RRC connection establishment succeeds, the procedure ends.

2> otherwise:

3> if the message triggering the MBMS counting procedure included the IE "Continue MCCH reading" with a value set to TRUE:

4> continue acquiring further MBMS ACCESS INFORMATION messages without delaying reading of MCCH until the next modification period and without stopping at the end of the modification period, in accordance with subclause 8.7.1.3.

3> otherwise:

4> continue acquiring further MBMS ACCESS INFORMATION messages without delaying reading of MCCH until the next modification period and with stopping at the end of the modification period, in accordance with subclause 8.7.1.3.

1> if the UE is in URA_PCH state, Cell_PCH or Cell_FACH state and the IE "Connected mode counting scope" indicates that counting is applicable for this UE state:

2> draw a random number, "rand", uniformly distributed in the range: $0 \leq \text{rand} < 1$.

2> if 'rand' is lower than the value indicated by the IE 'Access probability factor-connected' for the concerned service:

3> if a cell update has not been successfully transmitted for this service in the current modification period:

4> initiate the cell update procedure with 'Cell update cause' set to "MBMS reception", in accordance with subclause 8.3.1;

4> if the above condition applies for more than one service, initiate a single cell update;

4> if the cell update procedure succeeds,

5> the procedure ends.

2> otherwise:

3> if the message triggering the MBMS counting procedure included the IE "Continue MCCH reading" with a value set to TRUE:

4> continue acquiring further MBMS ACCESS INFORMATION messages without delaying reading of MCCH until the next modification period and without stopping at the end of the modification period, in accordance with subclause 8.7.1.3.

3> otherwise:

4> continue acquiring further MBMS ACCESS INFORMATION messages without delaying reading of MCCH until the next modification period and with stopping at the end of the modification period, in accordance with subclause 8.7.1.3.

1> otherwise:

2> the procedure ends;

Upon receiving the MBMS ACCESS INFORMATION message not including an MBMS service(s) the UE has joined:

1> the procedure ends;

### 8.7.4.4 Termination of the MBMS counting procedure

If the UE detects that the MBMS ACCESS INFORMATION message is not provided at an access info period; OR

If the UE receives an MBMS ACCESS INFORMATION message not including an MBMS service the UE has joined, the UE shall:

1> terminate the MBMS counting procedure.

### 8.7.4.5 Failure of the counting response procedure

If the counting response procedure (RRC connection establishment or Cell update) fails, the UE shall:

1> if the failure occurs in the same modification period as the one in which the UE initiated the counting response procedure; or

1> if the message triggering the MBMS counting procedure included the IE "Continue MCCH reading" with a value set to TRUE that is applicable in the modification period in which the UE detects the failure:

2> continue acquiring further MBMS ACCESS INFORMATION messages without delaying reading of MCCH until the next modification period and without stopping at the end of the modification period, in accordance with subclause 8.7.1.3.

1> otherwise:

2> the procedure ends.

## 8.7.5 MBMS p-t-m radio bearer configuration




**Figure 8.7.5-1: MBMS p-t-m radio bearer modification, normal**

### 8.7.5.1 General

The MBMS p-t-m radio bearer configuration procedure is used by the UE to acquire the (modified) radio bearer configuration for one or more MBMS services the UE has joined. The procedure applies to all UEs supporting MBMS, irrespective of their state (idle and connected mode: URA_PCH, CELL_PCH, CELL_FACH and CELL_DCH).

### 8.7.5.2 Initiation

The UE applies the MBMS p-t-m radio bearer configuration procedure whenever it detects that one of the services it has joined is provided by means of a p-t-m radio bearerer. This may occur as part of the MCCH acquisition or the MBMS Notification procedure.

### 8.7.5.3 Reception of the MBMS Current Cell PTM RB information

Upon completing the reception of the MBMS COMMON P-T-M RB INFORMATION and the MBMS CURRENT CELL P-T-M RB INFORMATION messages for an MBMS service it has joined, the UE shall:

1> if the UE is already receiving an MTCH and does not have the capability to receive the new service in addition:

2> the UE behaviour is undefined.

NOTE: In this case, the UE may request upper layers to prioritise the services and only receive the service(s) prioritised by upper layers.

1> act upon all received information elements as specified in subclause 8.6, unless specified otherwise in the following;

1> if the UE previously received the service by means of p-t-p radio bearers or;

1> if the UE previously received the service by means of a p-t-m radio bearer from a cell belonging to another MBMS cell group:

2> re-establish RLC;

2> re-initialise PDCP.

1> start immediately to use the indicated configuration unless specified otherwise;

1> start or continue receiving the indicated p-t-m radio bearers depending on its UE capabilities.

The UE shall continue acquiring the above messages until it has received a consistent set of MCCH information i.e. the MBMS MODIFIED SERVICES INFORMATION message, MBMS UNMODIFIED SERVICES INFORMATION message, MBMS COMMON P-T-M RB INFORMATION and the MBMS CURRENT CELL P-T-M RB INFORMATION message should be acquired in the same modification period.

### 8.7.5.4 Reception of the MBMS Neighbouring Cell PTM RB information

Upon receiving the MBMS NEIGHBOURING CELL P-T-M RB INFORMATION message for an MBMS service it has joined, the UE shall

1> start immediately to use the indicated neighbouring cells and configuration, or a subset of them, for L1- or L2 combining unless specified otherwise;

1> start or continue receiving the indicated p-t-m radio bearers from the selected neighbouring cells depending on its UE capabilities.

The UE shall apply MBMS NEIGHBOURING CELL P-T-M RB INFORMATION only in combination with an MBMS MODIFIED SERVICES INFORMATION message, MBMS UNMODIFIED SERVICES INFORMATION message, MBMS COMMON P-T-M RB INFORMATION and MBMS CURRENT CELL P-T-M RB INFORMATION message acquired in the same modification period.

## 8.7.6 MBMS modification request

**Figure 8.7.6-1: MBMS modification request, normal**

### 8.7.6.1 General

The MBMS modification request procedure is used by the UE to request UTRAN to release the p-t-p radio bearers ofone or more MBMS services the UE is receiving. The procedure is also used to request to be moved to a preferred frequency applicable for one or more (prioritised) MBMS services, the UE has joined. The procedure applies to all UEs supporting MBMS, that are in state CELL_DCH.

### 8.7.6.2 Initiation

The UE shall initiate the MBMS modification request procedure in the following cases:

1> the preferred frequency applicable for the MBMS service prioritised by upper layers is different from the currently used frequency;

1> upper layers request to discontinue reception of an MBMS service provided via a p-t-p radio bearer e.g. because this inhibits reception of a higher priority service.

NOTE: The above case may occur upon receiving a dedicated notification or in other cases eg. a change of transfer mode from p-t-p to p-t-m for the UE's highest priority MBMS service.

The UE shall set the contents of the MBMS MODIFICATION REQUEST message as follows:

1> if the preferred frequency applicable for the MBMS service prioritised by upper layers is different from the currently used frequency:

2> include the IE "MBMS preferred frequency request" and set it to the prioritised MBMS service identity;

1> if upper layers request to discontinue reception of an MBMS service provided via a p-t-p radio bearer:

2> include the p-t-p radio bearers used for the corresponding MBMS services within the IE "MBMS RB list requested to be released".

### 8.7.6.3 Reception of a MBMS MODIFICATION REQUEST message by the UTRAN

Upon reception of a MBMS MODIFICATION REQUEST message, the UTRAN may take further action depending on the contents of the received message.

The procedure ends.

## 8.7.7 MBMS service scheduling



**Figure 8.7.7-1: MBMS service scheduling, normal**

### 8.7.7.1 General

The MBMS service scheduling procedure is used by the UE that is receiving one or more MBMS services that the UE has joined to acquire the MBMS scheduling information for the MBMS services. The procedure applies to all UEs that are receiving an MBMS service provided via a p-t-m radio bearer, irrespective of their state (idle and connected mode: URA_PCH, CELL_PCH, CELL_FACH and CELL_DCH).

### 8.7.7.2 Initiation

The UE may initiate the MBMS service scheduling procedure for any scheduling period of the concerned MBMS service while receiving an SCCPCH carrying an MBMS service.

### 8.7.7.3 Reception of the MBMS scheduling information

Upon receiving the MBMS SCHEDULING INFORMATION message, the UE should:

1> act as follows for each of the services included in these messages provided that the service is included in variable MBMS_ACTIVATED_SERVICES;

1> act upon all received information elements as specified in subclause 8.6, unless specified otherwise in the following.

The procedure ends.

# 9 Handling of unknown, unforeseen and erroneous protocol data

## 9.1 General

This subclause specifies procedures for the handling of unknown, unforeseen, and erroneous protocol data by the receiving entity. These procedures are called "error handling procedures", but in addition to provide recovery mechanisms for error situations they define a compatibility mechanism for future extensions of the protocol.

The error handling procedures specified in this subclause shall apply to all RRC messages. When there is a specific handling for messages received on different logical channels this is specified.

For system information received on the BCCH, the error handling procedures are applied on the BCCH message SYSTEM INFORMATION, the re-assembled system information segments as well as the system information blocks (including the master information block and the scheduling blocks), with specific error handling as specified below.

When the UE receives an RRC message, it shall set the variable PROTOCOL_ERROR_REJECT to FALSE and then perform the checks in the order as defined below.

The error cases specified in the following include the handling upon reception of spare values. This behaviour also applies in case the actual value of the IE results from mapping the originally sent IE value. Moreover, in certain error cases, as specified in the following, default values apply. In this case, the default values specified within the ASN.1, the tabular and the procedure specifications apply.

## 9.2 ASN.1 violation or encoding error

If the UE receives an RRC message on the DCCH for which the encoded message does not result in any valid abstract syntax value [49] (or "encoding error"), it shall perform the following. The UE shall:

1> set the variable PROTOCOL_ERROR_REJECT to TRUE;

1> transmit an RRC STATUS message on the uplink DCCH. The IE "Protocol error information" shall contain an IE "Protocol error cause" set to "ASN.1 violation or encoding error";

1> when RRC STATUS message has been submitted to lower layers for transmission:

2> continue with any ongoing processes and procedures as if the invalid message had not been received.

NOTE In this case, the UE does not perform procedure specific error handling according to clause 8.

If the UE receives an RRC message sent via a radio access technology other than UTRAN, for which the encoded message does not result in any valid abstract syntax, the UE shall:

1> set the variable PROTOCOL_ERROR_REJECT to TRUE;

1> set the IE "Protocol error cause" in the variable PROTOCOL_ERROR_INFORMATION to "ASN.1 violation or encoding error";

1> perform procedure specific error handling according to clause 8.

If a reassembled set of system information segments received in messages on the BCCH does not result in any valid abstract syntax value, the UE shall:

1> ignore the reassembled set of system information segments;

1> treat the rest of each message containing the ignored system information segments as if those segments were not present.

If the UE receives an RRC message on the BCCH, PCCH, CCCH, MCCH, MSCH or SHCCH for which the encoded message does not result in any valid abstract syntax value, it shall ignore the message.

## 9.3 Unknown or unforeseen message type

If a UE receives an RRC message on the DCCH with a message type not defined for the DCCH it shall:

1> set the variable PROTOCOL_ERROR_REJECT to TRUE;

1> transmit an RRC STATUS message on the uplink DCCH. The IE "Protocol error information" shall contain an IE "Protocol error cause" set to "Message type non-existent or not implemented";

1> when the RRC STATUS message has been submitted to lower layers for transmission:

2> continue with any ongoing processes and procedures as if the invalid message had not been received.

If the UE receives an RRC message on the BCCH, PCCH, CCCH, MCCH, MSCH or SHCCH with a message type not defined for the logical channel type the message was received on, it shall ignore the message.

## 9.3a Unsolicited received message

If the UE receives any of the following messages:

- an RRC CONNECTION SETUP message addressed to the UE on the CCCH; or
- an RRC CONNECTION REJECT message addressed to the UE on the CCCH; or
- a UE CAPABILITY INFORMATION CONFIRM message on the DCCH; or
- a CELL UPDATE CONFIRM message addressed to the UE on the CCCH or on the DCCH; or
- a URA UPDATE CONFIRM message addressed to the UE on the CCCH or on the DCCH

and no procedure is ongoing according to clause 8 which expects the message to be received:

the UE shall:

1> ignore the received message.

## 9.3b Unexpected critical message extension

If the UE receives an RRC message on the DCCH, or addressed to the UE on the CCCH or on the SHCCH, or sent via a radio access technology other than UTRAN, containing an undefined critical message extension, the UE shall:

1> set the variable PROTOCOL_ERROR_REJECT to TRUE;

1> set the IE "Protocol error cause" in the variable PROTOCOL_ERROR_INFORMATION to "Message extension not comprehended";

1> if the IE "Message Type" of the received message is not present in the table "Rejected transactions" in the variable TRANSACTIONS:

2> store the IE "Message type" of the received message in the table "Rejected transactions" in the variable TRANSACTIONS; and

2> set the IE "RRC transaction identifier" to zero in that table entry.

1> perform procedure specific error handling according to clause 8.

If the UE receives an RRC message on the BCCH, MCCH, MSCH or PCCH, containing an undefined critical message extension, the UE shall:

1> ignore the message.

## 9.4 Unknown or unforeseen information element value, mandatory information element

If the UE receives an RRC message on the DCCH, or addressed to the UE on the CCCH or on the SHCCH, or sent via a radio access technology other than UTRAN, with a mandatory IE having a value, including choice, reserved for future extension (spare) or a value not used in this version of the specification (e.g. a dummy value), the UE shall:

1> if a default value of the IE is defined:

2> treat the rest of the message using the default value of the IE.

1> if no default value of the IE is defined:

2> set the variable PROTOCOL_ERROR_REJECT to TRUE;

2> set the IE "Protocol error cause" in the variable PROTOCOL_ERROR_INFORMATION to "Information element value not comprehended";

2> perform procedure specific error handling according to clause 8.

If the UE receives a system information block on the BCCH with a mandatory IE having a value reserved for future extension (spare)or a value not used in this version of the specification (e.g. a dummy value), the UE shall:

1> if a default value of the IE is defined:

2> treat the rest of the system information block using the default value of the IE.

1> if no default value of the IE is defined:

2> ignore the system information block.

If the UE receives an RRC message on the BCCH, MCCH, MSCH or PCCH with a mandatory IE having a value reserved for future extension (spare) or a value not used in this version of the specification (e.g. a dummy value), the UE shall:

1> if a default value of the IE is defined:

2> treat the rest of the message using the default value of the IE.

1> if no default value of the IE is defined:

2> ignore the message.

## 9.5 Conditional information element error

If the UE receives an RRC message on the DCCH, BCCH, PCCH, MCCH, MSCH or addressed to the UE on the CCCH or on the SHCCH, or sent via a radio access technology other than UTRAN, for which the specified conditions for absence of a conditional IE are met and that IE is present, the UE shall:

1> ignore the IE;

1> treat the rest of the message as if the IE was not present.

If the UE receives an RRC message on the DCCH, or addressed to the UE on the CCCH or on the SHCCH, or sent via a radio access technology other than UTRAN, for which the specified conditions for presence of a conditional IE are met and that IE is absent, the UE shall:

1> set the variable PROTOCOL_ERROR_REJECT to TRUE;

1> set the IE "Protocol error cause" in the variable PROTOCOL_ERROR_INFORMATION to " Information element missing";

1> perform procedure specific error handling according to clause 8.

If the UE receives a system information block on the BCCH for which the specified conditions for presence of a conditional IE are met and that IE is absent, the UE shall:

1> ignore the system information block.

If the UE receives an RRC message on the BCCH, MCCH, MSCH or PCCH for which the specified conditions for presence of a conditional IE are met and that IE is absent, the UE shall:

1> ignore the message.

## 9.6 Unknown or unforeseen information element value, conditional information element

If the UE receives an RRC message on the DCCH, or addressed to the UE on the CCCH or on the SHCCH, or sent via a radio access technology other than UTRAN, for which the specified conditions for presence of a conditional IE are met, that IE is present, and that IE has a value, including choice, reserved for future extension (spare) or a value not used in this version of the specification (e.g. a dummy value), the UE shall:

1> if a default value of the IE is defined:

2> treat the rest of the message using the default value of the IE.

1> if no default value of the IE is defined:

2> set the variable PROTOCOL_ERROR_REJECT to TRUE;

2> set the IE "Protocol error cause" in the variable PROTOCOL_ERROR_INFORMATION to "Information element value not comprehended";

2> perform procedure specific error handling according to clause 8.

If the UE receives a system information block on the BCCH for which the specified conditions for presence of a conditional IE are met, that IE is present, and that IE has a value, including choice, reserved for future extension (spare) or a value not used in this version of the specification (e.g. a dummy value), the UE shall:

1> if a default value of the IE is defined:

2> treat the rest of the system information block using the default value of the IE.

1> if no default value of the IE is defined:

2> ignore the system information block.

If the UE receives an RRC message on the BCCH, MCCH, MSCH or PCCH for which the specified conditions for presence of a conditional IE are met, that IE is present, and that IE has a value, including choice, reserved for future extension (spare) or a value not used in this version of the specification (e.g. a dummy value), the UE shall:

1> if a default value of the IE is defined:

2> treat the rest of the message using the default value of the IE.

1> if no default value of the IE is defined:

2> ignore the message.

## 9.7 Unknown or unforeseen information element value, optional information element

If the UE receives an RRC message on the DCCH, or addressed to the UE on the CCCH or on the SHCCH, or sent via a radio access technology other than UTRAN, with an optional IE having a value, including choice, reserved for future extension (spare) or a value not used in this version of the specification (e.g. a dummy value), it shall:

1> ignore the value of the IE;

1> treat the rest of the message as if the IE was not present.

If the UE receives a system information block on the BCCH with an optional IE having a value, including choice, reserved for future extension (spare) or a value not used in this version of the specification (e.g. a dummy value), it shall:

1> ignore the value of the IE;

1> treat the rest of the system information block as if the IE was not present.

If the UE receives an RRC message on the BCCH, MCCH or MSCH or PCCH with an optional IE having a value, including choice, reserved for future extension (spare) or a value not used in this version of the specification (e.g. a dummy value), it shall:

1> ignore the value of the IE;

1> treat the rest of the message as if the IE was not present.

## 9.8 Unexpected non-critical message extension

If the UE receives an RRC message on the DCCH, or addressed to the UE on the CCCH or on the SHCCH, or sent via a radio access technology other than UTRAN, containing an undefined non-critical message extension, the UE shall:

1> if the non critical extension is included in the "Variable Length Extension Container":

2> ignore the content of the extension and the contents of this container after the not comprehended extension, and continue decoding the rest of the message.

1> otherwise:

2> ignore the content of the extension and the message contents after the extension, but treat the parts of the message up to the extension normally.

If the UE receives a system information block on the BCCH containing an undefined non-critical message extension, the UE shall:

1> ignore the content of the extension and the system information block contents after the extension, but treat the parts of the system information block up to the extension normally.

If the UE receives an RRC message on the BCCH, MCCH or MSCH or PCCH, containing an undefined non-critical message extension, the UE shall:

1> ignore the content of the extension and the message contents after the extension, but treat the parts of the message up to the extension normally.

## 9.9 Handling of errors in nested information elements

An erroneous IE may be included in another IE, which may be included in another IE and so on. This subclause specifies the handling of errors in mandatory IEs as well as for conditional IEs for which the specified conditions for presence are met, that are nested in another IE.

In case the UE receives an IE (IE1) that includes a mandatory IE (IE1-1) having a value, including choice, reserved for future extension (spare) or a value not used in this version of the specification (e.g. a dummy value), the UE shall:

1> consider IE1 to have an undefined value; and

1> apply the corresponding generic error handling to IE1.

In case there are many IE nesting levels, in all of which the IE is mandatory while no default value is defined, this treatment may need to be repeated several times. The following example illustrates the general principle.

```
ExampleMessage ::=                  SEQUENCE {
    ie1                                 IE1                                 OPTIONAL,
    ie2                                 IE2
}

IE1 ::=                              SEQUENCE {
    ie1-1                               INTEGER (1..16),
    -- ie1-1 values 13..16 are spare and should not be used in this version of the protocol
    ie1-2                               IE1-2                               OPTIONAL,
    ie1-3                               IE1-3
}
```

If in the above example, UTRAN would include ie1 and set ie1-1 to value 13, the UE experiences an error in a mandatory IE. The guideline outlined in the previous then means that the UE shall not discard the entire message but instead consider "ie1" to have an unknown value. Since IE1 is optional, the generic error handling would be to ignore "ie1".

In case the UE receives an IE (IE1) that includes a list of another IE (IE1-1) for which one or more entries in the list have a value, including choice, reserved for future extension (spare) or a value not used in this version of the specification (e.g. a dummy value), the UE shall:

1> consider the list as if these entries were not included.

NOTE: In case the above generic error handling procedures do not result in the desired behaviour, the introduction of spares may need to be reconsidered.

# 10 Message and information element functional definition and content

## 10.1 General

The function of each Radio Resource Control message together with message contents in the form of a list of information elements is defined in subclause 10.2.

Functional definitions of the information elements are then described in subclause 10.3.

Information elements are marked as either MP - Mandatory present, MD - Mandatory with default value, OP - Optional, CV - Conditional on value or CH - Conditional on history (see Table 10.1 with information extracted from [14]).

**Table 10.1: Meaning of abbreviations used in RRC messages and information elements**

| Abbreviation | Meaning |
|---|---|
| MP | Mandatory present<br>A value for that information is always needed, and no information is provided about a particular default value. If ever the transfer syntax allows absence (e.g., due to extension), then absence leads to an error diagnosis. |
| MD | Mandatory with default value<br>A value for that information is always needed, and a particular default value is mentioned (in the 'Semantical information' column). This opens the possibility for the transfer syntax to use absence or a special pattern to encode the default value. |
| CV | Conditional on value<br>The need for a value for that information depends on the value of some other IE or IEs, and/or on the message flow (e.g., channel, SAP). The need is specified by means of a condition, the result of which may be that the information is mandatory present, mandatory with default value, not needed or optional.<br>If one of the results of the condition is that the information is mandatory present, the transfer syntax must allow for the presence of the information. If in this case the information is absent an error is diagnosed.<br>If one of the results of the condition is that the information is mandatory with default value, and a particular default value is mentioned (in the 'Semantical information' column), the transfer syntax may use absence or a special pattern to encode the default value.<br>If one of the results of the condition is that the information is not needed, the transfer syntax must allow encoding the absence. If in this case the information is present, it will be ignored. In specific cases however, an error may be diagnosed instead.<br>If one of the results of the condition is that the information is optional, the transfer syntax must allow for the presence of the information. In this case, neither absence nor presence of the information leads to an error diagnosis. |
| CH | Conditional on history<br>The need for a value for that information depends on information obtained in the past (e.g., from messages received in the past from the peer). The need is specified by means of a condition, the result of which may be that the information is mandatory present, mandatory with default value, not needed or optional.<br>The handling of the conditions is the same as described for CV. |
| OP | Optional<br>The presence or absence is significant and modifies the behaviour of the receiver. However whether the information is present or not does not lead to an error diagnosis. |

### 10.1.1 Protocol extensions

RRC messages may be extended in future versions of this protocol, either by adding values for choices, enumerated and size constrained types or by adding information elements. An important aspect concerns the behaviour of a UE, conforming to this revision of the standard, upon receiving a not comprehended future extension. The details of this error handling behaviour are provided in clause 9.

NOTE 1: By avoiding the need for partial decoding (skipping uncomprehended IEs to continue decoding the remainder of the message), the RRC protocol extension mechanism also avoids the overhead of length determinants for extensions. "Variable length extension containers" (i.e. non critical extension containers that have their abstract syntax defined using the ASN.1 type "BIT STRING") have been defined to support the introduction of extensions to a release after the subsequent release is frozen (and UEs based on that subsequent release may appear). For this container a length determinant is used, which facilitates partial decoding of the container as well as the decoding of the extensions included after the container.

Two kinds of protocol extensions are distinguished: non-critical and critical extensions. In general, a receiver shall process a message including not comprehended non-critical extensions as if the extensions were absent. However, a receiver shall entirely reject a message including not comprehended critical extensions (there is no partial rejection) and notify the sender, as specified in clause 9.

The general mechanism for adding critical extensions is by defining a new version of the message, which is indicated at the beginning of the message.

The UE shall always comprehend the complete transfer syntax specified for the protocol version it supports; if the UE comprehends the transfer syntax defined within protocol version A for message 1, it shall also comprehend the transfer syntax defined within protocol version A for message 2.

The following table shows for which messages only non-critical extensions may be added while for others both critical and non-critical extensions may be added.

NOTE 2: Critical extensions can only be added to certain downlink messages.

| Extensions | Message |
|---|---|
| Critical and non-critical extensions | ACTIVE SET UPDATE 10.2.1<br>ASSISTANCE DATA DELIVERY 10.2.4<br>CELL CHANGE ORDER FROM UTRAN 10.2.5<br>CELL UPDATE CONFIRM 10.2.8<br>COUNTER CHECK 10.2.9<br>DOWNLINK DIRECT TRANSFER 10.2.11<br>HANDOVER TO UTRAN COMMAND 10.2.16a<br>HANDOVER FROM UTRAN COMMAND 10.2.15<br>MEASUREMENT CONTROL 10.2.17<br>PHYSICAL CHANNEL RECONFIGURATION 10.2.22<br>PHYSICAL SHARED CHANNEL ALLOCATION 10.2.25<br>RADIO BEARER RECONFIGURATION 10.2.27<br>RADIO BEARER RELEASE 10.2.30<br>RADIO BEARER SETUP 10.2.33<br>RRC CONNECTION REJECT 10.2.36<br>RRC CONNECTION RELEASE 10.2.37<br>RRC CONNECTION SETUP 10.2.40<br>SECURITY MODE COMMAND 10.2.43<br>SIGNALLING CONNECTION RELEASE 10.2.46<br>TRANSPORT CHANNEL RECONFIGURATION 10.2.50<br>UE CAPABILITY ENQUIRY 10.2.55<br>UE CAPABILITY INFORMATION CONFIRM 10.2.57<br>UPLINK PHYSICAL CHANNEL CONTROL 10.2.59<br>URA UPDATE CONFIRM 10.2.61<br>UTRAN MOBILITY INFORMATION 10.2.62 |
| Non-critical extensions only | ACTIVE SET UPDATE COMPLETE 10.2.2<br>ACTIVE SET UPDATE FAILURE 10.2.3<br>CELL CHANGE ORDER FROM UTRAN FAILURE 10.2.6<br>CELL UPDATE 10.2.7<br>COUNTER CHECK RESPONSE 10.2.10<br>HANDOVER TO UTRAN COMPLETE 10.2.16b<br>INITIAL DIRECT TRANSFER 10.2.16c<br>HANDOVER FROM UTRAN FAILURE 10.2.16<br>MBMS ACCESS INFORMATION 10.2.16e<br>MBMS COMMON P-T-M RB INFORMATION 10.2.16f<br>MBMS CURRENT CELL P-T-M RB INFORMATION 10.2.16g<br>MBMS GENERAL INFORMATION 10.2.16h<br>MBMS MODIFICATION REQUEST 10.2.16i<br>MBMS MODIFIED SERVICES INFORMATION 10.2.16j<br>MBMS NEIGHBOURING CELL P-T-M RB INFORMATION 10.2.16k |

| Extensions | Message |
|---|---|
| | MBMS SCHEDULING INFORMATION 10.2.16L<br>MBMS UNMODIFIED SERVICES INFORMATION 10.2.16m<br>MEASUREMENT CONTROL FAILURE 10.2.18<br>MEASUREMENT REPORT 10.2.19<br>PAGING TYPE 1 10.2.20<br>PAGING TYPE 2 10.2.21<br>PHYSICAL CHANNEL RECONFIGURATION COMPLETE 10.2.23<br>PHYSICAL CHANNEL RECONFIGURATION FAILURE 10.2.24<br>PUSCH CAPACITY REQUEST 10.2.26<br>RADIO BEARER RECONFIGURATION COMPLETE 10.2.28<br>RADIO BEARER RECONFIGURATION FAILURE 10.2.29<br>RADIO BEARER RELEASE COMPLETE 10.2.31<br>RADIO BEARER RELEASE FAILURE 10.2.32<br>RADIO BEARER SETUP COMPLETE 10.2.34<br>RADIO BEARER SETUP FAILURE 10.2.35<br>RRC CONNECTION RELEASE COMPLETE 10.2.38<br>RRC CONNECTION REQUEST 10.2.39<br>RRC CONNECTION SETUP COMPLETE 10.2.41<br>RRC STATUS 10.2.42<br>SECURITY MODE COMPLETE 10.2.44<br>SECURITY MODE FAILURE 10.2.45<br>SIGNALLING CONNECTION RELEASE INDICATION 10.2.47<br>Master Information Block 10.2.48.8.1<br>System Information Block type 1 to<br>System Information Block type 18 10.2.48.8.4 to 10.2.48.8.21<br>SYSTEM INFORMATION CHANGE INDICATION 10.2.49<br>TRANSPORT CHANNEL RECONFIGURATION COMPLETE 10.2.51<br>TRANSPORT CHANNEL RECONFIGURATION FAILURE 10.2.52<br>TRANSPORT FORMAT COMBINATION CONTROL 10.2.53<br>TRANSPORT FORMAT COMBINATION CONTROL FAILURE 10.2.54<br>UE CAPABILITY INFORMATION 10.2.56<br>UPLINK DIRECT TRANSFER 10.2.58<br>URA UPDATE 10.2.60<br>UTRAN MOBILITY INFORMATION CONFIRM 10.2.63<br>UTRAN MOBILITY INFORMATION FAILURE 10.2.64 |
| No extensions | SYSTEM INFORMATION 10.2.48<br>First Segment 10.2.48.1<br>Subsequent or last Segment 10.2.48.3<br>Complete SIB 10.2.48.5<br>SIB content 10.2.48.8.1 |

NOTE 3: For the SYSTEM INFORMATION message protocol extensions are only possible at the level of system information blocks.

### 10.1.1.1 Non-critical extensions

#### 10.1.1.1.1 Extension of an information element with additional values or choices

In future versions of this protocol, non-critical values may be added to choices, enumerated and size constrained types.

For choices, enumerated and size constrained types it is possible to indicate how many non-critical spare values need to be reserved for future extension. In this case, the tabular format should indicate the number of spare values that are needed. The value range defined in ASN.1 for the extensible IE should include the number of spares that are needed, since a value outside the range defined for this IE will result in a general ASN.1 violation error.

For downlink messages, spare values may be defined for non-critical information elements for which the need is specified to be MD or OP (or CV case leading to MD or OP). In this case, a receiver not comprehending the received spare value shall consider the information element to have the default value or consider it to be absent respectively.

For uplink messages spare values may be defined for all information elements, including those for which the need is specified to be MP (or CV case leading to MP).

In all cases at most one spare should be defined for choices. In this case, information elements applicable to the spare choices shall be added to the end of the message.

#### 10.1.1.1.2 Extension of a message with additional information elements

In future versions of this protocol, non-critical information elements may be added to RRC messages. These additional information elements shall be normally appended at the end of the message; the transfer syntax specified in this revision of the standard facilitates this. A receiver conformant to this revision of the standard shall accept such extension, and proceed as if it was not included.
A transmitter conformant to this version of the standard shall not include an extension reserved for introducing non critical extensions in later versions of the standard; i.e. the corresponding parameter defined in the ASN.1 shall be absent.

NOTE: If an extension, reserved for future non-critical extensions, is included (even if it is empty), this may result in transfer syntax errors when received by an implementation conforming to a later version of the standard.

Extensions to a release that are introduced after the subsequent release is frozen may however be inserted prior to the end of the message. To facilitate this, "variable length extension containers" have been introduced in most messages.

### 10.1.1.2 Critical extensions

#### 10.1.1.2.1 Extension of an information element with additional values or choices

In versions of this protocol, choices, enumerated and size constrained types may be extended with critical values. For extension with critical values the general critical extension mechanism is used, i.e. for this no spare values are reserved since backward compatibility is not required.

#### 10.1.1.2.2 Extension of a message with additional information elements

In future versions of this protocol, RRC messages may be extended with new information elements. Since messages including critical extensions are rejected by receivers not comprehending them, these messages may be modified completely, e.g. IEs may be inserted at any place and IEs may be removed or redefined.

## 10.2 Radio Resource Control messages

## 10.2.1 ACTIVE SET UPDATE

NOTE: Only for FDD.

This message is used by UTRAN to add, replace or delete radio links in the active set of the UE.

RLC-SAP: AM or UM

Logical channel: DCCH

Direction: UTRAN → UE

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| Message Type | MP | | Message Type | | |
| **UE information elements** | | | | | |
| RRC transaction identifier | MP | | RRC transaction identifier 10.3.3.36 | | |
| Integrity check info | CH | | Integrity check info 10.3.3.16 | | |
| Activation time | MD | | Activation time 10.3.3.1 | Default value is "now". | |
| New U-RNTI | OP | | U-RNTI | | |

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| | | | 10.3.3.47 | | |
| New H-RNTI | OP | | H-RNTI 10.3.3.14a | | REL-6 |
| New Primary E-RNTI | OP | | E-RNTI 10.3.3.10a | | REL-6 |
| New Secondary E-RNTI | OP | | E-RNTI 10.3.3.10a | | REL-6 |
| **CN information elements** | | | | | |
| CN Information info | OP | | CN Information info 10.3.1.3 | | |
| **Phy CH information elements** | | | | | |
| **Uplink radio resources** | | | | | |
| Maximum allowed UL TX power | MD | | Maximum allowed UL TX power 10.3.6.39 | Default value is the existing "maximum UL TX power. | |
| **Downlink radio resources** | | | | | |
| Radio link addition information | OP | 1 to <maxRL-1> | | Radio link addition information required for each RL to add | |
| >Radio link addition information | MP | | Radio link addition information 10.3.6.68 | | |
| Radio link removal information | OP | 1 to <maxRL> | | Radio link removal information required for each RL to remove | |
| >Radio link removal information | MP | | Radio link removal information 10.3.6.69 | | |
| TX Diversity Mode | MD | | TX Diversity Mode 10.3.6.86 | Default value is the TX diversity mode currently used in all or part of the active set. | |
| DPC Mode | OP | | Enumerated (Single TPC, TPC triplet in soft) | "Single TPC" is DPC_Mode=0 and "TPC triplet in soft" is DPC_mode=1 in [29]. | REL-5 |
| Serving HS-DSCH cell information | OP | | Serving HS-DSCH cell information 10.3.6.74a | | REL-6 |
| E-DCH reconfiguration information | OP | | E-DCH reconfiguration information 10.3.6.69a | | REL-6 |

## 10.2.2 ACTIVE SET UPDATE COMPLETE

NOTE: For FDD only.

This message is sent by UE when active set update has been completed.

RLC-SAP: AM

Logical channel: DCCH

Direction: UE→UTRAN

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Message Type | MP | | Message Type | |
| **UE information elements** | | | | |
| RRC transaction identifier | MP | | RRC transaction identifier 10.3.3.36 | |
| Integrity check info | CH | | Integrity check info 10.3.3.16 | |

## 10.2.3 ACTIVE SET UPDATE FAILURE

NOTE: Only for FDD.

This message is sent by UE if the update of the active set has failed, e.g. because the radio link is not a part of the active set.

RLC-SAP: AM

Logical channel: DCCH

Direction: UE→UTRAN

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Message Type | MP | | Message Type | |
| **UE information elements** | | | | |
| RRC transaction identifier | MP | | RRC transaction identifier 10.3.3.36 | |
| Integrity check info | CH | | Integrity check info 10.3.3.16 | |
| Failure cause | MP | | Failure cause and error information 10.3.3.14 | |

## 10.2.4 ASSISTANCE DATA DELIVERY

This message is sent by UTRAN to convey UE positioning assistance data to the UE.

RLC-SAP: AM

Logical channel: DCCH

Direction: UTRAN→UE

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Message Type | MP | | Message Type | |
| **UE information elements** | | | | |
| RRC transaction identifier | MP | | RRC | |

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| | | | transaction identifier 10.3.3.36 | |
| Integrity check info | CH | | Integrity check info 10.3.3.16 | |
| **Measurement Information elements** | | | | |
| UE positioning OTDOA assistance data for UE-based | OP | | UE positioning OTDOA assistance data for UE-based 10.3.7.103a | |
| UE positioning GPS assistance data | OP | | UE positioning GPS assistance data 10.3.7.90 | |

## 10.2.5 CELL CHANGE ORDER FROM UTRAN

This message is used to order a cell change from UTRA to another radio access technology, e.g., GSM.

RLC-SAP: AM

Logical channel: DCCH

Direction: UTRAN→UE

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| Message Type | MP | | Message Type | | |
| **UE information elements** | | | | | |
| RRC transaction identifier | MP | | RRC transaction identifier 10.3.3.36 | | |
| Integrity check info | CH | | Integrity check info 10.3.3.16 | | |
| Activation time | MD | | Activation time 10.3.3.1 | Default value is "now" | |
| **RB Information elements** | | | | | |
| RAB information list | OP | 1 to <maxRABsetup> | | This IE should not be included in this version of the protocol. | |
| >RAB info | MP | | RAB info 10.3.4.8 | | |
| **Other information elements** | | | | | |
| Target cell description | MP | | | | |
| >CHOICE *Radio Access Technology* | MP | | | Two spare values are needed. | |
| >>GSM | | | | | |
| >>>BSIC | MP | | BSIC 10.3.8.2 | | |
| >>>Band Indicator | MP | | Enumerated (DCS 1800 band used, PCS 1900 | Indicates how to interpret the BCCH ARFCN | |

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| | | | band used) | | |
| >>>BCCH ARFCN | MP | | Integer (0..1023) | [45] | |
| >>>NC mode | OP | | Bit string(3) | Includes bits b1-b3 of the NC mode IE specified in [43]. b1 is the least significant bit. NOTE: The Bit string should be extended to 4 bits in a later version of the message. | |
| >>>CHOICE *GERAN System Info type* | OP | | | | REL-5 |
| >>>>SI | | | GERAN system information 10.3.8.4f | See [44] | REL-5 |
| >>>>PSI | | | GERAN system information 10.3.8.4f | See [44] | REL-5 |
| >>IS-2000 | | | | | |

## 10.2.6 CELL CHANGE ORDER FROM UTRAN FAILURE

This message is sent on the RRC connection used before the Cell change order from UTRAN was executed. The message indicates that the UE has failed to seize the new channel in the other radio access technology.

RLC-SAP: AM

Logical channel: DCCH

Direction: UE→UTRAN

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Message Type | MP | | Message Type | |
| **UE information elements** | | | | |
| RRC transaction identifier | MP | | RRC transaction identifier 10.3.3.36 | |
| Integrity check info | CH | | Integrity check info 10.3.3.16 | |
| **Other information elements** | | | | |
| Inter-RAT change failure | MP | | Inter-RAT change failure 10.3.8.5 | |

## 10.2.7 CELL UPDATE

This message is used by the UE to initiate a cell update procedure.

RLC-SAP: TM

Logical channel: CCCH

Direction: UE→UTRAN

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| Message Type | MP | | Message Type | | |
| **UE information elements** | | | | | |
| U-RNTI | MP | | U-RNTI 10.3.3.47 | | |
| RRC transaction identifier | CV-*Failure* | | RRC transaction identifier 10.3.3.36 | | |
| Integrity check info | CH | | Integrity check info 10.3.3.16 | | |
| START list | MP | 1 to <maxCN domains> | | START [40] values for all CN domains. | |
| >CN domain identity | MP | | CN domain identity 10.3.1.1 | | |
| >START | MP | | START 10.3.3.38 | START value to be used in this CN domain. | |
| AM_RLC error indication(RB2, RB3 or RB4) | MP | | Boolean | TRUE indicates AM_RLC unrecoverable error [16] occurred on RB2, RB3 or RB4 in the UE | |
| AM_RLC error indication(RB>4) | MP | | Boolean | TRUE indicates AM_RLC unrecoverable error [16] occurred on RB>4 in the UE | |
| Cell update cause | MP | | Cell update cause 10.3.3.3 | | |
| Traffic volume indicator | OP | | Enumerated (true) | This IE shall be set to TRUE when the criteria for event based traffic volume measurement reporting is fulfilled. Absence of this element means not fulfilled. | REL-6 |
| Failure cause | OP | | Failure cause and error information 10.3.3.14 | | |
| RB timer indicator | MP | | RB timer indicator 10.3.3.28 | | |

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| Establishment cause | OP | | Establishment cause 10.3.3.11 | | REL-5 |
| Reconfiguration Status Indicator | OP | | Enumerated (true) | TRUE indicates a reconfiguration procedure is ongoing within the UE or a response message has been submitted to RLC and the UE is waiting for the layer 2 ACK. | REL-6 |
| **Measurement information elements** | | | | | |
| Measured results on RACH | OP | | Measured results on RACH 10.3.7.45 | | |

| Condition | Explanation |
|---|---|
| *Failure* | This IE is mandatory present if the IE "Failure cause" is present and not needed otherwise. |

## 10.2.8 CELL UPDATE CONFIRM

This message confirms the cell update procedure and can be used to reallocate new RNTI information for the UE valid in the new cell.

RLC-SAP: UM

Logical channel: CCCH or DCCH

Direction: UTRAN→UE

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| Message Type | MP | | Message Type | | |
| **UE Information Elements** | | | | | |
| U-RNTI | CV-*CCCH* | | U-RNTI 10.3.3.47 | | |
| RRC transaction identifier | MP | | RRC transaction identifier 10.3.3.36 | | |
| Integrity check info | CH | | Integrity check info 10.3.3.16 | | |
| Integrity protection mode info | OP | | Integrity protection mode info 10.3.3.19 | The UTRAN should not include this IE unless it is performing an SRNS relocation or a cell reselection from GERAN *Iu mode* | |
| Ciphering mode info | OP | | Ciphering mode info 10.3.3.5 | The UTRAN should not include this IE unless it is performing either an SRNS relocation or a cell reselection from | |

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| | | | | GERAN *Iu mode*, and a change in ciphering algorithm. | |
| Activation time | MD | | Activation time 10.3.3.1 | Default value is "now" | |
| New U-RNTI | OP | | U-RNTI 10.3.3.47 | | |
| New C-RNTI | OP | | C-RNTI 10.3.3.8 | | |
| New DSCH-RNTI | OP | | DSCH-RNTI 10.3.3.9a | Should not be set in FDD. If received, the UE should ignore it | |
| New H-RNTI | OP | | H-RNTI 10.3.3.14a | | REL-5 |
| New Primary E-RNTI | OP | | E-RNTI 10.3.3.10a | | REL-6 |
| New Secondary E-RNTI | OP | | E-RNTI 10.3.3.10a | | REL-6 |
| RRC State Indicator | MP | | RRC State Indicator 10.3.3.35a | | |
| UTRAN DRX cycle length coefficient | OP | | UTRAN DRX cycle length coefficient 10.3.3.49 | | |
| RLC re-establish indicator (RB2, RB3 and RB4) | MP | | RLC re-establish indicator 10.3.3.35 | Should not be set to TRUE if IE "Downlink counter synchronisation info" is included in message. | |
| RLC re-establish indicator (RB5 and upwards) | MP | | RLC re-establish indicator 10.3.3.35 | Should not be set to TRUE if IE "Downlink counter synchronisation info" is included in message. | |
| **CN Information Elements** | | | | | |
| CN Information info | OP | | CN Information info 10.3.1.3 | | |
| **UTRAN Information Elements** | | | | | |
| URA identity | OP | | URA identity 10.3.2.6 | | |
| **RB information elements** | | | | | |
| RB information to release list | OP | 1 to <maxRB> | | | |
| >RB information to release | MP | | RB information to release 10.3.4.19 | | |
| RB information to reconfigure list | OP | 1 to <maxRB> | | | |
| >RB information to reconfigure | MP | | RB information to reconfigure 10.3.4.18 | | |
| RB information to be affected list | OP | 1 to <maxRB> | | | |
| >RB information to be affected | MP | | RB information to be | | |

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| | | | affected 10.3.4.17 | | |
| Downlink counter synchronisation info | OP | | | | |
| >RB with PDCP information list | OP | 1 to <maxRBallRABs> | | | |
| >>RB with PDCP information | MP | | RB with PDCP information 10.3.4.22 | This IE is needed for each RB having PDCP in the case of lossless SRNS relocation | |
| | OP | | | | REL-5 |
| >>PDCP context relocation info | OP | | PDCP context relocation info 10.3.4.1a | This IE is needed for each RB having PDCP and performing PDCP context relocation | REL-5 |
| PDCP ROHC target mode | OP | | PDCP ROHC target mode 10.3.4.2a | | REL-5 |
| **TrCH Information Elements** | | | | | |
| **Uplink transport channels** | | | | | |
| UL Transport channel information common for all transport channels | OP | | UL Transport channel information common for all transport channels 10.3.5.24 | | |
| Deleted TrCH information list | OP | 1 to <maxTrCH> | | | |
| >Deleted UL TrCH information | MP | | Deleted UL TrCH information 10.3.5.5 | | |
| Added or Reconfigured TrCH information list | OP | 1 to <maxTrCH> | | | |
| >Added or Reconfigured UL TrCH information | MP | | Added or Reconfigured UL TrCH information 10.3.5.2 | | |
| **Downlink transport channels** | | | | | |
| DL Transport channel information common for all transport channels | OP | | DL Transport channel information common for all transport channels 10.3.5.6 | | |
| Deleted TrCH information list | OP | 1 to <maxTrCH> | | | |
| >Deleted DL TrCH information | MP | | Deleted DL TrCH information 10.3.5.4 | | |
| Added or Reconfigured TrCH information list | OP | 1 to <maxTrCH> | | | |

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| >Added or Reconfigured DL TrCH information | MP | | Added or Reconfigured DL TrCH information 10.3.5.1 | | |
| **PhyCH information elements** | | | | | |
| Frequency info | OP | | Frequency info 10.3.6.36 | | |
| **Uplink radio resources** | | | | | |
| Maximum allowed UL TX power | MD | | Maximum allowed UL TX power 10.3.6.39 | Default value is the existing maximum UL TX power | |
| Uplink DPCH info | OP | | Uplink DPCH info 10.3.6.88. | | |
| E-DCH Info | OP | | E-DCH Info 10.3.6.97 | | REL-6 |
| **Downlink radio resources** | | | | | |
| Downlink HS-PDSCH Information | OP | | Downlink HS_PDSCH Information 10.3.6.23a | | REL-5 |
| Downlink information common for all radio links | OP | | Downlink information common for all radio links 10.3.6.24 | | |
| Downlink information per radio link list | OP | 1 to <maxRL> | | Send downlink information for each radio link to be set-up | |
| >Downlink information for each radio link | MP | | Downlink information for each radio link 10.3.6.27 | | |
| MBMS PL Service Restriction Information | OP | | Enumerated (TRUE) | Absence means that on the MBMS Preferred Layer (PL) no restrictions apply concerning the use of non-MBMS services i.e. the PL is not congested | REL-6 |

| Condition | Explanation |
|---|---|
| *CCCH* | This IE is mandatory present when CCCH is used and ciphering is not required and not needed otherwise. |

## 10.2.9 COUNTER CHECK

This message is used by the UTRAN to indicate the current COUNT-C MSB values associated to each radio bearer utilising UM or AM RLC mode and to request the UE to compare these to its COUNT-C MSB values and to report the comparison results to UTRAN.

RLC-SAP: AM

Logical channel: DCCH

Direction: UTRAN→UE

| Information Element/Group name | Presence | Multi | IE type and reference | Semantics description |
|---|---|---|---|---|
| Message Type | MP | | | |
| **UE information elements** | | | | |
| RRC transaction identifier | MP | | RRC transaction identifier 10.3.3.36 | |
| Integrity check info | CH | | Integrity check info 10.3.3.16 | |
| **RB information elements** | | | | |
| RB COUNT-C MSB information | MP | 1 to < maxRBallRABs > | | For each RB (excluding signalling radio bearers) using UM or AM RLC. |
| >RB COUNT-C MSB information | MP | | RB COUNT-C MSB information 10.3.4.14 | |

## 10.2.10 COUNTER CHECK RESPONSE

This message is used by the UE to respond to a COUNTER CHECK message.

RLC-SAP: AM

Logical channel: DCCH

Direction: UE→UTRAN

| Information Element/Group name | Presence | Multi | IE type and reference | Semantics description |
|---|---|---|---|---|
| Message Type | MP | | | |
| **UE information elements** | | | | |
| RRC transaction identifier | MP | | RRC transaction identifier 10.3.3.36 | |
| Integrity check info | CH | | Integrity check info 10.3.3.16 | |
| **RB information elements** | | | | |
| RB COUNT-C information | OP | 1 to < maxRBallRABs > | | |
| >RB COUNT-C information | MP | | RB COUNT-C information 10.3.4.15 | |

## 10.2.11 DOWNLINK DIRECT TRANSFER

This message is sent by UTRAN to transfer higher layer messages.

RLC-SAP: AM

Logical channel: DCCH

Direction: UTRAN -> UE

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Message Type | MP | | Message Type | |
| **UE information elements** | | | | |
| RRC transaction identifier | MP | | RRC transaction identifier 10.3.3.36 | |
| Integrity check info | CH | | Integrity check info 10.3.3.16 | |
| **CN information elements** | | | | |
| CN Domain Identity | MP | | Core Network Domain Identity 10.3.1.1 | |
| NAS message | MP | | NAS message 10.3.1.8 | |

## 10.2.12 Void

## 10.2.13 Void

## 10.2.14 Void

## 10.2.15 HANDOVER FROM UTRAN COMMAND

This message is used for handover from UMTS to another system e.g. GSM. One or several messages from the other system can be included in the Inter-RAT message information element in this message. These messages are structured and coded according to that systems specification.

RLC-SAP: AM

Logical channel: DCCH

Direction: UTRAN→UE

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| Message Type | MP | | Message Type | | |
| **UE information elements** | | | | | |
| RRC transaction identifier | MP | | RRC transaction identifier 10.3.3.36 | | |
| Integrity check info | CH | | Integrity check info 10.3.3.16 | | |
| Activation time | MD | | Activation time 10.3.3.1 | Default value is "now" | |

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| **RB information elements** | | | | | |
| RAB information list | OP | 1 to <maxRABsetup> | | For each RAB to be handed over. In handover to GERAN *Iu mode* the RAB information is included in the GERAN Iu message below. | |
| >RAB info | MP | | RAB info 10.3.4.8 | | |
| **Other information elements** | | | | | |
| CHOICE *System type* | MP | | | This IE indicates which specification to apply, to decode the transported messages | |
| >GSM | | | | | |
| >>Frequency band | MP | | Enumerated (GSM/DCS 1800 band used), GSM/PCS 1900 band used) | | |
| >>GSM message | | | | | |
| >>>Single GSM message | MP | | Bit string (no explicit size constraint) | Formatted and coded according to GSM specifications The first/leftmost/most significant bit of the bit string contains bit 8 of the first octet of the GSM message. | |
| >>>GSM message List | MP | 1.to.<maxInterSysMessages> | Bit string (1..512) | Formatted and coded according to GSM specifications. The first/leftmost/most significant bit of the bit string contains bit 8 of the first octet of the GSM message. | |
| >>CHOICE *GERAN System Info type* | OP | | | | REL-6 |
| >>>SI | | | GERAN system information 10.3.8.4f | See [44] | REL-6 |
| >>>PSI | | | GERAN system information 10.3.8.4f | See [44] | REL-6 |

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| >GERAN Iu | | | | | REL-5 |
| >>Frequency band | MP | | Enumerated (GSM/DCS 1800 band used), GSM/PCS 1900 band used) | | REL-5 |
| >>GERAN Iu message | | | | | REL-5 |
| >>>Single GERAN Iu message | MP | | Bit string (no explicit size constraint) | Formatted and coded according to [53]. The first/leftmost/most significant bit of the bit string contains bit 8 of the first octet of the message. | REL-5 |
| >>>GERAN Iu message List | MP | 1 to <maxInterSysMessages> | Bit string (1..32768) | Formatted and coded according to [53]. The first/leftmost/most significant bit of the bit string contains bit 8 of the first octet of the message. | REL-5 |
| >cdma2000 | | | | | |
| >>cdma2000MessageList | MP | 1.to.<maxInterSysMessages> | | | |
| >>>MSG_TYPE(s) | MP | | Bit string (8) | Formatted and coded according to cdma2000 specifications. The MSG_TYPE bits are numbered b0 to b7. The first/leftmost/most significant bit of the bit string contains bit 7 of the MSG_TYPE. | |
| >>>cdma2000Messagepayload(s) | MP | | Bit string (1..512) | Formatted and coded according to cdma2000 specifications. The first/leftmost/most significant bit of the bit string contains the bit 7 of the first octet of the cdma2000 message. | |

## 10.2.16 HANDOVER FROM UTRAN FAILURE

This message is sent on the RRC connection used before the Inter-RAT Handover was executed. The message indicates that the UE has failed to seize the new channel in the other system.

RLC-SAP: AM

Logical channel: DCCH

Direction: UE→UTRAN

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| Message Type | MP | | Message Type | | |

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| **UE information elements** | | | | | |
| RRC transaction identifier | MP | | RRC transaction identifier 10.3.3.36 | | |
| Integrity check info | CH | | Integrity check info 10.3.3.16 | | |
| **Other information elements** | | | | | |
| Inter-RAT handover failure | OP | | Inter-RAT handover failure 10.3.8.6 | | |
| CHOICE *System type* | OP | | | This IE indicates which specification to apply to decode the transported messages | |
| >GSM | | | | | |
| >>GSM message List | MP | 1.to.<maxInterSysMessages> | Bit string (1..512) | Formatted and coded according to GSM specifications. The first/leftmost/most significant bit of the bit string contains bit 8 of the first octet of the GSM message. | |
| >GERAN Iu | | | | | REL-5 |
| >>GERAN Iu message List | MP | 1 to <maxInterSysMessages> | Bit string (1..32768) | Formatted and coded according to [53]. The first/leftmost/most significant bit of the bit string contains bit 8 of the first octet of the message. | REL-5 |
| >cdma2000 | | | | | |
| >>cdma2000MessageList | MP | 1.to.<maxInterSysMessages> | | | |
| >>>MSG_TYPE(s) | MP | | Bit string (8) | Formatted and coded according to cdma2000 specifications. The MSG_TYPE bits are numbered b0 to b7. The first/leftmost/most significant bit of the bit string contains bit 7 of the MSG_TYPE. | |
| >>>cdma2000Messagepayload(s) | MP | | Bit string (1..512) | Formatted and coded according to cdma2000 specifications. The first/leftmost/most significant bit of the bit string contains bit 7 of the first octet of the cdma2000 message. | |

## 10.2.16a HANDOVER TO UTRAN COMMAND

This message is sent to the UE via other system to make a handover to UTRAN.

RLC-SAP: N/A (Sent through a different RAT)

Logical channel: N/A (Sent through a different RAT)

Direction: UTRAN → UE

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| New U-RNTI | MP | | U-RNTI Short 10.3.3.48 | | |
| Ciphering algorithm | OP | | Ciphering algorithm 10.3.3.4 | | |
| CHOICE *specification mode* | MP | | | | |
| >Complete specification | | | | | |
| **RB information elements** | | | | | |
| >>Signalling RB information to setup list | MP | 1 to <maxSRBsetup> | | For each signalling radio bearer established | |
| >>>Signalling RB information to setup | MP | | Signalling RB information to setup 10.3.4.24 | | |
| >>RAB information to setup list | OP | 1 to <maxRABsetup> | | For each RAB established | |
| >>>RAB information for setup | MP | | RAB information for setup 10.3.4.10 | | |
| **Uplink transport channels** | | | | | |
| >>UL Transport channel information common for all transport channels | MP | | UL Transport channel information common for all transport channels 10.3.5.24 | | |
| >>Added or Reconfigured TrCH information | MP | 1 to <maxTrCH> | | | |
| >>>Added or Reconfigured UL TrCH information | MP | | Added or Reconfigured UL TrCH information 10.3.5.2 | | |
| **Downlink transport channels** | | | | | |
| >>DL Transport channel information common for all transport channels | MP | | DL Transport channel information common for all transport channels 10.3.5.6 | | |
| >>Added or Reconfigured TrCH information | MP | 1 to <maxTrCH> | | | |
| >>>Added or Reconfigured DL TrCH information | MP | | Added or Reconfigured DL TrCH information 10.3.5.1 | | |
| **Uplink radio resources** | | | | | |
| >>Uplink DPCH info | MP | | Uplink DPCH info | | |

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| | | | 10.3.6.88 | | |
| E-DCH Info | OP | | E-DCH Info 10.3.6.97 | | REL-6 |
| **Downlink radio resources** | | | | | |
| Downlink HS-PDSCH Information | OP | | Downlink HS-PDSCH Information 10.3.6.23a | | REL-6 |
| >>Downlink information common for all radio links | MP | | Downlink information common for all radio links 10.3.6.24 | | |
| >>Downlink information per radio link | MP | 1 to <maxRL> | | | |
| >>>Downlink information for each radio link | MP | | Downlink information for each radio link 10.3.6.27 | | |
| >Preconfiguration | | | | | |
| >>CHOICE *Preconfiguration mode* | MP | | | | |
| >>>Predefined configuration | MP | | Predefined configuration identity 10.3.4.5 | | |
| >>>Default configuration | | | | | |
| >>>>Default configuration mode | MP | | Enumerated (FDD, TDD) | Indicates whether the FDD or TDD version of the default configuration shall be used | |
| >>>>Default configuration identity | MP | | Default configuration identity 10.3.4.0 | | |
| >>RAB info | OP | | RAB info Post 10.3.4.9 | One RAB is established | |
| >>Uplink DPCH info | MP | | Uplink DPCH info Post 10.3.6.89 | | |
| **Downlink radio resources** | | | | | |
| >>Downlink information common for all radio links | MP | | Downlink information common for all radio links Post 10.3.6.25 | | |
| >>Downlink information per radio link | MP | 1 to <maxRL> | | Send downlink information for each radio link to be set-up. In TDD MaxRL is 1. | |

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| >>>Downlink information for each radio link | MP | | Downlink information for each radio link Post 10.3.6.28 | | |
| >>CHOICE *mode* | MP | | | | |
| >>>FDD | | | | (no data) | |
| >>>TDD | | | | | |
| >>>>Primary CCPCH Tx Power | MP | | Primary CCPCH Tx Power 10.3.6.59 | | |
| Frequency info | MP | | Frequency info 10.3.6.36 | | |
| Maximum allowed UL TX power | MP | | Maximum allowed UL TX power 10.3.6.39 | | |

## 10.2.16b HANDOVER TO UTRAN COMPLETE

This message is sent by the UE when a handover to UTRAN has been completed.

RLC-SAP: AM

Logical channel: DCCH

Direction: UE → UTRAN

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Message Type | MP | | Message Type | |
| **UE Information elements** | | | | |
| START list | CH | 1 to <maxCNdomains> | | START [40] values for all CN domains. |
| >CN domain identity | MP | | CN domain identity 10.3.1.1 | |
| >START | MP | | START 10.3.3.38 | |
| **RB Information elements** | | | | |
| COUNT-C activation time | OP | | Activation time 10.3.3.1 | Used for radio bearers mapped on RLC-TM. |

## 10.2.16c INITIAL DIRECT TRANSFER

This message is used to initiate a signalling connection based on indication from the upper layers, and to transfer a NAS message.

RLC-SAP: AM

Logical channel: DCCH

Direction: UE -> UTRAN

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| Message Type | MP | | Message Type | | |
| **UE information elements** | | | | | |
| Integrity check info | CH | | Integrity check info 10.3.3.16 | | |
| PLMN identity | OP | | PLMN identity 10.3.1.11 | This IE indicates the PLMN to which the UE requests the signalling connection to be established. | REL-6 |
| **CN information elements** | | | | | |
| CN domain identity | MP | | CN domain identity 10.3.1.1 | | |
| Intra Domain NAS Node Selector | MP | | Intra Domain NAS Node Selector 10.3.1.6 | | |
| NAS message | MP | | NAS message 10.3.1.8 | | |
| START | OP | | START 10.3.3.38 | START value to be used in the CN domain as indicated in the IE "CN domain identity". This IE shall always be present in this version of the protocol. | |
| Establishment cause | OP | | Establishment cause 10.3.3.11 | | Rel-5 |
| **Measurement information elements** | | | | | |
| Measured results on RACH | OP | | Measured results on RACH 10.3.7.45 | | |
| MBMS joined information | OP | | | | REL-6 |
| >P-TMSI | OP | | P-TMSI (GSM-MAP) 10.3.1.13 | | REL-6 |

## 10.2.16d INTER RAT HANDOVER INFO

This message is sent by the UE via another radio access technology to provide information to the target RNC when preparing for a handover to UTRAN.

RLC-SAP: N/A (Sent through a different RAT)

Logical channel: N/A (Sent through a different RAT)

Direction: UE → UTRAN

| Information Element/Group Name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| **Radio Bearer IEs** | | | | | |
| Predefined configuration status information | OP | | Predefined configuration status information 10.3.4.5a | | |
| Predefined configuration status information compressed | OP | | Predefined configuration status information compressed 10.3.4.5b | | REL-5 |
| **UE Information elements** | | | | | |
| UE security information | OP | | UE security information 10.3.3.42b | | |
| UE security information2 | OP | | UE security information2 10.3.3.42c | | REL-6 |
| UE Specific Behaviour Information 1 interRAT | OP | | UE Specific Behaviour Information 1 interRAT 10.3.3.52 | This IE shall not be included in this version of the protocol | |
| UE capability container | OP | | | | |
| >UE radio access capability | MP | | UE radio access capability 10.3.3.42 | | |
| >UE radio access capability extension | MP | | UE radio access capability extension 10.3.3.42a | Although this IE is not always required, the need has been set to MP to align with the ASN.1 | |
| UE radio access capability compressed | OP | | UE radio access capability compressed 10.3.3.42o | | REL-5 |
| UE radio access capability comp 2 | MP | | UE radio access capability comp 2 10.3.3.42oa | | REL6 |

## 10.2.16e MBMS Access Information

This message is transmitted periodically by UTRAN to inform UEs that have joined a particular MBMS service about the need to establish an RRC connection or to perform a cell update. While the message contents may change within a modification period, all occurances of the information within a modification period concern the same MBMS service(s).

RLC-SAP: UM

Logical channel: MCCH

Direction: UTRAN → UE

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| Message type | MP | | Message Type | | REL-6 |
| Service list | MP | 1 to <maxMBMSservCount> | | | REL-6 |
| >MBMS short transmission ID | MP | | MBMS Short transmission identity 10.3.9a.10 | Reference/ index to a transmission listed in the MBMS MODIFIED SERVICES INFORMATION or MBMS UNMODIFIED SERVICES INFORMATION | REL-6 |
| >Access probability factor - Idle | MP | | Integer (0 to 960 by step of 32, 1000) | Access probability factor for UEs in idle mode. The actual Access Probability (AP) is a function of the Access Probability Factor (APF): $AP(APF) = 2^{-(APF/100)}$ | REL-6 |
| >Access probability factor – connected | MD | | Integer (0 to 960 by step of 32, 1000) | Access probability factor for UEs in connected mode. The actual Access Probability (AP) is a function of the Access Probability Factor (APF): $AP(APF) = 2^{-(APF/100)}$<br><br>Default value is the value included in IE "Access probability factor - Idle" | REL-6 |
| >Connected mode counting scope | MP | | | | REL-6 |
| >>URA_PCH | MP | | BOOLEAN | TRUE means that UEs in URA_PCH state shall participate in counting | REL-6 |
| >>CELL_PCH | MP | | BOOLEAN | TRUE means that UEs in CELL_PCH state shall participate in counting | REL-6 |
| >> CELL_FACH | MP | | BOOLEAN | TRUE means that UEs in CELL_FACH state shall participate in counting | REL-6 |

## 10.2.16f MBMS Common p-t-m rb Information

This message is transmitted periodically by UTRAN to inform UEs about the p-t-m RB configuration information that may be common between different services, applicable in the current and/ or in neighbouring cells. The message contents does not change within a modification period.

RLC-SAP: UM

Logical channel: MCCH

Direction: UTRAN → UE

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| Message type | MP | | Message Type | | REL-6 |
| RB information list | MP | 1 to <maxMBMS-CommonRB> | | | REL-6 |
| >RB identity | MP | | MBMS Common RB identity 10.3.9a.3 | | REL-6 |
| >PDCP info | MP | | PDCP info 10.3.4.2 | | REL-6 |
| >RLC info | MP | | RLC info MBMS 10.3.4.23a | | REL-6 |
| TrCh information for each TrCh | MP | 1 to <maxMBMS-CommonTrCh> | | | REL-6 |
| >Transport channel identity | MP | | MBMS Common TrCh identity 10.3.9a.4 | | REL-6 |
| >TFS | MP | | Transport format set 10.3.5.23 | | REL-6 |
| TrCh information for each CCTrCh | OP | 1 to <maxMBMS-CommonCCTrCh> | | The list needs not include the CCTrCh for which the default TFCS for MBMS applies, as specified in subclause 14.10.1. | REL-6 |
| >CCTrCH identity | MP | | MBMS Common CCTrCh identity 10.3.9a.1 | | REL-6 |
| >TFCS | MP | | Transport format combination set 10.3.5.20 | | REL-6 |
| PhyCh information | MP | 1 to <maxMBMS-CommonPhyCh> | | | REL-6 |
| >PhyCh identity | MP | | MBMS Common PhyCh identity 10.3.9a.2 | | REL-6 |
| >Secondary CCPCH info MBMS | MP | | Secondary CCPCH info MBMS 10.3.6.71a | | REL-6 |

## 10.2.16g MBMS Current Cell p-t-m rb Information

This message is transmitted periodically by UTRAN to inform UEs about the PTM RB configuration used to in a cell, in case one or more MBMS service is provided using p-t-m radio bearers. The message contents does not change within a modification period.

RLC-SAP: UM

Logical channel: MCCH

Direction: UTRAN → UE

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| Message type | MP | | Message Type | Current cell PTM RB info | REL-6 |
| S-CCPCH list | OP | 1 to <maxSCCPCH> | | Absent in case MTCH are only mapped to the S-CCPCH(s) included in SIB type 5 | REL-6 |
| >S-CCPCH identity | OP | | MBMS Current cell S-CCPCH identity 10.3.9a.5 | When L1- combining applies, this identity is used to refer to this S-CCPCH within the NEIGHBOURING CELL P-T-M RB INFORMATION message | REL-6 |
| >Secondary CCPCH info | MP | | MBMS Common PhyCh identity 10.3.9a.2 | Refers to a configuration in the common RB info | REL-6 |
| >MBMS Soft Combining Timing Offset | CV-*Soft-FDD* | | MBMS Soft Combining Timing Offset 10.3.9a.10a | Timing offset applied in the CFN calculation in sub-clause 8.5.15.5. The default value is 0 ms. | REL-6 |
| >TrCh information common for all TrCh | MD | | MBMS Common CCTrCh identity 10.3.9a.1 | Refers to a (TFCS) configuration in the common RB info<br>The default value of the TFCS is specified in subclause 14.10.1 | REL-6 |
| >TrCH information list | MP | 1 to <maxFACHPCH> | | List of FACH transport channels carrying one or more MTCH and optionally one MSCH | REL-6 |
| >>TrCh information | MP | | MBMS Common TrCh identity 10.3.9a.4 | Refers to a (TFS) configuration in the common RB info | REL-6 |
| >>RB information list | OP | 1 to <maxRBperTrCh> | | The IE is absent if temporarily no RBs are mapped to this TrCh or if the TrCH only carries MSCH | REL-6 |
| >>>RB information | MP | | MBMS p-t-m RB information 10.3.9a.7a | | REL-6 |
| >>MSCH configuration information | OP | | MSCH configuration information 10.3.9a.16 | | REL-6 |
| S-CCPCH in SIB type 5 | OP | 1 to <maxSCCPCH> | | Every S-CCPCH"s included in SIB type 5 may carry MTCH | REL-6 |
| >S-CCPCH identity | | | Integer (1..maxSCCPCH) | Index of the S-CCPCH within the list included in SIB type 5 | REL-6 |
| >TrCH information list | MP | 1 to <maxFACHPCH> | | List of FACH transport channels carrying one or more MTCH and optionally one MSCH | REL-6 |
| >>TrCh identity | MP | | Integer (1..maxF | Index of the FACH within the list of TrChs defined for that S- | REL-6 |

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| | | | ACHPCH) | CCPCH as included in SIB type 5 | |
| >>RB information list | OP | 1 to <maxRB perTrCh > | | The IE is absent if this TrCh only carries MSCH | REL-6 |
| >>>RB information | MP | | MBMS p-t-m RB information 10.3.9a.7a | | REL-6 |
| >>MSCH configuration information | OP | | MSCH configuration information 10.3.9a.16 | Included if the TrCH carries MSCH | REL-6 |

| Condition | Explanation |
|---|---|
| *Soft-FDD* | This IE is used only for FDD. It is mandatory default for FDD if the IE "L1 combining" is included in MBMS NEIGHBOURING CELL P-T-M RB INFORMATION. Otherwise it is not needed. |

## 10.2.16h MBMS General Information

This message is transmitted periodically by UTRAN to inform UEs about the general MBMS (configuration) information. The message contents does not change within a modification period.

RLC-SAP: UM

Logical channel: MCCH

Direction: UTRAN → UE

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| Message type | MP | | Message Type | | REL-6 |
| MBMS preferred frequency information | OP | | MBMS preferred frequency information 10.3.7.43a | | REL-6 |
| MBMS timers and counters | MP | | MBMS specific timers and counters 10.3.9a.11 | | REL-6 |
| MICH configuration information | MP | | MICH configuration information 10.3.9a.14 | | REL-6 |
| Cell group identity | MP | | Bit string (12) | Identifies the group of cells for which the same common RLC and PDCP entity is used as the current cell | REL-6 |
| Default MSCH configuration information | OP | | MSCH configuration information 10.3.9a.16 | The default MSCH configuration | REL-6 |

## 10.2.16i MBMS Modification request

The UE transmits this message to request UTRAN to take certain actions to improve the UE's ability to receive its (prioritised) activated MBMS services and/ or sessions.

RLC-SAP: AM or UM

Logical channel: DCCH

Direction: UE → UTRAN

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| Message type | MP | | Message Type | | REL-6 |
| MBMS preferred frequency request | OP | | MBMS service identity 10.3.9a.8 | The MBMS preferred frequency the UE would like to be moved to. The MBMS preferred frequency is identified by the identity of the MBMS service the UE would like to receive. | REL-6 |
| MBMS RB list requested to be released | OP | 1 to <maxRB> | | RBs of lower priority MBMS services inhibiting reception of a higher priority service | REL-6 |
| >RB information to release | MP | | RB information to release 10.3.4.19 | | REL-6 |

## 10.2.16j MBMS Modified services Information

This information is transmitted periodically by UTRAN to inform UEs about a change applicable for one or more MBMS services available in the current cell and possibly in neighbouring cells.

RLC-SAP: AM (DCCH only) or UM

Logical channel: MCCH, DCCH

Direction: UTRAN → UE

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| Message type | MP | | Message Type | | REL-6 |
| Modified service list | OP | 1.. <maxMBMSservModif> | | | REL-6 |
| >MBMS Transmission identity | MP | | MBMS Transmission identity 10.3.9a.12 | | REL-6 |
| >MBMS required UE action | MP | | Enumerated (None, Acquire counting info, Acquire counting info – PTM RBs unmodified, Acquire PTM RB info, RequestPTP RB, Release PTM RB) | Indicates required UE action upon receiving the message. When sent on the DCCH, only the following values apply: None (FLC), Acquire PTM RB info, request PTP RB). | REL-6 |
| >MBMS preferred frequency | OP | | | Indicates the frequency that UEs shall consider as the preferred frequency layer for cell re-selection during a session for an MBMS service the UE has joined, as specified in [25.304]. | REL-6 |
| >>PFL index | CV-*MCCH* | | Integer (1.. <maxMBMS-Freq>) | Index pointing to an entry in the list included in MBMS GENERAL INFORMATION. | REL-6 |
| >>PFL info | CV-*DCCH* | | Frequency info 10.3.6.36 | | REL-6 |
| > MBMS dispersion indicator | CV-*PTM release* | | Enumerated (True) | Indicates whether or not the UE should attempt a cell selection on another frequency other than the current one. | REL-6 |
| >Continue MCCH reading | MP | | BOOLEAN | MCCH in- band notification. Indicates whether or not the UE should continue reading MCCH in the next modification period. Not applicable when sent on the DCCH | REL-6 |
| MBMS re- acquire MCCH | CV-MCCH | | Enumerated (True) | | REL-6 |
| MBMS dynamic persistence level | OP | | Dynamic persistence level 10.3.6.35 | | REL-6 |
| End of modified MCCH information | OP | | Integer (1..16) | If present: the UE may assume that, in each repetition period, all the MCCH information preceding the MBMS UNMODIFIED SERVICES INFORMATION message is transmitted within the indicated number of TTIs. | REL-6 |

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| MBMS number of neighbour cells | MP | | Integer (0..32) | Indicates the number of MBMS NEIGHBOURING CELL P-T-M RB INFORMATION messages that are contained within the MCCH transmission. | REL-6 |
| MBMS all unmodified p-t-m services | CV-*MCCHOP* | | Enumerated (True) | True means that the UE should re-acquire the PtM information for all services listed in the message MBMS UNMODIFIED SERVICES INFORMATION with the IE 'MBMS required UE action' set to 'Acquire PTM RB info' | REL-6 |
| MBMS p-t-m activation time | CV-*MCCHOP* | | MBMS p-t-m activation time 10.3.9a.7o | | REL-6 |

| Condition | Explanation |
|---|---|
| *MCCH* | This IE is mandatory present if the message is sent via MCCH and not needed otherwise. |
| *DCCH* | This IE is mandatory present if the message is sent via DCCH and not needed otherwise. |
| *PTM release* | This IE is optionally present if the IE MBMS required UE action is set to "Release PTM RB" and not needed otherwise |
| *MCCHOP* | This IE is optionally present if the message is sent via MCCH and not needed otherwise. |

## 10.2.16k MBMS Neighbouring Cell p-t-m rb Information

This message is transmitted periodically by UTRAN to inform UEs about the p-t-m RB configuration used to in neighbouring cells, indicating the UE may perform selection and/ or soft combining. The message content does not change within a modification period.

RLC-SAP: UM

Logical channel: MCCH

Direction: UTRAN → UE

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| Message type | MP | | Message Type | | REL-6 |
| Neighbouring cell identity | MP | | Integer (0..<max CellMeas –1>) | The intra-frequency cell id of the cell obtained from the IE 'Intra-frequency Cell Info list' in SIB 11. | REL-6 |
| Neighbouring cell"s S-CCPCH list | MP | 1 to <maxSCCPCH> | | | REL-6 |
| >Secondary CCPCH info | MP | | MBMS Common PhyCh identity 10.3.9a.2 | S-CCPCH configuration used in neighbouring cell. Refers to a configuration in the common RB info of the current cell | REL-6 |
| >Secondary CCPCH Power Offset Difference | MD | | Integer (-6, -3, 3, 6) | Difference (Pn – Of) between the S-CCPCH power offset (Pn) of the neighboring cell S-CCPCH and the S-CCPCH power offset (Of) of the serving cell that is going to be combined to this neighbour cell S-CCPCH, in dB. Default value is 0. Note 3 and 4. | REL-6 |
| >L1 combining | OP | | | L2- combining applies if the IE is absent | REL-6 |
| >>CHOICE *mode* | MP | | | | REL-6 |
| >>>FDD | | | | | REL-6 |
| >>>>MBMS Soft Combining Timing Offset | MP | | MBMS Soft Combining Timing Offset 10.3.9a.10a | Timing offset applied in the CFN calculation in subclause 8.5.15.5 | REL-6 |
| >>>>MBMS transmission time difference | MP | | Integer (0..3) | Indicates the time difference between the TTIs on the current and the neighbouring cell"s SCCPCH that can be L1-combined | REL-6 |
| >>>>MBMS L1 combining schedule | OP | | MBMS L1 combining schedule 10.3.9a.7 | If included partial layer 1 combining applies, in which case this IE indicates when L1-combining applies. If the IE is absent, L1 combining applies continuously | REL-6 |
| >>>TDD | | | | (no data) | REL-6 |
| >CHOICE L23 configuration | MP | | | | REL-6 |
| >>SameAs Current cell | | | | Apart from the physical channel configuration and the MSCH configuration information, the same configuration as for the indicated S-CCPCH used in the current cell applies. The MSCH is mapped on the same transport channel as in the current cell. | REL-6 |
| >>>Current cell's S-CCPCH | MP | | MBMS Current cell S-CCPCH identity 10.3.9a.5 | Reference to the S-CCPCH in the current cell which uses exaclty the same configuration (excluding MSCH configuration). | REL-6 |
| >>>MSCH configuration information | OP | | MSCH configuration informatio | | REL-6 |

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| | | | n 10.3.9a.16 | | |
| >>Different | | | | | REL-6 |
| >>>TrCh information for common for all TrCh | MD | | MBMS Common CCTrCh identity 10.3.9a.1 | Refers to a (TFCS) configuration in the common RB info<br>The default value of the TFCS is specified in subclause 14.10.1 | REL-6 |
| >>>TrCH information list | MP | 1 to <maxFACHPCH> | | List of FACH transport channels carrying one or more MTCH and optionally one MSCH | REL-6 |
| >>>>TrCh information | MP | | MBMS Common TrCh identity 10.3.9a.4 | Refers to a (TFS) configuration in the common RB info | REL-6 |
| >>>>TrCh combining status | MP | | BOOLEAN | Value TRUE means that TrCh combining is used for this transport channel (TDD only). Note 2.<br>The IE shall be ignored in FDD mode. | REL-6 |
| >>>>RB information list | OP | 1 to <maxRBperTrCh> | | The IE is only present for the radio bearers for which selection (FDD) or transport channel (TDD) combining applies. | REL-6 |
| >>>>>RB information | MP | | MBMS p-t-m RB information 10.3.9a.7a | | REL-6 |
| >>>>MSCH configuration information | OP | | MSCH configuration information 10.3.9a.16 | Included if the TrCH carries MSCH | REL-6 |

NOTE 1: The signalling supports the option that UTRAN maps one service to L1 combining slots for some neighbours and to the L2 combining slots for other neighbours ie. the use of different combining schemes for different neighbours

NOTE 2: Transport combining can only be indicated when the complete L2 configuration is provided for the neighbouring cell (i.e. using L2 configuration choice 'different'). Fortunately, a scenario in which the neighbouring cell configuration is different from the current cell is regarded as the typical scenario for using transport combining.

NOTE 3: For FDD, an S-CCPCH power offset is defined as the offset between the transmitted power of the data part of one S-CCPCH and the transmitted power of the P-CPICH of a given cell (Ps-ccpch – Pp-cpich). For TDD, an S-CCPCH power offset is defined as the offset between one S-CCPCH and the P-CCPCH of a given cell (Ps-ccpch – Pp-ccpch).

NOTE 4: The Secondary CCPCH Power Offset Difference IE gives the UE an indication of the S-CCPCH power on the neighbouring cells that may be used to complete the neighbouring cell ranking based on P-CPICH power for FDD or P-CCPCH for TDD.

## 10.2.16L MBMS Scheduling Information

This message is transmitted periodically by UTRAN to inform UEs when the MBMS services, provided on the same S-CCPCH as the message is sent, are scheduled to be transmitted. The UE may use the scheduling information to discontinue receiving the concerned S-CCPCH. The message is transmitted in accordance with the MSCH configuration applicable for the corresponding S-CCPCH.

RLC-SAP: UM

Logical channel: MSCH

Direction: UTRAN → UE

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| Message type | MP | | Message Type | | REL-6 |
| Service scheduling info list | MP | 1 to < maxMBMSservSched> | | | REL-6 |
| >MBMS Transmission identity | MP | | MBMS Transmission identity 10.3.9a.12 | | REL-6 |
| >MBMS Service transmissions info list | OP | 1 to < maxMBMSTransmis> | | One or more sets of scheduling information comprising of the beginning and duration of an MBMS service transmission for one scheduling period | REL-6 |
| >>Start | MP | | Integer (0..1020) by step of 4 | Indicates the start of the transmission relative to the TTI in which the MBMS SCHEDULING INFORMATION message was received. In number of radio frames. | REL-6 |
| >>Duration | MP | | Integer (4..1024) | In number of radio frames | REL-6 |
| >Next scheduling period | MP | | Integer (0..31) | Number of scheduling periods (see 10.3.9a.16), after the current scheduling period, in which no data will be transmitted for the concerned service. If the Next scheduling period is set to 0, data may be transmitted for the concerned service in the scheduling period immediately following the current scheduling period | REL-6 |

## 10.2.16m MBMS Unmodified services Information

This message is transmitted periodically by UTRAN to inform UEs about the MBMS services, available in the current cell and possibly in neighbouring cells, that have not changed if the IE "MBMS all unmodified p-t-m services" is not included in the MBMS MODIFIED SERVICES INFORMATION message in this modification period. The message is repeated every repetition period while its contents does not change within a modification period.

RLC-SAP: UM

Logical channel: MCCH

Direction: UTRAN → UE

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| Message type | MP | | Message Type | | REL-6 |
| Unmodified services list | OP | 1 to <maxMBMSservUnmodif> | | If the IE 'MBMS all unmodified p-t-m services' is included in the MBMS MODIFIED SERVICES INFORMATION message in this modification period, the services with the IE 'MBMS required UE action' set to 'Acquire PTM RB info' in the message MBMS UNMODIFIED SERVICES INFORMATION should be considered as modified. | REL-6 |
| >MBMS Transmission identity | MP | | MBMS Transmission identity 10.3.9a.12 | | REL-6 |
| >MBMS required UE action | MP | | Enumerated (None, Acquire PTM RB info, Request PTP RB ) | Indication of the UE action required to receive the service. | REL-6 |
| >MBMS preferred frequency | OP | | Integer (1..<maxMBMS-Freq>) | Information about the frequency that UEs shall consider as the preferred frequency layer for cell re-selection during a session for an MBMS service the UE has joined, as specified in [25.304] .<br>Index pointing to an entry in the list included in MBMS GENERAL INFORMATION | REL-6 |

## 10.2.17 MEASUREMENT CONTROL

This message is sent by UTRAN to setup, modify or release a measurement in the UE.

RLC-SAP: AM

Logical channel: DCCH

Direction: UTRAN→UE

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Message Type | MP | | Message Type | |
| **UE information elements** | | | | |
| RRC transaction identifier | MP | | RRC transaction identifier 10.3.3.36 | |
| Integrity check info | CH | | Integrity check info 10.3.3.16 | |
| **Measurement Information elements** | | | | |
| Measurement Identity | MP | | Measurement Identity 10.3.7.48 | |
| Measurement Command | MP | | Measurement Command | |

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| | | | 10.3.7.46 | |
| Measurement Reporting Mode | OP | | Measurement Reporting Mode 10.3.7.49 | |
| Additional measurements list | OP | | Additional measurements list 10.3.7.1 | |
| CHOICE *Measurement type* | CV-*command* | | | |
| >Intra-frequency measurement | | | Intra-frequency measurement 10.3.7.36 | |
| >Inter-frequency measurement | | | Inter-frequency measurement 10.3.7.16 | |
| >Inter-RAT measurement | | | Inter-RAT measurement 10.3.7.27 | |
| >UE positioning measurement | | | UE positioning measurement 10.3.7.100 | |
| >Traffic Volume measurement | | | Traffic Volume measurement 10.3.7.68 | |
| >Quality measurement | | | Quality measurement 10.3.7.56 | |
| >UE internal measurement | | | UE internal measurement 10.3.7.77 | |
| **Physical channel information elements** | | | | |
| DPCH compressed mode status info | OP | | DPCH compressed mode status info 10.3.6.34 | |

| Condition | Explanation |
|---|---|
| *Command* | The IE is mandatory present if the IE "Measurement command" is set to "Setup", optional if the IE "Measurement command" is set to "modify", otherwise the IE is not needed. |

## 10.2.18 MEASUREMENT CONTROL FAILURE

This message is sent by UE, if it cannot initiate a measurement as instructed by UTRAN.

RLC-SAP: AM

Logical channel: DCCH

Direction: UE→UTRAN

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Message Type | MP | | Message Type | |
| **UE information elements** | | | | |
| RRC transaction identifier | MP | | RRC transaction identifier 10.3.3.36 | |
| Integrity check info | CH | | Integrity check info 10.3.3.16 | |
| Failure cause | MP | | Failure cause and error information 10.3.3.14 | |

## 10.2.19 MEASUREMENT REPORT

This message is used by UE to transfer measurement results to the UTRAN.

RLC-SAP: AM or UM

Logical channel: DCCH

Direction: UE→UTRAN

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| Message Type | MP | | Message Type | | |
| **UE information elements** | | | | | |
| Integrity check info | CH | | Integrity check info 10.3.3.16 | | |
| **Measurement Information Elements** | | | | | |
| Measurement identity | MP | | Measurement identity 10.3.7.48 | | |
| Measured Results | OP | | Measured Results 10.3.7.44 | | |
| Measured Results on RACH | OP | | Measured Results on RACH 10.3.7.45 | | |
| Additional Measured results | OP | 1 to <maxAdditional Meas> | | | |
| >Measured Results | MP | | Measured Results 10.3.7.44 | | |
| Event results | OP | | Event results 10.3.7.7 | | |
| GSM OTD reference cell | OP | | Primary CPICH info 10.3.6.60 | | REL-4 |
| Inter-RAT cell info indication | CV-*IRAT* | | Integer (0..3) | | REL-5 |

| Condition | Explanation |
|---|---|
| *IRAT* | The IE is optionally present if at least one of the IE "Inter-RAT measured results list" and the IE "Inter-RAT measurement event results" is included in the message. Otherwise, the IE is not needed. |

## 10.2.20 PAGING TYPE 1

This message is used to send information on the paging channel. One or several UEs, in idle or connected mode, can be paged in one message, which also can contain other information.

RLC-SAP: TM

Logical channel: PCCH

Direction: UTRAN → UE

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Message Type | MP | | Message Type | |
| **UE Information elements** | | | | |
| Paging record list | OP | 1 to <maxPage 1> | | |
| >Paging record | MP | | Paging record 10.3.3.23 | |
| **Other information elements** | | | | |
| BCCH modification info | OP | | BCCH modification info 10.3.8.1 | |

If the encoded message does not fill a transport block, the RRC layer shall add padding according to subclause 12.1.

## 10.2.21 PAGING TYPE 2

This message is used to page a UE in connected mode, when using the DCCH for CN originated paging.

RLC-SAP: AM

Logical channel: DCCH

Direction: UTRAN → UE

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Message Type | MP | | Message Type | |
| **UE information elements** | | | | |
| RRC transaction identifier | MP | | RRC transaction identifier 10.3.3.36 | |
| Integrity check info | CH | | Integrity check info 10.3.3.16 | |
| Paging cause | MP | | Paging cause 10.3.3.22 | |
| **CN Information elements** | | | | |
| CN domain identity | MP | | CN domain identity 10.3.1.1 | |
| Paging Record Type Identifier | MP | | Paging Record Type Identifier 10.3.1.10 | |

## 10.2.22 PHYSICAL CHANNEL RECONFIGURATION

This message is used by UTRAN to assign, replace or release a set of physical channels used by a UE.

RLC-SAP: AM or UM

Logical channel: DCCH

Direction: UTRAN → UE

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| Message Type | MP | | Message Type | | |
| **UE Information Elements** | | | | | |
| RRC transaction identifier | MP | | RRC transaction identifier 10.3.3.36 | | |
| Integrity check info | CH | | Integrity check info 10.3.3.16 | | |
| Integrity protection mode info | OP | | Integrity protection mode info 10.3.3.19 | The UTRAN should not include this IE unless it is performing an SRNS relocation | |
| Ciphering mode info | OP | | Ciphering mode info 10.3.3.5 | The UTRAN should not include this IE unless it is performing an SRNS relocation and a change in ciphering algorithm | |
| Activation time | MD | | Activation time 10.3.3.1 | Default value is "now" | |
| Delay restriction flag | OP | Enumerated (TRUE) | | This IE is always set to TRUE and included if the activation time is restricted according to subclause 8.6.3.1 | REL-6 |
| New U-RNTI | OP | | U-RNTI 10.3.3.47 | | |
| New C-RNTI | OP | | C-RNTI 10.3.3.8 | | |
| New DSCH-RNTI | OP | | DSCH-RNTI 10.3.3.9a | Should not be set in FDD. If received the UE should ignore it | |
| New H-RNTI | OP | | H-RNTI 10.3.3.14a | | REL-5 |
| New Primary E-RNTI | OP | | E-RNTI 10.3.3.10a | | REL-6 |
| New Secondary E-RNTI | OP | | E-RNTI 10.3.3.10a | | REL-6 |
| RRC State Indicator | MP | | RRC State Indicator 10.3.3.35a | | |
| UTRAN DRX cycle length coefficient | OP | | UTRAN DRX cycle length coefficient 10.3.3.49 | | |
| **CN Information Elements** | | | | | |
| CN Information info | OP | | CN Information info 10.3.1.3 | | |
| **UTRAN mobility information elements** | | | | | |
| URA identity | OP | | URA identity 10.3.2.6 | | |
| **RB information elements** | | | | | |
| Downlink counter synchronisation info | OP | | | | |
| >RB with PDCP information list | OP | 1 to | | | |

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| | | <maxRBallRABs> | | | |
| >>RB with PDCP information | MP | | RB with PDCP information 10.3.4.22 | This IE is needed for each RB having PDCP in the case of lossless SRNS relocation | |
| | OP | | | | REL-5 |
| >>PDCP context relocation info | OP | | PDCP context relocation info 10.3.4.1a | This IE is needed for each RB having PDCP and performing PDCP context relocation | REL-5 |
| **PhyCH information elements** | | | | | |
| Frequency info | OP | | Frequency info 10.3.6.36 | | |
| **Uplink radio resources** | | | | | |
| Maximum allowed UL TX power | MD | | Maximum allowed UL TX power 10.3.6.39 | Default value is the existing value of the maximum allowed UL TX power | |
| Uplink DPCH info | OP | | Uplink DPCH info 10.3.6.88 | | |
| E-DCH Info | OP | | E-DCH Info 10.3.6.97 | | REL-6 |
| **Downlink radio resources** | | | | | |
| Downlink HS-PDSCH Information | OP | | Downlink HS_PDSCH Information 10.3.6.23a | | REL-5 |
| Downlink information common for all radio links | OP | | Downlink information common for all radio links 10.3.6.24 | | |
| Downlink information per radio link list | OP | 1 to <maxRL> | | Send downlink information for each radio link | |
| >Downlink information for each radio link | MP | | Downlink information for each radio link 10.3.6.27 | | |
| MBMS PL Service Restriction Information | OP | | Enumerated (TRUE) | Absence means that on the MBMS Preferred Layer (PL) no restrictions apply concerning the use of non-MBMS services i.e. the PL is not congested | REL-6 |

## 10.2.23 PHYSICAL CHANNEL RECONFIGURATION COMPLETE

This message is sent from the UE when a physical channel reconfiguration has been done.

RLC-SAP: AM

Logical channel: DCCH

Direction: UE → UTRAN

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| Message Type | MP | | Message Type | | |
| **UE information elements** | | | | | |
| RRC transaction identifier | MP | | RRC transaction identifier 10.3.3.36 | | |
| Integrity check info | CH | | Integrity check info 10.3.3.16 | | |
| Uplink integrity protection activation info | OP | | Integrity protection activation info 10.3.3.17 | | |
| CHOICE *mode* | MP | | | | |
| >FDD | | | | (no data) | |
| >TDD | | | | | |
| >>CHOICE *TDD option* | MP | | | | REL-4 |
| >>>3.84 Mcps TDD | | | | | REL-4 |
| >>>>Uplink Timing Advance | OP | | Uplink Timing Advance 10.3.6.95 | | |
| >>>7.68 Mcps TDD | | | | | REL-7 |
| >>>>Uplink Timing Advance | OP | | Uplink Timing Advance 10.3.6.95a | | REL-7 |
| >>>1.28 Mcps TDD | | | | (no data) | REL-4 |
| **RB Information elements** | | | | | |
| COUNT-C activation time | OP | | Activation time 10.3.3.1 | Used for radio bearers mapped on RLC-TM. | |
| Uplink counter synchronisation info | OP | | | | |
| >RB with PDCP information list | OP | 1 to <maxRBallRABs> | | | |
| >>RB with PDCP information | MP | | RB with PDCP information 10.3.4.22 | | |
| >START list | MP | 1 to <maxCNdomains> | | START [40] values for all CN domains. | |
| >>CN domain identity | MP | | CN domain identity 10.3.1.1 | | |
| >>START | MP | | START 10.3.3.38 | START value to be used in this CN domain. | |

## 10.2.24 PHYSICAL CHANNEL RECONFIGURATION FAILURE

This message is sent by UE if the configuration given by UTRAN is unacceptable or if the UE failed to assign, replace or release a set of physical channel(s).

RLC-SAP: AM

Logical channel: DCCH

Direction: UE→UTRAN

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Message type | MP | | Message type | |
| **UE information elements** | | | | |
| RRC transaction identifier | OP | | RRC transaction identifier 10.3.3.36 | |
| Integrity check info | CH | | Integrity check info 10.3.3.16 | |
| Failure cause | MP | | Failure cause and error information 10.3.3.14 | |

## 10.2.25 PHYSICAL SHARED CHANNEL ALLOCATION

NOTE: Only for TDD.

This message is used by UTRAN to assign physical resources to USCH/DSCH transport channels in TDD, for temporary usage by the UE.

RLC-SAP: UM on SHCCH, UM on DCCH

Logical channel: SHCCH or DCCH

Direction: UTRAN → UE

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Message Type | MP | | Message type | |
| DSCH-RNTI | OP | | DSCH-RNTI 10.3.3.9a | |
| RRC transaction identifier | MP | | RRC transaction identifier 10.3.3.36 | |
| Uplink timing advance Control | MD | | Uplink Timing Advance Control 10.3.6.96 | Default value is the existing value for uplink timing advance |
| PUSCH capacity allocation info | OP | | PUSCH Capacity Allocation info 10.3.6.64 | |
| PDSCH capacity allocation info | OP | | PDSCH Capacity Allocation info 10.3.6.42 | |
| Confirm request | MD | | Enumerated( No Confirm, Confirm PDSCH, Confirm PUSCH) | Default value is No Confirm |

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Traffic volume report request | OP | | Integer (0 .. 255) | Indicates the number of frames between start of the allocation period and sending measurement report. The value should be less than the value for Allocation Duration. |
| ISCP Timeslot list | OP | 1 to maxTS | | |
| >Timeslot number | MP | | Timeslot number 10.3.6.84 | Timeslot numbers, for which the UE shall report the timeslot ISCP in PUSCH CAPACITY REQUEST message. |
| Request P-CCPCH RSCP | MP | | Boolean | TRUE indicates that a Primary CCPCH RSCP measurement shall be reported by the UE in PUSCH CAPACITY REQUEST message. |

## 10.2.26 PUSCH CAPACITY REQUEST

NOTE: Only for TDD.

This message is used by the UE for request of PUSCH resources to the UTRAN.

RLC-SAP: TM

Logical channel: SHCCH

Direction: UE → UTRAN

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Message Type | MP | | Message Type | |
| DSCH-RNTI | OP | | DSCH-RNTI 10.3.3.9a | |
| RRC transaction identifier | CV-*ProtErr* | | RRC transaction identifier 10.3.3.36 | |
| Traffic Volume | OP | | Traffic Volume, measured results list 10.3.7.67 | |
| Timeslot list | OP | 1 to maxTS | | |
| >Timeslot number | MP | | Timeslot number 10.3.6.84 | |
| >Timeslot ISCP | MP | | Timeslot ISCP info 10.3.7.65 | |
| Primary CCPCH RSCP | OP | | Primary CCPCH RSCP info 10.3.7.54 | |
| CHOICE *Allocation confirmation* | OP | | | |
| >PDSCH Confirmation | | | Integer(1..hiPDSCHidentities) | |
| >PUSCH Confirmation | | | Integer(1..hiPUSCHidentities) | |

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Protocol error indicator | MD | | Protocol error indicator 10.3.3.27 | Default value is FALSE |
| Protocol error information | CV-*ProtErr* | | Protocol error information 10.3.8.12 | |

| Condition | Explanation |
|---|---|
| *ProtErr* | This IE is mandatory present if the IE "Protocol error indicator" has the value "TRUE". Otherwise it is not needed. |

## 10.2.27 RADIO BEARER RECONFIGURATION

This message is sent from UTRAN to reconfigure parameters related to a change of QoS. This procedure can also change the multiplexing of MAC, reconfigure transport channels and physical channels. This message is also used to perform a handover from GERAN *Iu mode* to UTRAN.

RLC-SAP: AM or UM or sent through GERAN *Iu mode*

Logical channel: DCCH or sent through GERAN *Iu mode*

Direction: UTRAN → UE

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| Message Type | MP | | Message Type | | |
| **UE Information elements** | | | | | |
| RRC transaction identifier | MP | | RRC transaction identifier 10.3.3.36 | | |
| Integrity check info | CH | | Integrity check info 10.3.3.16 | | |
| Integrity protection mode info | OP | | Integrity protection mode info 10.3.3.19 | The UTRAN should not include this IE unless it is performing an SRNS relocation or a handover from GERAN *Iu mode* | |
| Ciphering mode info | OP | | Ciphering mode info 10.3.3.5 | The UTRAN should not include this IE unless it is performing either an SRNS relocation or a handover from GERAN *Iu mode* and a change in ciphering algorithm | |
| Activation time | MD | | Activation time 10.3.3.1 | Default value is "now" | |
| Delay restriction flag | OP | Enumerated (TRUE) | | This IE is always set to TRUE and included if the activation time is | REL-6 |

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| | | | | restricted according to subclause 8.6.3.1 | |
| New U-RNTI | OP | | U-RNTI 10.3.3.47 | | |
| New C-RNTI | OP | | C-RNTI 10.3.3.8 | | |
| New DSCH-RNTI | OP | | DSCH-RNTI 10.3.3.9a | Should not be set in FDD. If received The UE should ignore it | |
| New H-RNTI | OP | | H-RNTI 10.3.3.14a | | REL-5 |
| New Primary E-RNTI | OP | | E-RNTI 10.3.3.10a | | REL-6 |
| New Secondary E-RNTI | OP | | E-RNTI 10.3.3.10a | | REL-6 |
| RRC State Indicator | MP | | RRC State Indicator 10.3.3.35a | | |
| UTRAN DRX cycle length coefficient | OP | | UTRAN DRX cycle length coefficient 10.3.3.49 | | |
| **CN information elements** | | | | | |
| CN Information info | OP | | CN Information info 10.3.1.3 | | |
| **UTRAN mobility information elements** | | | | | |
| URA identity | OP | | URA identity 10.3.2.6 | | |
| CHOICE specification mode | MP | | | | REL-5 |
| >Complete specification | | | | | |
| **RB information elements** | | | | | |
| >>RAB information to reconfigure list | OP | 1 to < maxRABsetup > | | | |
| >>>RAB information to reconfigure | MP | | RAB information to reconfigure 10.3.4.11 | | |
| >>RB information to reconfigure list | MP | 1to <maxRB> | | Although this IE is not always required, need is MP to align with ASN.1 | |
| | OP | | | | REL-4 |
| >>>RB information to reconfigure | MP | | RB information to reconfigure 10.3.4.18 | | |
| >>RB information to be affected list | OP | 1 to <maxRB> | | | |
| >>>RB information to be affected | MP | | RB information to be affected 10.3.4.17 | | |
| >>RB with PDCP context relocation info list | OP | 1 to <maxRBallRABs> | | This IE is needed for each RB having PDCP and performing PDCP | REL-5 |

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| | | | | context relocation | |
| >>>PDCP context relocation info | MP | | PDCP context relocation info 10.3.4.1a | | REL-5 |
| PDCP ROHC target mode | OP | | PDCP ROHC target mode 10.3.4.2a | | REL-5 |
| **TrCH Information Elements** | | | | | |
| **Uplink transport channels** | | | | | |
| >>UL Transport channel information common for all transport channels | OP | | UL Transport channel information common for all transport channels 10.3.5.24 | | |
| >>Deleted TrCH information list | OP | 1 to <maxTrCH> | | | |
| >>>Deleted UL TrCH information | MP | | Deleted UL TrCH information 10.3.5.5 | | |
| >>Added or Reconfigured TrCH information list | OP | 1 to <maxTrCH> | | | |
| >>>Added or Reconfigured UL TrCH information | MP | | Added or Reconfigured UL TrCH information 10.3.5.2 | | |
| **Downlink transport channels** | | | | | |
| >>DL Transport channel information common for all transport channels | OP | | DL Transport channel information common for all transport channels 10.3.5.6 | | |
| >>Deleted TrCH information list | OP | 1 to <maxTrCH> | | | |
| >>>Deleted DL TrCH information | MP | | Deleted DL TrCH information 10.3.5.4 | | |
| >>Added or Reconfigured TrCH information list | OP | 1 to <maxTrCH> | | | |
| >>>Added or Reconfigured DL TrCH information | MP | | Added or Reconfigured DL TrCH information 10.3.5.1 | | |

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| >Preconfiguration | | | | | REL-5 |
| >>CHOICE *Preconfiguration mode* | MP | | | This value only applies in case the message is sent through GERAN *Iu mode* | |
| >>>Predefined configuration identity | MP | | Predefined configuration identity 10.3.4.5 | | |
| >>>Default configuration | | | | | |
| >>>>Default configuration mode | MP | | Enumerated (FDD, TDD) | Indicates whether the FDD or TDD version of the default configuration shall be used | |
| >>>>Default configuration identity | MP | | Default configuration identity 10.3.4.0 | | |
| **PhyCH information elements** | | | | | |
| Frequency info | OP | | Frequency info 10.3.6.36 | | |
| **Uplink radio resources** | | | | | |
| Maximum allowed UL TX power | MD | | Maximum allowed UL TX power 10.3.6.39 | Default value is the existing maximum UL TX power | |
| Uplink DPCH info | OP | | Uplink DPCH info 10.3.6.88 | | |
| E-DCH Info | OP | | E-DCH Info 10.3.6.97 | | REL-6 |
| **Downlink radio resources** | | | | | |
| Downlink HS-PDSCH Information | OP | | Downlink HS-PDSCH Information 10.3.6.23a | | REL-5 |
| Downlink information common for all radio links | OP | | Downlink information common for all radio links 10.3.6.24 | | |
| Downlink information per radio link list | MP | 1 to <maxRL> | | Although this IE is not always required, need is MP to align with ASN.1 | |
| | OP | | | | REL-4 |
| >Downlink information for each radio link | MP | | Downlink information for each radio link 10.3.6.27 | | |
| MBMS PL Service Restriction Information | OP | | Enumerated (TRUE) | Absence means that on the MBMS Preferred Layer (PL) no restrictions apply concerning the use of non-MBMS services i.e. the PL is not congested | REL-6 |

## 10.2.28 RADIO BEARER RECONFIGURATION COMPLETE

This message is sent from the UE when a RB and signalling link reconfiguration has been done.

RLC-SAP: AM

Logical channel: DCCH

Direction: UE → UTRAN

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| Message Type | MP | | Message Type | | |
| **UE information elements** | | | | | |
| RRC transaction identifier | MP | | RRC transaction identifier 10.3.3.36 | | |
| Integrity check info | CH | | Integrity check info 10.3.3.16 | | |
| Uplink integrity protection activation info | OP | | Integrity protection activation info 10.3.3.17 | | |
| CHOICE *mode* | MP | | | | |
| >FDD | | | | (no data) | |
| >TDD | | | | | |
| >>CHOICE *TDD option* | MP | | | | REL-4 |
| >>>3.84 Mcps TDD | | | | | REL-4 |
| >>>>Uplink Timing Advance | OP | | Uplink Timing Advance 10.3.6.95 | | |
| >>>7.68 Mcps TDD | | | | | REL-7 |
| >>>>Uplink Timing Advance | OP | | Uplink Timing Advance 10.3.6.95a | | REL-7 |
| >>>1.28 Mcps TDD | | | | (no data) | REL-4 |
| **RB Information elements** | | | | | |
| COUNT-C activation time | OP | | Activation time 10.3.3.1 | Used for radio bearers mapped on RLC-TM. | |
| Uplink counter synchronisation info | OP | | | | |
| >RB with PDCP information list | OP | 1 to <maxRBallRABs> | | | |
| >>RB with PDCP information | MP | | RB with PDCP information 10.3.4.22 | | |
| >START list | MP | 1 to <maxCNdomains> | | START [40] values for all CN domains. | |
| >>CN domain identity | MP | | CN domain identity 10.3.1.1 | | |
| >>START | MP | | START 10.3.3.38 | START value to be used in this CN domain. | |

## 10.2.29 RADIO BEARER RECONFIGURATION FAILURE

This message is sent by UE if the configuration given by UTRAN is unacceptable or if the UE failed to establish the physical channel(s).

RLC-SAP: AM

Logical channel: DCCH

Direction: UE→UTRAN

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Message Type | MP | | Message Type | |
| **UE information elements** | | | | |
| RRC transaction identifier | MP | | RRC transaction identifier 10.3.3.36 | |
| Integrity check info | CH | | Integrity check info 10.3.3.16 | |
| Failure cause | MP | | Failure cause and error information 10.3.3.14 | |
| **RB information elements** | | | | |
| Radio bearers for which reconfiguration would have succeeded List | OP | 1 to <maxRB> | | |
| >Radio bearer for which reconfiguration would have succeeded | MP | | RB identity, 10.3.4.16 | |

## 10.2.30 RADIO BEARER RELEASE

This message is used by UTRAN to release a radio bearer. It can also include modifications to the configurations of transport channels and/or physical channels. It can simultaneously indicate release of a signalling connection when UE is connected to more than one CN domain.

RLC-SAP: AM or UM

Logical channel: DCCH

Direction: UTRAN → UE

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| Message Type | MP | | Message Type | | |
| **UE Information Elements** | | | | | |
| RRC transaction identifier | MP | | RRC transaction identifier 10.3.3.36 | | |
| Integrity check info | CH | | Integrity check info 10.3.3.16 | | |
| Integrity protection mode info | OP | | Integrity protection | The UTRAN should not include this IE unless it is | |

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| | | | mode info 10.3.3.19 | performing an SRNS relocation. | |
| Ciphering mode info | OP | | Ciphering mode info 10.3.3.5 | The UTRAN should not include this IE unless it is performing an SRNS relocation and a change in ciphering algorithm. | |
| Activation time | MD | | Activation time 10.3.3.1 | Default value is "now" | |
| New U-RNTI | OP | | U-RNTI 10.3.3.47 | | |
| New C-RNTI | OP | | C-RNTI 10.3.3.8 | | |
| New DSCH-RNTI | OP | | DSCH-RNTI 10.3.3.9a | Should not be set in FDD. If received the UE should ignore it | |
| New H-RNTI | OP | | H-RNTI 10.3.3.14a | | REL-5 |
| New Primary E-RNTI | OP | | E-RNTI 10.3.3.10a | | REL-6 |
| New Secondary E-RNTI | OP | | E-RNTI 10.3.3.10a | | REL-6 |
| RRC State Indicator | MP | | RRC State Indicator 10.3.3.35a | | |
| UTRAN DRX cycle length coefficient | OP | | UTRAN DRX cycle length coefficient 10.3.3.49 | | |
| **CN Information Elements** | | | | | |
| CN Information info | OP | | CN Information info 10.3.1.3 | | |
| Signalling Connection release indication | OP | | CN domain identity 10.3.1.1 | | |
| **UTRAN mobility information elements** | | | | | |
| URA identity | OP | | URA identity 10.3.2.6 | | |
| **RB Information Elements** | | | | | |
| RAB information to reconfigure list | OP | 1 to < maxRABsetup > | | | |
| >RAB information to reconfigure | MP | | RAB information to reconfigure 10.3.4.11 | | |
| RB information to release list | MP | 1 to <maxRB> | | | |
| >RB information to release | MP | | RB information to release 10.3.4.19 | | |
| RB information to reconfigure list | OP | 1to <maxRB> | | | REL-6 |
| >RB information to reconfigure | MP | | RB information to reconfigure 10.3.4.18 | | REL-6 |
| RB information to be affected list | OP | 1 to <maxRB> | | | |
| >RB information to be affected | MP | | RB | | |

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| | | | information to be affected 10.3.4.17 | | |
| Downlink counter synchronisation info | OP | | | | |
| >RB with PDCP information list | OP | 1 to <maxRBallRABs> | | | |
| >>RB with PDCP information | MP | | RB with PDCP information 10.3.4.22 | This IE is needed for each RB having PDCP in the case of lossless SRNS relocation | |
| | OP | | | | REL-5 |
| >RB with PDCP context relocation info list | OP | 1 to <maxRBallRABs> | | | REL-5 |
| >>PDCP context relocation info | MP | | PDCP context relocation info 10.3.4.1a | This IE is needed for each RB having PDCP and performing PDCP context relocation | REL-5 |
| **TrCH Information Elements** | | | | | |
| **Uplink transport channels** | | | | | |
| UL Transport channel information common for all transport channels | OP | | UL Transport channel information common for all transport channels 10.3.5.24 | | |
| Deleted TrCH information list | OP | 1 to <maxTrCH> | | | |
| >Deleted UL TrCH information | MP | | Deleted UL TrCH information 10.3.5.5 | | |
| Added or Reconfigured TrCH information list | OP | 1 to <maxTrCH> | | | |
| >Added or Reconfigured UL TrCH information | MP | | Added or Reconfigured UL TrCH information 10.3.5.2 | | |
| **Downlink transport channels** | | | | | |
| DL Transport channel information common for all transport channels | OP | | DL Transport channel information common for all transport channels 10.3.5.6 | | |
| Deleted TrCH information list | OP | 1 to <maxTrCH> | | | |
| >Deleted DL TrCH information | MP | | Deleted DL TrCH information 10.3.5.4 | | |
| Added or Reconfigured TrCH information list | OP | 1 to <maxTrCH> | | | |
| >Added or Reconfigured DL | MP | | Added or | | |

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| TrCH information | | | Reconfigured DL TrCH information 10.3.5.1 | | |
| **PhyCH information elements** | | | | | |
| Frequency info | OP | | Frequency info 10.3.6.36 | | |
| **Uplink radio resources** | | | | | |
| Maximum allowed UL TX power | MD | | Maximum allowed UL TX power 10.3.6.39 | Default value is the existing maximum UL TX power | |
| Uplink DPCH info | OP | | Uplink DPCH info 10.3.6.88 | | |
| E-DCH Info | OP | | E-DCH Info 10.3.6.97 | | REL-6 |
| **Downlink radio resources** | | | | | |
| Downlink HS-PDSCH Information | OP | | Downlink HS-PDSCH Information 10.3.6.23a | | REL-5 |
| Downlink information common for all radio links | OP | | Downlink information common for all radio links 10.3.6.24 | | |
| Downlink information per radio link list | OP | 1 to <maxRL> | | Send downlink information for each radio link to be set-up | |
| >Downlink information for each radio link | MP | | Downlink information for each radio link 10.3.6.27 | | |
| MBMS PL Service Restriction Information | OP | | Enumerated (TRUE) | Absence means that on the MBMS Preferred Layer (PL) no restrictions apply concerning the use of non-MBMS services i.e. the PL is not congested | REL-6 |
| MBMS RB list released to change transfer mode | OP | 1 to <maxRB> | | | REL-6 |
| >RB information to release | MP | | RB information to release 10.3.4.19 | | REL-6 |

## 10.2.31 RADIO BEARER RELEASE COMPLETE

This message is sent from the UE when radio bearer release has been completed.

RLC-SAP: AM

Logical channel: DCCH

Direction: UE → UTRAN

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| Message Type | MP | | Message Type | | |
| **UE information elements** | | | | | |

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| RRC transaction identifier | MP | | RRC transaction identifier 10.3.3.36 | | |
| Integrity check info | CH | | Integrity check info 10.3.3.16 | Integrity check info is included if integrity protection is applied | |
| Uplink integrity protection activation info | OP | | Integrity protection activation info 10.3.3.17 | | |
| CHOICE *mode* | MP | | | | |
| >FDD | | | | (no data) | |
| >TDD | | | | | |
| >>CHOICE *TDD option* | MP | | | | REL-4 |
| >>>3.84 Mcps TDD | | | | | REL-4 |
| >>>>Uplink Timing Advance | OP | | Uplink Timing Advance 10.3.6.95 | This information element shall be present in case of handover procedure if timing advance is enabled. Calculated timing advance value for the new cell after handover in a synchronous TDD network | |
| >>>7.68 Mcps TDD | | | | | REL-7 |
| >>>>Uplink Timing Advance | OP | | Uplink Timing Advance 10.3.6.95a | This information element shall be present in case of handover procedure if timing advance is enabled. Calculated timing advance value for the new cell after handover in a synchronous TDD network | REL-7 |
| >>>1.28 Mcps TDD | | | | (no data) | REL-4 |
| **RB Information elements** | | | | | |
| COUNT-C activation time | OP | | Activation time 10.3.3.1 | Used for radio bearers mapped on RLC-TM. | |
| Uplink counter synchronisation info | OP | | | | |
| >RB with PDCP information list | OP | 1 to <maxRBallRABs> | | This IE is needed for each RB having PDCP in the case of lossless SRNS relocation | |
| >>RB with PDCP information | MP | | RB with PDCP information 10.3.4.22 | | |
| >START list | MP | 1 to <maxCNdomains> | | START [40] values for all CN domains. | |
| >>CN domain identity | MP | | CN domain | | |

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| | | | identity 10.3.1.1 | | |
| >>START | MP | | START 10.3.3.38 | START value to be used in this CN domain. | |

## 10.2.32 RADIO BEARER RELEASE FAILURE

This message is sent by UE if the configuration given by UTRAN is unacceptable or if radio bearer cannot be released.

RLC-SAP: AM

Logical channel: DCCH

Direction: UE→UTRAN

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Message Type | MP | | Message Type | |
| **UE information elements** | | | | |
| RRC transaction identifier | MP | | RRC transaction identifier 10.3.3.36 | |
| Integrity check info | CH | | Integrity check info 10.3.3.16 | |
| Failure cause | MP | | Failure cause and error information 10.3.3.14 | |
| **RB information elements** | | | | |
| Radio bearers for which reconfiguration would have succeeded | OP | 1 to <maxRB> | | |
| >Radio bearer for which reconfiguration would have been succeeded | MP | | RB identity, 10.3.4.16 | |

## 10.2.33 RADIO BEARER SETUP

This message is sent by UTRAN to the UE to establish new radio bearer(s). It can also include modifications to the configurations of transport channels and/or physical channels.

RLC-SAP: AM or UM

Logical channel: DCCH

Direction: UTRAN → UE

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| Message Type | MP | | Message Type | | |
| **UE Information Elements** | | | | | |
| RRC transaction identifier | MP | | RRC transaction identifier 10.3.3.36 | | |

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| Integrity check info | CH | | Integrity check info 10.3.3.16 | | |
| Integrity protection mode info | OP | | Integrity protection mode info 10.3.3.19 | The UTRAN should not include this IE unless it is performing an SRNS relocation | |
| Ciphering mode info | OP | | Ciphering mode info 10.3.3.5 | The UTRAN should not include this IE unless it is performing an SRNS relocation and a change in ciphering algorithm | |
| Activation time | MD | | Activation time 10.3.3.1 | Default value is "now" | |
| New U-RNTI | OP | | U-RNTI 10.3.3.47 | | |
| New C-RNTI | OP | | C-RNTI 10.3.3.8 | | |
| New DSCH-RNTI | OP | | DSCH-RNTI 10.3.3.9a | Should not be set in FDD. If received the UE should ignore it | |
| New H-RNTI | OP | | H-RNTI 10.3.3.14a | | REL-5 |
| New Primary E-RNTI | OP | | E-RNTI 10.3.3.10a | | REL-6 |
| New Secondary E-RNTI | OP | | E-RNTI 10.3.3.10a | | REL-6 |
| RRC State Indicator | MP | | RRC State Indicator 10.3.3.35a | | |
| UTRAN DRX cycle length coefficient | OP | | UTRAN DRX cycle length coefficient 10.3.3.49 | | |
| **CN Information Elements** | | | | | |
| CN Information info | OP | | CN Information info 10.3.1.3 | | |
| **UTRAN mobility information elements** | | | | | |
| URA identity | OP | | URA identity 10.3.2.6 | | |
| **RB Information Elements** | | | | | |
| CHOICE specification mode | MP | | | | REL-6 |
| >Complete specification | | | | | REL-6 |
| >>Signalling RB information to setup list | OP | 1 to <maxSRBsetup> | | For each signalling radio bearer established | |
| >>>Signalling RB information to setup | MP | | Signalling RB information to setup 10.3.4.24 | | |
| >>RAB information to setup list | OP | 1 to <maxRABsetup> | | For each RAB established | |
| >>>RAB information for setup | MP | | RAB information for setup 10.3.4.10 | | |
| >>RAB information to | OP | 1 to < | | | REL-6 |

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| reconfigure list | | maxRABsetup > | | | |
| >>>RAB information to reconfigure | MP | | RAB information to reconfigure 10.3.4.11 | | REL-6 |
| >>RB information to reconfigure list | OP | 1to <maxRB> | | | REL-6 |
| >>>RB information to reconfigure | MP | | RB information to reconfigure 10.3.4.18 | | REL-6 |
| >>RB information to be affected list | OP | 1 to <maxRB> | | | |
| >>>RB information to be affected | MP | | RB information to be affected 10.3.4.17 | | |
| >>Downlink counter synchronisation info | OP | | | | |
| >>>RB with PDCP information list | OP | 1 to <maxRBallRABs> | | | |
| >>>>RB with PDCP information | MP | | RB with PDCP information 10.3.4.22 | This IE is needed for each RB having PDCP in the case of lossless SRNS relocation | |
| | OP | | | | REL-5 |
| >>>>PDCP context relocation info | OP | | PDCP context relocation info 10.3.4.1a | This IE is needed for each RB having PDCP and performing PDCP context relocation | REL-5 |
| >>PDCP ROHC target mode | OP | | PDCP ROHC target mode 10.3.4.2a | | REL-5 |
| **TrCH Information Elements** | | | | | |
| **Uplink transport channels** | | | | | |
| >>UL Transport channel information common for all transport channels | OP | | UL Transport channel information common for all transport channels 10.3.5.24 | | |
| >>Deleted TrCH information list | OP | 1 to <maxTrCH> | | | |
| >>>Deleted UL TrCH information | MP | | Deleted UL TrCH information 10.3.5.5 | | |
| >>Added or Reconfigured TrCH information list | OP | 1 to <maxTrCH> | | | |
| >>>Added or Reconfigured UL TrCH information | MP | | Added or Reconfigured UL TrCH information 10.3.5.2 | | |

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| **Downlink transport channels** | | | | | |
| >>DL Transport channel information common for all transport channels | OP | | DL Transport channel information common for all transport channels10.3.5.6 | | |
| >>Deleted TrCH information list | OP | 1 to <maxTrCH> | | | |
| >>>Deleted DL TrCH information | MP | | Deleted DL TrCH information 10.3.5.4 | | |
| >>Added or Reconfigured TrCH information list | OP | 1 to <maxTrCH> | | | |
| >>>Added or Reconfigured DL TrCH information | MP | | Added or Reconfigured DL TrCH information 10.3.5.1 | | |
| >Preconfiguration | | | | This value only applies in case the message is not sent through GERAN *Iu mode* | REL-6 |
| >>RAB info | MP | | RAB info 10.3.4.8 | | REL-6 |
| >>Default configuration mode | MP | | Enumerated (FDD, TDD) | Indicates whether the FDD or TDD version of the default configuration shall be used | REL-6 |
| >>Default configuration identity | MP | | Default configuration identity 10.3.4.0 | | REL-6 |
| >>RB information change list | OP | 1 to <maxRB> | | | REL-6 |
| >>>RB identity | MP | | RB identity 10.3.4.16 | Absence of an RB implies that the RB is to be "maintained" | REL-6 |
| >>>CHOICE RB change | MP | | | | REL-6 |
| >>>>Release | | | | (no data) | REL-6 |
| >>>>Re-map to default RB | MD | | RB identity 10.3.4.16 | Default value is the current RB identity | REL-6 |
| >>Power offset information short | MP | | | | REL-6 |
| >>>Reference TFC | MP | | Transport Format Combination (TFC) 10.3.5.19 | Identified by TFCI | REL-6 |
| >>>CHOICE *mode* | | | | | REL-6 |
| >>>>FDD | | | | | REL-6 |
| >>>>>Gain Factor $\beta_c$ | MP | | Integer (0..15) | For UL DPCCH or control part of PRACH | REL-6 |
| >>>>TDD | | | | (no data) | REL-6 |
| >>>Gain Factor $\beta_d$ | MP | | Integer (0..15) | For UL DPDCH or data part of PRACH and all uplink channels in TDD | REL-6 |
| **PhyCH information elements** | | | | | |
| Frequency info | OP | | Frequency info | | |

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| | | | 10.3.6.36 | | |
| **Uplink radio resources** | | | | | |
| Maximum allowed UL TX power | MD | | Maximum allowed UL TX power 10.3.6.39 | Default value is the existing maximum UL TX power | |
| Uplink DPCH info | OP | | Uplink DPCH info 10.3.6.88 | | |
| E-DCH Info | OP | | E-DCH Info 10.3.6.97 | | REL-6 |
| **Downlink radio resources** | | | | | |
| Downlink HS-PDSCH Information | OP | | Downlink HS-PDSCH Information 10.3.6.23a | | REL-5 |
| Downlink information common for all radio links | OP | | Downlink information common for all radio links 10.3.6.24 | | |
| Downlink information per radio link list | OP | 1 to <maxRL> | | Send downlink information for each radio link | |
| >Downlink information for each radio link | MP | | Downlink information for each radio link 10.3.6.27 | | |
| MBMS PL Service Restriction Information | OP | | Enumerated (TRUE) | Absence means that on the MBMS Preferred Layer (PL) no restrictions apply concerning the use of non-MBMS services i.e. the PL is not congested | REL-6 |

## 10.2.34 RADIO BEARER SETUP COMPLETE

This message is sent by the UE to confirm the establishment of the radio bearer.

RLC-SAP: AM

Logical channel: DCCH

Direction: UE → UTRAN

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| Message Type | MP | | Message Type | | |
| **UE information elements** | | | | | |
| RRC transaction identifier | MP | | RRC transaction identifier 10.3.3.36 | | |
| Integrity check info | CH | | Integrity check info 10.3.3.16 | | |
| Uplink integrity protection activation info | OP | | Integrity protection | | |

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| | | | activation info 10.3.3.17 | | |
| CHOICE *mode* | OP | | | | |
| >FDD | | | | (no data) | |
| >TDD | | | | | |
| >>CHOICE *TDD option* | MP | | | | REL-4 |
| >>>3.84 Mcps TDD | | | | | REL-4 |
| >>>>Uplink Timing Advance | OP | | Uplink Timing Advance 10.3.6.95 | This information element shall be present in case of handover procedure if timing advance is enabled. Calculated timing advance value for the new cell after handover in a synchronous TDD network | |
| >>>7.68 Mcps TDD | | | | | REL-7 |
| >>>>Uplink Timing Advance | OP | | Uplink Timing Advance 10.3.6.95a | This information element shall be present in case of handover procedure if timing advance is enabled. Calculated timing advance value for the new cell after handover in a synchronous TDD network | REL-7 |
| >>>1.28 Mcps TDD | | | | (No data) | REL-4 |
| START | OP | | START 10.3.3.38 | This information element is not needed for transparent mode RBs if prior to this procedure there exists one RB using RLC-TM. | |
| **RB Information elements** | | | | | |
| COUNT-C activation time | OP | | Activation time 10.3.3.1 | Used for radio bearers mapped on RLC-TM. | |
| Uplink counter synchronisation info | OP | | | | |
| >RB with PDCP information list | OP | 1 to <maxRBallRABs> | | This IE is needed for each RB having PDCP in the case of lossless SRNS relocation | |
| >>RB with PDCP information | MP | | RB with PDCP information 10.3.4.22 | | |
| >START list | MP | 1 to <maxCNdomains> | | START [40] values for all CN domains. | |
| >>CN domain identity | MP | | CN domain identity 10.3.1.1 | | |

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| >>START | MP | | START 10.3.3.38 | START value to be used in this CN domain. | |

## 10.2.35 RADIO BEARER SETUP FAILURE

This message is sent by UE, if it does not support the configuration given by UTRAN.

RLC-SAP: AM

Logical channel: DCCH

Direction: UE→UTRAN

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Message Type | MP | | Message Type | |
| **UE information elements** | | | | |
| RRC transaction identifier | MP | | RRC transaction identifier 10.3.3.36 | |
| Integrity check info | CH | | Integrity check info 10.3.3.16 | |
| Failure cause | MP | | Failure cause and error information 10.3.3.14 | |
| **RB information elements** | | | | |
| Radio bearers for which reconfiguration would have succeeded | OP | 1 to <maxRB> | | |
| >Radio bearer for which reconfiguration would have succeeded | MP | | RB identity, 10.3.4.16 | |

## 10.2.36 RRC CONNECTION REJECT

The network transmits this message when the requested RRC connection cannot be accepted.

RLC-SAP: UM

Logical channel: CCCH

Direction: UTRAN → UE

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Message Type | MP | | Message Type | |
| **UE information elements** | | | | |
| RRC transaction identifier | MP | | RRC transaction identifier 10.3.3.36 | |
| Initial UE identity | MP | | Initial UE identity 10.3.3.15 | |
| Rejection cause | MP | | Rejection | |

| | | | | |
|---|---|---|---|---|
| | | | cause 10.3.3.31 | |
| Wait time | MP | | Wait time 10.3.3.50 | |
| Redirection info | OP | | Redirection info 10.3.3.29 | |

## 10.2.37 RRC CONNECTION RELEASE

This message is sent by UTRAN to release the RRC connection. The message also releases the signalling connection and all radio bearers between the UE and UTRAN.

RLC-SAP: UM

Logical channel: CCCH or DCCH

Direction: UTRAN→UE

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| Message Type | MP | | Message Type | | |
| **UE information elements** | | | | | |
| CHOICE identity type | *CV-CCCH* | | | | REL-5 |
| >U-RNTI | | | U-RNTI 10.3.3.47 | | |
| > Group identity | | 1 to <maxURNTIgroup> | | | REL-5 |
| >>Group release information | MP | | Group release information 10.3.3.14 o | | REL-5 |
| RRC transaction identifier | MP | | RRC transaction identifier 10.3.3.36 | | |
| Integrity check info | CV-*DCCH* | | Integrity check info 10.3.3.16 | Integrity check info is included if integrity protection is applied | |
| N308 | CH-*Cell_DCH* | | Integer(1..8) | | |
| Release cause | MP | | Release cause 10.3.3.32 | | |
| **Other information elements** | | | | | |
| Rplmn information | OP | | Rplmn information 10.3.8.15 | | |
| Redirection info | OP | | Redirection info 10.3.3.29 | | REL-6 |

| Condition | Explanation |
|---|---|
| *CCCH* | This IE is mandatory present when CCCH is used and not needed otherwise. |
| *DCCH* | This IE is mandatory present when DCCH is used and not needed otherwise. |
| *Cell_DCH* | This IE is mandatory present when UE is in CELL_DCH state and not needed otherwise. |

## 10.2.38 RRC CONNECTION RELEASE COMPLETE

This message is sent by UE to confirm that the RRC connection has been released.

RLC-SAP: AM or UM

Logical channel: DCCH

Direction: UE → UTRAN

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Message Type | MP | | Message Type | |
| **UE information elements** | | | | |
| RRC transaction identifier | MP | | RRC transaction identifier 10.3.3.36 | |
| Integrity check info | CH | | Integrity check info 10.3.3.16 | |
| Error indication | OP | | Failure cause and error information 10.3.3.14 | |

## 10.2.39 RRC CONNECTION REQUEST

RRC Connection Request is the first message transmitted by the UE when setting up an RRC Connection to the network.

RLC-SAP: TM

Logical channel: CCCH

Direction: UE → UTRAN

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| Message Type | MP | | Message Type | | |
| **Radio Bearer IEs** | | | | | |
| Predefined configuration status information | MP | | Boolean | True indicates the UE has all pre-configurations stored with the same value tag as broadcast in the cell in which the RRC connection establishment is initiated | REL-5 |
| **UE information elements** | | | | | |
| Initial UE identity | MP | | Initial UE identity 10.3.3.15 | | |
| Establishment cause | MP | | Establishment cause 10.3.3.11 | | |
| Protocol error indicator | MD | | Protocol error indicator 10.3.3.27 | Default value is FALSE | |
| **>**UE Specific Behaviour Information 1 idle | OP | | UE Specific Behaviour Information 1 idle 10.3.3.51 | This IE shall not be included in this version of the protocol | |
| Domain indicator | MP | | CN domain identity 10.3.1.1 | | REL-6 |
| Call type | CV-*CS-domain* | | Enumerated (speech, video, other) | One spare value is needed | REL-6 |
| UE capability indication | OP | | Enumerated (HS-DSCH, HS-DSCH+E-DCH) | Absence of this IE implies that neither HS-DSCH nor E-DCH are supported by the UE | REL-6 |
| **Measurement information elements** | | | | | |
| Measured results on RACH | OP | | Measured results on RACH 10.3.7.45 | | |
| Access stratum release indicator | MP | | Enumerated( REL-4, | Absence of the IE implies R99. The IE also indicates the release of the RRC transfer syntax supported by the UE 13 spare values are needed | REL-4 |
| | | | REL-5 | | REL-5 |
| | | | REL-6) | | REL-6 |

| Condition | Explanation |
|---|---|
| *CS-domain* | This IE is mandatory present if the IE "Domain indicator" has the value "CS domain". Otherwise it is not needed. |

If the encoded message does not fill a transport block, the RRC layer shall insert padding according to subclause 12.1.

## 10.2.40 RRC CONNECTION SETUP

This message is used by the network to accept the establishment of an RRC connection for a UE, including assignment of signalling link information, transport channel information and optionally physical channel information.

RLC-SAP: UM

Logical channel: CCCH

Direction: UTRAN → UE

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| Message Type | MP | | Message Type | | |
| **UE Information Elements** | | | | | |
| Initial UE identity | MP | | Initial UE identity 10.3.3.15 | | |
| RRC transaction identifier | MP | | RRC transaction identifier 10.3.3.36 | | |
| Activation time | MD | | Activation time 10.3.3.1 | Default value is "now" | |
| New U-RNTI | MP | | U-RNTI 10.3.3.47 | | |
| New C-RNTI | OP | | C-RNTI 10.3.3.8 | | |
| New H-RNTI | OP | | H-RNTI 10.3.3.14a | | REL-6 |
| New Primary E-RNTI | OP | | E-RNTI 10.3.3.10a | | REL-6 |
| New Secondary E-RNTI | OP | | E-RNTI 10.3.3.10a | | REL-6 |
| RRC State Indicator | MP | | RRC State Indicator 10.3.3.35a | | |
| UTRAN DRX cycle length coefficient | MP | | UTRAN DRX cycle length coefficient 10.3.3.49 | | |
| Capability update requirement | MD | | Capability update requirement 10.3.3.2 | Default value is defined in subclause 10.3.3.2 | |
| CHOICE *specification mode* | MP | | | | REL-5 |
| >Complete specification | | | | | |
| **RB Information Elements** | | | | | |
| >>Signalling RB information to setup list | MP | 3 to 4 | | | |
| >>>Signalling RB information to setup | MP | | Signalling RB information to setup 10.3.4.24 | | |
| **TrCH Information Elements** | | | | | |
| **Uplink transport channels** | | | | | |

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| >>UL Transport channel information common for all transport channels | OP | | UL Transport channel information common for all transport channels 10.3.5.24 | | |
| >>Added or Reconfigured TrCH information list | MP | 1 to <maxTrCH> | | Although this IE is not required when the IE "RRC state indicator" is set to "CELL_FACH", need is MP to align with ASN.1 | |
| | OP | | | | REL-4 |
| >>>Added or Reconfigured UL TrCH information | MP | | Added or Reconfigured UL TrCH information 10.3.5.2 | | |
| **Downlink transport channels** | | | | | |
| >>DL Transport channel information common for all transport channels | OP | | DL Transport channel information common for all transport channels 10.3.5.6 | | |
| >>Added or Reconfigured TrCH information list | MP | 1 to <maxTrCH> | | Although this IE is not required when the IE "RRC state indicator" is set to "CELL_FACH", need is MP to align with ASN.1 | |
| | OP | | | | REL-4 |
| >>>Added or Reconfigured DL TrCH information | MP | | Added or Reconfigured DL TrCH information 10.3.5.1 | | |
| >Preconfiguration | | | | | REL-5 |
| >>CHOICE *Preconfiguration mode* | MP | | | | REL-5 |
| >>>Predefined configuration identity | MP | | Predefined configuration identity 10.3.4.5 | | REL-5 |
| >>>Default configuration | | | | | REL-5 |
| >>>>Default configuration mode | MP | | Enumerated (FDD, TDD) | Indicates whether the FDD or TDD version of the default configuration shall be used | REL-5 |
| >>>>Default configuration identity | MP | | Default configuration identity 10.3.4.0 | | REL-5 |
| **PhyCH information elements** | | | | | |
| Frequency info | OP | | Frequency info 10.3.6.36 | | |
| **Uplink radio resources** | | | | | |
| Maximum allowed UL TX power | MD | | Maximum allowed UL | Default value is the existing | |

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| | | | TX power 10.3.6.39 | maximum UL TX power | |
| Uplink DPCH info | OP | | Uplink DPCH info 10.3.6.88 | | |
| E-DCH Info | OP | | E-DCH Info 10.3.6.97 | | REL-6 |
| **Downlink radio resources** | | | | | |
| Downlink HS-PDSCH Information | OP | | Downlink HS-PDSCH information 10.3.6.23a | | REL-6 |
| Downlink information common for all radio links | OP | | Downlink information common for all radio links 10.3.6.24 | | |
| Downlink information per radio link list | OP | 1 to <MaxRL> | | Send downlink information for each radio link to be set-up | |
| >Downlink information for each radio link | MP | | Downlink information for each radio link 10.3.6.27 | | |

## 10.2.41 RRC CONNECTION SETUP COMPLETE

This message confirms the establishment of the RRC Connection by the UE.

RLC-SAP: AM

Logical channel: DCCH

Direction: UE → UTRAN

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Message Type | MP | | Message Type | |
| **UE Information Elements** | | | | |
| RRC transaction identifier | MP | | RRC transaction identifier 10.3.3.36 | |
| START list | MP | 1 to <maxCNdomains> | | START [40] values for all CN domains. |
| >CN domain identity | MP | | CN domain identity 10.3.1.1 | |
| >START | MP | | START 10.3.3.38 | START value to be used in this CN domain. |
| UE radio access capability | OP | | UE radio access capability 10.3.3.42 | |
| UE radio access capability extension | OP | | UE radio access capability extension 10.3.3.42a | |

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| **Other information elements** | | | | |
| UE system specific capability | OP | 1 to <maxInterSysMessages> | | |
| >Inter-RAT UE radio access capability | MP | | Inter-RAT UE radio access capability 10.3.8.7 | |

## 10.2.41a RRC FAILURE INFO

This message is sent by the UE via another radio access technology to provide information about the cause for failure to perform the requested operation.

RLC-SAP: N/A (Sent through a different RAT)

Logical channel: N/A (Sent through a different RAT)

Direction: UE → UTRAN

| Information Element/Group Name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| **Other Information elements** | | | | |
| Failure cause | MP | | Failure cause 10.3.3.13 | |
| Protocol error information | CV-*ProtErr* | | Protocol error information 10.3.8.12 | |

| Condition | Explanation |
|---|---|
| *ProtErr* | Presence is mandatory if the IE "Failure cause" has the value "Protocol error"; otherwise the element is not needed in the message. |

## 10.2.42 RRC STATUS

This message is sent to indicate a protocol error.

RLC-SAP: AM

Logical channel: DCCH

Direction: UE→UTRAN

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Message Type | MP | | Message Type | |
| **UE information elements** | | | | |
| Integrity check info | CH | | Integrity check info 10.3.3.16 | Integrity check info is included if integrity protection is applied |
| Identification of received message | CV-*Message identified* | | | |
| >Received message type | MP | | Message Type | |

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| >RRC transaction identifier | MP | | RRC transaction identifier 10.3.3.36 | |
| **Other information elements** | | | | |
| Protocol error information | MP | | Protocol error information 10.3.8.12 | |

| Condition | Explanation |
|---|---|
| *Message identified* | This IE is mandatory present if the IE "Protocol error cause" in the IE "Protocol error information" has any other value than "ASN.1 violation or encoding error" or "Message type non-existent or not implemented" and not needed otherwise. |

## 10.2.43 SECURITY MODE COMMAND

This message is sent by UTRAN to start or reconfigure ciphering and/or integrity protection parameters.

RLC-SAP: AM

Logical channel: DCCH

Direction: UTRAN to UE

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Message Type | MP | | Message Type | |
| **UE information elements** | | | | |
| RRC transaction identifier | MP | | RRC transaction identifier 10.3.3.36 | |
| Integrity check info | MP | | Integrity check info 10.3.3.16 | |
| Security capability | MP | | Security capability 10.3.3.37 | |
| Ciphering mode info | OP | | Ciphering mode info 10.3.3.5 | Only present if ciphering shall be controlled |
| Integrity protection mode info | OP | | Integrity protection mode info 10.3.3.19 | Only present if integrity protection shall be controlled |
| **CN Information elements** | | | | |
| CN domain identity | MP | | CN domain identity 10.3.1.1 | Indicates which ciphering and integrity protection keys are applicable |
| **Other information elements** | | | | |
| UE system specific security capability | CH | 1 to <maxInterSysMessages> | | This IE is included if the IE "Inter-RAT UE radio access capability" was included in RRC CONNECTION SETUP COMPLETE message |
| >Inter-RAT UE security capability | MP | | Inter-RAT UE security capability 10.3.8.8a | |

## 10.2.44 SECURITY MODE COMPLETE

This message is sent by UE to confirm the reconfiguration of ciphering and/or integrity protection.

RLC-SAP: AM

Logical channel: DCCH

Direction: UE to UTRAN

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Message Type | MP | | Message Type | |
| **UE information elements** | | | | |
| RRC transaction identifier | MP | | RRC transaction identifier 10.3.3.36 | |
| Integrity check info | MP | | Integrity check info 10.3.3.16 | |
| Uplink integrity protection activation info | OP | | Integrity protection activation info 10.3.3.17 | |
| **RB Information elements** | | | | |
| Radio bearer uplink ciphering activation time info | OP | | RB activation time info 10.3.4.13 | |

## 10.2.45 SECURITY MODE FAILURE

This message is sent to indicate a failure to act on a received SECURITY MODE COMMAND message.

RLC-SAP: AM

Logical channel: DCCH

Direction: UE→UTRAN

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Message Type | MP | | Message Type | |
| **UE information elements** | | | | |
| RRC transaction identifier | MP | | RRC transaction identifier 10.3.3.36 | |
| Integrity check info | CH | | Integrity check info 10.3.3.16 | |
| Failure cause | MP | | Failure cause and error information 10.3.3.14 | |

## 10.2.46 SIGNALLING CONNECTION RELEASE

This message is used to notify the UE that its ongoing signalling connection to a CN domain has been released.

RLC-SAP: AM

Logical channel: DCCH

Direction: UTRAN→UE

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Message Type | MP | | Message Type | |
| **UE information elements** | | | | |
| RRC transaction identifier | MP | | RRC transaction identifier 10.3.3.36 | |
| Integrity check info | CH | | Integrity check info 10.3.3.16 | Integrity check info is included if integrity protection is applied |
| **CN information elements** | | | | |
| CN domain identity | MP | | CN domain identity 10.3.1.1 | |

## 10.2.47 SIGNALLING CONNECTION RELEASE INDICATION

This message is used by the UE to indicate to UTRAN the release of an existing signalling connection.

RLC-SAP: AM

Logical channel: DCCH

Direction: UE→UTRAN

| Information Element/Group name | Need | Multi | IE type and reference | Semantics description |
|---|---|---|---|---|
| Message Type | MP | | Message type | |
| **UE Information Elements** | | | | |
| Integrity check info | CH | | Integrity check info 10.3.3.16 | |
| **CN information elements** | | | | |
| CN domain identity | MP | | CN domain identity 10.3.1.1 | |

## 10.2.48 SYSTEM INFORMATION

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Message type | CV-*channel1* | | Message type | |
| SFNprime | CV-*channel2* | | Integer(0..4094 by step of 2) | SFN=SFNprime (for first 10ms frame of 20ms TTI), SFN=SFNprime+1 (for last 10ms frame of 20ms TTI) |
| CHOICE *Segment combination* | MP | | | Five spares are needed |
| >Combination 1 | | | | (no data) |
| >Combination 2 | | | | |

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| >>First Segment | MP | | First Segment, 10.2.48.1 | |
| >Combination 3 | | | | |
| >>Subsequent Segment | MP | | Subsequent Segment, 10.2.48.3 | |
| >Combination 4 | | | | |
| >>Last segment | MP | | Last segment (short),10.2.48.5 | |
| >Combination 5 | | | | |
| >>Last segment | MP | | Last Segment (short)10.2.48.5 | |
| >>First Segment | MP | | First Segment (short), 10.2.48.2 | |
| >Combination 6 | | | | |
| >>Last Segment | MP | | Last Segment (short), 10.2.48.5 | |
| >>Complete list | MP | 1 to maxSIBperMsg | | Note 1 |
| >>>Complete | MP | | Complete SIB (short),10.2.48.7 | |
| >Combination 7 | | | | |
| >>Last Segment | MP | | Last Segment (short), 10.2.48.5 | |
| >>Complete list | MP | 1..< maxSIBperMsg> | | Note 1 |
| >>>Complete | MP | | Complete SIB (short),10.2.48.7 | |
| >>First Segment | MP | | First Segment (short), 10.2.48.2 | |
| >Combination 8 | | | | |
| >>Complete list | MP | 1 to maxSIBperMsg | | Note 1 |
| >>>Complete | MP | | Complete SIB (short),10.2.48.7 | |
| >Combination 9 | | | | |
| >>Complete list | MP | 1..MaxSIBperMsg | | Note 1 |
| >>>Complete | MP | | Complete SIB (short),10.2.48.7 | |
| >>First Segment | MP | | First | |

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| | | | Segment (short), 10.2.48.2 | |
| >Combination 10 | | | | |
| >>>Complete SIB of size 215 to 226 | MP | | Complete SIB,10.2.48.6 | |
| >Combination 11 | | | | |
| >>Last segment of size 215 to 222 | MP | | Last segment,10.2.48.4 | |

| Condition | Explanation |
|---|---|
| *channel1* | The IE is mandatory present if the message is sent on the FACH and not needed otherwise. |
| *channel2* | This IE is mandatory present if the channel is BCH, otherwise it is not needed. |

If the encoded message does not fill a transport block, the RRC layer shall insert padding according to subclause 12.1. Padding is needed e.g. if the remaining space is insufficient to start a new First Segment (which requires several bits for SIB type, SEG_COUNT and SIB data).

NOTE 1: If Combination 6 - 9 contains a Master information block Master information shall be located as the first IE in the list.

### 10.2.48.1 First Segment

This segment type is used to transfer the first segment of a segmented system information block. The IE is used when the first segment fills the entire transport block (Combination 2).

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| **Other information elements** | | | | |
| SIB type | MP | | SIB Type, 10.3.8.21 | |
| SEG_COUNT | MP | | SEG COUNT, 10.3.8.17 | |
| SIB data fixed | MP | | SIB data fixed, 10.3.8.19 | |

### 10.2.48.2 First Segment (short)

This segment type is used to transfer the first segment of a segmented system information block. The IE is used when the first segment is concatenated after other segments in a transport block (Combination 5, 7 and 9).

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| **Other information elements** | | | | |
| SIB type | MP | | SIB Type, 10.3.8.21 | |
| SEG_COUNT | MP | | SEG COUNT, 10.3.8.17 | |
| SIB data variable | MP | | SIB data variable, 10.3.8.20 | |

### 10.2.48.3 Subsequent Segment

This segment type is used to transfer a subsequent segment of a segmented system information block.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| **Other information elements** | | | | |
| SIB type | MP | | SIB Type, 10.3.8.21 | |
| Segment index | MP | | Segment Index, 10.3.8.18 | |
| SIB data fixed | MP | | SIB data fixed, 10.3.8.19 | |

### 10.2.48.4 Last Segment

This segment type is used to transfer the last segment of a segmented system information block. The IE is used when the last segment has a length, excluding length denominator, from 215 through 222 (Combination 11).

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| **Other information elements** | | | | |
| SIB type | MP | | SIB Type, 10.3.8.21 | |
| Segment index | MP | | Segment Index, 10.3.8.18 | |
| SIB data fixed | MP | | SIB data fixed, 10.3.8.19 | In case the SIB data is less than 222 bits, padding shall be used. The same padding bits shall be used as defined in clause 12.1 |

### 10.2.48.5 Last Segment (short)

This segment type is used to transfer the last segment of a segmented system information block. The IE is used when the last segment has a length, excluding length denominator, of upto 214 bits (Combination 4, 5, 6 and 7).

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| **Other information elements** | | | | |
| SIB type | MP | | SIB Type, 10.3.8.21 | |
| Segment index | MP | | Segment Index, 10.3.8.18 | |
| SIB data variable | MP | | SIB data variable, 10.3.8.20 | |

### 10.2.48.6 Complete SIB

This segment type is used to transfer a non-segmented system information block. The IE is used when the complete SIB has a length, excluding length denominator, from 215 through 226 (Combination 10).

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| **Other information elements** | | | | |
| SIB type | MP | | SIB Type, 10.3.8.21 | |
| SIB data fixed | MP | | Bit string (226) | The first/leftmost/most significant bit of the bit string contains the first bit of the segment. In case the SIB data is less than 226 bits, padding shall be used. The same padding bits shall be used as defined in clause 12.1 |

### 10.2.48.7 Complete SIB (short)

This segment type is used to transfer a non-segmented system information block. The IE is used when the complete SIB has a length, excluding length denominator, of upto 214 bits (Combination 6, 7, 8 and 9).

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| **Other information elements** | | | | |
| SIB type | MP | | SIB Type, 10.3.8.21 | |
| SIB data variable | MP | | SIB data variable, 10.3.8.20 | |

### 10.2.48.8 System Information Blocks

The IE "SIB data" within the IEs, "First Segment", "Subsequent or last Segment" and "Complete SIB" contains either complete system information block or a segment of a system information block. The actual system information blocks are defined in the following clauses.

#### 10.2.48.8.1 Master Information Block

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| **Other information elements** | | | | | |
| MIB Value tag | MP | | MIB Value tag 10.3.8.9 | | |
| **CN information elements** | | | | | |
| Supported PLMN types | MP | | PLMN Type 10.3.1.12 | | |
| PLMN Identity | CV-*GSM* | | PLMN Identity 10.3.1.11 | | |
| Multiple PLMN List | OP | | Multiple PLMN List 10.3.1.7a | If present, this IE specifies the PLMNs of the cell. If absent, the IE 'PLMN Identity' specifies the PLMN of the cell. | REL-6 |
| **ANSI-41 information elements** | | | | | |
| ANSI-41 Core Network Information | CV-*ANSI-41* | | ANSI-41 Core Network Information 10.3.9.1 | | |
| References to other system information blocks and scheduling blocks | MP | | References to other system information blocks and scheduling blocks 10.3.8.14 | | |

| Condition | Explanation |
|---|---|
| *GSM* | The IE is mandatory present if the IE "Supported PLMN Types" is set to 'GSM-MAP' or 'GSM-MAP AND ANSI-41', and not needed otherwise |
| *ANSI-41* | The IE is mandatory present if the IE "Supported PLMN Types" is set to 'ANSI-41' or 'GSM-MAP AND ANSI-41', and not needed otherwise |

#### 10.2.48.8.2 Scheduling Block 1

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| References to other system information blocks | MP | | References to other system information blocks 10.3.8.13 | |

#### 10.2.48.8.3 Scheduling Block 2

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| References to other system information blocks | MP | | References to other system information blocks 10.3.8.13 | |

### 10.2.48.8.4 System Information Block type 1

The system information block type 1 contains NAS system information as well as UE timers and counters to be used in idle mode and in connected mode.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| **CN information elements** | | | | |
| CN common GSM-MAP NAS system information | MP | | NAS system information (GSM-MAP) 10.3.1.9 | |
| CN domain system information list | MP | 1 to <maxCNdomains> | | Send CN information for each CN domain. |
| >CN domain system information | MP | | CN domain system information 10.3.1.2 | |
| **UE information** | | | | |
| UE Timers and constants in idle mode | MD | | UE Timers and constants in idle mode 10.3.3.44 | The UE behaviour is unspecified if this IE is absent. |
| UE Timers and constants in connected mode | MD | | UE Timers and constants in connected mode 10.3.3.43 | Default value means that for all timers and constants<br>- For parameters with need MD, the defaults specified in 10.3.3.43 apply and<br>- For parameters with need OP, the parameters are absent |

### 10.2.48.8.5 System Information Block type 2

The system information block type 2 contains the URA identity.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| **UTRAN mobility information elements** | | | | |
| URA identity list | MP | 1 ..<maxURA> | | |
| >URA identity | MP | | URA identity 10.3.2.6 | |

### 10.2.48.8.6 System Information Block type 3

The system information block type 3 contains parameters for cell selection and re-selection.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| SIB4 Indicator | MP | | Boolean | TRUE indicates that SIB4 is broadcast in the cell. | |
| **UTRAN mobility information elements** | | | | | |
| Cell identity | MP | | Cell identity 10.3.2.2 | | |
| Cell selection and re-selection info | MP | | Cell selection and re-selection info for SIB3/4 10.3.2.3 | | |
| Cell Access Restriction | MP | | Cell Access Restriction 10.3.2.1 | | |
| Domain Specific Access Restriction Parameters For PLMN Of MIB | OP | | Domain Specific Access Restriction Parameters 10.3.1.3c | This IE specifies the Domain Specific Access Restriction Parameters for UEs which has chosen the PLMN in the IE 'PLMN identity' of the Master Information Block. | REL-6 |
| Domain Specific Access Restriction For Shared Network | OP | | | | REL-6 |
| >CHOICE *barring representation* | MP | | | | REL-6 |
| >>Domain Specific Access Restriction List | | | | | REL-6 |
| >>>Domain Specific Access Restriction Parameters For Operator1 | OP | | Domain Specific Access Restriction Parameters 10.3.1.3c | This IE specifies the Domain Specific Access Restriction Parameters for UEs which has chosen the first PLMN in the IE 'multiplePLMNs' in the IE 'Multiple PLMN List' of the Master Information Block. | REL-6 |
| >>>Domain Specific Access Restriction Parameters For Operator2 | OP | | Domain Specific Access Restriction Parameters 10.3.1.3c | This IE specifies the Domain Specific Access Restriction Parameters for UEs which has chosen the second PLMN in the IE 'multiplePLMNs' in the IE 'Multiple PLMN List' of the Master Information Block. | REL-6 |
| >>>Domain Specific Access Restriction Parameters For Operator3 | OP | | Domain Specific Access Restriction Parameters 10.3.1.3c | This IE specifies the Domain Specific Access Restriction Parameters for UEs which has chosen the third PLMN in the IE 'multiplePLMNs' in the IE 'Multiple PLMN List' of the Master Information Block. | REL-6 |
| >>>Domain Specific Access Restriction Parameters For Operator4 | OP | | Domain Specific Access Restriction Parameters 10.3.1.3c | This IE specifies the Domain Specific Access Restriction Parameters for UEs which has chosen the fourth PLMN in the IE 'multiplePLMNs' in the IE 'Multiple PLMN List' of the Master Information Block. | REL-6 |
| >>>Domain Specific Access Restriction Parameters For Operator5 | OP | | Domain Specific Access Restriction Parameters 10.3.1.3c | This IE specifies the Domain Specific Access Restriction Parameters for UEs which has chosen the fifth PLMN in the IE 'multiplePLMNs' in the IE 'Multiple PLMN List' of the Master Information Block. | REL-6 |
| >>Domain Specific Access Restriction Parameters For All | | | | | REL-6 |
| >>>Domain Specific Access Restriction Parameters | | | Domain Specific | This IE specifies the common Domain Specific Access | REL-6 |

| | | | | | |
|---|---|---|---|---|---|
| | | | Access Restriction Parameters 10.3.1.3c | Restriction Parameters applied to all PLMNs in the IE 'multiplePLMNs' in the IE 'Multiple PLMN List' of the Master Information Block. | |

### 10.2.48.8.7 System Information Block type 4

The system information block type 4 contains parameters for cell selection and re-selection to be used in connected mode.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| **UTRAN mobility information elements** | | | | |
| Cell identity | MP | | Cell identity 10.3.2.2 | |
| Cell selection and re-selection info | MP | | Cell selection and re-selection info for SIB3/4 10.3.2.3 | |
| Cell Access Restriction | MP | | Cell Access Restriction 10.3.2.1 | |

### 10.2.48.8.8 System Information Block type 5 and 5bis

The system information block type 5 contains parameters for the configuration of the common physical channels in the cell. System information block type 5bis uses the same structure as System information block type 5. System information block type 5bis is sent instead of system information block type 5 in networks that use Band IV.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| SIB6 Indicator | MP | | Boolean | TRUE indicates that SIB6 is broadcast in the cell. | |
| **PhyCH information elements** | | | | | |
| PICH Power offset | MP | | PICH Power offset 10.3.6.50 | | |
| CHOICE *mode* | MP | | | | |
| >FDD | | | | | |
| >>AICH Power offset | MP | | AICH Power offset 10.3.6.3 | This AICH Power offset also indicates the power offset for AP-AICH and for CD/CA-ICH. | |
| >TDD | | | | | |
| >>PUSCH system information | OP | | PUSCH system information 10.3.6.66 | | |
| >>PUSCH system information VHCR | OP | | PUSCH system information VHCR 10.3.6.66a | Only for 7.68 Mcps TDD | REL-7 |
| >>PDSCH system | OP | | PDSCH | | |

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| information | | | system information 10.3.6.46 | | |
| >>TDD open loop power control | MP | | TDD open loop power control 10.3.6.79 | | |
| Primary CCPCH info | OP | | Primary CCPCH info 10.3.6.57 | Note 1 | |
| PRACH system information list | MP | | PRACH system information list 10.3.6.55 | | |
| Secondary CCPCH system information | MP | | Secondary CCPCH system information 10.3.6.72 | Note 2 | |
| CBS DRX Level 1 information | CV-*CTCH* | | CBS DRX Level 1 information 10.3.8.3 | | |

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| Frequency band indicator | OP | | Frequency band indicator 10.3.6.35b | | REL-6 |
| Frequency band indicator 2 | OP | | Frequency band indicator 2 10.3.6.35c | | REL-6 |
| HSDPA cell Indicator | MD | | Enumerated (HSDPA Capable Cell) | Default is "HSDPA capability not indicated".<br><br>"HSDPA Capable Cell" means that the UE may consider this cell as part of the HSDPA coverage area for display indication only.<br>This indication shall not be used for any other purpose. | REL-6 |
| E-DCH cell Indicator | MD | | Enumerated (E-DCH Capable Cell) | Default is "E-DCH capability not indicated".<br><br>"E-DCH Capable Cell" means that the UE may consider this cell as part of the E-DCH coverage area for display indication only.<br>This indication shall not be used for any other purpose. | REL-6 |
| Secondary CCPCH system information MBMS | OP | | Secondary CCPCH system information MBMS 10.3.6.72a | Included if MCCH is on an S-CCPCH used only for MBMS. Note 2 | REL-6 |

NOTE 1: DL scrambling code of the Primary CCPCH is the same as the one for Primary CPICH (FDD only).

NOTE 2: There is only one MCCH in a cell, which may either be mapped on to an S-CCPCH also used for non-MBMS purposes or to an S-CCPCH dedicated to MBMS. In the first case the MCCH configuration is specified within the IE "Secondary CCPCH system information", in the latter case the MCCH configuration is provided within the IE "Secondary CCPCH system information MBMS".

| Condition | Explanation |
|---|---|
| *CTCH* | The IE is mandatory present if the IE "CTCH indicator" is equal to TRUE for at least one FACH, otherwise the IE is not needed in the message |

### 10.2.48.8.9 System Information Block type 6

The system information block type 6 contains parameters for the configuration of the common and shared physical channels to be used in connected mode.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| **PhyCH information elements** | | | | | |
| PICH Power offset | MP | | PICH Power offset 10.3.6.50 | | |
| CHOICE *mode* | MP | | | | |
| >FDD | | | | | |
| >>AICH Power offset | MP | | AICH Power offset 10.3.6.3 | This AICH Power offset also indicates the power offset for AP-AICH and for CD/CA-ICH. | |
| >TDD | | | | | |
| >>PUSCH system information | OP | | PUSCH system information 10.3.6.66 | | |
| >>PUSCH system information VHCR | OP | | PUSCH system information VHCR 10.3.6.66a | Only for 7.68 Mcps TDD | REL-7 |
| >>PDSCH system information | OP | | PDSCH system information 10.3.6.46 | | |
| >>TDD open loop power control | MP | | TDD open loop power control 10.3.6.79 | | |
| Primary CCPCH info | OP | | Primary CCPCH info 10.3.6.57 | Note 1 | |
| PRACH system information list | OP | | PRACH system information list 10.3.6.55 | | |
| Secondary CCPCH system information | OP | | Secondary CCPCH system information 10.3.6.72 | | |
| CBS DRX Level 1 information | CV-*CTCH* | | CBS DRX Level 1 information 10.3.8.3 | | |

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| Frequency band indicator | OP | | Frequency band indicator 10.3.6.35b | | REL-6 |
| Frequency band indicator 2 | OP | | Frequency band indicator 2 10.3.6.35c | | REL-6 |

NOTE 1: DL scrambling code of the Primary CCPCH is the same as the one for Primary CPICH (FDD only).

| Condition | Explanation |
|---|---|
| *CTCH* | The IE is mandatory present if the IE "CTCH indicator" is equal to TRUE for at least one FACH, otherwise the IE is not needed |

### 10.2.48.8.10 System Information Block type 7

The system information block type 7 contains the fast changing parameters UL interference and Dynamic persistence level.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| CHOICE *mode* | MP | | | |
| >FDD | | | | |
| >>UL interference | MP | | UL interference 10.3.6.87 | |
| >TDD | | | | (no data) |
| **PhyCH information elements** | | | | |
| PRACHs listed in system information block type 5 | MP | 1 to<maxPRACH> | | The order of the PRACHs is the same as in system information block type 5. |
| >Dynamic persistence level | MP | | Dynamic persistence level 10.3.6.35 | |
| PRACHs listed in system information block type 6 | OP | 1 to <maxPRACH> | | The order of the PRACHs is the same as in system information block type 6. |
| >Dynamic persistence level | MP | | Dynamic persistence level 10.3.6.35 | |
| Expiration Time Factor | MD | | Expiration Time Factor 10.3.3.12 | Default is 1. |

### 10.2.48.8.11 Void

### 10.2.48.8.12 Void

#### 10.2.48.8.13 Void

#### 10.2.48.8.14 System Information Block type 11

The system information block type 11 contains measurement control information to be used in the cell.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| SIB12 Indicator | MP | | Boolean | TRUE indicates that SIB12 is broadcast in the cell. |
| **Measurement information elements** | | | | |
| FACH measurement occasion info | OP | | FACH measurement occasion info 10.3.7.8 | |
| Measurement control system information | MP | | Measurement control system information 10.3.7.47 | |

#### 10.2.48.8.15 System Information Block type 12

The system information block type 12 contains measurement control information to be used in connected mode.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| **Measurement information elements** | | | | |
| FACH measurement occasion info | OP | | FACH measurement occasion info 10.3.7.8 | |
| Measurement control system information | MP | | Measurement control system information 10.3.7.47 | |

#### 10.2.48.8.16 System Information Block type 13

The system information block type 13 contains ANSI-41 system information.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| **Other information elements** | | | | |
| **CN Information Elements** | | | | |
| CN Domain system information list | MP | 1 to <maxCNdomains> | | Send CN information for each CN domain. |
| >CN Domain system information | MP | | CN Domain system information 10.3.1.2 | |
| **UE Information** | | | | |
| UE timers and constants in idle mode | MD | | UE timers and constants in idle mode 10.3.3.44 | The UE behaviour is unspecified if this IE is absent. |
| Capability update requirement | MD | | Capability update requirement 10.3.3.2 | Default value is defined in subclause 10.3.3.2 |

#### 10.2.48.8.16.1 System Information Block type 13.1

The system information block type 13.1 contains the ANSI-41 RAND information.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| **ANSI-41 information elements** | | | | |
| ANSI-41 RAND information | MP | | ANSI-41 RAND information 10.3.9.6 | |

#### 10.2.48.8.16.2 System Information Block type 13.2

The system information block type 13.2 contains the ANSI-41 User Zone Identification information.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| **ANSI-41 information elements** | | | | |
| ANSI-41 User Zone Identification information | MP | | ANSI-41 User Zone Identification information 10.3.9.7 | |

#### 10.2.48.8.16.3 System Information Block type 13.3

The system information block type 13.3 contains the ANSI-41 Private Neighbour List information.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| **ANSI-41 information elements** | | | | |
| ANSI-41 Private Neighbour List information | MP | | ANSI-41 Private Neighbour List information 10.3.9.5 | |

#### 10.2.48.8.16.4 System Information Block type 13.4

The system information block type 13.4 contains the ANSI-41 Global Service Redirection information.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| **ANSI-41 information elements** | | | | |
| ANSI-41 Global Service Redirection information | MP | | ANSI-41 Global Service Redirection information 10.3.9.2 | |

### 10.2.48.8.17 System Information Block type 14

NOTE: Only for 3.84 Mcps TDD and 7.68 Mcps TDD.

The system information block type 14 contains parameters for common and dedicated physical channel uplink outer loop power control information to be used in both idle and connected mode.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| **PhyCH information elements** | | | | |
| Individual Timeslot interference list | MP | 1 to <maxTS> | | |
| >Individual Timeslot interference | MP | | Individual Timeslot interference 10.3.6.38 | |
| Expiration Time Factor | MD | | Expiration Time Factor 10.3.3.12 | Default is 1. |

### 10.2.48.8.18 System Information Block type 15

The system information block type 15 contains information useful for UE-based or UE-assisted positioning methods.

| Information Element/Group name | Need | Multi | Type and Reference | Semantics description |
|---|---|---|---|---|
| GPS Data ciphering info | OP | | UE positioning Ciphering info 10.3.7.86 | If this IE is present then the SIB types 15.1, 15.2 & 15.3 are ciphered in accordance with the Data Assistance Ciphering Algorithm specified in [18] |
| Reference position | MP | | Ellipsoid point with altitude and uncertainty ellipsoid 10.3.8.4c | approximate position where the UE is located |
| GPS reference time | MP | | UE positioning GPS reference time 10.3.7.96 | |
| Satellite information | OP | 1 to <maxSat> | | This IE is present whenever bad (failed/failing) satellites are detected by UTRAN [18]. |
| >BadSatID | MP | | Enumerated( 0..63) | |

#### 10.2.48.8.18.1 System Information Block type 15.1

The system information block type 15.1 contains information useful for UE positioning DGPS Corrections. The DGPS Corrections message contents are based on a Type-1 message of DGPS specified in [13].

| Information Element/Group name | Need | Multi | Type and Reference | Semantics description |
|---|---|---|---|---|
| DGPS corrections | MP | | UE positioning GPS DGPS corrections 10.3.7.91 | |

#### 10.2.48.8.18.2 System Information Block type 15.2

The system information block type 15.2 contains information useful for GPS Navigation Model. These IE fields are based on information extracted from the subframes 1 to 3 of the GPS navigation message [12].

| Information Element/Group name | Need | Multi | Type and Reference | Semantics description |
|---|---|---|---|---|
| Transmission TOW | MP | | Integer (0..604799) | The approximate GPS time-of-week when the message is broadcast.<br>in seconds |
| SatID | MP | | Enumerated( 0..63) | Satellite ID |
| GPS Ephemeris and Clock Correction Parameters | MP | | UE positioning GPS Ephemeris and Clock Correction parameters 10.3.7.91a | |

#### 10.2.48.8.18.3 System Information Block type 15.3

The system information block type 15.3 contains information useful for ionospheric delay, UTC offset, and Almanac. These IEs contain information extracted from the subframes 4 and 5 of the GPS navigation message, [12].

| Information Element/Group name | Need | Multi | Type and Reference | Semantics description |
|---|---|---|---|---|
| Transmission TOW | MP | | Integer (0..604799) | The approximate GPS time-of-week when the message is broadcast. in seconds |
| GPS Almanac and Satellite Health | OP | | UE positioning GPS almanac 10.3.7.89 | |
| GPS ionospheric model | OP | | UE positioning GPS ionospheric model 10.3.7.92 | |
| GPS UTC model | OP | | UE positioning GPS UTC model 10.3.7.97 | |
| SatMask | CV-*Almanac* | | Bit string(1..32) | indicates the satellites that contain the pages being broadcast in this data set |
| LSB TOW | CV-*Almanac* | | Bit string(8) | |

| Condition | Explanation |
|---|---|
| *Almanac* | This IE is mandatory present if the IE "GPS Almanac and Satellite Health" is present |

### 10.2.48.8.18.4 System Information Block type 15.4

The system information block type 15.4 contains ciphering information for System Information Block type 15.5 and information useful for OTDOA UE-assisted Positioning method.

| Information Element/Group name | Need | Multi | Type and Reference | Semantics description |
|---|---|---|---|---|
| OTDOA Data ciphering info | OP | | UE positioning Ciphering info 10.3.7.86 | If this IE is present then the for UE-based the System Information Block type 15.5 is ciphered in accordance with the Data Assistance Ciphering Algorithm specified in [18] |
| OTDOA assistance data for UE-assisted | MP | | UE positioning OTDOA assistance data for UE-assisted 10.3.7.103 | |

### 10.2.48.8.18.4a System Information Block type 15.5

The system information block type 15.5 contains information useful for OTDOA UE-based Positioning method.

| Information Element/Group name | Need | Multi | Type and Reference | Semantics description |
|---|---|---|---|---|
| OTDOA assistance data for UE-based | MP | | UE positioning OTDOA assistance data for UE-based 10.3.7.103a | |

### 10.2.48.8.19 System Information Block type 16

The system information block type 16 contains radio bearer, transport channel and physical channel parameters to be stored by UE in idle and connected mode for use during handover to UTRAN.

| Information Element/Group name | Need | Multi | Type and Reference | Semantics description |
|---|---|---|---|---|
| **RB information elements** | | | | |
| Predefined RB configuration | MP | | Predefined RB configuration 10.3.4.7 | |
| **TrCH Information Elements** | | | | |
| Predefined TrCH configuration | MP | | Predefined TrCH configuration 10.3.5.9 | |
| **PhyCH Information Elements** | | | | |
| Predefined PhyCH configuration | MP | | Predefined PhyCH configuration 10.3.6.56 | |

### 10.2.48.8.20 System Information Block type 17

NOTE: Only for TDD.

The system information block type 17 contains fast changing parameters for the configuration of the shared physical channels to be used in connected mode.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| **PhyCH information elements** | | | | |
| PUSCH system information | OP | | PUSCH system information 10.3.6.66 | |
| PUSCH system information VHCR | OP | | PUSCH system information VHCR 10.3.6.66a | REL-7<br>Only for 7.68 Mcps TDD |
| PDSCH system information | OP | | PDSCH system information 10.3.6.46 | |

#### 10.2.48.8.21 System Information Block type 18

The System Information Block type 18 contains PLMN identities of neighbouring cells to be considered in idle mode as well as in connected mode.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Idle mode PLMN identities | OP | | PLMN identities of neighbour cells 10.3.7.53a | |
| Connected mode PLMN identities | OP | | PLMN identities of neighbour cells 10.3.7.53a | |

## 10.2.49 SYSTEM INFORMATION CHANGE INDICATION

This message is used to send information on FACH to the UEs in state CELL_FACH or CELL_DCH(TDD only) about coming modification of the system information.

RLC-SAP: TM

Logical channel: BCCH

Direction: UTRAN → UE

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Message Type | MP | | Message Type | |
| **Other information elements** | | | | |
| BCCH modification info | MP | | BCCH modification info 10.3.8.1 | |

If the encoded message does not fill a transport block, the RRC layer shall insert padding according to subclause 12.1.

## 10.2.50 TRANSPORT CHANNEL RECONFIGURATION

This message is used by UTRAN to configure the transport channel of a UE. This also includes a possible reconfiguration of physical channels. The message can also be used to assign a TFC subset and reconfigure physical channel.

RLC-SAP: AM or UM

Logical channel: DCCH

Direction: UTRAN → UE

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| Message Type | MP | | Message Type | | |
| **UE Information Elements** | | | | | |
| RRC transaction identifier | MP | | RRC transaction identifier 10.3.3.36 | | |
| Integrity check info | CH | | Integrity check info | | |

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| | | | 10.3.3.16 | | |
| Integrity protection mode info | OP | | Integrity protection mode info 10.3.3.19 | The UTRAN should not include this IE unless it is performing an SRNS relocation | |
| Ciphering mode info | OP | | Ciphering mode info 10.3.3.5 | The UTRAN should not include this IE unless it is performing an SRNS relocation and a change in ciphering algorithm | |
| Activation time | MD | | Activation time 10.3.3.1 | Default value is "now" | |
| Delay restriction flag | OP | Enumerated (TRUE) | | This IE is always set to TRUE and included if the activation time is restricted according to subclause 8.6.3.1 | REL-6 |
| New U-RNTI | OP | | U-RNTI 10.3.3.47 | | |
| New C-RNTI | OP | | C-RNTI 10.3.3.8 | | |
| New DSCH-RNTI | OP | | DSCH-RNTI 10.3.3.9a | Should not be set in FDD. If received the UE should ignore it | |
| New H-RNTI | OP | | H-RNTI 10.3.3.14a | | REL-5 |
| New Primary E-RNTI | OP | | E-RNTI 10.3.3.10a | | REL-6 |
| New Secondary E-RNTI | OP | | E-RNTI 10.3.3.10a | | REL-6 |
| RRC State Indicator | MP | | RRC State Indicator 10.3.3.35a | | |
| UTRAN DRX cycle length coefficient | OP | | UTRAN DRX cycle length coefficient 10.3.3.49 | | |
| **CN Information Elements** | | | | | |
| CN Information info | OP | | CN Information info 10.3.1.3 | | |
| **UTRAN mobility information elements** | | | | | |
| URA identity | OP | | URA identity 10.3.2.6 | | |
| **RB information elements** | | | | | |
| Downlink counter synchronisation info | OP | | | | |
| >RB with PDCP information list | OP | 1 to <maxRBallRABs> | | | |
| >>RB with PDCP information | MP | | RB with PDCP information 10.3.4.22 | This IE is needed for each RB having PDCP in the case of lossless SRNS relocation | |
| | OP | | | | REL-5 |

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| >>PDCP context relocation info | OP | | PDCP context relocation info 10.3.4.1a | This IE is needed for each RB having PDCP and performing PDCP context relocation | REL-5 |
| **TrCH Information Elements** | | | | | |
| **Uplink transport channels** | | | | | |
| UL Transport channel information common for all transport channels | OP | | UL Transport channel information common for all transport channels 10.3.5.24 | | |
| Added or Reconfigured TrCH information list | OP | 1 to <maxTrCH> | | | |
| >Added or Reconfigured UL TrCH information | MP | | Added or Reconfigured UL TrCH information 10.3.5.2 | | |
| **Downlink transport channels** | | | | | |
| DL Transport channel information common for all transport channels | OP | | DL Transport channel information common for all transport channels 10.3.5.6 | | |
| Added or Reconfigured TrCH information list | OP | 1 to <maxTrCH> | | | |
| >Added or Reconfigured DL TrCH information | MP | | Added or Reconfigured DL TrCH information 10.3.5.1 | | |
| **PhyCH information elements** | | | | | |
| Frequency info | OP | | Frequency info 10.3.6.36 | | |
| **Uplink radio resources** | | | | | |
| Maximum allowed UL TX power | MD | | Maximum allowed UL TX power 10.3.6.39 | Default value is the existing maximum UL TX power | |
| Uplink DPCH info | OP | | Uplink DPCH info 10.3.6.88 | | |
| E-DCH Info | OP | | E-DCH Info 10.3.6.97 | | REL-6 |
| **Downlink radio resources** | | | | | |
| Downlink HS-PDSCH Information | OP | | Downlink HS-PDSCH Information 10.3.6.23a | | REL-5 |
| Downlink information common for all radio links | OP | | Downlink information common for all radio links 10.3.6.24 | | |
| Downlink information per radio link list | OP | 1 to <maxRL> | | Send downlink information for each radio link | |

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| >Downlink information for each radio link | MP | | Downlink information for each radio link 10.3.6.27 | | |
| MBMS PL Service Restriction Information | OP | | Enumerated (TRUE) | Absence means that on the MBMS Preferred Layer (PL) no restrictions apply concerning the use of non-MBMS services i.e. the PL is not congested | REL-6 |

## 10.2.51 TRANSPORT CHANNEL RECONFIGURATION COMPLETE

This message is sent from the UE when a transport channel reconfiguration has been done.

RLC-SAP: AM

Logical channel: DCCH

Direction: UE → UTRAN

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| Message Type | MP | | Message Type | | |
| **UE information elements** | | | | | |
| RRC transaction identifier | MP | | RRC transaction identifier 10.3.3.36 | | |
| Integrity check info | CH | | Integrity check info 10.3.3.16 | | |
| Uplink integrity protection activation info | OP | | Integrity protection activation info 10.3.3.17 | | |
| CHOICE *mode* | OP | | | | |
| >FDD | | | | (no data) | |
| >TDD | | | | | |
| >>CHOICE *TDD option* | MP | | | | REL-4 |
| >>>3.84 Mcps TDD | | | | | REL-4 |
| >>>>Uplink Timing Advance | OP | | Uplink Timing Advance 10.3.6.95 | | |
| >>>7.68 Mcps TDD | | | | | REL-7 |
| >>>>Uplink Timing Advance | OP | | | Uplink Timing Advance 10.3.6.95a | REL-7 |
| >>>1.28 Mcps TDD | | | | (no data) | REL-4 |
| **RB Information elements** | | | | | |
| COUNT-C activation time | OP | | Activation time 10.3.3.1 | Used for radio bearers mapped on RLC-TM. Only applicable if the UE is moving to | |

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| | | | | CELL_DCH state due to this procedure | |
| Uplink counter synchronisation info | OP | | | | |
| >RB with PDCP information list | OP | 1 to <maxRBallRABs> | | | |
| >>RB with PDCP information | MP | | RB with PDCP information 10.3.4.22 | | |
| >START list | MP | 1 to <maxCNdomains> | | START [40] values for all CN domains. | |
| >>CN domain identity | MP | | CN domain identity 10.3.1.1 | | |
| >>START | MP | | START 10.3.3.38 | START value to be used in this CN domain. | |

## 10.2.52 TRANSPORT CHANNEL RECONFIGURATION FAILURE

This message is sent by UE if the configuration given by UTRAN is unacceptable or if the UE failed to establish the physical channel(s).

RLC-SAP: AM

Logical channel: DCCH

Direction: UE→UTRAN

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Message Type | MP | | Message Type | |
| **UE information elements** | | | | |
| RRC transaction identifier | MP | | RRC transaction identifier 10.3.3.36 | |
| Integrity check info | CH | | Integrity check info 10.3.3.16 | |
| Failure cause | MP | | Failure cause and error information 10.3.3.14 | |

## 10.2.53 TRANSPORT FORMAT COMBINATION CONTROL

This message is sent by UTRAN to control the uplink transport format combination within the allowed transport format combination set. This message has different structures depending if the message is sent on transparent (TM) or non-transparent mode (AM or UM).

RLC-SAP: AM or UM

Logical channel: DCCH

Direction: UTRAN→UE

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Message Type | MP | | Message Type | |
| **UE information elements** | | | | |
| RRC transaction identifier | MP | | RRC transaction identifier 10.3.3.36 | |
| Integrity check info | CH | | Integrity check info 10.3.3.16 | |
| **TrCH information elements** | | | | |
| CHOICE *mode* | MP | | | |
| >FDD | | | | (no data) |
| >TDD | | | | |
| >>TFCS Id | OP | | Transport Format Combination Set Identity 10.3.5.21 | |
| DPCH/PUSCH TFCS in uplink | MP | | Transport Format Combination subset 10.3.5.22 | |
| Activation time for TFC subset | MD | | Activation time 10.3.3.1 | Default value is "now" |
| TFC Control duration | OP | | TFC Control duration 10.3.6.80 | |

In case of transparent mode signalling the following message structure shall be used:

RLC-SAP: TM

Logical channel: DCCH

Direction: UTRAN→UE

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| TFC subset identity | MP | | INTEGER (0..7) | |

The encoding of this message is specified in subclause 12.4.1.1.

## 10.2.54 TRANSPORT FORMAT COMBINATION CONTROL FAILURE

This message is sent to indicate that a received TRANSPORT FORMAT COMBINATION CONTROL message could not be handled by the UE.

RLC-SAP: AM

Logical channel: DCCH

Direction: UE→UTRAN

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Message Type | MP | | Message Type | |
| **UE information elements** | | | | |
| RRC transaction identifier | MP | | RRC transaction identifier 10.3.3.36 | |
| Integrity check info | CH | | Integrity check info 10.3.3.16 | |
| Failure cause | MP | | Failure cause and error information 10.3.3.14 | |

## 10.2.55 UE CAPABILITY ENQUIRY

The UE CAPABILITY ENQUIRY is used by the UTRAN to enquire inter-RAT classmarks from the UE.

RLC-SAP: AM or UM

Logical channel: DCCH

Direction: UTRAN → UE

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Message Type | MP | | Message Type | |
| **UE information elements** | | | | |
| RRC transaction identifier | MP | | RRC transaction identifier 10.3.3.36 | |
| Integrity check info | CH | | Integrity check info 10.3.3.16 | Integrity check info is included if integrity protection is applied |
| Capability update requirement | MP | | Capability update requirement 10.3.3.2 | |

## 10.2.56 UE CAPABILITY INFORMATION

This message is sent by UE to convey UE specific capability information to the UTRAN.

RLC-SAP: AM

Logical channel: DCCH

Direction: UE → UTRAN

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Message Type | MP | | Message Type | |
| **UE information elements** | | | | |
| RRC transaction identifier | OP | | RRC transaction identifier 10.3.3.36 | |
| Integrity check info | CH | | Integrity check info 10.3.3.16 | Integrity check info is included if integrity protection is applied |
| UE radio access capability | OP | | UE radio access capability 10.3.3.42 | |
| UE radio access capability extension | OP | | UE radio access capability extension 10.3.3.42a | |
| **Other information elements** | | | | |
| UE system specific capability | OP | 1 to <maxInterSysMessages> | | |
| >Inter-RAT UE radio access capability | MP | | Inter-RAT UE radio access capability10.3.8.7 | |

## 10.2.57 UE CAPABILITY INFORMATION CONFIRM

This message is sent by UTRAN to confirm that UE capability information has been received.

RLC-SAP: AM or UM

Logical channel: DCCH

Direction: UTRAN → UE

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Message Type | MP | | Message Type | |
| **UE information elements** | | | | |
| RRC transaction identifier | MP | | RRC transaction identifier 10.3.3.36 | |
| Integrity check info | CH | | Integrity check info 10.3.3.16 | Integrity check info is included if integrity protection is applied |

## 10.2.58 UPLINK DIRECT TRANSFER

This message is used to transfer NAS messages for an existing signalling connection.

RLC-SAP: AM

Logical channel: DCCH

Direction: UE ->UTRAN

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Message Type | MP | | Message Type | |
| **UE information elements** | | | | |
| Integrity check info | CH | | Integrity check info 10.3.3.16 | Integrity check info is included if integrity protection is applied |
| **CN information elements** | | | | |
| CN domain identity | MP | | CN domain identity 10.3.1.1 | |
| NAS message | MP | | NAS message 10.3.1.8 | |
| **Measurement information elements** | | | | |
| Measured results on RACH | OP | | Measured results on RACH 10.3.7.45 | |

## 10.2.59 UPLINK PHYSICAL CHANNEL CONTROL

NOTE: Only for TDD.

This message is used to transfer uplink physical channel parameters to the UE.

RLC-SAP: AM or UM

Logical channel: DCCH

Direction: UTRAN→UE

| Information Element/Group name | Need | Multi | Type and Reference | Semantics description | Version |
|---|---|---|---|---|---|
| Message Type | MP | | Message Type | | |
| **UE information elements** | | | | | |
| RRC transaction identifier | MP | | RRC transaction identifier 10.3.3.36 | | |
| Integrity check info | OP | | Integrity check info 10.3.3.16 | | |
| **PhyCH information elements** | | | | | |
| CCTrCH power control info | OP | | CCTrCH power control info 10.3.6.8 | Power control information for one CCTrCH | |
| Special Burst Scheduling | OP | | Special Burst Scheduling 10.3.6.75a | UL Special Burst generation period in radio frames | |
| CHOICE *TDD option* | MP | | | | REL-4 |
| >3.84 Mcps TDD | | | | | REL-4 |
| >>Alpha | OP | | Alpha 10.3.6.5 | | |
| >>Timing Advance Control | OP | | UL Timing Advance Control 10.3.6.96 | | |
| >>PRACH Constant Value | OP | | Constant value TDD | Operator controlled PRACH | |

| Information Element/Group name | Need | Multi | Type and Reference | Semantics description | Version |
|---|---|---|---|---|---|
| | | | 10.3.6.11a | Margin | |
| >>PUSCH Constant Value | OP | | Constant value TDD 10.3.6.11a | Operator controlled PUSCH Margin | |
| >>UE positioning related parameters | CV-*IPDLs* | | | | REL-4 |
| >>>IPDL-Alpha | MP | | Alpha 10.3.6.5 | | REL-4 |
| >>>Max power increase | MP | | Integer (0..3) | In dB | REL-4 |
| >> HS-SICH power control info | OP | | HS-SICH Power Control Info 10.3.6.36b | Only applies to TDD 3.84 Mcps | REL-5 |
| >7.68 Mcps TDD | | | | | REL-7 |
| >>Alpha | OP | | Alpha 10.3.6.5 | | |
| >>Timing Advance Control | OP | | UL Timing Advance Control 10.3.6.96 | | |
| >>PRACH Constant Value | OP | | Constant value TDD 10.3.6.11a | Operator controlled PRACH Margin | |
| >>PUSCH Constant Value | OP | | Constant value TDD 10.3.6.11a | Operator controlled PUSCH Margin | |
| >>UE positioning related parameters | CV-*IPDLs* | | | | REL-4 |
| >>>IPDL-Alpha | MP | | Alpha 10.3.6.5 | | REL-4 |
| >>>Max power increase | MP | | Integer (0..3) | In dB | REL-4 |
| >> HS-SICH power control info | OP | | HS-SICH Power Control Info 10.3.6.36b | Only applies to TDD 7.68 Mcps | REL-5 |
| >1.28 Mcps TDD | | | | | REL-4 |
| >>Uplink synchronisation parameters | MD | | | Default: Uplink synchronisation step size 1. Uplink synchronisation frequency 1. | REL-4 |
| >>>Uplink synchronisation step size | MP | | Integer(1..8) | This parameter specifies the step size to be used for the adjustment of the uplink transmission timing | REL-4 |
| >>>Uplink synchronisation frequency | MP | | Integer(1..8) | This parameter specifies the frequency of the adjustment of the uplink transmission timing | REL-4 |

| Condition | Explanation |
|---|---|
| *IPDLs* | This IE is present only if idle periods are applied |

## 10.2.60 URA UPDATE

This message is used by the UE to initiate a URA update procedure.

RLC-SAP: TM

Logical channel: CCCH

Direction: UE→UTRAN

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Message Type | MP | | Message Type | |
| **UE information elements** | | | | |
| U-RNTI | MP | | U-RNTI 10.3.3.47 | |
| RRC transaction identifier | CV-*ProtErr* | | RRC transaction identifier 10.3.3.36 | |
| Integrity check info | CH | | Integrity check info 10.3.3.16 | |
| URA update cause | MP | | URA update cause 10.3.3.46 | |
| Protocol error indicator | MD | | Protocol error indicator 10.3.3.27 | Default value is FALSE |
| **Other information elements** | | | | |
| Protocol error information | CV-*ProtErr* | | Protocol error information 10.3.8.12 | |

| Condition | Explanation |
|---|---|
| *ProtErr* | The IE is mandatory present if the IE "Protocol error indicator" has the value "TRUE" and not needed otherwise. |

## 10.2.61 URA UPDATE CONFIRM

This message confirms the URA update procedure and can be used to reallocate new RNTI information for the UE valid after the URA update.

RLC-SAP: UM

Logical channel: CCCH or DCCH

Direction: UTRAN→UE

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| Message Type | MP | | Message Type | | |
| **UE information elements** | | | | | |
| U-RNTI | CV-*CCCH* | | U-RNTI 10.3.3.47 | | |
| RRC transaction identifier | MP | | RRC transaction identifier 10.3.3.36 | | |

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| Integrity check info | CH | | Integrity check info 10.3.3.16 | Integrity check info is included if integrity protection is applied | |
| Integrity protection mode info | OP | | Integrity protection mode info 10.3.3.19 | The UTRAN should not include this IE unless it is performing an SRNS relocation | |
| Ciphering mode info | OP | | Ciphering mode info 10.3.3.5 | The UTRAN should not include this IE unless it is performing an SRNS relocation and a change in ciphering algorithm | |
| New U-RNTI | OP | | U-RNTI 10.3.3.47 | | |
| New C-RNTI | OP | | C-RNTI 10.3.3.8 | | |
| RRC State Indicator | MP | | RRC State Indicator 10.3.3.35a | | |
| UTRAN DRX cycle length coefficient | OP | | UTRAN DRX cycle length coefficient 10.3.3.49 | | |
| **CN Information Elements** | | | | | |
| CN Information info | OP | | CN Information info 10.3.1.3 | | |
| **UTRAN mobility information elements** | | | | | |
| URA identity | OP | | URA identity 10.3.2.6 | | |
| **RB information elements** | | | | | |
| Downlink counter synchronisation info | OP | | | | |
| >RB with PDCP information list | OP | 1 to <maxRBallRABs> | | | |
| >>RB with PDCP information | MP | | RB with PDCP information 10.3.4.22 | This IE is needed for each RB having PDCP in the case of lossless SRNS relocation | |
| | OP | | | | REL-5 |
| >>PDCP context relocation info | OP | | PDCP context relocation info 10.3.4.1a | This IE is needed for each RB having PDCP and performing PDCP context relocation | REL-5 |

| Condition | Explanation |
|---|---|
| *CCCH* | This IE is mandatory present when CCCH is used and not needed otherwise. |

## 10.2.62 UTRAN MOBILITY INFORMATION

This message is used by UTRAN to allocate a new RNTI and to convey other UTRAN mobility related information to a UE.

RLC-SAP: AM or UM

Logical channel: DCCH

Direction: UTRAN→UE

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| Message Type | MP | | Message Type | | |
| **UE Information Elements** | | | | | |
| Integrity check info | CH | | Integrity check info 10.3.3.16 | | |
| RRC transaction identifier | MP | | RRC transaction identifier 10.3.3.36 | | |
| Integrity protection mode info | OP | | Integrity protection mode info 10.3.3.19 | The UTRAN should not include this IE unless it is performing an SRNS relocation | |
| Ciphering mode info | OP | | Ciphering mode info 10.3.3.5 | The UTRAN should not include this IE unless it is performing an SRNS relocation and a change in ciphering algorithm | |
| New U-RNTI | OP | | U-RNTI 10.3.3.47 | | |
| New C-RNTI | OP | | C-RNTI 10.3.3.8 | | |
| UE Timers and constants in connected mode | OP | | UE Timers and constants in connected mode 10.3.3.43 | | |
| **CN Information Elements** | | | | | |
| CN Information info | OP | | CN Information info full 10.3.1.3a | | |
| **UTRAN Information Elements** | | | | | |
| URA identity | OP | | URA identity 10.3.2.6 | | |
| **RB Information elements** | | | | | |
| Downlink counter synchronisation info | OP | | | | |
| >RB with PDCP information list | OP | 1 to <maxRBallRABs> | | | |
| >>RB with PDCP information | MP | | RB with PDCP information 10.3.4.22 | This IE is needed for each RB having PDCP in the case of lossless SRNS relocation | |
| | OP | | | | REL-5 |
| >>PDCP context relocation info | OP | | PDCP context relocation info 10.3.4.1a | This IE is needed for each RB having PDCP and performing PDCP context relocation | REL-5 |

## 10.2.63 UTRAN MOBILITY INFORMATION CONFIRM

This message is used to confirm the new UTRAN mobility information for the UE.

RLC-SAP: AM

Logical channel: DCCH

Direction: UE→UTRAN

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Message Type | MP | | Message Type | |
| **UE information elements** | | | | |
| RRC transaction identifier | MP | | RRC transaction identifier 10.3.3.36 | |
| Integrity check info | CH | | Integrity check info 10.3.3.16 | |
| Uplink integrity protection activation info | OP | | Integrity protection activation info 10.3.3.17 | |
| **RB Information elements** | | | | |
| COUNT-C activation time | OP | | Activation time 10.3.3.1 | Used for radio bearers mapped on RLC-TM. Only applicable if the UE is moving to CELL_DCH state due to this procedure |
| Uplink counter synchronisation info | OP | | | |
| >RB with PDCP information list | OP | 1 to <maxRBallRABs> | | This IE is needed for each RB having PDCP in the case of lossless SRNS relocation |
| >>RB with PDCP information | MP | | RB with PDCP information 10.3.4.22 | |
| >START list | MP | 1 to <maxCNdomains> | | START [40] values for all CN domains. |
| >>CN domain identity | MP | | CN domain identity 10.3.1.1 | |
| >>START | MP | | START 10.3.3.38 | START value to be used in this CN domain. |

## 10.2.64 UTRAN MOBILITY INFORMATION FAILURE

This message is sent to indicate a failure to act on a received UTRAN MOBILITY INFORMATION message.

RLC-SAP: AM

Logical channel: DCCH

Direction: UE→UTRAN

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Message Type | MP | | Message Type | |
| **UE information elements** | | | | |
| RRC transaction identifier | MP | | RRC transaction identifier 10.3.3.36 | |
| Integrity check info | CH | | Integrity check info 10.3.3.16 | |
| Failure cause | MP | | Failure cause and error information 10.3.3.14 | |

# 10.3 Information element functional definitions

## 10.3.1 CN Information elements

### 10.3.1.1 CN domain identity

Identifies the type of core network domain.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| CN domain identity | MP | | Enumerated (CS domain, PS domain) | |

### 10.3.1.2 CN Domain System Information

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| CN domain identity | MP | | CN domain identity 10.3.1.1 | |
| CHOICE *CN Type* | MP | | | |
| >GSM-MAP | | | | |
| >>CN domain specific NAS system information | MP | | NAS system information (GSM-MAP) 10.3.1.9 | |
| >ANSI-41 | | | | |
| >>CN domain specific NAS system information | MP | | ANSI-41 NAS system information, 10.3.9.4 | |
| CN domain specific DRX cycle length coefficient | MP | | CN domain specific DRX cycle length coefficient, 10.3.3.6 | |

### 10.3.1.3 CN Information info

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| PLMN identity | OP | | PLMN identity 10.3.1.11 | | |
| CN common GSM-MAP NAS system information | OP | | NAS system information (GSM-MAP) 10.3.1.9 | | |
| CN domain related information | OP | 1 to <maxCNdomains> | | | |
| >CN domain identity | MP | | CN domain identity 10.3.1.1 | | |
| >CN domain specific GSM-MAP NAS system info | MP | | NAS system information (GSM-MAP) 10.3.1.9 | | |
| Primary PLMN identity | OP | | PLMN identity 10.3.1.11 | | REL-6 |

### 10.3.1.3a CN Information info full

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| PLMN identity | OP | | PLMN identity 10.3.1.11 | | |
| CN common GSM-MAP NAS system information | OP | | NAS system information (GSM-MAP) 10.3.1.9 | | |
| CN domain related information | OP | 1 to <maxCNdomains> | | | |
| >CN domain identity | MP | | CN domain identity 10.3.1.1 | | |
| >CN domain specific GSM-MAP NAS system info | MP | | NAS system information (GSM-MAP) 10.3.1.9 | | |
| >CN domain specific DRX cycle length coefficient | MP | | CN domain specific DRX cycle length coefficient, 10.3.3.6 | | |
| Primary PLMN identity | OP | | PLMN identity 10.3.1.11 | | REL-6 |

### 10.3.1.3b Domain Specific Access Restriction

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| CHOICE *restriction status* | MP | | | | REL-6 |
| >no restriction | | | | (no data) | REL-6 |
| >restriction | | | | | REL-6 |
| >>Domain Specific Access Class Barred List | MD | <MaxAC> | | The first instance of the parameter corresponds to Access Class 0, the second to Access Class 1 and so on up to Access Class 15. UE reads this IE of its access class stored in SIM.<br>The default value is the Access Control Barred List contained in the IE "Cell Access Restriction" of the System Information Block Type 3. | REL-6 |
| >>>Access Class Barred | MP | | Enumerated( barred, not barred) | | REL-6 |

### 10.3.1.3c Domain Specific Access Restriction Parameters

This IE specifies domain specific access class restriction parameters for CS and PS domain.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| CS Domain Specific Access Restriction | MP | | Domain Specific Access Restriction 10.3.1.3b | This IE contains Domain Specific Access Restriction Parameters for CS domain. | REL-6 |
| PS Domain Specific Access Restriction | MP | | Domain Specific Access Restriction 10.3.1.3b | This IE contains Domain Specific Access Restriction Parameters for PS domain. | REL-6 |

### 10.3.1.4 IMEI

This IE contains an International Mobile Equipment Identity. Setting specified in [11].

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| IMEI | MP | 15 | | The first element contains the first IMEI digit, the second element the second IMEI digit and so on. |
| >IMEI digit | MP | | INTEGER(0. .15) | |

### 10.3.1.5 IMSI (GSM-MAP)

This IE contains an International Mobile Subscriber Identity, used towards a GSM-MAP type of PLMN. Setting specified in [11].

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| IMSI | MP | 6 to 21 | | The first element contains the first IMSI digit, the second element the second IMSI digit and so on.<br>Although normally upto 15 digits are used for this IE, a bigger length is used to support future extension. |
| >IMSI digit | MP | | INTEGER(0. .9) | |

### 10.3.1.6 Intra Domain NAS Node Selector

This IE carries information to be used to route the establishment of a signalling connection to a CN node within a CN domain.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| CHOICE *version* | MP | | | |
| >R99 | | | | This choice shall also be used by mobiles that are compliant to this version of the protocol |
| >>CHOICE *CN type* | MP | | | |
| >>>GSM-MAP | | | | |
| >>>>CHOICE *Routing basis* | MP | | | |
| >>>>>local (P)TMSI | | | | TMSI allocated in the current LA or PTMSI allocated in the current RA |
| >>>>>>Routing parameter | MP | | Bit string (10) | The TMSI/ PTMSI consists of 4 octets (32bits). This can be represented by a string of bits numbered from b0 to b31, with bit b0 being the least significant<br>The "Routing parameter" bit string consists of bits b14 through b23 of the TMSI/ PTMSI. The first/leftmost/most significant bit of the bit string contains bit b23 of the TMSI/PTMSI. |
| >>>>>(P)TMSI of same PLMN, different (RA)LA | | | | TMSI allocated in another LA of this PLMN or PTMSI allocated in another RA this PLMN |
| >>>>>>Routing parameter | MP | | Bit string (10) | The TMSI/ PTMSI consists of 4 octets (32bits). This can be represented by a string of bits numbered from b0 to b31, with bit b0 being the least significant<br>The "Routing parameter" bit string consists of bits b14 through b23 of the TMSI/ PTMSI. The first/leftmost/most significant bit of the bit string contains bit b23 of the TMSI/ PTMSI. |
| >>>>>(P)TMSI of different PLMN | | | | TMSI or a PTMSI allocated in another PLMN |

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| >>>>>>Routing parameter | MP | | Bit string (10) | The TMSI/ PTMSI consists of 4 octets (32bits). This can be represented by a string of bits numbered from b0 to b31, with bit b0 being the least significant.<br>The "Routing parameter" bit string consists of bits b14 through b23 of the TMSI/ PTMSI. The first/leftmost/most significant bit of the bit string contains bit b23 of the TMSI/ PTMSI. |
| >>>>>IMSI(response to IMSI paging) | | | | NAS identity is IMSI |
| >>>>>>Routing parameter | MP | | Bit string (10) | The "Routing parameter" bit string consists of DecimalToBinary [(IMSI div 10) mod 1000]. The first/leftmost bit of the bit string contains the most significant bit of the result. |
| >>>>>IMSI(cause UE initiated event) | | | | NAS identity is IMSI |
| >>>>>>Routing parameter | MP | | Bit string (10) | The "Routing parameter" bit string consists of DecimalToBinary [(IMSI div 10) mod 1000]. The first/leftmost bit of the bit string contains the most significant bit of the result. |
| >>>>>IMEI | | | | NAS parameter is IMEI |
| >>>>>>Routing parameter | MP | | Bit string (10) | The "Routing parameter" bit string consists of DecimalToBinary [(IMEI div 10) mod 1000]. The first/leftmost bit of the bit string contains the most significant bit of the result. |
| >>>>>Spare 1 | | | Bit string (10) | This choice shall not be used in this version |
| >>>>>Spare 2 | | | Bit string (10) | This choice shall not be used in this version |
| >>>ANSI-41 | | | Bit string (14) | All bits shall be set to 0 |
| >Later | | | Bit string(15) | This bit string shall not be sent by mobiles that are compliant to this version of the protocol. |

### 10.3.1.7 Location Area Identification

Identifies uniquely a location area for a GSM-MAP type of PLMN. Setting specified in [5].

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| PLMN identity | MP | | PLMN identity 10.3.1.11 | |
| LAC | MP | | Bit string(16) | The first/leftmost bit of the bit string contains the most significant bit of the LAC.. |

### 10.3.1.7a Multiple PLMN List

This information element identifies the multiple Public Land Mobile Networks (for a GSM-MAP type of PLMN) of a cell in a shared network.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| MIB PLMN Identity | MP | | Boolean | The PLMN identity IE 10.3.1.11, broadcasted in the MIB, shall be included in the multiple PLMN list if and only if this IE is TRUE. | REL-6 |
| Multiple PLMNs | MP | 1 to 5 | | | REL-6 |
| >PLMN identity with Optional MCC | | | PLMN identity with Optional MCC 10.3.1.11a | | REL-6 |

### 10.3.1.8 NAS message

A non-access stratum message to be transferred transparently through UTRAN.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| NAS message | MP | | Octet string (1..4095) | The first octet contains octet 1 [17] of the NAS message, the second octet contains octet 2 of the NAS message and so on. |

### 10.3.1.9 NAS system information (GSM-MAP)

This information element contains system information that belongs to the non-access stratum for a GSM-MAP type of PLMN. This information is transparent to RRC. It may contain either information specific to one CN domain (CS or PS) or information common for both CN domains.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| GSM-MAP NAS system information | MP | | Octet string(1..8 ) | The first octet contains octet 1 [5] of the NAS system information element, the second octet contains octet 2 of the NAS system information element and so on. |

### 10.3.1.10 Paging record type identifier

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Paging record type identifier | MP | | Enumerated (IMSI (GSM-MAP), TMSI (GSM-MAP)/ P-TMSI, IMSI (DS-41), TMSI (DS-41)) | |

### 10.3.1.11 PLMN identity

This information element identifies a Public Land Mobile Network for a GSM-MAP type of PLMN. Setting of digits is defined in [11].

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| MCC | MP | 3 | | The first element contains the first MCC digit, the second element the second MCC digit and so on. |
| >MCC digit | MP | | INTEGER(0..9) | |
| MNC | MP | 2 to 3 | | The first element contains the first MNC digit, the second element the second MNC digit and so on. |
| >MNC digit | MP | | INTEGER(0..9) | |

### 10.3.1.11a PLMN identity with Optional MCC

This information element is a PLMN identity in subclause 10.3.1.11 where MCC is optional. It is used in a shared network and inserted in the Multiple PLMN List in subclause 10.3.1.7a.

| Information Element/ Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| MCC | MD | 3 | | The first element contains the first MCC digit, the second element the second MCC digit and so on. | REL-6 |
| >MCC digit | MP | | Integer (0..9) | | REL-6 |
| MNC | MP | 2 to 3 | | The first element contains the first MNC digit, the second element the second MNC digit and so on. | REL-6 |
| >MNC digit | MP | | Integer (0..9) | | REL-6 |

### 10.3.1.12 PLMN Type

Identifies the type of Public Land Mobile Network (PLMN). This IE shall be used to control the interpretation of network dependent messages and information elements in the RRC protocol.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| PLMN Type | MP | | Enumerated (GSM-MAP, ANSI-41, GSM-MAP and ANSI-41) | One spare value is needed. |

### 10.3.1.13 P-TMSI (GSM-MAP)

This IE contains a Packet Temporary Mobile Subscriber Identity, used towards a GSM-MAP type of PLMN.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| P-TMSI | MP | | Bit string (32) | Setting specified in [11]. The first/leftmost bit of the bit string contains the most significant bit of the P-TMSI. |

### 10.3.1.14 RAB identity

This information element uniquely identifies a radio access bearer within a CN domain.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| CHOICE *RAB identity type* | MP | | | |
| >RAB identity (GSM-MAP) | | | Bit string (8) | Formatted according to [5]. The first/leftmost bit of the bit string contains the most significant bit of the RAB identity. |
| >RAB identity (ANSI-41) | | | Bit string (8) | The first/leftmost bit of the bit string contains the most significant bit of the RAB identity. |

| CHOICE *NAS binding info type* | Condition under which the given *RAB identity type* is chosen |
|---|---|
| RAB identity (GSM-MAP) | PLMN is of type GSM-MAP |
| RAB identity (ANSI-41) | PLMN is of type ANSI-41 |

### 10.3.1.15 Routing Area Code

Identifies a routing area within a location area for a GSM-MAP type of PLMN.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Routing Area Code | MP | | Bit string(8) | Setting specified in [11]. The first/leftmost bit of the bit string contains the most significant bit of the Routing Area Code. |

### 10.3.1.16 Routing Area Identification

Identifies uniquely a routing area for a GSM-MAP type of PLMN. Setting specified in [11].

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| LAI | MP | | Location area identification 10.3.1.7 | |
| RAC | MP | | Routing area code 10.3.1.15 | |

#### 10.3.1.17 TMSI (GSM-MAP)

This IE contains a Temporary Mobile Subscriber Identity, used towards a GSM-MAP type of PLMN.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| TMSI (GSM-MAP) | MP | | Bit string (32) | Setting specified in [11]. The first/leftmost bit of the bit string contains the most significant bit of the TMSI. |

### 10.3.2 UTRAN mobility Information elements

#### 10.3.2.1 Cell Access Restriction

Indicates the restrictions to cell access.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Cell Barred | MP | | Enumerated( not barred, barred) | |
| Intra-frequency cell re-selection indicator | CV-*Barred* | | Enumerated( not allowed, allowed) | |
| $T_{barred}$ | CV-*Barred* | | Integer (10,20,40,80 ,160,320,640 ,1280) | [4] [s] |
| Cell Reserved for operator use | MP | | Enumerated( reserved, not reserved) | |
| Cell Reservation Extension | MP | | Enumerated( reserved, not reserved) | |
| Access Class Barred list | CV-*SIB3-MD* | maxAC | | Default is no access class barred is applied. The first instance of the parameter corresponds to Access Class 0, the second to Access Class 1 and so on up to Access Class 15. UE reads this IE of its access class stored in SIM. |
| >Access Class Barred | MP | | Enumerated( not barred, barred) | |

| Condition | Explanation |
|---|---|
| *Barred* | The IE is mandatory present if the IE "Cell Barred" has the value "Barred"; otherwise the element is not needed in the message. |
| *SIB3-MD* | The IE is mandatory and has a default value if the IE "Cell Access Restriction" is included in SIB 3. Otherwise the IE is not needed. |

#### 10.3.2.2 Cell identity

This information element identifies a cell unambiguously within a PLMN.

NOTE: This information element may carry any implementation dependent identity that unambiguously identifies a cell within a PLMN.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Cell identity | MP | | bit string(28) | |

### 10.3.2.3 Cell selection and re-selection info for SIB3/4

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| Mapping Info | OP | | Mapping info 10.3.2.5 | This IE should not be sent. | |
| Cell selection and reselection quality measure | MP | | Enumerated (CPICH Ec/N0, CPICH RSCP) | Choice of measurement (CPICH Ec/N0 or CPICH RSCP) to use as quality measure Q for FDD cells.<br>This IE is also sent to the UE in SIB11/12. Both occurrences of the IE should be set to the same value. | |
| CHOICE *mode* | MP | | | | |
| >FDD | | | | | |
| >>$S_{intrasearch}$ | OP | | Integer (-32..20 by step of 2) | If a negative value is received the UE shall consider the value to be 0.<br>[4]<br>[dB] | |
| >>$S_{intersearch}$ | OP | | Integer (-32..20 by step of 2) | If a negative value is received the UE shall consider the value to be 0.<br>[4]<br>[dB] | |
| >>$S_{searchHCS}$ | OP | | Integer (-105..91 by step of 2) | If a negative value is received the UE shall consider the value to be 0.<br>[4]<br>[dB] | |
| >>RAT List | OP | 1 to <maxOtherRAT> | | | |
| >>>RAT identifier | MP | | Enumerated (GSM, cdma2000) | | |
| >>>$S_{search,RAT}$ | MP | | Integer (-32..20 by step of 2) | In case the value 20 is received the UE shall consider this IE as if it was absent according to [4]<br>If a negative value is received the UE shall consider the value to be 0.<br>[dB] | |
| >>>$S_{HCS,RAT}$ | OP | | Integer (-105..91 by step of 2) | If a negative value is received the UE shall consider the value to be 0.<br>[4]<br>[dB] | |
| >>>$S_{limit,SearchRAT}$ | MP | | Integer (- | If a negative value is | |

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| | | | 32..20 by step of 2) | received the UE shall consider the value to be 0.<br>[4]<br>[dB] | |
| >>Qqualmin | MP | | Integer (-24..0) | Ec/N0, [dB] | |
| >>Qrxlevmin | MP | | Integer (-115..-25 by step of 2) | RSCP, [dBm] | |
| >> $Delta_{Qrxlevmin}$ | CV-*Delta* | | Integer(-4..-2 by step of 2) | If present, the actual value of Qrxlevmin = Qrxlevmin + $Delta_{Qrxlevmin}$ | REL-5 |
| >TDD | | | | | |
| >>$S_{intrasearch}$ | OP | | Integer (-105..91 by step of 2) | If a negative value is received the UE shall consider the value to be 0.<br>[4]<br>[dB] | |
| >>$S_{intersearch}$ | OP | | Integer (-105..91 by step of 2) | If a negative value is received the UE shall consider the value to be 0.<br>[4]<br>[dB] | |
| >>$S_{searchHCS}$ | OP | | Integer (-105..91 by step of 2) | If a negative value is received the UE shall consider the value to be 0.<br>[4]<br>[dB] | |
| >>RAT List | OP | 1 to <maxOtherRAT> | | | |
| >>>RAT identifier | MP | | Enumerated (GSM, cdma2000) | | |
| >>>$S_{search,RAT}$ | MP | | Integer (-105..91 by step of 2) | In case the value 91 is received the UE shall consider this IE as if it was absent according to [4]<br>If a negative value is received the UE shall consider the value to be 0.<br>[dB] | |
| >>>$S_{HCS,RAT}$ | OP | | Integer (-105..91 by step of 2) | If a negative value is received the UE shall consider the value to be 0.<br>[4]<br>[dB] | |
| >>>$S_{limit,SearchRAT}$ | MP | | Integer (-105..91 by step of 2) | If a negative value is received the UE shall consider the value to be 0.<br>[4]<br>[dB] | |
| >>Qrxlevmin | MP | | Integer (-115..-25 | RSCP, [dBm] | |

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| | | | by step of 2) | | |
| >>$Delta_{Qrxlevmin}$ | CV-*Delta* | | Integer(-4..-2 by step of 2) | If present, the actual value of Qrxlevmin = Qrxlevmin + $Delta_{Qrxlevmin}$ | REL-5 |
| $Qhyst1_s$ | MP | | Integer (0..40 by step of 2) | [4] [dB] | |
| $Qhyst1_{s,PCH}$ | CV-*SIB4* | | Integer (0..40) | If present, it is used as $Qhyst1_s$ for UE in CELL_PCH or URA_PCH state [4] [dB] | REL-5 |
| $Qhyst1_{s,FACH}$ | CV-*SIB4* | | Integer (0..40) | If present, it is used as $Qhyst1_s$ for UE in CELL_FACH state [4] [dB] | REL-5 |
| $Qhyst2_s$ | CV-*FDD-Quality-Measure* | | Integer (0..40 by step of 2) | Default value is $Qhyst1_s$ [4] [dB] | |
| $Qhyst2_{s,PCH}$ | CV-SIB4-FDD-Quality-Measure | | Integer (0..40) | If present, it is used as $Qhyst2_s$ for UE using CPICH Ec/No quality measure in CELL_PCH or URA_PCH state. Default value is $Qhyst1_{s,PCH}$ [4] [dB] | REL-5 |
| $Qhyst2_{s,FACH}$ | CV-SIB4-FDD-Quality-Measure | | Integer (0..40) | If present, it is used as $Qhyst2_s$ for UE using CPICH Ec/No quality measure in CELL_FACH state. Default value is $Qhyst1_{s,FACH}$ [4] [dB] | REL-5 |
| $Treselection_s$ | MP | | Integer (0..31) | [s] | |
| $Treselection_{s,PCH}$ | CV-*SIB4* | | Integer (0..31) | If present, it is used as $Treselection_s$ for UE in CELL_PCH or URA_PCH state [4] [s] | REL-5 |
| $Treselection_{s,FACH}$ | CV-*SIB4* | | Real (0..6.2 by step of 0.2) | If present, it is used as $Treselection_s$ for UE in CELL_FACH state [4] [s] | REL-5 |
| Speed dependent ScalingFactor for Treselection | OP | | Real (0..1 by step of 0.1) | This IE is used by the UE in high mobility state as scaling factor for $Treselection_s$ or $Treselection_{s,PCH}$ or $Treselection_{s,FACH}$ [4]. | REL-5 |
| Inter-frequency ScalingFactor for | OP | | Real (1..4.75 | If present, it is used by the UE as scaling factor | REL-5 |

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| Treselection | | | by step of 0.25) | for $Treselection_s$ or $Treselection_{s,PCH}$ or $Treselection_{s,FACH}$ for inter-frequency cell reselection evaluation [4]. | |
| Inter-RAT ScalingFactor for Treselection | OP | | Real (1..4.75 by step of 0.25) | If present, it is used by the UE as scaling factor for $Treselection_s$ or $Treselection_{s,PCH}$ or $Treselection_{s,FACH}$ for inter-RAT cell reselection evaluation [4]. | REL-5 |
| Non-HCS_$T_{CRmax}$ | MD | | Enumerated (not used, 30, 60, 120, 180, 240) | [s]<br>Default value is "not used". | REL-5 |
| Non-HCS_$N_{CR}$ | CV-*UE speed detector_MD* | | Integer (1..16) | Default value = 8 | REL-5 |
| Non-HCS_$T_{CRmaxHyst}$ | CV-*UE speed detector_MP* | | Enumerated (not used, 10, 20, 30, 40, 50, 60, 70) | [s] | REL-5 |
| HCS Serving cell Information | OP | | HCS Serving cell information 10.3.7.12 | | |
| Maximum allowed UL TX power | MP | | Maximum allowed UL TX power 10.3.6.39 | [dBm]<br>UE_TXPWR_MAX_RACH in [4]. | |

| Condition | Explanation |
|---|---|
| *FDD-Quality-Measure* | The IE is not needed if the IE "Cell selection and reselection quality measure" has the value CPICH RSCP, otherwise the IE is mandatory and has a default value. |
| *Delta* | This IE is optional if the value of Qrxlevmin is below –115dBm. It is not needed otherwise. |
| *SIB4* | This IE is optional if the IE 'Cell selection and re-selection info for SIB3/4' is included in SIB type 4. It is not needed otherwise. |
| *SIB4-FDD-Quality-Measure* | This IE is optional if the IE 'Cell selection and re-selection info for SIB3/4' is included in SIB type 4, and the IE "Cell selection and reselection quality measure" has the value CPICH Ec/N0. It is not needed otherwise. |
| *UE Speed detector_MD (non-HCS)* | This IE is not needed if non-HCS_$T_{CRmax}$ equals 'not used', else it is mandatory default. |
| *UE Speed detector_MP (non-HCS)* | This IE is not needed if non-HCS_$T_{CRmax}$ equals 'not used', else it is mandatory present. |

### 10.3.2.4 Cell selection and re-selection info for SIB11/12

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| Qoffset1$_{s,n}$ | MD | | Integer(-50..50) | Default value is 0. [dB] | |
| Qoffset2$_{s,n}$ | CV-*FDD-Quality-Measure* | | Integer(-50..50) | Default value is 0. [dB] | |
| Maximum allowed UL TX power | MD | | Maximum allowed UL TX power 10.3.6.39 | According to UE_TXPWR_MAX_RACH in [4], [dBm]. If applied to FDD or TDD cells, the default is the Maximum allowed UL TX power for the serving cell. If applied to a GSM cell, the default is the UE maximum output power applicable for this GSM cell, according to the UE's radio access capability. | |
| HCS neighbouring cell information | OP | | HCS Neighbouring cell information 10.3.7.11 | | |
| CHOICE *mode* | MP | | | | |
| >FDD | | | | | |
| >>Qqualmin | CV-*FDD-Serving-Cell* | | Integer (-24..0) | Ec/N0, [dB] Default value is Qqualmin for the serving cell | |
| >>Qrxlevmin | MD | | Integer (-115..-25 by step of 2) | RSCP, [dBm] Default value is Qrxlevmin for the serving cell | |

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| >>$Delta_{Qrxlevmin}$ | CV-*Delta* | | Integer(-4..-2 by step of 2) | If present, the actual value of Qrxlevmin = Qrxlevmin + $Delta_{Qrxlevmin}$ | REL-5 |
| >TDD | | | | | |
| >>Qrxlevmin | MD | | Integer (-115..-25 by step of 2) | RSCP, [dBm] Default value is Qrxlevmin for the serving cell | |
| >> $Delta_{Qrxlevmin}$ | CV-*Delta* | | Integer(-4..-2 by step of 2) | If present, the actual value of Qrxlevmin = Qrxlevmin + $Delta_{Qrxlevmin}$ | REL-5 |
| >GSM | | | | | |
| >>Qrxlevmin | MD | | Integer (-115..-25 by step of 2) | GSM RSSI, [dBm] Default value is Qrxlevmin for the serving cell | |

| Condition | Explanation |
|---|---|
| *FDD-Quality-Measure* | This IE is mandatory and has a default value for Intra/Inter Frequency Cells if the IE "Cell selection and reselection quality measure" has the value CPICH Ec/No. Otherwise the IE is absent. |
| *FDD-Serving-Cell* | This IE is mandatory and has a default value if the serving cell is an FDD cell. Otherwise the IE is mandatory present. |
| *Delta* | This IE is optional if Qrxlevmin is present and the value of Qrxlevmin is below –115dBm. It is not needed otherwise. |

### 10.3.2.5 Mapping Info

| Information Element/Group name | Need | Multi | Type and Reference | Semantics description | Version |
|---|---|---|---|---|---|
| Mapping List | MP | 1 to <MaxRAT> | | | |
| >RAT | MP | | Enumerated (UTRA FDD, UTRA TDD 3.84 Mcps, UTRA TDD 1.28 Mcps, GSM, cdma2000) | | UTRA TDD 1.28 Mcps is included for REL-4. |
| >Mapping Function Parameter List | MP | 1 to <maxMeas Intervals> | | | |
| >>Function type | MP | | Enumerated (linear, function type 2, function type 3, function type 4) | Type of the function within the interval. | |
| >>Map_parameter_1 | MD | | Integer (0..99) | Parameter describing the mapping function between the quality measurement and the representing quality value, see | |

| Information Element/Group name | Need | Multi | Type and Reference | Semantics description | Version |
|---|---|---|---|---|---|
| | | | | [4].<br>Default value is zero for the first interval or otherwise the value of Map_parameter_2 of the interval before. | |
| >>Map_parameter_2 | MP | | Integer (0..99) | Parameter describing the mapping function between the quality measurement and the representing quality value, see [4]. | |
| >>Upper_limit | CV-*MaxInt* | | Integer (1..MaxMeas ) | Upper limit of interval for which the Map_parameter_1 and Map_parameter_2 are valid.<br>MaxMeas = 25 if RAT = UTRA FDD / CPICH Ec/N0,<br>MaxMeas = 91 if RAT = UTRA TDD 3.84 Mcps or if RAT = UTRA TDD 1.28 Mcps or if RAT = UTRA FDD/ CPICH RSCP,<br>MaxMeas = 63 if RAT = GSM. | UTRA TDD 1.28 Mcps is included for REL-4. |

| Condition | Explanation |
|---|---|
| *MaxInt* | This IE is mandatory present if Mapping Function Parameter List has not reached maxMeasIntervals and is not needed otherwise. |

### 10.3.2.6 URA identity

Gives the identity of the UTRAN Registration Area. It can be used to indicate to the UE which URA it shall use in case of overlapping URAs.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| URA identity | MP | | bit string(16) | |

## 10.3.3 UE Information elements

### 10.3.3.1 Activation time

Activation Time defines the frame number/time at which the operation/changes caused by the related message shall take effect. Values between 0 and 255 indicate the absolute value of CFN (Connection Frame Number) of that frame number/time.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Activation time | MP | | Integer(0.. 255) | CFN [10] |

### 10.3.3.2 Capability Update Requirement

This IE indicates to the UE which specific capabilities to transfer to the network.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| UE radio access FDD capability update requirement | MP | | Boolean | TRUE indicates update required | |
| UE radio access 3.84 Mcps TDD capability update requirement | MP | | Boolean | TRUE indicates update required | Name changed in REL-4 |
| UE radio access 7.68 Mcps TDD capability update requirement | MP | | Boolean | TRUE indicates update required | REL-7 |
| UE radio access 1.28 Mcps TDD capability update requirement | MP | | Boolean | TRUE indicates update required | REL-4 |
| System specific capability update requirement list | OP | 1 to <maxSystemCapability> | | In this version, a maximum size of 4 of the list shall be applied and any items after the 4th item in the list shall be ignored. | |
| >System specific capability update requirement | MP | | Enumerated (GSM | | |
| | | | , GERAN Iu) | | REL-5 |

Default value is:

"UE radio capability FDD update requirement" = false

"UE radio capability 3.84 Mcps TDD update requirement" = false

"UE radio capability 7.68 Mcps TDD update requirement" = false

"UE radio capability 1.28 Mcps TDD update requirement" = false

"System specific capability update requirement" not present.

### 10.3.3.3 Cell update cause

Indicates the cause for cell update.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Cell update cause | MP | | Enumerated (cell reselection, periodical cell update, uplink data transmission, paging response, re-entered service area, radio link failure, RLC unrecoverable error, MBMS reception, MBMS ptp RB request) | Two spare values are needed. |

### 10.3.3.4 Ciphering Algorithm

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Ciphering algorithm | MP | | Enumerated (UEA0, UEA1) | |

### 10.3.3.5 Ciphering mode info

This information element contains the ciphering specific security mode control information.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Ciphering mode command | MP | | Enumerated (start/restart) | |
| Ciphering algorithm | MP | | Ciphering algorithm 10.3.3.4 | |
| Ciphering activation time for DPCH | OP | | Activation time 10.3.3.1 | Used for radio bearers mapped on RLC-TM. Only applicable if the UE is already in CELL_DCH state |
| Radio bearer downlink ciphering activation time info | OP | | RB activation time info, 10.3.4.13 | Used for radio bearers mapped on RLC-AM or RLC-UM<br>The UTRAN should not include this IE in a message other than a SECURITY MODE COMMAND |

### 10.3.3.6 CN domain specific DRX cycle length coefficient

A coefficient in the formula to count the paging occasions to be used by a specific UE (specified in [4]) .

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| CN domain specific DRX cycle length coefficient | MP | | Integer(6...9) | Refers to 'k' in the formula as specified in [4], Discontinuous reception |

### 10.3.3.7 Void

### 10.3.3.8 C-RNTI

The cell RNTI (C-RNTI) identifies a UE having a RRC connection within a cell.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| C-RNTI | MP | | bit string(16) | |

### 10.3.3.9 Void

### 10.3.3.9a DSCH-RNTI

In TDD, the DSCH-RNTI identifies a UE in CELL_DCH or CELL_FACH using a DSCH or USCH within the cell.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| DSCH-RNTI | MP | | bit string(16) | |

### 10.3.3.10 Void

### 10.3.3.10a E-RNTI

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| E-RNTI | MP | | bit string(16) | | REL-6 |

### 10.3.3.11 Establishment cause

Cause for an RRC connection establishment request.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Establishment cause | MP | | Enumerated( Originating Conversational Call, Originating Streaming Call, Originating Interactive Call, Originating Background Call, Originating Subscribed traffic Call, Terminating Conversational Call, Terminating Streaming Call, Terminating Interactive Call, Terminating Background Call, Emergency Call, Inter-RAT cell re-selection, Inter-RAT cell change order, Registration, Detach, Originating High Priority Signalling, Originating Low Priority Signalling, Call re-establishment, Terminating High Priority Signalling, Terminating Low Priority Signalling, Terminating – cause unknown, MBMS reception, MBMS ptp RB request) | Eleven spare values are needed. |

### 10.3.3.12 Expiration Time Factor

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Expiration Time Factor | MP | | Enumerated( 2times, 4times, 8times, 16times, 32times, 64times, 128times, 256times) | |

### 10.3.3.13 Failure cause

Cause for failure to perform the requested procedure.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Failure cause | MP | | Enumerated (configuration unsupported, physical channel failure, incompatible simultaneous reconfiguration, protocol error, compressed mode runtime error, cell update occurred, invalid configuration, configuration incomplete, unsupported measurement, MBMS session already received correctly, lower priority MBMS service) | Five spare values are needed. |

### 10.3.3.14 Failure cause and error information

Cause for failure to perform the requested procedure.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Failure cause | MP | | Failure cause 10.3.3.13 | |

| | | | | |
|---|---|---|---|---|
| Protocol error information | CV-*ProtErr* | | Protocol error information 10.3.8.12 | |
| Deleted TGPSI | CV-*CompModeErr* | | TGPSI 10.3.6.82 | |

| Condition | Explanation |
|---|---|
| *ProtErr* | The IE is mandatory present if the IE "Failure cause" has the value "Protocol error"; otherwise it is not needed in the message. |
| *CompModeErr* | The IE is mandatory present if the IE "Failure cause" has the value " Compressed mode runtime error"; otherwise it is not needed in the message |

### 10.3.3.14o Group release information

Contains addressing information to perform a release of a group of RRC connections.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| U-RNTI group | MP | | U-RNTI group 10.3.3.47a | | REL-5 |

### 10.3.3.14a H-RNTI

The H-RNTI identifies an UE having a HS-PDSCH assignment within a cell.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| H-RNTI | MP | | bit string(16) | | REL-5 |

### 10.3.3.15 Initial UE identity

This information element identifies the UE at a request of an RRC connection.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| CHOICE *UE id type* | MP | | | |
| >IMSI (GSM-MAP) | | | IMSI (GSM-MAP) 10.3.1.5 | |
| >TMSI and LAI (GSM-MAP) | | | | |
| >>TMSI (GSM-MAP) | MP | | TMSI (GSM-MAP) 10.3.1.17 | |
| >>LAI (GSM-MAP) | MP | | Location Area Identification 10.3.1.7 | |
| >P-TMSI and RAI (GSM-MAP) | | | | |
| >>P-TMSI (GSM-MAP) | MP | | P-TMSI (GSM-MAP) 10.3.1.13 | |
| >>RAI (GSM-MAP) | MP | | Routing Area Identification 10.3.1.16 | |
| >IMEI | | | IMEI 10.3.1.4 | |

| | | | | |
|---|---|---|---|---|
| >ESN (DS-41) | | | Bit string (SIZE (32)) | TIA/EIA/IS-2000-4 |
| >IMSI (DS-41) | | | Octet string (SIZE (5..7)) | TIA/EIA/IS-2000-4 |
| >IMSI and ESN (DS-41) | | | | TIA/EIA/IS-2000-4 |
| >>IMSI (DS-41) | MP | | Octet string (SIZE (5..7)) | TIA/EIA/IS-2000-4 |
| >>ESN (DS-41) | MP | | Bit string (SIZE (32)) | TIA/EIA/IS-2000-4 |
| >TMSI (DS-41) | | | Octet string (SIZE (2..17)) | TIA/EIA/IS-2000-4<br>Although normally upto 12 digits are used for this IE, a bigger length is used to support future extension. |

### 10.3.3.16 Integrity check info

The Integrity check info contains the RRC message sequence number needed in the calculation of XMAC-I [40] and the calculated MAC-I.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Message authentication code | MP | | bit string(32) | MAC-I [40]. The first/leftmost bit of the bit string contains the most significant bit of the MAC-I. The 27 MSB of the IE shall be set to zero and the 5 LSB of the IE shall be set to the value of the IE "RB identity" for the used signalling radio bearer when the encoded RRC message is used as the MESSAGE parameter in the integrity protection algorithm. |
| RRC Message sequence number | MP | | Integer (0..15) | The local RRC hyper frame number (RRC HFN) is concatenated with the RRC message sequence number to form the input parameter COUNT-I for the integrity protection algorithm.<br>The IE value shall be set to zero when the encoded RRC message is used as the MESSAGE parameter in the integrity protection algorithm. |

### 10.3.3.17 Integrity protection activation info

This IE contains the time, in terms of RRC sequence numbers, when a new integrity protection configuration shall be activated for the signalling radio bearers.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| RRC message sequence number list | MP | 4 to 5 | | The RRC sequence number when a new integrity protection configuration shall be applied, for signalling radio bearers in the order RB0, RB1, RB2, RB3, RB4.<br><br>The value for RB1 shall be ignored if this IE was included in a RRC message sent on RB1.<br><br>The value for RB2 shall be ignored if this IE was included in a RRC message sent on RB2. |
| >RRC message sequence number | MP | | Integer (0.. 15) | |

### 10.3.3.18 Integrity protection Algorithm

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Integrity protection algorithm | MP | | Enumerated (UIA1) | |

### 10.3.3.19 Integrity protection mode info

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Integrity protection mode command | MP | | Enumerated( start, modify) | |
| Downlink integrity protection activation info | CV-*modify* | | Integrity protection activation info 10.3.3.17 | |
| Integrity protection algorithm | OP | | Integrity protection algorithm 10.3.3.18 | |
| Integrity protection initialisation number | CV-*start* | | Bit string(32) | FRESH [40]. The first/leftmost bit of the bit string contains the most significant bit of the FRESH. |

| Condition | Explanation |
|---|---|
| *Start* | The IE is mandatory present if the IE "Integrity protection mode command" has the value "start ", otherwise it is not needed in the message. |
| *Modify* | The IE is mandatory present if the IE "Integrity protection mode command" has the value "modify" and not needed otherwise. |

### 10.3.3.19a Void

### 10.3.3.20 Void

### 10.3.3.21 Measurement capability

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| **Need for downlink compressed mode** | | | | | |
| FDD measurements | MP | | Boolean | TRUE means that the UE requires DL compressed mode in order to perform measurements on FDD | |
| 3.84 Mcps TDD measurements | CV-*3.84_Mcps_tdd_sup* | | Boolean | TRUE means that the UE requires DL compressed mode in order to perform measurements on 3.84 Mcps TDD | Name changed in REL-4 |
| 7.68 Mcps TDD measurements | CV-*7.68_Mcps_tdd_sup* | | Boolean | TRUE means that the UE requires DL compressed mode in order to perform measurements on 7.68 Mcps TDD | REL-7 |
| 1.28 Mcps TDD measurements | CV-*1.28_Mcps_tdd_sup* | | Boolean | TRUE means that the UE requires DL compressed mode in order to perform measurements on 1.28 Mcps TDD | REL-4 |
| GSM measurements | CV-*gsm_sup* | | | | |
| >GSM 900 | MP | | Boolean | TRUE means that the UE requires DL compressed mode in order to perform measurements on GSM 900 | |
| >DCS 1800 | MP | | Boolean | TRUE means that the UE requires DL compressed mode in order to perform measurements on DCS 1800 | |
| >GSM 1900 | MP | | Boolean | TRUE means that the UE requires DL compressed mode in order to perform measurements on GSM 1900 | |
| Multi-carrier measurement | CV-*mc_sup* | | Boolean | TRUE means that the UE requires DL compressed mode in order to perform measurements on | |

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| | | | | multi-carrier | |
| **Need for uplink compressed mode** | | | | | |
| FDD measurements | MP | | Boolean | TRUE means that the UE requires UL compressed mode in order to perform measurements on FDD | |
| 3.84 Mcps TDD measurements | CV-*3.84_Mcps_tdd_sup* | | Boolean | TRUE means that the UE requires UL compressed mode in order to perform measurements on 3.84 Mcps TDD | Name changed in REL-4 |
| 7.68 Mcps TDD measurements | CV-*7.68_Mcps_tdd_sup* | | Boolean | TRUE means that the UE requires UL compressed mode in order to perform measurements on 7.68 Mcps TDD | REL-7 |
| 1.28 Mcps TDD measurements | CV-*1.28_Mcps_tdd_sup* | | Boolean | TRUE means that the UE requires DL compressed mode in order to perform measurements on 1.28 Mcps TDD | REL-4 |
| GSM measurements | CV-*gsm_sup* | | | | |
| >GSM 900 | MP | | Boolean | TRUE means that the UE requires UL compressed mode in order to perform measurements on GSM 900 | |
| >DCS 1800 | MP | | Boolean | TRUE means that the UE requires UL compressed mode in order to perform measurements on DCS 1800 | |
| >GSM 1900 | MP | | Boolean | TRUE means that the UE requires UL compressed mode in order to perform measurements on GSM 1900 | |
| Multi-carrier measurement | CV-*mc_sup* | | Boolean | TRUE means that the UE requires UL compressed mode in order to perform measurements on multi-carrier | |

| Condition | Explanation |
|---|---|
| *3.84_Mcps_tdd_sup* | The IE is mandatory present if an IE "TDD RF capability" is present with the IE "Chip rate capability" set to "3.84 Mcps". Otherwise this field is not needed in the message. |
| *7.68_Mcps_tdd_sup* | The IE is mandatory present if an IE 'TDD RF capability' is present with the IE 'Chip rate capability' set to '7.68 Mcps'. Otherwise this field is not needed in the message. |
| *1.28_Mcps_tdd_sup* | The IE is mandatory present if an IE "TDD RF capability" is present with the IE "Chip rate capability" set to "1.28 Mcps". Otherwise this field is not needed in the message. |
| *gsm_sup* | The IE is mandatory present if the IE "Inter-RAT UE radio access capability" indicates support for GSM900, GSM1800 and/or GSM1900. Otherwise this field is not needed in the message. |
| *mc_sup* | The IE is mandatory present if the IE "Support of multi-carrier" has the value TRUE. Otherwise this field is not needed in the message. |

### 10.3.3.21a Measurement capability extension

This IE may be used to replace the measurement capability information provided within IE "Measurement capability".

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| FDD measurements | MP | 1 to <maxFreqBands FDD> | | | |
| >FDD Frequency band | MD | | Enumerated(Band I, Band II, | The default value is the same as indicated in the IE "Frequency band" included in the IE " UE radio access capability extension". Band numbering is defined in [21]. | |
| | | | Band III, | | REL-5 |
| | | | Band VI, Band IV, Band V, Band VII, extension indicator) | The default value is the same as R99, if the IE 'FDD Frequency band 2' below is not included. The default value is the same as the IE 'FDD Frequency band 2', if the IE 'FDD Frequency band 2' is included. | REL-6 |
| >FDD Frequency band 2 | MD | | Enumerated(Band VIII, Band IX, extension Indicator) | The default value is the same as indicated in the IE "Frequency band 2" included in the IE " UE radio access capability extension"., if the IE 'FDD Frequency band' above is not included. The default value is the same as the IE 'FDD Frequency band', if the IE 'FDD Frequency band' is included. Thirteen spare values are needed | REL-6 |

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| >Need for DL compressed mode | MP | | Boolean | TRUE means that the UE requires DL compressed mode in order to perform measurements on the FDD frequency band indicated by the IE "FDD Frequency band" | |
| >Need for UL compressed mode | MP | | Boolean | TRUE means that the UE requires UL compressed mode in order to perform measurements on the FDD frequency band indicated by the IE "FDD Frequency band" | |
| TDD measurements | CV-*tdd_sup* | 1 to <maxFreqBandsTDD> | | | |
| >TDD Frequency band | MP | | Enumerated(a, b, c) | | |
| >Need for DL compressed mode | MP | | Boolean | TRUE means that the UE requires DL compressed mode in order to perform measurements on TDD frequency band indicated by the IE "TDD Frequency band" | |
| >Need for UL compressed mode | MP | | Boolean | TRUE means that the UE requires UL compressed mode in order to perform measurements on TDD frequency band indicated by the IE "TDD Frequency band" | |
| GSM measurements | CV-*gsm_sup* | 1 to <maxFreqBandsGSM> | | | |
| >GSM Frequency band | MP | | Enumerated(GSM450, GSM480, GSM850, GSM900P, GSM900E, GSM1800, GSM1900) | as defined in [45]. Nine spare values are needed. | |
| >Need for DL compressed mode | MP | | Boolean | TRUE means that the UE requires DL compressed mode in order to perform measurements on GSM frequency band indicated by the IE "GSM Frequency band" | |

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| >Need for UL compressed mode | MP | | Boolean | TRUE means that the UE requires UL compressed mode in order to perform measurements on GSM frequency band indicated by the IE "GSM Frequency band" | |
| Multi-carrier measurement | CV-*mc_sup* | | | | |
| >Need for DL compressed mode | MP | | Boolean | TRUE means that the UE requires DL compressed mode in order to perform measurements on multi-carrier | |
| >Need for UL compressed mode | MP | | Boolean | TRUE means that the UE requires UL compressed mode in order to perform measurements on multi-carrier | |

| Condition | Explanation |
|---|---|
| *tdd_sup* | The IE is mandatory present if the IE "Multi-mode capability" has the value "TDD" or "FDD/TDD". Otherwise this field is not needed in the message. |
| *gsm_sup* | The IE is mandatory present if the IE "Support of GSM" has the value TRUE. Otherwise this field is not needed in the message. |
| *mc_sup* | The IE is mandatory present if the IE "Support of multi-carrier" has the value TRUE. Otherwise this field is not needed in the message. |

### 10.3.3.22 Paging cause

Cause for a CN originated page.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Paging cause | MP | | Enumerated( Terminating Conversational Call, Terminating Streaming Call, Terminating Interactive Call, Terminating Background Call, Terminating High Priority Signalling, Terminating Low Priority Signalling, Terminating – cause unknown ) | One spare value is needed. |

### 10.3.3.23 Paging record

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| CHOICE *Used paging identity* | MP | | | | |
| >CN identity | | | | | |
| >>Paging cause | MP | | Paging cause 10.3.3.22 | | |
| >>CN domain identity | MP | | CN domain identity 10.3.1.1 | | |
| >>CHOICE *UE Identity* | MP | | | Three spare values are needed. | |
| >>>IMSI (GSM-MAP) | | | IMSI (GSM-MAP) 10.3.1.5 | | |
| >>>TMSI (GSM-MAP) | | | TMSI (GSM-MAP) 10.3.1.17 | | |
| >>>P-TMSI (GSM-MAP) | | | P-TMSI (GSM-MAP) 10.3.1.13 | | |
| >>>IMSI (DS-41) | | | TIA/EIA/IS-2000-4 | | |
| >>>TMSI (DS-41) | | | TIA/EIA/IS-2000-4 | | |
| >UTRAN single UE identity | | | | | |
| >>U-RNTI | MP | | U-RNTI 10.3.3.47 | | |

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| >>CN originated page to connected mode UE | OP | | | | |
| >>>Paging cause | MP | | Paging cause 10.3.3.22 | | |
| >>>CN domain identity | MP | | CN domain identity 10.3.1.1 | | |
| >>>Paging record type identifier | MP | | Paging record type identifier 10.3.1.10 | | |
| >>RRC connection release information | MP | | RRC connection release information 10.3.3.35 o | | REL-5 |
| >UTRAN group identity | | 1 to <maxURNTIgroup> | | | REL-5 |
| >>RRC connection release information | MP | | RRC connection release information 10.3.3.35 o | | REL-5 |
| >>Group release information | MP | | Group release information 10.3.3.14 o | | REL-5 |

| Condition | Explanation |
|---|---|
| **CHOICE *Used paging identity*** | **Condition under which the given *used paging identity* is chosen** |
| CN identity | For CN originating pages (for idle mode UEs) |
| UTRAN single UE identity | For UTRAN originating pages (for connected mode UEs), addressing a single UE |
| UTRAN group identity | For UTRAN originating pages (for connected mode UEs), addressing a group of UEs |

### 10.3.3.24 PDCP capability

Indicates which algorithms and which value range of their parameters are supported by the UE.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| Support for lossless SRNS relocation | MP | | Boolean | TRUE means supported | |
| Support for lossless DL RLC PDU size change | CV-*not_iRAT_HoInfo2* | | Boolean | TRUE means supported Default value is FALSE | REL-5 |
| Support for RFC2507 | MP | | Boolean | TRUE means supported | |

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| >Max HC context space | MP | | Integer(1024, 2048, 4096, 8192, | | |
| | | | 16384, 32768, 65536, 131072) | Note 1 | REL-5 |
| Support for RFC 3095 | CV-*not_iRAT_HoInfo* | | Boolean | TRUE means supported | REL-4 |
| >Maximum number of ROHC context sessions | MD | | Integer( 2, 4, 8, 12, 16, 24, 32, 48, 64, 128, 256, 512, 1024, 16384) | Default value is 16. | REL-4 |
| >Reverse decompression depth | MD | | Integer (0..65535) | Default value is 0 (reverse decompression is not supported). | REL-4 |
| >Support for RFC 3095 context relocation | MP | | Boolean | TRUE means supported | REL-5 |
| Note 1: The IE "Max HC context space" values 16384, 32768, 65536 and 131072 are not used in the INTER RAT HANDOVER INFO message. | | | | | |

| Condition | Explanation |
|---|---|
| *not_iRAT_HoInfo* | The IE is not needed in the INTER RAT HANDOVER INFO message. Otherwise, it is mandatory present. |
| *not_iRAT_HoInfo2* | The IE is not needed in the INTER RAT HANDOVER INFO message. Otherwise, it is mandatory default. |

### 10.3.3.25 Physical channel capability

| Information Element/Group name | Need | Multi | Type and Reference | Semantics description | Version |
|---|---|---|---|---|---|
| Downlink physical channel capability information elements | | | | | |
| FDD downlink physical channel capability | CH-*fdd_req_sup* | | | | |
| >Max no DPCH codes | MP | | Integer (1..8) | Maximum number of DPCH codes to be simultaneously received | |
| >Max no physical channel bits received | MP | | Integer (1200, 2400, 3600, 4800, 7200, 9600, 14400, 19200, 28800, 38400, 48000, 57600, 67200, 76800) | Maximum number of physical channel bits received in any 10 ms interval (DPCH, S-CCPCH) | |
| >Support for SF 512 and 80 ms TTI for DPCH | MP | | Boolean | TRUE means supported | |
| >CHOICE *Support of HS-PDSCH* | CV-*not_iRAT_HoInfo* | | | | REL-5 |
| >>Supported | | | | | REL-5 |
| >>>HS-DSCH physical layer | MP | | Integer | | REL-5 |

| Information Element/Group name | Need | Multi | Type and Reference | Semantics description | Version |
|---|---|---|---|---|---|
| category | | | (1..64) | | |
| >>Unsupported | | | | (no data) | REL-5 |
| 3.84 Mcps TDD downlink physical channel capability | CH-*3.84_Mcps_tdd_req_sup* | | | | Name changed in REL-4 |
| >Maximum number of timeslots per frame | MP | | Integer (1..14) | | |
| >Maximum number of physical channels per frame | MP | | Integer (5..224) | | |
| >Minimum SF | MP | | Integer (1, 16) | | |
| >Support of PDSCH | MP | | Boolean | TRUE means supported | |
| >CHOICE *Support of HS-PDSCH* | CV-*not_iRAT_HoInfo* | | | | REL-5 |
| >>Supported | | | | | REL-5 |
| >>>HS-DSCH physical layer category | MP | | Integer (1..64) | | REL-5 |
| >>Unsupported | | | | (no data) | REL-5 |
| >Maximum number of physical channels per timeslot | MP | | Integer (5..16) | | |
| 7.68 Mcps TDD downlink physical channel capability | CH-7.68_*Mcps_tdd_req_sup* | | | | REL-7 |
| >Maximum number of timeslots per frame | MP | | Integer (1..14) | | |
| >Maximum number of physical channels per frame | MP | | Integer (5..448) | | |
| >Minimum SF | MP | | Integer (1, 32) | | |
| >Support of PDSCH | MP | | Boolean | TRUE means supported | |
| >CHOICE *Support of HS-PDSCH* | CV-*not_iRAT_HoInfo* | | | | |
| >>Supported | | | | | |
| >>>HS-DSCH physical layer category | MP | | Integer (1..64) | | |
| >>Unsupported | | | | (no data) | |
| >Maximum number of physical channels per timeslot | MP | | Integer (5..32) | | |
| 1.28 Mcps TDD downlink physical channel capability | CH-*1.28_Mcps_tdd_req_sup* | | | | REL-4 |
| >Maximum number of timeslots per subframe | MP | | Integer (1..6) | | REL-4 |
| >Maximum number of physical channels per subframe | MP | | Integer (1..96) | | REL-4 |
| >Minimum SF | MP | | Integer (1, 16) | | REL-4 |
| >Support of PDSCH | MP | | Boolean | TRUE means supported | REL-4 |
| >CHOICE *Support of HS-PDSCH* | CV-*not_iRAT_HoInfo* | | | | REL-5 |
| >>Supported | | | | | REL-5 |
| >>>HS-DSCH physical layer category | MP | | Integer (1..64) | | REL-5 |
| >>Unsupported | | | | (no data) | REL-5 |
| >Maximum number of physical channels per timeslot | MP | | Integer (1..16) | | REL-4 |

| Information Element/Group name | Need | Multi | Type and Reference | Semantics description | Version |
|---|---|---|---|---|---|
| >Support of 8PSK | MP | | Boolean | TRUE means supported | REL-4 |
| **Uplink physical channel capability information elements** | | | | | |
| FDD uplink physical channel capability | CH-*fdd_req_sup* | | | | |
| >Maximum number of DPDCH bits transmitted per 10 ms | MP | | Integer (600, 1200, 2400, 4800. 9600, 19200. 28800, 38400, 48000, 57600) | | |
| >CHOICE *Support of E-DCH* | CV-*not_iRAT_HoInfo* | | | | REL-6 |
| >>Supported | | | | | REL-6 |
| >>>E-DCH physical layer category | MP | | Integer (1..16) | | REL-6 |
| >>Unsupported | | | | (no data) | REL-6 |
| 3.84 Mcps TDD uplink physical channel capability | CH-*3.84_Mcps_tdd_req_sup* | | | | Name changed in REL-4 |
| >Maximum Number of timeslots per frame | MP | | Integer (1..14) | | |
| >Maximum number of physical channels per timeslot | MP | | Integer (1, 2) | | |
| >Minimum SF | MP | | Integer (1, 2, 4, 8) | | |
| >Support of PUSCH | MP | | Boolean | TRUE means supported | |
| 7.68 Mcps TDD uplink physical channel capability | CH-*7.68_Mcps_tdd_req_sup* | | | | REL-7 |
| >Maximum Number of timeslots per frame | MP | | Integer (1..14) | | |
| >Maximum number of physical channels per timeslot | MP | | Integer (1, 2) | | |
| >Minimum SF | MP | | Integer (1, 2, 4, 8) | | |
| >Support of PUSCH | MP | | Boolean | TRUE means supported | |
| 1.28 Mcps TDD uplink physical channel capability | CH-*1.28_Mcps_tdd_req_sup* | | | | REL-4 |
| >Maximum Number of timeslots per subframe | MP | | Integer (1..6) | | REL-4 |
| >Maximum number of physical channels per timeslot | MP | | Integer (1, 2) | | REL-4 |
| >Minimum SF | MP | | Integer (1, 2, 4, 8, 16) | | REL-4 |
| >Support of PUSCH | MP | | Boolean | TRUE means supported | REL-4 |
| >Support of 8PSK | MP | | Boolean | TRUE means supported | REL-4 |

| Condition | Explanation |
|---|---|
| *3.84_Mcps_tdd_req_sup* | The IE is mandatory present if the IE "TDD RF capability" is present with the IE "Chip rate capability" set to "3.84 Mcps" and a 3.84 Mcps TDD capability update has been requested in a previous message. Otherwise this field is not needed in the message. |
| *7.68_Mcps_tdd_req_sup* | The IE is mandatory present if the IE "TDD RF capability" is present with the IE "Chip rate capability" set to "7.68 Mcps" and a 7.68 Mcps TDD capability update has been requested in a previous message. Otherwise this field is not needed in the message. |
| *1.28_Mcps_tdd_req_sup* | The IE is mandatory present if the IE "TDD RF capability" is present with the IE "Chip rate capability" set to "1.28 Mcps" and a 1.28 Mcps TDD capability update has been requested in a previous message. Otherwise this field is not needed in the message. |
| *fdd_req_sup* | The IE is mandatory present if the IE "Multi-mode capability" has the value "FDD" or "FDD/TDD" and a FDD capability update has been requested in a previous message. Otherwise this field is not needed in the message. |
| *not_iRAT_HoInfo* | The CHOICE *Support of HS-PDSCH* is not needed in the INTER RAT HANDOVER INFO message. Otherwise, it is mandatory present. |
| *not_iRAT_HoInfo* | The CHOICE *Support of E-DCH* is not needed in the INTER RAT HANDOVER INFO message. Otherwise, it is mandatory present. |

### 10.3.3.26 Protocol error cause

This IE indicates the cause for a message or information that was not comprehended.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Protocol error cause | MP | | Enumerated (ASN.1 violation or encoding error, Message type non-existent or not implemented, Message not compatible with receiver state, Information element value not comprehended, Information element missing, Message extension not comprehended) | Two spare values are needed. |

### 10.3.3.27 Protocol error indicator

This IE indicates whether a message was transmitted due to a protocol error or not.

| Information Element/Group name | Need | Multi | Type and Reference | Semantics description |
|---|---|---|---|---|
| Protocol error indicator | MP | | Boolean | TRUE means a protocol error occurred. FALSE means a protocol error did not occur. |

### 10.3.3.28 RB timer indicator

This IE is used to indicate to UTRAN if the timers T314 or T315 has expired in the UE.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| T314 expired | MP | | Boolean | TRUE means that the timer has expired or the stored value is zero.<br>FALSE means that the timer has not expired. |
| T315 expired | MP | | Boolean | TRUE means that the timer has expired or the stored value is zero.<br>FALSE means that the timer has not expired. |

### 10.3.3.29 Redirection info

This IE is used to redirect the UE to another frequency or other system. With the Release 6 version a list of cells may be provided to the UE, where cell selection shall be started.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| CHOICE *Redirection Information* | MP | | | | |
| >Frequency info | | | Frequency info 10.3.6.36 | | |
| >Inter-RAT info | | | Inter-RAT info 10.3.7.25 | | |

### 10.3.3.30 Re-establishment timer

This information element indicates which timer to associate with RAB.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Re-establishment timer | MP | | Enumerated( useT314, useT315) | |

### 10.3.3.31 Rejection cause

Cause for rejection of RRC connection establishment request.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Rejection cause | MP | | Enumerated( congestion, unspecified) | |

### 10.3.3.32 Release cause

Cause for release of RRC connection.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Release cause | MP | | Enumerated (normal event, unspecified, pre-emptive release, congestion, re-establishment reject, user inactivity), directed signalling connection re-establishment) | One spare value is needed. |

### 10.3.3.32a RF Capability Compressed

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| CHOICE *FDD* | MP | | | | REL-5 |
| >Supported | | | | | REL-5 |
| >>RF capability band FDD list Compressed | MP | 1..<maxfreqbandsFDD> | | | REL-5 |
| | | 1..<maxfreqbandsFDD-ext> | | | REL-6 |
| >>>RF Capability Band FDD Compressed | MP | | Enumerated (not supported, default TxRx separation) | TX/RX frequency separation capability for the supported frequency band(s). Default is the TX/RX frequency separation defined in [21] for each frequency band. Two spare values are needed. | REL-5 |
| >Not supported | | | NULL | | REL-5 |
| CHOICE *TDD-3.84Mcps* | MP | | | | REL-5 |
| >Supported | | | | | REL-5 |
| >>Radio Frequency Band TDD List | MP | | Enumerated (a, b, c, a+b, a+c, b+c, a+b+c) | As defined in [22]. One spare value needed | REL-5 |
| >Not supported | | | NULL | | REL-5 |
| CHOICE *TDD-7.68Mcps* | MP | | | | REL-7 |
| >Supported | | | | | REL-7 |
| >>Radio Frequency Band TDD List | MP | | Enumerated (a, b, c, a+b, a+c, b+c, a+b+c) | As defined in [22]. One spare value needed | REL-7 |
| >Not supported | | | NULL | | REL-7 |
| CHOICE *TDD-1.28Mcps* | MP | | | | REL-5 |
| >Supported | | | | | REL-5 |
| >>Radio Frequency Band TDD List | MP | | Enumerated (a, b, c, a+b, a+c, b+c, a+b+c) | As defined in [22]. One spare value needed | REL-5 |
| >Not supported | | | NULL | | REL-5 |

### 10.3.3.33 RF capability FDD

| Information Element/Group name | Need | Multi | Type and Reference | Semantics description | Version |
|---|---|---|---|---|---|
| UE power class | MP | | Enumerated( 1..4) | As defined in [21] | |
| Tx/Rx frequency separation | MP | | Enumerated( default TxRx separation) | Default is the TX/RX frequency separation defined in [21] for each frequency band. Two spare values are needed. | |

### 10.3.3.33a RF capability FDD extension

| Information Element/Group name | Need | Multi | Type and Reference | Semantics description |
|---|---|---|---|---|
| UE power class extension | MP | | Enumerated( 1..4) | As defined in [21]. Four spare values are needed |
| Tx/Rx frequency separation | MP | | Enumerated( default TxRx separation) | Default is the TX/RX frequency separation defined in [21] for each frequency band. Two spare values are needed. |

### 10.3.3.33b RF capability TDD

| Information Element/Group name | Need | Multi | Type and Reference | Semantics description |
|---|---|---|---|---|
| UE power class | MP | | Enumerated (1..4) | as defined in [22] |
| Radio frequency bands | MP | | Enumerated( a, b, c, a+b, a+c, b+c, a+b+c) | as defined in [22]. One spare value needed. |
| Chip rate capability | MP | | Enumerated( 3.84Mcps, 7.68 Mcps,1.28M cps) | as defined in [22] |

### 10.3.3.33c RF capability TDD 1.28 Mcps

| Information Element/Group name | Need | Multi | Type and Reference | Semantics description |
|---|---|---|---|---|
| Radio frequency bands | MP | | Enumerated( a, b, c, a+b, a+c, b+c, a+b+c) | as defined in [22]. One spare value needed. |

### 10.3.3.34 RLC capability

| Information Element/Group name | Need | Multi | Type and Reference | Semantics description | Version |
|---|---|---|---|---|---|
| Total RLC AM buffer size | MP | | Integer (10, 50, 100, 150, 500, 1000, | Total receiving and transmitting RLC AM buffer and MAC-hs reordering buffer capability in kBytes. Note 1. | |
| | | | 200, 300, 400, 750) | | REL-5 |
| Maximum RLC AM Window Size | MP | | Integer(2047,4095) | Maximum supported RLC TX and RX window in UE | |
| Maximum number of AM entities | MP | | Integer (4,5,6,8,16,30) | | |
| Note 1: The IE "Total RLC AM buffer size" values 200, 300, 400 and 750 are not used in the INTER RAT HANDOVER INFO message. | | | | | |

### 10.3.3.35 RLC re-establish indicator

This IE is used to re-configure AM RLC on c-plane and u-plane.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| RLC re-establish indicator | MP | | Boolean | TRUE means re-establish required<br>FALSE means re-establish not required |

### 10.3.3.35o RRC connection release information

Indicates whether the UE shall perform a release of the RRC connection.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| CHOICE *Release indicator* | MD | | | Default value is 'No release' | REL-5 |
| >No release | | | | | REL-5 |
| >Release | | | | | REL-5 |
| >>Release cause | MP | | Release cause 10.3.3.32 | | REL-5 |

### 10.3.3.35a RRC State Indicator

Indicates to a UE the RRC state to be entered.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| RRC State indicator | MP | | Enumerated( CELL_DCH, CELL_FACH, CELL_PCH, URA_PCH) | |

### 10.3.3.36 RRC transaction identifier

This IE contains an identification of the RRC procedure transaction local for the type of the message this IE was included within.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| CHOICE *RRC Tr Id type* | MP | | | | REL-5 |
| *>Normal* | | | | | |
| >>RRC transaction identifier | MP | | Integer (0..3) | | |
| *>Extended* | | | | | REL-5 |
| >>RRC transaction identifier | MP | | Integer (0..15) | | REL-5 |

| CHOICE *RRC Tr Id type* | Condition under which the given *RRC Tr Id type* is chosen |
|---|---|
| *Normal* | All cases where the *RRC Tr Id type: Extended* is not chosen. |
| *Extended* | Optional in the MEASUREMENT CONTROL message. Mandatory in the MEASUREMENT CONTROL FAILURE message. |

### 10.3.3.37 Security capability

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Ciphering algorithm capability | MP | | | |
| >UEA0 | MP | | Boolean | |
| >UEA1 | MP | | Boolean | |
| >Spare | MP | 14 | Boolean | Shall be set to FALSE by UEs complying with this version of the protocol. |
| Integrity protection algorithm capability | MP | | | |
| >UIA1 | MP | | Boolean | The value TRUE means that UIA1, Kasumi, is supported |
| >Spare | MP | 15 | Boolean | Shall be set to FALSE by UEs complying with this version of the protocol. |

### 10.3.3.38 START

There is a START value per CN domain. The START is used to initialise the 20 MSBs of all hyper frame numbers (MAC-d HFN, RLC UM HFN, RLC AM HFN, RRC HFN) for a CN domain.

| Information Element/Group name | Need | Multi | Type and Reference | Semantics description |
|---|---|---|---|---|
| START | MP | | Bit string (20) | START [40]. The first/leftmost bit of the bit string contains the most significant bit of the START. |

### 10.3.3.39 Void

### 10.3.3.40 Transport channel capability

| Information Element/Group name | Need | Multi | Type and Reference | Semantics description |
|---|---|---|---|---|
| **Downlink transport channel capability information elements** | | | | |
| Max no of bits received | MP | | Integer(640, 1280, 2560, 3840, 5120, 6400, 7680, 8960, 10240, 20480, 40960, 81920, 163840) | Maximum sum of number of bits of all transport blocks received at an arbitrary time instant |
| Max convolutionally coded bits received | MP | | Integer(640, 1280, 2560, 3840, 5120, 6400, 7680, 8960, 10240, 20480, 40960, 81920, 163840) | Maximum sum of number of bits of all convolutionally coded transport blocks received at an arbitrary time instant |
| Max turbo coded bits received | CV-*turbo_dec_sup* | | Integer(640, 1280, 2560, 3840, 5120, 6400, 7680, | Maximum sum of number of bits of all turbo coded transport blocks received at an arbitrary time instant |

| Information Element/Group name | Need | Multi | Type and Reference | Semantics description |
|---|---|---|---|---|
| | | | 8960, 10240, 20480, 40960, 81920, 163840) | |
| Maximum number of simultaneous transport channels | MP | | Integer(4, 8, 16, 32) | |
| Maximum number of simultaneous CCTrCH | MP | | Integer (1..8) | |
| Max no of received transport blocks | MP | | Integer(4, 8, 16, 32, 48, 64, 96, 128, 256, 512) | Maximum total number of transport blocks received within TTIs that end at within the same 10ms interval |
| Maximum number of TFC | MP | | Integer(16, 32, 48, 64, 96, 128, 256, 512, 1024) | |
| Maximum number of TF | MP | | Integer(32, 64, 128, 256, 512, 1024) | |
| Support for turbo decoding | MP | | Boolean | TRUE means supported |
| **Uplink transport channel capability information elements** | | | | |
| Max no of bits transmitted | MP | | Integer(640, 1280, 2560, 3840, 5120, 6400, 7680, 8960, 10240, 20480, 40960, 81920, 163840) | Maximum sum of number of bits of all transport blocks transmitted at an arbitrary time instant |
| Max convolutionally coded bits transmitted | MP | | Integer(640, 1280, 2560, 3840, 5120, 6400, 7680, 8960, 10240, 20480, 40960, 81920, 163840) | Maximum sum of number of bits of all convolutionally coded transport blocks transmitted at an arbitrary time instant |
| Max turbo coded bits transmitted | CV-*turbo_enc_sup* | | Integer(640, 1280, 2560, 3840, 5120, 6400, 7680, 8960, 10240, 20480, 40960, 81920, 163840) | Maximum sum of number of bits of all turbo coded transport blocks transmitted at an arbitrary time instant |
| Maximum number of simultaneous transport channels | MP | | Integer(4, 8, 16, 32) | |
| Maximum number of simultaneous CCTrCH of DCH type | CH-*tdd_req_sup* | | Integer (1..8) | |
| Max no of transmitted transport blocks | MP | | Integer(4, 8, 16, 32, 48, 64, 96, 128, 256, 512) | Maximum total number of transport blocks transmitted within TTIs that start at the same time |
| Maximum number of TFC | MP | | Integer(16, 32, 48, 64, 96, 128, 256, 512, 1024) | |
| Maximum number of TF | MP | | Integer(32, 64, 128, 256, | |

| Information Element/Group name | Need | Multi | Type and Reference | Semantics description |
|---|---|---|---|---|
| | | | 512, 1024) | |
| Support for turbo encoding | MP | | Boolean | TRUE means supported |

| Condition | Explanation |
|---|---|
| *turbo_dec_sup* | The IE is mandatory present if the IE "Support of turbo decoding" = True. Otherwise this field is not needed in the message. |
| *turbo_enc_sup* | The IE is mandatory present if the IE "Support of turbo encoding" = True. Otherwise this field is not needed in the message. |
| *tdd_req_sup* | The IE is mandatory present if the IE "Multi-mode capability" has the value "TDD" or "FDD/TDD" and a TDD capability update has been requested in a previous message. Otherwise this field is not needed in the message. |

### 10.3.3.41 UE multi-mode/multi-RAT capability

| Information Element/Group name | Need | Multi | Type and Reference | Semantics description | Version |
|---|---|---|---|---|---|
| **Multi-RAT capability** | | | | | |
| Support of GSM | MP | | Boolean | | |
| Support of multi-carrier | MP | | Boolean | | |
| Multi-mode capability | MP | | Enumerated (TDD, FDD, FDD/TDD) | | |
| Support of UTRAN to GERAN NACC | CV-*not_iRAT_HoInfo* | | Boolean | | REL-5 |
| Support of Handover to GAN | OP | | Enumerated ( DoesSupportHandoverToGAN ) | Absence of this IE means that the UE does not support Handover to GAN. | REL-6 |
| Support of Inter-RAT PS handover | CV-*not_iRAT_HoInfo2* | | Enumerated (DoesSupportInter-RAT-PS-Handover ) | Absence of this IE means that the UE does not support Inter-RAT PS Handover | REL-6 |

| Condition | Explanation |
|---|---|
| *not_iRAT_HoInfo* | The IE is not needed in the INTER RAT HANDOVER INFO message. Otherwise, it is mandatory present. |
| CV-*not_iRAT_HoInfo2* | The IE is not needed in the INTER RAT HANDOVER INFO message. Otherwise, it is optional. |

### 10.3.3.42 UE radio access capability

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| Access stratum release indicator | MP | | Enumerated( R99) | Indicates the release of the UE according to [35]. The IE also indicates the release of the RRC transfer syntax supported by the UE.. | |
| | CV-*not_rrc_connectionSetupComplete* | | Enumerated( REL-4, | 13 spare values are needed. | REL-4 |
| | | | REL-5 | | REL-5 |
| | | | REL-6) | | REL-6 |
| DL capability with simultaneous HS-DSCH configuration | CV-*not_iRAT_HoInfo* | | Enumerated( 32kbps, 64kbps, 128kbps, 384kbps) | | REL-5 |
| PDCP capability | MP | | PDCP capability 10.3.3.24 | | |
| RLC capability | MP | | RLC capability 10.3.3.34 | | |
| Transport channel capability | MP | | Transport channel capability 10.3.3.40 | | |
| RF capability FDD | OP | | RF capability FDD 10.3.3.33 | | |
| RF capability TDD | OP | | RF capability TDD 10.3.3.33b | One "TDD RF capability" entity shall be included for every Chip rate capability supported. | |
| | | 1 to 2 | | Note 1 | REL-4 |
| RF capability TDD 1.28 Mcps | CV-*iRAT_HoInfo* | | RF capability TDD 1.28 Mcps 10.3.3.33c | Note 1 | REL-4 |
| Physical channel capability | MP | | Physical channel capability 10.3.3.25 | | |
| UE multi-mode/multi-RAT capability | MP | | UE multi-mode/multi-RAT capability 10.3.3.41 | | |
| Security capability | MP | | Security capability 10.3.3.37 | | |
| UE positioning capability | MP | | UE positioning capability 10.3.3.45 | | |
| Measurement capability | CV-*fdd_req_sup* | | Measurement capability 10.3.3.21 | | |

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| Device type | MD | | Enumerated (DoesNotBenefitFromBatteryConsumptionOptimisation) | Absence of this value means that the device does benefit from NW-based battery consumption optimisation.<br><br>UE may set the value to DoesNotBenefitFromBatteryConsumptionOptimisation when it does not foresee to particularly benefit from NW-based | REL-6 |
| Note 1: The second entity of the "RF capability TDD" is not needed in the INTER RAT HANDOVER INFO message: if both TDD 3.84/7.68 Mcps and TDD 1.28 Mcps are supported, the "RF capability TDD 1.28 Mcps" entity shall be used for TDD 1.28 Mcps; the "UE power class" in the "RF capability TDD" entity shall apply for both chip rates. | | | | | |

| Condition | Explanation |
|---|---|
| *fdd_req_sup* | The IE is mandatory present if the IE "Multi-mode capability" has the value "FDD" or "FDD/TDD" and a FDD capability update has been requested in a previous message. Otherwise this field is not needed in the message. |
| *not_rrc_connectionSetupComplete* | The IE is not needed in the RRC CONNECTION SETUP COMPLETE message. Otherwise the IE is mandatory present. |
| *not_iRAT_HoInfo* | The IE is not needed in the INTER RAT HANDOVER INFO message. Otherwise, it is optional. |
| *iRAT_HoInfo* | The IE is optional in the INTER RAT HANDOVER INFO message. Otherwise, the IE is not needed. |

### 10.3.3.42o UE radio access capability compressed

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| Access stratum release indicator | MP | | Enumerated( R99, REL-4, REL-5 | 13 spare values are needed | REL-5 |
| | | | REL-6) | | REL-6 |
| Total AM RLC buffer size exceeds 10 kByte | MP | | BOOLEAN | | REL-5 |
| RF capability compressed | MP | | RF capability compressed 10.3.3.32a | | REL-5 |

### 10.3.3.42oa UE radio access capability comp 2

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| FDD physical channel capability for HS-PDSCH/E-DCH | OP | | | | REL-6 |
| >DL capability with simultaneous HS-DSCH configuration | MP | | Enumerated (32, 64, 128, 384) | Unit: kbps. | REL-6 |
| >HS-DSCH physical layer category | MP | | Integer (1..64) | | REL-6 |
| >CHOICE Support of E-DCH | MP | | | | REL-6 |

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| >>Supported | | | | | REL-6 |
| >>>E-DCH physical layer category | MP | | Integer (1..16) | | REL-6 |
| >>Unsupported | | | | (no data) | REL-6 |

## 10.3.3.42a UE radio access capability extension

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| Frequency band specific capability list | MP | 1 to <maxFreqbandsFDD> | | | |
| >Frequency band | MP | | Enumerated(Band I, Band II, | | |
| | | | Band III, | | REL-5 |
| | | | Band VI, Band IV, Band V, Band VII, extension indicator) | | REL-6 |
| >Frequency band 2 | OP | | Enumerated(Band VIII, Band IX, extension Indicator) | This IE indicates the supported frequency bands Band VIII and beyond. Thirteen spare values are needed | REL-6 |
| >RF capability FDD extension | MD | | RF capability FDD extension 10.3.3.33a | the default values are the same values as in the immediately preceding IE "RF capability FDD extension"; the first occurrence is MP | |
| >Measurement capability extension | MP | | Measurement capability extension 10.3.3.21a | | |

## 10.3.3.42b UE security information

Upon receiving a UE information request from another system, the UE shall indicate the requested security information. The UE security information includes the following RRC information.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| **UE information elements** | | | | |
| START-CS | MP | | START 10.3.3.38 | START values to be used in this CN domain. |

## 10.3.3.42c UE security information2

Upon receiving a UE information request from another system, the UE shall indicate the requested security information. The UE security information includes the following RRC information.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| START-PS | MP | | START 10.3.3.38 | START values to be used in this CN domain. | Rel-6 |

### 10.3.3.43 UE Timers and Constants in connected mode

This information element specifies timer- and constants values used by the UE in connected mode.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| T301 | MD | | Integer(100, 200 .. 2000 by step of 200, 3000, 4000, 6000, 8000) | Value in milliseconds. Default value is 2000. This IE should not be used by the UE in this release of the protocol. One spare value is needed. | |
| N301 | MD | | Integer(0..7) | Default value is 2. This IE should not be used by the UE in this release of the protocol. | |
| T302 | MD | | Integer(100, 200... 2000 by step of 200, 3000, 4000, 6000, 8000) | Value in milliseconds. Default value is 4000. One spare value is needed. | |
| N302 | MD | | Integer(0..7) | Default value is 3. | |
| T304 | MD | | Integer(100, 200, 400, 1000, 2000) | Value in milliseconds. Default value is 2000. Three spare values are needed. | |
| N304 | MD | | Integer(0..7) | Default value is 2.. | |
| T305 | MD | | Integer(5, 10, 30, 60, 120, 360, 720, infinity) | Value in minutes. Default value is 30. Infinity means no update | |
| T307 | MD | | Integer(5, 10, 15, 20, 30, 40, 50) | Value in seconds. Default value is 30. One spare value is needed. | |
| T308 | MD | | Integer(40, 80, 160, 320) | Value in milliseconds. Default value is 160. | |
| T309 | MD | | Integer(1 …8) | Value in seconds. Default value is 5. | |
| T310 | MD | | Integer(40 .. 320 by step of 40) | Value in milliseconds. Default value is 160. | |
| N310 | MD | | Integer(0 .. 7) | Default value is 4. | |

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| T311 | MD | | Integer(250 .. 2000 by step of 250) | Value in milliseconds. Default value is 2000. | |
| T312 | MD | | Integer (0..15) | Value in seconds. Default value is 1. The value 0 is not used in this version of the specification. | |
| N312 | MD | | Integer (1, 2, 4, 10, 20, 50, 100, 200, 400, 600, 800, 1000) | Default value is 1. | |
| T313 | MD | | Integer (0..15) | Value in seconds. Default value is 3. | |
| N313 | MD | | Integer (1, 2, 4, 10, 20, 50, 100, 200) | Default value is 20. | |
| T314 | MD | | Integer(0, 2, 4, 6, 8, 12, 16, 20) | Value in seconds. Default value is 12. | |
| T315 | MD | | Integer (0,10, 30, 60, 180, 600, 1200, 1800) | Value in seconds. Default value is 180. | |
| N315 | MD | | Integer (1, 2, 4, 10, 20, 50, 100, 200, 400, 600, 800, 1000) | Default value is 1. | |
| T316 | MD | | Integer(0, 10, 20, 30, 40, 50, infinity) | Value in seconds. Default value is 30. One spare value is needed. | |
| T317 | MD | | | Default value is infinity. | |
| | | | Enumerated (infinity, infinity, infinity, infinity, infinity, infinity, infinity, infinity) | All the values are changed to "infinity" in the Rel-5. | REL-5 |

### 10.3.3.44 UE Timers and Constants in idle mode

This information element specifies timer- and constant values used by the UE in idle mode.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| T300 | MP | | Integer(100, | Value in milliseconds. Default |

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| | | | 200... 2000 by step of 200, 3000, 4000, 6000, 8000) | value is 1000. Use of Default is described in 10.2.48.8.4 and in 10.2.48.8.16. |
| N300 | MP | | Integer(0..7) | Default value is 3. Use of Default is described in 10.2.48.8.4 and in 10.2.48.8.16. |
| T312 | MP | | Integer(0 .. 15) | Value in seconds. Default value is 1. Use of Default is described in 10.2.48.8.4 and in 10.2.48.8.16. The value 0 is not used in this version of the specification. |
| N312 | MP | | Integer (1, 2, 4, 10, 20, 50, 100, 200, 400, 600, 800, 1000) | Default value is 1. Use of Default is described in 10.2.48.8.4 and in 10.2.48.8.16. |

### 10.3.3.45 UE positioning capability

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Standalone location method(s) supported | MP | | Boolean | Defines if a UE can measure its location by some means unrelated to UTRAN<br>TRUE means supported |
| UE based OTDOA supported | MP | | Boolean | TRUE means supported |
| Network Assisted GPS support | MP | | Enumerated ('Network based', 'UE based', 'Both', 'None') | Defines if the UE supports network based or UE based GPS methods. |
| Support for GPS timing of cell frames measurement | MP | | Boolean | Defines if a UE has the capability to perform the UE GPS timing of cell frames measurement [7].<br>TRUE means capable |
| Support for IPDL | MP | | Boolean | Defines if a UE has the capability to use IPDL to enhance its 'SFN-SFN observed time difference –type 2' measurement.<br>TRUE means supported |
| Support for Rx-Tx time difference type2 measurement | MP | | Boolean | TRUE means supported |
| Support for UP assisted GPS measurement validity in CELL_PCH and URA_PCH states | CV-GPSsupported | | Enumerated (true) | |
| Support for SFN-SFN observed time difference type 2 measurement | OP | | Enumerated (true) | Absence of this element means not supported and presence means supported. |

| Condition | Explanation |
|---|---|
| *GPSsupported* | This IE is mandatory present if the IE 'Network Assisted GPS support' is set to 'Network based', 'UE based' or 'Both'. Otherwise, it is not needed. |

### 10.3.3.46 URA update cause

Indicates the cause for s URA update.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| URA update cause | MP | | Enumerated( change of URA, periodic URA update) | One spare value is needed. |

### 10.3.3.47 U-RNTI

The U-RNTI (UTRAN Radio Network Temporary Identity) is allocated to a UE having a RRC connection and identifies the UE within UTRAN.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| SRNC identity | MP | | bit string(12) | The SRNC identity bits are numbered b20 to b31, where b20 is the least significant bit. |
| S-RNTI | MP | | bit string(20) | The S-RNTI bits are numbered b0 to b19, where b0 is the least significant bit. |

### 10.3.3.47a U-RNTI group

The U-RNTI group is used to identify a group of UEs having an RRC connection.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| CHOICE *group discrimimator* | MP | | | | REL-5 |
| >All | | | | (no data) | REL-5 |
| >U-RNTI mask | | | | | REL-5 |
| >>U-RNTI | MP | | U-RNTI 10.3.3.47 | The bits that are less significant than the bit position indicated by the U-RNTI bit mask index shall be ignored. | REL-5 |
| >>U-RNTI bit mask index | MP | | Enumerated( b1, b2,..b31) | Values b1 to b19 indicate bit positions in the S-RNTI. Values b20 to b31 indicate bit positions in the SRNC identity. | REL-5 |

### 10.3.3.48 U-RNTI Short

The U-RNTI (UTRAN Radio Network Temporary Identity) is allocated to a UE having a RRC connection and identifies the UE within UTRAN.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| SRNC identity | MP | | bit string(12) | The SRNC identity bits are numbered b20 to b31, where b20 is the least significant bit. |
| S-RNTI 2 | MP | | bit string(10) | The S-RNTI 2 bits are numbered b0 to b9, where b0 is the least significant bit. |

### 10.3.3.49 UTRAN DRX cycle length coefficient

A coefficient in the formula to count the paging occasions to be used by a specific UE (specified in [4]).

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| DRX cycle length coefficient | MP | | Integer(3...9) | Refers to 'k' in the formula as specified in [4], Discontinuous reception |

### 10.3.3.50 Wait time

Wait time defines the time period the UE has to wait before repeating the rejected procedure.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Wait time | MP | | Integer(0..15) | Wait time in seconds<br>The value 0 indicates that repetition is not allowed. |

### 10.3.3.51 UE Specific Behaviour Information 1 idle

This IE indicates the UE conformance typically for RRC connection establishment from idle mode.

| Information Element/Group name | Need | Multi | Type and Reference | Semantics description |
|---|---|---|---|---|
| UE Specific Behaviour Information 1 idle | MP | | bit string(4) | |

### 10.3.3.52 UE Specific Behaviour Information 1 interRAT

This IE indicates the UE conformance typically for RRC connection establishment from another RAT.

| Information Element/Group name | Need | Multi | Type and Reference | Semantics description |
|---|---|---|---|---|
| UE Specific Behaviour Information 1 interRAT | MP | | bit string(8) | |

## 10.3.4 Radio Bearer Information elements

### 10.3.4.0 Default configuration identity

This information element identifies a default radio parameter configuration.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| Default configuration identity | MP | | Integer (0..10, | The corresponding default configurations are specified in 13.7 | |
| | | | 11, 12, | | REL-4 |
| | | | 13, | Default configuration ID 2 is not used. | REL-5 |
| | | | 14, 15, | | REL-6 |
| | | | 17, | Used only in RRC Connection Setup and Handover To UTRAN Command messages. | REL-6 |
| | | | 16, 18..31) | Reserved for future extension | REL-6 |

### 10.3.4.1 Downlink RLC STATUS info

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Timer_Status_Prohibit | OP | | Integer(10..50 by step of 10, 550..1000 by step of 50) | Minimum time in ms between STATUS reports |
| Missing PDU Indicator | MP | | Boolean | Value true indicates that UE should send a STATUS report for each missing PDU that is detected |
| Timer_STATUS_periodic | OP | | Integer(100, 200, 300, 400, 500, 750, 1000, 2000) | Time in milliseconds |

### 10.3.4.1a PDCP context relocation info

This information element indicates that the header compression context relocation is to be performed during SRNS relocation for the given radio bearer.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| RB identity | MP | | RB identity 10.3.4.16 | | REL-5 |
| Downlink RFC 3095 context relocation indication | MP | | Boolean | TRUE means RFC 3095 context relocation is performed in downlink | REL-5 |
| Uplink RFC 3095 context relocation indication | MP | | Boolean | TRUE means RFC 3095 context relocation is performed in uplink | REL-5 |

### 10.3.4.2 PDCP info

The purpose of the PDCP info IE is to indicate which algorithms shall be established and to configure the parameters of each of the algorithms.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| Support for lossless SRNS relocation or for lossless DL RLC PDU size change | CV-*LosslessCriteria* | | Boolean | TRUE means support | |
| Max PDCP SN window size | CV-*Lossless* | | Enumerated( sn255, sn65535) | Maximum PDCP sequence number window size. The handling of sequence number when the Max PDCP SN window size is 255 is specified in [23]. | |
| PDCP PDU header | MP | | Enumerated (present, absent) | Whether a PDCP PDU header is existent or not. | |
| Header compression information | OP | 1 to <maxPDCPAlgoType> | | | |
| >CHOICE *algorithm type* | MP | | | | |
| >>RFC 2507 | | | | Header compression according to IETF standard RFC 2507 | |
| >>>F_MAX_PERIOD | MD | | Integer (1..65535) | Largest number of compressed non-TCP headers that may be sent without sending a full header. Default value is 256. | |
| >>>F_MAX_TIME | MD | | Integer (1..255) | Compressed headers may not be sent more than F_MAX_TIME seconds after sending last full header. Default value is 5. | |
| >>>MAX_HEADER | MD | | Integer (60..65535) | The largest header size in octets that may be compressed. Default value is 168. | |
| >>>TCP_SPACE | MD | | Integer (3..255) | Maximum CID value for TCP connections. Default value is 15. | |
| >>>NON_TCP_SPACE | MD | | Integer (3..65535) | Maximum CID value for non-TCP connections. Default value is 15. | |
| >>>EXPECT_REORDERING | MD | | Enumerated (reordering not expected, | Whether the algorithm shall reorder PDCP SDUs or not. | |

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| | | | reordering expected) | Default value is "reordering not expected". | |
| >>RFC 3095 | | | | Header compression according to IETF standard RFC 3095 | REL-4 |
| >>>Profiles | MP | 1 to <maxROHC-Profiles> | | Profiles supported by both compressor and decompressor in both UE and UTRAN. Profile 0 shall always be supported. | REL-4 |
| >>>>Profile instance | MP | | Integer(1.. 3) | 1 = 0x0001, 2 = 0x0002, 3 = 0x0003 (see [52]) | REL-4 |
| >>>Uplink | OP | | | Indicates the necessary information elements for Uplink. | REL-4 |
| >>>>CID inclusion info | MP | | Enumerated (PDCP header, RFC3095 packet format) | Configures which method shall be used to carry RFC3095 CID values. | REL-4 |
| >>>>Max_CID | MD | | Integer (1.. 16383) | Highest context ID number to be used by the UE compressor. Default value is 15. | REL-4 |
| >>>>Packet_Sizes_Allowed | OP | 1 to <maxROHC-PacketSizes> | | List of packet sizes that are allowed to be produced by the UE compressor. | REL-4 |
| >>>>>Packet size | MP | | Integer (2 .. 1500) | Packet size as defined in RFC 3095. | REL-4 |
| >>>Downlink | OP | | | Indicates the necessary information elements for Downlink. | REL-4 |
| >>>>CID inclusion info | MP | | Enumerated (PDCP header, RFC3095 packet format) | Configures which method shall be used to carry RFC3095 CID values. | REL-4 |
| >>>>Max_CID | MD | | Integer (1.. 16383) | Highest context ID number to be used by the UE decompressor. Default value is 15. | REL-4 |
| >>>>Reverse_Decompression_Depth | MD | | Integer (0..65535) | Determines whether reverse decompression should be used or not and the | REL-4 |

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| | | | | maximum number of packets that can be reverse decompressed by the UE decompressor. Default value is 0 (reverse decompression shall not be used). | |

| Condition | Explanation |
|---|---|
| *LosslessCriteria* | This IE is mandatory present if the IE "RLC mode" is "Acknowledged", the IE "In-sequence delivery " is "True" and the IE "SDU Discard Mode" is "No discard" and not needed otherwise. |
| *Lossless* | This IE is mandatory present if the IE "Support for lossless SRNS relocation or for lossless RLC PDU size change" Is TRUE, otherwise it is not needed. |

### 10.3.4.2a PDCP ROHC target mode

| Information Element/Group name | Need | Multi | Type and Reference | Semantics description | Version |
|---|---|---|---|---|---|
| Target Mode | MP | | Enumerated (O-mode, R-mode) | The UE shall only transit to the signalled mode for operation of ROHC as decribed in [36]. | REL-5 |

### 10.3.4.3 PDCP SN info

| Information Element/Group name | Need | Multi | Type and Reference | Semantics description |
|---|---|---|---|---|
| Receive PDCP sequence number | MP | | Integer(0..65 535) | The PDCP sequence number, which the sender of the message is expecting next to be received. |

### 10.3.4.4 Polling info

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Timer_poll_prohibit | OP | | Integer(10..550 by step of 10, 600..1000 by step of 50) | Minimum time between polls in ms |
| Timer_poll | OP | | Integer(10..550 by step of 10, 600..1000 by step of 50) | Time in ms. |
| Poll_PDU | OP | | Integer(1,2,4,8,16,32,64,128) | Number of PDUs, interval between pollings |
| Poll_SDU | OP | | Integer(1,4,16,64) | Number of SDUs, interval between pollings |
| Last transmission PDU poll | MP | | Boolean | TRUE indicates that poll is made at last PDU in transmission buffer |
| Last retransmission PDU poll | MP | | Boolean | TRUE indicates that poll is made at last PDU in retransmission buffer |
| Poll_Window | OP | | Integer(50,60,70,80,85,90,95,99) | Percentage of transmission window, threshold for polling |
| Timer_poll_periodic | OP | | Integer(100, 200, 300, 400, 500, 750, 1000, 2000) | Time in milliseconds Timer for periodic polling. |

### 10.3.4.5 Predefined configuration identity

This information element identifies a pre- defined radio parameter configuration.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Predefined radio configuration identity | MP | | Integer (0..15) | |

### 10.3.4.5a Predefined configuration status information

Another system may provide the UE with one or more predefined UTRAN configurations, comprising of radio bearer, transport channel and physical channel parameters. If requested, the UE shall indicate the configurations it has stored. The predefined configuration status information should include the following RRC information.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| **RB information elements** | | | | |
| Predefined configurations | | maxPredefConfigCount | | The list is in order of preconfiguration identity |
| >Predefined configuration value tag | OP | | Predefined configuration value tag 10.3.4.6 | The UE shall include the value tag if it has stored the concerned configuration |

| Multi Bound | Explanation |
|---|---|
| MaxPredefConfigCount | Maximum number of predefined configurations |

### 10.3.4.5b Predefined configuration status information compressed

Another system may provide the UE with one or more predefined UTRAN configurations, comprising of radio bearer, transport channel and physical channel parameters. If requested, the UE shall indicate the configurations it has stored. The compressed predefined configuration status information should include the following RRC information.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| Sets with different value tags | MP | | | | REL-5 |
| >Pre-defined configuration set with different value tags | MP | 1..2 | | | REL-5 |
| >>Start position | MD | | INTEGER (0..10) | Default value is 0, corresponding with the first pre-defined configuration. The pre-defined configuration where the consecutive sequence of pre-defined configurations begins. | REL-5 |
| >>Pre-defined configuration value tag list | MP | 6..<max PredefConfig> | Pre-defined configuration value tag 10.3.4.6 | Value Tags for each pre-defined configuration starting from the lowest. | REL-5 |
| Other Entries | OP | | | | REL-5 |
| >Pre-defined configuration list with variable size | MP | 1..<max PredefConfig> | | List of other pre-defined configurations not included within the Sets with different value tags, in consecutive order starting with the lowest. If there are stored pre-defined configurations positioned after a pre-defined configuration that is not stored, the UE shall indicate the not-stored pre-defined configuration by explicitly indicating it to be absent. If there are no stored pre-defined configurations positioned after a pre-defined configuration that is not stored, then the UE may totally omit these pre-defined configurations from the IE, i.e. reduce the size of the list to correspond to the last position that contained a stored pre-defined configuration. | REL-5 |
| >>Predefined configuration value tag | OP | | Predefined configuration value tag 10.3.4.6 | The UE shall include the value tag if it has stored the concerned configuration | REL-5 |

### 10.3.4.6 Predefined configuration value tag

This information element is used to identify different versions of a radio bearer configuration as may be used within one PLMN e.g. to support different UTRAN implementations.

| Information Element/Group name | Need | Multi | Type and Reference | Semantics description |
|---|---|---|---|---|
| Predefined configuration value tag | MP | | Integer(0..15) | |

### 10.3.4.7 Predefined RB configuration

This information element concerns a pre- defined configuration of radio bearer parameters

| Information Element/Group name | Need | Multi | Type and Reference | Semantics description |
|---|---|---|---|---|
| **UE information elements** | | | | |
| Re-establishment timer | MP | | Re-establishment timer 10.3.3.30 | Only one RAB supported |
| **Signalling radio bearer information** | | | | |
| Signalling RB information to setup List | MP | 1 to <maxSRBsetup> | | For each signalling radio bearer |
| >Signalling RB information to setup | MP | | Signalling RB information to setup 10.3.4.24 | |
| **RB information** | | | | Only one RAB supported |
| RB information to setup list | MP | 1 to <maxRBperRAB> | | |
| >RB information to setup | MP | | RB information to setup 10.3.4.20 | |

### 10.3.4.8 RAB info

This IE contains information used to uniquely identify a radio access bearer.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| RAB identity | MP | | RAB identity 10.3.1.14 | | |
| MBMS Session identity | CV-*Message* | | MBMS Session identity 10.3.9a.9 | | REL-6 |
| CN domain identity | MP | | CN domain identity 10.3.1.1 | | |
| NAS Synchronization Indicator | OP | | NAS Synchronization indicator 10.3.4.12 | | |
| Re-establishment timer | MP | | Re-establishment timer 10.3.3.30 | | |

| Condition | Explanation |
|---|---|
| *Message* | This IE is optionally present in the RADIO BEARER SETUP and the SRNS RELOCATION INFO messages and not needed otherwise. |

### 10.3.4.9 RAB info Post

This IE contains information used to uniquely identify a radio access bearer.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| RAB identity | MP | | RAB identity 10.3.1.14 | |
| CN domain identity | MP | | CN domain identity 10.3.1.1 | |
| NAS Synchronization Indicator | OP | | NAS Synchronization indicator 10.3.4.12 | |

### 10.3.4.10 RAB information for setup

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| RAB info | MP | | RAB info 10.3.4.8 | |
| RB information to setup list | MP | 1 to <maxRBperRAB> | | |
| >RB information to setup | MP | | RB information to setup 10.3.4.20 | |

### 10.3.4.11 RAB information to reconfigure

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| RAB identity | MP | | RAB Identity 10.3.1.14 | |
| CN domain identity | MP | | CN domain identity 10.3.1.1 | |
| NAS synchronization indicator | MP | | NAS Synchronization info 10.3.4.12 | |

### 10.3.4.12 NAS Synchronization indicator

A container for non-access stratum information to be transferred transparently through UTRAN.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| NAS Synchronization indicator | MP | | Bit string(4) | The first/leftmost bit of the bit string contains the most significant bit of the NAS Synchronization indicator. |

### 10.3.4.13 RB activation time info

This IE contains the time, in terms of RLC sequence numbers, when a certain configuration shall be activated, for a number of radio bearers.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Radio bearer activation time | MP | 1 to <maxRB> | | |
| >RB identity | MP | | RB identity 10.3.4.16 | |
| >RLC sequence number | MP | | Integer (0.. 4095) | RLC SN [16] .<br>Used for radio bearers mapped on RLC AM and UM |

### 10.3.4.14 RB COUNT-C MSB information

The MSB of the COUNT-C values of the radio bearer.

| Information Element/Group name | Needed | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| RB identity | MP | | RB identity 10.3.4.16 | |
| COUNT-C-MSB-uplink | MP | | Integer (0.. 2^25-1) | 25 MSBs from COUNT-C associated to this RB |
| COUNT-C-MSB-downlink | MP | | Integer (0.. 2^25-1) | 25 MSBs from COUNT-C associated to this RB |

### 10.3.4.15 RB COUNT-C information

The COUNT-C values of the radio bearer.

| Information Element/Group name | Needed | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| RB identity | MP | | RB identity 10.3.4.16 | |
| COUNT-C-uplink | MP | | Integer (0.. 2^32-1) | |
| COUNT-C-downlink | MP | | Integer (0.. 2^32-1) | |

### 10.3.4.16 RB identity

An identification number for the radio bearer affected by a certain message.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| RB identity | MP | | Integer(1..32 ) | Values 1-4 shall only be used for signalling radio bearers.<br>The IE value minus one shall be used as BEARER in the ciphering algorithm. |

### 10.3.4.17 RB information to be affected

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| RB identity | MP | | RB identity 10.3.4.16 | |
| RB mapping info | MP | | RB mapping info 10.3.4.21 | |

### 10.3.4.18 RB information to reconfigure

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| RB identity | MP | | RB identity 10.3.4.16 | |
| PDCP info | OP | | PDCP info 10.3.4.2 | |
| PDCP SN info | OP | | PDCP SN info 10.3.4.3 | PDCP sequence number info from the network. Present only in case of lossless SRNS relocation. |
| RLC info | OP | | RLC info 10.3.4.23 | |
| RB mapping info | OP | | RB mapping info 10.3.4.21 | |
| RB stop/continue | OP | | Enumerated( stop, continue) | |

### 10.3.4.19 RB information to release

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| RB identity | MP | | RB identity 10.3.4.16 | |

### 10.3.4.20 RB information to setup

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| RB identity | MP | | RB identity 10.3.4.16 | |
| PDCP info | OP | | PDCP info 10.3.4.2 | |
| CHOICE *RLC info type* | MP | | | |
| >RLC info | | | RLC info 10.3.4.23 | |
| >Same as RB | | | RB identity 10.3.4.16 | Identity of RB with exactly the same RLC info IE values |
| RB mapping info | MP | | RB mapping info 10.3.4.21 | |

NOTE: This information element is included within IE "Predefined RB configuration".

### 10.3.4.21 RB mapping info

A multiplexing option for each possible transport channel MAC-d flow or E-DCH MAC-d flow this RB can be multiplexed on.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| Information for each multiplexing option | MP | 1 to <maxRBMuxOptions> | | | |
| >RLC logical channel mapping indicator | CV-*UL-RLCLogicalChannels* | | Boolean | TRUE indicates that the first logical channel shall be used for data PDUs and the second logical channel shall be used for control PDUs.<br>FALSE indicates that control and data PDUs can be sent on either of the two logical channels.<br>This parameter is not used in this release and shall be set to TRUE. | |
| >Number of uplink RLC logical channels | CV-*UL-RLC info* | 1 to MaxLoCHperRLC | | 1 or 2 logical channels per RLC entity or radio bearer<br>RLC [16] | |
| >>CHOICE *Uplink transport channel type* | | | | | REL-6 |
| >>>DCH, RACH, USCH | | | | | REL-6 |
| >>>>Uplink transport channel type | MP | | Enumerated(DCH,RACH, USCH | USCH is TDD only | |
| >>>>ULTransport channel identity | CV-*UL-DCH/USCH* | | Transport channel identity 10.3.5.18 | This is the ID of a DCH or USCH (TDD only) that this RB could be mapped onto. | |
| >>>>Logical channel identity | OP | | Integer(1..15) | This parameter is used to distinguish logical channels multiplexed by MAC on a transport channel. | |
| >>>>CHOICE *RLC size list* | MP | | | The RLC sizes that are allowed for this logical channel. | |
| >>>>>All | | | Null | All RLC sizes listed in the *Transport Format Set*. 10.3.5.23 | |
| >>>>>Configured | | | Null | The RLC sizes configured for this logical channel in the *Transport Format Set*. 10.3.5.23 if present in this message or in the | |

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| | | | | previously stored configuration otherwise | |
| >>>>>Explicit List | | 1 to <maxTF> | | Lists the RLC sizes that are valid for the logical channel. | |
| >>>>>>RLC size index | MP | | Integer(1..maxTF) | The integer number is a reference to the *RLC size* which arrived at that position in the *Transport Format Set* 10.3.5.23 | |
| >>>E-DCH | | | | Note 4 | REL-6 |
| >>>>Logical channel identity | MP | | Integer(1..15) | This parameter is used to distinguish logical channels multiplexed by MAC on a transport channel | REL-6 |
| >>>>E-DCH MAC-d flow identity | MP | | E-DCH MAC-d flow identity 10.3.5.7e | | REL-6 |
| >>>>DDI | MP | | Integer (0..62) | If more than 1 UL RLC PDU size is configured for this RB, the different sizes will use subsequent DDI values starting from this DDI value.<br>Value '0x3F' is reserved | REL-6 |
| >>>>RLC PDU size list | MP | 1 to <maxRLCPDUsizePerLogChan> | | | REL-6 |
| >>>>>RLC PDU size | MP | | Integer(16..5000 by step of 8) | Unit is bits | REL-6 |
| >>>>Include in Scheduling Info | MP | | Boolean | Indicates whether or not this logical channel is to be considered when performing scheduling info reporting, as per [15] | REL-6 |
| >>MAC logical channel priority | MP | | Integer(1..8) | This is priority between a user's different RBs (or logical channels). [15] | |
| >Downlink RLC logical channel info | CV-*DL-RLC info* | | | | |
| >>Number of downlink RLC logical channels | *MD* | 1 to MaxLoCHperRLC | | 1 or 2 logical channels per RLC entity or radio bearer<br>RLC [16] | |

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| | | | | Default value is that parameter values for DL are exactly the same as for corresponding UL logical channel. In case two multiplexing options are specified for the UL, the first options shall be used as default for the DL. As regards to the IE "Channel type", rule is specified in 8.6.4.8. | |
| >>>Downlink transport channel type | MP | | Enumerated( DCH,FACH, DSCH,DCH+ DSCH | Note 3 | |
| | | | , HS-DSCH, DCH + HS-DSCH) | Note 4 | REL-5 |
| >>>DL DCH Transport channel identity | CV-*DL-DCH* | | Transport channel identity 10.3.5.18 | | |
| >>>DL DSCH Transport channel identity | CV-*DL-DSCH* | | Transport channel identity 10.3.5.18 | | |
| >>>DL HS-DSCH MAC-d flow identity | *CV-DL-HS-DSCH* | | MAC-d flow identity 10.3.5.7c | | REL-5 |
| >>>Logical channel identity | OP | | Integer(1..15 ) | 16 is reserved | |
| Note 3: The IE "Downlink transport channel type" values " DSCH' and 'DCH+DSCH " should not be used for FDD. If received the UE behaviour is unspecified. | | | | | |
| Note 4: If included in System Information Block Type 16, the values "HS-DSCH" and "DCH + HS-DSCH" do not apply for the IE "Downlink transport channel type". Furthermore, if included in System Information Block Type 16, the value "E-DCH' for the IE "Uplink transport channel type" does not apply. | | | | | |

| Condition | Explanation |
|---|---|
| *UL-RLC info* | If "CHOICE *Uplink RLC mode*" in the IE "RLC info" that applies for that RB (i.e. either the one stored or received in the same message for the RB for which the "RB mapping info" was received, or the one stored or received in the same message for the RB pointed at in the IE "Same as RB" in the IE "RB information to setup" stored or received in the same message) is present this IE is mandatory present. Otherwise the IE is not needed. |
| *DL-RLC info* | If "CHOICE *Downlink RLC mode*" in the IE "RLC info" that applies for that RB (i.e. either the one stored or received in the same message for the RB for which the "RB mapping info" was received, or the one stored or received in the same message for the RB pointed at in the IE "Same as RB" in the IE "RB information to setup" stored or received in the same message) is present this IE is mandatory present. Otherwise the IE is not needed. |

| | |
|---|---|
| *UL-RLCLogicalChannels* | If "Number of uplink RLC logical channels" in IE "RB mapping info" is 2, then this IE is mandatory present. Otherwise this IE is not needed. |
| *UL-DCH/USCH* | If IE "Uplink transport channel type" is equal to "DCH" or "USCH" (TDD only) this IE is mandatory present. Otherwise the IE is not needed. |
| *DL-DCH* | If IE "Downlink transport channel type" is equal to "DCH", "DCH+DSCH" or 'DCH + HS-DSCH' this IE is mandatory present. Otherwise the IE is not needed. |
| *DL-DSCH* | If IE "Downlink transport channel type" is equal to "DSCH" or "DCH+DSCH" this IE is mandatory present. Otherwise the IE is not needed. |
| *DL-HS-DSCH* | If IE "Downlink transport channel type" is equal to "HSDSCH" or 'DCH + HS-DSCH' this IE is mandatory present. Otherwise the IE is not needed. |

### 10.3.4.22 RB with PDCP information

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| RB identity | MP | | RB identity 10.3.4.16 | | |
| PDCP SN info | MP | | PDCP SN info 10.3.4.3 | PDCP sequence number info from the sender of the message for lossless SRNS relocation. | |
| | | | | PDCP sequence number info from the sender of the message for lossless SRNS relocation or for lossless DL RLC PDU size change. | REL-5 |

### 10.3.4.23 RLC info

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| CHOICE *Uplink RLC mode* | OP | | | Indicates if Acknowledged, Unacknowledged or Transparent mode RLC shall be used. | |
| >AM RLC | | | | | |
| >>Transmission RLC discard | MP | | Transmission RLC discard 10.3.4.25 | | |
| >>Transmission window size | MP | | Integer(1,8,16,32,64,128,256,512,768,1024,1536,2047,2560,3072,3584,4095) | Maximum number of RLC PUs sent without getting them acknowledged. This parameter is needed if acknowledged mode is used. UE shall also assume that the UTRAN receiver window is equal to this value. | |
| >>Timer_RST | MP | | Integer(50, 100, 150, 200, 250, 300, 350, 400, 450, 500, 550, 600, 700, 800, 900, 1000) | Elapsed time in milliseconds. It is used to trigger the retransmission of RESET PDU. | |
| >>Max_RST | MP | | Integer(1, 4, 6, 8, 12 16, | Defined in [16] | |

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| | | | 24, 32) | | |
| >>Polling info | OP | | Polling info 10.3.4.4 | | |
| >UM RLC | | | | | |
| >>Transmission RLC discard | OP | | Transmission RLC discard 10.3.4.25 | | |
| >TM RLC | | | | | |
| >>Transmission RLC discard | OP | | Transmission RLC discard 10.3.4.25 | | |
| >>Segmentation indication | MP | | Boolean | TRUE indicates that segmentation is performed. | |
| CHOICE *Downlink RLC mode* | OP | | | Indicates if Acknowledged, Unacknowledged or Transparent mode RLC shall be used | |
| >AM RLC | | | | | |
| >>DL RLC PDU size | MP | | Integer(16..5000 by step of 8) | Unit is bits | REL-5 |
| >>In-sequence delivery | MP | | Boolean | TRUE indicates that RLC shall preserve the order of higher layer PDUs when these are delivered.<br>FALSE indicates that receiving RLC entity could allow SDUs to be delivered to the higher layer in different order than submitted to RLC sublayer at the transmitting side. | |
| >>Receiving window size | MP | | Integer(1,8,16,32,64,128,256,512,768,1024,1536,2047,2560,3072,3584,4095) | Maximum number of RLC PUs allowed to be received. This parameter is needed if acknowledged mode is used. UE shall also assume that the UTRAN transmitter window is equal to this value | |
| >>Downlink RLC status Info | MP | | Downlink RLC status info 10.3.4.1 | | |
| >UM RLC | | | | | |
| >>DL UM RLC LI size | MP | | Integer(7, 15) | Size in bits to use for the downlink RLC UM LI. | REL-5 |
| >>DL Reception Window Size | CV-*Not-SIB16o* | | Integer(32, 48, 64, 80, 96, 112) | | REL-6 |
| >TM RLC | | | | | |
| >>Segmentation indication | MP | | Boolean | TRUE indicates that segmentation is performed. | |
| One sided RLC re-establishment | MP | | Boolean | TRUE indicates that only one side of the AM RLC entity is re-established. | REL-5 |
| Alternative E-bit interpretation | CV-*Not-SIB16o* | | Enumerated (true) | The absence of this IE implies: "normal E-bit interpretation". | REL-6 |

| Condition | Explanation |
|---|---|
| *Not-SIB16o* | If included in SYSTEM INFORMATION BLOCK TYPE 16, this IE is not needed. Otherwise the IE is optional |

NOTE: This information element is included within IE "Predefined RB configuration".

### 10.3.4.23a RLC info MBMS

The IE RLC info MBMS is used for point-to-multipoint radio bearers, featuring only the downlink RLC UMD.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| DL UM RLC LI size | MP | | Integer (7, 15) | Size in bits to use for the downlink RLC UM LI. | REL-6 |
| DL Duplication Avoidance and Reordering info | CV-*MTCH* | | UM Duplication Avoidance and Reordering info 10.3.4.26 | | REL-6 |
| DL Out of sequence delivery info | CV-*MCCH* | | UM Out of sequence delivery info 10.3.4.27 | | REL-6 |

| Condition | Explanation |
|---|---|
| *MTCH* | If the IE concerns MTCH, this IE is optional. Otherwise the IE is not needed. |
| *MCCH* | If the IE concerns MCCH, this IE is optional. Otherwise the IE is not needed. |

### 10.3.4.24 Signalling RB information to setup

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| RB identity | MD | | RB identity 10.3.4.16 | Default value is specified in subclause 8.6.4.1 |
| CHOICE *RLC info type* | MP | | | |
| >RLC info | | | RLC info 10.3.4.23 | |
| >Same as RB | | | RB identity 10.3.4.16 | Identity of RB with exactly the same RLC info IE values |
| RB mapping info | MP | | RB mapping info 10.3.4.21 | |

NOTE: This information element is included within IE "Predefined RB configuration".

### 10.3.4.25 Transmission RLC Discard

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| CHOICE *SDU Discard Mode* | MP | | | Different modes for discharge the RLC buffer on the transmitter side; "Timer based with explicit signalling", "Timer based without explicit signalling", "Discard after Max_DAT retransmissions" or "No_discard". For unacknowledged mode and transparent mode, only Timer based without explicit signalling is applicable. If |

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| | | | | "No_discard" is used, reset procedure shall be done after Max_DAT retransmissions |
| >Timer based explicit | | | | |
| >>Timer_MRW | MP | | Integer(50,60, 70, 80, 90, 100, 120, 140, 160, 180, 200, 300, 400, 500, 700, 900) | Elapsed time in milliseconds. It is used to trigger the retransmission of a STATUS PDU containing an MRW SUFI field |
| >>Timer_discard | MP | | Integer(100, 250, 500, 750, 1000, 1250, 1500, 1750, 2000, 2500, 3000, 3500, 4000, 4500, 5000, 7500) | Elapsed time in milliseconds before a SDU is discarded. |
| >>MaxMRW | MP | | Integer(1, 4, 6, 8, 12 16, 24, 32) | Defined in [16] |
| >Timer based no explicit | | | | |
| >>Timer_discard | MP | | Integer(10,20,30,40,50,60,70,80,90,100) | Elapsed time in milliseconds before a SDU is discarded. |
| >Max DAT retransmissions | | | | |
| >>Max_DAT | MP | | Integer(1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 15, 20, 25, 30, 35, 40) | Defined in [16] |
| >>Timer_MRW | MP | | Integer(50, 60, 70, 80, 90, 100, 120, 140, 160, 180, 200, 300, 400, 500, 700, 900) | Elapsed time in milliseconds. It is used to trigger the retransmission of a STATUS PDU containing an MRW SUFI field |
| >>MaxMRW | MP | | Integer(1, 4, 6, 8, 12 16, 24, 32) | Defined in [16] |
| >No discard | | | | |
| >>Max_DAT | MP | | Integer(1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 15, 20, 25, 30, 35, 40) | Defined in [16] |

| **CHOICE *SDU Discard Mode*** | **Condition under which the given *SDU Discard Mode* is chosen** |
|---|---|
| Timer based explicit | If the modes for discharge of the RLC buffer on the transmitter side is "Timer based with explicit signalling" |
| Timer based no explicit | If the modes for discharge of the RLC buffer on the transmitter side is "Timer based without explicit signalling"<br>For unacknowledged mode, only Timer based without explicit signalling is applicable. |
| Max DAT retransmissions | If the modes for discharge of the RLC buffer on the transmitter side is "Discard after Max_DAT |

| | |
|---|---|
| | retransmissions" |
| No discard | If the modes for discharge the of RLC buffer on the transmitter side is "Reset procedure shall be done after Max_DAT retransmissions" |

### 10.3.4.26 UM Duplication Avoidance and Reordering info

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| Timer_DAR | MP | | Integer(40, 80, 120, 160, 240, 320, 480, 640, 960, 1280, 1920, 2560, 3840, 5120) | Timer (in milliseconds) when PDUs are released to the upper layers even though there are outstanding PDUs with lower RLC SN values. | REL-6 |
| Window size DAR | MP | | Integer(4, 8, 16, 32, 40, 48, 56, 64) | | REL-6 |

### 10.3.4.27 UM Out of sequence delivery info

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| Timer_OSD | CV-*notMCCH* | | Integer (40, 80, 120, 160, 240, 320, 480, 640, 960, 1280, 1920, 2560, 3840, 5120) | | REL-6 |
| Window size OSD | MP | | Integer(8, 16, 32,40, 48, 56, 64) | | REL-6 |

NOTE: This timer used to flush the buffer is configured at RRC level and indicated via a local primitive.

| Condition | Explanation |
|---|---|
| *notMCCH* | If this concerns a logical channel other than MCCH then this IE is mandatory otherwise it is not needed. In the latter case Timer_OSD takes the value of the IE Modification Period as indicated within the IE MCCH configuration information |

## 10.3.5 Transport CH Information elements

### 10.3.5.1 Added or Reconfigured DL TrCH information

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| Downlink transport channel type | MP | | Enumerated( DCH,DSCH | Note 2 | |
| | | | ,HS-DSCH) | Note 1 | REL-5 |
| DL Transport channel identity | MP | | Transport channel identity 10.3.5.18 | | |

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| | CV-*not HS-DSCH* | | | | REL-5 |
| CHOICE *DL parameters* | | | | | |
| >Explicit | | | | | |
| >>TFS | MP | | Transport Format Set 10.3.5.23 | | |
| >SameAsUL | | | | | |
| >>Uplink transport channel type | MP | | Enumerated( DCH,USCH) | USCH is TDD only | |
| >>UL TrCH identity | MP | | Transport channel identity 10.3.5.18 | Same TFS applies as specified for indicated UL TrCH | |
| >HS-DSCH | | | | Note 1 | REL-5 |
| >>HARQ Info | OP | | HARQ info 10.3.5.7a | | REL-5 |
| >>Added or reconfigured MAC-d flow | OP | | Added or reconfigured MAC-d flow 10.3.5.1a | | REL-5 |
| DCH quality target | OP | | Quality target 10.3.5.10 | | |
| Note 1: The IE "Downlink transport channel type" value "HS-DSCH" is not used in the RRC CONNECTION SETUP message, nor is the CHOICE *DL parameters* = "HS-DSCH". | | | | | |
| Note 2: The IE "Downlink transport channel type" value " DSCH " should not be used for FDD. If received the UE behaviour is unspecified. | | | | | |

| Condition | Explanation |
|---|---|
| *NotHS-DSCH* | If the downlink transport channel type is DCH or DSCH then this IE is mandatory otherwise it is not needed. |

### 10.3.5.1a Added or reconfigured MAC-d flow

This IE is used in relation to the MAC-d flows mapped to the HS-DSCH transport channel.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| MAC-hs queue to add or reconfigure list | OP | <1 to maxQueue ID> | | | REL-5 |
| >MAC-hs queue Id | MP | | Integer(0..7) | The MAC-hs queue ID is unique across all MAC-d flows. | REL-5 |
| >MAC-d Flow Identity | MP | | MAC-d Flow Identity 10.3.5.7c | | REL-5 |
| >T1 | MP | | Integer(10, 20, 30, 40, 50, 60, 70, 80, 90, 100, 120, 140, 160, 200, 300, 400) | Timer (in milliseconds) when PDUs are released to the upper layers even though there are outstanding PDUs with lower TSN values. | REL-5 |
| >MAC-hs window size | MP | | Integer(4, 6, 8, 12, 16, 24, 32) | | REL-5 |
| >MAC-d PDU size Info | OP | <1 to max MACdPDU sizes> | | Mapping of the different MAC-d PDU sizes configured for the HS-DSCH to the MAC-d PDU size index in the MAC-hs header. | REL-5 |
| >>MAC-d PDU size | MP | | Integer (1..5000) | | REL-5 |
| >>MAC-d PDU size index | MP | | Integer(0..7) | | REL-5 |
| MAC-hs queue to delete list | OP | <1 to maxQueue ID> | | | REL-5 |
| >MAC-hs queue Id | MP | | Integer(0..7) | The MAC-hs queue ID is unique across all MAC-d flows. | REL-5 |

### 10.3.5.1b Added or reconfigured E-DCH MAC-d flow

This IE is used in relation to MAC-d flows mapped to the E-DCH transport channel.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| E-DCH MAC-d flow identity | MP | | E-DCH MAC-d flow identity 10.3.5.7e | | REL-6 |
| E-DCH MAC-d flow power offset | OP | | Integer(0..6) | Only allowed to be absent when already defined for this E-DCH MAC-d flow, unit is dB | REL-6 |
| E-DCH MAC-d flow maximum number of retransmissions | OP | | Integer (0..15) | Only allowed to be absent when already defined for this E-DCH MAC-d flow | REL-6 |
| E-DCH MAC-d flow multiplexing list | OP | | Bitstring (maxE-DCHMACdFlow) | Indicates, if this is the first MAC-d flow for which PDUs are placed in the MAC-e PDU, the other MAC-d flows from which MAC-d PDUs are allowed to be included in the same MAC-e PDU.<br>Bit 0 is for MAC-d flow 0, Bit 1 is for MAC-d flow 1, …<br>Value '1' for a bit means multiplexing is allowed. Bit 0 is the first/leftmost bit of the bit string.<br><br>NOTE: The bit that corresponds to the MAC-d flow itself is ignored. | REL-6 |
| CHOICE transmission grant type | OP | | | Only allowed to be absent when already defined for this E-DCH MAC-d flow | REL-6 |
| >Non-scheduled transmission grant info | | | | | REL-6 |
| >>Max MAC-e PDU contents size | MP | | Integer (1..19982) | | REL-6 |
| >>2ms non-scheduled transmission grant HARQ process allocation | MD | | Bitstring (8) | MAC-d PDUs for this MAC-d flow are only allowed to be transmitted in those processes for which the bit is set to '1'.<br>Bit 0 corresponds to HARQ process 0, bit 1 corresponds to HARQ process 1,…<br>Default value is: transmission in all | REL-6 |

| | | | | | |
|---|---|---|---|---|---|
| | | | | HARQ processes is allowed. Bit 0 is the first/leftmost bit of the bit string. | |
| >Scheduled transmission grant info | | | NULL | | REL-6 |

### 10.3.5.2 Added or Reconfigured UL TrCH information

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| Uplink transport channel type | MP | | Enumerated( DCH,USCH | USCH is TDD only | |
| | | | ,E-DCH) | Note 1 | REL-6 |
| UL Transport channel identity | MP | | Transport channel identity 10.3.5.18 | | |
| | *CV-NotE-DCH* | | | | REL-6 |
| CHOICE *UL parameters* | | | | | REL-6 |
| >DCH,USCH | | | | | REL-6 |
| >>TFS | MP | | Transport Format Set 10.3.5.23 | | |
| >E-DCH | | | | | REL-6 |
| >>E-DCH Transmission Time Interval | MP | | Integer(2,10) | Unit is ms. | REL-6 |
| >>HARQ info for E-DCH | MP | | 10.3.5.7d | | REL-6 |
| >>Added or reconfigured E-DCH MAC-d flow list | OP | <1 to maxE-DCHMACd Flow> | | | REL-6 |
| >>>Added or reconfigured E-DCH MAC-d flow | MP | | Added or reconfigured E-DCH MAC-d flow 10.3.5.1b | | REL-6 |
| Note 1: If included in System Information Block Type 16, the values "E-DCH" does not apply for the IE "Uplink transport channel type". | | | | | |

| Condition | Explanation |
|---|---|
| *NotE-DCH* | If the uplink transport channel type is DCH or USCH then this IE is mandatory otherwise it is not needed. |

NOTE: This information element is included within IE "Predefined RB configuration".

### 10.3.5.2a Additional Dynamic Transport Format Information for CCCH

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| RLC Size | MP | | Integer (16..4968 by step of 8) | Unit is bits | Rel-6 |
| Number of Transport blocks | MP | | Integer(1) | | Rel-6 |

### 10.3.5.2b Additional RACH TFCS for CCCH

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| Power offset Information | MP | | Power Offset | The actual TFCS | Rel-6 |

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| | | | Information 10.3.5.8 | is specified in 8.6.5.12a | |

### 10.3.5.3 Void

### 10.3.5.4 Deleted DL TrCH information

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| Downlink transport channel type | MP | | Enumerated( DCH,DSCH | Note 1 | |
| | | | ,HS-DSCH) | | REL-5 |
| DL Transport channel identity | MP | | Transport channel identity 10.3.5.18 | | |
| | CV-*notHS-DSCH* | | | | REL-5 |
| DL HS-DSCH MAC-d flow identity | CV-*HS-DSCH* | | MAC-d flow identity 10.3.5.7c | | REL-5 |
| Note 1: The IE "Downlink transport channel type" value " DSCH " should not be used for FDD. If received the UE behaviour is unspecified. | | | | | |

| Condition | Explanation |
|---|---|
| *NotHS-DSCH* | If the downlink transport channel type is DCH or DSCH then this IE is mandatory otherwise it is not needed. |
| *HS-DSCH* | If the downlink transport channel type is HSDSCH then this IE is mandatory otherwise it is not needed. |

### 10.3.5.5 Deleted UL TrCH information

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| Uplink transport channel type | MP | | Enumerated( DCH,USCH | USCH is TDD only | |
| | | | ,E-DCH) | | REL-6 |
| UL Transport channel identity | MP | | Transport channel identity 10.3.5.18 | | |
| | CV-NotE-DCH | | | | REL-6 |
| E-DCH MAC-d flow identity | CV-*E-DCH* | | E-DCH MAC-d flow identity 10.3.5.7e | | REL-6 |

| Condition | Explanation |
|---|---|
| *NotE-DCH* | If the uplink transport channel type is DCH or USCH then this IE is mandatory otherwise it is not needed. |
| *E-DCH* | If the uplink transport channel type is E-DCH then this IE is mandatory otherwise it is not needed. |

### 10.3.5.6 DL Transport channel information common for all transport channels

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| SCCPCH TFCS | OP | | Transport Format Combination Set 10.3.5.20 | This IE should not be included in this version of the protocol. | |
| CHOICE *mode* | MP | | | Although this IE is not always required, need is MP to align with ASN.1 | |
| | OP | | | | REL-4 |
| >FDD | | | | | |
| >>CHOICE *DL parameters* | OP | | | | |
| >>>Explicit | | | | | |
| >>>>DL DCH TFCS | MP | | Transport Format Combination Set 10.3.5.20 | Although this IE is not always required, need is MP to align with ASN.1 | |
| | OP | | | | REL-4 |
| >>>SameAsUL | | | | (no data)<br>See note 2 | |
| >TDD | | | | | |
| >>Individual DL CCTrCH information | OP | 1 to <maxCCTrCH> | | | |
| >>>DL TFCS Identity | MP | | Transport format combination set identity 10.3.5.21 | Identifies a special CCTrCH for shared or dedicated channels. | |
| >>>CHOICE *DL parameters* | MP | | | | |
| >>>>Independent | | | | | |
| >>>>>DL TFCS | MP | | Transport format combination set 10.3.5.20 | | |
| >>>>SameAsUL | | | | See note 2 | |
| >>>>>UL DCH TFCS Identity | MP | | Transport format combination set identity 10.3.5.21 | Same TFCS applies as specified for the indicated UL DCH TFCS identity except for information applicable for UL only | |

NOTE 1: This information element is included within IE "Predefined TrCh configuration".

NOTE 2: The UTRAN should only use the choice "SameAsUL" if the transport channel numbering, the number of TFs in the TFS of each transport channel, and the TFCS are identical in the uplink and downlink.

### 10.3.5.7 Void

### 10.3.5.7a HARQ Info

This IE is used in relation to the HS-DSCH transport channel.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| Number of Processes | MP | | Integer (1..8) | | REL-5 |
| CHOICE *Memory Partitioning* | MP | | | | REL-5 |
| >Implicit | | | | UE shall apply memory partitioning of equal size across all HARQ processes | REL-5 |
| >Explicit | | | | | REL-5 |
| >>Memory size | MP | <1 to MaxHProcesses> | | | REL-5 |
| >>>Process Memory size | MP | | Integer(800 .. 16000 by step of 800, 17600 .. 32000 by step of 1600, 36000 .. 80000 by step of 4000, 88000 .. 160000 by step of 8000, 176000 .. 304000 by step of 16000) | Maximum number of soft channel bits available in the virtual IR buffer [27] | REL-5 |

### 10.3.5.7b Void

### 10.3.5.7c MAC-d Flow Identity

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| MAC-d flow identity | MP | | Integer (0..7) | | REL-5 |

### 10.3.5.7d HARQ Info for E-DCH

This IE is used in relation to the E-DCH transport channel.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| HARQ RV Configuration | MP | | Enumerated (rv0, rvtable) | If 'rv0' is indicated, the UE shall only use E_DCH RV index 0.<br>If 'rvtable' is indicated, the UE shall use an RSN based RV index as specified in [27] | REL-6 |

### 10.3.5.7e E-DCH MAC-d Flow Identity

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| E-DCH MAC-d flow identity | MP | | Integer (0..maxE-DCHMACdFlow-1) | | REL-6 |

### 10.3.5.8 Power Offset Information

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| CHOICE *Gain Factors* | MP | | | |
| >Signalled Gain Factors | | | | |
| >>CHOICE *mode* | | | | |
| >>>FDD | | | | |
| >>>>Gain Factor $\beta_c$ | MP | | Integer (0.. 15) | For UL DPCCH or control part of PRACH |
| >>>TDD | | | | (no data) |
| >>Gain Factor $\beta_d$ | MP | | Integer (0..15) | For UL DPDCH or data part of PRACH and all uplink channels in TDD |
| >>Reference TFC ID | OP | | Integer (0..3) | If this TFC is a reference TFC, indicates the reference ID. |
| >Computed Gain Factors | | | | |
| >>Reference TFC ID | MP | | Integer (0.. 3) | Indicates the reference TFC Id of the TFC to be used to calculate the gain factors for this TFC. In case of using computed gain factors, at least one signalled gain factor is necessary for reference. |
| CHOICE *mode* | MP | | | |
| >FDD | | | | |
| >>Power offset $P_{p\text{-}m}$ | OP | | Integer(-5..10) | In dB. Power offset between the last transmitted preamble and the control part of the message (added to the preamble power to receive the power of the message control part )<br>Needed only for PRACH |
| >TDD | | | | (no data) |

| **CHOICE *Gain Factors*** | **Condition under which the way to signal the *Gain Factors* is chosen** |
|---|---|
| *Signalled Gain Factors* | The values for gain factors $\beta_c$ (only in FDD mode) and $\beta_d$ are signalled directly for a TFC. |
| *Computed Gain Factors* | The gain factors $\beta_c$ (only in FDD mode) and $\beta_d$ are computed for a TFC, based on the signalled settings for the associated reference TFC. |

### 10.3.5.9 Predefined TrCH configuration

This information element concerns a pre- defined configuration of transport channel parameters.

| Information Element/Group name | Need | Multi | Type and Reference | Semantics description |
|---|---|---|---|---|
| UL Transport channel information common for all transport channels | MP | | UL Transport channel information common for all transport channels 10.3.5.24 | |
| **Added or Reconfigured TrCH information** | | | | |
| Added or Reconfigured UL TrCH information | MP | 1 to <maxTrCH preconf> | | |
| >Added or Reconfigured UL TrCH information | MP | | Added or Reconfigured UL TrCH information 10.3.5.2 | |
| DL Transport channel information common for all transport channels | MP | | DL Transport channel information common for all transport channels 10.3.5.6 | |
| **Downlink transport channels** | | | | |
| Added or Reconfigured DL TrCH information | MP | 1 to <maxTrCH preconf> | | |
| >Added or Reconfigured DL TrCH information | MP | | Added or Reconfigured DL TrCH information 10.3.5.1 | |

### 10.3.5.10 Quality Target

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| BLER Quality value | MP | | Real(-6.3 ..0 by step of 0.1) | Signalled value is Log10(Transport channel BLER quality target) |

### 10.3.5.11 Semi-static Transport Format Information

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| Transmission time interval | MP | | Integer(10, 20, 40, 80, dynamic | In ms. The value dynamic is only used in TDD mode. For FDD DCH, the value '80' is applicable only when SF=512. | |

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| | | | 5) | 5 is only applicable for the RACH in 1.28 Mcps TDD | REL-4 |
| Type of channel coding | MP | | Enumerated( No coding, Convolutional, Turbo) | The option "No coding" is only valid for TDD. | |
| Coding Rate | CV-*Coding* | | Enumerated( 1/2, 1/3) | | |
| Rate matching attribute | MP | | Integer(1..hiRM) | | |
| CRC size | MP | | Integer(0, 8, 12, 16, 24) | in bits | |

| Condition | Explanation |
|---|---|
| *Coding* | This IE is mandatory present if IE "Type of channel coding" is "Convolutional" and not needed otherwise. |

### 10.3.5.12 Void

### 10.3.5.13 TFCS Explicit Configuration

| Information Element/Group name | Need | Multi | IE type and reference | Semantics description |
|---|---|---|---|---|
| CHOICE *TFCS representation* | MP | | | |
| >Complete reconfiguration | | | | |
| >>TFCS complete reconfiguration information | MP | | TFCS Reconfiguration/Addition information 10.3.5.15 | |
| >Addition | | | | |
| >>TFCS addition information | MP | | TFCS Reconfiguration/Addition information 10.3.5.15 | |
| >Removal | | | | |
| >>TFCS removal information | MP | | TFCS Removal Information 10.3.5.16 | |
| >Replace | | | | |
| >>TFCS removal information | MP | | TFCS Removal Information 10.3.5.16 | |
| >>TFCS addition information | MP | | TFCS Reconfiguration/Addition information 10.3.5.15 | |

### 10.3.5.14 Void

### 10.3.5.15 TFCS Reconfiguration/Addition Information

| Information Element/Group name | Need | Multi | IE type and reference | Semantics description |
|---|---|---|---|---|
| CHOICE *CTFC Size* | MP | | | |
| >2 bit CTFC | | | | |
| >>CTFC information | MP | 1 to <maxTFC> | | |
| >>>2bit CTFC | MP | | Integer(0..3) | |
| >>>Power offset Information | OP | | Power Offset Information 10.3.5.8 | Needed only for uplink physical channels. |
| >4 bit CTFC | | | | |
| >>CTFC information | MP | 1 to <maxTFC> | | |
| >>>4bit CTFC | MP | | Integer(0..15) | |
| >>>Power offset Information | OP | | Power Offset Information 10.3.5.8 | Needed only for uplink physical channels. |
| >6 bit CTFC | | | | |
| >>CTFC information | MP | 1 to <maxTFC> | | |
| >>>6 bit CTFC | MP | | Integer(0..63) | |
| >>>Power offset Information | OP | | Power Offset Information 10.3.5.8 | Needed only for uplink physical channels. |
| >8 bit CTFC | | | | |
| >>CTFC information | MP | 1 to <MaxTFC> | | |
| >>>8 bit CTFC | MP | | Integer(0..255) | |
| >>>Power offset Information | OP | | Power Offset Information 10.3.5.8 | Needed only for uplink physical channels. |
| >12 bit CTFC | | | | |
| >>CTFC information | MP | 1 to <maxTFC> | | |
| >>>12 bit CTFC | MP | | Integer(0..4095) | |
| >>>Power offset Information | OP | | Power Offset Information 10.3.5.8 | Needed only for uplink physical channels. |
| >16 bit CTFC | | | | |
| >>CTFC information | MP | 1 to <maxTFC> | | |
| >>>16 bit CTFC | MP | | Integer(0..65535) | |
| >>>Power offset Information | OP | | Power Offset Information 10.3.5.8 | Needed only for uplink physical channels. |
| >24 bit CTFC | | | | |
| >>CTFC information | MP | 1 to <MaxTFC> | | |
| >>>24 bit CTFC | MP | | Integer(0..16777215) | |
| >>>Power offset Information | OP | | Power Offset Information 10.3.5.8 | Needed only for uplink physical channels. |

### 10.3.5.16 TFCS Removal Information

| Information Element/Group name | Need | Multi | IE type and reference | Semantics description |
|---|---|---|---|---|
| Removal TFCI information | MP | 1 to <maxTFC> | | |
| >TFCI | MP | | Transport Format Combination (TFC) 10.3.5.19 | In TDD 0 is a reserved value |

### 10.3.5.17 Void

### 10.3.5.18 Transport channel identity

This information element is used to distinguish transport channels. Transport channels of different type (RACH, USCH, FACH/PCH, DSCH or DCH) have separate series of identities. This also holds for uplink and downlink transport channel identities (i.e. for DCH). Depending on in which context a transport channel identity *n* that is sent, it will have different meaning

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Transport channel identity | MP | | Integer(1..32 ) | |

### 10.3.5.19 Transport Format Combination (TFC)

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Transport format combination | MP | | Integer (0.. 1023) | |

### 10.3.5.20 Transport Format Combination Set

Indicates the allowed combinations of already defined Transport formats and the mapping between these allowed TFCs and the corresponding TFCI values.

For TDD, different coded composite transport channels have independent transport format combination sets and thus independent TFCI values.

| Information Element/Group name | Need | Multi | IE type and reference | Semantics description |
|---|---|---|---|---|
| TFCI Field 1 Information | MP | | TFCS explicit Configuratio n 10.3.5.13 | |

### 10.3.5.21 Transport Format Combination Set Identity

NOTE: Only for TDD.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| TFCS ID | MD | | Integer | Indicates the identity of every |

| | | | | |
|---|---|---|---|---|
| | | | (1...8) | TFCS within a UE. Default value is 1. |
| Shared Channel Indicator | MP | | Boolean | TRUE indicates the use of shared channels. Default is false. |

### 10.3.5.22 Transport Format Combination Subset

Indicates which Transport format combinations in the already defined Transport format combination set are allowed.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| CHOICE *Subset representation* | MP | | | |
| >Minimum allowed Transport format combination index | | | Transport format combination 10.3.5.19 | |
| >Allowed transport format combination list | | 1 to <maxTFC> | | |
| >>Allowed transport format combination | MP | | Transport format combination 10.3.5.19 | |
| >Non-allowed transport format combination list | | 1 to <maxTFC> | | |
| >>Non-allowed transport format combination | MP | | Transport format combination 10.3.5.19 | |
| >Restricted TrCH information | | 1 to <maxTrCH> | | |
| >>Uplink transport channel type | MP | | Enumerated( DCH, USCH) | USCH is TDD only |
| >>Restricted UL TrCH identity | MP | | Transport channel identity 10.3.5.18 | |
| >>Allowed TFIs | OP | 1 to <maxTF> | | |
| >>>Allowed TFI | MP | | Integer(0..31 ) | |
| >Full transport format combination set | | | | (No data) |

### 10.3.5.23 Transport Format Set

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| CHOICE *Transport channel type* | MP | | | | |
| >Dedicated transport channels | | | | The transport channel that is configured with this TFS is of type DCH | |
| >>Dynamic Transport Format Information | MP | 1 to <maxTF> | | | |
| >>>RLC Size | MP | | Integer(16..5 000 by step of 8) | Unit is bits | |
| >>>Number of TBs and TTI List | MP | 1 to <maxTF> | | Present for every valid number of TB's (and TTI) for this RLC Size. | |
| >>>>Transmission Time Interval | CV-*dynamicTT* | | Integer(10,2 0,40,80) | Unit is ms. | |

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| | *I* | | | | |
| >>>>Number of Transport blocks | MP | | Integer(0..512) | | |
| >>>CHOICE *Logical Channel List* | MP | | | The logical channels that are allowed to use this RLC Size | |
| >>>>ALL | | | Null | All logical channels mapped to this transport channel. | |
| >>>>Configured | | | Null | The logical channels configured to use this RLC size in the *RB mapping info*. 10.3.4.21 if present in this message or in the previously stored configuration otherwise | |
| >>>>Explicit List | | 1 to 15 | | Lists the logical channels that are allowed to use this RLC size. | |
| >>>>>RB Identity | MP | | RB identity 10.3.4.16 | | |
| >>>>>LogicalChannel | CH-*UL-RLCLogicalChannels* | | Integer(0..1) | Indicates the relevant UL logical channel for this RB. "0" corresponds to the first, "1" corresponds to the second UL logical channel configured for this RB in the IE "RB mapping info". | |
| >>Semi-static Transport Format Information | MP | | Semi-static Transport Format Information 10.3.5.11 | | |
| >Common transport channels | | | | The transport channel that is configured with this TFS is of a type not equal to DCH | |
| >>Dynamic Transport Format Information | MP | 1 to <maxTF> | | Note | |
| >>>RLC Size | MP | | Integer(16..5000 by step of 8) | Unit is bits | |
| >>>Number of TBs and TTI List | MP | 1 to <maxTF> | | Present for every valid number of TB's (and TTI) for this RLC Size. | |
| >>>>Number of Transport blocks | MP | | Integer(0..512) | | |
| >>>>CHOICE *mode* | MP | | | | |
| >>>>>FDD | | | | (no data) | |
| >>>>>TDD | | | | | |
| >>>>>>Transmission Time Interval | CV-*dynamicTTI* | | Integer(10,20,40,80) | Unit is ms. | |
| >>>CHOICE *Logical Channel List* | MP | | | The logical channels that are allowed to use this RLC Size. | |
| >>>>ALL | | | Null | All logical channels mapped to this transport channel. | |
| >>>>Configured | | | Null | The logical channels configured to use this RLC size in the *RB mapping info*. 10.3.4.21 if present in this message or in the previously stored configuration otherwise | |
| >>>>Explicit List | | 1 to 15 | | Lists the logical channels that are allowed to use this RLC size. | |
| >>>>>RB Identity | MP | | RB identity | | |

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| | | | 10.3.4.16 | | |
| >>>>>LogicalChannel | CV-*UL-RLCLogicalChannels* | | Integer(0..1) | Indicates the relevant UL logical channel for this RB. "0" corresponds to the first, "1" corresponds to the second UL logical channel configured for this RB in the IE "RB mapping info". | |
| >>Semi-static Transport Format Information | MP | | Semi-static Transport Format Information 10.3.5.11 | | |

| Condition | Explanation |
|---|---|
| *dynamicTTI* | This IE is mandatory present if dynamic TTI usage is indicated in IE Transmission Time Interval in Semi-static Transport Format Information. Otherwise it is not needed. |
| *UL-RLCLogicalChannels* | If "Number of uplink RLC logical channels" in IE "RB mapping info" in this message is 2 or the IE "RB mapping info" is not present in this message and 2 UL logical channels are configured for this RB, then this IE is mandatory present. Otherwise this IE is not needed. |

### 10.3.5.24 UL Transport channel information common for all transport channels

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| PRACH TFCS | OP | | Transport format combination set 10.3.5.20 | This IE should not be included in this version of the protocol. | |
| CHOICE *mode* | OP | | | | |
| >FDD | | | | | |

| | | | | | |
|---|---|---|---|---|---|
| >>TFC subset | MD | | Transport Format Combination Subset 10.3.5.22 | Default value is the complete existing set of transport format combinations | |
| >>UL DCH TFCS | MP | | Transport format combination set 10.3.5.20 | | |
| >TDD | | | | | |
| >>Individual UL CCTrCH information | OP | 1 to <maxCCTrCH> | | | |
| >>>UL TFCS Identity | MP | | Transport format combination set identity 10.3.5.21 | Identifies a special CCTrCH for shared or dedicated channels. | |
| >>>UL TFCS | MP | | Transport format combination set 10.3.5.20 | | |
| >>>TFC subset | MD | | Transport Format Combination Subset 10.3.5.22 | Default value is the complete existing set of transport format combinations | |
| TFC subset list | OP | 1 to <maxTFCsub> | | The maximum number of elements in the TFC subset list is 8. | REL-4 |
| >CHOICE *mode* | MP | | | | REL-4 |
| >>FDD | | | | (no data) | REL-4 |
| >>TDD | | | | | REL-4 |
| >>>TFCS Id | OP | | Transport Format Combination Set Identity 10.3.5.21 | | REL-4 |
| >TFC subset | MD | | Transport Format Combination Subset 10.3.5.22 | | REL-4 |

NOTE: This information element is included within IE "Predefined TrCh configuration".

## 10.3.6 Physical CH Information elements

### 10.3.6.1 AC-to-ASC mapping

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| AC-to-ASC mapping table | MP | maxASCmap | | |
| >AC-to-ASC mapping | MP | | Integer(0…7) | Mapping of Access Classes to Access Service Classes (see subclause 8.5.13.) |

### 10.3.6.2 AICH Info

NOTE: Only for FDD.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Channelisation code | MP | | Integer(0..255) | SF is fixed and equal to 256 |
| STTD indicator | MP | | STTD Indicator 10.3.6.78 | |
| AICH transmission timing | MP | | Enumerated (0, 1) | See parameter AICH_Transmission_Timing in [26] |

### 10.3.6.3 AICH Power offset

NOTE: Only for FDD.

This parameter is used to indicate the power level of AICH, AP-AICH and CD/CA-ICH channels. This is the power per transmitted Acquisition Indicator, AP Acquisition Indicator or CD/CA Indicator minus power of the Primary CPICH.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| AICH Power offset | MP | | Integer(-22..+5) | Offset in dB |

### 10.3.6.4 Allocation period info

NOTE: Only for TDD.

Parameters used by UE to determine period of shared channel allocation.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Allocation Activation Time | MP | | Integer (0..255) | Start the allocation period at the given CFN. |
| Allocation Duration | MP | | Integer (1..256) | Total number of frames for the allocation period. |

### 10.3.6.5 Alpha

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Alpha Value | MP | | Enumerated( 0, 1/8, 2/8, 3/8, 4/8, 5/8, 6/8, 7/8, 1) | |

### 10.3.6.6 ASC setting

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| CHOICE *mode* | MP | | | | |
| >FDD | | | | | |
| >>Available signature Start Index | MP | | Integer(0..15) | | |
| >>Available signature End Index | MP | | Integer(0..15) | | |
| >>Assigned Sub-Channel | MP | | Bit string(4) | This IE defines | |

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| Number | | | | the subchannel assignment as specified in 8.6.6.29. The first/leftmost bit of the bit string contains the most significant bit of the Assigned Sub-Channel Number.. | |
| >TDD | | | | | |
| >>CHOICE *TDD option* | MP | | | | REL-4 |
| >>>3.84 Mcps TDD | | | | | REL-4 |
| >>>>Available Channelisation codes indices | MD | | Bit string(8) | Each bit indicates availability of a channelisation code index, where the channelisation code indices are numbered "channelisation code index 0" to "channelisation code index 7". The value 1 of a bit indicates that the channelisation code index is available for the ASC this IE is associated to. The value 0 of a bit indicates that the channelisation code index is not available for the ASC this IE is associated to. Default is that all channelisation codes defined in PRACH Info are available. | |
| >>>7.68 Mcps TDD | | | | | REL-7 |
| >>>>Available Channelisation codes indices | MD | | Bit string(16) | Each bit indicates availability of a channelisation code index, where the channelisation code indices are numbered "channelisation code index 0" to "channelisation code index 15". The value 1 of a bit indicates that the channelisation code index is available for the ASC this IE is associated to. The value 0 of a bit indicates that the channelisation code index is not | |

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| | | | | available for the ASC this IE is associated to. Default is that all channelisation codes defined in PRACH Info are available. | |
| >>>1.28 Mcps TDD | | | | | REL-4 |
| >>>>Available SYNC_UL codes indices | MD | | Bit string(8) | Each bit indicates availability of a SYNC_UL code index, where the SYNC_UL code indices are numbered "SYNC_UL code index 0" to "SYNC_UL code index 7". The value 1 of a bit indicates that the SYNC_UL code index is available for the ASC this IE is associated to. The value 0 of a bit indicates that the SYNC_UL code index is not available for the ASC this IE is associated to. Default is that all SYNC_UL codes defined in SYNC_UL Info are available. | REL-4 |
| >>CHOICE *subchannel size* | MP | | | | |
| >>>Size1 | | | | | |
| >>>>Available Subchannels | MP | | null | Indicates that all Subchannels are available | |
| >>>Size2 | | | | | |
| >>>>Available Subchannels | MD | | Bit string (2) | NOTE | |
| >>>Size4 | | | | | |
| >>>>Available Subchannels | MD | | Bit string (4) | NOTE | |
| >>>Size8 | | | | | |
| >>>>Available Subchannels | MD | | Bit string (8) | NOTE | |
| >>>Size16 | | | | | |
| >>>>Available Subchannels | MD | | Bit string (16) | NOTE | |

NOTE: Each bit indicates availability of a subchannel, where the subchannels are numbered subchannel 0, subchannel 1 etc. The value 1 of a bit indicates that the subchannel is available for the ASC this IE is associated with. The value 0 of a bit indicates that the subchannel is not available for the ASC this IE is associated with. Default value of the IE is that all subchannels within the size are available for the ASC this IE is associated with.

### 10.3.6.7 Void

### 10.3.6.8 CCTrCH power control info

Parameters used by UE to set the SIR target value for uplink open loop power control in TDD.

| Information Element/Group name | Need | Multi | Type and Reference | Semantics description |
|---|---|---|---|---|
| TFCS Identity | OP | | Transport Format Combination Set Identity 10.3.5.21 | TFCS Identity of this CCTrCH. Default value is 1. |
| Uplink DPCH power control info | MP | | Uplink DPCH power control info 10.3.6.91 | |

### 10.3.6.8a Cell and Channel Identity info

NOTE: Only for TDD.

| Information Element/Group name | Need | Multi | Type and Reference | Semantics description |
|---|---|---|---|---|
| Burst type | MP | | Enumerated (Type1, Type2) | Identifies the channel in combination with the Midamble shift and slot number. It is not used in 1.28 Mcps TDD and may be set to either value. This IE should be ignored by the receiver. |
| Midamble Shift | MP | | Integer (0…15) | |
| Time Slot | OP | | Timeslot number 10.3.6.84 | This IE is present only if no IPDL scheme is configured in the reference cell. Otherwise the slot is defined by the IPDL configuration. |
| Cell parameters ID | MP | | Cell parameters ID 10.3.6.9 | Identifies the cell |

### 10.3.6.9 Cell parameters Id

| Information Element/Group name | Need | Multi | Type and Reference | Semantics description |
|---|---|---|---|---|
| Cell parameter Id | MP | | Integer(0..127) | |

### 10.3.6.10 Common timeslot info

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| 2nd interleaving mode | MD | | Enumerated( Frame, Timeslot) | Frame timeslot related interleaving. Default value is "Frame" |
| TFCI coding | MD | | Integer(4,8,16,32) | Describes the amount of bits for the TFCI bits code word as described in [31]. Defaults is no TFCI bit: In case of 8 PSK in 1.28Mcps TDD: 4 corresponds to 6 TFCI code word bits. |

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| | | | | 8 corresponds to 12 TFCI code word bits.<br>16 corresponds to 24 TFCI code word bits.<br>32 corresponds to 48 TFCI code word bits. |
| Puncturing limit | MP | | Real(0.40..1.0 by step of 0.04) | |
| Repetition period | MD | | Integer(1, 2,4,8,16,32,64) | Default is continuous allocation. Value 1 indicate continuous |
| Repetition length | MP | | Integer(1.. Repetition period –1 ) | NOTE: This is empty if repetition period is set to 1. |

### 10.3.6.11 Constant value

NOTE: Only for FDD.

This constant value is used by the UE to calculate the initial output power on PRACH according to the Open loop power control procedure.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Constant value | MP | | Integer (-35..-10) | In dB |

### 10.3.6.11a Constant value TDD

NOTE: Only for 3.84 Mcps TDD and 7.68 Mcps TDD.

3.84 Mcps TDD and 7.68 Mcps TDD constant values are used for open loop power control of PRACH, USCH, HS-SICH and UL DPCH as defined in subclause 8.5.7.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| TDD Constant value | MP | | Integer (-35..+10) | In dB |

### 10.3.6.12 Void

### 10.3.6.13 Void

### 10.3.6.14 Void

### 10.3.6.15 Void

### 10.3.6.16 Default DPCH Offset Value

Indicates the default offset value within interleaving size at a resolution of 512chip (1/5 slot) in FDD and a resolution of one frame in TDD to offset CFN in the UE. This is used to distribute discontinuous transmission periods in time and also to distribute NodeB-RNC transmission traffics in time. Even though the CFN is offset by DOFF, the start timing of the interleaving will be the timing that "CFN mod (interleaving size)"=0 (e.g. interleaving size: 2,4,8) in both UE and SRNC.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| CHOICE *mode* | | | | |
| >FDD | | | | |
| >>Default DPCH Offset Value (DOFF) | MP | | Integer (0..306688 by step of 512) | Number of chips=. 0 to 599 time 512 chips, see [10]. |
| >TDD | | | | |
| >>Default DPCH Offset Value (DOFF) | MP | | Integer(0..7) | Number of frames; See [10] |

### 10.3.6.17 Downlink channelisation codes

NOTE: Only for 1.28 Mcps TDD and 3.84 Mcps TDD.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| CHOICE *codes representation* | MP | | | |
| >Consecutive codes | | | | |
| >>First channelisation code | MP | | Enumerated ( (16/1)...(16/16)) | If a TFCI exists in this timeslot, it is mapped to the channelisation code as defined in [30]. |
| >>Last channelisation code | MP | | Enumerated ( (16/1)...(16/16)) | If this is the same as First channelisation code, only one code is used by the physical layer. |
| >Bitmap | | | | |
| >>Channelisation codes bitmap | MP | | Bit string(16) | Each bit indicates the availability of a channelisation code for SF16, where the channelisation codes are numbered as channelisation code 1 (SF16) to channelisation code 16 (SF16). (For SF 16, a 1 in the bitmap means that the corresponding code is used, a 0 means that the corresponding code is not used.) If all bits are set to zero, SF 1 shall be used. |

### 10.3.6.17a Downlink channelisation codes VHCR

NOTE: Only for 7.68 Mcps TDD VHCR

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| CHOICE *codes representation* | MP | | | |
| >Consecutive codes | | | | |
| >>First channelisation code | MP | | Enumerated ( (32/1)...(32/32)) | If a TFCI exists in this timeslot, it is mapped to the channelisation code as defined in [30]. |
| >>Last channelisation code | MP | | Enumerated ( (32/1)...(32/32)) | If this is the same as First channelisation code, only one code is used by the physical layer. |
| >Bitmap | | | | |
| >>Channelisation codes bitmap | MP | | Bit string(32) | Each bit indicates the availability of a channelisation code for SF32, where the channelisation codes are numbered as channelisation code 1 (SF32) to channelisation code 32 (SF32). (For SF 32, a 1 in the bitmap means that the corresponding code is used, a 0 means that the corresponding code is not used.)<br>If all bits are set to zero, SF 1 shall be used. |

### 10.3.6.18 Downlink DPCH info common for all RL

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| Timing Indication | MP | | Enumerated(Initialise, Maintain) | NOTE | |
| Timing maintained Synchronization indicator | CV-*Synch* | | Enumerated (false) | FALSE indicates that no synchronisation procedure shall be performed for timing maintained inter-frequency hard handover [29]. Absence of this element means that the synchronization procedure A shall be used. | REL-6 |
| Downlink DPCH power control information | OP | | Downlink DPCH power control information 10.3.6.23 | | |
| MAC-d HFN initial value | CV-*Message* | | Bit string(24) | | REL-4 |
| CHOICE *mode* | MP | | | | |
| >FDD | | | | | |
| >>Power offset $P_{Pilot-DPDCH}$ | MP | | Integer(0..24) | Power offset equals $P_{Pilot} - P_{DPDCH}$, range 0..6 dB, in steps of 0.25 dB | |
| >>Downlink rate matching restriction | OP | | Downlink rate | If this IE is set to "absent", no Transport | |

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| information | | | matching restriction information 10.3.6.31 | CH is restricted in TFI. | |
| >>Spreading factor | MP | | Integer(4, 8, 16, 32, 64, 128, 256, 512) | | |
| >>Fixed or Flexible Position | MP | | Enumerated (Fixed, Flexible) | | |
| >>TFCI existence | MP | | Boolean | TRUE indicates that TFCI is used. When spreading factor is less than or equal to 64, FALSE indicates that TFCI is not used and therefore DTX is used in the TFCI field. | |
| >>CHOICE *SF* | MP | | | | |
| >>>SF = 256 | | | | | |
| >>>>Number of bits for Pilot bits | MP | | Integer (2,4,8) | In bits | |
| >>>SF = 128 | | | | | |
| >>>>Number of bits for Pilot bits | MP | | Integer(4, 8) | In bits | |
| >>>Otherwise | | | | (no data). In ASN.1 choice "Otherwise" is not explicitly available as all values are available, it is implied by the use of any value other than 128 or 256. | |
| >TDD | | | | (no data) | |

| CHOICE *SF* | Condition under which the given *SF* is chosen |
|---|---|
| SF=128 | "Spreading factor" is set to 128 |
| SF=256 | "Spreading factor" is set to 256 |
| Otherwise | "Spreading factor" is set to a value distinct from 128 and 256 |

| Condition | Explanation |
|---|---|
| *Message* | This IE is not needed if the IE "Downlink DPCH info common for all RL" is included in RRC CONNECTION SETUP or HANDOVER TO UTRAN COMMAND messages. Otherwise it is optional. |
| *Synch* | The IE is not needed in the CELL UPDATE CONFIRM, HANDOVER TO UTRAN COMMAND and the RRC CONNECTION SETUP messages or if the IE "Timing Indication" is set to "Initialise" or if the IE 'Frequency Info' is not included. Otherwise, it is optional. |

NOTE: Within the HANDOVER TO UTRAN COMMAND message, only value "initialise" is applicable.

### 10.3.6.19 Downlink DPCH info common for all RL Post

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Downlink DPCH power control information | OP | | Downlink DPCH power control information 10.3.6.23 | |

### 10.3.6.20 Downlink DPCH info common for all RL Pre

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| CHOICE *mode* | MP | | | |
| >FDD | | | | |
| >>Spreading factor | MP | | Integer(4, 8, 16, 32, 64, 128, 256, 512) | Defined in CHOICE SF512-Andpilot with "number of its for pilot bits" in ASN.1 |
| >>Fixed or Flexible Position | MP | | Enumerated (Fixed, Flexible) | |
| >>TFCI existence | MP | | Boolean | TRUE indicates that TFCI is used. When spreading factor is less than or equal to 64, FALSE indicates that TFCI is not used and therefore DTX is used in the TFCI field. |
| >>CHOICE *SF* | MP | | | |
| >>>SF = 256 | | | | |
| >>>>Number of bits for Pilot bits | MP | | Integer (2,4,8) | In bits |
| >>>SF = 128 | | | | |
| >>>>Number of bits for Pilot bits | MP | | Integer(4,8) | In bits |
| >>>Otherwise | | | | (no data) |
| >TDD | | | | |
| >>Common timeslot info | MP | | Common Timeslot Info 10.3.6.10 | |

| CHOICE *SF* | Condition under which the given *SF* is chosen |
|---|---|
| SF=128 | "Spreading factor" is set to 128 |
| SF=256 | "Spreading factor" is set to 256 |
| Otherwise | "Spreading factor" is set to a value distinct from 128 and 256 |

### 10.3.6.21 Downlink DPCH info for each RL

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| CHOICE *mode* | MP | | | | |
| >FDD | | | | | |
| >>Primary CPICH usage for channel estimation | MP | | Primary CPICH usage for channel estimation 10.3.6.62 | | |
| >>DPCH frame offset | MP | | Integer(0.. 38144 by | Offset (in number of chips) between the | |

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| | | | step of 256) | beginning of the P-CCPCH frame and the beginning of the DPCH frame<br>This is called $\tau_{DPCH,n}$ in [26] | |
| >>Secondary CPICH info | OP | | Secondary CPICH info 10.3.6.73 | | |
| >>DL channelisation code | MP | 1 to <maxDPCH-DLchan> | | For the purpose of physical channel mapping [27] the DPCHs are numbered, starting from DPCH number 1, according to the order that they are contained in this IE. | |
| >>>Secondary scrambling code | MD | | Secondary scrambling code 10.3.6.74 | Default is the same scrambling code as for the Primary CPICH | |
| >>>Spreading factor | MP | | Integer(4, 8, 16, 32, 64, 128, 256, 512) | Defined in CHOICE SF512-AndCodenumber with "code number" in ASN.1 | |
| >>>Code number | MP | | Integer(0.. Spreading factor - 1) | | |
| >>>Scrambling code change | CH-*SF/2* | | Enumerated (code change, no code change) | Indicates whether the alternative scrambling code is used for compressed mode method 'SF/2'. | |
| >>TPC combination index | MP | | TPC combination index 10.3.6.85 | | |
| >>Power offset $P_{TPC-DPDCH}$ | OP | | Integer (0..24) | Power offset equals $P_{TPC}$- $P_{DPDCH}$, range 0..6 dB, in steps of 0.25 dB | REL-5 |
| >>Closed loop timing adjustment mode | CH-*TxDiversity Mode* | | Integer(1, 2) | It is present if Tx Diversity is used in the radio link. | |
| >1.28 Mcps TDD or 3.84 Mcps TDD | | | | | |
| >>DL CCTrCh List | OP | 1..<maxCCTrCH> | | DL physical channels to establish or reconfigure list. | |
| >>>TFCS ID | MD | | Integer(1.. 8) | Identity of this CCTrCh. Default value is 1 | |
| >>>Time info | MP | | Time Info 10.3.6.83 | | |
| >>>Common timeslot info | MD | | Common Timeslot Info 10.3.6.10 | Default is the current Common timeslot info | |
| >>>Downlink DPCH timeslots and codes | MD | | Downlink Timeslots and Codes 10.3.6.32 | Default is to use the old timeslots and codes. | |
| >>>UL CCTrCH TPC List | MD | 0..<maxCCTrCH | | UL CCTrCH identities for TPC commands | |

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| | | > | | associated with this DL CCTrCH. Default is previous list or all defined UL CCTrCHs. This list is not required for 1.28 Mcps TDD and is to be ignored by the UE. | |
| >>>>UL TPC TFCS Identity | MP | | Transport Format Combination Set Identity 10.3.5.21 | | |
| >>DL CCTrCH List to Remove | OP | 1..<max CCTrCH> | | DL physical channels to remove list. | |
| >>>TFCS ID | MP | | Integer(1..8) | | |
| >7.68 Mcps TDD | | | | | REL-7 |
| >>DL CCTrCh List | OP | 1..<max CCTrCH> | | DL physical channels to establish or reconfigure list. | |
| >>>TFCS ID | MD | | Integer(1..8) | Identity of this CCTrCh. Default value is 1 | |
| >>>Time info | MP | | Time Info 10.3.6.83 | | |
| >>>Common timeslot info | MD | | Common Timeslot Info 10.3.6.10 | Default is the current Common timeslot info | |
| >>>Downlink DPCH timeslots and codes VHCR | MD | | Downlink Timeslots and Codes VHCR 10.3.6.32a | Default is to use the old timeslots and codes. | |
| >>>UL CCTrCH TPC List | MD | 0..<max CCTrCH> | | UL CCTrCH identities for TPC commands associated with this DL CCTrCH. Default is previous list or all defined UL CCTrCHs. This list is not required for 1.28 Mcps TDD and is to be ignored by the UE. | |
| >>>>UL TPC TFCS Identity | MP | | Transport Format Combination Set Identity 10.3.5.21 | | |
| >>DL CCTrCH List to Remove | OP | 1..<max CCTrCH> | | DL physical channels to remove list. | |
| >>>TFCS ID | MP | | Integer(1..8) | | |

| Condition | Explanation |
|---|---|
| *SF/2* | The information element is mandatory present if the UE has a compressed mode pattern sequence configured in variable TGPS_IDENTITY or included in the message including IE "Downlink DPCH info for each RL", which is using compressed mode method "SF/2". Otherwise the IE is not needed. |
| *TxDiversity Mode* | This IE is mandatory present if any TX Diversity Mode is used on the radio link, i.e. if STTD or "closed loop mode 1" is used on the radio link. Otherwise the IE is not needed. |

### 10.3.6.22 Downlink DPCH info for each RL Post

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| CHOICE *mode* | MP | | | |
| >FDD | | | | |
| >>Primary CPICH usage for channel estimation | MP | | Primary CPICH usage for channel estimation 10.3.6.62 | |
| >>Secondary scrambling code | MD | | Secondary scrambling code 10.3.6.74 | Default is the same scrambling code as for the Primary CPICH |
| >>CHOICE *Spreading factor* | MP | | Integer(4, 8, 16, 32, 64, 128, 256, 512) | Defined in CHOICE SF512-AndCodenumber with "code number" in ASN.1 |
| >>Code number | MP | | Integer(0.. Spreading factor - 1) | |
| >>Scrambling code change | CH-*SF/2* | | Enumerated (code change, no code change) | Indicates whether the alternative scrambling code is used for compressed mode method 'SF/2'. |
| >>TPC combination index | MP | | TPC combination index 10.3.6.85 | |
| >1.28 Mcps TDD or 3.84 Mcps TDD | | | | |
| >>Downlink DPCH timeslots and codes | MP | | Downlink Timeslots and Codes 10.3.6.32 | |
| >7.68 Mcps TDD | | | | REL-7 |
| >>Downlink DPCH timeslots and codes VHCR | MP | | Downlink Timeslots and Codes VHCR 10.3.6.32a | REL-7 |

| Condition | Explanation |
|---|---|
| *SF/2* | The information element is mandatory present if the UE has a compressed mode pattern sequence configured in variable TGPS_IDENTITY or included in the message including IE "Downlink DPCH info for each RL Post", which is using compressed mode method "SF/2". Otherwise the IE is not needed. |

### 10.3.6.23 Downlink DPCH power control information

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| CHOICE *mode* | MP | | | |
| >FDD | | | | |
| >>DPC Mode | MP | | Enumerated (Single TPC, TPC triplet in soft) | "Single TPC" is DPC_Mode=0 and "TPC triplet in soft" is DPC_mode=1 in [29]. |
| >TDD | | | | |
| >>TPC Step Size | OP | | Integer (1, 2, 3) | In dB |

### 10.3.6.23oa Downlink F-DPCH info common for all RL

NOTE: For FDD only.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| Timing Indication | MP | | Enumerated (Initialise, Maintain) | | REL-6 |
| Timing maintained Synchronization indicator | CV-*Synch* | | Enumerated (false) | FALSE indicates that no synchronisation procedure shall be performed for timing maintained intra- and inter-frequency hard handover [29]. Absence of this element means that the synchronization procedure A shall be used. | REL-6 |
| Downlink F-DPCH power control information | OP | | Downlink DPCH power control information 10.3.6.23 | | REL-6 |
| TPC command error rate target | OP | | Real (0.01..0.1 by step of 0.01) | | REL-6 |

| Condition | Explanation |
|---|---|
| *Synch* | The IE is not needed in the CELL UPDATE CONFIRM, HANDOVER TO UTRAN COMMAND and the RRC CONNECTION SETUP messages or if the IE "Timing Indication" is set to "Initialise". Otherwise, it is optional. |

### 10.3.6.23ob Downlink F-DPCH info for each RL

NOTE: For FDD only.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| Primary CPICH usage for channel estimation | MP | | Primary CPICH usage for channel estimation 10.3.6.62 | | REL-6 |
| F-DPCH frame | MP | | Integer (0..38144 | Offset (in | REL-6 |

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| offset | | | by step of 256) | number of chips) between the beginning of the P-CCPCH frame and the beginning of the F-DPCH frame This is called $\tau_{F\text{-}DPCH,n}$ in [26] | |
| Secondary CPICH info | OP | | Secondary CPICH info 10.3.6.73 | | REL-6 |
| Secondary scrambling code | MD | | Secondary scrambling code 10.3.6.74 | Default is the same scrambling code as for the Primary CPICH | REL-6 |
| Code number | MP | | Integer (0..255) | | REL-6 |
| TPC combination index | MP | | TPC combination index 10.3.6.85 | | REL-6 |

## 10.3.6.23a Downlink HS-PDSCH Information

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| HS-SCCH Info | OP | | HS-SCCH Info 10.3.6.36a | | REL-5 |
| Measurement Feedback Info | OP | | Measurement Feedback Info 10.3.6.40a | | REL-5 |
| CHOICE mode | MP | | | | REL-5 |
| >TDD | | | | | |
| >>CHOICE *TDD option* | MP | | | | REL-5 |
| >>>3.84 Mcps | | | | | |
| >>>>HS-PDSCH Timeslot Configuration | OP | | HS-PDSCH Timeslot Configuration 10.3.6.36o | | REL-5 |
| >>>7.68 Mcps | | | | | |
| >>>>HS-PDSCH Timeslot Configuration VHCR | OP | | HS-PDSCH Timeslot Configuration VHCR 10.3.6.36oa | | REL-7 |
| >>> 1.28 Mcps | | | | | |
| >>>> HS-PDSCH Midamble Configuration | OP | | HS-PDSCH Midamble Configuration 10.3.6.36oo | | REL-5 |
| >FDD | | | | (No data) | |

## 10.3.6.24 Downlink information common for all radio links

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| CHOICE *DPCH info* | OP | | | | REL-6 |
| >Downlink DPCH info common for all RL | MP | | Downlink DPCH info | | |

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| | | | common for all RL 10.3.6.18 | | |
| >Downlink F-DPCH info common for all RL | MP | | Downlink F-DPCH info common for all RL 10.3.6.23oa | | REL-6 |
| CHOICE *mode* | MP | | | | |
| >FDD | | | | | |
| >>DPCH compressed mode info | OP | | DPCH compressed mode info 10.3.6.33 | | |
| >>TX Diversity Mode | MD | | TX Diversity Mode 10.3.6.86 | Default value is the existing value of TX Diversity mode | |
| >TDD | | | | (no data) | |
| >>CHOICE *TDD option* | MP | | | | REL-4 |
| >>>3.84 Mcps TDD | | | | (no data) | REL-4 |
| >>>7.68 Mcps TDD | | | | (no data) | REL-7 |
| >>>1.28 Mcps TDD | | | | | REL-4 |
| >>>>TSTD indicator | MP | | TSTD indicator 10.3.6.85a | | REL-4 |
| Default DPCH Offset Value | OP | | Default DPCH Offset Value, 10.3.6.16 | | |
| MAC-hs reset indicator | CV-*messageType* | | Enumerated (true) | TRUE Indicates the MAC-hs entity needs to be reset. | REL-5 |
| Post-verification period | OP | | Enumerated (true) | TRUE indicates that a post-verification period shall be used [29]. Absence of this element means that a post-verification period shall not be used. | REL-6 |

| Condition | Explanation |
|---|---|
| *MessageType* | The IE is not needed in the HANDOVER TO UTRAN COMMAND and the RRC CONNECTION SETUP messages. Otherwise, it is optional. |

### 10.3.6.25 Downlink information common for all radio links Post

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Downlink DPCH info common for all RL | MP | | Downlink DPCH info common for all RL Post 10.3.6.19 | |

### 10.3.6.26 Downlink information common for all radio links Pre

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Downlink DPCH info common for all RL | MP | | Downlink DPCH info common for all RL Pre 10.3.6.20 | |

### 10.3.6.27 Downlink information for each radio link

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| Choice mode | MP | | | | |
| >FDD | | | | | |
| >>Primary CPICH info | MP | | Primary CPICH info 10.3.6.60 | | |
| >>Cell ID | OP | | Cell ID 10.3.2.2 | | REL-4 |
| >>Serving HS-DSCH radio link indicator | MP | | Boolean | The value "TRUE" indicates that this radio link is the serving HS-DSCH radio link | REL-5 |
| >> Serving E-DCH radio link indicator | MP | | Boolean | The value "TRUE" indicates that this radio link is the serving E-DCH radio link | REL-6 |
| >TDD | | | | | |
| >>Primary CCPCH info | MP | | Primary CCPCH info 10.3.6.57 | | |
| CHOICE *DPCH info* | OP | | | | REL-6 |
| >Downlink DPCH info for each RL | MP | | Downlink DPCH info for each RL 10.3.6.21 | | |
| >Downlink F-DPCH info for each RL | MP | | Downlink F-DPCH info for each RL 10.3.6.23ob | | REL-6 |
| E-AGCH Info | OP | | E-AGCH Info 10.3.6.100 | | REL-6 |
| CHOICE E-HICH Information | OP | | | | REL-6 |
| >E-HICH Information | MP | | E-HICH Info 10.3.6.101 | | REL-6 |
| >E-HICH release indicator | | | | (no data) | REL-6 |
| CHOICE E-RGCH Information | OP | | | | REL-6 |
| >E-RGCH Information | MP | | E-RGCH Info 10.3.6.102 | | REL-6 |
| >E-RGCH release indicator | | | | (no data) | REL-6 |

### 10.3.6.28 Downlink information for each radio link Post

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| Choice mode | MP | | | | |
| >FDD | | | | | |
| >>Primary CPICH info | MP | | Primary | | |

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| | | | CPICH info 10.3.6.60 | | |
| >>Cell ID | OP | | Cell ID 10.3.2.2 | | REL-4 |
| >TDD | | | | | |
| >>Primary CCPCH info | MP | | Primary CCPCH info post 10.3.6.58 | | |
| Downlink DPCH info for each RL | MP | | Downlink DPCH info for each RL Post 10.3.6.22 | | |

### 10.3.6.29 Void

### 10.3.6.30 Void

### 10.3.6.31 Downlink rate matching restriction information

This IE indicates which TrCH is restricted in TFI.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Restricted TrCH information | OP | 1 to <maxTrCH> | | |
| >Downlink transport channel type | MP | | Enumerated( DCH) | |
| >Restricted DL TrCH identity | MP | | Transport channel identity 10.3.5.18 | |
| >Allowed TFIs | MP | 1 to <maxTF> | | |
| >>Allowed TFI | MP | | Integer(0..31 ) | |

### 10.3.6.32 Downlink Timeslots and Codes

NOTE: Only for 1.28 Mcps TDD and 3.84 Mcps TDD.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| First Individual timeslot info | MP | | Individual timeslot info 10.3.6.37 | Individual timeslot info for the first timeslot used by the physical layer. |
| First timeslot channelisation codes | MP | | Downlink channelisation codes 10.3.6.17 | These codes shall be used by the physical layer in the timeslot given in First Individual timeslot info. |
| CHOICE *more timeslots* | MP | | | |
| >No more timeslots | | | | (no data) |
| >Consecutive timeslots | | | | |

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| >>Number of additional timeslots | MP | | Integer(1..maxTS-1) | The timeslots used by the physical layer shall be timeslots:<br>N mod maxTS<br>(N+1) mod maxTS<br>...<br>(N+k) mod maxTS<br>in that order, where N is the timeslot number in the First individual timeslot info and k the Number of additional timeslots.<br>The additional timeslots shall use the same parameters (e.g. channelisation codes, midamble shifts etc.) as the first timeslot. |
| >Timeslot list | | | | |
| >>Additional timeslot list | MP | 1 to <maxTS-1> | | The first instance of this parameter corresponds to the timeslot that shall be used second by the physical layer, the second to the timeslot that shall be used third and so on. |
| >>>CHOICE *parameters* | MP | | | |
| >>>>Same as last | | | | |
| >>>>>Timeslot number | MP | | Timeslot Number 10.3.6.84 | The physical layer shall use the same parameters (e.g. channelisation codes, midamble shifts etc.) for this timeslot as for the last one. |
| >>>>New parameters | | | | |
| >>>>>Individual timeslot info | MP | | Individual timeslot info 10.3.6.37 | |
| >>>>>Channelisation codes | MP | | Downlink channelisation codes 10.3.6.17 | |

## 10.3.6.32a Downlink Timeslots and Codes VHCR

NOTE: Only for 7.68 Mcps TDD.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| First Individual timeslot info | MP | | Individual timeslot info 10.3.6.37 | Individual timeslot info for the first timeslot used by the physical layer. |
| First timeslot channelisation codes VHCR | MP | | Downlink channelisation codes VHCR 10.3.6.17a | These codes shall be used by the physical layer in the timeslot given in First Individual timeslot info. |
| CHOICE *more timeslots* | MP | | | |
| >No more timeslots | | | | (no data) |
| >Consecutive timeslots | | | | |

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| >>Number of additional timeslots | MP | | Integer(1..maxTS-1) | The timeslots used by the physical layer shall be timeslots:<br>N mod maxTS<br>(N+1) mod maxTS<br>...<br>(N+k) mod maxTS<br>in that order, where N is the timeslot number in the First individual timeslot info and k the Number of additional timeslots.<br>The additional timeslots shall use the same parameters (e.g. channelisation codes, midamble shifts etc.) as the first timeslot. |
| >Timeslot list | | | | |
| >>Additional timeslot list | MP | 1 to <maxTS-1> | | The first instance of this parameter corresponds to the timeslot that shall be used second by the physical layer, the second to the timeslot that shall be used third and so on. |
| >>>CHOICE *parameters* | MP | | | |
| >>>>Same as last | | | | |
| >>>>>Timeslot number | MP | | Timeslot Number 10.3.6.84 | The physical layer shall use the same parameters (e.g. channelisation codes, midamble shifts etc.) for this timeslot as for the last one. |
| >>>>New parameters | | | | |
| >>>>>Individual timeslot info | MP | | Individual timeslot info 10.3.6.37 | |
| >>>>>Channelisation codes VHCR | MP | | Downlink channelisation codes VHCR 10.3.6.17a | |

## 10.3.6.33 DPCH compressed mode info

NOTE: Only for FDD.

This information element indicates the parameters of the compressed mode to be used by the UE in order to perform inter-frequency and inter-RAT measurements.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Transmission gap pattern sequence | MP | 1 to <maxTGPS> | | |
| >TGPSI | MP | | TGPSI 10.3.6.82 | |
| >TGPS Status Flag | MP | | Enumerated( activate, deactivate) | This flag indicates whether the Transmission Gap Pattern Sequence shall be activated or deactivated. |

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| >TGCFN | CV-*Active* | | Integer (0..255) | Connection Frame Number of the first frame of the first pattern within the Transmission Gap Pattern Sequence. |
| >Transmission gap pattern sequence configuration parameters | OP | | | |
| >>TGMP | MP | | Enumerated( TDD measurement, FDD measurement, GSM carrier RSSI measurement, GSM Initial BSIC identification, GSM BSIC re-confirmation, Multi-carrier measurement) | Transmission Gap pattern sequence Measurement Purpose. |
| >>TGPRC | MP | | Integer (1..511, Infinity) | The number of transmission gap patterns within the Transmission Gap Pattern Sequence. |
| >>TGSN | MP | | Integer (0..14) | Transmission Gap Starting Slot Number<br>The slot number of the first transmission gap slot within the TGCFN. |
| >>TGL1 | MP | | Integer(1..14 ) | The length of the first Transmission Gap within the transmission gap pattern expressed in number of slots |
| >>TGL2 | MD | | Integer (1..14) | The length of the second Transmission Gap within the transmission gap pattern. If omitted, then TGL2=TGL1. The value of TGL2 shall be ignored if TGD is set to "undefined" |
| >>TGD | MP | | Integer(15..269, undefined) | Transmission gap distance indicates the number of slots between starting slots of two consecutive transmission gaps within a transmission gap pattern. If there is only one transmission gap in the transmission gap pattern, this parameter shall be set to undefined. |
| >>TGPL1 | MP | | Integer (1..144) | The duration of transmission gap pattern 1. |
| >>RPP | MP | | Enumerated (mode 0, mode 1). | Recovery Period Power control mode during the frame after the transmission gap within the compressed frame. Indicates whether normal PC mode or compressed PC mode is applied |

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| >>ITP | MP | | Enumerated (mode 0, mode 1). | Initial Transmit Power is the uplink power control method to be used to compute the initial transmit power after the compressed mode gap. |
| >>CHOICE *UL/DL mode* | MP | | | |
| >>>DL only | | | | Compressed mode used in DL only |
| >>>>Downlink compressed mode method | MP | | Enumerated (SF/2, higher layer scheduling) | Method for generating downlink compressed mode gap.<br>If F-DPCH is configured this IE shall not be used by the UE |
| >>>UL only | | | | Compressed mode used in UL only |
| >>>>Uplink compressed mode method | MP | | Enumerated (SF/2, higher layer scheduling) | Method for generating uplink compressed mode gap |
| >>>UL and DL | | | | Compressed mode used in UL and DL |
| >>>>Downlink compressed mode method | MP | | Enumerated (SF/2, higher layer scheduling) | Method for generating downlink compressed mode gap.<br>If F-DPCH is configured this IE shall not be used by the UE |
| >>>>Uplink compressed mode method | MP | | Enumerated (SF/2, higher layer scheduling) | Method for generating uplink compressed mode gap |
| >>Downlink frame type | MP | | Enumerated (A, B) | If F-DPCH is configured this IE shall not be used by the UE |
| >>DeltaSIR1 | MP | | Real(0..3 by step of 0.1) | Delta in DL SIR target value to be set in the UE during the frame containing the start of the first transmission gap in the transmission gap pattern (without including the effect of the bit-rate increase).<br>If F-DPCH is configured this IE shall not be used by the UE |
| >>DeltaSIRafter1 | MP | | Real(0..3 by step of 0.1) | Delta in DL SIR target value to be set in the UE one frame after the frame containing the start of the first transmission gap in the transmission gap pattern.<br>If F-DPCH is configured this IE shall not be used by the UE |
| >>DeltaSIR2 | OP | | Real(0..3 by step of 0.1) | Delta in DL SIR target value to be set in the UE during the frame containing the start of the second transmission gap in the transmission gap pattern (without including the effect of the bit-rate increase)<br>When omitted, DeltaSIR2 = DeltaSIR1.<br>If F-DPCH is configured this IE shall not be used by the UE |
| >>DeltaSIRafter2 | OP | | Real(0..3 by step of 0.1) | Delta in DL SIR target value to be set in the UE one frame after the frame containing the start of the second transmission gap in the |

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| | | | | transmission gap pattern. When omitted, DeltaSIRafter2 = DeltaSIRafter1. If F-DPCH is configured this IE shall not be used by the UE |
| >>N Identify abort | CV-*Initial BSIC* | | Integer(1..128) | Indicates the maximum number of repeats of patterns that the UE shall use to attempt to decode the unknown BSIC of the GSM cell in the initial BSIC identification procedure |
| >>T Reconfirm abort | CV-*Re-confirm BSIC* | | Real(0.5..10.0 by step of 0.5) | Indicates the maximum time allowed for the re-confirmation of the BSIC of one GSM cell in the BSIC re-confirmation procedure. The time is given in steps of 0.5 seconds. |

| Condition | Explanation |
|---|---|
| *Active* | This IE is mandatory present when the value of the IE "TGPS Status Flag" is "Activate" and not needed otherwise. |
| *Initial BSIC* | This IE is mandatory present when the value of the IE "TGMP" is set to "GSM Initial BSIC identification" and not needed otherwise. |
| *Re-confirm BSIC* | This IE is mandatory present when the value of the IE "TGMP" is set to "GSM BSIC re-confirmation" and not needed otherwise. |

### 10.3.6.34 DPCH Compressed Mode Status Info

This information element indicates status information of the compressed mode used by the UE in order to perform inter-frequency and inter-RAT measurements.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| TGPS reconfiguration CFN | MP | | Integer (0..255) | |
| Transmission gap pattern sequence | MP | 1 to <maxTGPS> | | |
| >TGPSI | MP | | TGPSI 10.3.6.82 | Transmission Gap Pattern Sequence Identifier |
| >TGPS Status Flag | MP | | Enumerated( activate, deactivate) | This flag indicates whether the Transmission Gap Pattern Sequence it shall be activated or deactivated. |
| >TGCFN | CV-*Active* | | Integer (0..255) | Connection Frame Number of the first frame of the first pattern within the Transmission Gap Pattern Sequence. |

| Condition | Explanation |
|---|---|
| *Active* | This IE is mandatory present when the value of the IE "TGPS Status Flag" is "Activate" and not needed otherwise. |

### 10.3.6.35 Dynamic persistence level

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Dynamic persistence level | MP | | Integer(1..8) | Level shall be mapped to a dynamic persistence value in the range 0 .. 1. The mapping is described in subclause 8.5.12. |

### 10.3.6.35a FPACH info

NOTE: Only for 1.28 Mcps TDD.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| Timeslot number | MP | | Integer(0..6) | | REL-4 |
| Channelisation code | MP | | Enumerated( (16/1)..(16/16) | | REL-4 |
| Midamble Shift and burst type | MP | | Midamble shift and burst type 10.3.6.41 | | REL-4 |
| WT | MP | | Integer(1..4) | The number of sub-frames, following the sub-frame in which the SYNC UL is transmitted, in which the FPACH can be transmitted. | REL-4 |

### 10.3.6.35b Frequency band indicator

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| Frequency band indicator | MP | | Enumerated( Band I, Band II, Band III, Band IV, Band V, Band VI, Band VII, extension indicator) | | REL-6 |

### 10.3.6.35c Frequency band indicator 2

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| Frequency band indicator 2 | MP | | Enumerated( Band VIII, Band IX, Band X, Band XI, Band XII, Band XIII, Band XIV, Band XV, Band XVI, | Band X – Band XXII are yet to be defined in this version of the specification | REL-6 |

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| | | | Band XVII, Band XVIII, Band XIX, Band XX, Band XXI, Band XXII, extension indicator) | | |

## 10.3.6.36 Frequency info

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| CHOICE *mode* | MP | | | |
| >FDD | | | | |
| >>UARFCN uplink (Nu) | OP | | Integer(0..16383) | If this IE is not present, the default duplex distance defined for the operating frequency band shall be used [21] |
| >>UARFCN downlink (Nd) | MP | | Integer(0 .. 16383) | [21] |
| >TDD | | | | |
| >>UARFCN (Nt) | MP | | Integer(0 .. 16383) | [22] |

## 10.3.6.36oo HS-PDSCH Midamble Configuration

NOTE: Only for TDD 1.28 Mcps.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| Midamble Allocation Mode | MP | | Enumerated( Default midamble, Common midamble, UE specific midamble) | This midamble allocation mode applies to all HS-PDSCH resources assigned to the UE. | REL-5 |
| Midamble Configuration | MP | | Integer(2, 4, 6, 8, 10, 12, 14, 16) | This configuration applies to all HS-PDSCH resources assigned to the UE. | REL-5 |
| Midamble Shift | *CV-UE* | | Integer(0..15) | This shift, when present, applies to all HS-PDSCH resources assigned to the UE. | REL-5 |

| Condition | Explanation |
|---|---|
| *UE* | This IE is mandatory present when the value of the IE "Midamble Allocation Mode" is "UE specific midamble" and not needed otherwise. |

## 10.3.6.36o HS-PDSCH Timeslot Configuration

NOTE: Only for TDD 3.84 Mcps.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| HS-PDSCH Timeslot Configuration List | MP | 1 to <maxTS-1> | | | REL-5 |
| >Timeslot Number | MP | | Integer (0..14) | | REL-5 |
| >CHOICE Burst Type | MP | | | | REL-5 |
| >>Type 1 | | | | | REL-5 |
| >>>Midamble Allocation Mode | MP | | Enumerated (Default midamble, Common midamble, UE specific midamble) | | REL-5 |
| >>>Midamble configuration burst type 1 and 3 | MP | | Integer (4, 8, 16) | As defined in [30] | REL-5 |
| >>>Midamble Shift | CV-UE | | Integer (0..15) | | REL-5 |
| >>Type 2 | | | | | REL-5 |
| >>>Midamble Allocation Mode | MP | | Enumerated (Default midamble, Common midamble, UE specific midamble) | | REL-5 |
| >>>Midamble configuration burst type 2 | MP | | Integer (3, 6) | As defined in [30] | REL-5 |
| >>>Midamble Shift | CV-UE | | Integer (0..5) | | REL-5 |

| Condition | Explanation |
|---|---|
| *UE* | This IE is mandatory present when the value of the IE "Midamble Allocation Mode" is "UE specific midamble" and not needed otherwise. |

## 10.3.6.36oa HS-PDSCH Timeslot Configuration VHCR

NOTE: Only for TDD 7.68 Mcps.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| HS-PDSCH Timeslot Configuration List | MP | 1 to <maxTS-1> | | | REL-5 |
| >Timeslot Number | MP | | Integer (0..14) | | REL-5 |
| >CHOICE Burst Type | MP | | | | REL-5 |
| >>Type 1 | | | | | REL-5 |
| >>>Midamble Allocation Mode | MP | | Enumerated (Default midamble, Common midamble, UE specific midamble) | | REL-5 |
| >>>Midamble configuration burst type 1 and 3 | MP | | Integer (4, 8, 16) | As defined in [30] | REL-5 |
| >>>Midamble Shift | CV-UE | | Integer (0..15) | | REL-5 |
| >>Type 2 | | | | | REL-5 |
| >>>Midamble Allocation Mode | MP | | Enumerated (Default midamble, Common midamble, UE specific midamble) | | REL-5 |
| >>>Midamble configuration burst type 2 | MP | | Integer (4, 8) | As defined in [30] | REL-5 |
| >>>Midamble Shift | CV-UE | | Integer (0..7) | | REL-5 |

| Condition | Explanation |
|---|---|
| *UE* | This IE is mandatory present when the value of the IE "Midamble Allocation Mode" is "UE specific midamble" and not needed otherwise. |

### 10.3.6.36a HS-SCCH Info

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| CHOICE mode | MP | | | | REL-5 |
| >FDD | | | | | REL-5 |
| >>DL Scrambling Code | MD | | Secondary scrambling code 10.3.6.74 | DL Scrambling code to be applied for HS-DSCH and HS-SCCH. Default is same scrambling code as for the primary CPICH. | REL-5 |
| >>HS-SCCH Channelisation Code Information | MP | 1 to <maxHSSCCHs > | | | REL-5 |
| >>>HS-SCCH Channelisation Code | MP | | Integer (0..127) | | REL-5 |
| >TDD | | | | | REL-5 |
| >>CHOICE *TDD option* | MP | | | | REL-5 |
| >>>3.84 Mcps | | | | | REL-5 |
| >>>> Ack-Nack Power Offset | MP | | Integer (-7..8 by step of 1) | dB<br><br>Note | REL-5 |
| >>>> HS-SICH Power Control Info | MP | | HS-SICH Power Control Info 10.3.6.36b | | REL-5 |
| >>>> $D_{hs\text{-}sync}$ | OP | | Integer (-20..+10) | Value in dB set to indicate the dB difference between the maximum allowed HS-SCCH physical channel transmit power [33] and the beacon reference power (it is one means of controlling the area of HS-DSCH operation within the cell). | REL-6 |
| >>>>HS-SCCH Set Configuration | MP | 1 to <maxHSSCCHs> | | | REL-5 |
| >>>>>Timeslot number | MP | | Integer (0..14) | | REL-5 |
| >>>>>Channelisation code | MP | | Enumerated ((16/1) ..(16/16)) | | REL-5 |
| >>>>>Midamble Allocation mode | MP | | Enumerated (Default midamble, Common midamble, UE specific midamble) | HS-SCCH always uses burst type 1. | REL-5 |
| >>>>>Midamble configuration | MP | | Integer (4, 8, 16) | | REL-5 |
| >>>>>Midamble Shift | CV-UE | | Integer(0..15) | | REL-5 |
| >>>>>BLER target | MP | | Real (-3.15..0 by step of 0.05) | Signalled value is Log10(HS-SCCH BLER quality | REL-5 |

| | | | | | |
|---|---|---|---|---|---|
| | | | | target).<br>The UE shall use the BLER target signalled in the first occurrence of the HS-SCCH Set Configuration. | |
| >>>>>HS-SICH configuration | | | | | REL-5 |
| >>>>>>Timeslot number | MP | | Integer (0..14) | | REL-5 |
| >>>>>>Channelisation code | MP | | Enumerated ((16/1) ..(16/16)) | | REL-5 |
| >>>>>>Midamble Allocation mode | MP | | Enumerated (Default midamble, UE specific midamble) | HS-SICH always uses burst type 1. | REL-5 |
| >>>>>>Midamble configuration | MP | | Integer (4, 8, 16) | | REL-5 |
| >>>>>>Midamble Shift | CV-*UE* | | Integer (0..15) | | REL-5 |
| >>>7.68 Mcps | | | | | REL-7 |
| >>>> Ack-Nack Power Offset | MP | | Integer (-7..8 by step of 1) | dB | REL-7 |
| >>>> HS-SICH Power Control Info | MP | | HS-SICH Power Control Info 10.3.6.36b | | REL-7 |
| >>>>HS-SCCH Set Configuration | MP | 1 to <maxHS-SCCHs> | | | REL-7 |
| >>>>>Timeslot number | MP | | Integer (0..14) | | REL-7 |
| >>>>>Channelisation code | MP | | Enumerated ((32/1) ..(32/32)) | | REL-7 |
| >>>>>Midamble Allocation mode | MP | | Enumerated (Default midamble, Common midamble, UE specific midamble) | HS-SCCH always uses burst type 1. | REL-7 |
| >>>>>Midamble configuration | MP | | Integer (4, 8, 16) | | REL-7 |
| >>>>>Midamble Shift | CV-UE | | Integer(0..15 ) | | REL-7 |
| >>>>>BLER target | MP | | Real (-3.15..0 by step of 0.05) | Signalled value is Log10(HS-SCCH BLER quality target).<br>The UE shall use the BLER target signalled in the first occurrence of the HS-SCCH Set Configuration. | REL-7 |
| >>>>>HS-SICH configuration | | | | | REL-5 |
| >>>>>>Timeslot number | MP | | Integer (0..14) | | REL-5 |
| >>>>>>Channelisation code | MP | | Enumerated ((32/1) ..(32/32)) | | REL-5 |
| >>>>>>Midamble Allocation mode | MP | | Enumerated (Default midamble, | HS-SICH always uses burst type 1. | REL-5 |

| | | | | | |
|---|---|---|---|---|---|
| | | | UE specific midamble) | | |
| >>>>>>Midamble configuration | MP | | Integer (4, 8, 16) | | REL-5 |
| >>>>>>Midamble Shift | CV-*UE* | | Integer (0..15) | | REL-5 |
| >>>1.28 Mcps | | | | | REL-5 |
| >>>>HS-SCCH Set Configuration | MP | 1 to <maxHSSCCHs> | | | REL-5 |
| >>>>>Timeslot number | MP | | Integer (0..6) | | REL-5 |
| >>>>>First Channelisation code | MP | | Enumerated ((16/1) ..(16/16)) | | REL-5 |
| >>>>>Second Channelisation code | MP | | Enumerated ((16/1) ..(16/16)) | | REL-5 |
| >>>>>Midamble Allocation mode | MP | | Enumerated (Default midamble, Common midamble, UE specific midamble) | | REL-5 |
| >>>>> Midamble Shift | CV-UE | | Integer (0..15) | | REL-5 |
| >>>>>Midamble configuration | MP | | Integer (2, 4, 6, 8, 10, 12, 14, 16) | | REL-5 |
| >>>>>BLER target | MP | | Real (-3.15..0 by step of 0.05) | Signalled value is Log10(HS-SCCH BLER quality target). The UE shall use the BLER target signalled in the first occurrence of the HS-SCCH Set Configuration. | REL-5 |
| >>>>>HS-SICH configuration | | | | | REL-5 |
| >>>>>>Timeslot number | MP | | Integer (0..6) | | REL-5 |
| >>>>>>Channelisation code | MP | | Enumerated ((16/1) ..(16/16)) | | REL-5 |
| >>>>>>Midamble Allocation mode | MP | | Enumerated (Default midamble, UE specific midamble) | | REL-5 |
| >>>>>>Midamble configuration | MP | | Integer (2, 4, 6, 8, 10, 12, 14, 16) | | REL-5 |
| >>>>>>Midamble Shift | CV-*UE* | | Integer (0..15) | | REL-5 |
| >>>>>>Ack-Nack Power Offset | MP | | Integer (-7..8 by step of 1) | dB.<br><br>Note | REL-5 |
| >>>>>>$PRX_{HS-SICH}$ | MP | | Integer (-120..-58 by step of 1) | dBm. Desired power level for HS-SICH. | REL-5 |
| >>>>>>TPC step size | MP | | Integer (1, 2, 3) | dB. | REL-5 |

| Note: | Ack-Nack Power Offset is the difference in the desired RX power between HS-SICH transmissions conveying an acknowledgement and transmissions conveying a negative acknowledgement signalled to the UE in IE "HS-SCCH Info". |
|---|---|

| Condition | Explanation |
|---|---|
| *UE* | This IE is mandatory present when the value of the IE "Midamble Allocation Mode" is "UE specific midamble" and not needed otherwise. |

### 10.3.6.36b HS-SICH Power Control Info

This IE is used to transfer HS-SICH power control info to the UE and only applies to TDD 3.84 Mcps and 7.68 Mcps.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| UL target SIR | MP | | Real (-11..20 by step of 0.5 ) | dB | REL-5 |
| HS-SICH Constant value | MP | | Constant value TDD 10.3.6.11a | | REL-5 |

### 10.3.6.37 Individual timeslot info

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| Timeslot number | MP | | Timeslot number 10.3.6.84 | Timeslot within a frame | |
| TFCI existence | MP | | Boolean | TRUE indicates that the TFCI exists. It shall be coded in the physical channel defined in [30] of this timeslot. | |
| Midamble Shift and burst type | MP | | Midamble shift and burst type 10.3.6.41 | | |
| CHOICE *TDD option* | MP | | | | REL-4 |
| >3.84 Mcps TDD | | | | (no data) | REL-4 |
| >7.68 Mcps TDD | | | | (no data) | REL-7 |
| >1.28 Mcps TDD | | | | | REL-4 |
| >>Modulation | MP | | Enumerated( QPSK, 8PSK) | | REL-4 |
| >>SS-TPC Symbols | MP | | Enumerated( 0, 1, 16/SF) | Denotes amount of SS and TPC bits send in this timeslot | REL-4 |
| >>Additional TPC-SS Symbols | OP | | Integer(1..15 ) | Specifies the number of additional codes in this timeslot that carry TPC and SS symbols as specified in [33] | REL-4 |

### 10.3.6.38 Individual Timeslot interference

Parameters used by the UE for uplink open loop power control in TDD.

| Information element | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Timeslot number | MP | | Timeslot number 10.3.6.84 | |
| UL Timeslot Interference | MP | | UL Interference TDD 10.3.6.87a | |

### 10.3.6.39 Maximum allowed UL TX power

This information element indicates the maximum allowed uplink transmit power.

| Information Element | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Maximum allowed UL TX power | MP | | Integer(-50..33) | In dBm |

### 10.3.6.40 Void

### 10.3.6.40a Measurement Feedback Info

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| CHOICE *mode* | MP | | | | REL-5 |
| >FDD | | | | | REL-5 |
| >>Measurement Power Offset | MP | | Real (-6 .. 13 by step of 0.5) | The measurement power offset, $\Gamma$, in dB, as described in [29]. | REL-5 |
| >>CQI Feedback cycle, k | MP | | Integer (0, 2, 4, 8, 10, 20, 40, 80, 160) | In milliseconds. | REL-5 |
| >>CQI repetition factor | MP | | Integer (1..4) | | REL-5 |
| >>$\Delta_{CQI}$ | MP | | Integer (0..8) | Refer to quantization of the power offset in [28] | REL-5 |
| >TDD | | | | (no data) | REL-5 |

### 10.3.6.41 Midamble shift and burst type

NOTE: Only for TDD.

This information element indicates burst type and midamble allocation. Three different midamble allocation schemes exist:

- Default midamble: the midamble shift is selected by layer 1 depending on the associated channelisation code (DL and UL)
- Common midamble: the midamble shift is chosen by layer 1 depending on the number of channelisation codes (possible in DL only)

- UE specific midamble: a UE specific midamble is explicitly assigned (DL and UL).

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| CHOICE *TDD option* | MP | | | | REL-4 |
| >3.84 Mcps TDD | | | | | REL-4 |
| >>CHOICE *Burst Type* | MP | | | | |
| >>>Type 1 | | | | | |
| >>>>Midamble Allocation Mode | MP | | Enumerated (Default midamble, Common midamble, UE specific midamble) | | |
| >>>>Midamble configuration burst type 1 and 3 | MP | | Integer(4, 8, 16) | As defined in [30] | |
| >>>>Midamble Shift | CV-*UE* | | Integer(0..15) | | |
| >>>Type 2 | | | | | |
| >>>>Midamble Allocation Mode | MP | | Enumerated (Default midamble, Common midamble, UE specific midamble) | | |
| >>>>Midamble configuration burst type 2 | MP | | Integer(3, 6) | As defined in [30] | |
| >>>>Midamble Shift | CV-*UE* | | Integer(0..5) | | |
| >>>Type 3 | | | | | |
| >>>>Midamble Allocation Mode | MP | | Enumerated (Default midamble, UE specific midamble) | | |
| >>>>Midamble configuration burst type 1 and 3 | MP | | Integer(4, 8, 16) | As defined in [30] | |
| >>>>Midamble Shift | CV-*UE* | | Integer (0..15) | NOTE: Burst Type 3 is only used in uplink. | |
| >7.68 Mcps TDD | | | | | REL-7 |
| >>CHOICE *Burst Type* | MP | | | | |
| >>>Type 1 | | | | | |
| >>>>Midamble Allocation Mode | MP | | Enumerated (Default midamble, Common midamble, UE specific midamble) | | |
| >>>>Midamble configuration burst type 2 | MP | | Integer(4, 8) | As defined in [30] | |
| >>>>Midamble Shift | CV-*UE* | | Integer(0..7) | | |
| >>>Type 3 | | | | | |
| >>>>Midamble Allocation Mode | MP | | Enumerated (Default midamble, UE specific midamble) | | |
| >>>>Midamble configuration burst type 1 and 3 | MP | | Integer(4, 8, 16) | As defined in [30] | |
| >>>>Midamble Shift | CV-*UE* | | Integer (0..15) | NOTE: Burst Type 3 is only used in uplink. | |
| >1.28 Mcps TDD | | | | | REL-4 |

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| >>Midamble Allocation Mode | MP | | Enumerated (Default midamble, Common midamble, UE specific midamble) | | REL-4 |
| >>Midamble configuration | MP | | Integer(2, 4, 6, 8, 10, 12, 14, 16) | As defined in [30] | REL-4 |
| >>Midamble Shift | CV-*UE* | | Integer (0..15) | | REL-4 |

| Condition | Explanation |
|---|---|
| *UE* | This IE is mandatory present when the value of the IE "Midamble Allocation Mode" is "UE-specific midamble" and not needed otherwise. |

### 10.3.6.42 PDSCH Capacity Allocation info

NOTE: Only for TDD.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| PDSCH allocation period info | MP | | Allocation Period Info 10.3.6.4 | |
| CHOICE *Configuration* | MP | | | |
| >Old configuration | | | | |
| >>TFCS ID | MD | | Integer(1..8) | Default is 1. |
| >>PDSCH Identity | MP | | Integer(1..hiPDSCHidentities) | |
| >New configuration | | | | |
| >>PDSCH Info | MP | | PDSCH Info 10.3.6.44 | |
| >>PDSCH Identity | OP | | Integer(1..hiPDSCHidentities) | |
| >>PDSCH power control info | OP | | PDSCH power control info 10.3.6.45 | |

### 10.3.6.43 Void

### 10.3.6.44 PDSCH info

NOTE: Only for TDD.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| TFCS ID | MD | | Integer(1..8) | TFCS to be used. Default value is 1. |
| Common timeslot info | OP | | Common timeslot info 10.3.6.10 | |
| PDSCH timeslots and codes for1.28 Mcps TDD or 3.84 Mcps TDD | OP | | Downlink Timeslots and Codes 10.3.6.32 | Default is to use the old timeslots and codes. |
| PDSCH timeslots and codes for 7.68 Mcps TDD | OP | | Downlink Timeslots and Codes VHR 10.3.6.32a | Default is to use the old timeslots and codes. |

### 10.3.6.45 PDSCH Power Control info

NOTE: Only for TDD.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| TPC Step Size | OP | | Integer (1, 2, 3) | In dB |
| UL CCTrCH TPC List | OP | 1..<maxCCTrCH> | | UL CCTrCH identities for TPC commands associated with this DL CCTrCH.<br><br>This list is not used in 1.28 Mcps TDD. |
| >UL TPC TFCS Identity | MP | | Transport Format Combination Set Identity 10.3.5.21 | |

### 10.3.6.46 PDSCH system information

NOTE: Only for TDD.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| PDSCH information | MP | 1 to <maxPDSCH> | | | |
| >PDSCH Identity | MP | | Integer(1..hiPDSCHidentities) | | |
| >PDSCH info | MP | | PDSCH info 10.3.6.44 | | |
| >SFN Time Info | CH-*Block17* | | SFN Time Info 10.3.6.75 | | |
| >DSCH TFS | OP | | Transport format set 10.3.5.23 | | |
| >DSCH Transport Channels | OP | 1 to <maxTrCH> | | If PDSCH is configured for 3.84Mcps TDD in Rel-5 or for 7.68 Mcps in Rel-7 this IE may be included. | REL-5 |
| >> DSCH Transport channel identity | MP | | Transport channel identity 10.3.5.18 | | REL-5 |
| >>DSCH TFS | MP | | Transport format set 10.3.5.23 | | REL-5 |
| >DSCH TFCS | OP | | Transport Format Combination Set 10.3.5.20 | | |

| Condition | Explanation |
|---|---|
| *Block17* | This IE is not needed in System Information Block 17. Otherwise it is optional. |

## 10.3.6.47 Void

## 10.3.6.48 Persistence scaling factors

This IE defines scaling factors associated with ASC 2 – ASC 7 to be applied to the dynamic persistence value.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Access Service Class | MP | 1 to maxASCpersist | | multiplicity corresponds to the number of PRACH partitions minus 2 |
| >Persistence scaling factor | MP | | Real(0.9..0.2, by step of 0.1) | Scaling factors in the range 0,…,1 |

## 10.3.6.49 PICH Info

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| CHOICE *mode* | MP | | | | |
| >FDD | | | | | |

| | | | | | |
|---|---|---|---|---|---|
| >>Channelisation code | MP | | Integer(0..255) | SF is fixed and equal to 256 | |
| >>Number of PI per frame | MP | | Integer (18, 36, 72, 144) | | |
| >>STTD indicator | MP | | STTD Indicator 10.3.6.78 | | |
| >TDD | | | | | |
| >>Timeslot number | MD | | Timeslot number 10.3.6.84 | Default value is the timeslot used by the SCCPCH carrying the associated PCH. | |
| >>Midamble shift and burst type | MP | | Midamble shift and burst type 10.3.6.41 | | |
| >>CHOICE *TDD option* | MP | | | | REL-4 |
| >>>3.84 Mcps TDD | | | | | REL-4 |
| >>>>Channelisation code | MD | | Enumerated ( (16/1)...(16/16)) | Default value is the channelisation code used by the SCCPCH carrying the associated PCH. | |
| >>>7.68 Mcps TDD | | | | | REL-7 |
| >>>>Channelisation code | MD | | Enumerated ( (32/1)...(32/32)) | Default value is the channelisation code used by the SCCPCH carrying the associated PCH. | |
| >>>1.28 Mcps TDD | | | | | REL-4 |
| >>>>Codes list | MP | 1..2 | | | REL-4 |
| >>>>>Channelisation code | MP | | Enumerated ( (16/1)...(16/16)) | | REL-4 |
| >>Repetition period/length | MD | | Enumerated( (4/2),(8/2), (8/4),(16/2), (16/4), (32/2),(32/4), (64/2),(64/4)) | Default value is "(64/2)". | |
| >>Offset | MP | | Integer (0...Repetition period -1) | SFN mod Repetitionperiod = Offset. | |
| >>Paging indicator length | MD | | Integer (4, 8, 16) | Indicates the length of one paging indicator in Bits. Default value is 4. | |
| >>$N_{GAP}$ | MD | | Integer(2, 4, 8) | Number of frames between the last frame carrying PICH for this Paging Occasion and the first frame carrying paging messages for this Paging Occasion. Default value is 4. | |
| >>$N_{PCH}$ | MD | | Integer(1 .. 8) | Number of paging groups. Default value is 2. | |

### 10.3.6.50 PICH Power offset

This is the power transmitted on the PICH minus power of the Primary CPICH in FDD and Primary CCPCH Tx Power in TDD.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| PICH Power offset | MP | | Integer(-10 .. +5) | Offset in dB |

### 10.3.6.50a PLCCH Info

NOTE: Only for 1.28 Mcps TDD

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| PLCCH sequence number | M | | Integer(1.. 17) | |
| Timeslot number | M | | Integer(0.. 6) | |
| Channelisation Code | M | | Enumerated((16/1)..(16/16)) | |
| TPC command target rate | M | | Real(0.01.. 0.1 by steps of 0.01) | Transmit Power Control command target rate |

### 10.3.6.51 PRACH Channelisation Code List

NOTE: Only for 3.84 Mcps TDD.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| CHOICE *SF* | MP | | | | |
| >SF16 | | | | | |
| >>Channelisation Code List | MP | 1 to 8 | | | |
| >>>Channelisation code | MP | | Enumerated ((16/1)...(16/16)) | There is a 1:1 mapping between spreading code and midamble shift defined in [30] for channelisation codes (16/1) to (16/8).<br><br>NOTE: channelisation codes (16/9) to (16/16) are not to be used. | |
| >SF8 | | | | | |
| >>Channelisation Code List | MP | 1 to 8 | | | |
| >>>Channelisation Code | MP | | Enumerated((8/1)..(8/8)) | | |

### 10.3.6.51a PRACH Channelisation Code 1.28 Mcps TDD

NOTE: Only for 1.28 Mcps TDD.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| Channelisation Code List | MP | 1 to 4 | | | REL-4 |
| >Channelisation Code | MP | | Enumerated( (4/1)..(4/4),(8 /1)..(8/8),(16/ 1)..(16/16)) | | REL-4 |

## 10.3.6.51b PRACH Channelisation Code List VHCR

NOTE: Only for 7.68 Mcps TDD.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| CHOICE *SF* | MP | | | | |
| >SF32 | | | | | |
| >>Channelisation Code List | MP | 1 to 16 | | | |
| >>>Channelisation code | MP | | Enumerated ((32/1)...(32/ 32)) | There is a 1:1 mapping between spreading code and midamble shift defined in [30] for channelisation codes (32/1) to (32/16).<br><br>NOTE: channelisation codes (32/17) to (32/32) are not to be used. | |
| | | | | | |
| >SF16 | | | | | |
| >>Channelisation Code List | MP | 1 to 16 | | | |
| >>>Channelisation code | MP | | Enumerated ((16/1)...(16/ 16)) | There is a 1:1 mapping between spreading code and midamble shift defined in [30] for channelisation codes (16/1) to (16/16). | |
| >SF8 | | | | | |
| >>Channelisation Code List | MP | 1 to 8 | | | |
| >>>Channelisation Code | MP | | Enumerated( (8/1)..(8/8)) | | |

## 10.3.6.52 PRACH info (for RACH)

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| CHOICE *mode* | MP | | | | |
| >FDD | | | | | |
| >>Available Signature | MP | | Bit string(16) | Each bit indicates availability for a signature, where the signatures are numbered "signature 0" up to "signature 15". The value 1 of a | |

| | | | | | |
|---|---|---|---|---|---|
| | | | | bit indicates that the corresponding signature is available and the value 0 that it is not available. | |
| >>Available SF | MP | | Integer (32,64,128,256) | In chips per symbol Defines the minimum allowed SF (i.e. the maximum rate) | |
| >>Preamble scrambling code number | MP | | Integer (0 .. 15) | Identification of scrambling code see [28] | |
| >>Puncturing Limit | MP | | Real(0.40..1.00 by step of 0.04) | | |
| >>Available Sub Channel Number | MP | | Bit string(12) | Each bit indicates availability for a subchannel, where the subchannels are numbered "subchannel 0" to "subchannel 11". The value 1 of a bit indicates that the corresponding subchannel is available and the value 0 indicates that it is not available. | |
| >TDD | | | | | |
| >>CHOICE *TDD option* | MP | | | | REL-4 |
| >>>3.84 Mcps TDD | | | | | REL-4 |
| >>>>Timeslot number | MP | | Timeslot number 10.3.6.84 | | |
| >>>>PRACH Channelisation Code List | MP | | PRACH Channelisation Code List 10.3.6.51 | | |
| >>>>PRACH Midamble | MP | | Enumerated (Direct, Direct/Inverted) | Direct or direct and inverted midamble are used for PRACH | |
| >>>>PNBSCH allocation | OP | | PNBSCH allocation 10.3.8.10a | Identifies frames used for cell synchronisation purposes | REL-4 |
| >>>7.68 Mcps TDD | | | | | REL-7 |
| >>>>Timeslot number | MP | | Timeslot number 10.3.6.84 | | |
| >>>>PRACH Channelisation Code List VHCR | MP | | PRACH Channelisation Code List VHCR 10.3.6.51b | | |
| >>>>PRACH Midamble | MP | | Enumerated (Direct, Direct/Inverted) | Direct or direct and inverted midamble are used for PRACH | |
| >>>>PNBSCH allocation | OP | | PNBSCH allocation 10.3.8.10a | Identifies frames used for cell synchronisation | REL-4 |

| | | | | | |
|---|---|---|---|---|---|
| | | | | purposes | |
| >>>1.28 Mcps TDD | | | | | REL-4 |
| >>>>SYNC_UL info | MP | | SYNC_UL info 10.3.6.78a | | REL-4 |
| >>>>PRACH Definition | MP | 1..<maxPRACH_FPACH> | | | REL-4 |
| >>>>>Timeslot number | MP | | Timeslot number 10.3.6.84 | | REL-4 |
| >>>>>PRACH Channelisation Code | MP | | PRACH Channelisation Code 1.28 Mcps TDD 10.3.6.51a | | REL-4 |
| >>>>>Midamble Shift and burst type | MP | | Midamble shift and burst type 10.3.6.41 | | REL-4 |
| >>>>>FPACH info | MP | | FPACH info 10.3.6.35a | | REL-4 |

### 10.3.6.53 PRACH partitioning

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Access Service class | MP | 1 to maxASC | | If only "NumASC+1" (with, NumASC+1 < maxASC) ASCs are listed, the remaining (NumASC+2 through maxASC) ASCs are unspecified. |
| >ASC Setting | MD | | ASC setting 10.3.6.6 | The default values are same as the previous ASC.<br>If the "default" is used for the first ASC, the default values are all available signatures and "all available sub-channels" for FDD and "all available channelisation codes" and "all available subchannels" with "subchannel size=Size 1" in TDD. |

### 10.3.6.54 PRACH power offset

NOTE: Only for FDD.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Power Ramp Step | MP | | Integer (1..8) | Power step when no acquisition indicator is received in dB |
| Preamble Retrans Max | MP | | Integer (1..64) | Maximum number of preambles in one preamble ramping cycle |

### 10.3.6.55 PRACH system information list

| Information element | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| PRACH system information | MP | 1 .. <maxPRACH> | | | |
| >PRACH info | MP | | PRACH info (for RACH) 10.3.6.52 | | |
| >Transport channel identity | MP | | Transport channel identity 10.3.5.18 | | |
| >RACH TFS | MD | | Transport format set 10.3.5.23 | Default value is the value of "RACH TFS" for the previous PRACH in the list<br>NOTE: The first occurrence is then MP).<br>NOTE: For TDD in this release there is a single TF within the RACH TFS. | |
| >Additional RACH TFS for CCCH | OP | | Additional Dynamic Transport Format Information for CCCH 10.3.5.2a | FDD only | REL-6 |
| >RACH TFCS | MD | | Transport Format Combination Set 10.3.5.20 | Default value is the value of "RACH TFCS" for the previous PRACH in the list.<br>NOTE: The first occurrence is then MP).<br>NOTE: For TDD in this release there is no TFCS required. | |
| >Additional RACH TFCS for CCCH | CV-*Add-RACH-TFS* | | Additional RACH TFCS for CCCH 10.3.5.2b | | REL-6 |
| >PRACH partitioning | MD | | PRACH partitioning 10.3.6.53 | Default value is the value of "PRACH partitioning" for the previous PRACH in the list (note : the first occurrence is then MP) | |
| >Persistence scaling factors | OP | | Persistence scaling factors 10.3.6.48 | This IE shall not be present if only ASC 0 and ASC 1 are defined. If this IE is absent, value is the value of "Persistence scaling factors" for the previous PRACH in the list if value exists | |
| >AC-to-ASC mapping | CV-*SIB5-MD* | | AC-to-ASC mapping 10.3.6.1 | Only present in SIB 5 and in SIB 5bis.<br>Default value is the value of "AC-to-ASC mapping" for the previous PRACH in the list.<br>NOTE: The first occurrence is then MP in SIB5 and in SIB5bis. | |
| >CHOICE *mode* | MP | | | | |
| >>FDD | | | | | |
| >>>Primary CPICH TX power | MD | | Primary CPICH TX power 10.3.6.61 | Default value is the value of "Primary CPICH TX power" for the previous PRACH in the list.<br>NOTE: The first occurrence is | |

| Information element | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| | | | | then MP. | |
| >>>Constant value | MD | | Constant value 10.3.6.11 | Default value is the value of "Constant value" for the previous PRACH in the list. NOTE: The first occurrence is then MP. | |
| >>>PRACH power offset | MD | | PRACH power offset 10.3.6.54 | Default value is the value of "PRACH power offset" for the previous PRACH in the list. NOTE: The first occurrence is then MP. | |
| >>>RACH transmission parameters | MD | | RACH transmission parameters 10.3.6.67 | Default value is the value of "RACH transmission parameters" for the previous PRACH in the list. NOTE: The first occurrence is then MP. | |
| >>>AICH info | MD | | AICH info 10.3.6.2 | Default value is the value of "AICH info" for the previous PRACH in the list. NOTE: The first occurrence is then MP. | |
| >>TDD | | | | (no data) | |

| Condition | Explanation |
|---|---|
| *SIB5-MD* | The information element is present only in SIB 5 and in SIB5bis. In SIB 5 and in SIB 5bis it is mandatory with default. |
| *Add-RACH-TFS* | The information element is MP if the IE "Additional RACH TFS for CCCH" is included. Otherwise the information element is not needed. |

NOTE: If the setting of the PRACH information results in that a combination of a signature, preamble scrambling code and subchannel corresponds to a RACH with different TFS and/or TFCS, then for that combination only the TFS/TFCS of the PRACH listed first is valid, where PRACHs listed in System Information Block type 5 or 5bis shall be counted first.

### 10.3.6.56 Predefined PhyCH configuration

This information element concerns a pre- defined configuration of physical channel parameters.

| Information Element/Group name | Need | Multi | Type and Reference | Semantics description |
|---|---|---|---|---|
| **Uplink radio resources** | | | | |
| Uplink DPCH info | MP | | Uplink DPCH info Pre 10.3.6.90 | |
| **Downlink radio resources** | | | | |
| Downlink information common for all radio links | OP | | Downlink information common for all radio links Pre 10.3.6.26 | |

### 10.3.6.57 Primary CCPCH info

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| CHOICE *mode* | MP | | | | |

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| >FDD | | | | | |
| >>TX Diversity indicator | MP | | Boolean | TRUE indicates that transmit diversity is used. | |
| >TDD | | | | | |
| >>CHOICE *TDD option* | MP | | | | REL-4 |
| >>>3.84 Mcps TDD | | | | | REL-4 |
| >>>>CHOICE *SyncCase* | OP | | | | |
| >>>>>Sync Case 1 | | | | | |
| >>>>>>Timeslot | MP | | Integer (0...14) | PCCPCH timeslot | |
| >>>>>Sync Case 2 | | | | | |
| >>>>>>Timeslot | MP | | Integer(0..6) | | |
| >>>7.68 Mcps TDD | | | | | REL-7 |
| >>>>CHOICE *SyncCase* | OP | | | | |
| >>>>>Sync Case 1 | | | | | |
| >>>>>>Timeslot | MP | | Integer (0...14) | PCCPCH timeslot | |
| >>>>>Sync Case 2 | | | | | |
| >>>>>>Timeslot | MP | | Integer(0..6) | | |
| >>>1.28 Mcps TDD | | | | | REL-4 |
| >>>>TSTD indicator | MP | | TSTD indicator 10.3.6.85a | | REL-4 |
| >>Cell parameters ID | OP | | Cell parameters Id 10.3.6.9 | The Cell parameters ID is described in [32]. | |
| >>SCTD indicator | MP | | SCTD indicator 10.3.6.70a | | |

## 10.3.6.58 Primary CCPCH info post

NOTE: Only for TDD

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| CHOICE *TDD option* | MP | | | | REL-4 |
| >3.84 Mcps TDD | | | | | REL-4 |
| >>CHOICE *SyncCase* | MP | | | | |
| >>>Sync Case 1 | | | | | |
| >>>>Timeslot | MP | | Integer (0...14) | PCCPCH timeslot | |
| >>>Sync Case 2 | | | | | |
| >>>>Timeslot | MP | | Integer(0..6) | | |
| >7.68 Mcps TDD | | | | | REL-7 |
| >>CHOICE *SyncCase* | MP | | | | |
| >>>Sync Case 1 | | | | | |
| >>>>Timeslot | MP | | Integer (0…14) | PCCPCH timeslot | |
| >>>Sync Case 2 | | | | | |
| >>>>Timeslot | MP | | Integer(0..6) | | |
| >1.28 Mcps TDD | | | | | REL-4 |
| >>TSTD indicator | MP | | TSTD indicator 10.3.6.85a | | REL-4 |
| Cell parameters ID | MP | | Cell parameters | The Cell parameters ID is | |

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| | | | Id 10.3.6.9 | described in [32]. | |
| SCTD indicator | MP | | SCTD indicator 10.3.6.70a | | |

### 10.3.6.59 Primary CCPCH TX Power

NOTE: Only for TDD.

| Information Element/group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Primary CCPCH Tx Power | MP | | Integer(6..43) | In dBm |

### 10.3.6.60 Primary CPICH info

NOTE: Only for FDD.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Primary scrambling code | MP | | Integer(0..511) | |

### 10.3.6.61 Primary CPICH Tx power

NOTE: Only for FDD.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Primary CPICH Tx Power | MP | | Integer(-10..50) | Power in dBm. |

### 10.3.6.62 Primary CPICH usage for channel estimation

NOTE: Only for FDD.

| Information Element/Group name | Need | Multi | Type and Reference | Semantics description |
|---|---|---|---|---|
| Primary CPICH usage for channel estimation | MP | | Enumerated( Primary CPICH may be used, Primary CPICH shall not be used) | |

### 10.3.6.63 PUSCH info

NOTE: Only for 1.28 Mcps and 3.84 Mcps TDD.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| TFCS ID | MD | | Integer(1..8) | Default value is 1 |
| Common timeslot info | OP | | Common timeslot info 10.3.6.10 | |
| PUSCH timeslots and codes | OP | | Uplink Timeslots and Codes 10.3.6.94 | |

### 10.3.6.63a PUSCH info VHCR

NOTE: Only 7.68 Mcps TDD (REL-7).

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| TFCS ID | MD | | Integer(1..8) | Default value is 1 |
| Common timeslot info | OP | | Common timeslot info 10.3.6.10 | |
| PUSCH timeslots and codes VHCR | OP | | Uplink Timeslots and Codes VHCR 10.3.6.94b | |

### 10.3.6.64 PUSCH Capacity Allocation info

NOTE: Only for TDD.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| CHOICE *PUSCH allocation* | MP | | | |
| >PUSCH allocation pending | | | | (no data) |
| >PUSCH allocation assignment | | | | |
| >>PUSCH allocation period info | MP | | Allocation Period Info 10.3.6.4 | |
| >>PUSCH power control info | OP | | PUSCH power control info 10.3.6.65 | |
| >>CHOICE *Configuration* | MP | | | |
| >>>Old configuration | | | | |
| >>>>TFCS ID | MD | | Integer(1..8) | Default is 1. |
| >>>>PUSCH Identity | MP | | Integer(1..hiPUSCHidentities) | |
| >>>New 1.28 Mcps TDD or 3.84 Mcps TDD configuration | | | | |
| >>>>PUSCH info | MP | | PUSCH info 10.3.6.63 | |
| >>>>PUSCH Identity | OP | | Integer(1..hiPUSCHidentities) | |
| >>>New 7.68 Mcps TDD configuration | | | | REL-7 |
| >>>>PUSCH info VHCR | MP | | PUSCH info VHCR 10.3.6.63a | REL-7 |
| >>>>PUSCH Identity | OP | | Integer(1..hiPUSCHidentities) | |

### 10.3.6.65 PUSCH power control info

NOTE: Only for TDD.

Interference level measured for a frequency at the UTRAN access point used by UE to set PUSCH output power.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| UL target SIR | MP | | Real (-11 .. 20 by step of 0.5 dB) | | |
| | | | | For 1.28 Mcps TDD this parameter represents $PRX_{PUSCHdes}$ with range Integer(-120…-58 by step of 1) dBm | REL-4 |
| CHOICE TDD option | MP | | | | REL-4 |
| >3.84 Mcps TDD | | | | (no data) | REL-4 |
| >7.68 Mcps TDD | | | | (no data) | REL-7 |
| >1.28 Mcps TDD | | | | | REL-4 |
| >>TPC Step Size | OP | | Integer (1, 2, 3) | In dB | REL-4 |

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| >>Beacon PL Est. | OP | | Enumerated (true) | The presence of this IE indicates that the UE may take into account path loss estimated from beacon function physical channels. The absence indicates that UE may not take into account path loss estimated from beacon function physical channels | REL-6 |

## 10.3.6.66 PUSCH system information

NOTE: Only for 1.28 Mcps or 3.84 Mcps TDD.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| PUSCH information | MP | 1 to <maxPUSCH> | | | |
| >PUSCH Identity | MP | | Integer(1..hiPUSCHidentities) | | |
| >PUSCH info | MP | | PUSCH info 10.3.6.63 | | |
| >SFN Time Info | CH-*Block17* | | SFN Time Info 10.3.6.75 | | |
| >USCH TFS | OP | | Transport format set 10.3.5.23 | | |
| >USCH Transport Channels | OP | 1 to <maxTrCH> | | If PUSCH is configured for 3.84 Mcps TDD in Rel-5 this IE may be included. | REL-5 |
| >> USCH Transport channel identity | MP | | Transport channel identity 10.3.5.18 | | REL-5 |
| >>USCH TFS | MP | | Transport format set 10.3.5.23 | | REL-5 |
| >USCH TFCS | OP | | Transport Format Combination Set 10.3.5.20 | | |

| Condition | Explanation |
|---|---|
| *Block17* | This IE is not needed in System Information Block 17. Otherwise it is optional. |

## 10.3.6.66a PUSCH system information VHCR

NOTE: Only for 7.68 Mcps TDD (REL-7).

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| PUSCH information | MP | 1 to <maxPUSCH> | | | |
| >PUSCH Identity | MP | | Integer(1..hiPUSCHidentities) | | |
| >PUSCH info VHCR | MP | | PUSCH info VHCR 10.3.6.63a | | REL-7 |
| >SFN Time Info | CH-*Block17* | | SFN Time Info 10.3.6.75 | | |
| >USCH TFS | OP | | Transport format set 10.3.5.23 | | |
| >USCH Transport Channels | OP | 1 to <maxTrCH> | | If PUSCH is configured for 7.68 Mcps TDD in Rel-7 this IE may be included. | REL-5 |
| >> USCH Transport channel identity | MP | | Transport channel identity 10.3.5.18 | | REL-5 |
| >>USCH TFS | MP | | Transport format set 10.3.5.23 | | REL-5 |
| >USCH TFCS | OP | | Transport Format Combination Set 10.3.5.20 | | |

| Condition | Explanation |
|---|---|
| *Block17* | This IE is not needed in System Information Block 17. Otherwise it is optional. |

## 10.3.6.67 RACH transmission parameters

NOTE: Only for FDD.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Mmax | MP | | Integer(1..32) | Maximum number of preamble cycles |
| NB01min | MP | | Integer(0..50) | Sets lower bound for random back-off |
| NB01max | MP | | Integer(0..50) | Sets upper bound for random back-off |

## 10.3.6.68 Radio link addition information

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| Primary CPICH info | MP | | Primary CPICH info 10.3.6.60 | | |
| Cell ID | OP | | Cell ID 10.3.2.2 | | REL-4 |
| CHOICE *DPCH info* | MP | | | | REL-6 |

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| >Downlink DPCH info for each RL | MP | | Downlink DPCH info for each RL 10.3.6.21 | | |
| >Downlink F-DPCH info for each RL | MP | | Downlink F-F-DPCH info for each RL 10.3.6.23ob | | REL-6 |
| E-HICH Information | OP | | E-HICH Info 10.3.6.101 | | REL-6 |
| E-RGCH Information | OP | | E-RGCH Info 10.3.6.102 | | REL-6 |

### 10.3.6.69 Radio link removal information

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Primary CPICH info | MP | | Primary CPICH info 10.3.6.60 | |

### 10.3.6.69a E-DCH reconfiguration information

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| E-DCH RL Info new serving cell | OP | | | | REL-6 |
| >Primary CPICH info | MP | | Primary CPICH info 10.3.6.60 | Indicates scheduling E-DCH cell from the active set cells. | REL-6 |
| >E-AGCH Info | MP | | E-AGCH Info 10.3.6.100 | | REL-6 |

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| >Serving Grant | OP | | | | REL-6 |
| >>Serving Grant value | MP | | Integer (0..37,38) | (0..37) indicates E-DCH serving grant index as defined in [15]; index 38 means zero grant. | REL-6 |
| >>Primary/Secondary Grant Selector | MP | | Enumerated ('primary', 'secondary') | Indicates whether the Serving Grant is received with a Primary E-RNTI or Secondary E-RNTI. | REL-6 |
| >E-DPCCH/DPCCH power offset | OP | | Integer (0..8) | Refer to quantization of the power offset in [28]. | REL-6 |
| >Reference E-TFCIs | OP | 1 to 8 | | See [29]. | REL-6 |
| >>Reference E-TFCI | MP | | Integer (0..127) | | REL-6 |
| >>Reference E-TFCI PO | MP | | Integer (0..29) | Refer to quantization of the power offset in [28]. | REL-6 |
| >Power Offset for Scheduling Info | OP | | Integer (0..6) | Only used when no MACd PDU"s are included in the same MACe PDU. Unit is in dB. | REL-6 |
| >3-Index-Step Threshold | OP | | Integer (0..37) | Refers to an index in the 'SG-Table' (see [15]). | REL-6 |
| >2-Index-Step Threshold | OP | | Integer (0..37) | Refers to an index in the 'SG-Table' (see [15]). | REL-6 |
| >E-HICH Information | OP | | E-HICH Info 10.3.6.101 | This IE is not present if the serving E-DCH cell is added to the active set with this message. | REL-6 |
| >CHOICE E-RGCH Information | OP | | | This IE is not present if the serving E-DCH cell is added to the active set with this message | REL-6 |
| >>E-RGCH Information | MP | | E-RGCH Info 10.3.6.102 | | REL-6 |
| >>E-RGCH release indicator | | | | (no data) | REL-6 |
| E-DCH RL Info other cells | OP | 1 to <maxEDCHRL> | | This IE is not allowed to include information on a RL added by this message | REL-6 |
| >Primary CPICH info | MP | | Primary CPICH info 10.3.6.60 | | REL-6 |
| >CHOICE E-HICH Information | OP | | | | REL-6 |
| >>E-HICH Information | MP | | E-HICH Info 10.3.6.101 | | REL-6 |
| >>E-HICH release indicator | | | | (no data) | REL-6 |
| >CHOICE E-RGCH Information | OP | | | | REL-6 |
| >>E-RGCH Information | MP | | E-RGCH | | REL-6 |

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| | | | Info 10.3.6.102 | | |
| >>E-RGCH release indicator | | | | (no data) | REL-6 |

### 10.3.6.70 Void

### 10.3.6.70a SCTD indicator

NOTE: Only for TDD

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| SCTD indicator | MP | | Boolean | TRUE indicates that SCTD is used |

### 10.3.6.71 Secondary CCPCH info

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| CHOICE *mode* | MP | | | |
| >FDD | | | | |
| >>Secondary scrambling code | OP | | Secondary scrambling code 10.3.6.74 | May only be sent for SCCPCH channels not carrying the PCH. |
| >>STTD indicator | MP | | STTD Indicator 10.3.6.78 | |
| >>Spreading factor | MP | | Integer(4, 8, 16, 32, 64, 128, 256) | |
| >>Code number | MP | | Integer(0..Spreading factor - 1) | |
| >>Pilot symbol existence | MP | | Boolean | TRUE means the existence. |
| >>TFCI existence | MP | | Boolean | TRUE indicates that TFCI is used. When spreading factor is less than or equal to 64, FALSE indicates that TFCI is not used and therefore DTX is used in the TFCI field. |
| >>Fixed or Flexible Position | MP | | Enumerated (Fixed, Flexible) | |
| >>Timing Offset | MD | | Integer(0..38144 by step of 256) | Chip<br>Delay of the Secondary CCPCH relative to the Primary CCPCH.<br>Default value is 0. |
| >1.28 Mcps TDD or 3.84 Mcps TDD | | | | |
| >>Offset | MP | | Integer (0...Repetition Period -1) | SFN modulo Repetition period = offset. Repetition period is the one indicated in the accompanying Common timeslot info IE |
| >>Common timeslot info | MP | | Common timeslot info 10.3.6.10 | |
| >>Individual timeslot info | MP | | Individual timeslot info 10.3.6.37 | |
| >>Code List | MP | 1 to 16 | | |
| >>>Channelisation Code | MP | | Enumerated((16/1)..(16/16)) | |
| >7.68 Mcps TDD | | | | REL-7 |
| >>Offset | MP | | Integer (0...Repetition Period -1) | SFN modulo Repetition period = offset. Repetition period is the one indicated in the accompanying Common timeslot info IE |
| >>Common timeslot info | MP | | Common timeslot info 10.3.6.10 | |
| >>Individual timeslot info | MP | | Individual timeslot info 10.3.6.37 | |
| >>Code List | MP | 1 to 32 | | |
| >>>Channelisation Code | MP | | Enumerated((32/1)..(32/32)) | |

### 10.3.6.71a Secondary CCPCH info MBMS

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| CHOICE *mode* | MP | | | | REL-6 |
| >FDD | | | | | REL-6 |
| >>Secondary scrambling code | OP | | Secondary scrambling code 10.3.6.74 | May only be sent for SCCPCH channels not carrying the PCH. | REL-6 |
| >>STTD indicator | MP | | STTD Indicator 10.3.6.78 | | REL-6 |
| >>Spreading factor | MP | | Integer(4, 8, 16, 32, 64, 128, 256) | | REL-6 |
| >>Code number | MP | | Integer(0..Spreading factor – 1) | | REL-6 |
| >>Timing Offset | MD | | Integer(0..38144 by step of 256) | Chip Delay of the Secondary CCPCH relative to the Primary CCPCH. Default value is 0. | REL-6 |
| >TDD | | | | | REL-6 |
| >>Downlink Timeslots and Codes | MP | | Downlink timeslots and codes 10.3.6.32 | One or more timeslots and codes for S-CCPCH supporting MBMS MTCHSFN | REL-6 |

NOTE: For FDD, the S-CCPCH signalled in this IE is always configured with flexible position, TFCI is always present and pilot is always absent.

### 10.3.6.72 Secondary CCPCH system information

| Information element | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| Secondary CCPCH system information list | MP | 1 to <maxSCCPCH> | | | |
| >Secondary CCPCH info | MP | | Secondary CCPCH info 10.3.6.71 | Note 1 | |
| >TFCS | MD | | Transport format combination set 10.3.5.20 | For FACHs and PCH<br>Default value is the value of "TFCS" for the previous SCCPCH in the list.<br>NOTE: The first occurrence is then MP. | |
| >FACH/PCH information list | MD | 1 to <maxFACHPCH> | | Default value is the value of "FACH/PCH" for the previous SCCPCH in the list.<br>NOTE: The first occurrence is then MP. | |
| >>TFS | MP | | Transport format set 10.3.5.23 | For each FACH and PCH<br>Note 2 | |
| >>Transport channel identity | MP | | Transport channel identity 10.3.5.18 | | |
| >>CTCH indicator | MP | | Boolean | The value "TRUE" indicates that a CTCH is mapped on the FACH, and "FALSE" that no CTCH is mapped. | |
| >PICH info | OP | | PICH info 10.3.6.49 | PICH info is present only when PCH is multiplexed on Secondary CCPCH | |
| MCCH configuration information | CV-SIB type 5 | | MCCH configuration information 10.3.9a.13 | Included if MCCH is on an S-CCPCH used also for Non-MBMS<br>Note 3 | REL-6 |

NOTE 1: The secondary CCPCHs carrying a PCH shall be listed first.

NOTE 2: TFS for PCH shall be the first "FACH/PCH information" in the list if a PCH exists for the respective secondary CCPCH.

NOTE 3: If the IE "MCCH configuration information is included", it applies to the last S-CCPCH in the IE "Secondary CCPCH system information list" and to the last FACH included in the IE "FACH/PCH information list".

| Condition | Explanation |
|---|---|
| *SIB type 5* | The IE is optional if the IE " Secondary CCPCH system information" is included in the SIB type 5, otherwise the IE is not needed in the message |

### 10.3.6.72a Secondary CCPCH system information MBMS

| Information element | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| Secondary CCPCH system information | MP | | | An S-CCPCH carrying MCCH and possibly also MTCH and MSCH | REL-6 |
| >Secondary CCPCH info MBMS | MP | | Secondary CCPCH info MBMS 10.3.6.71a | | REL-6 |
| >TFCS | MP | | Transport format combination set 10.3.5.20 | | REL-6 |
| >FACH carrying MCCH | MP | | | | REL-6 |
| >>TFS | MP | | Transport format set 10.3.5.23 | | REL-6 |
| >>MCCH configuration information | MP | | MCCH configuration information 10.3.9a.13 | | REL-6 |
| >FACH carrying MTCH list | OP | 1 to <maxFACHPCH> | | | REL-6 |
| >>TFS | MP | | Transport format set 10.3.5.23 | | REL-6 |
| >Scheduling information | OP | | | | REL-6 |
| >>FACH carrying MSCH | MP | | Transport format set 10.3.5.23 | Transport channel carrying MSCH | REL-6 |
| >>MSCH configuration information | MP | | MSCH configuration information 10.3.9a.16 | | REL-6 |

### 10.3.6.73 Secondary CPICH info

NOTE: Only for FDD.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Secondary scrambling code | MD | | Secondary scrambling code 10.3.6.74 | Default is the same scrambling code as for the Primary CPICH |
| Channelisation code | MP | | Integer(0..255) | SF=256 |

### 10.3.6.74 Secondary scrambling code

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Secondary scrambling code | MP | | Integer(1..15) | |

### 10.3.6.74a Serving HS-DSCH cell information

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| $\Delta_{ACK}$ | OP | | Integer(0..8) | Refer to quantization of the power offset in [28] | REL-6 |
| $\Delta_{NACK}$ | OP | | Integer(0..8) | Refer to quantization of the power offset in [28] | REL-6 |
| HARQ_preamble_mode | MP | | Integer(0, 1) | 1 indicates that preamble and postamble are used on the HS-DPCCH – see [29] | REL-6 |
| Primary CPICH info | OP | | Primary CPICH info 10.3.6.60 | Indicate the new HS-DSCH serving cell | REL-6 |
| Downlink HS-PDSCH Information | OP | | Downlink HS_PDSCH Information 10.3.6.23a | | REL-6 |
| HARQ Info | OP | | HARQ info 10.3.5.7a | | REL-6 |
| MAC-hs reset indicator | OP | | Enumerated (true) | TRUE Indicates the MAC-hs entity needs to be reset. | REL-6 |

### 10.3.6.75 SFN Time info

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Activation time SFN | MP | | Integer (0..4095) | System frame number start of the physical channel existence. |
| Duration | MP | | Integer(1..4096) | Total number of frames the physical channel will exist. |

### 10.3.6.75a Special Burst Scheduling

NOTE: Only for TDD.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Special Burst Generation Period | MP | | Integer (0..7) | Value represents number of radio frames<br>0 = 2 frames, 1 = 4 frames,<br>2 = 8 frames, 3 = 16 frames,<br>4 = 32 frames, 5 = 64 frames,<br>6 = 128 frames, 7 =256 frames |

### 10.3.6.76 Void

### 10.3.6.77 Void

### 10.3.6.78 STTD indicator

NOTE: Only for FDD

Indicates whether STTD is used or not.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| STTD Indicator | MP | | Boolean | TRUE means that STTD is used |

### 10.3.6.78a SYNC_UL info

NOTE: Only for 1.28 Mcps TDD.

| Information Element/ Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| SYNC_UL codes bitmap | MP | | Bitstring(8) | Each bit indicates availability of a SYNC_UL code, where the SYNC_UL codes are numbered "code 0" to "code 7".<br>The value 1 of a bit indicates that the corresponding SYNC_UL code can be used.<br>The value 0 of a bit indicates that the corresponding SYNC_UL code can not be used. | REL-4 |
| $PRX_{UpPCHdes}$ | MP | | Integer(-120…-58 by step of 1) | In dBm | REL-4 |
| Power Ramp Step | MP | | Integer(0,1,2,3) | In dB | REL-4 |
| Max SYNC_UL Transmissions | MP | | Integer(1,2,4,8) | Maximum numbers of SYNC_UL transmissions in a power ramping sequence. | REL-4 |
| Mmax | MP | | Integer(1..32) | Maximum number of synchronisation attempts. | REL-4 |

### 10.3.6.79 TDD open loop power control

This information element contains parameters for open loop power control setting for TDD.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| Primary CCPCH Tx Power | MP | | Primary CCPCH Tx Power 10.3.6.59 | For path loss calculation | |
| CHOICE *TDD option* | MP | | | | REL-4 |
| >3.84 Mcps TDD | | | | | REL-4 |
| >>Alpha | OP | | Alpha 10.3.6.5 | | |
| >>PRACH Constant Value | MP | | Constant Value TDD 10.3.6.11a | Operator controlled PRACH Margin | |
| >>DPCH Constant Value | MP | | Constant | Operator | |

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| | | | Value TDD 10.3.6.11a | controlled UL DPCH Margin | |
| >>PUSCH Constant Value | OP | | Constant Value TDD 10.3.6.11a | Operator controlled PUSCH Margin | |
| >>UE positioning related parameters | CV-*IPDLs* | | | | REL-4 |
| >>>IPDL-Alpha | MP | | Alpha 10.3.6.5 | | REL-4 |
| >>>Max power increase | MP | | Integer (0..3) | In db | REL-4 |
| >7.68 Mcps TDD | | | | | REL-7 |
| >>Alpha | OP | | Alpha 10.3.6.5 | | |
| >>PRACH Constant Value | MP | | Constant Value TDD 10.3.6.11a | Operator controlled PRACH Margin | |
| >>DPCH Constant Value | MP | | Constant Value TDD 10.3.6.11a | Operator controlled UL DPCH Margin | |
| >>PUSCH Constant Value | OP | | Constant Value TDD 10.3.6.11a | Operator controlled PUSCH Margin | |
| >>UE positioning related parameters | CV-*IPDLs* | | | | |
| >>>IPDL-Alpha | MP | | Alpha 10.3.6.5 | | |
| >1.28 Mcps TDD | | | | (no data) | REL-4 |

| Condition | Explanation |
|---|---|
| *IPDLs* | This IE is present only if idle periods are applied |

### 10.3.6.80 TFC Control duration

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| TFC Control duration | MP | | Integer (1, 2, 4, 8, 16, 24, 32, 48, 64, 128, 192, 256, 512) | Defines the period in multiples of 10 ms frames for which the defined TFC sub-set is to be applied. |

### 10.3.6.81 Void

### 10.3.6.82 TGPSI

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| TGPSI | MP | | Integer(1..MaxTGPS) | Transmission Gap Pattern Sequence Identifier Establish a reference to the compressed mode pattern sequence. Up to <MaxTGPS> simultaneous compressed mode pattern sequences can be used. |

### 10.3.6.83 Time info

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Activation time | MD | | Activation time 10.3.3.1 | Frame number start of the physical channel existence. Default value is "Now" |
| Duration | MD | | Integer(1..4096, infinite) | Total number of frames the physical channel will exist. Default value is "infinite". |

### 10.3.6.84 Timeslot number

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| CHOICE *TDD option* | MP | | | | REL-4 |
| >3.84 Mcps TDD | | | | | REL-4 |
| >>Timeslot number | MP | | Integer(0..14) | Timeslot within a frame | |
| >7.68 Mcps TDD | | | | | REL-7 |
| >>Timeslot number | MP | | Integer(0..14) | Timeslot within a frame | |
| >1.28 Mcps TDD | | | | | REL-4 |
| >>Timeslot number | MP | | Integer(0..6) | Timeslot within a subframe | REL-4 |

### 10.3.6.85 TPC combination index

NOTE: Only for FDD.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| TPC combination index | MP | | Integer(0..5) | Radio links with the same index have TPC bits, which for the UE are known to be the same. | |
| | | | | Radio links that are part of the E-DCH active set and with the same index have acknowledgement feedback signals on the E-HICH which for the UE are known to be the same. | REL-6 |

### 10.3.6.85a TSTD indicator

NOTE: Only for 1.28 Mcps TDD.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| TSTD indicator | MD | | Boolean | Default value is "TRUE" | REL-4 |

### 10.3.6.86 TX Diversity Mode

NOTE: Only for FDD.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Tx diversity Mode | MP | | Enumerated (none, STTD, closed loop mode1) | |

### 10.3.6.87 UL interference

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| UL interference | MP | | Integer (-110..-70) | In dBm |

NOTE: In TDD, this IE is a timeslot specific value.

### 10.3.6.87a UL interference TDD

NOTE: Only for TDD.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| TDD UL interference | MP | | Integer (-110..-52) | In dBm |

NOTE: This IE is a timeslot specific value.

### 10.3.6.88 Uplink DPCH info

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| Uplink DPCH power control info | OP | | Uplink DPCH power control info 10.3.6.91 | | |
| CHOICE *mode* | MP | | | | |
| >FDD | | | | | |
| >>Scrambling code type | MP | | Enumerated(short, long) | | |
| >>Scrambling code number | MP | | Integer(0..16777215) | | |
| >>Number of DPDCH | MD | | Integer(0..maxDPDCH-UL) | Default value is 1. Number of DPDCH is 1 in HANDOVER TO UTRAN COMMAND. Value 0 may only be used if target configuration has no uplink DPDCH. | |
| >>Spreading factor | *CV-DPDCH present* | | Integer(4, 8, 16, 32, 64, 128, 256) | Minimum allowed SF of the channelisation code for data part | |
| >>TFCI existence | MP | | Boolean | TRUE means existence. | |
| >>Number of FBI bits | OP | | Integer (1, 2) | In bits. | |
| >>Puncturing Limit | *CV-DPDCH present* | | Real(0.40..1 by step of 0.04) | | |
| >1.28 Mcps TDD or 3.84 Mcps TDD | | | | | |
| >>Uplink Timing Advance Control | OP | | Uplink Timing Advance Control 10.3.6.96 | | |
| >>UL CCTrCH List | OP | 1 to <maxCCTrCH> | | UL physical channels to establish or reconfigure list. | |
| >>>TFCS ID | MD | | Integer(1..8) | Default value is 1. | |
| >>>UL target SIR | MP | | Real (-11 .. 20 by step of 0.5dB) | In dB | |
| | | | | For 1.28 Mcps TDD this parameter represents $PRX_{DPCHdes}$ with range Integer(-120…-58 by step of 1) dBm | REL-4 |
| >>>Time info | MP | | Time info 10.3.6.83 | | |
| >>>Common timeslot info | MD | | Common timeslot info 10.3.6.10 | Default is the current Common timeslot info | |
| >>> CHOICE TDD option | | | | | REL-7 |
| >>>> 3.84 Mcps TDD | | | | | REL-7 |
| >>>>>Uplink DPCH timeslots and codes | MD | | Uplink Timeslots and | Default is to use the old timeslots and codes. | |

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| | | | Codes 10.3.6.94 | | |
| >>>> 1.28 Mcps TDD | | | | | REL-7 |
| >>>>>Uplink DPCH timeslots and codes LCR | MD | | Uplink Timeslots and Codes LCR 10.3.6.94a | Default is to use the old timeslots and codes. | REL-7 |
| >>UL CCTrCH List to Remove | OP | 1..<maxCCTrCH> | | UL physical channels to remove list | |
| >>>TFCS ID | MP | | Integer(1..8) | | |
| >7.68 Mcps TDD | | | | | |
| >>Uplink Timing Advance Control | OP | | Uplink Timing Advance Control 10.3.6.96 | | |
| >>UL CCTrCH List | OP | 1 to <maxCCTrCH> | | UL physical channels to establish or reconfigure list. | |
| >>>TFCS ID | MD | | Integer(1..8) | Default value is 1. | |
| >>>UL target SIR | MP | | Real (-11 .. 20 by step of 0.5dB) | In dB | |
| | | | | For 1.28 Mcps TDD this parameter represents $PRX_{DPCHdes}$ with range Integer(-120…-58 by step of 1) dBm | REL-4 |
| >>>Time info | MP | | Time info 10.3.6.83 | | |
| >>>Common timeslot info | MD | | Common timeslot info 10.3.6.10 | Default is the current Common timeslot info | |
| >>>Uplink DPCH timeslots and codes VHCR | MD | | Uplink Timeslots and Codes VHCR 10.3.6.94b | Default is to use the old timeslots and codes. | |
| >>UL CCTrCH List to Remove | OP | 1..<maxCCTrCH> | | UL physical channels to remove list | |
| >>>TFCS ID | MP | | Integer(1..8) | | |

| Condition | Explanation |
|---|---|
| *DPDCHpresent* | This IE is mandatory if the target configuration includes a DPDCH, otherwise it is not needed. |

### 10.3.6.89 Uplink DPCH info Post

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Uplink DPCH power control info | MP | | Uplink DPCH power control info Post 10.3.6.92 | |
| CHOICE *mode* | MP | | | |
| >FDD | | | | |
| >>Scrambling code type | MP | | Enumerated( short, long) | |
| >>Reduced scrambling code number | MP | | Integer(0..8191) | Sub-range of values for initial use upon handover to UTRAN. |
| >>Spreading factor | MP | | Integer(4, 8, 16, 32, 64, 128, 256) | SF of the channelisation code for data part<br>There is only one DPDCH for this case |
| >1.28 Mcps TDD and 3.84 Mcps TDD | | | | |
| >>Uplink Timing Advance Control | OP | | Uplink Timing Advance Control 10.3.6.96 | |
| >>Uplink DPCH timeslots and codes | MP | | Uplink Timeslots and Codes 10.3.6.94 | |
| >7.68 Mcps TDD | | | | |
| >>Uplink Timing Advance Control | OP | | Uplink Timing Advance Control 10.3.6.96 | |
| >>Uplink DPCH timeslots and codes | MP | | Uplink Timeslots and Codes VHCR 10.3.6.94b | |

### 10.3.6.90 Uplink DPCH info Pre

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Uplink DPCH power control info | OP | | Uplink DPCH power control info Pre 10.3.6.93 | |
| CHOICE *mode* | MP | | | |
| >FDD | | | | |
| >>TFCI existence | MP | | Boolean | TRUE means existence.<br>Default value is "TRUE" |
| >>Puncturing Limit | MP | | Real(0.40 ..1 by step of 0.04) | |
| >TDD | | | | |
| >>Common timeslot info | MP | | Common Timeslot Info 10.3.6.10 | |

| Condition | Explanation |
|---|---|
| *Single* | This IE is mandatory present if the IE "Number of DPDCH" is "1" and not needed otherwise. |

### 10.3.6.91 Uplink DPCH power control info

Parameters used by UE to set DPCH initial output power and to use for closed-loop power control in FDD and 1.28 Mcps TDD and parameters for uplink open loop power control in 3.84 Mcps TDD and 7.68 Mcps TDD.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| CHOICE *mode* | MP | | | | |
| >FDD | | | | | |
| >>DPCCH Power offset | MP | | Integer(-164,..-6 by step of 2) | In dB | |
| >>PC Preamble | MP | | Integer (0..7) | In number of frames | |
| >>SRB delay | MP | | Integer(0..7) | In number of frames | |
| >>Power Control Algorithm | MP | | Enumerated (algorithm 1, algorithm 2) | Specifies algorithm to be used by UE to interpret TPC commands | |
| >>TPC step size | CV-*algo* | | Integer (1, 2) | In dB | |
| >>$\Delta_{ACK}$ | OP | | Integer (0..8) | Refer to quantization of the power offset in [28] | REL-5 |
| >>$\Delta_{NACK}$ | OP | | Integer (0..8) | refer to quantization of the power offset in [28] | REL-5 |
| >>Ack-Nack repetition factor | OP | | Integer(1..4) | | REL-5 |
| >>HARQ_preamble_mode | MP | | Integer (0, 1) | 1 indicates that preamble and postamble are used on the HS-DPCCH – see [29] | REL-6 |
| >TDD | | | | | |
| >>>>UL target SIR | OP | | Real (-11 .. 20 by step of 0.5dB) | In dB | |
| | | | | For 1.28 Mcps TDD this parameter represents $PRX_{DPCHdes}$ with range Integer(-120…-58 by step of 1) dBm | REL-4 |
| >>CHOICE *UL OL PC info* | MP | | | | |
| >>>Broadcast UL OL PC info | | | Null | No data | |
| >>>Individually Signalled | OP | | | | |
| >>>>CHOICE *TDD option* | MP | | | | REL-4 |
| >>>>>3.84 Mcps TDD | | | | | REL-4 |
| >>>>>>Individual timeslot interference info | MP | 1 to <maxTS> | | | |
| >>>>>>>Individual timeslot interference | MP | | Individual timeslot interference 10.3.6.38 | | |
| >>>>>>DPCH Constant Value | OP | | Constant Value TDD 10.3.6.11a | Quality Margin | |
| >>>>>7.68 Mcps TDD | | | | | REL-7 |

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| >>>>>>Individual timeslot interference info | MP | 1 to <maxTS> | | | |
| >>>>>>>Individual timeslot interference | MP | | Individual timeslot interference 10.3.6.38 | | |
| >>>>>>DPCH Constant Value | OP | | Constant Value TDD 10.3.6.11a | Quality Margin | |
| >>>>>1.28 Mcps TDD | | | | | REL-4 |
| >>>>>>Beacon PL Est. | CV-houtran | | Enumerated (true) | The presence of this IE indicates that the UE may take into account path loss estimated from beacon function physical channels. The absence indicates that UE may not take into account path loss estimated from beacon function physical channels | REL-6 |
| >>>>>>TPC step size | MP | | Integer(1,2,3) | | REL-4 |
| >>>>Primary CCPCH Tx Power | OP | | Primary CCPCH Tx Power 10.3.6.59 | For Pathloss Calculation | |

| Condition | Explanation |
|---|---|
| *algo* | The IE is mandatory present if the IE "Power Control Algorithm" is set to "algorithm 1", otherwise the IE is not needed |
| *houtran* | This IE is optional in Cell Update Confirm, Physical Channel Reconfiguration, Radio Bearer Reconfiguration, Radio Bearer Release, Radio Bearer Setup, Transport Channel Reconfiguration and Uplink Physical Channel Control. The IE is not included in the Handover To UTRAN Command |

### 10.3.6.92 Uplink DPCH power control info Post

Parameters used by UE to set DPCH initial output power and to use for closed-loop power control.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| CHOICE *mode* | MP | | | | |
| >FDD | | | | | |
| >>DPCCH Power offset | MP | | Integer(-110..-50 by step of 4) | In dB | |
| >>PC Preamble | MP | | Integer (0..7) | in number of frames | |
| >>SRB delay | MP | | Integer (0..7) | In number of frames | |
| >TDD | | | | | |
| >>UL target SIR | MP | | Real (-11 .. | In dB | |

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| | | | 20 by step of 0.5dB) | For 1.28 Mcps TDD this parameter represents $PRX_{DPCHdes}$ with range Integer(-120…-58 by step of 1) dBm | REL-4 |
| >>CHOICE *TDD option* | MP | | | | REL-4 |
| >>>3.84 Mcps TDD | | | | | REL-4 |
| >>>>UL Timeslot Interference | MP | | UL Interference TDD 10.3.6.87a | | |
| >>>7.68 Mcps TDD | | | | | REL-7 |
| >>>>UL Timeslot Interference | MP | | UL Interference TDD 10.3.6.87a | | |
| >>>1.28 Mcps TDD | | | | (no data) | REL-4 |

| Condition | Explanation |
|---|---|
| *algo* | The IE is mandatory present if the IE "Power Control Algorithm" is set to "algorithm 1", otherwise the IE is not needed |

## 10.3.6.93 Uplink DPCH power control info Pre

Parameters used by UE to set DPCH initial output power and to use for closed-loop power control in FDD and parameters for uplink open loop power control in 3.84 Mcps TDD and 7.68 Mcps TDD.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| CHOICE *mode* | MP | | | | |
| >FDD | | | | | |
| >>Power Control Algorithm | MP | | Enumerated (algorithm 1, algorithm 2) | Specifies algorithm to be used by UE to interpret TPC commands | |
| >>TPC step size | CV-*algo* | | Integer (1, 2) | In dB | |
| >TDD | | | | (No data) | |
| >>CHOICE *TDD option* | MP | | | | REL-4 |
| >>>3.84 Mcps TDD | | | | | REL-4 |
| >>DPCH Constant Value | MP | | Constant Value TDD 10.3.6.11a | Quality Margin | |
| >>>7.68 Mcps TDD | | | | | REL-7 |
| >>DPCH Constant Value | MP | | Constant Value TDD 10.3.6.11a | Quality Margin | |
| >>>1.28 Mcps TDD | | | | (no data) | REL-4 |

| Condition | Explanation |
|---|---|
| *algo* | The IE is mandatory present if the IE "Power Control Algorithm" is set to "algorithm 1", otherwise the IE is not needed |

### 10.3.6.94 Uplink Timeslots and Codes

NOTE: Only for 1.28 Mcps TDD and 3.84 Mcps TDD.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Dynamic SF usage | MP | | Boolean | |
| First Individual timeslot info | MP | | Individual timeslot info 10.3.6.37 | Individual timeslot info for the first timeslot used by the physical layer. |
| First timeslot Code List | MP | 1..2 | | Code list used in the timeslot. given in First individual timeslot info. |
| >Channelisation Code | MP | | Enumerated( (1/1),)(2/1),( 2/2),(4/1)..(4/ 4),(8/1)..(8/8) ,(16/1)..(16/1 6)) | |
| CHOICE *more timeslots* | MP | | | |
| >No more timeslots | | | | (no data) |
| >Consecutive timeslots | | | | |
| >>Number of additional timeslots | MP | | Integer(1..m axTS-1) | The timeslots used by the physical layer shall be timeslots:<br>N mod maxTS<br>(N+1) mod maxTS<br>...<br>(N+k) mod maxTS<br>in that order, where N is the timeslot number in the First individual timeslot info and k the Number of additional timeslots.<br>The additional timeslots shall use the same parameters (e.g. channelisation codes, midamble shifts etc.) as the first timeslot. |
| >Timeslot list | | | | |
| >>Additional timeslot list | MP | 1 to <maxTS-1> | | The first instance of this parameter corresponds to the timeslot that shall be used second by the physical layer, the second to the timeslot that shall be used third and so on. |
| >>>CHOICE *parameters* | MP | | | |
| >>>>Same as last | | | | |
| >>>>>Timeslot number | MP | | Timeslot Number 10.3.6.84 | This physical layer shall use the same parameters (e.g. channelisation codes, midamble shifts etc.) for this timeslot as for the last one. |
| >>>>New parameters | | | | |
| >>>>>Individual timeslot info | MP | | Individual timeslot info 10.3.6.37 | |
| >>>>>Code List | MP | 1..2 | | |
| >>>>>>Channelisation Code | MP | | Enumerated( (1/1),)(2/1),( 2/2),(4/1)..(4/ 4),(8/1)..(8/8) ,(16/1)..(16/1 6)) | |

### 10.3.6.94a Uplink Timeslots and Codes LCR

NOTE: Only for 1.28 Mcps TDD

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Dynamic SF usage | MP | | Boolean | |
| First Individual timeslot info | MP | | Individual timeslot info 10.3.6.37 | Individual timeslot info for the first timeslot used by the physical layer. |
| First timeslot Code List | MP | 1..2 | | Code list used in the timeslot. given in First individual timeslot info. |
| >Channelisation Code | MP | | Enumerated((1/1),)(2/1),(2/2),(4/1)..(4/4),(8/1)..(8/8),(16/1)..(16/16)) | |
| >PLCCH Info | CV-no_DL_DPCH | | PLCCH Info 10.3.6.50a | |
| CHOICE *more timeslots* | MP | | | |
| >No more timeslots | | | | (no data) |
| >Consecutive timeslots | | | | |
| >>Number of additional timeslots | MP | | Integer(1..maxTS-1) | The timeslots used by the physical layer shall be timeslots:<br>N mod maxTS<br>(N+1) mod maxTS<br>…<br>(N+k) mod maxTS<br>in that order, where N is the timeslot number in the First individual timeslot info and k the Number of additional timeslots.<br>The additional timeslots shall use the same parameters (e.g. channelisation codes, midamble shifts etc.) as the first timeslot. |
| >Timeslot list | | | | |
| >>Additional timeslot list | MP | 1 to <maxTS-1> | | The first instance of this parameter corresponds to the timeslot that shall be used second by the physical layer, the second to the timeslot that shall be used third and so on. |
| >>>CHOICE *parameters* | MP | | | |
| >>>>Same as last | | | | |
| >>>>>Timeslot number | MP | | Timeslot Number 10.3.6.84 | This physical layer shall use the same parameters (e.g. channelisation codes, midamble shifts etc.) for this timeslot as for the last one. |
| >>>>New parameters | | | | |
| >>>>>Individual timeslot info | MP | | Individual timeslot | |

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| | | | info 10.3.6.37 | |
| >>>>>Code List | MP | 1..2 | | |
| >>>>>>Channelisation Code | MP | | Enumerated((1/1),)(2/1),(2/2),(4/1)..(4/4),(8/1)..(8/8),(16/1)..(16/16)) | |
| >>>>>> PLCCH Info | CV-no_DL_DPCH | | PLCCH Info 10.3.6.50a | Default is same as set of parameter values as assigned to last timeslot |

| Condition | Explanation |
|---|---|
| *No_DL_DPCH* | This IE is mandatory present for 1.28 Mcps TDD only in the case that Uplink Timeslots and Codes are assigned for UL DPCH and no DL DPCH is allocated to the UE. |

## 10.3.6.94b Uplink Timeslots and Codes VHCR

NOTE: Only for 7.68 Mcps TDD

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Dynamic SF usage | MP | | Boolean | |
| First Individual timeslot info | MP | | Individual timeslot info 10.3.6.37 | Individual timeslot info for the first timeslot used by the physical layer. |
| First timeslot Code List | MP | 1..2 | | Code list used in the timeslot. given in First individual timeslot info. |
| >Channelisation Code | MP | | Enumerated((1/1),)(2/1),(2/2),(4/1)..(4/4),(8/1)..(8/8.16/1) .. (16/16).(32/1)..(32/32)) | |
| CHOICE *more timeslots* | MP | | | |
| >No more timeslots | | | | (no data) |
| >Consecutive timeslots | | | | |
| >>Number of additional timeslots | MP | | Integer(1..maxTS-1) | The timeslots used by the physical layer shall be timeslots:<br>N mod maxTS<br>(N+1) mod maxTS<br>...<br>(N+k) mod maxTS<br>in that order, where N is the timeslot number in the First individual timeslot info and k the Number of additional timeslots.<br>The additional timeslots shall use the same parameters (e.g. channelisation codes, midamble shifts etc.) as the first timeslot. |
| >Timeslot list | | | | |
| >>Additional timeslot list | MP | 1 to | | The first instance of this |

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| | | <maxTS-1> | | parameter corresponds to the timeslot that shall be used second by the physical layer, the second to the timeslot that shall be used third and so on. |
| >>>CHOICE *parameters* | MP | | | |
| >>>>Same as last | | | | |
| >>>>>Timeslot number | MP | | Timeslot Number 10.3.6.84 | This physical layer shall use the same parameters (e.g. channelisation codes, midamble shifts etc.) for this timeslot as for the last one. |
| >>>>New parameters | | | | |
| >>>>>Individual timeslot info | MP | | Individual timeslot info 10.3.6.37 | |
| >>>>>Code List | MP | 1..2 | | |
| >>>>>>Channelisation Code | MP | | Enumerated( (1/1),)(2/1),( 2/2),(4/1)..(4/ 4),(8/1)..(8/8) .(16/1).. (16/16).(32/1 )..(32/32)) | |

## 10.3.6.95 Uplink Timing Advance

NOTE: Only for 3.84 Mcps TDD.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| UL Timing Advance | MP | | Integer (0..63) | Absolute timing advance value to be used to avoid large delay spread at the NodeB | |

## 10.3.6.95a Uplink Timing Advance VHCR

NOTE: Only for 7.68 Mcps TDD.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| UL Timing Advance | MP | | Integer (0..127) | Absolute timing advance value to be used to avoid large delay spread at the NodeB | |

## 10.3.6.96 Uplink Timing Advance Control

NOTE: Only for TDD

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| CHOICE *Timing Advance* | MP | | | | |
| >Disabled | | | Null | Indicates that no timing advance is applied | |
| >Enabled | | | | | |

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| >>CHOICE *TDD option* | MP | | | | REL-4 |
| >>>3.84 Mcps TDD | | | | | REL-4 |
| >>>>UL Timing Advance | MD | | Uplink Timing Advance 10.3.6.95 | Absolute timing advance value to be used to avoid large delay spread at the NodeB. Default value is the existing value for uplink timing advance. | |
| >>>>Activation Time | OP | | Activation Time 10.3.3.1 | Frame number timing advance is to be applied. This IE is required when a new UL Timing Advance adjustment is specified and Activation Time is not otherwise specified in the RRC message. | |
| >>>7.68 Mcps TDD | | | | | REL-7 |
| >>>>UL Timing Advance | MD | | Uplink Timing Advance 10.3.6.95a | Absolute timing advance value to be used to avoid large delay spread at the NodeB. Default value is the existing value for uplink timing advance. | |
| >>>>Activation Time | OP | | Activation Time 10.3.3.1 | Frame number timing advance is to be applied. This IE is required when a new UL Timing Advance adjustment is specified and Activation Time is not otherwise specified in the RRC message. | |
| >>1.28 Mcps TDD | | | | (no data) | REL-4 |
| >>>Uplink synchronisation parameters | MD | | | Default: Uplink synchronisation step size is 1. Uplink synchronisation frequency is 1. | REL-4 |
| >>>>Uplink synchronisation step size | MP | | Integer(1..8) | This parameter specifies the step size to be used for the adjustment of the uplink transmission timing | REL-4 |
| >>>>Uplink synchronisation frequency | MP | | Integer(1..8) | This parameter specifies the frequency of the adjustment of the uplink transmission timing | REL-4 |

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| >>>Synchronisation parameters | OP | | | | |
| >>>>SYNC_UL codes bitmap | MP | | Bitstring(8) | Each bit indicates availability of a SYNC_UL code, where the SYNC_UL codes are numbered "code 0" to "code 7".<br>The value 1 of a bit indicates that the corresponding SYNC_UL code can be used.<br>The value 0 of a bit indicates that the corresponding SYNC_UL code can not be used. | REL-4 |
| >>>>FPACH info | MP | | FPACH info 10.3.6.35a | | REL-4 |
| >>>>$PRX_{UpPCHdes}$ | MP | | Integer(-120…-58 by step of 1) | In dBm | REL-4 |
| >>>>SYNC_UL procedure | MD | | | Default is: Max SYNC_UL Transmission is 2. Power Ramp Step is 2. | REL-4 |
| >>>>>Max SYNC_UL Transmissions | MP | | Integer(1,2,4,8) | Maximum numbers of SYNC_UL transmissions in a power ramping sequence. | REL-4 |
| >>>>>Power Ramp Step | MP | | Integer(0,1,2,3) | In dB | REL-4 |

### 10.3.6.97 E-DCH Info

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| MAC-es/e reset indicator | OP | | Enumerated (true) | TRUE Indicates the MAC-es/e entity needs to be reset. | REL-6 |
| E-DPCCH info | OP | | E-DPCCH Info 10.3.6.98 | | REL-6 |
| E-DPDCH info | OP | | E-DPDCH info 10.3.6.99 | | REL-6 |
| Scheduled Transmission configuration | OP | | | | REL-6 |
| >2ms scheduled transmission grant HARQ process allocation | MD | | Bitstring (8) | MAC-d PDUs belonging to MAC-d flows not configured with a 'Max MAC-e PDU contents size' are only allowed to be transmitted in those processes for which the bit is set to '1'.<br>Bit 0 corresponds to HARQ process 0, bit 1 corresponds to HARQ process 1,…<br>Default value is: transmission in all HARQ processes is allowed. Bit 0 is the first/leftmost bit of the bit string. | REL-6 |
| >Serving Grant | OP | | | | REL-6 |
| >>Serving Grant value | MP | | Integer (0..37,38) | (0..37) indicates E-DCH serving grant index as defined in [15]; index 38 means zero grant. | REL-6 |
| >>Primary/Secondary Grant Selector | MP | | Enumerated ('primary', 'secondary') | Indicates whether the Serving Grant is received with a Primary E-RNTI or Secondary E-RNTI | REL-6 |

### 10.3.6.98 E-DPCCH Info

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| E-DPCCH/DPCCH power offset | MP | | Integer (0..8) | Refer to quantization of the power offset in [28] | REL-6 |
| Happy bit delay condition | MP | | Enumerated (2ms, 10ms,20ms, 50ms, 100ms, 200ms, 500ms, 1000ms) | To be used when determining the setting of the happy bit (see [15]) | REL-6 |

### 10.3.6.99 E-DPDCH Info

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| E-TFCI table index | MP | | Integer (0..1) | Indicates which standardised E-TFCI TB size table shall be used | REL-6 |
| E-DCH minimum set E-TFCI | MD | | Integer (0..127) | See [15]; Absence means no E-DCH minimum set | REL-6 |
| Reference E-TFCIs | MP | 1 to 8 | | See [29] | REL-6 |
| >Reference E-TFCI | MP | | Integer (0..127) | | REL-6 |
| >Reference E-TFCI PO | MP | | Integer (0..29) | Refer to quantization of the power offset in [28] | REL-6 |
| Maximum channelisation codes | MP | | Enumerated (sf256, sf128, sf64, sf32, sf16, sf8, sf4, 2sf4, 2sf2, 2sf2and2sf4) | | REL-6 |
| $PL_{non-max}$ | MP | | Real (0.44 ..1.0 by step of 0.04) | As defined in [27] | REL-6 |
| Scheduling Information Configuration | MP | | | | REL-6 |
| >Periodicity for Scheduling Info – no grant | MD | | Enumerated (everyEDCHTTI,4,10,20,50,100,200,500,1000) | Values in ms. Default value is 'no report' NOTE. | REL-6 |
| >Periodicity for Scheduling Info – grant | MD | | Enumerated (everyEDCHTTI,4,10,20,50,100,200,500,1000) | Values in ms. Default value is 'no report' NOTE. | REL-6 |
| >Power Offset for Scheduling Info | MP | | Integer (0..6) | Only used when no MACd PDUs are included in the same MACe PDU. Unit is in dB. | REL-6 |
| 3-Index-Step Threshold | MD | | Integer (0..37) | Refers to an index in the 'SG-Table' (see [15]). Default value is 0. | REL-6 |
| 2-Index-Step Threshold | MD | | Integer (0..37) | Refers to an index in the 'SG-Table' (see [15]). Default value is 0. | REL-6 |
| NOTE: If the Periodicity is set to 4ms and the E-DCH TTI is set to 10ms, the UE shall interpret the periodicity value as 10ms. | | | | | |

### 10.3.6.100 E-AGCH Info

Includes the configuration for the E-DCH related Absolute Grant Channel. The E-AGCH is using the same DL scrambling code as configured for the E-HICH channel (see subclause 10.3.6.101).

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| E-AGCH Channelisation Code | MP | | Integer (0..255) | | REL-6 |

### 10.3.6.101 E-HICH Info

Includes the configuration for the E-DCH related HARQ Acknowledgement Indicator Channel.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| Channelisation Code | MP | | Integer (0..127) | | REL-6 |
| Signature Sequence | MP | | Integer (0..39) | | REL-6 |

### 10.3.6.102 E-RGCH Info

Includes the configuration for the E-DCH related Relative Grant Channel. The E-RGCH is using the same DL scrambling code and channelisation code as configured for the E-HICH channel (see subclause 10.3.6.101).

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| Signature Sequence | MP | | Integer(0..39) | | REL-6 |
| RG combination index | MP | | Integer(0..5) | Cells with an index equal to the index of the Serving E-DCH cell belong to the Serving E-DCH RLS. The E-RGCH from these cells have RG commands which for the UE are known to be the same as the RG commands from the Serving E-DCH cell. | REL-6 |

## 10.3.7 Measurement Information elements

### 10.3.7.1 Additional measurements list

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Additional measurements | MP | 1 to <MaxAdditionalMeas> | | |
| >Additional measurement identity | MP | | Measurement identity 10.3.7.48 | |

### 10.3.7.2 Cell info

Includes non-frequency related cell info used in the IE "inter-frequency cell info list" and "intra frequency cell info list".

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| Cell individual offset | MD | | Real(-10..10 by step of 0.5) | In dB<br>Default value is 0 dB<br>Used to offset measured quantity value | |
| Reference time difference to cell | OP | | Reference time difference to cell 10.3.7.60 | In chips.<br>This IE is absent for serving cell. | |
| Read SFN indicator | MP | | Boolean | TRUE indicates that read of SFN is requested for the target cell | |
| CHOICE *mode* | MP | | | | |
| >FDD | | | | | |
| >>Primary CPICH info | OP | | Primary CPICH info 10.3.6.60 | This IE is absent only if measuring RSSI only (broadband measurement.) | |
| >>Primary CPICH Tx power | OP | | Primary CPICH Tx power 10.3.6.61 | Required if calculating pathloss. | |
| >>TX Diversity Indicator | MP | | Boolean | TRUE indicates that transmit diversity is used. | |
| >TDD | | | | | |
| >>Primary CCPCH info | MP | | Primary CCPCH info 10.3.6.57 | | |
| >>Primary CCPCH TX power | OP | | Primary CCPCH TX power 10.3.6.59 | | |
| >>Timeslot list | OP | 1 to <maxTS> | | The UE shall report Timeslot ISCP values according the order of the listed Timeslot numbers | |
| >>>CHOICE *TDD option* | MP | | | | REL-4 |
| >>>>3.84 Mcps TDD | | | | | REL-4 |
| >>>>>Timeslot number | MP | | Integer (0...14) | Timeslot numbers, for which the UE shall report Timeslot ISCP | |
| >>>>>Burst Type | MD | | Enumerated (Type1, Type2) | Use for Timeslot ISCP measurements only. Default value is "Type1" | |
| >>>>7.68 Mcps TDD | | | | | REL-7 |
| >>>>>Timeslot number | MP | | Integer (0...14) | Timeslot numbers, for which the UE shall report Timeslot ISCP | |

| | | | | | |
|---|---|---|---|---|---|
| >>>>>Burst Type | MD | | Enumerated (Type1, Type2) | Use for Timeslot ISCP measurements only. Default value is "Type1" | |
| >>>>1.28 Mcps TDD | | | | | REL-4 |
| >>>>>Timeslot number | MP | | Integer (0...6) | Timeslot numbers, for which the UE shall report Timeslot ISCP | REL-4 |
| Cell Selection and Re-selection Info | CV-*BCHopt* | | Cell Selection and Re-selection for SIB11/12Info 10.3.2.4 | This IE is absent for the serving cell. | |

| Condition | Explanation |
|---|---|
| *BCHopt* | This IE is Optional when sent in SYSTEM INFORMATION, Otherwise, the IE is not needed |

### 10.3.7.3 Cell measured results

Includes non-frequency related measured results for a cell.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| Cell Identity | OP | | Cell Identity 10.3.2.2 | | |
| Cell synchronisation information | OP | | Cell synchronisation information 10.3.7.6 | | |
| CHOICE *mode* | MP | | | | |
| >FDD | | | | | |
| >>Primary CPICH info | MP | | Primary CPICH info 10.3.6.60 | | |
| >>CPICH Ec/N0 | OP | | Integer(0..49) | According to CPICH_Ec/No in [19] and [20]. Fourteen spare values are needed. | |
| >>CPICH RSCP | OP | | Integer(0..91) | According to CPICH_RSCP in [19] and [20]. Thirty-six spare values are needed. | |
| >>$Delta_{CPICH\ RSCP}$ | CV-*RSCP* | | Integer(-5..-1) | If present, the actual value of CPICH RSCP = CPICH RSCP+ $Delta_{CPICH\ RSCP}$ | REL-5 |
| >>Pathloss | OP | | Integer(46..158) | In dB. Fifteen spare values are needed. | |
| >TDD | | | | | |
| >>Cell parameters Id | MP | | Cell parameters Id 10.3.6.9 | | |
| >>Proposed TGSN | OP | | Integer | Proposal for the next | |

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| | | | (0..14) | TGSN | |
| >>Primary CCPCH RSCP | OP | | Primary CCPCH RSCP info 10.3.7.54 | | |
| >>Pathloss | OP | | Integer(46 ..158) | In dB. Fifteen spare values are needed. | |
| >>Timeslot list | OP | 1 to < maxTS> | | | |
| >>>Timeslot ISCP | MP | | Timeslot ISCP Info 10.3.7.65 | The UE shall report the Timeslot ISCP in the same order as indicated in the cell info | |

| Condition | Explanation |
|---|---|
| *RSCP* | This IE is mandatory if the IE "Cell measured results" is included in the IE "Measured Results" (i.e. not included in the IE "Additional Measured Results") and if CPICH RSCP is present and if the value of the CPICH RSCP is below 0. It is not needed otherwise. |

### 10.3.7.4 Cell measurement event results

Includes non-frequency related cell reporting quantities.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| CHOICE *mode* | MP | | | |
| >FDD | | | | |
| >>Primary CPICH info | MP | 1 to <maxCellMeas> | Primary CPICH info 10.3.6.60 | |
| >TDD | | | | |
| >>Primary CCPCH info | MP | 1 to <maxCellMeas> | Primary CCPCH info 10.3.6.57 | |

### 10.3.7.5 Cell reporting quantities

Includes non-frequency related cell reporting quantities.

For all boolean types TRUE means inclusion in the report is requested.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Cell synchronisation information reporting indicator | MP | | Boolean | |
| Cell Identity reporting indicator | MP | | Boolean | |
| CHOICE *mode* | MP | | | |
| >FDD | | | | |
| >>CPICH Ec/N0 reporting indicator | MP | | Boolean | |
| >>CPICH RSCP reporting indicator | MP | | Boolean | |
| >>Pathloss reporting indicator | MP | | Boolean | |
| >TDD | | | | |

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| >>Timeslot ISCP reporting indicator | MP | | Boolean | |
| >>Proposed TGSN Reporting required | MP | | Boolean | |
| >>Primary CCPCH RSCP reporting indicator | MP | | Boolean | |
| >>Pathloss reporting indicator | MP | | Boolean | |

### 10.3.7.6 Cell synchronisation information

The IE "Cell synchronisation information" contains the OFF and Tm as defined in [7] and [8] and the four most significant bits of the difference between the 12 least significant bits of the RLC Transparent Mode COUNT-C in the UE and the SFN of the measured cell. It is notified to SRNC by Measurement Report message or Measurement Information Element in other RRC messages

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| CHOICE *mode* | MP | | | |
| >FDD | | | | |
| >>COUNT-C-SFN frame difference | OP | | | |
| >>>COUNT-C-SFN high | MP | | Integer(0..3840 by step of 256) | in frames |
| >>>OFF | MP | | Integer(0..255) | in frames |
| >>Tm | MP | | Integer(0..38399) | in chips |
| >TDD | | | | |
| >>COUNT-C-SFN frame difference | OP | | | |
| >>>COUNT-C-SFN high | MP | | Integer(0..3840 by step of 256) | in frames |
| >>>OFF | MP | | Integer(0..255) | in frames |

### 10.3.7.7 Event results

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| CHOICE *event result* | MP | | | One spare value is needed. |
| >Intra-frequency measurement event results | | | Intra-frequency measurement event results 10.3.7.37 | |
| >Inter-frequency measurement event results | | | Inter-frequency measurement event results 10.3.7.17 | |
| >Inter-RAT measurement event results | | | Inter-RAT measurement event results 10.3.7.28 | For IS-2000 results, include fields of the *Pilot Strength Measurement Message* from subclause 2.7.2.3.2.5 of TIA/EIA/IS-2000.5 |
| >Traffic volume measurement event results | | | Traffic volume | |

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| | | | measurement event results 10.3.7.69 | |
| >Quality measurement event results | | | Quality measurement event results 10.3.7.57 | |
| >UE internal measurement event results | | | UE internal measurement event results 10.3.7.78 | |
| >UE positioning measurement event results | | | UE positioning measurement event results 10.3.7.101 | |

| CHOICE *event result* | Condition under which the given *event result* is chosen |
|---|---|
| Intra-frequency measurement event results | If measurement type = intra-frequency measurement |
| Inter-frequency measurement event results | If measurement type = inter-frequency measurement |
| Inter-RAT measurement event results | If measurement type = inter-RAT measurement |
| Traffic volume measurement event results | If measurement type = traffic volume measurement |
| Quality measurement event results | If measurement type = Quality measurement |
| UE internal measurement event results | If measurement type = UE internal measurement |
| UE positioning measurement event results | If measurement type = UE positioning measurement |

### 10.3.7.8 FACH measurement occasion info

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| FACH Measurement occasion cycle length coefficient | OP | | Integer(1..12) | | |
| Inter-frequency FDD measurement indicator | MP | | Boolean | TRUE means that measurements are required | |
| Inter-frequency TDD 3.84 Mcps measurement indicator | MP | | Boolean | TRUE means that measurements are required | REL-4 |
| Inter-frequency TDD 7.68 Mcps measurement indicator | MP | | Boolean | TRUE means that measurements are required | REL-7 |
| Inter-frequency TDD 1.28 Mcps measurement indicator | MP | | Boolean | TRUE means that measurements are required | REL-4 |
| Inter-RAT measurement indicators | OP | 1 to <maxOtherRAT> | | | |
| >RAT type | MP | | Enumerated(GSM, IS2000) | | |

### 10.3.7.9 Filter coefficient

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Filter coefficient | MD | | Integer(0, 1, 2, 3, 4, 5, 6, 7, 8, 9, 11, 13, 15, 17, 19) | Default value is 0 |

### 10.3.7.10 HCS Cell re-selection information

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Penalty_time | MD | | Integer(0, 10, 20, 30, 40, 50, 60) | Default value is 0 which means = not used<br>In seconds |
| Temporary_offsets | CV-*Penalty used* | | | |
| >Temporary_offset1 | MP | | Integer(3, 6, 9, 12, 15, 18, 21, inf) | [dB] |
| >Temporary_offset2 | CV-*FDD-Quality-Measure* | | Integer(2, 3, 4, 6, 8, 10, 12, inf) | [dB] |

| Condition | Explanation |
|---|---|
| *Penalty used* | This IE is not needed if the IE "Penalty time" equals "not used", else it is mandatory present. |
| *FDD-Quality-Measure* | This IE is not needed if the IE "Cell selection and reselection quality measure" has the value CPICH RSCP, otherwise the IE is mandatory present. This conditional presence is implemented in ASN.1 by the use of a specific RSCP and EcN0 variant of 10.3.7.10. |

### 10.3.7.11 HCS neighbouring cell information

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| HCS_PRIO | MD | | Integer (0..7) | Default value = 0 |
| Qhcs | MD | | Qhcs 10.3.7.54a | Default value = 0 |
| HCS Cell Re-selection Information | MP | | HCS Cell Re-selection Information 10.3.7.10 | |

### 10.3.7.12 HCS Serving cell information

| Information Element/Group name | Need | Multi | Type and Reference | Semantics description |
|---|---|---|---|---|
| HCS_PRIO | MD | | Integer (0..7) | Default value = 0 |
| Qhcs | MD | | Qhcs 10.3.7.54a | Default value = 0 |
| $T_{CRmax}$ | MD | | Enumerated( not used, 30, 60, 120, 180, 240) | [s]<br>Default value is not used |
| $N_{CR}$ | CV-*UE speed detector* | | Integer(1..16 ) | Default value = 8 |
| $T_{CrmaxHyst}$ | CV-*UE speed detector* | | Enumerated( not used, 10, 20, 30, 40, 50, 60, 70) | [s] |

| Condition | Explanation |
|---|---|
| *UE Speed detector* | This IE is not needed if $T_{Crmax}$ equals 'not used', else it is mandatory present. |

### 10.3.7.13 Inter-frequency cell info list

Contains the information for the list of measurement objects for an inter-frequency measurement.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| CHOICE *Inter-frequency cell removal* | OP | | | |
| >Remove all inter-frequency cells | | | | No data |
| >Remove some inter-frequency cells | | | | |
| >>Removed inter-frequency cells | MP | 1 .. <maxCellMeas> | | |
| >>>Inter-frequency cell id | MP | | Integer(0 .. <maxCellMeas>-1) | |
| >No inter-frequency cells removed | | | | No data |
| New inter-frequency cells | OP | 1 to <maxCellMeas> | | |
| >Inter-frequency cell id | MD | | Integer(0 .. <maxCellMeas>-1) | |
| >Frequency info | MD | | Frequency info 10.3.6.36 | Default value is the value of the previous "frequency info" in the list.<br>NOTE: The first occurrence is then MP. |
| >Cell info | MP | | Cell info 10.3.7.2 | |
| Cells for measurement | CV-*BCHopt* | 1 to <maxCellMeas> | | |
| >Inter-frequency cell id | MP | | Integer(0 .. <maxCellMeas>-1) | |

| Condition | Explanation |
|---|---|
| *BCHopt* | This IE is not needed when sent in SYSTEM INFORMATION. Otherwise, the IE is Optional |

### 10.3.7.14 Inter-frequency event identity

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Inter-frequency event identity | MP | | Enumerated( 2a, 2b, 2c, 2d, 2e, 2f) | Two spare values are needed. |

### 10.3.7.15 Inter-frequency measured results list

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Inter-frequency measurement results | OP | 1 to <maxFreq> | | |
| >Frequency info | MD | | Frequency info 10.3.6.36 | Default value is the value of the previous "frequency info" in the list.<br>NOTE: The first occurrence is then MP. |
| >UTRA carrier RSSI | OP | | Integer(0..76 ) | According to UTRA_carrier_RSSI_LEV in [19] and [20].<br>Fifty-one spare values are needed. |
| >Inter-frequency cell measurement results | OP | 1 to <maxCellMeas> | | Only cells for which all reporting quantities are available should be included. |
| >>Cell measured results | MP | | Cell measured results 10.3.7.3 | |

### 10.3.7.16 Inter-frequency measurement

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Inter-frequency measurement objects list | MP | | Inter-frequency cell info list 10.3.7.13 | |
| Inter-frequency measurement quantity | OP | | Inter-frequency measurement quantity 10.3.7.18 | |
| Inter-frequency reporting quantity | OP | | Inter-frequency reporting quantity 10.3.7.21 | |
| Reporting cell status | CV-*reporting* | | Reporting cell status 10.3.7.61 | |
| Measurement validity | OP | | Measurement validity 10.3.7.51 | |
| Inter-frequency set update | OP | | Inter-frequency | |

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| | | | set update 10.3.7.22 | |
| CHOICE *report criteria* | MP | | | |
| >Intra-frequency measurement reporting criteria | | | Intra-frequency measurement reporting criteria 10.3.7.39 | |
| >Inter-frequency measurement reporting criteria | | | Inter-frequency measurement reporting criteria 10.3.7.19 | |
| >Periodical reporting criteria | | | Periodical reporting criteria 10.3.7.53 | |
| >No reporting | | | | (no data)<br>Chosen when this measurement only is used as additional measurement to another measurement |

| Condition | Explanation |
|---|---|
| *reporting* | This IE is optional if the CHOICE "*report criteria*" is equal to "periodical reporting criteria" or "No reporting", otherwise the IE is not needed |

### 10.3.7.17 Inter-frequency measurement event results

This IE contains the measurement event results that are reported to UTRAN for inter-frequency measurements.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Inter-frequency event identity | MP | | Inter-frequency event identity 10.3.7.14 | |
| Inter-frequency cells | OP | 1 to <maxFreq> | | |
| >Frequency info | MP | | Frequency info 10.3.6.36 | |
| >Non frequency related measurement event results | MP | | Cell measurement event results 10.3.7.4 | |

### 10.3.7.18 Inter-frequency measurement quantity

The quantity the UE shall measure in case of inter-frequency measurement. It also includes the filtering of the measurements.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| CHOICE *reporting criteria* | MP | | | |
| >Intra-frequency reporting | | | | |

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| criteria | | | | |
| >>Intra-frequency measurement quantity | MP | | Intra-frequency measurement quantity 10.3.7.38 | |
| >Inter-frequency reporting criteria | | | | |
| >>Filter coefficient | MP | | Filter coefficient 10.3.7.9 | |
| >>CHOICE *mode* | MP | | | |
| >>>FDD | | | | |
| >>>>Measurement quantity for frequency quality estimate | MP | | Enumerated( CPICH Ec/N0, CPICH RSCP) | |
| >>>TDD | | | | |
| >>>>Measurement quantity for frequency quality estimate | MP | | Enumerated( Primary CCPCH RSCP) | |

### 10.3.7.19 Inter-frequency measurement reporting criteria

The triggering of the event-triggered reporting for an inter-frequency measurements. All events concerning inter-frequency measurements are labelled 2x where x is a,b,c, ...

Event 2a: Change of best frequency.

Event 2b: The estimated quality of the currently used frequency is below a certain threshold **and** the estimated quality of a non-used frequency is above a certain threshold.

Event 2c: The estimated quality of a non-used frequency is above a certain threshold.

Event 2d: The estimated quality of the currently used frequency is below a certain threshold.

Event 2e: The estimated quality of a non-used frequency is below a certain threshold.

Event 2f: The estimated quality of the currently used frequency is above a certain threshold.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| Parameters required for each event | OP | 1 to <maxMeasEvent> | | | |
| >Inter-frequency event identity | MP | | Inter-frequency event identity 10.3.7.14 | | |
| >Threshold used frequency | CV–*clause 0* | | Integer(-115..0) | Ranges used depend on measurement quantity.<br>CPICH Ec/No -24..0dB<br>CPICH/Primary CCPCH RSCP -115..-25dBm | |
| | | | Integer (-120..0) | Ranges used depend on measurement quantity.<br>CPICH Ec/No -24..0dB<br>CPICH/Primary CCPCH RSCP -120..-25dBm | REL-6 |
| >$Delta_{Threshold\ used\ frequency}$ | CV-*clause 3* | | Integer(-5..-1) | If present, the actual value of Threshold used frequency = Threshold used frequency + $Delta_{Threshold\ used\ frequency}$ | REL-5 |
| | | | | Not used in Release 6 and later | REL-6 |
| >W used frequency | CV–*clause 2* | | Real(0, 0.1..2.0 by step of 0.1) | | |
| >Hysteresis | MP | | Real(0, 0.5..14.5 by step of 0.5) | In event 2a, 2b, 2c, 2d, 2e, 2f | |
| >Time to trigger | MP | | Time to trigger 10.3.7.64 | Indicates the period of time during which the event condition has to be satisfied, before sending a Measurement Report. Time in ms. | |
| >Reporting cell status | OP | | Reporting cell status 10.3.7.61 | | |
| >Parameters required for each non-used frequency | OP | 1 to <maxFreq> | | In this release, the first listed threshold and W parameter shall apply to all non-used frequencies. | |

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| >>Threshold non used frequency | CV–*clause 1* | | Integer(-115..0) | Ranges used depend on measurement quantity.<br>CPICH Ec/No -24..0dB<br>CPICH/Primary CCPCH RSCP -115..-25dBm.<br>This IE is not needed if the IE "Inter-frequency event identity" is set to 2a. However, it is specified to be mandatory to align with the ASN.1. | |
| | | | Integer (-120..0) | Ranges used depend on measurement quantity.<br>CPICH Ec/No -24..0dB<br>CPICH/Primary CCPCH RSCP -120..-25dBm<br>This IE is not needed if the IE "Inter-frequency event identity" is set to 2a. | REL-6 |
| >> $Delta_{Threshold\ non\ used\ frequency}$ | CV-*clause 4* | | Integer(-5..-1) | If present, the actual value of Threshold non used frequency = Threshold non used frequency + $Delta_{Threshold\ non\ used\ frequency}$ | REL-5 |
| | | | | Not used in Release 6 and later | REL-6 |
| >>W non-used frequency | CV-*clause 1* | | Real(0, 0.1..2.0 by step of 0.1) | | |

| Condition | Explanation |
|---|---|
| *Clause 0* | This IE is mandatory present if the IE "Inter frequency event identity" is set to 2b, 2d, or 2f, otherwise the IE is not needed. |
| *Clause 1* | This IE is mandatory present if the IE "Inter frequency event identity" is set to 2a, 2b, 2c or 2e, otherwise the IE is not needed |
| *Clause 2* | This IE is mandatory present if the IE "Inter-frequency event identity" is set to 2a, 2b, 2d or 2f, otherwise the IE is not needed. |
| *Clause 3* | This IE is optional if the IE "Inter frequency event identity" is set to 2b, 2d, or 2f. Otherwise the IE is not needed.<br>Note that in order to align with the ASN.1, this IE is always included when the IE '$Delta_{Threshold\ non\ used\ frequency}$' is present, but the value shall be ignored if the "Inter-frequency event identity" is not set to 2b, 2d or 2f. |
| *Clause 4* | This IE is optional if the IE "Inter frequency event identity" is set to 2a, 2b, 2c or 2e. Otherwise the IE is not needed. |

### 10.3.7.20 Inter-frequency measurement system information

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| Inter-frequency cell info list | OP | | Inter-frequency cell info list 10.3.7.13 | | |
| Inter-frequency RACH reporting information | OP | | Inter-frequency RACH reporting information 10.3.7.20a | | REL-6 |

### 10.3.7.20a Inter-frequency RACH reporting information

Contains the reporting configuration information for an inter-frequency measurement report, which is sent on the RACH.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| CHOICE *mode* | MP | | | | REL-6 |
| >FDD | | | | | REL-6 |
| >> Inter-frequency RACH reporting quantity | MP | | Enumerated(CPICH Ec/N0, CPICH RSCP) | | REL-6 |
| >TDD | | | | | REL-6 |
| >>Reporting quantity list | MP | 1 to 2 | | | REL-6 |
| >>> Inter-frequency RACH reporting quantity | MP | | Enumerated(Timeslot ISCP, Primary CCPCH RSCP) | | REL-6 |
| Inter-frequency RACH reporting threshold | MP | | Integer(-115..0) | Ranges used depend on measurement quantity. CPICH Ec/No -24..0dB CPICH/Primary CCPCH RSCP -115..-25dBm. | REL-6 |
| Maximum number of inter-frequency RACH reporting cells | MP | | Integer(1..8) | Indicates the total number for all non-used frequencies | REL-6 |

### 10.3.7.21 Inter-frequency reporting quantity

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| UTRA Carrier RSSI | MP | | Boolean | TRUE means report is requested. |
| Frequency quality estimate | MP | | Boolean | TRUE means that report is requested. This parameter is not used in this release and should be set to FALSE. It shall be ignored by the UE. |
| Non frequency related cell reporting quantities | MP | | Cell reporting quantities 10.3.7.5 | |

### 10.3.7.22 Inter-frequency SET UPDATE

NOTE 1: Only for FDD.

This information makes it possible to use events defined for Intra-frequency measurement within the same non-used frequency for Inter-frequency measurement reporting criteria.

| Information Element/group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| UE autonomous update mode | MP | | Enumerated (On with no reporting) | Required for backwards compatibility with a UE not supporting this revision of the standard |

### 10.3.7.23 Inter-RAT cell info list

Contains the information for the list of measurement objects for an inter-RAT measurement.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| CHOICE *Inter-RAT cell removal* | MP | | | | |
| >Remove all inter-RAT cells | | | | No data | |
| >Remove some inter-RAT cells | | | | | |
| >>Removed inter-RAT cells | MP | 1 to <maxCellMeas> | | | |
| >>>Inter-RAT cell id | MP | | Integer(0 .. <maxCellMeas> - 1) | | |
| >Remove no inter-RAT cells | | | | | |
| New inter-RAT cells | MP | 1 to <maxCellMeas> | | Although this IE is not always required, need is MP to align with ASN.1 | |
| | OP | | | | REL-4 |
| >Inter-RAT cell id | OP | | Integer(0 .. <maxCellMeas> - 1) | | |
| >CHOICE *Radio Access Technology* | MP | | | | |
| >>GSM | | | | | |
| >>>Cell individual offset | MP | | Integer (-50..50 ) | In dB<br>Used to offset measured quantity value | |
| >>>Cell selection and re-selection info | OP | | Cell selection and re-selection info for SIB11/12 10.3.2.4 | See subclause 8.6.7.3 | |
| >>>BSIC | MP | | BSIC 10.3.8.2 | | |
| >>>Band indicator | MP | | Enumerated (DCS 1800 band used, PCS 1900 band used) | Indicates how to interpret the BCCH ARFCN | |
| >>>BCCH ARFCN | MP | | Integer (0..1023) | [45] | |
| >>IS-2000 | | | | | |
| >>>System specific measurement info | MP | | enumerated (frequency, timeslot, | For IS-2000, use fields from TIA/EIA/IS- | |

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| | | | colour code, output power, PN offset) | 2000.5, subclause 3. 7.3.3.2.27, *Candidate Frequency Neighbour List Message* | |
| >>None | | | (no data) | This value has been introduced to handle the case when IE "New inter-RAT cells" is not required | |
| Cell for measurement | OP | 1 to <maxCellMeas> | | | |
| >Inter-RAT cell id | MP | | Integer(0 .. <maxCellMeas>-1) | | |
| Inter-RAT cell info indication | CV-*Message* | | Integer (0..3) | NOTE 1 and 2 | REL-5 |

| Condition | Explanation |
|---|---|
| *Message* | The IE is optionally present in the MEASUREMENT CONTROL and in the SRNS RELOCATION INFO messages, otherwise the IE is not needed. |

NOTE 1: The UTRAN may choose not to use the "Inter-RAT cell info indication" value "0" in the MEASUREMENT CONTROL message, to distinguish that case from those cases where the UE receives the IE "Inter-RAT cell info list" in SIB11 or SIB12.

NOTE 2: In case of an SRNS relocation, if the UE has been sent the "Inter-RAT cell info indication" in the MEASUREMENT CONTROL message and the IE "Inter-RAT cell info list" is included in the SRNS RELOCATION INFO sent from the source RNC to the target RNC, the "Inter-RAT cell info indication" should be included in the IE "Inter-RAT cell info list".

### 10.3.7.24 Inter-RAT event identity

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Inter-RAT event identity | MP | | Enumerated (3a, 3b, 3c, 3d) | |

### 10.3.7.25 Inter-RAT info

Inter-RAT info defines the target system for redirected cell selection.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| Inter-RAT info | MP | | Enumerated (GSM) | | |
| GSM target cell info | CV-*GSM* | | GSM target cell info 10.3.8.4g | | REL-6 |

| Condition | Explanation |
|---|---|
| *GSM* | This IE is optional if the IE "Inter-RAT info" is set to "GSM" and not needed otherwise. |

### 10.3.7.26 Inter-RAT measured results list

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Inter-RAT measurement results | OP | 1 to <maxOtherRAT-16> | | |
| >CHOICE *system* | MP | | | One spare value is needed. |
| >>GSM | | | | |
| >>>Measured GSM cells | MP | 1 to <maxReportedGSMCells> | | |
| >>>>GSM carrier RSSI | OP | | bit string(6) | RXLEV is mapped to a value between 0 and 63, [46]. When mapping the RXLEV value to the RSSI bit string, the first/leftmost bit of the bit string contains the most significant bit. |
| >>>>CHOICE *BSIC* | MP | | | |
| >>>>>Verified BSIC | | | | |
| >>>>>>inter-RAT cell id | MP | | Integer(0..<maxCellMeas>-1) | |
| >>>>>Non verified BSIC | | | | |
| >>>>>>BCCH ARFCN | MP | | Integer (0..1023) | [45] |

### 10.3.7.27 Inter-RAT measurement

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Inter-RAT measurement objects list | OP | | Inter-RAT cell info list 10.3.7.23 | |
| Inter-RAT measurement quantity | OP | | Inter-RAT measurement quantity 10.3.7.29 | |
| Inter-RAT reporting quantity | OP | | Inter-RAT reporting quantity 10.3.7.32 | |
| Reporting cell status | CV-*reporting* | | Reporting cell status 10.3.7.61 | |
| CHOICE *report criteria* | MP | | | |
| >Inter-RAT measurement reporting criteria | | | Inter-RAT measurement reporting criteria 10.3.7.30 | |
| >Periodical reporting criteria | | | Periodical reporting criteria 10.3.7.53 | |
| >No reporting | | | | (no data)<br>Chosen when this measurement only is used as additional measurement to another measurement |

| Condition | Explanation |
|---|---|
| *reporting* | This IE is optional if the CHOICE "*report criteria*" is equal to "periodical reporting criteria" or "No reporting", otherwise the IE is not needed |

### 10.3.7.28 Inter-RAT measurement event results

This IE contains the measurement event results that are reported to UTRAN for inter-RAT measurements.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Inter-RAT event identity | MP | | Inter-RAT event identity 10.3.7.24 | |
| Cells to report | MP | 1 to <maxCellMeas> | | |
| >CHOICE *BSIC* | MP | | | |
| >>Verified BSIC | | | | |
| >>>inter-RAT cell id | MP | | Integer(0..<maxCellMeas>-1) | |
| >>Non verified BSIC | | | | |
| >>>BCCH ARFCN | MP | | Integer (0..1023) | [45] |

### 10.3.7.29 Inter-RAT measurement quantity

The quantity the UE shall measure in case of inter-RAT measurement. It also includes the filtering of the measurements.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Measurement quantity for UTRAN quality estimate | OP | | Intra-frequency measurement quantity 10.3.7.38 | |
| CHOICE *system* | MP | | | |
| >GSM | | | | |
| >>Measurement quantity | MP | | Enumerated( GSM Carrier RSSI) | |
| >>Filter coefficient | MP | | Filter coefficient 10.3.7.9 | |
| >>BSIC verification required | MP | | Enumerated( required, not required) | |
| >IS2000 | | | | |
| >>TADD $E_c/I_0$ | MP | | Integer(0..63 ) | Admission criteria for neighbours, see subclause 2.6.6.2.6 of TIA/EIA/IS-2000.5 |
| >>TCOMP $E_c/I_0$ | MP | | Integer(0..15 ) | Admission criteria for neighbours, see subclause 2.6.6.2.5.2 of TIA/EIA/IS-2000.5 |
| >>SOFT SLOPE | OP | | Integer(0..63 ) | Admission criteria for neighbours, see subclause 2.6.6.2.3 and 2.6.6.2.5.2 of TIA/EIA/IS-2000.5 |
| >>ADD_INTERCEPT | OP | | Integer(0..63 ) | Admission criteria for neighbours, see subclause 2.6.6.2.5.2 of TIA/EIA/IS-2000.5 |

### 10.3.7.30 Inter-RAT measurement reporting criteria

The triggering of the event-triggered reporting for an inter-RAT measurement. All events concerning inter-RAT measurements are labelled 3x where x is a,b,c, ...

Event 3a: The estimated quality of the currently used UTRAN frequency is below a certain threshold **and** the estimated quality of the other system is above a certain threshold.

Event 3b: The estimated quality of other system is below a certain threshold.

Event 3c: The estimated quality of other system is above a certain threshold.

Event 3d: Change of best cell in other system.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Parameters required for each event | OP | 1 to <maxMeasEvent> | | |
| >Inter-RAT event identity | MP | | Inter-RAT event identity 10.3.7.24 | |
| >Threshold own system | CV–*clause 0* | | Integer (-115..0) | |
| >W | CV–*clause 0* | | Real(0, 0.1..2.0 by step of 0.1) | In event 3a |
| >Threshold other system | CV–*clause 1* | | Integer (-115..0) | In event 3a, 3b, 3c |
| >Hysteresis | MP | | Real(0..7.5 by step of 0.5) | |
| >Time to trigger | MP | | Time to trigger 10.3.7.64 | Indicates the period of time during which the event condition has to be satisfied, before sending a Measurement Report. |
| >Reporting cell status | OP | | Reporting cell status 10.3.7.61 | |

| Condition | Explanation |
|---|---|
| *Clause 0* | The IE is mandatory present if the IE "Inter-RAT event identity" is set to "3a", otherwise the IE is not needed |
| *Clause 1* | The IE is mandatory present if the IE "Inter-RAT event identity" is set to 3a, 3b or 3c, otherwise the IE is not needed |

### 10.3.7.31 Inter-RAT measurement system information

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Inter-RAT cell info list | OP | | Inter-RAT cell info list 10.3.7.23 | |

### 10.3.7.32 Inter-RAT reporting quantity

For all boolean types TRUE means inclusion in the report is requested.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| UTRAN estimated quality | MP | | Boolean | This parameter is not used in this release and should be set to FALSE. |
| CHOICE *system* | MP | | | |
| >GSM | | | | |
| >>GSM Carrier RSSI Reporting indicator | MP | | Boolean | |

### 10.3.7.33 Intra-frequency cell info list

Contains the information for the list of measurement objects for an intra-frequency measurement.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| CHOICE *Intra-frequency cell removal* | OP | | | Absence of this IE is equivalent to choice "Remove no intra-frequency cells". |
| >Remove all intra-frequency cells | | | | No data |
| >Remove some intra-frequency cells | | | | |
| >>Removed intra-frequency cells | MP | 1 to <maxCell Meas> | | |
| >>>Intra-frequency cell id | MP | | Integer(0 .. <maxCellMeas> - 1) | |
| >Remove no intra-frequency cells | | | | |
| New intra-frequency cells | OP | 1 to <maxCell Meas> | | This information element must be present when "Intra-frequency cell info list" is included in the system information |
| >Intra-frequency cell id | OP | | Integer(0 .. <maxCellMeas> - 1) | |
| >Cell info | MP | | Cell info 10.3.7.2 | This IE must be included for the serving cell when the IE "Intra frequency cell info list" is included in System Information Block type 11. |
| Cells for measurement | CV-*BCHopt* | 1 to <maxCell Meas> | | |
| >Intra-frequency cell id | MP | | Integer(0 .. <maxCellMeas>-1) | |

| Condition | Explanation |
|---|---|
| *BCHopt* | This IE is not needed when sent in SYSTEM INFORMATION. Otherwise, the IE is Optional |

### 10.3.7.34 Intra-frequency event identity

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| Intra-frequency event identity | MP | | Enumerated (1a,1b,1c,1d, 1e,1f,1g,1h,1 i, | Seven spare values are needed. | |
| | | | 1j) | Six spare values are needed. | REL-6 |

### 10.3.7.35 Intra-frequency measured results list

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Intra-frequency measurement results | OP | 1 to <maxCellMeas> | | |
| >Cell measured results | MP | | Cell measured results 10.3.7.3 | Only cells for which all reporting quantities are available should be included. |

### 10.3.7.36 Intra-frequency measurement

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Intra-frequency measurement objects list | OP | | Intra-frequency cell info list 10.3.7.33 | |
| Intra-frequency measurement quantity | OP | | Intra-frequency measurement quantity 10.3.7.38 | |
| Intra-frequency reporting quantity | OP | | Intra-frequency reporting quantity 10.3.7.41 | |
| Reporting cell status | CV-*reporting* | | Reporting cell status 10.3.7.61 | |
| Measurement validity | OP | | Measurement validity 10.3.7.51 | |
| CHOICE *report criteria* | OP | | | |
| >Intra-frequency measurement reporting criteria | | | Intra-frequency measurement reporting criteria 10.3.7.39 | |
| >Periodical reporting criteria | | | Periodical reporting criteria 10.3.7.53 | |
| >No reporting | | | | (no data)<br>Chosen when this measurement only is used as additional measurement to another measurement |

| Condition | Explanation |
|---|---|
| *reporting* | This IE is optional if the CHOICE "*report criteria*" is equal to "periodical reporting criteria" or "No reporting", otherwise the IE is not needed |

### 10.3.7.37 Intra-frequency measurement event results

This IE contains the measurement event results that are reported to UTRAN for intra-frequency measurements.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Intra-frequency event identity | MP | | Intra-frequency event identity 10.3.7.34 | |
| Cell measurement event results | MP | | Cell measurement event results 10.3.7.4 | |

### 10.3.7.38 Intra-frequency measurement quantity

The quantity the UE shall measure in case of intra-frequency measurement. It also includes the filtering of the measurements.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Filter coefficient | MP | | Filter coefficient 10.3.7.9 | |
| CHOICE *mode* | MP | | | |
| >FDD | | | | |
| >>Measurement quantity | MP | | Enumerated( CPICH Ec/N0, CPICH RSCP, Pathloss) | |
| >TDD | | | | |
| >>Measurement quantity list | MP | 1 to 4 | | |
| >>>Measurement quantity | MP | | Enumerated( Primary CCPCH RSCP, Pathloss, Timeslot ISCP) | |

### 10.3.7.39 Intra-frequency measurement reporting criteria

The triggering of the event-triggered reporting for an intra-frequency measurement. All events concerning intra-frequency measurements are labelled 1x where x is a, b, c….

Event 1a: A Primary CPICH enters the Reporting Range (FDD only).

Event 1b: A Primary CPICH leaves the Reporting Range (FDD only).

Event 1c: A Non-active Primary CPICH becomes better than an active Primary CPICH (FDD only).

Event 1d: Change of best cell (FDD only).

Event 1e: A Primary CPICH becomes better than an absolute threshold (FDD only).

Event 1f: A Primary CPICH becomes worse than an absolute threshold (FDD only).

Event 1g: Change of best cell in TDD.

Event 1h: Timeslot ISCP below a certain threshold (TDD only).

Event 1i: Timeslot ISCP above a certain threshold (TDD only).

Event 1j: A Non-active E-DCH but active DCH Primary CPICH becomes better than an active E-DCH Primary CPICH (FDD only).

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| Parameters required for each event | OP | 1 to <maxMeasEvent> | | | |
| >Intra-frequency event identity | MP | | Intra-frequency event identity 10.3.7.34 | | |
| >Triggering condition 1 | CV–*clause 0* | | Enumerated(Active set cells, Monitored set cells, Active set cells and monitored set cells) | Indicates which cells can trigger the event | |
| >Triggering condition 2 | CV–*clause 6* | | Enumerated(Active set cells, Monitored set cells, Active set cells and monitored set cells, Detected set cells, Detected set cells and monitored set cells) | Indicates which cells can trigger the event | |
| | *CV-clause 10* | | | | REL-5 |
| >Reporting Range Constant | CV–*clause 2* | | Real(0..14.5 by step of 0.5) | In dB. In event 1a,1b. | |
| >Cells forbidden to affect Reporting range | CV–*clause 1* | 1 to <maxCellMeas> | | In event 1a,1b | |
| >>CHOICE *mode* | MP | | | | |
| >>>FDD | | | | | |
| >>>>Primary CPICH info | MP | | Primary CPICH info 10.3.6.60 | | |
| >>>TDD | | | | | |
| >>>>Primary CCPCH info | MP | | Primary CCPCH info 10.3.6.57 | | |
| >W | CV–*clause 2* | | Real(0.0..2.0 by step of 0.1) | | |
| >Hysteresis | MP | | Real(0..7.5 by step of 0.5) | In dB. | |
| >Threshold used frequency | CV-*clause 3* | | Integer (-115..165) | Range used depend on measurement quantity. CPICH RSCP -115..-25 dBm | |

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| | | | | CPICH Ec/No -24..0 dB<br>Pathloss 30..165dB<br>ISCP -115..-25 dBm | |
| | | | Integer (-120..165) | Range used depend on measurement quantity.<br>CPICH RSCP -120..-25 dBm<br>CPICH Ec/No -24..0 dB<br>Pathloss 30..165dB<br>ISCP -120..-25 dBm | REL-6 |
| >Delta$_{\text{Threshold used frequency}}$ | CV-*clause 8* | | Integer(-5..-1) | If present, the actual value of Threshold used frequency = Threshold used frequency + Delta$_{\text{Threshold used frequency}}$ | REL-5 |
| | | | | Not used in Release 6 and later | REL-6 |
| >Reporting deactivation threshold | CV–*clause 4* | | Integer(0, 1, 2, 3, 4, 5, 6, 7) | In event 1a<br>Indicates the maximum number of cells allowed in the active set in order for event 1a to occur.<br>0 means not applicable<br>. | |
| >Replacement activation threshold | CV-*clause 5* | | Integer(0, 1, 2, 3, 4, 5, 6, 7) | In event 1c<br>Indicates the minimum number of cells allowed in the active set in order for event 1c to occur.<br>0 means not applicable | |
| | | | | In event 1j<br>Indicates the minimum number of cells allowed in the E-DCH active set in order for event 1j to occur.<br>For event 1j values 5, 6 and 7 are not applicable.<br>0 means not applicable | REL-6 |
| >Time to trigger | MP | | Time to trigger 10.3.7.64 | Indicates the period of time during which the event condition has to be satisfied, before sending a Measurement Report.<br>Time in ms | |
| >Amount of reporting | CV–*clause 7* | | Integer(1, 2, 4, 8, 16, 32, 64, Infinity) | In case the IE "Intra-frequency reporting criteria" is included in the IE "Inter-frequency measurement", this IE is not needed. | |

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| >Reporting interval | CV– *clause 7* | | Integer(0, 250, 500, 1000, 2000, 4000, 8000, 16000) | Indicates the interval of periodical reporting when such reporting is triggered by an event. Interval in milliseconds. 0 means no periodical reporting. In case the IE "Intra-frequency reporting criteria" is included in the IE "Inter-frequency measurement", this IE is not needed. | |
| >Reporting cell status | OP | | Reporting cell status 10.3.7.61 | | |
| >Periodical reporting information-1b | CV– *clause 9* | | Periodical reporting info-1b 10.3.7.53 aa | In case the IE "Intra-frequency reporting criteria" is included in the IE "Inter-frequency measurement", this IE is not needed. | REL-5 |
| >Use CIO | CV- *clause 10* | | Boolean | TRUE indicates that the cell individual offset shall be used for event evaluation | REL-5 |

| Condition | Explanation |
|---|---|
| *Clause 0* | The IE is mandatory present if the IE "Intra-frequency event identity" is set to "1b" or "1f", otherwise the IE is not needed. |
| *Clause 1* | The IE is optional if the IE "Intra-frequency event identity" is set to "1a" or "1b", otherwise the IE is not needed. |
| *Clause 2* | The IE is mandatory present if the IE "Intra-frequency event identity" is set to "1a" or "1b", otherwise the IE is not needed. |
| *Clause 3* | The IE is mandatory present if the IE "Intra-frequency event identity" is set to , "1e", "1f", "1h" or "1i", otherwise the IE is not needed. |
| *Clause 4* | The IE is mandatory present if the IE "Intra-frequency event identity" is set to "1a", otherwise the IE is not needed. |
| *Clause 5* | The IE is mandatory present if the IE "Intra-frequency event identity" is set to "1c" or 1j , otherwise the IE is not needed. |
| *Clause 6* | The IE is mandatory present if the IE "Intra-frequency event identity" is set to "1a" or "1e", otherwise the IE is not needed. |
| *Clause 7* | The IE is mandatory present if the IE "Intra-frequency event identity" is set to "1a", "1c" or 1j, otherwise the IE is not needed. |
| *Clause 8* | The IE is optional if the IE "Intra-frequency event identity" is set to "1e", "1f", "1h" or "1i". Otherwise the IE is not needed. |
| *Clause 9* | The IE is optional if the IE "Intra-frequency event identity" is set to "1b", otherwise the IE is not needed. |
| *Clause 10* | The IE is optional if the IE "Intra-frequency event identity" is set to "1d", otherwise the IE is not needed. |

### 10.3.7.40 Intra-frequency measurement system information

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Intra-frequency measurement identity | MD | | Measurement identity 10.3.7.48 | The intra-frequency measurement identity has default value 1. |
| Intra-frequency cell info list | OP | | Intra-frequency cell info list 10.3.7.33 | |
| Intra-frequency measurement quantity | OP | | Intra-frequency measurement quantity 10.3.7.38 | |
| Intra-frequency reporting quantity for RACH Reporting | OP | | Intra-frequency reporting quantity for RACH Reporting 10.3.7.42 | |
| Maximum number of reported cells on RACH | OP | | Maximum number of reported cells on RACH 10.3.7.43 | |
| Reporting information for state CELL_DCH | OP | | Reporting information for state CELL_DCH 10.3.7.62 | Note 1 |

NOTE 1: The reporting of intra-frequency measurements is activated when state CELL_DCH is entered.

### 10.3.7.41 Intra-frequency reporting quantity

Contains the reporting quantity information for an intra-frequency measurement.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Reporting quantities for active set cells | MP | | Cell reporting quantities 10.3.7.5 | |
| Reporting quantities for monitored set cells | MP | | Cell reporting quantities 10.3.7.5 | |
| Reporting quantities for detected set cells | OP | | Cell reporting quantities 10.3.7.5 | |

### 10.3.7.42 Intra-frequency reporting quantity for RACH reporting

Contains the reporting quantity information for an intra-frequency measurement report, which is sent on the RACH.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| SFN-SFN observed time difference reporting indicator | MP | | Enumerated( No report, | |

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| | | | type 1, type 2) | |
| CHOICE *mode* | MP | | | |
| >FDD | | | | |
| >>Reporting quantity | MP | | Enumerated( CPICH Ec/N0, CPICH RSCP, Pathloss, No report) | |
| >TDD | | | | |
| >>Reporting quantity list | MP | 1 to 2 | | |
| >>>Reporting quantity | MP | | Enumerated( Timeslot ISCP, Primary CCPCH RSCP, No report) | |

### 10.3.7.43 Maximum number of reported cells on RACH

Contains the maximum number of intra-frequency cells to be reported on RACH.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Maximum number of reported cells | MP | | Enumerated (no report, current cell, current cell + best neighbour, current cell+2 best neighbours, …, current cell+6 best neighbours) | |

### 10.3.7.43a MBMS preferred frequency information

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| MBMS preferred frequency list | MP | 1 to < maxMBMS-Freq> | | | REL-6 |
| >MBMS preferred frequency | OP | | Integer(1 .. <maxMBMS-Freq>) | Absence of this information element means the currently used frequency. Value n corresponds with the $n^{th}$ frequency included in the IE New inter-frequency cells that is specified within SIB 11 | REL-6 |
| >CHOICE *Layer convergence information* | MP | | | | REL-6 |
| >>*No HCS* | | | | | REL-6 |
| >>>Qoffmbms | MP | | Enumerated (4, 8, 12, 16, 20, 30, 40, infinity) | The offset in decibel [dB] added to cells on this MBMS preferred frequency | REL-6 |
| >>*HCS* | | | | | REL-6 |
| >>>$HCS_OFF_{mbms}$ | MP | | Integer (0..7) | Offset added to the normal HCS priority level of cells on this MBMS preferred frequency | REL-6 |
| >MBMS PL Service Restriction Information | OP | | Enumerated (TRUE) | Included if some service restrictions apply for this preferred frequency e.g. congestion | REL-6 |

### 10.3.7.44 Measured results

Contains the measured results of the quantity indicated optionally by Reporting Quantity in Measurement Control. "Measured results" can be used for both event trigger mode and periodical reporting mode. For intra-frequency and inter-frequency measurements the list shall be in the order of the value of the measurement quantity (the first cell shall be the best cell). The "best" FDD cell has the largest value when the measurement quantity is "Ec/No" or "RSCP". On the other hand, the "best" cell has the smallest value when the measurement quantity is "Pathloss". The "best" TDD cell has the largest value when measurement quantity is "Primary CCPCH RSCP". For intra-frequency measurements, the ordering shall be applied to all cells included in the IE "Measured results". For inter-frequency measurements, the ordering shall be applied to all cells on the same frequency included in the IE "Measured results". For other measurements, the order of reported measurement objects is not specified.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| CHOICE *Measurement* | MP | | | One spare value is needed. |
| >Intra-frequency measured results list | | | Intra-frequency measured results list 10.3.7.35 | |
| >Inter-frequency measured results list | | | Inter-frequency measured results list 10.3.7.15 | |
| >Inter-RAT measured results list | | | Inter-RAT measured results list 10.3.7.26 | |
| >Traffic volume measured | | | Traffic | |

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| results list | | | volume measured results list 10.3.7.67 | |
| >Quality measured results list | | | Quality measured results list 10.3.7.55 | |
| >UE Internal measured results | | | UE Internal measured results 10.3.7.76 | |
| >UE positioning measured results | | | UE positioning measured results 10.3.7.99 | |

### 10.3.7.45 Measured results on RACH

For measurements on used frequency, this IE contains the measured results on RACH of the quantity indicated by Reporting quantity in the IE "Intra-frequency reporting quantity for RACH Reporting" in system information broadcast on BCH. The list, measurement results for monitored cells (not including the current cell) shall be in the order of the value of the measurement quantity as indicated by Reporting Quantity in the IE "Intra-frequency reporting quantity for RACH Reporting" (the first cell shall be the best cell).

For measurements on non-used frequencies, this IE includes the best cell on each non- used frequency, in order of decreasing quality and up to a maximum number as specified by the IE "Maximum number of inter-frequency RACH reporting cells".

The "best" FDD cell has the largest value when the measurement quantity is "Ec/No" or "RSCP". On the other hand, the "best" cell has the smallest value when the measurement quantity is "Pathloss". The "best" TDD cell has the largest value when measurement quantity is "Primary CCPCH RSCP".

| Information Element/group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| Measurement result for current cell | MP | | | | |
| >CHOICE *mode* | MP | | | | |
| >>FDD | | | | | |
| >>>CHOICE *measurement quantity* | MP | | | One spare value is needed. | |
| >>>>CPICH Ec/N0 | | | Integer(0..49) | In dB. According to CPICH_Ec/No in [19]. Fourteen spare values are needed. | |
| >>>>CPICH RSCP | | | Integer(0..91) | In dBm. According to CPICH_RSCP_LEV in [19]. Thirty-six spare values are needed. | |
| >>>>Pathloss | | | Integer(46..158) | In dB. Fifteen spare values are needed. | |
| >>TDD | | | | | |
| >>>CHOICE *TDD option* | MP | | | | REL-4 |
| >>>>3.84 Mcps TDD | | | | | REL-4 |
| >>>>>Timeslot List | OP | 1 to 14 | | | |

| Information Element/group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| >>>>>>Timeslot ISCP | MP | | Timeslot ISCP info 10.3.7.65 | The UE shall report the Timeslot ISCP in the same order as indicated in the cell info | |
| >>>7.68 Mcps TDD | | | | | REL-7 |
| >>>>Timeslot List | OP | 1 to 14 | | | |
| >>>>>Timeslot ISCP | MP | | Timeslot ISCP info 10.3.7.65 | The UE shall report the Timeslot ISCP in the same order as indicated in the cell info | |
| >>>>1.28 Mcps TDD | | | | | REL-4 |
| >>>>>Timeslot List | OP | 1 to 6 | | | REL-4 |
| >>>>>>Timeslot ISCP | MP | | Timeslot ISCP info 10.3.7.65 | The UE shall report the Timeslot ISCP in the same order as indicated in the cell info | REL-4 |
| >>>Primary CCPCH RSCP | OP | | Primary CCPCH RSCP info 10.3.7.54 | | |
| Measurement results for monitored cells on used frequency | OP | 1 to 8 | | | |
| >SFN-SFN observed time difference | OP | | SFN-SFN observed time difference 10.3.7.63 | | |
| >CHOICE *mode* | MP | | | | |
| >>FDD | | | | | |
| >>>Primary CPICH info | MP | | Primary CPICH info 10.3.6.60 | | |
| >>>CHOICE *measurement quantity* | OP | | | One spare value is needed. | |
| >>>>CPICH Ec/N0 | | | Integer(0..49) | In dB. According to CPICH_Ec/No in [19]. Fourteen spare values are needed. | |
| >>>>CPICH RSCP | | | Integer(0..91) | In dBm. According to CPICH_RSCP_LEV in [19]. Thirty-six spare values are needed. | |
| >>>>Pathloss | | | Integer(46..158) | In dB. Fifteen spare values are needed. | |
| >>TDD | | | | | |
| >>>Cell parameters Id | MP | | Cell parameters Id 10.3.6.9 | | |
| >>>Primary CCPCH RSCP | MP | | Primary CCPCH RSCP info | | |

| Information Element/group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| | | | 10.3.7.54 | | |
| Measurement results for monitored cells on non-used frequencies | OP | | | | REL-6 |
| >Inter-frequency cell indication-SIB11 | MP | | Integer (0..1) | | REL-6 |
| >Inter-frequency cell indication-SIB12 | MP | | Integer (0..1) | | REL-6 |
| >Inter-frequency cell list | MP | 1 to <maxFreq> | | | REL-6 |
| >>Inter-frequency cell id | MP | | Integer(0 .. <maxCellMeas>-1) | | REL-6 |

NOTE: Monitored cells consist of neighbouring cells.

### 10.3.7.46 Measurement Command

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Measurement command | MP | | Enumerated( Setup, Modify, Release) | |

### 10.3.7.47 Measurement control system information

| Information element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Use of HCS | MP | | Enumerated (Not used, used) | Indicates if the serving cell belongs to a HCS structure |
| Cell selection and reselection quality measure | MP | | Enumerated (CPICH Ec/N0, CPICH RSCP) | Choice of measurement (CPICH Ec/N0 or CPICH RSCP) to use as quality measure Q.<br>NOTE: For TDD,each choice of this parameter represents PCCPCH RSCP. |
| Intra-frequency measurement system information | OP | | Intra-frequency measurement system information 10.3.7.40 | |
| Inter-frequency measurement system information | OP | | Inter-frequency measurement system information 10.3.7.20 | |
| Inter-RAT measurement system information | OP | | Inter-RAT measurement system information 10.3.7.31 | |
| Traffic volume measurement system information | OP | | Traffic volume measuremen | |

| | | | | |
|---|---|---|---|---|
| | | | t system information 10.3.7.73 | |

### 10.3.7.48 Measurement Identity

A reference number that is used by the UTRAN at modification and release of the measurement, and by the UE in the measurement report.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Measurement identity | MP | | Integer(1..16) | |

### 10.3.7.49 Measurement reporting mode

Contains the type of Measurement Report transfer mode and the indication of periodical/event trigger.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Measurement Report Transfer Mode | MP | | enumerated (Acknowledged mode RLC, Unacknowledged mode RLC) | |
| Periodical Reporting / Event Trigger Reporting Mode | MP | | Enumerated (Periodical reporting, Event trigger) | |

### 10.3.7.50 Measurement Type

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Measurement Type | MP | | Enumerated( Intra-frequency, Inter-frequency, Inter-RAT, Traffic volume, Quality, UE internal, UE positioning) | |

### 10.3.7.51 Measurement validity

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| UE state | MP | | Enumerated( CELL_DCH, all states except CELL_DCH, all states) | |

### 10.3.7.52 Void

### 10.3.7.53 Periodical reporting criteria

Contains the periodical reporting criteria information. It is necessary only in the periodical reporting mode.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Amount of reporting | MD | | Integer(1, 2, 4, 8, 16, 32, 64, Infinity) | The default value is infinity. |
| Reporting interval | MP | | Integer(250, 500, 1000, 2000, 3000, 4000, 6000, 8000, 12000, 16000, 20000, 24000, 28000, 32000, 64000) | Indicates the interval of periodical report. Interval in milliseconds |

### 10.3.7.53aa Periodical reporting info-1b

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| Amount of reporting | MP | | Integer(1, 2, 4, 8, 16, 32, 64, Infinity) | | REL-5 |
| Reporting interval | MP | | Integer(0, 250, 500, 1000, 2000, 4000, 8000, 16000) | Indicates the interval of periodical reporting when such reporting is triggered by an event. Interval in milliseconds. 0 means no periodical reporting. | REL-5 |

### 10.3.7.53a PLMN identities of neighbour cells

This IE contains the PLMN identities of neighbour cells.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| PLMNs of intra-frequency cells list | OP | 1 to <maxCellMeas> | | |

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| >PLMN identity | OP | | PLMN identity 10.3.1.11 | Action when not present is specified in subclause 8.1.1.6.18. |
| PLMNs of inter-frequency cells list | OP | 1 to <maxCellMeas> | | |
| >PLMN identity | OP | | PLMN identity 10.3.1.11 | Action when not present is specified in subclause 8.1.1.6.18. |
| PLMNs of inter-RAT cells list | OP | 1 to <maxCellMeas> | | |
| >PLMN identity | OP | | PLMN identity 10.3.1.11 | Action when not present is specified in subclause 8.1.1.6.18. |

### 10.3.7.54 Primary CCPCH RSCP info

NOTE: Only for TDD

| Information Element/Group name | Need | Multi | IE type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| Primary CCPCH RSCP | MP | | Integer(0..91) | According to P-CCPCH_RSCP_LEV in [19] and [20]. Thirty-six spare values are needed. | |
| $Delta_{Primary\ CCPCH\ RSCP}$ | CV-*Rel5* | | Integer(-5..-1) | If present, the actual value of Primary CCPCH RSCP = Primary CCPCH RSCP+ $Delta_{Primary\ CCPCH\ RSCP}$ | REL-5 |

| Condition | Explanation |
|---|---|
| *Rel5* | This IE is mandatory if the value of Primary CCPCH RSCP is below 0. Othewise the IE is not needed. |

### 10.3.7.54a Qhcs

| Information Element/Group name | Need | Multi | Type and Reference | Semantics description | Version |
|---|---|---|---|---|---|

| Information Element/Group name | Need | Multi | Type and Reference | Semantics description | Version |
|---|---|---|---|---|---|
| Qhcs | MP | | Integer(0..99) | Qhcs, mapped from CPICH Ec/No (FDD), see [4]<br>[dB]<br>0: -24<br>1: -23.5<br>2: -23<br>3: -22.5<br>...<br>45: -1.5<br>46: -1<br>47: -0.5<br>48: 0<br>49: (spare)<br>...<br>98: (spare)<br>99: (spare) | |
| | | | | Qhcs, mapped from CPICH RSCP (FDD), see [4]<br>[dBm]<br>0: -115<br>1: -114<br>2: -113<br>:<br>88: -27<br>89: -26<br>90: -(spare)<br>91: -(spare)<br>:<br>98: -(spare)<br>99: -(spare) | |
| | | | | Qhcs, mapped from PCCPCH RSCP (TDD), see [4]<br>[dBm]<br>0: -115<br>1: -114<br>2: -113<br>:<br>88: -27<br>89: -26<br>90: -(spare)<br>91: -(spare)<br>:<br>98: -(spare)<br>99: -(spare) | |

| Information Element/Group name | Need | Multi | Type and Reference | Semantics description | Version |
|---|---|---|---|---|---|
| | | | | Qhcs level, mapped from Averaged received signal level RSSI (GSM), see [4]<br>[dBm]<br>0: -110<br>1: -109<br>2: -108<br>:<br>61: -49<br>62: -48<br>63: -47<br>64: -46<br>65: -45<br>66: -44<br>67: -43<br>68: -42<br>69: -41<br>70: -40<br>71: -39<br>72: -38<br>73: -37<br>74: -(spare)<br>:<br>98: -(spare)<br>99: -(spare) | |
| $Delta_{Qhcs-RSCP}$ | CV-*RSCP* | | Integer(-5..-1) | If present, the actual value of Qhcs = Qhcs + $Delta_{Qhcs-RSCP}$ | REL-5 |

| Condition | Explanation |
|---|---|
| *RSCP* | This IE is optional if Qhcs is mapped from CPICH RSCP or PCCPCH RSCP, and if the value of the RSCP is below 0 (-115dBm). It is not needed otherwise. |

### 10.3.7.55 Quality measured results list

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| BLER measurement results | OP | 1 to <maxTrCH> | | |
| >DL Transport channel identity | MP | | Transport channel identity 10.3.5.18 | transport channel type = DCH |
| >DL Transport Channel BLER | OP | | Integer (0..63) | According to BLER_LOG in [19] and [20] |
| CHOICE *mode* | MP | | | |
| >FDD | | | | No data |
| >TDD | | | | |
| >>SIR measurement results | OP | 1 to <MaxCCTrCH> | | SIR measurements for DL CCTrCH |
| >>>TFCS ID | MP | | Integer(1...8) | |
| >>>Timeslot list | MP | 1 to <maxTS> | | for all timeslot on which the CCTrCH is mapped on |
| >>>>SIR | MP | | Integer(0..63) | According to UE_SIR in [20] |

### 10.3.7.56 Quality measurement

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Quality reporting quantity | OP | | Quality reporting quantity 10.3.7.59 | |
| CHOICE *report criteria* | MP | | | |
| >Quality measurement reporting criteria | | | Quality measurement reporting criteria 10.3.7.58 | Note<br>Given this choice, the IE "DL Transport Channel BLER" shall be set to "False" (see subclause 10.3.7.59) |
| >Periodical reporting criteria | | | Periodical reporting criteria 10.3.7.53 | Note |
| >No reporting | | | | Note<br>(no data)<br>Chosen when this measurement only is used as additional measurement to another measurement |

NOTE: In this version of the specification, BLER as additional measurement is not supported.

### 10.3.7.57 Quality measurement event results

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Transport channels causing the event | OP | 1 to <maxTrCH> | | |
| >DL Transport channel identity | MP | | Transport channel identity 10.3.5.18 | transport channel type = DCH |

### 10.3.7.58 Quality measurement reporting criteria

Event 5a: Number of bad CRCs on a certain transport channel exceeds a threshold.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Parameters sent for each transport channel | MP | 1 to <maxTrCH> | | |
| >DL Transport channel identity | MP | | Transport channel identity 10.3.5.18 | transport channel type = DCH |
| >Total CRC | MP | | Integer(1..512) | Number of CRCs |
| >Bad CRC | MP | | Integer(1..512) | Number of CRCs |
| >Pending after trigger | MP | | Integer(1..512) | Number of CRCs |

### 10.3.7.59 Quality reporting quantity

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| DL Transport Channel BLER | MP | | Boolean | TRUE means report requested |
| Transport channels for BLER reporting | CV-*BLER reporting* | 1 to <maxTrCH> | | The default, if no transport channel identities are present, is that the BLER is reported for all downlink transport channels |
| >DL Transport channel identity | MP | | Transport channel identity 10.3.5.18 | transport channel type = DCH |
| CHOICE *mode* | MP | | | |
| >FDD | | | | No data |
| >TDD | | | | |
| >>SIR measurement list | OP | 1 to <maxCCTrCH> | | SIR measurements shall be reported for all listed TFCS IDs |
| >>>TFCS ID | MP | | Integer(1...8) | |

| Condition | Explanation |
|---|---|
| *BLER reporting* | This IE is not needed if the IE "DL Transport Channel BLER" is "False" and optional if the IE "DL Transport Channel BLER" is "True" |

### 10.3.7.60 Reference time difference to cell

In the System Information message, the reference time difference to cell indicates the timing difference between the primary CCPCH of the current cell and the primary CCPCH of a neighbouring cell..

In the Measurement Control message, the reference time difference to cell indicates the timing difference between UE uplink transmission timing and the primary CCPCH of a neighbouring cell.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| CHOICE *accuracy* | MP | | | |
| >40 chips | | | | |
| >>Reference time difference | MP | | Integer(0..38400 by step of 40) | In chips |
| >256 chips | | | | |
| >>Reference time difference | MP | | Integer(0..38400 by step of 256) | In chips |
| >2560 chips | | | | |
| >>Reference time difference | MP | | Integer(0..38400 by step of 2560) | In chips |

### 10.3.7.61 Reporting Cell Status

Indicates maximum allowed number of cells to report and whether active set cells and/or virtual active set cells and/or monitored set cells on and/or detected set cells used frequency and/or monitored set cells on non used frequency should/should not be included in the IE "Measured results".

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| CHOICE *reported cell* | MP | | | |
| >Report cells within active set | | | | This choice is not valid for inter-RAT measurements. For inter-frequency measurements |

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| | | | | it is only valid for reporting events 2D and 2F. See NOTE 1. |
| >>Maximum number of reported cells | MP | | Integer(1..6) | |
| >Report cells within monitored set cells on used frequency | | | | This choice is not valid for inter-RAT or inter-frequency measurements |
| >>Maximum number of reported cells | MP | | Integer(1..6) | |
| >Report cells within active set and/or monitored set cells on used frequency | | | | This choice is not valid for inter-RAT or inter-frequency measurements |
| >>Maximum number of reported cells | MP | | Integer(1..6) | |
| >Report cells within detected set on used frequency | | | | This choice is not valid for inter-RAT or inter-frequency measurements |
| >>Maximum number of reported cells | MP | | Integer(1..6) | |
| >Report cells within monitored set and/or detected set on used frequency | | | | This choice is not valid for inter-RAT or inter-frequency measurements |
| >>Maximum number of reported cells | MP | | Integer(1..6) | |
| >Report all active set cells + cells within monitored set on used frequency | | | | This choice is not valid for inter-RAT or inter-frequency measurements |
| >>Maximum number of reported cells | MP | | Enumerated (virtual/active set cells+1, virtual/active set cells+2, …., virtual/active set cells+6) | |
| >Report all active set cells + cells within detected set on used frequency | | | | This choice is not valid for inter-RAT or inter-frequency measurements |
| >>Maximum number of reported cells | MP | | Enumerated (virtual/active set cells+1, virtual/active set cells+2, …., virtual/active set cells+6) | |
| >Report all active set cells + cells within monitored set and/or detected set on used frequency | | | | This choice is not valid for inter-RAT or inter-frequency measurements |
| >>Maximum number of reported cells | MP | | Enumerated (virtual/active set cells+1, virtual/active set cells+2, …., virtual/active set cells+6) | |
| >Report cells within virtual active set | | | | This choice is not valid for intra-frequency or inter-RAT measurements |
| >>Maximum number of reported cells per reported non-used frequency | MP | | Integer(1..6) | |
| >Report cells within monitored set on non-used frequency | | | | This choice is not valid for intra-frequency or inter-RAT |

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| | | | | measurements |
| >>Maximum number of reported cells per reported non-used frequency | MP | | Integer(1..6) | |
| >Report cells within monitored and/or virtual active set on non-used frequency | | | | This choice is not valid for intra-frequency or inter-RAT measurements |
| >>Maximum number of reported cells per reported non-used frequency | MP | | Integer(1..6) | |
| >Report all virtual active set cells + cells within monitored set on non-used frequency | | | | This choice is not valid for intra-frequency or inter-RAT measurements |
| >>Maximum number of reported cells per reported non-used frequency | MP | | Enumerated (virtual/active set cells+1, virtual/active set cells+2, …., virtual/active set cells+6) | |
| >Report cells within active set or within virtual active set or of the other RAT | | | | If this choice is selected for inter-RAT measurements, the UE shall report only cells of the other RAT.<br>If this choice is selected for intra-frequency measurements, the UE shall report cells within the active set. If this choice is selected for inter-frequency measurements, the UE shall report cells within the virtual active set. |
| >>Maximum number of reported cells | MP | | Integer (1..12) | |
| >Report cells within active and/or monitored set on used frequency or within virtual active and/or monitored set on non-used frequency | | | | This choice is not valid for inter-RAT measurements.<br>If this choice is selected for intra-frequency measurements, the UE shall report cells within the active and/or monitored set.<br>If this choice is selected for inter-frequency measurements, the UE shall report cells within the virtual active set and/or monitored set on non-used frequency. |
| >>Maximum number of reported cells | MP | | Integer(1..12) | |

NOTE 1: For Inter-frequency reporting events 2D and 2F, only CHOICE "Report cells within active set" is valid.

### 10.3.7.62 Reporting information for state CELL_DCH

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Intra-frequency reporting quantity | MP | | Intra-frequency reporting quantity 10.3.7.41 | |
| Measurement Reporting Mode | MP | | Measurement Reporting Mode 10.3.7.49 | |
| CHOICE *report criteria* | MP | | | |
| >Intra-frequency measurement reporting criteria | | | Intra-frequency measurement reporting criteria 10.3.7.39 | |
| >Periodical reporting criteria | | | Periodical reporting criteria 10.3.7.53 | |

### 10.3.7.63 SFN-SFN observed time difference

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| CHOICE *type* | MP | | | | |
| >Type 1 | | | Integer(0..9830399) | According to T1_SFN-SFN_TIME in [19] and [20].<br>For FDD and 3.84 Mcps TDD and 7.68 Mcps TDD:<br>6946816 spare values are needed. | |
| | | | Integer(0..3276799) | For 1.28 Mcps TDD:<br>13500416 spare values are needed. | Rel-4 |
| >Type 2 | | | Integer(0..40961) | According to T2_SFN-SFN_TIME in [19] and [20].<br>24574 spare values are needed. | |
| | | | Integer(0..27649) | For 1.28 Mcps TDD:<br>37886 spare values are needed. | Rel-4 |

### 10.3.7.64 Time to trigger

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Time to trigger | MP | | Integer(0, 10, 20, 40, 60, 80, 100, 120, 160, 200, 240, 320, 640, 1280, 2560, 5000) | Time in ms |

### 10.3.7.65 Timeslot ISCP info

NOTE: Only for TDD

| Information Element/Group name | Need | Multi | IE type and reference | Semantics description |
|---|---|---|---|---|
| Timeslot ISCP | MP | | Integer (0..91) | According to UE_TS_ISCP_LEV in [20]. Thirty-six spare values are needed. |

### 10.3.7.66 Traffic volume event identity

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Traffic volume event identity | MP | | Enumerated( 4a, 4b) | |

### 10.3.7.67 Traffic volume measured results list

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Traffic volume measurement results | OP | 1 to <maxRB> | | |
| >RB Identity | MP | | RB Identity 10.3.4.16 | |
| >RLC Buffers Payload | OP | | Enumerated( 0, 4, 8, 16, 32, 64, 128, 256, 512, 1024, 2K, 4K, 8K, 16K, 32K, 64K, 128K, 256K, 512K, 1024K) | In bytes And N Kbytes = N*1024 bytes. Twelve spare values are needed. |
| >Average of RLC Buffer Payload | OP | | Enumerated( 0, 4, 8, 16, 32, 64, 128, 256, 512, 1024, 2K, 4K, 8K, 16K, 32K, 64K, 128K, 256K, 512K, 1024K) | In bytes And N Kbytes = N*1024 bytes. Twelve spare values are needed. |
| >Variance of RLC Buffer Payload | OP | | Enumerated( 0, 4, 8, 16, 32, 64, 128, 256, 512, 1024, 2K, 4K, 8K, 16K) | In bytes And N Kbytes = N*1024 bytes. Two spare values are needed. |

### 10.3.7.68 Traffic volume measurement

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Traffic volume measurement Object | OP | | Traffic volume measurement Object 10.3.7.70 | |
| Traffic volume measurement quantity | OP | | Traffic volume measurement quantity 10.3.7.71 | |
| Traffic volume reporting quantity | OP | | Traffic volume reporting quantity 10.3.7.74 | |
| Measurement validity | OP | | Measurement validity 10.3.7.51 | |
| CHOICE *report criteria* | MP | | | |
| >Traffic volume measurement reporting criteria | | | Traffic volume measurement reporting criteria 10.3.7.72 | |
| >Periodical reporting criteria | | | Periodical reporting criteria 10.3.7.53 | |
| >No reporting | | | | (no data)<br>Chosen when this measurement only is used as additional measurement to another measurement |

### 10.3.7.69 Traffic volume measurement event results

Contains the event result for a traffic volume measurement.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Uplink transport channel type causing the event | MP | | Enumerated( DCH,RACH, USCH) | USCH is TDD only.<br>RACH is the currently configured default in the uplink. |
| UL Transport Channel identity | CV-*UL-DCH/USCH* | | Transport channel identity 10.3.5.18 | |
| Traffic volume event identity | MP | | Traffic volume event identity 10.3.7.66 | |

| Condition | Explanation |
|---|---|
| *UL-DCH/USCH* | If IE "Uplink transport channel type" is equal to "DCH" or "USCH" (TDD only) this IE is mandatory present. Otherwise the IE is not needed. |

### 10.3.7.70 Traffic volume measurement object

Contains the measurement object information for a traffic volume measurement.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Traffic volume measurement objects | MP | 1 to <maxTrCH> | | |
| >Uplink transport channel type | MP | | Enumerated( DCH,RACH, USCH) | USCH is TDD only. RACH is the currently configured default in the uplink. |
| >UL Target Transport Channel ID | CV-*UL-DCH/USCH* | | Transport channel identity 10.3.5.18 | |

| Condition | Explanation |
|---|---|
| *UL-DCH/USCH* | If IE "Uplink transport channel type" is equal to "DCH" or "USCH" (TDD only) this IE is mandatory present. Otherwise the IE is not needed. |

### 10.3.7.71 Traffic volume measurement quantity

Contains the measurement quantity information for a traffic volume measurement.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Measurement quantity | MP | | Enumerated( RLC buffer payload, Average RLC buffer payload, Variance of RLC buffer payload) | This parameter should be ignored. |
| Time Interval to take an average or a variance | CV-*A/V* | | Integer(20, 40, ..260, by steps of 20) | In ms |

| Condition | Explanation |
|---|---|
| *A/V* | This IE is mandatory present when "Average RLC buffer" or "Variance of RLC buffer payload" is chosen and not needed otherwise. |

### 10.3.7.72 Traffic volume measurement reporting criteria

Contains the measurement reporting criteria information for a traffic volume measurement.

Event 4a: Transport Channel Traffic Volume [15] exceeds an absolute threshold.

Event 4b: Transport Channel Traffic Volume [15] becomes smaller than an absolute threshold.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Parameters sent for each transport channel | OP | 1 to <maxTrCH> | | This IE is always required, need is OP to align with ASN.1 |
| >Uplink transport channel type | OP | | Enumerated( DCH,RACH, USCH) | USCH is TDD only. RACH is the currently configured default in the uplink. |
| >UL Transport Channel ID | CV-*UL-DCH/USCH* | | Transport channel identity 10.3.5.18 | |
| >Parameters required for each Event | OP | 1 to <maxMeasparEvent> | | |
| >>Traffic volume event identity | MP | | Traffic volume event identity 10.3.7.66 | |
| >>Reporting Threshold | MP | | Enumerated( 8,16,32,64,128,256,512,1024,2K,3K,4K,6K,8K,12K,16K,24K,32K,48K,64K,96K,128K,192K,256K,384K,512K,768K) | Threshold in bytes And N Kbytes = N*1024 bytes |
| >>Time to trigger | OP | | Time to trigger 10.3.7.64 | Indicates the period of time during which the event condition has to be satisfied, before sending a Measurement Report. Time in ms |
| >>Pending time after trigger | OP | | Integer(250, 500, 1000, 2000, 4000, 8000, 16000) | Indicates the period of time during which it is forbidden to send any new measurement reports with the same Traffic volume event identity even if the triggering condition is fulfilled. Time in milliseconds |
| >>Tx interruption after trigger | OP | | Integer (250, 500, 1000, 2000, 4000, 8000, 16000) | Time in milliseconds. Indicates how long the UE shall block DTCH transmissions on the RACH after a measurement report is triggered. |

| Condition | Explanation |
|---|---|
| *UL-DCH/USCH* | If IE "Uplink transport channel type" is equal to "DCH" or "USCH" (TDD only) this IE is optional. Otherwise the IE is not needed. |

### 10.3.7.73 Traffic volume measurement system information

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Traffic volume measurement identity | MD | | Measurement identity 10.3.7.48 | The traffic volume measurement identity has default value 4. |
| Traffic volume measurement object | OP | | Traffic volume measurement object 10.3.7.70 | |
| Traffic volume measurement quantity | OP | | Traffic volume measurement quantity 10.3.7.71 | |
| Traffic volume reporting quantity | OP | | Traffic volume reporting quantity 10.3.7.74 | |
| Measurement validity | OP | | Measurement validity 10.3.7.51 | |
| Measurement Reporting Mode | MP | | Measurement Reporting Mode 10.3.7.49 | |
| CHOICE *reporting criteria* | MP | | | |
| >Traffic volume measurement reporting criteria | | | Traffic volume measurement reporting criteria 10.3.7.72 | |
| >Periodical reporting criteria | | | Periodical reporting criteria 10.3.7.53 | |

### 10.3.7.74 Traffic volume reporting quantity

Contains the reporting quantity information for a traffic volume measurement.

For all boolean types TRUE means inclusion in the report is requested.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| RLC Buffer Payload for each RB | MP | | Boolean | |
| Average of RLC Buffer Payload for each RB | MP | | Boolean | |
| Variance of RLC Buffer Payload for each RB | MP | | Boolean | |

### 10.3.7.75 UE internal event identity

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| UE internal event identity | MP | | Enumerated( 6a,6b,6c,6d, 6e, 6f, 6g) | |

### 10.3.7.76 UE internal measured results

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| CHOICE *mode* | MP | | | | |
| >FDD | | | | | |
| >>UE Transmitted Power | OP | | UE Transmitted Power info 10.3.7.85 | | |
| >>UE Rx-Tx report entries | OP | 1 to <maxRL> | | | |
| >>>Primary CPICH info | MP | | Primary CPICH info 10.3.6.60 | Primary CPICH info for each cell included in the active set | |
| >>>UE Rx-Tx time difference type 1 | MP | | UE Rx-Tx time difference type 1 10.3.7.83 | UE Rx-Tx time difference in chip for each RL included in the active set | |
| >TDD | | | | | |
| >>UE Transmitted Power list | OP | 1 to <maxTS> | | UE Transmitted Power for each used uplink timeslot in ascending timeslot number order | |
| >>>UE Transmitted Power | MP | | UE Transmitted Power info 10.3.7.85 | | |
| >>CHOICE *TDD option* | MP | | | | REL-4 |
| >>>3.84 Mcps TDD | | | | | REL-4 |
| >>>>Applied TA | OP | | Uplink Timing Advance 10.3.6.95 | Uplink timing advance applied by the UE | |
| >>>7.68 Mcps TDD | | | | | REL-7 |
| >>>>Applied TA VHCR | OP | | Uplink Timing Advance VHCR 10.3.6.95a | Uplink timing advance applied by the UE | |
| >>>1.28 Mcps TDD | | | | | REL-4 |
| >>>>$T_{ADV}$ | OP | | $T_{ADV}$ info 10.3.7.112 | | REL-4 |

### 10.3.7.77 UE internal measurement

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| UE internal measurement quantity | OP | | UE internal measurement quantity 10.3.7.79 | |
| UE internal reporting quantity | OP | | UE internal reporting quantity 10.3.7.82 | |
| CHOICE *report criteria* | MP | | | |
| >UE internal measurement reporting criteria | | | UE internal measurement reporting criteria 10.3.7.80 | |
| >Periodical reporting criteria | | | Periodical reporting criteria 10.3.7.53 | |
| >No reporting | | | | (no data)<br>Chosen when this measurement only is used as additional measurement to another measurement |

| CHOICE *report criteria* | Condition under which the given *report criteria* is chosen |
|---|---|
| UE internal measurement reporting criteria | Chosen when UE internal measurement event triggering is required |
| Periodical reporting criteria | Chosen when periodical reporting is required |
| No reporting | Chosen when this measurement only is used as additional measurement to another measurement |

### 10.3.7.78 UE internal measurement event results

This IE contains the measurement event results that are reported to UTRAN for UE internal measurements.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| UE internal event identity | MP | | UE internal event identity 10.3.7.75 | |
| CHOICE *mode* | MP | | | |
| >FDD | | | | |
| >Primary CPICH info | CV-*clause 1* | | Primary CPICH info 10.3.6.60 | |
| >TDD | | | | (no data) |

| Condition | Explanation |
|---|---|
| *Clause 1* | This IE is mandatory present if the IE "UE internal event identity" is set to "6f" or "6g", otherwise the IE is not needed. |

### 10.3.7.79 UE internal measurement quantity

The quantity the UE shall measure in case of UE internal measurement.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| CHOICE *mode* | MP | | | | |
| >FDD | | | | | |
| >>Measurement quantity | MP | | Enumerated( UE Transmitted Power, UTRA Carrier RSSI, UE Rx-Tx time difference) | | |
| >TDD | | | | | |
| >>Measurement quantity | MP | | Enumerated( UE Transmitted Power, UTRA Carrier RSSI, | | |
| | | | $T_{ADV}$) | Measurement on Timing Advance is for 1.28 Mcps TDD | REL-4 |
| Filter coefficient | OP | | Filter coefficient 10.3.7.9 | If the IE "Measurement quantity" is set to "Rx-Tx time difference" and this IE is present, the UE behaviour is unspecified. | |

### 10.3.7.80 UE internal measurement reporting criteria

The triggering of the event-triggered reporting for a UE internal measurement. All events concerning UE internal measurements are labelled 6x where x is a, b, c…. In TDD, the events 6a - 6d are measured and reported on timeslot basis.

Event 6a: The UE Transmitted Power becomes larger than an absolute threshold

Event 6b: The UE Transmitted Power becomes less than an absolute threshold

Event 6c: The UE Transmitted Power reaches its minimum value

Event 6d: The UE Transmitted Power reaches its maximum value

Event 6e: The UE RSSI reaches the UEs dynamic receiver range

Event 6f (FDD): The UE Rx-Tx time difference for a RL included in the active set becomes larger than an absolute threshold

Event 6f (1.28 Mcps TDD): The time difference indicated by $T_{ADV}$ becomes larger than an absolute threshold

Event 6g: The UE Rx-Tx time difference for a RL included in the active set becomes less than an absolute threshold

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| Parameters sent for each UE internal measurement event | OP | 1 to <maxMeas Event> | | | |
| >UE internal event identity | MP | | UE internal event identity 10.3.7.75 | | |

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| >Time-to-trigger | MP | | Integer(0, 10, 20, 40, 60, 80, 100, 120, 160, 200, 240, 320, 640, 1280, 2560, 5000) | Time in ms. Indicates the period of time between the timing of event detection and the timing of sending Measurement Report. | |
| >UE Transmitted Power Tx power threshold | CV-*clause 1* | | Integer(-50..33) | Power in dBm. In event 6a, 6b. | |
| >UE Rx-Tx time difference threshold | CV-*clause 2* | | Integer(768..1280) | Time difference in chip. In event 6f, 6g. | |
| >$T_{ADV}$ threshold | CV-*clause 3* | | Real (0..63 step 0.125) | Time difference in chip. In event 6f | REL-4 |

| Condition | Explanation |
|---|---|
| *Clause 1* | The IE is mandatory present if the IE "UE internal event identity" is set to "6a" or "6b", otherwise the IE is not needed. |
| *Clause 2* | In FDD, the IE is mandatory present if the IE "UE internal event identity" is set to "6f" or "6g", otherwise the IE is not needed. |
| *Clause 3* | In 1.28 Mcps TDD the IE is mandatory present if the IE "UE internal event identity" is set to "6f", otherwise the IE is not needed. |

### 10.3.7.81 Void

### 10.3.7.82 UE Internal reporting quantity

For all boolean types TRUE means inclusion in the report is requested.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| UE Transmitted Power | MP | | Boolean | | |
| CHOICE *mode* | MP | | | | |
| >FDD | | | | | |
| >>UE Rx-Tx time difference | MP | | Boolean | | |
| >TDD | | | | | |
| >>CHOICE *TDD option* | | | | | REL-4 |
| >>>3.84 Mcps TDD | | | | (no data) | REL-4 |
| >>Applied TA | MP | | Boolean | | |
| >>>7.68 Mcps TDD | | | | (no data) | REL-7 |
| >>Applied TA | MP | | Boolean | | |
| >>>1.28 Mcps TDD | | | | | REL-4 |
| >>>>$T_{ADV}$ info | MP | | Boolean | | REL-4 |

### 10.3.7.83 UE Rx-Tx time difference type 1

The difference in time between the UE uplink DPCCH/DPDCH frame transmission and the first detected path (in time), of the downlink DPCH or F-DPCH frame from the measured radio link, as defined in [7]. This measurement is for FDD only.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| UE Rx-Tx time difference type 1 | MP | | Integer(768..1280) | In chips.<br>511 spare values are needed. |

### 10.3.7.84 UE Rx-Tx time difference type 2

The difference in time between the UE uplink DPCCH/DPDCH frame transmission and the first detected path (in time), of the downlink DPCH or F-DPCH frame from the measured radio link, as defined in [7].

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| UE Rx-Tx time difference type 2 | MP | | Integer (0..8191) | According to [19]. |

### 10.3.7.85 UE Transmitted Power info

| Information Element/Group name | Need | Multi | IE type and reference | Semantics description |
|---|---|---|---|---|
| UE Transmitted Power | MP | | Integer (0..104) | According to UE_TX_POWER in [19] and [20] |

### 10.3.7.86 UE positioning Ciphering info

This IE contains information for the ciphering of UE positioning assistance data broadcast in System Information.

| Information Element/Group name | Need | Multi | Type and Reference | Semantics description |
|---|---|---|---|---|
| Ciphering Key Flag | MP | | Bit string(1) | |
| Ciphering Serial Number | MP | | Integer(0..65535) | The serial number used in the DES ciphering algorithm |

### 10.3.7.87 UE positioning Error

| Information Element/Group name | Need | Multi | Type and Reference | Semantics description |
|---|---|---|---|---|
| Error reason | MP | | Enumerated( Not Enough OTDOA Cells, Not Enough GPS Satellites, Assistance Data Missing, Not Accomplished GPS Timing Of Cell Frames, Undefined Error, Request Denied By User, Not Processed And Timeout, Reference Cell Not Serving Cell) | Note 1 |
| GPS Additional Assistance Data Request | CV-*GPSdataMissing* | | UE positioning GPS Additional Assistance Data Request 10.3.7.88a | |

NOTE 1: The following table describes each value of the IE "Error reason".

| Value | Indication |
|---|---|
| Not Enough OTDOA Cells | There were not enough cells to be received. |
| Not Enough GPS Satellites | There were not enough GPS satellites to be received. |
| Assistance Data Missing | UE positioning GPS assistance data missing. |
| Not Accomplished GPS Timing Of Cell Frames | UE was not able to accomplish the GPS timing of cell frames measurement. |
| Undefined Error | Undefined error. |
| Request Denied By User | UE positioning request denied by upper layers. |
| Not Processed And Timeout | UE positioning request not processed by upper layers and timeout. |
| Reference Cell Not Serving Cell | UE was not able to read the SFN of the reference cell. |

| Condition | Explanation |
|---|---|
| *GPSdataMissing* | The IE is optional if the IE "Error reason" is " Assistance Data Missing " and not needed otherwise. |

### 10.3.7.88 UE positioning GPS acquisition assistance

This IE contains parameters that enable fast acquisition of the GPS signals in UE-assisted GPS positioning.

| Information Element/Group name | Need | Multi | Type and Reference | Semantics description |
|---|---|---|---|---|
| GPS TOW msec | MP | | Integer(0..6. | GPS Time of Week in |

| Information Element/Group name | Need | Multi | Type and Reference | Semantics description |
|---|---|---|---|---|
| | | | 048*$10^8$-1) | milliseconds rounded down to the nearest millisecond unit. It is also the time when satellite information is valid. |
| UTRAN GPS reference time | OP | | | |
| >UTRAN GPS timing of cell frames | MP | | Integer(0 ... 2322431999 999) | GPS timing of cell frames in steps of 1 chip. |
| >CHOICE *mode* | OP | | | |
| >>FDD | | | | |
| >>>Primary CPICH Info | MP | | Primary CPICH Info 10.3.6.60 | Identifies the reference cell for the GPS TOW-SFN relationship |
| >>TDD | | | | |
| >>>cell parameters id | MP | | Cell parameters id 10.3.6.9 | Identifies the reference cell for the GPS TOW-SFN relationship |
| >SFN | MP | | Integer(0..4095) | The SFN which the UTRAN GPS timing of cell frames time stamps. |
| Satellite information | MP | 1 to <maxSat> | | |
| >SatID | MP | | Integer (0..63) | Identifies the satellite and is equal to (SV ID No - 1) where SV ID No is defined in [12]. |
| >Doppler ($0^{th}$ order term) | MP | | Real(-5120..5117.5 by step of 2.5) | Hz |
| >Extra Doppler | OP | | | |
| >>Doppler ($1^{st}$ order term) | MP | | Real (-0.966..0.483 by step of 0.023) | Hz/s |
| >>Doppler Uncertainty | MP | | Enumerated (12.5,25,50, 100,200) | Hz.<br>Three spare values are needed.<br>The Doppler experienced by a stationary UE is in the range 'Doppler – Doppler Uncertainty' to 'Doppler + Doppler Uncertainty'. |
| >Code Phase | MP | | Integer(0..1022) | GPS chips.<br>Increasing binary values of the field signify increasing predicted pseudoranges. |
| >Integer Code Phase | MP | | Integer(0..19) | Number of code periods that have elapsed since the latest GPS bit boundary, in units of C/A code period. |
| >GPS Bit number | MP | | Integer(0..3) | Specifies GPS bit number modulo 4 |
| >Code Phase Search Window | MP | | Integer(1023,1,2,3,4,6,8,12,16,24,32,48,64,96,128, 192) | Expected code-phase is in the range 'Code Phase – Code Phase Search Window' to 'Code Phase + Code Phase Search Window'. |
| >Azimuth and Elevation | OP | | | |
| >>Azimuth | MP | | Real(0..348.75 by step of 11.25) | Degrees<br>An angle of x degrees means the satellite azimuth a is in the range $x \leq a < x+11.25$ degrees. |
| >>Elevation | MP | | Real(0..78.75 by step of | Degrees<br>An angle of y degrees means |

| Information Element/Group name | Need | Multi | Type and Reference | Semantics description |
|---|---|---|---|---|
| | | | 11.25) | the satellite elevation e is in the range y ≤ e < y+11.25 degrees except for y=78.75 where the range is extended to include 90 degrees. |

## 10.3.7.88a UE positioning GPS Additional Assistance Data Request

| Information Element/Group name | Need | Multi | Type and Reference | Semantics description |
|---|---|---|---|---|
| Almanac | MP | | Boolean | TRUE means requested |
| UTC Model | MP | | Boolean | TRUE means requested |
| Ionospheric model | MP | | Boolean | TRUE means requested |
| Navigation Model | MP | | Boolean | TRUE means requested |
| DGPS Corrections | MP | | Boolean | TRUE means requested |
| Reference Location | MP | | Boolean | TRUE means requested |
| Reference Time | MP | | Boolean | TRUE means requested |
| Acquisition Assistance | MP | | Boolean | TRUE means requested |
| Real-Time Integrity | MP | | Boolean | TRUE means requested |
| Navigation Model Additional data | CV-*Navigation Model* | | | this IE is present only if "Navigation Model" is set to TRUE otherwise it is absent |
| >GPS Week | MP | | Integer (0..1023) | |
| >GPS_Toe | MP | | Integer (0..167) | GPS time of ephemeris in hours of the latest ephemeris set contained by the UE. Eighty-eight spare values needed. |
| >T-Toe limit | MP | | Integer (0..10) | ephemeris age tolerance of the UE to UTRAN in hours. Five spare values needed. |
| >Satellites list related data | MP | 0 to <maxSat> | | |
| >>SatID | MP | | Integer (0..63) | Identifies the satellite and is equal to (SV ID No - 1) where SV ID No is defined in [12]. |
| >>IODE | MP | | Integer (0..255) | Issue of Data Ephemeris for SatID |

### 10.3.7.89 UE positioning GPS almanac

This IE contains a reduced-precision subset of the ephemeris and clock correction parameters.

| Information Element/Group name | Need | Multi | Type and Reference | Semantics description |
|---|---|---|---|---|
| $WN_a$ | MP | | Bit string(8) | Almanac Reference Week [12] |
| Satellite information | MP | 1 to <maxSat> | | |
| >DataID | MP | | Integer(0..3) | See [12] |
| >SatID | MP | | Enumerated( 0..63) | Identifies the satellite and is equal to (SV ID No - 1) where SV ID No is defined in [12]. |
| >e | MP | | Bit string(16) | Eccentricity [12] |
| >$t_{oa}$ | MP | | Bit string(8) | Reference Time of Almanac [12] |
| >$\delta i$ | MP | | Bit string(16) | |
| >OMEGADOT | MP | | Bit string(16) | Longitude of Ascending Node of Orbit Plane at Weekly Epoch (semi-circles/sec) [12] |
| >SV Health | MP | | Bit string(8) | |
| >$A^{1/2}$ | MP | | Bit string(24) | Semi-Major Axis (meters)$^{1/2}$ [12] |
| >$OMEGA_0$ | MP | | Bit string(24) | Longitude of Ascending Node of Orbit Plane at Weekly Epoch (semi-circles) [12] |
| >$M_0$ | MP | | Bit string(24) | Mean Anomaly at Reference Time (semi-circles) [12] |
| >$\omega$ | MP | | Bit string(24) | Argument of Perigee (semi-circles) [12] |
| >$af_0$ | MP | | Bit string(11) | apparent clock correction [12] |
| >$af_1$ | MP | | Bit string(11) | apparent clock correction [12] |
| SV Global Health | OP | | Bit string(364) | This enables GPS time recovery and possibly extended GPS correlation intervals. It is specified in page 25 of subframes 4 and 5 [12] |

### 10.3.7.90 UE positioning GPS assistance data

This IE contains GPS assistance data.

| Information Element/Group name | Need | Multi | Type and Reference | Semantics description |
|---|---|---|---|---|
| UE positioning GPS reference time | OP | | UE positioning GPS reference time 10.3.7.96 | |
| UE positioning GPS reference UE position | OP | | Ellipsoid point with altitude and uncertainty ellipsoid 10.3.8.4c | A priori knowledge of UE 3-D position. |
| UE positioning GPS DGPS corrections | OP | | UE positioning GPS DGPS corrections 10.3.7.91 | |

| Information Element/Group name | Need | Multi | Type and Reference | Semantics description |
|---|---|---|---|---|
| UE positioning GPS navigation model | OP | | UE positioning GPS navigation model 10.3.7.94 | |
| UE positioning GPS ionospheric model | OP | | UE positioning GPS ionospheric model 10.3.7.92 | |
| UE positioning GPS UTC model | OP | | UE positioning GPS UTC model 10.3.7.97 | |
| UE positioning GPS almanac | OP | | UE positioning GPS almanac 10.3.7.89 | |
| UE positioning GPS acquisition assistance | OP | | UE positioning GPS acquisition assistance 10.3.7.88 | |
| UE positioning GPS real-time integrity | OP | | UE positioning GPS real-time integrity 10.3.7.95 | |

### 10.3.7.90a Void

### 10.3.7.91 UE positioning GPS DGPS corrections

This IE contains DGPS corrections to be used by the UE.

| Information Element/Group name | Need | Multi | Type and Reference | Semantics description |
|---|---|---|---|---|
| GPS TOW sec | MP | | Integer(0..604799) | seconds<br>GPS time-of-week when the DGPS corrections were calculated |
| Status/Health | MP | | Enumerated( UDRE scale 1.0, UDRE scale 0.75, UDRE scale 0.5, UDRE scale 0.3, UDRE scale 0.2, UDRE scale 0.1, no data, invalid data) | |
| DGPS information | CV-*Status/Health* | 1 to <maxSat> | | If the Cipher information is included these fields are ciphered. |

| Information Element/Group name | Need | Multi | Type and Reference | Semantics description |
|---|---|---|---|---|
| >SatID | MP | | Enumerated (0…63) | Identifies the satellite and is equal to (SV ID No - 1) where SV ID No is defined in [12]. |
| >IODE | MP | | Integer(0..255) | |
| >UDRE | MP | | Enumerated( UDRE ≤ 1.0 m, 1.0m < UDRE ≤ 4.0m, 4.0m < UDRE ≤ 8.0m, 8.0m < UDRE) | The value in this field shall be multiplied by the UDRE Scale Factor in the IE Status/Health to determine the final UDRE estimate for the particular satellite. |
| >PRC | MP | | Real(-655.04..655.04 by step of 0.32) | meters (different from [13]) |
| >RRC | MP | | Real(-4.064..4.064 by step of 0.032) | meters/sec (different from [13]) |
| >Delta PRC2 | MP | | Integer(-127..127) | In this version of the protocol this IE should be set to zero and the UE shall ignore it |
| >Delta RRC2 | MP | | Real(-0.224..0.224 by step of 0.032) | In this version of the protocol this IE should be set to zero and the UE shall ignore it |
| >Delta PRC3 | OP | | Integer(-127..127) | This IE should not be included in this version of the protocol and if received the UE shall ignore it |
| >Delta RRC3 | OP | | Real(-0.224..0.224 by step of 0.032) | This IE should not be included in this version of the protocol and if received the UE shall ignore it |

| Condition | Explanation |
|---|---|
| *Status/Health* | This IE is mandatory present if "status" is not equal to "no data" or "invalid data", otherwise the IE is not needed. |

### 10.3.7.91a UE positioning GPS Ephemeris and Clock Correction parameters

This IE contains information for GPS ephemeris and clock correction.

| Information Element/Group name | Need | Multi | Type and Reference | Semantics description |
|---|---|---|---|---|
| C/A or P on L2 | MP | | Bit string(2) | Code(s) on L2 Channel [12] |
| URA Index | MP | | Bit string(4) | User Range Accuracy [12] |
| SV Health | MP | | Bit string(6) | [12] |
| IODC | MP | | Bit string(10) | Issue of Data, Clock [12] |
| L2 P Data Flag | MP | | Bit string(1) | [12] |
| SF 1 Reserved | MP | | Bit string(87) | [12] |
| $T_{GD}$ | MP | | Bit string(8) | Estimated group delay differential [12] |
| $t_{oc}$ | MP | | Bit string(16) | apparent clock correction [12] |
| $af_2$ | MP | | Bit string(8) | apparent clock correction [12] |

| Information Element/Group name | Need | Multi | Type and Reference | Semantics description |
|---|---|---|---|---|
| $af_1$ | MP | | Bit string(16) | apparent clock correction [12] |
| $af_0$ | MP | | Bit string(22) | apparent clock correction [12] |
| $C_{rs}$ | MP | | Bit string(16) | Amplitude of the Sine Harmonic Correction Term to the Orbit Radius (meters) [12] |
| $\Delta n$ | MP | | Bit string(16) | Mean Motion Difference From Computed Value (semi-circles/sec) [12] |
| $M_0$ | MP | | Bit string(32) | Mean Anomaly at Reference Time (semi-circles) [12] |
| $C_{uc}$ | MP | | Bit string(16) | Amplitude of the Cosine Harmonic Correction Term To The Argument Of Latitude (radians) [12] |
| e | MP | | Bit string(32) | c |
| $C_{us}$ | MP | | Bit string(16) | Amplitude of the Sine Harmonic Correction Term To The Argument Of Latitude (radians) [12] |
| $(A)^{1/2}$ | MP | | Bit string(32) | Semi-Major Axis (meters)$^{1/2}$ [12] |
| $t_{oe}$ | MP | | Bit string(16) | Reference Time Ephemeris [12] |
| Fit Interval Flag | MP | | Bit string(1) | [12] |
| AODO | MP | | Bit string(5) | Age Of Data Offset [12] |
| $C_{ic}$ | MP | | Bit string(16) | Amplitude of the Cosine Harmonic Correction Term To The Angle Of Inclination (radians) [12] |
| $OMEGA_0$ | MP | | Bit string(32) | Longitude of Ascending Node of Orbit Plane at Weekly Epoch (semi-circles) [12] |
| $C_{is}$ | MP | | Bit string(16) | Amplitude of the Sine Harmonic Correction Term To The Angle Of Inclination (radians) [12] |
| $i_0$ | MP | | Bit string(32) | Inclination Angle at Reference Time (semi-circles) [12] |
| $C_{rc}$ | MP | | Bit string(16) | Amplitude of the Cosine Harmonic Correction Term to the Orbit Radius (meters) [12] |
| $\omega$ | MP | | Bit string(32) | Argument of Perigee (semi-circles) [12] |
| OMEGAdot | MP | | Bit string(24) | Longitude of Ascending Node of Orbit Plane at Weekly Epoch (semi-circles/sec) [12] |
| Idot | MP | | Bit string(14) | Rate of Inclination Angle (semi-circles/sec) [12] |

### 10.3.7.92 UE positioning GPS ionospheric model

The IE contains fields needed to model the propagation delays of the GPS signals through the ionosphere.

| Information Element/Group name | Need | Multi | Type and Reference | Semantics description |
|---|---|---|---|---|
| $\alpha_0$ | MP | | Bit string(8) | Note 1 |
| $\alpha_1$ | MP | | Bit string(8) | Note 1 |
| $\alpha_2$ | MP | | Bit string(8) | Note 1 |
| $\alpha_3$ | MP | | Bit string(8) | Note 1 |
| $\beta_0$ | MP | | Bit string(8) | Note 2 |
| $\beta_1$ | MP | | Bit string(8) | Note 2 |
| $\beta_2$ | MP | | Bit string(8) | Note 2 |
| $\beta_3$ | MP | | Bit string(8) | Note 2 |

NOTE 1: The parameters $\alpha$n are the coefficients of a cubic equation representing the amplitude of the vertical delay [12].

NOTE 2: The parameters $\beta$n are the coefficients of a cubic equation representing the period of the ionospheric model [12].

### 10.3.7.93 UE positioning GPS measured results

| Information Element/Group name | Need | Multi | Type and Reference | Semantics description |
|---|---|---|---|---|
| CHOICE *Reference Time* | MP | | | |
| >UTRAN reference time | | | | |
| >>UE GPS timing of cell frames | MP | | Integer(0..3715891199 9999 | GPS Time of Week in units of 1/16$^{th}$ UMTS chips according to [19]. 33209832177664 spare values are needed. |
| >>CHOICE *mode* | MP | | | |
| >>>FDD | | | | |
| >>>>Primary CPICH Info | MP | | Primary CPICH Info 10.3.6.60 | Identifies the reference cell for the GPS TOW-SFN relationship. |
| >>>TDD | | | | |
| >>>>cell parameters id | MP | | Cell parameters id 10.3.6.9 | Identifies the reference cell for the GPS TOW-SFN relationship. |
| >>Reference SFN | MP | | Integer(0..4095) | The SFN for which the location is valid. This IE indicates the SFN at which the UE timing of cell frames is captured. |
| >GPS reference time only | | | | |
| >>GPS TOW msec | MP | | Integer(0..6.048*10$^8$-1) | GPS Time of Week in milliseconds (rounded down to the nearest millisecond unit). |
| Measurement Parameters | MP | 1 to <maxSat> | | |
| >Satellite ID | MP | | Enumerated(0..63) | Identifies the satellite and is equal to (SV ID No - 1) where SV ID No is defined in [12]. |
| >C/N$_o$ | MP | | Integer(0..63) | the estimate of the carrier-to-noise ratio of the received signal from the particular satellite used in the measurement. It is given in units of dB-Hz (typical levels will be in the range of 20 – 50 dB-Hz). |

| Information Element/Group name | Need | Multi | Type and Reference | Semantics description |
|---|---|---|---|---|
| >Doppler | MP | | Integer(-32768..32768) | Hz, scale factor 0.2. |
| >Whole GPS Chips | MP | | Integer(0..1022) | Unit in GPS chips.<br>Whole value of the UE GPS code-phase measurement, where increasing binary values of the field signify increasing measured pseudoranges.The UE GPS code-phase measurement is divided into the fields 'Whole GPS Chips' and 'Fractional GPS Chips'. |
| >Fractional GPS Chips | MP | | Integer(0..($2^{10}$-1)) | Scale factor $2^{-10}$<br>Fractional value of the UE GPS code-phase measurement. |
| >Multipath Indicator | MP | | Enumerated( NM, low, medium, high) | Note 1. |
| >Pseudorange RMS Error | MP | | Enumerated( range index 0..range index 63) | Note 2. |

NOTE 1: The following table gives the mapping of the multipath indicator field.

| Value | Multipath Indication |
|---|---|
| NM | Not measured |
| Low | MP error < 5m |
| Medium | 5m < MP error < 43m |
| High | MP error > 43m |

NOTE 2: The following table gives the bitmapping of the Pseudorange RMS Error field.

| Range Index | Mantissa | Exponent | Floating-Point value, $x_i$ | Pseudorange value, P |
|---|---|---|---|---|
| 0 | 000 | 000 | 0.5 | P < 0.5 |
| 1 | 001 | 000 | 0.5625 | 0.5 <= P < 0.5625 |
| I | X | Y | $0.5 * (1 + x/8) * 2^y$ | $x_{i-1}$ <= P < $x_i$ |
| 62 | 110 | 111 | 112 | 104 <= P < 112 |
| 63 | 111 | 111 | -- | 112 <= P |

## 10.3.7.94 UE positioning GPS navigation model

This IE contain information required to manage the transfer of precise navigation data to the GPS-capable UE.

| Information Element/Group name | Need | Multi | Type and Reference | Semantics description |
|---|---|---|---|---|
| Satellite information | MP | 1 to <maxSat> | | |
| >SatID | MP | | Enumerated( 0..63) | Identifies the satellite and is equal to (SV ID No - 1) where SV ID No is defined in [12]. |
| >Satellite Status | MP | | Enumerated( NS_NN, | NOTE |

| Information Element/Group name | Need | Multi | Type and Reference | Semantics description |
|---|---|---|---|---|
| | | | ES_SN, ES_NN, REVD) | |
| >GPS Ephemeris and Clock Correction parameters | CV-*Satellite status* | | UE positioning GPS Ephemeris and Clock Correction parameters 10.3.7.91a | |

NOTE: The UE shall interpret enumerated symbols as follows.

| Value | Indication |
|---|---|
| NS_NN | New satellite, new Navigation Model |
| ES_SN | Existing satellite, same Navigation Model |
| ES_NN | Existing satellite, new Navigation Model |
| REVD | Reserved |

| Condition | Explanation |
|---|---|
| *Satellite status* | The IE is not needed if the IE "Satellite status" is ES_SN and mandatory present otherwise. |

### 10.3.7.95 UE positioning GPS real-time integrity

This IE contains parameters that describe the real-time status of the GPS constellation.

| Information Element/Group name | Need | Multi | Type and Reference | Semantics description |
|---|---|---|---|---|
| Satellite information | MP | 1 to <maxSat> | | |
| >BadSatID | MP | | Enumerated( 0..63) | Identifies the satellite and is equal to (SV ID No - 1) where SV ID No is defined in [12]. |

### 10.3.7.95a Void

### 10.3.7.96 UE positioning GPS reference time

| Information Element/Group name | Need | Multi | Type and Reference | Semantics description |
|---|---|---|---|---|
| GPS Week | MP | | Integer(0..1023) | |
| GPS TOW msec | MP | | Integer(0..6.048*$10^8$-1) | GPS Time of Week in milliseconds (rounded down to the nearest millisecond unit). |
| UTRAN GPS reference time | OP | | | |
| >UTRAN GPS timing of cell frames | MP | | Integer(0..2322431999999) | UTRAN GPS timing of cell frames in steps of 1 chip |
| >CHOICE *mode* | OP | | | |
| >>FDD | | | | |
| >>>Primary CPICH Info | MP | | Primary CPICH Info 10.3.6.60 | Identifies the reference cell for the GPS TOW-SFN relationship |
| >>TDD | | | | |

| Information Element/Group name | Need | Multi | Type and Reference | Semantics description |
|---|---|---|---|---|
| >>>cell parameters id | MP | | Cell parameters id 10.3.6.9 | Identifies the reference cell for the GPS TOW-SFN relationship |
| >SFN | MP | | Integer(0..4095) | The SFN which the UTRAN GPS timing of cell frames time stamps. |
| SFN-TOW Uncertainty | OP | | Enumerated (lessThan10, moreThan10) | This field indicates the uncertainty of the relation GPS TOW/SFN. lessThan10 means the relation is accurate to at least 10 ms. |
| $T_{UTRAN-GPS}$ drift rate | OP | | Integer (0, 1, 2, 5, 10, 15, 25, 50, -1, -2, -5, -10, -15, -25, -50) | in 1/256 chips per sec. |
| GPS TOW Assist | OP | 1 to <maxSat> | | |
| >SatID | MP | | Enumerated(0..63) | Identifies the satellite and is equal to (SV ID No - 1) where SV ID No is defined in [12]. |
| >TLM Message | MP | | Bit string(14) | |
| >TLM Reserved | MP | | Bit string(2) | |
| >Alert | MP | | Boolean | |
| >Anti-Spoof | MP | | Boolean | |

## 10.3.7.97 UE positioning GPS UTC model

The UTC Model field contains a set of parameters needed to relate GPS time to Universal Time Coordinate (UTC).

| Information Element/Group name | Need | Multi | Type and Reference | Semantics description |
|---|---|---|---|---|
| $A_1$ | MP | | Bit string(24) | sec/sec [12] |
| $A_0$ | MP | | Bit string(32) | seconds [12] |
| $t_{ot}$ | MP | | Bit string(8) | seconds [12] |
| $WN_t$ | MP | | Bit string(8) | weeks [12] |
| $\Delta t_{LS}$ | MP | | Bit string(8) | seconds [12] |
| $WN_{LSF}$ | MP | | Bit string(8) | weeks [12] |
| DN | MP | | Bit string(8) | days [12] |
| $\Delta t_{LSF}$ | MP | | Bit string(8) | seconds [12] |

## 10.3.7.98 UE positioning IPDL parameters

This IE contains parameters for the IPDL mode. The use of this parameters is described in [29].

| Information Element/Group name | Need | Multi | Type and Reference | Semantics description | Version |
|---|---|---|---|---|---|
| CHOICE *mode* | | | | | REL-4 |
| >FDD | | | | | REL-4 |
| >>IP spacing | MP | | Integer(5,7,10,15,20,30,40,50) | See [29] | |
| >>IP length | MP | | Integer(5,10) | See [29] | |
| >>IP offset | MP | | Integer(0..9) | See [29] | |
| >>Seed | MP | | Integer(0..63) | See [29] | |
| >TDD | | | | | REL-4 |
| >>IP spacing | MP | | Integer(30,40,50,70,100) | See [33] | REL-4 |
| >>IP_Start | MP | | Integer(0..40 | See [33] | REL-4 |

| Information Element/Group name | Need | Multi | Type and Reference | Semantics description | Version |
|---|---|---|---|---|---|
| | | | 95) | | |
| >>IP_Slot | MP | | Integer(0..14) | See [33] | REL-4 |
| >>IP_PCCPCH | CV-*channel* | | Boolean | See [33] | REL-4 |
| Burst mode parameters | OP | | | | |
| >Burst Start | MP | | Integer(0..15) | See [29] and [33] | |
| >Burst Length | MP | | Integer(10..25) | See [29] and [33] | |
| >Burst freq | MP | | Integer(1..16) | See [29] and [33] | |

| Condition | Explanation |
|---|---|
| *channel* | This IE is present only if the idle slot carries the PCCPCH |

### 10.3.7.99 UE positioning measured results

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| UE positioning OTDOA measured results | OP | | UE positioning OTDOA measured results 10.3.7.105 | |
| UE positioning Position estimate info | OP | | UE positioning Position estimate info 10.3.7.109 | |
| UE positioning GPS measured results | OP | | UE positioning GPS measured results 10.3.7.93 | |
| UE positioning error | OP | | UE positioning error 10.3.7.87 | Included if UE positioning error occurred |

### 10.3.7.100 UE positioning measurement

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| UE positioning reporting quantity | MP | | UE positioning reporting quantity 10.3.7.111 | |
| Measurement validity | OP | | Measurement validity 10.3.7.51 | |
| CHOICE *reporting criteria* | MP | | | |
| >UE positioning reporting criteria | | | UE positioning reporting criteria 10.3.7.110 | |

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| >Periodical reporting criteria | | | Periodical reporting criteria 10.3.7.53 | |
| >No reporting | | | | (no data) |
| UE positioning OTDOA assistance data for UE-assisted | OP | | UE positioning OTDOA assistance data for UE-assisted 10.3.7.103 | |
| UE positioning OTDOA assistance data for UE-based | OP | | UE positioning OTDOA assistance data for UE-based 10.3.7.103a | |
| UE positioning GPS assistance data | OP | | UE positioning GPS assistance data 10.3.7.90 | |

### 10.3.7.101 UE positioning measurement event results

This IE contains the measurement event results that are reported to UTRAN for UE positioning measurements.

| Information Element/Group name | Need | Multi | Type and Reference | Semantics description |
|---|---|---|---|---|
| CHOICE *Event ID* | MP | | | One spare value is needed. |
| >7a | | | | |
| >>UE positioning Position estimate info | MP | | UE positioning Position estimate info 10.3.7.109 | |
| >7b | | | | |
| >>UE positioning OTDOA measured results | MP | | UE positioning OTDOA measured results 10.3.7.105 | |
| >7c | | | | |
| >>UE positioning GPS measurement | MP | | UE positioning GPS measured results 10.3.7.93 | |

### 10.3.7.102 Void

### 10.3.7.103 UE positioning OTDOA assistance data for UE-assisted

| Information Element/Group name | Need | Multi | Type and Reference | Semantics description |
|---|---|---|---|---|
| UE positioning OTDOA reference cell info for UE-assisted | OP | | UE positioning OTDOA reference cell info 10.3.7.108 | |
| UE positioning OTDOA neighbour cell list for UE-assisted | OP | 1 to <maxCellMeas> | | |
| >UE positioning OTDOA neighbour cell info for UE-assisted | MP | | UE positioning OTDOA neighbour cell info 10.3.7.106 | |

### 10.3.7.103a UE positioning OTDOA assistance data for UE-based

| Information Element/Group name | Need | Multi | Type and Reference | Semantics description |
|---|---|---|---|---|
| UE positioning OTDOA reference cell info for UE-based | OP | | UE positioning OTDOA reference cell info for UE-based 10.3.7.108a | |
| UE positioning OTDOA neighbour cell list for UE-based | OP | 1 to <maxCellMeas> | | |
| >UE positioning OTDOA neighbour cell info for UE-based | MP | | UE positioning OTDOA neighbour cell info for UE-based 10.3.7.106a | |

### 10.3.7.104 Void

### 10.3.7.105 UE positioning OTDOA measured results

| Information Element/Group name | Need | Multi | Type and Reference | Semantics description |
|---|---|---|---|---|
| SFN | MP | | Integer(0..4095) | SFN during which the last measurement was performed |
| CHOICE *mode* | | | | |
| >FDD | | | | |
| >>Reference cell id | MP | | Primary CPICH info 10.3.6.60 | |
| >>UE Rx-Tx time difference type 2 info | MP | | | |
| >>>UE Rx-Tx time difference type 2 | MP | | UE Rx-Tx time difference | |

| Information Element/Group name | Need | Multi | Type and Reference | Semantics description |
|---|---|---|---|---|
| | | | type 2 10.3.7.84 | |
| >>>UE positioning OTDOA quality | MP | | UE positioning OTDOA quality 10.3.7.107 | Quality of the UE Rx-Tx time difference type 2 measurement from the reference cell. |
| >TDD | | | | (no data) |
| >>Reference cell id | MP | | Cell parameters ID 10.3.6.9 | |
| Neighbours | MP | 0 to <maxCellMeas> | | |
| >CHOICE *mode* | MP | | | |
| >>FDD | | | | |
| >>>Neighbour Identity | MD | | Primary CPICH info 10.3.6.60 | Default value is the same as in the first set of multiple sets. |
| >>>Frequency info | MD | | Frequency info 10.3.6.36 | Default value is the existing value of frequency information |
| >>>UE Rx-Tx time difference type 2 info | OP | | | Included for cell in the active set excluding the reference cell. |
| >>>>UE Rx-Tx time difference type 2 | MP | | UE Rx-Tx time difference type 2 10.3.7.84 | |
| >>>>UE positioning OTDOA quality | MP | | UE positioning OTDOA quality 10.3.7.107 | Quality of the UE Rx-Tx time difference type 2 measurement from the neighbour cell. |
| >>TDD | | | | |
| >>>Cell and Channel ID | MD | | Cell and Channel Identity info 10.3.6.8a | Default value is the same as in the first set of multiple sets. |
| >UE positioning OTDOA quality | MP | | UE positioning OTDOA quality 10.3.7.107 | Quality of the SFN-SFN observed time difference type 2 measurement from the neighbour cell. |
| >SFN-SFN observed time difference type 2 | MP | | SFN-SFN observed time difference 10.3.7.63 | Gives the timing relative to the reference cell. Only type 2 is allowed. |

### 10.3.7.106 UE positioning OTDOA neighbour cell info

This IE gives approximate cell timing in order to decrease the search window.

| Information Element/Group name | Need | Multi | Type and Reference | Semantics description |
|---|---|---|---|---|
| CHOICE *mode* | MP | | | |
| >FDD | | | | |
| >>Primary CPICH info | MP | | Primary CPICH info 10.3.6.60 | |
| >TDD | | | | |

| Information Element/Group name | Need | Multi | Type and Reference | Semantics description |
|---|---|---|---|---|
| >>cell and channel ID | MP | | Cell and Channel Identity info 10.3.6.8a | Identifies the channel to be measured on. |
| Frequency info | MD | | Frequency info 10.3.6.36 | Default value is the existing value of frequency information |
| IPDL parameters | CV-*IPDLs* | | UE positioning IPDL parameters 10.3.7.98 | |
| SFN offset | MP | | Integer (0 .. 4095) | Although this IE is not always required, need is MP to align with ASN.1.<br>Define Tref as the time of beginning of system frame number SFNref of the reference cell. Define Tnc as the beginning of a frame from the neighbour cell occurring immediately after the time Tref. Let the corresponding system frame number be SFNnc. Then SFNnc = SFNref-SFN offset modulo 4096. |
| SFN offset validity | MD | | Enumerated (false) | Absence of this element means SFN offset is valid.<br>False means SFN offset is not valid. |
| SFN-SFN relative time difference | MP | | Integer(0.. 38399) | Gives the relative timing compared to the reference cell. Equal to $\lfloor$ (Tnc-Tref)*($3.84*10^6$) $\rfloor$ where $\lfloor()\rfloor$ denotes rounding to the nearest lower integer.<br>In chips, Tnc = the time of beginning of a system frame from the neighbour cell, Tref = the time of beginning of a system frame from the reference cell. |
| SFN-SFN drift | OP | | Integer (0, -1, -2, -3, -4, -5, -8, -10, -15, -25, -35, -50, -65, -80, -100, 1, 2, 3, 4, 5, 8, 10, 15, 25, 35, 50, 65, 80, 100) | in 1/256 chips per second |
| Search Window Size | MP | | Integer(20, 40, 80, 160, 320, 640, 1280, infinity) | In chips. If the value is X then the expected SFN-SFN observed time difference is in the range [RTD-X, RTD+X] where RTD is the value of the field SFN-SFN relative time difference.<br>Infinity means that the uncertainty is larger than 1280 chips. |
| CHOICE *PositioningMode* | MP | | | |
| >UE based | | | | (no data) |

| Information Element/Group name | Need | Multi | Type and Reference | Semantics description |
|---|---|---|---|---|
| >UE assisted | | | | (no data) |

| Condition | Explanation |
|---|---|
| *IPDLs* | This IE is mandatory present if IPDLs are applied and not needed otherwise. |

## 10.3.7.106a UE positioning OTDOA neighbour cell info for UE-based

This IE gives approximate cell timing in order to decrease the search window, as well as the cell locations and fine cell timing for UE based OTDOA.

| Information Element/Group name | Need | Multi | Type and Reference | Semantics description |
|---|---|---|---|---|
| UE positioning OTDOA neighbour cell info | MP | | UE positioning OTDOA neighbour cell info 10.3.7.106 | |
| Cell Position | MD | | | Default is the same as previous cell |
| >Relative North | OP | | Integer(-20000..20000) | Seconds of angle, scale factor 0.03. Relative position compared to reference cell. |
| >Relative East | OP | | Integer(-20000..20000) | Seconds of angle, scale factor 0.03. Relative position compared to reference cell. |
| >Relative Altitude | OP | | Integer(-4000..4000) | Relative altitude in meters compared to ref. cell. |
| Fine SFN-SFN | MP | | Real(0..0.9375 in steps of 0.0625) | Gives finer resolution |
| UE positioning Relative Time Difference Quality | MP | | UE positioning OTDOA quality 10.3.7.109a | Quality of the relative time difference between neighbour and reference cell. |
| Round Trip Time | OP | | Real(876.00 .. 2923.875) in steps of 0.0625 | In chips. Included if cell is in active set. |

## 10.3.7.107 UE positioning OTDOA quality

| Information Element/Group name | Need | Multi | Type and Reference | Semantics description |
|---|---|---|---|---|
| Std Resolution | MP | | Bit string(2) | Std Resolution field includes the resolution used in Std of OTDOA Measurements field. Encoding on two bits as follows:<br>'00' 10 meters<br>'01' 20 meters<br>'10' 30 meters<br>'11' Reserved |
| Number of OTDOA Measurements | MP | | Bit string(3) | The 'Number of OTDOA measurements' field indicates how many OTDOA measurements have been used in the UE to determine the sample standard deviation |

| Information Element/Group name | Need | Multi | Type and Reference | Semantics description |
|---|---|---|---|---|
| | | | | of the measurements.<br>Following 3 bit encoding is used:<br>'001' 5-9<br>'010' 10-14<br>'011' 15-24<br>'100' 25-34<br>'101' 35-44<br>'110' 45-54<br>'111' 55 or more<br>Special case:<br>'000':In this case the field 'Std of OTDOA measurements' contains the std of the reported SFN-SFN otd value = $\sqrt{E[(x-\mu)^2]}$, where x is the reported value and $\mu = E[x]$ is the expectation value (i.e. the true value) of x. This std can be used irrespective of the number of measurements and reporting of the number of measurements is not needed. Also other measurements such as Ec/No or Rx levels can be utilised in this case to evaluate the 'Std of OTDOA measurements' reported in this IE. |
| Std of OTDOA Measurements | MP | | Bit string(5) | Std of OTDOA Measurements field includes sample standard deviation of OTDOA measurements (when number of measurements is reported in 'Number of OTDOA measurements field') or standard deviation of the reported SFN-SFN otd value = $\sqrt{E[(x-\mu)^2]}$, where x is the reported value and $\mu = E[x]$ is the expectation value (i.e. the true value) of x (when '000' is given in 'Number of OTDOA measurements' field).<br>Following linear 5 bit encoding is used:<br>'00000' 0 - (R*1-1) meters<br>'00001' R*1 – (R*2-1) meters<br>'00010' R*2 – (R*3-1) meters<br>…<br>'11111' R*31 meters or more<br>where R is the resolution defined by Std Resolution field. E.g. R=20 m corresponds to 0-19 m, 20-39 m,…,620+ m. |

### 10.3.7.108 UE positioning OTDOA reference cell info

This IE defines the cell used for time references in all OTDOA measurements.

| Information Element/Group name | Need | Multi | Type and Reference | Semantics description |
|---|---|---|---|---|

| Information Element/Group name | Need | Multi | Type and Reference | Semantics description |
|---|---|---|---|---|
| SFN | OP | | Integer (0..4095) | Time stamp (SFN of Reference Cell) of the SFN-SFN relative time differences and SFN-SFN drift rates. Included if any SFN-SFN drift value is included in IE UE positioning OTDOA neighbour cell info. |
| CHOICE *mode* | MP | | | |
| >FDD | | | | |
| >>Primary CPICH info | MP | | Primary CPICH info 10.3.6.60 | |
| >TDD | | | | |
| >>cell and channel ID | MP | | Cell and Channel Identity info 10.3.6.8a | Identifies the channel to be measured on. |
| Frequency info | MD | | Frequency info 10.3.6.36 | Default value is the existing value of frequency information. This IE shall always be set to default value |
| CHOICE *PositioningMode* | MP | | | |
| >UE based | | | | |
| >UE assisted | | | | (no data) |
| IPDL parameters | OP | | UE positioning IPDL parameters 10.3.7.98 | If this element is not included there are no idle periods present |

## 10.3.7.108a UE positioning OTDOA reference cell info for UE-based

This IE defines the cell used for time references in all OTDOA measurements for UE-based methods.

| Information Element/Group name | Need | Multi | Type and Reference | Semantics description |
|---|---|---|---|---|
| UE positioning OTDOA reference cell info | MP | | UE positioning OTDOA reference cell info 10.3.7.108 | |
| CHOICE *Cell Position* | OP | | | The position of the antenna that defines the cell. Used for the UE based method. |
| >Ellipsoid | | | | |
| >>Ellipsoid point | MP | | Ellipsoid point 10.3.8.4a | |
| >Ellipsoid with altitude | | | | |
| >>Ellipsoid point with altitude | MP | | Ellipsoid point with altitude 10.3.8.4b | |
| Round Trip Time | OP | | Real(876.00 .. 2923.875) in steps of 0.0625 | In chips. |

### 10.3.7.109 UE positioning position estimate info

The purpose of this IE is to provide the position estimate from the UE to the network, if the UE is capable of determining its own position.

| Information Element/Group name | Need | Multi | Type and Reference | Semantics description | Version |
|---|---|---|---|---|---|
| CHOICE *Reference Time* | MP | | | | |
| >UTRAN GPS reference time | | | | | |
| >>UE GPS timing of cell frames | MP | | Integer(0..3715891199 9999) | GPS Time of Week in units of 1/16$^{th}$ UMTS chips according to [19]. 33209832177664 spare values are needed. | |
| >>CHOICE *mode* | MP | | | | |
| >>>FDD | | | | | |
| >>>>Primary CPICH Info | MP | | Primary CPICH Info 10.3.6.60 | Identifies the reference cell for the GPS TOW-SFN relationship | |
| >>>TDD | | | | | |
| >>cell parameters id | MP | | Cell parameters id 10.3.6.9 | Identifies the reference cell for the GPS TOW-SFN relationship. | |
| >>Reference SFN | MP | | Integer(0..4095) | The SFN for which the location is valid. This IE indicates the SFN at which the UE timing of cell frame is captured. | |
| >GPS reference time only | | | | | |
| >>GPS TOW msec | MP | | Integer(0..6.048*10$^8$-1) | GPS Time of Week in milliseconds (rounded down to the nearest millisecond unit). | |
| >Cell timing | | | | | |
| >>SFN | MP | | Integer(0..4095) | SFN during which the position was calculated. | |
| >>CHOICE *mode* | MP | | | | |
| >>>FDD | | | | | |
| >>>>Primary CPICH Info | MP | | Primary CPICH Info 10.3.6.60 | Identifies the reference cell for SFN | |
| >>>TDD | | | | | |
| >>cell parameters id | MP | | Cell parameters id 10.3.6.9 | Identifies reference cell for SFN | |
| CHOICE *Position estimate* | MP | | | | |
| >Ellipsoid Point | | | Ellipsoid Point; 10.3.8.4a | | |
| >Ellipsoid point with uncertainty circle | | | Ellipsoid point with uncertainty circle 10.3.8.4d | | |
| >Ellipsoid point with uncertainty ellipse | | | Ellipsoid point with uncertainty ellipse 10.3.8.4e | | |
| >Ellipsoid point with altitude | | | Ellipsoid point with altitude 10.3.8.4b | | |
| >Ellipsoid point with altitude and uncertainty ellipsoid | | | Ellipsoid point with altitude and uncertainty ellipsoid 10.3.8.4c | | |

| Information Element/Group name | Need | Multi | Type and Reference | Semantics description | Version |
|---|---|---|---|---|---|
| CHOICE *Velocity estimate* | OP | | | | REL-7 |
| >Horizontal Velocity | | | Horizontal Velocity 10.3.8.4h | | REL-7 |
| >Horizontal with Vertical Velocity | | | Horizontal with Vertical Velocity 10.3.8.4i | | REL-7 |
| >Horizontal Velocity with Uncertainty | | | Horizontal Velocity with Uncertainty 10.3.8.4j | | REL-7 |
| >Horizontal with Vertical Velocity and Uncertainty | | | Horizontal with Vertical Velocity and Uncertainty 10.3.8.4k | | REL-7 |

### 10.3.7.109a UE positioning Relative Time Difference quality

| Information Element/Group name | Need | Multi | Type and Reference | Semantics description |
|---|---|---|---|---|
| Relative Time Difference Std Resolution | MP | | Bit string(2) | Std Resolution field includes the resolution used in Std of Relative Time Difference field. Encoding on two bits as follows:<br>'00' 10 meters<br>'01' 20 meters<br>'10' 30 meters<br>'11' Reserved |
| Std of Relative Time Difference | MP | | Bit string(5) | Std of Relative Time difference field includes standard deviation of (SFN-SFN relative time difference + Fine SFN-SFN). Following linear 5 bit encoding is used:<br>'00000' 0 - (R*1-1) meters<br>'00001' R*1 – (R*2-1) meters<br>'00010' R*2 – (R*3-1) meters<br>…<br>'11111' R*31 meters or more<br>where R is the resolution defined by Std Resolution field. E.g. R=20 m corresponds to 0-19 m, 20-39 m,…,620+ m. |

### 10.3.7.110 UE positioning reporting criteria

The triggering of the event-triggered reporting for a UE positioning measurement.

| Information Element/Group name | Need | Multi | Type and Reference | Semantics description |
|---|---|---|---|---|
| Parameters required for each event | OP | 1 to <maxMeasEvent> | | |
| >Amount of reporting | MP | | Integer(1, 2, 4, 8, 16, 32, 64,infinite) | |
| >Report first fix | MP | | Boolean | If true the UE reports the position once the measurement control is received, and then each time an event is triggered. |
| >Measurement interval | MP | | Integer(5,15, 60,300,900,1800,3600,7200) | Indicates how often the UE should make the measurement In seconds |
| >CHOICE *Event ID* | MP | | | |
| >>7a | | | | |
| >>>Threshold Position Change | MP | | Integer(10,20,30,40,50,100,200,300,500,1000,2000,5000,10000,20000,50000,100000) | Meters. Indicated how much the position should change compared to last reported position fix in order to trigger the event. |
| >>7b | | | | |
| >>>Threshold SFN-SFN change | MP | | Real(0.25,0.5,1,2,3,4,5,10,20,50,100,200,500,1000,2000,5000) | Chips. Indicates how much the SFN-SFN measurement of ANY measured cell is allowed to change before the event is triggered. |
| >>7c | | | | |
| >>>Threshold SFN-GPS TOW | MP | | Integer(1,2,3,5,10,20,50,100) | Time in ms. When the GPS TOW and SFN timer has drifted apart more than the specified value the event is triggered. |

## 10.3.7.111 UE positioning reporting quantity

The purpose of the element is to express the allowed/required location method(s), and to provide information desired QoS.

| Information Element/Group name | Need | Multi | Type and Reference | Semantics description | Version |
|---|---|---|---|---|---|
| Method Type | MP | | Enumerated( UE assisted, UE based, UE based is preferred but UE assisted is allowed, UE assisted is preferred but UE based is allowed) | | |
| Positioning Methods | MP | | Enumerated( OTDOA, GPS, OTDOA or GPS, Cell ID) | | |
| Response Time | MP | | Integer(1,2,4 | This IE shall be ignored. | |

| Information Element/Group name | Need | Multi | Type and Reference | Semantics description | Version |
|---|---|---|---|---|---|
| | | | , 8, 16, 32, 64, 128) | | |
| Horizontal Accuracy | CV-*MethodType* | | Bit string(7) | The uncertainty is derived from the "uncertainty code" k by $r = 10*(1.1^k-1)$ in meters. | |
| Vertical Accuracy | CV-*MethodType* | | Bit string(7) | The uncertainty is derived from the "uncertainty code" k by $r = 45*(1.025^k-1)$ in meters. | |
| GPS timing of Cell wanted | MP | | Boolean | If true the SRNC wants the UE to report the SFN-GPS timing of the reference cell. This is however optional in the UE. | |
| Multiple Sets | MP | | Boolean | This IE shall be ignored. | |
| Additional Assistance Data Request | MP | | Boolean | TRUE indicates that the UE is requested to send the IE "Additional assistance Data Request" when the IE "UE positioning Error" is present in the UE positioning measured results. FALSE indicates that the UE shall use the assistance data available. | |
| Environment Characterisation | OP | | Enumerated( possibly heavy multipath and NLOS conditions, no or light multipath and usually LOS conditions, not defined or mixed environment) | One spare value is needed. | |
| Velocity Requested | OP | | Enumerated( requested) | If this element is present the UE is requested to send a velocity estimate | REL-7 |

| Condition | Explanation |
|---|---|
| *Method Type* | The IE is optional if the IE "Method Type" is "UE assisted"; otherwise it is mandatory present. |

## 10.3.7.112 $T_{ADV}$ info

NOTE: Only for 1.28 Mcps TDD.

$T_{ADV}$ indicates the difference between the Rx timing and Tx timing of a UE.

| Information Element/group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| $T_{ADV}$ | MP | | Integer (0..2047) | As defined in [20]. | REL-4 |
| SFN | MP | | Integer(0..4095) | SFN during which the $T_{ADV}$ measurement was performed. | REL-4 |

## 10.3.8 Other Information elements

### 10.3.8.1 BCCH modification info

Indicates modification of the System Information on BCCH.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| MIB Value tag | MP | | MIB Value tag 10.3.8.9 | |
| BCCH modification time | OP | | Integer (0.. 4088 in step of 8) | All SFN values in which MIB may be mapped are allowed. |

### 10.3.8.2 BSIC

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Base transceiver Station Identity Code (BSIC) | MP | | | [11] |
| >Network Colour Code (NCC) | MP | | bit string(3) | The first/leftmost bit of the bit string contains the most significant bit of the NCC. |
| >Base Station Colour Code (BCC) | MP | | bit string(3) | The first/leftmost bit of the bit string contains the most significant bit of the BCC. |

### 10.3.8.3 CBS DRX Level 1 information

This information element contains the CBS discontinuous reception information to be broadcast for CBS DRX Level 1 calculations in the UE.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| Period of CTCH allocation (N) | MP | | Integer (1..256) | $M_{TTI} \leq N \leq 256$, N multiple of $M_{TTI}$ | |
| CBS frame offset (K) | MP | | Integer (0..255) | $0 \leq K \leq N-1$, K multiple of $M_{TTI}$ | |
| Period of BMC scheduling messages (P) | CV-*SIB5* | | Integer (8, 16, 32, 64, 128, 256) | | REL-6 |

| Condition | Explanation |
|---|---|
| *SIB5* | The IE is optional when the IE "CBS DRX Level 1 information" in SIB5, otherwise the IE is not needed |

### 10.3.8.4 Cell Value tag

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Cell Value tag | MP | | Integer (1..4) | |

### 10.3.8.4a Ellipsoid point

This IE contains the description of an ellipsoid point as in [24].

| Information Element/Group name | Need | Multi | Type and Reference | Semantics description |
|---|---|---|---|---|
| Latitude sign | MP | | Enumerated (North, South) | |
| Degrees Of Latitude | MP | | Integer $(0...2^{23}-1)$ | The IE value ($N$) is derived by this formula: $N \leq 2^{23} X/90 < N+1$ $X$ being the latitude in degree (0°.. 90°) |
| Degrees Of Longitude | MP | | Integer $(-2^{23}...2^{23}-1)$ | The IE value ($N$) is derived by this formula: $N \leq 2^{24} X/360 < N+1$ $X$ being the longitude in degree (-180°..+180°) |

### 10.3.8.4b Ellipsoid point with Altitude

This IE contains the description of an ellipsoid point with altitude as in [24].

| Information Element/Group name | Need | Multi | Type and Reference | Semantics description |
|---|---|---|---|---|
| Latitude sign | MP | | Enumerated (North, South) | |
| Degrees Of Latitude | MP | | Integer $(0...2^{23}-1)$ | The IE value ($N$) is derived by this formula: $N \leq 2^{23} X/90 < N+1$ $X$ being the latitude in degree (0°.. 90°) |
| Degrees Of Longitude | MP | | Integer $(-2^{23}...2^{23}-1)$ | The IE value ($N$) is derived by this formula: $N \leq 2^{24} X/360 < N+1$ $X$ being the longitude in degree (-180°..+180°) |
| Altitude Direction | MP | | Enumerated (Height, Depth) | |
| Altitude | MP | | Integer $(0..2^{15}-1)$ | The IE value ($N$) is derived by this formula: $N \leq a < N+1$ $a$ being the altitude in metres |

### 10.3.8.4c Ellipsoid point with Altitude and uncertainty ellipsoid

This IE contains the description of an ellipsoid point with altitude and uncertainty ellipsoid as in [24].

| Information Element/Group name | Need | Multi | Type and Reference | Semantics description |
|---|---|---|---|---|
| Latitude sign | MP | | Enumerated (North, South) | |
| Degrees Of Latitude | MP | | Integer $(0...2^{23}-1)$ | The IE value ($N$) is derived by this formula: $N \leq 2^{23} X/90 < N+1$ $X$ being the latitude in degree (0°.. 90°) |

| Information Element/Group name | Need | Multi | Type and Reference | Semantics description |
|---|---|---|---|---|
| Degrees Of Longitude | MP | | Integer (-$2^{23}$...$2^{23}$-1) | The IE value (*N*) is derived by this formula:<br>$N \leq 2^{24} X/360 < N+1$<br>*X* being the longitude in degree (-180°..+180°) |
| Altitude Direction | MP | | Enumerated (Height, Depth) | |
| Altitude | MP | | Integer (0..$2^{15}$-1) | The IE value (*N*) is derived by this formula:<br>$N \leq a < N+1$<br>*a* being the altitude in metres |
| Uncertainty semi-major | MP | | Integer (0...127) | The uncertainty *r* is derived from the "uncertainty code" *k* by<br>$r = 10x(1.1^k-1)$ |
| Uncertainty semi-minor | MP | | Integer (0...127) | The uncertainty *r* is derived from the "uncertainty code" *k* by<br>$r = 10x(1.1^k-1)$ |
| Orientation of major axis | MP | | Integer (0..89) | The IE value (*N*) is derived by this formula:<br>$2N \leq a < 2(N+1)$<br>*a* being the orientation in degree (0°.. 179°) |
| Uncertainty Altitude | MP | | Integer(0..127) | The uncertainty in altitude, h, expressed in metres is mapped from the IE value (*K*), with the following formula:<br>$h = C\left((1+x)^K - 1\right)$<br>with $C = 45$ and $x = 0.025$. |
| Confidence | MP | | Integer (0..100) | in percentage |

### 10.3.8.4d Ellipsoid point with uncertainty Circle

This IE contains the description of an ellipsoid point with an uncertainty circle as in [24].

| Information Element/Group name | Need | Multi | Type and Reference | Semantics description |
|---|---|---|---|---|
| Latitude sign | MP | | Enumerated (North, South) | |
| Degrees Of Latitude | MP | | Integer (0...$2^{23}$-1) | The IE value (N) is derived by this formula:<br>$N \leq 2^{23} X/90 < N+1$<br>*X* being the latitude in degree (0°.. 90°) |
| Degrees Of Longitude | MP | | Integer (-$2^{23}$...$2^{23}$-1) | The IE value (*N*) is derived by this formula:<br>$N \leq 2^{24} X/360 < N+1$<br>*X* being the longitude in degree (-180°..+180°) |
| Uncertainty Code | MP | | Integer (0...127) | The uncertainty *r* is derived from the "uncertainty code" *k* by<br>$r = 10x(1.1^k-1)$ |

### 10.3.8.4e Ellipsoid point with uncertainty Ellipse

This IE contains the description of an ellipsoid point with an uncertainty ellipse as in [24].

| Information Element/Group name | Need | Multi | Type and Reference | Semantics description |
|---|---|---|---|---|
| Latitude sign | MP | | Enumerated (North, South) | |
| Degrees Of Latitude | MP | | Integer ($0...2^{23}-1$) | The IE value (N) is derived by this formula: $N \leq 2^{23} X/90 < N+1$ $X$ being the latitude in degree (0°.. 90°) |
| Degrees Of Longitude | MP | | Integer ($-2^{23}...2^{23}-1$) | The IE value (N) is derived by this formula: $N \leq 2^{24} X/360 < N+1$ $X$ being the longitude in degree (-180°..+180°) |
| Uncertainty semi-major | MP | | Integer (0...127) | The uncertainty $r$ is derived from the "uncertainty code" $k$ by $r = 10x(1.1^k-1)$ |
| Uncertainty semi-minor | MP | | Integer (0...127) | The uncertainty $r$ is derived from the "uncertainty code" $k$ by $r = 10x(1.1^k-1)$ |
| Orientation of major axis | MP | | Integer (0..89) | The IE value ($N$) is derived by this formula: $2N \leq a < 2(N+1)$ $a$ being the orientation in degree (0°.. 179°) |
| Confidence | MP | | Integer (0..100) | in percentage |

### 10.3.8.4f GERAN system information

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| >>> GERAN System Info | MP | 1 to <maxGERANSI> | | | REL-5 |
| >>>> GERAN system info block | MP | | Octet string(1..23) | The first octet contains octet 1 of the GERAN system information block, the second octet contains octet 2 of the GERAN system information block and so on. | REL-5 |

### 10.3.8.4g GSM Target Cell Info

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| GSM Target Cell Info List | MP | 1 to <maxGSMTargetCells> | | | REL-6 |
| >BCCH ARFCN | MP | | Integer (0..1023) | [45] | REL-6 |
| >Band indicator | MP | | Enumerated | Indicates how to | REL-6 |

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| | | | (DCS 1800 band used, PCS 1900 band used) | interpret the BCCH ARFCN | |
| >BSIC | OP | | BSIC 10.3.8.2 | | REL-6 |

### 10.3.8.4h Horizontal Velocity

This IE contains the description of a horizontal velocity as in [24].

| Information Element/Group name | Need | Multi | Type and Reference | Semantics description |
|---|---|---|---|---|
| Bearing | MP | | Integer (0...359) | The direction of movement is given in degrees where "0" represents North, "90" represents East, etc. |
| Horizontal Speed | MP | | Integer ($0...2^{11}-1$) | The relationship between (N) and the horizontal speed (h) in kilometers per hour it describes is:<br>$N \le h < N + 0.5$, for (N=0)<br>$N-0.5 \le h < N + 0.5$, for ($0<N<2^{11}-1$)<br>$N - 0.5 \le h$, for ($N = 2^{11}-1$) |

### 10.3.8.4i Horizontal with Vertical Velocity

This IE contains the description of horizontal with vertical velocity as in [24].

| Information Element/Group name | Need | Multi | Type and Reference | Semantics description |
|---|---|---|---|---|
| Vertical Speed direction | MP | | ENUMERATED (upward, downward) | |
| Bearing | MP | | Integer (0...359) | The direction of movement is given in degrees where "0" represents North, "90" represents East, etc. |
| Horizontal Speed | MP | | Integer ($0...2^{11}-1$) | The relationship between (N) and the horizontal speed (h) in kilometers per hour it describes is:<br>$N \le h < N + 0.5$, for (N=0)<br>$N-0.5 \le h < N + 0.5$, for ($0<N<2^{11}-1$)<br>$N - 0.5 \le h$, for ($N = 2^{11}-1$) |
| Vertical Speed | MP | | Integer (0..255) | The relationship between (N) and the vertical speed (v) in kilometres per hour it describes is given by the formula:<br>$N \le v < N + 0.5$, for (N=0)<br>$N-0.5 \le v < N + 0.5$, for ($0<N<2^{8}-1$)<br>$N - 0.5 \le v$, for ($N = 2^{8}-1$) |

### 10.3.8.4j Horizontal Velocity with Uncertainty

This IE contains the description of horizontal velocity with uncertainty as in [24].

| Information Element/Group name | Need | Multi | Type and Reference | Semantics description |
|---|---|---|---|---|
| Bearing | MP | | Integer (0...359) | The direction of movement is given in degrees where "0" represents North, "90" represents East, etc. |
| Horizontal Speed | MP | | Integer ($0...2^{11}-1$) | The relationship between (N) and the horizontal speed (h) in kilometers per hour it describes is:<br>$N \le h < N + 0.5$, for (N=0)<br>$N-0.5 \le h < N + 0.5$, for ($0<N<2^{11}-1$)<br>$N - 0.5 \le h$, for ($N = 2^{11}-1$) |
| Horizontal Uncertainty Speed | MP | | Integer (0..255) | The IE value is encoded in increments of 1 kilometer per hour. The value of N give the uncertainty speed except for N=255 which indicates that the uncertainty is not specified |

### 10.3.8.4k Horizontal with Vertical Velocity and Uncertainty

This IE contains the description of horizontal with vertical velocity and uncertainty as in [24].

| Information Element/Group name | Need | Multi | Type and Reference | Semantics description |
|---|---|---|---|---|
| Vertical Speed direction | MP | | ENUMERATED (upward, downward) | |
| Bearing | MP | | Integer (0...359) | The direction of movement is given in degrees where "0" represents North, "90" represents East, etc. |
| Horizontal Speed | MP | | Integer ($0...2^{11}-1$) | The relationship between (N) and the horizontal speed (h) in kilometers per hour it describes is:<br>$N \le h < N + 0.5$, for (N=0)<br>$N-0.5 \le h < N + 0.5$, for ($0<N<2^{11}-1$)<br>$N - 0.5 \le h$, for ($N = 2^{11}-1$) |
| Vertical Speed | MP | | Integer (0..255) | The relationship between (N) and the vertical speed (v) in kilometres per hour it describes is given by the formula:<br>$N \le v < N + 0.5$, for (N=0)<br>$N-0.5 \le v < N + 0.5$, for ($0<N<2^{8}-1$)<br>$N - 0.5 \le v$, for ($N = 2^{8}-1$) |
| Horizontal Uncertainty Speed | MP | | Integer (0..255) | The IE value is encoded in increments of 1 kilometer per hour. The value of N give the uncertainty speed except for N=255 which indicates that the uncertainty is not specified |

| Information Element/Group name | Need | Multi | Type and Reference | Semantics description |
|---|---|---|---|---|
| Vertical Uncertainty Speed | MP | | Integer (0..255) | The IE value is encoded in increments of 1 kilometer per hour. The value of N give the uncertainty speed except for N=255 which indicates that the uncertainty is not specified |

### 10.3.8.5 Inter-RAT change failure

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Inter-RAT change failure cause | MP | | Enumerated( Configuration unacceptable, physical channel failure, protocol error, unspecified) | Four spare values are needed. |
| Protocol error information | CV-*ProtErr* | | Protocol error information 10.3.8.12 | |

| Condition | Explanation |
|---|---|
| *ProtErr* | The IE is mandatory present if the IE "Inter-RAT change failure cause" has the value "Protocol error" and not needed otherwise. |

### 10.3.8.6 Inter-RAT handover failure

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Inter-RAT handover failure cause | MD | | Enumerated( Configuration unacceptable, physical channel failure, protocol error, inter-RAT protocol error, unspecified) | Default value is "unspecified".<br><br>Eleven spare values are needed. |
| Protocol error information | CV-*ProtErr* | | Protocol error information 10.3.8.12 | |

| Condition | Explanation |
|---|---|
| *ProtErr* | The IE is mandatory present if the IE "Inter-RAT handover failure cause" has the value "Protocol error" and not needed otherwise. |

### 10.3.8.7 Inter-RAT UE radio access capability

This Information Element contains the inter-RAT UE radio access capability that is structured and coded according to the specification used for the corresponding system type.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| CHOICE *system* | MP | | | | |
| >GSM | | | | | |
| >>Mobile Station Classmark 2 | MP | | Octet string (5) | This IE is formatted as 'TLV' and is coded in the same way as the *Mobile Station Classmark 2* information element in [5]. The first octet is the *Mobile station classmark 2 IEI* and its value shall be set to 33H. The second octet is the *Length of mobile station classmark 2* and its value shall be set to 3.<br>The octet 3 contains the first octet of the value part of the *Mobile Station Classmark 2* information element, the octet 4 contains the second octet of the value part of the *Mobile Station Classmark 2* information element and so on. For each of these octets, the first/ leftmost/ most significant bit of the octet contains b8 of the corresponding octet of the *Mobile Station Classmark 2*.<br>In this version of the protocol the first two octets of the Mobile Station Classmark 2 IE containing the *Mobile station classmark 2 IEI* and the *Length of mobile station classmark 2 contents* should be ignored by the receiver. | |
| >>Mobile Station Classmark 3 | MP | | Octet string (1..32) | This IE is formatted as 'V' and is coded in the same way as the value part in the *Mobile station classmark 3* information element in [5].<br>The first octet contains octet 1 of the value part of *Mobile station classmark 3*, the second octet contains octet 2 of the value part of *Mobile station classmark 3* and so on. | |

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| | | | | See NOTE 1. | |
| >>MS Radio Access Capability | OP | | Octet string (1..64) | This IE is formatted as 'V' and is coded in the same way as the value part in the *MS Radio Access Capability* information element in [5]. | REL-6 |
| >GERAN Iu | | | | | REL-5 |
| >>MS GERAN Iu mode Radio Access Capability | MP | | Bit string (1..170) | Formatted and coded according to [53]. The first/leftmost/most significant bit of the bit string contains bit 8 of the first octet of the IE. | REL-5 |
| >cdma2000 | | | | | |
| >>cdma2000Message | MP | 1.to.<maxInterSysMessages> | | | |
| >>>MSG_TYPE(s) | MP | | Bit string (8) | Formatted and coded according to cdma2000 specifications. The first/leftmost/most significant bit of the bit string contains bit 7 of the MSG_TYPE. | |
| >>>cdma2000Messagepayload(s) | MP | | Bit string (1..512) | Formatted and coded according to cdma2000 specifications. The first/leftmost/most significant bit of the bit string contains bit 7 of the first octet of the cdma2000 message. | |

NOTE 1: The value part is specified by means of CSN.1, which encoding results in a bit string, to which final padding may be appended upto the next octet boundary [5]. The first/ leftmost bit of the CSN.1 bit string is placed in the first/ leftmost/ most significant bit of the first octet. This continues until the last bit of the CSN.1 bit string, which is placed in the last/ rightmost/ least significant bit of the last octet.

### 10.3.8.8 Void

### 10.3.8.8a Inter-RAT UE security capability

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| CHOICE *system* | MP | | | | |
| >GSM | | | | | |
| >>GSM security capability | MP | | | The value TRUE means that the indicated ciphering algorithm is supported. | |
| >>>A5/7 supported | MP | | Boolean | | |
| >>>A5/6 supported | MP | | Boolean | | |
| >>>A5/5 supported | MP | | Boolean | | |
| >>>A5/4 supported | MP | | Boolean | | |
| >>>A5/3 supported | MP | | Boolean | | |
| >>>A5/2 supported | MP | | Boolean | | |
| >>>A5/1 supported | MP | | Boolean | | |

### 10.3.8.9 MIB Value tag

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| MIB Value tag | MP | | Integer (1..8) | |

### 10.3.8.10 PLMN Value tag

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| PLMN Value tag | MP | | Integer (1..256) | |

### 10.3.8.10a PNBSCH allocation

UTRAN may use this IE to provide silent periods in the cell that may be used for cell synchronisation purposes.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| Number of repetitions per SFN period | MP | | Integer(2, 3, 4, 5, 6, 7, 8, 9, 10, 12, 14, 16, 18, 20, 24, 28, 32, 36, 40, 48, 56, 64, 72, 80) | | REL-4 |

### 10.3.8.11 Predefined configuration identity and value tag

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Predefined configuration identity | MP | | Predefined configuration identity 10.3.4.5 | |
| Predefined configuration value tag | MP | | Predefined configuration value tag 10.3.4.6 | |

### 10.3.8.12 Protocol error information

This information element contains diagnostics information returned by the receiver of a message that was not completely understood.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| CHOICE *diagnostics type* | MP | | | One spare value is needed. |
| >Protocol error cause | | | Protocol error cause 10.3.3.26 | |

### 10.3.8.13 References to other system information blocks

| Information element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| References to other system information blocks | MP | 1 to <maxSIB> | | System information blocks for which multiple occurrences are used, may appear more than once in this list |
| >Scheduling information | MP | | Scheduling information, 10.3.8.16 | |
| >SIB type SIBs only | MP | | SIB Type SIBs only, 10.3.8.22 | |

### 10.3.8.14 References to other system information blocks and scheduling blocks

| Information element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| References to other system information blocks | MP | 1 to <maxSIB> | | System information blocks for which multiple occurrences are used, may appear more than once in this list |
| >Scheduling information | MP | | Scheduling information, 10.3.8.16 | |
| >SIB and SB type | MP | | SIB and SB Type, 10.3.8.18a | |

### 10.3.8.15 Rplmn information

Contains information to provide faster RPLMN selection in the UE.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| GSM BA Range | OP | 1 to maxNumGSMFreqRanges | | GSM BA Range | |
| >GSM Lower Range (UARFCN) | MP | | Integer(0..16383) | Lower bound for range of GSM BA freqs | |
| >GSM Upper Range (UARFCN) | MP | | Integer(0..16383) | Upper bound for range of GSM BA freqs | |
| FDD UMTS Frequency list | OP | 1 to maxNumFDDFreqs | | | |
| >UARFCN (Nlow) | MP | | Integer(0..16 | [21] | |

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| | | | 383) | | |
| >UARFCN (Nupper) | OP | | Integer(0..16383) | [21]<br>This IE is only needed when the FDD frequency list is specifying a range. | |
| 3.84 Mcps TDD UMTS Frequency list | OP | 1 to maxNumTDDFreqs | | | |
| >UARFCN | MP | | Integer(0..16383) | [22] | |
| 7.68 Mcps TDD UMTS Frequency list | OP | 1 to maxNumTDDFreqs | | | |
| >UARFCN | MP | | Integer(0..16383) | [22] | |
| 1.28 Mcps TDD UMTS Frequency list | OP | 1 to maxNumTDDFreqs | | | REL-4 |
| >UARFCN | MP | | Integer(0..16383) | [22] | REL-4 |
| CDMA2000 UMTS Frequency list | OP | 1 to maxNumCDMA200Freqs | | | |
| >BAND_CLASS | MP | | Bit string(5 bits) | TIA/EIA/IS-2000<br>When mapping the BAND_CLASS to the bit string, the first/leftmost bit of the bit string contains the most significant bit.. | |
| >CDMA_FREQ | MP | | Bit string (11 bits) | TIA/EIA/IS-2000<br>When mapping the CDMA_FREQ to the bit string, the first/leftmost bit of the bit string contains the most significant bit.. | |

### 10.3.8.16 Scheduling information

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| CHOICE *Value tag* | OP | | | |
| >PLMN Value tag | | | PLMN Value tag 10.3.8.10 | This IE is included if the following conditions are fulfilled:<br>the SIB type equals system information block type 1 |
| >Predefined configuration identity and value tag | | | Predefined configuration identity and value tag 10.3.8.11 | This IE is included if the following conditions are fulfilled:<br>the SIB type equals system information block type 16 |
| >Cell Value tag | | | Cell Value tag 10.3.8.4 | This IE is included if the following conditions are fulfilled:<br>the area scope for the system information block is set to |

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| | | | | "cell" in table 8.1.1.<br>a value tag is used to indicate changes in the system information block. |
| >SIB occurrence identity and value tag | | | SIB occurrence identity and value tag 10.3.8.20b | This IE is included if the following conditions are fulfilled:<br>the SIB type equals system information block types 15.2 and 15.3 |
| Scheduling | MP | | | |
| >SEG_COUNT | MD | | SEG COUNT 10.3.8.17 | Default value is 1 |
| >SIB_REP | MP | | Integer (4, 8, 16, 32, 64, 128, 256, 512, 1024, 2048, 4096) | Repetition period for the SIB in frames |
| >SIB_POS | MP | | Integer (0 ..Rep-2 by step of 2) | Position of the first segment Rep is the value of the SIB_REP IE |
| >SIB_POS offset info | MD | 1..15 | | see below for default value |
| >>SIB_OFF | MP | | Integer(2..32 by step of 2) | Offset of subsequent segments |

| Field | Default value |
|---|---|
| SIB_POS offset info | The default value is that all segments are consecutive, i.e., that the SIB_OFF = 2 for all segments except when MIB segment/complete MIB is scheduled to be transmitted in between segments from same SIB. In that case, SIB_OFF=4 in between segments which are scheduled to be transmitted at SFNprime = 8 *n-2 and 8*n + 2, and SIB_OFF=2 for the rest of the segments. |

### 10.3.8.17 SEG COUNT

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| SEG_COUNT | MP | | Integer (1..16) | Number of segments in the system information block |

### 10.3.8.18 Segment index

Each system information segment has an individual segment index.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Segment index | MP | | Integer (1..15) | Segments of a system information block are numbered starting with 0 for the first segment and 1 for the next segment, which can be the first subsequent segment or a last segment. |

### 10.3.8.18a SIB and SB type

The SIB type identifies a specific system information block.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| SIB and SB type | MP | | Enumerated, see below | Two spare values are needed |

| List of enumerated values | Version |
|---|---|
| System Information Type 1,<br>System Information Type 2,<br>System Information Type 3,<br>System Information Type 4,<br>System Information Type 5,<br>System Information Type 6,<br>System Information Type 7,<br>System Information Type 11,<br>System Information Type 12,<br>System Information Type 13,<br>System Information Type 13.1,<br>System Information Type 13.2,<br>System Information Type 13.3,<br>System Information Type 13.4,<br>System Information Type 14,<br>System Information Type 15,<br>System Information Type 15.1,<br>System Information Type 15.2,<br>System Information Type 15.3,<br>System Information Type 15.4,<br>System Information Type 15.5,<br>System Information Type 16,<br>System Information Type 17,<br>System Information Type 18,<br>Scheduling Block 1,<br>Scheduling Block 2, | |
| System Information Type 5bis | REL-6 |

### 10.3.8.19 SIB data fixed

Contains the result of a master information block or a system information block after encoding and segmentation. The IE is used for segments with fixed length (segments filling an entire transport block).

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| SIB data fixed | MP | | Bit string ( 222) | The first bit contains the first bit of the segment. |

### 10.3.8.20 SIB data variable

Contains either a complete system information block or a segment of a system information block. Contains the result of a master information block or a system information block after encoding and segmentation. The IE is used for segments with variable length. The system information blocks are defined in clauses10.2.48.8.1 to10.2.48.8.18.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| SIB data variable | MP | | Bit string ( 1..214) | The first bit contains the first bit of the segment. |

### 10.3.8.20a SIB occurrence identity

This information element identifies a SIB occurrence for System Information Block types 15.2 and 15.3. For System Information Block type 15.2, this identity is assigned to the visible satellite only. Unused identities are claimed by newly rising satellites.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| SIB occurrence identity | MP | | Integer (0..15) | |

### 10.3.8.20b SIB occurrence identity and value tag

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| SIB occurrence identity | MP | | SIB occurrence identity 10.3.8.20a | |
| SIB occurrence value tag | MP | | SIB occurrence value tag 10.3.8.20c | |

### 10.3.8.20c SIB occurrence value tag

This information element is used to identify different versions of SIB occurrence for System Information Block types 15.2 and 15.3.

| Information Element/Group name | Need | Multi | Type and Reference | Semantics description |
|---|---|---|---|---|
| SIB occurrence value tag | MP | | Integer(0..15) | |

### 10.3.8.21 SIB type

The SIB type identifies a specific system information block.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| SIB type | MP | | Enumerated, see below | One spare value is needed |

| List of enumerated values | Version |
|---|---|
| Master information block,<br>System Information Type 1,<br>System Information Type 2,<br>System Information Type 3,<br>System Information Type 4,<br>System Information Type 5,<br>System Information Type 6,<br>System Information Type 7,<br>System Information Type 11,<br>System Information Type 12,<br>System Information Type 13,<br>System Information Type 13.1,<br>System Information Type 13.2,<br>System Information Type 13.3,<br>System Information Type 13.4,<br>System Information Type 14,<br>System Information Type 15,<br>System Information Type 15.1,<br>System Information Type 15.2,<br>System Information Type 15.3,<br>System Information Type 15.4,<br>System Information Type 15.5,<br>System Information Type 16,<br>System Information Type 17,<br>System Information Type 18,<br>Scheduling Block 1,<br>Scheduling Block 2, | |
| System Information Type 5bis | REL-6 |

### 10.3.8.22 SIB type SIBs only

The SIB type identifies a specific system information block.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| SIB type SIBs only | MP | | Enumerated, see below | Four spare values are needed |

| List of enumerated values | Version |
|---|---|
| System Information Type 1,<br>System Information Type 2,<br>System Information Type 3,<br>System Information Type 4,<br>System Information Type 5,<br>System Information Type 6,<br>System Information Type 7,<br>System Information Type 11,<br>System Information Type 12,<br>System Information Type 13,<br>System Information Type 13.1,<br>System Information Type 13.2,<br>System Information Type 13.3,<br>System Information Type 13.4,<br>System Information Type 14,<br>System Information Type 15,<br>System Information Type 15.1,<br>System Information Type 15.2,<br>System Information Type 15.3,<br>System Information Type 15.4,<br>System Information Type 15.5,<br>System Information Type 16,<br>System Information Type 17,<br>System Information Type 18, | |
| System Information Type 5bis | REL-6 |

## 10.3.9 ANSI-41 Information elements

### 10.3.9.1 ANSI-41 Core Network Information

| Information element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| P_REV | MP | | P_REV 10.3.9.10 | |
| MIN_P_REV | MP | | MIN_P_REV 10.3.9.8 | |
| SID | MP | | SID 10.3.9.11 | |
| NID | MP | | NID 10.3.9.9 | |

### 10.3.9.2 ANSI-41 Global Service Redirection information

This Information Element contains ANSI-41 Global Service Redirection information.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| ANSI-41 Global Service Redirection information | MP | | ANSI-41 NAS parameter, 10.3.9.3 | Formatted and coded according to the 3GPP2 document "G3G CDMA DS on ANSI-41" |

### 10.3.9.3 ANSI-41 NAS parameter

This Information Element contains ANSI-41 User Zone Identification information.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| ANSI-41 NAS parameter | MP | | Bit string (size (1..2048)) | The first bit contains the first bit of the ANSI-41 information. |

### 10.3.9.4 ANSI-41 NAS system information

This Information Element contains ANSI-41 system information.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| NAS (ANSI-41) system information | MP | | ANSI-41 NAS parameter, 10.3.9.3 | Formatted and coded according to the 3GPP2 document "G3G CDMA DS on ANSI-41" |

### 10.3.9.5 ANSI-41 Private Neighbour List information

This Information Element contains ANSI-41 Private Neighbour List information.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| ANSI-41 Private Neighbour List information | MP | | ANSI-41 NAS parameter, 10.3.9.3 | Formatted and coded according to the 3GPP2 document "G3G CDMA DS on ANSI-41" |

### 10.3.9.6 ANSI-41 RAND information

This Information Element contains ANSI-41 RAND information.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| ANSI-41 RAND information | MP | | ANSI-41 NAS parameter, 10.3.9.3 | Formatted and coded according to the 3GPP2 document "G3G CDMA DS on ANSI-41" |

### 10.3.9.7 ANSI-41 User Zone Identification information

This Information Element contains ANSI-41 User Zone Identification information.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| ANSI-41 User Zone Identification information | MP | | ANSI-41 NAS parameter, 10.3.9.3 | Formatted and coded according to the 3GPP2 document "G3G CDMA DS on ANSI-41" |

### 10.3.9.8 MIN_P_REV

This Information Element contains minimum protocol revision level.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| MIN_P_REV | MP | | Bit string (8) | Minimum protocol revision level. The first/leftmost bit of the bit string contains the most significant bit of the MIN_P_REV. |

#### 10.3.9.9 NID

This Information Element contains Network identification.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| NID | MP | | Bit string (16) | Network identification. The first/leftmost bit of the bit string contains the most significant bit of the NID. |

#### 10.3.9.10 P_REV

This Information Element contains protocol revision level.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| P_REV | MP | | Bit string (8) | Protocol revision level. The first/leftmost bit of the bit string contains the most significant bit of the P_REV. |

#### 10.3.9.11 SID

This Information Element contains System identification.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| SID | MP | | Bit string (15) | System identification. The first/leftmost bit of the bit string contains the most significant bit of the SID. |

### 10.3.9a MBMS Information elements

#### 10.3.9a.1 MBMS Common CCTrCH identity

Identifies a Coded Composite Transport channel configuration included within the MBMS COMMON P-T-M RB INFORMATION message.

| Information element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| MBMS Common CCTrCh identity | MP | | Integer (1..32) | | REL-6 |

### 10.3.9a.2 MBMS Common PhyCh identity

Identifies a physical channel configuration included within the MBMS COMMON P-T-M RB INFORMATION message.

| Information element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| MBMS Common PhyCh identity | MP | | Integer (1..32) | | REL-6 |

### 10.3.9a.3 MBMS Common RB identity

Identifies a radio bearer channel configuration included within the MBMS COMMON P-T-M RB INFORMATION message.

| Information element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| MBMS Common RB identity | MP | | Integer (1..32) | | REL-6 |

### 10.3.9a.4 MBMS Common TrCh identity

Identifies a transport channel configuration included within the MBMS COMMON P-T-M RB INFORMATION message.

| Information element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| MBMS Common TrCh identity | MP | | Integer (1..32) | | REL-6 |

### 10.3.9a.5 MBMS Current cell S-CCPCH identity

Identifies one of the current cell's Secondary CCPCH's.

| Information element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| MBMS Current cell S-CCPCH identity | MP | | Integer (1..maxSCCPCH) | | REL-6 |

### 10.3.9a.6 Void

### 10.3.9a.7 MBMS L1 combining schedule

Includes information about the MBMS L1 combining schedule.

| Information element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| MBMS L1 combining cycle length | MP | | Enumerated (32, 64, 128, 256, 512, 1024) | In number of radio frames | REL-6 |
| MBMS L1 combining cycle offset | MD | | Integer (0.. MBMS L1 combining cycle length - 4) by step of 4 | Start of the L1 combining cycle (relative to the timing of the current cell) in number of radio frames. Default value is no offset | REL-6 |
| MTCH L1- combining period list | MP | 1 to < maxMBMS-L1CP> | | One or more periods in which L1 combining is performed | REL-6 |
| >Start | MP | | Integer (0.. MBMS L1 combining cycle length - 4) by step of 4 | Number of frames from the end of the previous combining period or the start of the cycle (for the first period) | REL-6 |
| >Duration | MP | | Integer (4.. MBMS L1 combining cycle length) by step of 4 | Number of frames (see note) | REL-6 |

NOTE: The MTCH L1- combining period should indicate one or more complete TTIs.

### 10.3.9a.7o MBMS p-t-m activation time

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| MBMS p-t-m activation time | MP | | Integer (0..2047) | The 11 LSB of the SFN. Note 1 and 2. | REL-6 |
| Note 1: The 'MBMS p-t-m activation time' indicates the start of the 10 ms frame corresponding to the indicated SFN value and of the primary CCPCH of the cell where this IE is transmitted. | | | | | |
| Note 2: The range of the 'MBMS p-t-m activation time' is from 10 ms after the beginning of the MCCH modification period wherein it is transmitted and to the end of next following MCCH modification period. The UE shall consider a value out of this range as expired. | | | | | |

### 10.3.9a.7a MBMS p-t-m RB information

Includes information about an MBMS p-t-m radio bearers mapped on a TrCH.

| Information element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| RB information | CV-*Curr* | | MBMS Common RB identity 10.3.9a.3 | | REL-6 |
| MBMS short transmission ID | MP | | MBMS Short transmission identity 10.3.9a.10 | | REL-6 |
| MBMS logical channel identity | MP | | Integer (1..15) | This identifier is used to distinguish different MTCH mapped on to a TrCh ('MBMS-Id' within the MAC header[15]) | REL-6 |
| L1 combining status | CV-*Neigh* | | Boolean | The IE is only applicable in case of partial L1 comining, in which case value TRUE means that L1 combining is used for this radio bearer | REL-6 |

| Condition | Explanation |
|---|---|
| *Curr* | The IE is mandatory present if the IE 'MBMS p-t-m RB information list' is included in the MBMS CURRENT CELL P-T-M RB INFORMATION message and not needed otherwise |
| *Neigh* | The IE is mandatory present if the IE 'MBMS p-t-m RB information list' is included in the MBMS NEIGHBOURING CELL P-T-M RB INFORMATION message and not needed otherwise |

### 10.3.9a.8 MBMS Service identity

Includes information about the identity of an MBMS service.

| Information element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| MBMS Service ID | MP | | MBMS Service ID 10.3.9a.8a | | REL-6 |
| CHOICE *PLMN identity* | MP | | | | REL-6 |
| >*SameAs-MIB* | | | | (No data) The PLMN identity is the same as indicated by the IE 'PLMN identity' in MIB | REL-6 |
| >*SameAsMIB-MultiPLMN-Id* | | | | | REL-6 |
| >>Multi PLMN id | MP | | Integer (1..5) | The PLMN identity is one of the PLMN identities (1 to 5) in the IE "Multiple PLMN List" in MIB | REL-6 |
| >*ExplicitPLMN-Id* | | | | | REL-6 |
| >>PLMN identity | MP | | PLMN identity 10.3.1.11 | | REL-6 |

### 10.3.9a.8a MBMS Service ID

Uniquely identifies an MBMS bearer service within a PLMN.

| Information element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| MBMS Service ID | MP | | Octet string (3 ) | The content of the MBMS Service ID field is coded as octets 3 to 5 of the IE *Temporary Mobile Group Identity* [5] | REL-6 |

### 10.3.9a.9 MBMS Session identity

Includes information about the the identity of a session of an MBMS service.

| Information element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| MBMS Session ID | MP | | Octet string (1) | | REL-6 |

### 10.3.9a.10 MBMS Short transmission identity

Includes a short identity of the MBMS transmission identity, which concerns a session of a specific service.

| Information element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| MBMS short transmission identity | MP | | Integer (1..maxMBMSservUnmodif) | Reference/ index to a transmission listed in the MBMS MODIFIED SERVICES INFORMATION or MBMS UNMODIFIED SERVICES INFORMATION | REL-6 |

### 10.3.9a.10a MBMS Soft Combining Timing Offset

Indicates the timing offset applied in the CFN calculation in sub-clause 8.5.15.5 for a secondary CCPCH carrying only MBMS logical channels. It is used for FDD only.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| >MBMS Soft Combining Timing Offset | MP | | Integer (0, 10, 20, 40) | Timing offset applied in the CFN calculation in sub-clause 8.5.15.5, in ms. | REL-6 |

### 10.3.9a.11 MBMS specific timers and counters

Includes MBMS specific timers and counters.

| Information element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| T318 | MD | | Integer(250... 2000 by step of 250, 3000, 4000, 6000, 8000, 10000, 12000, 16000) | Value in milliseconds. Default value is 1000. | REL-6 |

### 10.3.9a.12 MBMS Transmission identity

Includes information about the MBMS transmission identity, which concerns a session of a specific service.

| Information element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| MBMS Service ID | MP | | MBMS Service identity 10.3.9a.8 | | REL-6 |
| MBMS Session ID | OP | | MBMS Session identity 10.3.9a.9 | | REL-6 |

### 10.3.9a.13 MCCH configuration information

Includes information about the MCCH configuration.

| Information element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| Access Info Period coefficient | MP | | Integer (0..3) | Represents *a*, the access information coefficient. The number of repetitions per modification period equals $2^a$ while the actual access information period, in number of frames, equals MP DIV $2^a$ | REL-6 |
| Repetition Period coefficient | MP | | Integer (0..3) | Represents *r*, the repetition period coefficient. The number of repetitions per modification period equals $2^r$ while the actual repetition period, in number of frames, equals MP DIV $2^r$ | REL-6 |

| | | | | | |
|---|---|---|---|---|---|
| Modification period coefficient | MP | | Integer (7..10) | Represents *m*, the modification period coefficient. The actual modification period (MP), in number of frames, equals $2^m$ | REL-6 |
| RLC info | MP | | RLC info MBMS 10.3.4.23a | | REL-6 |
| TCTF presence | CV-*MBMS* | | Enumerated (false) | By default the TCTF is present even though the FACH only carries one logical channel (type). When this IE is included, the TCTF is absent | REL-6 |

| Condition | Explanation |
|---|---|
| *MBMS* | This IE is not needed if the IE is contained within the IE 'Secondary CCPCH system information', otherwise the IE is optional. |

### 10.3.9a.14 MICH configuration information

Includes information about the MICH configuration.

| Information element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| MICH Power offset | MP | | MICH Power offset 10.3.9a.15 | | REL-6 |
| CHOICE *mode* | MP | | | | REL-6 |
| >FDD | | | | | REL-6 |
| >>Channelisation code | MP | | Integer (0.255) | | REL-6 |
| >>Number of NI per frame | MP | | Integer (18, 36, 72, 144) | | REL-6 |
| >>STTD indicator | MP | | STTD Indicator 10.3.6.78 | | REL-6 |
| >TDD | | | | | REL-6 |
| >>Timeslot number | MP | | Timeslot number 10.3.6.84 | | REL-6 |
| >>Midamble shift and burst type | MP | | Midamble shift and burst type 10.3.6.41 | | REL-6 |
| >>CHOICE *TDD option* | MP | | | | REL-6 |
| >>>3.84 Mcps TDD | | | | | REL-6 |
| >>>>Channelisation code | MP | | Enumerated ( (16/1)…(16/16)) | | REL-6 |
| >>>7.68 Mcps TDD | | | | | REL-7 |
| >>>>Channelisation code | MP | | Enumerated ( (32/1)…(32/32)) | | REL-7 |
| >>>1.28 Mcps TDD | | | | | REL-6 |
| >>>>Codes list | MP | 1 to 2 | | | REL-6 |
| >>>>>Channelisation code | MP | | Enumerated ( (16/1)…(16/16)) | | REL-6 |
| >>Repetition period/length | MD | | Enumerated((4/2),(8/2), (8/4),(16/2), (16/4), (32/2),(32/4),(64/2),(64/4)) | Default value is '(64/2)'. | REL-6 |
| >>Offset | MP | | Integer (0…Repetition period - 1) | SFN mod Repetitionperiod = Offset. | REL-6 |
| >>MBMS Notification indicator length | MD | | Integer (4, 8, 16) | Indicates the length of one MBMS Notification indicator in bits. Default value is 4. | REL-6 |

### 10.3.9a.15 MICH Power offset

This is the power transmitted on the MICH minus power of the Primary CPICH in FDD and Primary CCPCH Tx Power in TDD.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| MICH Power offset | MP | | Integer(-10 .. +5) | Offset in dB | REL-6 |

### 10.3.9a.16 MSCH configuration information

Includes information about the MSCH configuration.

| Information element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| MSCH configuration information | MP | | | For FDD, scheduling information is provided starting at (SFN – (SCTO div 10ms)) mod MSCH_REP = MSCH_OFF<br>For TDD, scheduling information is provided starting at SFN mod MSCH_REP = MSCH_OFF | REL-6 |
| >Scheduling period | MD | | Enumerated (32, 64, 128, 256, 512, 1024) | The period, in number of frames, between MBMS scheduling messages (MSCH_REP)<br>Default value is the value included in the MBMS GENERAL INFORMATION message | REL-6 |
| >Scheduling offset | MD | | Integer (0..(MSCH_REP-1)) | The position of MBMS scheduling messages relative to timing of the corresponding cell (MSCH_OFF)<br>Default value is the value included in the MBMS GENERAL INFORMATION message | REL-6 |
| >RLC info | MD | | RLC info MBMS 10.3.4.23a | Default value is the one included in the MBMS GENERAL INFORMATION message | REL-6 |
| TCTF presence | OP | | Enumerated (false) | By default the TCTF is present even though the FACH only carries one logical channel (type). When this IE is included, the TCTF is absent | REL-6 |

## 10.3.10 Multiplicity values and type constraint values

The following table includes constants that are either used as multi bounds (name starting with "max") or as high or low value in a type specification (name starting with "lo" or "hi"). Constants are specified only for values appearing more than once in the RRC specification. In case a constant is related to one or more other constants, an expression is included in the "value" column instead of the actual value.

| Constant | Explanation | Value | Version |
|---|---|---|---|
| **CN information** | | | |
| maxCNdomains | Maximum number of CN domains | 4 | |
| **UTRAN mobility information** | | | |
| maxRAT | Maximum number or Radio Access Technologies | maxOtherRAT + 1 | |
| maxOtherRAT | Maximum number or other Radio Access Technologies | 15 | |
| maxURA | Maximum number of URAs in a cell | 8 | |
| maxInterSysMessages | Maximum number of Inter System Messages | 4 | |
| maxRABsetup | Maximum number of RABs to be established | 16 | |
| **UE information** | | | |
| maxtransactions | Maximum number of parallel RRC transactions in downlink | 25 | |
| maxPDCPalgoType | Maximum number of PDCP algorithm types | 8 | |
| maxFreqBandsFDD | Maximum number of frequency bands supported by the UE as defined in [21] | 8 | |
| maxFreqBandsFDD-ext | Maximum number of frequency bands as defined in [21] and treated by RRC | 22 | REL-6 |
| maxFreqBandsTDD | Maximum number of frequency bands supported by the UE as defined in [22] | 4 | |
| maxFreqBandsGSM | Maximum number of frequency bands supported by the UE as defined in [45] | 16 | |
| maxPage1 | Number of UEs paged in the Paging Type 1 message | 8 | |
| maxSystemCapability | Maximum number of system specific capabilities that can be requested in one message. | 16 | |
| MaxURNTIgroup | Maximum number of U-RNTI groups in one message | 8 | REL-5 |
| **RB information** | | | |
| maxPredefConfig | Maximum number of predefined configurations | 16 | |
| maxRB | Maximum number of RBs | 32 | |
| maxSRBsetup | Maximum number of signalling RBs to be established | 8 | |
| maxRBperRAB | Maximum number of RBs per RAB | 8 | |
| maxRBallRABs | Maximum number of non signalling RBs | 27 | |
| maxRBperTrCh | Maximum number of RB per TrCh | 16 | REL-6 |
| maxRBMuxOptions | Maximum number of RB multiplexing options | 8 | |
| maxLoCHperRLC | Maximum number of logical channels per RLC entity | 2 | |
| maxRLCPDUsizePerLogChan | Maximum number of RLC PDU sizes per logical channel mapped on E-DCH | 32 | REL-6 |
| MaxROHC-PacketSizes | Maximum number of packet sizes that are allowed to be produced by ROHC. | 16 | |
| MaxROHC-Profiles | Maximum number of profiles supported by ROHC on a given RB. | 8 | |
| maxRFC 3095-CID | Maximum number of available CID values per radio bearer | 16384 | REL-5 |
| **TrCH information** | | | |
| maxE-DCHMACdFlow | Maximum number of E-DCH MAC-d flows | 8 | REL-6 |
| MaxHProcesses | Maximum number of H-ARQ processes | 8 | REL-5 |
| MaxHSDSCH_TB_index | Maximum number of TB set size configurations for the HS-DSCH. | 64 (FDD and 1.28 MCPS TDD); 512 (3.84 Mcps TDD); 1024 (7.68 Mcps TDD) | REL-5 |

| Constant | Explanation | Value | Version |
|---|---|---|---|
| maxMACdPDUSizes | Maximum number of MAC-d PDU sizes per queue permitted for MAC-hs | 8 | REL-5 |
| maxTrCH | Maximum number of transport channels used in one direction (UL or DL) | 32 | |
| maxTrCHpreconf | Maximum number of preconfigured Transport channels, per direction | 16 | |
| maxCCTrCH | Maximum number of CCTrCHs | 8 | |
| maxQueueID | Maximum number of Mac-hs queues | 8 | REL-5 |
| MaxTF | Maximum number of different transport formats that can be included in the Transport format set for one transport channel | 32 | |
| maxTFC | Maximum number of Transport Format Combinations | 1024 | |
| maxTFCsub | Maximum number of Transport Format Combinations Subset | 1024 | |
| maxSIBperMsg | Maximum number of complete system information blocks per SYSTEM INFORMATION message | 16 | |
| maxSIB | Maximum number of references to other system information blocks. | 32 | |
| maxSIB-FACH | Maximum number of references to system information blocks on the FACH | 8 | |
| **PhyCH information** | | | |
| maxHSSCCHs | Maximum number of HSSCCH codes that can be assigned to a UE | 4 | REL-5 |
| maxAC | Maximum number of access classes | 16 | |
| maxASC | Maximum number of access service classes | 8 | |
| maxASCmap | Maximum number of access class to access service classes mappings | 7 | |
| maxASCpersist | Maximum number of access service classes for which persistence scaling factors are specified | 6 | |
| maxPRACH | Maximum number of PRACHs in a cell | 16 | |
| MaxPRACH_FPACH | Maximum number of PRACH / FPACH pairs in a cell (1.28 Mcps TDD) | 8 | REL-4 |
| maxFACHPCH | Maximum number of FACHs and PCHs mapped onto one secondary CCPCHs | 8 | |
| maxRL | Maximum number of radio links | 8 | |
| maxEDCHRL | Maximum number of E-DCH radio links | 4 | REL-6 |
| maxSCCPCH | Maximum number of secondary CCPCHs per cell | 16 | |
| maxDPDCH-UL | Maximum number of DPDCHs per cell | 6 | |
| maxDPCH-DLchan | Maximum number of channelisation codes used for DL DPCH | 8 | |
| maxPUSCH | Maximum number of PUSCHs | (8) | |
| maxPDSCH | Maximum number of PDSCHs | 8 | |
| maxTS | Maximum number of timeslots used in one direction (UL or DL) | 14 (3.84 Mcps TDD and 7.68 Mcps TDD) | |
| | | 6 (1.28 Mcps TDD) | REL-4 |
| hiPUSCHidentities | Maximum number of PUSCH Identities | 64 | |
| hiPDSCHidentities | Maximum number of PDSCH Identities | 64 | |
| **Measurement information** | | | |
| maxTGPS | Maximum number of transmission gap pattern sequences | 6 | |
| maxAdditionalMeas | Maximum number of additional measurements for a given measurement identity | 4 | |
| maxMeasEvent | Maximum number of events that can be listed in measurement reporting criteria | 8 | |
| maxMeasParEvent | Maximum number of measurement parameters (e.g. thresholds) per event | 2 | |
| maxMeasIntervals | Maximum number of intervals that define the mapping function between the measurements for the cell quality Q of a cell and the representing quality value | 1 | |
| maxCellMeas | Maximum number of cells to measure | 32 | |

| Constant | Explanation | Value | Version |
|---|---|---|---|
| maxReportedGSMCells | Maximum number of GSM cells to be reported | 8 | |
| maxFreq | Maximum number of frequencies to measure | 8 | |
| maxSat | Maximum number of satellites to measure | 16 | |
| maxSatAlmanacStorage | Maximum number of satellites for which to store GPS Almanac information | 32 | |
| HiRM | Maximum number that could be set as rate matching attribute for a transport channel | 256 | |
| **Frequency information** | | | |
| MaxFDDFreqList | Maximum number of FDD carrier frequencies to be stored in USIM | 4 | |
| MaxTDDFreqList | Maximum number of TDD carrier frequencies to be stored in USIM | 4 | |
| MaxFDDFreqCellList | Maximum number of neighbouring FDD cells to be stored in USIM | 32 | |
| MaxTDDFreqCellList | Maximum number of neighbouring TDD cells to be stored in USIM | 32 | |
| MaxGSMCellList | Maximum number of GSM cells to be stored in USIM | 32 | |
| **Other information** | | | |
| MaxGERANSI | Maximum number of GERAN SI blocks that can be provided as part of NACC information | 8 | REL-5 |
| maxNumGSMFreqRanges | Maximum number of GSM Frequency Ranges to store | 32 | |
| MaxNumFDDFreqs | Maximum number of FDD centre frequencies to store | 8 | |
| MaxNumTDDFreqs | Maximum number of TDD centre frequencies to store | 8 | |
| maxNumCDMA200Freqs | Maximum number of CDMA2000 centre frequencies to store | 8 | |
| maxGSMTargetCells | Maximum number of GSM target cells | 32 | REL-6 |
| **MBMS information** | | | |
| maxMBMS-CommonCCTrCh | Maximum number of CCTrCh configurations included in the MBMS COMMON P-T-M RB INFORMATION message | 32 | REL-6 |
| maxMBMS-CommonPhyCh | Maximum number of PhyCh configurations included in the MBMS COMMON P-T-M RB INFORMATION message | 32 | REL-6 |
| maxMBMS-CommonRB | Maximum number of RB configurations included in the MBMS COMMON P-T-M RB INFORMATION message | 32 | REL-6 |
| maxMBMS-CommonTrCh | Maximum number of TrCh configurations included in the MBMS COMMON P-T-M RB INFORMATION message | 32 | REL-6 |
| maxMBMS-Freq | Maximum number of MBMS preferred frequencies | 4 | REL-6 |
| maxMBMS-L1CP | Maximum number of periods in which layer 1 combining applies | 4 | REL-6 |
| maxMBMSservCount | Maximum number of MBMS services in a Access Info message | 8 | REL-6 |
| maxMBMSservModif | Maximum number of MBMS services in a MBMS MODIFIED SERVICES INFORMATION message | 32 | REL-6 |
| maxMBMSservSched | Maximum number of MBMS services in a MBMS SCHEDULING INFORMATION | 16 | REL-6 |

| Constant | Explanation | Value | Version |
|---|---|---|---|
| | message | | |
| maxMBMSservUnmodif | Maximum number of MBMS services in a MBMS UNMODIFIED SERVICES INFORMATION message | 64 | REL-6 |
| maxMBMSTransmis | Maximum number of transmissions for which scheduling information is provided within a scheduling period | 4 | REL-6 |

# 11 Message and Information element abstract syntax (with ASN.1)

# 11 Message and Information element abstract syntax (with ASN.1)

## 11.1 General message structure

```
Class-definitions DEFINITIONS AUTOMATIC TAGS ::=

BEGIN

IMPORTS

    ActiveSetUpdate,
    ActiveSetUpdateComplete,
    ActiveSetUpdateFailure,
    AssistanceDataDelivery,
    CellChangeOrderFromUTRAN,
    CellChangeOrderFromUTRANFailure,
    CellUpdate,
    CellUpdateConfirm-CCCH,
    CellUpdateConfirm,
    CounterCheck,
    CounterCheckResponse,
    DownlinkDirectTransfer,
    HandoverToUTRANComplete,
    InitialDirectTransfer,
    HandoverFromUTRANCommand-GERANIu,
    HandoverFromUTRANCommand-GSM,
    HandoverFromUTRANCommand-CDMA2000,
    HandoverFromUTRANFailure,
    MBMSAccessInformation,
    MBMSCommonPTMRBInformation,
    MBMSCurrentCellPTMRBInformation,
    MBMSGeneralInformation,
    MBMSModificationRequest,
    MBMSModifiedServicesInformation,
    MBMSNeighbouringCellPTMRBInformation,
    MBMSSchedulingInformation,
    MBMSUnmodifiedServicesInformation,
    MeasurementControl,
    MeasurementControlFailure,
    MeasurementReport,
    PagingType1,
    PagingType2,
    PhysicalChannelReconfiguration,
    PhysicalChannelReconfigurationComplete,
    PhysicalChannelReconfigurationFailure,
    PhysicalSharedChannelAllocation,
    PUSCHCapacityRequest,
    RadioBearerReconfiguration,
```

```
    RadioBearerReconfigurationComplete,
    RadioBearerReconfigurationFailure,
    RadioBearerRelease,
    RadioBearerReleaseComplete,
    RadioBearerReleaseFailure,
    RadioBearerSetup,
    RadioBearerSetupComplete,
    RadioBearerSetupFailure,
    RRCConnectionReject,
    RRCConnectionRelease,
    RRCConnectionRelease-CCCH,
    RRCConnectionReleaseComplete,
    RRCConnectionRequest,
    RRCConnectionSetup,
    RRCConnectionSetupComplete,
    RRCStatus,
    SecurityModeCommand,
    SecurityModeComplete,
    SecurityModeFailure,
    SignallingConnectionRelease,
    SignallingConnectionReleaseIndication,
    SystemInformation-BCH,
    SystemInformation-FACH,
    SystemInformationChangeIndication,
    TransportChannelReconfiguration,
    TransportChannelReconfigurationComplete,
    TransportChannelReconfigurationFailure,
    TransportFormatCombinationControl,
    TransportFormatCombinationControlFailure,
    UECapabilityEnquiry,
    UECapabilityInformation,
    UECapabilityInformationConfirm,
    UplinkDirectTransfer,
    UplinkPhysicalChannelControl,
    URAUpdate,
    URAUpdateConfirm,
    URAUpdateConfirm-CCCH,
    UTRANMobilityInformation,
    UTRANMobilityInformationConfirm,
    UTRANMobilityInformationFailure
FROM PDU-definitions

-- User Equipment IEs :
    IntegrityCheckInfo
FROM InformationElements;

--********************************************************************
--
-- Downlink DCCH messages
--
--********************************************************************

DL-DCCH-Message ::= SEQUENCE {
    integrityCheckInfo      IntegrityCheckInfo      OPTIONAL,
    message                 DL-DCCH-MessageType
}

DL-DCCH-MessageType ::= CHOICE {
    activeSetUpdate                     ActiveSetUpdate,
    assistanceDataDelivery              AssistanceDataDelivery,
    cellChangeOrderFromUTRAN            CellChangeOrderFromUTRAN,
    cellUpdateConfirm                   CellUpdateConfirm,
    counterCheck                        CounterCheck,
    downlinkDirectTransfer              DownlinkDirectTransfer,
    handoverFromUTRANCommand-GSM        HandoverFromUTRANCommand-GSM,
    handoverFromUTRANCommand-CDMA2000   HandoverFromUTRANCommand-CDMA2000,
    measurementControl                  MeasurementControl,
    pagingType2                         PagingType2,
    physicalChannelReconfiguration      PhysicalChannelReconfiguration,
    physicalSharedChannelAllocation     PhysicalSharedChannelAllocation,
    radioBearerReconfiguration          RadioBearerReconfiguration,
    radioBearerRelease                  RadioBearerRelease,
    radioBearerSetup                    RadioBearerSetup,
    rrcConnectionRelease                RRCConnectionRelease,
    securityModeCommand                 SecurityModeCommand,
    signallingConnectionRelease         SignallingConnectionRelease,
    transportChannelReconfiguration     TransportChannelReconfiguration,
    transportFormatCombinationControl   TransportFormatCombinationControl,
```

```
    ueCapabilityEnquiry                 UECapabilityEnquiry,
    ueCapabilityInformationConfirm      UECapabilityInformationConfirm,
    uplinkPhysicalChannelControl        UplinkPhysicalChannelControl,
    uraUpdateConfirm                    URAUpdateConfirm,
    utranMobilityInformation            UTRANMobilityInformation,
    handoverFromUTRANCommand-GERANIu    HandoverFromUTRANCommand-GERANIu,
    mbmsModifiedServicesInformation     MBMSModifiedServicesInformation,
    spare5                              NULL,
    spare4                              NULL,
    spare3                              NULL,
    spare2                              NULL,
    spare1                              NULL
}

--************************************************************
--
-- Uplink DCCH messages
--
--************************************************************

UL-DCCH-Message ::= SEQUENCE {
    integrityCheckInfo      IntegrityCheckInfo      OPTIONAL,
    message                 UL-DCCH-MessageType
}

UL-DCCH-MessageType ::= CHOICE {
    activeSetUpdateComplete             ActiveSetUpdateComplete,
    activeSetUpdateFailure              ActiveSetUpdateFailure,
    cellChangeOrderFromUTRANFailure     CellChangeOrderFromUTRANFailure,
    counterCheckResponse                CounterCheckResponse,
    handoverToUTRANComplete             HandoverToUTRANComplete,
    initialDirectTransfer               InitialDirectTransfer,
    handoverFromUTRANFailure            HandoverFromUTRANFailure,
    measurementControlFailure           MeasurementControlFailure,
    measurementReport                   MeasurementReport,
    physicalChannelReconfigurationComplete
                                        PhysicalChannelReconfigurationComplete,
    physicalChannelReconfigurationFailure
                                        PhysicalChannelReconfigurationFailure,
    radioBearerReconfigurationComplete  RadioBearerReconfigurationComplete,
    radioBearerReconfigurationFailure   RadioBearerReconfigurationFailure,
    radioBearerReleaseComplete          RadioBearerReleaseComplete,
    radioBearerReleaseFailure           RadioBearerReleaseFailure,
    radioBearerSetupComplete            RadioBearerSetupComplete,
    radioBearerSetupFailure             RadioBearerSetupFailure,
    rrcConnectionReleaseComplete        RRCConnectionReleaseComplete,
    rrcConnectionSetupComplete          RRCConnectionSetupComplete,
    rrcStatus                           RRCStatus,
    securityModeComplete                SecurityModeComplete,
    securityModeFailure                 SecurityModeFailure,
    signallingConnectionReleaseIndication
                                        SignallingConnectionReleaseIndication,
    transportChannelReconfigurationComplete
                                        TransportChannelReconfigurationComplete,
    transportChannelReconfigurationFailure
                                        TransportChannelReconfigurationFailure,
    transportFormatCombinationControlFailure
                                        TransportFormatCombinationControlFailure,
    ueCapabilityInformation             UECapabilityInformation,
    uplinkDirectTransfer                UplinkDirectTransfer,
    utranMobilityInformationConfirm     UTRANMobilityInformationConfirm,
    utranMobilityInformationFailure     UTRANMobilityInformationFailure,
    mbmsModificationRequest             MBMSModificationRequest,
    spare1                              NULL
}

--************************************************************
--
-- Downlink CCCH messages
--
--************************************************************

DL-CCCH-Message ::= SEQUENCE {
    integrityCheckInfo      IntegrityCheckInfo      OPTIONAL,
    message                 DL-CCCH-MessageType
}

DL-CCCH-MessageType ::= CHOICE {
```

```
    cellUpdateConfirm                   CellUpdateConfirm-CCCH,
    rrcConnectionReject                 RRCConnectionReject,
    rrcConnectionRelease                RRCConnectionRelease-CCCH,
    rrcConnectionSetup                  RRCConnectionSetup,
    uraUpdateConfirm                    URAUpdateConfirm-CCCH,
    spare3                              NULL,
    spare2                              NULL,
    spare1                              NULL
}

--********************************************************************
--
-- Uplink CCCH messages
--
--********************************************************************

UL-CCCH-Message ::= SEQUENCE {
    integrityCheckInfo      IntegrityCheckInfo      OPTIONAL,
    message                 UL-CCCH-MessageType
}

UL-CCCH-MessageType ::= CHOICE {
    cellUpdate                          CellUpdate,
    rrcConnectionRequest                RRCConnectionRequest,
    uraUpdate                           URAUpdate,
    spare                               NULL
}

--********************************************************************
--
-- PCCH messages
--
--********************************************************************

PCCH-Message ::= SEQUENCE {
    message             PCCH-MessageType
}

PCCH-MessageType ::= CHOICE {
    pagingType1                         PagingType1,
    spare                               NULL
}

--********************************************************************
--
-- Downlink SHCCH messages
--
--********************************************************************

DL-SHCCH-Message ::= SEQUENCE {
    message                 DL-SHCCH-MessageType
}

DL-SHCCH-MessageType ::= CHOICE {
    physicalSharedChannelAllocation     PhysicalSharedChannelAllocation,
    spare                               NULL
}

--********************************************************************
--
-- Uplink SHCCH messages
--
--********************************************************************

UL-SHCCH-Message ::= SEQUENCE {
    message                 UL-SHCCH-MessageType
}

UL-SHCCH-MessageType ::= CHOICE {
    puschCapacityRequest                PUSCHCapacityRequest,
    spare                               NULL
}


--********************************************************************
--
-- BCCH messages sent on FACH
--
```

```
--**************************************************************

BCCH-FACH-Message ::= SEQUENCE {
    message             BCCH-FACH-MessageType
}

BCCH-FACH-MessageType ::= CHOICE {
    systemInformation                   SystemInformation-FACH,
    systemInformationChangeIndication   SystemInformationChangeIndication,
    spare2                              NULL,
    spare1                              NULL
}

--**************************************************************
--
-- BCCH messages sent on BCH
--
--**************************************************************

BCCH-BCH-Message ::= SEQUENCE {
    message             SystemInformation-BCH
}

--**************************************************************
--
-- MCCH messages
--
--**************************************************************

MCCH-Message ::= SEQUENCE {
    message             MCCH-MessageType
}

MCCH-MessageType ::= CHOICE {
    mbmsAccessInformation               MBMSAccessInformation,
    mbmsCommonPTMRBInformation          MBMSCommonPTMRBInformation,
    mbmsCurrentCellPTMRBInformation     MBMSCurrentCellPTMRBInformation,
    mbmsGeneralInformation              MBMSGeneralInformation,
    mbmsModifiedServicesInformation     MBMSModifiedServicesInformation,
    mbmsNeighbouringCellPTMRBInformation
                                        MBMSNeighbouringCellPTMRBInformation,
    mbmsUnmodifiedServicesInformation   MBMSUnmodifiedServicesInformation,
    spare9                              NULL,
    spare8                              NULL,
    spare7                              NULL,
    spare6                              NULL,
    spare5                              NULL,
    spare4                              NULL,
    spare3                              NULL,
    spare2                              NULL,
    spare1                              NULL
}

--**************************************************************
--
-- MSCH messages
--
--**************************************************************

MSCH-Message ::= SEQUENCE {
    message             MSCH-MessageType
}

MSCH-MessageType ::= CHOICE {
    mbmsSchedulingInformation           MBMSSchedulingInformation,
    spare3                              NULL,
    spare2                              NULL,
    spare1                              NULL
}

END
```

## 11.2 PDU definitions

```
--**************************************************************
--
-- TABULAR: The message type and integrity check info are not
```

```
-- visible in this module as they are defined in the class module.
-- Also, all FDD/TDD specific choices have the FDD option first
-- and TDD second, just for consistency.
--
--**************************************************************

PDU-definitions DEFINITIONS AUTOMATIC TAGS ::=

BEGIN

--**************************************************************
--
-- IE parameter types from other modules
--
--**************************************************************

IMPORTS

-- Core Network IEs :
    CN-DomainIdentity,
    CN-InformationInfo,
    CN-InformationInfo-r6,
    CN-InformationInfoFull,
    NAS-Message,
    PagingRecordTypeID,
    PLMN-Identity,
-- UTRAN Mobility IEs :
    CellIdentity,
    CellIdentity-PerRL-List,
    URA-Identity,
-- User Equipment IEs :
    UE-RadioAccessCapabilityComp-r7,
    UE-RadioAccessCapability-v7xyext,
    UE-RadioAccessCapabBandFDDList2,
    UE-RadioAccessCapabBandFDDList-ext,
    AccessStratumReleaseIndicator,
    ActivationTime,
    C-RNTI,
    CapabilityUpdateRequirement,
    CapabilityUpdateRequirement-r4,
    CapabilityUpdateRequirement-r4-ext,
    CapabilityUpdateRequirement-r5,
    CapabilityUpdateRequirement-r7-ext,
    CellUpdateCause,
    CellUpdateCause-ext,
    CipheringAlgorithm,
    CipheringModeInfo,
    DelayRestrictionFlag,
    DSCH-RNTI,
    E-RNTI,
    EstablishmentCause,
    FailureCauseWithProtErr,
    FailureCauseWithProtErrTrId,
    GroupReleaseInformation,
    H-RNTI,
    UESpecificBehaviourInformation1idle,
    UESpecificBehaviourInformation1interRAT,
    InitialUE-Identity,
    IntegrityProtActivationInfo,
    IntegrityProtectionModeInfo,
    N-308,
    PagingCause,
    PagingRecordList,
    PagingRecord2List-r5,
    ProtocolErrorIndicator,
    ProtocolErrorIndicatorWithMoreInfo,
    RadioFrequencyBandTDDList,
    Rb-timer-indicator,
    RedirectionInfo,
    RedirectionInfo-r6,
    RejectionCause,
    ReleaseCause,
    RF-CapabilityComp,
    RRC-StateIndicator,
    RRC-TransactionIdentifier,
    SecurityCapability,
    START-Value,
    STARTList,
```

```
    SystemSpecificCapUpdateReq-v590ext,
    U-RNTI,
    U-RNTI-Short,
    UE-CapabilityContainer-IEs,
    UE-RadioAccessCapability,
    UE-RadioAccessCapability-v370ext,
    UE-RadioAccessCapability-v380ext,
    UE-RadioAccessCapability-v3a0ext,
    UE-RadioAccessCapability-v3g0ext,
    UE-RadioAccessCapability-v4b0ext,
    UE-RadioAccessCapability-v590ext,
    UE-RadioAccessCapability-v5c0ext,
    UE-RadioAccessCapability-v650ext,
    UE-RadioAccessCapability-v680ext,
    UE-RadioAccessCapabilityComp,
    UE-RadioAccessCapabilityComp-ext,
    UE-RadioAccessCapabilityComp2,
    DL-PhysChCapabilityFDD-v380ext,
    UE-ConnTimersAndConstants,
    UE-ConnTimersAndConstants-v3a0ext,
    UE-ConnTimersAndConstants-r5,
    UE-SecurityInformation,
    UE-SecurityInformation2,
    URA-UpdateCause,
    UTRAN-DRX-CycleLengthCoefficient,
    WaitTime,
-- Radio Bearer IEs :
    DefaultConfigIdentity,
    DefaultConfigIdentity-r4,
    DefaultConfigIdentity-r5,
    DefaultConfigIdentity-r6,
    DefaultConfigMode,
    DL-CounterSynchronisationInfo,
    DL-CounterSynchronisationInfo-r5,
    PDCP-ROHC-TargetMode,
    PredefinedConfigIdentity,
    PredefinedConfigStatusList,
    PredefinedConfigStatusListComp,
    PredefinedConfigSetWithDifferentValueTag,
    RAB-Info,
    RAB-Info-r6,
    RAB-Info-Post,
    RAB-InformationList,
    RAB-InformationList-r6,
    RAB-InformationReconfigList,
    RAB-InformationSetupList,
    RAB-InformationSetupList-r4,
    RAB-InformationSetupList-r5,
    RAB-InformationSetupList-r6-ext,
    RAB-InformationSetupList-r6,
    RB-ActivationTimeInfoList,
    RB-COUNT-C-InformationList,
    RB-COUNT-C-MSB-InformationList,
    RB-IdentityList,
    RB-InformationAffectedList,
    RB-InformationAffectedList-r5,
    RB-InformationAffectedList-r6,
    RB-InformationChangedList-r6,
    RB-InformationReconfigList,
    RB-InformationReconfigList-r4,
    RB-InformationReconfigList-r5,
    RB-InformationReconfigList-r6,
    RB-InformationReleaseList,
    RB-PDCPContextRelocationList,
    SRB-InformationSetupList,
    SRB-InformationSetupList-r5,
    SRB-InformationSetupList-r6,
    SRB-InformationSetupList2,
    SRB-InformationSetupList2-r6,
    UL-CounterSynchronisationInfo,
-- Transport Channel IEs:
    CPCH-SetID,
    DL-AddReconfTransChInfo2List,
    DL-AddReconfTransChInfoList,
    DL-AddReconfTransChInfoList-r4,
    DL-AddReconfTransChInfoList-r5,
    DL-CommonTransChInfo,
    DL-CommonTransChInfo-r4,
```

```
    DL-DeletedTransChInfoList,
    DL-DeletedTransChInfoList-r5,
    DRAC-StaticInformationList,
    PowerOffsetInfoShort,
    TFC-Subset,
    TFCS-Identity,
    UL-AddReconfTransChInfoList,
    UL-AddReconfTransChInfoList-r6,
    UL-CommonTransChInfo,
    UL-CommonTransChInfo-r4,
    UL-DeletedTransChInfoList,
    UL-DeletedTransChInfoList-r6,
-- Physical Channel IEs :
    Alpha,
    BEACON-PL-Est,
    CCTrCH-PowerControlInfo,
    CCTrCH-PowerControlInfo-r4,
    CCTrCH-PowerControlInfo-r5,
    CCTrCH-PowerControlInfo-r7,
    ConstantValue,
    ConstantValueTdd,
    CPCH-SetInfo,
    DHS-Sync,
    DL-CommonInformation,
    DL-CommonInformation-r4,
    DL-CommonInformation-r5,
    DL-CommonInformation-r6,
    DL-CommonInformation-r7,
    DL-CommonInformationPost,
    DL-HSPDSCH-Information,
    DL-HSPDSCH-Information-r6,
    DL-HSPDSCH-Information-r7,
    DL-InformationPerRL-List,
    DL-InformationPerRL-List-r4,
    DL-InformationPerRL-List-r5,
    DL-InformationPerRL-List-r5bis,
    DL-InformationPerRL-List-r6,
    DL-InformationPerRL-List-r7,
    DL-InformationPerRL-ListPostFDD,
    DL-InformationPerRL-PostTDD,
    DL-InformationPerRL-PostTDD-LCR-r4,
    DL-PDSCH-Information,
    DL-TPC-PowerOffsetPerRL-List,
    DPC-Mode,
    DPCH-CompressedModeStatusInfo,
    DynamicPersistenceLevel,
    E-DCH-ReconfigurationInfo,
    FrequencyInfo,
    FrequencyInfoFDD,
    FrequencyInfoTDD,
    HARQ-Preamble-Mode,
    HS-SICH-Power-Control-Info-TDD384,
    HS-SICH-Power-Control-Info-TDD768,
    MaxAllowedUL-TX-Power,
    OpenLoopPowerControl-IPDL-TDD-r4,
    PDSCH-CapacityAllocationInfo,
    PDSCH-CapacityAllocationInfo-r4,
    PDSCH-CapacityAllocationInfo-r7,
    PDSCH-Identity,
    PrimaryCPICH-Info,
    PrimaryCCPCH-TX-Power,
    PUSCH-CapacityAllocationInfo,
    PUSCH-CapacityAllocationInfo-r4,
    PUSCH-CapacityAllocationInfo-r7,
    PUSCH-Identity,
    PUSCH-SysInfoList-HCR-r5,
    PDSCH-SysInfoList-HCR-r5,
    RL-AdditionInformationList,
    RL-AdditionInformationList-r6,
    RL-RemovalInformationList,
    Serving-HSDSCH-CellInformation,
    SpecialBurstScheduling,
    SSDT-Information,
    SSDT-Information-r4,
    TFC-ControlDuration,
    SSDT-UL,
    TimingMaintainedSynchInd,
    TimeslotList,
    TimeslotList-r4,
```

```
    TX-DiversityMode,
    UL-ChannelRequirement,
    UL-ChannelRequirement-r4,
    UL-ChannelRequirement-r5,
    UL-ChannelRequirementWithCPCH-SetID,
    UL-ChannelRequirementWithCPCH-SetID-r4,
    UL-ChannelRequirementWithCPCH-SetID-r5,
    UL-DPCH-Info,
    UL-DPCH-Info-r4,
    UL-DPCH-Info-r5,
    UL-DPCH-Info-r6,
    UL-DPCH-Info-r7,
    UL-DPCH-InfoPostFDD,
    UL-DPCH-InfoPostTDD,
    UL-DPCH-InfoPostTDD-LCR-r4,
    UL-EDCH-Information-r6,
    UL-SynchronisationParameters-r4,
    UL-TimingAdvance,
    UL-TimingAdvanceControl,
    UL-TimingAdvanceControl-r4,
    UL-TimingAdvanceControl-r7,
    UL-TimingAdvance-VHCR,
-- Measurement IEs :
    AdditionalMeasurementID-List,
    DeltaRSCP,
    Frequency-Band,
    EventResults,
    Inter-FreqEventCriteriaList-v590ext,
    Intra-FreqEventCriteriaList-v590ext,
    IntraFreqReportingCriteria-1b-r5,
    IntraFreqEvent-1d-r5,
    IntraFreqCellID,
    InterFreqEventResults-LCR-r4-ext,
    InterRATCellInfoIndication,
    InterRAT-TargetCellDescription,
    MeasuredResults,
    MeasuredResults-v390ext,
    MeasuredResults-v590ext,
    MeasuredResultsList,
    MeasuredResultsList-LCR-r4-ext,
    MeasuredResultsOnRACH,
    MeasuredResultsOnRACHinterFreq,
    MeasurementCommand,
    MeasurementCommand-r4,
    MeasurementCommand-r6,
    MeasurementIdentity,
    MeasurementReportingMode,
    PrimaryCCPCH-RSCP,
    SFN-Offset-Validity,
    TimeslotListWithISCP,
    TrafficVolumeMeasuredResultsList,
    UE-Positioning-GPS-AssistanceData,
    UE-Positioning-Measurement-v390ext,
    UE-Positioning-Measurement-v7xyext,
    UE-Positioning-OTDOA-AssistanceData,
    UE-Positioning-OTDOA-AssistanceData-r4ext,
    UE-Positioning-OTDOA-AssistanceData-UEB,
    VelocityEstimate,
    UE-InternalMeasuredResults-r7,
-- Other IEs :
    BCCH-ModificationInfo,
    CDMA2000-MessageList,
    GSM-TargetCellInfoList,
    GERANIu-MessageList,
    GERAN-SystemInformation,
    GSM-MessageList,
    InterRAT-ChangeFailureCause,
    InterRAT-HO-FailureCause,
    InterRAT-UE-RadioAccessCapabilityList,
    InterRAT-UE-RadioAccessCapability-v590ext,
    InterRAT-UE-SecurityCapList,
    IntraDomainNasNodeSelector,
    ProtocolErrorMoreInformation,
    Rplmn-Information,
    Rplmn-Information-r4,
    SegCount,
    SegmentIndex,
    SFN-Prime,
    SIB-Data-fixed,
```

```
    SIB-Data-variable,
    SIB-Type,
-- MBMS IEs:
    MBMS-CellGroupIdentity-r6,
    MBMS-CommonRBInformationList-r6,
    MBMS-CurrentCell-SCCPCHList-r6,
    MBMS-JoinedInformation-r6,
    MBMS-MICHConfigurationInfo-r6,
    MBMS-MICHConfigurationInfo-r7,
    MBMS-ModifedServiceList-r6,
    MBMS-MSCH-ConfigurationInfo-r6,
    MBMS-NeighbouringCellSCCPCHList-r6,
    MBMS-NumberOfNeighbourCells-r6,
    MBMS-PhyChInformationList-r6,
    MBMS-PL-ServiceRestrictInfo-r6,
    MBMS-PreferredFreqRequest-r6,
    MBMS-PreferredFrequencyList-r6,
    MBMS-PTMActivationTime-r6,
    MBMS-ServiceAccessInfoList-r6,
    MBMS-ServiceIdentity-r6,
    MBMS-ServiceSchedulingInfoList-r6,
    MBMS-SIBType5-SCCPCHList-r6,
    MBMS-TimersAndCounters-r6,
    MBMS-TranspChInfoForEachCCTrCh-r6,
    MBMS-TranspChInfoForEachTrCh-r6,
    MBMS-UnmodifiedServiceList-r6
FROM InformationElements

    maxSIBperMsg,
    maxURNTI-Group
FROM Constant-definitions;

-- **************************************************
--
-- ACTIVE SET UPDATE (FDD only)
--
-- **************************************************

ActiveSetUpdate ::= CHOICE {
    r3                              SEQUENCE {
        activeSetUpdate-r3              ActiveSetUpdate-r3-IEs,
        laterNonCriticalExtensions      SEQUENCE {
            -- Container for additional R99 extensions
            activeSetUpdate-r3-add-ext      BIT STRING      OPTIONAL,
            v4b0NonCriticalExtensions       SEQUENCE {
                activeSetUpdate-v4b0ext     ActiveSetUpdate-v4b0ext-IEs,
                v590NonCriticalExtensions       SEQUENCE {
                    activeSetUpdate-v590ext         ActiveSetUpdate-v590ext-IEs,
                    v690NonCriticalExtensions       SEQUENCE {
                        activeSetUpdate-v690ext         ActiveSetUpdate-v690ext-IEs,
                        nonCriticalExtensions           SEQUENCE {} OPTIONAL
                    }   OPTIONAL
                }   OPTIONAL
            } OPTIONAL
        } OPTIONAL
    },
    later-than-r3                   SEQUENCE {
        rrc-TransactionIdentifier       RRC-TransactionIdentifier,
        criticalExtensions              CHOICE {
            r6                              SEQUENCE {
                activeSetUpdate-r6              ActiveSetUpdate-r6-IEs,
                activeSetUpdate-r6-add-ext      BIT STRING      OPTIONAL,
                nonCriticalExtensions           SEQUENCE {}     OPTIONAL
            },
            criticalExtensions              SEQUENCE {}
        }
    }
}

ActiveSetUpdate-r3-IEs ::= SEQUENCE {
    -- User equipment IEs
        rrc-TransactionIdentifier       RRC-TransactionIdentifier,
        -- dummy and dummy2 are not used in this version of the specification, they should
        -- not be sent and if received they should be ignored.
        dummy                       IntegrityProtectionModeInfo         OPTIONAL,
        dummy2                      CipheringModeInfo                   OPTIONAL,
        activationTime                  ActivationTime                      OPTIONAL,
        newU-RNTI                       U-RNTI                              OPTIONAL,
```

```
    -- Core network IEs
        cn-InformationInfo              CN-InformationInfo                  OPTIONAL,
    -- Radio bearer IEs
        -- dummy3 is not used in this version of the specification, it should
        -- not be sent and if received it should be ignored.
        dummy3                      DL-CounterSynchronisationInfo       OPTIONAL,
    -- Physical channel IEs
        maxAllowedUL-TX-Power           MaxAllowedUL-TX-Power               OPTIONAL,
        rl-AdditionInformationList      RL-AdditionInformationList          OPTIONAL,
        rl-RemovalInformationList       RL-RemovalInformationList           OPTIONAL,
        tx-DiversityMode                TX-DiversityMode                    OPTIONAL,
        -- dummy4 is not used in this version of the specification, it should
        -- not be sent and if received it should be ignored.
        dummy4                          SSDT-Information                    OPTIONAL
}

ActiveSetUpdate-v4b0ext-IEs ::= SEQUENCE {
    -- Physical channel IEs
        -- dummy is not used in this version of the specification, it should
        -- not be sent and if received it should be ignored.
        dummy                           SSDT-UL                                 OPTIONAL,
        -- The order of the RLs in IE cell-id-PerRL-List is the same as
        -- in IE RL-AdditionInformationList included in this message
        cell-id-PerRL-List              CellIdentity-PerRL-List             OPTIONAL
}

ActiveSetUpdate-v590ext-IEs ::= SEQUENCE {
    -- Physical channel IEs
        dpc-Mode                        DPC-Mode,
        dl-TPC-PowerOffsetPerRL-List    DL-TPC-PowerOffsetPerRL-List            OPTIONAL
}

ActiveSetUpdate-v690ext-IEs ::= SEQUENCE {
    -- Core network IEs
        primary-plmn-Identity           PLMN-Identity                       OPTIONAL
}

ActiveSetUpdate-r6-IEs ::= SEQUENCE {
    -- User equipment IEs
        activationTime                  ActivationTime                      OPTIONAL,
        newU-RNTI                       U-RNTI                              OPTIONAL,
        newH-RNTI                       H-RNTI                              OPTIONAL,
        newPrimary-E-RNTI               E-RNTI                              OPTIONAL,
        newSecondary-E-RNTI             E-RNTI                              OPTIONAL,
    -- Core network IEs
        cn-InformationInfo              CN-InformationInfo-r6               OPTIONAL,
    -- Physical channel IEs
        maxAllowedUL-TX-Power           MaxAllowedUL-TX-Power               OPTIONAL,
        rl-AdditionInformationList      RL-AdditionInformationList-r6       OPTIONAL,
        rl-RemovalInformationList       RL-RemovalInformationList           OPTIONAL,
        tx-DiversityMode                TX-DiversityMode                    OPTIONAL,
        dpc-Mode                        DPC-Mode                            OPTIONAL,
        serving-HSDSCH-CellInformation  Serving-HSDSCH-CellInformation      OPTIONAL,
        e-dch-ReconfigurationInfo       E-DCH-ReconfigurationInfo           OPTIONAL
}

-- **************************************************
--
-- ACTIVE SET UPDATE COMPLETE (FDD only)
--
-- **************************************************

ActiveSetUpdateComplete ::= SEQUENCE {
    -- User equipment IEs
        rrc-TransactionIdentifier       RRC-TransactionIdentifier,
        -- dummy is not used in this version of the specification, it should
        -- not be sent and if received it should be ignored.
        dummy                       IntegrityProtActivationInfo         OPTIONAL,
    -- Radio bearer IEs
        -- dummy2 and dummy3 are not used in this version of the specification, they should
        -- not be sent and if received they should be ignored.
        dummy2                      RB-ActivationTimeInfoList           OPTIONAL,
        dummy3                      UL-CounterSynchronisationInfo       OPTIONAL,
        laterNonCriticalExtensions      SEQUENCE {
            -- Container for additional R99 extensions
            activeSetUpdateComplete-r3-add-ext      BIT STRING      OPTIONAL,
            nonCriticalExtensions           SEQUENCE {} OPTIONAL
        }   OPTIONAL
```

```
}

-- **************************************************
--
-- ACTIVE SET UPDATE FAILURE (FDD only)
--
-- **************************************************

ActiveSetUpdateFailure ::= SEQUENCE {
    -- User equipment IEs
        rrc-TransactionIdentifier       RRC-TransactionIdentifier,
        failureCause                    FailureCauseWithProtErr,
        laterNonCriticalExtensions      SEQUENCE {
            -- Container for additional R99 extensions
            activeSetUpdateFailure-r3-add-ext       BIT STRING      OPTIONAL,
            nonCriticalExtensions           SEQUENCE {} OPTIONAL
    }   OPTIONAL
}

-- **************************************************
--
-- Assistance Data Delivery
--
-- **************************************************

AssistanceDataDelivery ::= CHOICE {
    r3                              SEQUENCE {
        assistanceDataDelivery-r3       AssistanceDataDelivery-r3-IEs,
        v3a0NonCriticalExtensions       SEQUENCE {
            assistanceDataDelivery-v3a0ext  AssistanceDataDelivery-v3a0ext,
            laterNonCriticalExtensions      SEQUENCE {
                -- Container for additional R99 extensions
                assistanceDataDelivery-r3-add-ext       BIT STRING      OPTIONAL,
                v4b0NonCriticalExtensions       SEQUENCE {
                    assistanceDataDelivery-v4b0ext
                                                    AssistanceDataDelivery-v4b0ext-IEs,
                    nonCriticalExtensions           SEQUENCE {}                     OPTIONAL
                }   OPTIONAL
            }   OPTIONAL
        }   OPTIONAL
    },
    later-than-r3                   SEQUENCE {
        rrc-TransactionIdentifier       RRC-TransactionIdentifier,
        criticalExtensions              SEQUENCE {}
    }
}

AssistanceDataDelivery-r3-IEs ::= SEQUENCE {
    -- User equipment IEs
    rrc-TransactionIdentifier       RRC-TransactionIdentifier,
    -- Measurement Information Elements
    ue-positioning-GPS-AssistanceData           UE-Positioning-GPS-AssistanceData
    OPTIONAL,
    ue-positioning-OTDOA-AssistanceData-UEB     UE-Positioning-OTDOA-AssistanceData-UEB
    OPTIONAL
}

AssistanceDataDelivery-v3a0ext ::= SEQUENCE {
    sfn-Offset-Validity                 SFN-Offset-Validity     OPTIONAL
}

AssistanceDataDelivery-v4b0ext-IEs ::= SEQUENCE {
    ue-Positioning-OTDOA-AssistanceData-r4ext   UE-Positioning-OTDOA-AssistanceData-r4ext   OPTIONAL
}

 -- **************************************************
--
-- CELL CHANGE ORDER FROM UTRAN
--
-- **************************************************

CellChangeOrderFromUTRAN ::= CHOICE {
    r3                              SEQUENCE {
        cellChangeOrderFromUTRAN-IEs        CellChangeOrderFromUTRAN-r3-IEs,
        laterNonCriticalExtensions      SEQUENCE {
            -- Container for additional R99 extensions
            cellChangeOrderFromUTRAN-r3-add-ext     BIT STRING      OPTIONAL,
            v590NonCriticalExtensions           SEQUENCE {
```

```
                cellChangeOrderFromUTRAN-v590ext    CellChangeOrderFromUTRAN-v590ext-IEs,
                nonCriticalExtensions           SEQUENCE {} OPTIONAL
            }   OPTIONAL
        }   OPTIONAL
    },
    later-than-r3                   SEQUENCE {
        rrc-TransactionIdentifier       RRC-TransactionIdentifier,
        criticalExtensions              SEQUENCE {}
    }
}

CellChangeOrderFromUTRAN-r3-IEs ::= SEQUENCE {
    -- User equipment IEs
        rrc-TransactionIdentifier       RRC-TransactionIdentifier,
        -- dummy is not used in this version of the specification, it should
        -- not be sent and if received it should be ignored.
        dummy                           IntegrityProtectionModeInfo         OPTIONAL,
        activationTime                  ActivationTime                      OPTIONAL,
        -- the IE rab-InformationList is not used in this version of the specification, it should
        -- not be sent and if received it should be ignored. The IE may be used in a later
        -- version of the protocol and hence it is not changed into a dummy
        rab-InformationList             RAB-InformationList                 OPTIONAL,
        interRAT-TargetCellDescription  InterRAT-TargetCellDescription
}

CellChangeOrderFromUTRAN-v590ext-IEs ::= SEQUENCE {
        geran-SystemInfoType                CHOICE  {
            sI                                  GERAN-SystemInformation,
            pSI                                 GERAN-SystemInformation
        }       OPTIONAL
}

-- **************************************************
--
-- CELL CHANGE ORDER FROM UTRAN FAILURE
--
-- **************************************************

CellChangeOrderFromUTRANFailure ::= CHOICE {
    r3                              SEQUENCE {
        cellChangeOrderFromUTRANFailure-r3
                                        CellChangeOrderFromUTRANFailure-r3-IEs,
        laterNonCriticalExtensions      SEQUENCE {
            -- Container for additional R99 extensions
            cellChangeOrderFromUTRANFailure-r3-add-ext      BIT STRING  OPTIONAL,
            nonCriticalExtensions           SEQUENCE {} OPTIONAL
        }   OPTIONAL
    },
    -- dummy is not used in this version of the specification and it
    -- should be ignored.
    dummy                           SEQUENCE {
        rrc-TransactionIdentifier       RRC-TransactionIdentifier,
        criticalExtensions              SEQUENCE {}
    }
}

CellChangeOrderFromUTRANFailure-r3-IEs ::= SEQUENCE {
    -- User equipment IEs
        rrc-TransactionIdentifier       RRC-TransactionIdentifier,
        -- dummy is not used in this version of the specification, it should
        -- not be sent and if received it should be ignored.
        dummy                           IntegrityProtectionModeInfo         OPTIONAL,
        interRAT-ChangeFailureCause     InterRAT-ChangeFailureCause
}

-- **************************************************
--
-- CELL UPDATE
--
-- **************************************************

CellUpdate ::= SEQUENCE {
    -- User equipment IEs
        u-RNTI                          U-RNTI,
        startList       STARTList,
        am-RLC-ErrorIndicationRb2-3or4      BOOLEAN,
        am-RLC-ErrorIndicationRb5orAbove    BOOLEAN,
        cellUpdateCause                 CellUpdateCause,
```

```
        -- TABULAR: RRC transaction identifier is nested in FailureCauseWithProtErrTrId
        failureCause                    FailureCauseWithProtErrTrId         OPTIONAL,
        rb-timer-indicator              Rb-timer-indicator,
    -- Measurement IEs
        measuredResultsOnRACH           MeasuredResultsOnRACH               OPTIONAL,
        laterNonCriticalExtensions      SEQUENCE {
            -- Container for additional R99 extensions
            cellUpdate-r3-add-ext           BIT STRING  OPTIONAL,
            v590NonCriticalExtensions   SEQUENCE {
                cellUpdate-v590ext  CellUpdate-v590ext,
                v690NonCriticalExtensions       SEQUENCE {
                    cellUpdate-v690ext              CellUpdate-v690ext-IEs,
                    nonCriticalExtensions           SEQUENCE {} OPTIONAL
                }       OPTIONAL
            }       OPTIONAL
        }   OPTIONAL
}

CellUpdate-v590ext ::= SEQUENCE {
    establishmentCause              EstablishmentCause  OPTIONAL
}

CellUpdate-v690ext-IEs ::=          SEQUENCE {
    -- User equipment IEs
        cellUpdateCause-ext             CellUpdateCause-ext                 OPTIONAL,
        trafficVolumeIndicator          ENUMERATED { true }                 OPTIONAL,
    -- Measurement IEs
        measuredResultsOnRACHinterFreq  MeasuredResultsOnRACHinterFreq      OPTIONAL,
        reconfigurationStatusIndicator  ENUMERATED { true }                 OPTIONAL
}

-- **************************************************
--
-- CELL UPDATE CONFIRM
--
-- **************************************************

CellUpdateConfirm ::= CHOICE {
    r3                              SEQUENCE {
        cellUpdateConfirm-r3            CellUpdateConfirm-r3-IEs,
        v3a0NonCriticalExtensions       SEQUENCE {
            cellUpdateConfirm-v3a0ext       CellUpdateConfirm-v3a0ext,
            laterNonCriticalExtensions      SEQUENCE {
                -- Container for additional R99 extensions
                cellUpdateConfirm-r3-add-ext    BIT STRING  OPTIONAL,
                v4b0NonCriticalExtensions       SEQUENCE {
                    cellUpdateConfirm-v4b0ext       CellUpdateConfirm-v4b0ext-IEs,
                    v590NonCriticalExtenstions      SEQUENCE {
                        cellUpdateConfirm-v590ext       CellUpdateConfirm-v590ext-IEs,
                        v5d0NonCriticalExtenstions      SEQUENCE {
                            cellUpdateConfirm-v5d0ext       CellUpdateConfirm-v5d0ext-IEs,
                            v690NonCriticalExtensions       SEQUENCE {
                                cellUpdateConfirm-v690ext       CellUpdateConfirm-v690ext-IEs,
                                nonCriticalExtensions           SEQUENCE {} OPTIONAL
                            }       OPTIONAL
                        }       OPTIONAL
                    }       OPTIONAL
                }       OPTIONAL
            }       OPTIONAL
        }       OPTIONAL
    },
    later-than-r3                   SEQUENCE {
        rrc-TransactionIdentifier       RRC-TransactionIdentifier,
        criticalExtensions              CHOICE {
            r4                              SEQUENCE {
                cellUpdateConfirm-r4            CellUpdateConfirm-r4-IEs,
                v4d0NonCriticalExtensions       SEQUENCE {
                    -- Container for adding non critical extensions after freezing REL-5
                    cellUpdateConfirm-r4-add-ext    BIT STRING      OPTIONAL,
                    v590NonCriticalExtenstions      SEQUENCE {
                        cellUpdateConfirm-v590ext       CellUpdateConfirm-v590ext-IEs,
                        v5d0NonCriticalExtenstions      SEQUENCE {
                            cellUpdateConfirm-v5d0ext       CellUpdateConfirm-v5d0ext-IEs,
                            v690NonCriticalExtensions       SEQUENCE {
                                cellUpdateConfirm-v690ext       CellUpdateConfirm-v690ext-IEs,
                                nonCriticalExtensions           SEQUENCE {}     OPTIONAL
                            }   OPTIONAL
                        }   OPTIONAL
```

```
                    }   OPTIONAL
                }   OPTIONAL
            },
            criticalExtensions              CHOICE {
                r5                              SEQUENCE {
                    cellUpdateConfirm-r5            CellUpdateConfirm-r5-IEs,
                    -- Container for adding non critical extensions after freezing REL-6
                    cellUpdateConfirm-r5-add-ext    BIT STRING      OPTIONAL,
                    v5d0NonCriticalExtenstions      SEQUENCE {
                        cellUpdateConfirm-v5d0ext       CellUpdateConfirm-v5d0ext-IEs,
                        v690NonCriticalExtensions       SEQUENCE {
                            cellUpdateConfirm-v690ext       CellUpdateConfirm-v690ext-IEs,
                            nonCriticalExtensions           SEQUENCE {}     OPTIONAL
                        }   OPTIONAL
                    }   OPTIONAL
                },
                criticalExtensions              CHOICE {
                    r6                              SEQUENCE {
                        cellUpdateConfirm-r6            CellUpdateConfirm-r6-IEs,
                        -- Container for adding non critical extensions after freezing REL-7
                        cellUpdateConfirm-r6-add-ext    BIT STRING      OPTIONAL,
                        nonCriticalExtensions           SEQUENCE {}     OPTIONAL
                    },
                    criticalExtensions              CHOICE {
                        r7                              SEQUENCE {
                            cellUpdateConfirm-r7            CellUpdateConfirm-r7-IEs,
                            -- Container for adding non critical extensions after freezing REL-8
                            cellUpdateConfirm-r7-add-ext    BIT STRING      OPTIONAL,
                            nonCriticalExtensions           SEQUENCE {}     OPTIONAL
                        },
                        criticalExtensions              SEQUENCE {}
                    }
                }
            }
        }
    }
}

CellUpdateConfirm-r3-IEs ::= SEQUENCE {
    -- User equipment IEs
        rrc-TransactionIdentifier       RRC-TransactionIdentifier,
        integrityProtectionModeInfo     IntegrityProtectionModeInfo         OPTIONAL,
        cipheringModeInfo               CipheringModeInfo                   OPTIONAL,
        activationTime                  ActivationTime                      OPTIONAL,
        new-U-RNTI                      U-RNTI                              OPTIONAL,
        new-C-RNTI                      C-RNTI                              OPTIONAL,
        rrc-StateIndicator              RRC-StateIndicator,
        utran-DRX-CycleLengthCoeff      UTRAN-DRX-CycleLengthCoefficient    OPTIONAL,
        rlc-Re-establishIndicatorRb2-3or4       BOOLEAN,
        rlc-Re-establishIndicatorRb5orAbove     BOOLEAN,
    -- CN information elements
        cn-InformationInfo              CN-InformationInfo                  OPTIONAL,
    -- UTRAN mobility IEs
        ura-Identity                    URA-Identity                        OPTIONAL,
    -- Radio bearer IEs
        rb-InformationReleaseList       RB-InformationReleaseList           OPTIONAL,
        rb-InformationReconfigList      RB-InformationReconfigList          OPTIONAL,
        rb-InformationAffectedList      RB-InformationAffectedList          OPTIONAL,
        dl-CounterSynchronisationInfo   DL-CounterSynchronisationInfo       OPTIONAL,
    -- Transport channel IEs
        ul-CommonTransChInfo            UL-CommonTransChInfo                OPTIONAL,
        ul-deletedTransChInfoList       UL-DeletedTransChInfoList           OPTIONAL,
        ul-AddReconfTransChInfoList     UL-AddReconfTransChInfoList         OPTIONAL,
        modeSpecificTransChInfo         CHOICE {
            fdd                             SEQUENCE {
                -- dummy and dummy2 are not used in this version of the specification, they should
                -- not be sent and if received they should be ignored.
                dummy                           CPCH-SetID                  OPTIONAL,
                dummy2                          DRAC-StaticInformationList  OPTIONAL
            },
            tdd                             NULL
        },
        dl-CommonTransChInfo            DL-CommonTransChInfo                OPTIONAL,
        dl-DeletedTransChInfoList       DL-DeletedTransChInfoList           OPTIONAL,
        dl-AddReconfTransChInfoList     DL-AddReconfTransChInfoList         OPTIONAL,
    -- Physical channel IEs
        frequencyInfo                   FrequencyInfo                       OPTIONAL,
        maxAllowedUL-TX-Power           MaxAllowedUL-TX-Power               OPTIONAL,
```

```
        ul-ChannelRequirement           UL-ChannelRequirement               OPTIONAL,
        modeSpecificPhysChInfo          CHOICE {
            fdd                             SEQUENCE {
                -- dummy is not used in this version of specification, it should
                -- not be sent and if received it should be ignored.
                dummy                           DL-PDSCH-Information        OPTIONAL
            },
            tdd                             NULL
        },
        dl-CommonInformation            DL-CommonInformation                OPTIONAL,
        dl-InformationPerRL-List        DL-InformationPerRL-List            OPTIONAL
}

CellUpdateConfirm-v3a0ext ::= SEQUENCE {
    -- The IE 'new-DSCH-RNTI' should not be included in FDD mode, and if received the UE behaviour
    -- is unspecified
    new-DSCH-RNTI               DSCH-RNTI                               OPTIONAL
}

CellUpdateConfirm-v4b0ext-IEs ::= SEQUENCE {
    -- Physical channel IEs
        -- dummy is not used in this version of the specification, it should
        -- not be sent and if received it should be ignored.
        dummy                           SSDT-UL                             OPTIONAL,
        -- The order of the RLs in IE cell-id-PerRL-List is the same as
        -- in IE DL-InformationPerRL-List included in this message
        cell-id-PerRL-List              CellIdentity-PerRL-List             OPTIONAL
}

CellUpdateConfirm-v590ext-IEs ::= SEQUENCE {
    -- Physical channel IEs
        dl-TPC-PowerOffsetPerRL-List    DL-TPC-PowerOffsetPerRL-List        OPTIONAL
}

CellUpdateConfirm-v5d0ext-IEs ::=   SEQUENCE {
    --Radio Bearer IEs
        pdcp-ROHC-TargetMode            PDCP-ROHC-TargetMode                OPTIONAL
}
CellUpdateConfirm-r4-IEs ::= SEQUENCE {
    -- User equipment IEs
        integrityProtectionModeInfo     IntegrityProtectionModeInfo         OPTIONAL,
        cipheringModeInfo               CipheringModeInfo                   OPTIONAL,
        activationTime                  ActivationTime                      OPTIONAL,
        new-U-RNTI                      U-RNTI                              OPTIONAL,
        new-C-RNTI                      C-RNTI                              OPTIONAL,
        -- The IE 'new-DSCH-RNTI' should not be included in FDD mode, and if received
        -- the UE behaviour is unspecified
        new-DSCH-RNTI                   DSCH-RNTI                           OPTIONAL,
        rrc-StateIndicator              RRC-StateIndicator,
        utran-DRX-CycleLengthCoeff      UTRAN-DRX-CycleLengthCoefficient    OPTIONAL,
        rlc-Re-establishIndicatorRb2-3or4       BOOLEAN,
        rlc-Re-establishIndicatorRb5orAbove BOOLEAN,
    -- CN information elements
        cn-InformationInfo              CN-InformationInfo                  OPTIONAL,
    -- UTRAN mobility IEs
        ura-Identity                    URA-Identity                        OPTIONAL,
    -- Radio bearer IEs
        rb-InformationReleaseList       RB-InformationReleaseList           OPTIONAL,
        rb-InformationReconfigList      RB-InformationReconfigList-r4       OPTIONAL,
        rb-InformationAffectedList      RB-InformationAffectedList          OPTIONAL,
        dl-CounterSynchronisationInfo   DL-CounterSynchronisationInfo       OPTIONAL,
    -- Transport channel IEs
        ul-CommonTransChInfo            UL-CommonTransChInfo-r4             OPTIONAL,
        ul-deletedTransChInfoList       UL-DeletedTransChInfoList           OPTIONAL,
        ul-AddReconfTransChInfoList     UL-AddReconfTransChInfoList         OPTIONAL,
        modeSpecificTransChInfo         CHOICE {
            fdd                             SEQUENCE {
                -- dummy and dummy2 are not used in this version of the specification, they should
                -- not be sent and if received they should be ignored.
                dummy                           CPCH-SetID                  OPTIONAL,
                dummy2                          DRAC-StaticInformationList  OPTIONAL
            },
            tdd                             NULL
        },
        dl-CommonTransChInfo            DL-CommonTransChInfo-r4             OPTIONAL,
        dl-DeletedTransChInfoList       DL-DeletedTransChInfoList           OPTIONAL,
        dl-AddReconfTransChInfoList     DL-AddReconfTransChInfoList-r4      OPTIONAL,
    -- Physical channel IEs
```

```
        frequencyInfo                   FrequencyInfo                       OPTIONAL,
        maxAllowedUL-TX-Power           MaxAllowedUL-TX-Power               OPTIONAL,
        ul-ChannelRequirement           UL-ChannelRequirement-r4            OPTIONAL,
        modeSpecificPhysChInfo          CHOICE {
            fdd                             SEQUENCE {
                -- dummy is not used in this version of specification, it should
                -- not be sent and if received it should be ignored.
                dummy                           DL-PDSCH-Information        OPTIONAL
            },
            tdd                             NULL
        },
        dl-CommonInformation            DL-CommonInformation-r4             OPTIONAL,
        dl-InformationPerRL-List        DL-InformationPerRL-List-r4         OPTIONAL
}

CellUpdateConfirm-r5-IEs ::= SEQUENCE {
    -- User equipment IEs
        integrityProtectionModeInfo     IntegrityProtectionModeInfo         OPTIONAL,
        cipheringModeInfo               CipheringModeInfo                   OPTIONAL,
        activationTime                  ActivationTime                      OPTIONAL,
        new-U-RNTI                      U-RNTI                              OPTIONAL,
        new-C-RNTI                      C-RNTI                              OPTIONAL,
        -- The IE 'new-DSCH-RNTI' should not be included in FDD mode, and if received
        -- the UE behaviour is unspecified
        new-DSCH-RNTI                   DSCH-RNTI                           OPTIONAL,
        new-H-RNTI                      H-RNTI                              OPTIONAL,
        rrc-StateIndicator              RRC-StateIndicator,
        utran-DRX-CycleLengthCoeff      UTRAN-DRX-CycleLengthCoefficient    OPTIONAL,
        rlc-Re-establishIndicatorRb2-3or4       BOOLEAN,
        rlc-Re-establishIndicatorRb5orAbove BOOLEAN,
    -- CN information elements
        cn-InformationInfo              CN-InformationInfo                  OPTIONAL,
    -- UTRAN mobility IEs
        ura-Identity                    URA-Identity                        OPTIONAL,
    -- Radio bearer IEs
        rb-InformationReleaseList       RB-InformationReleaseList           OPTIONAL,
        rb-InformationReconfigList      RB-InformationReconfigList-r5       OPTIONAL,
        rb-InformationAffectedList      RB-InformationAffectedList-r5       OPTIONAL,
        dl-CounterSynchronisationInfo   DL-CounterSynchronisationInfo-r5    OPTIONAL,
    -- Transport channel IEs
        ul-CommonTransChInfo            UL-CommonTransChInfo-r4             OPTIONAL,
        ul-deletedTransChInfoList       UL-DeletedTransChInfoList           OPTIONAL,
        ul-AddReconfTransChInfoList     UL-AddReconfTransChInfoList         OPTIONAL,
        modeSpecificTransChInfo         CHOICE {
            fdd                             SEQUENCE {
                -- dummy and dummy2 are not used in this version of the specification, they should
                -- not be sent and if received they should be ignored.
                dummy                           CPCH-SetID                  OPTIONAL,
                dummy2                          DRAC-StaticInformationList  OPTIONAL
            },
            tdd                             NULL
        },
        dl-CommonTransChInfo            DL-CommonTransChInfo-r4             OPTIONAL,
        dl-DeletedTransChInfoList       DL-DeletedTransChInfoList-r5        OPTIONAL,
        dl-AddReconfTransChInfoList     DL-AddReconfTransChInfoList-r5      OPTIONAL,
    -- Physical channel IEs
        frequencyInfo                   FrequencyInfo                       OPTIONAL,
        maxAllowedUL-TX-Power           MaxAllowedUL-TX-Power               OPTIONAL,
        ul-ChannelRequirement           UL-ChannelRequirement-r5            OPTIONAL,
        modeSpecificPhysChInfo          CHOICE {
            fdd                             SEQUENCE {
                -- dummy is not used in this version of specification, it should
                -- not be sent and if received it should be ignored.
                dummy                           DL-PDSCH-Information        OPTIONAL
            },
            tdd                             NULL
        },
        dl-HSPDSCH-Information          DL-HSPDSCH-Information              OPTIONAL,
        dl-CommonInformation            DL-CommonInformation-r5             OPTIONAL,
        dl-InformationPerRL-List        DL-InformationPerRL-List-r5         OPTIONAL
}

CellUpdateConfirm-r6-IEs ::= SEQUENCE {
    -- User equipment IEs
        integrityProtectionModeInfo     IntegrityProtectionModeInfo         OPTIONAL,
        cipheringModeInfo               CipheringModeInfo                   OPTIONAL,
        activationTime                  ActivationTime                      OPTIONAL,
        new-U-RNTI                      U-RNTI                              OPTIONAL,
```

```
        new-C-RNTI                      C-RNTI                                  OPTIONAL,
        -- The IE 'new-DSCH-RNTI' should not be included in FDD mode,
        -- and if received the UE behaviour is unspecified
        new-DSCH-RNTI                   DSCH-RNTI                               OPTIONAL,
        new-H-RNTI                      H-RNTI                                  OPTIONAL,
        newPrimary-E-RNTI               E-RNTI                                  OPTIONAL,
        newSecondary-E-RNTI             E-RNTI                                  OPTIONAL,
        rrc-StateIndicator              RRC-StateIndicator,
        utran-DRX-CycleLengthCoeff      UTRAN-DRX-CycleLengthCoefficient        OPTIONAL,
        rlc-Re-establishIndicatorRb2-3or4       BOOLEAN,
        rlc-Re-establishIndicatorRb5orAbove     BOOLEAN,
    -- CN information elements
        cn-InformationInfo              CN-InformationInfo-r6                   OPTIONAL,
    -- UTRAN mobility IEs
        ura-Identity                    URA-Identity                            OPTIONAL,
    -- Radio bearer IEs
        rb-InformationReleaseList       RB-InformationReleaseList               OPTIONAL,
        rb-InformationReconfigList      RB-InformationReconfigList-r6           OPTIONAL,
        rb-InformationAffectedList      RB-InformationAffectedList-r6           OPTIONAL,
        dl-CounterSynchronisationInfo   DL-CounterSynchronisationInfo-r5        OPTIONAL,
        pdcp-ROHC-TargetMode            PDCP-ROHC-TargetMode                    OPTIONAL,
    -- Transport channel IEs
        ul-CommonTransChInfo            UL-CommonTransChInfo-r4                 OPTIONAL,
        ul-deletedTransChInfoList       UL-DeletedTransChInfoList-r6            OPTIONAL,
        ul-AddReconfTransChInfoList     UL-AddReconfTransChInfoList-r6          OPTIONAL,
        dl-CommonTransChInfo            DL-CommonTransChInfo-r4                 OPTIONAL,
        dl-DeletedTransChInfoList       DL-DeletedTransChInfoList-r5            OPTIONAL,
        dl-AddReconfTransChInfoList     DL-AddReconfTransChInfoList-r5          OPTIONAL,
    -- Physical channel IEs
        frequencyInfo                   FrequencyInfo                           OPTIONAL,
        maxAllowedUL-TX-Power           MaxAllowedUL-TX-Power                   OPTIONAL,
        ul-DPCH-Info                    UL-DPCH-Info-r6                         OPTIONAL,
        ul-EDCH-Information             UL-EDCH-Information-r6                  OPTIONAL,
        dl-HSPDSCH-Information          DL-HSPDSCH-Information-r6               OPTIONAL,
        dl-CommonInformation            DL-CommonInformation-r6                 OPTIONAL,
        dl-InformationPerRL-List        DL-InformationPerRL-List-r6             OPTIONAL,
    -- MBMS IEs
        mbms-PL-ServiceRestrictInfo     MBMS-PL-ServiceRestrictInfo-r6          OPTIONAL
}

CellUpdateConfirm-v690ext-IEs ::=   SEQUENCE {
    -- Core network IEs
        primary-plmn-Identity           PLMN-Identity                           OPTIONAL,
    -- Physical channel IEs
        -- The IE harq-Preamble-Mode should not be used in the r3 and r4 versions of the message
        -- If included in the r3 or r4 version of the message, the UE should ignore the IE
        harq-Preamble-Mode              HARQ-Preamble-Mode                      OPTIONAL,
        beaconPLEst                     BEACON-PL-Est                           OPTIONAL,
        postVerificationPeriod          ENUMERATED { true }                     OPTIONAL,
        dhs-sync                        DHS-Sync                                OPTIONAL,
    -- MBMS IEs
        mbms-PL-ServiceRestrictInfo     MBMS-PL-ServiceRestrictInfo-r6          OPTIONAL
}

CellUpdateConfirm-r7-IEs ::= SEQUENCE {
    -- User equipment IEs
        integrityProtectionModeInfo     IntegrityProtectionModeInfo             OPTIONAL,
        cipheringModeInfo               CipheringModeInfo                       OPTIONAL,
        activationTime                  ActivationTime                          OPTIONAL,
        new-U-RNTI                      U-RNTI                                  OPTIONAL,
        new-C-RNTI                      C-RNTI                                  OPTIONAL,
        -- The IE 'new-DSCH-RNTI' should not be included in FDD mode,
        -- and if received the UE behaviour is unspecified
        new-DSCH-RNTI                   DSCH-RNTI                               OPTIONAL,
        new-H-RNTI                      H-RNTI                                  OPTIONAL,
        newPrimary-E-RNTI               E-RNTI                                  OPTIONAL,
        newSecondary-E-RNTI             E-RNTI                                  OPTIONAL,
        rrc-StateIndicator              RRC-StateIndicator,
        utran-DRX-CycleLengthCoeff      UTRAN-DRX-CycleLengthCoefficient        OPTIONAL,
        rlc-Re-establishIndicatorRb2-3or4       BOOLEAN,
        rlc-Re-establishIndicatorRb5orAbove     BOOLEAN,
    -- CN information elements
        cn-InformationInfo              CN-InformationInfo-r6                   OPTIONAL,
    -- UTRAN mobility IEs
        ura-Identity                    URA-Identity                            OPTIONAL,
    -- Radio bearer IEs
        rb-InformationReleaseList       RB-InformationReleaseList               OPTIONAL,
        rb-InformationReconfigList      RB-InformationReconfigList-r6           OPTIONAL,
```

```
        rb-InformationAffectedList      RB-InformationAffectedList-r6       OPTIONAL,
        dl-CounterSynchronisationInfo   DL-CounterSynchronisationInfo-r5    OPTIONAL,
        pdcp-ROHC-TargetMode            PDCP-ROHC-TargetMode                OPTIONAL,
    -- Transport channel IEs
        ul-CommonTransChInfo            UL-CommonTransChInfo-r4             OPTIONAL,
        ul-deletedTransChInfoList       UL-DeletedTransChInfoList-r6        OPTIONAL,
        ul-AddReconfTransChInfoList     UL-AddReconfTransChInfoList-r6      OPTIONAL,
        dl-CommonTransChInfo            DL-CommonTransChInfo-r4             OPTIONAL,
        dl-DeletedTransChInfoList       DL-DeletedTransChInfoList-r5        OPTIONAL,
        dl-AddReconfTransChInfoList     DL-AddReconfTransChInfoList-r5      OPTIONAL,
    -- Physical channel IEs
        frequencyInfo                   FrequencyInfo                       OPTIONAL,
        maxAllowedUL-TX-Power           MaxAllowedUL-TX-Power               OPTIONAL,
        ul-DPCH-Info                    UL-DPCH-Info-r7                     OPTIONAL,
        ul-EDCH-Information             UL-EDCH-Information-r6              OPTIONAL,
        dl-HSPDSCH-Information          DL-HSPDSCH-Information-r7           OPTIONAL,
        dl-CommonInformation            DL-CommonInformation-r7             OPTIONAL,
        dl-InformationPerRL-List        DL-InformationPerRL-List-r7         OPTIONAL,
    -- MBMS IEs
        mbms-PL-ServiceRestrictInfo     MBMS-PL-ServiceRestrictInfo-r6      OPTIONAL
}

-- **************************************************
--
-- CELL UPDATE CONFIRM for CCCH
--
-- **************************************************

CellUpdateConfirm-CCCH ::= CHOICE {
    r3                              SEQUENCE {
        -- User equipment IEs
            u-RNTI                      U-RNTI,
        -- The rest of the message is identical to the one sent on DCCH.
            cellUpdateConfirm-r3                CellUpdateConfirm-r3-IEs,
            laterNonCriticalExtensions      SEQUENCE {
                -- Container for additional R99 extensions
                cellUpdateConfirm-CCCH-r3-add-ext           BIT STRING  OPTIONAL,
                v4b0NonCriticalExtensions       SEQUENCE {
                    cellUpdateConfirm-v4b0ext       CellUpdateConfirm-v4b0ext-IEs,
                    v590NonCriticalExtensions       SEQUENCE {
                        cellUpdateConfirm-v590ext       CellUpdateConfirm-v590ext-IEs,
                        v5d0NonCriticalExtenstions      SEQUENCE {
                            cellUpdateConfirm-v5d0ext       CellUpdateConfirm-v5d0ext-IEs,
                            v690NonCriticalExtensions       SEQUENCE {
                                cellUpdateConfirm-v690ext       CellUpdateConfirm-v690ext-IEs,
                                nonCriticalExtensions           SEQUENCE {} OPTIONAL
                            }   OPTIONAL
                        }   OPTIONAL
                    }   OPTIONAL
                }   OPTIONAL
            }   OPTIONAL
    },
    later-than-r3                   SEQUENCE {
        u-RNTI                          U-RNTI,
        rrc-TransactionIdentifier       RRC-TransactionIdentifier,
        criticalExtensions              CHOICE {
            r4                              SEQUENCE {
                -- The rest of the message is identical to the one sent on DCCH.
                cellUpdateConfirm-r4            CellUpdateConfirm-r4-IEs,
                v4d0NonCriticalExtensions           SEQUENCE {
                    -- Container for adding non critical extensions after freezing REL-5
                    cellUpdateConfirm-CCCH-r4-add-ext       BIT STRING      OPTIONAL,
                    v590NonCriticalExtensions       SEQUENCE {
                        cellUpdateConfirm-v590ext       CellUpdateConfirm-v590ext-IEs,
                        v5d0NonCriticalExtenstions      SEQUENCE {
                            cellUpdateConfirm-v5d0ext       CellUpdateConfirm-v5d0ext-IEs,
                            v690NonCriticalExtensions       SEQUENCE {
                                cellUpdateConfirm-v690ext       CellUpdateConfirm-v690ext-IEs,
                                nonCriticalExtensions           SEQUENCE {}     OPTIONAL
                            }   OPTIONAL
                        }   OPTIONAL
                    }   OPTIONAL
                }   OPTIONAL
            },
            criticalExtensions              CHOICE {
                r5                              SEQUENCE {
                    cellUpdateConfirm-r5            CellUpdateConfirm-r5-IEs,
                    cellUpdateConfirm-CCCH-r5-add-ext       BIT STRING      OPTIONAL,
```

```
                    v5d0NonCriticalExtenstions      SEQUENCE {
                        cellUpdateConfirm-v5d0ext       CellUpdateConfirm-v5d0ext-IEs,
                        v690NonCriticalExtensions       SEQUENCE {
                            cellUpdateConfirm-v690ext       CellUpdateConfirm-v690ext-IEs,
                            nonCriticalExtensions           SEQUENCE {}     OPTIONAL
                        }   OPTIONAL
                    }   OPTIONAL
                },
                criticalExtensions              CHOICE {
                    r6                              SEQUENCE {
                        cellUpdateConfirm-r6            CellUpdateConfirm-r6-IEs,
                        cellUpdateConfirm-r6-add-ext    BIT STRING      OPTIONAL,
                        nonCriticalExtensions           SEQUENCE {}     OPTIONAL
                    },
                    criticalExtensions              CHOICE {
                        r7                              SEQUENCE {
                            cellUpdateConfirm-r7            CellUpdateConfirm-r7-IEs,
                            cellUpdateConfirm-r7-add-ext    BIT STRING      OPTIONAL,
                            nonCriticalExtensions           SEQUENCE {}     OPTIONAL
                        },
                        criticalExtensions              SEQUENCE {}
                    }
                }
            }
        }
    }
}

-- ****************************************************
--
-- COUNTER CHECK
--
-- ****************************************************

CounterCheck ::= CHOICE {
    r3                              SEQUENCE {
        counterCheck-r3                 CounterCheck-r3-IEs,
        laterNonCriticalExtensions      SEQUENCE {
            -- Container for additional R99 extensions
            counterCheck-r3-add-ext     BIT STRING  OPTIONAL,
            nonCriticalExtensions       SEQUENCE {} OPTIONAL
        }   OPTIONAL
    },
    later-than-r3                   SEQUENCE {
        rrc-TransactionIdentifier       RRC-TransactionIdentifier,
        criticalExtensions              SEQUENCE {}
    }
}

CounterCheck-r3-IEs ::= SEQUENCE {
    -- User equipment IEs
        rrc-TransactionIdentifier       RRC-TransactionIdentifier,
    -- Radio bearer IEs
        rb-COUNT-C-MSB-InformationList  RB-COUNT-C-MSB-InformationList
}

-- ****************************************************
--
-- COUNTER CHECK RESPONSE
--
-- ****************************************************

CounterCheckResponse ::= SEQUENCE {
    -- User equipment IEs
        rrc-TransactionIdentifier       RRC-TransactionIdentifier,
    -- Radio bearer IEs
        rb-COUNT-C-InformationList      RB-COUNT-C-InformationList          OPTIONAL,
        laterNonCriticalExtensions      SEQUENCE {
            -- Container for additional R99 extensions
            counterCheckResponse-r3-add-ext     BIT STRING  OPTIONAL,
            nonCriticalExtensions               SEQUENCE {} OPTIONAL
        }   OPTIONAL
}

-- ****************************************************
--
-- DOWNLINK DIRECT TRANSFER
--
```

```
-- **************************************************

DownlinkDirectTransfer ::= CHOICE {
    r3                              SEQUENCE {
        downlinkDirectTransfer-r3       DownlinkDirectTransfer-r3-IEs,
        laterNonCriticalExtensions      SEQUENCE {
            -- Container for additional R99 extensions
            downlinkDirectTransfer-r3-add-ext       BIT STRING  OPTIONAL,
            nonCriticalExtensions           SEQUENCE {} OPTIONAL
        }   OPTIONAL
    },
    later-than-r3                   SEQUENCE {
        rrc-TransactionIdentifier       RRC-TransactionIdentifier,
        criticalExtensions              SEQUENCE {}
    }
}

DownlinkDirectTransfer-r3-IEs ::= SEQUENCE {
    -- User equipment IEs
        rrc-TransactionIdentifier       RRC-TransactionIdentifier,
    -- Core network IEs
        cn-DomainIdentity               CN-DomainIdentity,
        nas-Message                     NAS-Message
}

-- **************************************************
--
-- HANDOVER TO UTRAN COMMAND
--
-- **************************************************


HandoverToUTRANCommand ::= CHOICE {
    r3                              SEQUENCE {
        handoverToUTRANCommand-r3       HandoverToUTRANCommand-r3-IEs,
        nonCriticalExtensions           SEQUENCE {} OPTIONAL
    },
    criticalExtensions              CHOICE {
        r4                              SEQUENCE {
            handoverToUTRANCommand-r4       HandoverToUTRANCommand-r4-IEs,
            nonCriticalExtensions           SEQUENCE {}     OPTIONAL
        },
        criticalExtensions              CHOICE {
            r5                              SEQUENCE {
                handoverToUTRANCommand-r5       HandoverToUTRANCommand-r5-IEs,
                nonCriticalExtensions           SEQUENCE {}     OPTIONAL
            },
            criticalExtensions              CHOICE {
                r6                              SEQUENCE {
                    handoverToUTRANCommand-r6       HandoverToUTRANCommand-r6-IEs,
                    nonCriticalExtensions           SEQUENCE {}     OPTIONAL
                },
                criticalExtensions              CHOICE {
                    r7                              SEQUENCE {
                        handoverToUTRANCommand-r7       HandoverToUTRANCommand-r7-IEs,
                        nonCriticalExtensions           SEQUENCE {}     OPTIONAL
                    },
                    criticalExtensions              SEQUENCE {}
                }
            }
        }
    }
}

HandoverToUTRANCommand-r3-IEs ::= SEQUENCE {
    -- User equipment IEs
        new-U-RNTI                      U-RNTI-Short,
        -- dummy is not used in this version of specification, it should
        -- not be sent and if received it should be ignored.
        dummy                           ActivationTime                      OPTIONAL,
        cipheringAlgorithm              CipheringAlgorithm                  OPTIONAL,
    -- Radio bearer IEs
    -- Specification mode information
        specificationMode               CHOICE {
            complete                        SEQUENCE {
                srb-InformationSetupList        SRB-InformationSetupList,
                rab-InformationSetupList        RAB-InformationSetupList            OPTIONAL,
                ul-CommonTransChInfo            UL-CommonTransChInfo,
```

```
                ul-AddReconfTransChInfoList     UL-AddReconfTransChInfoList,
                dl-CommonTransChInfo            DL-CommonTransChInfo,
                dl-AddReconfTransChInfoList     DL-AddReconfTransChInfoList,
                ul-DPCH-Info                    UL-DPCH-Info,
                modeSpecificInfo                CHOICE {
                    fdd                             SEQUENCE {
                        -- dummy and dummy2 are not used in this version of specification,
                        -- they should not be sent and if received they should be ignored.
                        dummy                           DL-PDSCH-Information OPTIONAL,
                        dummy2                          CPCH-SetInfo        OPTIONAL
                    },
                    tdd                             NULL
                },
                dl-CommonInformation            DL-CommonInformation,
                dl-InformationPerRL-List        DL-InformationPerRL-List,
                frequencyInfo                   FrequencyInfo
            },
            preconfiguration                SEQUENCE {
-- All IEs that include an FDD/TDD choice are split in two IEs for this message,
-- one for the FDD only elements and one for the TDD only elements, so that one
-- FDD/TDD choice in this level is sufficient.
                preConfigMode                   CHOICE {
                    predefinedConfigIdentity        PredefinedConfigIdentity,
                    defaultConfig                   SEQUENCE {
                        defaultConfigMode               DefaultConfigMode,
                        defaultConfigIdentity           DefaultConfigIdentity
                    }
                },
                rab-Info                        RAB-Info-Post       OPTIONAL,
                modeSpecificInfo                CHOICE {
                    fdd                             SEQUENCE {
                        ul-DPCH-Info                    UL-DPCH-InfoPostFDD,
                        dl-CommonInformationPost        DL-CommonInformationPost,
                        dl-InformationPerRL-List        DL-InformationPerRL-ListPostFDD,
                        frequencyInfo                   FrequencyInfoFDD
                    },
                    tdd                             SEQUENCE {
                        ul-DPCH-Info                    UL-DPCH-InfoPostTDD,
                        dl-CommonInformationPost        DL-CommonInformationPost,
                        dl-InformationPerRL             DL-InformationPerRL-PostTDD,
                        frequencyInfo                   FrequencyInfoTDD,
                        primaryCCPCH-TX-Power           PrimaryCCPCH-TX-Power
                    }
                }
            }
        },
    -- Physical channel IEs
        maxAllowedUL-TX-Power           MaxAllowedUL-TX-Power
}

HandoverToUTRANCommand-r4-IEs ::= SEQUENCE {
    -- User equipment IEs
        new-U-RNTI                  U-RNTI-Short,
        cipheringAlgorithm          CipheringAlgorithm                  OPTIONAL,
    -- Radio bearer IEs
    -- Specification mode information
        specificationMode           CHOICE {
            complete                    SEQUENCE {
                srb-InformationSetupList        SRB-InformationSetupList,
                rab-InformationSetupList        RAB-InformationSetupList-r4         OPTIONAL,
                ul-CommonTransChInfo            UL-CommonTransChInfo-r4,
                ul-AddReconfTransChInfoList     UL-AddReconfTransChInfoList,
                dl-CommonTransChInfo            DL-CommonTransChInfo-r4,
                dl-AddReconfTransChInfoList     DL-AddReconfTransChInfoList-r4,
                ul-DPCH-Info                    UL-DPCH-Info-r4,
                modeSpecificInfo                CHOICE {
                    fdd                             SEQUENCE {
                        -- dummy and dummy2 are not used in this version of specification,
                        -- they should not be sent and if received they should be ignored.
                        dummy                           DL-PDSCH-Information OPTIONAL,
                        dummy2                          CPCH-SetInfo        OPTIONAL
                    },
                    tdd                             NULL
                },
                dl-CommonInformation            DL-CommonInformation-r4,
                dl-InformationPerRL-List        DL-InformationPerRL-List-r4,
                frequencyInfo                   FrequencyInfo
            },
```

```
            preconfiguration                SEQUENCE {
-- All IEs that include an FDD/TDD choice are split in two IEs for this message,
-- one for the FDD only elements and one for the TDD only elements, so that one
-- FDD/TDD choice in this level is sufficient.
                preConfigMode                   CHOICE {
                    predefinedConfigIdentity        PredefinedConfigIdentity,
                    defaultConfig                   SEQUENCE {
                        defaultConfigMode               DefaultConfigMode,
                        defaultConfigIdentity           DefaultConfigIdentity-r4
                    }
                },
                rab-Info                        RAB-Info-Post       OPTIONAL,
                modeSpecificInfo                CHOICE {
                    fdd                             SEQUENCE {
                        ul-DPCH-Info                    UL-DPCH-InfoPostFDD,
                        dl-CommonInformationPost        DL-CommonInformationPost,
                        dl-InformationPerRL-List        DL-InformationPerRL-ListPostFDD,
                        frequencyInfo                   FrequencyInfoFDD
                    },
                    tdd                             CHOICE {
                        tdd384                          SEQUENCE {
                            ul-DPCH-Info                    UL-DPCH-InfoPostTDD,
                            dl-InformationPerRL             DL-InformationPerRL-PostTDD,
                            frequencyInfo                   FrequencyInfoTDD,
                            primaryCCPCH-TX-Power           PrimaryCCPCH-TX-Power
                        },
                        tdd128                          SEQUENCE {
                            ul-DPCH-Info                    UL-DPCH-InfoPostTDD-LCR-r4,
                            dl-InformationPerRL             DL-InformationPerRL-PostTDD-LCR-r4,
                            frequencyInfo                   FrequencyInfoTDD,
                            primaryCCPCH-TX-Power           PrimaryCCPCH-TX-Power
                        }
                    }
                }
            }
        },
    -- Physical channel IEs
        maxAllowedUL-TX-Power           MaxAllowedUL-TX-Power
}

HandoverToUTRANCommand-r5-IEs ::= SEQUENCE {
    -- User equipment IEs
        new-U-RNTI                      U-RNTI-Short,
        cipheringAlgorithm              CipheringAlgorithm                  OPTIONAL,
    -- Radio bearer IEs
    -- Specification mode information
        specificationMode               CHOICE {
            complete                        SEQUENCE {
                srb-InformationSetupList        SRB-InformationSetupList-r5,
                rab-InformationSetupList        RAB-InformationSetupList-r5         OPTIONAL,
                ul-CommonTransChInfo            UL-CommonTransChInfo-r4,
                ul-AddReconfTransChInfoList     UL-AddReconfTransChInfoList,
                dl-CommonTransChInfo            DL-CommonTransChInfo-r4,
                dl-AddReconfTransChInfoList     DL-AddReconfTransChInfoList-r5,
                ul-DPCH-Info                    UL-DPCH-Info-r5,
                modeSpecificInfo                CHOICE {
                    fdd                             SEQUENCE {
                        -- dummy and dummy2 are not used in this version of specification,
                        -- they should not be sent and if received they should be ignored.
                        dummy                           DL-PDSCH-Information OPTIONAL,
                        dummy2                          CPCH-SetInfo        OPTIONAL
                    },
                    tdd                             NULL
                },
                dl-CommonInformation            DL-CommonInformation-r4,
                dl-InformationPerRL-List        DL-InformationPerRL-List-r5,
                frequencyInfo                   FrequencyInfo
            },
            preconfiguration                SEQUENCE {
-- All IEs that include an FDD/TDD choice are split in two IEs for this message,
-- one for the FDD only elements and one for the TDD only elements, so that one
-- FDD/TDD choice in this level is sufficient.
                preConfigMode                   CHOICE {
                    predefinedConfigIdentity        PredefinedConfigIdentity,
                    defaultConfig                   SEQUENCE {
                        defaultConfigMode               DefaultConfigMode,
                        defaultConfigIdentity           DefaultConfigIdentity-r5
                    }
```

```
                },
                rab-Info                        RAB-Info-Post       OPTIONAL,
                modeSpecificInfo                CHOICE {
                    fdd                             SEQUENCE {
                        ul-DPCH-Info                    UL-DPCH-InfoPostFDD,
                        dl-CommonInformationPost        DL-CommonInformationPost,
                        dl-InformationPerRL-List        DL-InformationPerRL-ListPostFDD,
                        frequencyInfo                   FrequencyInfoFDD
                    },
                    tdd                             CHOICE {
                        tdd384                          SEQUENCE {
                            ul-DPCH-Info                    UL-DPCH-InfoPostTDD,
                            dl-InformationPerRL             DL-InformationPerRL-PostTDD,
                            frequencyInfo                   FrequencyInfoTDD,
                            primaryCCPCH-TX-Power           PrimaryCCPCH-TX-Power
                        },
                        tdd128                          SEQUENCE {
                            ul-DPCH-Info                    UL-DPCH-InfoPostTDD-LCR-r4,
                            dl-InformationPerRL             DL-InformationPerRL-PostTDD-LCR-r4,
                            frequencyInfo                   FrequencyInfoTDD,
                            primaryCCPCH-TX-Power           PrimaryCCPCH-TX-Power
                        }
                    }
                }
            }
        },
    -- Physical channel IEs
        maxAllowedUL-TX-Power           MaxAllowedUL-TX-Power
}

HandoverToUTRANCommand-r6-IEs ::= SEQUENCE {
    -- User equipment IEs
        new-U-RNTI                      U-RNTI-Short,
        cipheringAlgorithm              CipheringAlgorithm                  OPTIONAL,
    -- Radio bearer IEs
    -- Specification mode information
        specificationMode               CHOICE {
            complete                        SEQUENCE {
                srb-InformationSetupList        SRB-InformationSetupList-r6,
                rab-InformationSetupList        RAB-InformationSetupList-r6     OPTIONAL,
                ul-CommonTransChInfo            UL-CommonTransChInfo-r4,
                ul-AddReconfTransChInfoList     UL-AddReconfTransChInfoList-r6,
                dl-CommonTransChInfo            DL-CommonTransChInfo-r4,
                dl-AddReconfTransChInfoList     DL-AddReconfTransChInfoList-r5,
                ul-DPCH-Info                    UL-DPCH-Info-r6,
                ul-EDCH-Information             UL-EDCH-Information-r6          OPTIONAL,
                dl-HSPDSCH-Information          DL-HSPDSCH-Information-r6       OPTIONAL,
                dl-CommonInformation            DL-CommonInformation-r6,
                dl-InformationPerRL-List        DL-InformationPerRL-List-r6,
                frequencyInfo                   FrequencyInfo
            },
            preconfiguration                SEQUENCE {
                -- All IEs that include an FDD/TDD choice are split in two IEs for this message,
                -- one for the FDD only elements and one for the TDD only elements, so that one
                -- FDD/TDD choice in this level is sufficient.
                preConfigMode                   CHOICE {
                    predefinedConfigIdentity        PredefinedConfigIdentity,
                    defaultConfig                   SEQUENCE {
                        defaultConfigMode               DefaultConfigMode,
                        defaultConfigIdentity           DefaultConfigIdentity-r6
                    }
                },
                rab-Info                        RAB-Info-Post       OPTIONAL,
                modeSpecificInfo                CHOICE {
                    fdd                             SEQUENCE {
                        ul-DPCH-Info                    UL-DPCH-InfoPostFDD,
                        dl-CommonInformationPost        DL-CommonInformationPost,
                        dl-InformationPerRL-List        DL-InformationPerRL-ListPostFDD,
                        frequencyInfo                   FrequencyInfoFDD
                    },
                    tdd                             CHOICE {
                        tdd384                          SEQUENCE {
                            ul-DPCH-Info                    UL-DPCH-InfoPostTDD,
                            dl-InformationPerRL             DL-InformationPerRL-PostTDD,
                            frequencyInfo                   FrequencyInfoTDD,
                            primaryCCPCH-TX-Power           PrimaryCCPCH-TX-Power
                        },
                        tdd128                          SEQUENCE {
```

```
                            ul-DPCH-Info                    UL-DPCH-InfoPostTDD-LCR-r4,
                            dl-InformationPerRL             DL-InformationPerRL-PostTDD-LCR-r4,
                            frequencyInfo                   FrequencyInfoTDD,
                            primaryCCPCH-TX-Power           PrimaryCCPCH-TX-Power
                        }
                    }
                }
            }
        },
    -- Physical channel IEs
        maxAllowedUL-TX-Power           MaxAllowedUL-TX-Power
}

HandoverToUTRANCommand-r7-IEs ::= SEQUENCE {
    -- User equipment IEs
        new-U-RNTI                      U-RNTI-Short,
        cipheringAlgorithm              CipheringAlgorithm                      OPTIONAL,
    -- Radio bearer IEs
    -- Specification mode information
        specificationMode               CHOICE {
            complete                        SEQUENCE {
                srb-InformationSetupList        SRB-InformationSetupList-r6,
                rab-InformationSetupList        RAB-InformationSetupList-r6     OPTIONAL,
                ul-CommonTransChInfo            UL-CommonTransChInfo-r4,
                ul-AddReconfTransChInfoList     UL-AddReconfTransChInfoList-r6,
                dl-CommonTransChInfo            DL-CommonTransChInfo-r4,
                dl-AddReconfTransChInfoList     DL-AddReconfTransChInfoList-r5,
                ul-DPCH-Info                    UL-DPCH-Info-r7,
                dl-CommonInformation            DL-CommonInformation-r4,
                dl-InformationPerRL-List        DL-InformationPerRL-List-r7,
                frequencyInfo                   FrequencyInfo
            }
            -- For the 'preconfiguration' specificationMode the r5 message is used.
        },
    -- Physical channel IEs
        maxAllowedUL-TX-Power           MaxAllowedUL-TX-Power
}

-- **************************************************
--
-- HANDOVER TO UTRAN COMPLETE
--
-- **************************************************

HandoverToUTRANComplete ::= SEQUENCE {
    --TABULAR: Integrity protection shall not be performed on this message.
    -- User equipment IEs
    -- TABULAR: startList is conditional on history.
        startList                       STARTList                           OPTIONAL,
    -- Radio bearer IEs
        count-C-ActivationTime          ActivationTime                      OPTIONAL,
        laterNonCriticalExtensions      SEQUENCE {
            -- Container for additional R99 extensions
            handoverToUTRANComplete-r3-add-ext      BIT STRING  OPTIONAL,
            nonCriticalExtensions           SEQUENCE {}     OPTIONAL
        }   OPTIONAL
}

-- **************************************************
--
-- INITIAL DIRECT TRANSFER
--
-- **************************************************

InitialDirectTransfer ::= SEQUENCE {
    -- Core network IEs
        cn-DomainIdentity               CN-DomainIdentity,
        intraDomainNasNodeSelector      IntraDomainNasNodeSelector,
        nas-Message                     NAS-Message,
    -- Measurement IEs
        measuredResultsOnRACH           MeasuredResultsOnRACH               OPTIONAL,
        v3a0NonCriticalExtensions       SEQUENCE {
        initialDirectTransfer-v3a0ext   InitialDirectTransfer-v3a0ext,
        laterNonCriticalExtensions      SEQUENCE {
            -- Container for additional R99 extensions
            initialDirectTransfer-r3-add-ext        BIT STRING  OPTIONAL,
                v590NonCriticalExtensions       SEQUENCE {
                    initialDirectTransfer-v590ext   InitialDirectTransfer-v590ext,
```

```
                    v690NonCriticalExtensions       SEQUENCE {
                        initialDirectTransfer-v690ext   InitialDirectTransfer-v690ext-IEs,
                        nonCriticalExtensions           SEQUENCE {}     OPTIONAL
                    }       OPTIONAL
                }       OPTIONAL
            }       OPTIONAL
        }   OPTIONAL
}

InitialDirectTransfer-v3a0ext ::= SEQUENCE {
    -- start-value shall always be included in this version of the protocol
    start-Value                     START-Value                         OPTIONAL
}
InitialDirectTransfer-v590ext ::= SEQUENCE {
    establishmentCause      EstablishmentCause  OPTIONAL
}

InitialDirectTransfer-v690ext-IEs ::= SEQUENCE {
    -- Core network IEs
        plmn-Identity                   PLMN-Identity                       OPTIONAL,
    -- Measurement IEs
        measuredResultsOnRACHinterFreq  MeasuredResultsOnRACHinterFreq      OPTIONAL,
    -- MBMS IEs
        mbms-JoinedInformation          MBMS-JoinedInformation-r6           OPTIONAL
}

-- **************************************************
--
-- HANDOVER FROM UTRAN COMMAND
--
-- **************************************************

HandoverFromUTRANCommand-GSM ::= CHOICE {
    r3                              SEQUENCE {
        handoverFromUTRANCommand-GSM-r3
                                        HandoverFromUTRANCommand-GSM-r3-IEs,
        -- UTRAN should not include the IE laterNonCriticalExtensions when it sets the IE
        -- gsm-message included in handoverFromUTRANCommand-GSM-r3 to single-GSM-Message. The UE
        -- behaviour upon receiving a message with this combination of IE values is unspecified.
        laterNonCriticalExtensions      SEQUENCE {
            -- Container for additional R99 extensions
            handoverFromUTRANCommand-GSM-r3-add-ext     BIT STRING  OPTIONAL,
            -- UTRAN may apply the r3 version of the message to perform PS handover
            -- for a single RAB only
            v690NonCriticalExtensions       SEQUENCE {
                handoverFromUTRANCommand-GSM-v690ext    HandoverFromUTRANCommand-GSM-v690ext-IEs,
                nonCriticalExtensions           SEQUENCE {} OPTIONAL
            }   OPTIONAL
        }   OPTIONAL
    },
    later-than-r3                   SEQUENCE {
        rrc-TransactionIdentifier       RRC-TransactionIdentifier,
        criticalExtensions              CHOICE {
            r6                              SEQUENCE {
                handoverFromUTRANCommand-GSM-r6     HandoverFromUTRANCommand-GSM-r6-IEs,
                handoverFromUTRANCommand-GSM-r6-add-ext     BIT STRING  OPTIONAL,
                nonCriticalExtensions           SEQUENCE {} OPTIONAL
            },
            criticalExtensions              SEQUENCE {}
        }
    }
}

HandoverFromUTRANCommand-GSM-r3-IEs ::= SEQUENCE {
    -- User equipment IEs
        rrc-TransactionIdentifier       RRC-TransactionIdentifier,
        activationTime                  ActivationTime                      OPTIONAL,
    -- Radio bearer IEs
        toHandoverRAB-Info              RAB-Info                            OPTIONAL,
    -- Measurement IEs
        frequency-band                  Frequency-Band,
    -- Other IEs
        gsm-message                     CHOICE {
            -- In the single-GSM-Message case the following rules apply:
            -- 1> the GSM message directly follows the basic production; the final padding that
            --    results when PER encoding the abstract syntax value is removed prior to appending
            --    the GSM message.
            -- 2> the RRC message excluding the GSM part, does not contain a length determinant;
```

```
            --    there is no explicit parameter indicating the size of the included GSM message.
            -- 3> depending on need, final padding (all '0's) is added to ensure the final result
            --    comprises a full number of octets
            single-GSM-Message              SEQUENCE {},
            gsm-MessageList                 SEQUENCE {
                gsm-Messages                    GSM-MessageList
            }
        }
}

HandoverFromUTRANCommand-GSM-r6-IEs ::= SEQUENCE {
    -- User equipment IEs
        activationTime                  ActivationTime                      OPTIONAL,
    -- Radio bearer IEs
        toHandoverRAB-Info              RAB-InformationList-r6              OPTIONAL,
    -- Measurement IEs
        frequency-band                  Frequency-Band,
    -- Other IEs
        gsm-message                     CHOICE {
            -- In the single-GSM-Message case the following rules apply:
            -- 1> the GSM message directly follows the basic production; the final padding that
            --    results when PER encoding the abstract syntax value is removed prior to appending
            --    the GSM message.
            -- 2> the RRC message excluding the GSM part, does not contain a length determinant;
            --    there is no explicit parameter indicating the size of the included GSM message.
            -- 3> depending on need, final padding (all '0's) is added to ensure the final result
            --    comprises a full number of octets
            single-GSM-Message              SEQUENCE {},
            gsm-MessageList                 SEQUENCE {
                gsm-Messages                    GSM-MessageList
            }
        },
        geran-SystemInfoType                CHOICE  {
            sI                                  GERAN-SystemInformation,
            pSI                                 GERAN-SystemInformation
        }       OPTIONAL
}

HandoverFromUTRANCommand-GSM-v690ext-IEs ::= SEQUENCE {
        geran-SystemInfoType                CHOICE  {
            sI                                  GERAN-SystemInformation,
            pSI                                 GERAN-SystemInformation
        }       OPTIONAL
}

HandoverFromUTRANCommand-GERANIu ::= SEQUENCE {
    rrc-TransactionIdentifier       RRC-TransactionIdentifier,
    handoverFromUTRANCommand-GERANIu    CHOICE {
        r5                                  SEQUENCE {
            handoverFromUTRANCommand-GERANIu-r5
                                                HandoverFromUTRANCommand-GERANIu-r5-IEs,
            -- UTRAN should not include the IE nonCriticalExtensions when it sets
            -- the IE geranIu-message included in handoverFromUTRANCommand-GERANIu-r5 to
            -- single-GERANIu-Message
            -- The UE behaviour upon receiving a message including this combination of IE values is
            -- not specified
            nonCriticalExtensions           SEQUENCE {} OPTIONAL
        },
        later-than-r5                   SEQUENCE {
            criticalExtensions              SEQUENCE {}
        }
    }
}

HandoverFromUTRANCommand-GERANIu-r5-IEs ::= SEQUENCE {
    -- User equipment IEs
        activationTime                  ActivationTime                      OPTIONAL,
    -- Measurement IEs
        frequency-Band                  Frequency-Band,
    -- Other IEs
        geranIu-Message                     CHOICE {
            -- In the single-GERANIu-Message case the following rules apply:
            -- 1> the GERAN Iu message directly follows the basic production; the final padding that
            --    results when PER encoding the abstract syntax value is removed prior to appending
            --    the GERAN Iu message.
            -- 2> the RRC message excluding the GERAN Iu part does not contain a length determinant;
--    there is no explicit parameter indicating the size of the included GERAN Iu
--    message.
```

```
            -- 3> depending on need, final padding (all '0's) is added to ensure the final result
            --    comprises a full number of octets.
            single-GERANIu-Message          SEQUENCE {},
            geranIu-MessageList             SEQUENCE {
                geranIu-Messages                GERANIu-MessageList
            }
        }
}

HandoverFromUTRANCommand-CDMA2000 ::= CHOICE {
    r3                          SEQUENCE {
        handoverFromUTRANCommand-CDMA2000-r3
                                        HandoverFromUTRANCommand-CDMA2000-r3-IEs,
        laterNonCriticalExtensions          SEQUENCE {
            -- Container for additional R99 extensions
            handoverFromUTRANCommand-CDMA2000-r3-add-ext
                                                BIT STRING      OPTIONAL,
            nonCriticalExtensions               SEQUENCE {}     OPTIONAL
        }   OPTIONAL
    },
    later-than-r3               SEQUENCE {
        rrc-TransactionIdentifier       RRC-TransactionIdentifier,
        criticalExtensions              SEQUENCE {}
    }
}

HandoverFromUTRANCommand-CDMA2000-r3-IEs ::= SEQUENCE {
    -- User equipment IEs
        rrc-TransactionIdentifier       RRC-TransactionIdentifier,
        activationTime                  ActivationTime                      OPTIONAL,
    -- Radio bearer IEs
        toHandoverRAB-Info              RAB-Info                            OPTIONAL,
    -- Other IEs
        cdma2000-MessageList            CDMA2000-MessageList
}

-- **************************************************
--
-- HANDOVER FROM UTRAN FAILURE
--
-- **************************************************

HandoverFromUTRANFailure ::= SEQUENCE {
    -- User equipment IEs
        rrc-TransactionIdentifier       RRC-TransactionIdentifier,
    -- Other IEs
        interRAT-HO-FailureCause        InterRAT-HO-FailureCause            OPTIONAL,
        -- In case the interRATMessage to be transferred is for GERAN Iu mode, the
        -- message should be placed in the HandoverFromUtranFailure-v590ext-IEs
        -- non-critical extension container.
        interRATMessage                 CHOICE {
            gsm                             SEQUENCE {
                gsm-MessageList                     GSM-MessageList
            },
            cdma2000                        SEQUENCE {
                cdma2000-MessageList            CDMA2000-MessageList
            }
        }               OPTIONAL,
        laterNonCriticalExtensions      SEQUENCE {
            -- Container for additional R99 extensions
            handoverFromUTRANFailure-r3-add-ext     BIT STRING  OPTIONAL,
            v590NonCriticalExtensions       SEQUENCE {
                handoverFromUTRANFailure-v590ext    HandoverFromUtranFailure-v590ext-IEs,
                nonCriticalExtensions           SEQUENCE {}     OPTIONAL
            }   OPTIONAL
        }   OPTIONAL
}

HandoverFromUtranFailure-v590ext-IEs ::= SEQUENCE {
    geranIu-MessageList                 GERANIu-MessageList         OPTIONAL
}

-- **************************************************
--
-- INTER RAT HANDOVER INFO
--
-- **************************************************
```

```
InterRATHandoverInfo ::= SEQUENCE {
    -- This structure is defined for historical reasons, backward compatibility with 44.018
    predefinedConfigStatusList      CHOICE {
        absent                          NULL,
        present                         PredefinedConfigStatusList
    },
    uE-SecurityInformation          CHOICE {
        absent                          NULL,
        present                         UE-SecurityInformation
    },
    ue-CapabilityContainer          CHOICE {
        absent                          NULL,
        -- present is an octet aligned string containing IE UE-RadioAccessCapabilityInfo
        present                         OCTET STRING (SIZE (0..63))
    },
    -- Non critical extensions
    v390NonCriticalExtensions       CHOICE {
        absent                          NULL,
        present                         SEQUENCE {
            interRATHandoverInfo-v390ext    InterRATHandoverInfo-v390ext-IEs,
            v3a0NonCriticalExtensions       SEQUENCE  {
                interRATHandoverInfo-v3a0ext    InterRATHandoverInfo-v3a0ext-IEs,
                laterNonCriticalExtensions      SEQUENCE {
                    interRATHandoverInfo-v3d0ext    InterRATHandoverInfo-v3d0ext-IEs,
                    -- Container for additional R99 extensions
                    interRATHandoverInfo-r3-add-ext     BIT STRING
                                (CONTAINING InterRATHandoverInfo-r3-add-ext-IEs)    OPTIONAL,
                    v3g0NonCriticalExtensions           SEQUENCE {
                        interRATHandoverInfo-v3g0ext    InterRATHandoverInfo-v3g0ext-IEs,
                        v4b0NonCriticalExtensions       SEQUENCE {
                            interRATHandoverInfo-v4b0ext    InterRATHandoverInfo-v4b0ext-IEs,
                            v4d0NonCriticalExtensions       SEQUENCE {
                                interRATHandoverInfo-v4d0ext    InterRATHandoverInfo-v4d0ext-IEs,
                                -- Reserved for future non critical extension
                                v590NonCriticalExtensions       SEQUENCE {
                                    interRATHandoverInfo-v590ext
                                                                    InterRATHandoverInfo-v590ext-IEs,
                                    v690NonCriticalExtensions       SEQUENCE {
                                        interRATHandoverInfo-v690ext
                                                                    InterRATHandoverInfo-v690ext-IEs,
                                        v7xyNonCriticalExtensions       SEQUENCE {
                                            interRATHandoverInfo-v7xyext
                                                                    InterRATHandoverInfo-v7xyext-IEs,
                                            nonCriticalExtensions           SEQUENCE {} OPTIONAL
                                        }   OPTIONAL
                                    }   OPTIONAL
                                }   OPTIONAL
                            }   OPTIONAL
                        }   OPTIONAL
                    }   OPTIONAL
                }   OPTIONAL
            }   OPTIONAL
        }
    }
}

InterRATHandoverInfo-v390ext-IEs ::= SEQUENCE {
    -- User equipment IEs
        ue-RadioAccessCapability-v380ext    UE-RadioAccessCapability-v380ext        OPTIONAL,
        dl-PhysChCapabilityFDD-v380ext      DL-PhysChCapabilityFDD-v380ext
}

InterRATHandoverInfo-v3a0ext-IEs ::= SEQUENCE {
    -- User equipment IEs
        ue-RadioAccessCapability-v3a0ext    UE-RadioAccessCapability-v3a0ext        OPTIONAL
}

InterRATHandoverInfo-v3d0ext-IEs ::= SEQUENCE {
    -- User equipment IEs
        uESpecificBehaviourInformation1interRAT     UESpecificBehaviourInformation1interRAT
    OPTIONAL
}

InterRATHandoverInfo-v3g0ext-IEs ::= SEQUENCE {
    -- User equipment IEs
        ue-RadioAccessCapability-v3g0ext    UE-RadioAccessCapability-v3g0ext        OPTIONAL
}
```

```
InterRATHandoverInfo-r3-add-ext-IEs ::= SEQUENCE {
        interRATHandoverInfo-v690ext1       InterRATHandoverInfo-v690ext1-IEs,
        nonCriticalExtensions               SEQUENCE {}     OPTIONAL
}

InterRATHandoverInfo-v4b0ext-IEs ::= SEQUENCE {
    -- User equipment IEs
        accessStratumReleaseIndicator       AccessStratumReleaseIndicator
}

InterRATHandoverInfo-v4d0ext-IEs ::= SEQUENCE {
    -- User equipment IEs
    tdd128-RF-Capability                RadioFrequencyBandTDDList       OPTIONAL
}

InterRATHandoverInfo-v590ext-IEs ::= SEQUENCE {
    -- User equipment IEs
        predefinedConfigStatusListComp      PredefinedConfigStatusListComp          OPTIONAL,
        ue-RadioAccessCapabilityComp        UE-RadioAccessCapabilityComp            OPTIONAL
}

InterRATHandoverInfo-v690ext1-IEs ::= SEQUENCE {
    -- User equipment IEs
        ue-RadioAccessCapability-v650ext        UE-RadioAccessCapability-v650ext    OPTIONAL
}

InterRATHandoverInfo-v690ext-IEs ::= SEQUENCE {
    -- User equipment IEs
        ue-SecurityInformation2             UE-SecurityInformation2                 OPTIONAL,
        ue-RadioAccessCapabilityComp        UE-RadioAccessCapabilityComp-ext        OPTIONAL,
        ue-RadioAccessCapabilityComp2       UE-RadioAccessCapabilityComp2
}

InterRATHandoverInfo-v7xyext-IEs ::= SEQUENCE {
        ue-RadioAccessCapability-v7xyext    UE-RadioAccessCapability-v7xyext        OPTIONAL,
        ue-RadioAccessCapabilityComp        UE-RadioAccessCapabilityComp-r7         OPTIONAL
}

-- **************************************************
--
-- MEASUREMENT CONTROL
--
-- **************************************************

MeasurementControl ::= CHOICE {
    -- The Rel-4 functionality of UE Positioning OTDOA AssistanceData TDD is only available
    -- in the later-than-r3 branch of this message (i.e. through the use of the IE
    -- ue-Positioning-OTDOA-AssistanceData-r4)
    r3                              SEQUENCE {
        measurementControl-r3           MeasurementControl-r3-IEs,
        v390nonCriticalExtensions       SEQUENCE {
            measurementControl-v390ext      MeasurementControl-v390ext,
            v3a0NonCriticalExtensions           SEQUENCE {
                measurementControl-v3a0ext          MeasurementControl-v3a0ext,
                laterNonCriticalExtensions      SEQUENCE {
                    -- Container for additional R99 extensions
                    measurementControl-r3-add-ext       BIT STRING  OPTIONAL,
                    v4b0NonCriticalExtensions           SEQUENCE{
                        -- The content of the v4b0 non-critical extension has been removed. If sent
                        -- to a UE of AS release 4, the UE behaviour is unspecified. A UE of AS
                        -- release 5 onward shall comply with the v4b0 and later extensions in this
                        -- branch of the message.
                        v590NonCriticalExtensions       SEQUENCE {
                            measurementControl-v590ext      MeasurementControl-v590ext-IEs,
                            v5b0NonCriticalExtensions       SEQUENCE {
                                measurementControl-v5b0ext      MeasurementControl-v5b0ext-IEs,
                                nonCriticalExtensions           SEQUENCE {}     OPTIONAL
                            }                                   OPTIONAL
                        }                                   OPTIONAL
                    }                                   OPTIONAL
                }                                   OPTIONAL
            }                                   OPTIONAL
        }                                   OPTIONAL
    },
    later-than-r3                   SEQUENCE {
        rrc-TransactionIdentifier       RRC-TransactionIdentifier,
        criticalExtensions              CHOICE {
            r4                              SEQUENCE {
```

```
                measurementControl-r4           MeasurementControl-r4-IEs,
                v4d0NonCriticalExtensions           SEQUENCE {
                    -- Container for adding non critical extensions after freezing REL-5
                    measurementControl-r4-add-ext       BIT STRING      OPTIONAL,
                    v590NonCriticalExtensions       SEQUENCE{
                        measurementControl-v590ext      MeasurementControl-v590ext-IEs,
                        v5b0NonCriticalExtensions       SEQUENCE {
                            measurementControl-v5b0ext      MeasurementControl-v5b0ext-IEs,

                            v7xyNonCriticalExtensions   SEQUENCE {
                                measurementControl-v7xy     MeasurementControl-v7xyext-IEs,
                                nonCriticalExtensions       SEQUENCE {}     OPTIONAL
                            }   OPTIONAL
                        }   OPTIONAL
                    }   OPTIONAL
                }   OPTIONAL
            },
            -- Most significant part of "RRC transaction identifier" (MSP),
            -- "RRC transaction identifier" = rrc-TransactionIdentifier-MSP-r6-ext * 4 +
            -- rrc-TransactionIdentifier
            rrc-TransactionIdentifier-MSP-r6-ext        RRC-TransactionIdentifier,
            criticalExtensions              CHOICE {
                r6                              SEQUENCE {
                    measurementControl-r6           MeasurementControl-r6-IEs,
                    nonCriticalExtensions           SEQUENCE {}     OPTIONAL
                },
                criticalExtensions              SEQUENCE {}
            }
        }
    }
}

MeasurementControl-r3-IEs ::= SEQUENCE {
    -- User equipment IEs
        rrc-TransactionIdentifier       RRC-TransactionIdentifier,
    -- Measurement IEs
        measurementIdentity     MeasurementIdentity,
        -- TABULAR: The measurement type is included in MeasurementCommand.
        measurementCommand              MeasurementCommand,
        measurementReportingMode        MeasurementReportingMode            OPTIONAL,
        additionalMeasurementList       AdditionalMeasurementID-List        OPTIONAL,
    -- Physical channel IEs
        dpch-CompressedModeStatusInfo   DPCH-CompressedModeStatusInfo       OPTIONAL
}

MeasurementControl-v390ext ::= SEQUENCE {
        ue-Positioning-Measurement-v390ext      UE-Positioning-Measurement-v390ext  OPTIONAL
}

MeasurementControl-v3a0ext ::= SEQUENCE {
    sfn-Offset-Validity             SFN-Offset-Validity     OPTIONAL
}

MeasurementControl-r4-IEs ::= SEQUENCE {
    -- Measurement IEs
        measurementIdentity     MeasurementIdentity,
        -- TABULAR: The measurement type is included in measurementCommand.
        measurementCommand              MeasurementCommand-r4,
        measurementReportingMode        MeasurementReportingMode            OPTIONAL,
        additionalMeasurementList       AdditionalMeasurementID-List        OPTIONAL,
    -- Physical channel IEs
        dpch-CompressedModeStatusInfo   DPCH-CompressedModeStatusInfo       OPTIONAL
}

MeasurementControl-v590ext-IEs ::= SEQUENCE {
    measurementCommand-v590ext          CHOICE {
        -- the choice 'intra-frequency' shall be used for the case of intra-frequency measurement,
        -- as well as when intra-frequency events are configured for inter-frequency measurement
        intra-frequency                     Intra-FreqEventCriteriaList-v590ext,
        inter-frequency                     Inter-FreqEventCriteriaList-v590ext
    }       OPTIONAL,
    intraFreqReportingCriteria-1b-r5        IntraFreqReportingCriteria-1b-r5    OPTIONAL,
    intraFreqEvent-1d-r5                    IntraFreqEvent-1d-r5                OPTIONAL,
    -- most significant part of "RRC transaction identifier" (MSP),
    -- "RRC transaction identifier" = rrc-TransactionIdentifier-MSP-v590ext * 4 +
    -- rrc-TransactionIdentifier
    rrc-TransactionIdentifier-MSP-v590ext   RRC-TransactionIdentifier
}
```

```
MeasurementControl-v5b0ext-IEs ::=  SEQUENCE {
    interRATCellInfoIndication          InterRATCellInfoIndication          OPTIONAL
}

MeasurementControl-r6-IEs ::= SEQUENCE {
    -- Measurement IEs
        measurementIdentity     MeasurementIdentity,
        -- TABULAR: The measurement type is included in measurementCommand.
        measurementCommand              MeasurementCommand-r6,
        measurementReportingMode        MeasurementReportingMode            OPTIONAL,
        additionalMeasurementList       AdditionalMeasurementID-List        OPTIONAL,
    -- Physical channel IEs
        dpch-CompressedModeStatusInfo   DPCH-CompressedModeStatusInfo       OPTIONAL
}

MeasurementControl-v7xyext-IEs ::=  SEQUENCE {
    ue-Positioning-Measurement-v7xyext      UE-Positioning-Measurement-v7xyext
}

-- **************************************************
--
-- MEASUREMENT CONTROL FAILURE
--
-- **************************************************

MeasurementControlFailure ::= SEQUENCE {
    -- User equipment IEs
        rrc-TransactionIdentifier       RRC-TransactionIdentifier,
        failureCause                    FailureCauseWithProtErr,
        laterNonCriticalExtensions      SEQUENCE {
            -- Container for additional R99 extensions
            measurementControlFailure-r3-add-ext        BIT STRING      OPTIONAL,
            v590NonCriticalExtensions       SEQUENCE {
                measurementControlFailure-v590ext       MeasurementControlFailure-v590ext-IEs,
                nonCriticalExtensions           SEQUENCE {}     OPTIONAL
            }   OPTIONAL
        }   OPTIONAL
}

MeasurementControlFailure-v590ext-IEs ::= SEQUENCE {
    -- most significant part of "RRC transaction identifier" (MSP),
    -- "RRC transaction identifier" = rrc-TransactionIdentifier-MSP-v590ext * 4 +
    -- rrc-TransactionIdentifier
    -- If the rrc-TransactionIdentifier-MSP-v590ext was not received in the MEASUREMENT CONTROL
    -- message, then the rrc-TransactionIdentifier-MSP-v590ext shall be set to zero
    rrc-TransactionIdentifier-MSP-v590ext   RRC-TransactionIdentifier
}

-- **************************************************
--
-- MEASUREMENT REPORT
--
-- **************************************************

MeasurementReport ::= SEQUENCE {
    -- Measurement IEs
        measurementIdentity     MeasurementIdentity,
        measuredResults                 MeasuredResults                     OPTIONAL,
        measuredResultsOnRACH           MeasuredResultsOnRACH               OPTIONAL,
        additionalMeasuredResults       MeasuredResultsList                 OPTIONAL,
        eventResults                    EventResults                        OPTIONAL,
    -- Non-critical extensions
        v390nonCriticalExtensions           SEQUENCE {
            measurementReport-v390ext       MeasurementReport-v390ext,
            laterNonCriticalExtensions      SEQUENCE {
                -- Container for additional R99 extensions
                measurementReport-r3-add-ext        BIT STRING      OPTIONAL,
                v4b0NonCriticalExtensions       SEQUENCE {
                    measurementReport-v4b0ext       MeasurementReport-v4b0ext-IEs,
                    -- Extension mechanism for non-Rel4 information
                    v590NonCriticalExtensions   SEQUENCE {
                        measurementReport-v590ext       MeasurementReport-v590ext-IEs,
                        v5b0NonCriticalExtensions       SEQUENCE {
                            measurementReport-v5b0ext       MeasurementReport-v5b0ext-IEs,
                            v690NonCriticalExtensions           SEQUENCE {
                                measurementReport-v690ext       MeasurementReport-v690ext-IEs,
```

```
                                v7xyNonCriticalExtensions       SEQUENCE {
                                    measurementReport-v7xyext       MeasurementReport-v7xyext-IEs,
                                    nonCriticalExtensions           SEQUENCE {}             OPTIONAL
                                }       OPTIONAL
                            }       OPTIONAL
                        }       OPTIONAL
                    }       OPTIONAL
                }       OPTIONAL
            }       OPTIONAL
        }       OPTIONAL
}

MeasurementReport-v390ext ::= SEQUENCE {
        measuredResults-v390ext         MeasuredResults-v390ext             OPTIONAL
}

MeasurementReport-v4b0ext-IEs ::= SEQUENCE {
    interFreqEventResults-LCR       InterFreqEventResults-LCR-r4-ext        OPTIONAL,
    -- additionalMeasuredResults-LCR shall contain measurement results and additional measurement
    -- results list.
    additionalMeasuredResults-LCR   MeasuredResultsList-LCR-r4-ext          OPTIONAL,
    gsmOTDreferenceCell             PrimaryCPICH-Info                       OPTIONAL
}

MeasurementReport-v590ext-IEs ::= SEQUENCE {
    measuredResults-v590ext             MeasuredResults-v590ext             OPTIONAL
}

MeasurementReport-v5b0ext-IEs ::=   SEQUENCE {
    interRATCellInfoIndication          InterRATCellInfoIndication          OPTIONAL
}

MeasurementReport-v690ext-IEs ::= SEQUENCE {
    measuredResultsOnRACHinterFreq      MeasuredResultsOnRACHinterFreq      OPTIONAL
}

MeasurementReport-v7xyext-IEs ::= SEQUENCE {
    velocityEstimate                    VelocityEstimate                    OPTIONAL,
    ue-InternalMeasuredResults          UE-InternalMeasuredResults-r7       OPTIONAL
}

-- **************************************************
--
-- PAGING TYPE 1
--
-- **************************************************

PagingType1 ::= SEQUENCE {
    -- User equipment IEs
        pagingRecordList                PagingRecordList                    OPTIONAL,
    -- Other IEs
        bcch-ModificationInfo           BCCH-ModificationInfo               OPTIONAL,
        laterNonCriticalExtensions      SEQUENCE {
            -- Container for additional R99 extensions
            pagingType1-r3-add-ext          BIT STRING      OPTIONAL,
            v590NonCriticalExtensions       SEQUENCE {
                pagingType1-v590ext             PagingType1-v590ext-IEs,
                nonCriticalExtensions           SEQUENCE {}     OPTIONAL
            }   OPTIONAL
        }   OPTIONAL
}

PagingType1-v590ext-IEs ::= SEQUENCE {
    -- User equipment IEs
        pagingRecord2List               PagingRecord2List-r5                OPTIONAL
}

-- **************************************************
--
-- PAGING TYPE 2
--
-- **************************************************

PagingType2 ::= SEQUENCE {
    -- User equipment IEs
        rrc-TransactionIdentifier       RRC-TransactionIdentifier,
        pagingCause                     PagingCause,
    -- Core network IEs
```

```
        cn-DomainIdentity               CN-DomainIdentity,
        pagingRecordTypeID              PagingRecordTypeID,
        laterNonCriticalExtensions      SEQUENCE {
            -- Container for additional R99 extensions
            pagingType2-r3-add-ext          BIT STRING      OPTIONAL,
            nonCriticalExtensions           SEQUENCE {}     OPTIONAL
        }   OPTIONAL
}

-- **************************************************
--
-- PHYSICAL CHANNEL RECONFIGURATION
--
-- **************************************************

PhysicalChannelReconfiguration ::= CHOICE {
    r3                              SEQUENCE {
        physicalChannelReconfiguration-r3
                                        PhysicalChannelReconfiguration-r3-IEs,
        v3a0NonCriticalExtensions           SEQUENCE {
            physicalChannelReconfiguration-v3a0ext      PhysicalChannelReconfiguration-v3a0ext,
            laterNonCriticalExtensions      SEQUENCE {
                -- Container for additional R99 extensions
                physicalChannelReconfiguration-r3-add-ext           BIT STRING      OPTIONAL,
                v4b0NonCriticalExtenstions          SEQUENCE {
                    physicalChannelReconfiguration-v4b0ext
                                                PhysicalChannelReconfiguration-v4b0ext-IEs,
                    v590NonCriticalExtenstions          SEQUENCE {
                        physicalChannelReconfiguration-v590ext
                                                PhysicalChannelReconfiguration-v590ext-IEs,
                        v690NonCriticalExtensions       SEQUENCE {
                            physicalChannelReconfiguration-v690ext
                                                PhysicalChannelReconfiguration-v690ext-IEs,
                            nonCriticalExtensions                   SEQUENCE {} OPTIONAL
                        }   OPTIONAL
                    }   OPTIONAL
                }   OPTIONAL
            }   OPTIONAL
        }   OPTIONAL
    },
    later-than-r3                   SEQUENCE {
        rrc-TransactionIdentifier       RRC-TransactionIdentifier,
            criticalExtensions              CHOICE {
            r4                              SEQUENCE {
                physicalChannelReconfiguration-r4
                                            PhysicalChannelReconfiguration-r4-IEs,
                v4d0NonCriticalExtensions           SEQUENCE {
                    -- Container for adding non critical extensions after freezing REL-5
                    physicalChannelReconfiguration-r4-add-ext       BIT STRING      OPTIONAL,
                    v590NonCriticalExtenstions          SEQUENCE {
                        physicalChannelReconfiguration-v590ext
                                                PhysicalChannelReconfiguration-v590ext-IEs,
                        v690NonCriticalExtensions       SEQUENCE {
                            physicalChannelReconfiguration-v690ext
                                                PhysicalChannelReconfiguration-v690ext-IEs,
                            nonCriticalExtensions           SEQUENCE {}     OPTIONAL
                        }   OPTIONAL
                    }   OPTIONAL
                }   OPTIONAL
            },
            criticalExtensions              CHOICE {
                r5                              SEQUENCE {
                    physicalChannelReconfiguration-r5
                                                PhysicalChannelReconfiguration-r5-IEs,
                    -- Container for adding non critical extensions after freezing REL-6
                    physicalChannelReconfiguration-r5-add-ext       BIT STRING      OPTIONAL,
                    v690NonCriticalExtensions       SEQUENCE {
                        physicalChannelReconfiguration-v690ext
                                                PhysicalChannelReconfiguration-v690ext-IEs,
                        nonCriticalExtensions           SEQUENCE {}     OPTIONAL
                    }   OPTIONAL
                },
                criticalExtensions              CHOICE {
                    r6                              SEQUENCE {
                        physicalChannelReconfiguration-r6
                                                PhysicalChannelReconfiguration-r6-IEs,
                        -- Container for adding non critical extensions after freezing REL-7
                        physicalChannelReconfiguration-r6-add-ext       BIT STRING      OPTIONAL,
```

```
                    nonCriticalExtensions           SEQUENCE {}     OPTIONAL
                },
                criticalExtensions              CHOICE {
                    r7                              SEQUENCE {
                        physicalChannelReconfiguration-r7
                                                    PhysicalChannelReconfiguration-r7-IEs,
                        -- Container for adding non critical extensions after freezing REL-8
                        physicalChannelReconfiguration-r7-add-ext   BIT STRING  OPTIONAL,
                        nonCriticalExtensions                       SEQUENCE {}     OPTIONAL
                    },
                    criticalExtensions              SEQUENCE {}
                }
            }
        }
    }
}

PhysicalChannelReconfiguration-r3-IEs ::= SEQUENCE {
    -- User equipment IEs
        rrc-TransactionIdentifier       RRC-TransactionIdentifier,
        integrityProtectionModeInfo     IntegrityProtectionModeInfo         OPTIONAL,
        cipheringModeInfo               CipheringModeInfo                   OPTIONAL,
        activationTime                  ActivationTime                      OPTIONAL,
        new-U-RNTI                      U-RNTI                              OPTIONAL,
        new-C-RNTI                      C-RNTI                              OPTIONAL,
        rrc-StateIndicator              RRC-StateIndicator,
        utran-DRX-CycleLengthCoeff      UTRAN-DRX-CycleLengthCoefficient    OPTIONAL,
    -- Core network IEs
        cn-InformationInfo              CN-InformationInfo                  OPTIONAL,
    -- UTRAN mobility IEs
        ura-Identity                    URA-Identity                        OPTIONAL,
    -- Radio bearer IEs
        dl-CounterSynchronisationInfo   DL-CounterSynchronisationInfo       OPTIONAL,
    -- Physical channel IEs
        frequencyInfo                   FrequencyInfo                       OPTIONAL,
        maxAllowedUL-TX-Power           MaxAllowedUL-TX-Power               OPTIONAL,
        -- Note: the reference to CPCH in the element name below is incorrect. The name is not
        -- changed to keep it aligned with R99.
        ul-ChannelRequirement           UL-ChannelRequirementWithCPCH-SetID     OPTIONAL,
        modeSpecificInfo                CHOICE {
            fdd                             SEQUENCE {
                -- dummy is not used in this version of specification, it should
                -- not be sent and if received it should be ignored.
                dummy                           DL-PDSCH-Information        OPTIONAL
            },
            tdd                             NULL
        },
        dl-CommonInformation            DL-CommonInformation                OPTIONAL,
        dl-InformationPerRL-List        DL-InformationPerRL-List            OPTIONAL
}

PhysicalChannelReconfiguration-v3a0ext ::= SEQUENCE {
    -- The IE 'new-DSCH-RNTI' should not be included in FDD mode, and if received the UE behaviour
    -- is unspecified
    new-DSCH-RNTI                   DSCH-RNTI                           OPTIONAL
}

PhysicalChannelReconfiguration-v4b0ext-IEs ::= SEQUENCE {
    -- Physical channel IEs
        -- dummy is not used in this version of the specification, it should
        -- not be sent and if received it should be ignored.
        dummy                           SSDT-UL                             OPTIONAL,
        -- The order of the RLs in IE cell-id-PerRL-List is the same as
        -- in IE DL-InformationPerRL-List included in this message
        cell-id-PerRL-List              CellIdentity-PerRL-List             OPTIONAL
}

PhysicalChannelReconfiguration-v590ext-IEs ::= SEQUENCE {
    -- Physical channel IEs
        dl-TPC-PowerOffsetPerRL-List    DL-TPC-PowerOffsetPerRL-List        OPTIONAL
}

PhysicalChannelReconfiguration-r4-IEs ::= SEQUENCE {
    -- User equipment IEs
        integrityProtectionModeInfo     IntegrityProtectionModeInfo         OPTIONAL,
        cipheringModeInfo               CipheringModeInfo                   OPTIONAL,
        activationTime                  ActivationTime                      OPTIONAL,
```

```
        new-U-RNTI                      U-RNTI                              OPTIONAL,
        new-C-RNTI                      C-RNTI                              OPTIONAL,
        -- The IE 'new-DSCH-RNTI' should not be included in FDD mode, and if received
        -- the UE behaviour is unspecified
        new-DSCH-RNTI                   DSCH-RNTI                           OPTIONAL,
        rrc-StateIndicator              RRC-StateIndicator,
        utran-DRX-CycleLengthCoeff      UTRAN-DRX-CycleLengthCoefficient    OPTIONAL,
    -- Core network IEs
        cn-InformationInfo              CN-InformationInfo                  OPTIONAL,
    -- UTRAN mobility IEs
        ura-Identity                    URA-Identity                        OPTIONAL,
    -- Radio bearer IEs
        dl-CounterSynchronisationInfo   DL-CounterSynchronisationInfo       OPTIONAL,
    -- Physical channel IEs
        frequencyInfo                   FrequencyInfo                       OPTIONAL,
        maxAllowedUL-TX-Power           MaxAllowedUL-TX-Power               OPTIONAL,
        -- Note: the reference to CPCH in the element name below is incorrect. The name is not
        -- changed to keep it aligned with R99.
        ul-ChannelRequirement           UL-ChannelRequirementWithCPCH-SetID-r4  OPTIONAL,
        modeSpecificInfo                CHOICE {
            fdd                             SEQUENCE {
                -- dummy is not used in this version of specification, it should
                -- not be sent and if received it should be ignored.
                dummy                           DL-PDSCH-Information        OPTIONAL
            },
            tdd                             NULL
        },
        dl-CommonInformation            DL-CommonInformation-r4             OPTIONAL,
        dl-InformationPerRL-List        DL-InformationPerRL-List-r4         OPTIONAL
}

PhysicalChannelReconfiguration-r5-IEs ::= SEQUENCE {
    -- User equipment IEs
        integrityProtectionModeInfo     IntegrityProtectionModeInfo         OPTIONAL,
        cipheringModeInfo               CipheringModeInfo                   OPTIONAL,
        activationTime                  ActivationTime                      OPTIONAL,
        new-U-RNTI                      U-RNTI                              OPTIONAL,
        new-C-RNTI                      C-RNTI                              OPTIONAL,
        -- The IE 'new-DSCH-RNTI' should not be included in FDD mode, and if received
        -- the UE behaviour is unspecified
        new-DSCH-RNTI                   DSCH-RNTI                           OPTIONAL,
        new-H-RNTI                      H-RNTI                              OPTIONAL,
        rrc-StateIndicator              RRC-StateIndicator,
        utran-DRX-CycleLengthCoeff      UTRAN-DRX-CycleLengthCoefficient    OPTIONAL,
    -- Core network IEs
        cn-InformationInfo              CN-InformationInfo                  OPTIONAL,
    -- UTRAN mobility IEs
        ura-Identity                    URA-Identity                        OPTIONAL,
    -- Radio bearer IEs
        dl-CounterSynchronisationInfo   DL-CounterSynchronisationInfo-r5    OPTIONAL,
    -- Physical channel IEs
        frequencyInfo                   FrequencyInfo                       OPTIONAL,
        maxAllowedUL-TX-Power           MaxAllowedUL-TX-Power               OPTIONAL,
        -- Note: the reference to CPCH in the element name below is incorrect. The name is not
        -- changed to keep it aligned with R99.
        ul-ChannelRequirement           UL-ChannelRequirementWithCPCH-SetID-r5  OPTIONAL,
        modeSpecificInfo                CHOICE {
            fdd                             SEQUENCE {
                -- dummy is not used in this version of specification, it should
                -- not be sent and if received it should be ignored.
                dummy                           DL-PDSCH-Information        OPTIONAL
            },
            tdd                             NULL
        },
        dl-HSPDSCH-Information          DL-HSPDSCH-Information              OPTIONAL,
        dl-CommonInformation            DL-CommonInformation-r5             OPTIONAL,
        dl-InformationPerRL-List        DL-InformationPerRL-List-r5         OPTIONAL
}

PhysicalChannelReconfiguration-r6-IEs ::= SEQUENCE {
    -- User equipment IEs
        integrityProtectionModeInfo     IntegrityProtectionModeInfo         OPTIONAL,
        cipheringModeInfo               CipheringModeInfo                   OPTIONAL,
        activationTime                  ActivationTime                      OPTIONAL,
        delayRestrictionFlag            DelayRestrictionFlag                OPTIONAL,
        new-U-RNTI                      U-RNTI                              OPTIONAL,
        new-C-RNTI                      C-RNTI                              OPTIONAL,
        -- The IE 'new-DSCH-RNTI' should not be included in FDD mode,
```

```
        -- and if received the UE behaviour is unspecified
        new-DSCH-RNTI                   DSCH-RNTI                           OPTIONAL,
        new-H-RNTI                      H-RNTI                              OPTIONAL,
        newPrimary-E-RNTI               E-RNTI                              OPTIONAL,
        newSecondary-E-RNTI             E-RNTI                              OPTIONAL,
        rrc-StateIndicator              RRC-StateIndicator,
        utran-DRX-CycleLengthCoeff      UTRAN-DRX-CycleLengthCoefficient    OPTIONAL,
    -- Core network IEs
        cn-InformationInfo              CN-InformationInfo-r6               OPTIONAL,
    -- UTRAN mobility IEs
        ura-Identity                    URA-Identity                        OPTIONAL,
    -- Radio bearer IEs
        dl-CounterSynchronisationInfo   DL-CounterSynchronisationInfo-r5    OPTIONAL,
    -- Physical channel IEs
        frequencyInfo                   FrequencyInfo                       OPTIONAL,
        maxAllowedUL-TX-Power           MaxAllowedUL-TX-Power               OPTIONAL,
        ul-DPCH-Info                    UL-DPCH-Info-r6                     OPTIONAL,
        ul-EDCH-Information             UL-EDCH-Information-r6              OPTIONAL,
        dl-HSPDSCH-Information          DL-HSPDSCH-Information-r6           OPTIONAL,
        dl-CommonInformation            DL-CommonInformation-r6             OPTIONAL,
        dl-InformationPerRL-List        DL-InformationPerRL-List-r6         OPTIONAL,
    -- MBMS IEs
        mbms-PL-ServiceRestrictInfo     MBMS-PL-ServiceRestrictInfo-r6      OPTIONAL
}

PhysicalChannelReconfiguration-v690ext-IEs ::= SEQUENCE {
    -- User Equipment IEs
        delayRestrictionFlag            DelayRestrictionFlag                OPTIONAL,
    -- Core network IEs
        primary-plmn-Identity           PLMN-Identity                       OPTIONAL,
    -- Physical channel IEs
        -- The IE harq-Preamble-Mode should not be used in the r3 and r4 versions of the message
        -- If included in the r3 or r4 version of the message, the UE should ignore the IE
        harq-Preamble-Mode              HARQ-Preamble-Mode                  OPTIONAL,
        beaconPLEst                     BEACON-PL-Est                       OPTIONAL,
        postVerificationPeriod          ENUMERATED { true }                 OPTIONAL,
        dhs-sync                        DHS-Sync                            OPTIONAL,
        timingMaintainedSynchInd        TimingMaintainedSynchInd            OPTIONAL,
    -- MBMS IEs
        mbms-PL-ServiceRestrictInfo     MBMS-PL-ServiceRestrictInfo-r6      OPTIONAL
}

PhysicalChannelReconfiguration-r7-IEs ::= SEQUENCE {
    -- User equipment IEs
        integrityProtectionModeInfo     IntegrityProtectionModeInfo         OPTIONAL,
        cipheringModeInfo               CipheringModeInfo                   OPTIONAL,
        activationTime                  ActivationTime                      OPTIONAL,
        delayRestrictionFlag            DelayRestrictionFlag                OPTIONAL,
        new-U-RNTI                      U-RNTI                              OPTIONAL,
        new-C-RNTI                      C-RNTI                              OPTIONAL,
        -- The IE 'new-DSCH-RNTI' should not be included in FDD mode,
        -- and if received the UE behaviour is unspecified
        new-DSCH-RNTI                   DSCH-RNTI                           OPTIONAL,
        new-H-RNTI                      H-RNTI                              OPTIONAL,
        newPrimary-E-RNTI               E-RNTI                              OPTIONAL,
        newSecondary-E-RNTI             E-RNTI                              OPTIONAL,
        rrc-StateIndicator              RRC-StateIndicator,
        utran-DRX-CycleLengthCoeff      UTRAN-DRX-CycleLengthCoefficient    OPTIONAL,
    -- Core network IEs
        cn-InformationInfo              CN-InformationInfo-r6               OPTIONAL,
    -- UTRAN mobility IEs
        ura-Identity                    URA-Identity                        OPTIONAL,
    -- Radio bearer IEs
        dl-CounterSynchronisationInfo   DL-CounterSynchronisationInfo-r5    OPTIONAL,
    -- Physical channel IEs
        frequencyInfo                   FrequencyInfo                       OPTIONAL,
        maxAllowedUL-TX-Power           MaxAllowedUL-TX-Power               OPTIONAL,
        ul-DPCH-Info                    UL-DPCH-Info-r7                     OPTIONAL,
        ul-EDCH-Information             UL-EDCH-Information-r6              OPTIONAL,
        dl-HSPDSCH-Information          DL-HSPDSCH-Information-r7           OPTIONAL,
        dl-CommonInformation            DL-CommonInformation-r7             OPTIONAL,
        dl-InformationPerRL-List        DL-InformationPerRL-List-r7         OPTIONAL,
    -- MBMS IEs
        mbms-PL-ServiceRestrictInfo     MBMS-PL-ServiceRestrictInfo-r6      OPTIONAL
}


-- **************************************************
```

```
--
-- PHYSICAL CHANNEL RECONFIGURATION COMPLETE
--
-- **************************************************

PhysicalChannelReconfigurationComplete ::= SEQUENCE {
    -- User equipment IEs
        rrc-TransactionIdentifier       RRC-TransactionIdentifier,
        ul-IntegProtActivationInfo      IntegrityProtActivationInfo         OPTIONAL,
        -- TABULAR: UL-TimingAdvance is applicable for TDD mode only.
        ul-TimingAdvance                UL-TimingAdvance                    OPTIONAL,
    -- Radio bearer IEs
        count-C-ActivationTime          ActivationTime                      OPTIONAL,
        -- dummy is not used in this version of the specification and
        -- it should be ignored by the receiver.
        dummy                           RB-ActivationTimeInfoList           OPTIONAL,
        ul-CounterSynchronisationInfo   UL-CounterSynchronisationInfo       OPTIONAL,
        laterNonCriticalExtensions      SEQUENCE {
            -- Container for additional R99 extensions
            physicalChannelReconfigurationComplete-r3-add-ext       BIT STRING      OPTIONAL,
            v7xyNonCriticalExtensions       SEQUENCE {
                physicalChannelReconfigurationComplete-v7xyext
                                PhysicalChannelReconfigurationComplete-v7xyext-IEs,
                nonCriticalExtensions           SEQUENCE {}     OPTIONAL
            }   OPTIONAL
        }   OPTIONAL
}

PhysicalChannelReconfigurationComplete-v7xyext-IEs ::=  SEQUENCE {
        ul-TimingAdvance-VHCR           UL-TimingAdvance-VHCR               OPTIONAL
}

-- **************************************************
--
-- PHYSICAL CHANNEL RECONFIGURATION FAILURE
--
-- **************************************************

PhysicalChannelReconfigurationFailure ::= SEQUENCE {
    -- User equipment IEs
        rrc-TransactionIdentifier       RRC-TransactionIdentifier           OPTIONAL,
        failureCause                    FailureCauseWithProtErr,
        laterNonCriticalExtensions      SEQUENCE {
            -- Container for additional R99 extensions
            physicalChannelReconfigurationFailure-r3-add-ext        BIT STRING      OPTIONAL,
            nonCriticalExtensions           SEQUENCE {}     OPTIONAL
        }   OPTIONAL
}

-- **************************************************
--
-- PHYSICAL SHARED CHANNEL ALLOCATION (TDD only)
--
-- **************************************************

PhysicalSharedChannelAllocation ::= CHOICE {
    r3                              SEQUENCE {
        physicalSharedChannelAllocation-r3
                                    PhysicalSharedChannelAllocation-r3-IEs,
        laterNonCriticalExtensions      SEQUENCE {
            -- Container for additional R99 extensions
            physicalSharedChannelAllocation-r3-add-ext      BIT STRING      OPTIONAL,
            nonCriticalExtensions           SEQUENCE {} OPTIONAL
        }   OPTIONAL
    },
    later-than-r3                   SEQUENCE {
        dsch-RNTI                       DSCH-RNTI                           OPTIONAL,
        rrc-TransactionIdentifier       RRC-TransactionIdentifier,
        criticalExtensions              CHOICE {
            r4                              SEQUENCE {
                physicalSharedChannelAllocation-r4
                                            PhysicalSharedChannelAllocation-r4-IEs,
                v4d0NonCriticalExtensions       SEQUENCE {
                    -- Container for adding non critical extensions after freezing REL-5
                    physicalSharedChannelAllocation-r4-add-ext      BIT STRING      OPTIONAL,
                    v690NonCriticalExtensions       SEQUENCE {
                        physicalSharedChannelAllocation-v690ext
                                                    PhysicalSharedChannelAllocation-v690ext-IEs,
```

```
                        v7xyNonCriticalExtensions       SEQUENCE {
                            physicalSharedChannelAllocation-v7xyext
                                                            PhysicalSharedChannelAllocation-v7xyext-IEs,
                            nonCriticalExtensions           SEQUENCE {}     OPTIONAL
                        }       OPTIONAL
                    }       OPTIONAL
                }       OPTIONAL
            },
            criticalExtensions              SEQUENCE {}
        }
    }
}

PhysicalSharedChannelAllocation-r3-IEs ::= SEQUENCE {
    -- TABULAR: Integrity protection shall not be performed on this message.
    -- User equipment IEs
        dsch-RNTI                       DSCH-RNTI                           OPTIONAL,
        rrc-TransactionIdentifier       RRC-TransactionIdentifier,
    -- Physical channel IEs
        ul-TimingAdvance                UL-TimingAdvanceControl             OPTIONAL,
        pusch-CapacityAllocationInfo    PUSCH-CapacityAllocationInfo        OPTIONAL,
        pdsch-CapacityAllocationInfo    PDSCH-CapacityAllocationInfo        OPTIONAL,
        -- TABULAR: If confirmRequest is not present, the default value "No Confirm"
        -- shall be used as specified in 10.2.25.
        confirmRequest                  ENUMERATED {
                                            confirmPDSCH, confirmPUSCH }    OPTIONAL,
        trafficVolumeReportRequest      INTEGER (0..255)                    OPTIONAL,
        iscpTimeslotList                    TimeslotList                        OPTIONAL,
        requestPCCPCHRSCP                   BOOLEAN
}

PhysicalSharedChannelAllocation-r4-IEs ::= SEQUENCE {
    -- TABULAR: Integrity protection shall not be performed on this message.
    -- Physical channel IEs
        ul-TimingAdvance                UL-TimingAdvanceControl-r4          OPTIONAL,
        pusch-CapacityAllocationInfo    PUSCH-CapacityAllocationInfo-r4     OPTIONAL,
        pdsch-CapacityAllocationInfo    PDSCH-CapacityAllocationInfo-r4     OPTIONAL,
        -- TABULAR: If confirmRequest is not present, the default value "No Confirm"
        -- shall be used as specified in 10.2.25.
        confirmRequest                  ENUMERATED {
                                            confirmPDSCH, confirmPUSCH }    OPTIONAL,
        trafficVolumeReportRequest      INTEGER (0..255)                    OPTIONAL,
        iscpTimeslotList                TimeslotList-r4                     OPTIONAL,
        requestPCCPCHRSCP               BOOLEAN
}

PhysicalSharedChannelAllocation-v690ext-IEs ::= SEQUENCE {
    -- Physical Channel IEs
        beaconPLEst                     BEACON-PL-Est                       OPTIONAL
}

PhysicalSharedChannelAllocation-v7xyext-IEs ::= SEQUENCE {
        ul-TimingAdvance                UL-TimingAdvanceControl-r7          OPTIONAL,
        pusch-CapacityAllocationInfo    PUSCH-CapacityAllocationInfo-r7     OPTIONAL,
        pdsch-CapacityAllocationInfo    PDSCH-CapacityAllocationInfo-r7     OPTIONAL
}

-- **************************************************
--
-- PUSCH CAPACITY REQUEST (TDD only)
--
-- **************************************************

PUSCHCapacityRequest ::= SEQUENCE {
    -- User equipment IEs
        dsch-RNTI                       DSCH-RNTI                           OPTIONAL,
    -- Measurement IEs
        trafficVolume                   TrafficVolumeMeasuredResultsList    OPTIONAL,
        timeslotListWithISCP            TimeslotListWithISCP                OPTIONAL,
        primaryCCPCH-RSCP               PrimaryCCPCH-RSCP                   OPTIONAL,
        allocationConfirmation          CHOICE {
            pdschConfirmation               PDSCH-Identity,
            puschConfirmation               PUSCH-Identity
        }                                                                   OPTIONAL,
        protocolErrorIndicator          ProtocolErrorIndicatorWithMoreInfo,
        laterNonCriticalExtensions      SEQUENCE {
            -- Container for additional R99 extensions
            puschCapacityRequest-r3-add-ext     BIT STRING      OPTIONAL,
```

```
            v590NonCriticalExtensions       SEQUENCE {
                puschCapacityRequest-v590ext    PUSCHCapacityRequest-v590ext,
                nonCriticalExtensions           SEQUENCE {} OPTIONAL
            }       OPTIONAL
        }   OPTIONAL
}

PUSCHCapacityRequest-v590ext ::= SEQUENCE {
    primaryCCPCH-RSCP-delta             DeltaRSCP           OPTIONAL
}
-- **************************************************
--
-- RADIO BEARER RECONFIGURATION
--
-- **************************************************

RadioBearerReconfiguration ::= CHOICE {
    r3                              SEQUENCE {
        radioBearerReconfiguration-r3   RadioBearerReconfiguration-r3-IEs,
        -- Prefix "v3ao" is used (in one instance) to keep alignment with R99
        v3aoNonCriticalExtensions       SEQUENCE {
            radioBearerReconfiguration-v3a0ext  RadioBearerReconfiguration-v3a0ext,
            laterNonCriticalExtensions      SEQUENCE {
                -- Container for additional R99 extensions
                radioBearerReconfiguration-r3-add-ext       BIT STRING      OPTIONAL,
                v4b0NonCriticalExtensions           SEQUENCE {
                    radioBearerReconfiguration-v4b0ext
                                                    RadioBearerReconfiguration-v4b0ext-IEs,
                    v590NonCriticalExtensions           SEQUENCE {
                        radioBearerReconfiguration-v590ext
                                                        RadioBearerReconfiguration-v590ext-IEs,
                        v5d0NonCriticalExtenstions          SEQUENCE {
                            radioBearerReconfiguration-v5d0ext
                                                            RadioBearerReconfiguration-v5d0ext-IEs,
                            v690NonCriticalExtensions       SEQUENCE {
                                radioBearerReconfiguration-v690ext
                                                            RadioBearerReconfiguration-v690ext-IEs,
                                nonCriticalExtensions           SEQUENCE {} OPTIONAL
                            }   OPTIONAL
                        }   OPTIONAL
                    }   OPTIONAL
                }   OPTIONAL
            }   OPTIONAL
        }   OPTIONAL
    },
    later-than-r3                   SEQUENCE {
        rrc-TransactionIdentifier       RRC-TransactionIdentifier,
        criticalExtensions              CHOICE {
            r4                              SEQUENCE {
                radioBearerReconfiguration-r4   RadioBearerReconfiguration-r4-IEs,
                v4d0NonCriticalExtensions           SEQUENCE {
                    -- Container for adding non critical extensions after freezing REL-5
                    radioBearerReconfiguration-r4-add-ext       BIT STRING      OPTIONAL,
                    v590NonCriticalExtensions           SEQUENCE {
                        radioBearerReconfiguration-v590ext
                                                        RadioBearerReconfiguration-v590ext-IEs,
                        v5d0NonCriticalExtenstions          SEQUENCE {
                            radioBearerReconfiguration-v5d0ext
                                                            RadioBearerReconfiguration-v5d0ext-IEs,
                            v690NonCriticalExtensions       SEQUENCE {
                                radioBearerReconfiguration-v690ext
                                                            RadioBearerReconfiguration-v690ext-IEs,
                                nonCriticalExtensions           SEQUENCE {}     OPTIONAL
                            }   OPTIONAL
                        }   OPTIONAL
                    }   OPTIONAL
                }   OPTIONAL
            },
            criticalExtensions              CHOICE {
                r5                                  SEQUENCE {
                    radioBearerReconfiguration-r5       RadioBearerReconfiguration-r5-IEs,
                    -- Container for adding non critical extensions after freezing REL-6
                    radioBearerReconfiguration-r5-add-ext       BIT STRING      OPTIONAL,
                    v5d0NonCriticalExtenstions          SEQUENCE {
                        radioBearerReconfiguration-v5d0ext  RadioBearerReconfiguration-v5d0ext-IEs,
                        v690NonCriticalExtensions           SEQUENCE {
                            radioBearerReconfiguration-v690ext
                                                            RadioBearerReconfiguration-v690ext-IEs,
```

```
                        nonCriticalExtensions               SEQUENCE {}     OPTIONAL
                    }   OPTIONAL
                }   OPTIONAL
            },
            criticalExtensions              CHOICE {
                r6                                  SEQUENCE {
                    radioBearerReconfiguration-r6       RadioBearerReconfiguration-r6-IEs,
                    -- Container for adding non critical extensions after freezing REL-7
                    radioBearerReconfiguration-r6-add-ext       BIT STRING      OPTIONAL,
                    nonCriticalExtensions               SEQUENCE {}     OPTIONAL
                },
                criticalExtensions              CHOICE {
                    r7                                      SEQUENCE {
                        radioBearerReconfiguration-r7       RadioBearerReconfiguration-r7-IEs,
                        -- Container for adding non critical extensions after freezing REL-8
                        radioBearerReconfiguration-r7-add-ext       BIT STRING      OPTIONAL,
                        nonCriticalExtensions               SEQUENCE {}     OPTIONAL
                    },
                    criticalExtensions              SEQUENCE {}
                }
            }
        }
    }
}

RadioBearerReconfiguration-r3-IEs ::= SEQUENCE {
    -- User equipment IEs
        rrc-TransactionIdentifier       RRC-TransactionIdentifier,
        integrityProtectionModeInfo     IntegrityProtectionModeInfo         OPTIONAL,
        cipheringModeInfo               CipheringModeInfo                   OPTIONAL,
        activationTime                  ActivationTime                      OPTIONAL,
        new-U-RNTI                      U-RNTI                              OPTIONAL,
        new-C-RNTI                      C-RNTI                              OPTIONAL,
        rrc-StateIndicator              RRC-StateIndicator,
        utran-DRX-CycleLengthCoeff      UTRAN-DRX-CycleLengthCoefficient    OPTIONAL,
    -- Core network IEs
        cn-InformationInfo              CN-InformationInfo                  OPTIONAL,
    -- UTRAN mobility IEs
        ura-Identity                    URA-Identity                        OPTIONAL,
    -- Radio bearer IEs
        rab-InformationReconfigList     RAB-InformationReconfigList         OPTIONAL,
        -- NOTE: IE rb-InformationReconfigList should be optional in later versions
        -- of this message
        rb-InformationReconfigList      RB-InformationReconfigList,
        rb-InformationAffectedList      RB-InformationAffectedList          OPTIONAL,
    -- Transport channel IEs
        ul-CommonTransChInfo            UL-CommonTransChInfo                OPTIONAL,
        ul-deletedTransChInfoList       UL-DeletedTransChInfoList           OPTIONAL,
        ul-AddReconfTransChInfoList     UL-AddReconfTransChInfoList         OPTIONAL,
        -- 'dummy', 'dummy1' and 'dummy2' are not used in this version of the specification,
        -- they should not be sent and if received they should be ignored.
        dummy                           CHOICE {
            fdd                             SEQUENCE {
                dummy1                          CPCH-SetID                  OPTIONAL,
                dummy2                          DRAC-StaticInformationList  OPTIONAL
            },
            tdd                             NULL
        }                                                                   OPTIONAL,
        dl-CommonTransChInfo            DL-CommonTransChInfo                OPTIONAL,
        dl-DeletedTransChInfoList       DL-DeletedTransChInfoList           OPTIONAL,
        dl-AddReconfTransChInfoList     DL-AddReconfTransChInfo2List        OPTIONAL,
    -- Physical channel IEs
        frequencyInfo                   FrequencyInfo                       OPTIONAL,
        maxAllowedUL-TX-Power           MaxAllowedUL-TX-Power               OPTIONAL,
        ul-ChannelRequirement           UL-ChannelRequirement               OPTIONAL,
        modeSpecificPhysChInfo          CHOICE {
            fdd                             SEQUENCE {
                -- dummy is not used in this version of specification, it should
                -- not be sent and if received it should be ignored.
                dummy                           DL-PDSCH-Information        OPTIONAL
            },
            tdd                             NULL
        },
        dl-CommonInformation            DL-CommonInformation                OPTIONAL,
        -- NOTE: IE dl-InformationPerRL-List is optional in later versions
        -- of this message
        dl-InformationPerRL-List        DL-InformationPerRL-List
```

```
}

RadioBearerReconfiguration-v3a0ext ::= SEQUENCE {
    -- The IE 'new-DSCH-RNTI' should not be included in FDD mode, and if received the UE behaviour
    -- is unspecified
    new-DSCH-RNTI                   DSCH-RNTI                           OPTIONAL
}

RadioBearerReconfiguration-v4b0ext-IEs ::= SEQUENCE {
    -- Physical channel IEs
        -- dummy is not used in this version of the specification, it should
        -- not be sent and if received it should be ignored.
        dummy                           SSDT-UL                             OPTIONAL,
        -- The order of the RLs in IE cell-id-PerRL-List is the same as
        -- in IE DL-InformationPerRL-List included in this message
        cell-id-PerRL-List              CellIdentity-PerRL-List             OPTIONAL
}

RadioBearerReconfiguration-v590ext-IEs ::= SEQUENCE {
    -- Physical channel IEs
        dl-TPC-PowerOffsetPerRL-List    DL-TPC-PowerOffsetPerRL-List        OPTIONAL
}

RadioBearerReconfiguration-v5d0ext-IEs ::= SEQUENCE {
    --Radio Bearer IEs
        pdcp-ROHC-TargetMode            PDCP-ROHC-TargetMode                OPTIONAL
}

RadioBearerReconfiguration-r4-IEs ::= SEQUENCE {
    -- User equipment IEs
        integrityProtectionModeInfo     IntegrityProtectionModeInfo         OPTIONAL,
        cipheringModeInfo               CipheringModeInfo                   OPTIONAL,
        activationTime                  ActivationTime                      OPTIONAL,
        new-U-RNTI                      U-RNTI                              OPTIONAL,
        new-C-RNTI                      C-RNTI                              OPTIONAL,
        -- The IE 'new-DSCH-RNTI' should not be included in FDD mode, and if received
        -- the UE behaviour is unspecified
        new-DSCH-RNTI                   DSCH-RNTI                           OPTIONAL,
        rrc-StateIndicator              RRC-StateIndicator,
        utran-DRX-CycleLengthCoeff      UTRAN-DRX-CycleLengthCoefficient    OPTIONAL,
    -- Core network IEs
        cn-InformationInfo              CN-InformationInfo                  OPTIONAL,
    -- UTRAN mobility IEs
        ura-Identity                    URA-Identity                        OPTIONAL,
    -- Radio bearer IEs
        rab-InformationReconfigList     RAB-InformationReconfigList         OPTIONAL,
        rb-InformationReconfigList      RB-InformationReconfigList-r4       OPTIONAL,
        rb-InformationAffectedList      RB-InformationAffectedList          OPTIONAL,
    -- Transport channel IEs
        ul-CommonTransChInfo            UL-CommonTransChInfo-r4             OPTIONAL,
        ul-deletedTransChInfoList       UL-DeletedTransChInfoList           OPTIONAL,
        ul-AddReconfTransChInfoList     UL-AddReconfTransChInfoList         OPTIONAL,
        -- 'dummy', 'dummy1' and 'dummy2' are not used in this version of the specification,
        -- they should not be sent and if received they should be ignored.
        dummy                           CHOICE {
            fdd                             SEQUENCE {
                dummy1                          CPCH-SetID                  OPTIONAL,
                dummy2                          DRAC-StaticInformationList  OPTIONAL
            },
            tdd                             NULL
        }                                                                   OPTIONAL,
        dl-CommonTransChInfo            DL-CommonTransChInfo-r4             OPTIONAL,
        dl-DeletedTransChInfoList       DL-DeletedTransChInfoList           OPTIONAL,
        dl-AddReconfTransChInfoList     DL-AddReconfTransChInfoList-r4      OPTIONAL,
    -- Physical channel IEs
        frequencyInfo                   FrequencyInfo                       OPTIONAL,
        maxAllowedUL-TX-Power           MaxAllowedUL-TX-Power               OPTIONAL,
        ul-ChannelRequirement           UL-ChannelRequirement-r4            OPTIONAL,
        modeSpecificPhysChInfo          CHOICE {
            fdd                             SEQUENCE {
                -- dummy is not used in this version of specification, it should
                -- not be sent and if received it should be ignored.
                dummy                           DL-PDSCH-Information        OPTIONAL
            },
            tdd                             NULL
        },
        dl-CommonInformation            DL-CommonInformation-r4             OPTIONAL,
        dl-InformationPerRL-List        DL-InformationPerRL-List-r4         OPTIONAL
```

```
}

RadioBearerReconfiguration-r5-IEs ::= SEQUENCE {
    -- User equipment IEs
        integrityProtectionModeInfo     IntegrityProtectionModeInfo         OPTIONAL,
        cipheringModeInfo               CipheringModeInfo                   OPTIONAL,
        activationTime                  ActivationTime                      OPTIONAL,
        new-U-RNTI                      U-RNTI                              OPTIONAL,
        new-C-RNTI                      C-RNTI                              OPTIONAL,
        -- The IE 'new-DSCH-RNTI' should not be included in FDD mode, and if received
        -- the UE behaviour is unspecified
        new-DSCH-RNTI                   DSCH-RNTI                           OPTIONAL,
        new-H-RNTI                      H-RNTI                              OPTIONAL,
        rrc-StateIndicator              RRC-StateIndicator,
        utran-DRX-CycleLengthCoeff      UTRAN-DRX-CycleLengthCoefficient    OPTIONAL,
    -- Core network IEs
        cn-InformationInfo              CN-InformationInfo                  OPTIONAL,
    -- UTRAN mobility IEs
        ura-Identity                    URA-Identity                        OPTIONAL,
    -- Specification mode information
        specificationMode               CHOICE {
            complete                        SEQUENCE {
            -- Radio bearer IEs
                rab-InformationReconfigList     RAB-InformationReconfigList         OPTIONAL,
                rb-InformationReconfigList      RB-InformationReconfigList-r5       OPTIONAL,
                rb-InformationAffectedList      RB-InformationAffectedList-r5       OPTIONAL,
                rb-PDCPContextRelocationList    RB-PDCPContextRelocationList        OPTIONAL,
            -- Transport channel IEs
                ul-CommonTransChInfo            UL-CommonTransChInfo-r4             OPTIONAL,
                ul-deletedTransChInfoList       UL-DeletedTransChInfoList           OPTIONAL,
                ul-AddReconfTransChInfoList     UL-AddReconfTransChInfoList         OPTIONAL,
                -- 'dummy', 'dummy1' and 'dummy2' are not used in this version of the
                -- specification, they should not be sent and if received they should be ignored.
                dummy                           CHOICE {
                    fdd                             SEQUENCE {
                        dummy1                          CPCH-SetID                  OPTIONAL,
                        dummy2                          DRAC-StaticInformationList  OPTIONAL
                    },
                    tdd                             NULL
                }                                                                   OPTIONAL,
                dl-CommonTransChInfo            DL-CommonTransChInfo-r4             OPTIONAL,
                dl-DeletedTransChInfoList       DL-DeletedTransChInfoList-r5        OPTIONAL,
                dl-AddReconfTransChInfoList     DL-AddReconfTransChInfoList-r5      OPTIONAL
            },
            preconfiguration                SEQUENCE {
            -- All IEs that include an FDD/TDD choice are split in two IEs for this message,
            -- one for the FDD only elements and one for the TDD only elements, so that one
            -- FDD/TDD choice in this level is sufficient.
                preConfigMode                   CHOICE {
                    predefinedConfigIdentity        PredefinedConfigIdentity,
                    defaultConfig                   SEQUENCE {
                        defaultConfigMode               DefaultConfigMode,
                        defaultConfigIdentity           DefaultConfigIdentity-r5
                    }
                }
            }
        },
    -- Physical channel IEs
        frequencyInfo                   FrequencyInfo                       OPTIONAL,
        maxAllowedUL-TX-Power           MaxAllowedUL-TX-Power               OPTIONAL,
        ul-ChannelRequirement           UL-ChannelRequirement-r5            OPTIONAL,
        modeSpecificPhysChInfo          CHOICE {
            fdd                             SEQUENCE {
                -- dummy is not used in this version of specification, it should
                -- not be sent and if received it should be ignored.
                dummy                           DL-PDSCH-Information        OPTIONAL
            },
            tdd                             NULL
        },
        dl-HSPDSCH-Information          DL-HSPDSCH-Information              OPTIONAL,
        dl-CommonInformation            DL-CommonInformation-r5             OPTIONAL,
        dl-InformationPerRL-List        DL-InformationPerRL-List-r5         OPTIONAL
}

RadioBearerReconfiguration-r6-IEs ::= SEQUENCE {
    -- User equipment IEs
        integrityProtectionModeInfo     IntegrityProtectionModeInfo         OPTIONAL,
        cipheringModeInfo               CipheringModeInfo                   OPTIONAL,
```

```
        activationTime                  ActivationTime                      OPTIONAL,
        delayRestrictionFlag            DelayRestrictionFlag                OPTIONAL,
        new-U-RNTI                      U-RNTI                              OPTIONAL,
        new-C-RNTI                      C-RNTI                              OPTIONAL,
        -- The IE 'new-DSCH-RNTI' should not be included in FDD mode,
        -- and if received the UE behaviour is unspecified
        new-DSCH-RNTI                   DSCH-RNTI                           OPTIONAL,
        new-H-RNTI                      H-RNTI                              OPTIONAL,
        newPrimary-E-RNTI               E-RNTI                              OPTIONAL,
        newSecondary-E-RNTI             E-RNTI                              OPTIONAL,
        rrc-StateIndicator              RRC-StateIndicator,
        utran-DRX-CycleLengthCoeff      UTRAN-DRX-CycleLengthCoefficient    OPTIONAL,
    -- Core network IEs
        cn-InformationInfo              CN-InformationInfo-r6               OPTIONAL,
    -- UTRAN mobility IEs
        ura-Identity                    URA-Identity                        OPTIONAL,
    -- Specification mode information
        specificationMode               CHOICE {
            complete                        SEQUENCE {
            -- Radio bearer IEs
                rab-InformationReconfigList     RAB-InformationReconfigList         OPTIONAL,
                rb-InformationReconfigList      RB-InformationReconfigList-r6       OPTIONAL,
                rb-InformationAffectedList      RB-InformationAffectedList-r6       OPTIONAL,
                rb-PDCPContextRelocationList    RB-PDCPContextRelocationList        OPTIONAL,
                pdcp-ROHC-TargetMode            PDCP-ROHC-TargetMode                OPTIONAL,
            -- Transport channel IEs
                ul-CommonTransChInfo            UL-CommonTransChInfo-r4             OPTIONAL,
                ul-deletedTransChInfoList       UL-DeletedTransChInfoList-r6        OPTIONAL,
                ul-AddReconfTransChInfoList     UL-AddReconfTransChInfoList-r6      OPTIONAL,
                dl-CommonTransChInfo            DL-CommonTransChInfo-r4             OPTIONAL,
                dl-DeletedTransChInfoList       DL-DeletedTransChInfoList-r5        OPTIONAL,
                dl-AddReconfTransChInfoList     DL-AddReconfTransChInfoList-r5      OPTIONAL
            },
            preconfiguration                SEQUENCE {
            -- All IEs that include an FDD/TDD choice are split in two IEs for this message,
            -- one for the FDD only elements and one for the TDD only elements, so that one
            -- FDD/TDD choice in this level is sufficient.
                preConfigMode                   CHOICE {
                    predefinedConfigIdentity        PredefinedConfigIdentity,
                    defaultConfig                   SEQUENCE {
                        defaultConfigMode               DefaultConfigMode,
                        defaultConfigIdentity           DefaultConfigIdentity-r6
                    }
                }
            }
        },
    -- Physical channel IEs
        frequencyInfo                   FrequencyInfo                       OPTIONAL,
        maxAllowedUL-TX-Power           MaxAllowedUL-TX-Power               OPTIONAL,
        ul-DPCH-Info                    UL-DPCH-Info-r6                     OPTIONAL,
        ul-EDCH-Information             UL-EDCH-Information-r6              OPTIONAL,
        dl-HSPDSCH-Information          DL-HSPDSCH-Information-r6           OPTIONAL,
        dl-CommonInformation            DL-CommonInformation-r6             OPTIONAL,
        dl-InformationPerRL-List        DL-InformationPerRL-List-r6         OPTIONAL,
    -- MBMS IEs
        mbms-PL-ServiceRestrictInfo     MBMS-PL-ServiceRestrictInfo-r6      OPTIONAL
}

RadioBearerReconfiguration-v690ext-IEs ::= SEQUENCE {
    -- User Equipment IEs
        delayRestrictionFlag            DelayRestrictionFlag                OPTIONAL,
    -- Core network IEs
        primary-plmn-Identity           PLMN-Identity                       OPTIONAL,
    -- Physical channel IEs
        -- The IE harq-Preamble-Mode should not be used in the r3 and r4 versions of the message
        -- If included in the r3 or r4 version of the message, the UE should ignore the IE
        harq-Preamble-Mode              HARQ-Preamble-Mode                  OPTIONAL,
        beaconPLEst                     BEACON-PL-Est                       OPTIONAL,
        postVerificationPeriod          ENUMERATED { true }                 OPTIONAL,
        dhs-sync                        DHS-Sync                            OPTIONAL,
        timingMaintainedSynchInd        TimingMaintainedSynchInd            OPTIONAL,
    -- MBMS IEs
        mbms-PL-ServiceRestrictInfo     MBMS-PL-ServiceRestrictInfo-r6      OPTIONAL
}

RadioBearerReconfiguration-r7-IEs ::= SEQUENCE {
    -- User equipment IEs
        integrityProtectionModeInfo     IntegrityProtectionModeInfo         OPTIONAL,
```

```
        cipheringModeInfo               CipheringModeInfo                   OPTIONAL,
        activationTime                  ActivationTime                      OPTIONAL,
        delayRestrictionFlag            DelayRestrictionFlag                OPTIONAL,
        new-U-RNTI                      U-RNTI                              OPTIONAL,
        new-C-RNTI                      C-RNTI                              OPTIONAL,
        -- The IE 'new-DSCH-RNTI' should not be included in FDD mode,
        -- and if received the UE behaviour is unspecified
        new-DSCH-RNTI                   DSCH-RNTI                           OPTIONAL,
        new-H-RNTI                      H-RNTI                              OPTIONAL,
        newPrimary-E-RNTI               E-RNTI                              OPTIONAL,
        newSecondary-E-RNTI             E-RNTI                              OPTIONAL,
        rrc-StateIndicator              RRC-StateIndicator,
        utran-DRX-CycleLengthCoeff      UTRAN-DRX-CycleLengthCoefficient    OPTIONAL,
    -- Core network IEs
        cn-InformationInfo              CN-InformationInfo-r6               OPTIONAL,
    -- UTRAN mobility IEs
        ura-Identity                    URA-Identity                        OPTIONAL,
    -- Specification mode information
        specificationMode               CHOICE {
            complete                        SEQUENCE {
            -- Radio bearer IEs
                rab-InformationReconfigList     RAB-InformationReconfigList         OPTIONAL,
                rb-InformationReconfigList      RB-InformationReconfigList-r6       OPTIONAL,
                rb-InformationAffectedList      RB-InformationAffectedList-r6       OPTIONAL,
                rb-PDCPContextRelocationList    RB-PDCPContextRelocationList        OPTIONAL,
                pdcp-ROHC-TargetMode            PDCP-ROHC-TargetMode                OPTIONAL,
            -- Transport channel IEs
                ul-CommonTransChInfo            UL-CommonTransChInfo-r4             OPTIONAL,
                ul-deletedTransChInfoList       UL-DeletedTransChInfoList-r6        OPTIONAL,
                ul-AddReconfTransChInfoList     UL-AddReconfTransChInfoList-r6      OPTIONAL,
                dl-CommonTransChInfo            DL-CommonTransChInfo-r4             OPTIONAL,
                dl-DeletedTransChInfoList       DL-DeletedTransChInfoList-r5        OPTIONAL,
                dl-AddReconfTransChInfoList     DL-AddReconfTransChInfoList-r5      OPTIONAL
            },
            preconfiguration                SEQUENCE {
            -- All IEs that include an FDD/TDD choice are split in two IEs for this message,
            -- one for the FDD only elements and one for the TDD only elements, so that one
            -- FDD/TDD choice in this level is sufficient.
                preConfigMode                   CHOICE {
                    predefinedConfigIdentity        PredefinedConfigIdentity,
                    defaultConfig                   SEQUENCE {
                        defaultConfigMode               DefaultConfigMode,
                        defaultConfigIdentity           DefaultConfigIdentity-r5
                    }
                }
            }
        },
    -- Physical channel IEs
        frequencyInfo                   FrequencyInfo                       OPTIONAL,
        maxAllowedUL-TX-Power           MaxAllowedUL-TX-Power               OPTIONAL,
        ul-DPCH-Info                    UL-DPCH-Info-r7                     OPTIONAL,
        ul-EDCH-Information             UL-EDCH-Information-r6              OPTIONAL,
        dl-HSPDSCH-Information          DL-HSPDSCH-Information-r7           OPTIONAL,
        dl-CommonInformation            DL-CommonInformation-r7             OPTIONAL,
        dl-InformationPerRL-List        DL-InformationPerRL-List-r7         OPTIONAL,
    -- MBMS IEs
        mbms-PL-ServiceRestrictInfo     MBMS-PL-ServiceRestrictInfo-r6      OPTIONAL
}

-- **************************************************
--
-- RADIO BEARER RECONFIGURATION COMPLETE
--
-- **************************************************

RadioBearerReconfigurationComplete ::= SEQUENCE {
    -- User equipment IEs
        rrc-TransactionIdentifier       RRC-TransactionIdentifier,
        ul-IntegProtActivationInfo      IntegrityProtActivationInfo         OPTIONAL,
        -- TABULAR: UL-TimingAdvance is applicable for TDD mode only.
        ul-TimingAdvance                UL-TimingAdvance                    OPTIONAL,
    -- Radio bearer IEs
        count-C-ActivationTime          ActivationTime                      OPTIONAL,
        -- dummy is not used in this version of the specification and
        -- it should be ignored by the receiver.
        dummy                           RB-ActivationTimeInfoList           OPTIONAL,
        ul-CounterSynchronisationInfo   UL-CounterSynchronisationInfo       OPTIONAL,
        laterNonCriticalExtensions      SEQUENCE {
```

```
            -- Container for additional R99 extensions
            radioBearerReconfigurationComplete-r3-add-ext       BIT STRING      OPTIONAL,
            v7xyNonCriticalExtensions       SEQUENCE {
                radioBearerReconfigurationComplete-v7xyext
                                            RadioBearerReconfigurationComplete-v7xyext-IEs,
                nonCriticalExtensions       SEQUENCE {} OPTIONAL
            }   OPTIONAL
        }   OPTIONAL
}

RadioBearerReconfigurationComplete-v7xyext-IEs ::= SEQUENCE {
        ul-TimingAdvance-VHCR           UL-TimingAdvance-VHCR               OPTIONAL
}

-- **************************************************
--
-- RADIO BEARER RECONFIGURATION FAILURE
--
-- **************************************************

RadioBearerReconfigurationFailure ::= SEQUENCE {
    -- User equipment IEs
        rrc-TransactionIdentifier       RRC-TransactionIdentifier,
        failureCause                    FailureCauseWithProtErr,
    -- Radio bearer IEs
        potentiallySuccesfulBearerList  RB-IdentityList                     OPTIONAL,
        laterNonCriticalExtensions      SEQUENCE {
            -- Container for additional R99 extensions
            radioBearerReconfigurationFailure-r3-add-ext        BIT STRING      OPTIONAL,
            nonCriticalExtensions           SEQUENCE {} OPTIONAL
        }   OPTIONAL
}

-- **************************************************
--
-- RADIO BEARER RELEASE
--
-- **************************************************

RadioBearerRelease ::= CHOICE {
    r3                              SEQUENCE {
        radioBearerRelease-r3           RadioBearerRelease-r3-IEs,
        v3a0NonCriticalExtensions       SEQUENCE {
            radioBearerRelease-v3a0ext      RadioBearerRelease-v3a0ext,
        laterNonCriticalExtensions      SEQUENCE {
            -- Container for additional R99 extensions
            radioBearerRelease-r3-add-ext       BIT STRING      OPTIONAL,
                v4b0NonCriticalExtensions       SEQUENCE {
                    radioBearerRelease-v4b0ext      RadioBearerRelease-v4b0ext-IEs,
                    v590NonCriticalExtensions       SEQUENCE {
                        radioBearerRelease-v590ext      RadioBearerRelease-v590ext-IEs,
                        v690NonCriticalExtensions       SEQUENCE {
                            radioBearerRelease-v690ext      RadioBearerRelease-v690ext-IEs,
                            nonCriticalExtensions           SEQUENCE {} OPTIONAL
                        }       OPTIONAL
                    }   OPTIONAL
                }   OPTIONAL
            }   OPTIONAL
        }   OPTIONAL
    },
    later-than-r3                   SEQUENCE {
        rrc-TransactionIdentifier       RRC-TransactionIdentifier,
        criticalExtensions              CHOICE {
            r4                              SEQUENCE {
                radioBearerRelease-r4           RadioBearerRelease-r4-IEs,
                v4d0NonCriticalExtensions           SEQUENCE {
                    -- Container for adding non critical extensions after freezing REL-5
                    radioBearerRelease-r4-add-ext       BIT STRING      OPTIONAL,
                    v590NonCriticalExtensions       SEQUENCE {
                        radioBearerRelease-v590ext      RadioBearerRelease-v590ext-IEs,
                        v690NonCriticalExtensions       SEQUENCE {
                            radioBearerRelease-v690ext      RadioBearerRelease-v690ext-IEs,
                            nonCriticalExtensions           SEQUENCE {}     OPTIONAL
                        }   OPTIONAL
                    }   OPTIONAL
                }   OPTIONAL
            },
            criticalExtensions              CHOICE {
```

```
                r5                              SEQUENCE {
                    radioBearerRelease-r5           RadioBearerRelease-r5-IEs,
                    -- Container for adding non critical extensions after freezing REL-6
                    radioBearerRelease-r5-add-ext   BIT STRING      OPTIONAL,
                    v690NonCriticalExtensions       SEQUENCE {
                        radioBearerRelease-v690ext      RadioBearerRelease-v690ext-IEs,
                        nonCriticalExtensions           SEQUENCE {}     OPTIONAL
                    }   OPTIONAL
                },
                criticalExtensions              CHOICE {
                    r6                              SEQUENCE {
                        radioBearerRelease-r6           RadioBearerRelease-r6-IEs,
                        -- Container for adding non critical extensions after freezing REL-7
                        radioBearerRelease-r6-add-ext   BIT STRING      OPTIONAL,
                        nonCriticalExtensions           SEQUENCE {}     OPTIONAL
                    },
                    criticalExtensions              CHOICE {
                        r7                              SEQUENCE {
                            radioBearerRelease-r7           RadioBearerRelease-r7-IEs,
                            -- Container for adding non critical extensions after freezing REL-8
                            radioBearerRelease-r7-add-ext   BIT STRING      OPTIONAL,
                            nonCriticalExtensions           SEQUENCE {}     OPTIONAL
                        },
                        criticalExtensions              SEQUENCE {}
                    }
                }
            }
        }
    }
}

RadioBearerRelease-r3-IEs ::= SEQUENCE {
    -- User equipment IEs
        rrc-TransactionIdentifier       RRC-TransactionIdentifier,
        integrityProtectionModeInfo     IntegrityProtectionModeInfo         OPTIONAL,
        cipheringModeInfo               CipheringModeInfo                   OPTIONAL,
        activationTime                  ActivationTime                      OPTIONAL,
        new-U-RNTI                      U-RNTI                              OPTIONAL,
        new-C-RNTI                      C-RNTI                              OPTIONAL,
        rrc-StateIndicator              RRC-StateIndicator,
        utran-DRX-CycleLengthCoeff      UTRAN-DRX-CycleLengthCoefficient    OPTIONAL,
    -- Core network IEs
        cn-InformationInfo              CN-InformationInfo                  OPTIONAL,
        signallingConnectionRelIndication   CN-DomainIdentity               OPTIONAL,
    -- UTRAN mobility IEs
        ura-Identity                    URA-Identity                        OPTIONAL,
    -- Radio bearer IEs
        rab-InformationReconfigList     RAB-InformationReconfigList         OPTIONAL,
        rb-InformationReleaseList       RB-InformationReleaseList,
        rb-InformationAffectedList      RB-InformationAffectedList          OPTIONAL,
        dl-CounterSynchronisationInfo   DL-CounterSynchronisationInfo       OPTIONAL,
    -- Transport channel IEs
        ul-CommonTransChInfo            UL-CommonTransChInfo                OPTIONAL,
        ul-deletedTransChInfoList       UL-DeletedTransChInfoList           OPTIONAL,
        ul-AddReconfTransChInfoList     UL-AddReconfTransChInfoList         OPTIONAL,
        -- 'dummy', 'dummy1' and 'dummy2' are not used in this version of the specification,
        -- they should not be sent and if received they should be ignored.
        dummy                           CHOICE {
            fdd                             SEQUENCE {
                dummy1                          CPCH-SetID                  OPTIONAL,
                dummy2                          DRAC-StaticInformationList  OPTIONAL
            },
            tdd                             NULL
        }                                                                   OPTIONAL,
        dl-CommonTransChInfo            DL-CommonTransChInfo                OPTIONAL,
        dl-DeletedTransChInfoList       DL-DeletedTransChInfoList           OPTIONAL,
        dl-AddReconfTransChInfoList     DL-AddReconfTransChInfo2List        OPTIONAL,
    -- Physical channel IEs
        frequencyInfo                   FrequencyInfo                       OPTIONAL,
        maxAllowedUL-TX-Power           MaxAllowedUL-TX-Power               OPTIONAL,
        ul-ChannelRequirement           UL-ChannelRequirement               OPTIONAL,
        modeSpecificPhysChInfo          CHOICE {
            fdd                             SEQUENCE {
                -- dummy is not used in this version of specification, it should
                -- not be sent and if received it should be ignored.
                dummy                           DL-PDSCH-Information        OPTIONAL
            },
            tdd                         NULL
```

```
        },
        dl-CommonInformation            DL-CommonInformation                OPTIONAL,
        dl-InformationPerRL-List        DL-InformationPerRL-List            OPTIONAL
}

RadioBearerRelease-v3a0ext ::= SEQUENCE {
    -- The IE 'new-DSCH-RNTI' should not be included in FDD mode, and if received the UE behaviour
    -- is unspecified
    new-DSCH-RNTI                   DSCH-RNTI                           OPTIONAL
}

RadioBearerRelease-v4b0ext-IEs ::= SEQUENCE {
    -- Physical channel IEs
        -- dummy is not used in this version of the specification, it should
        -- not be sent and if received it should be ignored.
        dummy                           SSDT-UL                             OPTIONAL,
        -- The order of the RLs in IE cell-id-PerRL-List is the same as
        --  in IE DL-InformationPerRL-List included in this message
        cell-id-PerRL-List              CellIdentity-PerRL-List             OPTIONAL
}

RadioBearerRelease-v590ext-IEs ::= SEQUENCE {
    -- Physical channel IEs
        dl-TPC-PowerOffsetPerRL-List    DL-TPC-PowerOffsetPerRL-List        OPTIONAL
}

RadioBearerRelease-r4-IEs ::= SEQUENCE {
    -- User equipment IEs
        integrityProtectionModeInfo     IntegrityProtectionModeInfo         OPTIONAL,
        cipheringModeInfo               CipheringModeInfo                   OPTIONAL,
        activationTime                  ActivationTime                      OPTIONAL,
        new-U-RNTI                      U-RNTI                              OPTIONAL,
        new-C-RNTI                      C-RNTI                              OPTIONAL,
        -- The IE 'new-DSCH-RNTI' should not be included in FDD mode, and if received
        -- the UE behaviour is unspecified
        new-DSCH-RNTI                   DSCH-RNTI                           OPTIONAL,
        rrc-StateIndicator              RRC-StateIndicator,
        utran-DRX-CycleLengthCoeff      UTRAN-DRX-CycleLengthCoefficient    OPTIONAL,
    -- Core network IEs
        cn-InformationInfo              CN-InformationInfo                  OPTIONAL,
        signallingConnectionRelIndication   CN-DomainIdentity               OPTIONAL,
    -- UTRAN mobility IEs
        ura-Identity                    URA-Identity                        OPTIONAL,
    -- Radio bearer IEs
        rab-InformationReconfigList     RAB-InformationReconfigList         OPTIONAL,
        rb-InformationReleaseList       RB-InformationReleaseList,
        rb-InformationAffectedList      RB-InformationAffectedList          OPTIONAL,
        dl-CounterSynchronisationInfo   DL-CounterSynchronisationInfo       OPTIONAL,
    -- Transport channel IEs
        ul-CommonTransChInfo            UL-CommonTransChInfo-r4             OPTIONAL,
        ul-deletedTransChInfoList       UL-DeletedTransChInfoList           OPTIONAL,
        ul-AddReconfTransChInfoList     UL-AddReconfTransChInfoList         OPTIONAL,
        -- 'dummy', 'dummy1' and 'dummy2' are not used in this version of the specification,
        -- they should not be sent and if received they should be ignored.
        dummy                           CHOICE {
            fdd                             SEQUENCE {
                dummy1                          CPCH-SetID                  OPTIONAL,
                dummy2                          DRAC-StaticInformationList  OPTIONAL
            },
            tdd                             NULL
        }                                                                   OPTIONAL,
        dl-CommonTransChInfo            DL-CommonTransChInfo-r4             OPTIONAL,
        dl-DeletedTransChInfoList       DL-DeletedTransChInfoList           OPTIONAL,
        dl-AddReconfTransChInfoList     DL-AddReconfTransChInfoList-r4      OPTIONAL,
    -- Physical channel IEs
        frequencyInfo                   FrequencyInfo                       OPTIONAL,
        maxAllowedUL-TX-Power           MaxAllowedUL-TX-Power               OPTIONAL,
        ul-ChannelRequirement           UL-ChannelRequirement-r4            OPTIONAL,
        modeSpecificPhysChInfo          CHOICE {
            fdd                             SEQUENCE {
                -- dummy is not used in this version of specification, it should
                -- not be sent and if received it should be ignored.
                dummy                           DL-PDSCH-Information        OPTIONAL
            },
            tdd                             NULL
        },
        dl-CommonInformation            DL-CommonInformation-r4             OPTIONAL,
        dl-InformationPerRL-List        DL-InformationPerRL-List-r4         OPTIONAL
```

```
}

RadioBearerRelease-r5-IEs ::= SEQUENCE {
    -- User equipment IEs
        integrityProtectionModeInfo     IntegrityProtectionModeInfo         OPTIONAL,
        cipheringModeInfo               CipheringModeInfo                   OPTIONAL,
        activationTime                  ActivationTime                      OPTIONAL,
        new-U-RNTI                      U-RNTI                              OPTIONAL,
        new-C-RNTI                      C-RNTI                              OPTIONAL,
        -- The IE 'new-DSCH-RNTI' should not be included in FDD mode,
        -- and if received the UE behaviour is unspecified
        new-DSCH-RNTI                   DSCH-RNTI                           OPTIONAL,
        new-H-RNTI                      H-RNTI                              OPTIONAL,
        rrc-StateIndicator              RRC-StateIndicator,
        utran-DRX-CycleLengthCoeff      UTRAN-DRX-CycleLengthCoefficient    OPTIONAL,
    -- Core network IEs
        cn-InformationInfo              CN-InformationInfo                  OPTIONAL,
        signallingConnectionRelIndication   CN-DomainIdentity               OPTIONAL,
    -- UTRAN mobility IEs
        ura-Identity                    URA-Identity                        OPTIONAL,
    -- Radio bearer IEs
        rab-InformationReconfigList     RAB-InformationReconfigList         OPTIONAL,
        rb-InformationReleaseList       RB-InformationReleaseList,
        rb-InformationAffectedList      RB-InformationAffectedList-r5       OPTIONAL,
        dl-CounterSynchronisationInfo   DL-CounterSynchronisationInfo-r5    OPTIONAL,
    -- Transport channel IEs
        ul-CommonTransChInfo            UL-CommonTransChInfo-r4             OPTIONAL,
        ul-deletedTransChInfoList       UL-DeletedTransChInfoList           OPTIONAL,
        ul-AddReconfTransChInfoList     UL-AddReconfTransChInfoList         OPTIONAL,
        -- 'dummy', 'dummy1' and 'dummy2' are not used in this version of the specification,
        -- they should not be sent and if received they should be ignored.
        dummy                           CHOICE {
            fdd                             SEQUENCE {
                dummy1                          CPCH-SetID                  OPTIONAL,
                dummy2                          DRAC-StaticInformationList  OPTIONAL
            },
            tdd                             NULL
        }                                                                   OPTIONAL,
        dl-CommonTransChInfo            DL-CommonTransChInfo-r4             OPTIONAL,
        dl-DeletedTransChInfoList       DL-DeletedTransChInfoList-r5        OPTIONAL,
        dl-AddReconfTransChInfoList     DL-AddReconfTransChInfoList-r5      OPTIONAL,
    -- Physical channel IEs
        frequencyInfo                   FrequencyInfo                       OPTIONAL,
        maxAllowedUL-TX-Power           MaxAllowedUL-TX-Power               OPTIONAL,
        ul-ChannelRequirement           UL-ChannelRequirement-r5            OPTIONAL,
        modeSpecificPhysChInfo          CHOICE {
            fdd                             SEQUENCE {
                -- dummy is not used in this version of specification, it should
                -- not be sent and if received it should be ignored.
                dummy                           DL-PDSCH-Information        OPTIONAL
            },
            tdd                             NULL
        },
        dl-HSPDSCH-Information          DL-HSPDSCH-Information              OPTIONAL,
        dl-CommonInformation            DL-CommonInformation-r5             OPTIONAL,
        dl-InformationPerRL-List        DL-InformationPerRL-List-r5         OPTIONAL
}

RadioBearerRelease-v690ext-IEs ::= SEQUENCE {
    -- Core network IEs
        primary-plmn-Identity           PLMN-Identity                       OPTIONAL,
    -- Physical channel IEs
        -- The IE harq-Preamble-Mode should not be used in the r3 and r4 versions of the message
        -- If included in the r3 or r4 version of the message, the UE should ignore the IE
        harq-Preamble-Mode              HARQ-Preamble-Mode                  OPTIONAL,
        beaconPLEst                     BEACON-PL-Est                       OPTIONAL,
        postVerificationPeriod          ENUMERATED { true }                 OPTIONAL,
        dhs-sync                        DHS-Sync                            OPTIONAL,
        timingMaintainedSynchInd        TimingMaintainedSynchInd            OPTIONAL,
    -- MBMS IEs
        mbms-PL-ServiceRestrictInfo     MBMS-PL-ServiceRestrictInfo-r6      OPTIONAL,
        mbms-RB-ListReleasedToChangeTransferMode
                                        RB-InformationReleaseList           OPTIONAL
}

RadioBearerRelease-r6-IEs ::= SEQUENCE {
    -- User equipment IEs
        integrityProtectionModeInfo     IntegrityProtectionModeInfo         OPTIONAL,
```

```
        cipheringModeInfo               CipheringModeInfo                   OPTIONAL,
        activationTime                  ActivationTime                      OPTIONAL,
        new-U-RNTI                      U-RNTI                              OPTIONAL,
        new-C-RNTI                      C-RNTI                              OPTIONAL,
        -- The IE 'new-DSCH-RNTI' should not be included in FDD mode,
        -- and if received the UE behaviour is unspecified
        new-DSCH-RNTI                   DSCH-RNTI                           OPTIONAL,
        new-H-RNTI                      H-RNTI                              OPTIONAL,
        newPrimary-E-RNTI               E-RNTI                              OPTIONAL,
        newSecondary-E-RNTI             E-RNTI                              OPTIONAL,
        rrc-StateIndicator              RRC-StateIndicator,
        utran-DRX-CycleLengthCoeff      UTRAN-DRX-CycleLengthCoefficient    OPTIONAL,
    -- Core network IEs
        cn-InformationInfo              CN-InformationInfo-r6               OPTIONAL,
        signallingConnectionRelIndication   CN-DomainIdentity               OPTIONAL,
    -- UTRAN mobility IEs
        ura-Identity                    URA-Identity                        OPTIONAL,
    -- Radio bearer IEs
        rab-InformationReconfigList     RAB-InformationReconfigList         OPTIONAL,
        rb-InformationReleaseList       RB-InformationReleaseList,
        rb-InformationReconfigList      RB-InformationReconfigList-r6       OPTIONAL,
        rb-InformationAffectedList      RB-InformationAffectedList-r6       OPTIONAL,
        dl-CounterSynchronisationInfo   DL-CounterSynchronisationInfo-r5    OPTIONAL,
    -- Transport channel IEs
        ul-CommonTransChInfo            UL-CommonTransChInfo-r4             OPTIONAL,
        ul-deletedTransChInfoList       UL-DeletedTransChInfoList-r6        OPTIONAL,
        ul-AddReconfTransChInfoList     UL-AddReconfTransChInfoList-r6      OPTIONAL,
        dl-CommonTransChInfo            DL-CommonTransChInfo-r4             OPTIONAL,
        dl-DeletedTransChInfoList       DL-DeletedTransChInfoList-r5        OPTIONAL,
        dl-AddReconfTransChInfoList     DL-AddReconfTransChInfoList-r5      OPTIONAL,
    -- Physical channel IEs
        frequencyInfo                   FrequencyInfo                       OPTIONAL,
        maxAllowedUL-TX-Power           MaxAllowedUL-TX-Power               OPTIONAL,
        ul-DPCH-Info                    UL-DPCH-Info-r6                     OPTIONAL,
        ul-EDCH-Information             UL-EDCH-Information-r6              OPTIONAL,
        dl-HSPDSCH-Information          DL-HSPDSCH-Information-r6           OPTIONAL,
        dl-CommonInformation            DL-CommonInformation-r6             OPTIONAL,
        dl-InformationPerRL-List        DL-InformationPerRL-List-r6         OPTIONAL,
    -- MBMS IEs
        mbms-PL-ServiceRestrictInfo     MBMS-PL-ServiceRestrictInfo-r6      OPTIONAL,
        mbms-RB-ListReleasedToChangeTransferMode
                                        RB-InformationReleaseList           OPTIONAL
}

RadioBearerRelease-r7-IEs ::= SEQUENCE {
    -- User equipment IEs
        integrityProtectionModeInfo     IntegrityProtectionModeInfo         OPTIONAL,
        cipheringModeInfo               CipheringModeInfo                   OPTIONAL,
        activationTime                  ActivationTime                      OPTIONAL,
        new-U-RNTI                      U-RNTI                              OPTIONAL,
        new-C-RNTI                      C-RNTI                              OPTIONAL,
        -- The IE 'new-DSCH-RNTI' should not be included in FDD mode,
        -- and if received the UE behaviour is unspecified
        new-DSCH-RNTI                   DSCH-RNTI                           OPTIONAL,
        new-H-RNTI                      H-RNTI                              OPTIONAL,
        newPrimary-E-RNTI               E-RNTI                              OPTIONAL,
        newSecondary-E-RNTI             E-RNTI                              OPTIONAL,
        rrc-StateIndicator              RRC-StateIndicator,
        utran-DRX-CycleLengthCoeff      UTRAN-DRX-CycleLengthCoefficient    OPTIONAL,
    -- Core network IEs
        cn-InformationInfo              CN-InformationInfo-r6               OPTIONAL,
        signallingConnectionRelIndication   CN-DomainIdentity               OPTIONAL,
    -- UTRAN mobility IEs
        ura-Identity                    URA-Identity                        OPTIONAL,
    -- Radio bearer IEs
        rab-InformationReconfigList     RAB-InformationReconfigList         OPTIONAL,
        rb-InformationReleaseList       RB-InformationReleaseList,
        rb-InformationReconfigList      RB-InformationReconfigList-r6       OPTIONAL,
        rb-InformationAffectedList      RB-InformationAffectedList-r6       OPTIONAL,
        dl-CounterSynchronisationInfo   DL-CounterSynchronisationInfo-r5    OPTIONAL,
    -- Transport channel IEs
        ul-CommonTransChInfo            UL-CommonTransChInfo-r4             OPTIONAL,
        ul-deletedTransChInfoList       UL-DeletedTransChInfoList-r6        OPTIONAL,
        ul-AddReconfTransChInfoList     UL-AddReconfTransChInfoList-r6      OPTIONAL,
        dl-CommonTransChInfo            DL-CommonTransChInfo-r4             OPTIONAL,
        dl-DeletedTransChInfoList       DL-DeletedTransChInfoList-r5        OPTIONAL,
        dl-AddReconfTransChInfoList     DL-AddReconfTransChInfoList-r5      OPTIONAL,
    -- Physical channel IEs
```

```
        frequencyInfo                   FrequencyInfo                       OPTIONAL,
        maxAllowedUL-TX-Power           MaxAllowedUL-TX-Power               OPTIONAL,
        ul-DPCH-Info                    UL-DPCH-Info-r7                     OPTIONAL,
        ul-EDCH-Information             UL-EDCH-Information-r6              OPTIONAL,
        dl-HSPDSCH-Information          DL-HSPDSCH-Information-r7           OPTIONAL,
        dl-CommonInformation            DL-CommonInformation-r7             OPTIONAL,
        dl-InformationPerRL-List        DL-InformationPerRL-List-r7         OPTIONAL,
    -- MBMS IEs
        mbms-PL-ServiceRestrictInfo     MBMS-PL-ServiceRestrictInfo-r6      OPTIONAL,
        mbms-RB-ListReleasedToChangeTransferMode
                                        RB-InformationReleaseList           OPTIONAL
}

-- **************************************************
--
-- RADIO BEARER RELEASE COMPLETE
--
-- **************************************************

RadioBearerReleaseComplete ::= SEQUENCE {
    -- User equipment IEs
        rrc-TransactionIdentifier       RRC-TransactionIdentifier,
        ul-IntegProtActivationInfo      IntegrityProtActivationInfo         OPTIONAL,
        -- TABULAR: UL-TimingAdvance is applicable for TDD mode only.
        ul-TimingAdvance                UL-TimingAdvance                    OPTIONAL,
    -- Radio bearer IEs
        count-C-ActivationTime          ActivationTime                      OPTIONAL,
        -- dummy is not used in this version of the specification and
        -- it should be ignored by the receiver.
        dummy                           RB-ActivationTimeInfoList           OPTIONAL,
        ul-CounterSynchronisationInfo   UL-CounterSynchronisationInfo       OPTIONAL,
        laterNonCriticalExtensions      SEQUENCE {
            -- Container for additional R99 extensions
            radioBearerReleaseComplete-r3-add-ext       BIT STRING      OPTIONAL,
            v7xyNonCriticalExtensions       SEQUENCE {
                radioBearerReleaseComplete-v7xyext
                                            RadioBearerReleaseComplete-v7xyext-IEs,
                nonCriticalExtensions           SEQUENCE {}     OPTIONAL
            }   OPTIONAL
        }   OPTIONAL
}

RadioBearerReleaseComplete-v7xyext-IEs ::= SEQUENCE {
        ul-TimingAdvance-VHCR           UL-TimingAdvance-VHCR               OPTIONAL
}

-- **************************************************
--
-- RADIO BEARER RELEASE FAILURE
--
-- **************************************************

RadioBearerReleaseFailure ::= SEQUENCE {
    -- User equipment IEs
        rrc-TransactionIdentifier       RRC-TransactionIdentifier,
        failureCause                    FailureCauseWithProtErr,
    -- Radio bearer IEs
        potentiallySuccesfulBearerList  RB-IdentityList                     OPTIONAL,
        laterNonCriticalExtensions      SEQUENCE {
            -- Container for additional R99 extensions
            radioBearerReleaseFailure-r3-add-ext        BIT STRING      OPTIONAL,
            nonCriticalExtensions           SEQUENCE {}     OPTIONAL
        }   OPTIONAL
}

-- **************************************************
--
-- RADIO BEARER SETUP
--
-- **************************************************

RadioBearerSetup ::= CHOICE {
    r3                              SEQUENCE {
        radioBearerSetup-r3             RadioBearerSetup-r3-IEs,
        v3a0NonCriticalExtensions       SEQUENCE {
            radioBearerSetup-v3a0ext        RadioBearerSetup-v3a0ext,
            laterNonCriticalExtensions      SEQUENCE {
                -- Container for additional R99 extensions
```

```
                radioBearerSetup-r3-add-ext     BIT STRING      OPTIONAL,
                v4b0NonCriticalExtensions       SEQUENCE {
                    radioBearerSetup-v4b0ext        RadioBearerSetup-v4b0ext-IEs,
                    v590NonCriticalExtensions       SEQUENCE {
                        radioBearerSetup-v590ext        RadioBearerSetup-v590ext-IEs,
                        v5d0NonCriticalExtenstions      SEQUENCE {
                            radioBearerSetup-v5d0ext        RadioBearerSetup-v5d0ext-IEs,
                            v690NonCriticalExtensions       SEQUENCE {
                                radioBearerSetup-v690ext        RadioBearerSetup-v690ext-IEs,
                                nonCriticalExtensions           SEQUENCE {} OPTIONAL
                            }   OPTIONAL
                        }   OPTIONAL
                    }   OPTIONAL
                }   OPTIONAL
            }   OPTIONAL
        },
        later-than-r3                   SEQUENCE {
            rrc-TransactionIdentifier       RRC-TransactionIdentifier,
            criticalExtensions              CHOICE {
                r4                              SEQUENCE {
                    radioBearerSetup-r4             RadioBearerSetup-r4-IEs,
                    v4d0NonCriticalExtensions           SEQUENCE {
                        -- Container for adding non critical extensions after freezing REL-5
                        radioBearerSetup-r4-add-ext     BIT STRING      OPTIONAL,
                        v590NonCriticalExtensions       SEQUENCE {
                            radioBearerSetup-v590ext        RadioBearerSetup-v590ext-IEs,
                            v5d0NonCriticalExtenstions      SEQUENCE {
                                radioBearerSetup-v5d0ext        RadioBearerSetup-v5d0ext-IEs,
                                v690NonCriticalExtensions       SEQUENCE {
                                    radioBearerSetup-v690ext        RadioBearerSetup-v690ext-IEs,
                                    nonCriticalExtensions           SEQUENCE {}     OPTIONAL
                                }   OPTIONAL
                            }   OPTIONAL
                        }   OPTIONAL
                    }   OPTIONAL
                },
                criticalExtensions              CHOICE {
                    r5                              SEQUENCE {
                        radioBearerSetup-r5             RadioBearerSetup-r5-IEs,
                        -- Container for adding non critical extensions after freezing REL-6
                        radioBearerSetup-r5-add-ext     BIT STRING      OPTIONAL,
                        v5d0NonCriticalExtenstions      SEQUENCE {
                            radioBearerSetup-v5d0ext        RadioBearerSetup-v5d0ext-IEs,
                            v690NonCriticalExtensions       SEQUENCE {
                                radioBearerSetup-v690ext        RadioBearerSetup-v690ext-IEs,
                                nonCriticalExtensions           SEQUENCE {}     OPTIONAL
                            }   OPTIONAL
                        }   OPTIONAL
                    },
                    criticalExtensions              CHOICE {
                        r6                              SEQUENCE {
                            radioBearerSetup-r6             RadioBearerSetup-r6-IEs,
                            -- Container for adding non critical extensions after freezing REL-7
                            radioBearerSetup-r6-add-ext     BIT STRING      OPTIONAL,
                            nonCriticalExtensions           SEQUENCE {}     OPTIONAL
                        },
                        criticalExtensions              CHOICE {
                            r7                              SEQUENCE {
                                radioBearerSetup-r7             RadioBearerSetup-r7-IEs,
                                -- Container for adding non critical extensions after freezing REL-8
                                radioBearerSetup-r7-add-ext     BIT STRING      OPTIONAL,
                                nonCriticalExtensions           SEQUENCE {}     OPTIONAL
                            },
                            criticalExtensions              SEQUENCE {}
                        }
                    }
                }
            }
        }
    }
}

RadioBearerSetup-r3-IEs ::= SEQUENCE {
    -- User equipment IEs
        rrc-TransactionIdentifier       RRC-TransactionIdentifier,
        integrityProtectionModeInfo     IntegrityProtectionModeInfo         OPTIONAL,
        cipheringModeInfo               CipheringModeInfo                   OPTIONAL,
        activationTime                  ActivationTime                      OPTIONAL,
```

```
        new-U-RNTI                      U-RNTI                                  OPTIONAL,
        new-C-RNTI                      C-RNTI                                  OPTIONAL,
        rrc-StateIndicator              RRC-StateIndicator,
        utran-DRX-CycleLengthCoeff      UTRAN-DRX-CycleLengthCoefficient        OPTIONAL,
    -- UTRAN mobility IEs
        ura-Identity                    URA-Identity                            OPTIONAL,
    -- Core network IEs
        cn-InformationInfo              CN-InformationInfo                      OPTIONAL,
    -- Radio bearer IEs
        srb-InformationSetupList        SRB-InformationSetupList                OPTIONAL,
        rab-InformationSetupList        RAB-InformationSetupList                OPTIONAL,
        rb-InformationAffectedList      RB-InformationAffectedList              OPTIONAL,
        dl-CounterSynchronisationInfo   DL-CounterSynchronisationInfo           OPTIONAL,
    -- Transport channel IEs
        ul-CommonTransChInfo            UL-CommonTransChInfo                    OPTIONAL,
        ul-deletedTransChInfoList       UL-DeletedTransChInfoList               OPTIONAL,
        ul-AddReconfTransChInfoList     UL-AddReconfTransChInfoList             OPTIONAL,
        -- 'dummy', 'dummy1' and 'dummy2' are not used in this version of the specification,
        -- they should not be sent and if received they should be ignored.
        dummy                           CHOICE {
            fdd                             SEQUENCE {
                dummy1                          CPCH-SetID                      OPTIONAL,
                dummy2                          DRAC-StaticInformationList      OPTIONAL
            },
            tdd                             NULL
        }                                                                       OPTIONAL,
        dl-CommonTransChInfo            DL-CommonTransChInfo                    OPTIONAL,
        dl-DeletedTransChInfoList       DL-DeletedTransChInfoList               OPTIONAL,
        dl-AddReconfTransChInfoList     DL-AddReconfTransChInfoList             OPTIONAL,
    -- Physical channel IEs
        frequencyInfo                   FrequencyInfo                           OPTIONAL,
        maxAllowedUL-TX-Power           MaxAllowedUL-TX-Power                   OPTIONAL,
        ul-ChannelRequirement           UL-ChannelRequirement                   OPTIONAL,
        modeSpecificPhysChInfo          CHOICE {
            fdd                             SEQUENCE {
                -- dummy is not used in this version of specification, it should
                -- not be sent and if received it should be ignored.
                dummy                           DL-PDSCH-Information            OPTIONAL
            },
            tdd                             NULL
        },
        dl-CommonInformation            DL-CommonInformation                    OPTIONAL,
        dl-InformationPerRL-List        DL-InformationPerRL-List                OPTIONAL
}

RadioBearerSetup-v3a0ext ::= SEQUENCE {
    -- The IE 'new-DSCH-RNTI' should not be included in FDD mode, and if received the UE behaviour
    -- is unspecified
    new-DSCH-RNTI                   DSCH-RNTI                               OPTIONAL
}

RadioBearerSetup-v4b0ext-IEs ::= SEQUENCE {
    -- Physical channel IEs
        -- dummy is not used in this version of the specification, it should
        -- not be sent and if received it should be ignored.
        dummy                           SSDT-UL                                 OPTIONAL,
        -- The order of the RLs in IE cell-id-PerRL-List is the same as
        -- in IE DL-InformationPerRL-List included in this message
        cell-id-PerRL-List              CellIdentity-PerRL-List                 OPTIONAL
}

RadioBearerSetup-v590ext-IEs ::= SEQUENCE {
    -- Physical channel IEs
        dl-TPC-PowerOffsetPerRL-List    DL-TPC-PowerOffsetPerRL-List            OPTIONAL
}

RadioBearerSetup-v5d0ext-IEs ::=    SEQUENCE {
    --Radio Bearer IEs
        pdcp-ROHC-TargetMode            PDCP-ROHC-TargetMode                    OPTIONAL
}

RadioBearerSetup-r4-IEs ::= SEQUENCE {
    -- User equipment IEs
        integrityProtectionModeInfo     IntegrityProtectionModeInfo             OPTIONAL,
        cipheringModeInfo               CipheringModeInfo                       OPTIONAL,
        activationTime                  ActivationTime                          OPTIONAL,
        new-U-RNTI                      U-RNTI                                  OPTIONAL,
        new-C-RNTI                      C-RNTI                                  OPTIONAL,
```

```
        -- The IE 'new-DSCH-RNTI' should not be included in FDD mode, and if received
        -- the UE behaviour is unspecified
        new-DSCH-RNTI                   DSCH-RNTI                           OPTIONAL,
        rrc-StateIndicator              RRC-StateIndicator,
        utran-DRX-CycleLengthCoeff      UTRAN-DRX-CycleLengthCoefficient    OPTIONAL,
    -- UTRAN mobility IEs
        ura-Identity                    URA-Identity                        OPTIONAL,
    -- Core network IEs
        cn-InformationInfo              CN-InformationInfo                  OPTIONAL,
    -- Radio bearer IEs
        srb-InformationSetupList        SRB-InformationSetupList            OPTIONAL,
        rab-InformationSetupList        RAB-InformationSetupList-r4         OPTIONAL,
        rb-InformationAffectedList      RB-InformationAffectedList          OPTIONAL,
        dl-CounterSynchronisationInfo   DL-CounterSynchronisationInfo       OPTIONAL,
    -- Transport channel IEs
        ul-CommonTransChInfo            UL-CommonTransChInfo-r4             OPTIONAL,
        ul-deletedTransChInfoList       UL-DeletedTransChInfoList           OPTIONAL,
        ul-AddReconfTransChInfoList     UL-AddReconfTransChInfoList         OPTIONAL,
        -- 'dummy', 'dummy1' and 'dummy2' are not used in this version of the specification,
        -- they should not be sent and if received they should be ignored.
        dummy                           CHOICE {
            fdd                             SEQUENCE {
                dummy1                          CPCH-SetID                  OPTIONAL,
                dummy2                          DRAC-StaticInformationList  OPTIONAL
            },
            tdd                             NULL
        }                                                                   OPTIONAL,
        dl-CommonTransChInfo            DL-CommonTransChInfo-r4             OPTIONAL,
        dl-DeletedTransChInfoList       DL-DeletedTransChInfoList           OPTIONAL,
        dl-AddReconfTransChInfoList     DL-AddReconfTransChInfoList-r4      OPTIONAL,
    -- Physical channel IEs
        frequencyInfo                   FrequencyInfo                       OPTIONAL,
        maxAllowedUL-TX-Power           MaxAllowedUL-TX-Power               OPTIONAL,
        ul-ChannelRequirement           UL-ChannelRequirement-r4            OPTIONAL,
        modeSpecificPhysChInfo          CHOICE {
            fdd                             SEQUENCE {
                -- dummy is not used in this version of specification, it should
                -- not be sent and if received it should be ignored.
                dummy                           DL-PDSCH-Information        OPTIONAL
            },
            tdd                             NULL
        },
        dl-CommonInformation            DL-CommonInformation-r4             OPTIONAL,
        dl-InformationPerRL-List        DL-InformationPerRL-List-r4         OPTIONAL
}

RadioBearerSetup-r5-IEs ::= SEQUENCE {
    -- User equipment IEs
        integrityProtectionModeInfo     IntegrityProtectionModeInfo         OPTIONAL,
        cipheringModeInfo               CipheringModeInfo                   OPTIONAL,
        activationTime                  ActivationTime                      OPTIONAL,
        new-U-RNTI                      U-RNTI                              OPTIONAL,
        new-C-RNTI                      C-RNTI                              OPTIONAL,
        -- The IE 'new-DSCH-RNTI' should not be included in FDD mode, and if received
        -- the UE behaviour is unspecified
        new-DSCH-RNTI                   DSCH-RNTI                           OPTIONAL,
        new-H-RNTI                      H-RNTI                              OPTIONAL,
        rrc-StateIndicator              RRC-StateIndicator,
        utran-DRX-CycleLengthCoeff      UTRAN-DRX-CycleLengthCoefficient    OPTIONAL,
    -- UTRAN mobility IEs
        ura-Identity                    URA-Identity                        OPTIONAL,
    -- Core network IEs
        cn-InformationInfo              CN-InformationInfo                  OPTIONAL,
    -- Radio bearer IEs
        srb-InformationSetupList        SRB-InformationSetupList-r5         OPTIONAL,
        rab-InformationSetupList        RAB-InformationSetupList-r5         OPTIONAL,
        rb-InformationAffectedList      RB-InformationAffectedList-r5       OPTIONAL,
        dl-CounterSynchronisationInfo   DL-CounterSynchronisationInfo-r5    OPTIONAL,
    -- Transport channel IEs
        ul-CommonTransChInfo            UL-CommonTransChInfo-r4             OPTIONAL,
        ul-deletedTransChInfoList       UL-DeletedTransChInfoList           OPTIONAL,
        ul-AddReconfTransChInfoList     UL-AddReconfTransChInfoList         OPTIONAL,
        -- 'dummy', 'dummy1' and 'dummy2' are not used in this version of the specification,
        -- they should not be sent and if received they should be ignored.
        dummy                           CHOICE {
            fdd                             SEQUENCE {
                dummy1                          CPCH-SetID                  OPTIONAL,
                dummy2                          DRAC-StaticInformationList  OPTIONAL
```

```
            },
            tdd                             NULL
        }                                                               OPTIONAL,
        dl-CommonTransChInfo            DL-CommonTransChInfo-r4         OPTIONAL,
        dl-DeletedTransChInfoList       DL-DeletedTransChInfoList-r5    OPTIONAL,
        dl-AddReconfTransChInfoList     DL-AddReconfTransChInfoList-r5  OPTIONAL,
    -- Physical channel IEs
        frequencyInfo                   FrequencyInfo                   OPTIONAL,
        maxAllowedUL-TX-Power           MaxAllowedUL-TX-Power           OPTIONAL,
        ul-ChannelRequirement           UL-ChannelRequirement-r5        OPTIONAL,
        modeSpecificPhysChInfo          CHOICE {
            fdd                             SEQUENCE {
                -- dummy is not used in this version of specification, it should
                -- not be sent and if received it should be ignored.
                dummy                           DL-PDSCH-Information    OPTIONAL
            },
            tdd                             NULL
        },
        dl-HSPDSCH-Information          DL-HSPDSCH-Information          OPTIONAL,
        dl-CommonInformation            DL-CommonInformation-r5         OPTIONAL,
        dl-InformationPerRL-List        DL-InformationPerRL-List-r5     OPTIONAL
}

RadioBearerSetup-v690ext-IEs ::= SEQUENCE {
    -- Core network IEs
        primary-plmn-Identity           PLMN-Identity                   OPTIONAL,
    -- Physical channel IEs
        -- The IE harq-Preamble-Mode should not be used in the r3 and r4 versions of the message
        -- If included in the r3 or r4 version of the message, the UE should ignore the IE
        harq-Preamble-Mode              HARQ-Preamble-Mode              OPTIONAL,
        beaconPLEst                     BEACON-PL-Est                   OPTIONAL,
        postVerificationPeriod          ENUMERATED { true }             OPTIONAL,
        dhs-sync                        DHS-Sync                        OPTIONAL,
        timingMaintainedSynchInd        TimingMaintainedSynchInd        OPTIONAL,
    -- Radio bearer IEs
        rab-InformationSetupList        RAB-InformationSetupList-r6-ext OPTIONAL,
    -- MBMS IEs
        mbms-PL-ServiceRestrictInfo     MBMS-PL-ServiceRestrictInfo-r6  OPTIONAL
}

RadioBearerSetup-r6-IEs ::= SEQUENCE {
    -- User equipment IEs
        integrityProtectionModeInfo     IntegrityProtectionModeInfo     OPTIONAL,
        cipheringModeInfo               CipheringModeInfo               OPTIONAL,
        activationTime                  ActivationTime                  OPTIONAL,
        new-U-RNTI                      U-RNTI                          OPTIONAL,
        new-C-RNTI                      C-RNTI                          OPTIONAL,
        -- The IE 'new-DSCH-RNTI' should not be included in FDD mode,
        -- and if received the UE behaviour is unspecified
        new-DSCH-RNTI                   DSCH-RNTI                       OPTIONAL,
        new-H-RNTI                      H-RNTI                          OPTIONAL,
        newPrimary-E-RNTI               E-RNTI                          OPTIONAL,
        newSecondary-E-RNTI             E-RNTI                          OPTIONAL,
        rrc-StateIndicator              RRC-StateIndicator,
        utran-DRX-CycleLengthCoeff      UTRAN-DRX-CycleLengthCoefficient OPTIONAL,
    -- UTRAN mobility IEs
        ura-Identity                    URA-Identity                    OPTIONAL,
    -- Core network IEs
        cn-InformationInfo              CN-InformationInfo-r6           OPTIONAL,
        specificationMode               CHOICE {
            complete                        SEQUENCE {
            -- Radio bearer IEs
                srb-InformationSetupList        SRB-InformationSetupList-r6         OPTIONAL,
                rab-InformationSetupList        RAB-InformationSetupList-r6         OPTIONAL,
                rab-InformationReconfigList     RAB-InformationReconfigList         OPTIONAL,
                rb-InformationReconfigList      RB-InformationReconfigList-r6       OPTIONAL,
                rb-InformationAffectedList      RB-InformationAffectedList-r6       OPTIONAL,
                dl-CounterSynchronisationInfo   DL-CounterSynchronisationInfo-r5    OPTIONAL,
                pdcp-ROHC-TargetMode            PDCP-ROHC-TargetMode                OPTIONAL,
            -- Transport channel IEs
                ul-CommonTransChInfo            UL-CommonTransChInfo-r4             OPTIONAL,
                ul-deletedTransChInfoList       UL-DeletedTransChInfoList-r6        OPTIONAL,
                ul-AddReconfTransChInfoList     UL-AddReconfTransChInfoList-r6      OPTIONAL,
                dl-CommonTransChInfo            DL-CommonTransChInfo-r4             OPTIONAL,
                dl-DeletedTransChInfoList       DL-DeletedTransChInfoList-r5        OPTIONAL,
                dl-AddReconfTransChInfoList     DL-AddReconfTransChInfoList-r5      OPTIONAL
            },
            preconfiguration                SEQUENCE {
```

```
                rab-Info                        RAB-Info-r6,
                defaultConfigMode               DefaultConfigMode,
                defaultConfigIdentity           DefaultConfigIdentity-r6,
                rb-InformationChangedList       RB-InformationChangedList-r6        OPTIONAL,
                powerOffsetInfoShort            PowerOffsetInfoShort
            }
        },
    -- Physical channel IEs
        frequencyInfo                   FrequencyInfo                       OPTIONAL,
        maxAllowedUL-TX-Power           MaxAllowedUL-TX-Power               OPTIONAL,
        ul-DPCH-Info                    UL-DPCH-Info-r6                     OPTIONAL,
        ul-EDCH-Information             UL-EDCH-Information-r6              OPTIONAL,
        dl-HSPDSCH-Information          DL-HSPDSCH-Information-r6           OPTIONAL,
        dl-CommonInformation            DL-CommonInformation-r6             OPTIONAL,
        dl-InformationPerRL-List        DL-InformationPerRL-List-r6         OPTIONAL,
    -- MBMS IEs
        mbms-PL-ServiceRestrictInfo     MBMS-PL-ServiceRestrictInfo-r6      OPTIONAL
}

RadioBearerSetup-r7-IEs ::= SEQUENCE {
    -- User equipment IEs
        integrityProtectionModeInfo     IntegrityProtectionModeInfo         OPTIONAL,
        cipheringModeInfo               CipheringModeInfo                   OPTIONAL,
        activationTime                  ActivationTime                      OPTIONAL,
        new-U-RNTI                      U-RNTI                              OPTIONAL,
        new-C-RNTI                      C-RNTI                              OPTIONAL,
        -- The IE 'new-DSCH-RNTI' should not be included in FDD mode,
        -- and if received the UE behaviour is unspecified
        new-DSCH-RNTI                   DSCH-RNTI                           OPTIONAL,
        new-H-RNTI                      H-RNTI                              OPTIONAL,
        newPrimary-E-RNTI               E-RNTI                              OPTIONAL,
        newSecondary-E-RNTI             E-RNTI                              OPTIONAL,
        rrc-StateIndicator              RRC-StateIndicator,
        utran-DRX-CycleLengthCoeff      UTRAN-DRX-CycleLengthCoefficient    OPTIONAL,
    -- UTRAN mobility IEs
        ura-Identity                    URA-Identity                        OPTIONAL,
    -- Core network IEs
        cn-InformationInfo              CN-InformationInfo-r6               OPTIONAL,
        specificationMode               CHOICE {
            complete                        SEQUENCE {
            -- Radio bearer IEs
                srb-InformationSetupList        SRB-InformationSetupList-r6         OPTIONAL,
                rab-InformationSetupList        RAB-InformationSetupList-r6         OPTIONAL,
                rb-InformationReconfigList      RB-InformationReconfigList-r6       OPTIONAL,
                rb-InformationAffectedList      RB-InformationAffectedList-r6       OPTIONAL,
                dl-CounterSynchronisationInfo   DL-CounterSynchronisationInfo-r5    OPTIONAL,
                pdcp-ROHC-TargetMode            PDCP-ROHC-TargetMode                OPTIONAL,
            -- Transport channel IEs
                ul-CommonTransChInfo            UL-CommonTransChInfo-r4             OPTIONAL,
                ul-deletedTransChInfoList       UL-DeletedTransChInfoList-r6        OPTIONAL,
                ul-AddReconfTransChInfoList     UL-AddReconfTransChInfoList-r6      OPTIONAL,
                dl-CommonTransChInfo            DL-CommonTransChInfo-r4             OPTIONAL,
                dl-DeletedTransChInfoList       DL-DeletedTransChInfoList-r5        OPTIONAL,
                dl-AddReconfTransChInfoList     DL-AddReconfTransChInfoList-r5      OPTIONAL
            },
            preconfiguration                SEQUENCE {
                rab-Info                        RAB-Info-r6,
                defaultConfigMode               DefaultConfigMode,
                defaultConfigIdentity           DefaultConfigIdentity-r5,
                rb-InformationChangedList       RB-InformationChangedList-r6        OPTIONAL,
                powerOffsetInfoShort            PowerOffsetInfoShort
            }
        },
    -- Physical channel IEs
        frequencyInfo                   FrequencyInfo                       OPTIONAL,
        maxAllowedUL-TX-Power           MaxAllowedUL-TX-Power               OPTIONAL,
        ul-DPCH-Info                    UL-DPCH-Info-r7                     OPTIONAL,
        ul-EDCH-Information             UL-EDCH-Information-r6              OPTIONAL,
        dl-HSPDSCH-Information          DL-HSPDSCH-Information-r7           OPTIONAL,
        dl-CommonInformation            DL-CommonInformation-r7             OPTIONAL,
        dl-InformationPerRL-List        DL-InformationPerRL-List-r7         OPTIONAL,
    -- MBMS IEs
        mbms-PL-ServiceRestrictInfo     MBMS-PL-ServiceRestrictInfo-r6      OPTIONAL
}

-- **************************************************
--
-- RADIO BEARER SETUP COMPLETE
```

```
--
-- **************************************************

RadioBearerSetupComplete ::= SEQUENCE {
    -- User equipment IEs
        rrc-TransactionIdentifier       RRC-TransactionIdentifier,
        ul-IntegProtActivationInfo      IntegrityProtActivationInfo         OPTIONAL,
        -- TABULAR: UL-TimingAdvance is applicable for TDD mode only.
        ul-TimingAdvance                UL-TimingAdvance                    OPTIONAL,
        start-Value             START-Value                                 OPTIONAL,
    -- Radio bearer IEs
        count-C-ActivationTime          ActivationTime                      OPTIONAL,
        -- dummy is not used in this version of the specification and
        -- it should be ignored by the receiver.
        dummy                           RB-ActivationTimeInfoList           OPTIONAL,
        ul-CounterSynchronisationInfo   UL-CounterSynchronisationInfo       OPTIONAL,
        laterNonCriticalExtensions      SEQUENCE {
            -- Container for additional R99 extensions
            radioBearerSetupComplete-r3-add-ext     BIT STRING      OPTIONAL,
            v7xyNonCriticalExtensions       SEQUENCE {
                radioBearerSetupComplete-v7xyext
                                            RadioBearerSetupComplete-v7xyext-IEs,
                nonCriticalExtensions           SEQUENCE {}     OPTIONAL
            }   OPTIONAL
        }   OPTIONAL
}

RadioBearerSetupComplete-v7xyext-IEs ::= SEQUENCE {
        ul-TimingAdvance-VHCR           UL-TimingAdvance-VHCR               OPTIONAL
}

-- **************************************************
--
-- RADIO BEARER SETUP FAILURE
--
-- **************************************************

RadioBearerSetupFailure ::= SEQUENCE {
    -- User equipment IEs
        rrc-TransactionIdentifier       RRC-TransactionIdentifier,
        failureCause                    FailureCauseWithProtErr,
    -- Radio bearer IEs
        potentiallySuccesfulBearerList  RB-IdentityList                     OPTIONAL,
        laterNonCriticalExtensions      SEQUENCE {
            -- Container for additional R99 extensions
            radioBearerSetupFailure-r3-add-ext      BIT STRING      OPTIONAL,
            nonCriticalExtensions           SEQUENCE {}     OPTIONAL
        }   OPTIONAL
}

-- **************************************************
--
-- RRC CONNECTION REJECT
--
-- **************************************************

RRCConnectionReject ::= CHOICE {
    r3                              SEQUENCE {
        rrcConnectionReject-r3          RRCConnectionReject-r3-IEs,
        laterNonCriticalExtensions      SEQUENCE {
            -- Container for additional R99 extensions
            rrcConnectionReject-r3-add-ext      BIT STRING      OPTIONAL,
            v690NonCriticalExtensions           SEQUENCE {
                rrcConnectionReject-v690ext     RRCConnectionReject-v690ext-IEs,
                nonCriticalExtensions           SEQUENCE {}     OPTIONAL
            }   OPTIONAL
        }   OPTIONAL
    },
    later-than-r3                   SEQUENCE {
        initialUE-Identity              InitialUE-Identity,
        rrc-TransactionIdentifier       RRC-TransactionIdentifier,
        criticalExtensions              SEQUENCE {}
    }
}

RRCConnectionReject-r3-IEs ::= SEQUENCE {
    -- TABULAR: Integrity protection shall not be performed on this message.
    -- User equipment IEs
```

```
        initialUE-Identity              InitialUE-Identity,
        rrc-TransactionIdentifier       RRC-TransactionIdentifier,
        rejectionCause                  RejectionCause,
        waitTime                        WaitTime,
        redirectionInfo                 RedirectionInfo                     OPTIONAL
}

RRCConnectionReject-v690ext-IEs ::= SEQUENCE {
    redirectionInfo-v690ext             GSM-TargetCellInfoList          OPTIONAL
}

-- **************************************************
--
-- RRC CONNECTION RELEASE
--
-- **************************************************

RRCConnectionRelease ::= CHOICE {
    r3                              SEQUENCE {
        rrcConnectionRelease-r3         RRCConnectionRelease-r3-IEs,
        laterNonCriticalExtensions      SEQUENCE {
            -- Container for additional R99 extensions
            rrcConnectionRelease-r3-add-ext     BIT STRING      OPTIONAL,
            v690NonCriticalExtensions           SEQUENCE {
                rrcConnectionRelease-v690ext    RRCConnectionRelease-v690ext-IEs,
                nonCriticalExtensions           SEQUENCE {}     OPTIONAL
            }   OPTIONAL
        }   OPTIONAL
    },
    later-than-r3                   SEQUENCE {
        rrc-TransactionIdentifier       RRC-TransactionIdentifier,
        criticalExtensions              CHOICE {
            r4                              SEQUENCE {
                rrcConnectionRelease-r4         RRCConnectionRelease-r4-IEs,
                v4d0NonCriticalExtensions           SEQUENCE {
                    -- Container for adding non critical extensions after freezing REL-6
                    rrcConnectionRelease-r4-add-ext     BIT STRING      OPTIONAL,
                    v690NonCriticalExtensions           SEQUENCE {
                        rrcConnectionRelease-v690ext
                                                        RRCConnectionRelease-v690ext-IEs,
                        nonCriticalExtensions           SEQUENCE {}     OPTIONAL
                    }   OPTIONAL
                }   OPTIONAL
            },
            criticalExtensions              SEQUENCE {}
        }
    }
}

RRCConnectionRelease-r3-IEs ::= SEQUENCE {
    -- User equipment IEs
        rrc-TransactionIdentifier       RRC-TransactionIdentifier,
        -- n-308 is conditional on the UE state
        n-308                           N-308                               OPTIONAL,
        releaseCause                    ReleaseCause,
        rplmn-information               Rplmn-Information                   OPTIONAL
}

RRCConnectionRelease-r4-IEs ::= SEQUENCE {
    -- User equipment IEs
        -- n-308 is conditional on the UE state.
        n-308                           N-308                               OPTIONAL,
        releaseCause                    ReleaseCause,
        rplmn-information               Rplmn-Information-r4                OPTIONAL
}

RRCConnectionRelease-v690ext-IEs ::= SEQUENCE {
    redirectionInfo-v690ext             RedirectionInfo-r6  OPTIONAL
}

-- **************************************************
--
-- RRC CONNECTION RELEASE for CCCH
--
-- **************************************************

RRCConnectionRelease-CCCH ::= CHOICE {
    r3                              SEQUENCE {
```

```
        rrcConnectionRelease-CCCH-r3    RRCConnectionRelease-CCCH-r3-IEs,
        laterNonCriticalExtensions      SEQUENCE {
            -- Container for additional R99 extensions
            rrcConnectionRelease-CCCH-r3-add-ext        BIT STRING      OPTIONAL,
            v690NonCriticalExtensions       SEQUENCE {
                rrcConnectionRelease-v690ext    RRCConnectionRelease-CCCH-v690ext-IEs,
                nonCriticalExtensions           SEQUENCE {} OPTIONAL
            }   OPTIONAL
        }   OPTIONAL
    },
    later-than-r3                   SEQUENCE {
        u-RNTI                          U-RNTI,
        rrc-TransactionIdentifier       RRC-TransactionIdentifier,
        criticalExtensions              CHOICE {
            r4                              SEQUENCE {
                rrcConnectionRelease-CCCH-r4    RRCConnectionRelease-CCCH-r4-IEs,
                v4d0NonCriticalExtensions           SEQUENCE {
                    -- Container for adding non critical extensions after freezing REL-5
                    rrcConnectionRelease-CCCH-r4-add-ext        BIT STRING      OPTIONAL,
                    v690NonCriticalExtensions       SEQUENCE {
                        rrcConnectionRelease-v690ext    RRCConnectionRelease-CCCH-v690ext-IEs,
                        nonCriticalExtensions           SEQUENCE {}     OPTIONAL
                    }   OPTIONAL
                }       OPTIONAL
            },
            criticalExtensions              SEQUENCE {
                -- TABULAR: CHOICE IdentityType (U-RNTI, GroupIdentity) is replaced with the
                -- optional element groupIdentity, since the U-RNTI is mandatory in ASN.1.
                -- In case CHOICE IdentityType is equal to GroupIdentity the value of the U-RNTI
                -- shall be ignored by a UE complying with this version of the message.
                groupIdentity       SEQUENCE ( SIZE (1 .. maxURNTI-Group) ) OF
                                        GroupReleaseInformation     OPTIONAL,
                criticalExtensions              CHOICE {
                    r5                              SEQUENCE {
                        rrcConnectionRelease-CCCH-r5    RRCConnectionRelease-CCCH-r5-IEs,
                        -- Container for adding non critical extensions after freezing REL-6
                        rrcConnectionRelease-CCCH-r5-add-ext        BIT STRING      OPTIONAL,
                        v690NonCriticalExtensions       SEQUENCE {
                            rrcConnectionRelease-v690ext    RRCConnectionRelease-CCCH-v690ext-IEs,
                            nonCriticalExtensions           SEQUENCE {} OPTIONAL
                        }   OPTIONAL
                    },
                    criticalExtensions              SEQUENCE {}
                }
            }
        }
    }
}

RRCConnectionRelease-CCCH-r3-IEs ::= SEQUENCE {
    -- User equipment IEs
        u-RNTI                          U-RNTI,
    -- The rest of the message is identical to the one sent on DCCH.
        rrcConnectionRelease            RRCConnectionRelease-r3-IEs
}

RRCConnectionRelease-CCCH-r4-IEs ::= SEQUENCE {
    -- The rest of the message is identical to the one sent on DCCH.
        rrcConnectionRelease            RRCConnectionRelease-r4-IEs
}

-- The R5 and R4 sequence of IEs are identical in this message
RRCConnectionRelease-CCCH-r5-IEs ::= RRCConnectionRelease-CCCH-r4-IEs

-- The R6 non-critical extension is identical to the one sent on DCCH.
RRCConnectionRelease-CCCH-v690ext-IEs ::= RRCConnectionRelease-v690ext-IEs

-- **************************************************
--
-- RRC CONNECTION RELEASE COMPLETE
--
-- **************************************************

RRCConnectionReleaseComplete ::= SEQUENCE {
    -- User equipment IEs
        rrc-TransactionIdentifier       RRC-TransactionIdentifier,
        errorIndication                 FailureCauseWithProtErr             OPTIONAL,
        laterNonCriticalExtensions      SEQUENCE {
```

```
            -- Container for additional R99 extensions
            rrcConnectionReleaseComplete-r3-add-ext     BIT STRING      OPTIONAL,
            nonCriticalExtensions           SEQUENCE {}     OPTIONAL
        }   OPTIONAL
}

-- **************************************************
--
-- RRC CONNECTION REQUEST
--
-- **************************************************

RRCConnectionRequest ::= SEQUENCE {
    -- TABULAR: Integrity protection shall not be performed on this message.
    -- User equipment IEs
        initialUE-Identity              InitialUE-Identity,
        establishmentCause              EstablishmentCause,
        -- protocolErrorIndicator is MD, but for compactness reasons no default value
        -- has been assigned to it.
        protocolErrorIndicator          ProtocolErrorIndicator,
    -- Measurement IEs
        measuredResultsOnRACH           MeasuredResultsOnRACH               OPTIONAL,
    --  Non critical Extensions
        v3d0NonCriticalExtensions           SEQUENCE {
            rRCConnectionRequest-v3d0ext    RRCConnectionRequest-v3d0ext-IEs,
        -- Reserved for future non critical extension
            v4b0NonCriticalExtensions           SEQUENCE {
                rrcConnectionRequest-v4b0ext        RRCConnectionRequest-v4b0ext-IEs,
                v590NonCriticalExtensions           SEQUENCE {
                    rrcConnectionRequest-v590ext        RRCConnectionRequest-v590ext-IEs,
                    v690NonCriticalExtensions           SEQUENCE {
                        rrcConnectionRequest-v690ext    RRCConnectionRequest-v690ext-IEs,
                        -- Reserved for future non critical extension
                        nonCriticalExtensions           SEQUENCE {}     OPTIONAL
                    }   OPTIONAL
                }   OPTIONAL
            }   OPTIONAL
        }   OPTIONAL
}

RRCConnectionRequest-v3d0ext-IEs ::= SEQUENCE {
    -- User equipment IEs
        uESpecificBehaviourInformation1idle     UESpecificBehaviourInformation1idle     OPTIONAL
}

RRCConnectionRequest-v4b0ext-IEs ::=    SEQUENCE {
    -- User equipment IEs
        accessStratumReleaseIndicator           AccessStratumReleaseIndicator
}

RRCConnectionRequest-v590ext-IEs ::=    SEQUENCE {
    -- User equipment IEs
        predefinedConfigStatusInfo          BOOLEAN
}

RRCConnectionRequest-v690ext-IEs ::=    SEQUENCE {
    -- User equipment IEs
        ueCapabilityIndication              ENUMERATED { hsdch, hsdch-edch }    OPTIONAL,
    -- Measurement IEs
        measuredResultsOnRACHinterFreq      MeasuredResultsOnRACHinterFreq          OPTIONAL,
        domainIndicator                     CHOICE {
            cs-domain                           SEQUENCE {
                csCallType                          ENUMERATED {speech, video, other, spare }
            },
            ps-domain                           NULL
        }
}

-- **************************************************
--
-- RRC CONNECTION SETUP
--
-- **************************************************

RRCConnectionSetup ::= CHOICE {
    r3                              SEQUENCE {
        rrcConnectionSetup-r3           RRCConnectionSetup-r3-IEs,
        laterNonCriticalExtensions      SEQUENCE {
```

```
            -- Container for additional R99 extensions
            rrcConnectionSetup-r3-add-ext   BIT STRING      OPTIONAL,
            v4b0NonCriticalExtensions       SEQUENCE {
                rrcConnectionSetup-v4b0ext      RRCConnectionSetup-v4b0ext-IEs,
                v590NonCriticalExtensions       SEQUENCE {
                    rrcConnectionSetup-v590ext      RRCConnectionSetup-v590ext-IEs,
                    v690NonCriticalExtensions       SEQUENCE {
                        rrcConnectionSetup-v690ext      RRCConnectionSetup-v690ext-IEs,
                        v7xyNonCriticalExtensions       SEQUENCE {
                            rrcConnectionSetup-v7xyext      RRCConnectionSetup-v7xyext-IEs,
                            nonCriticalExtensions           SEQUENCE {}     OPTIONAL
                        }   OPTIONAL
                    }   OPTIONAL
                }   OPTIONAL
            }   OPTIONAL
        }   OPTIONAL
    },
    later-than-r3                   SEQUENCE {
        initialUE-Identity              InitialUE-Identity,
        rrc-TransactionIdentifier       RRC-TransactionIdentifier,
        criticalExtensions              CHOICE {
            r4                              SEQUENCE {
                rrcConnectionSetup-r4           RRCConnectionSetup-r4-IEs,
                v4d0NonCriticalExtensions           SEQUENCE {
                    -- Container for adding non critical extensions after freezing REL-5
                    rrcConnectionSetup-r4-add-ext   BIT STRING      OPTIONAL,
                    v590NonCriticalExtensions       SEQUENCE {
                        rrcConnectionSetup-v590ext      RRCConnectionSetup-v590ext-IEs,
                        v690NonCriticalExtensions       SEQUENCE {
                            rrcConnectionSetup-v690ext      RRCConnectionSetup-v690ext-IEs,
                            v7xyNonCriticalExtensions       SEQUENCE {
                                rrcConnectionSetup-v7xyext      RRCConnectionSetup-v7xyext-IEs,
                                nonCriticalExtensions           SEQUENCE {}     OPTIONAL
                            }   OPTIONAL
                        }   OPTIONAL
                    }   OPTIONAL
                }   OPTIONAL
            },
            criticalExtensions              CHOICE {
                r5                              SEQUENCE {
                    rrcConnectionSetup-r5           RRCConnectionSetup-r5-IEs,
                    -- Container for adding non critical extensions after freezing REL-6
                    rrcConnectionSetup-r5-add-ext   BIT STRING      OPTIONAL,
                    v690NonCriticalExtensions       SEQUENCE {
                        rrcConnectionSetup-v690ext      RRCConnectionSetup-v690ext-IEs,
                        v7xyNonCriticalExtensions       SEQUENCE {
                            rrcConnectionSetup-v7xyext      RRCConnectionSetup-v7xyext-IEs,
                            nonCriticalExtensions           SEQUENCE {}     OPTIONAL
                        }   OPTIONAL
                    }   OPTIONAL
                },
                criticalExtensions              CHOICE {
                    r6                              SEQUENCE {
                        rrcConnectionSetup-r6           RRCConnectionSetup-r6-IEs,
                        -- Container for adding non critical extensions after freezing REL-7
                        rrcConnectionSetup-r6-add-ext   BIT STRING                  OPTIONAL,
                        v7xyNonCriticalExtensions       SEQUENCE {
                            rrcConnectionSetup-v7xyext      RRCConnectionSetup-v7xyext-IEs,
                            nonCriticalExtensions           SEQUENCE {}                 OPTIONAL
                        }   OPTIONAL
                    },
                    criticalExtensions              CHOICE {
                        r7                              SEQUENCE {
                            rrcConnectionSetup-r7           RRCConnectionSetup-r7-IEs,
                            -- Container for adding non critical extensions after freezing REL-8
                            rrcConnectionSetup-r7-add-ext   BIT STRING                  OPTIONAL,
                            nonCriticalExtensions           SEQUENCE {}                 OPTIONAL
                        },
                        criticalExtensions              SEQUENCE {}
                    }
                }
            }
        }
    }
}

RRCConnectionSetup-r3-IEs ::= SEQUENCE {
    -- TABULAR: Integrity protection shall not be performed on this message.
```

```
    -- User equipment IEs
        initialUE-Identity              InitialUE-Identity,
        rrc-TransactionIdentifier       RRC-TransactionIdentifier,
        activationTime                  ActivationTime                      OPTIONAL,
        new-U-RNTI                      U-RNTI,
        new-c-RNTI                      C-RNTI                              OPTIONAL,
        rrc-StateIndicator              RRC-StateIndicator,
        utran-DRX-CycleLengthCoeff      UTRAN-DRX-CycleLengthCoefficient,
        -- TABULAR: If capabilityUpdateRequirement is not present, the default value
        -- defined in 10.3.3.2 shall be used.
        capabilityUpdateRequirement     CapabilityUpdateRequirement         OPTIONAL,
    -- Radio bearer IEs
        srb-InformationSetupList        SRB-InformationSetupList2,
    -- Transport channel IEs
        ul-CommonTransChInfo            UL-CommonTransChInfo                OPTIONAL,
        -- NOTE: ul-AddReconfTransChInfoList should be optional in later versions of
        -- this message
        ul-AddReconfTransChInfoList     UL-AddReconfTransChInfoList,
        dl-CommonTransChInfo            DL-CommonTransChInfo                OPTIONAL,
        -- NOTE: dl-AddReconfTransChInfoList should be optional in later versions
        -- of this message
        dl-AddReconfTransChInfoList     DL-AddReconfTransChInfoList,
    -- Physical channel IEs
        frequencyInfo                   FrequencyInfo                       OPTIONAL,
        maxAllowedUL-TX-Power           MaxAllowedUL-TX-Power               OPTIONAL,
        ul-ChannelRequirement           UL-ChannelRequirement               OPTIONAL,
        dl-CommonInformation            DL-CommonInformation                OPTIONAL,
        dl-InformationPerRL-List        DL-InformationPerRL-List            OPTIONAL
}

RRCConnectionSetup-v4b0ext-IEs ::= SEQUENCE {
        capabilityUpdateRequirement-r4-ext  CapabilityUpdateRequirement-r4-ext  OPTIONAL,
    -- Physical channel IEs
        -- dummy is not used in this version of the specification, it should
        -- not be sent and if received it should be ignored.
        dummy                           SSDT-UL                             OPTIONAL,
        -- The order of the RLs in IE cell-id-PerRL-List is the same as
        -- in IE DL-InformationPerRL-List included in this message
        cell-id-PerRL-List              CellIdentity-PerRL-List             OPTIONAL
}

RRCConnectionSetup-v590ext-IEs ::= SEQUENCE {
    -- User equipment IEs
        systemSpecificCapUpdateReq      SystemSpecificCapUpdateReq-v590ext      OPTIONAL,
    -- Physical channel IEs
        dl-TPC-PowerOffsetPerRL-List    DL-TPC-PowerOffsetPerRL-List        OPTIONAL
}

RRCConnectionSetup-r4-IEs ::= SEQUENCE {
    -- TABULAR: Integrity protection shall not be performed on this message.
        activationTime                  ActivationTime                      OPTIONAL,
        new-U-RNTI                      U-RNTI,
        new-c-RNTI                      C-RNTI                              OPTIONAL,
        rrc-StateIndicator              RRC-StateIndicator,
        utran-DRX-CycleLengthCoeff      UTRAN-DRX-CycleLengthCoefficient,
        -- TABULAR: If capabilityUpdateRequirement is not present, the default value
        -- defined in 10.3.3.2 shall be used.
        capabilityUpdateRequirement     CapabilityUpdateRequirement-r4      OPTIONAL,
    -- Radio bearer IEs
        srb-InformationSetupList        SRB-InformationSetupList2,
    -- Transport channel IEs
        ul-CommonTransChInfo            UL-CommonTransChInfo-r4             OPTIONAL,
        ul-AddReconfTransChInfoList     UL-AddReconfTransChInfoList         OPTIONAL,
        dl-CommonTransChInfo            DL-CommonTransChInfo-r4             OPTIONAL,
        dl-AddReconfTransChInfoList     DL-AddReconfTransChInfoList-r4      OPTIONAL,
    -- Physical channel IEs
        frequencyInfo                   FrequencyInfo                       OPTIONAL,
        maxAllowedUL-TX-Power           MaxAllowedUL-TX-Power               OPTIONAL,
        ul-ChannelRequirement           UL-ChannelRequirement-r4            OPTIONAL,
        dl-CommonInformation            DL-CommonInformation-r4             OPTIONAL,
        dl-InformationPerRL-List        DL-InformationPerRL-List-r4         OPTIONAL
}

RRCConnectionSetup-r5-IEs ::= SEQUENCE {
    -- TABULAR: Integrity protection shall not be performed on this message.
        activationTime                  ActivationTime                      OPTIONAL,
        new-U-RNTI                      U-RNTI,
        new-c-RNTI                      C-RNTI                              OPTIONAL,
```

```
        rrc-StateIndicator              RRC-StateIndicator,
        utran-DRX-CycleLengthCoeff      UTRAN-DRX-CycleLengthCoefficient,
        -- TABULAR: If capabilityUpdateRequirement is not present, the default value
        -- defined in 10.3.3.2 shall be used.
        capabilityUpdateRequirement     CapabilityUpdateRequirement-r5      OPTIONAL,
    -- Specification mode information
        specificationMode               CHOICE {
            complete                        SEQUENCE {
                -- Radio bearer IEs
                srb-InformationSetupList        SRB-InformationSetupList2,
                -- Transport channel IEs
                ul-CommonTransChInfo            UL-CommonTransChInfo-r4             OPTIONAL,
                ul-AddReconfTransChInfoList     UL-AddReconfTransChInfoList         OPTIONAL,
                dl-CommonTransChInfo            DL-CommonTransChInfo-r4             OPTIONAL,
                dl-AddReconfTransChInfoList     DL-AddReconfTransChInfoList-r4      OPTIONAL
            },
            preconfiguration                SEQUENCE {
                -- All IEs that include an FDD/TDD choice are split in two IEs for this message,
                -- one for the FDD only elements and one for the TDD only elements, so that one
                -- FDD/TDD choice in this level is sufficient.
                preConfigMode                   CHOICE {
                    predefinedConfigIdentity        PredefinedConfigIdentity,
                    defaultConfig                   SEQUENCE {
                        defaultConfigMode               DefaultConfigMode,
                        defaultConfigIdentity           DefaultConfigIdentity-r5
                    }
                }
            }
        },
    -- Physical channel IEs
        frequencyInfo                   FrequencyInfo                       OPTIONAL,
        maxAllowedUL-TX-Power           MaxAllowedUL-TX-Power               OPTIONAL,
        ul-ChannelRequirement           UL-ChannelRequirement-r4            OPTIONAL,
        dl-CommonInformation            DL-CommonInformation-r4             OPTIONAL,
        dl-InformationPerRL-List        DL-InformationPerRL-List-r5bis      OPTIONAL
}

RRCConnectionSetup-v690ext-IEs ::= SEQUENCE {
    -- Physical Channel IEs
        beaconPLEst                     BEACON-PL-Est                       OPTIONAL,
        postVerificationPeriod          ENUMERATED { true }                 OPTIONAL
}

RRCConnectionSetup-r6-IEs ::= SEQUENCE {
    -- TABULAR: Integrity protection shall not be performed on this message.
        activationTime                  ActivationTime                      OPTIONAL,
        new-U-RNTI                      U-RNTI,
        new-c-RNTI                      C-RNTI                              OPTIONAL,
        new-H-RNTI                      H-RNTI                              OPTIONAL,
        newPrimary-E-RNTI               E-RNTI                              OPTIONAL,
        newSecondary-E-RNTI             E-RNTI                              OPTIONAL,
        rrc-StateIndicator              RRC-StateIndicator,
        utran-DRX-CycleLengthCoeff      UTRAN-DRX-CycleLengthCoefficient,
        -- TABULAR: If capabilityUpdateRequirement is not present, the default value
        -- defined in 10.3.3.2 shall be used.
        capabilityUpdateRequirement     CapabilityUpdateRequirement-r5      OPTIONAL,
    -- Specification mode information
        specificationMode               CHOICE {
            complete                        SEQUENCE {
                -- Radio bearer IEs
                srb-InformationSetupList        SRB-InformationSetupList2-r6,
                -- Transport channel IEs
                ul-CommonTransChInfo            UL-CommonTransChInfo-r4             OPTIONAL,
                ul-AddReconfTransChInfoList     UL-AddReconfTransChInfoList-r6      OPTIONAL,
                dl-CommonTransChInfo            DL-CommonTransChInfo-r4             OPTIONAL,
                dl-AddReconfTransChInfoList     DL-AddReconfTransChInfoList-r5      OPTIONAL
            },
            preconfiguration                SEQUENCE {
                -- All IEs that include an FDD/TDD choice are split in two IEs for this message,
                -- one for the FDD only elements and one for the TDD only elements, so that one
                -- FDD/TDD choice in this level is sufficient.
                preConfigMode                   CHOICE {
                    predefinedConfigIdentity        PredefinedConfigIdentity,
                    defaultConfig                   SEQUENCE {
                        defaultConfigMode               DefaultConfigMode,
                        defaultConfigIdentity           DefaultConfigIdentity-r6
                    }
                }
```

```
            }
        },
    -- Physical channel IEs
        frequencyInfo                   FrequencyInfo                       OPTIONAL,
        maxAllowedUL-TX-Power           MaxAllowedUL-TX-Power               OPTIONAL,
        ul-DPCH-Info                    UL-DPCH-Info-r6                     OPTIONAL,
        ul-EDCH-Information             UL-EDCH-Information-r6              OPTIONAL,
        dl-HSPDSCH-Information          DL-HSPDSCH-Information-r6           OPTIONAL,
        dl-CommonInformation            DL-CommonInformation-r6             OPTIONAL,
        dl-InformationPerRL-List        DL-InformationPerRL-List-r6         OPTIONAL
}

RRCConnectionSetup-r7-IEs ::= SEQUENCE {
    -- TABULAR: Integrity protection shall not be performed on this message.
        activationTime                  ActivationTime                      OPTIONAL,
        new-U-RNTI                      U-RNTI,
        new-c-RNTI                      C-RNTI                              OPTIONAL,
        new-H-RNTI                      H-RNTI                              OPTIONAL,
        newPrimary-E-RNTI               E-RNTI                              OPTIONAL,
        newSecondary-E-RNTI             E-RNTI                              OPTIONAL,
        rrc-StateIndicator              RRC-StateIndicator,
        utran-DRX-CycleLengthCoeff      UTRAN-DRX-CycleLengthCoefficient,
        -- TABULAR: If capabilityUpdateRequirement is not present, the default value
        -- defined in 10.3.3.2 shall be used.
        capabilityUpdateRequirement     CapabilityUpdateRequirement-r5      OPTIONAL,
    -- Specification mode information
        specificationMode               CHOICE {
            complete                        SEQUENCE {
                -- Radio bearer IEs
                srb-InformationSetupList        SRB-InformationSetupList2-r6,
                -- Transport channel IEs
                ul-CommonTransChInfo            UL-CommonTransChInfo-r4             OPTIONAL,
                ul-AddReconfTransChInfoList     UL-AddReconfTransChInfoList-r6      OPTIONAL,
                dl-CommonTransChInfo            DL-CommonTransChInfo-r4             OPTIONAL,
                dl-AddReconfTransChInfoList     DL-AddReconfTransChInfoList-r5      OPTIONAL
            },
            preconfiguration                SEQUENCE {
                -- All IEs that include an FDD/TDD choice are split in two IEs for this message,
                -- one for the FDD only elements and one for the TDD only elements, so that one
                -- FDD/TDD choice in this level is sufficient.
                preConfigMode                   CHOICE {
                    predefinedConfigIdentity        PredefinedConfigIdentity,
                    defaultConfig                   SEQUENCE {
                        defaultConfigMode               DefaultConfigMode,
                        defaultConfigIdentity           DefaultConfigIdentity-r5
                    }
                }
            }
        },
    -- Physical channel IEs
        frequencyInfo                   FrequencyInfo                       OPTIONAL,
        maxAllowedUL-TX-Power           MaxAllowedUL-TX-Power               OPTIONAL,
        ul-DPCH-Info                    UL-DPCH-Info-r7                     OPTIONAL,
        ul-EDCH-Information             UL-EDCH-Information-r6              OPTIONAL,
        dl-HSPDSCH-Information          DL-HSPDSCH-Information-r7           OPTIONAL,
        dl-CommonInformation            DL-CommonInformation-r7             OPTIONAL,
        dl-InformationPerRL-List        DL-InformationPerRL-List-r7         OPTIONAL
}

RRCConnectionSetup-v7xyext-IEs ::= SEQUENCE {
        capabilityUpdateRequirement-r7-ext  CapabilityUpdateRequirement-r7-ext      OPTIONAL
}

-- **************************************************
--
-- RRC CONNECTION SETUP COMPLETE
--
-- **************************************************

RRCConnectionSetupComplete ::= SEQUENCE {
    -- TABULAR: Integrity protection shall not be performed on this message.
    -- User equipment IEs
        rrc-TransactionIdentifier       RRC-TransactionIdentifier,
        startList                       STARTList,
        ue-RadioAccessCapability        UE-RadioAccessCapability            OPTIONAL,
    --  Other IEs
        ue-RATSpecificCapability        InterRAT-UE-RadioAccessCapabilityList   OPTIONAL,
    -- Non critical extensions
```

```
        v370NonCriticalExtensions           SEQUENCE {
            rrcConnectionSetupComplete-v370ext  RRCConnectionSetupComplete-v370ext,
            v380NonCriticalExtensions           SEQUENCE {
                rrcConnectionSetupComplete-v380ext  RRCConnectionSetupComplete-v380ext-IEs,
                -- Reserved for future non critical extension
                v3a0NonCriticalExtensions           SEQUENCE {
                    rrcConnectionSetupComplete-v3a0ext  RRCConnectionSetupComplete-v3a0ext-IEs,
                    laterNonCriticalExtensions          SEQUENCE {
                        -- Container for additional R99 extensions
                        rrcConnectionSetupComplete-r3-add-ext       BIT STRING
                                (CONTAINING RRCConnectionSetupComplete-r3-add-ext-IEs)  OPTIONAL,
                        v3g0NonCriticalExtensions           SEQUENCE {
                            rrcConnectionSetupComplete-v3g0ext  RRCConnectionSetupComplete-v3g0ext-IEs,
                            v4b0NonCriticalExtensions           SEQUENCE {
                                rrcConnectionSetupComplete-v4b0ext
                                                                    RRCConnectionSetupComplete-v4b0ext-IEs,
                                v590NonCriticalExtensions           SEQUENCE {
                                    rrcConnectionSetupComplete-v590ext
                                                                    RRCConnectionSetupComplete-v590ext-IEs,
                                    v5c0NonCriticalExtensions           SEQUENCE {
                                        rrcConnectionSetupComplete-v5c0ext
                                                                    RRCConnectionSetupComplete-v5c0ext-IEs,
                                        v690NonCriticalExtensions           SEQUENCE {
                                            rrcConnectionSetupComplete-v690ext
                                                                    RRCConnectionSetupComplete-v690ext-IEs,
                                            v7xyNonCriticalExtensions       SEQUENCE {
                                                rrcConectionSetupComplete-v7xyext
                                                                    RRCConnectionSetupComplete-v7xyext-IEs,
                                                nonCriticalExtensions       SEQUENCE {}     OPTIONAL
                                            }       OPTIONAL
                                        }       OPTIONAL
                                    }       OPTIONAL
                                }       OPTIONAL
                            }       OPTIONAL
                        }       OPTIONAL
                    }       OPTIONAL
                }       OPTIONAL
            }       OPTIONAL
        }       OPTIONAL
}

RRCConnectionSetupComplete-v370ext ::= SEQUENCE {
    -- User equipment IEs
        ue-RadioAccessCapability-v370ext    UE-RadioAccessCapability-v370ext    OPTIONAL
}

RRCConnectionSetupComplete-v380ext-IEs ::= SEQUENCE {
    -- User equipment IEs
        ue-RadioAccessCapability-v380ext    UE-RadioAccessCapability-v380ext        OPTIONAL,
        dl-PhysChCapabilityFDD-v380ext      DL-PhysChCapabilityFDD-v380ext
}

RRCConnectionSetupComplete-v3a0ext-IEs ::= SEQUENCE {
    -- User equipment IEs
        ue-RadioAccessCapability-v3a0ext    UE-RadioAccessCapability-v3a0ext    OPTIONAL
}

RRCConnectionSetupComplete-v3g0ext-IEs ::= SEQUENCE {
    -- User equipment IEs
        ue-RadioAccessCapability-v3g0ext    UE-RadioAccessCapability-v3g0ext    OPTIONAL
}

RRCConnectionSetupComplete-r3-add-ext-IEs ::= SEQUENCE {
        rrcConnectionSetupComplete-v650ext      RRCConnectionSetupComplete-v650ext-IEs  OPTIONAL,
        v680NonCriticalExtensions               SEQUENCE {
            rrcConnectionSetupComplete-v680ext      RRCConnectionSetupComplete-v680ext-IEs,
            nonCriticalExtensions                   SEQUENCE {}     OPTIONAL
        }       OPTIONAL
}

RRCConnectionSetupComplete-v4b0ext-IEs ::= SEQUENCE {
    -- User equipment IEs
        ue-RadioAccessCapability-v4b0ext        UE-RadioAccessCapability-v4b0ext        OPTIONAL
}

RRCConnectionSetupComplete-v590ext-IEs ::= SEQUENCE {
    -- User equipment IEs
        ue-RadioAccessCapability-v590ext        UE-RadioAccessCapability-v590ext        OPTIONAL,
```

```
    -- Other IEs
        ue-RATSpecificCapability-v590ext        InterRAT-UE-RadioAccessCapability-v590ext   OPTIONAL
}

RRCConnectionSetupComplete-v5c0ext-IEs ::= SEQUENCE {
    -- User equipment IEs
        ue-RadioAccessCapability-v5c0ext        UE-RadioAccessCapability-v5c0ext        OPTIONAL
}

RRCConnectionSetupComplete-v650ext-IEs ::= SEQUENCE {
    -- User equipment IEs
        ue-RadioAccessCapability-v650ext        UE-RadioAccessCapability-v650ext
}

RRCConnectionSetupComplete-v680ext-IEs ::= SEQUENCE {
    -- User equipment IEs
        ue-RadioAccessCapability-v680ext        UE-RadioAccessCapability-v680ext
}

RRCConnectionSetupComplete-v690ext-IEs ::= SEQUENCE {
    -- User equipment IEs
        ueCapabilityContainer               BIT STRING
                                                (CONTAINING UE-CapabilityContainer-IEs) OPTIONAL
}

RRCConnectionSetupComplete-v7xyext-IEs ::= SEQUENCE {
        ue-RadioAccessCapability-v7xyext    UE-RadioAccessCapability-v7xyext        OPTIONAL
}

-- **************************************************
--
-- RRC FAILURE INFO
--
-- **************************************************

RRC-FailureInfo ::= CHOICE {
    r3                                          SEQUENCE {
        rRC-FailureInfo-r3                          RRC-FailureInfo-r3-IEs,
        laterNonCriticalExtensions      SEQUENCE {
            -- Container for additional R99 extensions
            rrc-FailureInfo-r3-add-ext      BIT STRING      OPTIONAL,
            nonCriticalExtensions                       SEQUENCE {} OPTIONAL
        }   OPTIONAL
    },
    criticalExtensions                          SEQUENCE {}
}

RRC-FailureInfo-r3-IEs ::=      SEQUENCE {
    -- Non-RRC IEs
        failureCauseWithProtErr                         FailureCauseWithProtErr
}

-- **************************************************
--
-- RRC STATUS
--
-- **************************************************

RRCStatus ::= SEQUENCE {
    -- Other IEs
        -- TABULAR: Identification of received message is nested in
        -- ProtocolErrorMoreInformation
        protocolErrorInformation        ProtocolErrorMoreInformation,
        laterNonCriticalExtensions      SEQUENCE {
            -- Container for additional R99 extensions
            rrcStatus-r3-add-ext        BIT STRING      OPTIONAL,
            nonCriticalExtensions           SEQUENCE {}     OPTIONAL
        }   OPTIONAL
}

-- **************************************************
--
-- SECURITY MODE COMMAND
--
-- **************************************************

SecurityModeCommand ::= CHOICE {
    r3                              SEQUENCE {
```

```
        securityModeCommand-r3          SecurityModeCommand-r3-IEs,
        laterNonCriticalExtensions      SEQUENCE {
            -- Container for additional R99 extensions
            securityModeCommand-r3-add-ext      BIT STRING      OPTIONAL,
            nonCriticalExtensions           SEQUENCE {}     OPTIONAL
        }   OPTIONAL
    },
    later-than-r3                   SEQUENCE {
        rrc-TransactionIdentifier       RRC-TransactionIdentifier,
        criticalExtensions              SEQUENCE {}
    }
}

SecurityModeCommand-r3-IEs ::= SEQUENCE {
-- TABULAR: Integrity protection shall always be performed on this message.
    -- User equipment IEs
        rrc-TransactionIdentifier       RRC-TransactionIdentifier,
        securityCapability              SecurityCapability,
        cipheringModeInfo               CipheringModeInfo                   OPTIONAL,
        integrityProtectionModeInfo     IntegrityProtectionModeInfo         OPTIONAL,
    -- Core network IEs
        cn-DomainIdentity               CN-DomainIdentity,
    -- Other IEs
        ue-SystemSpecificSecurityCap    InterRAT-UE-SecurityCapList         OPTIONAL
}

-- **************************************************
--
-- SECURITY MODE COMPLETE
--
-- **************************************************

SecurityModeComplete ::= SEQUENCE {
-- TABULAR: Integrity protection shall always be performed on this message.

    -- User equipment IEs
        rrc-TransactionIdentifier       RRC-TransactionIdentifier,
        ul-IntegProtActivationInfo      IntegrityProtActivationInfo         OPTIONAL,
    -- Radio bearer IEs
        rb-UL-CiphActivationTimeInfo    RB-ActivationTimeInfoList           OPTIONAL,
        laterNonCriticalExtensions      SEQUENCE {
            -- Container for additional R99 extensions
            securityModeComplete-r3-add-ext     BIT STRING      OPTIONAL,
            nonCriticalExtensions           SEQUENCE {}     OPTIONAL
        }   OPTIONAL
}

-- **************************************************
--
-- SECURITY MODE FAILURE
--
-- **************************************************

SecurityModeFailure ::= SEQUENCE {
    -- User equipment IEs
        rrc-TransactionIdentifier       RRC-TransactionIdentifier,
        failureCause                    FailureCauseWithProtErr,
        laterNonCriticalExtensions      SEQUENCE {
            -- Container for additional R99 extensions
            securityModeFailure-r3-add-ext      BIT STRING      OPTIONAL,
            nonCriticalExtensions           SEQUENCE {}     OPTIONAL
        }   OPTIONAL
}

-- **************************************************
--
-- SIGNALLING CONNECTION RELEASE
--
-- **************************************************

SignallingConnectionRelease ::= CHOICE {
    r3                              SEQUENCE {
        signallingConnectionRelease-r3  SignallingConnectionRelease-r3-IEs,
        laterNonCriticalExtensions      SEQUENCE {
            -- Container for additional R99 extensions
            signallingConnectionRelease-r3-add-ext      BIT STRING      OPTIONAL,
            nonCriticalExtensions           SEQUENCE {}     OPTIONAL
        }   OPTIONAL
```

```
    },
    later-than-r3                   SEQUENCE {
        rrc-TransactionIdentifier       RRC-TransactionIdentifier,
        criticalExtensions              SEQUENCE {}
    }
}

SignallingConnectionRelease-r3-IEs ::= SEQUENCE {
    -- User equipment IEs
        rrc-TransactionIdentifier       RRC-TransactionIdentifier,
    -- Core network IEs
        cn-DomainIdentity               CN-DomainIdentity
}

-- **************************************************
--
-- SIGNALLING CONNECTION RELEASE INDICATION
--
-- **************************************************

SignallingConnectionReleaseIndication ::= SEQUENCE {
    -- Core network IEs
        cn-DomainIdentity               CN-DomainIdentity,
        laterNonCriticalExtensions      SEQUENCE {
            -- Container for additional R99 extensions
            signallingConnectionReleaseIndication-r3-add-ext        BIT STRING      OPTIONAL,
            nonCriticalExtensions           SEQUENCE {}     OPTIONAL
        }   OPTIONAL
}

-- **************************************************
--
-- SYSTEM INFORMATION for BCH
--
-- **************************************************

SystemInformation-BCH ::= SEQUENCE {
    -- Other information elements
        sfn-Prime                       SFN-Prime,
        payload                         CHOICE {
            noSegment                       NULL,
            firstSegment                    FirstSegment,
            subsequentSegment               SubsequentSegment,
            lastSegmentShort                        LastSegmentShort,
            lastAndFirst                    SEQUENCE {
                lastSegmentShort                LastSegmentShort,
                firstSegment                    FirstSegmentShort
            },
            lastAndComplete                 SEQUENCE {
                lastSegmentShort                LastSegmentShort,
                completeSIB-List                CompleteSIB-List
            },
            lastAndCompleteAndFirst         SEQUENCE {
                lastSegmentShort                LastSegmentShort,
                completeSIB-List                CompleteSIB-List,
                firstSegment                    FirstSegmentShort
            },
            completeSIB-List                CompleteSIB-List,
            completeAndFirst                SEQUENCE {
                completeSIB-List                CompleteSIB-List,
                firstSegment                    FirstSegmentShort
            },
            completeSIB                     CompleteSIB,
            lastSegment                     LastSegment,
            spare5                          NULL,
            spare4                          NULL,
            spare3                          NULL,
            spare2                          NULL,
            spare1                          NULL
        }
}

-- **************************************************
--
-- SYSTEM INFORMATION for FACH
--
-- **************************************************
```

```
SystemInformation-FACH ::= SEQUENCE {
    -- Other information elements
        payload                         CHOICE {
            noSegment                       NULL,
            firstSegment                    FirstSegment,
            subsequentSegment               SubsequentSegment,
            lastSegmentShort                LastSegmentShort,
            lastAndFirst                    SEQUENCE {
                lastSegmentShort                LastSegmentShort,
                firstSegment                    FirstSegmentShort
            },
            lastAndComplete                 SEQUENCE {
                lastSegmentShort                LastSegmentShort,
                completeSIB-List                CompleteSIB-List
            },
            lastAndCompleteAndFirst         SEQUENCE {
                lastSegmentShort                LastSegmentShort,
                completeSIB-List                CompleteSIB-List,
                firstSegment                    FirstSegmentShort
            },
            completeSIB-List                CompleteSIB-List,
            completeAndFirst                SEQUENCE {
                completeSIB-List                CompleteSIB-List,
                firstSegment                    FirstSegmentShort
            },
            completeSIB                     CompleteSIB,
            lastSegment                     LastSegment,
            spare5                          NULL,
            spare4                          NULL,
            spare3                          NULL,
            spare2                          NULL,
            spare1                          NULL
        }
}

-- **************************************************
--
-- First segment
--
-- **************************************************

FirstSegment ::=                    SEQUENCE {
    -- Other information elements
        sib-Type                        SIB-Type,
        seg-Count                       SegCount,
        sib-Data-fixed                  SIB-Data-fixed
}

-- **************************************************
--
-- First segment (short)
--
-- **************************************************

FirstSegmentShort ::=               SEQUENCE {
    -- Other information elements
        sib-Type                        SIB-Type,
        seg-Count                       SegCount,
        sib-Data-variable               SIB-Data-variable
}

-- **************************************************
--
-- Subsequent segment
--
-- **************************************************

SubsequentSegment ::=               SEQUENCE {
    -- Other information elements
        sib-Type                        SIB-Type,
        segmentIndex                    SegmentIndex,
        sib-Data-fixed                  SIB-Data-fixed
}

-- **************************************************
--
-- Last segment
--
```

```
-- **************************************************

LastSegment ::=                     SEQUENCE {
    -- Other information elements
        sib-Type                        SIB-Type,
        segmentIndex                    SegmentIndex,
        -- For sib-Data-fixed, in case the SIB data is less than 222 bits, padding
        -- shall be used. The same padding bits shall be used as defined in clause 12.1
        sib-Data-fixed                  SIB-Data-fixed
}

LastSegmentShort ::=                        SEQUENCE {
    -- Other information elements
        sib-Type                        SIB-Type,
        segmentIndex                    SegmentIndex,
        sib-Data-variable               SIB-Data-variable
}

-- **************************************************
--
-- Complete SIB
--
-- **************************************************

CompleteSIB-List ::=                SEQUENCE (SIZE (1..maxSIBperMsg)) OF
                                        CompleteSIBshort

CompleteSIB ::=                     SEQUENCE {
    -- Other information elements
        sib-Type                        SIB-Type,
        -- For sib-Data-fixed, in case the SIB data is less than 226 bits, padding
        -- shall be used. The same padding bits shall be used as defined in clause 12.1
        sib-Data-fixed                  BIT STRING (SIZE (226))
}

CompleteSIBshort ::=                        SEQUENCE {
    -- Other information elements
        sib-Type                        SIB-Type,
        sib-Data-variable               SIB-Data-variable
}

-- **************************************************
--
-- SYSTEM INFORMATION CHANGE INDICATION
--
-- **************************************************

SystemInformationChangeIndication ::=   SEQUENCE {
    -- Other IEs
        bcch-ModificationInfo               BCCH-ModificationInfo,
        laterNonCriticalExtensions          SEQUENCE {
            -- Container for additional R99 extensions
            systemInformationChangeIndication-r3-add-ext        BIT STRING      OPTIONAL,
            nonCriticalExtensions           SEQUENCE {}     OPTIONAL
        }   OPTIONAL
}

-- **************************************************
--
-- TRANSPORT CHANNEL RECONFIGURATION
--
-- **************************************************

TransportChannelReconfiguration ::= CHOICE {
    r3                              SEQUENCE {
        transportChannelReconfiguration-r3
                                        TransportChannelReconfiguration-r3-IEs,
        v3a0NonCriticalExtensions       SEQUENCE {
            transportChannelReconfiguration-v3a0ext
                                            TransportChannelReconfiguration-v3a0ext,
            laterNonCriticalExtensions          SEQUENCE {
                -- Container for additional R99 extensions
                transportChannelReconfiguration-r3-add-ext      BIT STRING      OPTIONAL,
                v4b0NonCriticalExtensions       SEQUENCE {
                    transportChannelReconfiguration-v4b0ext
                                                    TransportChannelReconfiguration-v4b0ext-IEs,
                    v590NonCriticalExtensions       SEQUENCE {
                        transportChannelReconfiguration-v590ext
```

```
                                                TransportChannelReconfiguration-v590ext-IEs,
                        v690NonCriticalExtensions       SEQUENCE {
                            transportChannelReconfiguration-v690ext
                                                TransportChannelReconfiguration-v690ext-IEs,
                            nonCriticalExtensions           SEQUENCE {}     OPTIONAL
                        }       OPTIONAL
                    }       OPTIONAL
                }       OPTIONAL
            }       OPTIONAL
        },
        later-than-r3                   SEQUENCE {
            rrc-TransactionIdentifier       RRC-TransactionIdentifier,
            criticalExtensions              CHOICE {
                r4                              SEQUENCE {
                    transportChannelReconfiguration-r4
                                                TransportChannelReconfiguration-r4-IEs,
                    v4d0NonCriticalExtensions           SEQUENCE {
                        -- Container for adding non critical extensions after freezing REL-5
                        transportChannelReconfiguration-r4-add-ext      BIT STRING      OPTIONAL,
                        v590NonCriticalExtensions       SEQUENCE {
                            transportChannelReconfiguration-v590ext
                                                TransportChannelReconfiguration-v590ext-IEs,
                            v690NonCriticalExtensions       SEQUENCE {
                                transportChannelReconfiguration-v690ext
                                                TransportChannelReconfiguration-v690ext-IEs,
                                nonCriticalExtensions           SEQUENCE {}     OPTIONAL
                            }   OPTIONAL
                        }   OPTIONAL
                    }   OPTIONAL
                },
                criticalExtensions              CHOICE {
                    r5                              SEQUENCE {
                        transportChannelReconfiguration-r5
                                                TransportChannelReconfiguration-r5-IEs,
                        -- Container for adding non critical extensions after freezing REL-6
                        transportChannelReconfiguration-r5-add-ext      BIT STRING      OPTIONAL,
                        v690NonCriticalExtensions       SEQUENCE {
                            transportChannelReconfiguration-v690ext
                                                TransportChannelReconfiguration-v690ext-IEs,
                            nonCriticalExtensions           SEQUENCE {}     OPTIONAL
                        }   OPTIONAL
                    },
                    criticalExtensions              CHOICE {
                        r6                              SEQUENCE {
                            transportChannelReconfiguration-r6
                                                TransportChannelReconfiguration-r6-IEs,
                            -- Container for adding non critical extensions after freezing REL-7
                            transportChannelReconfiguration-r6-add-ext      BIT STRING      OPTIONAL,
                            nonCriticalExtensions           SEQUENCE {}     OPTIONAL
                        },
                        criticalExtensions              CHOICE {
                            r7                              SEQUENCE {
                                transportChannelReconfiguration-r7
                                                TransportChannelReconfiguration-r7-IEs,
                                -- Container for adding non critical extensions after freezing REL-8
                                transportChannelReconfiguration-r7-add-ext      BIT STRING  OPTIONAL,
                                nonCriticalExtensions           SEQUENCE {}     OPTIONAL
                            },
                            criticalExtensions              SEQUENCE {}
                        }
                    }
                }
            }
        }
    }
}

TransportChannelReconfiguration-r3-IEs ::= SEQUENCE {
    -- User equipment IEs
        rrc-TransactionIdentifier       RRC-TransactionIdentifier,
        integrityProtectionModeInfo     IntegrityProtectionModeInfo         OPTIONAL,
        cipheringModeInfo               CipheringModeInfo                   OPTIONAL,
        activationTime                  ActivationTime                      OPTIONAL,
        new-U-RNTI                      U-RNTI                              OPTIONAL,
        new-C-RNTI                      C-RNTI                              OPTIONAL,
        rrc-StateIndicator              RRC-StateIndicator,
        utran-DRX-CycleLengthCoeff      UTRAN-DRX-CycleLengthCoefficient    OPTIONAL,
    -- Core network IEs
```

```
        cn-InformationInfo              CN-InformationInfo                  OPTIONAL,
    -- UTRAN mobility IEs
        ura-Identity                    URA-Identity                        OPTIONAL,
    -- Radio bearer IEs
        dl-CounterSynchronisationInfo   DL-CounterSynchronisationInfo       OPTIONAL,
    -- Transport channel IEs
        ul-CommonTransChInfo            UL-CommonTransChInfo                OPTIONAL,
        ul-AddReconfTransChInfoList     UL-AddReconfTransChInfoList         OPTIONAL,
        -- 'dummy', 'dummy1' and 'dummy2' are not used in this version of the specification,
        -- they should not be sent and if received they should be ignored.
        dummy                           CHOICE {
            fdd                             SEQUENCE {
                dummy1                          CPCH-SetID                  OPTIONAL,
                dummy2                          DRAC-StaticInformationList  OPTIONAL
            },
            tdd                             NULL
        }                                                                   OPTIONAL,
        dl-CommonTransChInfo            DL-CommonTransChInfo                OPTIONAL,
        dl-AddReconfTransChInfoList     DL-AddReconfTransChInfoList         OPTIONAL,
    -- Physical channel IEs
        frequencyInfo                   FrequencyInfo                       OPTIONAL,
        maxAllowedUL-TX-Power           MaxAllowedUL-TX-Power               OPTIONAL,
        ul-ChannelRequirement           UL-ChannelRequirement               OPTIONAL,
        modeSpecificPhysChInfo          CHOICE {
            fdd                             SEQUENCE {
                -- dummy is not used in this version of specification, it should
                -- not be sent and if received it should be ignored.
                dummy                           DL-PDSCH-Information        OPTIONAL
            },
            tdd                             NULL
        },
        dl-CommonInformation            DL-CommonInformation                OPTIONAL,
        dl-InformationPerRL-List        DL-InformationPerRL-List            OPTIONAL
}

TransportChannelReconfiguration-v3a0ext ::= SEQUENCE {
    -- The IE 'new-DSCH-RNTI' should not be included in FDD mode, and if received
    -- the UE behaviour is unspecified
    new-DSCH-RNTI                   DSCH-RNTI                           OPTIONAL
}

TransportChannelReconfiguration-v4b0ext-IEs ::= SEQUENCE {
    -- Physical channel IEs
        -- dummy is not used in this version of the specification, it should
        -- not be sent and if received it should be ignored.
        dummy                           SSDT-UL                                 OPTIONAL,
        -- The order of the RLs in IE cell-id-PerRL-List is the same as
        -- in IE DL-InformationPerRL-List included in this message
        cell-id-PerRL-List              CellIdentity-PerRL-List                 OPTIONAL
}

TransportChannelReconfiguration-v590ext-IEs ::= SEQUENCE {
    -- Physical channel IEs
        dl-TPC-PowerOffsetPerRL-List    DL-TPC-PowerOffsetPerRL-List        OPTIONAL
}

TransportChannelReconfiguration-r4-IEs ::= SEQUENCE {
    -- User equipment IEs
        integrityProtectionModeInfo     IntegrityProtectionModeInfo         OPTIONAL,
        cipheringModeInfo               CipheringModeInfo                   OPTIONAL,
        activationTime                  ActivationTime                      OPTIONAL,
        new-U-RNTI                      U-RNTI                              OPTIONAL,
        new-C-RNTI                      C-RNTI                              OPTIONAL,
        -- The IE 'new-DSCH-RNTI' should not be included in FDD mode, and if received
        -- the UE behaviour is unspecified
        new-DSCH-RNTI                   DSCH-RNTI                           OPTIONAL,
        rrc-StateIndicator              RRC-StateIndicator,
        utran-DRX-CycleLengthCoeff      UTRAN-DRX-CycleLengthCoefficient    OPTIONAL,
    -- Core network IEs
        cn-InformationInfo              CN-InformationInfo                  OPTIONAL,
    -- UTRAN mobility IEs
        ura-Identity                    URA-Identity                        OPTIONAL,
    -- Radio bearer IEs
        dl-CounterSynchronisationInfo   DL-CounterSynchronisationInfo       OPTIONAL,
    -- Transport channel IEs
        ul-CommonTransChInfo            UL-CommonTransChInfo-r4             OPTIONAL,
        ul-AddReconfTransChInfoList     UL-AddReconfTransChInfoList         OPTIONAL,
        -- 'dummy', 'dummy1' and 'dummy2' are not used in this version of the specification,
```

```
        -- they should not be sent and if received they should be ignored.
        dummy                           CHOICE {
            fdd                             SEQUENCE {
                dummy1                          CPCH-SetID                  OPTIONAL,
                dummy2                          DRAC-StaticInformationList  OPTIONAL
            },
            tdd                             NULL
        }                                                                   OPTIONAL,
        dl-CommonTransChInfo            DL-CommonTransChInfo-r4             OPTIONAL,
        dl-AddReconfTransChInfoList     DL-AddReconfTransChInfoList-r4      OPTIONAL,
    -- Physical channel IEs
        frequencyInfo                   FrequencyInfo                       OPTIONAL,
        maxAllowedUL-TX-Power           MaxAllowedUL-TX-Power               OPTIONAL,
        ul-ChannelRequirement           UL-ChannelRequirement-r4            OPTIONAL,
        modeSpecificPhysChInfo          CHOICE {
            fdd                             SEQUENCE {
                -- dummy is not used in this version of specification, it should
                -- not be sent and if received it should be ignored.
                dummy                           DL-PDSCH-Information        OPTIONAL
            },
            tdd                         NULL
        },
        dl-CommonInformation            DL-CommonInformation-r4             OPTIONAL,
        dl-InformationPerRL-List        DL-InformationPerRL-List-r4         OPTIONAL
}

TransportChannelReconfiguration-r5-IEs ::= SEQUENCE {
    -- User equipment IEs
        integrityProtectionModeInfo     IntegrityProtectionModeInfo         OPTIONAL,
        cipheringModeInfo               CipheringModeInfo                   OPTIONAL,
        activationTime                  ActivationTime                      OPTIONAL,
        new-U-RNTI                      U-RNTI                              OPTIONAL,
        new-C-RNTI                      C-RNTI                              OPTIONAL,
        -- The IE 'new-DSCH-RNTI' should not be included in FDD mode, and if received
        -- the UE behaviour is unspecified
        new-DSCH-RNTI                   DSCH-RNTI                           OPTIONAL,
        new-H-RNTI                      H-RNTI                              OPTIONAL,
        rrc-StateIndicator              RRC-StateIndicator,
        utran-DRX-CycleLengthCoeff      UTRAN-DRX-CycleLengthCoefficient    OPTIONAL,
    -- Core network IEs
        cn-InformationInfo              CN-InformationInfo                  OPTIONAL,
    -- UTRAN mobility IEs
        ura-Identity                    URA-Identity                        OPTIONAL,
    -- Radio bearer IEs
        dl-CounterSynchronisationInfo   DL-CounterSynchronisationInfo-r5    OPTIONAL,
    -- Transport channel IEs
        ul-CommonTransChInfo            UL-CommonTransChInfo-r4             OPTIONAL,
        ul-AddReconfTransChInfoList     UL-AddReconfTransChInfoList         OPTIONAL,
        -- 'dummy', 'dummy1' and 'dummy2' are not used in this version of the specification,
        -- they should not be sent and if received they should be ignored.
        dummy                           CHOICE {
            fdd                             SEQUENCE {
                dummy1                          CPCH-SetID                  OPTIONAL,
                dummy2                          DRAC-StaticInformationList  OPTIONAL
            },
            tdd                             NULL
        }                                                                   OPTIONAL,
        dl-CommonTransChInfo            DL-CommonTransChInfo-r4             OPTIONAL,
        dl-AddReconfTransChInfoList     DL-AddReconfTransChInfoList-r5      OPTIONAL,
    -- Physical channel IEs
        frequencyInfo                   FrequencyInfo                       OPTIONAL,
        maxAllowedUL-TX-Power           MaxAllowedUL-TX-Power               OPTIONAL,
        ul-ChannelRequirement           UL-ChannelRequirement-r5            OPTIONAL,
        modeSpecificPhysChInfo          CHOICE {
            fdd                             SEQUENCE {
                -- dummy is not used in this version of specification, it should
                -- not be sent and if received it should be ignored.
                dummy                           DL-PDSCH-Information        OPTIONAL
            },
            tdd                         NULL
        },
        dl-HSPDSCH-Information          DL-HSPDSCH-Information              OPTIONAL,
        dl-CommonInformation            DL-CommonInformation-r5             OPTIONAL,
        dl-InformationPerRL-List        DL-InformationPerRL-List-r5         OPTIONAL
}

TransportChannelReconfiguration-v690ext-IEs ::= SEQUENCE {
    -- User Equipment IEs
```

```
        delayRestrictionFlag            DelayRestrictionFlag                OPTIONAL,
    -- Core network IEs
        primary-plmn-Identity           PLMN-Identity                       OPTIONAL,
    -- Physical channel IEs
        -- The IE harq-Preamble-Mode should not be used in the r3 and r4 versions of the message
        -- If included in the r3 or r4 version of the message, the UE should ignore the IE
        harq-Preamble-Mode              HARQ-Preamble-Mode                  OPTIONAL,
        beaconPLEst                     BEACON-PL-Est                       OPTIONAL,
        postVerificationPeriod          ENUMERATED { true }                 OPTIONAL,
        dhs-sync                        DHS-Sync                            OPTIONAL,
        timingMaintainedSynchInd        TimingMaintainedSynchInd            OPTIONAL,
    -- MBMS IEs
        mbms-PL-ServiceRestrictInfo     MBMS-PL-ServiceRestrictInfo-r6      OPTIONAL
}

TransportChannelReconfiguration-r6-IEs ::= SEQUENCE {
    -- User equipment IEs
        integrityProtectionModeInfo     IntegrityProtectionModeInfo         OPTIONAL,
        cipheringModeInfo               CipheringModeInfo                   OPTIONAL,
        activationTime                  ActivationTime                      OPTIONAL,
        delayRestrictionFlag            DelayRestrictionFlag                OPTIONAL,
        new-U-RNTI                      U-RNTI                              OPTIONAL,
        new-C-RNTI                      C-RNTI                              OPTIONAL,
        -- The IE 'new-DSCH-RNTI' should not be included in FDD mode,
        -- and if received the UE behaviour is unspecified
        new-DSCH-RNTI                   DSCH-RNTI                           OPTIONAL,
        new-H-RNTI                      H-RNTI                              OPTIONAL,
        newPrimary-E-RNTI               E-RNTI                              OPTIONAL,
        newSecondary-E-RNTI             E-RNTI                              OPTIONAL,
        rrc-StateIndicator              RRC-StateIndicator,
        utran-DRX-CycleLengthCoeff      UTRAN-DRX-CycleLengthCoefficient    OPTIONAL,
    -- Core network IEs
        cn-InformationInfo              CN-InformationInfo-r6               OPTIONAL,
    -- UTRAN mobility IEs
        ura-Identity                    URA-Identity                        OPTIONAL,
    -- Radio bearer IEs
        dl-CounterSynchronisationInfo   DL-CounterSynchronisationInfo-r5    OPTIONAL,
    -- Transport channel IEs
        ul-CommonTransChInfo            UL-CommonTransChInfo-r4             OPTIONAL,
        ul-AddReconfTransChInfoList     UL-AddReconfTransChInfoList-r6      OPTIONAL,
        dl-CommonTransChInfo            DL-CommonTransChInfo-r4             OPTIONAL,
        dl-AddReconfTransChInfoList     DL-AddReconfTransChInfoList-r5      OPTIONAL,
    -- Physical channel IEs
        frequencyInfo                   FrequencyInfo                       OPTIONAL,
        maxAllowedUL-TX-Power           MaxAllowedUL-TX-Power               OPTIONAL,
        ul-DPCH-Info                    UL-DPCH-Info-r6                     OPTIONAL,
        ul-EDCH-Information             UL-EDCH-Information-r6              OPTIONAL,
        dl-HSPDSCH-Information          DL-HSPDSCH-Information-r6           OPTIONAL,
        dl-CommonInformation            DL-CommonInformation-r6             OPTIONAL,
        dl-InformationPerRL-List        DL-InformationPerRL-List-r6         OPTIONAL,
    -- MBMS IEs
        mbms-PL-ServiceRestrictInfo     MBMS-PL-ServiceRestrictInfo-r6      OPTIONAL
}

TransportChannelReconfiguration-r7-IEs ::= SEQUENCE {
    -- User equipment IEs
        integrityProtectionModeInfo     IntegrityProtectionModeInfo         OPTIONAL,
        cipheringModeInfo               CipheringModeInfo                   OPTIONAL,
        activationTime                  ActivationTime                      OPTIONAL,
        delayRestrictionFlag            DelayRestrictionFlag                OPTIONAL,
        new-U-RNTI                      U-RNTI                              OPTIONAL,
        new-C-RNTI                      C-RNTI                              OPTIONAL,
        -- The IE 'new-DSCH-RNTI' should not be included in FDD mode,
        -- and if received the UE behaviour is unspecified
        new-DSCH-RNTI                   DSCH-RNTI                           OPTIONAL,
        new-H-RNTI                      H-RNTI                              OPTIONAL,
        newPrimary-E-RNTI               E-RNTI                              OPTIONAL,
        newSecondary-E-RNTI             E-RNTI                              OPTIONAL,
        rrc-StateIndicator              RRC-StateIndicator,
        utran-DRX-CycleLengthCoeff      UTRAN-DRX-CycleLengthCoefficient    OPTIONAL,
    -- Core network IEs
        cn-InformationInfo              CN-InformationInfo-r6               OPTIONAL,
    -- UTRAN mobility IEs
        ura-Identity                    URA-Identity                        OPTIONAL,
    -- Radio bearer IEs
        dl-CounterSynchronisationInfo   DL-CounterSynchronisationInfo-r5    OPTIONAL,
    -- Transport channel IEs
        ul-CommonTransChInfo            UL-CommonTransChInfo-r4             OPTIONAL,
```

```
        ul-AddReconfTransChInfoList     UL-AddReconfTransChInfoList-r6      OPTIONAL,
        dl-CommonTransChInfo            DL-CommonTransChInfo-r4             OPTIONAL,
        dl-AddReconfTransChInfoList     DL-AddReconfTransChInfoList-r5      OPTIONAL,
    -- Physical channel IEs
        frequencyInfo                   FrequencyInfo                       OPTIONAL,
        maxAllowedUL-TX-Power           MaxAllowedUL-TX-Power               OPTIONAL,
        ul-DPCH-Info                    UL-DPCH-Info-r7                     OPTIONAL,
        ul-EDCH-Information             UL-EDCH-Information-r6              OPTIONAL,
        dl-HSPDSCH-Information          DL-HSPDSCH-Information-r7           OPTIONAL,
        dl-CommonInformation            DL-CommonInformation-r7             OPTIONAL,
        dl-InformationPerRL-List        DL-InformationPerRL-List-r7         OPTIONAL,
    -- MBMS IEs
        mbms-PL-ServiceRestrictInfo     MBMS-PL-ServiceRestrictInfo-r6      OPTIONAL
}

-- **************************************************
--
-- TRANSPORT CHANNEL RECONFIGURATION COMPLETE
--
-- **************************************************

TransportChannelReconfigurationComplete ::= SEQUENCE {
    -- User equipment IEs
        rrc-TransactionIdentifier       RRC-TransactionIdentifier,
        ul-IntegProtActivationInfo      IntegrityProtActivationInfo         OPTIONAL,
        -- TABULAR: UL-TimingAdvance is applicable for TDD mode only.
        ul-TimingAdvance                UL-TimingAdvance                    OPTIONAL,
    -- Radio bearer IEs
        count-C-ActivationTime          ActivationTime                      OPTIONAL,
        -- dummy is not used in this version of the specification and
        -- it should be ignored by the receiver.
        dummy                           RB-ActivationTimeInfoList           OPTIONAL,
        ul-CounterSynchronisationInfo   UL-CounterSynchronisationInfo       OPTIONAL,
        laterNonCriticalExtensions      SEQUENCE {
            -- Container for additional R99 extensions
            transportChannelReconfigurationComplete-r3-add-ext      BIT STRING      OPTIONAL,
            v7xyNonCriticalExtensions       SEQUENCE {
                transportChannelReconfigurationComplete-v7xyext
                                    TransportChannelReconfigurationComplete-v7xyext-IEs,
                nonCriticalExtensions           SEQUENCE {}     OPTIONAL
            }   OPTIONAL
        }   OPTIONAL
}

TransportChannelReconfigurationComplete-v7xyext-IEs ::= SEQUENCE {
        ul-TimingAdvance-VHCR           UL-TimingAdvance-VHCR               OPTIONAL
}

-- **************************************************
--
-- TRANSPORT CHANNEL RECONFIGURATION FAILURE
--
-- **************************************************

TransportChannelReconfigurationFailure ::= SEQUENCE {
    -- User equipment IEs
        rrc-TransactionIdentifier       RRC-TransactionIdentifier,
        failureCause                    FailureCauseWithProtErr,
        laterNonCriticalExtensions          SEQUENCE {
            -- Container for additional R99 extensions
            transportChannelReconfigurationFailure-r3-add-ext       BIT STRING      OPTIONAL,
            nonCriticalExtensions           SEQUENCE {}     OPTIONAL
        }   OPTIONAL
}

-- **********************************************************
--
-- TRANSPORT FORMAT COMBINATION CONTROL in AM or UM RLC mode
--
-- **********************************************************

TransportFormatCombinationControl ::= SEQUENCE {
        -- rrc-TransactionIdentifier is always included in this version of the specification
        rrc-TransactionIdentifier       RRC-TransactionIdentifier           OPTIONAL,
        modeSpecificInfo                    CHOICE {
            fdd                                 NULL,
            tdd                                 SEQUENCE {
                tfcs-ID                             TFCS-Identity   OPTIONAL
```

```
            }
        },
        dpch-TFCS-InUplink                  TFC-Subset,
        activationTimeForTFCSubset          ActivationTime                      OPTIONAL,
        tfc-ControlDuration                 TFC-ControlDuration                 OPTIONAL,
        laterNonCriticalExtensions          SEQUENCE {
            -- Container for additional R99 extensions
            transportFormatCombinationControl-r3-add-ext        BIT STRING      OPTIONAL,
                nonCriticalExtensions           SEQUENCE {}     OPTIONAL
        }   OPTIONAL
}

-- **************************************************
--
-- TRANSPORT FORMAT COMBINATION CONTROL FAILURE
--
-- **************************************************

TransportFormatCombinationControlFailure ::= SEQUENCE {
    -- User equipment IEs
        rrc-TransactionIdentifier       RRC-TransactionIdentifier,
        failureCause                    FailureCauseWithProtErr,
        laterNonCriticalExtensions          SEQUENCE {
            -- Container for additional R99 extensions
            transportFormatCombinationControlFailure-r3-add-ext     BIT STRING      OPTIONAL,
            nonCriticalExtensions           SEQUENCE {}     OPTIONAL
        }   OPTIONAL
}

-- **************************************************
--
-- UE CAPABILITY ENQUIRY
--
-- **************************************************

UECapabilityEnquiry ::= CHOICE {
    r3                              SEQUENCE {
        ueCapabilityEnquiry-r3          UECapabilityEnquiry-r3-IEs,
        laterNonCriticalExtensions      SEQUENCE {
            -- Container for additional R99 extensions
            ueCapabilityEnquiry-r3-add-ext      BIT STRING      OPTIONAL,
            v4b0NonCriticalExtensions       SEQUENCE {
                ueCapabilityEnquiry-v4b0ext     UECapabilityEnquiry-v4b0ext-IEs,
                v590NonCriticalExtensions       SEQUENCE {
                    ueCapabilityEnquiry-v590ext     UECapabilityEnquiry-v590ext-IEs,
                    v7xyNonCriticalExtensions       SEQUENCE {
                        ueCapabilityEnquiry-v7xyext     UECapabilityEnquiry-v7xyext-IEs,
                        nonCriticalExtensions           SEQUENCE {}     OPTIONAL
                    }   OPTIONAL
                }   OPTIONAL
            }   OPTIONAL
        }   OPTIONAL
    },
    later-than-r3                   SEQUENCE {
        rrc-TransactionIdentifier       RRC-TransactionIdentifier,
        criticalExtensions              SEQUENCE {}
    }
}

UECapabilityEnquiry-r3-IEs ::= SEQUENCE {
    -- User equipment IEs
        rrc-TransactionIdentifier       RRC-TransactionIdentifier,
        capabilityUpdateRequirement     CapabilityUpdateRequirement
}

UECapabilityEnquiry-v4b0ext-IEs ::= SEQUENCE {
        capabilityUpdateRequirement-r4-ext  CapabilityUpdateRequirement-r4-ext
}

UECapabilityEnquiry-v590ext-IEs ::= SEQUENCE {
        systemSpecificCapUpdateReq      SystemSpecificCapUpdateReq-v590ext
}

UECapabilityEnquiry-v7xyext-IEs ::= SEQUENCE {
        capabilityUpdateRequirement-r7-ext      CapabilityUpdateRequirement-r7-ext      OPTIONAL
}

-- **************************************************
```

```
--
-- UE CAPABILITY INFORMATION
--
-- **************************************************

UECapabilityInformation ::= SEQUENCE {
    -- User equipment IEs
        rrc-TransactionIdentifier       RRC-TransactionIdentifier           OPTIONAL,
        ue-RadioAccessCapability        UE-RadioAccessCapability            OPTIONAL,
    -- Other IEs
        ue-RATSpecificCapability        InterRAT-UE-RadioAccessCapabilityList       OPTIONAL,
        v370NonCriticalExtensions           SEQUENCE {
            ueCapabilityInformation-v370ext UECapabilityInformation-v370ext,
            v380NonCriticalExtensions           SEQUENCE {
                ueCapabilityInformation-v380ext     UECapabilityInformation-v380ext-IEs,
                v3a0NonCriticalExtensions           SEQUENCE {
                    ueCapabilityInformation-v3a0ext     UECapabilityInformation-v3a0ext-IEs,
                    laterNonCriticalExtensions          SEQUENCE {
                        -- Container for additional R99 extensions
                        ueCapabilityInformation-r3-add-ext      BIT STRING
                                (CONTAINING UECapabilityInformation-r3-add-ext-IEs) OPTIONAL,
                        -- Reserved for future non critical extension
                        v4b0NonCriticalExtensions           SEQUENCE {
                            ueCapabilityInformation-v4b0ext     UECapabilityInformation-v4b0ext,
                            v590NonCriticalExtensions           SEQUENCE {
                                ueCapabilityInformation-v590ext     UECapabilityInformation-v590ext,
                                v5c0NonCriticalExtensions           SEQUENCE {
                                    ueCapabilityInformation-v5c0ext
                                                                    UECapabilityInformation-v5c0ext,
                                    v690NonCriticalExtensions           SEQUENCE {
                                        ueCapabilityInformation-v690ext
                                                                    UECapabilityInformation-v690ext-IEs,
                                        v7xyNonCriticalExtensions           SEQUENCE {
                                            ueCapabilityInformation-v7xyext
                                                                    UECapabilityInformation-v7xyext-IEs,
                                            nonCriticalExtensions           SEQUENCE {}     OPTIONAL
                                        }       OPTIONAL
                                    }       OPTIONAL
                                }       OPTIONAL
                            }       OPTIONAL
                        }       OPTIONAL
                    }       OPTIONAL
                }       OPTIONAL
            }       OPTIONAL
        }       OPTIONAL
}

UECapabilityInformation-v370ext ::= SEQUENCE {
    -- User equipment IEs
        ue-RadioAccessCapability-v370ext        UE-RadioAccessCapability-v370ext        OPTIONAL
}

UECapabilityInformation-v380ext-IEs ::= SEQUENCE {
    -- User equipment IEs
        ue-RadioAccessCapability-v380ext        UE-RadioAccessCapability-v380ext        OPTIONAL,
        dl-PhysChCapabilityFDD-v380ext          DL-PhysChCapabilityFDD-v380ext
}

UECapabilityInformation-v3a0ext-IEs ::= SEQUENCE {
    -- User equipment IEs
        ue-RadioAccessCapability-v3a0ext        UE-RadioAccessCapability-v3a0ext        OPTIONAL
}

UECapabilityInformation-r3-add-ext-IEs ::= SEQUENCE {
        ueCapabilityInformation-v650ext     UECapabilityInformation-v650ext-IEs     OPTIONAL,
        v680NonCriticalExtensions           SEQUENCE {
            ueCapabilityInformation-v680ext     UECapabilityInformation-v680ext-IEs,
            nonCriticalExtensions               SEQUENCE {}     OPTIONAL
        }       OPTIONAL
}

UECapabilityInformation-v4b0ext ::= SEQUENCE {
    -- User equipment IEs
        ue-RadioAccessCapability-v4b0ext        UE-RadioAccessCapability-v4b0ext        OPTIONAL
}

UECapabilityInformation-v590ext ::= SEQUENCE {
    -- User equipment IEs
```

```
        ue-RadioAccessCapability-v3g0ext        UE-RadioAccessCapability-v3g0ext        OPTIONAL,
        ue-RadioAccessCapability-v590ext        UE-RadioAccessCapability-v590ext        OPTIONAL,
    -- Other IEs
        ue-RATSpecificCapability-v590ext    InterRAT-UE-RadioAccessCapability-v590ext   OPTIONAL
}

UECapabilityInformation-v5c0ext ::= SEQUENCE {
    -- User equipment IEs
        ue-RadioAccessCapability-v5c0ext        UE-RadioAccessCapability-v5c0ext        OPTIONAL
}

UECapabilityInformation-v650ext-IEs ::= SEQUENCE {
        ue-RadioAccessCapability-v650ext        UE-RadioAccessCapability-v650ext
}

UECapabilityInformation-v680ext-IEs ::= SEQUENCE {
    -- User equipment IEs
        ue-RadioAccessCapability-v680ext        UE-RadioAccessCapability-v680ext
}

UECapabilityInformation-v690ext-IEs ::= SEQUENCE {
    -- User equipment IEs
        ueCapabilityContainer               BIT STRING
                                                (CONTAINING UE-CapabilityContainer-IEs) OPTIONAL
}

UECapabilityInformation-v7xyext-IEs ::= SEQUENCE {
        ue-RadioAccessCapability-v7xyext    UE-RadioAccessCapability-v7xyext        OPTIONAL
}

-- ****************************************************
--
-- UE CAPABILITY INFORMATION CONFIRM
--
-- ****************************************************

UECapabilityInformationConfirm ::= CHOICE {
    r3                              SEQUENCE {
        ueCapabilityInformationConfirm-r3
                                        UECapabilityInformationConfirm-r3-IEs,
        laterNonCriticalExtensions          SEQUENCE {
            -- Container for additional R99 extensions
            ueCapabilityInformationConfirm-r3-add-ext       BIT STRING      OPTIONAL,
            nonCriticalExtensions           SEQUENCE {}     OPTIONAL
        }   OPTIONAL
    },
    later-than-r3                   SEQUENCE {
        rrc-TransactionIdentifier       RRC-TransactionIdentifier,
        criticalExtensions              SEQUENCE {}
    }
}

UECapabilityInformationConfirm-r3-IEs ::= SEQUENCE {
    -- User equipment IEs
        rrc-TransactionIdentifier       RRC-TransactionIdentifier
}

-- ****************************************************
--
-- UPLINK DIRECT TRANSFER
--
-- ****************************************************

UplinkDirectTransfer ::= SEQUENCE {
    -- Core network IEs
        cn-DomainIdentity               CN-DomainIdentity,
        nas-Message                     NAS-Message,
    -- Measurement IEs
        measuredResultsOnRACH           MeasuredResultsOnRACH               OPTIONAL,
        laterNonCriticalExtensions          SEQUENCE {
            -- Container for additional R99 extensions
            uplinkDirectTransfer-r3-add-ext     BIT STRING      OPTIONAL,
            v690NonCriticalExtensions           SEQUENCE {
                uplinkDirectTransfer-v690ext        UplinkDirectTransfer-v690ext-IEs,
                nonCriticalExtensions               SEQUENCE {}     OPTIONAL
            }   OPTIONAL
        }   OPTIONAL
}
```

```
UplinkDirectTransfer-v690ext-IEs ::= SEQUENCE {
    -- Measurement IEs
    measuredResultsOnRACHinterFreq      MeasuredResultsOnRACHinterFreq              OPTIONAL
}

-- **************************************************
--
-- UPLINK PHYSICAL CHANNEL CONTROL
--
-- **************************************************

UplinkPhysicalChannelControl ::= CHOICE {
    r3                              SEQUENCE {
        uplinkPhysicalChannelControl-r3 UplinkPhysicalChannelControl-r3-IEs,
        laterNonCriticalExtensions          SEQUENCE {
            -- Container for additional R99 extensions
            uplinkPhysicalChannelControl-r3-add-ext     BIT STRING      OPTIONAL,
            v4b0NonCriticalExtensions       SEQUENCE {
                uplinkPysicalChannelControl-v4b0ext     UplinkPhysicalChannelControl-v4b0ext-IEs,
                -- Extension mechanism for non-release 4 information
                noncriticalExtensions           SEQUENCE {}                     OPTIONAL
            }   OPTIONAL
        }   OPTIONAL
    },
    later-than-r3                   SEQUENCE {
        rrc-TransactionIdentifier       RRC-TransactionIdentifier,
        criticalExtensions              CHOICE {
            r4                              SEQUENCE {
                uplinkPhysicalChannelControl-r4 UplinkPhysicalChannelControl-r4-IEs,
                v4d0NonCriticalExtensions           SEQUENCE {
                    -- Container for adding non critical extensions after freezing REL-5
                    uplinkPhysicalChannelControl-r4-add-ext     BIT STRING      OPTIONAL,
                    v690NonCriticalExtensions       SEQUENCE {
                        uplinkPhysicalChannelControl-v690ext    UplinkPhysicalChannelControl-v690ext-IEs,
                        nonCriticalExtensions           SEQUENCE {} OPTIONAL
                    }   OPTIONAL
                }   OPTIONAL
            },
            criticalExtensions          CHOICE {
                r5                              SEQUENCE {
                    uplinkPhysicalChannelControl-r5 UplinkPhysicalChannelControl-r5-IEs,
                    -- Container for adding non critical extensions after freezing REL-6
                    uplinkPhysicalChannelControl-r5-add-ext     BIT STRING      OPTIONAL,
                    v690NonCriticalExtensions       SEQUENCE {
                        uplinkPhysicalChannelControl-v690ext    UplinkPhysicalChannelControl-v690ext-IEs,
                        nonCriticalExtensions           SEQUENCE {} OPTIONAL
                    }   OPTIONAL
                },
                criticalExtensions              CHOICE {
                    r7                              SEQUENCE {
                        uplinkPhysicalChannelControl-r7 UplinkPhysicalChannelControl-r7-IEs,
                        -- Container for adding non critical extensions after freezing REL-8
                        uplinkPhysicalChannelControl-r7-add-ext     BIT STRING      OPTIONAL,
                        nonCriticalExtensions           SEQUENCE {}     OPTIONAL
                    },
                    criticalExtensions              SEQUENCE {}
                }
            }
        }
    }
}

UplinkPhysicalChannelControl-r3-IEs ::= SEQUENCE {
    -- User equipment IEs
        rrc-TransactionIdentifier       RRC-TransactionIdentifier,
    -- Physical channel IEs
        ccTrCH-PowerControlInfo         CCTrCH-PowerControlInfo             OPTIONAL,
        timingAdvance                   UL-TimingAdvanceControl             OPTIONAL,
        alpha                           Alpha                               OPTIONAL,
        specialBurstScheduling          SpecialBurstScheduling              OPTIONAL,
        prach-ConstantValue             ConstantValueTdd                    OPTIONAL,
        pusch-ConstantValue             ConstantValueTdd                    OPTIONAL
}

UplinkPhysicalChannelControl-v4b0ext-IEs ::= SEQUENCE {
    -- In case of TDD, openLoopPowerControl-IPDL-TDD is included instead of IE
    -- up-IPDL-Parameters in up-OTDOA-AssistanceData
```

```
    openLoopPowerControl-IPDL-TDD   OpenLoopPowerControl-IPDL-TDD-r4    OPTIONAL
}

UplinkPhysicalChannelControl-r4-IEs ::= SEQUENCE {
    -- Physical channel IEs
        ccTrCH-PowerControlInfo         CCTrCH-PowerControlInfo-r4          OPTIONAL,
        specialBurstScheduling          SpecialBurstScheduling              OPTIONAL,
        tddOption                       CHOICE {
            tdd384                          SEQUENCE {
                timingAdvance                   UL-TimingAdvanceControl-r4  OPTIONAL,
                alpha                           Alpha                       OPTIONAL,
                prach-ConstantValue             ConstantValueTdd            OPTIONAL,
                pusch-ConstantValue             ConstantValueTdd            OPTIONAL,
                openLoopPowerControl-IPDL-TDD   OpenLoopPowerControl-IPDL-TDD-r4    OPTIONAL
            },
            tdd128                          SEQUENCE {
                ul-SynchronisationParameters    UL-SynchronisationParameters-r4 OPTIONAL
            }
        }
}

UplinkPhysicalChannelControl-r5-IEs ::= SEQUENCE {
    -- Physical channel IEs
        ccTrCH-PowerControlInfo         CCTrCH-PowerControlInfo-r5          OPTIONAL,
        specialBurstScheduling          SpecialBurstScheduling              OPTIONAL,
        tddOption                       CHOICE {
            tdd384                          SEQUENCE {
                timingAdvance                   UL-TimingAdvanceControl-r4  OPTIONAL,
                alpha                           Alpha                       OPTIONAL,
                prach-ConstantValue             ConstantValueTdd            OPTIONAL,
                pusch-ConstantValue             ConstantValueTdd            OPTIONAL,
                openLoopPowerControl-IPDL-TDD   OpenLoopPowerControl-IPDL-TDD-r4    OPTIONAL,
                hs-SICH-PowerControl            HS-SICH-Power-Control-Info-TDD384   OPTIONAL
            },
            tdd128                          SEQUENCE {
                ul-SynchronisationParameters    UL-SynchronisationParameters-r4 OPTIONAL
            }
        }
}

UplinkPhysicalChannelControl-v690ext-IEs ::= SEQUENCE {
    -- Physical Channel IEs
        beaconPLEst                     BEACON-PL-Est                       OPTIONAL
}

UplinkPhysicalChannelControl-r7-IEs ::= SEQUENCE {
    -- Physical channel IEs
        ccTrCH-PowerControlInfo         CCTrCH-PowerControlInfo-r7          OPTIONAL,
        specialBurstScheduling          SpecialBurstScheduling              OPTIONAL,
        tddOption                       CHOICE {
            tdd384                          SEQUENCE {
                timingAdvance                   UL-TimingAdvanceControl-r4  OPTIONAL,
                alpha                           Alpha                       OPTIONAL,
                prach-ConstantValue             ConstantValueTdd            OPTIONAL,
                pusch-ConstantValue             ConstantValueTdd            OPTIONAL,
                openLoopPowerControl-IPDL-TDD   OpenLoopPowerControl-IPDL-TDD-r4    OPTIONAL,
                hs-SICH-PowerControl            HS-SICH-Power-Control-Info-TDD384   OPTIONAL
            },
            tdd768                          SEQUENCE {
                timingAdvance                   UL-TimingAdvanceControl-r7  OPTIONAL,
                alpha                           Alpha                       OPTIONAL,
                prach-ConstantValue             ConstantValueTdd            OPTIONAL,
                pusch-ConstantValue             ConstantValueTdd            OPTIONAL,
                openLoopPowerControl-IPDL-TDD   OpenLoopPowerControl-IPDL-TDD-r4    OPTIONAL,
                hs-SICH-PowerControl            HS-SICH-Power-Control-Info-TDD768   OPTIONAL
            },
            tdd128                          SEQUENCE {
                ul-SynchronisationParameters    UL-SynchronisationParameters-r4 OPTIONAL
            }
        }
}

-- **************************************************
--
-- URA UPDATE
--
-- **************************************************
```

```
URAUpdate ::= SEQUENCE {
    -- User equipment IEs
        u-RNTI                          U-RNTI,
        ura-UpdateCause                 URA-UpdateCause,
        protocolErrorIndicator          ProtocolErrorIndicatorWithMoreInfo,
        laterNonCriticalExtensions          SEQUENCE {
            -- Container for additional R99 extensions
            uraUpdate-r3-add-ext        BIT STRING      OPTIONAL,
            nonCriticalExtensions           SEQUENCE {}     OPTIONAL
        }   OPTIONAL
}

-- **************************************************
--
-- URA UPDATE CONFIRM
--
-- **************************************************

URAUpdateConfirm ::= CHOICE {
    r3                              SEQUENCE {
        uraUpdateConfirm-r3             URAUpdateConfirm-r3-IEs,
        laterNonCriticalExtensions          SEQUENCE {
            -- Container for additional R99 extensions
            uraUpdateConfirm-r3-add-ext     BIT STRING      OPTIONAL,
            v690NonCriticalExtensions       SEQUENCE {
                uraUpdateConfirm-v690ext            URAUpdateConfirm-v690ext-IEs,
                nonCriticalExtensions           SEQUENCE {}     OPTIONAL
            }   OPTIONAL
        }   OPTIONAL
    },
    later-than-r3                   SEQUENCE {
        rrc-TransactionIdentifier       RRC-TransactionIdentifier,
        criticalExtensions              CHOICE {
            r5                              SEQUENCE {
                uraUpdateConfirm-r5             URAUpdateConfirm-r5-IEs,
                v690NonCriticalExtensions       SEQUENCE {
                    uraUpdateConfirm-v690ext            URAUpdateConfirm-v690ext-IEs,
                    nonCriticalExtensions           SEQUENCE {}     OPTIONAL
                }   OPTIONAL
            },
            criticalExtensions              SEQUENCE {}
        }
    }
}

URAUpdateConfirm-r3-IEs ::= SEQUENCE {
    -- User equipment IEs
        rrc-TransactionIdentifier       RRC-TransactionIdentifier,
        integrityProtectionModeInfo     IntegrityProtectionModeInfo         OPTIONAL,
        cipheringModeInfo               CipheringModeInfo                   OPTIONAL,
        new-U-RNTI                      U-RNTI                              OPTIONAL,
        new-C-RNTI                      C-RNTI                              OPTIONAL,
        rrc-StateIndicator              RRC-StateIndicator,
        utran-DRX-CycleLengthCoeff      UTRAN-DRX-CycleLengthCoefficient    OPTIONAL,
    -- CN information elements
        cn-InformationInfo              CN-InformationInfo                  OPTIONAL,
    -- UTRAN mobility IEs
        ura-Identity                    URA-Identity                        OPTIONAL,
    -- Radio bearer IEs
        dl-CounterSynchronisationInfo   DL-CounterSynchronisationInfo       OPTIONAL
}

URAUpdateConfirm-r5-IEs ::= SEQUENCE {
    -- User equipment IEs
        integrityProtectionModeInfo     IntegrityProtectionModeInfo         OPTIONAL,
        cipheringModeInfo               CipheringModeInfo                   OPTIONAL,
        new-U-RNTI                      U-RNTI                              OPTIONAL,
        new-C-RNTI                      C-RNTI                              OPTIONAL,
        rrc-StateIndicator              RRC-StateIndicator,
        utran-DRX-CycleLengthCoeff      UTRAN-DRX-CycleLengthCoefficient    OPTIONAL,
    -- CN information elements
        cn-InformationInfo              CN-InformationInfo                  OPTIONAL,
    -- UTRAN mobility IEs
        ura-Identity                    URA-Identity                        OPTIONAL,
    -- Radio bearer IEs
        dl-CounterSynchronisationInfo   DL-CounterSynchronisationInfo-r5    OPTIONAL
}
```

```
URAUpdateConfirm-v690ext-IEs ::= SEQUENCE {
    -- Core network IEs
        primary-plmn-Identity               PLMN-Identity                   OPTIONAL
}

-- **************************************************
--
-- URA UPDATE CONFIRM for CCCH
--
-- **************************************************

URAUpdateConfirm-CCCH ::= CHOICE {
    r3                              SEQUENCE {
        uraUpdateConfirm-CCCH-r3        URAUpdateConfirm-CCCH-r3-IEs,
        laterNonCriticalExtensions          SEQUENCE {
            -- Container for additional R99 extensions
            uraUpdateConfirm-CCCH-r3-add-ext        BIT STRING      OPTIONAL,
            v690NonCriticalExtensions       SEQUENCE {
                uraUpdateConfirm-v690ext            URAUpdateConfirm-v690ext-IEs,
                nonCriticalExtensions           SEQUENCE {}     OPTIONAL
            }   OPTIONAL
        }   OPTIONAL
    },
    later-than-r3                   SEQUENCE {
        u-RNTI                          U-RNTI,
        rrc-TransactionIdentifier       RRC-TransactionIdentifier,
        criticalExtensions              SEQUENCE {}
    }
}

URAUpdateConfirm-CCCH-r3-IEs ::= SEQUENCE {
    -- User equipment IEs
        u-RNTI                          U-RNTI,
    -- The rest of the message is identical to the one sent on DCCH.
        uraUpdateConfirm                URAUpdateConfirm-r3-IEs
}

-- **************************************************
--
-- UTRAN MOBILITY INFORMATION
--
-- **************************************************

UTRANMobilityInformation ::= CHOICE {
    r3                              SEQUENCE {
        utranMobilityInformation-r3     UTRANMobilityInformation-r3-IEs,
        v3a0NonCriticalExtensions       SEQUENCE {
            utranMobilityInformation-v3a0ext    UTRANMobilityInformation-v3a0ext-IEs,
            laterNonCriticalExtensions          SEQUENCE {
                -- Container for additional R99 extensions
                utranMobilityInformation-r3-add-ext     BIT STRING      OPTIONAL,
                v690NonCriticalExtensions           SEQUENCE {
                    utranMobilityInformation-v690ext    UtranMobilityInformation-v690ext-IEs,
                    nonCriticalExtensions               SEQUENCE {}     OPTIONAL
                }       OPTIONAL
            }       OPTIONAL
        }       OPTIONAL
    },
    later-than-r3                   SEQUENCE {
        rrc-TransactionIdentifier       RRC-TransactionIdentifier,
        criticalExtensions              CHOICE {
            r5                              SEQUENCE {
                utranMobilityInformation-r5     UTRANMobilityInformation-r5-IEs,
                v690NonCriticalExtensions       SEQUENCE {
                    utranMobilityInformation-v690ext    UtranMobilityInformation-v690ext-IEs,
                    nonCriticalExtensions           SEQUENCE {}     OPTIONAL
                }   OPTIONAL
            },
            criticalExtensions              SEQUENCE {}
        }
    }
}

UTRANMobilityInformation-r3-IEs ::= SEQUENCE {
    -- User equipment IEs
        rrc-TransactionIdentifier       RRC-TransactionIdentifier,
        integrityProtectionModeInfo     IntegrityProtectionModeInfo         OPTIONAL,
        cipheringModeInfo               CipheringModeInfo                   OPTIONAL,
```

```
        new-U-RNTI                      U-RNTI                              OPTIONAL,
        new-C-RNTI                      C-RNTI                              OPTIONAL,
        ue-ConnTimersAndConstants       UE-ConnTimersAndConstants           OPTIONAL,
    -- CN information elements
        cn-InformationInfo              CN-InformationInfoFull              OPTIONAL,
    -- UTRAN mobility IEs
        ura-Identity                    URA-Identity                        OPTIONAL,
    -- Radio bearer IEs
        dl-CounterSynchronisationInfo   DL-CounterSynchronisationInfo       OPTIONAL,
    -- Extension mechanism for non- release99 information
        nonCriticalExtensions           SEQUENCE {}     OPTIONAL
}

UTRANMobilityInformation-v3a0ext-IEs ::= SEQUENCE {
    ue-ConnTimersAndConstants-v3a0ext       UE-ConnTimersAndConstants-v3a0ext
}

UTRANMobilityInformation-r5-IEs ::= SEQUENCE {
    -- User equipment IEs
        integrityProtectionModeInfo     IntegrityProtectionModeInfo         OPTIONAL,
        cipheringModeInfo               CipheringModeInfo                   OPTIONAL,
        new-U-RNTI                      U-RNTI                              OPTIONAL,
        new-C-RNTI                      C-RNTI                              OPTIONAL,
        ue-ConnTimersAndConstants       UE-ConnTimersAndConstants-r5        OPTIONAL,
    -- CN information elements
        cn-InformationInfo              CN-InformationInfoFull              OPTIONAL,
    -- UTRAN mobility IEs
        ura-Identity                    URA-Identity                        OPTIONAL,
    -- Radio bearer IEs
        dl-CounterSynchronisationInfo   DL-CounterSynchronisationInfo-r5    OPTIONAL
}

UtranMobilityInformation-v690ext-IEs ::= SEQUENCE {
    -- Core network IEs
        primary-plmn-Identity               PLMN-Identity                       OPTIONAL
}

-- **************************************************
--
-- UTRAN MOBILITY INFORMATION CONFIRM
--
-- **************************************************

UTRANMobilityInformationConfirm ::= SEQUENCE {
    -- User equipment IEs
        rrc-TransactionIdentifier       RRC-TransactionIdentifier,
        ul-IntegProtActivationInfo      IntegrityProtActivationInfo         OPTIONAL,
    -- Radio bearer IEs
        count-C-ActivationTime          ActivationTime                      OPTIONAL,
        -- dummy is not used in this version of the specification and
        -- it should be ignored by the receiver.
        dummy                           RB-ActivationTimeInfoList           OPTIONAL,
        ul-CounterSynchronisationInfo   UL-CounterSynchronisationInfo       OPTIONAL,
        laterNonCriticalExtensions          SEQUENCE {
            -- Container for additional R99 extensions
            utranMobilityInformationConfirm-r3-add-ext      BIT STRING      OPTIONAL,
            nonCriticalExtensions           SEQUENCE {}     OPTIONAL
        }   OPTIONAL
}

-- **************************************************
--
-- UTRAN MOBILITY INFORMATION FAILURE
--
-- **************************************************

UTRANMobilityInformationFailure ::= SEQUENCE {
    -- UE information elements
        rrc-TransactionIdentifier       RRC-TransactionIdentifier,
        failureCause                    FailureCauseWithProtErr,
        laterNonCriticalExtensions          SEQUENCE {
            -- Container for additional R99 extensions
            utranMobilityInformationFailure-r3-add-ext      BIT STRING      OPTIONAL,
            nonCriticalExtensions           SEQUENCE {}     OPTIONAL
        }   OPTIONAL
}

-- **************************************************
```

```
--
-- MBMS ACCESS INFORMATION
--
-- ****************************************************

MBMSAccessInformation ::= SEQUENCE {
    -- Access Information IEs
        mbms-ServiceAccessInfoList      MBMS-ServiceAccessInfoList-r6,
    -- Non critical extensions
        nonCriticalExtensions           SEQUENCE {}     OPTIONAL
}

-- ****************************************************
--
-- MBMS COMMON PTM RB INFORMATION
--
-- ****************************************************

MBMSCommonPTMRBInformation ::= SEQUENCE {
    -- Common PTM RB Information IEs
        mbms-CommonRBInformationList    MBMS-CommonRBInformationList-r6,
        mbms-TranspChInfoForEachTrCh    MBMS-TranspChInfoForEachTrCh-r6,
        mbms-TranspChInfoForEachCCTrCh  MBMS-TranspChInfoForEachCCTrCh-r6   OPTIONAL,
        mbms-PhyChInformationList       MBMS-PhyChInformationList-r6,
    -- Non critical extensions
        nonCriticalExtensions           SEQUENCE {}     OPTIONAL
}

-- ****************************************************
--
-- MBMS CURRENT CELL PTM RB INFORMATION
--
-- ****************************************************

MBMSCurrentCellPTMRBInformation ::= SEQUENCE {
    -- Current Cell PTM RB Information IEs
        mbms-CurrentCell-SCCPCHList     MBMS-CurrentCell-SCCPCHList-r6      OPTIONAL,
        mbms-SIBType5-SCCPCHList        MBMS-SIBType5-SCCPCHList-r6         OPTIONAL,
    -- Non critical extensions
        nonCriticalExtensions           SEQUENCE {}     OPTIONAL
}

-- ****************************************************
--
-- MBMS GENERAL INFORMATION
--
-- ****************************************************

MBMSGeneralInformation ::= SEQUENCE {
    -- MBMS General Information IEs
        mbms-PreferredFrequencyInfo     MBMS-PreferredFrequencyList-r6      OPTIONAL,
        mbms-TimersAndCounters          MBMS-TimersAndCounters-r6,
        michConfigurationInfo           MBMS-MICHConfigurationInfo-r6,
        cellGroupIdentity               MBMS-CellGroupIdentity-r6,
        mschDefaultConfigurationInfo    MBMS-MSCH-ConfigurationInfo-r6      OPTIONAL,
    -- Non critical extensions
        v7xyNonCriticalExtensions       SEQUENCE {
            mbmsGenerAlInformation-v7xyext  MBMSGeneralInformation-v7xyext-IEs,
            nonCriticalExtensions           SEQUENCE {}     OPTIONAL
        }
}

MBMSGeneralInformation-v7xyext-IEs ::= SEQUENCE {
        mbmsMICHConfiguration-v7xyext   MBMS-MICHConfigurationInfo-r7       OPTIONAL
}

-- ****************************************************
--
-- MBMS MODIFICATION REQUEST
--
-- ****************************************************

MBMSModificationRequest ::= SEQUENCE {
    -- MBMS Modification Request IEs
        mbms-PreferredFreqRequest       MBMS-ServiceIdentity-r6             OPTIONAL,
        rb-InformationReleaseList       RB-InformationReleaseList           OPTIONAL,
    -- Non critical extensions
        nonCriticalExtensions           SEQUENCE {}     OPTIONAL
```

```
}

-- **************************************************
--
-- MBMS MODIFIED SERVICES INFORMATION
--
-- **************************************************

MBMSModifiedServicesInformation ::= SEQUENCE {
    -- MBMS Modified Services Information IEs
        modifedServiceList              MBMS-ModifedServiceList-r6          OPTIONAL,
        mbms-ReacquireMCCH              ENUMERATED { true }                 OPTIONAL,
        mbms-DynamicPersistenceLevel    DynamicPersistenceLevel             OPTIONAL,
        endOfModifiedMCCHInformation    INTEGER (1..16)                     OPTIONAL,
        mbmsNumberOfNeighbourCells      MBMS-NumberOfNeighbourCells-r6,
        mbms-AllUnmodifiedPTMServices   ENUMERATED { true }                 OPTIONAL,
        mbms-PTMActivationTime          MBMS-PTMActivationTime-r6           OPTIONAL,
    -- Non critical extensions
        nonCriticalExtensions           SEQUENCE {}     OPTIONAL
}

-- **************************************************
--
-- MBMS NEIGHBOURING CELL PTM RB INFORMATION
--
-- **************************************************

MBMSNeighbouringCellPTMRBInformation ::= SEQUENCE {
    -- MBMS Neighbouring Cell PTM RB Information IEs
        neighbouringCellIdentity        IntraFreqCellID,
        neighbouringCellSCCPCHList      MBMS-NeighbouringCellSCCPCHList-r6,
    -- Non critical extensions
        nonCriticalExtensions           SEQUENCE {}     OPTIONAL
}

-- **************************************************
--
-- MBMS SCHEDULING INFORMATION
--
-- **************************************************

MBMSSchedulingInformation ::= SEQUENCE {
    -- MBMS Scheduling Information IEs
        serviceSchedulingInfoList       MBMS-ServiceSchedulingInfoList-r6,
    -- Non critical extensions
        nonCriticalExtensions           SEQUENCE {}     OPTIONAL
}

-- **************************************************
--
-- MBMS UNMODIFIED SERVICES INFORMATION
--
-- **************************************************

MBMSUnmodifiedServicesInformation ::= SEQUENCE {
    -- MBMS Unmodified Services Information IEs
        unmodifiedServiceList           MBMS-UnmodifiedServiceList-r6       OPTIONAL,
    -- Non critical extensions
        nonCriticalExtensions           SEQUENCE {}     OPTIONAL
}

END
```

# 11.3 Information element definitions

```
InformationElements DEFINITIONS AUTOMATIC TAGS ::=

-- **************************************************
--
--     CORE NETWORK INFORMATION ELEMENTS (10.3.1)
--
-- **************************************************

BEGIN

IMPORTS
```

```
hiPDSCHidentities,
hiPUSCHidentities,
hiRM,
maxAC,
maxAdditionalMeas,
maxASC,
maxASCmap,
maxASCpersist,
maxCCTrCH,
maxCellMeas,
maxCellMeas-1,
maxCNdomains,
maxCPCHsets,
maxDPCH-DLchan,
maxDPDCH-UL,
maxDRACclasses,
maxE-DCHMACdFlow,
maxE-DCHMACdFlow-1,
maxFACHPCH,
maxFreq,
maxFreqBandsFDD,
maxFreqBandsFDD-ext,
maxFreqBandsTDD,
maxFreqBandsGSM,
maxGERAN-SI,
maxHProcesses,
maxHSDSCHTBIndex,
maxHSDSCHTBIndex-tdd384,
maxHSSCCHs,
maxInterSysMessages,
maxLoCHperRLC,
maxMAC-d-PDUsizes,
maxMBMS-CommonCCTrCh,
maxMBMS-CommonPhyCh,
maxMBMS-CommonRB,
maxMBMS-CommonTrCh,
maxMBMS-Freq,
maxMBMS-L1CP,
maxMBMSservCount,
maxMBMSservModif,
maxMBMSservSched,
maxMBMSservUnmodif,
maxMBMSTransmis,
maxMeasEvent,
maxMeasIntervals,
maxMeasParEvent,
maxNumCDMA2000Freqs,
maxNumFDDFreqs,
maxNumGSMFreqRanges,
maxGSMTargetCells,
maxNumTDDFreqs,
maxOtherRAT,
maxOtherRAT-16,
maxPage1,
maxPCPCH-APsig,
maxPCPCH-APsubCh,
maxPCPCH-CDsig,
maxPCPCH-CDsubCh,
maxPCPCH-SF,
maxPCPCHs,
maxPDCPAlgoType,
maxPDSCH,
maxPDSCH-TFCIgroups,
maxPRACH,
maxPRACH-FPACH,
maxPredefConfig,
maxPUSCH,
maxQueueIDs,
maxRABsetup,
maxRAT,
maxRB,
maxRBallRABs,
maxRBperTrCh,
maxRBMuxOptions,
maxRBperRAB,
maxReportedGSMCells,
maxRLCPDUsizePerLogChan,
maxSRBsetup,
maxRL,
```

```
    maxRL-1,
    maxEDCHRL,
    maxROHC-PacketSizes-r4,
    maxROHC-Profile-r4,
    maxSCCPCH,
    maxSat,
    maxSIB,
    maxSIB-FACH,
    maxSystemCapability,
    maxTF,
    maxTF-CPCH,
    maxTFC,
    maxTFCsub,
    maxTFCI-2-Combs,
    maxTGPS,
    maxTrCH,
    maxTrCHpreconf,
    maxTS,
    maxTS-1,
    maxTS-2,
    maxTS-LCR,
    maxTS-LCR-1,
    maxURA,
    maxURNTI-Group
FROM Constant-definitions;

Ansi-41-IDNNS ::=                       BIT STRING (SIZE (14))

CN-DomainIdentity ::=               ENUMERATED {
                                        cs-domain,
                                        ps-domain }

CN-DomainInformation ::=            SEQUENCE {
    cn-DomainIdentity                   CN-DomainIdentity,
    cn-DomainSpecificNAS-Info           NAS-SystemInformationGSM-MAP
}

CN-DomainInformationFull ::=        SEQUENCE {
    cn-DomainIdentity                   CN-DomainIdentity,
    cn-DomainSpecificNAS-Info           NAS-SystemInformationGSM-MAP,
    cn-DRX-CycleLengthCoeff             CN-DRX-CycleLengthCoefficient
}

CN-DomainInformationList ::=        SEQUENCE (SIZE (1..maxCNdomains)) OF
                                        CN-DomainInformation

CN-DomainInformationListFull ::=    SEQUENCE (SIZE (1..maxCNdomains)) OF
                                        CN-DomainInformationFull

CN-DomainSysInfo ::=                SEQUENCE {
    cn-DomainIdentity                   CN-DomainIdentity,
    cn-Type                             CHOICE {
        gsm-MAP                             NAS-SystemInformationGSM-MAP,
        ansi-41                             NAS-SystemInformationANSI-41
    },
    cn-DRX-CycleLengthCoeff             CN-DRX-CycleLengthCoefficient
}

CN-DomainSysInfoList ::=            SEQUENCE (SIZE (1..maxCNdomains)) OF
                                        CN-DomainSysInfo

CN-InformationInfo ::=              SEQUENCE {
    plmn-Identity                       PLMN-Identity                       OPTIONAL,
    cn-CommonGSM-MAP-NAS-SysInfo        NAS-SystemInformationGSM-MAP        OPTIONAL,
    cn-DomainInformationList            CN-DomainInformationList            OPTIONAL
}

CN-InformationInfo-r6 ::=           SEQUENCE {
    plmn-Identity                       PLMN-Identity                       OPTIONAL,
    cn-CommonGSM-MAP-NAS-SysInfo        NAS-SystemInformationGSM-MAP        OPTIONAL,
    cn-DomainInformationList            CN-DomainInformationList            OPTIONAL,
    primary-plmn-Identity               PLMN-Identity                       OPTIONAL
}

CN-InformationInfoFull ::=          SEQUENCE {
    plmn-Identity                       PLMN-Identity                       OPTIONAL,
    cn-CommonGSM-MAP-NAS-SysInfo        NAS-SystemInformationGSM-MAP        OPTIONAL,
    cn-DomainInformationListFull        CN-DomainInformationListFull        OPTIONAL
}
```

```
Digit ::=                           INTEGER (0..9)

Gsm-map-IDNNS ::=                           SEQUENCE {
    routingbasis                                    CHOICE {
        localPTMSI                                      SEQUENCE {
            routingparameter                                RoutingParameter
        },
        tMSIofsamePLMN                                  SEQUENCE {
            routingparameter                                RoutingParameter
        },
        tMSIofdifferentPLMN                             SEQUENCE {
            routingparameter                                RoutingParameter
        },
        iMSIresponsetopaging                            SEQUENCE {
            routingparameter                                RoutingParameter
        },
        iMSIcauseUEinitiatedEvent                       SEQUENCE {
            routingparameter                                RoutingParameter
        },
        iMEI                                            SEQUENCE {
            routingparameter                                RoutingParameter
        },
        spare2                                          SEQUENCE {
            routingparameter                                RoutingParameter
        },
        spare1                                          SEQUENCE {
            routingparameter                                RoutingParameter
        }
    },
    -- dummy is not used in this version of the specification and
    -- it should be ignored by the receiver.
    dummy                                   BOOLEAN
}

IMEI ::=                            SEQUENCE (SIZE (15)) OF
                                        IMEI-Digit

IMEI-Digit ::=                      INTEGER (0..15)

IMSI-GSM-MAP ::=                    SEQUENCE (SIZE (6..21)) OF
                                        Digit

IntraDomainNasNodeSelector ::=                  SEQUENCE {
    version                                         CHOICE {
        release99                                       SEQUENCE {
            cn-Type                                         CHOICE {
                gsm-Map-IDNNS                                   Gsm-map-IDNNS,
                ansi-41-IDNNS                                   Ansi-41-IDNNS
            }
        },
        later                                           SEQUENCE {
            futurecoding                                    BIT STRING (SIZE (15))
        }
    }
}

LAI ::=                             SEQUENCE {
    plmn-Identity                       PLMN-Identity,
    lac                                 BIT STRING (SIZE (16))
}

MCC ::=                             SEQUENCE (SIZE (3)) OF
                                        Digit

MNC ::=                             SEQUENCE (SIZE (2..3)) OF
                                        Digit

MultiplePLMN-List-r6 ::=            SEQUENCE {
    mibPLMN-Identity                    BOOLEAN,
    multiplePLMNs                       SEQUENCE (SIZE (1..5)) OF
                                            PLMN-IdentityWithOptionalMCC-r6
}

NAS-Message ::=                     OCTET STRING (SIZE (1..4095))

NAS-Synchronisation-Indicator ::=   BIT STRING(SIZE(4))
```

```
NAS-SystemInformationGSM-MAP ::=    OCTET STRING (SIZE (1..8))

P-TMSI-GSM-MAP ::=                  BIT STRING (SIZE (32))

PagingRecordTypeID ::=              ENUMERATED {
                                        imsi-GSM-MAP,
                                        tmsi-GSM-MAP-P-TMSI,
                                        imsi-DS-41,
                                        tmsi-DS-41 }

PLMN-Identity ::=                   SEQUENCE {
    mcc                                 MCC,
    mnc                                 MNC
}

PLMN-IdentityWithOptionalMCC-r6 ::= SEQUENCE {
    mcc                                 MCC                     OPTIONAL,
    mnc                                 MNC
}

PLMN-Type ::=                       CHOICE {
    gsm-MAP                             SEQUENCE {
        plmn-Identity                       PLMN-Identity
    },
    ansi-41                         SEQUENCE {
        p-REV                           P-REV,
        min-P-REV                       Min-P-REV,
        sid                             SID,
        nid                             NID
    },
    gsm-MAP-and-ANSI-41             SEQUENCE {
        plmn-Identity                   PLMN-Identity,
        p-REV                           P-REV,
        min-P-REV                       Min-P-REV,
        sid                             SID,
        nid                             NID
    },
    spare                           NULL
}

RAB-Identity ::=                    CHOICE {
    gsm-MAP-RAB-Identity                BIT STRING (SIZE (8)),
    ansi-41-RAB-Identity                BIT STRING (SIZE (8))
}

RAI ::=                             SEQUENCE {
    lai                                 LAI,
    rac                                 RoutingAreaCode
}

RoutingAreaCode ::=                 BIT STRING (SIZE (8))

RoutingParameter ::=                            BIT STRING (SIZE (10))

TMSI-GSM-MAP ::=                    BIT STRING (SIZE (32))

-- **************************************************
--
--     UTRAN MOBILITY INFORMATION ELEMENTS (10.3.2)
--
-- **************************************************

AccessClassBarred ::=               ENUMERATED {
                                        barred, notBarred }

AccessClassBarredList ::=           SEQUENCE (SIZE (maxAC)) OF
                                        AccessClassBarred

AllowedIndicator ::=                ENUMERATED {
                                        allowed, notAllowed }

CellAccessRestriction ::=           SEQUENCE {
    cellBarred                          CellBarred,
    cellReservedForOperatorUse          ReservedIndicator,
    cellReservationExtension            ReservedIndicator,
    -- NOTE: IE accessClassBarredList should not be included if the IE CellAccessRestriction
    -- is included in the IE SysInfoType4
    accessClassBarredList               AccessClassBarredList               OPTIONAL
```

```
}

CellBarred ::=                      CHOICE {
    barred                              SEQUENCE {
        intraFreqCellReselectionInd         AllowedIndicator,
        t-Barred                            T-Barred
    },
    notBarred                           NULL
}

CellIdentity ::=                    BIT STRING (SIZE (28))

CellIdentity-PerRL-List ::=         SEQUENCE (SIZE (1..maxRL)) OF CellIdentity

CellSelectReselectInfoSIB-3-4 ::=   SEQUENCE {
    mappingInfo                         MappingInfo                         OPTIONAL,
    cellSelectQualityMeasure            CHOICE {
        cpich-Ec-N0                         SEQUENCE {
            -- Default value for q-HYST-2-S is q-HYST-1-S
            q-HYST-2-S                          Q-Hyst-S                    OPTIONAL
            -- Default value for q-HYST-2-S is q-HYST-1-S
        },
        cpich-RSCP                          NULL
    },
    modeSpecificInfo                    CHOICE {
        fdd                                 SEQUENCE {
            s-Intrasearch                       S-SearchQual                OPTIONAL,
            s-Intersearch                       S-SearchQual                OPTIONAL,
            s-SearchHCS                         S-SearchRXLEV               OPTIONAL,
            rat-List                            RAT-FDD-InfoList            OPTIONAL,
            q-QualMin                           Q-QualMin,
            q-RxlevMin                          Q-RxlevMin
        },
        tdd                                 SEQUENCE {
            s-Intrasearch                       S-SearchRXLEV               OPTIONAL,
            s-Intersearch                       S-SearchRXLEV               OPTIONAL,
            s-SearchHCS                         S-SearchRXLEV               OPTIONAL,
            rat-List                            RAT-TDD-InfoList            OPTIONAL,
            q-RxlevMin                          Q-RxlevMin
        }
    },
    q-Hyst-l-S                          Q-Hyst-S,
    t-Reselection-S                     T-Reselection-S,
    hcs-ServingCellInformation          HCS-ServingCellInformation          OPTIONAL,
    maxAllowedUL-TX-Power               MaxAllowedUL-TX-Power
}

DomainSpecificAccessRestrictionForSharedNetwork-v670ext ::= CHOICE {
        domainSpecificAccessRestictionList                  DomainSpecificAccessRestrictionList-
v670ext,
        domainSpecificAccessRestictionParametersForAll      DomainSpecificAccessRestrictionParam-
v670ext
}

DomainSpecificAccessRestrictionList-v670ext ::= SEQUENCE {
        domainSpecificAccessRestrictionParametersForOperator1
                                    DomainSpecificAccessRestrictionParam-v670ext    OPTIONAL,
        domainSpecificAccessRestrictionParametersForOperator2
                                    DomainSpecificAccessRestrictionParam-v670ext    OPTIONAL,
        domainSpecificAccessRestrictionParametersForOperator3
                                    DomainSpecificAccessRestrictionParam-v670ext    OPTIONAL,
        domainSpecificAccessRestrictionParametersForOperator4
                                    DomainSpecificAccessRestrictionParam-v670ext    OPTIONAL,
        domainSpecificAccessRestrictionParametersForOperator5
                                    DomainSpecificAccessRestrictionParam-v670ext    OPTIONAL
}

DomainSpecificAccessRestrictionParam-v670ext ::= SEQUENCE {
        cSDomainSpecificAccessRestriction       DomainSpecificAccessRestriction-v670ext,
        pSDomainSpecificAccessRestriction       DomainSpecificAccessRestriction-v670ext
}

DomainSpecificAccessRestriction-v670ext ::= CHOICE {
        noRestriction       NULL,
        restriction         SEQUENCE {
            domainSpecficAccessClassBarredList      AccessClassBarredList   OPTIONAL
        }
}
```

```
MapParameter ::=                    INTEGER (0..99)

Mapping ::=                         SEQUENCE {
    rat                                 RAT,
    mappingFunctionParameterList        MappingFunctionParameterList
}

Mapping-LCR-r4 ::=                  SEQUENCE {
    mappingFunctionParameterList        MappingFunctionParameterList
}

MappingFunctionParameter ::=        SEQUENCE {
    functionType                        MappingFunctionType,
    mapParameter1                       MapParameter                        OPTIONAL,
    mapParameter2                       MapParameter,
    -- The presence of upperLimit is conditional on the number of repetition
    upperLimit                          UpperLimit                          OPTIONAL
}

MappingFunctionParameterList ::=    SEQUENCE (SIZE (1..maxMeasIntervals)) OF
                                        MappingFunctionParameter

MappingFunctionType ::=             ENUMERATED {
                                        linear,
                                        functionType2,
                                        functionType3,
                                        functionType4 }

-- In MappingInfo list, mapping for FDD and 3.84Mcps TDD is defined.
-- For 1.28Mcps TDD, Mapping-LCR-r4 is used instead.
MappingInfo ::=                     SEQUENCE (SIZE (1..maxRAT)) OF
                                        Mapping

-- Actual value Q-Hyst-S = IE value * 2
Q-Hyst-S ::=                        INTEGER (0..20)

Q-Hyst-S-Fine ::= INTEGER (0..40)

RAT ::=                             ENUMERATED {
                                        utra-FDD,
                                        utra-TDD,
                                        gsm,
                                        cdma2000 }

RAT-FDD-Info ::=                    SEQUENCE {
    rat-Identifier                      RAT-Identifier,
    s-SearchRAT                         S-SearchQual,
    s-HCS-RAT                           S-SearchRXLEV                           OPTIONAL,
    s-Limit-SearchRAT                   S-SearchQual
}

RAT-FDD-InfoList ::=                SEQUENCE (SIZE (1..maxOtherRAT)) OF
                                        RAT-FDD-Info

RAT-Identifier ::=                  ENUMERATED {
                                        gsm, cdma2000 }

RAT-TDD-Info ::=                    SEQUENCE {
    rat-Identifier                      RAT-Identifier,
    s-SearchRAT                         S-SearchRXLEV,
    s-HCS-RAT                           S-SearchRXLEV                       OPTIONAL,
    s-Limit-SearchRAT                   S-SearchRXLEV
}

RAT-TDD-InfoList ::=                SEQUENCE (SIZE (1..maxOtherRAT)) OF
                                        RAT-TDD-Info

ReservedIndicator ::=               ENUMERATED {
                                        reserved,
                                        notReserved }

-- Actual value S-SearchQual = IE value * 2
S-SearchQual ::=                        INTEGER (-16..10)

-- Actual value S-SearchRXLEV = (IE value * 2) + 1
S-SearchRXLEV ::=                       INTEGER (-53..45)
```

```
-- Actual value ScalingFactor = IE value * 0.1
SpeedDependentScalingFactor ::=     INTEGER (0..10)

T-Barred ::=                        ENUMERATED {
                                        s10, s20, s40, s80,
                                        s160, s320, s640, s1280 }

T-Reselection-S ::=                 INTEGER (0..31)

-- Actual value T-Reselection-S-Fine = IE value * 0.2
T-Reselection-S-Fine ::=            INTEGER (0..31)

-- Actual value ScalingFactor = IE value * 0.25
TreselectionScalingFactor ::=       INTEGER (4..19)

-- For UpperLimit, the used range depends on the RAT used.
UpperLimit ::=                      INTEGER (1..91)

URA-Identity ::=                    BIT STRING (SIZE (16))

URA-IdentityList ::=                SEQUENCE (SIZE (1..maxURA)) OF
                                        URA-Identity

-- **************************************************
--
--     USER EQUIPMENT INFORMATION ELEMENTS (10.3.3)
--
-- **************************************************

AccessStratumReleaseIndicator ::=   ENUMERATED {
                                        rel-4, rel-5, rel-6, rel-7,
                                        spare12, spare11, spare10, spare9, spare8,
                                        spare7, spare6, spare5, spare4, spare3,
                                        spare2, spare1 }

-- TABULAR : for ActivationTime, value 'now' always appear as default, and is encoded
-- by absence of the field
ActivationTime ::=                  INTEGER (0..255)

BackoffControlParams ::=            SEQUENCE {
    n-AP-RetransMax                     N-AP-RetransMax,
    n-AccessFails                       N-AccessFails,
    nf-BO-NoAICH                        NF-BO-NoAICH,
    ns-BO-Busy                          NS-BO-Busy,
    nf-BO-AllBusy                       NF-BO-AllBusy,
    nf-BO-Mismatch                      NF-BO-Mismatch,
    t-CPCH                              T-CPCH
}

C-RNTI ::=                          BIT STRING (SIZE (16))

CapabilityUpdateRequirement ::=     SEQUENCE {
    ue-RadioCapabilityFDDUpdateRequirement  BOOLEAN,
    -- ue-RadioCapabilityTDDUpdateRequirement is for 3.84Mcps TDD update requirement
    ue-RadioCapabilityTDDUpdateRequirement  BOOLEAN,
    systemSpecificCapUpdateReqList      SystemSpecificCapUpdateReqList      OPTIONAL
}

CapabilityUpdateRequirement-r4-ext ::= SEQUENCE {
    ue-RadioCapabilityUpdateRequirement-TDD128  BOOLEAN
}

CapabilityUpdateRequirement-r4 ::=  SEQUENCE {
    ue-RadioCapabilityFDDUpdateRequirement-FDD  BOOLEAN,
    ue-RadioCapabilityTDDUpdateRequirement-TDD384   BOOLEAN,
    ue-RadioCapabilityTDDUpdateRequirement-TDD128   BOOLEAN,
    systemSpecificCapUpdateReqList      SystemSpecificCapUpdateReqList      OPTIONAL
}

CapabilityUpdateRequirement-r7-ext ::= SEQUENCE {
    ue-RadioCapabilityUpdateRequirement-TDD768  BOOLEAN
}

-- If the IE CellUpdateCause has the value 'cellUpdateCause-ext', the actual value is
-- defined in the IE CellUpdateCause-ext.
CellUpdateCause ::=                 ENUMERATED {
                                        cellReselection,
                                        periodicalCellUpdate,
```

```
                                        uplinkDataTransmission,
                                        utran-pagingResponse,
                                        re-enteredServiceArea,
                                        radiolinkFailure,
                                        rlc-unrecoverableError,
                                        cellUpdateCause-ext }

-- The IE CellUpdateCause-ext shall be present, if the IE CellUpdateCause has the
-- value 'cellUpdateCause-ext'.
CellUpdateCause-ext ::=             ENUMERATED {
                                        mbms-Reception,
                                        mbms-PTP-RB-Request, spare2, spare1 }

ChipRateCapability ::=              ENUMERATED {
                                        mcps3-84, mcps1-28 }

ChipRateCapability-r7 ::=               ENUMERATED {
                                        mcps3-84, mcps7-68, mcps1-28 }

CipheringAlgorithm ::=              ENUMERATED {
                                        uea0, uea1 }

CipheringModeCommand ::=            CHOICE {
    startRestart                        CipheringAlgorithm,
    dummy                       NULL
}

CipheringModeInfo ::=               SEQUENCE {
    -- TABULAR: The ciphering algorithm is included in the CipheringModeCommand.
    cipheringModeCommand                CipheringModeCommand,
    activationTimeForDPCH               ActivationTime                      OPTIONAL,
    rb-DL-CiphActivationTimeInfo        RB-ActivationTimeInfoList           OPTIONAL
}

CN-DRX-CycleLengthCoefficient ::=   INTEGER (6..9)

CN-PagedUE-Identity ::=             CHOICE {
    imsi-GSM-MAP                        IMSI-GSM-MAP,
    tmsi-GSM-MAP                        TMSI-GSM-MAP,
    p-TMSI-GSM-MAP                      P-TMSI-GSM-MAP,
    imsi-DS-41                          IMSI-DS-41,
    tmsi-DS-41                          TMSI-DS-41,
    spare3                              NULL,
    spare2                              NULL,
    spare1                              NULL
}

CompressedModeMeasCapability ::=    SEQUENCE {
    fdd-Measurements                    BOOLEAN,
    -- TABULAR: The IEs tdd-Measurements, gsm-Measurements and multiCarrierMeasurements
    -- are made optional since they are conditional based on another information element.
    -- Their absence corresponds to the case where the condition is not true.
    tdd-Measurements                    BOOLEAN                             OPTIONAL,
    gsm-Measurements                    GSM-Measurements                    OPTIONAL,
    multiCarrierMeasurements            BOOLEAN                             OPTIONAL
}

CompressedModeMeasCapability-LCR-r4 ::= SEQUENCE {
    tdd128-Measurements                     BOOLEAN                         OPTIONAL
}

CompressedModeMeasCapabFDDList ::=  SEQUENCE (SIZE (1..maxFreqBandsFDD)) OF
                                        CompressedModeMeasCapabFDD

CompressedModeMeasCapabFDDList2 ::= SEQUENCE (SIZE (1..maxFreqBandsFDD)) OF
                                        CompressedModeMeasCapabFDD2

CompressedModeMeasCapabFDDList-ext ::= SEQUENCE (SIZE (1..maxFreqBandsFDD)) OF
                                            CompressedModeMeasCapabFDD-ext

CompressedModeMeasCapabFDD ::=      SEQUENCE {
    radioFrequencyBandFDD               RadioFrequencyBandFDD   OPTIONAL,
    dl-MeasurementsFDD                  BOOLEAN,
    ul-MeasurementsFDD                  BOOLEAN
}

CompressedModeMeasCapabFDD2 ::=     SEQUENCE {
    -- UE may omit both IEs if this IE indicates the compressed mode capability within the same
```

```
    -- frequency band. Otherwise, the UE shall include either one of the following OPTIONAL IEs.
    radioFrequencyBandFDD               RadioFrequencyBandFDD   OPTIONAL,
    radioFrequencyBandFDD2              RadioFrequencyBandFDD2  OPTIONAL,
    dl-MeasurementsFDD                  BOOLEAN,
    ul-MeasurementsFDD                  BOOLEAN
}

CompressedModeMeasCapabFDD-ext ::=      SEQUENCE {
    radioFrequencyBandFDD2              RadioFrequencyBandFDD2,
    dl-MeasurementsFDD                  BOOLEAN,
    ul-MeasurementsFDD                  BOOLEAN
}

CompressedModeMeasCapabTDDList ::=  SEQUENCE (SIZE (1..maxFreqBandsTDD)) OF
                                        CompressedModeMeasCapabTDD

CompressedModeMeasCapabTDD ::=      SEQUENCE {
    radioFrequencyBandTDD               RadioFrequencyBandTDD,
    dl-MeasurementsTDD                  BOOLEAN,
    ul-MeasurementsTDD                  BOOLEAN
}

CompressedModeMeasCapabGSMList ::=  SEQUENCE (SIZE (1..maxFreqBandsGSM)) OF
                                        CompressedModeMeasCapabGSM

CompressedModeMeasCapabGSM ::=      SEQUENCE {
    radioFrequencyBandGSM               RadioFrequencyBandGSM,
    dl-MeasurementsGSM                  BOOLEAN,
    ul-MeasurementsGSM                  BOOLEAN
}

CompressedModeMeasCapabMC ::=       SEQUENCE {
    dl-MeasurementsMC                   BOOLEAN,
    ul-MeasurementsMC                   BOOLEAN
}

CPCH-Parameters ::=                 SEQUENCE {
    initialPriorityDelayList            InitialPriorityDelayList            OPTIONAL,
    backoffControlParams                BackoffControlParams,
    -- TABULAR: TPC step size nested inside PowerControlAlgorithm
    powerControlAlgorithm               PowerControlAlgorithm,
    dl-DPCCH-BER                        DL-DPCCH-BER
}

DL-CapabilityWithSimultaneousHS-DSCHConfig ::=  ENUMERATED{kbps32, kbps64, kbps128, kbps384}

DL-DPCCH-BER ::=                    INTEGER (0..63)

DL-PhysChCapabilityFDD ::=          SEQUENCE {
    -- The IE 'maxNoDPCH-PDSCH-Codes' only gives information on the maximum number of DPCH Codes.
    maxNoDPCH-PDSCH-Codes               INTEGER (1..8),
    maxNoPhysChBitsReceived             MaxNoPhysChBitsReceived,
    supportForSF-512                    BOOLEAN,
    -- dummy and dummy2 are not used in this version of the specification, they should not be sent
    -- and if received they should be ignored.
    dummy                               BOOLEAN,
    dummy2                              SimultaneousSCCPCH-DPCH-Reception
}

DL-PhysChCapabilityFDD-v380ext ::=          SEQUENCE {
    -- dummy is not used in this version of the specification, it should
    -- not be sent and if received it should be ignored.
    dummy                                   SupportOfDedicatedPilotsForChEstimation     OPTIONAL
}

SupportOfDedicatedPilotsForChEstimation ::=         ENUMERATED { true }

DL-PhysChCapabilityTDD ::=          SEQUENCE {
    maxTS-PerFrame                      MaxTS-PerFrame,
    maxPhysChPerFrame                   MaxPhysChPerFrame,
    minimumSF                           MinimumSF-DL,
    supportOfPDSCH                      BOOLEAN,
    maxPhysChPerTS                      MaxPhysChPerTS
}

DL-PhysChCapabilityTDD-LCR-r4 ::=   SEQUENCE {
    maxTS-PerSubFrame                   MaxTS-PerSubFrame-r4,
    maxPhysChPerFrame                   MaxPhysChPerSubFrame-r4,
```

```
    minimumSF                           MinimumSF-DL,
    supportOfPDSCH                      BOOLEAN,
    maxPhysChPerTS                      MaxPhysChPerTS,
    supportOf8PSK                       BOOLEAN
}

DL-PhysChCapabilityTDD-768 ::=      SEQUENCE {
    maxTS-PerFrame                      MaxTS-PerFrame,
    maxPhysChPerFrame                   MaxPhysChPerFrame-768,
    minimumSF                           MinimumSF-DL-768,
    supportOfPDSCH                      BOOLEAN,
    maxPhysChPerTS                      MaxPhysChPerTS-768
}

DL-TransChCapability ::=            SEQUENCE {
    maxNoBitsReceived                   MaxNoBits,
    maxConvCodeBitsReceived             MaxNoBits,
    turboDecodingSupport                TurboSupport,
    maxSimultaneousTransChs             MaxSimultaneousTransChsDL,
    maxSimultaneousCCTrCH-Count         MaxSimultaneousCCTrCH-Count,
    maxReceivedTransportBlocks          MaxTransportBlocksDL,
    maxNumberOfTFC                      MaxNumberOfTFC-DL,
    maxNumberOfTF                       MaxNumberOfTF
}

DRAC-SysInfo ::=                    SEQUENCE {
    transmissionProbability             TransmissionProbability,
    maximumBitRate                      MaximumBitRate
}

DRAC-SysInfoList ::=                SEQUENCE (SIZE (1..maxDRACclasses)) OF
                                        DRAC-SysInfo

DSCH-RNTI ::=                       BIT STRING (SIZE (16))

DelayRestrictionFlag ::=            ENUMERATED { true }

E-RNTI ::=                          BIT STRING (SIZE (16))

ESN-DS-41 ::=                       BIT STRING (SIZE (32))

EstablishmentCause ::=              ENUMERATED {
                                        originatingConversationalCall,
                                        originatingStreamingCall,
                                        originatingInteractiveCall,
                                        originatingBackgroundCall,
                                        originatingSubscribedTrafficCall,
                                        terminatingConversationalCall,
                                        terminatingStreamingCall,
                                        terminatingInteractiveCall,
                                        terminatingBackgroundCall,
                                        emergencyCall,
                                        interRAT-CellReselection,
                                        interRAT-CellChangeOrder,
                                        registration,
                                        detach,
                                        originatingHighPrioritySignalling,
                                        originatingLowPrioritySignalling,
                                        callRe-establishment,
                                        terminatingHighPrioritySignalling,
                                        terminatingLowPrioritySignalling,
                                        terminatingCauseUnknown,
                                        mbms-Reception,
                                        mbms-PTP-RB-Request,
                                        spare10,
                                        spare9,
                                        spare8,
                                        spare7,
                                        spare6,
                                        spare5,
                                        spare4,
                                        spare3,
                                        spare2,
                                        spare1 }

FailureCauseWithProtErr ::=         CHOICE {
    configurationUnsupported            NULL,
    physicalChannelFailure              NULL,
```

```
    incompatibleSimultaneousReconfiguration
                                        NULL,
    compressedModeRuntimeError          TGPSI,
    protocolError                       ProtocolErrorInformation,
    cellUpdateOccurred                  NULL,
    invalidConfiguration                NULL,
    configurationIncomplete             NULL,
    unsupportedMeasurement              NULL,
    mbmsSessionAlreadyReceivedCorrectly NULL,
    lowerPriorityMBMSService            NULL,
    spare5                              NULL,
    spare4                              NULL,
    spare3                              NULL,
    spare2                              NULL,
    spare1                              NULL
}

FailureCauseWithProtErrTrId ::=     SEQUENCE {
        rrc-TransactionIdentifier       RRC-TransactionIdentifier,
        failureCause                    FailureCauseWithProtErr
}

GroupIdentityWithReleaseInformation ::=     SEQUENCE {
        rrc-ConnectionReleaseInformation        RRC-ConnectionReleaseInformation,
        groupReleaseInformation                 GroupReleaseInformation
    }

GroupReleaseInformation ::=         SEQUENCE {
    uRNTI-Group                         U-RNTI-Group
}

GSM-Measurements ::=                SEQUENCE {
    gsm900                              BOOLEAN,
    dcs1800                             BOOLEAN,
    gsm1900                             BOOLEAN
}

H-RNTI ::=                          BIT STRING (SIZE (16))

HSDSCH-physical-layer-category ::=      INTEGER (1..64)

UESpecificBehaviourInformation1idle ::= BIT STRING (SIZE (4))

UESpecificBehaviourInformation1interRAT ::= BIT STRING (SIZE (8))


IMSI-and-ESN-DS-41 ::=              SEQUENCE {
    imsi-DS-41                          IMSI-DS-41,
    esn-DS-41                           ESN-DS-41
}

IMSI-DS-41 ::=                      OCTET STRING (SIZE (5..7))

InitialPriorityDelayList ::=        SEQUENCE (SIZE (1..maxASC)) OF
                                        NS-IP

InitialUE-Identity ::=              CHOICE {
    imsi                                IMSI-GSM-MAP,
    tmsi-and-LAI                        TMSI-and-LAI-GSM-MAP,
    p-TMSI-and-RAI                      P-TMSI-and-RAI-GSM-MAP,
    imei                                IMEI,
    esn-DS-41                           ESN-DS-41,
    imsi-DS-41                          IMSI-DS-41,
    imsi-and-ESN-DS-41                  IMSI-and-ESN-DS-41,
    tmsi-DS-41                          TMSI-DS-41
}

IntegrityCheckInfo ::=              SEQUENCE {
    messageAuthenticationCode           MessageAuthenticationCode,
    rrc-MessageSequenceNumber           RRC-MessageSequenceNumber
}

IntegrityProtActivationInfo ::=     SEQUENCE {
    rrc-MessageSequenceNumberList       RRC-MessageSequenceNumberList
}

IntegrityProtectionAlgorithm ::=    ENUMERATED {
                                        uia1 }
```

```
IntegrityProtectionModeCommand ::=  CHOICE {
    startIntegrityProtection            SEQUENCE {
        integrityProtInitNumber             IntegrityProtInitNumber
    },
    modify                              SEQUENCE {
        dl-IntegrityProtActivationInfo      IntegrityProtActivationInfo
    }
}

IntegrityProtectionModeInfo ::=     SEQUENCE {
    -- TABULAR: DL integrity protection activation info and Integrity
    -- protection intialisation number have been nested inside
    -- IntegrityProtectionModeCommand.
    integrityProtectionModeCommand      IntegrityProtectionModeCommand,
    integrityProtectionAlgorithm        IntegrityProtectionAlgorithm        OPTIONAL
}

IntegrityProtInitNumber ::=         BIT STRING (SIZE (32))

-- dummy is not used in this version of the specification, it should
-- not be sent and if received it should be ignored.
MaxHcContextSpace ::=                   ENUMERATED  {
                                            dummy, by1024, by2048, by4096,
                                            by8192 }

MaxHcContextSpace-r5-ext ::=            ENUMERATED  {
                                            by16384, by32768, by65536, by131072 }


MaxROHC-ContextSessions-r4 ::=      ENUMERATED  {
                                            s2, s4, s8, s12, s16, s24, s32, s48,
                                            s64, s128, s256, s512, s1024, s16384 }

MaximumAM-EntityNumberRLC-Cap ::=   ENUMERATED {
                                        dummy, am4, am5, am6,
                                        am8, am16, am30 }

-- Actual value MaximumBitRate = IE value * 16
MaximumBitRate ::=                  INTEGER (0..32)

MaximumRLC-WindowSize ::=           ENUMERATED { mws2047, mws4095 }

MaxNoDPDCH-BitsTransmitted ::=      ENUMERATED {
                                        b600, b1200, b2400, b4800,
                                        b9600, b19200, b28800, b38400,
                                        b48000, b57600 }

MaxNoBits ::=                       ENUMERATED {
                                        b640, b1280, b2560, b3840, b5120,
                                        b6400, b7680, b8960, b10240,
                                        b20480, b40960, b81920, b163840 }

MaxNoPhysChBitsReceived ::=         ENUMERATED {
                                        dummy, b1200, b2400, b3600,
                                        b4800, b7200, b9600, b14400,
                                        b19200, b28800, b38400, b48000,
                                        b57600, b67200, b76800 }

MaxNoSCCPCH-RL ::=                  ENUMERATED {
                                        rl1 }

MaxNumberOfTF ::=                   ENUMERATED {
                                        tf32, tf64, tf128, tf256,
                                        tf512, tf1024 }

MaxNumberOfTFC-DL ::=               ENUMERATED {
                                        tfc16, tfc32, tfc48, tfc64, tfc96,
                                        tfc128, tfc256, tfc512, tfc1024 }

MaxNumberOfTFC-UL ::=               ENUMERATED {
                                        dummy1, dummy2, tfc16, tfc32, tfc48, tfc64,
                                        tfc96, tfc128, tfc256, tfc512, tfc1024 }

-- the values 1 …4 for MaxPhysChPerFrame are not used in this version of the protocol
MaxPhysChPerFrame ::=               INTEGER (1..224)
```

```
MaxPhysChPerFrame-768 ::=           INTEGER (1..448)

MaxPhysChPerSubFrame-r4 ::=         INTEGER (1..96)

MaxPhysChPerTimeslot ::=            ENUMERATED {
                                        ts1, ts2 }

-- the values 1 …4 for MaxPhysChPerTS are not used in this version of the protocol
MaxPhysChPerTS ::=                  INTEGER (1..16)

MaxPhysChPerTS-768 ::=              INTEGER (1..32)

MaxSimultaneousCCTrCH-Count ::=     INTEGER (1..8)

MaxSimultaneousTransChsDL ::=       ENUMERATED {
                                        e4, e8, e16, e32 }

MaxSimultaneousTransChsUL ::=       ENUMERATED {
                                        dummy, e4, e8, e16, e32 }

MaxTransportBlocksDL ::=            ENUMERATED {
                                        tb4, tb8, tb16, tb32, tb48,
                                        tb64, tb96, tb128, tb256, tb512 }

MaxTransportBlocksUL ::=            ENUMERATED {
                                        dummy, tb4, tb8, tb16, tb32, tb48,
                                        tb64, tb96, tb128, tb256, tb512 }

MaxTS-PerFrame ::=                  INTEGER (1..14)

MaxTS-PerSubFrame-r4 ::=            INTEGER (1..6)

-- TABULAR: MeasurementCapability contains dependencies to UE-MultiModeRAT-Capability,
-- the conditional fields have been left mandatory for now.
MeasurementCapability ::=           SEQUENCE {
    downlinkCompressedMode              CompressedModeMeasCapability,
    uplinkCompressedMode                CompressedModeMeasCapability
}

MeasurementCapabilityExt ::=        SEQUENCE{
    compressedModeMeasCapabFDDList      CompressedModeMeasCapabFDDList,
    compressedModeMeasCapabTDDList      CompressedModeMeasCapabTDDList  OPTIONAL,
    compressedModeMeasCapabGSMList      CompressedModeMeasCapabGSMList  OPTIONAL,
    compressedModeMeasCapabMC           CompressedModeMeasCapabMC       OPTIONAL
}

MeasurementCapabilityExt2 ::=       SEQUENCE{
    compressedModeMeasCapabFDDList      CompressedModeMeasCapabFDDList2,
    compressedModeMeasCapabTDDList      CompressedModeMeasCapabTDDList  OPTIONAL,
    compressedModeMeasCapabGSMList      CompressedModeMeasCapabGSMList  OPTIONAL,
    compressedModeMeasCapabMC           CompressedModeMeasCapabMC       OPTIONAL
}


MeasurementCapability-r4-ext ::=    SEQUENCE {
    downlinkCompressedMode-LCR          CompressedModeMeasCapability-LCR-r4,
    uplinkCompressedMode-LCR            CompressedModeMeasCapability-LCR-r4
}

MessageAuthenticationCode ::=       BIT STRING (SIZE (32))

MinimumSF-DL ::=                    ENUMERATED {
                                        sf1, sf16 }

MinimumSF-DL-768 ::=                ENUMERATED {
                                        sf1, sf32 }

MinimumSF-UL ::=                    ENUMERATED {
                                        sf1, sf2, sf4, sf8, dummy }

MultiModeCapability ::=             ENUMERATED {
                                        tdd, fdd, fdd-tdd }

MultiRAT-Capability ::=             SEQUENCE {
    supportOfGSM                        BOOLEAN,
    supportOfMulticarrier               BOOLEAN
}
```

```
MultiModeRAT-Capability-v590ext ::= SEQUENCE {
    supportOfUTRAN-ToGERAN-NACC         BOOLEAN
}

MultiModeRAT-Capability-v680ext ::= SEQUENCE {
    supportOfHandoverToGAN              ENUMERATED { doesSupportHandoverToGAN }     OPTIONAL
}

N-300 ::=                           INTEGER (0..7)

N-301 ::=                           INTEGER (0..7)

N-302 ::=                           INTEGER (0..7)

N-304 ::=                           INTEGER (0..7)

N-308 ::=                           INTEGER (1..8)

N-310 ::=                           INTEGER (0..7)

N-312 ::=                           ENUMERATED {
                                        s1, s50, s100, s200, s400,
                                        s600, s800, s1000 }

N-312ext ::=                        ENUMERATED {
                                        s2, s4, s10, s20 }

N-312-r5 ::=                            ENUMERATED {
                                        s1, s2, s4, s10, s20,
                                        s50, s100, s200, s400,
                                        s600, s800, s1000 }

N-313 ::=                           ENUMERATED {
                                        s1, s2, s4, s10, s20,
                                         s50, s100, s200 }

N-315 ::=                           ENUMERATED {
                                        s1, s50, s100, s200, s400,
                                        s600, s800, s1000 }

N-315ext ::=                        ENUMERATED {
                                        s2, s4, s10, s20 }

N-315-r5 ::=                            ENUMERATED {
                                        s1, s2, s4, s10, s20,
                                        s50, s100, s200, s400,
                                        s600, s800, s1000 }


N-AccessFails ::=                   INTEGER (1..64)

N-AP-RetransMax ::=                 INTEGER (1..64)

NetworkAssistedGPS-Supported ::=    ENUMERATED {
                                        networkBased,
                                        ue-Based,
                                        bothNetworkAndUE-Based,
                                        noNetworkAssistedGPS }

NF-BO-AllBusy ::=                   INTEGER (0..31)

NF-BO-NoAICH ::=                    INTEGER (0..31)

NF-BO-Mismatch ::=                  INTEGER (0..127)

NS-BO-Busy ::=                      INTEGER (0..63)

NS-IP ::=                           INTEGER (0..28)

P-TMSI-and-RAI-GSM-MAP ::=          SEQUENCE {
    p-TMSI                              P-TMSI-GSM-MAP,
    rai                                 RAI
}

PagingCause ::=                     ENUMERATED {
                                        terminatingConversationalCall,
                                        terminatingStreamingCall,
                                        terminatingInteractiveCall,
```

```
                                        terminatingBackgroundCall,
                                        terminatingHighPrioritySignalling,
                                        terminatingLowPrioritySignalling,
                                        terminatingCauseUnknown,
                                        spare
 }

PagingRecord ::=                    CHOICE {
    cn-Identity                         SEQUENCE {
        pagingCause                         PagingCause,
        cn-DomainIdentity                   CN-DomainIdentity,
        cn-pagedUE-Identity                 CN-PagedUE-Identity
    },
    utran-Identity                      SEQUENCE {
        u-RNTI                              U-RNTI,
        cn-OriginatedPage-connectedMode-UE  SEQUENCE {
            pagingCause                         PagingCause,
            cn-DomainIdentity                   CN-DomainIdentity,
            pagingRecordTypeID                  PagingRecordTypeID
        }                                                               OPTIONAL
    }
}

PagingRecord2-r5 ::=                CHOICE {
    utran-SingleUE-Identity             SEQUENCE {
        u-RNTI                              U-RNTI,
        cn-OriginatedPage-connectedMode-UE  SEQUENCE {
            pagingCause                         PagingCause,
            cn-DomainIdentity                   CN-DomainIdentity,
            pagingRecordTypeID                  PagingRecordTypeID
        }                                                               OPTIONAL,
        rrc-ConnectionReleaseInformation        RRC-ConnectionReleaseInformation
    },
    utran-GroupIdentity                 SEQUENCE ( SIZE (1 .. maxURNTI-Group) ) OF
                                            GroupIdentityWithReleaseInformation
}

PagingRecordList ::=                SEQUENCE (SIZE (1..maxPage1)) OF
                                        PagingRecord

PagingRecord2List-r5 ::=            SEQUENCE (SIZE (1..maxPage1)) OF
                                        PagingRecord2-r5

PDCP-Capability ::=                 SEQUENCE {
    losslessSRNS-RelocationSupport      BOOLEAN,
    -- If present, the "maxHcContextSpace" in the IE "PDCP-Capability-r5-ext" overrides the
    -- "supported" value in this IE. The value in this IE may be used by a pre-REL-5 UTRAN.
    supportForRfc2507                   CHOICE {
        notSupported                        NULL,
        supported                           MaxHcContextSpace
    }
}

PDCP-Capability-r4-ext ::=          SEQUENCE {
    supportForRfc3095               CHOICE {
        notSupported                        NULL,
        supported                           SEQUENCE {
            maxROHC-ContextSessions             MaxROHC-ContextSessions-r4  DEFAULT s16,
            reverseCompressionDepth             INTEGER (0..65535)          DEFAULT 0
        }
    }
}

PDCP-Capability-r5-ext ::=          SEQUENCE {
    supportForRfc3095ContextRelocation      BOOLEAN,
    maxHcContextSpace                       MaxHcContextSpace-r5-ext    OPTIONAL
}

PDCP-Capability-r5-ext2 ::=         SEQUENCE {
    losslessDLRLC-PDUSizeChange         ENUMERATED { true }                 OPTIONAL
}

PhysicalChannelCapability ::=       SEQUENCE {
        fddPhysChCapability                 SEQUENCE {
            downlinkPhysChCapability            DL-PhysChCapabilityFDD,
            uplinkPhysChCapability              UL-PhysChCapabilityFDD
        }                                           OPTIONAL,
        -- tddPhysChCapability describes the 3.84Mcps TDD physical channel capability
```

```
        tddPhysChCapability                 SEQUENCE {
            downlinkPhysChCapability            DL-PhysChCapabilityTDD,
            uplinkPhysChCapability              UL-PhysChCapabilityTDD
        }                                           OPTIONAL
}

PhysicalChannelCapability-r7 ::=        SEQUENCE {
        fddPhysChCapability                 SEQUENCE {
            downlinkPhysChCapability            DL-PhysChCapabilityFDD,
            uplinkPhysChCapability              UL-PhysChCapabilityFDD
        }                                           OPTIONAL,
        -- tddPhysChCapability describes the 3.84Mcps TDD physical channel capability
        tddPhysChCapability                 SEQUENCE {
            downlinkPhysChCapability            DL-PhysChCapabilityTDD,
            uplinkPhysChCapability              UL-PhysChCapabilityTDD
        }                                           OPTIONAL,
        -- tddPhysicalChaCapability-768 describes the 7.68 TDD physical channel capability
        tddPhysChCapability-768             SEQUENCE {
            downlinkPhysChCapability            DL-PhysChCapabilityTDD-768,
            uplinkPhysChCapability              UL-PhysChCapabilityTDD
        }
}

-- PhysicalChannelCapability-LCR-r4 describes the 1.28Mcps TDD physical channel capability
PhysicalChannelCapability-LCR-r4 ::=        SEQUENCE {
        tdd128-PhysChCapability             SEQUENCE {
            downlinkPhysChCapability            DL-PhysChCapabilityTDD-LCR-r4,
            uplinkPhysChCapability              UL-PhysChCapabilityTDD-LCR-r4
        }                                           OPTIONAL
}

-- PhysicalChannelCapability-hspdsch-r5 describes the HS-PDSCH physical channel capability
PhysicalChannelCapability-hspdsch-r5 ::=        SEQUENCE {
    fdd-hspdsch                                 CHOICE {
        supported                                   SEQUENCE {
            hsdsch-physical-layer-category              HSDSCH-physical-layer-category,
            -- dummy and dummy2 are not used in this version of the specification, they should not
            -- be sent and if received they should be ignored.
            dummy                                       BOOLEAN,
            dummy2                                      BOOLEAN
        },
        unsupported                                 NULL
    },
    tdd384-hspdsch                              CHOICE {
        supported                                   HSDSCH-physical-layer-category,
        unsupported                                 NULL
    },
    tdd128-hspdsch                              CHOICE {
        supported                                   HSDSCH-physical-layer-category,
        unsupported                                 NULL
    }
}

PNBSCH-Allocation-r4 ::=                SEQUENCE {
        numberOfRepetitionsPerSFNPeriod ENUMERATED {
                                            c2, c3, c4, c5, c6, c7, c8, c9, c10,
                                            c12, c14, c16, c18, c20, c24, c28, c32,
                                            c36, c40, c48, c56, c64, c72, c80  }
}

ProtocolErrorCause ::=              ENUMERATED {
                                        asn1-ViolationOrEncodingError,
                                        messageTypeNonexistent,
                                        messageNotCompatibleWithReceiverState,
                                        ie-ValueNotComprehended,
                                        informationElementMissing,
                                        messageExtensionNotComprehended,
                                        spare2, spare1 }

ProtocolErrorIndicator ::=          ENUMERATED {
                                        noError, errorOccurred }

ProtocolErrorIndicatorWithMoreInfo ::=
                                    CHOICE {
    noError                             NULL,
    errorOccurred                       SEQUENCE {
        rrc-TransactionIdentifier           RRC-TransactionIdentifier,
        protocolErrorInformation            ProtocolErrorInformation
```

```
    }
}

ProtocolErrorMoreInformation ::=    SEQUENCE {
    diagnosticsType                     CHOICE {
        type1                               CHOICE {
            asn1-ViolationOrEncodingError       NULL,
            messageTypeNonexistent              NULL,
            messageNotCompatibleWithReceiverState
                                                IdentificationOfReceivedMessage,
            ie-ValueNotComprehended             IdentificationOfReceivedMessage,
            conditionalInformationElementError  IdentificationOfReceivedMessage,
            messageExtensionNotComprehended     IdentificationOfReceivedMessage,
            spare1                              NULL,
            spare2                              NULL
        },
        spare                               NULL
    }
}

RadioFrequencyBandFDD ::=           ENUMERATED {
    -- fdd2100, fdd1900, fdd1800 correspond to Band I, Band II and Band III respectively
                                        fdd2100,
                                        fdd1900,
                                        fdd1800,
                                        bandVI,
                                        bandIV,
                                        bandV,
                                        bandVII,
                                        extension-indicator }

RadioFrequencyBandFDD2 ::=          ENUMERATED {
                                        bandVIII,
                                        bandIX,
                                        bandX,
                                        bandXI,
                                        bandXII,
                                        bandXIII,
                                        bandXIV,
                                        bandXV,
                                        bandXVI,
                                        bandXVII,
                                        bandXVIII,
                                        bandXIX,
                                        bandXX,
                                        bandXXI,
                                        bandXXII,
                                        extension-indicator }

RadioFrequencyBandTDDList ::=       ENUMERATED {
                                        a, b, c, ab, ac, bc, abc, spare }

RadioFrequencyBandTDD ::=           ENUMERATED {a, b, c, spare}

RadioFrequencyBandGSM ::=           ENUMERATED {
                                        gsm450,
                                        gsm480,
                                        gsm850,
                                        gsm900P,
                                        gsm900E,
                                        gsm1800,
                                        gsm1900,
                                        spare9, spare8, spare7, spare6, spare5,
                                        spare4, spare3, spare2, spare1}

Rb-timer-indicator ::=              SEQUENCE {
    t314-expired                        BOOLEAN,
    t315-expired                        BOOLEAN }

Re-EstablishmentTimer ::=           ENUMERATED {
                                        useT314, useT315
}

RedirectionInfo ::=                 CHOICE {
    frequencyInfo                       FrequencyInfo,
    interRATInfo                        InterRATInfo
}
```

```
RedirectionInfo-r6 ::=              CHOICE {
    frequencyInfo                       FrequencyInfo,
    interRATInfo                        InterRATInfo-r6
}

RejectionCause ::=                  ENUMERATED {
                                        congestion,
                                        unspecified }

ReleaseCause ::=                    ENUMERATED {
                                        normalEvent,
                                        unspecified,
                                        pre-emptiveRelease,
                                        congestion,
                                        re-establishmentReject,
                                        directedsignallingconnectionre-establishment,
                                        userInactivity,
                                        spare }

RF-Capability ::=                   SEQUENCE {
        fddRF-Capability                SEQUENCE {
            ue-PowerClass                   UE-PowerClass,
            txRxFrequencySeparation         TxRxFrequencySeparation
        }                                   OPTIONAL,
        tddRF-Capability                            SEQUENCE {
            ue-PowerClass               UE-PowerClass,
            radioFrequencyTDDBandList   RadioFrequencyBandTDDList,
            chipRateCapability          ChipRateCapability
        }                                   OPTIONAL
}

RF-Capability-r4-ext ::=            SEQUENCE {
        tddRF-Capability                            SEQUENCE {
            ue-PowerClass               UE-PowerClass,
            radioFrequencyBandTDDList   RadioFrequencyBandTDDList,
            chipRateCapability          ChipRateCapability
        }                                   OPTIONAL
}

RF-Capability-r7 ::=                SEQUENCE {
        fddRF-Capability                SEQUENCE {
            ue-PowerClass                   UE-PowerClass,
            txRxFrequencySeparation         TxRxFrequencySeparation
        }                                   OPTIONAL,
        tddRF-Capability                SEQUENCE {
            ue-PowerClass                   UE-PowerClass,
            radioFrequencyTDDBandList       RadioFrequencyBandTDDList,
            chipRateCapability              ChipRateCapability-r7
        }   OPTIONAL
}

RLC-Capability ::=                  SEQUENCE {
    -- If present, the "totalRLC-AM-BufferSize" in the IE "RLC-Capability-r5-ext" overrides the
    -- corresponding value in this IE. The value in this IE may be used by a pre-REL-5 UTRAN.
    totalRLC-AM-BufferSize              TotalRLC-AM-BufferSize,
    maximumRLC-WindowSize               MaximumRLC-WindowSize,
    maximumAM-EntityNumber              MaximumAM-EntityNumberRLC-Cap
}

RLC-Capability-r5-ext ::=               SEQUENCE {
    totalRLC-AM-BufferSize              TotalRLC-AM-BufferSize-r5-ext       OPTIONAL
}

RRC-ConnectionReleaseInformation ::=    CHOICE {
    noRelease                           NULL,
    release                             SEQUENCE {
        releaseCause                        ReleaseCause
    }
}

RRC-MessageSequenceNumber ::=       INTEGER (0..15)


RRC-MessageSequenceNumberList ::=   SEQUENCE (SIZE (4..5)) OF
                                        RRC-MessageSequenceNumber

RRC-StateIndicator ::=              ENUMERATED {
                                        cell-DCH, cell-FACH, cell-PCH, ura-PCH }
```

```
RRC-TransactionIdentifier ::=       INTEGER (0..3)

S-RNTI ::=                          BIT STRING (SIZE (20))

S-RNTI-2 ::=                        BIT STRING (SIZE (10))

SecurityCapability ::=              SEQUENCE {
    cipheringAlgorithmCap               BIT STRING {
                                        -- For each bit value '0' means false/ not supported
                                            spare15(0),
                                            spare14(1),
                                            spare13(2),
                                            spare12(3),
                                            spare11(4),
                                            spare10(5),
                                            spare9(6),
                                            spare8(7),
                                            spare7(8),
                                            spare6(9),
                                            spare5(10),
                                            spare4(11),
                                            spare3(12),
                                            spare2(13),
                                            uea1(14),
                                            uea0(15)
                                            }   (SIZE (16)),
    integrityProtectionAlgorithmCap     BIT STRING {
                                        -- For each bit value '0' means false/ not supported
                                            spare15(0),
                                            spare14(1),
                                            spare13(2),
                                            spare12(3),
                                            spare11(4),
                                            spare10(5),
                                            spare9(6),
                                            spare8(7),
                                            spare7(8),
                                            spare6(9),
                                            spare5(10),
                                            spare4(11),
                                            spare3(12),
                                            spare2(13),
                                            uia1(14),
                                            spare0(15)
                                            }    (SIZE (16))
}

Serving-HSDSCH-CellInformation ::=      SEQUENCE {
    deltaACK                        DeltaACK                    OPTIONAL,
    deltaNACK                       DeltaNACK                   OPTIONAL,
    harq-Preamble-Mode              HARQ-Preamble-Mode,
    primaryCPICH-Info               PrimaryCPICH-Info           OPTIONAL,
    dl-hspdsch-Information          DL-HSPDSCH-Information      OPTIONAL,
    harqInfo                        HARQ-Info                   OPTIONAL,
    mac-hsResetIndicator            ENUMERATED { true }         OPTIONAL
}

SimultaneousSCCPCH-DPCH-Reception ::= CHOICE {
    notSupported                        NULL,
    supported                           SEQUENCE {
        maxNoSCCPCH-RL                      MaxNoSCCPCH-RL,
        -- simultaneousSCCPCH-DPCH-DPDCH-Reception is applicable only if
        -- the IE Support of PDSCH = TRUE
        -- Note: the reference to DPDCH in the element name below is incorrect (see tabular). The
        -- name is not changed, to keep it aligned with R99.
        simultaneousSCCPCH-DPCH-DPDCH-Reception     BOOLEAN
    }
}

SRNC-Identity ::=                   BIT STRING (SIZE (12))


START-Value ::=                     BIT STRING (SIZE (20))

STARTList ::=                       SEQUENCE (SIZE (1..maxCNdomains)) OF
                                        STARTSingle
```

```
STARTSingle ::=                     SEQUENCE {
    cn-DomainIdentity                   CN-DomainIdentity,
    start-Value                         START-Value
}

CapabilityUpdateRequirement-r5 ::=  SEQUENCE {
    ue-RadioCapabilityFDDUpdateRequirement-FDD  BOOLEAN,
    ue-RadioCapabilityTDDUpdateRequirement-TDD384   BOOLEAN,
    ue-RadioCapabilityTDDUpdateRequirement-TDD128   BOOLEAN,
    systemSpecificCapUpdateReqList      SystemSpecificCapUpdateReqList-r5       OPTIONAL
}

SystemSpecificCapUpdateReq ::=      ENUMERATED {
                                        gsm }

SystemSpecificCapUpdateReq-v590ext ::=      ENUMERATED {
                                        geranIu }

SystemSpecificCapUpdateReq-r5 ::=       ENUMERATED {
                                        gsm, geranIu }

SystemSpecificCapUpdateReqList ::= SEQUENCE (SIZE (1..maxSystemCapability)) OF
                                        SystemSpecificCapUpdateReq

SystemSpecificCapUpdateReqList-r5 ::= SEQUENCE (SIZE (1..maxSystemCapability)) OF
                                        SystemSpecificCapUpdateReq-r5

T-300 ::=                           ENUMERATED {
                                        ms100, ms200, ms400, ms600, ms800,
                                        ms1000, ms1200, ms1400, ms1600,
                                        ms1800, ms2000, ms3000, ms4000,
                                        ms6000, ms8000 }

T-301 ::=                           ENUMERATED {
                                        ms100, ms200, ms400, ms600, ms800,
                                        ms1000, ms1200, ms1400, ms1600,
                                        ms1800, ms2000, ms3000, ms4000,
                                        ms6000, ms8000, spare }

T-302 ::=                           ENUMERATED {
                                        ms100, ms200, ms400, ms600, ms800,
                                        ms1000, ms1200, ms1400, ms1600,
                                        ms1800, ms2000, ms3000, ms4000,
                                        ms6000, ms8000, spare }

T-304 ::=                           ENUMERATED {
                                        ms100, ms200, ms400,
                                        ms1000, ms2000, spare3, spare2, spare1 }

T-305 ::=                           ENUMERATED {
                                        noUpdate, m5, m10, m30,
                                        m60, m120, m360, m720 }

T-307 ::=                           ENUMERATED {
                                        s5, s10, s15, s20,
                                        s30, s40, s50, spare }

T-308 ::=                           ENUMERATED {
                                        ms40, ms80, ms160, ms320 }

T-309 ::=                           INTEGER (1..8)

T-310 ::=                           ENUMERATED {
                                        ms40, ms80, ms120, ms160,
                                        ms200, ms240, ms280, ms320 }

T-311 ::=                           ENUMERATED {
                                        ms250, ms500, ms750, ms1000,
                                        ms1250, ms1500, ms1750, ms2000 }

-- The value 0 for T-312 is not used in this version of the specification
T-312 ::=                           INTEGER (0..15)

T-313 ::=                           INTEGER (0..15)

T-314 ::=                           ENUMERATED {
                                        s0, s2, s4, s6, s8,
                                        s12, s16, s20 }
```

```
T-315 ::=                           ENUMERATED {
                                        s0, s10, s30, s60, s180,
                                        s600, s1200, s1800 }

T-316 ::=                           ENUMERATED {
                                        s0, s10, s20, s30, s40,
                                        s50, s-inf, spare }

-- All the values are changed to "infinity" in Rel-5
T-317 ::=                           ENUMERATED {
                                        infinity0,  infinity1,  infinity2, infinity3, infinity4,
                                        infinity5, infinity6, infinity7}

T-318 ::=                           ENUMERATED {
                                        ms250, ms500, ms750, ms1000, ms1250, ms1500,
                                        ms1750, ms2000, ms3000, ms4000, ms6000, ms8000,
                                        ms10000, ms12000, ms16000 }

T-CPCH ::=                          ENUMERATED {
                                        ct0, ct1 }

TMSI-and-LAI-GSM-MAP ::=            SEQUENCE {
    tmsi                                TMSI-GSM-MAP,
    lai                                 LAI
}

TMSI-DS-41 ::=                      OCTET STRING (SIZE (2..17))

TotalRLC-AM-BufferSize ::=          ENUMERATED {
                                        dummy, kb10, kb50, kb100,
                                        kb150, kb500, kb1000, spare }

TotalRLC-AM-BufferSize-r5-ext ::=   ENUMERATED {
                                        kb200, kb300, kb400, kb750 }

-- Actual value TransmissionProbability = IE value * 0.125
TransmissionProbability ::=         INTEGER (1..8)

TransportChannelCapability ::=      SEQUENCE {
    dl-TransChCapability                DL-TransChCapability,
    ul-TransChCapability                UL-TransChCapability
}

TurboSupport ::=                    CHOICE {
    notSupported                        NULL,
    supported                           MaxNoBits
}

-- Values defined as spare shall not be sent in this version of the protocol. If a spare value is
-- received, it should be interpreted as 'default-RxTX-sparation'.
TxRxFrequencySeparation ::=         ENUMERATED {
                                        default-TxRx-separation, spare2, spare1 }

U-RNTI ::=                          SEQUENCE {
    srnc-Identity                       SRNC-Identity,
    s-RNTI                              S-RNTI
}

U-RNTI-Group ::=                    CHOICE {
-- TABULAR: not following the tabular strictly, but this will most likely save bits
    all                                 NULL,
    u-RNTI-BitMaskIndex-b1              BIT STRING (SIZE (31)),
    u-RNTI-BitMaskIndex-b2              BIT STRING (SIZE (30)),
    u-RNTI-BitMaskIndex-b3              BIT STRING (SIZE (29)),
    u-RNTI-BitMaskIndex-b4              BIT STRING (SIZE (28)),
    u-RNTI-BitMaskIndex-b5              BIT STRING (SIZE (27)),
    u-RNTI-BitMaskIndex-b6              BIT STRING (SIZE (26)),
    u-RNTI-BitMaskIndex-b7              BIT STRING (SIZE (25)),
    u-RNTI-BitMaskIndex-b8              BIT STRING (SIZE (24)),
    u-RNTI-BitMaskIndex-b9              BIT STRING (SIZE (23)),
    u-RNTI-BitMaskIndex-b10             BIT STRING (SIZE (22)),
    u-RNTI-BitMaskIndex-b11             BIT STRING (SIZE (21)),
    u-RNTI-BitMaskIndex-b12             BIT STRING (SIZE (20)),
    u-RNTI-BitMaskIndex-b13             BIT STRING (SIZE (19)),
    u-RNTI-BitMaskIndex-b14             BIT STRING (SIZE (18)),
    u-RNTI-BitMaskIndex-b15             BIT STRING (SIZE (17)),
    u-RNTI-BitMaskIndex-b16             BIT STRING (SIZE (16)),
```

```
    u-RNTI-BitMaskIndex-b17             BIT STRING (SIZE (15)),
    u-RNTI-BitMaskIndex-b18             BIT STRING (SIZE (14)),
    u-RNTI-BitMaskIndex-b19             BIT STRING (SIZE (13)),
    u-RNTI-BitMaskIndex-b20             BIT STRING (SIZE (12)),
    u-RNTI-BitMaskIndex-b21             BIT STRING (SIZE (11)),
    u-RNTI-BitMaskIndex-b22             BIT STRING (SIZE (10)),
    u-RNTI-BitMaskIndex-b23             BIT STRING (SIZE (9)),
    u-RNTI-BitMaskIndex-b24             BIT STRING (SIZE (8)),
    u-RNTI-BitMaskIndex-b25             BIT STRING (SIZE (7)),
    u-RNTI-BitMaskIndex-b26             BIT STRING (SIZE (6)),
    u-RNTI-BitMaskIndex-b27             BIT STRING (SIZE (5)),
    u-RNTI-BitMaskIndex-b28             BIT STRING (SIZE (4)),
    u-RNTI-BitMaskIndex-b29             BIT STRING (SIZE (3)),
    u-RNTI-BitMaskIndex-b30             BIT STRING (SIZE (2)),
    u-RNTI-BitMaskIndex-b31             BIT STRING (SIZE (1))
}

U-RNTI-Short ::=                    SEQUENCE {
    srnc-Identity                       SRNC-Identity,
    s-RNTI-2                            S-RNTI-2
}

UE-CapabilityContainer-IEs ::=          SEQUENCE {
-- Container for transparent transfer of capability information not related to
-- features for which early implementation is desired
        ue-RadioAccessCapability-v690ext    UE-RadioAccessCapability-v690ext,
        ue-RATSpecificCapability-v690ext    InterRAT-UE-RadioAccessCapability-v690ext   OPTIONAL,
        nonCriticalExtensions               SEQUENCE {}     OPTIONAL
}

UE-ConnTimersAndConstants ::=       SEQUENCE {
-- Optional is used also for parameters for which the default value is the last one read in SIB1
-- t-301 and n-301 should not be used by the UE in this version of the specification
    t-301                               T-301                                   DEFAULT ms2000,
    n-301                               N-301                                   DEFAULT 2,
    t-302                               T-302                                   DEFAULT ms4000,
    n-302                               N-302                                   DEFAULT 3,
    t-304                               T-304                                   DEFAULT ms2000,
    n-304                               N-304                                   DEFAULT 2,
    t-305                               T-305                                   DEFAULT m30,
    t-307                               T-307                                   DEFAULT s30,
    t-308                               T-308                                   DEFAULT ms160,
    t-309                               T-309                                   DEFAULT 5,
    t-310                               T-310                                   DEFAULT ms160,
    n-310                               N-310                                   DEFAULT 4,
    t-311                               T-311                                   DEFAULT ms2000,
    t-312                               T-312                                   DEFAULT 1,
    -- n-312 shall be ignored if n-312 in UE-ConnTimersAndConstants-v3a0ext is present, and the
    -- value of that element shall be used instead.
    n-312                               N-312                                   DEFAULT s1,
    t-313                               T-313                                   DEFAULT 3,
    n-313                               N-313                                   DEFAULT s20,
    t-314                               T-314                                   DEFAULT s12,
    t-315                               T-315                                   DEFAULT s180,
    -- n-315 shall be ignored if n-315 in UE-ConnTimersAndConstants-v3a0ext is present, and the
    -- value of that element shall be used instead.
    n-315                               N-315                                   DEFAULT s1,
    t-316                               T-316                                   DEFAULT s30,
    t-317                               T-317                                   DEFAULT infinity4
}

UE-ConnTimersAndConstants-v3a0ext ::=       SEQUENCE {
    n-312                               N-312ext                                    OPTIONAL,
    n-315                               N-315ext                                    OPTIONAL
}

UE-ConnTimersAndConstants-r5 ::=        SEQUENCE {
-- Optional is used also for parameters for which the default value is the last one read in SIB1
-- t-301 and n-301 should not be used by the UE in this version of the specification
    t-301                               T-301                                   DEFAULT ms2000,
    n-301                               N-301                                   DEFAULT 2,
    t-302                               T-302                                   DEFAULT ms4000,
    n-302                               N-302                                   DEFAULT 3,
    t-304                               T-304                                   DEFAULT ms2000,
    n-304                               N-304                                   DEFAULT 2,
    t-305                               T-305                                   DEFAULT m30,
    t-307                               T-307                                   DEFAULT s30,
    t-308                               T-308                                   DEFAULT ms160,
```

```
    t-309                               T-309                               DEFAULT 5,
    t-310                               T-310                               DEFAULT ms160,
    n-310                               N-310                               DEFAULT 4,
    t-311                               T-311                               DEFAULT ms2000,
    t-312                               T-312                               DEFAULT 1,
    n-312                               N-312-r5                            DEFAULT s1,
    t-313                               T-313                               DEFAULT 3,
    n-313                               N-313                               DEFAULT s20,
    t-314                               T-314                               DEFAULT s12,
    t-315                               T-315                               DEFAULT s180,
    n-315                               N-315-r5                            DEFAULT s1,
    t-316                               T-316                               DEFAULT s30,
    t-317                               T-317                               DEFAULT infinity4
}

UE-IdleTimersAndConstants ::=       SEQUENCE {
    t-300                               T-300,
    n-300                               N-300,
    t-312                               T-312,
    -- n-312 shall be ignored if n-312 in UE-IdleTimersAndConstants-v3a0ext is present, and the
    -- value of that element shall be used instead.
    n-312                               N-312
}

UE-IdleTimersAndConstants-v3a0ext ::=       SEQUENCE {
    n-312                               N-312ext                                OPTIONAL
}

UE-MultiModeRAT-Capability ::=      SEQUENCE {
    multiRAT-CapabilityList             MultiRAT-Capability,
    multiModeCapability                 MultiModeCapability
}

UE-PowerClass ::=                   INTEGER (1..4)

UE-PowerClassExt ::=                ENUMERATED {class1, class2, class3, class4,
                                         spare4, spare3, spare2, spare1 }

UE-RadioAccessCapability ::=        SEQUENCE {
    -- UE-RadioAccessCapability is compatible with R99, although accessStratumReleaseIndicator
    -- is removed from this IE, since its encoding did not does in bits. The
    -- accessStratumReleaseIndicator is provided in the relevant REL-4 extension IEs.
    pdcp-Capability                     PDCP-Capability,
    rlc-Capability                      RLC-Capability,
    transportChannelCapability          TransportChannelCapability,
    rf-Capability                       RF-Capability,
    physicalChannelCapability           PhysicalChannelCapability,
    ue-MultiModeRAT-Capability          UE-MultiModeRAT-Capability,
    securityCapability                  SecurityCapability,
    ue-positioning-Capability           UE-Positioning-Capability,
    measurementCapability               MeasurementCapability       OPTIONAL
}

UE-RadioAccessCapabilityInfo ::=        SEQUENCE {
    ue-RadioAccessCapability            UE-RadioAccessCapability,
    ue-RadioAccessCapability-v370ext    UE-RadioAccessCapability-v370ext
}

UE-RadioAccessCapability-v370ext ::=    SEQUENCE {
    ue-RadioAccessCapabBandFDDList      UE-RadioAccessCapabBandFDDList
}

UE-RadioAccessCapability-v380ext ::=    SEQUENCE {
    ue-PositioningCapabilityExt-v380        UE-PositioningCapabilityExt-v380
}

UE-RadioAccessCapability-v3a0ext ::=    SEQUENCE {
    ue-PositioningCapabilityExt-v3a0        UE-PositioningCapabilityExt-v3a0
}

UE-RadioAccessCapability-v3g0ext ::=    SEQUENCE {
    ue-PositioningCapabilityExt-v3g0        UE-PositioningCapabilityExt-v3g0
}

UE-RadioAccessCapability-v650ext ::=    SEQUENCE {
    ue-RadioAccessCapabBandFDDList2     UE-RadioAccessCapabBandFDDList2,
    -- This IE shall be included if the UE also supports Band I-VII
    ue-RadioAccessCapabBandFDDList-ext  UE-RadioAccessCapabBandFDDList-ext  OPTIONAL
```

```
}

UE-RadioAccessCapability-v690ext ::= SEQUENCE {
        physicalchannelcapability-edch  PhysicalChannelCapability-edch-r6,
        -- TABULAR: deviceType is MD in tabular description
        -- Default value is 'doesBenefitFromBatteryConsumptionOptimisation'
        deviceType      ENUMERATED { doesNotBenefitFromBatteryConsumptionOptimisation } OPTIONAL
}

UE-RadioAccessCapability-v7xyext ::=        SEQUENCE {
    -- UE-RadioAccessCapability is compatible with R99, although accessStratumReleaseIndicator
    -- is removed from this IE, since its encoding did not does in bits. The
    -- accessStratumReleaseIndicator is provided in the relevant REL-4 extension IEs.
    pdcp-Capability                             PDCP-Capability,
    rlc-Capability                              RLC-Capability,
    transportChannelCapability                  TransportChannelCapability,
    rf-Capability                               RF-Capability-r7,
    physicalChannelCapability-r7                PhysicalChannelCapability-r7,
    ue-MultiModeRAT-Capability                  UE-MultiModeRAT-Capability,
    securityCapability                          SecurityCapability,
    ue-positioning-Capability                   UE-Positioning-Capability,
    measurementCapability                       MeasurementCapability       OPTIONAL
}

UE-RadioAccessCapabBandFDDList2 ::= SEQUENCE (SIZE (1..maxFreqBandsFDD)) OF
                                        UE-RadioAccessCapabBandFDD2

UE-RadioAccessCapabBandFDD2 ::= SEQUENCE {
    radioFrequencyBandFDD2              RadioFrequencyBandFDD2,
    fddRF-Capability                    SEQUENCE {
        ue-PowerClass                       UE-PowerClassExt,
        txRxFrequencySeparation             TxRxFrequencySeparation
    }       OPTIONAL,
    measurementCapability2              MeasurementCapabilityExt2
}


UE-PositioningCapabilityExt-v380 ::=    SEQUENCE {
    rx-tx-TimeDifferenceType2Capable        BOOLEAN
}

UE-PositioningCapabilityExt-v3a0 ::=    SEQUENCE {
    validity-CellPCH-UraPCH                 ENUMERATED { true }
}

UE-PositioningCapabilityExt-v3g0 ::=    SEQUENCE {
    sfn-sfnType2Capability              ENUMERATED { true }
}

UE-RadioAccessCapabBandFDDList ::=  SEQUENCE (SIZE (1..maxFreqBandsFDD)) OF
                                        UE-RadioAccessCapabBandFDD

UE-RadioAccessCapabBandFDDList-ext ::= SEQUENCE (SIZE (1..maxFreqBandsFDD)) OF
                                    UE-RadioAccessCapabBandFDD-ext

UE-RadioAccessCapabBandFDD ::=  SEQUENCE{
    radioFrequencyBandFDD               RadioFrequencyBandFDD,
    fddRF-Capability                    SEQUENCE {
        ue-PowerClass                       UE-PowerClassExt,
        txRxFrequencySeparation             TxRxFrequencySeparation
    }                                                       OPTIONAL,
    measurementCapability               MeasurementCapabilityExt
}

UE-RadioAccessCapabBandFDD-ext ::= SEQUENCE {
    radioFrequencyBandFDD               RadioFrequencyBandFDD,
    compressedModeMeasCapabFDDList-ext  CompressedModeMeasCapabFDDList-ext
}

UE-RadioAccessCapability-v4b0ext ::=    SEQUENCE {
    pdcp-Capability-r4-ext              PDCP-Capability-r4-ext,
    tdd-CapabilityExt                   SEQUENCE {
        rf-Capability                       RF-Capability-r4-ext,
        physicalChannelCapability-LCR       PhysicalChannelCapability-LCR-r4,
        measurementCapability-r4-ext        MeasurementCapability-r4-ext
    }                                           OPTIONAL,
    -- IE " AccessStratumReleaseIndicator" is not needed in RRC CONNECTION SETUP COMPLETE
    accessStratumReleaseIndicator               AccessStratumReleaseIndicator   OPTIONAL
```

```
}

UE-RadioAccessCapabilityComp ::= SEQUENCE {
    totalAM-RLCMemoryExceeds10kB            BOOLEAN,
    rf-CapabilityComp                       RF-CapabilityComp
}

UE-RadioAccessCapabilityComp-ext ::= SEQUENCE {
    rf-CapabilityFDDComp                RF-CapabBandListFDDComp-ext
}

UE-RadioAccessCapabilityComp-r7 ::= SEQUENCE {
    totalAM-RLCMemoryExceeds10kB            BOOLEAN,
    rf-CapabilityComp                       RF-CapabilityComp-r7
}

UE-RadioAccessCapabilityComp2 ::=       SEQUENCE {
    fddPhysicalChannelCapab-hspdsch-edch    SEQUENCE {
        dl-CapabilityWithSimultaneousHS-DSCHConfig
                                                DL-CapabilityWithSimultaneousHS-DSCHConfig
    OPTIONAL,
        physicalChannelCapabComp-hspdsch-r6     HSDSCH-physical-layer-category,
        physicalChannelCapability-edch-r6       PhysicalChannelCapability-edch-r6
    }       OPTIONAL
}

RF-CapabilityComp ::= SEQUENCE {
    fdd                     CHOICE {
        notSupported                    NULL,
        supported                       RF-CapabBandListFDDComp
    },
    tdd384-RF-Capability    CHOICE {
        notSupported                    NULL,
        supported                       RadioFrequencyBandTDDList
    },
    tdd128-RF-Capability    CHOICE {
        notSupported                    NULL,
        supported                       RadioFrequencyBandTDDList
    }
}

RF-CapabilityComp-r7 ::= SEQUENCE {
    fdd                     CHOICE {
        notSupported                    NULL,
        supported                       RF-CapabBandListFDDComp
    },
    tdd384-RF-Capability    CHOICE {
        notSupported                    NULL,
        supported                       RadioFrequencyBandTDDList
    },
    tdd768-RF-Capability    CHOICE  {
        notSupported                    NULL,
        supported                       RadioFrequencyBandTDDList
    },
    tdd128-RF-Capability    CHOICE {
        notSupported                    NULL,
        supported                       RadioFrequencyBandTDDList
    }
}

-- NOTE: This IE defines the supported TX/RX frequency separation for the respective supported
-- frequency band. Values defined as spare shall not be sent in this version of the protocol.
-- If a spare value is received, it should be interpreted as 'default-RxTX-sparation'.
RF-CapabBandFDDComp ::=             ENUMERATED { notSupported,
                                        default-TxRx-separation, spare2, spare1 }

RF-CapabBandListFDDComp ::=         SEQUENCE (SIZE (1..maxFreqBandsFDD)) OF
    -- The first entry corresponds with the first value of IE RadioFrequencyBandFDD,
    -- fdd2100, and so on. No more than seven entries should be included in this IE. The
    -- 8'th entry, if present, shall be ignored.
    -- An extension of this IE may be provided using the IE 'RF-CapabBandListFDDComp-ext'.
    RF-CapabBandFDDComp

RF-CapabBandListFDDComp-ext ::=     SEQUENCE (SIZE (1..maxFreqBandsFDD-ext)) OF
    -- The first entry corresponds with the first value of IE RadioFrequencyBandFDD2,
    -- bandVIII, and so on.
    RF-CapabBandFDDComp
```

```
UE-RadioAccessCapability-v590ext ::=    SEQUENCE {
    dl-CapabilityWithSimultaneousHS-DSCHConfig  DL-CapabilityWithSimultaneousHS-DSCHConfig
    OPTIONAL,
    pdcp-Capability-r5-ext              PDCP-Capability-r5-ext,
    rlc-Capability-r5-ext               RLC-Capability-r5-ext,
    physicalChannelCapability           PhysicalChannelCapability-hspdsch-r5,
    multiModeRAT-Capability-v590ext     MultiModeRAT-Capability-v590ext
}

UE-RadioAccessCapability-v5c0ext ::= SEQUENCE {
    pdcp-Capability-r5-ext2             PDCP-Capability-r5-ext2
}

UE-RadioAccessCapability-v680ext ::= SEQUENCE {
    multiModeRAT-Capability-v680ext     MultiModeRAT-Capability-v680ext
}

UL-PhysChCapabilityFDD ::=          SEQUENCE {
    maxNoDPDCH-BitsTransmitted          MaxNoDPDCH-BitsTransmitted,
    -- dummy is not used in this version of the specification and
    -- it should be ignored by the receiver.
    dummy                               BOOLEAN
}

UL-PhysChCapabilityFDD-r6 ::=           SEQUENCE {
    maxNoDPDCH-BitsTransmitted              MaxNoDPDCH-BitsTransmitted,
    physicalchannelcapability-edch          PhysicalChannelCapability-edch-r6
}

UL-PhysChCapabilityTDD ::=          SEQUENCE {
    maxTS-PerFrame                      MaxTS-PerFrame,
    maxPhysChPerTimeslot                MaxPhysChPerTimeslot,
    minimumSF                           MinimumSF-UL,
    supportOfPUSCH                      BOOLEAN
}

UL-PhysChCapabilityTDD-LCR-r4 ::=   SEQUENCE {
    maxTS-PerSubFrame                   MaxTS-PerSubFrame-r4,
    maxPhysChPerTimeslot                MaxPhysChPerTimeslot,
    minimumSF                           MinimumSF-UL,
    supportOfPUSCH                      BOOLEAN,
    supportOf8PSK                       BOOLEAN
}

PhysicalChannelCapability-edch-r6 ::=   SEQUENCE {
    fdd-edch                                CHOICE {
        supported                               SEQUENCE {
            edch-PhysicalLayerCategory              INTEGER (1..16)
        },
        unsupported                             NULL
    }
}

UL-TransChCapability ::=            SEQUENCE {
    maxNoBitsTransmitted                MaxNoBits,
    maxConvCodeBitsTransmitted          MaxNoBits,
    turboEncodingSupport                TurboSupport,
    maxSimultaneousTransChs             MaxSimultaneousTransChsUL,
    modeSpecificInfo                    CHOICE {
        fdd                                 NULL,
        tdd                                 SEQUENCE {
            maxSimultaneousCCTrCH-Count         MaxSimultaneousCCTrCH-Count
        }
    },
    maxTransmittedBlocks                MaxTransportBlocksUL,
    maxNumberOfTFC                      MaxNumberOfTFC-UL,
    maxNumberOfTF                       MaxNumberOfTF
}

UE-Positioning-Capability ::=       SEQUENCE {
    standaloneLocMethodsSupported           BOOLEAN,
    ue-BasedOTDOA-Supported                 BOOLEAN,
    networkAssistedGPS-Supported            NetworkAssistedGPS-Supported,
    supportForUE-GPS-TimingOfCellFrames     BOOLEAN,
    supportForIPDL                          BOOLEAN
}

UE-SecurityInformation ::=          SEQUENCE {
```

```
    start-CS                            START-Value
}

UE-SecurityInformation2 ::=         SEQUENCE {
    start-PS                            START-Value
}

URA-UpdateCause ::=                 ENUMERATED {
                                        changeOfURA,
                                        periodicURAUpdate,
                                        dummy,
                                        spare1 }

UTRAN-DRX-CycleLengthCoefficient ::= INTEGER (3..9)

WaitTime ::=                        INTEGER (0..15)

-- **************************************************
--
--     RADIO BEARER INFORMATION ELEMENTS (10.3.4)
--
-- **************************************************

AlgorithmSpecificInfo ::=           CHOICE {
    rfc2507-Info                        RFC2507-Info
}

AlgorithmSpecificInfo-r4 ::=        CHOICE {
    rfc2507-Info                        RFC2507-Info,
    rfc3095-Info                        RFC3095-Info-r4
}

CID-InclusionInfo-r4 ::=            ENUMERATED {
                                        pdcp-Header,
                                        rfc3095-PacketFormat }

-- Upper limit of COUNT-C is 2^32 - 1
COUNT-C ::=                         INTEGER (0..4294967295)

-- Upper limit of COUNT-C-MSB is 2^25 - 1
COUNT-C-MSB ::=                     INTEGER (0..33554431)

DefaultConfigIdentity ::=           INTEGER (0..10)

DefaultConfigIdentity-r4 ::=        INTEGER (0..12)

DefaultConfigIdentity-r5 ::=        INTEGER (0..13)

DefaultConfigIdentity-r6 ::=        INTEGER (0..31)

DefaultConfigMode ::=               ENUMERATED {
                                        fdd,
                                        tdd }

DDI ::=                             INTEGER (0..62)

DL-AM-RLC-Mode ::=                  SEQUENCE {
    inSequenceDelivery                  BOOLEAN,
    receivingWindowSize                 ReceivingWindowSize,
    dl-RLC-StatusInfo                   DL-RLC-StatusInfo
}

DL-AM-RLC-Mode-r5 ::=                   SEQUENCE {
    dl-RLC-PDU-size                     OctetModeRLC-SizeInfoType1,
    inSequenceDelivery                  BOOLEAN,
    receivingWindowSize                 ReceivingWindowSize,
    dl-RLC-StatusInfo                   DL-RLC-StatusInfo
}

DL-CounterSynchronisationInfo ::=       SEQUENCE {
    rB-WithPDCP-InfoList                    RB-WithPDCP-InfoList    OPTIONAL
}

DL-CounterSynchronisationInfo-r5 ::=    SEQUENCE {
    rb-WithPDCP-InfoList                    RB-WithPDCP-InfoList            OPTIONAL,
    rb-PDCPContextRelocationList            RB-PDCPContextRelocationList    OPTIONAL
}
```

```
DL-LogicalChannelMapping ::=        SEQUENCE {
    -- TABULAR: DL-TransportChannelType contains TransportChannelIdentity as well.
    dl-TransportChannelType             DL-TransportChannelType,
    logicalChannelIdentity              LogicalChannelIdentity              OPTIONAL
}

DL-LogicalChannelMapping-r5 ::=     SEQUENCE {
    -- TABULAR: DL-TransportChannelType contains TransportChannelIdentity as well.
    dl-TransportChannelType             DL-TransportChannelType-r5,
    logicalChannelIdentity              LogicalChannelIdentity              OPTIONAL
}

DL-LogicalChannelMappingList ::=    SEQUENCE (SIZE (1..maxLoCHperRLC)) OF
                                        DL-LogicalChannelMapping

DL-LogicalChannelMappingList-r5 ::= SEQUENCE (SIZE (1..maxLoCHperRLC)) OF
                                        DL-LogicalChannelMapping-r5

DL-Reception-Window-Size-r6 ::=     ENUMERATED { size32, size48, size64, size80, size96, size112 }

DL-RFC3095-r4 ::=                   SEQUENCE {
    cid-InclusionInfo                   CID-InclusionInfo-r4,
    max-CID                             INTEGER (1..16383)                  DEFAULT 15,
    reverseDecompressionDepth           INTEGER (0..65535)                  DEFAULT 0
}

DL-RLC-Mode ::=                     CHOICE {
    dl-AM-RLC-Mode                      DL-AM-RLC-Mode,
    dl-UM-RLC-Mode                      NULL,
    dl-TM-RLC-Mode                      DL-TM-RLC-Mode
}

DL-RLC-Mode-r5 ::=                  CHOICE {
    dl-AM-RLC-Mode                      DL-AM-RLC-Mode-r5,
    dl-UM-RLC-Mode                      DL-UM-RLC-Mode-r5,
    dl-TM-RLC-Mode                      DL-TM-RLC-Mode
}

DL-RLC-Mode-r6 ::=                  CHOICE {
    dl-AM-RLC-Mode                      DL-AM-RLC-Mode-r5,
    dl-UM-RLC-Mode                      DL-UM-RLC-Mode-r6,
    dl-TM-RLC-Mode                      DL-TM-RLC-Mode
}

DL-RLC-StatusInfo ::=               SEQUENCE {
    timerStatusProhibit                 TimerStatusProhibit                 OPTIONAL,
    -- dummy is not used in this version of the specification, it should not be sent
    -- and if received they should be ignored.
    dummy                           TimerEPC                            OPTIONAL,
    missingPDU-Indicator                BOOLEAN,
    timerStatusPeriodic                 TimerStatusPeriodic                 OPTIONAL
}

DL-TM-RLC-Mode ::=                  SEQUENCE {
    segmentationIndication              BOOLEAN
}

DL-TransportChannelType ::=         CHOICE {
    dch                                 TransportChannelIdentity,
    fach                                NULL,
    -- The choice 'dsch' should not be used in FDD mode, and if received
    -- the UE behaviour is unspecified.
    dsch                                TransportChannelIdentity,
    -- The choice 'dch-and-dsch' should not be used in FDD mode, and if received the UE
    -- behaviour is unspecified
    dch-and-dsch                        TransportChannelIdentityDCHandDSCH
}

DL-TransportChannelType-r5 ::=          CHOICE {
    dch                                 TransportChannelIdentity,
    fach                                NULL,
    -- The choice 'dsch' should not be used in FDD mode, and if received
    -- the UE behaviour is unspecified.
    dsch                                TransportChannelIdentity,
    -- The choice 'dch-and-dsch' should not be used in FDD mode, and if received the UE
    -- behaviour is unspecified
    dch-and-dsch                        TransportChannelIdentityDCHandDSCH,
    hsdsch                              MAC-d-FlowIdentity,
```

```
    dch-and-hsdsch                      MAC-d-FlowIdentityDCHandHSDSCH
}

DL-UM-RLC-LI-size ::=                   ENUMERATED {
                                        size7, size15 }

DL-UM-RLC-Mode-r5 ::=                   SEQUENCE {
    dl-UM-RLC-LI-size                   DL-UM-RLC-LI-size
}

DL-UM-RLC-Mode-r6 ::=               SEQUENCE {
    dl-UM-RLC-LI-size                   DL-UM-RLC-LI-size,
    dl-Reception-Window-Size            DL-Reception-Window-Size-r6         OPTIONAL
}

ExpectReordering ::=                ENUMERATED {
                                        reorderingNotExpected,
                                        reorderingExpected }

ExplicitDiscard ::=                 SEQUENCE {
    timerMRW                            TimerMRW,
    timerDiscard                        TimerDiscard,
    maxMRW                              MaxMRW
}

HeaderCompressionInfo ::=           SEQUENCE {
    algorithmSpecificInfo               AlgorithmSpecificInfo
}

HeaderCompressionInfoList ::=       SEQUENCE (SIZE (1..maxPDCPAlgoType)) OF
                                        HeaderCompressionInfo

HeaderCompressionInfo-r4 ::=        SEQUENCE {
    algorithmSpecificInfo               AlgorithmSpecificInfo-r4
}

HeaderCompressionInfoList-r4 ::=    SEQUENCE (SIZE (1..maxPDCPAlgoType)) OF
                                        HeaderCompressionInfo-r4

LogicalChannelIdentity ::=          INTEGER (1..15)

LosslessSRNS-RelocSupport ::=       CHOICE {
    supported                           MaxPDCP-SN-WindowSize,
    notSupported                        NULL
}

MAC-d-HFN-initial-value ::=         BIT STRING (SIZE (24))

MAC-LogicalChannelPriority ::=      INTEGER (1..8)

MaxDAT ::=                          ENUMERATED {
                                        dat1, dat2, dat3, dat4, dat5, dat6,
                                        dat7, dat8, dat9, dat10, dat15, dat20,
                                        dat25, dat30, dat35, dat40 }

MaxDAT-Retransmissions ::=          SEQUENCE {
    maxDAT                              MaxDAT,
    timerMRW                            TimerMRW,
    maxMRW                              MaxMRW
}

MaxMRW ::=                          ENUMERATED {
                                        mm1, mm4, mm6, mm8, mm12, mm16,
                                        mm24, mm32 }

MaxPDCP-SN-WindowSize ::=           ENUMERATED {
                                        sn255, sn65535 }

MaxRST ::=                          ENUMERATED {
                                        rst1, rst4, rst6, rst8, rst12,
                                        rst16, rst24, rst32 }

NoExplicitDiscard ::=               ENUMERATED {
                                        dt10, dt20, dt30, dt40, dt50,
                                        dt60, dt70, dt80, dt90, dt100 }

PDCP-Info ::=                       SEQUENCE {
    losslessSRNS-RelocSupport           LosslessSRNS-RelocSupport           OPTIONAL,
```

```
    -- TABULAR: pdcp-PDU-Header is MD in the tabular format and it can be encoded
    -- in one bit, so the OPTIONAL is removed for compactness.
    pdcp-PDU-Header                 PDCP-PDU-Header,
    headerCompressionInfoList       HeaderCompressionInfoList       OPTIONAL
}

PDCP-Info-r4 ::=                    SEQUENCE {
    losslessSRNS-RelocSupport       LosslessSRNS-RelocSupport       OPTIONAL,
    -- TABULAR: pdcp-PDU-Header is MD in the tabular format and it can be encoded
    -- in one bit, so the OPTIONAL is removed for compactness.
    pdcp-PDU-Header                 PDCP-PDU-Header,
    headerCompressionInfoList       HeaderCompressionInfoList-r4    OPTIONAL
}

PDCP-InfoReconfig ::=               SEQUENCE {
    pdcp-Info                       PDCP-Info,
    -- dummy is not used in this version of the specification and
    -- it should be ignored.
    dummy                           INTEGER (0..65535)
}

PDCP-InfoReconfig-r4 ::=            SEQUENCE {
    pdcp-Info                       PDCP-Info-r4
}

PDCP-PDU-Header ::=                 ENUMERATED {
                                    present, absent }

PDCP-ROHC-TargetMode ::=            ENUMERATED { o-Mode, r-Mode }

PDCP-SN-Info ::=                    INTEGER (0..65535)

Poll-PDU ::=                        ENUMERATED {
                                    pdu1, pdu2, pdu4, pdu8, pdu16,
                                    pdu32, pdu64, pdu128 }

Poll-SDU ::=                        ENUMERATED {
                                    sdu1, sdu4, sdu16, sdu64 }

PollingInfo ::=                     SEQUENCE {
    timerPollProhibit               TimerPollProhibit               OPTIONAL,
    timerPoll                       TimerPoll                       OPTIONAL,
    poll-PDU                        Poll-PDU                        OPTIONAL,
    poll-SDU                        Poll-SDU                        OPTIONAL,
    lastTransmissionPDU-Poll        BOOLEAN,
    lastRetransmissionPDU-Poll      BOOLEAN,
    pollWindow                      PollWindow                      OPTIONAL,
    timerPollPeriodic               TimerPollPeriodic               OPTIONAL
}

PollWindow ::=                      ENUMERATED {
                                    pw50, pw60, pw70, pw80, pw85,
                                    pw90, pw95, pw99 }

PredefinedConfigIdentity ::=        INTEGER (0..15)

PredefinedConfigValueTag ::=        INTEGER (0..15)

PredefinedRB-Configuration ::=      SEQUENCE {
    re-EstablishmentTimer           Re-EstablishmentTimer,
    srb-InformationList             SRB-InformationSetupList,
    rb-InformationList              RB-InformationSetupList
}

PreDefRadioConfiguration ::=        SEQUENCE {
    -- Radio bearer IEs
        predefinedRB-Configuration      PredefinedRB-Configuration,
    -- Transport channel IEs
        preDefTransChConfiguration      PreDefTransChConfiguration,
    -- Physical channel IEs
        preDefPhyChConfiguration        PreDefPhyChConfiguration
}

PredefinedConfigStatusList ::=      SEQUENCE (SIZE (maxPredefConfig)) OF
                                    PredefinedConfigStatusInfo

PredefinedConfigStatusInfo ::=      CHOICE {
    storedWithValueTagSameAsPrevius     NULL,
```

```
    other                               CHOICE {
        notStored                           NULL,
        storedWithDifferentValueTag         PredefinedConfigValueTag
    }
}

PredefinedConfigStatusListComp ::= SEQUENCE {
    setsWithDifferentValueTag           PredefinedConfigSetsWithDifferentValueTag,
    otherEntries                        PredefinedConfigStatusListVarSz             OPTIONAL
}

PredefinedConfigSetsWithDifferentValueTag ::= SEQUENCE (SIZE (1..2)) OF
                                            PredefinedConfigSetWithDifferentValueTag

PredefinedConfigSetWithDifferentValueTag ::= SEQUENCE {
    startPosition                           INTEGER (0..10)     DEFAULT 0,
    -- numberOfEntries                      INTEGER (6..16),
    -- numberOfEntries is covered by the size of the list in IE PredefinedConfigValueTagList
    valueTagList                            PredefinedConfigValueTagList
}


PredefinedConfigValueTagList ::=        SEQUENCE (SIZE (1..maxPredefConfig)) OF
                                            PredefinedConfigValueTag

PredefinedConfigStatusListVarSz ::=     SEQUENCE (SIZE (1..maxPredefConfig)) OF
                                            PredefinedConfigStatusInfo

RAB-Info ::=                        SEQUENCE {
    rab-Identity                        RAB-Identity,
    cn-DomainIdentity                   CN-DomainIdentity,
    nas-Synchronisation-Indicator       NAS-Synchronisation-Indicator   OPTIONAL,
    re-EstablishmentTimer               Re-EstablishmentTimer
}

RAB-Info-r6-ext ::=                 SEQUENCE {
    mbms-SessionIdentity                MBMS-SessionIdentity                OPTIONAL
}

RAB-Info-r6 ::=                     SEQUENCE {
    rab-Identity                        RAB-Identity,
    mbms-SessionIdentity                MBMS-SessionIdentity                OPTIONAL,
    cn-DomainIdentity                   CN-DomainIdentity,
    nas-Synchronisation-Indicator       NAS-Synchronisation-Indicator       OPTIONAL,
    re-EstablishmentTimer               Re-EstablishmentTimer
}

RAB-InformationList ::=             SEQUENCE (SIZE (1..maxRABsetup)) OF
                                        RAB-Info

RAB-InformationList-r6 ::=          SEQUENCE (SIZE (1..maxRABsetup)) OF
                                        RAB-Info-r6

RAB-InformationReconfigList ::=     SEQUENCE (SIZE (1.. maxRABsetup)) OF
                                        RAB-InformationReconfig

RAB-InformationReconfig ::=         SEQUENCE {
    rab-Identity                        RAB-Identity,
    cn-DomainIdentity                   CN-DomainIdentity,
    nas-Synchronisation-Indicator       NAS-Synchronisation-Indicator
}

RAB-Info-Post ::=                       SEQUENCE {
    rab-Identity                        RAB-Identity,
    cn-DomainIdentity                   CN-DomainIdentity,
    nas-Synchronisation-Indicator       NAS-Synchronisation-Indicator   OPTIONAL
}

RAB-InformationSetup ::=            SEQUENCE {
    rab-Info                            RAB-Info,
    rb-InformationSetupList             RB-InformationSetupList
}

RAB-InformationSetup-r4 ::=         SEQUENCE {
    rab-Info                            RAB-Info,
    rb-InformationSetupList             RB-InformationSetupList-r4
}
```

```
RAB-InformationSetup-r5 ::=         SEQUENCE {
    rab-Info                            RAB-Info,
    rb-InformationSetupList             RB-InformationSetupList-r5
}

RAB-InformationSetup-r6-ext ::=     SEQUENCE {
    rab-Info-r6-ext                     RAB-Info-r6-ext
}

RAB-InformationSetup-r6 ::=         SEQUENCE {
    rab-Info                            RAB-Info-r6,
    rb-InformationSetupList             RB-InformationSetupList-r6
}

RAB-InformationSetupList ::=        SEQUENCE (SIZE (1..maxRABsetup)) OF
                                        RAB-InformationSetup

RAB-InformationSetupList-r4 ::=     SEQUENCE (SIZE (1..maxRABsetup)) OF
                                        RAB-InformationSetup-r4

RAB-InformationSetupList-r5 ::=     SEQUENCE (SIZE (1..maxRABsetup)) OF
                                        RAB-InformationSetup-r5

RAB-InformationSetupList-r6 ::=     SEQUENCE (SIZE (1..maxRABsetup)) OF
                                        RAB-InformationSetup-r6

-- The IE 'RAB-InformationSetupList-r6-ext' provides elements of extension information, which
-- are added to the corresponding elements of the IE 'RAB-InformationSetupList/-r4/-r5'.
RAB-InformationSetupList-r6-ext ::= SEQUENCE (SIZE (1..maxRABsetup)) OF
                                        RAB-InformationSetup-r6-ext

RB-ActivationTimeInfo ::=           SEQUENCE {
    rb-Identity                         RB-Identity,
    rlc-SequenceNumber                  RLC-SequenceNumber
}

RB-ActivationTimeInfoList ::=       SEQUENCE (SIZE (1..maxRB)) OF
                                        RB-ActivationTimeInfo

RB-COUNT-C-Information ::=          SEQUENCE {
    rb-Identity                         RB-Identity,
    count-C-UL                          COUNT-C,
    count-C-DL                          COUNT-C
}

RB-COUNT-C-InformationList ::=      SEQUENCE (SIZE (1..maxRBallRABs)) OF
                                        RB-COUNT-C-Information

RB-COUNT-C-MSB-Information ::=      SEQUENCE {
    rb-Identity                         RB-Identity,
    count-C-MSB-UL                      COUNT-C-MSB,
    count-C-MSB-DL                      COUNT-C-MSB
}

RB-COUNT-C-MSB-InformationList ::=  SEQUENCE (SIZE (1..maxRBallRABs)) OF
                                        RB-COUNT-C-MSB-Information

RB-Identity ::=                     INTEGER (1..32)

RB-IdentityList ::=                 SEQUENCE (SIZE (1..maxRB)) OF
                                        RB-Identity

RB-InformationAffected ::=          SEQUENCE {
    rb-Identity                         RB-Identity,
    rb-MappingInfo                      RB-MappingInfo
}

RB-InformationAffected-r5 ::=       SEQUENCE {
    rb-Identity                         RB-Identity,
    rb-MappingInfo                      RB-MappingInfo-r5
}

RB-InformationAffected-r6 ::=       SEQUENCE {
    rb-Identity                         RB-Identity,
    rb-MappingInfo                      RB-MappingInfo-r6
}

RB-InformationAffectedList ::=      SEQUENCE (SIZE (1..maxRB)) OF
```

```
                                    RB-InformationAffected

RB-InformationAffectedList-r5 ::=   SEQUENCE (SIZE (1..maxRB)) OF
                                    RB-InformationAffected-r5

RB-InformationAffectedList-r6 ::=   SEQUENCE (SIZE (1..maxRB)) OF
                                    RB-InformationAffected-r6

RB-InformationChanged-r6 ::=        SEQUENCE {
    rb-Identity                         RB-Identity,
    rb-Change                           CHOICE {
        release                             NULL,
        re-mapToDefaultRb                   RB-Identity
    }
}

RB-InformationChangedList-r6 ::=        SEQUENCE (SIZE (1..maxRB)) OF
                                        RB-InformationChanged-r6

RB-InformationReconfig ::=          SEQUENCE {
    rb-Identity                         RB-Identity,
    pdcp-Info                           PDCP-InfoReconfig                   OPTIONAL,
    pdcp-SN-Info                        PDCP-SN-Info                        OPTIONAL,
    rlc-Info                            RLC-Info                            OPTIONAL,
    rb-MappingInfo                      RB-MappingInfo                      OPTIONAL,
    rb-StopContinue                     RB-StopContinue                     OPTIONAL
}

RB-InformationReconfig-r4 ::=       SEQUENCE {
    rb-Identity                         RB-Identity,
    pdcp-Info                           PDCP-InfoReconfig-r4                OPTIONAL,
    pdcp-SN-Info                        PDCP-SN-Info                        OPTIONAL,
    rlc-Info                            RLC-Info                            OPTIONAL,
    rb-MappingInfo                      RB-MappingInfo                      OPTIONAL,
    rb-StopContinue                     RB-StopContinue                     OPTIONAL
}

RB-InformationReconfig-r5 ::=       SEQUENCE {
    rb-Identity                         RB-Identity,
    pdcp-Info                           PDCP-InfoReconfig-r4                OPTIONAL,
    pdcp-SN-Info                        PDCP-SN-Info                        OPTIONAL,
    rlc-Info                            RLC-Info-r5                         OPTIONAL,
    rb-MappingInfo                      RB-MappingInfo-r5                   OPTIONAL,
    rb-StopContinue                     RB-StopContinue                     OPTIONAL
}

RB-InformationReconfig-r6 ::=       SEQUENCE {
    rb-Identity                         RB-Identity,
    pdcp-Info                           PDCP-InfoReconfig-r4                OPTIONAL,
    pdcp-SN-Info                        PDCP-SN-Info                        OPTIONAL,
    rlc-Info                            RLC-Info-r6                         OPTIONAL,
    rb-MappingInfo                      RB-MappingInfo-r6                   OPTIONAL,
    rb-StopContinue                     RB-StopContinue                     OPTIONAL
}

RB-InformationReconfigList ::=      SEQUENCE (SIZE (1..maxRB)) OF
                                    RB-InformationReconfig

RB-InformationReconfigList-r4 ::=   SEQUENCE (SIZE (1..maxRB)) OF
                                    RB-InformationReconfig-r4

RB-InformationReconfigList-r5 ::=   SEQUENCE (SIZE (1..maxRB)) OF
                                    RB-InformationReconfig-r5

RB-InformationReconfigList-r6 ::=   SEQUENCE (SIZE (1..maxRB)) OF
                                    RB-InformationReconfig-r6

RB-InformationReleaseList ::=       SEQUENCE (SIZE (1..maxRB)) OF
                                    RB-Identity

RB-InformationSetup ::=             SEQUENCE {
    rb-Identity                         RB-Identity,
    pdcp-Info                           PDCP-Info                           OPTIONAL,
    rlc-InfoChoice                      RLC-InfoChoice,
    rb-MappingInfo                      RB-MappingInfo
}

RB-InformationSetup-r4 ::=          SEQUENCE {
```

```
    rb-Identity                         RB-Identity,
    pdcp-Info                           PDCP-Info-r4                        OPTIONAL,
    rlc-InfoChoice                      RLC-InfoChoice,
    rb-MappingInfo                      RB-MappingInfo
}

RB-InformationSetup-r5 ::=          SEQUENCE {
    rb-Identity                         RB-Identity,
    pdcp-Info                           PDCP-Info-r4                        OPTIONAL,
    rlc-InfoChoice                      RLC-InfoChoice-r5,
    rb-MappingInfo                      RB-MappingInfo-r5
}

RB-InformationSetup-r6 ::=          SEQUENCE {
    rb-Identity                         RB-Identity,
    pdcp-Info                           PDCP-Info-r4                        OPTIONAL,
    rlc-InfoChoice                      RLC-InfoChoice-r6,
    rb-MappingInfo                      RB-MappingInfo-r6
}

RB-InformationSetupList ::=         SEQUENCE (SIZE (1..maxRBperRAB)) OF
                                        RB-InformationSetup

RB-InformationSetupList-r4 ::=      SEQUENCE (SIZE (1..maxRBperRAB)) OF
                                        RB-InformationSetup-r4

RB-InformationSetupList-r5 ::=      SEQUENCE (SIZE (1..maxRBperRAB)) OF
                                        RB-InformationSetup-r5

RB-InformationSetupList-r6 ::=      SEQUENCE (SIZE (1..maxRBperRAB)) OF
                                        RB-InformationSetup-r6

RB-MappingInfo ::=                  SEQUENCE (SIZE (1..maxRBMuxOptions)) OF
                                        RB-MappingOption

RB-MappingInfo-r5 ::=                   SEQUENCE (SIZE (1..maxRBMuxOptions)) OF
                                        RB-MappingOption-r5

RB-MappingInfo-r6 ::=                   SEQUENCE (SIZE (1..maxRBMuxOptions)) OF
                                        RB-MappingOption-r6

RB-MappingOption ::=                SEQUENCE {
    ul-LogicalChannelMappings           UL-LogicalChannelMappings           OPTIONAL,
    dl-LogicalChannelMappingList        DL-LogicalChannelMappingList        OPTIONAL
}

RB-MappingOption-r5 ::=                 SEQUENCE {
    ul-LogicalChannelMappings           UL-LogicalChannelMappings           OPTIONAL,
    dl-LogicalChannelMappingList        DL-LogicalChannelMappingList-r5     OPTIONAL
}

RB-MappingOption-r6 ::=                 SEQUENCE {
    ul-LogicalChannelMappings           UL-LogicalChannelMappings-r6        OPTIONAL,
    dl-LogicalChannelMappingList        DL-LogicalChannelMappingList-r5     OPTIONAL
}

RB-PDCPContextRelocation ::=            SEQUENCE {
    rb-Identity                             RB-Identity,
    dl-RFC3095-Context-Relocation           BOOLEAN,
    ul-RFC3095-Context-Relocation           BOOLEAN
}

RB-PDCPContextRelocationList ::=            SEQUENCE (SIZE (1..maxRBallRABs)) OF
                                            RB-PDCPContextRelocation

RB-StopContinue ::=                 ENUMERATED {
                                        stopRB, continueRB }

RB-WithPDCP-Info ::=                SEQUENCE {
    rb-Identity                         RB-Identity,
    pdcp-SN-Info                        PDCP-SN-Info
}

RB-WithPDCP-InfoList ::=            SEQUENCE (SIZE (1..maxRBallRABs)) OF
                                        RB-WithPDCP-Info

ReceivingWindowSize ::=             ENUMERATED {
                                        rw1, rw8, rw16, rw32, rw64, rw128, rw256,
```

```
                                    rw512, rw768, rw1024, rw1536, rw2047,
                                    rw2560, rw3072, rw3584, rw4095 }

RFC2507-Info ::=                    SEQUENCE {
    f-MAX-PERIOD                        INTEGER (1..65535)                  DEFAULT 256,
    f-MAX-TIME                          INTEGER (1..255)                    DEFAULT 5,
    max-HEADER                          INTEGER (60..65535)                 DEFAULT 168,
    tcp-SPACE                           INTEGER (3..255)                    DEFAULT 15,
    non-TCP-SPACE                       INTEGER (3..65535)                  DEFAULT 15,
    -- TABULAR: expectReordering has only two possible values, so using Optional or Default
    -- would be wasteful
    expectReordering                    ExpectReordering
}

RFC3095-Info-r4 ::=             SEQUENCE {
    rohcProfileList                     ROHC-ProfileList-r4,
    ul-RFC3095                          UL-RFC3095-r4                       OPTIONAL,
    dl-RFC3095                          DL-RFC3095-r4                       OPTIONAL
}

RLC-Info ::=                        SEQUENCE {
    ul-RLC-Mode                         UL-RLC-Mode                         OPTIONAL,
    dl-RLC-Mode                         DL-RLC-Mode                         OPTIONAL
}

RLC-Info-r5 ::=                     SEQUENCE {
    ul-RLC-Mode                         UL-RLC-Mode                         OPTIONAL,
    dl-RLC-Mode                         DL-RLC-Mode-r5                      OPTIONAL,
    rlc-OneSidedReEst                   BOOLEAN
}

RLC-Info-r6 ::=                     SEQUENCE {
    ul-RLC-Mode                         UL-RLC-Mode                         OPTIONAL,
    dl-RLC-Mode                         DL-RLC-Mode-r6                      OPTIONAL,
    rlc-OneSidedReEst                   BOOLEAN,
    altE-bitInterpretation              ENUMERATED { true }                 OPTIONAL
}

RLC-Info-MCCH-r6 ::=                SEQUENCE {
    dl-UM-RLC-LI-size                   DL-UM-RLC-LI-size,
    dl-UM-RLC-OutOSeqDelivery-Info      UM-RLC-OutOSeqDelivery-Info-r6      OPTIONAL
}

RLC-Info-MSCH-r6 ::=                SEQUENCE {
    dl-UM-RLC-LI-size                   DL-UM-RLC-LI-size
}

RLC-Info-MTCH-r6 ::=                SEQUENCE {
    dl-UM-RLC-LI-size                   DL-UM-RLC-LI-size,
    dl-UM-RLC-DuplAvoid-Reord-Info      UM-RLC-DuplAvoid-Reord-Info-r6      OPTIONAL
}

RLC-InfoChoice ::=                  CHOICE {
    rlc-Info                            RLC-Info,
    same-as-RB                          RB-Identity
}

RLC-InfoChoice-r5 ::=               CHOICE {
    rlc-Info                            RLC-Info-r5,
    same-as-RB                          RB-Identity
}

RLC-InfoChoice-r6 ::=               CHOICE {
    rlc-Info                            RLC-Info-r6,
    same-as-RB                          RB-Identity
}

RLC-PDU-Size ::=                    OctetModeRLC-SizeInfoType1

RLC-PDU-SizeList ::=                SEQUENCE (SIZE (1..maxRLCPDUsizePerLogChan)) OF
                                        RLC-PDU-Size

RLC-SequenceNumber ::=              INTEGER (0..4095)

RLC-SizeInfo ::=                    SEQUENCE {
    rlc-SizeIndex                       INTEGER (1..maxTF)
}
```

```
RLC-SizeExplicitList ::=            SEQUENCE (SIZE  (1..maxTF)) OF
                                        RLC-SizeInfo

ROHC-Profile-r4 ::=                 INTEGER (1..3)

ROHC-ProfileList-r4 ::=             SEQUENCE (SIZE  (1..maxROHC-Profile-r4))    OF
                                        ROHC-Profile-r4

ROHC-PacketSize-r4 ::=              INTEGER (2..1500)

ROHC-PacketSizeList-r4 ::=          SEQUENCE (SIZE  (1..maxROHC-PacketSizes-r4))    OF
                                        ROHC-PacketSize-r4

SRB-InformationSetup ::=            SEQUENCE {
    -- The default value for rb-Identity is the smallest value not used yet.
    rb-Identity                         RB-Identity                         OPTIONAL,
    rlc-InfoChoice                      RLC-InfoChoice,
    rb-MappingInfo                      RB-MappingInfo
}

SRB-InformationSetup-r5 ::=         SEQUENCE {
    -- The default value for rb-Identity is the smallest value not used yet.
    rb-Identity                         RB-Identity                         OPTIONAL,
    rlc-InfoChoice                      RLC-InfoChoice-r5,
    rb-MappingInfo                      RB-MappingInfo-r5
}

SRB-InformationSetup-r6 ::=         SEQUENCE {
    -- The default value for rb-Identity is the smallest value not used yet.
    rb-Identity                         RB-Identity                         OPTIONAL,
    rlc-InfoChoice                      RLC-InfoChoice-r6,
    rb-MappingInfo                      RB-MappingInfo-r6
}

SRB-InformationSetupList ::=        SEQUENCE (SIZE (1..maxSRBsetup)) OF
                                        SRB-InformationSetup

SRB-InformationSetupList-r5 ::=     SEQUENCE (SIZE (1..maxSRBsetup)) OF
                                        SRB-InformationSetup-r5

SRB-InformationSetupList-r6 ::=     SEQUENCE (SIZE (1..maxSRBsetup)) OF
                                        SRB-InformationSetup-r6

SRB-InformationSetupList2 ::=       SEQUENCE (SIZE (3..4)) OF
                                        SRB-InformationSetup

SRB-InformationSetupList2-r6 ::=    SEQUENCE (SIZE (3..4)) OF
                                        SRB-InformationSetup-r6

TimerDAR-r6 ::=                     ENUMERATED {
                                        ms40, ms80, ms120, ms160, ms240, ms320, ms480, ms640,
                                        ms960, ms1280, ms1920, ms2560, ms3840, ms5120 }

TimerDiscard ::=                    ENUMERATED {
                                        td0-1, td0-25, td0-5, td0-75,
                                        td1, td1-25, td1-5, td1-75,
                                        td2, td2-5, td3, td3-5, td4,
                                        td4-5, td5, td7-5 }

TimerEPC ::=                        ENUMERATED {
                                        te50, te60, te70, te80, te90,
                                        te100, te120, te140, te160, te180,
                                        te200, te300, te400, te500, te700,
                                        te900 }

TimerMRW ::=                        ENUMERATED {
                                        te50, te60, te70, te80, te90, te100,
                                        te120, te140, te160, te180, te200,
                                        te300, te400, te500, te700, te900 }

TimerOSD-r6 ::=                     ENUMERATED {
                                        ms40, ms80, ms120, ms160, ms240, ms320, ms480, ms640,
                                        ms960, ms1280, ms1920, ms2560, ms3840, ms5120 }

TimerPoll ::=                       ENUMERATED {
                                        tp10, tp20, tp30, tp40, tp50,
                                        tp60, tp70, tp80, tp90, tp100,
                                        tp110, tp120, tp130, tp140, tp150,
```

```
                                    tp160, tp170, tp180, tp190, tp200,
                                    tp210, tp220, tp230, tp240, tp250,
                                    tp260, tp270, tp280, tp290, tp300,
                                    tp310, tp320, tp330, tp340, tp350,
                                    tp360, tp370, tp380, tp390, tp400,
                                    tp410, tp420, tp430, tp440, tp450,
                                    tp460, tp470, tp480, tp490, tp500,
                                    tp510, tp520, tp530, tp540, tp550,
                                    tp600, tp650, tp700, tp750, tp800,
                                    tp850, tp900, tp950, tp1000 }

TimerPollPeriodic ::=               ENUMERATED {
                                    tper100, tper200, tper300, tper400,
                                    tper500, tper750, tper1000, tper2000 }

TimerPollProhibit ::=               ENUMERATED {
                                    tpp10, tpp20, tpp30, tpp40, tpp50,
                                    tpp60, tpp70, tpp80, tpp90, tpp100,
                                    tpp110, tpp120, tpp130, tpp140, tpp150,
                                    tpp160, tpp170, tpp180, tpp190, tpp200,
                                    tpp210, tpp220, tpp230, tpp240, tpp250,
                                    tpp260, tpp270, tpp280, tpp290, tpp300,
                                    tpp310, tpp320, tpp330, tpp340, tpp350,
                                    tpp360, tpp370, tpp380, tpp390, tpp400,
                                    tpp410, tpp420, tpp430, tpp440, tpp450,
                                    tpp460, tpp470, tpp480, tpp490, tpp500,
                                    tpp510, tpp520, tpp530, tpp540, tpp550,
                                    tpp600, tpp650, tpp700, tpp750, tpp800,
                                    tpp850, tpp900, tpp950, tpp1000 }

TimerRST ::=                        ENUMERATED {
                                    tr50, tr100, tr150, tr200, tr250, tr300,
                                    tr350, tr400, tr450, tr500, tr550,
                                    tr600, tr700, tr800, tr900, tr1000 }

TimerStatusPeriodic ::=             ENUMERATED {
                                    tsp100, tsp200, tsp300, tsp400, tsp500,
                                    tsp750, tsp1000, tsp2000 }

TimerStatusProhibit ::=             ENUMERATED {
                                    tsp10,tsp20,tsp30,tsp40,tsp50,
                                    tsp60,tsp70,tsp80,tsp90,tsp100,
                                    tsp110,tsp120,tsp130,tsp140,tsp150,
                                    tsp160,tsp170,tsp180,tsp190,tsp200,
                                    tsp210,tsp220,tsp230,tsp240,tsp250,
                                    tsp260,tsp270,tsp280,tsp290,tsp300,
                                    tsp310,tsp320,tsp330,tsp340,tsp350,
                                    tsp360,tsp370,tsp380,tsp390,tsp400,
                                    tsp410,tsp420,tsp430,tsp440,tsp450,
                                    tsp460,tsp470,tsp480,tsp490,tsp500,
                                    tsp510,tsp520,tsp530,tsp540,tsp550,
                                    tsp600,tsp650,tsp700,tsp750,tsp800,
                                    tsp850,tsp900,tsp950,tsp1000 }

TransmissionRLC-Discard ::=         CHOICE {
    timerBasedExplicit                  ExplicitDiscard,
    timerBasedNoExplicit                NoExplicitDiscard,
    maxDAT-Retransmissions              MaxDAT-Retransmissions,
    noDiscard                           MaxDAT
}

TransmissionWindowSize ::=          ENUMERATED {
                                    tw1, tw8, tw16, tw32, tw64, tw128, tw256,
                                    tw512, tw768, tw1024, tw1536, tw2047,
                                    tw2560, tw3072, tw3584, tw4095 }

UL-AM-RLC-Mode ::=                  SEQUENCE {
    transmissionRLC-Discard             TransmissionRLC-Discard,
    transmissionWindowSize              TransmissionWindowSize,
    timerRST                            TimerRST,
    max-RST                             MaxRST,
    pollingInfo                         PollingInfo                         OPTIONAL
}

UL-CounterSynchronisationInfo ::=       SEQUENCE {
    rB-WithPDCP-InfoList                    RB-WithPDCP-InfoList    OPTIONAL,
    startList                               STARTList
}
```

```
UL-LogicalChannelMapping ::=        SEQUENCE {
    -- TABULAR: UL-TransportChannelType contains TransportChannelIdentity as well.
    ul-TransportChannelType             UL-TransportChannelType,
    logicalChannelIdentity              LogicalChannelIdentity              OPTIONAL,
    rlc-SizeList                        CHOICE {
        allSizes                            NULL,
        configured                          NULL,
        explicitList                        RLC-SizeExplicitList
    },
    mac-LogicalChannelPriority          MAC-LogicalChannelPriority
}

UL-LogicalChannelMapping-r6 ::=     SEQUENCE {
    ul-TrCH-Type                        CHOICE {
        dch-rach-usch                       SEQUENCE {
            -- TABULAR: UL-TransportChannelType contains TransportChannelIdentity as well.
            ul-TransportChannelType             UL-TransportChannelType,
            logicalChannelIdentity              LogicalChannelIdentity              OPTIONAL,
            rlc-SizeList                        CHOICE {
                allSizes                            NULL,
                configured                          NULL,
                explicitList                        RLC-SizeExplicitList
            }
        },
        e-dch                               SEQUENCE {
            logicalChannelIdentity              LogicalChannelIdentity,
            e-DCH-MAC-d-FlowIdentity            E-DCH-MAC-d-FlowIdentity,
            ddi                                 DDI,
            rlc-PDU-SizeList                    RLC-PDU-SizeList,
            includeInSchedulingInfo             BOOLEAN
        }
    },
    mac-LogicalChannelPriority          MAC-LogicalChannelPriority
}

UL-LogicalChannelMappingList ::=    SEQUENCE {
    -- rlc-LogicalChannelMappingIndicator shall be set to TRUE in this version
    -- of the specification
    rlc-LogicalChannelMappingIndicator  BOOLEAN,
    ul-LogicalChannelMapping            SEQUENCE (SIZE (maxLoCHperRLC)) OF
                                        UL-LogicalChannelMapping
}

UL-LogicalChannelMappingList-r6 ::= SEQUENCE {
    -- rlc-LogicalChannelMappingIndicator shall be set to TRUE in this version
    -- of the specification
    rlc-LogicalChannelMappingIndicator  BOOLEAN,
    ul-LogicalChannelMapping            SEQUENCE (SIZE (maxLoCHperRLC)) OF
                                            UL-LogicalChannelMapping-r6
}

UL-LogicalChannelMappings ::=       CHOICE {
    oneLogicalChannel                   UL-LogicalChannelMapping,
    twoLogicalChannels                  UL-LogicalChannelMappingList
}

UL-LogicalChannelMappings-r6 ::=    CHOICE {
    oneLogicalChannel                   UL-LogicalChannelMapping-r6,
    twoLogicalChannels                  UL-LogicalChannelMappingList-r6
}

UL-RFC3095-r4 ::=                   SEQUENCE {
    cid-InclusionInfo                   CID-InclusionInfo-r4,
    max-CID                             INTEGER (1..16383)                  DEFAULT 15,
    rohcPacketSizeList                  ROHC-PacketSizeList-r4
}

UL-RLC-Mode ::=                     CHOICE {
    ul-AM-RLC-Mode                      UL-AM-RLC-Mode,
    ul-UM-RLC-Mode                      UL-UM-RLC-Mode,
    ul-TM-RLC-Mode                      UL-TM-RLC-Mode,
    spare                               NULL
}

UL-TM-RLC-Mode ::=                  SEQUENCE {
    transmissionRLC-Discard             TransmissionRLC-Discard             OPTIONAL,
    segmentationIndication              BOOLEAN
```

```
}

UL-UM-RLC-Mode ::=                  SEQUENCE {
    transmissionRLC-Discard             TransmissionRLC-Discard             OPTIONAL
}

UL-TransportChannelType ::=         CHOICE {
    dch                                 TransportChannelIdentity,
    rach                                NULL,
    -- dummy is not used in this version of the specification and
    -- if received the UE behaviour is not specified.
    dummy                               NULL,
    usch                                TransportChannelIdentity
}

UM-RLC-DuplAvoid-Reord-Info-r6 ::=  SEQUENCE {
    timer-DAR                           TimerDAR-r6,
    widowSize-DAR                       WindowSizeDAR-r6
}

UM-RLC-OutOSeqDelivery-Info-r6 ::=  SEQUENCE {
    timer-OSD                           TimerOSD-r6                         OPTIONAL,
    windowSize-OSD                      WindowSizeOSD-r6
}

WindowSizeDAR-r6 ::=                ENUMERATED {
                                        ws4, ws8, ws16, ws32, ws40, ws48,
                                        ws56, ws64 }

WindowSizeOSD-r6 ::=                ENUMERATED {
                                        ws8, ws16, ws32, ws40, ws48,
                                        ws56, ws64 }

-- **************************************************
--
--     TRANSPORT CHANNEL INFORMATION ELEMENTS (10.3.5)
--
-- **************************************************

AddOrReconfMAC-dFlow ::=            SEQUENCE {
    mac-hs-AddReconfQueue-List                  MAC-hs-AddReconfQueue-List  OPTIONAL,
    mac-hs-DelQueue-List                        MAC-hs-DelQueue-List    OPTIONAL
}

AllowedTFC-List ::=                 SEQUENCE (SIZE (1..maxTFC)) OF
                                        TFC-Value

AllowedTFI-List ::=                 SEQUENCE (SIZE (1..maxTF)) OF
                                        INTEGER (0..31)

BitModeRLC-SizeInfo ::=             CHOICE {
    sizeType1                           INTEGER (0..127),
    -- Actual value sizeType2 = (part1 * 8) + 128 + part2
    sizeType2                           SEQUENCE {
        part1                               INTEGER (0..15),
        part2                               INTEGER (1..7)                  OPTIONAL
    },
    -- Actual value sizeType3 = (part1 * 16) + 256 + part2
    sizeType3                           SEQUENCE {
        part1                               INTEGER (0..47),
        part2                               INTEGER (1..15)                 OPTIONAL
    },
    -- Actual value sizeType4 = (part1 * 64) + 1024 + part2
    sizeType4                           SEQUENCE {
        part1                               INTEGER (0..62),
        part2                               INTEGER (1..63)                 OPTIONAL
    }
}

-- Actual value BLER-QualityValue = IE value * 0.1
BLER-QualityValue ::=               INTEGER (-63..0)

ChannelCodingType ::=               CHOICE {
    -- noCoding is only used for TDD in this version of the specification,
    -- otherwise it should be ignored
    noCoding                            NULL,
    convolutional                       CodingRate,
    turbo                               NULL
```

```
}

CodingRate ::=                      ENUMERATED {
                                        half,
                                        third }

CommonDynamicTF-Info ::=            SEQUENCE {
    rlc-Size                            CHOICE {
        fdd                                 SEQUENCE {
            octetModeRLC-SizeInfoType2          OctetModeRLC-SizeInfoType2
        },
        tdd                                 SEQUENCE {
            commonTDD-Choice                    CHOICE {
                bitModeRLC-SizeInfo                 BitModeRLC-SizeInfo,
                octetModeRLC-SizeInfoType1          OctetModeRLC-SizeInfoType1
            }
        }
    },
    numberOfTbSizeList              SEQUENCE (SIZE (1..maxTF)) OF
                                            NumberOfTransportBlocks,
    logicalChannelList              LogicalChannelList
}

CommonDynamicTF-Info-DynamicTTI ::= SEQUENCE {
    commonTDD-Choice                    CHOICE {
        bitModeRLC-SizeInfo                 BitModeRLC-SizeInfo,
        octetModeRLC-SizeInfoType1          OctetModeRLC-SizeInfoType1
    },
    numberOfTbSizeAndTTIList            NumberOfTbSizeAndTTIList,
    logicalChannelList                  LogicalChannelList
}

CommonDynamicTF-InfoList ::=        SEQUENCE (SIZE (1..maxTF)) OF
                                        CommonDynamicTF-Info

CommonDynamicTF-InfoList-DynamicTTI ::= SEQUENCE (SIZE (1..maxTF)) OF
                                        CommonDynamicTF-Info-DynamicTTI

CommonTransChTFS ::=                SEQUENCE {
    tti                                 CHOICE {
        tti10                               CommonDynamicTF-InfoList,
        tti20                               CommonDynamicTF-InfoList,
        tti40                               CommonDynamicTF-InfoList,
        tti80                               CommonDynamicTF-InfoList,
        dynamic                             CommonDynamicTF-InfoList-DynamicTTI
    },
    semistaticTF-Information            SemistaticTF-Information
}

CommonTransChTFS-LCR ::=                SEQUENCE {
    tti                                 CHOICE {
        tti5                                CommonDynamicTF-InfoList,
        tti10                               CommonDynamicTF-InfoList,
        tti20                               CommonDynamicTF-InfoList,
        tti40                               CommonDynamicTF-InfoList,
        tti80                               CommonDynamicTF-InfoList,
        dynamic                             CommonDynamicTF-InfoList-DynamicTTI
    },
    semistaticTF-Information            SemistaticTF-Information
}

CPCH-SetID ::=                      INTEGER (1..maxCPCHsets)

CRC-Size ::=                        ENUMERATED {
                                        crc0, crc8, crc12, crc16, crc24 }

DedicatedDynamicTF-Info ::=         SEQUENCE {
    rlc-Size                            CHOICE {
        bitMode                             BitModeRLC-SizeInfo,
        octetModeType1                      OctetModeRLC-SizeInfoType1
    },
    numberOfTbSizeList              SEQUENCE (SIZE (1..maxTF)) OF
    NumberOfTransportBlocks,
    logicalChannelList              LogicalChannelList
}

DedicatedDynamicTF-Info-DynamicTTI ::= SEQUENCE {
    rlc-Size                            CHOICE {
```

```
        bitMode                             BitModeRLC-SizeInfo,
        octetModeType1                      OctetModeRLC-SizeInfoType1
    },
    numberOfTbSizeAndTTIList            NumberOfTbSizeAndTTIList,
    logicalChannelList              LogicalChannelList
}

DedicatedDynamicTF-InfoList ::=     SEQUENCE (SIZE (1..maxTF)) OF
                                        DedicatedDynamicTF-Info

DedicatedDynamicTF-InfoList-DynamicTTI ::= SEQUENCE (SIZE (1..maxTF)) OF
                                        DedicatedDynamicTF-Info-DynamicTTI

DedicatedTransChTFS ::=             SEQUENCE {
    tti                                 CHOICE {
        tti10                               DedicatedDynamicTF-InfoList,
        tti20                               DedicatedDynamicTF-InfoList,
        tti40                               DedicatedDynamicTF-InfoList,
        tti80                               DedicatedDynamicTF-InfoList,
        dynamic                             DedicatedDynamicTF-InfoList-DynamicTTI
    },
    semistaticTF-Information            SemistaticTF-Information
}

-- The maximum allowed size of DL-AddReconfTransChInfo2List sequence is 16
DL-AddReconfTransChInfo2List ::=    SEQUENCE (SIZE (1..maxTrCHpreconf)) OF
                                        DL-AddReconfTransChInformation2

-- The maximum allowed size of DL-AddReconfTransChInfoList sequence is 16
DL-AddReconfTransChInfoList ::=     SEQUENCE (SIZE (1..maxTrCHpreconf)) OF
                                        DL-AddReconfTransChInformation

-- The maximum allowed size of DL-AddReconfTransChInfoList-r4 sequence is 16
DL-AddReconfTransChInfoList-r4 ::=  SEQUENCE (SIZE (1..maxTrCHpreconf)) OF
                                        DL-AddReconfTransChInformation-r4

-- The maximum allowed size of DL-AddReconfTransChInfoList-r5 sequence is 16
DL-AddReconfTransChInfoList-r5 ::=  SEQUENCE (SIZE (1..maxTrCHpreconf)) OF
                                        DL-AddReconfTransChInformation-r5

-- ASN.1 for IE "Added or Reconfigured DL TrCH information"
-- in case of messages other than: Radio Bearer Release message and
-- Radio Bearer Reconfiguration message
DL-AddReconfTransChInformation ::=  SEQUENCE {
    dl-TransportChannelType             DL-TrCH-Type,
    dl-transportChannelIdentity         TransportChannelIdentity,
    tfs-SignallingMode                  CHOICE {
        explicit-config                     TransportFormatSet,
        sameAsULTrCH                        UL-TransportChannelIdentity
    },
    dch-QualityTarget                   QualityTarget                       OPTIONAL,
    -- dummy is not used in this version of the specification, it should
    -- not be sent and if received it should be ignored.
    dummy                               TM-SignallingInfo                   OPTIONAL
}

DL-AddReconfTransChInformation-r4 ::=   SEQUENCE {
    dl-TransportChannelType             DL-TrCH-Type,
    dl-transportChannelIdentity         TransportChannelIdentity,
    tfs-SignallingMode                  CHOICE {
        explicit-config                     TransportFormatSet,
        sameAsULTrCH                        UL-TransportChannelIdentity
    },
    dch-QualityTarget                   QualityTarget                       OPTIONAL
}

DL-AddReconfTransChInformation-r5 ::=   SEQUENCE {
    dl-TransportChannelType             DL-TrCH-TypeId1-r5,
    tfs-SignallingMode                  CHOICE {
        explicit-config                     TransportFormatSet,
        sameAsULTrCH                        UL-TransportChannelIdentity,
        hsdsch                              HSDSCH-Info
    },
    dch-QualityTarget                   QualityTarget                       OPTIONAL
}

-- ASN.1 for IE "Added or Reconfigured DL TrCH information"
-- in case of Radio Bearer Release message and
```

```
-- Radio Bearer Reconfiguration message
DL-AddReconfTransChInformation2 ::= SEQUENCE {
    dl-TransportChannelType             DL-TrCH-Type,
    transportChannelIdentity            TransportChannelIdentity,
    tfs-SignallingMode                  CHOICE {
        explicit-config                     TransportFormatSet,
        sameAsULTrCH                        UL-TransportChannelIdentity
    },
    qualityTarget                       QualityTarget                       OPTIONAL
}

DL-CommonTransChInfo ::=            SEQUENCE {
    sccpch-TFCS                         TFCS                                OPTIONAL,
    -- modeSpecificInfo should be optional. A new version of this IE should be defined
    -- to be used in later versions of messages using this IE
    modeSpecificInfo                    CHOICE {
        fdd                                 SEQUENCE {
            dl-Parameters                       CHOICE {
                dl-DCH-TFCS                         TFCS,
                sameAsUL                            NULL
            }                                                               OPTIONAL
        },
        tdd                                 SEQUENCE {
            individualDL-CCTrCH-InfoList        IndividualDL-CCTrCH-InfoList
                                                                            OPTIONAL
        }
    }
}

DL-CommonTransChInfo-r4 ::=         SEQUENCE {
    sccpch-TFCS                         TFCS                                OPTIONAL,
    modeSpecificInfo                    CHOICE {
        fdd                                 SEQUENCE {
            dl-Parameters                       CHOICE {
                dl-DCH-TFCS                         SEQUENCE {
                    tfcs                                TFCS                OPTIONAL
                },
                sameAsUL                            NULL
            }                                                               OPTIONAL
        },
        tdd                                 SEQUENCE {
            individualDL-CCTrCH-InfoList        IndividualDL-CCTrCH-InfoList
                                                                            OPTIONAL
        }
    }   OPTIONAL
}

DL-DeletedTransChInfoList ::=       SEQUENCE (SIZE (1..maxTrCH)) OF
                                        DL-TransportChannelIdentity

DL-DeletedTransChInfoList-r5 ::=    SEQUENCE (SIZE (1..maxTrCH)) OF
                                        DL-TransportChannelIdentity-r5

DL-TransportChannelIdentity ::=         SEQUENCE {
    dl-TransportChannelType             DL-TrCH-Type,
    dl-TransportChannelIdentity         TransportChannelIdentity
}

DL-TransportChannelIdentity-r5 ::=      SEQUENCE {
    dl-TransportChannelType             DL-TrCH-TypeId2-r5
}

-- The choice 'dsch' should not be used in FDD mode, and if received the UE behaviour is unspecified
DL-TrCH-Type ::=                    ENUMERATED {dch, dsch}

DL-TrCH-TypeId1-r5 ::=              CHOICE {
    dch                                 TransportChannelIdentity,
    -- The choice 'dsch' should not be used in FDD mode, and if received
    -- the UE behaviour is unspecified.
    dsch                                TransportChannelIdentity,
    hsdsch                              NULL
}

DL-TrCH-TypeId2-r5 ::=              CHOICE {
    dch                                 TransportChannelIdentity,
    -- The choice 'dsch' should not be used in FDD mode, and if received
    -- the UE behaviour is unspecified.
    dsch                                TransportChannelIdentity,
```

```
    hsdsch                              MAC-d-FlowIdentity
}

DRAC-ClassIdentity ::=              INTEGER (1..maxDRACclasses)

DRAC-StaticInformation ::=          SEQUENCE {
    transmissionTimeValidity            TransmissionTimeValidity,
    timeDurationBeforeRetry             TimeDurationBeforeRetry,
    drac-ClassIdentity                  DRAC-ClassIdentity
}

DRAC-StaticInformationList ::=      SEQUENCE (SIZE (1..maxTrCH)) OF
                                        DRAC-StaticInformation

E-DCH-AddReconf-MAC-d-Flow ::=      SEQUENCE {
    mac-d-FlowIdentity                  E-DCH-MAC-d-FlowIdentity,
    mac-d-FlowPowerOffset               E-DCH-MAC-d-FlowPowerOffset         OPTIONAL,
    mac-d-FlowMaxRetrans                E-DCH-MAC-d-FlowMaxRetrans          OPTIONAL,
    mac-d-FlowMultiplexingList          E-DCH-MAC-d-FlowMultiplexingList    OPTIONAL,
    transmissionGrantType               CHOICE {
        non-ScheduledTransGrantInfo         SEQUENCE {
            maxMAC-e-PDUContents                INTEGER (1..19982),
            ms2-NonSchedTransmGrantHARQAlloc    BIT STRING (SIZE (8))       OPTIONAL
        },
        scheduledTransmissionGrantInfo      NULL
    }   OPTIONAL
}

E-DCH-AddReconf-MAC-d-FlowList ::=  SEQUENCE (SIZE (1..maxE-DCHMACdFlow)) OF
                            E-DCH-AddReconf-MAC-d-Flow

E-DCH-MAC-d-FlowIdentity ::=        INTEGER (0..maxE-DCHMACdFlow-1)

E-DCH-MAC-d-FlowMaxRetrans ::=      INTEGER (0..15)

E-DCH-MAC-d-FlowMultiplexingList ::= BIT STRING (SIZE (maxE-DCHMACdFlow))

E-DCH-MAC-d-FlowPowerOffset ::=     INTEGER (0..6)

E-DCH-TTI ::=                       ENUMERATED { tti2, tti10 }

ExplicitTFCS-Configuration ::=      CHOICE {
    complete                            TFCS-ReconfAdd,
    addition                            TFCS-ReconfAdd,
    removal                             TFCS-RemovalList,
    replacement                         SEQUENCE {
        tfcsRemoval                         TFCS-RemovalList,
        tfcsAdd                             TFCS-ReconfAdd
    }
}

GainFactor ::=                      INTEGER (0..15)

GainFactorInformation ::=           CHOICE {
    signalledGainFactors                SignalledGainFactors,
    computedGainFactors                 ReferenceTFC-ID
}

HSDSCH-Info ::=                     SEQUENCE {
    harqInfo                            HARQ-Info               OPTIONAL,
    addOrReconfMAC-dFlow                AddOrReconfMAC-dFlow    OPTIONAL
}

HARQ-Info ::=                       SEQUENCE {
    numberOfProcesses                   INTEGER (1..8),
    memoryPartitioning                  CHOICE {
        implicit                            NULL,
        explicit                            SEQUENCE (SIZE (1..maxHProcesses)) OF
                                                HARQMemorySize
    }
}

HARQMemorySize ::=                  ENUMERATED {
                                        hms800, hms1600, hms2400, hms3200, hms4000,
                                        hms4800, hms5600, hms6400, hms7200, hms8000,
                                        hms8800, hms9600, hms10400, hms11200, hms12000,
                                        hms12800, hms13600, hms14400, hms15200, hms16000,
                                        hms17600, hms19200, hms20800, hms22400, hms24000,
```

```
                                        hms25600, hms27200, hms28800, hms30400, hms32000,
                                        hms36000, hms40000, hms44000, hms48000, hms52000,
                                        hms56000, hms60000, hms64000, hms68000, hms72000,
                                        hms76000, hms80000, hms88000, hms96000, hms104000,
                                        hms112000, hms120000, hms128000, hms136000, hms144000,
                                        hms152000, hms160000, hms176000, hms192000, hms208000,
                                        hms224000, hms240000, hms256000, hms272000, hms288000,
                                        hms304000 }

IndividualDL-CCTrCH-Info ::=        SEQUENCE {
    dl-TFCS-Identity                    TFCS-Identity,
    tfcs-SignallingMode                 CHOICE {
        explicit-config                     TFCS,
        sameAsUL                            TFCS-Identity
    }
}

IndividualDL-CCTrCH-InfoList ::=    SEQUENCE (SIZE (1..maxCCTrCH)) OF
                                        IndividualDL-CCTrCH-Info

IndividualUL-CCTrCH-Info ::=        SEQUENCE {
    ul-TFCS-Identity                    TFCS-Identity,
    ul-TFCS                             TFCS ,
    tfc-Subset                          TFC-Subset
}

IndividualUL-CCTrCH-InfoList ::=    SEQUENCE (SIZE (1..maxCCTrCH)) OF
                                        IndividualUL-CCTrCH-Info

LogicalChannelByRB ::=              SEQUENCE {
    rb-Identity                         RB-Identity,
    logChOfRb                           INTEGER (0..1)                      OPTIONAL
}

LogicalChannelList ::=              CHOICE {
        allSizes                            NULL,
        configured                          NULL,
        explicitList                        SEQUENCE (SIZE (1..15)) OF
                                                LogicalChannelByRB
}

MAC-d-FlowIdentityDCHandHSDSCH ::=  SEQUENCE {
    dch-transport-ch-id             TransportChannelIdentity,
    hsdsch-mac-d-flow-id            MAC-d-FlowIdentity
}

MAC-d-FlowIdentity ::=              INTEGER (0..7)

MAC-d-PDU-SizeInfo-List ::=         SEQUENCE (SIZE(1.. maxMAC-d-PDUsizes)) OF
                                        MAC-d-PDUsizeInfo

--MAC-d-Pdu sizes need to be defined
MAC-d-PDUsizeInfo ::=               SEQUENCE{
    mac-d-PDU-Size                      INTEGER (1..5000),
    mac-d-PDU-Index                     INTEGER(0..7)
}

MAC-hs-AddReconfQueue-List ::=          SEQUENCE (SIZE(1..maxQueueIDs)) OF
                                        MAC-hs-AddReconfQueue

MAC-hs-AddReconfQueue ::=           SEQUENCE {
    mac-hsQueueId                       INTEGER(0..7),
    mac-dFlowId                         MAC-d-FlowIdentity,
    reorderingReleaseTimer              T1-ReleaseTimer,
    mac-hsWindowSize                    MAC-hs-WindowSize,
    mac-d-PDU-SizeInfo-List             MAC-d-PDU-SizeInfo-List             OPTIONAL
}

MAC-hs-DelQueue-List ::=                SEQUENCE (SIZE(1..maxQueueIDs)) OF
                                        MAC-hs-DelQueue

MAC-hs-DelQueue ::=                 SEQUENCE {
    mac-hsQueueId                       INTEGER(0..7)
}

MAC-hs-WindowSize ::=               ENUMERATED {
                                        mws4, mws6, mws8, mws12, mws16, mws24, mws32 }
```

```
NumberOfTbSizeAndTTIList ::=        SEQUENCE (SIZE (1..maxTF)) OF SEQUENCE {
        numberOfTransportBlocks             NumberOfTransportBlocks,
        transmissionTimeInterval            TransmissionTimeInterval
}

MessType ::=                        ENUMERATED {
                                        transportFormatCombinationControl }

Non-allowedTFC-List ::=             SEQUENCE (SIZE (1..maxTFC)) OF
                                        TFC-Value

NumberOfTransportBlocks ::=         CHOICE {
    zero                                NULL,
    one                                 NULL,
    small                               INTEGER (2..17),
    large                               INTEGER (18..512)
}

OctetModeRLC-SizeInfoType1 ::=      CHOICE {
    -- Actual size = (8 * sizeType1) + 16
    sizeType1                           INTEGER (0..31),
    sizeType2                           SEQUENCE {
        -- Actual size = (32 * part1) + 272 + (part2 * 8)
        part1                               INTEGER (0..23),
        part2                               INTEGER (1..3)                  OPTIONAL
    },
    sizeType3                           SEQUENCE {
        -- Actual size = (64 * part1) + 1040 + (part2 * 8)
        part1                               INTEGER (0..61),
        part2                               INTEGER (1..7)                  OPTIONAL
    }
}

OctetModeRLC-SizeInfoType2 ::=      CHOICE {
    -- Actual size = (sizeType1 * 8) + 48
    sizeType1                           INTEGER (0..31),
    -- Actual size = (sizeType2 * 16) + 312
    sizeType2                           INTEGER (0..63),
    -- Actual size = (sizeType3 *64) + 1384
    sizeType3                           INTEGER (0..56)
}

PowerOffsetInfoShort ::=            SEQUENCE {
    referenceTFC                        TFC-Value,
    modeSpecificInfo                    CHOICE {
        fdd                                 SEQUENCE {
            gainFactorBetaC                     GainFactor
        },
        tdd                                 NULL
    },
    gainFactorBetaD                     GainFactor
}

PowerOffsetInformation ::=          SEQUENCE {
    gainFactorInformation               GainFactorInformation,
    -- PowerOffsetPp-m is always absent in TDD
    powerOffsetPp-m                     PowerOffsetPp-m                 OPTIONAL
}

PowerOffsetPp-m ::=                 INTEGER (-5..10)

PreDefTransChConfiguration ::=      SEQUENCE {
    ul-CommonTransChInfo                UL-CommonTransChInfo,
    ul-AddReconfTrChInfoList            UL-AddReconfTransChInfoList,
    dl-CommonTransChInfo                DL-CommonTransChInfo,
    dl-TrChInfoList                     DL-AddReconfTransChInfoList
}

QualityTarget ::=                   SEQUENCE {
    bler-QualityValue                   BLER-QualityValue
}

RateMatchingAttribute ::=           INTEGER (1..hiRM)


ReferenceTFC-ID ::=                 INTEGER (0..3)

RestrictedTrChInfo ::=              SEQUENCE {
```

```
    ul-TransportChannelType             UL-TrCH-Type,
    restrictedTrChIdentity              TransportChannelIdentity,
    allowedTFI-List                     AllowedTFI-List                     OPTIONAL
}

RestrictedTrChInfoList ::=          SEQUENCE (SIZE (1..maxTrCH)) OF
                                        RestrictedTrChInfo

SemistaticTF-Information ::=        SEQUENCE {
    -- TABULAR: Transmission time interval has been included in the IE CommonTransChTFS.
    channelCodingType                   ChannelCodingType,
    rateMatchingAttribute               RateMatchingAttribute,
    crc-Size                            CRC-Size
}

SignalledGainFactors ::=            SEQUENCE {
    modeSpecificInfo                    CHOICE {
        fdd                                 SEQUENCE {
            gainFactorBetaC                     GainFactor
        },
        tdd                                 NULL
    },
    gainFactorBetaD                     GainFactor,
    referenceTFC-ID                     ReferenceTFC-ID                     OPTIONAL
}

SplitTFCI-Signalling ::=            SEQUENCE {
    splitType                           SplitType                       OPTIONAL,
    tfci-Field2-Length                  INTEGER (1..10)                 OPTIONAL,
    tfci-Field1-Information             ExplicitTFCS-Configuration      OPTIONAL,
    tfci-Field2-Information             TFCI-Field2-Information         OPTIONAL
}

SplitType ::=                       ENUMERATED {
                                        hardSplit, logicalSplit }

T1-ReleaseTimer ::=                 ENUMERATED {
                                        rt10, rt20, rt30, rt40, rt50,
                                        rt60, rt70, rt80, rt90, rt100,
                                        rt120, rt140, rt160, rt200, rt300,
                                        rt400 }

TFC-Subset ::=                      CHOICE {
    minimumAllowedTFC-Number            TFC-Value,
    allowedTFC-List                     AllowedTFC-List,
    non-allowedTFC-List                 Non-allowedTFC-List,
    restrictedTrChInfoList              RestrictedTrChInfoList,
    fullTFCS                            NULL
}

TFC-SubsetList ::=                  SEQUENCE (SIZE (1.. maxTFCsub)) OF SEQUENCE {
    modeSpecificInfo                    CHOICE {
        fdd                                 NULL,
        tdd                                 SEQUENCE {
            tfcs-ID                             TFCS-Identity               OPTIONAL
        }
    },
    tfc-Subset                          TFC-Subset
}

TFC-Value ::=                       INTEGER (0..1023)

TFCI-Field2-Information ::=         CHOICE {
    tfci-Range                          TFCI-RangeList,
    explicit-config                     ExplicitTFCS-Configuration
}

TFCI-Range ::=                      SEQUENCE {
    maxTFCIField2Value                  INTEGER (1..1023),
    tfcs-InfoForDSCH                    TFCS-InfoForDSCH
}

TFCI-RangeList ::=                  SEQUENCE (SIZE (1..maxPDSCH-TFCIgroups)) OF
                                        TFCI-Range

TFCS ::=                            CHOICE {
    normalTFCI-Signalling               ExplicitTFCS-Configuration,
    -- dummy is not used in this version of specification, it should
```

```
    -- not be sent and if received it should be ignored.
    dummy                               SplitTFCI-Signalling
}

TFCS-Identity ::=                   SEQUENCE {
    tfcs-ID                             TFCS-IdentityPlain                  DEFAULT 1,
    sharedChannelIndicator              BOOLEAN
}

TFCS-IdentityPlain ::=              INTEGER (1..8)

TFCS-InfoForDSCH ::=                CHOICE {
    ctfc2bit                            INTEGER (0..3),
    ctfc4bit                            INTEGER (0..15),
    ctfc6bit                            INTEGER (0..63),
    ctfc8bit                            INTEGER (0..255),
    ctfc12bit                           INTEGER (0..4095),
    ctfc16bit                           INTEGER (0..65535),
    ctfc24bit                           INTEGER (0..16777215)
}

TFCS-ReconfAdd ::=                  SEQUENCE{
    ctfcSize                            CHOICE{
        ctfc2Bit                            SEQUENCE (SIZE (1..maxTFC)) OF SEQUENCE {
            ctfc2                               INTEGER (0..3),
            powerOffsetInformation              PowerOffsetInformation          OPTIONAL
        },
        ctfc4Bit                            SEQUENCE (SIZE (1..maxTFC)) OF SEQUENCE {
            ctfc4                               INTEGER (0..15),
            powerOffsetInformation              PowerOffsetInformation          OPTIONAL
        },
        ctfc6Bit                            SEQUENCE (SIZE (1..maxTFC)) OF SEQUENCE {
            ctfc6                               INTEGER (0..63),
            powerOffsetInformation              PowerOffsetInformation          OPTIONAL
        },
        ctfc8Bit                            SEQUENCE (SIZE (1..maxTFC)) OF SEQUENCE {
            ctfc8                               INTEGER (0..255),
            powerOffsetInformation              PowerOffsetInformation          OPTIONAL
        },
        ctfc12Bit                           SEQUENCE (SIZE(1..maxTFC)) OF SEQUENCE {
            ctfc12                              INTEGER (0..4095),
            powerOffsetInformation              PowerOffsetInformation          OPTIONAL
        },
        ctfc16Bit                           SEQUENCE (SIZE (1..maxTFC)) OF SEQUENCE {
            ctfc16                              INTEGER(0..65535),
            powerOffsetInformation              PowerOffsetInformation          OPTIONAL
        },
        ctfc24Bit                           SEQUENCE (SIZE (1..maxTFC)) OF SEQUENCE {
            ctfc24                              INTEGER(0..16777215),
            powerOffsetInformation              PowerOffsetInformation          OPTIONAL
        }
    }
}

TFCS-Removal ::=                    SEQUENCE {
    tfci                                INTEGER (0..1023)
}

TFCS-RemovalList ::=                SEQUENCE (SIZE (1..maxTFC)) OF
                                        TFCS-Removal

TimeDurationBeforeRetry ::=         INTEGER (1..256)

TM-SignallingInfo ::=               SEQUENCE {
    messType                            MessType,
    tm-SignallingMode                   CHOICE {
        mode1                               NULL,
        mode2                               SEQUENCE {
            -- in ul-controlledTrChList, TrCH-Type is always DCH
            ul-controlledTrChList               UL-ControlledTrChList
        }
    }
}

TransmissionTimeInterval ::=        ENUMERATED {
                                        tti10, tti20, tti40, tti80 }

TransmissionTimeValidity ::=        INTEGER (1..256)
```

```
TransportChannelIdentity ::=        INTEGER (1..32)

TransportChannelIdentityDCHandDSCH ::=  SEQUENCE {
    dch-transport-ch-id             TransportChannelIdentity,
    dsch-transport-ch-id            TransportChannelIdentity
}


TransportFormatSet ::=              CHOICE {
    dedicatedTransChTFS                 DedicatedTransChTFS,
    commonTransChTFS                    CommonTransChTFS
}

TransportFormatSet-LCR ::=              CHOICE {
    dedicatedTransChTFS                 DedicatedTransChTFS,
    commonTransChTFS-LCR                CommonTransChTFS-LCR
}

-- The maximum allowed size of UL-AddReconfTransChInfoList sequence is 16
UL-AddReconfTransChInfoList ::=     SEQUENCE (SIZE (1..maxTrCHpreconf)) OF
                                        UL-AddReconfTransChInformation

-- The maximum allowed size of UL-AddReconfTransChInfoList-r6 sequence is 32
UL-AddReconfTransChInfoList-r6 ::=  SEQUENCE (SIZE (1..maxTrCH)) OF
                                        UL-AddReconfTransChInformation-r6

UL-AddReconfTransChInformation ::= SEQUENCE {
    ul-TransportChannelType             UL-TrCH-Type,
    transportChannelIdentity            TransportChannelIdentity,
    transportFormatSet                  TransportFormatSet
}

UL-AddReconfTransChInformation-r6 ::= CHOICE {
    dch-usch                            SEQUENCE {
        ul-TransportChannelType             UL-TrCH-Type,
        transportChannelIdentity            TransportChannelIdentity,
        transportFormatSet                  TransportFormatSet
    },
    e-dch                               SEQUENCE {
        tti                                 E-DCH-TTI,
        harq-Info                           ENUMERATED { rv0, rvtable },
        addReconf-MAC-d-FlowList            E-DCH-AddReconf-MAC-d-FlowList  OPTIONAL
    }
}

UL-CommonTransChInfo ::=            SEQUENCE {
    -- TABULAR: tfc-subset is applicable to FDD only, TDD specifies tfc-subset in individual
    -- CCTrCH Info.
    tfc-Subset                          TFC-Subset                          OPTIONAL,
    prach-TFCS                          TFCS                                OPTIONAL,
    modeSpecificInfo                    CHOICE {
        fdd                                 SEQUENCE {
            ul-TFCS                             TFCS
        },
        tdd                                 SEQUENCE {

            individualUL-CCTrCH-InfoList        IndividualUL-CCTrCH-InfoList
                                                                            OPTIONAL
        }
    }                                                                       OPTIONAL
}

UL-CommonTransChInfo-r4 ::=         SEQUENCE {
    -- TABULAR: tfc-subset is applicable to FDD only, TDD specifies tfc-subset in individual
    -- CCTrCH Info.
    tfc-Subset                          TFC-Subset                          OPTIONAL,
    prach-TFCS                          TFCS                                OPTIONAL,
    modeSpecificInfo                    CHOICE {
        fdd                                 SEQUENCE {
            ul-TFCS                             TFCS
        },
        tdd                                 SEQUENCE {
            individualUL-CCTrCH-InfoList        IndividualUL-CCTrCH-InfoList        OPTIONAL
        }
    }                                                                       OPTIONAL,
    tfc-SubsetList                      TFC-SubsetList                      OPTIONAL
}
```

```
-- In UL-ControlledTrChList, TrCH-Type is always DCH
UL-ControlledTrChList ::=           SEQUENCE (SIZE (1..maxTrCH)) OF
                                        TransportChannelIdentity

UL-DeletedTransChInfoList ::=       SEQUENCE (SIZE (1..maxTrCH)) OF
                                        UL-TransportChannelIdentity

UL-DeletedTransChInfoList-r6 ::=    SEQUENCE (SIZE (1..maxTrCH)) OF
                                        UL-TransportChannelIdentity-r6

UL-TransportChannelIdentity ::=     SEQUENCE {
    ul-TransportChannelType             UL-TrCH-Type,
    ul-TransportChannelIdentity         TransportChannelIdentity
}

UL-TransportChannelIdentity-r6 ::=  CHOICE {
    dch-usch                            SEQUENCE {
        ul-TransportChannelType             UL-TrCH-Type,
        ul-TransportChannelIdentity         TransportChannelIdentity
    },
    e-dch                               E-DCH-MAC-d-FlowIdentity
}

UL-TrCH-Type ::=                    ENUMERATED {dch, usch}

USCH-TransportChannelsInfo ::=      SEQUENCE (SIZE (1..maxTrCH)) OF
                                        SEQUENCE {
    usch-TransportChannelIdentity           TransportChannelIdentity,
    usch-TFS                                TransportFormatSet
}
-- **************************************************
--
--     PHYSICAL CHANNEL INFORMATION ELEMENTS (10.3.6)
--
-- **************************************************

ACK-NACK-repetitionFactor ::=       INTEGER(1..4)

AC-To-ASC-Mapping ::=               INTEGER (0..7)

AC-To-ASC-MappingTable ::=          SEQUENCE (SIZE (maxASCmap)) OF
                                        AC-To-ASC-Mapping

AccessServiceClass-FDD ::=          SEQUENCE {
    availableSignatureStartIndex        INTEGER (0..15),
    availableSignatureEndIndex          INTEGER (0..15),

    assignedSubChannelNumber            BIT STRING {
                                            b3(0),
                                            b2(1),
                                            b1(2),
                                            b0(3)
                                            }    (SIZE(4))
}

AccessServiceClass-TDD ::=          SEQUENCE {
    channelisationCodeIndices           BIT STRING  {
                                            chCodeIndex7(0),
                                            chCodeIndex6(1),
                                            chCodeIndex5(2),
                                            chCodeIndex4(3),
                                            chCodeIndex3(4),
                                            chCodeIndex2(5),
                                            chCodeIndex1(6),
                                            chCodeIndex0(7)
                                            } (SIZE(8))             OPTIONAL,
    subchannelSize                      CHOICE {
        size1                               NULL,
        size2                               SEQUENCE {
            -- subch0 means bitstring '01' in the tabular, subch1 means bitsring '10'
            subchannels                         ENUMERATED  { subch0, subch1 }  OPTIONAL
        },
        size4                               SEQUENCE {
            subchannels                         BIT STRING  {
                                                    subCh3(0),
                                                    subCh2(1),
                                                    subCh1(2),
```

```
                                                subCh0(3)
                                                } (SIZE(4))     OPTIONAL
        },
        size8                                SEQUENCE {
            subchannels                          BIT STRING  {
                                                     subCh7(0),
                                                     subCh6(1),
                                                     subCh5(2),
                                                     subCh4(3),
                                                     subCh3(4),
                                                     subCh2(5),
                                                     subCh1(6),
                                                     subCh0(7)
                                                     } (SIZE(8))     OPTIONAL
        }
    }
}

AccessServiceClass-TDD-r7 ::=           SEQUENCE {
    channelisationCodeIndices           BIT STRING  {
                                            chCodeIndex15(0),
                                            chCodeIndex14(1),
                                            chCodeIndex13(2),
                                            chCodeIndex12(3),
                                            chCodeIndex11(4),
                                            chCodeIndex10(5),
                                            chCodeIndex9(6),
                                            chCodeIndex8(7),
                                            chCodeIndex7(8),
                                            chCodeIndex6(9),
                                            chCodeIndex5(10),
                                            chCodeIndex4(11),
                                            chCodeIndex3(12),
                                            chCodeIndex2(13),
                                            chCodeIndex1(14),
                                            chCodeIndex0(15)
                                            } (SIZE(16))                OPTIONAL,
    subchannelSize                      CHOICE {
        size1                               NULL,
        size2                               SEQUENCE {
            -- subch0 means bitstring '01' in the tabular, subch1 means bitsring '10'
            subchannels                         ENUMERATED  { subch0, subch1 }  OPTIONAL
        },
        size4                               SEQUENCE {
            subchannels                         BIT STRING  {
                                                    subCh3(0),
                                                    subCh2(1),
                                                    subCh1(2),
                                                    subCh0(3)
                                                    } (SIZE(4))     OPTIONAL
        },
        size8                               SEQUENCE {
            subchannels                         BIT STRING  {
                                                    subCh7(0),
                                                    subCh6(1),
                                                    subCh5(2),
                                                    subCh4(3),
                                                    subCh3(4),
                                                    subCh2(5),
                                                    subCh1(6),
                                                    subCh0(7)
                                                    } (SIZE(8))     OPTIONAL
        },
        size16                              SEQUENCE {
            subchannels                         BIT STRING  {
                                                    subCh15(0),
                                                    subCh14(1),
                                                    subCh13(2),
                                                    subCh12(3),
                                                    subCh11(4),
                                                    subCh10(5),
                                                    subCh9(6),
                                                    subCh8(7),
                                                    subCh7(8),
                                                    subCh6(9),
                                                    subCh5(10),
                                                    subCh4(11),
                                                    subCh3(12),
```

```
                                                subCh2(13),
                                                subCh1(14),
                                                subCh0(15)
                                                } (SIZE(16))        OPTIONAL
        }
    }
}

AccessServiceClass-TDD-LCR-r4 ::=   SEQUENCE {
    availableSYNC-UlCodesIndics         BIT STRING {
                                            sulCodeIndex7(0),
                                            sulCodeIndex6(1),
                                            sulCodeIndex5(2),
                                            sulCodeIndex4(3),
                                            sulCodeIndex3(4),
                                            sulCodeIndex2(5),
                                            sulCodeIndex1(6),
                                            sulCodeIndex0(7)
                                            } (SIZE(8))              OPTIONAL,
    subchannelSize                      CHOICE {
        size1                               NULL,
        size2                               SEQUENCE {
            -- subch0 means bitstring '01' in the tabular, subch1 means bitsring '10'.
            subchannels                         ENUMERATED  { subch0, subch1 }  OPTIONAL
        },
        size4                               SEQUENCE {
            subchannels                         BIT STRING  {
                                                    subCh3(0),
                                                    subCh2(1),
                                                    subCh1(2),
                                                    subCh0(3)
                                                    } (SIZE(4))         OPTIONAL
        },
        size8                               SEQUENCE {
            subchannels                         BIT STRING  {
                                                    subCh7(0),
                                                    subCh6(1),
                                                    subCh5(2),
                                                    subCh4(3),
                                                    subCh3(4),
                                                    subCh2(5),
                                                    subCh1(6),
                                                    subCh0(7)
                                                    } (SIZE(8))         OPTIONAL
        }
    }

}

AdditionalPRACH-TF-and-TFCS-CCCH-IEs ::= SEQUENCE {
    powerOffsetInformation              PowerOffsetInformation,
    dynamicTFInformationCCCH            DynamicTFInformationCCCH
}

AdditionalPRACH-TF-and-TFCS-CCCH ::=    SEQUENCE {
    additionalPRACH-TF-and-TFCS-CCCH-IEs    AdditionalPRACH-TF-and-TFCS-CCCH-IEs    OPTIONAL
}

-- The order is the same as in the PRACH-SystemInformationList
AdditionalPRACH-TF-and-TFCS-CCCH-List ::=   SEQUENCE (SIZE (1..maxPRACH)) OF
                                        AdditionalPRACH-TF-and-TFCS-CCCH

AICH-Info ::=                       SEQUENCE {
    channelisationCode256               ChannelisationCode256,
    sttd-Indicator                      BOOLEAN,
    aich-TransmissionTiming             AICH-TransmissionTiming
}

AICH-PowerOffset ::=                INTEGER (-22..5)

AICH-TransmissionTiming ::=         ENUMERATED {
                                        e0, e1 }

AllocationPeriodInfo ::=            SEQUENCE {
    allocationActivationTime            INTEGER (0..255),
    allocationDuration                  INTEGER (1..256)
}
```

```
-- Actual value Alpha = IE value * 0.125
Alpha ::=                           INTEGER (0..8)

AP-AICH-ChannelisationCode ::=      INTEGER (0..255)

AP-PreambleScramblingCode ::=       INTEGER (0..79)

AP-Signature ::=                    INTEGER (0..15)

AP-Signature-VCAM ::=               SEQUENCE {
    ap-Signature                        AP-Signature,
    availableAP-SubchannelList          AvailableAP-SubchannelList OPTIONAL
}

AP-Subchannel ::=                   INTEGER (0..11)

ASCSetting-FDD ::=                      SEQUENCE {
    -- TABULAR: accessServiceClass-FDD is MD in tabular description
    -- Default value is previous ASC
    -- If this is the first ASC, the default value is all available signature and sub-channels
    accessServiceClass-FDD                  AccessServiceClass-FDD  OPTIONAL
}

ASCSetting-TDD ::=                      SEQUENCE {
    -- TABULAR: accessServiceClass-TDD is MD in tabular description
    -- Default value is previous ASC
    -- If this is the first ASC, the default value is all available channelisation codes and
    -- all available sub-channels with subchannelSize=size1.
    accessServiceClass-TDD                  AccessServiceClass-TDD  OPTIONAL
}

ASCSetting-TDD-r7 ::=                       SEQUENCE {
    -- TABULAR: accessServiceClass-TDD is MD in tabular description
    -- Default value is previous ASC
    -- If this is the first ASC, the default value is all available channelisation codes and
    -- all available sub-channels with subchannelSize=size1.
    accessServiceClass-TDD                      AccessServiceClass-TDD-r7   OPTIONAL
}

ASCSetting-TDD-LCR-r4 ::=                       SEQUENCE {
    -- TABULAR: accessServiceClass-TDD-LCR is MD in tabular description
    -- Default value is previous ASC
    -- If this is the first ASC, the default value is all available SYNC_UL codes and
    -- all available sub-channels with subchannelSize=size1.
    accessServiceClass-TDD-LCR                  AccessServiceClass-TDD-LCR-r4   OPTIONAL
}

AvailableAP-Signature-VCAMList ::=  SEQUENCE (SIZE (1..maxPCPCH-APsig)) OF
                                        AP-Signature-VCAM

AvailableAP-SignatureList ::=       SEQUENCE (SIZE (1..maxPCPCH-APsig)) OF
                                        AP-Signature

AvailableAP-SubchannelList ::=      SEQUENCE (SIZE (1..maxPCPCH-APsubCh)) OF
                                        AP-Subchannel

AvailableMinimumSF-ListVCAM ::=     SEQUENCE (SIZE (1..maxPCPCH-SF)) OF
                                        AvailableMinimumSF-VCAM

AvailableMinimumSF-VCAM ::=         SEQUENCE {
    minimumSpreadingFactor              MinimumSpreadingFactor,
    nf-Max                              NF-Max,
    maxAvailablePCPCH-Number            MaxAvailablePCPCH-Number,
    availableAP-Signature-VCAMList      AvailableAP-Signature-VCAMList
}

AvailableSignatures ::=         BIT STRING {
                                    signature15(0),
                                    signature14(1),
                                    signature13(2),
                                    signature12(3),
                                    signature11(4),
                                    signature10(5),
                                    signature9(6),
                                    signature8(7),
                                    signature7(8),
                                    signature6(9),
                                    signature5(10),
```

```
                                    signature4(11),
                                    signature3(12),
                                    signature2(13),
                                    signature1(14),
                                    signature0(15)
                                    }    (SIZE(16))

AvailableSubChannelNumbers ::=      BIT STRING {
                                        subCh11(0),
                                        subCh10(1),
                                        subCh9(2),
                                        subCh8(3),
                                        subCh7(4),
                                        subCh6(5),
                                        subCh5(6),
                                        subCh4(7),
                                        subCh3(8),
                                        subCh2(9),
                                        subCh1(10),
                                        subCh0(11)
                                        }    (SIZE(12))

BEACON-PL-Est ::=                   ENUMERATED { true }

BurstType ::=                       ENUMERATED {
                                        type1, type2 }

-- Actual value Bler-Target = IE value * 0.05
Bler-Target ::=                     INTEGER (-63..0)

CCTrCH-PowerControlInfo ::=         SEQUENCE {
    tfcs-Identity                       TFCS-Identity                       OPTIONAL,
    ul-DPCH-PowerControlInfo            UL-DPCH-PowerControlInfo
}

CCTrCH-PowerControlInfo-r4 ::=      SEQUENCE {
    tfcs-Identity                       TFCS-Identity                       OPTIONAL,
    ul-DPCH-PowerControlInfo            UL-DPCH-PowerControlInfo-r4
}

CCTrCH-PowerControlInfo-r5 ::=      SEQUENCE {
    tfcs-Identity                       TFCS-Identity                       OPTIONAL,
    ul-DPCH-PowerControlInfo            UL-DPCH-PowerControlInfo-r5
}

CCTrCH-PowerControlInfo-r7 ::=      SEQUENCE {
    tfcs-Identity                       TFCS-Identity                       OPTIONAL,
    ul-DPCH-PowerControlInfo            UL-DPCH-PowerControlInfo-r7
}

CD-AccessSlotSubchannel ::=         INTEGER (0..11)

CD-AccessSlotSubchannelList ::=     SEQUENCE (SIZE (1..maxPCPCH-CDsubCh)) OF
                                        CD-AccessSlotSubchannel

CD-CA-ICH-ChannelisationCode ::=    INTEGER (0..255)

CD-PreambleScramblingCode ::=       INTEGER (0..79)

CD-SignatureCode ::=                INTEGER (0..15)

CD-SignatureCodeList ::=            SEQUENCE (SIZE (1..maxPCPCH-CDsig)) OF
                                        CD-SignatureCode

CellAndChannelIdentity ::=          SEQUENCE {
    -- burstType may be set to either value and should be ignored by the receiver for 1.28 Mcps TDD.
    burstType                           BurstType,
    midambleShift                       MidambleShiftLong,
    timeslot                            TimeslotNumber,
    cellParametersID                    CellParametersID
    }

CellParametersID ::=                INTEGER (0..127)

Cfntargetsfnframeoffset ::=             INTEGER(0..255)

ChannelAssignmentActive ::=         CHOICE {
    notActive                           NULL,
```

```
    isActive                            AvailableMinimumSF-ListVCAM
}

ChannelisationCode256 ::=           INTEGER (0..255)

ChannelReqParamsForUCSM ::=         SEQUENCE {
    availableAP-SignatureList           AvailableAP-SignatureList,
    availableAP-SubchannelList          AvailableAP-SubchannelList          OPTIONAL
}

ClosedLoopTimingAdjMode ::=         ENUMERATED {
                                        slot1, slot2 }

CodeNumberDSCH ::=                  INTEGER (0..255)

CodeRange ::=                       SEQUENCE {
    pdsch-CodeMapList                   PDSCH-CodeMapList
}

CodeWordSet ::=                     ENUMERATED {
                                        longCWS,
                                        mediumCWS,
                                        shortCWS,
                                        ssdtOff }

CommonTimeslotInfo ::=              SEQUENCE {
    -- TABULAR: secondInterleavingMode is MD, but since it can be encoded in a single
    -- bit it is not defined as OPTIONAL.
    secondInterleavingMode              SecondInterleavingMode,
    tfci-Coding                         TFCI-Coding                         OPTIONAL,
    puncturingLimit                     PuncturingLimit,
    repetitionPeriodAndLength           RepetitionPeriodAndLength           OPTIONAL
}

CommonTimeslotInfoSCCPCH ::=        SEQUENCE {
    -- TABULAR: secondInterleavingMode is MD, but since it can be encoded in a single
    -- bit it is not defined as OPTIONAL.
    secondInterleavingMode              SecondInterleavingMode,
    tfci-Coding                         TFCI-Coding                         OPTIONAL,
    puncturingLimit                     PuncturingLimit,
    repetitionPeriodLengthAndOffset     RepetitionPeriodLengthAndOffset     OPTIONAL
}

ConstantValue ::=                   INTEGER (-35..-10)

ConstantValueTdd ::=                INTEGER (-35..10)

CPCH-PersistenceLevels ::=          SEQUENCE {
    cpch-SetID                          CPCH-SetID,
    dynamicPersistenceLevelTF-List      DynamicPersistenceLevelTF-List
}

CPCH-PersistenceLevelsList ::=      SEQUENCE (SIZE (1..maxCPCHsets)) OF
                                        CPCH-PersistenceLevels

CPCH-SetInfo ::=                    SEQUENCE {
    cpch-SetID                          CPCH-SetID,
    transportFormatSet                  TransportFormatSet,
    tfcs                                TFCS,
    ap-PreambleScramblingCode           AP-PreambleScramblingCode,
    ap-AICH-ChannelisationCode          AP-AICH-ChannelisationCode,
    cd-PreambleScramblingCode           CD-PreambleScramblingCode,
    cd-CA-ICH-ChannelisationCode        CD-CA-ICH-ChannelisationCode,
    cd-AccessSlotSubchannelList         CD-AccessSlotSubchannelList         OPTIONAL,
    cd-SignatureCodeList                CD-SignatureCodeList                OPTIONAL,
    deltaPp-m                           DeltaPp-m,
    ul-DPCCH-SlotFormat                 UL-DPCCH-SlotFormat,
    n-StartMessage                      N-StartMessage,
    n-EOT                               N-EOT,
    -- TABULAR: VCAM info has been nested inside ChannelAssignmentActive,
    -- which in turn is mandatory since it's only a binary choice.
    channelAssignmentActive             ChannelAssignmentActive,
    cpch-StatusIndicationMode           CPCH-StatusIndicationMode,
    pcpch-ChannelInfoList               PCPCH-ChannelInfoList
}

CPCH-SetInfoList ::=                SEQUENCE (SIZE (1..maxCPCHsets)) OF
                                        CPCH-SetInfo
```

```
CPCH-StatusIndicationMode ::=       ENUMERATED {
                                        pa-mode,
                                        pamsf-mode }

CQI-RepetitionFactor ::=            INTEGER(1..4)

CSICH-PowerOffset ::=               INTEGER (-10..5)

-- DefaultDPCH-OffsetValueFDD and DefaultDPCH-OffsetValueTDD corresponds to
-- IE "Default DPCH Offset Value" depending on the mode.
-- Actual value DefaultDPCH-OffsetValueFDD = IE value * 512
DefaultDPCH-OffsetValueFDD ::=      INTEGER (0..599)

DefaultDPCH-OffsetValueTDD ::=      INTEGER (0..7)

DeltaPp-m ::=                       INTEGER (-10..10)

DeltaCQI ::=                        INTEGER (0..8)

DeltaNACK ::=                       INTEGER (0..8)

DeltaACK ::=                        INTEGER (0..8)

-- Actual value DeltaSIR = IE value * 0.1
DeltaSIR ::=                        INTEGER (0..30)

DHS-Sync ::=                        INTEGER (-20..10)

DL-CCTrCh ::=                       SEQUENCE {
    tfcs-ID                             TFCS-IdentityPlain                  DEFAULT 1,
    timeInfo                            TimeInfo,
    commonTimeslotInfo                  CommonTimeslotInfo                  OPTIONAL,
    dl-CCTrCH-TimeslotsCodes            DownlinkTimeslotsCodes              OPTIONAL,
    ul-CCTrChTPCList                    UL-CCTrChTPCList                    OPTIONAL
}

DL-CCTrCh-r4 ::=                    SEQUENCE {
    tfcs-ID                             TFCS-IdentityPlain                  DEFAULT 1,
    timeInfo                            TimeInfo,
    commonTimeslotInfo                  CommonTimeslotInfo                  OPTIONAL,
    tddOption                           CHOICE {
        tdd384                              SEQUENCE {
            dl-CCTrCH-TimeslotsCodes            DownlinkTimeslotsCodes  OPTIONAL
        },
        tdd128                              SEQUENCE {
            dl-CCTrCH-TimeslotsCodes            DownlinkTimeslotsCodes-LCR-r4   OPTIONAL
        }
    },
    ul-CCTrChTPCList                    UL-CCTrChTPCList        OPTIONAL
}

DL-CCTrCh-r7 ::=                    SEQUENCE {
    tfcs-ID                             TFCS-IdentityPlain                  DEFAULT 1,
    timeInfo                            TimeInfo,
    commonTimeslotInfo                  CommonTimeslotInfo                  OPTIONAL,
    tddOption                           CHOICE {
        tdd384                              SEQUENCE {
            dl-CCTrCH-TimeslotsCodes            DownlinkTimeslotsCodes  OPTIONAL
        },
        tdd768                              SEQUENCE {
            dl-CCTrCH-TimeslotsCodes            DownlinkTimeslotsCodes-VHCR     OPTIONAL
        },
        tdd128                              SEQUENCE {
            dl-CCTrCH-TimeslotsCodes            DownlinkTimeslotsCodes-LCR-r4   OPTIONAL
        }
    },
    ul-CCTrChTPCList                    UL-CCTrChTPCList        OPTIONAL
}

DL-CCTrChList ::=                   SEQUENCE (SIZE (1..maxCCTrCH)) OF
                                        DL-CCTrCh

DL-CCTrChList-r7 ::=                SEQUENCE (SIZE (1..maxCCTrCH)) OF
                                        DL-CCTrCh-r7

DL-CCTrChList-r4 ::=                SEQUENCE (SIZE (1..maxCCTrCH)) OF
                                        DL-CCTrCh-r4
```

```
DL-CCTrChListToRemove ::=           SEQUENCE (SIZE (1..maxCCTrCH)) OF
                                        TFCS-IdentityPlain

DL-CCTrChTPCList ::=                SEQUENCE (SIZE (0..maxCCTrCH)) OF
                                            TFCS-Identity

DL-ChannelisationCode ::=           SEQUENCE {
    secondaryScramblingCode             SecondaryScramblingCode             OPTIONAL,
    sf-AndCodeNumber                    SF512-AndCodeNumber,
    scramblingCodeChange                ScramblingCodeChange                OPTIONAL
}

DL-ChannelisationCodeList ::=       SEQUENCE (SIZE (1..maxDPCH-DLchan)) OF
                                        DL-ChannelisationCode

DL-CommonInformation ::=            SEQUENCE {
    dl-DPCH-InfoCommon                  DL-DPCH-InfoCommon          OPTIONAL,
    modeSpecificInfo                    CHOICE {
        fdd                                 SEQUENCE {
            defaultDPCH-OffsetValue             DefaultDPCH-OffsetValueFDD  OPTIONAL,
            dpch-CompressedModeInfo             DPCH-CompressedModeInfo     OPTIONAL,
            tx-DiversityMode                    TX-DiversityMode            OPTIONAL,
            -- dummy is not used in this version of the specification, it should
            -- not be sent and if received it should be ignored.
            dummy                               SSDT-Information            OPTIONAL
        },
        tdd                                 SEQUENCE {
            defaultDPCH-OffsetValue             DefaultDPCH-OffsetValueTDD  OPTIONAL
        }
    }
}

DL-CommonInformation-r4 ::=         SEQUENCE {
    dl-DPCH-InfoCommon                  DL-DPCH-InfoCommon-r4       OPTIONAL,
    modeSpecificInfo                    CHOICE {
        fdd                                 SEQUENCE {
            defaultDPCH-OffsetValue             DefaultDPCH-OffsetValueFDD  OPTIONAL,
            dpch-CompressedModeInfo             DPCH-CompressedModeInfo     OPTIONAL,
            tx-DiversityMode                    TX-DiversityMode            OPTIONAL,
            -- dummy is not used in this version of the specification, it should
            -- not be sent and if received it should be ignored.
            dummy                               SSDT-Information-r4         OPTIONAL
        },
        tdd                                 SEQUENCE {
            tddOption                           CHOICE {
                tdd384                              NULL,
                tdd128                              SEQUENCE {
                    tstd-Indicator                      BOOLEAN
                }
            },
            defaultDPCH-OffsetValue             DefaultDPCH-OffsetValueTDD  OPTIONAL
        }
    }
}


DL-CommonInformation-r5 ::=         SEQUENCE {
    dl-DPCH-InfoCommon                  DL-DPCH-InfoCommon-r4           OPTIONAL,
    modeSpecificInfo                    CHOICE {
        fdd                                 SEQUENCE {
            defaultDPCH-OffsetValue             DefaultDPCH-OffsetValueFDD  OPTIONAL,
            dpch-CompressedModeInfo             DPCH-CompressedModeInfo     OPTIONAL,
            tx-DiversityMode                    TX-DiversityMode            OPTIONAL,
            -- dummy is not used in this version of the specification, it should
            -- not be sent and if received it should be ignored.
            dummy                               SSDT-Information-r4         OPTIONAL
        },
        tdd                                 SEQUENCE {
            tddOption                           CHOICE {
                tdd384                              NULL,
                tdd128                              SEQUENCE {
                    tstd-Indicator                      BOOLEAN
                }
            },
            defaultDPCH-OffsetValue             DefaultDPCH-OffsetValueTDD  OPTIONAL
        }
    },
```

```
    mac-hsResetIndicator                ENUMERATED { true }         OPTIONAL
}

DL-CommonInformation-r6 ::=         SEQUENCE {
    dl-dpchInfoCommon                   CHOICE {
        dl-DPCH-InfoCommon                  DL-DPCH-InfoCommon-r6,
        dl-FDPCH-InfoCommon                 DL-FDPCH-InfoCommon-r6
    }                                                                   OPTIONAL,
    modeSpecificInfo                    CHOICE {
        fdd                                 SEQUENCE {
            defaultDPCH-OffsetValue             DefaultDPCH-OffsetValueFDD  OPTIONAL,
            dpch-CompressedModeInfo             DPCH-CompressedModeInfo     OPTIONAL,
            tx-DiversityMode                    TX-DiversityMode            OPTIONAL
        },
        tdd                                 SEQUENCE {
            tddOption                           CHOICE {
                tdd384                              NULL,
                tdd128                              SEQUENCE {
                    tstd-Indicator                      BOOLEAN
                }
            },
            defaultDPCH-OffsetValue             DefaultDPCH-OffsetValueTDD  OPTIONAL
        }
    },
    mac-hsResetIndicator                ENUMERATED { true }         OPTIONAL,
    postVerificationPeriod              ENUMERATED { true }         OPTIONAL
}

DL-CommonInformation-r7 ::=         SEQUENCE {
    dl-dpchInfoCommon                   CHOICE {
        dl-DPCH-InfoCommon                  DL-DPCH-InfoCommon-r6,
        dl-FDPCH-InfoCommon                 DL-FDPCH-InfoCommon-r6
    }                                                                   OPTIONAL,
    modeSpecificInfo                    CHOICE {
        fdd                                 SEQUENCE {
            defaultDPCH-OffsetValue             DefaultDPCH-OffsetValueFDD  OPTIONAL,
            dpch-CompressedModeInfo             DPCH-CompressedModeInfo     OPTIONAL,
            tx-DiversityMode                    TX-DiversityMode            OPTIONAL
        },
        tdd                                 SEQUENCE {
            tddOption                           CHOICE {
                tdd384                              NULL,
                tdd768                              NULL,
                tdd128                              SEQUENCE {
                    tstd-Indicator                      BOOLEAN
                }
            },
            defaultDPCH-OffsetValue             DefaultDPCH-OffsetValueTDD  OPTIONAL
        }
    },
    mac-hsResetIndicator                ENUMERATED { true }         OPTIONAL,
    postVerificationPeriod              ENUMERATED { true }         OPTIONAL
}

DL-CommonInformationPost ::=        SEQUENCE {
    dl-DPCH-InfoCommon                  DL-DPCH-InfoCommonPost
}

DL-CommonInformationPredef ::=      SEQUENCE {
    dl-DPCH-InfoCommon                  DL-DPCH-InfoCommonPredef    OPTIONAL
}

DL-CompressedModeMethod ::=         ENUMERATED {
        -- dummy is not used in this version of the specification, it should
        -- not be sent and if received it should be ignored.
                                        dummy, sf-2,
                                        higherLayerScheduling }

DL-DPCH-InfoCommon ::=              SEQUENCE {
    cfnHandling                         CHOICE {
        maintain                            NULL,
        initialise                          SEQUENCE {
            -- IE dummy is not used in this version of the specification
            -- The IE should not be sent and if received it should be ignored
            dummy                               Cfntargetsfnframeoffset             OPTIONAL
        }
    },
    modeSpecificInfo                    CHOICE {
```

```
        fdd                                 SEQUENCE {
            dl-DPCH-PowerControlInfo            DL-DPCH-PowerControlInfo            OPTIONAL,
            powerOffsetPilot-pdpdch             PowerOffsetPilot-pdpdch,
            dl-rate-matching-restriction        Dl-rate-matching-restriction        OPTIONAL,
            -- TABULAR: The number of pilot bits is nested inside the spreading factor.
            spreadingFactorAndPilot             SF512-AndPilot,
            positionFixedOrFlexible             PositionFixedOrFlexible,
            tfci-Existence                      BOOLEAN
        },
        tdd                                 SEQUENCE {
            dl-DPCH-PowerControlInfo            DL-DPCH-PowerControlInfo            OPTIONAL
        }
    }
}

DL-DPCH-InfoCommon-r4 ::=           SEQUENCE {
    cfnHandling                         CHOICE {
        maintain                            NULL,
        initialise                          SEQUENCE {
            -- IE dummy is not used in this version of the specification
            -- The IE should not be sent and if received it should be ignored
            dummy                               Cfntargetsfnframeoffset             OPTIONAL
        }
    },
    modeSpecificInfo                    CHOICE {
        fdd                                 SEQUENCE {
            dl-DPCH-PowerControlInfo            DL-DPCH-PowerControlInfo            OPTIONAL,
            powerOffsetPilot-pdpdch             PowerOffsetPilot-pdpdch,
            dl-rate-matching-restriction        Dl-rate-matching-restriction        OPTIONAL,
            -- TABULAR: The number of pilot bits is nested inside the spreading factor.
            spreadingFactorAndPilot             SF512-AndPilot,
            positionFixedOrFlexible             PositionFixedOrFlexible,
            tfci-Existence                      BOOLEAN
        },
        tdd                                 SEQUENCE {
            dl-DPCH-PowerControlInfo            DL-DPCH-PowerControlInfo            OPTIONAL
        }
    },
-- The IE mac-d-HFN-initial-value should be absent in the RRCConnectionSetup-r4-IEs or
-- RRCConnectionSetup-r5-IEs or HandoverToUTRANCommand-r4-IEs or HandoverToUTRANCommand-r5-IEs and
-- if the IE is included, the general error handling for conditional IEs applies.
    mac-d-HFN-initial-value             MAC-d-HFN-initial-value             OPTIONAL

}

DL-DPCH-InfoCommon-r6 ::=               SEQUENCE {
    cfnHandling                             CHOICE {
        maintain                                SEQUENCE {
            timingmaintainedsynchind                TimingMaintainedSynchInd            OPTIONAL
        },
        initialise                              NULL
    },
    modeSpecificInfo                        CHOICE {
        fdd                                     SEQUENCE {
            dl-DPCH-PowerControlInfo                DL-DPCH-PowerControlInfo            OPTIONAL,
            powerOffsetPilot-pdpdch                 PowerOffsetPilot-pdpdch,
            dl-rate-matching-restriction            Dl-rate-matching-restriction        OPTIONAL,
            -- TABULAR: The number of pilot bits is nested inside the spreading factor.
            spreadingFactorAndPilot                 SF512-AndPilot,
            positionFixedOrFlexible                 PositionFixedOrFlexible,
            tfci-Existence                          BOOLEAN
        },
        tdd                                     SEQUENCE {
            dl-DPCH-PowerControlInfo                DL-DPCH-PowerControlInfo            OPTIONAL
        }
    },
    -- The IE mac-d-HFN-initial-value should be absent in the RRCConnectionSetup and the
    -- HandoverToUTRANCommand messages. If the IE is included, the general error handling
    -- for conditional IEs applies.
    mac-d-HFN-initial-value             MAC-d-HFN-initial-value             OPTIONAL
}

DL-DPCH-InfoCommonPost ::=          SEQUENCE {
    dl-DPCH-PowerControlInfo            DL-DPCH-PowerControlInfo                OPTIONAL
}

DL-DPCH-InfoCommonPredef ::=        SEQUENCE {
    modeSpecificInfo                    CHOICE {
```

```
        fdd                                 SEQUENCE {
            -- TABULAR: The number of pilot bits is nested inside the spreading factor.
            spreadingFactorAndPilot             SF512-AndPilot,
            positionFixedOrFlexible             PositionFixedOrFlexible,
            tfci-Existence                      BOOLEAN
        },
        tdd                                 SEQUENCE {
            commonTimeslotInfo                  CommonTimeslotInfo
        }
    }
}

DL-DPCH-InfoPerRL ::=               CHOICE {
    fdd                                 SEQUENCE {
        pCPICH-UsageForChannelEst           PCPICH-UsageForChannelEst,
        dpch-FrameOffset                    DPCH-FrameOffset,
        secondaryCPICH-Info                 SecondaryCPICH-Info             OPTIONAL,
        dl-ChannelisationCodeList           DL-ChannelisationCodeList,
        tpc-CombinationIndex                TPC-CombinationIndex,
        -- dummy is not used in this version of the specification, it should
        -- not be sent and if received it should be ignored.
        dummy                               SSDT-CellIdentity               OPTIONAL,
        closedLoopTimingAdjMode             ClosedLoopTimingAdjMode         OPTIONAL
    },
    tdd                                 SEQUENCE {
        dl-CCTrChListToEstablish            DL-CCTrChList                   OPTIONAL,
        dl-CCTrChListToRemove               DL-CCTrChListToRemove           OPTIONAL
    }
}

DL-DPCH-InfoPerRL-r4 ::=            CHOICE {
    fdd                                 SEQUENCE {
        pCPICH-UsageForChannelEst           PCPICH-UsageForChannelEst,
        dpch-FrameOffset                    DPCH-FrameOffset,
        secondaryCPICH-Info                 SecondaryCPICH-Info             OPTIONAL,
        dl-ChannelisationCodeList           DL-ChannelisationCodeList,
        tpc-CombinationIndex                TPC-CombinationIndex,
        -- dummy is not used in this version of the specification, it should
        -- not be sent and if received it should be ignored.
        dummy                               SSDT-CellIdentity               OPTIONAL,
        closedLoopTimingAdjMode             ClosedLoopTimingAdjMode         OPTIONAL
    },
    tdd                                 SEQUENCE {
        dl-CCTrChListToEstablish            DL-CCTrChList-r4                OPTIONAL,
        dl-CCTrChListToRemove               DL-CCTrChListToRemove           OPTIONAL
    }
}

DL-DPCH-InfoPerRL-r5 ::=            CHOICE {
    fdd                                 SEQUENCE {
        pCPICH-UsageForChannelEst           PCPICH-UsageForChannelEst,
        dpch-FrameOffset                    DPCH-FrameOffset,
        secondaryCPICH-Info                 SecondaryCPICH-Info             OPTIONAL,
        dl-ChannelisationCodeList           DL-ChannelisationCodeList,
        tpc-CombinationIndex                TPC-CombinationIndex,
        powerOffsetTPC-pdpdch               PowerOffsetTPC-pdpdch           OPTIONAL,
        -- dummy is not used in this version of the specification, it should
        -- not be sent and if received it should be ignored.
        dummy                               SSDT-CellIdentity               OPTIONAL,
        closedLoopTimingAdjMode             ClosedLoopTimingAdjMode         OPTIONAL
    },
    tdd                                 SEQUENCE {
        dl-CCTrChListToEstablish            DL-CCTrChList-r4                OPTIONAL,
        dl-CCTrChListToRemove               DL-CCTrChListToRemove           OPTIONAL
    }
}

DL-DPCH-InfoPerRL-r6 ::=            CHOICE {
    fdd                                 SEQUENCE {
        pCPICH-UsageForChannelEst           PCPICH-UsageForChannelEst,
        dpch-FrameOffset                    DPCH-FrameOffset,
        secondaryCPICH-Info                 SecondaryCPICH-Info             OPTIONAL,
        dl-ChannelisationCodeList           DL-ChannelisationCodeList,
        tpc-CombinationIndex                TPC-CombinationIndex,
        powerOffsetTPC-pdpdch               PowerOffsetTPC-pdpdch           OPTIONAL,
        closedLoopTimingAdjMode             ClosedLoopTimingAdjMode         OPTIONAL
    },
    tdd                                 SEQUENCE {
```

```
        dl-CCTrChListToEstablish            DL-CCTrChList-r4                OPTIONAL,
        dl-CCTrChListToRemove               DL-CCTrChListToRemove           OPTIONAL
    }
}

DL-DPCH-InfoPerRL-r7 ::=            CHOICE {
    fdd                                 SEQUENCE {
        pCPICH-UsageForChannelEst           PCPICH-UsageForChannelEst,
        dpch-FrameOffset                    DPCH-FrameOffset,
        secondaryCPICH-Info                 SecondaryCPICH-Info             OPTIONAL,
        dl-ChannelisationCodeList           DL-ChannelisationCodeList,
        tpc-CombinationIndex                TPC-CombinationIndex,
        powerOffsetTPC-pdpdch               PowerOffsetTPC-pdpdch           OPTIONAL,
        closedLoopTimingAdjMode             ClosedLoopTimingAdjMode         OPTIONAL
    },
    tdd                                 SEQUENCE {
        dl-CCTrChListToEstablish            DL-CCTrChList-r7                OPTIONAL,
        dl-CCTrChListToRemove               DL-CCTrChListToRemove           OPTIONAL
    }
}

DL-FDPCH-InfoPerRL-r6 ::=           SEQUENCE {
    pCPICH-UsageForChannelEst           PCPICH-UsageForChannelEst,
    fdpch-FrameOffset                   DPCH-FrameOffset,
    secondaryCPICH-Info                 SecondaryCPICH-Info             OPTIONAL,
    secondaryScramblingCode             SecondaryScramblingCode         OPTIONAL,
    dl-ChannelisationCode               INTEGER (0..255),
    tpc-CombinationIndex                TPC-CombinationIndex
}

DL-DPCH-InfoPerRL-PostFDD ::=                           SEQUENCE {
        pCPICH-UsageForChannelEst               PCPICH-UsageForChannelEst,
        dl-ChannelisationCode                   DL-ChannelisationCode,
        tpc-CombinationIndex                    TPC-CombinationIndex
}

DL-DPCH-InfoPerRL-PostTDD ::=               SEQUENCE {
    dl-DPCH-TimeslotsCodes                      DownlinkTimeslotsCodes
}

DL-DPCH-InfoPerRL-PostTDD-LCR-r4 ::=        SEQUENCE {
    dl-CCTrCH-TimeslotsCodes                    DownlinkTimeslotsCodes-LCR-r4
}

DL-DPCH-PowerControlInfo ::=            SEQUENCE {
    modeSpecificInfo                        CHOICE {
        fdd                                     SEQUENCE {
            dpc-Mode                                DPC-Mode
        },
        tdd                                     SEQUENCE {
            tpc-StepSizeTDD                         TPC-StepSizeTDD         OPTIONAL
        }
    }
}

DL-FDPCH-InfoCommon-r6 ::=          SEQUENCE {
    cfnHandling                         CHOICE {
        maintain                            SEQUENCE {
            timingmaintainedsynchind            TimingMaintainedSynchInd            OPTIONAL
        },
        initialise                          NULL
    },
    dl-FDPCH-PowerControlInfo           DL-DPCH-PowerControlInfo            OPTIONAL,
-- Actual value dl-FDPCH-TPCcommandErrorRate = IE value * 0.01
-- dl-FDPCH-TPCcommandErrorRate values 11..16 are spare and shall not be used in this version of
-- the protocol
    dl-FDPCH-TPCcommandErrorRate        INTEGER (1..16)     OPTIONAL
}

DL-FrameType ::=                    ENUMERATED {
                                        dl-FrameTypeA, dl-FrameTypeB }

DL-HSPDSCH-Information ::=          SEQUENCE {
    hs-scch-Info                    HS-SCCH-Info    OPTIONAL,
    measurement-feedback-Info       Measurement-Feedback-Info   OPTIONAL,
    modeSpecificInfo                CHOICE {
    tdd                             CHOICE{
            tdd384                          SEQUENCE {
```

```
                dl-HSPDSCH-TS-Configuration DL-HSPDSCH-TS-Configuration     OPTIONAL
            },
            tdd128                          SEQUENCE {
                hs-PDSCH-Midamble-Configuration-tdd128
                        HS-PDSCH-Midamble-Configuration-TDD128              OPTIONAL
            }
        },
        fdd                         NULL
    }
}

DL-HSPDSCH-Information-r6 ::=   SEQUENCE {
    hs-scch-Info                    HS-SCCH-Info-r6                         OPTIONAL,
    measurement-feedback-Info       Measurement-Feedback-Info               OPTIONAL,
    modeSpecificInfo                CHOICE {
        tdd                             CHOICE {
            tdd384                          SEQUENCE {
                dl-HSPDSCH-TS-Configuration     DL-HSPDSCH-TS-Configuration OPTIONAL
            },
            tdd128                          SEQUENCE {
                hs-PDSCH-Midamble-Configuration-tdd128
                        HS-PDSCH-Midamble-Configuration-TDD128              OPTIONAL
            }
        },
        fdd                         NULL
    }
}

DL-HSPDSCH-Information-r7 ::=   SEQUENCE {
    hs-scch-Info                    HS-SCCH-Info-r7                         OPTIONAL,
    measurement-feedback-Info       Measurement-Feedback-Info               OPTIONAL,
    modeSpecificInfo                CHOICE {
        tdd                             CHOICE {
            tdd384                          SEQUENCE {
                dl-HSPDSCH-TS-Configuration     DL-HSPDSCH-TS-Configuration OPTIONAL
            },
            tdd768                          SEQUENCE {
                dl-HSPDSCH-TS-Configuration     DL-HSPDSCH-TS-Configuration-VHCR    OPTIONAL
            },
            tdd128                          SEQUENCE {
                hs-PDSCH-Midamble-Configuration-tdd128
                        HS-PDSCH-Midamble-Configuration-TDD128                  OPTIONAL
            }
        },
        fdd                         NULL
    }
}

-- The IE 'DL-HSPDSCH-TS-Configuration' applies to tdd-384 REL-5 onward
DL-HSPDSCH-TS-Configuration ::=     SEQUENCE (SIZE (1..maxTS-1)) OF
                                    SEQUENCE {
    timeslot                            TimeslotNumber,
    midambleShiftAndBurstType           MidambleShiftAndBurstType-DL
}

-- The IE 'DL-HSPDSCH-TS-Configuration-VHCR' applies to tdd-768 REL-7 onward
DL-HSPDSCH-TS-Configuration-VHCR ::= SEQUENCE (SIZE (1..maxTS-1)) OF
                                    SEQUENCE {
    timeslot                            TimeslotNumber,
    midambleShiftAndBurstType           MidambleShiftAndBurstType-DL-VHCR
}

DL-InformationPerRL ::=             SEQUENCE {
    modeSpecificInfo                    CHOICE {
        fdd                                 SEQUENCE {
            primaryCPICH-Info                   PrimaryCPICH-Info,
            -- dummy1 and dummy 2 are not used in this version of specification, they should
            -- not be sent and if received they should be ignored.
            dummy1                              PDSCH-SHO-DCH-Info          OPTIONAL,
            dummy2                              PDSCH-CodeMapping           OPTIONAL
        },
        tdd                                 PrimaryCCPCH-Info
    },
    dl-DPCH-InfoPerRL                   DL-DPCH-InfoPerRL                   OPTIONAL,
    -- dummy is not used in this version of the specification, it should
    -- not be sent and if received it should be ignored.
    dummy                               SCCPCH-InfoForFACH                  OPTIONAL
}
```

```
DL-InformationPerRL-r4 ::=          SEQUENCE {
    modeSpecificInfo                    CHOICE {
        fdd                                 SEQUENCE {
            primaryCPICH-Info                   PrimaryCPICH-Info,
            -- dummy1 and dummy 2 are not used in this version of specification, they should
            -- not be sent and if received they should be ignored.
            dummy1                              PDSCH-SHO-DCH-Info          OPTIONAL,
            dummy2                              PDSCH-CodeMapping           OPTIONAL
        },
        tdd                                 PrimaryCCPCH-Info-r4
    },
    dl-DPCH-InfoPerRL                   DL-DPCH-InfoPerRL-r4                OPTIONAL,
    -- dummy is not used in this version of the specification, it should
    -- not be sent and if received it should be ignored.
    dummy                               SCCPCH-InfoForFACH-r4               OPTIONAL,
    cell-id                             CellIdentity                        OPTIONAL
}

DL-InformationPerRL-r5 ::=          SEQUENCE {
    modeSpecificInfo                    CHOICE {
        fdd                                 SEQUENCE {
            primaryCPICH-Info                   PrimaryCPICH-Info,
            -- dummy1 and dummy 2 are not used in this version of specification, they should
            -- not be sent and if received they should be ignored.
            dummy1                              PDSCH-SHO-DCH-Info          OPTIONAL,
            dummy2                              PDSCH-CodeMapping           OPTIONAL,
            servingHSDSCH-RL-indicator          BOOLEAN
        },
        tdd                                 PrimaryCCPCH-Info-r4
    },
    dl-DPCH-InfoPerRL                   DL-DPCH-InfoPerRL-r5                OPTIONAL,
    -- dummy is not used in this version of the specification, it should
    -- not be sent and if received it should be ignored.
    dummy                               SCCPCH-InfoForFACH-r4               OPTIONAL,
    cell-id                             CellIdentity                        OPTIONAL
}

DL-InformationPerRL-r5bis ::=       SEQUENCE {
    modeSpecificInfo                    CHOICE {
        fdd                                 SEQUENCE {
            primaryCPICH-Info                   PrimaryCPICH-Info,
            -- dummy1 and dummy 2 are not used in this version of specification, they should
            -- not be sent and if received they should be ignored.
            dummy1                              PDSCH-SHO-DCH-Info          OPTIONAL,
            dummy2                              PDSCH-CodeMapping           OPTIONAL
        },
        tdd                                 PrimaryCCPCH-Info-r4
    },
    dl-DPCH-InfoPerRL                   DL-DPCH-InfoPerRL-r5                OPTIONAL,
    -- dummy is not used in this version of the specification, it should
    -- not be sent and if received it should be ignored.
    dummy                               SCCPCH-InfoForFACH-r4               OPTIONAL,
    cell-id                             CellIdentity                        OPTIONAL
}

DL-InformationPerRL-r6 ::=          SEQUENCE {
    modeSpecificInfo                    CHOICE {
        fdd                                 SEQUENCE {
            primaryCPICH-Info                   PrimaryCPICH-Info,
            servingHSDSCH-RL-indicator          BOOLEAN,
            servingEDCH-RL-indicator            BOOLEAN
        },
        tdd                                 PrimaryCCPCH-Info-r4
    },
    dl-dpchInfo                         CHOICE {
        dl-DPCH-InfoPerRL                   DL-DPCH-InfoPerRL-r6,
        dl-FDPCH-InfoPerRL                  DL-FDPCH-InfoPerRL-r6
    }                                                                       OPTIONAL,
    e-AGCH-Information                  E-AGCH-Information                  OPTIONAL,
    e-HICH-Info                         CHOICE  {
        e-HICH-Information                  E-HICH-Information,
        releaseIndicator                    NULL
    }   OPTIONAL,
    e-RGCH-Info                         CHOICE  {
        e-RGCH-Information                  E-RGCH-Information,
        releaseIndicator                    NULL
    }   OPTIONAL,
```

```
    cell-id                             CellIdentity                        OPTIONAL
}

DL-InformationPerRL-r7 ::=          SEQUENCE {
    modeSpecificInfo                    CHOICE {
        fdd                                 SEQUENCE {
            primaryCPICH-Info                   PrimaryCPICH-Info,
            servingHSDSCH-RL-indicator          BOOLEAN,
            servingEDCH-RL-indicator            BOOLEAN
        },
        tdd                                 PrimaryCCPCH-Info-r7
    },
    dl-dpchInfo                         CHOICE {
        dl-DPCH-InfoPerRL                   DL-DPCH-InfoPerRL-r7,
        dl-FDPCH-InfoPerRL                  DL-FDPCH-InfoPerRL-r6
    }                                                                       OPTIONAL,
    e-AGCH-Information                  E-AGCH-Information                  OPTIONAL,
    e-HICH-Info                         CHOICE  {
        e-HICH-Information                  E-HICH-Information,
        releaseIndicator                    NULL
    }   OPTIONAL,
    e-RGCH-Info                         CHOICE  {
        e-RGCH-Information                  E-RGCH-Information,
        releaseIndicator                    NULL
    }   OPTIONAL,
    cell-id                             CellIdentity                        OPTIONAL
}

DL-InformationPerRL-List ::=        SEQUENCE (SIZE (1..maxRL)) OF
                                        DL-InformationPerRL

DL-InformationPerRL-List-r4 ::=     SEQUENCE (SIZE (1..maxRL)) OF
                                        DL-InformationPerRL-r4

DL-InformationPerRL-List-r5 ::=     SEQUENCE (SIZE (1..maxRL)) OF
                                        DL-InformationPerRL-r5

DL-InformationPerRL-List-r6 ::=     SEQUENCE (SIZE (1..maxRL)) OF
                                        DL-InformationPerRL-r6

DL-InformationPerRL-List-r5bis ::=      SEQUENCE (SIZE (1..maxRL)) OF
                                            DL-InformationPerRL-r5bis

DL-InformationPerRL-List-r7 ::=     SEQUENCE (SIZE (1..maxRL)) OF
                                        DL-InformationPerRL-r7

DL-InformationPerRL-ListPostFDD ::= SEQUENCE (SIZE (1..maxRL)) OF
                                        DL-InformationPerRL-PostFDD

DL-InformationPerRL-PostFDD ::=     SEQUENCE {
            primaryCPICH-Info                   PrimaryCPICH-Info,
    dl-DPCH-InfoPerRL                   DL-DPCH-InfoPerRL-PostFDD
}

DL-InformationPerRL-PostTDD ::=     SEQUENCE {
    primaryCCPCH-Info                   PrimaryCCPCH-InfoPost,
    dl-DPCH-InfoPerRL                   DL-DPCH-InfoPerRL-PostTDD
}

DL-InformationPerRL-PostTDD-LCR-r4 ::=  SEQUENCE {
    primaryCCPCH-Info                   PrimaryCCPCH-InfoPostTDD-LCR-r4,
    dl-DPCH-InfoPerRL                   DL-DPCH-InfoPerRL-PostTDD-LCR-r4
}

DL-PDSCH-Information ::=            SEQUENCE {
    -- dummy1 and dummy 2 are not used in this version of specification, it should
    -- not be sent and if received it should be ignored.
    dummy1                              PDSCH-SHO-DCH-Info                  OPTIONAL,
    dummy2                              PDSCH-CodeMapping                   OPTIONAL
}

Dl-rate-matching-restriction ::=    SEQUENCE {
    restrictedTrCH-InfoList             RestrictedTrCH-InfoList             OPTIONAL
}

DL-TPC-PowerOffsetPerRL ::=     SEQUENCE {
        powerOffsetTPC-pdpdch               PowerOffsetTPC-pdpdch           OPTIONAL
}
```

```
-- NOTE: The radio links in the following list have a one-to-one mapping with the
-- radio links in the message.
DL-TPC-PowerOffsetPerRL-List ::=    SEQUENCE (SIZE (1..maxRL)) OF
                                        DL-TPC-PowerOffsetPerRL

DL-TS-ChannelisationCode ::=        ENUMERATED {
                                        cc16-1, cc16-2, cc16-3, cc16-4,
                                        cc16-5, cc16-6, cc16-7, cc16-8,
                                        cc16-9, cc16-10, cc16-11, cc16-12,
                                        cc16-13, cc16-14, cc16-15, cc16-16 }

DL-TS-ChannelisationCode-VHCR ::=   ENUMERATED {
                                        cc32-1, cc32-2, cc32-3, cc32-4,
                                        cc132-5, cc32-6, cc32-7, cc32-8,
                                        cc32-9, cc32-10, cc32-11, cc32-12,
                                        cc32-13, cc32-14, cc32-15, cc32-16,
                                        cc32-17, cc32-18, cc32-19, cc32-20,
                                        cc32-21, cc32-22, cc32-23, cc32-24,
                                        cc32-25, cc32-26, cc32-27, cc32-28,
                                        cc32-29, cc32-30, cc32-31, cc32-32 }

DL-TS-ChannelisationCodesShort ::=  SEQUENCE {
    codesRepresentation                 CHOICE {
        consecutive                         SEQUENCE {
            firstChannelisationCode             DL-TS-ChannelisationCode,
            lastChannelisationCode              DL-TS-ChannelisationCode
        },
        bitmap                              BIT STRING {
                                                chCode16-SF16(0),
                                                chCode15-SF16(1),
                                                chCode14-SF16(2),
                                                chCode13-SF16(3),
                                                chCode12-SF16(4),
                                                chCode11-SF16(5),
                                                chCode10-SF16(6),
                                                chCode9-SF16(7),
                                                chCode8-SF16(8),
                                                chCode7-SF16(9),
                                                chCode6-SF16(10),
                                                chCode5-SF16(11),
                                                chCode4-SF16(12),
                                                chCode3-SF16(13),
                                                chCode2-SF16(14),
                                                chCode1-SF16(15)
                                                }   (SIZE (16))
    }
}

DL-TS-ChannelisationCodesShort-VHCR ::= SEQUENCE {
    codesRepresentation                 CHOICE {
        consecutive                         SEQUENCE {
            firstChannelisationCode             DL-TS-ChannelisationCode-VHCR,
            lastChannelisationCode              DL-TS-ChannelisationCode-VHCR
        },
        bitmap                              BIT STRING {
                                                chCode32-SF32(0),
                                                chCode31-SF32(1),
                                                chCode30-SF32(2),
                                                chCode29-SF32(3),
                                                chCode28-SF32(4),
                                                chCode27-SF32(5),
                                                chCode26-SF32(6),
                                                chCode25-SF32(7),
                                                chCode24-SF32(8),
                                                chCode23-SF32(9),
                                                chCode22-SF32(10),
                                                chCode21-SF32(11),
                                                chCode20-SF32(12),
                                                chCode19-SF32(13),
                                                chCode18-SF32(14),
                                                chCode17-SF32(15),
                                                chCode16-SF32(16),
                                                chCode15-SF32(17),
                                                chCode14-SF32(18),
                                                chCode13-SF32(19),
                                                chCode12-SF32(20),
                                                chCode11-SF32(21),
```

```
                                        chCode10-SF32(22),
                                        chCode9-SF32(23),
                                        chCode8-SF32(24),
                                        chCode7-SF32(25),
                                        chCode6-SF32(26),
                                        chCode5-SF32(27),
                                        chCode4-SF32(28),
                                        chCode3-SF32(29),
                                        chCode2-SF32(30),
                                        chCode1-SF32(31)
                                        }   (SIZE (32))
    }
}

DownlinkAdditionalTimeslots ::=     SEQUENCE {
    parameters                          CHOICE {
        sameAsLast                          SEQUENCE {
            timeslotNumber                      TimeslotNumber
        },
        newParameters                       SEQUENCE {
            individualTimeslotInfo              IndividualTimeslotInfo,
            dl-TS-ChannelisationCodesShort      DL-TS-ChannelisationCodesShort
        }
    }
}

DownlinkAdditionalTimeslots-VHCR ::= SEQUENCE {
    parameters                          CHOICE {
        sameAsLast                          SEQUENCE {
            timeslotNumber                      TimeslotNumber
        },
        newParameters                       SEQUENCE {
            individualTimeslotInfo              IndividualTimeslotInfo-VHCR,
            dl-TS-ChannelisationCodesShort      DL-TS-ChannelisationCodesShort-VHCR
        }
    }
}

DownlinkAdditionalTimeslots-LCR-r4 ::=  SEQUENCE {
    parameters                          CHOICE {
        sameAsLast                          SEQUENCE {
            timeslotNumber                      TimeslotNumber-LCR-r4
        },
        newParameters                       SEQUENCE {
            individualTimeslotInfo              IndividualTimeslotInfo-LCR-r4,
            dl-TS-ChannelisationCodesShort      DL-TS-ChannelisationCodesShort
        }
    }
}

DownlinkTimeslotsCodes ::=      SEQUENCE {
    firstIndividualTimeslotInfo         IndividualTimeslotInfo,
    dl-TS-ChannelisationCodesShort      DL-TS-ChannelisationCodesShort,
    moreTimeslots                       CHOICE {
        noMore                              NULL,
        additionalTimeslots                 CHOICE {
            consecutive                         INTEGER (1..maxTS-1),
            timeslotList                        SEQUENCE (SIZE (1..maxTS-1)) OF
                                                    DownlinkAdditionalTimeslots

        }
    }
}

DownlinkTimeslotsCodes-VHCR ::=     SEQUENCE {
    firstIndividualTimeslotInfo         IndividualTimeslotInfo-VHCR,
    dl-TS-ChannelisationCodesShort      DL-TS-ChannelisationCodesShort,
    moreTimeslots                       CHOICE {
        noMore                              NULL,
        additionalTimeslots                 CHOICE {
            consecutive                         INTEGER (1..maxTS-1),
            timeslotList                        SEQUENCE (SIZE (1..maxTS-1)) OF
                                                    DownlinkAdditionalTimeslots-VHCR

        }
    }
}

DownlinkTimeslotsCodes-LCR-r4 ::=   SEQUENCE {
    firstIndividualTimeslotInfo         IndividualTimeslotInfo-LCR-r4,
```

```
    dl-TS-ChannelisationCodesShort      DL-TS-ChannelisationCodesShort,
    moreTimeslots                       CHOICE {
        noMore                              NULL,
        additionalTimeslots                 CHOICE {
            consecutive                         INTEGER (1..maxTS-LCR-1),
            timeslotList                        SEQUENCE (SIZE (1..maxTS-LCR-1)) OF
                                                    DownlinkAdditionalTimeslots-LCR-r4
        }
    }
}

DPC-Mode ::=                        ENUMERATED {
                                        singleTPC,
                                        tpcTripletInSoft }

-- Actual value DPCCH-PowerOffset = IE value * 2
DPCCH-PowerOffset ::=               INTEGER (-82..-3)

-- Actual value DPCCH-PowerOffset2 = 2 + (IE value * 4)
DPCCH-PowerOffset2 ::=              INTEGER (-28..-13)

DPCH-CompressedModeInfo ::=         SEQUENCE {
    tgp-SequenceList                    TGP-SequenceList
}

DPCH-CompressedModeStatusInfo ::=   SEQUENCE {
    tgps-Reconfiguration-CFN            TGPS-Reconfiguration-CFN,
    tgp-SequenceShortList                   SEQUENCE (SIZE (1..maxTGPS)) OF
                                            TGP-SequenceShort
}

-- Actual value DPCH-FrameOffset = IE value * 256
DPCH-FrameOffset::=                 INTEGER (0..149)

DSCH-Mapping ::=                    SEQUENCE {
    maxTFCI-Field2Value                 MaxTFCI-Field2Value,
    spreadingFactor                     SF-PDSCH,
    codeNumber                          CodeNumberDSCH,
    multiCodeInfo                       MultiCodeInfo
}

DSCH-MappingList ::=                SEQUENCE (SIZE (1..maxPDSCH-TFCIgroups)) OF
                                        DSCH-Mapping

DSCH-RadioLinkIdentifier ::=        INTEGER (0..511)

DSCH-TransportChannelsInfo ::=      SEQUENCE (SIZE (1..maxTrCH)) OF
                                        SEQUENCE {
    dsch-transport-channel-identity         TransportChannelIdentity,
    dsch-TFS                                TransportFormatSet
}
DurationTimeInfo ::=                INTEGER (1..4096)

DynamicPersistenceLevel ::=         INTEGER (1..8)

DynamicPersistenceLevelList ::=     SEQUENCE (SIZE (1..maxPRACH)) OF
                                        DynamicPersistenceLevel

DynamicPersistenceLevelTF-List ::= SEQUENCE (SIZE (1..maxTF-CPCH)) OF
                                        DynamicPersistenceLevel

DynamicTFInformationCCCH ::=        SEQUENCE {
    octetModeRLC-SizeInfoType2          OctetModeRLC-SizeInfoType2
}

E-AGCH-ChannelisationCode ::=       INTEGER (0..255)

E-AGCH-Information ::=              SEQUENCE {
    e-AGCH-ChannelisationCode           E-AGCH-ChannelisationCode
}

E-DCH-MinimumSet-E-TFCI ::=         INTEGER (0..127)

E-DCH-ReconfigurationInfo ::=   SEQUENCE {
    e-DCH-RL-InfoNewServingCell         E-DCH-RL-InfoNewServingCell             OPTIONAL,
    e-DCH-RL-InfoOtherCellList          SEQUENCE (SIZE (1..maxEDCHRL)) OF
                                            E-DCH-RL-InfoOtherCell              OPTIONAL
}
```

```
E-DCH-RL-InfoNewServingCell ::=     SEQUENCE {
    primaryCPICH-Info                   PrimaryCPICH-Info,
    e-AGCH-Information                  E-AGCH-Information,
    servingGrant                        SEQUENCE {
        value                               INTEGER (0..38)                     OPTIONAL,
        primary-Secondary-GrantSelector     ENUMERATED { primary, secondary }
    }   OPTIONAL,
    e-DPCCH-DPCCH-PowerOffset           E-DPCCH-DPCCH-PowerOffset               OPTIONAL,
    reference-E-TFCIs                   E-DPDCH-Reference-E-TFCIList            OPTIONAL,
    powerOffsetForSchedInfo             INTEGER (0..6)                          OPTIONAL,
    threeIndexStepThreshold             INTEGER (0..37)                         OPTIONAL,
    twoIndexStepThreshold               INTEGER (0..37)                         OPTIONAL,
    e-HICH-Information                  E-HICH-Information      OPTIONAL,
    e-RGCH-Info                         CHOICE  {
        e-RGCH-Information                  E-RGCH-Information,
        releaseIndicator                    NULL
    }   OPTIONAL
}

E-DCH-RL-InfoOtherCell ::=          SEQUENCE {
    primaryCPICH-Info                   PrimaryCPICH-Info,
    e-HICH-Info                         CHOICE {
        e-HICH-Information                  E-HICH-Information,
        releaseIndicator                    NULL
    }   OPTIONAL,
    e-RGCH-Info                         CHOICE {
        e-RGCH-Information                  E-RGCH-Information,
        releaseIndicator                    NULL
    }   OPTIONAL
}

E-DPCCH-Info ::=                    SEQUENCE {
    e-DPCCH-DPCCH-PowerOffset           E-DPCCH-DPCCH-PowerOffset,
    happyBit-DelayCondition             HappyBit-DelayCondition
}

E-DPCCH-DPCCH-PowerOffset ::=       INTEGER (0..8)

E-DPDCH-Info ::=                    SEQUENCE {
    e-TFCI-TableIndex                   E-TFCI-TableIndex,
    e-DCH-MinimumSet-E-TFCI             E-DCH-MinimumSet-E-TFCI             OPTIONAL,
    reference-E-TFCIs                   E-DPDCH-Reference-E-TFCIList,
    maxChannelisationCodes              E-DPDCH-MaxChannelisationCodes,
    pl-NonMax                           E-DPDCH-PL-NonMax,
    schedulingInfoConfiguration         E-DPDCH-SchedulingInfoConfiguration,
    threeIndexStepThreshold             INTEGER (0..37)                     OPTIONAL,
    twoIndexStepThreshold               INTEGER (0..37)                     OPTIONAL
}

E-DPDCH-PeriodicyOfSchedInfo ::=    ENUMERATED {
                                        everyEDCHTTI, ms4, ms10, ms20, ms50, ms100, ms200, ms500,
                                        ms1000 }

-- The actual value of E-DPDCH-PL-NonMax is: IE value * 0.04
E-DPDCH-PL-NonMax ::=               INTEGER (11..25)

E-DPDCH-Reference-E-TFCI ::=        SEQUENCE {
    reference-E-TFCI                    INTEGER (0..127),
    reference-E-TFCI-PO                 INTEGER (0..29)
}

E-DPDCH-Reference-E-TFCIList ::=    SEQUENCE (SIZE (1..8)) OF E-DPDCH-Reference-E-TFCI

E-DPDCH-SchedulingInfoConfiguration ::= SEQUENCE {
    periodicityOfSchedInfo-NoGrant      E-DPDCH-PeriodicyOfSchedInfo        OPTIONAL,
    periodicityOfSchedInfo-Grant        E-DPDCH-PeriodicyOfSchedInfo        OPTIONAL,
    powerOffsetForSchedInfo             INTEGER (0..6)
}

E-DPDCH-SchedulingTransmConfiguration ::= SEQUENCE {
    ms2-SchedTransmGrantHARQAlloc       BIT STRING (SIZE (8))               OPTIONAL,
    servingGrant                        SEQUENCE {
        value                               INTEGER (0..38),
        primary-Secondary-GrantSelector     ENUMERATED { primary, secondary }
    }       OPTIONAL
}
```

```
E-DPDCH-MaxChannelisationCodes ::=  ENUMERATED {
                                        sf256, sf128, sf64, sf32, sf16, sf8, sf4, sf4x2, sf2x2,
sf4x2-and-sf2x2 }

E-HICH-ChannelisationCode ::=       INTEGER (0..127)

E-HICH-Information ::=              SEQUENCE {
    channelisationCode                  E-HICH-ChannelisationCode,
    signatureSequence                   E-HICH-RGCH-SignatureSequence
}

E-HICH-RGCH-SignatureSequence ::=   INTEGER (0..39)

E-RGCH-CombinationIndex ::=         INTEGER (0..5)

E-RGCH-Information ::=              SEQUENCE {
    signatureSequence                   E-HICH-RGCH-SignatureSequence,
    rg-CombinationIndex                 E-RGCH-CombinationIndex
}

E-TFCI-TableIndex ::=               INTEGER (0..1)

FACH-PCH-Information ::=            SEQUENCE {
    transportFormatSet                  TransportFormatSet,
    transportChannelIdentity            TransportChannelIdentity,
    ctch-Indicator                      BOOLEAN
}

FACH-PCH-InformationList ::=        SEQUENCE (SIZE (1..maxFACHPCH)) OF
                                        FACH-PCH-Information

Feedback-cycle ::=                  ENUMERATED {
                                        fc0, fc2, fc4, fc8, fc10, fc20, fc40, fc80, fc160}

FPACH-Info-r4 ::=                       SEQUENCE {
    timeslot                            TimeslotNumber-LCR-r4,
    channelisationCode                  TDD-FPACH-CCode16-r4,
    midambleShiftAndBurstType           MidambleShiftAndBurstType-LCR-r4,
    wi                                  Wi-LCR
}

FrequencyInfo ::=                   SEQUENCE {
    modeSpecificInfo                    CHOICE {
        fdd                                 FrequencyInfoFDD,
        tdd                                 FrequencyInfoTDD    }
}

FrequencyInfoFDD ::=                SEQUENCE {
    uarfcn-UL                           UARFCN              OPTIONAL,
    uarfcn-DL                           UARFCN
}

FrequencyInfoTDD ::=                SEQUENCE {
    uarfcn-Nt                           UARFCN
}

HappyBit-DelayCondition ::=         ENUMERATED {
                                        ms2, ms10, ms20, ms50, ms100, ms200, ms500, ms1000 }

HARQ-Preamble-Mode ::=              INTEGER (0..1)

HS-ChannelisationCode-LCR ::=       ENUMERATED {
                                        cc16-1, cc16-2, cc16-3, cc16-4,
                                        cc16-5, cc16-6, cc16-7, cc16-8,
                                        cc16-9, cc16-10, cc16-11, cc16-12,
                                        cc16-13, cc16-14, cc16-15, cc16-16 }

HS-PDSCH-Midamble-Configuration-TDD128 ::=  SEQUENCE {
    midambleAllocationMode              CHOICE{
        defaultMidamble                     NULL,
        commonMidamble                      NULL,
        ueSpecificMidamble                  INTEGER (0..15)
    },
    -- Actual value midambleConfiguration = IE value * 2
    midambleConfiguration               INTEGER (1..8)
}

HS-SCCH-Info ::=                    SEQUENCE {
```

```
    modeSpecificInfo                    CHOICE {
        fdd                                 SEQUENCE {
            hS-SCCHChannelisationCodeInfo       SEQUENCE (SIZE (1..maxHSSCCHs)) OF
                                                    HS-SCCH-Codes,
            dl-ScramblingCode                   SecondaryScramblingCode     OPTIONAL
        },
        tdd                                 CHOICE {
            tdd384                              SEQUENCE {
                nack-ack-power-offset              INTEGER (-7..8),
                hs-SICH-PowerControl-Info          HS-SICH-Power-Control-Info-TDD384,
                hS-SCCH-SetConfiguration           SEQUENCE (SIZE (1..maxHSSCCHs)) OF
                        HS-SCCH-TDD384
                },
            tdd128                              SEQUENCE (SIZE (1..maxHSSCCHs)) OF
                                                    HS-SCCH-TDD128
        }
    }
}

HS-SCCH-Info-r6 ::=                 SEQUENCE {
    modeSpecificInfo                    CHOICE {
        fdd                                 SEQUENCE {
            hS-SCCHChannelisationCodeInfo       SEQUENCE (SIZE (1..maxHSSCCHs)) OF
                                                    HS-SCCH-Codes,
            dl-ScramblingCode                   SecondaryScramblingCode         OPTIONAL
        },
        tdd                                 CHOICE {
            tdd384                              SEQUENCE {
                nack-ack-power-offset               INTEGER (-7..8),
                hs-SICH-PowerControl-Info           HS-SICH-Power-Control-Info-TDD384,
                dhs-sync                            DHS-Sync                    OPTIONAL,
                hS-SCCH-SetConfiguration            SEQUENCE (SIZE (1..maxHSSCCHs)) OF
                                                        HS-SCCH-TDD384
                },
            tdd128                              SEQUENCE (SIZE (1..maxHSSCCHs)) OF
                                                    HS-SCCH-TDD128
        }
    }
}

HS-SCCH-Info-r7 ::=                 SEQUENCE {
    modeSpecificInfo                    CHOICE {
        fdd                                 SEQUENCE {
            hS-SCCHChannelisationCodeInfo       SEQUENCE (SIZE (1..maxHSSCCHs)) OF
                                                    HS-SCCH-Codes,
            dl-ScramblingCode                   SecondaryScramblingCode         OPTIONAL
        },
        tdd                                 CHOICE {
            tdd384                              SEQUENCE {
                nack-ack-power-offset               INTEGER (-7..8),
                hs-SICH-PowerControl-Info           HS-SICH-Power-Control-Info-TDD384,
                dhs-sync                            DHS-Sync                    OPTIONAL,
                hS-SCCH-SetConfiguration            SEQUENCE (SIZE (1..maxHSSCCHs)) OF
                                                        HS-SCCH-TDD384
                },
            tdd768                              SEQUENCE {
                nack-ack-power-offset               INTEGER (-7..8),
                hs-SICH-PowerControl-Info           HS-SICH-Power-Control-Info-TDD768,
                dhs-sync                            DHS-Sync                    OPTIONAL,
                hS-SCCH-SetConfiguration            SEQUENCE (SIZE (1..maxHSSCCHs)) OF
                                                        HS-SCCH-TDD768
                },
            tdd128                              SEQUENCE (SIZE (1..maxHSSCCHs)) OF
                                                    HS-SCCH-TDD128
        }
    }
}

HS-SCCH-Codes ::=                   INTEGER (0..127)

HS-SCCH-TDD128 ::=              SEQUENCE {
    timeslotNumber                      TimeslotNumber-LCR-r4,
    firstChannelisationCode             HS-ChannelisationCode-LCR,
    secondChannelisationCode            HS-ChannelisationCode-LCR,
    midambleAllocationMode              CHOICE {
        defaultMidamble                     NULL,
        commonMidamble                      NULL,
        ueSpecificMidamble                  INTEGER(0..15)
```

```
    },
    -- Actual value midambleConfiguration = IE value * 2
    midambleConfiguration              INTEGER (1..8),
    bler-target                        Bler-Target,
    hs-sich-configuration              HS-SICH-Configuration-TDD128
}

HS-SICH-Configuration-TDD128 ::=    SEQUENCE {
    timeslotNumber                     TimeslotNumber-LCR-r4,
    channelisationCode                 HS-ChannelisationCode-LCR,
    midambleAllocationMode             CHOICE {
        defaultMidamble                    NULL,
        ueSpecificMidamble                 SEQUENCE {
            midambleShift                      MidambleShiftLong
        }
    },
    -- Actual value midambleConfiguration = IE value * 2
    midambleConfiguration              INTEGER (1..8),
    nack-ack-power-offset              INTEGER (-7..8),
    power-level-HSSICH                 INTEGER (-120..-58),
    tpc-step-size                      ENUMERATED { s1, s2, s3 , spare1}
}



HS-SCCH-TDD384 ::=              SEQUENCE {
    timeslotNumber                     TimeslotNumber,
    channelisationCode                 DL-TS-ChannelisationCode,
    midambleAllocationMode             CHOICE {
        defaultMidamble                    NULL,
        commonMidamble                     NULL,
        ueSpecificMidamble                 SEQUENCE {
            midambleShift                      MidambleShiftLong
        }
    },
    midambleconfiguration              MidambleConfigurationBurstType1and3,
    bler-target                        Bler-Target,
    hs-sich-configuration              HS-SICH-Configuration-TDD384
}

HS-SCCH-TDD768 ::=              SEQUENCE {
    timeslotNumber                     TimeslotNumber,
    channelisationCode                 DL-TS-ChannelisationCode-VHCR,
    midambleAllocationMode             CHOICE {
        defaultMidamble                    NULL,
        commonMidamble                     NULL,
        ueSpecificMidamble                 SEQUENCE {
            midambleShift                      MidambleShiftLong
        }
    },
    midambleconfiguration              MidambleConfigurationBurstType1and3,
    bler-target                        Bler-Target,
    hs-sich-configuration              HS-SICH-Configuration-TDD768
}

HS-SICH-Configuration-TDD384 ::=    SEQUENCE {
    timeslotNumber                     TimeslotNumber,
    channelisationCode                 DL-TS-ChannelisationCode,
    midambleAllocationMode             CHOICE {
        defaultMidamble                    NULL,
        ueSpecificMidamble                 SEQUENCE {
            midambleShift                      MidambleShiftLong
        }
    },
    midambleconfiguration              MidambleConfigurationBurstType1and3
}

HS-SICH-Configuration-TDD768 ::=    SEQUENCE {
    timeslotNumber                     TimeslotNumber,
    channelisationCode                 DL-TS-ChannelisationCode-VHCR,
    midambleAllocationMode             CHOICE {
        defaultMidamble                    NULL,
        ueSpecificMidamble                 SEQUENCE {
            midambleShift                      MidambleShiftLong
        }
    },
    midambleconfiguration              MidambleConfigurationBurstType1and3
}
```

```
HS-SICH-Power-Control-Info-TDD384 ::= SEQUENCE {
    -- Actual value ul-target-SIR = IE value * 0.5
    ul-target-SIR                       INTEGER (-22..40),
    hs-sich-ConstantValue               ConstantValue
}

HS-SICH-Power-Control-Info-TDD768 ::= SEQUENCE {
    -- Actual value ul-target-SIR = IE value * 0.5
    ul-target-SIR                       INTEGER (-22..40),
    hs-sich-ConstantValue               ConstantValue
}

IndividualTimeslotInfo ::=          SEQUENCE {
    timeslotNumber                      TimeslotNumber,
    tfci-Existence                      BOOLEAN,
    midambleShiftAndBurstType           MidambleShiftAndBurstType
}

IndividualTimeslotInfo-VHCR ::=         SEQUENCE {
    timeslotNumber                      TimeslotNumber,
    tfci-Existence                      BOOLEAN,
    midambleShiftAndBurstType-VHCR      MidambleShiftAndBurstType-VHCR
}

IndividualTimeslotInfo-LCR-r4 ::=   SEQUENCE {
    timeslotNumber                      TimeslotNumber-LCR-r4,
    tfci-Existence                      BOOLEAN,
    midambleShiftAndBurstType           MidambleShiftAndBurstType-LCR-r4,
    modulation                          ENUMERATED { mod-QPSK, mod-8PSK },
    ss-TPC-Symbols                      ENUMERATED { zero, one, sixteenOverSF },
    additionalSS-TPC-Symbols            INTEGER(1..15)      OPTIONAL
}

IndividualTimeslotInfo-LCR-r4-ext ::=       SEQUENCE {
-- timeslotNumber and tfci-Existence is taken from IndividualTimeslotInfo.
-- midambleShiftAndBurstType in IndividualTimeslotInfo shall be ignored.
    midambleShiftAndBurstType           MidambleShiftAndBurstType-LCR-r4,
    modulation                          ENUMERATED { mod-QPSK, mod-8PSK },
    ss-TPC-Symbols                      ENUMERATED { zero, one, sixteenOverSF }
}

IndividualTS-Interference ::=       SEQUENCE {
    timeslot                            TimeslotNumber,
    ul-TimeslotInterference             TDD-UL-Interference
}

IndividualTS-InterferenceList ::=   SEQUENCE (SIZE (1..maxTS)) OF
                                        IndividualTS-Interference

ITP ::=                             ENUMERATED {
                                        mode0, mode1 }

NidentifyAbort ::=  INTEGER (1..128)

MaxAllowedUL-TX-Power ::=           INTEGER (-50..33)

MaxAvailablePCPCH-Number ::=        INTEGER (1..64)
MaxPowerIncrease-r4 ::=             INTEGER (0..3)

MaxTFCI-Field2Value ::=             INTEGER (1..1023)

Measurement-Feedback-Info ::=       SEQUENCE {
    modeSpecificInfo                CHOICE {
        fdd                             SEQUENCE {
            measurementPowerOffset          MeasurementPowerOffset,
            feedback-cycle                  Feedback-cycle,
            cqi-RepetitionFactor            CQI-RepetitionFactor,
            deltaCQI                        DeltaCQI
        },
        tdd                             NULL
    }
}


MidambleConfigurationBurstType1and3 ::= ENUMERATED {ms4, ms8, ms16}

MidambleConfigurationBurstType2 ::=     ENUMERATED {ms3, ms6}
```

```
MidambleConfigurationBurstType2-VHCR ::=        ENUMERATED {ms4, ms8}

MidambleShiftAndBurstType ::=       SEQUENCE {
    burstType                           CHOICE {
        type1                               SEQUENCE {
            midambleConfigurationBurstType1and3 MidambleConfigurationBurstType1and3,
            midambleAllocationMode              CHOICE {
                defaultMidamble                     NULL,
                commonMidamble                      NULL,
                ueSpecificMidamble                  SEQUENCE {
                    midambleShift                       MidambleShiftLong
                }
            }
        },
        type2                               SEQUENCE {
            midambleConfigurationBurstType2     MidambleConfigurationBurstType2,
            midambleAllocationMode              CHOICE {
                defaultMidamble                     NULL,
                commonMidamble                      NULL,
                ueSpecificMidamble                  SEQUENCE {
                    midambleShift                       MidambleShiftShort
                }
            }
        },
        type3                               SEQUENCE {
            midambleConfigurationBurstType1and3 MidambleConfigurationBurstType1and3,
            midambleAllocationMode              CHOICE {
                defaultMidamble                     NULL,
                ueSpecificMidamble                  SEQUENCE {
                    midambleShift                       MidambleShiftLong
                }
            }
        }
    }
}

MidambleShiftAndBurstType-VHCR ::=  SEQUENCE {
    burstType                           CHOICE {
        type1                               SEQUENCE {
            midambleConfigurationBurstType1and3 MidambleConfigurationBurstType1and3,
            midambleAllocationMode              CHOICE {
                defaultMidamble                     NULL,
                commonMidamble                      NULL,
                ueSpecificMidamble                  SEQUENCE {
                    midambleShift                       MidambleShiftLong
                }
            }
        },
        type2                               SEQUENCE {
            midambleConfigurationBurstType2     MidambleConfigurationBurstType2-VHCR,
            midambleAllocationMode              CHOICE {
                defaultMidamble                     NULL,
                commonMidamble                      NULL,
                ueSpecificMidamble                  SEQUENCE {
                    midambleShift                       MidambleShiftShort-VHCR
                }
            }
        },
        type3                               SEQUENCE {
            midambleConfigurationBurstType1and3 MidambleConfigurationBurstType1and3,
            midambleAllocationMode              CHOICE {
                defaultMidamble                     NULL,
                ueSpecificMidamble                  SEQUENCE {
                    midambleShift                       MidambleShiftLong
                }
            }
        }
    }
}

MidambleShiftAndBurstType-DL ::=        SEQUENCE {
    burstType                           CHOICE {
        type1                               SEQUENCE {
            midambleConfigurationBurstType1and3 MidambleConfigurationBurstType1and3,
            midambleAllocationMode              CHOICE {
                defaultMidamble                     NULL,
                commonMidamble                      NULL,
```

```
                ueSpecificMidamble                  SEQUENCE {
                    midambleShift                       MidambleShiftLong
                }
            }
        },
        type2                               SEQUENCE {
            midambleConfigurationBurstType2     MidambleConfigurationBurstType2,
            midambleAllocationMode              CHOICE {
                defaultMidamble                     NULL,
                commonMidamble                      NULL,
                ueSpecificMidamble                  SEQUENCE {
                    midambleShift                       MidambleShiftShort
                }
            }
        }
    }
}

MidambleShiftAndBurstType-DL-VHCR ::= SEQUENCE {
    burstType                           CHOICE {
        type1                               SEQUENCE {
            midambleConfigurationBurstType1and3 MidambleConfigurationBurstType1and3,
            midambleAllocationMode              CHOICE {
                defaultMidamble                     NULL,
                commonMidamble                      NULL,
                ueSpecificMidamble                  SEQUENCE {
                    midambleShift                       MidambleShiftLong
                }
            }
        },
        type2                               SEQUENCE {
            midambleConfigurationBurstType2     MidambleConfigurationBurstType2-VHCR,
            midambleAllocationMode              CHOICE {
                defaultMidamble                     NULL,
                commonMidamble                      NULL,
                ueSpecificMidamble                  SEQUENCE {
                    midambleShift                       MidambleShiftShort-VHCR
                }
            }
        }
    }
}

MidambleShiftAndBurstType-LCR-r4 ::=    SEQUENCE {
    midambleAllocationMode              CHOICE {
        defaultMidamble                     NULL,
        commonMidamble                      NULL,
        ueSpecificMidamble                  SEQUENCE {
            midambleShift                       INTEGER (0..15)
        }
    },
    -- Actual value midambleConfiguration = IE value * 2
    midambleConfiguration               INTEGER (1..8)
}

MidambleShiftLong ::=               INTEGER (0..15)


MidambleShiftShort ::=              INTEGER (0..5)

MidambleShiftShort-VHCR ::=         INTEGER (0..7)

MinimumSpreadingFactor ::=          ENUMERATED {
                                        sf4, sf8, sf16, sf32,
                                        sf64, sf128, sf256 }

MultiCodeInfo ::=                   INTEGER (1..16)


N-EOT ::=                           INTEGER (0..7)

N-GAP ::=                           ENUMERATED {
                                        f2, f4, f8 }

N-PCH ::=                           INTEGER (1..8)

N-StartMessage ::=                  INTEGER (1..8)
```

```
NB01 ::=                            INTEGER (0..50)

NF-Max ::=                          INTEGER (1..64)

NumberOfDPDCH ::=                   INTEGER (1..maxDPDCH-UL)

NumberOfFBI-Bits ::=                INTEGER (1..2)

OpenLoopPowerControl-TDD ::=        SEQUENCE {
    primaryCCPCH-TX-Power               PrimaryCCPCH-TX-Power,
    -- alpha, prach-ConstantValue, dpch-ConstantValue and pusch-ConstantValue
    -- shall be ignored in 1.28Mcps TDD mode.
    alpha                               Alpha                       OPTIONAL,
    prach-ConstantValue                 ConstantValueTdd,
    dpch-ConstantValue                  ConstantValueTdd,
    pusch-ConstantValue                 ConstantValueTdd            OPTIONAL
}

OpenLoopPowerControl-IPDL-TDD-r4 ::=    SEQUENCE {
    ipdl-alpha                          Alpha,
    maxPowerIncrease                    MaxPowerIncrease-r4
}

PagingIndicatorLength ::=           ENUMERATED {
                                        pi4, pi8, pi16 }

PC-Preamble ::=                     INTEGER (0..7)

PCP-Length ::=                      ENUMERATED {
                                        as0, as8 }

PCPCH-ChannelInfo ::=               SEQUENCE {
    pcpch-UL-ScramblingCode             INTEGER (0..79),
    pcpch-DL-ChannelisationCode         INTEGER (0..511),
    pcpch-DL-ScramblingCode             SecondaryScramblingCode             OPTIONAL,
    pcp-Length                          PCP-Length,
    ucsm-Info                           UCSM-Info                           OPTIONAL
}

PCPCH-ChannelInfoList ::=           SEQUENCE (SIZE (1..maxPCPCHs)) OF
                                        PCPCH-ChannelInfo

PCPICH-UsageForChannelEst ::=       ENUMERATED {
                                        mayBeUsed,
                                        shallNotBeUsed }

PDSCH-CapacityAllocationInfo ::=    SEQUENCE {
    -- pdsch-PowerControlInfo is conditional on new-configuration branch below, if this
    -- selected the IE is OPTIONAL otherwise it should not be sent
    pdsch-PowerControlInfo              PDSCH-PowerControlInfo              OPTIONAL,
    pdsch-AllocationPeriodInfo          AllocationPeriodInfo,
    configuration                       CHOICE {
        old-Configuration                   SEQUENCE {
            tfcs-ID                             TFCS-IdentityPlain                  DEFAULT 1,
            pdsch-Identity                      PDSCH-Identity
        },
        new-Configuration                   SEQUENCE {
            pdsch-Info                          PDSCH-Info,
            pdsch-Identity                      PDSCH-Identity              OPTIONAL
        }
    }
}

PDSCH-CapacityAllocationInfo-r4 ::= SEQUENCE {
    pdsch-AllocationPeriodInfo          AllocationPeriodInfo,
    configuration                       CHOICE {
        old-Configuration                   SEQUENCE {
            tfcs-ID                             TFCS-IdentityPlain                  DEFAULT 1,
            pdsch-Identity                      PDSCH-Identity
        },
        new-Configuration                   SEQUENCE {
            pdsch-Info                          PDSCH-Info-r4,
            pdsch-Identity                      PDSCH-Identity              OPTIONAL,
            pdsch-PowerControlInfo              PDSCH-PowerControlInfo      OPTIONAL
        }
    }
}
```

```
PDSCH-CapacityAllocationInfo-r7 ::= SEQUENCE {
    pdsch-AllocationPeriodInfo          AllocationPeriodInfo,
    configuration                       CHOICE {
        old-Configuration                   SEQUENCE {
            tfcs-ID                             TFCS-IdentityPlain                  DEFAULT 1,
            pdsch-Identity                      PDSCH-Identity
        },
        new-Configuration                   SEQUENCE {
            pdsch-Info                          PDSCH-Info-r7,
            pdsch-Identity                      PDSCH-Identity              OPTIONAL,
            pdsch-PowerControlInfo              PDSCH-PowerControlInfo      OPTIONAL
        }
    }
}

PDSCH-CodeInfo ::=                  SEQUENCE {
    spreadingFactor                     SF-PDSCH,
    codeNumber                          CodeNumberDSCH,
    multiCodeInfo                       MultiCodeInfo
}

PDSCH-CodeInfoList ::=              SEQUENCE (SIZE (1..maxTFCI-2-Combs)) OF
                                        PDSCH-CodeInfo

PDSCH-CodeMap ::=                   SEQUENCE {
    spreadingFactor                     SF-PDSCH,
    multiCodeInfo                       MultiCodeInfo,
    codeNumberStart                     CodeNumberDSCH,
    codeNumberStop                      CodeNumberDSCH
}

PDSCH-CodeMapList ::=               SEQUENCE (SIZE (1..maxPDSCH-TFCIgroups)) OF
                                        PDSCH-CodeMap

PDSCH-CodeMapping ::=               SEQUENCE {
    dl-ScramblingCode                   SecondaryScramblingCode             OPTIONAL,
    signallingMethod                    CHOICE {
        codeRange                           CodeRange,
        tfci-Range                          DSCH-MappingList,
        explicit-config                     PDSCH-CodeInfoList,
        replace                             ReplacedPDSCH-CodeInfoList
    }
}

PDSCH-Identity ::=                  INTEGER (1..hiPDSCHidentities)


PDSCH-Info ::=                      SEQUENCE {
    tfcs-ID                             TFCS-IdentityPlain                  DEFAULT 1,
    commonTimeslotInfo                  CommonTimeslotInfo                  OPTIONAL,
    pdsch-TimeslotsCodes                DownlinkTimeslotsCodes              OPTIONAL
}

PDSCH-Info-r4 ::=                       SEQUENCE {
    tfcs-ID                             TFCS-IdentityPlain                  DEFAULT 1,
    commonTimeslotInfo                  CommonTimeslotInfo                  OPTIONAL,
    tddOption                           CHOICE {
        tdd384                              SEQUENCE {
            pdsch-TimeslotsCodes                DownlinkTimeslotsCodes      OPTIONAL
        },
        tdd128                              SEQUENCE {
            pdsch-TimeslotsCodes                DownlinkTimeslotsCodes-LCR-r4   OPTIONAL
        }
    }
}

PDSCH-Info-r7 ::=                       SEQUENCE {
    tfcs-ID                             TFCS-IdentityPlain                  DEFAULT 1,
    commonTimeslotInfo                  CommonTimeslotInfo                  OPTIONAL,
    tddOption                           CHOICE {
        tdd384                              SEQUENCE {
            pdsch-TimeslotsCodes                DownlinkTimeslotsCodes      OPTIONAL
        },
        tdd768                              SEQUENCE {
            pdsch-TimeslotsCodes                DownlinkTimeslotsCodes-VHCR     OPTIONAL
        },
        tdd128                              SEQUENCE {
            pdsch-TimeslotsCodes                DownlinkTimeslotsCodes-LCR-r4   OPTIONAL
```

```
        }
    }
}

PDSCH-Info-LCR-r4 ::=               SEQUENCE {
    tfcs-ID                             TFCS-IdentityPlain                  DEFAULT 1,
    commonTimeslotInfo                  CommonTimeslotInfo                  OPTIONAL,
    pdsch-TimeslotsCodes                DownlinkTimeslotsCodes-LCR-r4       OPTIONAL
}

PDSCH-PowerControlInfo ::=          SEQUENCE {
    tpc-StepSizeTDD                     TPC-StepSizeTDD                     OPTIONAL,
    ul-CCTrChTPCList                    UL-CCTrChTPCList                    OPTIONAL
}

PDSCH-SHO-DCH-Info ::=              SEQUENCE {
    dsch-RadioLinkIdentifier            DSCH-RadioLinkIdentifier,
    rl-IdentifierList                   RL-IdentifierList                   OPTIONAL
}

PDSCH-SysInfo ::=                   SEQUENCE {
    pdsch-Identity                      PDSCH-Identity,
    pdsch-Info                          PDSCH-Info,
    dsch-TFS                            TransportFormatSet                  OPTIONAL,
    dsch-TFCS                           TFCS                                OPTIONAL
}

PDSCH-SysInfo-r7 ::=                SEQUENCE {
    pdsch-Identity                      PDSCH-Identity,
    pdsch-Info                          PDSCH-Info-r7,
    dsch-TransportChannelsInfo          DSCH-TransportChannelsInfo          OPTIONAL,
    dsch-TFCS                           TFCS                                OPTIONAL
}

PDSCH-SysInfo-HCR-r5 ::=                SEQUENCE {
    pdsch-Identity                  PDSCH-Identity,
    pdsch-Info                      PDSCH-Info,
    dsch-TransportChannelsInfo      DSCH-TransportChannelsInfo          OPTIONAL,
    dsch-TFCS                       TFCS                                OPTIONAL
}

PDSCH-SysInfo-LCR-r4 ::=            SEQUENCE {
    pdsch-Identity                      PDSCH-Identity,
    pdsch-Info                          PDSCH-Info-LCR-r4,
    dsch-TFS                            TransportFormatSet                  OPTIONAL,
    dsch-TFCS                           TFCS                                OPTIONAL
}

PDSCH-SysInfoList ::=               SEQUENCE (SIZE (1..maxPDSCH)) OF
                                        PDSCH-SysInfo

PDSCH-SysInfoList-r7 ::=            SEQUENCE (SIZE (1..maxPDSCH)) OF PDSCH-SysInfo-r7

PDSCH-SysInfoList-HCR-r5 ::=            SEQUENCE (SIZE (1..maxPDSCH)) OF PDSCH-SysInfo-HCR-r5

PDSCH-SysInfoList-LCR-r4 ::=        SEQUENCE (SIZE (1..maxPDSCH)) OF
                                        PDSCH-SysInfo-LCR-r4

PDSCH-SysInfoList-SFN ::=           SEQUENCE (SIZE (1..maxPDSCH)) OF
                                        SEQUENCE {
    pdsch-SysInfo                           PDSCH-SysInfo,
    sfn-TimeInfo                            SFN-TimeInfo                    OPTIONAL
}

PDSCH-SysInfoList-SFN-HCR-r5 ::=            SEQUENCE (SIZE (1..maxPDSCH)) OF
                                        SEQUENCE {
    pdsch-SysInfo                           PDSCH-SysInfo-HCR-r5,
    sfn-TimeInfo                            SFN-TimeInfo                    OPTIONAL
}

PDSCH-SysInfoList-SFN-LCR-r4 ::=    SEQUENCE (SIZE (1..maxPDSCH)) OF
                                        SEQUENCE {
    pdsch-SysInfo                           PDSCH-SysInfo-LCR-r4,
    sfn-TimeInfo                            SFN-TimeInfo                    OPTIONAL
}

PersistenceScalingFactor ::=        ENUMERATED {
                                        psf0-9, psf0-8, psf0-7, psf0-6,
```

```
                                    psf0-5, psf0-4, psf0-3, psf0-2 }

PersistenceScalingFactorList ::=    SEQUENCE (SIZE (1..maxASCpersist)) OF
                                    PersistenceScalingFactor

PI-CountPerFrame ::=                ENUMERATED {
                                    e18, e36, e72, e144 }

PichChannelisationCodeList-LCR-r4 ::=   SEQUENCE (SIZE (1..2)) OF
                                    DL-TS-ChannelisationCode

PICH-Info ::=                       CHOICE {
    fdd                             SEQUENCE {
        channelisationCode256           ChannelisationCode256,
        pi-CountPerFrame                PI-CountPerFrame,
        sttd-Indicator                  BOOLEAN
    },
    tdd                             SEQUENCE {
        channelisationCode              TDD-PICH-CCode                  OPTIONAL,
        timeslot                        TimeslotNumber                  OPTIONAL,
        midambleShiftAndBurstType       MidambleShiftAndBurstType,
        repetitionPeriodLengthOffset    RepPerLengthOffset-PICH         OPTIONAL,
        pagingIndicatorLength           PagingIndicatorLength           DEFAULT pi4,
        n-GAP                           N-GAP                           DEFAULT f4,
        n-PCH                           N-PCH                           DEFAULT 2
    }
}

PICH-Info-r7 ::=                    CHOICE {
    fdd                             SEQUENCE {
        channelisationCode256           ChannelisationCode256,
        pi-CountPerFrame                PI-CountPerFrame,
        sttd-Indicator                  BOOLEAN
    },
    tdd384                          SEQUENCE {
        channelisationCode              TDD-PICH-CCode                  OPTIONAL,
        timeslot                        TimeslotNumber                  OPTIONAL,
        midambleShiftAndBurstType       MidambleShiftAndBurstType,
        repetitionPeriodLengthOffset    RepPerLengthOffset-PICH         OPTIONAL,
        pagingIndicatorLength           PagingIndicatorLength           DEFAULT pi4,
        n-GAP                           N-GAP                           DEFAULT f4,
        n-PCH                           N-PCH                           DEFAULT 2
    },
    tdd768                          SEQUENCE {
        channelisationCode              TDD768-PICH-CCode               OPTIONAL,
        timeslot                        TimeslotNumber                  OPTIONAL,
        midambleShiftAndBurstType       MidambleShiftAndBurstType,
        repetitionPeriodLengthOffset    RepPerLengthOffset-PICH         OPTIONAL,
        pagingIndicatorLength           PagingIndicatorLength           DEFAULT pi4,
        n-GAP                           N-GAP                           DEFAULT f4,
        n-PCH                           N-PCH                           DEFAULT 2
    }
}

PICH-Info-LCR-r4 ::=                SEQUENCE {
    timeslot                        TimeslotNumber-LCR-r4               OPTIONAL,
    pichChannelisationCodeList-LCR-r4   PichChannelisationCodeList-LCR-r4,
    midambleShiftAndBurstType       MidambleShiftAndBurstType-LCR-r4,
    repetitionPeriodLengthOffset    RepPerLengthOffset-PICH             OPTIONAL,
    pagingIndicatorLength           PagingIndicatorLength           DEFAULT pi4,
    n-GAP                           N-GAP                           DEFAULT f4,
    n-PCH                           N-PCH                           DEFAULT 2
}

PICH-PowerOffset ::=                INTEGER (-10..5)

PilotBits128 ::=                    ENUMERATED {
                                    pb4, pb8 }

PilotBits256 ::=                    ENUMERATED {
                                    pb2, pb4, pb8 }

    -- Actual measurement power offset value = IE value * 0.5
MeasurementPowerOffset ::=          INTEGER (-12..26)

PLCCH-Info      ::=                 SEQUENCE {
    plcchSequenceNumber             INTEGER(1..17),
    timeslotNumber                  TimeslotNumber-LCR-r4,
```

```
    channelisationCode              DL-TS-ChannelisationCode,
    tpcCommandTargetRate            TPC-CommandTargetRate
}

PositionFixedOrFlexible ::=         ENUMERATED {
                                        fixed,
                                        flexible }

PowerControlAlgorithm ::=           CHOICE {
    algorithm1                          TPC-StepSizeFDD,
    algorithm2                          NULL
}

PowerOffsetPilot-pdpdch ::=         INTEGER (0..24)

PowerOffsetTPC-pdpdch ::=           INTEGER (0..24)

PowerRampStep ::=                   INTEGER (1..8)

PRACH-ChanCodes-LCR-r4 ::=          SEQUENCE (SIZE (1..4)) OF
                                        TDD-PRACH-CCode-LCR-r4

PRACH-Definition-LCR-r4 ::=         SEQUENCE {
    timeslot                            TimeslotNumber-PRACH-LCR-r4,
    prach-ChanCodes-LCR                 PRACH-ChanCodes-LCR-r4,
    midambleShiftAndBurstType           MidambleShiftAndBurstType-LCR-r4,
    fpach-Info                          FPACH-Info-r4
}

PRACH-Midamble ::=                  ENUMERATED {
                                        direct,
                                        direct-Inverted }

PRACH-Partitioning ::=              CHOICE {
    fdd                                 SEQUENCE (SIZE (1..maxASC)) OF
    -- TABULAR: If only "NumASC+1" (with, NumASC+1 < maxASC) ASCSetting-FDD are listed,
    -- the remaining (NumASC+2 through maxASC) ASCs are unspecified.
                                            ASCSetting-FDD,
    tdd                                 SEQUENCE (SIZE (1..maxASC)) OF
    -- TABULAR: If only "NumASC+1" (with, NumASC+1 < maxASC) ASCSetting-TDD are listed,
    -- the remaining (NumASC+2 through maxASC) ASCs are unspecified.
                                            ASCSetting-TDD
}

PRACH-Partitioning-r7 ::=           CHOICE {
    fdd                                 SEQUENCE (SIZE (1..maxASC)) OF
    -- TABULAR: If only "NumASC+1" (with, NumASC+1 < maxASC) ASCSetting-FDD are listed,
    -- the remaining (NumASC+2 through maxASC) ASCs are unspecified.
                                            ASCSetting-FDD,
    tdd                                 SEQUENCE (SIZE (1..maxASC)) OF
    -- TABULAR: If only "NumASC+1" (with, NumASC+1 < maxASC) ASCSetting-TDD are listed,
    -- the remaining (NumASC+2 through maxASC) ASCs are unspecified.
                                            ASCSetting-TDD-r7
}

PRACH-Partitioning-LCR-r4 ::=       SEQUENCE (SIZE (1..maxASC)) OF
    -- TABULAR: If only "NumASC+1" (with, NumASC+1 < maxASC) ASCSetting-TDD-LCR-r4 are listed,
    -- the remaining (NumASC+2 through maxASC) ASCs are unspecified.
                                            ASCSetting-TDD-LCR-r4

PRACH-PowerOffset ::=               SEQUENCE {
    powerRampStep                       PowerRampStep,
    preambleRetransMax                  PreambleRetransMax
}

PRACH-RACH-Info ::=                 SEQUENCE {
    modeSpecificInfo                    CHOICE {
        fdd                                 SEQUENCE {
            availableSignatures                 AvailableSignatures,
            availableSF                         SF-PRACH,
            preambleScramblingCodeWordNumber    PreambleScramblingCodeWordNumber,
            puncturingLimit                     PuncturingLimit,
            availableSubChannelNumbers          AvailableSubChannelNumbers
        },
        tdd                                 SEQUENCE {
            timeslot                            TimeslotNumber,
            channelisationCodeList              TDD-PRACH-CCodeList,
            prach-Midamble                      PRACH-Midamble
```

```
        }
    }
}

PRACH-RACH-Info-r7 ::=              SEQUENCE {
    modeSpecificInfo                    CHOICE {
        fdd                                 SEQUENCE {
            availableSignatures                 AvailableSignatures,
            availableSF                         SF-PRACH,
            preambleScramblingCodeWordNumber    PreambleScramblingCodeWordNumber,
            puncturingLimit                     PuncturingLimit,
            availableSubChannelNumbers          AvailableSubChannelNumbers
        },
        tdd384                              SEQUENCE {
            timeslot                            TimeslotNumber,
            channelisationCodeList              TDD-PRACH-CCodeList,
            prach-Midamble                      PRACH-Midamble
        },
        tdd768                              SEQUENCE {
            timeslot                            TimeslotNumber,
            channelisationCodeList              TDD768-PRACH-CCodeList,
            prach-Midamble                      PRACH-Midamble
        }
    }
}

PRACH-RACH-Info-LCR-r4 ::=          SEQUENCE {
    sync-UL-Info                        SYNC-UL-Info-r4,
    prach-DefinitionList                SEQUENCE (SIZE (1..maxPRACH-FPACH)) OF
                                            PRACH-Definition-LCR-r4
}

PRACH-SystemInformation ::=         SEQUENCE {
    prach-RACH-Info                     PRACH-RACH-Info,
    transportChannelIdentity            TransportChannelIdentity,
    rach-TransportFormatSet             TransportFormatSet                  OPTIONAL,
    rach-TFCS                           TFCS                                OPTIONAL,
    prach-Partitioning                  PRACH-Partitioning                  OPTIONAL,
    persistenceScalingFactorList        PersistenceScalingFactorList        OPTIONAL,
    ac-To-ASC-MappingTable              AC-To-ASC-MappingTable              OPTIONAL,
    modeSpecificInfo                    CHOICE {
        fdd                                 SEQUENCE {
            primaryCPICH-TX-Power               PrimaryCPICH-TX-Power       OPTIONAL,
            constantValue                       ConstantValue               OPTIONAL,
            prach-PowerOffset                   PRACH-PowerOffset           OPTIONAL,
            rach-TransmissionParameters         RACH-TransmissionParameters OPTIONAL,
            aich-Info                           AICH-Info                   OPTIONAL
        },
        tdd                                 NULL
    }
}

PRACH-SystemInformation-r7 ::=      SEQUENCE {
    prach-RACH-Info                     PRACH-RACH-Info-r7,
    transportChannelIdentity            TransportChannelIdentity,
    rach-TransportFormatSet             TransportFormatSet                  OPTIONAL,
    rach-TFCS                           TFCS                                OPTIONAL,
    prach-Partitioning                  PRACH-Partitioning-r7               OPTIONAL,
    persistenceScalingFactorList        PersistenceScalingFactorList        OPTIONAL,
    ac-To-ASC-MappingTable              AC-To-ASC-MappingTable              OPTIONAL,
    modeSpecificInfo                    CHOICE {
        fdd                                 SEQUENCE {
            primaryCPICH-TX-Power               PrimaryCPICH-TX-Power       OPTIONAL,
            constantValue                       ConstantValue               OPTIONAL,
            prach-PowerOffset                   PRACH-PowerOffset           OPTIONAL,
            rach-TransmissionParameters         RACH-TransmissionParameters OPTIONAL,
            aich-Info                           AICH-Info                   OPTIONAL
        },
        tdd                                 NULL
    }
}

PRACH-SystemInformation-LCR-r4 ::=  SEQUENCE {
    prach-RACH-Info-LCR                 PRACH-RACH-Info-LCR-r4,
    rach-TransportFormatSet-LCR         TransportFormatSet-LCR          OPTIONAL,
    prach-Partitioning-LCR              PRACH-Partitioning-LCR-r4       OPTIONAL
}
```

```
PRACH-SystemInformationList ::=     SEQUENCE (SIZE (1..maxPRACH)) OF
                                        PRACH-SystemInformation

PRACH-SystemInformationList-r7 ::=  SEQUENCE (SIZE (1..maxPRACH)) OF
                                        PRACH-SystemInformation-r7

PRACH-SystemInformationList-LCR-r4 ::=  SEQUENCE (SIZE (1..maxPRACH)) OF
                                            PRACH-SystemInformation-LCR-r4

PreambleRetransMax ::=              INTEGER (1..64)

PreambleScramblingCodeWordNumber ::=    INTEGER (0..15)

PreDefPhyChConfiguration ::=        SEQUENCE {
    ul-DPCH-InfoPredef                  UL-DPCH-InfoPredef,
    dl-CommonInformationPredef          DL-CommonInformationPredef  OPTIONAL
}

PrimaryCCPCH-Info ::=               CHOICE {
    fdd                                 SEQUENCE {
        tx-DiversityIndicator               BOOLEAN
    },
    tdd                                 SEQUENCE {
        -- syncCase should be ignored for 1.28Mcps TDD mode
        syncCase                            CHOICE {
            syncCase1                           SEQUENCE {
                timeslot                            TimeslotNumber
            },
            syncCase2                           SEQUENCE {
                timeslotSync2                       TimeslotSync2
            }
        }                                                               OPTIONAL,
        cellParametersID                CellParametersID                OPTIONAL,
        sctd-Indicator                  BOOLEAN
    }
}

PrimaryCCPCH-Info-r4 ::=            CHOICE {
    fdd                                 SEQUENCE {
        tx-DiversityIndicator               BOOLEAN
    },
    tdd                                 SEQUENCE {
        tddOption                           CHOICE {
            tdd384                              SEQUENCE {
                syncCase                            CHOICE {
                    syncCase1                           SEQUENCE {
                        timeslot                            TimeslotNumber
                    },
                    syncCase2                           SEQUENCE {
                        timeslotSync2                       TimeslotSync2
                    }
                }                                                       OPTIONAL
            },
            tdd128                              SEQUENCE {
                tstd-Indicator                      BOOLEAN
            }
        },
        cellParametersID                CellParametersID                OPTIONAL,
        sctd-Indicator                  BOOLEAN
    }
}

PrimaryCCPCH-Info-r7 ::=            CHOICE {
    fdd                                 SEQUENCE {
        tx-DiversityIndicator               BOOLEAN
    },
    tdd                                 SEQUENCE {
        tddOption                           CHOICE {
            tdd384                              SEQUENCE {
                syncCase                            CHOICE {
                    syncCase1                           SEQUENCE {
                        timeslot                            TimeslotNumber
                    },
                    syncCase2                           SEQUENCE {
                        timeslotSync2                       TimeslotSync2
                    }
                }                                                       OPTIONAL
            },
```

```
            tdd768                      SEQUENCE {
                syncCase                        CHOICE {
                    syncCase1                       SEQUENCE {
                        timeslot                        TimeslotNumber
                    },
                    syncCase2                       SEQUENCE {
                        timeslotSync2                   TimeslotSync2
                    }
                }                                                           OPTIONAL
            },
            tdd128                          SEQUENCE {
                tstd-Indicator                  BOOLEAN
            }
        },
        cellParametersID                CellParametersID            OPTIONAL,
        sctd-Indicator                  BOOLEAN
    }
}

PrimaryCCPCH-Info-LCR-r4 ::=        SEQUENCE {
    tstd-Indicator                      BOOLEAN,
    cellParametersID                    CellParametersID            OPTIONAL,
    sctd-Indicator                      BOOLEAN
}

-- For 1.28Mcps TDD, the following IE includes elements for the PCCPCH Info additional to those
-- in PrimaryCCPCH-Info
PrimaryCCPCH-Info-LCR-r4-ext ::=    SEQUENCE {
    tstd-Indicator                      BOOLEAN
}

PrimaryCCPCH-InfoPost ::=           SEQUENCE {
    syncCase                            CHOICE {
        syncCase1                           SEQUENCE {
            timeslot                            TimeslotNumber
        },
        syncCase2                           SEQUENCE {
            timeslotSync2                       TimeslotSync2
        }
    },
    cellParametersID                    CellParametersID,
    sctd-Indicator                      BOOLEAN
}

PrimaryCCPCH-InfoPostTDD-LCR-r4 ::= SEQUENCE {
    tstd-Indicator                      BOOLEAN,
    cellParametersID                    CellParametersID,
    sctd-Indicator                      BOOLEAN
}

PrimaryCCPCH-TX-Power ::=           INTEGER (6..43)

PrimaryCPICH-Info ::=               SEQUENCE {
    primaryScramblingCode               PrimaryScramblingCode
}

PrimaryCPICH-TX-Power ::=           INTEGER (-10..50)

PrimaryScramblingCode ::=           INTEGER (0..511)

PuncturingLimit ::=                 ENUMERATED {
                                        pl0-40, pl0-44, pl0-48, pl0-52, pl0-56,
                                        pl0-60, pl0-64, pl0-68, pl0-72, pl0-76,
                                        pl0-80, pl0-84, pl0-88, pl0-92, pl0-96, pl1 }

PUSCH-CapacityAllocationInfo ::=    SEQUENCE {
    pusch-Allocation                    CHOICE {
        pusch-AllocationPending             NULL,
        pusch-AllocationAssignment          SEQUENCE {
            pusch-AllocationPeriodInfo          AllocationPeriodInfo,
            pusch-PowerControlInfo              UL-TargetSIR            OPTIONAL,
            configuration                       CHOICE {
                old-Configuration                   SEQUENCE {
                    tfcs-ID                             TFCS-IdentityPlain      DEFAULT 1,
                    pusch-Identity                      PUSCH-Identity
                },
                new-Configuration                   SEQUENCE {
                    pusch-Info                          PUSCH-Info,
```

```
                    pusch-Identity                      PUSCH-Identity      OPTIONAL
                }
            }
        }
    }
}

PUSCH-CapacityAllocationInfo-r4 ::= SEQUENCE {
    pusch-Allocation                    CHOICE {
        pusch-AllocationPending             NULL,
        pusch-AllocationAssignment          SEQUENCE {
            pusch-AllocationPeriodInfo          AllocationPeriodInfo,
            pusch-PowerControlInfo              PUSCH-PowerControlInfo-r4   OPTIONAL,
            configuration                       CHOICE {
                old-Configuration                   SEQUENCE {
                    tfcs-ID                             TFCS-IdentityPlain          DEFAULT 1,
                    pusch-Identity                      PUSCH-Identity
                },
                new-Configuration                   SEQUENCE {
                    pusch-Info                          PUSCH-Info-r4,
                    pusch-Identity                      PUSCH-Identity      OPTIONAL
                }
            }
        }
    }
}

PUSCH-CapacityAllocationInfo-r7 ::= SEQUENCE {
    pusch-Allocation                    CHOICE {
        pusch-AllocationPending             NULL,
        pusch-AllocationAssignment          SEQUENCE {
            pusch-AllocationPeriodInfo          AllocationPeriodInfo,
            pusch-PowerControlInfo              PUSCH-PowerControlInfo-r7   OPTIONAL,
            configuration                       CHOICE {
                old-Configuration                   SEQUENCE {
                    tfcs-ID                             TFCS-IdentityPlain          DEFAULT 1,
                    pusch-Identity                      PUSCH-Identity
                },
                new-Configuration                   SEQUENCE {
                    pusch-Info                          PUSCH-Info-VHCR,
                    pusch-Identity                      PUSCH-Identity      OPTIONAL
                }
            }
        }
    }
}

PUSCH-Identity ::=                  INTEGER (1..hiPUSCHidentities)

PUSCH-Info ::=                      SEQUENCE {
    tfcs-ID                             TFCS-IdentityPlain                  DEFAULT 1,
    commonTimeslotInfo                  CommonTimeslotInfo                  OPTIONAL,
    pusch-TimeslotsCodes                UplinkTimeslotsCodes                OPTIONAL
}

PUSCH-Info-r4 ::=                   SEQUENCE {
    tfcs-ID                             TFCS-IdentityPlain                  DEFAULT 1,
    commonTimeslotInfo                  CommonTimeslotInfo                  OPTIONAL,
    tddOption                           CHOICE {
        tdd384                              SEQUENCE {
            pusch-TimeslotsCodes                UplinkTimeslotsCodes        OPTIONAL
        },
        tdd128                              SEQUENCE {
            pusch-TimeslotsCodes                UplinkTimeslotsCodes-LCR-r4 OPTIONAL
        }
    }
}

PUSCH-Info-VHCR ::=                 SEQUENCE {
    tfcs-ID                             TFCS-IdentityPlain                  DEFAULT 1,
    commonTimeslotInfo                  CommonTimeslotInfo                  OPTIONAL,
    pusch-TimeslotsCodes-VHCR           UplinkTimeslotsCodes-VHCR           OPTIONAL
}

PUSCH-Info-LCR-r4 ::=               SEQUENCE {
    tfcs-ID                             TFCS-IdentityPlain                  DEFAULT 1,

    commonTimeslotInfo                  CommonTimeslotInfo                  OPTIONAL,
```

```
    pusch-TimeslotsCodes                UplinkTimeslotsCodes-LCR-r4         OPTIONAL
}

PUSCH-PowerControlInfo-r4 ::=       SEQUENCE {
    -- The IE ul-TargetSIR corresponds to PRX-PUSCHdes for 1.28Mcps TDD
    -- Actual value PRX-PUSCHdes = (value of IE "ul-TargetSIR" - 120)
    ul-TargetSIR                        UL-TargetSIR,
    tddOption                           CHOICE {
        tdd384                              NULL,
        tdd128                              SEQUENCE {
            tpc-StepSize                        TPC-StepSizeTDD             OPTIONAL
        }
    }
}

PUSCH-PowerControlInfo-r7 ::=       SEQUENCE {
    -- The IE ul-TargetSIR corresponds to PRX-PUSCHdes for 1.28Mcps TDD
    -- Actual value PRX-PUSCHdes = (value of IE "ul-TargetSIR" - 120)
    ul-TargetSIR                        UL-TargetSIR,
    tddOption                           CHOICE {
        tdd384                              NULL,
        tdd768                              NULL,
        tdd128                              SEQUENCE {
            tpc-StepSize                        TPC-StepSizeTDD             OPTIONAL
        }
    }
}

PUSCH-SysInfo ::=                   SEQUENCE {
    pusch-Identity                      PUSCH-Identity,
    pusch-Info                          PUSCH-Info,
    usch-TFS                            TransportFormatSet                  OPTIONAL,
    usch-TFCS                           TFCS                                OPTIONAL
}

PUSCH-SysInfo-VHCR ::=                  SEQUENCE {
    pusch-Identity                      PUSCH-Identity,
    pusch-Info-VHCR                     PUSCH-Info-VHCR,
    usch-TransportChannelsInfo          USCH-TransportChannelsInfo          OPTIONAL,
    usch-TFCS                           TFCS                                OPTIONAL
}

PUSCH-SysInfo-HCR-r5 ::=                    SEQUENCE {
    pusch-Identity                      PUSCH-Identity,
    pusch-Info                          PUSCH-Info,
    usch-TransportChannelsInfo          USCH-TransportChannelsInfo          OPTIONAL,
    usch-TFCS                           TFCS                                OPTIONAL
}

PUSCH-SysInfo-LCR-r4 ::=            SEQUENCE {
    pusch-Identity                      PUSCH-Identity,
    pusch-Info                          PUSCH-Info-LCR-r4,
    usch-TFS                            TransportFormatSet                  OPTIONAL,
    usch-TFCS                           TFCS                                OPTIONAL
}

PUSCH-SysInfoList ::=               SEQUENCE (SIZE (1..maxPUSCH)) OF
                                        PUSCH-SysInfo

PUSCH-SysInfoList-HCR-r5 ::=            SEQUENCE (SIZE (1..maxPUSCH)) OF PUSCH-SysInfo-HCR-r5

PUSCH-SysInfoList-LCR-r4 ::=        SEQUENCE (SIZE (1..maxPUSCH)) OF
                                        PUSCH-SysInfo-LCR-r4

PUSCH-SysInfoList-SFN ::=           SEQUENCE (SIZE (1..maxPUSCH)) OF
                                        SEQUENCE {
    pusch-SysInfo                           PUSCH-SysInfo,
    sfn-TimeInfo                            SFN-TimeInfo                    OPTIONAL
}

PUSCH-SysInfoList-SFN-HCR-r5 ::=            SEQUENCE (SIZE (1..maxPUSCH)) OF
                                        SEQUENCE {
    pusch-SysInfo                           PUSCH-SysInfo-HCR-r5,
    sfn-TimeInfo                            SFN-TimeInfo                    OPTIONAL
}

PUSCH-SysInfoList-SFN-LCR-r4 ::=        SEQUENCE (SIZE (1..maxPUSCH)) OF
                                        SEQUENCE {
```

```
    pusch-SysInfo                           PUSCH-SysInfo-LCR-r4,
    sfn-TimeInfo                            SFN-TimeInfo                    OPTIONAL
}

PUSCH-SysInfoList-SFN-VHCR ::=      SEQUENCE (SIZE (1..maxPUSCH)) OF
                                        SEQUENCE {
    pusch-SysInfo-VHCR                      PUSCH-SysInfo-VHCR,
    sfn-TimeInfo                            SFN-TimeInfo                    OPTIONAL
}

RACH-TransmissionParameters ::=     SEQUENCE {
    mmax                                    INTEGER (1..32),
    nb01Min                                 NB01,
    nb01Max                                 NB01
}

ReducedScramblingCodeNumber ::=     INTEGER (0..8191)

RepetitionPeriodAndLength ::=       CHOICE {
    repetitionPeriod1                       NULL,
    -- repetitionPeriod2 could just as well be NULL also.
    repetitionPeriod2                       INTEGER (1..1),
    repetitionPeriod4                       INTEGER (1..3),
    repetitionPeriod8                       INTEGER (1..7),
    repetitionPeriod16                      INTEGER (1..15),
    repetitionPeriod32                      INTEGER (1..31),
    repetitionPeriod64                      INTEGER (1..63)
}

RepetitionPeriodLengthAndOffset ::= CHOICE {
    repetitionPeriod1                       NULL,
    repetitionPeriod2                       SEQUENCE {
        length                                  NULL,
        offset                                  INTEGER (0..1)
    },
    repetitionPeriod4                       SEQUENCE {
        length                                  INTEGER (1..3),
        offset                                  INTEGER (0..3)
    },
    repetitionPeriod8                       SEQUENCE {
        length                                  INTEGER (1..7),
        offset                                  INTEGER (0..7)
    },
    repetitionPeriod16                      SEQUENCE {
        length                                  INTEGER (1..15),
        offset                                  INTEGER (0..15)
    },
    repetitionPeriod32                      SEQUENCE {
        length                                  INTEGER (1..31),
        offset                                  INTEGER (0..31)
    },
    repetitionPeriod64                      SEQUENCE {
        length                                  INTEGER (1..63),
        offset                                  INTEGER (0..63)
    }
}

ReplacedPDSCH-CodeInfo ::=          SEQUENCE {
    tfci-Field2                             MaxTFCI-Field2Value,
    spreadingFactor                         SF-PDSCH,
    codeNumber                              CodeNumberDSCH,
    multiCodeInfo                           MultiCodeInfo
}

ReplacedPDSCH-CodeInfoList ::=      SEQUENCE (SIZE (1..maxTFCI-2-Combs)) OF
                                        ReplacedPDSCH-CodeInfo

RepPerLengthOffset-PICH ::=         CHOICE {
    rpp4-2                                  INTEGER (0..3),
    rpp8-2                                  INTEGER (0..7),
    rpp8-4                                  INTEGER (0..7),
    rpp16-2                                 INTEGER (0..15),
    rpp16-4                                 INTEGER (0..15),
    rpp32-2                                 INTEGER (0..31),
    rpp32-4                                 INTEGER (0..31),
    rpp64-2                                 INTEGER (0..63),
    rpp64-4                                 INTEGER (0..63)
}
```

```
RepPerLengthOffset-MICH ::=         CHOICE {
    rpp4-2                              INTEGER (0..3),
    rpp8-2                              INTEGER (0..7),
    rpp8-4                              INTEGER (0..7),
    rpp16-2                             INTEGER (0..15),
    rpp16-4                             INTEGER (0..15),
    rpp32-2                             INTEGER (0..31),
    rpp32-4                             INTEGER (0..31),
    rpp64-2                             INTEGER (0..63),
    rpp64-4                             INTEGER (0..63)
}

RestrictedTrCH ::=                  SEQUENCE {
    dl-restrictedTrCh-Type              DL-TrCH-Type,
    restrictedDL-TrCH-Identity          TransportChannelIdentity,
    allowedTFIList                      AllowedTFI-List
}

RestrictedTrCH-InfoList ::=         SEQUENCE (SIZE(1..maxTrCH)) OF
                                        RestrictedTrCH

RL-AdditionInformation ::=          SEQUENCE {
    primaryCPICH-Info                   PrimaryCPICH-Info,
    dl-DPCH-InfoPerRL                   DL-DPCH-InfoPerRL,
    -- dummy and dummy2 are not used in this version of specification
    -- and the IEs should be ignored.
    dummy                               BOOLEAN,
    dummy2                              SCCPCH-InfoForFACH              OPTIONAL
}

RL-AdditionInformation-r6 ::=       SEQUENCE {
    primaryCPICH-Info                   PrimaryCPICH-Info,
    cell-Id                             CellIdentity                    OPTIONAL,
    dl-dpchInfo                         CHOICE {
        dl-DPCH-InfoPerRL                   DL-DPCH-InfoPerRL-r5,
        dl-FDPCH-InfoPerRL                  DL-FDPCH-InfoPerRL-r6
    },
    e-HICH-Information                  E-HICH-Information              OPTIONAL,
    e-RGCH-Information                  E-RGCH-Information              OPTIONAL
}

RL-AdditionInformationList ::=      SEQUENCE (SIZE (1..maxRL-1)) OF
                                        RL-AdditionInformation

RL-AdditionInformationList-r6 ::=   SEQUENCE (SIZE (1..maxRL-1)) OF
                                        RL-AdditionInformation-r6

RL-IdentifierList ::=               SEQUENCE (SIZE (1..maxRL)) OF
                                        PrimaryCPICH-Info

RL-RemovalInformationList ::=       SEQUENCE (SIZE (1..maxRL)) OF
                                        PrimaryCPICH-Info

RPP ::=                             ENUMERATED {
                                        mode0, mode1 }

S-Field ::=                         ENUMERATED {
                                        e1bit, e2bits }

SCCPCH-ChannelisationCode ::=       ENUMERATED {
                                        cc16-1, cc16-2, cc16-3, cc16-4,
                                        cc16-5, cc16-6, cc16-7, cc16-8,
                                        cc16-9, cc16-10, cc16-11, cc16-12,
                                        cc16-13, cc16-14, cc16-15, cc16-16 }

SCCPCH-ChannelisationCode-VHCR ::=  ENUMERATED {
                                        cc32-1, cc32-2, cc32-3, cc32-4,
                                        cc32-5, cc32-6, cc32-7, cc32-8,
                                        cc32-9, cc32-10, cc32-11, cc32-12,
                                        cc32-13, cc32-14, cc32-15, cc32-16,
                                        cc32-17, cc32-18, cc32-19, cc32-20,
                                        cc32-21, cc32-22, cc32-23, cc32-24,
                                        cc32-25, cc32-26, cc32-27, cc32-28,
                                        cc32-29, cc32-30, cc32-31, cc32-32 }

SCCPCH-ChannelisationCodeList ::=   SEQUENCE (SIZE (1..16)) OF
                                        SCCPCH-ChannelisationCode
```

```
SCCPCH-ChannelisationCodeList-VHCR ::= SEQUENCE (SIZE (1..32)) OF
                                       SCCPCH-ChannelisationCode-VHCR

SCCPCH-InfoForFACH ::=              SEQUENCE {
    secondaryCCPCH-Info                 SecondaryCCPCH-Info,
    tfcs                                TFCS,
    modeSpecificInfo                CHOICE {
        fdd                             SEQUENCE {
            fach-PCH-InformationList            FACH-PCH-InformationList,
            sib-ReferenceListFACH               SIB-ReferenceListFACH
        },
        tdd                             SEQUENCE {
            fach-PCH-InformationList            FACH-PCH-InformationList
        }
    }
}

SCCPCH-InfoForFACH-r4 ::=           SEQUENCE {
    secondaryCCPCH-Info             SecondaryCCPCH-Info-r4,
    tfcs                            TFCS,
    fach-PCH-InformationList        FACH-PCH-InformationList,
    modeSpecificInfo            CHOICE {
        fdd                         SEQUENCE {
            sib-ReferenceListFACH       SIB-ReferenceListFACH
        },
        tdd                         NULL
    }
}

SCCPCH-SystemInformation ::=        SEQUENCE {
    secondaryCCPCH-Info             SecondaryCCPCH-Info,
    tfcs                            TFCS                            OPTIONAL,
    fach-PCH-InformationList        FACH-PCH-InformationList        OPTIONAL,
    pich-Info                       PICH-Info                       OPTIONAL
}

SCCPCH-SystemInformation-LCR-r4-ext ::= SEQUENCE {
    secondaryCCPCH-LCR-Extensions   SecondaryCCPCH-Info-LCR-r4-ext,
    -- pich-Info in the SCCPCH-SystemInformation IE shall be absent,
    -- and instead the following used.
    pich-Info                   PICH-Info-LCR-r4                    OPTIONAL
}

SCCPCH-SystemInformation-r7 ::=     SEQUENCE {
    secondaryCCPCH-Info             SecondaryCCPCH-Info-r7,
    tfcs                            TFCS                            OPTIONAL,
    fach-PCH-InformationList        FACH-PCH-InformationList        OPTIONAL,
    pich-Info                       PICH-Info-r7                    OPTIONAL
}

SCCPCH-SystemInformationList ::=    SEQUENCE (SIZE (1..maxSCCPCH)) OF
                                       SCCPCH-SystemInformation

SCCPCH-SystemInformationList-r7 ::= SEQUENCE (SIZE (1..maxSCCPCH)) OF
                                       SCCPCH-SystemInformation-r7

-- SCCPCH-SystemInformationList-LCR-r4-ext includes elements additional to those in
-- SCCPCH-SystemInformationList for the 1.28Mcps TDD. The order of the IEs
-- indicates which SCCPCH-SystemInformation-LCR-r4-ext IE extends which
-- SCCPCH-SystemInformation IE.
SCCPCH-SystemInformationList-LCR-r4-ext ::= SEQUENCE (SIZE (1..maxSCCPCH)) OF
                                            SCCPCH-SystemInformation-LCR-r4-ext

-- The SCCPCH-SystemInformation-MBMS-r6 is used for an S-CCPCH dedicated for MBMS purposes.
SCCPCH-SystemInformation-MBMS-r6 ::= SEQUENCE {
    secondaryCCPCHInfo-MBMS         SecondaryCCPCHInfo-MBMS-r6,
    transportFormatCombinationSet   TFCS,
    fachCarryingMCCH                SEQUENCE {
        mcch-transportFormatSet         TransportFormatSet,
        mcch-ConfigurationInfo          MBMS-MCCH-ConfigurationInfo-r6
    },
    fachCarryingMTCH-List           MBMS-FACHCarryingMTCH-List      OPTIONAL,
    -- If schedulingInformation is provided
    fachCarryingMSCH                SEQUENCE {
        msch-transportFormatSet         TransportFormatSet,
        msch-ConfigurationInfo          MBMS-MSCH-ConfigurationInfo-r6
    }       OPTIONAL
```

```
}

-- The SCCPCH-SystemInformation-MBMS-r7 is used for an S-CCPCH dedicated for MBMS purposes.
SCCPCH-SystemInformation-MBMS-r7 ::= SEQUENCE {
    secondaryCCPCHInfo-MBMS             SecondaryCCPCHInfo-MBMS-r7,
    transportFormatCombinationSet       TFCS,
    fachCarryingMCCH                    SEQUENCE {
        mcch-transportFormatSet             TransportFormatSet,
        mcch-ConfigurationInfo              MBMS-MCCH-ConfigurationInfo-r6
    },
    fachCarryingMTCH-List               MBMS-FACHCarryingMTCH-List          OPTIONAL,
    -- If schedulingInformation is provided
    fachCarryingMSCH                    SEQUENCE {
        msch-transportFormatSet             TransportFormatSet,
        msch-ConfigurationInfo              MBMS-MSCH-ConfigurationInfo-r6
    }       OPTIONAL
}

ScramblingCodeChange ::=            ENUMERATED {
                                        codeChange, noCodeChange }

ScramblingCodeType ::=              ENUMERATED {
                                        shortSC,
                                        longSC }

SecondaryCCPCH-Info ::=             SEQUENCE {
    modeSpecificInfo                CHOICE {
        fdd                             SEQUENCE {
            -- dummy1 is not used in this version of the specification and should be ignored.
            dummy1                          PCPICH-UsageForChannelEst,
            -- dummy2 is not used in this version of the specification.  It should not
            -- be sent and if received it should be ignored.
            dummy2                          SecondaryCPICH-Info             OPTIONAL,
            secondaryScramblingCode         SecondaryScramblingCode         OPTIONAL,
            sttd-Indicator                  BOOLEAN,
            sf-AndCodeNumber                SF256-AndCodeNumber,
            pilotSymbolExistence            BOOLEAN,
            tfci-Existence                  BOOLEAN,
            positionFixedOrFlexible         PositionFixedOrFlexible,
            timingOffset                    TimingOffset                    DEFAULT 0
        },
        tdd                             SEQUENCE {
            -- TABULAR: the offset is included in CommonTimeslotInfoSCCPCH
            commonTimeslotInfo              CommonTimeslotInfoSCCPCH,
            individualTimeslotInfo          IndividualTimeslotInfo,
            channelisationCode              SCCPCH-ChannelisationCodeList
        }
    }
}

SecondaryCCPCH-Info-r4 ::=      SEQUENCE {
    modeSpecificInfo                CHOICE {
        fdd                             SEQUENCE {
            secondaryScramblingCode         SecondaryScramblingCode         OPTIONAL,
            sttd-Indicator                  BOOLEAN,
            sf-AndCodeNumber                SF256-AndCodeNumber,
            pilotSymbolExistence            BOOLEAN,
            tfci-Existence                  BOOLEAN,
            positionFixedOrFlexible         PositionFixedOrFlexible,
            timingOffset                    TimingOffset                    DEFAULT 0
        },
        tdd                             SEQUENCE {
            -- TABULAR: the offset is included in CommonTimeslotInfoSCCPCH
            commonTimeslotInfo              CommonTimeslotInfoSCCPCH,
            tddOption                       CHOICE {
                tdd384                          SEQUENCE {
                    individualTimeslotInfo          IndividualTimeslotInfo
                },
                tdd128                          SEQUENCE {
                    individualTimeslotInfo          IndividualTimeslotInfo-LCR-r4
                }
            },
            channelisationCode              SCCPCH-ChannelisationCodeList
        }
    }
}

SecondaryCCPCH-Info-r7 ::=      SEQUENCE {
```

```
    modeSpecificInfo                CHOICE {
        fdd                             SEQUENCE {
            secondaryScramblingCode         SecondaryScramblingCode         OPTIONAL,
            sttd-Indicator                  BOOLEAN,
            sf-AndCodeNumber                SF256-AndCodeNumber,
            pilotSymbolExistence            BOOLEAN,
            tfci-Existence                  BOOLEAN,
            positionFixedOrFlexible         PositionFixedOrFlexible,
            timingOffset                    TimingOffset                    DEFAULT 0
        },
        tdd                             SEQUENCE {
            -- TABULAR: the offset is included in CommonTimeslotInfoSCCPCH
            commonTimeslotInfo              CommonTimeslotInfoSCCPCH,
            tddOption                       CHOICE {
                tdd384                          SEQUENCE {
                    individualTimeslotInfo          IndividualTimeslotInfo,
                    channelisationCode              SCCPCH-ChannelisationCodeList
                },
                tdd768                          SEQUENCE {
                    individualTimeslotInfo          IndividualTimeslotInfo-VHCR,
                    channelisationCode              SCCPCH-ChannelisationCodeList-VHCR
                },
                tdd128                          SEQUENCE {
                    individualTimeslotInfo          IndividualTimeslotInfo-LCR-r4,
                    channelisationCode              SCCPCH-ChannelisationCodeList
                }
            }
        }
    }
}

SecondaryCCPCH-Info-LCR-r4-ext ::=  SEQUENCE {
    individualTimeslotLCR-Ext           IndividualTimeslotInfo-LCR-r4-ext
}

SecondaryCCPCHInfo-MBMS-r6 ::=      SEQUENCE {
    modeSpecificInfo                CHOICE {
        fdd                             SEQUENCE {
            secondaryScramblingCode         SecondaryScramblingCode         OPTIONAL,
            sttd-Indicator                  BOOLEAN,
            sf-AndCodeNumber                SF256-AndCodeNumber,
            timingOffset                    TimingOffset                    DEFAULT 0
        },
        tdd384                          DownlinkTimeslotsCodes,
        tdd128                          DownlinkTimeslotsCodes-LCR-r4
    }
}

SecondaryCCPCHInfo-MBMS-r7 ::=      SEQUENCE {
    modeSpecificInfo                CHOICE {
        fdd                             SEQUENCE {
            secondaryScramblingCode         SecondaryScramblingCode         OPTIONAL,
            sttd-Indicator                  BOOLEAN,
            sf-AndCodeNumber                SF256-AndCodeNumber,
            timingOffset                    TimingOffset                    DEFAULT 0
        },
        tdd384                          DownlinkTimeslotsCodes,
        tdd768                          DownlinkTimeslotsCodes-VHCR,
        tdd128                          DownlinkTimeslotsCodes-LCR-r4
    }
}

SecondaryCPICH-Info ::=             SEQUENCE {
    secondaryDL-ScramblingCode          SecondaryScramblingCode             OPTIONAL,
    channelisationCode                  ChannelisationCode256
}

SecondaryScramblingCode ::=         INTEGER (1..15)

SecondInterleavingMode ::=          ENUMERATED {
                                        frameRelated, timeslotRelated }

-- SF256-AndCodeNumber encodes both "Spreading factor" and "Code Number"
SF256-AndCodeNumber ::=             CHOICE {
    sf4                                 INTEGER (0..3),
    sf8                                 INTEGER (0..7),
    sf16                                INTEGER (0..15),
    sf32                                INTEGER (0..31),
```

```
    sf64                                INTEGER (0..63),
    sf128                               INTEGER (0..127),
    sf256                               INTEGER (0..255)
}

-- SF512-AndCodeNumber encodes both "Spreading factor" and "Code Number"
SF512-AndCodeNumber ::=             CHOICE {
    sf4                                 INTEGER (0..3),
    sf8                                 INTEGER (0..7),
    sf16                                INTEGER (0..15),
    sf32                                INTEGER (0..31),
    sf64                                INTEGER (0..63),
    sf128                               INTEGER (0..127),
    sf256                               INTEGER (0..255),
    sf512                               INTEGER (0..511)
}

-- SF512-AndPilot encodes both "Spreading factor" and "Number of bits for Pilot bits"
SF512-AndPilot ::=                  CHOICE {
    sfd4                                NULL,
    sfd8                                NULL,
    sfd16                               NULL,
    sfd32                               NULL,
    sfd64                               NULL,
    sfd128                              PilotBits128,
    sfd256                              PilotBits256,
    sfd512                              NULL
}
SF-PDSCH ::=                        ENUMERATED {
                                        sfp4, sfp8, sfp16, sfp32,
                                        sfp64, sfp128, sfp256 }

SF-PRACH ::=                        ENUMERATED {
                                        sfpr32, sfpr64, sfpr128, sfpr256 }

SFN-TimeInfo ::=                    SEQUENCE {
    activationTimeSFN                   INTEGER (0..4095),
    physChDuration                  DurationTimeInfo
}

-- actual scheduling value = 2^(signalled value +1) and is the periodicity of sending special burst frames
SpecialBurstScheduling ::=              INTEGER (0..7)

SpreadingFactor ::=                 ENUMERATED {
                                        sf4, sf8, sf16, sf32,
                                        sf64, sf128, sf256 }

SRB-delay ::=                       INTEGER (0..7)

SSDT-CellIdentity ::=               ENUMERATED {
                                        ssdt-id-a, ssdt-id-b, ssdt-id-c,
                                        ssdt-id-d, ssdt-id-e, ssdt-id-f,
                                        ssdt-id-g, ssdt-id-h }

SSDT-Information ::=                SEQUENCE {
    s-Field                             S-Field,
    codeWordSet                         CodeWordSet
}

SSDT-Information-r4 ::=             SEQUENCE {
    s-Field                             S-Field,
    codeWordSet                         CodeWordSet,
    ssdt-UL-r4                          SSDT-UL                                 OPTIONAL
}

SSDT-UL ::=                         ENUMERATED {
                                        ul, ul-AndDL }

SynchronisationParameters-r4 ::=    SEQUENCE {
    sync-UL-CodesBitmap                 BIT STRING {
                                            code7(0),
                                            code6(1),
                                            code5(2),
                                            code4(3),
                                            code3(4),
                                            code2(5),
                                            code1(6),
                                            code0(7)
```

```
                                        } (SIZE (8)),
    fpach-Info                          FPACH-Info-r4,
    -- Actual value prxUpPCHdes = IE value - 120
    prxUpPCHdes                         INTEGER (0..62),
    sync-UL-Procedure                   SYNC-UL-Procedure-r4                    OPTIONAL
}

SYNC-UL-Procedure-r4 ::=            SEQUENCE {
    max-SYNC-UL-Transmissions           ENUMERATED { tr1, tr2, tr4, tr8 },
    powerRampStep                       INTEGER (0..3)
}

SYNC-UL-Info-r4 ::=                 SEQUENCE {
    sync-UL-Codes-Bitmap                BIT STRING {
                                            code7(0),
                                            code6(1),
                                            code5(2),
                                            code4(3),
                                            code3(4),
                                            code2(5),
                                            code1(6),
                                            code0(7)
                                            } ( SIZE (8)),
    -- Actual value prxUpPCHdes = IE value - 120
    prxUpPCHdes                         INTEGER (0..62),
    powerRampStep                       INTEGER (0..3),
    max-SYNC-UL-Transmissions           ENUMERATED { tr1, tr2, tr4, tr8 } ,
    mmax                                INTEGER(1..32)
}

TDD-FPACH-CCode16-r4 ::=            ENUMERATED {
                                        cc16-1, cc16-2, cc16-3, cc16-4,
                                        cc16-5, cc16-6, cc16-7, cc16-8,
                                        cc16-9, cc16-10, cc16-11, cc16-12,
                                        cc16-13, cc16-14, cc16-15, cc16-16 }

TDD-UL-Interference ::=             INTEGER (-110..-52)

TDD-PICH-CCode ::=                  ENUMERATED {
                                        cc16-1, cc16-2, cc16-3, cc16-4,
                                        cc16-5, cc16-6, cc16-7, cc16-8,
                                        cc16-9, cc16-10, cc16-11, cc16-12,
                                        cc16-13, cc16-14, cc16-15, cc16-16 }

TDD768-PICH-CCode ::=               ENUMERATED {
                                        cc32-1, cc32-2, cc32-3, cc32-4,
                                        cc32-5, cc32-6, cc32-7, cc32-8,
                                        cc32-9, cc32-10, cc32-11, cc32-12,
                                        cc32-13, cc32-14, cc32-15, cc32-16,
                                        cc32-17, cc32-18, cc32-19, cc32-20,
                                        cc32-21, cc32-22, cc32-23, cc32-24,
                                        cc32-25, cc32-26, cc32-27, cc32-28,
                                        cc32-29, cc32-30, cc32-31, cc32-32 }

TDD-PRACH-CCode8 ::=                ENUMERATED {
                                        cc8-1, cc8-2, cc8-3, cc8-4,
                                        cc8-5, cc8-6, cc8-7, cc8-8 }

TDD-PRACH-CCode16 ::=               ENUMERATED {
                                        cc16-1, cc16-2, cc16-3, cc16-4,
                                        cc16-5, cc16-6, cc16-7, cc16-8,
                                        cc16-9, cc16-10, cc16-11, cc16-12,
                                        cc16-13, cc16-14, cc16-15, cc16-16 }

TDD-PRACH-CCode-LCR-r4 ::=          ENUMERATED {
                                        cc4-1, cc4-2, cc4-3, cc4-4,
                                        cc8-1, cc8-2, cc8-3, cc8-4,
                                        cc8-5, cc8-6, cc8-7, cc8-8,
                                        cc16-1, cc16-2, cc16-3, cc16-4,
                                        cc16-5, cc16-6, cc16-7, cc16-8,
                                        cc16-9, cc16-10, cc16-11, cc16-12,
                                        cc16-13, cc16-14, cc16-15, cc16-16 }

TDD-PRACH-CCodeList ::=             CHOICE {
    sf8                                 SEQUENCE (SIZE (1..8)) OF
                                            TDD-PRACH-CCode8,
-- Channelisation codes cc16-9, cc16-10, cc16-11, cc16-12, cc16-13, cc16-14,
-- cc16-15 and cc16-16 shall not be used
```

```
    sf16                                SEQUENCE (SIZE (1..8)) OF
                                            TDD-PRACH-CCode16
}

TDD768-PRACH-CCode8 ::=             ENUMERATED {
                                        cc8-1, cc8-2, cc8-3, cc8-4,
                                        cc8-5, cc8-6, cc8-7, cc8-8 }

TDD768-PRACH-CCode16 ::=                ENUMERATED {
                                        cc16-1, cc16-2, cc16-3, cc16-4,
                                        cc16-5, cc16-6, cc16-7, cc16-8,
                                        cc16-9, cc16-10, cc16-11, cc16-12,
                                        cc16-13, cc16-14, cc16-15, cc16-16 }

TDD768-PRACH-CCode32 ::=                ENUMERATED {
                                        cc32-1, cc32-2, cc32-3, cc32-4,
                                        cc32-5, cc32-6, cc32-7, cc32-8,
                                        cc32-9, cc32-10, cc32-11, cc32-12,
                                        cc32-13, cc32-14, cc32-15, cc32-16 }

TDD768-PRACH-CCodeList ::=          CHOICE {
    sf32                                SEQUENCE (SIZE (1..16)) OF
                                            TDD768-PRACH-CCode32,
-- Channelisation codes cc32-17, cc32-18, cc32-19, cc32-20, cc32-21, cc32-22,
-- cc32-23, cc32-24, cc32-25, cc32-26, cc32-27, cc32-28, cc32-29, cc32-30, cc32-31
-- and cc32-32 shall not be used
    sf16                                SEQUENCE (SIZE (1..16)) OF
                                            TDD768-PRACH-CCode16,
    sf8                                 SEQUENCE (SIZE (1..8)) OF
                                            TDD768-PRACH-CCode8
}

TFC-ControlDuration ::=             ENUMERATED {
                                        tfc-cd1, tfc-cd2, tfc-cd4, tfc-cd8,
                                        tfc-cd16, tfc-cd24, tfc-cd32,
                                        tfc-cd48, tfc-cd64, tfc-cd128,
                                        tfc-cd192, tfc-cd256, tfc-cd512 }

TFCI-Coding ::=                     ENUMERATED {
                                        tfci-bits-4, tfci-bits-8,
                                        tfci-bits-16, tfci-bits-32 }

TGCFN ::=                           INTEGER (0..255)

-- In TGD, value 270 represents "undefined" in the tabular description.
TGD ::=                             INTEGER (15..270)

TGL ::=                             INTEGER (1..14)

TGMP ::=                            ENUMERATED {
                                        tdd-Measurement, fdd-Measurement,
                                        gsm-CarrierRSSIMeasurement,
                                        gsm-initialBSICIdentification, gsmBSICReconfirmation,
                                        multi-carrier }

TGP-Sequence ::=                    SEQUENCE {
    tgpsi                               TGPSI,
    tgps-Status                         CHOICE {
        activate                            SEQUENCE {
            tgcfn                               TGCFN
        },
        deactivate                          NULL
    },
    tgps-ConfigurationParams            TGPS-ConfigurationParams           OPTIONAL
}

TGPS-Reconfiguration-CFN ::=        INTEGER (0..255)

TGP-SequenceList ::=                SEQUENCE (SIZE (1..maxTGPS)) OF
                                        TGP-Sequence

TGP-SequenceShort ::=               SEQUENCE {
    tgpsi                               TGPSI,
    tgps-Status                         CHOICE {
        activate                            SEQUENCE {
            tgcfn                               TGCFN
        },
        deactivate                          NULL
```

```
    }
}

TGPL ::=                            INTEGER (1..144)

-- TABULAR: In TGPRC, value 0 represents "infinity" in the tabular description.
TGPRC ::=                           INTEGER (0..511)

TGPS-ConfigurationParams ::=        SEQUENCE {
    tgmp                                TGMP,
    tgprc                               TGPRC,
    tgsn                                TGSN,
    tgl1                                TGL,
    tgl2                                TGL                                 OPTIONAL,
    tgd                                 TGD,
    tgpl1                               TGPL,
    -- dummy is not used in this version of the specification, it should
    -- not be sent and if received it shall be ignored.
    dummy                           TGPL                                OPTIONAL,
    rpp                                 RPP,
    itp                                 ITP,
    -- TABULAR: Compressed mode method is nested inside UL-DL-Mode
    ul-DL-Mode                          UL-DL-Mode,
    dl-FrameType                        DL-FrameType,
    deltaSIR1                           DeltaSIR,
    deltaSIRAfter1                      DeltaSIR,
    deltaSIR2                           DeltaSIR                            OPTIONAL,
    deltaSIRAfter2                      DeltaSIR                            OPTIONAL,
    nidentifyAbort                      NidentifyAbort                      OPTIONAL,
    treconfirmAbort                     TreconfirmAbort                     OPTIONAL
}

TGPSI ::=                           INTEGER (1..maxTGPS)

TGSN ::=                            INTEGER (0..14)

TimeInfo ::=                        SEQUENCE {
    activationTime                      ActivationTime                      OPTIONAL,
    durationTimeInfo                    DurationTimeInfo                    OPTIONAL
}

TimeslotList ::=                    SEQUENCE (SIZE (1..maxTS)) OF
                                        TimeslotNumber

TimeslotList-r4 ::=                 CHOICE {
-- the choice for 7.68 Mcps TDD is as for 3.84 Mcps TDD  --
    tdd384                              SEQUENCE (SIZE (1..maxTS)) OF
                                            TimeslotNumber,
    tdd128                              SEQUENCE (SIZE (1..maxTS-LCR)) OF
                                            TimeslotNumber-LCR-r4
}

-- If TimeslotNumber is included for a 1.28Mcps TDD description, it shall take values from 0..6
TimeslotNumber ::=                  INTEGER (0..14)

TimeslotNumber-LCR-r4 ::=           INTEGER (0..6)

TimeslotNumber-PRACH-LCR-r4 ::=     INTEGER (1..6)

TimeslotSync2 ::=               INTEGER (0..6)

-- Actual value TimingOffset = IE value * 256
TimingOffset ::=                    INTEGER (0..149)

TimingMaintainedSynchInd ::=        ENUMERATED { false }

TPC-CombinationIndex ::=            INTEGER (0..5)

TPC-CommandTargetRate ::=           ENUMERATED  {
                                        zerop01, zerop02, zerop03, zerop04, zerop05,
                                        zerop06, zerop07, zerop08, zerop09, zerop10 }

-- Actual value TPC-StepSizeFDD = IE value + 1
TPC-StepSizeFDD ::=                 INTEGER (0..1)

TPC-StepSizeTDD ::=                 INTEGER (1..3)

-- Actual value TreconfirmAbort = IE value * 0.5 seconds
```

```
TreconfirmAbort ::= INTEGER (1..20)

TX-DiversityMode ::=                ENUMERATED {
                                        noDiversity,
                                        sttd,
                                        closedLoopMode1,
        -- dummy is not used in this version of the specification, it should
        -- not be sent and if received it should be ignored.
                                        dummy }

UARFCN ::=                      INTEGER (0..16383)

UCSM-Info ::=                       SEQUENCE {
    minimumSpreadingFactor              MinimumSpreadingFactor,
    nf-Max                              NF-Max,
    channelReqParamsForUCSM             ChannelReqParamsForUCSM
}

UL-CCTrCH ::=                       SEQUENCE {
    tfcs-ID                             TFCS-IdentityPlain                  DEFAULT 1,
    ul-TargetSIR                        UL-TargetSIR,
    timeInfo                            TimeInfo,
    commonTimeslotInfo                  CommonTimeslotInfo                  OPTIONAL,
    ul-CCTrCH-TimeslotsCodes            UplinkTimeslotsCodes                OPTIONAL
}

UL-CCTrCH-r4 ::=                    SEQUENCE {
    tfcs-ID                             TFCS-IdentityPlain                  DEFAULT 1,
    -- The IE ul-TargetSIR corresponds to PRX-DPCHdes for 1.28Mcps TDD
    -- Actual value PRX-DPCHdes = (value of IE "ul-TargetSIR" - 120)
    ul-TargetSIR                        UL-TargetSIR,
    timeInfo                            TimeInfo,
    commonTimeslotInfo                  CommonTimeslotInfo                  OPTIONAL,
    tddOption                           CHOICE {
        tdd384                              SEQUENCE {
            ul-CCTrCH-TimeslotsCodes            UplinkTimeslotsCodes        OPTIONAL
        },
        tdd128                              SEQUENCE {
            ul-CCTrCH-TimeslotsCodes            UplinkTimeslotsCodes-LCR-r4 OPTIONAL
        }
    }
}

UL-CCTrCH-r7 ::=                    SEQUENCE {
    tfcs-ID                             TFCS-IdentityPlain                  DEFAULT 1,
    -- The IE ul-TargetSIR corresponds to PRX-DPCHdes for 1.28Mcps TDD
    -- Actual value PRX-DPCHdes = (value of IE "ul-TargetSIR" - 120)
    ul-TargetSIR                        UL-TargetSIR,
    timeInfo                            TimeInfo,
    commonTimeslotInfo                  CommonTimeslotInfo                  OPTIONAL,
    tddOption                           CHOICE {
        tdd384                              SEQUENCE {
            ul-CCTrCH-TimeslotsCodes            UplinkTimeslotsCodes        OPTIONAL
        },
        tdd768                              SEQUENCE {
            ul-CCTrCH-TimeslotsCodes            UplinkTimeslotsCodes-VHCR   OPTIONAL
        },
        tdd128                              SEQUENCE {
            ul-CCTrCH-TimeslotsCodes            UplinkTimeslotsCodes-LCR-r7 OPTIONAL
        }
    }
}

UL-CCTrCHList ::=                   SEQUENCE (SIZE (1..maxCCTrCH)) OF
                                        UL-CCTrCH

UL-CCTrCHList-r4 ::=                SEQUENCE (SIZE (1..maxCCTrCH)) OF
                                        UL-CCTrCH-r4

UL-CCTrCHList-r7 ::=                SEQUENCE (SIZE (1..maxCCTrCH)) OF
                                        UL-CCTrCH-r7

UL-CCTrCHListToRemove ::=           SEQUENCE (SIZE (1..maxCCTrCH)) OF
                                        TFCS-IdentityPlain

UL-CCTrChTPCList ::=                SEQUENCE (SIZE (0..maxCCTrCH)) OF
                                            TFCS-Identity
```

```
UL-ChannelRequirement ::=           CHOICE {
    ul-DPCH-Info                        UL-DPCH-Info,
    -- dummy is not used in this version of the specification, it should
    -- not be sent and if received the UE behaviour is not specified.
    dummy                               CPCH-SetInfo
}

UL-ChannelRequirement-r4 ::=        CHOICE {
    ul-DPCH-Info                        UL-DPCH-Info-r4,
    -- dummy is not used in this version of the specification, it should
    -- not be sent and if received the UE behaviour is not specified.
    dummy                               CPCH-SetInfo
}

UL-ChannelRequirement-r5 ::=        CHOICE {
    ul-DPCH-Info                        UL-DPCH-Info-r5,
    -- dummy is not used in this version of the specification, it should
    -- not be sent and if received the UE behaviour is not specified.
    dummy                               CPCH-SetInfo
}

-- Note: the reference to CPCH in the element name below is incorrect. The name is not
-- changed to keep it aligned with R99.
UL-ChannelRequirementWithCPCH-SetID ::= CHOICE {
    ul-DPCH-Info                        UL-DPCH-Info,
    -- dummy1 and dummy 2 are not used in this version of the specification, they should
    -- not be sent and if received the UE behaviour is not specified.
    dummy1                              CPCH-SetInfo,
    dummy2                              CPCH-SetID
}

-- Note: the reference to CPCH in the element name below is incorrect. The name is not
-- changed to keep it aligned with R99.
UL-ChannelRequirementWithCPCH-SetID-r4 ::=  CHOICE {
    ul-DPCH-Info                        UL-DPCH-Info-r4,
    -- dummy1 and dummy2 are not used in this version of the specification, they
    -- should not be sent and if received the UE behaviour is not specified.
    dummy1                              CPCH-SetInfo,
    dummy2                              CPCH-SetID
}

-- Note: the reference to CPCH in the element name below is incorrect. The name is not
-- changed to keep it aligned with R99.
UL-ChannelRequirementWithCPCH-SetID-r5 ::=  CHOICE {
    ul-DPCH-Info                        UL-DPCH-Info-r5,
    -- dummy1 and dummy2 are not used in this version of the specification, they should
    -- not be sent and if received the UE behaviour is not specified.
    dummy1                              CPCH-SetInfo,
    dummy2                              CPCH-SetID
}

UL-CompressedModeMethod ::=         ENUMERATED {
                                        sf-2,
                                        higherLayerScheduling }

UL-DL-Mode ::=                      CHOICE {
    ul                                  UL-CompressedModeMethod,
    dl                                  DL-CompressedModeMethod,
    ul-and-dl                               SEQUENCE {
        ul                                  UL-CompressedModeMethod,
        dl                                  DL-CompressedModeMethod
    }}

UL-DPCCH-SlotFormat ::=             ENUMERATED {
                                        slf0, slf1, slf2 }

UL-DPCH-Info ::=                    SEQUENCE {
    ul-DPCH-PowerControlInfo            UL-DPCH-PowerControlInfo            OPTIONAL,
    modeSpecificInfo                    CHOICE {
        fdd                                 SEQUENCE {
            scramblingCodeType                  ScramblingCodeType,
            scramblingCode                      UL-ScramblingCode,
            numberOfDPDCH                       NumberOfDPDCH               DEFAULT 1,
            spreadingFactor                     SpreadingFactor,
            tfci-Existence                      BOOLEAN,
            -- numberOfFBI-Bits is conditional based on history
            numberOfFBI-Bits                    NumberOfFBI-Bits            OPTIONAL,
            puncturingLimit                     PuncturingLimit
```

```
        },
        tdd                                 SEQUENCE {
            ul-TimingAdvance                    UL-TimingAdvanceControl     OPTIONAL,
            ul-CCTrCHList                       UL-CCTrCHList               OPTIONAL,
            ul-CCTrCHListToRemove               UL-CCTrCHListToRemove       OPTIONAL
        }
    }
}

UL-DPCH-Info-r4 ::=                 SEQUENCE {
    ul-DPCH-PowerControlInfo            UL-DPCH-PowerControlInfo-r4         OPTIONAL,
    modeSpecificInfo                    CHOICE {
        fdd                                 SEQUENCE {
            scramblingCodeType                  ScramblingCodeType,
            scramblingCode                      UL-ScramblingCode,
            numberOfDPDCH                       NumberOfDPDCH               DEFAULT 1,
            spreadingFactor                     SpreadingFactor,
            tfci-Existence                      BOOLEAN,
            -- numberOfFBI-Bits is conditional based on history
            numberOfFBI-Bits                    NumberOfFBI-Bits            OPTIONAL,
            puncturingLimit                     PuncturingLimit
        },
        tdd                                 SEQUENCE {
            ul-TimingAdvance                    UL-TimingAdvanceControl-r4  OPTIONAL,
            ul-CCTrCHList                       UL-CCTrCHList-r4            OPTIONAL,
            ul-CCTrCHListToRemove               UL-CCTrCHListToRemove       OPTIONAL
        }
    }
}

UL-DPCH-Info-r5 ::=                 SEQUENCE {
    ul-DPCH-PowerControlInfo            UL-DPCH-PowerControlInfo-r5         OPTIONAL,
    modeSpecificInfo                    CHOICE {
        fdd                                 SEQUENCE {
            scramblingCodeType                  ScramblingCodeType,
            scramblingCode                      UL-ScramblingCode,
            numberOfDPDCH                       NumberOfDPDCH               DEFAULT 1,
            spreadingFactor                     SpreadingFactor,
            tfci-Existence                      BOOLEAN,
            -- numberOfFBI-Bits is conditional based on history
            numberOfFBI-Bits                    NumberOfFBI-Bits            OPTIONAL,
            puncturingLimit                     PuncturingLimit
        },
        tdd                                 SEQUENCE {
            ul-TimingAdvance                    UL-TimingAdvanceControl-r4  OPTIONAL,
            ul-CCTrCHList                       UL-CCTrCHList-r4            OPTIONAL,
            ul-CCTrCHListToRemove               UL-CCTrCHListToRemove       OPTIONAL
        }
    }
}

UL-DPCH-Info-r6 ::=                 SEQUENCE {
    ul-DPCH-PowerControlInfo            UL-DPCH-PowerControlInfo-r6         OPTIONAL,
    modeSpecificInfo                    CHOICE {
        fdd                                 SEQUENCE {
            scramblingCodeType                  ScramblingCodeType,
            scramblingCode                      UL-ScramblingCode,
            dpdchPresence                       CHOICE {
                present                             SEQUENCE {
                    numberOfDPDCH                       NumberOfDPDCH               DEFAULT 1,
                    spreadingFactor                     SpreadingFactor,
                    tfci-Existence                      BOOLEAN,
                    -- numberOfFBI-Bits is conditional based on history
                    numberOfFBI-Bits                    NumberOfFBI-Bits            OPTIONAL,
                    puncturingLimit                     PuncturingLimit
                },
                notPresent                          SEQUENCE {
                    tfci-Existence                      BOOLEAN,
                    -- numberOfFBI-Bits is conditional based on history
                    numberOfFBI-Bits                    NumberOfFBI-Bits            OPTIONAL
                }
            }
        },
        tdd                                 SEQUENCE {
            ul-TimingAdvance                    UL-TimingAdvanceControl-r4  OPTIONAL,
            ul-CCTrCHList                       UL-CCTrCHList-r4            OPTIONAL,
            ul-CCTrCHListToRemove               UL-CCTrCHListToRemove       OPTIONAL
        }
```

```
    }
}

UL-DPCH-Info-r7 ::=                 SEQUENCE {
    ul-DPCH-PowerControlInfo            UL-DPCH-PowerControlInfo-r6         OPTIONAL,
    modeSpecificInfo                    CHOICE {
        fdd                                 SEQUENCE {
            scramblingCodeType                  ScramblingCodeType,
            scramblingCode                      UL-ScramblingCode,
            dpdchPresence                       CHOICE {
                present                             SEQUENCE {
                    numberOfDPDCH                       NumberOfDPDCH               DEFAULT 1,
                    spreadingFactor                     SpreadingFactor,
                    tfci-Existence                      BOOLEAN,
                    -- numberOfFBI-Bits is conditional based on history
                    numberOfFBI-Bits                    NumberOfFBI-Bits            OPTIONAL,
                    puncturingLimit                     PuncturingLimit
                        },
                notPresent                          SEQUENCE {
                    tfci-Existence                      BOOLEAN,
                    -- numberOfFBI-Bits is conditional based on history
                    numberOfFBI-Bits                    NumberOfFBI-Bits            OPTIONAL
                }
            }
        },
        tdd                                 SEQUENCE {
            ul-TimingAdvance                    UL-TimingAdvanceControl-r7  OPTIONAL,
            ul-CCTrCHList                       UL-CCTrCHList-r7            OPTIONAL,
            ul-CCTrCHListToRemove               UL-CCTrCHListToRemove       OPTIONAL
        }
    }
}

UL-DPCH-InfoPostFDD ::=             SEQUENCE {
    ul-DPCH-PowerControlInfo            UL-DPCH-PowerControlInfoPostFDD,
            scramblingCodeType                  ScramblingCodeType,
            reducedScramblingCodeNumber         ReducedScramblingCodeNumber,
            spreadingFactor                     SpreadingFactor

}

UL-DPCH-InfoPostTDD ::=             SEQUENCE {
    ul-DPCH-PowerControlInfo            UL-DPCH-PowerControlInfoPostTDD,
    ul-TimingAdvance                    UL-TimingAdvanceControl                 OPTIONAL,
    ul-CCTrCH-TimeslotsCodes            UplinkTimeslotsCodes
}

UL-DPCH-InfoPostTDD-LCR-r4 ::=      SEQUENCE {
    ul-DPCH-PowerControlInfo            UL-DPCH-PowerControlInfoPostTDD-LCR-r4,
    ul-TimingAdvance                    UL-TimingAdvanceControl-LCR-r4              OPTIONAL,
    ul-CCTrCH-TimeslotsCodes            UplinkTimeslotsCodes-LCR-r4
}

UL-DPCH-InfoPredef ::=              SEQUENCE {
    ul-DPCH-PowerControlInfo            UL-DPCH-PowerControlInfoPredef,
    modeSpecificInfo                    CHOICE {
        fdd                                 SEQUENCE {
            tfci-Existence                      BOOLEAN,
            puncturingLimit                     PuncturingLimit
        },
        tdd                                 SEQUENCE {
            commonTimeslotInfo                  CommonTimeslotInfo
        }
    }
}

UL-DPCH-PowerControlInfo ::=        CHOICE {
    fdd                                 SEQUENCE {
        dpcch-PowerOffset                   DPCCH-PowerOffset,
        pc-Preamble                         PC-Preamble,
        sRB-delay                           SRB-delay,
        -- TABULAR: TPC step size nested inside PowerControlAlgorithm
        powerControlAlgorithm               PowerControlAlgorithm
    },
    tdd                                 SEQUENCE {
        ul-TargetSIR                        UL-TargetSIR                OPTIONAL,
        ul-OL-PC-Signalling                 CHOICE {
            broadcast-UL-OL-PC-info             NULL,
```

```
            individuallySignalled               SEQUENCE {
                individualTS-InterferenceList       IndividualTS-InterferenceList,
                dpch-ConstantValue                  ConstantValueTdd,
                primaryCCPCH-TX-Power               PrimaryCCPCH-TX-Power
            }
        }                                                               OPTIONAL
    }
}

UL-DPCH-PowerControlInfo-r4 ::=     CHOICE {
    fdd                                 SEQUENCE {
        dpcch-PowerOffset                   DPCCH-PowerOffset,
        pc-Preamble                         PC-Preamble,
        sRB-delay                           SRB-delay,
        -- TABULAR: TPC step size nested inside PowerControlAlgorithm
        powerControlAlgorithm               PowerControlAlgorithm
    },
    tdd                                 SEQUENCE {
        -- The IE ul-TargetSIR corresponds to PRX-DPCHdes for 1.28Mcps TDD
        -- Actual value PRX-DPCHdes = (value of IE "ul-TargetSIR" - 120)
        ul-TargetSIR                        UL-TargetSIR                OPTIONAL,
        ul-OL-PC-Signalling                 CHOICE {
            broadcast-UL-OL-PC-info             NULL,
            individuallySignalled               SEQUENCE {
                tddOption                           CHOICE {
                    tdd384                              SEQUENCE {
                        individualTS-InterferenceList       IndividualTS-InterferenceList,
                        dpch-ConstantValue                  ConstantValue
                    },
                    tdd128                              SEQUENCE {
                        tpc-StepSize                        TPC-StepSizeTDD
                    }
                },
                primaryCCPCH-TX-Power               PrimaryCCPCH-TX-Power
            }
        }
    }
}

UL-DPCH-PowerControlInfo-r5 ::=     CHOICE {
    fdd                                 SEQUENCE {
        dpcch-PowerOffset                   DPCCH-PowerOffset,
        pc-Preamble                         PC-Preamble,
        sRB-delay                           SRB-delay,
        -- TABULAR: TPC step size nested inside PowerControlAlgorithm
        powerControlAlgorithm               PowerControlAlgorithm,
        deltaACK                            DeltaACK    OPTIONAL,
        deltaNACK                           DeltaNACK   OPTIONAL,
        ack-NACK-repetition-factor          ACK-NACK-repetitionFactor   OPTIONAL
    },
    tdd                                 SEQUENCE {
        -- The IE ul-TargetSIR corresponds to PRX-DPCHdes for 1.28Mcps TDD
        -- Actual value PRX-DPCHdes = (value of IE "ul-TargetSIR" - 120)
        ul-TargetSIR                        UL-TargetSIR                OPTIONAL,
        ul-OL-PC-Signalling                 CHOICE {
            broadcast-UL-OL-PC-info             NULL,
            individuallySignalled               SEQUENCE {
                tddOption                           CHOICE {
                    tdd384                              SEQUENCE {
                        individualTS-InterferenceList       IndividualTS-InterferenceList,
                        dpch-ConstantValue                  ConstantValue
                    },
                    tdd128                              SEQUENCE {
                        tpc-StepSize                        TPC-StepSizeTDD
                    }
                },
                primaryCCPCH-TX-Power               PrimaryCCPCH-TX-Power
            }
        }
    }
}

UL-DPCH-PowerControlInfo-r6 ::=     CHOICE {
    fdd                                 SEQUENCE {
        dpcch-PowerOffset                   DPCCH-PowerOffset,
        pc-Preamble                         PC-Preamble,
        sRB-delay                           SRB-delay,
        -- TABULAR: TPC step size nested inside PowerControlAlgorithm
```

```
        powerControlAlgorithm               PowerControlAlgorithm,
        deltaACK                            DeltaACK    OPTIONAL,
        deltaNACK                           DeltaNACK   OPTIONAL,
        ack-NACK-repetition-factor          ACK-NACK-repetitionFactor   OPTIONAL,
        harq-Preamble-Mode                  HARQ-Preamble-Mode
    },
    tdd                                 SEQUENCE {
        -- The IE ul-TargetSIR corresponds to PRX-DPCHdes for 1.28Mcps TDD
        -- Actual value PRX-DPCHdes = (value of IE "ul-TargetSIR" - 120)
        ul-TargetSIR                        UL-TargetSIR                OPTIONAL,
        ul-OL-PC-Signalling                 CHOICE {
            broadcast-UL-OL-PC-info             NULL,
            individuallySignalled               SEQUENCE {
                tddOption                           CHOICE {
                    tdd384                              SEQUENCE {
                        individualTS-InterferenceList       IndividualTS-InterferenceList,
                        dpch-ConstantValue                  ConstantValue
                    },
                    tdd128                              SEQUENCE {
                        beaconPLEst                         BEACON-PL-Est       OPTIONAL,
                        tpc-StepSize                        TPC-StepSizeTDD
                    }
                },
                primaryCCPCH-TX-Power               PrimaryCCPCH-TX-Power
            }
        }
    }
}

UL-DPCH-PowerControlInfo-r7 ::=     CHOICE {
    fdd                                 SEQUENCE {
        dpcch-PowerOffset                   DPCCH-PowerOffset,
        pc-Preamble                         PC-Preamble,
        sRB-delay                           SRB-delay,
        -- TABULAR: TPC step size nested inside PowerControlAlgorithm
        powerControlAlgorithm               PowerControlAlgorithm,
        deltaACK                            DeltaACK    OPTIONAL,
        deltaNACK                           DeltaNACK   OPTIONAL,
        ack-NACK-repetition-factor          ACK-NACK-repetitionFactor   OPTIONAL,
        harq-Preamble-Mode                  HARQ-Preamble-Mode
    },
    tdd                                 SEQUENCE {
        -- The IE ul-TargetSIR corresponds to PRX-DPCHdes for 1.28Mcps TDD
        -- Actual value PRX-DPCHdes = (value of IE "ul-TargetSIR" - 120)
        ul-TargetSIR                        UL-TargetSIR                OPTIONAL,
        ul-OL-PC-Signalling                 CHOICE {
            broadcast-UL-OL-PC-info             NULL,
            individuallySignalled               SEQUENCE {
                tddOption                           CHOICE {
                    tdd384                              SEQUENCE {
                        individualTS-InterferenceList       IndividualTS-InterferenceList,
                        dpch-ConstantValue                  ConstantValue
                    },
                    tdd768                              SEQUENCE {
                        individualTS-InterferenceList       IndividualTS-InterferenceList,
                        dpch-ConstantValue                  ConstantValue
                    },
                    tdd128                              SEQUENCE {
                        beaconPLEst                         BEACON-PL-Est       OPTIONAL,
                        tpc-StepSize                        TPC-StepSizeTDD
                    }
                },
                primaryCCPCH-TX-Power               PrimaryCCPCH-TX-Power
            }
        }
    }
}

UL-DPCH-PowerControlInfoPostFDD ::= SEQUENCE {
    -- DPCCH-PowerOffset2 has a smaller range to save bits
    dpcch-PowerOffset                   DPCCH-PowerOffset2,
    pc-Preamble                         PC-Preamble,
    sRB-delay                           SRB-delay
}

UL-DPCH-PowerControlInfoPostTDD ::= SEQUENCE {
    ul-TargetSIR                        UL-TargetSIR,
    ul-TimeslotInterference             TDD-UL-Interference
```

```
}

UL-DPCH-PowerControlInfoPostTDD-LCR-r4 ::=  SEQUENCE {
    -- The IE ul-TargetSIR corresponds to PRX-DPCHdes for 1.28Mcps TDD
    -- Actual value PRX-DPCHdes = (value of IE "ul-TargetSIR" - 120)
    ul-TargetSIR                        UL-TargetSIR
}

UL-DPCH-PowerControlInfoPredef ::=      CHOICE {
    fdd                                 SEQUENCE {
        -- TABULAR: TPC step size nested inside PowerControlAlgorithm
        powerControlAlgorithm               PowerControlAlgorithm
    },
    tdd                                 SEQUENCE {
        -- dpch-ConstantValue shall be ignored if in 1.28Mcps TDD mode.
        dpch-ConstantValue                  ConstantValueTdd
    }
}

UL-EDCH-Information-r6 ::=          SEQUENCE {
    mac-es-e-resetIndicator             ENUMERATED { true }                     OPTIONAL,
    e-DPCCH-Info                        E-DPCCH-Info                            OPTIONAL,
    e-DPDCH-Info                        E-DPDCH-Info                            OPTIONAL,
    schedulingTransmConfiguration       E-DPDCH-SchedulingTransmConfiguration   OPTIONAL
}

UL-Interference ::=                 INTEGER (-110..-70)

UL-ScramblingCode ::=               INTEGER (0..16777215)


UL-SynchronisationParameters-r4 ::= SEQUENCE {
    stepSize                            INTEGER (1..8),
    frequency                           INTEGER (1..8)
}

-- Actual value UL-TargetSIR = (IE value * 0.5) - 11
UL-TargetSIR ::=                    INTEGER (0..62)

UL-TimingAdvance ::=                INTEGER (0..63)

UL-TimingAdvance-VHCR ::=           INTEGER (0..127)

UL-TimingAdvanceControl ::=         CHOICE {
    disabled                            NULL,
    enabled                             SEQUENCE {
        ul-TimingAdvance                    UL-TimingAdvance                OPTIONAL,
        activationTime                      ActivationTime                  OPTIONAL
    }
}

UL-TimingAdvanceControl-r4 ::=      CHOICE {
    disabled                            NULL,
    enabled                             SEQUENCE {
        tddOption                           CHOICE {
            tdd384                              SEQUENCE {
                ul-TimingAdvance                    UL-TimingAdvance                OPTIONAL,
                activationTime                      ActivationTime                  OPTIONAL
            },
            tdd128                              SEQUENCE {
                ul-SynchronisationParameters        UL-SynchronisationParameters-r4 OPTIONAL,
                synchronisationParameters           SynchronisationParameters-r4    OPTIONAL
            }
        }
    }
}

UL-TimingAdvanceControl-r7 ::=      CHOICE {
    disabled                            NULL,
    enabled                             SEQUENCE {
        tddOption                           CHOICE {
            tdd384                              SEQUENCE {
                ul-TimingAdvance                    UL-TimingAdvance                OPTIONAL,
                activationTime                      ActivationTime                  OPTIONAL
            },
            tdd768                              SEQUENCE {
                ul-TimingAdvance                    UL-TimingAdvance-VHCR           OPTIONAL,
                activationTime                      ActivationTime                  OPTIONAL
```

```
            },
            tdd128                              SEQUENCE {
                ul-SynchronisationParameters        UL-SynchronisationParameters-r4 OPTIONAL,
                synchronisationParameters           SynchronisationParameters-r4    OPTIONAL
            }
        }
    }
}

UL-TimingAdvanceControl-LCR-r4 ::=  CHOICE {
    disabled                            NULL,
    enabled                             SEQUENCE {
        ul-SynchronisationParameters        UL-SynchronisationParameters-r4 OPTIONAL,
        synchronisationParameters           SynchronisationParameters-r4    OPTIONAL
    }
}

UL-TS-ChannelisationCode ::=        ENUMERATED {
                                        cc1-1, cc2-1, cc2-2,
                                        cc4-1, cc4-2, cc4-3, cc4-4,
                                        cc8-1, cc8-2, cc8-3, cc8-4,
                                        cc8-5, cc8-6, cc8-7, cc8-8,
                                        cc16-1, cc16-2, cc16-3, cc16-4,
                                        cc16-5, cc16-6, cc16-7, cc16-8,
                                        cc16-9, cc16-10, cc16-11, cc16-12,
                                        cc16-13, cc16-14, cc16-15, cc16-16 }

UL-TS-ChannelisationCodeList ::=    SEQUENCE (SIZE (1..2)) OF
                                        UL-TS-ChannelisationCode

UL-TS-ChannelisationCodeList-r7 ::=     SEQUENCE (SIZE (1..2)) OF
                                            SEQUENCE {
        ul-TS-Channelisation-Code               UL-TS-ChannelisationCode,
        plcch-info                              PLCCH-Info      OPTIONAL
}

UL-TS-ChannelisationCode-VHCR ::=       ENUMERATED {
                                        cc1-1, cc2-1, cc2-2,
                                        cc4-1, cc4-2, cc4-3, cc4-4,
                                        cc8-1, cc8-2, cc8-3, cc8-4,
                                        cc8-5, cc8-6, cc8-7, cc8-8,
                                        cc16-1, cc16-2, cc16-3, cc16-4,
                                        cc16-5, cc16-6, cc16-7, cc16-8,
                                        cc16-9, cc16-10, cc16-11, cc16-12,
                                        cc16-13, cc16-14, cc16-15, cc16-16,
                                        cc32-1, cc32-2, cc32-3, cc32-4,
                                        cc32-5, cc32-6, cc32-7, cc32-8,
                                        cc32-9, cc32-10, cc32-11, cc32-12,
                                        cc32-13, cc32-14, cc32-15, cc32-16,
                                        cc32-17, cc32-18, cc32-19, cc32-20,
                                        cc32-21, cc32-22, cc32-23, cc32-24,
                                        cc32-25, cc32-26, cc32-27, cc32-28,
                                        cc32-29, cc32-30, cc32-31, cc32-32 }

UL-TS-ChannelisationCodeList-VHCR ::=   SEQUENCE (SIZE (1..2)) OF
                                            UL-TS-ChannelisationCode-VHCR

UplinkAdditionalTimeslots ::=       SEQUENCE {
    parameters                          CHOICE {
        sameAsLast                          SEQUENCE {
            timeslotNumber                      TimeslotNumber
        },
        newParameters                       SEQUENCE {
            individualTimeslotInfo                      IndividualTimeslotInfo,
            ul-TS-ChannelisationCodeList                UL-TS-ChannelisationCodeList
        }
    }
}

UplinkAdditionalTimeslots-LCR-r4 ::=    SEQUENCE {
    parameters                          CHOICE {
        sameAsLast                          SEQUENCE {
            timeslotNumber                      TimeslotNumber
        },
        newParameters                       SEQUENCE {
            individualTimeslotInfo                      IndividualTimeslotInfo-LCR-r4,
            ul-TS-ChannelisationCodeList                UL-TS-ChannelisationCodeList
        }
```

```
    }
}

UplinkAdditionalTimeslots-LCR-r7 ::=    SEQUENCE {
    parameters                          CHOICE {
        sameAsLast                          SEQUENCE {
            timeslotNumber                      TimeslotNumber
            -- plcch-info assigned as previously defined slot
        },
        newParameters                       SEQUENCE {
            individualTimeslotInfo              IndividualTimeslotInfo-LCR-r4,
            ul-TS-ChannelisationCodeList        UL-TS-ChannelisationCodeList-r7
        }
    }
}

UplinkTimeslotsCodes ::=            SEQUENCE {
    dynamicSFusage                      BOOLEAN,
    firstIndividualTimeslotInfo         IndividualTimeslotInfo,
    ul-TS-ChannelisationCodeList        UL-TS-ChannelisationCodeList,
    moreTimeslots                       CHOICE {
        noMore                              NULL,
        additionalTimeslots                 CHOICE {
            consecutive                         SEQUENCE {
                numAdditionalTimeslots              INTEGER (1..maxTS-1)
            },
            timeslotList                        SEQUENCE (SIZE (1..maxTS-1)) OF
                                                    UplinkAdditionalTimeslots
        }
    }
}

UplinkTimeslotsCodes-VHCR ::=       SEQUENCE {
    dynamicSFusage                      BOOLEAN,
    firstIndividualTimeslotInfo         IndividualTimeslotInfo-VHCR,
    ul-TS-ChannelisationCodeList        UL-TS-ChannelisationCodeList-VHCR,
    moreTimeslots                       CHOICE {
        noMore                              NULL,
        additionalTimeslots                 CHOICE {
            consecutive                         SEQUENCE {
                numAdditionalTimeslots              INTEGER (1..maxTS-1)
            },
            timeslotList                        SEQUENCE (SIZE (1..maxTS-1)) OF
                                                    UplinkAdditionalTimeslots
        }
    }
}

UplinkTimeslotsCodes-LCR-r4 ::=     SEQUENCE {
    dynamicSFusage                      BOOLEAN,
    firstIndividualTimeslotInfo         IndividualTimeslotInfo-LCR-r4,
    ul-TS-ChannelisationCodeList        UL-TS-ChannelisationCodeList,
    moreTimeslots                       CHOICE {
        noMore                              NULL,
        additionalTimeslots                 CHOICE {
            consecutive                         SEQUENCE {
                numAdditionalTimeslots              INTEGER (1..maxTS-LCR-1)
            },
            timeslotList                        SEQUENCE (SIZE (1..maxTS-LCR-1)) OF
                                                    UplinkAdditionalTimeslots-LCR-r4
        }
    }
}

UplinkTimeslotsCodes-LCR-r7 ::=     SEQUENCE {
    dynamicSFusage                      BOOLEAN,
    firstIndividualTimeslotInfo         IndividualTimeslotInfo-LCR-r4,
    ul-TS-ChannelisationCodeList        UL-TS-ChannelisationCodeList-r7,
    moreTimeslots                       CHOICE {
        noMore                              NULL,
        additionalTimeslots                 CHOICE {
            consecutive                         SEQUENCE {
            -- the choice of 'consecutive' is not needed because there is only 1 option.
                numAdditionalTimeslots              INTEGER (1..maxTS-LCR-1)
            },
            timeslotList                        SEQUENCE (SIZE (1..maxTS-LCR-1)) OF
                                                    UplinkAdditionalTimeslots-LCR-r7
        }
```

```
    }
}

Wi-LCR ::=                                                          INTEGER(1..4)

-- **************************************************
--
--     MEASUREMENT INFORMATION ELEMENTS (10.3.7)
--
-- **************************************************

AcquisitionSatInfo ::=              SEQUENCE {
    satID                               SatID,
    -- Actual value dopplerOthOrder = IE value * 2.5
    doppler0thOrder                     INTEGER (-2048..2047),
    extraDopplerInfo                    ExtraDopplerInfo                    OPTIONAL,
    codePhase                           INTEGER (0..1022),
    integerCodePhase                    INTEGER (0..19),
    gps-BitNumber                       INTEGER (0..3),
    codePhaseSearchWindow               CodePhaseSearchWindow,
    azimuthAndElevation                 AzimuthAndElevation                 OPTIONAL
}

AcquisitionSatInfoList ::=          SEQUENCE (SIZE (1..maxSat)) OF
                                        AcquisitionSatInfo


AdditionalMeasurementID-List ::=    SEQUENCE (SIZE (1..maxAdditionalMeas)) OF
                                        MeasurementIdentity

AlmanacSatInfo ::=                  SEQUENCE {
    dataID                              INTEGER (0..3),
    satID                               SatID,
    e                                   BIT STRING (SIZE (16)),
    t-oa                                BIT STRING (SIZE (8)),
    deltaI                              BIT STRING (SIZE (16)),
    omegaDot                            BIT STRING (SIZE (16)),
    satHealth                           BIT STRING (SIZE (8)),
    a-Sqrt                              BIT STRING (SIZE (24)),
    omega0                              BIT STRING (SIZE (24)),
    m0                                  BIT STRING (SIZE (24)),
    omega                               BIT STRING (SIZE (24)),
    af0                                 BIT STRING (SIZE (11)),
    af1                                 BIT STRING (SIZE (11))
}

AlmanacSatInfoList ::=              SEQUENCE (SIZE (1..maxSat)) OF
                                        AlmanacSatInfo

AverageRLC-BufferPayload ::=        ENUMERATED {
                                        pla0, pla4, pla8, pla16, pla32,
                                        pla64, pla128, pla256, pla512,
                                        pla1024, pla2k, pla4k, pla8k, pla16k,
                                        pla32k, pla64k, pla128k, pla256k,
                                        pla512k, pla1024k, spare12, spare11,
                                        spare10, spare9, spare8, spare7, spare6,
                                        spare5, spare4, spare3, spare2, spare1 }

AzimuthAndElevation ::=             SEQUENCE {
    -- Actual value azimuth = IE value * 11.25
    azimuth                             INTEGER (0..31),
    -- Actual value elevation = IE value * 11.25
    elevation                           INTEGER (0..7)
}

BadSatList ::=                      SEQUENCE (SIZE (1..maxSat)) OF
                                        INTEGER (0..63)

Frequency-Band ::=                  ENUMERATED {
                                        dcs1800BandUsed, pcs1900BandUsed }

BCCH-ARFCN ::=                      INTEGER (0..1023)

BLER-MeasurementResults ::=         SEQUENCE {
    transportChannelIdentity            TransportChannelIdentity,
    dl-TransportChannelBLER             DL-TransportChannelBLER             OPTIONAL
}
```

```
BLER-MeasurementResultsList ::=     SEQUENCE (SIZE (1..maxTrCH)) OF
                                        BLER-MeasurementResults

BLER-TransChIdList ::=              SEQUENCE (SIZE (1..maxTrCH)) OF
                                        TransportChannelIdentity

BSIC-VerificationRequired ::=       ENUMERATED {
                                        required, notRequired }

BSICReported ::=                    CHOICE {
    -- Value maxCellMeas is not allowed for verifiedBSIC
    verifiedBSIC                        INTEGER (0..maxCellMeas),
    nonVerifiedBSIC                     BCCH-ARFCN
}

BurstModeParameters ::=             SEQUENCE {
    burstStart                          INTEGER (0..15),
    burstLength                         INTEGER (10..25),
    burstFreq                           INTEGER (1..16)
}

CellDCH-ReportCriteria ::=          CHOICE {
    intraFreqReportingCriteria          IntraFreqReportingCriteria,
    periodicalReportingCriteria         PeriodicalReportingCriteria
}

CellDCH-ReportCriteria-LCR-r4 ::=   CHOICE {
    intraFreqReportingCriteria          IntraFreqReportingCriteria-LCR-r4,
    periodicalReportingCriteria         PeriodicalReportingCriteria
}

-- Actual value CellIndividualOffset = IE value * 0.5
CellIndividualOffset ::=            INTEGER (-20..20)


CellInfo ::=                        SEQUENCE {
    cellIndividualOffset                CellIndividualOffset                DEFAULT 0,
    referenceTimeDifferenceToCell       ReferenceTimeDifferenceToCell       OPTIONAL,
    modeSpecificInfo                    CHOICE {
        fdd                                 SEQUENCE {
            primaryCPICH-Info                   PrimaryCPICH-Info           OPTIONAL,
            primaryCPICH-TX-Power               PrimaryCPICH-TX-Power       OPTIONAL,
            readSFN-Indicator                   BOOLEAN,
            tx-DiversityIndicator               BOOLEAN
        },
        tdd                                 SEQUENCE {
            primaryCCPCH-Info                   PrimaryCCPCH-Info,
            primaryCCPCH-TX-Power               PrimaryCCPCH-TX-Power       OPTIONAL,
            timeslotInfoList                    TimeslotInfoList            OPTIONAL,
            readSFN-Indicator                   BOOLEAN
        }
    }
}

CellInfo-r4 ::=                     SEQUENCE {
    cellIndividualOffset                CellIndividualOffset                DEFAULT 0,
    referenceTimeDifferenceToCell       ReferenceTimeDifferenceToCell       OPTIONAL,
    modeSpecificInfo                    CHOICE {
        fdd                                 SEQUENCE {
            primaryCPICH-Info                   PrimaryCPICH-Info           OPTIONAL,
            primaryCPICH-TX-Power               PrimaryCPICH-TX-Power       OPTIONAL,
            readSFN-Indicator                   BOOLEAN,
            tx-DiversityIndicator               BOOLEAN
        },
        tdd                                 SEQUENCE {
            primaryCCPCH-Info                   PrimaryCCPCH-Info-r4,
            primaryCCPCH-TX-Power               PrimaryCCPCH-TX-Power       OPTIONAL,
            timeslotInfoList                    TimeslotInfoList-r4         OPTIONAL,
            readSFN-Indicator                   BOOLEAN

        }
    }
}

CellInfoSI-RSCP ::=                 SEQUENCE {
    cellIndividualOffset                CellIndividualOffset                DEFAULT 0,
    referenceTimeDifferenceToCell       ReferenceTimeDifferenceToCell       OPTIONAL,
    modeSpecificInfo                    CHOICE {
```

```
        fdd                                 SEQUENCE {
            primaryCPICH-Info                   PrimaryCPICH-Info           OPTIONAL,
            primaryCPICH-TX-Power               PrimaryCPICH-TX-Power       OPTIONAL,
            readSFN-Indicator                   BOOLEAN,
            tx-DiversityIndicator               BOOLEAN
        },
        tdd                                 SEQUENCE {
            primaryCCPCH-Info                   PrimaryCCPCH-Info,
            primaryCCPCH-TX-Power               PrimaryCCPCH-TX-Power       OPTIONAL,
            timeslotInfoList                    TimeslotInfoList            OPTIONAL,
            readSFN-Indicator                   BOOLEAN
        }
    },
    cellSelectionReselectionInfo        CellSelectReselectInfoSIB-11-12-RSCP        OPTIONAL
}

CellInfoSI-RSCP-LCR-r4 ::=          SEQUENCE {
    cellIndividualOffset                CellIndividualOffset                DEFAULT 0,
    referenceTimeDifferenceToCell       ReferenceTimeDifferenceToCell       OPTIONAL,
    primaryCCPCH-Info                   PrimaryCCPCH-Info-LCR-r4,
    primaryCCPCH-TX-Power               PrimaryCCPCH-TX-Power               OPTIONAL,
    timeslotInfoList                    TimeslotInfoList-LCR-r4             OPTIONAL,
    readSFN-Indicator                   BOOLEAN,
    cellSelectionReselectionInfo        CellSelectReselectInfoSIB-11-12-RSCP        OPTIONAL
}

CellInfoSI-ECN0 ::=                 SEQUENCE {
    cellIndividualOffset                CellIndividualOffset                DEFAULT 0,
    referenceTimeDifferenceToCell       ReferenceTimeDifferenceToCell       OPTIONAL,
    modeSpecificInfo                    CHOICE {
        fdd                                 SEQUENCE {
            primaryCPICH-Info                   PrimaryCPICH-Info           OPTIONAL,
            primaryCPICH-TX-Power               PrimaryCPICH-TX-Power       OPTIONAL,
            readSFN-Indicator                   BOOLEAN,
            tx-DiversityIndicator               BOOLEAN
        },
        tdd                                 SEQUENCE {
            primaryCCPCH-Info                   PrimaryCCPCH-Info,
            primaryCCPCH-TX-Power               PrimaryCCPCH-TX-Power       OPTIONAL,
            timeslotInfoList                    TimeslotInfoList            OPTIONAL,
            readSFN-Indicator                   BOOLEAN
        }
    },
    cellSelectionReselectionInfo        CellSelectReselectInfoSIB-11-12-ECN0    OPTIONAL
}

CellInfoSI-ECN0-LCR-r4 ::=          SEQUENCE {
    cellIndividualOffset                CellIndividualOffset                DEFAULT 0,
    referenceTimeDifferenceToCell       ReferenceTimeDifferenceToCell       OPTIONAL,
    primaryCCPCH-Info                   PrimaryCCPCH-Info-LCR-r4,
    primaryCCPCH-TX-Power               PrimaryCCPCH-TX-Power               OPTIONAL,
    timeslotInfoList                    TimeslotInfoList-LCR-r4             OPTIONAL,
    readSFN-Indicator                   BOOLEAN,
    cellSelectionReselectionInfo        CellSelectReselectInfoSIB-11-12-ECN0    OPTIONAL
}

CellInfoSI-HCS-RSCP ::=             SEQUENCE {
    cellIndividualOffset                CellIndividualOffset                DEFAULT 0,
    referenceTimeDifferenceToCell       ReferenceTimeDifferenceToCell       OPTIONAL,
    modeSpecificInfo                    CHOICE {
        fdd                                 SEQUENCE {
            primaryCPICH-Info                   PrimaryCPICH-Info           OPTIONAL,
            primaryCPICH-TX-Power               PrimaryCPICH-TX-Power       OPTIONAL,
            readSFN-Indicator                   BOOLEAN,
            tx-DiversityIndicator               BOOLEAN
        },
        tdd                                 SEQUENCE {
            primaryCCPCH-Info                   PrimaryCCPCH-Info,
            primaryCCPCH-TX-Power               PrimaryCCPCH-TX-Power       OPTIONAL,
            timeslotInfoList                    TimeslotInfoList            OPTIONAL,
            readSFN-Indicator                   BOOLEAN
        }
    },
    cellSelectionReselectionInfo        CellSelectReselectInfoSIB-11-12-HCS-RSCP    OPTIONAL
}

CellInfoSI-HCS-RSCP-LCR-r4 ::=      SEQUENCE {
    cellIndividualOffset                CellIndividualOffset                DEFAULT 0,
```

```
    referenceTimeDifferenceToCell       ReferenceTimeDifferenceToCell       OPTIONAL,
    primaryCCPCH-Info                   PrimaryCCPCH-Info-LCR-r4,
    primaryCCPCH-TX-Power               PrimaryCCPCH-TX-Power               OPTIONAL,
    timeslotInfoList                    TimeslotInfoList-LCR-r4             OPTIONAL,
    readSFN-Indicator                   BOOLEAN,
    cellSelectionReselectionInfo        CellSelectReselectInfoSIB-11-12-HCS-RSCP    OPTIONAL
}

CellInfoSI-HCS-ECN0 ::=             SEQUENCE {
    cellIndividualOffset                CellIndividualOffset                DEFAULT 0,
    referenceTimeDifferenceToCell       ReferenceTimeDifferenceToCell       OPTIONAL,
    modeSpecificInfo                    CHOICE {
        fdd                                 SEQUENCE {
            primaryCPICH-Info                   PrimaryCPICH-Info           OPTIONAL,
            primaryCPICH-TX-Power               PrimaryCPICH-TX-Power       OPTIONAL,
            readSFN-Indicator                   BOOLEAN,
            tx-DiversityIndicator               BOOLEAN
        },
        tdd                                 SEQUENCE {
            primaryCCPCH-Info                   PrimaryCCPCH-Info,
            primaryCCPCH-TX-Power               PrimaryCCPCH-TX-Power       OPTIONAL,
            timeslotInfoList                    TimeslotInfoList            OPTIONAL,
            readSFN-Indicator                   BOOLEAN
        }
    },
    cellSelectionReselectionInfo        CellSelectReselectInfoSIB-11-12-HCS-ECN0    OPTIONAL
}

CellInfoSI-HCS-ECN0-LCR-r4 ::=      SEQUENCE {
    cellIndividualOffset                CellIndividualOffset                DEFAULT 0,
    referenceTimeDifferenceToCell       ReferenceTimeDifferenceToCell       OPTIONAL,
    primaryCCPCH-Info                   PrimaryCCPCH-Info-LCR-r4,
    primaryCCPCH-TX-Power               PrimaryCCPCH-TX-Power               OPTIONAL,
    timeslotInfoList                    TimeslotInfoList-LCR-r4             OPTIONAL,
    readSFN-Indicator                   BOOLEAN,
    cellSelectionReselectionInfo        CellSelectReselectInfoSIB-11-12-HCS-ECN0    OPTIONAL
}

CellMeasuredResults ::=             SEQUENCE {
    cellIdentity                        CellIdentity                        OPTIONAL,
    -- dummy is not used in this version of the specification, it should
    -- not be sent and if received it should be ignored.
    dummy           SFN-SFN-ObsTimeDifference           OPTIONAL,
    cellSynchronisationInfo         CellSynchronisationInfo         OPTIONAL,
    modeSpecificInfo                    CHOICE {
        fdd                                 SEQUENCE {
            primaryCPICH-Info                   PrimaryCPICH-Info,
            cpich-Ec-N0                         CPICH-Ec-N0                 OPTIONAL,
            cpich-RSCP                          CPICH-RSCP                  OPTIONAL,
            pathloss                            Pathloss                    OPTIONAL
        },
        tdd                                 SEQUENCE {
            cellParametersID                    CellParametersID,
            proposedTGSN                        TGSN                        OPTIONAL,
            primaryCCPCH-RSCP                   PrimaryCCPCH-RSCP           OPTIONAL,
            pathloss                            Pathloss                    OPTIONAL,
            timeslotISCP-List                   TimeslotISCP-List           OPTIONAL
        }
    }
}

CellMeasurementEventResults ::=     CHOICE {
    fdd                                 SEQUENCE (SIZE (1..maxCellMeas)) OF
                                            PrimaryCPICH-Info,
    tdd                                 SEQUENCE (SIZE (1..maxCellMeas)) OF
                                            PrimaryCCPCH-Info
}

CellMeasurementEventResults-LCR-r4 ::=  SEQUENCE (SIZE (1..maxCellMeas)) OF
                                            PrimaryCCPCH-Info-LCR-r4

CellReportingQuantities ::=         SEQUENCE {
    -- dummy is not used in this version of the specification, it should
    -- not be sent and if received it should be ignored.
    dummy                   SFN-SFN-OTD-Type,
    cellIdentity-reportingIndicator                     BOOLEAN,
    cellSynchronisationInfoReportingIndicator           BOOLEAN,
    modeSpecificInfo                    CHOICE {
```

```
        fdd                                 SEQUENCE {
            cpich-Ec-N0-reportingIndicator                          BOOLEAN,
            cpich-RSCP-reportingIndicator                           BOOLEAN,
            pathloss-reportingIndicator                         BOOLEAN
        },
        tdd                                 SEQUENCE {
            timeslotISCP-reportingIndicator                     BOOLEAN,
            proposedTGSN-ReportingRequired                      BOOLEAN,
            primaryCCPCH-RSCP-reportingIndicator                    BOOLEAN,
            pathloss-reportingIndicator                         BOOLEAN
        }
    }
}

CellSelectReselectInfoSIB-11-12 ::= SEQUENCE {
    q-Offset1S-N                        Q-OffsetS-N                         DEFAULT 0,
    q-Offset2S-N                        Q-OffsetS-N                         OPTIONAL,
    maxAllowedUL-TX-Power               MaxAllowedUL-TX-Power               OPTIONAL,
    hcs-NeighbouringCellInformation-RSCP        HCS-NeighbouringCellInformation-RSCP
    OPTIONAL,
    modeSpecificInfo                    CHOICE {
        fdd                                 SEQUENCE {
            q-QualMin                           Q-QualMin                   OPTIONAL,
            q-RxlevMin                          Q-RxlevMin                  OPTIONAL
        },
        tdd                                 SEQUENCE {
            q-RxlevMin                          Q-RxlevMin                  OPTIONAL
        },
        gsm                                 SEQUENCE {
            q-RxlevMin                          Q-RxlevMin                  OPTIONAL
        }
    }
}

CellSelectReselectInfoSIB-11-12-RSCP ::=    SEQUENCE {
    q-OffsetS-N                     Q-OffsetS-N                     DEFAULT 0,
    maxAllowedUL-TX-Power               MaxAllowedUL-TX-Power               OPTIONAL,
    modeSpecificInfo                    CHOICE {
        fdd                                 SEQUENCE {
            q-QualMin                           Q-QualMin                   OPTIONAL,
            q-RxlevMin                          Q-RxlevMin                  OPTIONAL
        },
        tdd                                 SEQUENCE {
            q-RxlevMin                          Q-RxlevMin                  OPTIONAL
        },
        gsm                                 SEQUENCE {
            q-RxlevMin                          Q-RxlevMin                  OPTIONAL
        }
    }
}

CellSelectReselectInfoSIB-11-12-ECN0 ::=    SEQUENCE {
    q-Offset1S-N                        Q-OffsetS-N                     DEFAULT 0,
    q-Offset2S-N                        Q-OffsetS-N                     DEFAULT 0,
    maxAllowedUL-TX-Power               MaxAllowedUL-TX-Power               OPTIONAL,
    modeSpecificInfo                    CHOICE {
        fdd                                 SEQUENCE {
            q-QualMin                           Q-QualMin                   OPTIONAL,
            q-RxlevMin                          Q-RxlevMin                  OPTIONAL
        },
        tdd                                 SEQUENCE {
            q-RxlevMin                          Q-RxlevMin                  OPTIONAL
        },
        gsm                                 SEQUENCE {
            q-RxlevMin                          Q-RxlevMin                  OPTIONAL
        }
    }
}

CellSelectReselectInfoSIB-11-12-HCS-RSCP ::=    SEQUENCE {
    q-OffsetS-N                     Q-OffsetS-N                     DEFAULT 0,
    maxAllowedUL-TX-Power               MaxAllowedUL-TX-Power               OPTIONAL,
    hcs-NeighbouringCellInformation-RSCP        HCS-NeighbouringCellInformation-RSCP
    OPTIONAL,
    modeSpecificInfo                    CHOICE {
        fdd                                 SEQUENCE {
            q-QualMin                           Q-QualMin                   OPTIONAL,
            q-RxlevMin                          Q-RxlevMin                  OPTIONAL
```

```
        },
        tdd                                 SEQUENCE {
            q-RxlevMin                          Q-RxlevMin                  OPTIONAL
        },
        gsm                                 SEQUENCE {
            q-RxlevMin                          Q-RxlevMin                  OPTIONAL
        }
    }
}

CellSelectReselectInfoSIB-11-12-HCS-ECN0 ::=    SEQUENCE {
    q-Offset1S-N                        Q-OffsetS-N                     DEFAULT 0,
    q-Offset2S-N                        Q-OffsetS-N                     DEFAULT 0,
    maxAllowedUL-TX-Power               MaxAllowedUL-TX-Power               OPTIONAL,
    hcs-NeighbouringCellInformation-ECN0        HCS-NeighbouringCellInformation-ECN0
    OPTIONAL,
    modeSpecificInfo                    CHOICE {
        fdd                                 SEQUENCE {
            q-QualMin                           Q-QualMin                   OPTIONAL,
            q-RxlevMin                          Q-RxlevMin                  OPTIONAL
        },
        tdd                                 SEQUENCE {
            q-RxlevMin                          Q-RxlevMin                  OPTIONAL
        },
        gsm                                 SEQUENCE {
            q-RxlevMin                          Q-RxlevMin                  OPTIONAL
        }
    }
}

CellSelectReselectInfo-v590ext ::= SEQUENCE {
    deltaQrxlevmin                  DeltaQrxlevmin                  OPTIONAL,
    deltaQhcs                       DeltaRSCP                       OPTIONAL
}

CellSelectReselectInfoPCHFACH-v5b0ext ::= SEQUENCE {
    q-Hyst-l-S-PCH              Q-Hyst-S-Fine                       OPTIONAL,
    q-Hyst-l-S-FACH             Q-Hyst-S-Fine                       OPTIONAL,
    q-Hyst-2-S-PCH              Q-Hyst-S-Fine                       OPTIONAL,
    q-Hyst-2-S-FACH             Q-Hyst-S-Fine                       OPTIONAL,
    t-Reselection-S-PCH         T-Reselection-S                     OPTIONAL,
    t-Reselection-S-FACH        T-Reselection-S-Fine                OPTIONAL
}

CellSelectReselectInfoTreselectionScaling-v5c0ext ::= SEQUENCE {
    -- For speed detection, the same HCS parameters are utilised
    non-HCS-t-CR-Max                        T-CRMax                                 OPTIONAL,
    speedDependentScalingFactor             SpeedDependentScalingFactor             OPTIONAL,
    interFrequencyTreselectionScalingFactor     TreselectionScalingFactor           OPTIONAL,
    interRATTreselectionScalingFactor           TreselectionScalingFactor           OPTIONAL
}

CellsForInterFreqMeasList ::=       SEQUENCE (SIZE  (1..maxCellMeas)) OF
                                        InterFreqCellID
CellsForInterRATMeasList ::=            SEQUENCE (SIZE  (1..maxCellMeas)) OF
                                        InterRATCellID
CellsForIntraFreqMeasList ::=       SEQUENCE (SIZE  (1..maxCellMeas)) OF
                                        IntraFreqCellID

CellSynchronisationInfo ::=         SEQUENCE {
    modeSpecificInfo                    CHOICE {
        fdd                                 SEQUENCE {
            countC-SFN-Frame-difference         CountC-SFN-Frame-difference     OPTIONAL,
            tm                                  INTEGER(0..38399)
        },
        tdd                                 SEQUENCE {
            countC-SFN-Frame-difference         CountC-SFN-Frame-difference     OPTIONAL
        }
    }
}

CellToReport ::=                    SEQUENCE {
    bsicReported                        BSICReported
}

CellToReportList ::=                SEQUENCE (SIZE (1..maxCellMeas)) OF
                                        CellToReport
```

```
CodePhaseSearchWindow ::=           ENUMERATED {
                                        w1023, w1, w2, w3, w4, w6, w8,
                                        w12, w16, w24, w32, w48, w64,
                                        w96, w128, w192 }

CountC-SFN-Frame-difference ::= SEQUENCE {
    -- Actual value countC-SFN-High = IE value * 256
    countC-SFN-High                 INTEGER(0..15),
    off                             INTEGER(0..255)
}

-- SPARE: CPICH-Ec-No, Max = 49
-- Values above Max are spare
CPICH-Ec-N0 ::=                     INTEGER (0..63)

-- SPARE: CPICH- RSCP, Max = 91
-- Values above Max are spare
CPICH-RSCP ::=                      INTEGER (0..127)


DeltaPRC ::=                        INTEGER (-127..127)

--Actual value DeltaQrxlevmin = IE value * 2
DeltaQrxlevmin ::= INTEGER (-2..-1)

DeltaRSCP ::= INTEGER (-5..-1)

DeltaRSCPPerCell ::= SEQUENCE {
    deltaRSCP                       DeltaRSCP   OPTIONAL
}

-- Actual value DeltaRRC = IE value * 0.032
DeltaRRC ::=                        INTEGER (-7..7)

DGPS-CorrectionSatInfo ::=          SEQUENCE {
    satID                               SatID,
    iode                                IODE,
    udre                                UDRE,
    prc                                 PRC,
    rrc                                 RRC,
-- dummy1 and dummy2 are not used in this version of the specification and should be ignored.
    dummy1                          DeltaPRC,
    dummy2                          DeltaRRC,
    -- dummy3 and dummy4 are not used in this version of the specification. They should not
    -- be sent and if received they should be ignored.
    dummy3                          DeltaPRC            OPTIONAL,
    dummy4                          DeltaRRC            OPTIONAL
}

DGPS-CorrectionSatInfoList ::=      SEQUENCE (SIZE (1..maxSat)) OF
                                        DGPS-CorrectionSatInfo

DiffCorrectionStatus ::=            ENUMERATED {
                                        udre-1-0, udre-0-75, udre-0-5, udre-0-3,
                                        udre-0-2, udre-0-1, noData, invalidData }

DL-TransportChannelBLER ::=         INTEGER (0..63)

DopplerUncertainty ::=              ENUMERATED {
                                        hz12-5, hz25, hz50, hz100, hz200,
                                        spare3, spare2, spare1 }

EllipsoidPoint ::=                  SEQUENCE {
    latitudeSign        ENUMERATED { north, south },
    latitude            INTEGER (0..8388607),
    longitude           INTEGER (-8388608..8388607)
}


EllipsoidPointAltitude ::=          SEQUENCE {
    latitudeSign        ENUMERATED { north, south },
    latitude            INTEGER (0..8388607),
    longitude           INTEGER (-8388608..8388607),
    altitudeDirection   ENUMERATED {height, depth},
    altitude            INTEGER (0..32767)
}
```

```
EllipsoidPointAltitudeEllipsoide ::=    SEQUENCE {
    latitudeSign            ENUMERATED { north, south },
    latitude                INTEGER (0..8388607),
    longitude               INTEGER (-8388608..8388607),
    altitudeDirection       ENUMERATED {height, depth},
    altitude                INTEGER (0..32767),
    uncertaintySemiMajor    INTEGER (0..127),
    uncertaintySemiMinor    INTEGER (0..127),
    -- Actual value orientationMajorAxis = IE value * 2
    orientationMajorAxis    INTEGER (0..89),
    uncertaintyAltitude     INTEGER (0..127),
    confidence              INTEGER (0..100)
}


EllipsoidPointUncertCircle ::=      SEQUENCE {
    latitudeSign            ENUMERATED { north, south },
    latitude                INTEGER (0..8388607),
    longitude               INTEGER (-8388608..8388607),
    uncertaintyCode         INTEGER (0..127)
}


EllipsoidPointUncertEllipse ::=     SEQUENCE {
    latitudeSign            ENUMERATED { north, south },
    latitude                INTEGER (0..8388607),
    longitude               INTEGER (-8388608..8388607),
    uncertaintySemiMajor    INTEGER (0..127),
    uncertaintySemiMinor    INTEGER (0..127),
    -- Actual value orientationMajorAxis = IE value * 2
    orientationMajorAxis    INTEGER (0..89),
    confidence              INTEGER (0..100)
}


EnvironmentCharacterisation ::=     ENUMERATED {
                                        possibleHeavyMultipathNLOS,
                                        lightMultipathLOS,
                                        notDefined,
                                        spare }

Event1a ::=                         SEQUENCE {
    triggeringCondition                 TriggeringCondition2,
    reportingRange                      ReportingRange,
    forbiddenAffectCellList             ForbiddenAffectCellList             OPTIONAL,
    w                                   W,
    reportDeactivationThreshold         ReportDeactivationThreshold,
    reportingAmount                     ReportingAmount,
    reportingInterval                   ReportingInterval
}

Event1a-r4 ::=                      SEQUENCE {
    triggeringCondition                 TriggeringCondition2,
    reportingRange                      ReportingRange,
    forbiddenAffectCellList             ForbiddenAffectCellList-r4          OPTIONAL,
    w                                   W,
    reportDeactivationThreshold         ReportDeactivationThreshold,
    reportingAmount                     ReportingAmount,
    reportingInterval                   ReportingInterval
}

Event1a-LCR-r4 ::=                  SEQUENCE {
    triggeringCondition                 TriggeringCondition2,
    reportingRange                      ReportingRange,
    forbiddenAffectCellList             ForbiddenAffectCellList-LCR-r4          OPTIONAL,
    w                                   W,
    reportDeactivationThreshold         ReportDeactivationThreshold,
    reportingAmount                     ReportingAmount,
    reportingInterval                   ReportingInterval
}

Event1b ::=                         SEQUENCE {
    triggeringCondition                 TriggeringCondition1,
    reportingRange                      ReportingRange,
    forbiddenAffectCellList             ForbiddenAffectCellList             OPTIONAL,
    w                                   W
}
```

```
Event1b-r4 ::=                      SEQUENCE {
    triggeringCondition                 TriggeringCondition1,
    reportingRange                      ReportingRange,
    forbiddenAffectCellList             ForbiddenAffectCellList-r4          OPTIONAL,
    w                                   W
}

Event1b-r6 ::=                      SEQUENCE {
    triggeringCondition                 TriggeringCondition1,
    reportingRange                      ReportingRange,
    forbiddenAffectCellList             ForbiddenAffectCellList-r4          OPTIONAL,
    w                                   W,
    -- The IE periodicReportingInfo should not be included in case the IE is
    -- included in the IE InterFreqReportCriteria
    periodicReportingInfo               PeriodicReportingInfo-1b
}

Event1b-LCR-r4 ::=                  SEQUENCE {
    triggeringCondition                 TriggeringCondition1,
    reportingRange                      ReportingRange,
    forbiddenAffectCellList             ForbiddenAffectCellList-LCR-r4          OPTIONAL,
    w                                   W
}

Event1c ::=                         SEQUENCE {
    replacementActivationThreshold      ReplacementActivationThreshold,
    reportingAmount                     ReportingAmount,
    reportingInterval                   ReportingInterval
}

Event1d ::=                         SEQUENCE {
    triggeringCondition                 TriggeringCondition2    OPTIONAL,
    useCIO                              BOOLEAN                 OPTIONAL
}

Event1e ::=                     SEQUENCE {
    triggeringCondition             TriggeringCondition2,
    thresholdUsedFrequency          ThresholdUsedFrequency
}

Event1e-r6 ::=                  SEQUENCE {
    triggeringCondition             TriggeringCondition2,
    thresholdUsedFrequency          ThresholdUsedFrequency-r6
}

Event1f ::=                     SEQUENCE {
    triggeringCondition             TriggeringCondition1,
    thresholdUsedFrequency          ThresholdUsedFrequency
}

Event1f-r6 ::=                  SEQUENCE {
    triggeringCondition             TriggeringCondition1,
    thresholdUsedFrequency          ThresholdUsedFrequency-r6
}

Event1j-r6 ::=                  SEQUENCE {
    replacementActivationThreshold      ReplacementActivationThreshold,
    reportingAmount                     ReportingAmount,
    reportingInterval                   ReportingInterval
}

Event2a ::=                         SEQUENCE {
    -- dummy is not used in this version of the specification and should be ignored
    dummy                               Threshold,
    usedFreqW                           W,
    hysteresis                          HysteresisInterFreq,
    timeToTrigger                       TimeToTrigger,
    reportingCellStatus                 ReportingCellStatus                 OPTIONAL,
    nonUsedFreqParameterList            NonUsedFreqParameterList            OPTIONAL
}

Event2a-r6 ::=                      SEQUENCE {
    usedFreqW                           W,
    hysteresis                          HysteresisInterFreq,
    timeToTrigger                       TimeToTrigger,
    reportingCellStatus                 ReportingCellStatus                 OPTIONAL,
    nonUsedFreqParameterList            NonUsedFreqWList-r6                 OPTIONAL
}
```

```
Event2b ::=                         SEQUENCE {
    usedFreqThreshold                   Threshold,
    usedFreqW                           W,
    hysteresis                          HysteresisInterFreq,
    timeToTrigger                       TimeToTrigger,
    reportingCellStatus                 ReportingCellStatus                 OPTIONAL,
    nonUsedFreqParameterList            NonUsedFreqParameterList            OPTIONAL
}

Event2b-r6 ::=                      SEQUENCE {
    usedFreqThreshold                   Threshold-r6,
    usedFreqW                           W,
    hysteresis                          HysteresisInterFreq,
    timeToTrigger                       TimeToTrigger,
    reportingCellStatus                 ReportingCellStatus                 OPTIONAL,
    nonUsedFreqParameterList            NonUsedFreqParameterList-r6         OPTIONAL
}

Event2c ::=                         SEQUENCE {
    hysteresis                          HysteresisInterFreq,
    timeToTrigger                       TimeToTrigger,
    reportingCellStatus                 ReportingCellStatus                 OPTIONAL,
    nonUsedFreqParameterList            NonUsedFreqParameterList            OPTIONAL
}

Event2c-r6 ::=                      SEQUENCE {
    hysteresis                          HysteresisInterFreq,
    timeToTrigger                       TimeToTrigger,
    reportingCellStatus                 ReportingCellStatus                 OPTIONAL,
    nonUsedFreqParameterList            NonUsedFreqParameterList-r6         OPTIONAL
}

Event2d ::=                         SEQUENCE {
    usedFreqThreshold                   Threshold,
    usedFreqW                           W,
    hysteresis                          HysteresisInterFreq,
    timeToTrigger                       TimeToTrigger,
    reportingCellStatus                 ReportingCellStatus                 OPTIONAL
}

Event2d-r6 ::=                      SEQUENCE {
    usedFreqThreshold                   Threshold-r6,
    usedFreqW                           W,
    hysteresis                          HysteresisInterFreq,
    timeToTrigger                       TimeToTrigger,
    reportingCellStatus                 ReportingCellStatus                 OPTIONAL
}

Event2e ::=                         SEQUENCE {
    hysteresis                          HysteresisInterFreq,
    timeToTrigger                       TimeToTrigger,
    reportingCellStatus                 ReportingCellStatus                 OPTIONAL,
    nonUsedFreqParameterList            NonUsedFreqParameterList            OPTIONAL
}

Event2e-r6 ::=                      SEQUENCE {
    hysteresis                          HysteresisInterFreq,
    timeToTrigger                       TimeToTrigger,
    reportingCellStatus                 ReportingCellStatus                 OPTIONAL,
    nonUsedFreqParameterList            NonUsedFreqParameterList-r6         OPTIONAL
}

Event2f ::=                         SEQUENCE {
    usedFreqThreshold                   Threshold,
    usedFreqW                           W,
    hysteresis                          HysteresisInterFreq,
    timeToTrigger                       TimeToTrigger,
    reportingCellStatus                 ReportingCellStatus                 OPTIONAL
}

Event2f-r6 ::=                      SEQUENCE {
    usedFreqThreshold                   Threshold-r6,
    usedFreqW                           W,
    hysteresis                          HysteresisInterFreq,
    timeToTrigger                       TimeToTrigger,
    reportingCellStatus                 ReportingCellStatus                 OPTIONAL
}
```

```
Event3a ::=                         SEQUENCE {
    thresholdOwnSystem                  Threshold,
    w                                   W,
    thresholdOtherSystem                Threshold,
    hysteresis                          Hysteresis,
    timeToTrigger                       TimeToTrigger,
    reportingCellStatus                 ReportingCellStatus             OPTIONAL
}

Event3b ::=                         SEQUENCE {
    thresholdOtherSystem                Threshold,
    hysteresis                          Hysteresis,
    timeToTrigger                       TimeToTrigger,
    reportingCellStatus                 ReportingCellStatus             OPTIONAL

}

Event3c ::=                         SEQUENCE {
    thresholdOtherSystem                Threshold,
    hysteresis                          Hysteresis,
    timeToTrigger                       TimeToTrigger,
    reportingCellStatus                 ReportingCellStatus             OPTIONAL
}

Event3d ::=                         SEQUENCE {
    hysteresis                          Hysteresis,
    timeToTrigger                       TimeToTrigger,
    reportingCellStatus                 ReportingCellStatus             OPTIONAL
}

EventIDInterFreq ::=                ENUMERATED {
                                        e2a, e2b, e2c, e2d, e2e, e2f, spare2, spare1 }

EventIDInterRAT ::=                 ENUMERATED {
                                        e3a, e3b, e3c, e3d }

EventIDIntraFreq ::=                ENUMERATED {
                                        e1a, e1b, e1c, e1d, e1e,
                                        e1f, e1g, e1h, e1i, e1j,
                                        spare6, spare5, spare4, spare3, spare2,
                                        spare1 }

EventResults ::=                    CHOICE {
    intraFreqEventResults               IntraFreqEventResults,
    interFreqEventResults               InterFreqEventResults,
    interRATEventResults                InterRATEventResults,
    trafficVolumeEventResults           TrafficVolumeEventResults,
    qualityEventResults                 QualityEventResults,
    ue-InternalEventResults             UE-InternalEventResults,
    ue-positioning-MeasurementEventResults          UE-Positioning-MeasurementEventResults,
    spare                               NULL
}

ExtraDopplerInfo ::=                SEQUENCE {
    -- Actual value doppler1stOrder = IE value * 0.023
    doppler1stOrder                     INTEGER (-42..21),
    dopplerUncertainty                  DopplerUncertainty
}

FACH-MeasurementOccasionInfo ::=    SEQUENCE {
    fACH-meas-occasion-coeff            INTEGER (1..12)                 OPTIONAL,
    inter-freq-FDD-meas-ind             BOOLEAN,
    -- inter-freq-TDD-meas-ind is for 3.84Mcps TDD and 7.68 Mcps TDD. For 1.28Mcps TDD, the IE in
    -- FACH-MeasurementOccasionInfo-LCR-r4-ext is used.
    inter-freq-TDD-meas-ind             BOOLEAN,
    inter-RAT-meas-ind                  SEQUENCE (SIZE (1..maxOtherRAT)) OF
                                            RAT-Type                    OPTIONAL
}

FACH-MeasurementOccasionInfo-LCR-r4-ext ::= SEQUENCE {
    inter-freq-TDD128-meas-ind              BOOLEAN
}

FilterCoefficient ::=               ENUMERATED {
                                        fc0, fc1, fc2, fc3, fc4, fc5,
                                        fc6, fc7, fc8, fc9, fc11, fc13,
                                        fc15, fc17, fc19, spare1 }
```

```
-- Actual value FineSFN-SFN = IE value * 0.0625
FineSFN-SFN ::=                     INTEGER (0..15)

ForbiddenAffectCell ::=             CHOICE {
    fdd                                 PrimaryCPICH-Info,
    tdd                                 PrimaryCCPCH-Info
}

ForbiddenAffectCell-r4 ::=          CHOICE {
    fdd                                 PrimaryCPICH-Info,
    tdd                                 PrimaryCCPCH-Info-r4
}

ForbiddenAffectCell-LCR-r4 ::=      SEQUENCE {
    tdd                                 PrimaryCCPCH-Info-LCR-r4
}

ForbiddenAffectCellList ::=         SEQUENCE (SIZE (1..maxCellMeas)) OF
                                        ForbiddenAffectCell

ForbiddenAffectCellList-r4 ::=          SEQUENCE (SIZE (1..maxCellMeas)) OF
                                        ForbiddenAffectCell-r4

ForbiddenAffectCellList-LCR-r4 ::=  SEQUENCE (SIZE (1..maxCellMeas)) OF
                                        ForbiddenAffectCell-LCR-r4

FreqQualityEstimateQuantity-FDD ::= ENUMERATED {
                                        cpich-Ec-N0,
                                        cpich-RSCP }

FreqQualityEstimateQuantity-TDD ::= ENUMERATED {
                                        primaryCCPCH-RSCP }

GPS-MeasurementParam ::=            SEQUENCE {
    satelliteID                         INTEGER (0..63),
    c-N0                                INTEGER (0..63),
    doppler                             INTEGER (-32768..32768),
    wholeGPS-Chips                      INTEGER (0..1022),
    fractionalGPS-Chips                 INTEGER (0..1023),
    multipathIndicator                  MultipathIndicator,
    pseudorangeRMS-Error                INTEGER (0..63)
}

GPS-MeasurementParamList ::=        SEQUENCE (SIZE (1..maxSat)) OF
                                        GPS-MeasurementParam

GSM-CarrierRSSI ::=                 BIT STRING (SIZE (6))


GSM-MeasuredResults ::=             SEQUENCE {
    gsm-CarrierRSSI                     GSM-CarrierRSSI                     OPTIONAL,
    -- dummy is not used in this version of the specification, it should
    -- not be sent and if received it should be ignored.
    dummy                               INTEGER (46..173)                   OPTIONAL,
    bsicReported                        BSICReported,
    -- dummy2 is not used in this version of the specification, it should
    -- not be sent and if received it should be ignored.
    dummy2                              ObservedTimeDifferenceToGSM         OPTIONAL
}

GSM-MeasuredResultsList ::=         SEQUENCE (SIZE (1..maxReportedGSMCells)) OF
                                        GSM-MeasuredResults

GPS-TOW-1msec ::=                   INTEGER (0..604799999)

GPS-TOW-Assist ::=                  SEQUENCE {
    satID                               SatID,
    tlm-Message                         BIT STRING (SIZE (14)),
    tlm-Reserved                        BIT STRING (SIZE (2)),
    alert                               BOOLEAN,
    antiSpoof                           BOOLEAN
}

GPS-TOW-AssistList ::=              SEQUENCE (SIZE (1..maxSat)) OF
                                        GPS-TOW-Assist

HCS-CellReselectInformation-RSCP ::=        SEQUENCE {
```

```
    -- TABULAR: The default value for penaltyTime is "notUsed"
    -- Temporary offset is nested inside PenaltyTime-RSCP
    penaltyTime                                 PenaltyTime-RSCP
}

HCS-CellReselectInformation-ECN0 ::=        SEQUENCE {
    -- TABULAR: The default value for penaltyTime is "notUsed"
    -- Temporary offset is nested inside PenaltyTime-ECN0
    penaltyTime                         PenaltyTime-ECN0
}

HCS-NeighbouringCellInformation-RSCP ::= SEQUENCE {
    hcs-PRIO                            HCS-PRIO                                DEFAULT 0,
    q-HCS                               Q-HCS                                   DEFAULT 0,
    hcs-CellReselectInformation         HCS-CellReselectInformation-RSCP
}

HCS-NeighbouringCellInformation-ECN0 ::= SEQUENCE {
    hcs-PRIO                            HCS-PRIO                                DEFAULT 0,
    q-HCS                               Q-HCS                                   DEFAULT 0,
    hcs-CellReselectInformation         HCS-CellReselectInformation-ECN0
}

HCS-PRIO ::=                        INTEGER (0..7)

HCS-ServingCellInformation ::=      SEQUENCE {
    hcs-PRIO                            HCS-PRIO                                DEFAULT 0,
    q-HCS                               Q-HCS                                   DEFAULT 0,
    t-CR-Max                            T-CRMax                                 OPTIONAL
}

HorizontalVelocity ::=              SEQUENCE {
    bearing                             INTEGER (0..359),
    horizontalSpeed                     INTEGER (0..2047)
    }

HorizontalWithVerticalVelocity ::=  SEQUENCE {
    verticalSpeedDirection              ENUMERATED { upward, downward },
    bearing                             INTEGER (0..359),
    horizontalSpeed                     INTEGER (0..2047),
    verticalSpeed                       INTEGER (0..255)
}

HorizontalVelocityWithUncertainty ::=   SEQUENCE {
    bearing                             INTEGER (0..359),
    horizontalSpeed                     INTEGER (0..2047),
    horizontalSpeedUncertainty          INTEGER (0..255)
}

HorizontalWithVerticalVelocityAndUncertainty ::=    SEQUENCE {
    verticalSpeedDirection              ENUMERATED { upward, downward },
    bearing                             INTEGER (0..359),
    horizontalSpeed                     INTEGER (0..2047),
    verticalSpeed                       INTEGER (0..255),
    horizontalSpeedUncertainty          INTEGER (0..255)
}

-- Actual value Hysteresis = IE value * 0.5
Hysteresis ::=                      INTEGER (0..15)

-- Actual value HysteresisInterFreq = IE value * 0.5
HysteresisInterFreq ::=             INTEGER (0..29)

InterFreqCell ::=                   SEQUENCE {
    frequencyInfo                       FrequencyInfo,
    nonFreqRelatedEventResults          CellMeasurementEventResults
}

InterFreqCell-LCR-r4 ::=            SEQUENCE {
    frequencyInfo                       FrequencyInfo,
    nonFreqRelatedEventResults          CellMeasurementEventResults-LCR-r4
}

InterFreqCellID ::=                 INTEGER (0..maxCellMeas-1)

InterFreqCellInfoList ::=           SEQUENCE {
    removedInterFreqCellList            RemovedInterFreqCellList            OPTIONAL,
    newInterFreqCellList                NewInterFreqCellList                OPTIONAL,
```

```
    cellsForInterFreqMeasList           CellsForInterFreqMeasList           OPTIONAL
}

InterFreqCellInfoList-r4 ::=        SEQUENCE {
    removedInterFreqCellList            RemovedInterFreqCellList            OPTIONAL,
    newInterFreqCellList                NewInterFreqCellList-r4             OPTIONAL,
    cellsForInterFreqMeasList           CellsForInterFreqMeasList           OPTIONAL
}

InterFreqCellInfoSI-List-RSCP ::=       SEQUENCE {
    removedInterFreqCellList            RemovedInterFreqCellList            OPTIONAL,
    newInterFreqCellList                NewInterFreqCellSI-List-RSCP        OPTIONAL
}

InterFreqCellInfoSI-List-ECN0 ::=       SEQUENCE {
    removedInterFreqCellList            RemovedInterFreqCellList            OPTIONAL,
    newInterFreqCellList                NewInterFreqCellSI-List-ECN0        OPTIONAL
}

InterFreqCellInfoSI-List-HCS-RSCP ::=       SEQUENCE {
    removedInterFreqCellList            RemovedInterFreqCellList            OPTIONAL,
    newInterFreqCellList                NewInterFreqCellSI-List-HCS-RSCP    OPTIONAL
}
InterFreqCellInfoSI-List-HCS-ECN0 ::=       SEQUENCE {
    removedInterFreqCellList            RemovedInterFreqCellList            OPTIONAL,
    newInterFreqCellList                NewInterFreqCellSI-List-HCS-ECN0    OPTIONAL
}

InterFreqCellInfoSI-List-RSCP-LCR ::=       SEQUENCE {
    removedInterFreqCellList            RemovedInterFreqCellList            OPTIONAL,
    newInterFreqCellList                NewInterFreqCellSI-List-RSCP-LCR-r4     OPTIONAL
}

InterFreqCellInfoSI-List-ECN0-LCR ::=       SEQUENCE {
    removedInterFreqCellList            RemovedInterFreqCellList            OPTIONAL,
    newInterFreqCellList                NewInterFreqCellSI-List-ECN0-LCR-r4     OPTIONAL
}

InterFreqCellInfoSI-List-HCS-RSCP-LCR ::=       SEQUENCE {
    removedInterFreqCellList            RemovedInterFreqCellList            OPTIONAL,
    newInterFreqCellList                NewInterFreqCellSI-List-HCS-RSCP-LCR-r4 OPTIONAL
}
InterFreqCellInfoSI-List-HCS-ECN0-LCR ::=       SEQUENCE {
    removedInterFreqCellList            RemovedInterFreqCellList            OPTIONAL,
    newInterFreqCellList                NewInterFreqCellSI-List-HCS-ECN0-LCR-r4 OPTIONAL
}

InterFreqCellList ::=               SEQUENCE (SIZE (1..maxFreq)) OF
                                        InterFreqCell

InterFreqCellList-LCR-r4-ext ::=    SEQUENCE (SIZE (1..maxFreq)) OF
                                        InterFreqCell-LCR-r4

InterFreqCellMeasuredResultsList ::= SEQUENCE (SIZE (1..maxCellMeas)) OF
                                        CellMeasuredResults

InterFreqEvent ::=                  CHOICE {
    event2a                             Event2a,
    event2b                             Event2b,
    event2c                             Event2c,
    event2d                             Event2d,
    event2e                             Event2e,
    event2f                             Event2f
}

InterFreqEvent-r6 ::=               CHOICE {
    event2a                             Event2a-r6,
    event2b                             Event2b-r6,
    event2c                             Event2c-r6,
    event2d                             Event2d-r6,
    event2e                             Event2e-r6,
    event2f                             Event2f-r6
}

InterFreqEventList ::=              SEQUENCE (SIZE (1..maxMeasEvent)) OF
                                        InterFreqEvent

InterFreqEventList-r6 ::=           SEQUENCE (SIZE (1..maxMeasEvent)) OF
```

```
                                        InterFreqEvent-r6

--Following IE shall be used regardless of CPICH RSCP(FDD) or Primary CCPCH RSCP(TDD)
--The order of the list corresponds to the order of the cells in InterFrequencyMeasuredResultsList
--The IE is only used for measured results and not for additional measured results.
InterFrequencyMeasuredResultsList-v590ext ::= SEQUENCE (SIZE (1..maxCellMeas)) OF
                                              DeltaRSCPPerCell

Inter-FreqEventCriteria-v590ext ::= SEQUENCE {
    threholdUsedFrequency-delta             DeltaRSCP,
    threholdNonUsedFrequency-deltaList      ThreholdNonUsedFrequency-deltaList      OPTIONAL
}

--The order of the list corresponds to the order of the events in Inter-FreqEventList
Inter-FreqEventCriteriaList-v590ext ::= SEQUENCE (SIZE (1..maxMeasEvent)) OF
                                        Inter-FreqEventCriteria-v590ext

--The order of the list corresponds to the order of relevant events in Intra-FreqEventCriteriaList
--i.e. the first element of the list corresponds to the first occurance of event 1e, 1f, 1h, 1i,
--the second element of the list corresponds to the second occurance of event 1e, 1f, 1h, 1i
Intra-FreqEventCriteriaList-v590ext ::= SEQUENCE (SIZE (1..maxMeasEvent)) OF
                                        DeltaRSCP

--Following IE shall be used regardless of CPICH RSCP(FDD) or Primary CCPCH RSCP(TDD)
--The order of the list corresponds to the order of the cells in IntraFrequencyMeasuredResultsList
--The IE is only used for measured results and not for additional measured results.
IntraFrequencyMeasuredResultsList-v590ext ::= SEQUENCE (SIZE (1..maxCellMeas)) OF
                                              DeltaRSCPPerCell

IntraFreqReportingCriteria-1b-r5 ::= SEQUENCE {
    periodicReportingInfo-1b            PeriodicReportingInfo-1b
}

PeriodicReportingInfo-1b ::= SEQUENCE {
    reportingAmount                     ReportingAmount,
    reportingInterval                   ReportingInterval
}

InterFreqEventResults ::=           SEQUENCE {
    eventID                             EventIDInterFreq,
    interFreqCellList                   InterFreqCellList                   OPTIONAL
}

InterFreqEventResults-LCR-r4-ext ::=    SEQUENCE {
    eventID                             EventIDInterFreq,
    interFreqCellList                   InterFreqCellList-LCR-r4-ext        OPTIONAL
}

InterFreqMeasQuantity ::=           SEQUENCE {
    reportingCriteria                   CHOICE {
        intraFreqReportingCriteria          SEQUENCE {
            intraFreqMeasQuantity               IntraFreqMeasQuantity
        },
        interFreqReportingCriteria          SEQUENCE {
            filterCoefficient                   FilterCoefficient           DEFAULT fc0,
            modeSpecificInfo                    CHOICE {
                fdd                                 SEQUENCE {
                    freqQualityEstimateQuantity-FDD     FreqQualityEstimateQuantity-FDD
                },
                tdd                                 SEQUENCE {
                    freqQualityEstimateQuantity-TDD     FreqQualityEstimateQuantity-TDD
                }
            }
        }
    }
}

InterFreqMeasuredResults ::=        SEQUENCE {
    frequencyInfo                       FrequencyInfo                       OPTIONAL,
    utra-CarrierRSSI                    UTRA-CarrierRSSI                    OPTIONAL,
    interFreqCellMeasuredResultsList    InterFreqCellMeasuredResultsList    OPTIONAL
}

InterFreqMeasuredResultsList ::=    SEQUENCE (SIZE (1..maxFreq)) OF
                                        InterFreqMeasuredResults


InterFreqMeasurementSysInfo-RSCP ::=    SEQUENCE {
```

```
    interFreqCellInfoSI-List                InterFreqCellInfoSI-List-RSCP       OPTIONAL
}

InterFreqMeasurementSysInfo-ECN0 ::=        SEQUENCE {
    interFreqCellInfoSI-List            InterFreqCellInfoSI-List-ECN0       OPTIONAL
}

InterFreqMeasurementSysInfo-HCS-RSCP ::=        SEQUENCE {
    interFreqCellInfoSI-List            InterFreqCellInfoSI-List-HCS-RSCP   OPTIONAL
}

InterFreqMeasurementSysInfo-HCS-ECN0 ::=        SEQUENCE {
    interFreqCellInfoSI-List            InterFreqCellInfoSI-List-HCS-ECN0   OPTIONAL
}

InterFreqMeasurementSysInfo-RSCP-LCR-r4 ::= SEQUENCE {
    interFreqCellInfoSI-List                InterFreqCellInfoSI-List-RSCP-LCR       OPTIONAL
}

InterFreqMeasurementSysInfo-ECN0-LCR-r4 ::=     SEQUENCE {
    interFreqCellInfoSI-List            InterFreqCellInfoSI-List-ECN0-LCR       OPTIONAL
}

InterFreqMeasurementSysInfo-HCS-RSCP-LCR-r4 ::=     SEQUENCE {
    interFreqCellInfoSI-List            InterFreqCellInfoSI-List-HCS-RSCP-LCR   OPTIONAL
}

InterFreqMeasurementSysInfo-HCS-ECN0-LCR-r4 ::=     SEQUENCE {
    interFreqCellInfoSI-List            InterFreqCellInfoSI-List-HCS-ECN0-LCR   OPTIONAL
}

InterFreqRACHRepCellsList ::=           SEQUENCE (SIZE (1..maxFreq)) OF
InterFreqCellID

InterFreqRACHReportingInfo ::= SEQUENCE {
    modeSpecificInfo                    CHOICE {
        fdd                                 SEQUENCE {
            interFreqRepQuantityRACH-FDD        InterFreqRepQuantityRACH-FDD
        },
        tdd                                 SEQUENCE {
            interFreqRepQuantityRACH-TDDList    InterFreqRepQuantityRACH-TDDList
        },
    interFreqRACHReportingThreshold     Threshold,
    maxReportedCellsOnRACHinterFreq     MaxReportedCellsOnRACHinterFreq
    }
}

InterFreqReportCriteria ::=         CHOICE {
    intraFreqReportingCriteria          IntraFreqReportingCriteria,
    interFreqReportingCriteria          InterFreqReportingCriteria,
    periodicalReportingCriteria         PeriodicalWithReportingCellStatus,
    noReporting                         ReportingCellStatusOpt
}

InterFreqReportCriteria-r4 ::=      CHOICE {
    intraFreqReportingCriteria          IntraFreqReportingCriteria-r4,
    interFreqReportingCriteria          InterFreqReportingCriteria,
    periodicalReportingCriteria         PeriodicalWithReportingCellStatus,
    noReporting                         ReportingCellStatusOpt
}

InterFreqReportCriteria-r6 ::=      CHOICE {
    intraFreqReportingCriteria          IntraFreqReportingCriteria-r6,
    interFreqReportingCriteria          InterFreqReportingCriteria-r6,
    periodicalReportingCriteria         PeriodicalWithReportingCellStatus,
    noReporting                         ReportingCellStatusOpt
}

InterFreqReportingCriteria ::=      SEQUENCE {
    interFreqEventList                  InterFreqEventList                  OPTIONAL
}

InterFreqReportingCriteria-r6 ::=   SEQUENCE {
    interFreqEventList                  InterFreqEventList-r6               OPTIONAL
}

InterFreqReportingQuantity ::=      SEQUENCE {
    utra-Carrier-RSSI                   BOOLEAN,
```

```
    frequencyQualityEstimate            BOOLEAN,
    nonFreqRelatedQuantities            CellReportingQuantities
}

InterFreqRepQuantityRACH-FDD ::=    ENUMERATED {
                                        cpich-EcN0, cpich-RSCP }

InterFreqRepQuantityRACH-TDD ::=    ENUMERATED {
                                        timeslotISCP,
                                        primaryCCPCH-RSCP }

InterFreqRepQuantityRACH-TDDList ::= SEQUENCE (SIZE (1..2)) OF
                                        InterFreqRepQuantityRACH-TDD

InterFrequencyMeasurement ::=       SEQUENCE {
    interFreqCellInfoList               InterFreqCellInfoList,
    interFreqMeasQuantity               InterFreqMeasQuantity               OPTIONAL,
    interFreqReportingQuantity          InterFreqReportingQuantity          OPTIONAL,
    measurementValidity                 MeasurementValidity                 OPTIONAL,
    interFreqSetUpdate                  UE-AutonomousUpdateMode             OPTIONAL,
    reportCriteria                      InterFreqReportCriteria
}

InterFrequencyMeasurement-r4 ::=    SEQUENCE {
    interFreqCellInfoList               InterFreqCellInfoList-r4,
    interFreqMeasQuantity               InterFreqMeasQuantity               OPTIONAL,
    interFreqReportingQuantity          InterFreqReportingQuantity          OPTIONAL,
    measurementValidity                 MeasurementValidity                 OPTIONAL,
    interFreqSetUpdate                  UE-AutonomousUpdateMode             OPTIONAL,
    reportCriteria                      InterFreqReportCriteria-r4
}

InterFrequencyMeasurement-r6 ::=    SEQUENCE {
    interFreqCellInfoList               InterFreqCellInfoList-r4,
    interFreqMeasQuantity               InterFreqMeasQuantity               OPTIONAL,
    interFreqReportingQuantity          InterFreqReportingQuantity          OPTIONAL,
    measurementValidity                 MeasurementValidity                 OPTIONAL,
    interFreqSetUpdate                  UE-AutonomousUpdateMode             OPTIONAL,
    reportCriteria                      InterFreqReportCriteria-r6
}

InterRAT-TargetCellDescription ::=  SEQUENCE {
    technologySpecificInfo              CHOICE {
        gsm                                 SEQUENCE {
            bsic                                BSIC,
            frequency-band                      Frequency-Band,
            bcch-ARFCN                          BCCH-ARFCN,
            ncMode                              NC-Mode             OPTIONAL
        },
        is-2000                             NULL,
        spare2                              NULL,
        spare1                              NULL
    }
}

InterRATCellID ::=              INTEGER (0..maxCellMeas-1)

InterRATCellInfoIndication ::=      INTEGER (0..3)

InterRATCellInfoList ::=            SEQUENCE {
    removedInterRATCellList         RemovedInterRATCellList,
    -- NOTE: Future revisions of dedicated messages including IE newInterRATCellList
    -- should use a corrected version of this IE
    newInterRATCellList             NewInterRATCellList,
    cellsForInterRATMeasList            CellsForInterRATMeasList            OPTIONAL
}

InterRATCellInfoList-B ::=          SEQUENCE {
    removedInterRATCellList         RemovedInterRATCellList,
    -- NOTE: IE newInterRATCellList should be optional.  However, system information
    -- does not support message versions.  Hence, this can not be corrected
    newInterRATCellList             NewInterRATCellList-B
}

InterRATCellInfoList-r4 ::=         SEQUENCE {
    removedInterRATCellList             RemovedInterRATCellList,
    newInterRATCellList                 NewInterRATCellList                 OPTIONAL,
    cellsForInterRATMeasList            CellsForInterRATMeasList            OPTIONAL
```

```
}

InterRATCellInfoList-r6 ::=         SEQUENCE {
    removedInterRATCellList                 RemovedInterRATCellList,
    newInterRATCellList                     NewInterRATCellList                 OPTIONAL,
    cellsForInterRATMeasList                CellsForInterRATMeasList            OPTIONAL,
    interRATCellInfoIndication-r6           InterRATCellInfoIndication          OPTIONAL
}

InterRATCellIndividualOffset ::=            INTEGER (-50..50)

InterRATEvent ::=               CHOICE {
    event3a                             Event3a,
    event3b                             Event3b,
    event3c                             Event3c,
    event3d                             Event3d
}

InterRATEventList ::=           SEQUENCE (SIZE (1..maxMeasEvent)) OF
                                    InterRATEvent

InterRATEventResults ::=            SEQUENCE {
    eventID                             EventIDInterRAT,
    cellToReportList                    CellToReportList
}

InterRATInfo ::=                    ENUMERATED {
                                    gsm }

InterRATInfo-r6 ::=                 SEQUENCE {
    rat                                 InterRATInfo,
    gsm-TargetCellInfoList              GSM-TargetCellInfoList          OPTIONAL
}

InterRATMeasQuantity ::=                SEQUENCE {
    measQuantityUTRAN-QualityEstimate       IntraFreqMeasQuantity           OPTIONAL,
    ratSpecificInfo                     CHOICE {
        gsm                                     SEQUENCE {
            measurementQuantity                     MeasurementQuantityGSM,
            filterCoefficient                       FilterCoefficient       DEFAULT fc0,
            bsic-VerificationRequired               BSIC-VerificationRequired
        },
        is-2000                                 SEQUENCE {
            tadd-EcIo                               INTEGER (0..63),
            tcomp-EcIo                              INTEGER (0..15),
            softSlope                               INTEGER (0..63)         OPTIONAL,
            addIntercept                            INTEGER (0..63)         OPTIONAL
        }
    }
}

InterRATMeasuredResults ::=     CHOICE {
    gsm                                 GSM-MeasuredResultsList,
    spare                               NULL
}

InterRATMeasuredResultsList ::= SEQUENCE (SIZE (1..maxOtherRAT-16)) OF
                                    InterRATMeasuredResults

InterRATMeasurement ::=         SEQUENCE {
    interRATCellInfoList                InterRATCellInfoList                OPTIONAL,
    interRATMeasQuantity                InterRATMeasQuantity                OPTIONAL,
    interRATReportingQuantity           InterRATReportingQuantity       OPTIONAL,
    reportCriteria                      InterRATReportCriteria
}

InterRATMeasurement-r4 ::=          SEQUENCE {
    interRATCellInfoList                InterRATCellInfoList-r4             OPTIONAL,
    interRATMeasQuantity                InterRATMeasQuantity                OPTIONAL,
    interRATReportingQuantity           InterRATReportingQuantity       OPTIONAL,
    reportCriteria                      InterRATReportCriteria
}

InterRATMeasurement-r6 ::=          SEQUENCE {
    interRATCellInfoList                InterRATCellInfoList-r6             OPTIONAL,
    interRATMeasQuantity                InterRATMeasQuantity                OPTIONAL,
    interRATReportingQuantity           InterRATReportingQuantity       OPTIONAL,
    reportCriteria                      InterRATReportCriteria
```

```
}

InterRATMeasurementSysInfo ::=  SEQUENCE {
    interRATCellInfoList                InterRATCellInfoList                OPTIONAL
}

InterRATMeasurementSysInfo-B ::=    SEQUENCE {
    interRATCellInfoList                InterRATCellInfoList-B          OPTIONAL
}

InterRATReportCriteria ::=      CHOICE {
    interRATReportingCriteria           InterRATReportingCriteria,
    periodicalReportingCriteria         PeriodicalWithReportingCellStatus,
    noReporting                         ReportingCellStatusOpt
}

InterRATReportingCriteria ::=   SEQUENCE {
    interRATEventList               InterRATEventList               OPTIONAL
}

InterRATReportingQuantity ::=   SEQUENCE {
    utran-EstimatedQuality              BOOLEAN,
    ratSpecificInfo                 CHOICE {
        gsm                                 SEQUENCE {
            -- dummy and dummy2 are not used in this version of the specification
            -- and when received they should be ignored.
            dummy                               BOOLEAN,
            dummy2                              BOOLEAN,
            gsm-Carrier-RSSI                    BOOLEAN
        }
    }
}

IntraFreqCellID ::=                 INTEGER (0..maxCellMeas-1)

IntraFreqCellInfoList ::=           SEQUENCE {
    removedIntraFreqCellList            RemovedIntraFreqCellList            OPTIONAL,
    newIntraFreqCellList                NewIntraFreqCellList                OPTIONAL,
    cellsForIntraFreqMeasList           CellsForIntraFreqMeasList           OPTIONAL
}

IntraFreqCellInfoList-r4 ::=        SEQUENCE {
    removedIntraFreqCellList            RemovedIntraFreqCellList            OPTIONAL,
    newIntraFreqCellList                NewIntraFreqCellList-r4             OPTIONAL,
    cellsForIntraFreqMeasList           CellsForIntraFreqMeasList           OPTIONAL
}

IntraFreqCellInfoSI-List-RSCP ::=   SEQUENCE {
    removedIntraFreqCellList            RemovedIntraFreqCellList            OPTIONAL,
    newIntraFreqCellList                NewIntraFreqCellSI-List-RSCP
}

IntraFreqCellInfoSI-List-ECN0 ::=       SEQUENCE {
    removedIntraFreqCellList            RemovedIntraFreqCellList            OPTIONAL,
    newIntraFreqCellList                NewIntraFreqCellSI-List-ECN0
}

IntraFreqCellInfoSI-List-HCS-RSCP ::=       SEQUENCE {
    removedIntraFreqCellList            RemovedIntraFreqCellList            OPTIONAL,
    newIntraFreqCellList                NewIntraFreqCellSI-List-HCS-RSCP
}

IntraFreqCellInfoSI-List-HCS-ECN0 ::=       SEQUENCE {
    removedIntraFreqCellList            RemovedIntraFreqCellList            OPTIONAL,
    newIntraFreqCellList                NewIntraFreqCellSI-List-HCS-ECN0
}

IntraFreqCellInfoSI-List-RSCP-LCR-r4 ::=    SEQUENCE {
    removedIntraFreqCellList            RemovedIntraFreqCellList            OPTIONAL,
    newIntraFreqCellList                NewIntraFreqCellSI-List-RSCP-LCR-r4
}

IntraFreqCellInfoSI-List-ECN0-LCR-r4 ::=        SEQUENCE {
    removedIntraFreqCellList            RemovedIntraFreqCellList            OPTIONAL,
    newIntraFreqCellList                NewIntraFreqCellSI-List-ECN0-LCR-r4
}

IntraFreqCellInfoSI-List-HCS-RSCP-LCR-r4 ::=        SEQUENCE {
```

```
    removedIntraFreqCellList            RemovedIntraFreqCellList            OPTIONAL,
    newIntraFreqCellList                NewIntraFreqCellSI-List-HCS-RSCP-LCR-r4
}

IntraFreqCellInfoSI-List-HCS-ECN0-LCR-r4 ::=        SEQUENCE {
    removedIntraFreqCellList            RemovedIntraFreqCellList            OPTIONAL,
    newIntraFreqCellList                NewIntraFreqCellSI-List-HCS-ECN0-LCR-r4
}

IntraFreqEvent ::=                  CHOICE {
    e1a                                 Event1a,
    e1b                                 Event1b,
    e1c                                 Event1c,
    e1d                                 NULL,
    e1e                                 Event1e,
    e1f                                 Event1f,
    e1g                                 NULL,
    e1h                                 ThresholdUsedFrequency,
    e1i                                 ThresholdUsedFrequency
}

IntraFreqEvent-r4 ::=               CHOICE {
    e1a                                 Event1a-r4,
    e1b                                 Event1b-r4,
    e1c                                 Event1c,
    e1d                                 NULL,
    e1e                                 Event1e,
    e1f                                 Event1f,
    e1g                                 NULL,
    e1h                                 ThresholdUsedFrequency,
    e1i                                 ThresholdUsedFrequency
}

IntraFreqEvent-LCR-r4 ::=           CHOICE {
    e1a                                 Event1a-LCR-r4,
    e1b                                 Event1b-LCR-r4,
    e1c                                 Event1c,
    e1d                                 NULL,
    e1e                                 Event1e,
    e1f                                 Event1f,
    e1g                                 NULL,
    e1h                                 ThresholdUsedFrequency,
    e1i                                 ThresholdUsedFrequency
}

IntraFreqEvent-r6 ::=               CHOICE {
    e1a                                 Event1a-r4,
    e1b                                 Event1b-r4,
    e1c                                 Event1c,
    e1d                                 Event1d,
    e1e                                 Event1e-r6,
    e1f                                 Event1f-r6,
    e1g                                 NULL,
    e1h                                 ThresholdUsedFrequency-r6,
    e1i                                 ThresholdUsedFrequency-r6,
    e1j                                 Event1j-r6
}

IntraFreqEvent-1d-r5 ::=        SEQUENCE {
    triggeringCondition                 TriggeringCondition2    OPTIONAL,
    useCIO                              BOOLEAN                 OPTIONAL
}

IntraFreqEventCriteria ::=          SEQUENCE {
    event                               IntraFreqEvent,
    hysteresis                          Hysteresis,
    timeToTrigger                       TimeToTrigger,
    reportingCellStatus                 ReportingCellStatus                 OPTIONAL
}

IntraFreqEventCriteria-r4 ::=       SEQUENCE {
    event                               IntraFreqEvent-r4,
    hysteresis                          Hysteresis,
    timeToTrigger                       TimeToTrigger,
    reportingCellStatus                 ReportingCellStatus                 OPTIONAL
}

IntraFreqEventCriteria-LCR-r4 ::=   SEQUENCE {
```

```
    event                               IntraFreqEvent-LCR-r4,
    hysteresis                          Hysteresis,
    timeToTrigger                       TimeToTrigger,
    reportingCellStatus                 ReportingCellStatus                 OPTIONAL
}

IntraFreqEventCriteria-r6 ::=   SEQUENCE {
    event                               IntraFreqEvent-r6,
    hysteresis                          Hysteresis,
    timeToTrigger                       TimeToTrigger,
    reportingCellStatus                 ReportingCellStatus                 OPTIONAL
}

IntraFreqEventCriteriaList ::=      SEQUENCE (SIZE (1..maxMeasEvent)) OF
                                        IntraFreqEventCriteria

IntraFreqEventCriteriaList-r4 ::=   SEQUENCE (SIZE (1..maxMeasEvent)) OF
                                        IntraFreqEventCriteria-r4

IntraFreqEventCriteriaList-LCR-r4 ::=   SEQUENCE (SIZE (1..maxMeasEvent)) OF
                                        IntraFreqEventCriteria-LCR-r4

IntraFreqEventCriteriaList-r6 ::=       SEQUENCE (SIZE (1..maxMeasEvent)) OF
                                        IntraFreqEventCriteria-r6

IntraFreqEventResults ::=           SEQUENCE {
    eventID                             EventIDIntraFreq,
    cellMeasurementEventResults         CellMeasurementEventResults
}

IntraFreqMeasQuantity ::=           SEQUENCE {
    filterCoefficient                   FilterCoefficient                   DEFAULT fc0,
    modeSpecificInfo                    CHOICE {
        fdd                             SEQUENCE {
            intraFreqMeasQuantity-FDD       IntraFreqMeasQuantity-FDD
        },
        tdd                             SEQUENCE {
            intraFreqMeasQuantity-TDDList   IntraFreqMeasQuantity-TDDList
        }
    }
}

-- If IntraFreqMeasQuantity-FDD is used in InterRATMeasQuantity, then only
-- cpich-Ec-N0 and cpich-RSCP are allowed.
-- dummy is not used in this version of the specification, it should
-- not be sent and if received it should be ignored.
IntraFreqMeasQuantity-FDD ::=       ENUMERATED {
                                        cpich-Ec-N0,
                                        cpich-RSCP,
                                        pathloss,
                                        dummy }

-- dummy is not used in this version of the specification, it should
-- not be sent and if received it should be ignored.
IntraFreqMeasQuantity-TDD ::=       ENUMERATED {
                                        primaryCCPCH-RSCP,
                                        pathloss,
                                        timeslotISCP,
                                        dummy }

IntraFreqMeasQuantity-TDDList ::=   SEQUENCE (SIZE (1..4)) OF
                                        IntraFreqMeasQuantity-TDD

IntraFreqMeasuredResultsList ::=    SEQUENCE (SIZE (1..maxCellMeas)) OF
                                        CellMeasuredResults

IntraFreqMeasurementSysInfo-RSCP ::=    SEQUENCE {
    intraFreqMeasurementID              MeasurementIdentity         DEFAULT 1,
    intraFreqCellInfoSI-List            IntraFreqCellInfoSI-List-RSCP       OPTIONAL,
    intraFreqMeasQuantity               IntraFreqMeasQuantity               OPTIONAL,
    intraFreqReportingQuantityForRACH   IntraFreqReportingQuantityForRACH   OPTIONAL,
    maxReportedCellsOnRACH              MaxReportedCellsOnRACH              OPTIONAL,
    reportingInfoForCellDCH             ReportingInfoForCellDCH             OPTIONAL
}

IntraFreqMeasurementSysInfo-ECN0 ::=        SEQUENCE {
    intraFreqMeasurementID              MeasurementIdentity         DEFAULT 1,
    intraFreqCellInfoSI-List            IntraFreqCellInfoSI-List-ECN0       OPTIONAL,
```

```
    intraFreqMeasQuantity               IntraFreqMeasQuantity               OPTIONAL,
    intraFreqReportingQuantityForRACH   IntraFreqReportingQuantityForRACH   OPTIONAL,
    maxReportedCellsOnRACH              MaxReportedCellsOnRACH              OPTIONAL,
    reportingInfoForCellDCH             ReportingInfoForCellDCH             OPTIONAL
}

IntraFreqMeasurementSysInfo-HCS-RSCP ::=    SEQUENCE {
    intraFreqMeasurementID              MeasurementIdentity         DEFAULT 1,
    intraFreqCellInfoSI-List            IntraFreqCellInfoSI-List-HCS-RSCP   OPTIONAL,
    intraFreqMeasQuantity               IntraFreqMeasQuantity               OPTIONAL,
    intraFreqReportingQuantityForRACH   IntraFreqReportingQuantityForRACH   OPTIONAL,
    maxReportedCellsOnRACH              MaxReportedCellsOnRACH              OPTIONAL,
    reportingInfoForCellDCH             ReportingInfoForCellDCH             OPTIONAL
}

IntraFreqMeasurementSysInfo-HCS-ECN0 ::=    SEQUENCE {
    intraFreqMeasurementID              MeasurementIdentity         DEFAULT 1,
    intraFreqCellInfoSI-List            IntraFreqCellInfoSI-List-HCS-ECN0   OPTIONAL,
    intraFreqMeasQuantity               IntraFreqMeasQuantity               OPTIONAL,
    intraFreqReportingQuantityForRACH   IntraFreqReportingQuantityForRACH   OPTIONAL,
    maxReportedCellsOnRACH              MaxReportedCellsOnRACH              OPTIONAL,
    reportingInfoForCellDCH             ReportingInfoForCellDCH             OPTIONAL
}

IntraFreqMeasurementSysInfo-RSCP-LCR-r4 ::= SEQUENCE {
    intraFreqMeasurementID              MeasurementIdentity         DEFAULT 1,
    intraFreqCellInfoSI-List            IntraFreqCellInfoSI-List-RSCP-LCR-r4    OPTIONAL,
    intraFreqMeasQuantity               IntraFreqMeasQuantity               OPTIONAL,
    intraFreqReportingQuantityForRACH   IntraFreqReportingQuantityForRACH   OPTIONAL,
    maxReportedCellsOnRACH              MaxReportedCellsOnRACH              OPTIONAL,
    reportingInfoForCellDCH             ReportingInfoForCellDCH-LCR-r4      OPTIONAL
}

IntraFreqMeasurementSysInfo-ECN0-LCR-r4 ::=     SEQUENCE {
    intraFreqMeasurementID              MeasurementIdentity         DEFAULT 1,
    intraFreqCellInfoSI-List            IntraFreqCellInfoSI-List-ECN0-LCR-r4    OPTIONAL,
    intraFreqMeasQuantity               IntraFreqMeasQuantity               OPTIONAL,
    intraFreqReportingQuantityForRACH   IntraFreqReportingQuantityForRACH   OPTIONAL,
    maxReportedCellsOnRACH              MaxReportedCellsOnRACH              OPTIONAL,
    reportingInfoForCellDCH             ReportingInfoForCellDCH-LCR-r4      OPTIONAL
}

IntraFreqMeasurementSysInfo-HCS-RSCP-LCR-r4 ::= SEQUENCE {
    intraFreqMeasurementID              MeasurementIdentity         DEFAULT 1,
    intraFreqCellInfoSI-List            IntraFreqCellInfoSI-List-HCS-RSCP-LCR-r4    OPTIONAL,
    intraFreqMeasQuantity               IntraFreqMeasQuantity               OPTIONAL,
    intraFreqReportingQuantityForRACH   IntraFreqReportingQuantityForRACH   OPTIONAL,
    maxReportedCellsOnRACH              MaxReportedCellsOnRACH              OPTIONAL,
    reportingInfoForCellDCH             ReportingInfoForCellDCH-LCR-r4      OPTIONAL
}

IntraFreqMeasurementSysInfo-HCS-ECN0-LCR-r4 ::= SEQUENCE {
    intraFreqMeasurementID              MeasurementIdentity         DEFAULT 1,
    intraFreqCellInfoSI-List            IntraFreqCellInfoSI-List-HCS-ECN0-LCR-r4    OPTIONAL,
    intraFreqMeasQuantity               IntraFreqMeasQuantity               OPTIONAL,
    intraFreqReportingQuantityForRACH   IntraFreqReportingQuantityForRACH   OPTIONAL,
    maxReportedCellsOnRACH              MaxReportedCellsOnRACH              OPTIONAL,
    reportingInfoForCellDCH             ReportingInfoForCellDCH-LCR-r4      OPTIONAL
}

IntraFreqReportCriteria ::=         CHOICE {
    intraFreqReportingCriteria          IntraFreqReportingCriteria,
    periodicalReportingCriteria         PeriodicalWithReportingCellStatus,
    noReporting                         ReportingCellStatusOpt
}

IntraFreqReportCriteria-r4 ::=      CHOICE {
    intraFreqReportingCriteria          IntraFreqReportingCriteria-r4,
    periodicalReportingCriteria         PeriodicalWithReportingCellStatus,
    noReporting                         ReportingCellStatusOpt
}

IntraFreqReportCriteria-r6 ::=      CHOICE {
    intraFreqReportingCriteria          IntraFreqReportingCriteria-r6,
    periodicalReportingCriteria         PeriodicalWithReportingCellStatus,
    noReporting                         ReportingCellStatusOpt
}
```

```
IntraFreqReportingCriteria ::=      SEQUENCE {
    eventCriteriaList                   IntraFreqEventCriteriaList      OPTIONAL
}

IntraFreqReportingCriteria-r4 ::=   SEQUENCE {
    eventCriteriaList                   IntraFreqEventCriteriaList-r4   OPTIONAL
}

IntraFreqReportingCriteria-LCR-r4 ::=   SEQUENCE {
    eventCriteriaList                   IntraFreqEventCriteriaList-LCR-r4   OPTIONAL
}

IntraFreqReportingCriteria-r6 ::= SEQUENCE {
    eventCriteriaList                   IntraFreqEventCriteriaList-r6   OPTIONAL
}

IntraFreqReportingQuantity ::=      SEQUENCE {
    activeSetReportingQuantities        CellReportingQuantities,
    monitoredSetReportingQuantities     CellReportingQuantities,
    detectedSetReportingQuantities      CellReportingQuantities             OPTIONAL
}

IntraFreqReportingQuantityForRACH ::= SEQUENCE {
    sfn-SFN-OTD-Type                    SFN-SFN-OTD-Type,
    modeSpecificInfo                    CHOICE {
        fdd                                 SEQUENCE {
            intraFreqRepQuantityRACH-FDD        IntraFreqRepQuantityRACH-FDD
        },
        tdd                                 SEQUENCE {
            intraFreqRepQuantityRACH-TDDList    IntraFreqRepQuantityRACH-TDDList
        }
    }
}

IntraFreqRepQuantityRACH-FDD ::=    ENUMERATED {
                                        cpich-EcN0, cpich-RSCP,
                                        pathloss, noReport }

IntraFreqRepQuantityRACH-TDD ::=    ENUMERATED {
                                        timeslotISCP,
                                        primaryCCPCH-RSCP,
                                        noReport }

IntraFreqRepQuantityRACH-TDDList ::= SEQUENCE (SIZE (1..2)) OF
                                        IntraFreqRepQuantityRACH-TDD

IntraFrequencyMeasurement ::=       SEQUENCE {
    intraFreqCellInfoList               IntraFreqCellInfoList               OPTIONAL,
    intraFreqMeasQuantity               IntraFreqMeasQuantity               OPTIONAL,
    intraFreqReportingQuantity          IntraFreqReportingQuantity          OPTIONAL,
    measurementValidity                 MeasurementValidity                 OPTIONAL,
    reportCriteria                      IntraFreqReportCriteria             OPTIONAL
}

IntraFrequencyMeasurement-r4 ::=    SEQUENCE {
    intraFreqCellInfoList               IntraFreqCellInfoList-r4            OPTIONAL,
    intraFreqMeasQuantity               IntraFreqMeasQuantity               OPTIONAL,
    intraFreqReportingQuantity          IntraFreqReportingQuantity          OPTIONAL,
    measurementValidity                 MeasurementValidity                 OPTIONAL,
    reportCriteria                      IntraFreqReportCriteria-r4          OPTIONAL
}

IntraFrequencyMeasurement-r6 ::=        SEQUENCE {
    intraFreqCellInfoList               IntraFreqCellInfoList-r4            OPTIONAL,
    intraFreqMeasQuantity               IntraFreqMeasQuantity               OPTIONAL,
    intraFreqReportingQuantity          IntraFreqReportingQuantity          OPTIONAL,
    measurementValidity                 MeasurementValidity                 OPTIONAL,
    reportCriteria                      IntraFreqReportCriteria-r6
}

IODE ::=                            INTEGER (0..255)

IP-Length ::=                       ENUMERATED {
                                        ipl5, ipl10 }

IP-PCCPCH-r4 ::=                    BOOLEAN

IP-Spacing ::=                      ENUMERATED {
```

```
                                    e5, e7, e10, e15, e20,
                                    e30, e40, e50 }

IP-Spacing-TDD ::=                  ENUMERATED {
                                    e30, e40, e50, e70, e100}

IS-2000SpecificMeasInfo ::=         ENUMERATED {
                                    frequency, timeslot, colourcode,
                                    outputpower, pn-Offset }

MaxNumberOfReportingCellsType1 ::=  ENUMERATED {
                                    e1, e2, e3, e4, e5, e6}

MaxNumberOfReportingCellsType2 ::=  ENUMERATED {
                                    e1, e2, e3, e4, e5, e6, e7, e8, e9, e10, e11, e12}

MaxNumberOfReportingCellsType3 ::=  ENUMERATED {
                                    viactCellsPlus1,
                                    viactCellsPlus2,
                                    viactCellsPlus3,
                                    viactCellsPlus4,
                                    viactCellsPlus5,
                                    viactCellsPlus6 }

MaxReportedCellsOnRACH ::=          ENUMERATED {
                                    noReport,
                                    currentCell,
                                    currentAnd-1-BestNeighbour,
                                    currentAnd-2-BestNeighbour,
                                    currentAnd-3-BestNeighbour,
                                    currentAnd-4-BestNeighbour,
                                    currentAnd-5-BestNeighbour,
                                    currentAnd-6-BestNeighbour }

MaxReportedCellsOnRACHinterFreq ::=     INTEGER (1..8)

MeasuredResults ::=                 CHOICE {
    intraFreqMeasuredResultsList        IntraFreqMeasuredResultsList,
    interFreqMeasuredResultsList        InterFreqMeasuredResultsList,
    interRATMeasuredResultsList     InterRATMeasuredResultsList,
    trafficVolumeMeasuredResultsList    TrafficVolumeMeasuredResultsList,
    qualityMeasuredResults              QualityMeasuredResults,
    ue-InternalMeasuredResults          UE-InternalMeasuredResults,
    ue-positioning-MeasuredResults      UE-Positioning-MeasuredResults,
    spare                               NULL
}

MeasuredResults-v390ext ::=                 SEQUENCE {
    ue-positioning-MeasuredResults-v390ext                  UE-Positioning-MeasuredResults-v390ext
}


MeasuredResults-v590ext ::= CHOICE {
    intraFrequencyMeasuredResultsList       IntraFrequencyMeasuredResultsList-v590ext,
    interFrequencyMeasuredResultsList       InterFrequencyMeasuredResultsList-v590ext
}

MeasuredResults-v7xyext ::= CHOICE {
    ueInternalMeasuredResults       UE-InternalMeasuredResults-r7
}

MeasuredResults-LCR-r4 ::=          CHOICE {
    intraFreqMeasuredResultsList        IntraFreqMeasuredResultsList,
    interFreqMeasuredResultsList        InterFreqMeasuredResultsList,
    interRATMeasuredResultsList     InterRATMeasuredResultsList,
    trafficVolumeMeasuredResultsList    TrafficVolumeMeasuredResultsList,
    qualityMeasuredResults              QualityMeasuredResults,
    ue-InternalMeasuredResults          UE-InternalMeasuredResults-LCR-r4,
    ue-positioniing-MeasuredResults     UE-Positioning-MeasuredResults,
    spare                               NULL
}

MeasuredResultsList ::=             SEQUENCE (SIZE (1..maxAdditionalMeas)) OF
                                    MeasuredResults

MeasuredResultsList-LCR-r4-ext ::=  SEQUENCE (SIZE (1..maxAdditionalMeas)) OF
                                    MeasuredResults-LCR-r4
```

```
MeasuredResultsOnRACH ::=           SEQUENCE {
    currentCell                         SEQUENCE {
        modeSpecificInfo                    CHOICE {
            fdd                                 SEQUENCE {
                measurementQuantity                 CHOICE {
                    cpich-Ec-N0                         CPICH-Ec-N0,
                    cpich-RSCP                          CPICH-RSCP,
                    pathloss                            Pathloss,
                    spare                               NULL
                }
            },
            tdd                                 SEQUENCE {
                -- For 3.84 Mcps and 7.68 Mcps TDD   --
                timeslotISCP                        TimeslotISCP-List       OPTIONAL,
                primaryCCPCH-RSCP                   PrimaryCCPCH-RSCP       OPTIONAL
            }
        }
    },
    monitoredCells                      MonitoredCellRACH-List              OPTIONAL
}

MeasuredResultsOnRACHinterFreq ::=      SEQUENCE {
    interFreqCellIndication-SIB11           INTEGER (0..1),
    interFreqCellIndication-SIB12           INTEGER (0..1),
    interFreqRACHRepCellsList               InterFreqRACHRepCellsList
}

MeasurementCommand ::=              CHOICE {
    setup                               MeasurementType,
    modify                              SEQUENCE {
        measurementType                     MeasurementType                 OPTIONAL
    },
    release                             NULL
}

MeasurementCommand-r4 ::=           CHOICE {
    setup                               MeasurementType-r4,
    modify                              SEQUENCE {
        measurementType                     MeasurementType-r4              OPTIONAL
    },
    release                             NULL
}

MeasurementCommand-r6 ::=           CHOICE {
    setup                               MeasurementType-r6,
    modify                              SEQUENCE {
        measurementType                     MeasurementType-r6              OPTIONAL
    },
    release                             NULL
}

MeasurementControlSysInfo ::=       SEQUENCE {
    -- CHOICE cellSelectQualityMeasure represents PCCPCH-RSCP in TDD mode.
    use-of-HCS                          CHOICE  {
        hcs-not-used                    SEQUENCE    {
            cellSelectQualityMeasure    CHOICE  {
                cpich-RSCP              SEQUENCE    {
                    intraFreqMeasurementSysInfo         IntraFreqMeasurementSysInfo-RSCP
    OPTIONAL,
                    interFreqMeasurementSysInfo         InterFreqMeasurementSysInfo-RSCP    OPTIONAL
                },
                cpich-Ec-N0             SEQUENCE    {
                    intraFreqMeasurementSysInfo         IntraFreqMeasurementSysInfo-ECN0
    OPTIONAL,
                    interFreqMeasurementSysInfo         InterFreqMeasurementSysInfo-ECN0    OPTIONAL
                }
            },
            interRATMeasurementSysInfo      InterRATMeasurementSysInfo-B        OPTIONAL
        },
        hcs-used                        SEQUENCE    {
            cellSelectQualityMeasure    CHOICE  {
                cpich-RSCP              SEQUENCE    {
                    intraFreqMeasurementSysInfo         IntraFreqMeasurementSysInfo-HCS-RSCP
    OPTIONAL,
                    interFreqMeasurementSysInfo         InterFreqMeasurementSysInfo-HCS-RSCP
    OPTIONAL
                },
                cpich-Ec-N0             SEQUENCE    {
```

```
                    intraFreqMeasurementSysInfo         IntraFreqMeasurementSysInfo-HCS-ECN0
    OPTIONAL,
                    interFreqMeasurementSysInfo         InterFreqMeasurementSysInfo-HCS-ECN0
    OPTIONAL                }
            },
            interRATMeasurementSysInfo      InterRATMeasurementSysInfo      OPTIONAL
        }
    },

    trafficVolumeMeasSysInfo            TrafficVolumeMeasSysInfo            OPTIONAL,
    -- dummy is not used in this version of specification and it shall be ignored by the UE.
    dummy       UE-InternalMeasurementSysInfo       OPTIONAL
}

MeasurementControlSysInfo-LCR-r4-ext ::=    SEQUENCE {
    -- CHOICE use-of-HCS shall have the same value as the use-of-HCS
    -- in MeasurementControlSysInfo
    -- CHOICE cellSelectQualityMeasure represents PCCPCH-RSCP in TDD mode.
    use-of-HCS                          CHOICE  {
        hcs-not-used                    SEQUENCE    {
            -- CHOICE cellSelectQualityMeasure shall have the same value as the
            -- cellSelectQualityMeasure in MeasurementControlSysInfo
            cellSelectQualityMeasure    CHOICE  {
                cpich-RSCP              SEQUENCE    {
                    intraFreqMeasurementSysInfo IntraFreqMeasurementSysInfo-RSCP-LCR-r4 OPTIONAL,
                    interFreqMeasurementSysInfo InterFreqMeasurementSysInfo-RSCP-LCR-r4 OPTIONAL
                },
                cpich-Ec-N0             SEQUENCE    {
                    intraFreqMeasurementSysInfo IntraFreqMeasurementSysInfo-ECN0-LCR-r4 OPTIONAL,
                    interFreqMeasurementSysInfo InterFreqMeasurementSysInfo-ECN0-LCR-r4 OPTIONAL
                }
            }
        },
        hcs-used                        SEQUENCE    {
            -- CHOICE cellSelectQualityMeasure shall have the same value as the
            -- cellSelectQualityMeasure in MeasurementControlSysInfo
            cellSelectQualityMeasure    CHOICE  {
                cpich-RSCP              SEQUENCE    {
                    intraFreqMeasurementSysInfo IntraFreqMeasurementSysInfo-HCS-RSCP-LCR-r4
    OPTIONAL,
                    interFreqMeasurementSysInfo InterFreqMeasurementSysInfo-HCS-RSCP-LCR-r4 OPTIONAL
                },
                cpich-Ec-N0             SEQUENCE    {
                    intraFreqMeasurementSysInfo IntraFreqMeasurementSysInfo-HCS-ECN0-LCR-r4
    OPTIONAL,
                    interFreqMeasurementSysInfo InterFreqMeasurementSysInfo-HCS-ECN0-LCR-r4 OPTIONAL
                }
            }
        }
    }
}

MeasurementIdentity ::=     INTEGER (1..16)

MeasurementQuantityGSM ::=          ENUMERATED {
                                        gsm-CarrierRSSI,
                                        dummy }

MeasurementReportingMode ::=        SEQUENCE {
    measurementReportTransferMode       TransferMode,
    periodicalOrEventTrigger            PeriodicalOrEventTrigger
}

MeasurementType ::=                 CHOICE {
    intraFrequencyMeasurement           IntraFrequencyMeasurement,
    interFrequencyMeasurement           InterFrequencyMeasurement,
    interRATMeasurement                 InterRATMeasurement,
    ue-positioning-Measurement          UE-Positioning-Measurement,
    trafficVolumeMeasurement            TrafficVolumeMeasurement,
    qualityMeasurement                  QualityMeasurement,
    ue-InternalMeasurement              UE-InternalMeasurement
}

MeasurementType-r4 ::=              CHOICE {
    intraFrequencyMeasurement           IntraFrequencyMeasurement-r4,
    interFrequencyMeasurement           InterFrequencyMeasurement-r4,
    interRATMeasurement                 InterRATMeasurement-r4,
    up-Measurement                      UE-Positioning-Measurement-r4,
```

```
    trafficVolumeMeasurement            TrafficVolumeMeasurement,
    qualityMeasurement                  QualityMeasurement,
    ue-InternalMeasurement              UE-InternalMeasurement-r4
}

MeasurementType-r6 ::=              CHOICE {
    intraFrequencyMeasurement           IntraFrequencyMeasurement-r6,
    interFrequencyMeasurement           InterFrequencyMeasurement-r6,
    interRATMeasurement                 InterRATMeasurement-r6,
    up-Measurement                      UE-Positioning-Measurement-r4,
    trafficVolumeMeasurement            TrafficVolumeMeasurement,
    qualityMeasurement                  QualityMeasurement,
    ue-InternalMeasurement              UE-InternalMeasurement-r4
}

MeasurementValidity ::=             SEQUENCE {
    ue-State                            ENUMERATED {
                                            cell-DCH, all-But-Cell-DCH, all-States }
}

MonitoredCellRACH-List ::=          SEQUENCE (SIZE (1..8)) OF
                                        MonitoredCellRACH-Result

MonitoredCellRACH-Result ::=        SEQUENCE {
    sfn-SFN-ObsTimeDifference           SFN-SFN-ObsTimeDifference           OPTIONAL,
    modeSpecificInfo                    CHOICE {
        fdd                                 SEQUENCE {
            primaryCPICH-Info                   PrimaryCPICH-Info,
            measurementQuantity                 CHOICE {
                cpich-Ec-N0                         CPICH-Ec-N0,
                cpich-RSCP                          CPICH-RSCP,
                pathloss                            Pathloss,
                spare                               NULL
            }                                                               OPTIONAL
        },
        tdd                                 SEQUENCE {
            cellParametersID                    CellParametersID,
            primaryCCPCH-RSCP                   PrimaryCCPCH-RSCP
        }
    }
}

MultipathIndicator ::=              ENUMERATED {
                                        nm,
                                        low,
                                        medium,
                                        high }

N-CR-T-CRMaxHyst ::=                SEQUENCE {
    n-CR                                INTEGER (1..16)                     DEFAULT 8,
    t-CRMaxHyst                         T-CRMaxHyst
}

NavigationModelSatInfo ::=          SEQUENCE {
    satID                               SatID,
    satelliteStatus                     SatelliteStatus,
    ephemerisParameter                  EphemerisParameter      OPTIONAL
}

NavigationModelSatInfoList ::=      SEQUENCE (SIZE (1..maxSat)) OF
                                        NavigationModelSatInfo

EphemerisParameter ::=                  SEQUENCE {
    codeOnL2                            BIT STRING (SIZE (2)),
    uraIndex                            BIT STRING (SIZE (4)),
    satHealth                           BIT STRING (SIZE (6)),
    iodc                                BIT STRING (SIZE (10)),
    l2Pflag                             BIT STRING (SIZE (1)),
    sf1Revd                             SubFrame1Reserved,
    t-GD                                BIT STRING (SIZE (8)),
    t-oc                                BIT STRING (SIZE (16)),
    af2                                 BIT STRING (SIZE (8)),
    af1                                 BIT STRING (SIZE (16)),
    af0                                 BIT STRING (SIZE (22)),
    c-rs                                BIT STRING (SIZE (16)),
    delta-n                             BIT STRING (SIZE (16)),
    m0                                  BIT STRING (SIZE (32)),
    c-uc                                BIT STRING (SIZE (16)),
```

```
    e                                   BIT STRING (SIZE (32)),
    c-us                                BIT STRING (SIZE (16)),
    a-Sqrt                              BIT STRING (SIZE (32)),
    t-oe                                BIT STRING (SIZE (16)),
    fitInterval                         BIT STRING (SIZE (1)),
    aodo                                BIT STRING (SIZE (5)),
    c-ic                                BIT STRING (SIZE (16)),
    omega0                              BIT STRING (SIZE (32)),
    c-is                                BIT STRING (SIZE (16)),
    i0                                  BIT STRING (SIZE (32)),
    c-rc                                BIT STRING (SIZE (16)),
    omega                               BIT STRING (SIZE (32)),
    omegaDot                            BIT STRING (SIZE (24)),
    iDot                                BIT STRING (SIZE (14))
}
NC-Mode ::=                         BIT STRING (SIZE (3))

Neighbour ::=                       SEQUENCE {
    modeSpecificInfo                CHOICE {
        fdd                             SEQUENCE {
            neighbourIdentity                   PrimaryCPICH-Info                   OPTIONAL,
            uE-RX-TX-TimeDifferenceType2Info    UE-RX-TX-TimeDifferenceType2Info    OPTIONAL
        },
        tdd                             SEQUENCE {
            neighbourAndChannelIdentity     CellAndChannelIdentity                  OPTIONAL
        }
    },
    neighbourQuality                    NeighbourQuality,
    sfn-SFN-ObsTimeDifference2          SFN-SFN-ObsTimeDifference2}

Neighbour-v390ext ::=                       SEQUENCE {
    modeSpecificInfo                CHOICE {
        fdd                             SEQUENCE {
            frequencyInfo                       FrequencyInfo
        },
        tdd                             NULL
    }
}

NeighbourList ::=                   SEQUENCE (SIZE (1..maxCellMeas)) OF
                                        Neighbour

-- The order of the cells in IE NeighbourList-v390ext shall be the
-- same as the order in IE NeighbourList
NeighbourList-v390ext ::=                   SEQUENCE (SIZE (1..maxCellMeas)) OF
                                        Neighbour-v390ext

NeighbourQuality ::=                SEQUENCE {
    ue-Positioning-OTDOA-Quality        UE-Positioning-OTDOA-Quality
}

NewInterFreqCell ::=                SEQUENCE {
    interFreqCellID                     InterFreqCellID                     OPTIONAL,
    frequencyInfo                       FrequencyInfo                       OPTIONAL,
    cellInfo                            CellInfo
}

NewInterFreqCell-r4 ::=             SEQUENCE {
    interFreqCellID                     InterFreqCellID                     OPTIONAL,
    frequencyInfo                       FrequencyInfo                       OPTIONAL,
    cellInfo                            CellInfo-r4
}

NewInterFreqCellList ::=            SEQUENCE (SIZE (1..maxCellMeas)) OF
                                        NewInterFreqCell

NewInterFreqCellList-r4 ::=         SEQUENCE (SIZE (1..maxCellMeas)) OF
                                        NewInterFreqCell-r4

NewInterFreqCellSI-RSCP ::=             SEQUENCE {
    interFreqCellID                     InterFreqCellID                     OPTIONAL,
    frequencyInfo                       FrequencyInfo                       OPTIONAL,
    cellInfo                            CellInfoSI-RSCP
}

NewInterFreqCellSI-ECN0 ::=             SEQUENCE {
    interFreqCellID                     InterFreqCellID                     OPTIONAL,
    frequencyInfo                       FrequencyInfo                       OPTIONAL,
```

```
    cellInfo                            CellInfoSI-ECN0
}

NewInterFreqCellSI-HCS-RSCP ::=             SEQUENCE {
    interFreqCellID                     InterFreqCellID                     OPTIONAL,
    frequencyInfo                       FrequencyInfo                       OPTIONAL,
    cellInfo                            CellInfoSI-HCS-RSCP
}

NewInterFreqCellSI-HCS-ECN0 ::=             SEQUENCE {
    interFreqCellID                     InterFreqCellID                     OPTIONAL,
    frequencyInfo                       FrequencyInfo                       OPTIONAL,
    cellInfo                            CellInfoSI-HCS-ECN0
}

NewInterFreqCellSI-RSCP-LCR-r4 ::=          SEQUENCE {
    interFreqCellID                     InterFreqCellID                     OPTIONAL,
    frequencyInfo                       FrequencyInfo                       OPTIONAL,
    cellInfo                            CellInfoSI-RSCP-LCR-r4
}

NewInterFreqCellSI-ECN0-LCR-r4 ::=          SEQUENCE {
    interFreqCellID                     InterFreqCellID                     OPTIONAL,
    frequencyInfo                       FrequencyInfo                       OPTIONAL,
    cellInfo                            CellInfoSI-ECN0-LCR-r4
}

NewInterFreqCellSI-HCS-RSCP-LCR-r4 ::=      SEQUENCE {
    interFreqCellID                     InterFreqCellID                     OPTIONAL,
    frequencyInfo                       FrequencyInfo                       OPTIONAL,
    cellInfo                            CellInfoSI-HCS-RSCP-LCR-r4
}

NewInterFreqCellSI-HCS-ECN0-LCR-r4 ::=      SEQUENCE {
    interFreqCellID                     InterFreqCellID                     OPTIONAL,
    frequencyInfo                       FrequencyInfo                       OPTIONAL,
    cellInfo                            CellInfoSI-HCS-ECN0-LCR-r4
}

NewInterFreqCellSI-List-ECN0 ::=            SEQUENCE (SIZE (1..maxCellMeas)) OF
                                    NewInterFreqCellSI-ECN0

NewInterFreqCellSI-List-HCS-RSCP ::=            SEQUENCE (SIZE (1..maxCellMeas)) OF
                                    NewInterFreqCellSI-HCS-RSCP

NewInterFreqCellSI-List-HCS-ECN0 ::=            SEQUENCE (SIZE (1..maxCellMeas)) OF
                                    NewInterFreqCellSI-HCS-ECN0

NewInterFreqCellSI-List-RSCP ::=        SEQUENCE (SIZE (1..maxCellMeas)) OF
                                    NewInterFreqCellSI-RSCP

NewInterFreqCellSI-List-ECN0-LCR-r4 ::=     SEQUENCE (SIZE (1..maxCellMeas)) OF
                                    NewInterFreqCellSI-ECN0-LCR-r4

NewInterFreqCellSI-List-HCS-RSCP-LCR-r4 ::= SEQUENCE (SIZE (1..maxCellMeas)) OF
                                    NewInterFreqCellSI-HCS-RSCP-LCR-r4

NewInterFreqCellSI-List-HCS-ECN0-LCR-r4 ::= SEQUENCE (SIZE (1..maxCellMeas)) OF
                                    NewInterFreqCellSI-HCS-ECN0-LCR-r4

NewInterFreqCellSI-List-RSCP-LCR-r4 ::=     SEQUENCE (SIZE (1..maxCellMeas)) OF
                                    NewInterFreqCellSI-RSCP-LCR-r4

NewInterRATCell ::=             SEQUENCE {
    interRATCellID                      InterRATCellID          OPTIONAL,
    technologySpecificInfo              CHOICE {
        gsm                                 SEQUENCE {
            cellSelectionReselectionInfo        CellSelectReselectInfoSIB-11-12     OPTIONAL,
            interRATCellIndividualOffset        InterRATCellIndividualOffset,
            bsic                                BSIC,
            frequency-band                      Frequency-Band,
            bcch-ARFCN                          BCCH-ARFCN,
            -- dummy is not used in this version of the specification, it should
            -- not be sent and if received it should be ignored.
            dummy                               NULL                OPTIONAL
        },
        is-2000                             SEQUENCE {
            is-2000SpecificMeasInfo             IS-2000SpecificMeasInfo
```

```
        },
        -- ASN.1 inconsistency: NewInterRATCellList should be optional within
        -- InterRATCellInfoList. The UE shall consider IE NewInterRATCell with
        -- technologySpecificInfo set to "absent" as valid and handle the
        -- message as if the IE NewInterRATCell was absent
        absent                          NULL,
        spare1                          NULL
    }
}

NewInterRATCell-B ::=               SEQUENCE {
    interRATCellID                      InterRATCellID              OPTIONAL,
    technologySpecificInfo              CHOICE {
        gsm                                 SEQUENCE {
            cellSelectionReselectionInfo        CellSelectReselectInfoSIB-11-12     OPTIONAL,
            interRATCellIndividualOffset        InterRATCellIndividualOffset,
            bsic                                BSIC,
            frequency-band                      Frequency-Band,
            bcch-ARFCN                          BCCH-ARFCN,
            -- dummy is not used in this version of the specification, it should
            -- not be sent and if received it should be ignored.
            dummy                               NULL                OPTIONAL
        },
        is-2000                             SEQUENCE {
            is-2000SpecificMeasInfo             IS-2000SpecificMeasInfo
        },
        -- ASN.1 inconsistency: NewInterRATCellList-B should be optional within
        -- InterRATCellInfoList-B. The UE shall consider IE NewInterRATCell-B with
        -- technologySpecificInfo set to "absent" as valid and handle the
        -- message as if the IE NewInterRATCell-B was absent
        absent                          NULL,
        spare1                          NULL
    }
}

NewInterRATCellList ::=         SEQUENCE (SIZE (1..maxCellMeas)) OF
                                    NewInterRATCell

NewInterRATCellList-B ::=           SEQUENCE (SIZE (1..maxCellMeas)) OF
                                    NewInterRATCell-B

NewIntraFreqCell ::=                SEQUENCE {
    intraFreqCellID                     IntraFreqCellID                     OPTIONAL,
    cellInfo                            CellInfo
}

NewIntraFreqCell-r4 ::=             SEQUENCE {
    intraFreqCellID                     IntraFreqCellID                     OPTIONAL,
    cellInfo                            CellInfo-r4
}

NewIntraFreqCellList ::=            SEQUENCE (SIZE (1..maxCellMeas)) OF
                                    NewIntraFreqCell

NewIntraFreqCellList-r4 ::=         SEQUENCE (SIZE (1..maxCellMeas)) OF
                                    NewIntraFreqCell-r4

NewIntraFreqCellSI-RSCP ::=             SEQUENCE {
    intraFreqCellID                     IntraFreqCellID                     OPTIONAL,
    cellInfo                            CellInfoSI-RSCP
}

NewIntraFreqCellSI-ECN0 ::=         SEQUENCE {
    intraFreqCellID                     IntraFreqCellID                     OPTIONAL,
    cellInfo                            CellInfoSI-ECN0
}
NewIntraFreqCellSI-HCS-RSCP ::=     SEQUENCE {
    intraFreqCellID                     IntraFreqCellID                     OPTIONAL,
    cellInfo                            CellInfoSI-HCS-RSCP
}

NewIntraFreqCellSI-HCS-ECN0 ::=     SEQUENCE {
    intraFreqCellID                     IntraFreqCellID                     OPTIONAL,
    cellInfo                            CellInfoSI-HCS-ECN0
}

NewIntraFreqCellSI-RSCP-LCR-r4 ::=      SEQUENCE {
    intraFreqCellID                     IntraFreqCellID                     OPTIONAL,
```

```
    cellInfo                            CellInfoSI-RSCP-LCR-r4
}

NewIntraFreqCellSI-ECN0-LCR-r4 ::=      SEQUENCE {
    intraFreqCellID                     IntraFreqCellID                     OPTIONAL,
    cellInfo                            CellInfoSI-ECN0-LCR-r4
}
NewIntraFreqCellSI-HCS-RSCP-LCR-r4 ::=  SEQUENCE {
    intraFreqCellID                     IntraFreqCellID                     OPTIONAL,
    cellInfo                            CellInfoSI-HCS-RSCP-LCR-r4
}

NewIntraFreqCellSI-HCS-ECN0-LCR-r4 ::=  SEQUENCE {
    intraFreqCellID                     IntraFreqCellID                     OPTIONAL,
    cellInfo                            CellInfoSI-HCS-ECN0-LCR-r4
}

NewIntraFreqCellSI-List-RSCP ::=        SEQUENCE (SIZE (1..maxCellMeas)) OF
                                            NewIntraFreqCellSI-RSCP

NewIntraFreqCellSI-List-ECN0 ::=        SEQUENCE (SIZE (1..maxCellMeas)) OF
                                        NewIntraFreqCellSI-ECN0

NewIntraFreqCellSI-List-HCS-RSCP ::=    SEQUENCE (SIZE (1..maxCellMeas)) OF
                                        NewIntraFreqCellSI-HCS-RSCP

NewIntraFreqCellSI-List-HCS-ECN0 ::=    SEQUENCE (SIZE (1..maxCellMeas)) OF
                                        NewIntraFreqCellSI-HCS-ECN0

NewIntraFreqCellSI-List-RSCP-LCR-r4 ::=     SEQUENCE (SIZE (1..maxCellMeas)) OF
                                            NewIntraFreqCellSI-RSCP-LCR-r4

NewIntraFreqCellSI-List-ECN0-LCR-r4 ::=     SEQUENCE (SIZE (1..maxCellMeas)) OF
                                        NewIntraFreqCellSI-ECN0-LCR-r4

NewIntraFreqCellSI-List-HCS-RSCP-LCR-r4 ::= SEQUENCE (SIZE (1..maxCellMeas)) OF
                                        NewIntraFreqCellSI-HCS-RSCP-LCR-r4

NewIntraFreqCellSI-List-HCS-ECN0-LCR-r4 ::= SEQUENCE (SIZE (1..maxCellMeas)) OF
                                        NewIntraFreqCellSI-HCS-ECN0-LCR-r4

    -- IE "nonUsedFreqThreshold" is not needed in case of event 2a
    -- In case of event 2a UTRAN should include value 0 within IE "nonUsedFreqThreshold"
    -- In case of event 2a, the UE shall be ignore IE "nonUsedFreqThreshold"
    -- In later versions of the message including this IE, a special version of
    -- IE "NonUsedFreqParameterList" may be defined for event 2a, namely a
    -- version not including IE "nonUsedFreqThreshold"
NonUsedFreqParameter ::=            SEQUENCE {
    nonUsedFreqThreshold                Threshold,
    nonUsedFreqW                        W
}

NonUsedFreqParameter-r6 ::=         SEQUENCE {
    nonUsedFreqThreshold                Threshold-r6,
    nonUsedFreqW                        W
}

NonUsedFreqParameterList ::=        SEQUENCE (SIZE (1..maxFreq)) OF
                                        NonUsedFreqParameter

NonUsedFreqParameterList-r6 ::=     SEQUENCE (SIZE (1..maxFreq)) OF
                                        NonUsedFreqParameter-r6

NonUsedFreqWList-r6 ::=     SEQUENCE (SIZE (1..maxFreq)) OF W

ObservedTimeDifferenceToGSM ::=     INTEGER (0..4095)

OTDOA-SearchWindowSize ::=          ENUMERATED {
                                        c20, c40, c80, c160, c320,
                                        c640, c1280, moreThan1280 }

-- SPARE: Pathloss, Max = 158
-- Values above Max are spare
Pathloss ::=                        INTEGER (46..173)

PenaltyTime-RSCP ::=                CHOICE {
    notUsed                             NULL,
    pt10                                TemporaryOffset1,
```

```
    pt20                                TemporaryOffset1,
    pt30                                TemporaryOffset1,
    pt40                                TemporaryOffset1,
    pt50                                TemporaryOffset1,
    pt60                                TemporaryOffset1
}

PenaltyTime-ECN0 ::=                CHOICE {
    notUsed                             NULL,
    pt10                                TemporaryOffsetList,
    pt20                                TemporaryOffsetList,
    pt30                                TemporaryOffsetList,
    pt40                                TemporaryOffsetList,
    pt50                                TemporaryOffsetList,
    pt60                                TemporaryOffsetList
}

PendingTimeAfterTrigger ::=         ENUMERATED {
                                        ptat0-25, ptat0-5, ptat1,
                                        ptat2, ptat4, ptat8, ptat16 }

PeriodicalOrEventTrigger ::=        ENUMERATED {
                                        periodical,
                                        eventTrigger }

PeriodicalReportingCriteria ::=     SEQUENCE {
    reportingAmount                     ReportingAmount                 DEFAULT ra-Infinity,
    reportingInterval                   ReportingIntervalLong
}

PeriodicalWithReportingCellStatus ::= SEQUENCE {
    periodicalReportingCriteria         PeriodicalReportingCriteria,
    reportingCellStatus                 ReportingCellStatus                 OPTIONAL
}

PLMNIdentitiesOfNeighbourCells ::=  SEQUENCE {
        plmnsOfIntraFreqCellsList       PLMNsOfIntraFreqCellsList           OPTIONAL,
        plmnsOfInterFreqCellsList       PLMNsOfInterFreqCellsList           OPTIONAL,
        plmnsOfInterRATCellsList        PLMNsOfInterRATCellsList            OPTIONAL
}

PLMNsOfInterFreqCellsList ::=           SEQUENCE (SIZE (1..maxCellMeas)) OF
                                            SEQUENCE {
    plmn-Identity                               PLMN-Identity               OPTIONAL
}

PLMNsOfIntraFreqCellsList ::=           SEQUENCE (SIZE (1..maxCellMeas)) OF
                                            SEQUENCE {
    plmn-Identity                               PLMN-Identity               OPTIONAL
}

PLMNsOfInterRATCellsList ::=            SEQUENCE (SIZE (1..maxCellMeas)) OF
                                            SEQUENCE {
    plmn-Identity                               PLMN-Identity               OPTIONAL
}

PositionEstimate ::=                CHOICE {
    ellipsoidPoint                      EllipsoidPoint,
    ellipsoidPointUncertCircle          EllipsoidPointUncertCircle,
    ellipsoidPointUncertEllipse         EllipsoidPointUncertEllipse,
    ellipsoidPointAltitude              EllipsoidPointAltitude,
    ellipsoidPointAltitudeEllipse       EllipsoidPointAltitudeEllipsoide
}

PositioningMethod ::=               ENUMERATED {
                                        otdoa,
                                        gps,
                                        otdoaOrGPS, cellID }

-- Actual value PRC = IE value * 0.32
PRC ::=                             INTEGER (-2047..2047)

-- SPARE: PrimaryCCPCH-RSCP, Max = 91
-- Values above Max are spare
PrimaryCCPCH-RSCP ::=               INTEGER (0..127)

Q-HCS ::=                           INTEGER (0..99)
```

```
Q-OffsetS-N ::=                     INTEGER (-50..50)

Q-QualMin ::=                       INTEGER (-24..0)

-- Actual value Q-RxlevMin = (IE value * 2) + 1
Q-RxlevMin ::=                      INTEGER (-58..-13)

QualityEventResults ::=             SEQUENCE (SIZE (1..maxTrCH)) OF
                                        TransportChannelIdentity

QualityMeasuredResults ::=          SEQUENCE {
    blerMeasurementResultsList          BLER-MeasurementResultsList         OPTIONAL,
    modeSpecificInfo                    CHOICE {
        fdd                                 NULL,
        tdd                                 SEQUENCE {
            sir-MeasurementResults              SIR-MeasurementList         OPTIONAL
        }
    }
}

QualityMeasurement ::=              SEQUENCE {
    qualityReportingQuantity            QualityReportingQuantity            OPTIONAL,
    reportCriteria                      QualityReportCriteria
}

QualityReportCriteria ::=           CHOICE {
    qualityReportingCriteria            QualityReportingCriteria,
    periodicalReportingCriteria         PeriodicalReportingCriteria,
    noReporting                         NULL
}

QualityReportingCriteria ::=        SEQUENCE (SIZE (1..maxTrCH)) OF
                                        QualityReportingCriteriaSingle

QualityReportingCriteriaSingle ::=  SEQUENCE {
    transportChannelIdentity            TransportChannelIdentity,
    totalCRC                            INTEGER (1..512),
    badCRC                              INTEGER (1..512),
    pendingAfterTrigger                 INTEGER (1..512)
}

QualityReportingQuantity ::=        SEQUENCE {
    dl-TransChBLER                      BOOLEAN,
    bler-dl-TransChIdList               BLER-TransChIdList                  OPTIONAL,
    modeSpecificInfo                    CHOICE {
        fdd                                 NULL,
        tdd                                 SEQUENCE {
            sir-TFCS-List                       SIR-TFCS-List               OPTIONAL
        }
    }
}

RAT-Type ::=                        ENUMERATED {
                                        gsm, is2000 }

ReferenceCellPosition ::=           CHOICE {
    ellipsoidPoint                      EllipsoidPoint,
    ellipsoidPointWithAltitude          EllipsoidPointAltitude
}

-- ReferenceLocation, as defined in 23.032
ReferenceLocation ::=           SEQUENCE {
    ellipsoidPointAltitudeEllipsoide        EllipsoidPointAltitudeEllipsoide
}

ReferenceTimeDifferenceToCell ::=   CHOICE {
    -- Actual value accuracy40 = IE value * 40
    accuracy40                          INTEGER (0..960),
    -- Actual value accuracy256 = IE value * 256
    accuracy256                         INTEGER (0..150),
    -- Actual value accuracy2560 = IE value * 2560
    accuracy2560                        INTEGER (0..15)
}

RemovedInterFreqCellList ::=        CHOICE {
    removeAllInterFreqCells             NULL,
    removeSomeInterFreqCells            SEQUENCE (SIZE (1..maxCellMeas)) OF
                                            InterFreqCellID,
```

```
    removeNoInterFreqCells              NULL
}

RemovedInterRATCellList ::=     CHOICE {
    removeAllInterRATCells          NULL,
    removeSomeInterRATCells         SEQUENCE (SIZE (1..maxCellMeas)) OF
                                            InterRATCellID,
    removeNoInterRATCells           NULL
}

RemovedIntraFreqCellList ::=        CHOICE {
    removeAllIntraFreqCells             NULL,
    removeSomeIntraFreqCells            SEQUENCE (SIZE (1..maxCellMeas)) OF
                                            IntraFreqCellID,
    removeNoIntraFreqCells              NULL
}

ReplacementActivationThreshold ::=  ENUMERATED {
                                        notApplicable, t1, t2,
                                        t3, t4, t5, t6, t7 }

ReportDeactivationThreshold ::=     ENUMERATED {
                                        notApplicable, t1, t2,
                                        t3, t4, t5, t6, t7 }

ReportingAmount ::=                 ENUMERATED {
                                        ra1, ra2, ra4, ra8, ra16, ra32,
                                        ra64, ra-Infinity }

ReportingCellStatus ::=             CHOICE{
    withinActiveSet                     MaxNumberOfReportingCellsType1,
    withinMonitoredSetUsedFreq          MaxNumberOfReportingCellsType1,
    withinActiveAndOrMonitoredUsedFreq  MaxNumberOfReportingCellsType1,
    withinDetectedSetUsedFreq           MaxNumberOfReportingCellsType1,
    withinMonitoredAndOrDetectedUsedFreq
                                        MaxNumberOfReportingCellsType1,
    allActiveplusMonitoredSet           MaxNumberOfReportingCellsType3,
    allActivePlusDetectedSet            MaxNumberOfReportingCellsType3,
    allActivePlusMonitoredAndOrDetectedSet
                                        MaxNumberOfReportingCellsType3,
    withinVirtualActSet             MaxNumberOfReportingCellsType1,
    withinMonitoredSetNonUsedFreq       MaxNumberOfReportingCellsType1,
    withinMonitoredAndOrVirtualActiveSetNonUsedFreq
                                        MaxNumberOfReportingCellsType1,
    allVirtualActSetplusMonitoredSetNonUsedFreq
                                        MaxNumberOfReportingCellsType3,
    withinActSetOrVirtualActSet-InterRATcells
                                        MaxNumberOfReportingCellsType2,
    withinActSetAndOrMonitoredUsedFreqOrVirtualActSetAndOrMonitoredNonUsedFreq
                                        MaxNumberOfReportingCellsType2
}

ReportingCellStatusOpt ::=          SEQUENCE {
    reportingCellStatus                 ReportingCellStatus                 OPTIONAL
}


ReportingInfoForCellDCH ::=         SEQUENCE {
    intraFreqReportingQuantity          IntraFreqReportingQuantity,
    measurementReportingMode            MeasurementReportingMode,
    reportCriteria                      CellDCH-ReportCriteria
}

ReportingInfoForCellDCH-LCR-r4 ::=  SEQUENCE {
    intraFreqReportingQuantity          IntraFreqReportingQuantity,
    measurementReportingMode            MeasurementReportingMode,
    reportCriteria                      CellDCH-ReportCriteria-LCR-r4
}

ReportingInterval ::=               ENUMERATED {
                                        noPeriodicalreporting, ri0-25,
                                        ri0-5, ri1, ri2, ri4, ri8, ri16 }

ReportingIntervalLong ::=           ENUMERATED {
                                        ril0, ril0-25, ril0-5, ril1,
                                        ril2, ril3, ril4, ril6, ril8,
                                        ril12, ril16, ril20, ril24,
                                        ril28, ril32, ril64 }
```

```
                                    -- When the value 'ril0' is used, the UE behaviour is not
                                    -- defined.

-- Actual value ReportingRange = IE value * 0.5
ReportingRange ::=                  INTEGER (0..29)

RL-AdditionInfoList ::=             SEQUENCE (SIZE (1..maxRL)) OF
                                        PrimaryCPICH-Info

RL-InformationLists ::=             SEQUENCE {
    rl-AdditionInfoList                 RL-AdditionInfoList                 OPTIONAL,
    rL-RemovalInformationList           RL-RemovalInformationList           OPTIONAL
}

RLC-BuffersPayload ::=              ENUMERATED {
                                        pl0, pl4, pl8, pl16, pl32,
                                        pl64, pl128, pl256, pl512, pl1024,
                                        pl2k, pl4k, pl8k, pl16k, pl32k,
                                        pl64k, pl128k, pl256k, pl512k, pl1024k,
                                        spare12, spare11, spare10, spare9, spare8,
                                        spare7, spare6, spare5, spare4, spare3,
                                        spare2, spare1 }

-- Actual value RRC = IE value * 0.032
RRC ::=                             INTEGER (-127..127)

SatData ::=                         SEQUENCE{
    satID                               SatID,
    iode                                IODE
}

SatDataList ::=                     SEQUENCE (SIZE (0..maxSat)) OF
                                        SatData

SatelliteStatus ::=                 ENUMERATED {
                                        ns-NN-U,
                                        es-SN,
                                        es-NN-U,
                                        rev2,
                                        rev }

-- Identifies the satellite and is equal to (SV ID No - 1) where SV ID No is defined in [12].
SatID ::=                           INTEGER (0..63)

SFN-Offset-Validity ::=         ENUMERATED { false }

SFN-SFN-Drift ::=                   ENUMERATED {
                                        sfnsfndrift0, sfnsfndrift1, sfnsfndrift2,
                                        sfnsfndrift3, sfnsfndrift4, sfnsfndrift5,
                                        sfnsfndrift8, sfnsfndrift10, sfnsfndrift15,
                                        sfnsfndrift25, sfnsfndrift35, sfnsfndrift50,
                                        sfnsfndrift65, sfnsfndrift80, sfnsfndrift100,
                                        sfnsfndrift-1, sfnsfndrift-2, sfnsfndrift-3,
                                        sfnsfndrift-4, sfnsfndrift-5, sfnsfndrift-8,
                                        sfnsfndrift-10, sfnsfndrift-15, sfnsfndrift-25,
                                        sfnsfndrift-35, sfnsfndrift-50, sfnsfndrift-65,
                                        sfnsfndrift-80, sfnsfndrift-100}

SFN-SFN-ObsTimeDifference ::=       CHOICE {
    type1                               SFN-SFN-ObsTimeDifference1,
    type2                               SFN-SFN-ObsTimeDifference2
}

-- SPARE: SFN-SFN-ObsTimeDifference1, Max = 9830399
-- For 1.28Mcps TDD, Max value of SFN-SFN-ObsTimeDifference1 is 3276799.
-- Values above Max are spare
SFN-SFN-ObsTimeDifference1 ::=      INTEGER (0..16777215)

-- SPARE: SFN-SFN-ObsTimeDifference2, Max = 40961
-- For 1.28Mcps TDD, Max value of SFN-SFN-ObsTimeDifference2 is 27649.
-- Values above Max are spare
SFN-SFN-ObsTimeDifference2 ::=      INTEGER (0..65535)

SFN-SFN-OTD-Type ::=                ENUMERATED {
                                        noReport,
                                        type1,
                                        type2 }
```

```
SFN-SFN-RelTimeDifference1 ::=      SEQUENCE {
    sfn-Offset                          INTEGER (0 .. 4095),
    sfn-sfn-Reltimedifference           INTEGER (0.. 38399)
}

SFN-TOW-Uncertainty ::=             ENUMERATED {
                                        lessThan10,
                                        moreThan10 }


SIR ::=                             INTEGER (0..63)


SIR-MeasurementList ::=             SEQUENCE (SIZE (1..maxCCTrCH)) OF
                                        SIR-MeasurementResults


SIR-MeasurementResults ::=          SEQUENCE {
    tfcs-ID                             TFCS-IdentityPlain,
    sir-TimeslotList                    SIR-TimeslotList
}

SIR-TFCS ::=                        TFCS-IdentityPlain


SIR-TFCS-List ::=                   SEQUENCE (SIZE (1..maxCCTrCH)) OF
                                        SIR-TFCS

SIR-TimeslotList ::=                SEQUENCE (SIZE (1..maxTS)) OF
                                        SIR

-- SubFrame1Reserved, reserved bits in subframe 1 of the GPS navigation message
SubFrame1Reserved ::=               SEQUENCE {
    reserved1                           BIT STRING (SIZE (23)),
    reserved2                           BIT STRING (SIZE (24)),
    reserved3                           BIT STRING (SIZE (24)),
    reserved4                           BIT STRING (SIZE (16))
}

T-ADVinfo ::=                       SEQUENCE {
                t-ADV                   INTEGER(0..2047),
                sfn                     INTEGER(0..4095)
}

T-CRMax ::=                         CHOICE {
    notUsed                             NULL,
    t30                                 N-CR-T-CRMaxHyst,
    t60                                 N-CR-T-CRMaxHyst,
    t120                                N-CR-T-CRMaxHyst,
    t180                                N-CR-T-CRMaxHyst,
    t240                                N-CR-T-CRMaxHyst
}

T-CRMaxHyst ::=                     ENUMERATED {
                                        notUsed, t10, t20, t30,
                                        t40, t50, t60, t70 }

TemporaryOffset1 ::=                ENUMERATED {
                                        to3, to6, to9, to12, to15,
                                        to18, to21, infinite }

TemporaryOffset2 ::=                ENUMERATED {
                                        to2, to3, to4, to6, to8,
                                        to10, to12, infinite }

TemporaryOffsetList ::=             SEQUENCE    {
        temporaryOffset1                TemporaryOffset1,
        temporaryOffset2                TemporaryOffset2
}

Threshold ::=                       INTEGER (-115..0)

Threshold-r6 ::=                            INTEGER (-120..0)

-- The order of the list corresponds to the order of frequency defined in Inter-FreqEventCriteria
ThreholdNonUsedFrequency-deltaList ::= SEQUENCE (SIZE (1..maxFreq)) OF
                                            DeltaRSCPPerCell
```

```
ThresholdPositionChange ::=         ENUMERATED {
                                        pc10, pc20, pc30, pc40, pc50,
                                        pc100, pc200, pc300, pc500,
                                        pc1000, pc2000, pc5000, pc10000,
                                        pc20000, pc50000, pc100000 }

ThresholdSFN-GPS-TOW ::=            ENUMERATED {
                                        ms1, ms2, ms3, ms5, ms10,
                                        ms20, ms50, ms100 }

ThresholdSFN-SFN-Change ::=         ENUMERATED {
                                        c0-25, c0-5, c1, c2, c3, c4, c5,
                                        c10, c20, c50, c100, c200, c500,
                                        c1000, c2000, c5000 }

ThresholdUsedFrequency ::=          INTEGER (-115..165)

ThresholdUsedFrequency-r6 ::=       INTEGER (-120..165)

-- Actual value TimeInterval = IE value * 20.
TimeInterval ::=                    INTEGER (1..13)


TimeslotInfo ::=                    SEQUENCE {
    timeslotNumber                      TimeslotNumber,
    burstType                           BurstType
}

TimeslotInfo-LCR-r4 ::=             SEQUENCE {
    timeslotNumber                      TimeslotNumber-LCR-r4
}

TimeslotInfoList ::=                SEQUENCE (SIZE (1..maxTS)) OF
                                        TimeslotInfo

TimeslotInfoList-LCR-r4 ::=         SEQUENCE (SIZE (1..maxTS-LCR)) OF
                                        TimeslotInfo-LCR-r4

TimeslotInfoList-r4 ::=             CHOICE {
    -- the choice for 7.68 Mcps TDD is the same as for 3.84 Mcps TDD --
    tdd384                              SEQUENCE (SIZE (1..maxTS)) OF
                                            TimeslotInfo,
    tdd128                              SEQUENCE (SIZE (1..maxTS-LCR)) OF
                                            TimeslotInfo-LCR-r4
}

-- SPARE: TimeslotISCP, Max = 91
-- Values above Max are spare
TimeslotISCP ::=                    INTEGER (0..127)


-- TimeslotISCP-List shall not include more than 6 elements in 1.28Mcps TDD mode.
TimeslotISCP-List ::=               SEQUENCE (SIZE (1..maxTS)) OF
                                        TimeslotISCP

TimeslotListWithISCP ::=            SEQUENCE (SIZE (1..maxTS)) OF
                                        TimeslotWithISCP

TimeslotWithISCP ::=                SEQUENCE {
    timeslot                            TimeslotNumber,
    timeslotISCP                        TimeslotISCP
}

TimeToTrigger ::=                   ENUMERATED {
                                        ttt0, ttt10, ttt20, ttt40, ttt60,
                                        ttt80, ttt100, ttt120, ttt160,
                                        ttt200, ttt240, tt320, ttt640,
                                        ttt1280, ttt2560, ttt5000 }

TrafficVolumeEventParam ::=         SEQUENCE {
    eventID                             TrafficVolumeEventType,
    reportingThreshold                  TrafficVolumeThreshold,
    timeToTrigger                       TimeToTrigger                       OPTIONAL,
    pendingTimeAfterTrigger             PendingTimeAfterTrigger             OPTIONAL,
    tx-InterruptionAfterTrigger         TX-InterruptionAfterTrigger         OPTIONAL
}

TrafficVolumeEventResults ::=       SEQUENCE {
```

```
    ul-transportChannelCausingEvent     UL-TrCH-Identity,
    trafficVolumeEventIdentity          TrafficVolumeEventType
}

TrafficVolumeEventType ::=          ENUMERATED {
                                        e4a,
                                        e4b }

TrafficVolumeMeasQuantity ::=       CHOICE {
    rlc-BufferPayload                   NULL,
    averageRLC-BufferPayload            TimeInterval,
    varianceOfRLC-BufferPayload         TimeInterval
}

TrafficVolumeMeasSysInfo ::=        SEQUENCE {
    trafficVolumeMeasurementID          MeasurementIdentity         DEFAULT 4,
    trafficVolumeMeasurementObjectList  TrafficVolumeMeasurementObjectList  OPTIONAL,
    trafficVolumeMeasQuantity           TrafficVolumeMeasQuantity           OPTIONAL,
    trafficVolumeReportingQuantity      TrafficVolumeReportingQuantity      OPTIONAL,
    -- dummy is not used in this version of specification, it should
    -- not be sent and if received it should be ignored.
    dummy                               TrafficVolumeReportingCriteria      OPTIONAL,
    measurementValidity                 MeasurementValidity                 OPTIONAL,
    measurementReportingMode            MeasurementReportingMode,
    reportCriteriaSysInf                TrafficVolumeReportCriteriaSysInfo

}

TrafficVolumeMeasuredResults ::=    SEQUENCE {
    rb-Identity                         RB-Identity,
    rlc-BuffersPayload                  RLC-BuffersPayload                  OPTIONAL,
    averageRLC-BufferPayload            AverageRLC-BufferPayload            OPTIONAL,
    varianceOfRLC-BufferPayload         VarianceOfRLC-BufferPayload         OPTIONAL
}

TrafficVolumeMeasuredResultsList ::= SEQUENCE (SIZE (1..maxRB)) OF
                                    TrafficVolumeMeasuredResults

TrafficVolumeMeasurement ::=        SEQUENCE {
    trafficVolumeMeasurementObjectList  TrafficVolumeMeasurementObjectList  OPTIONAL,
    trafficVolumeMeasQuantity           TrafficVolumeMeasQuantity           OPTIONAL,
    trafficVolumeReportingQuantity      TrafficVolumeReportingQuantity      OPTIONAL,
    measurementValidity                 MeasurementValidity                 OPTIONAL,
    reportCriteria                      TrafficVolumeReportCriteria
}

TrafficVolumeMeasurementObjectList ::= SEQUENCE (SIZE (1..maxTrCH)) OF
                                        UL-TrCH-Identity

TrafficVolumeReportCriteria ::=     CHOICE {
    trafficVolumeReportingCriteria      TrafficVolumeReportingCriteria,
    periodicalReportingCriteria         PeriodicalReportingCriteria,
    noReporting                         NULL
}

TrafficVolumeReportCriteriaSysInfo ::=  CHOICE {
    trafficVolumeReportingCriteria      TrafficVolumeReportingCriteria,
    periodicalReportingCriteria         PeriodicalReportingCriteria
}

TrafficVolumeReportingCriteria ::= SEQUENCE {
    -- NOTE: transChCriteriaList should be mandatory in later versions of this message
    transChCriteriaList                 TransChCriteriaList                 OPTIONAL
}

TrafficVolumeReportingQuantity ::= SEQUENCE {
    rlc-RB-BufferPayload                BOOLEAN,
    rlc-RB-BufferPayloadAverage         BOOLEAN,
    rlc-RB-BufferPayloadVariance        BOOLEAN
}

TrafficVolumeThreshold ::=          ENUMERATED {
                                        th8, th16, th32, th64, th128,
                                        th256, th512, th1024, th2k, th3k,
                                        th4k, th6k, th8k, th12k, th16k,
                                        th24k, th32k, th48k, th64k, th96k,
                                        th128k, th192k, th256k, th384k,
                                        th512k, th768k }
```

```
TransChCriteria ::=                 SEQUENCE {
    ul-transportChannelID               UL-TrCH-Identity                    OPTIONAL,
    eventSpecificParameters             SEQUENCE (SIZE (1..maxMeasParEvent)) OF
                                            TrafficVolumeEventParam         OPTIONAL
}

TransChCriteriaList ::=         SEQUENCE (SIZE (1..maxTrCH)) OF
                                        TransChCriteria

TransferMode ::=                    ENUMERATED {
                                        acknowledgedModeRLC,
                                        unacknowledgedModeRLC }

TransmittedPowerThreshold ::=       INTEGER (-50..33)

TriggeringCondition1 ::=            ENUMERATED {
                                        activeSetCellsOnly,
                                        monitoredSetCellsOnly,
                                        activeSetAndMonitoredSetCells }

TriggeringCondition2 ::=            ENUMERATED {
                                        activeSetCellsOnly,
                                        monitoredSetCellsOnly,
                                        activeSetAndMonitoredSetCells,
                                        detectedSetCellsOnly,
                                        detectedSetAndMonitoredSetCells }

TX-InterruptionAfterTrigger ::=     ENUMERATED {
                                        txiat0-25, txiat0-5, txiat1,
                                        txiat2, txiat4, txiat8, txiat16 }

UDRE ::=                            ENUMERATED {
                                        lessThan1,
                                        between1-and-4,
                                        between4-and-8,
                                        over8 }

UE-6AB-Event ::=                    SEQUENCE {
    timeToTrigger                       TimeToTrigger,
    transmittedPowerThreshold           TransmittedPowerThreshold
}

UE-6FG-Event ::=                    SEQUENCE {
    timeToTrigger                       TimeToTrigger,
    -- in 1.28 Mcps TDD ue-RX-TX-TimeDifferenceThreshold corresponds to T_ADV Threshold
    ue-RX-TX-TimeDifferenceThreshold    UE-RX-TX-TimeDifferenceThreshold
}

-- dummy and dummy2 are not used in this version of the specification, they should
-- not be sent and if received the UE behaviour is not specified.
UE-AutonomousUpdateMode ::=         CHOICE {
    dummy                               NULL,
    onWithNoReporting                   NULL,
    dummy2                              RL-InformationLists
}

UE-InternalEventParam ::=           CHOICE {
    event6a                             UE-6AB-Event,
    event6b                             UE-6AB-Event,
    event6c                             TimeToTrigger,
    event6d                             TimeToTrigger,
    event6e                             TimeToTrigger,
    event6f                             UE-6FG-Event,
    event6g                             UE-6FG-Event
}

UE-InternalEventParamList ::=       SEQUENCE (SIZE (1..maxMeasEvent)) OF
                                        UE-InternalEventParam

UE-InternalEventResults ::=         CHOICE {
    event6a                             NULL,
    event6b                             NULL,
    event6c                             NULL,
    event6d                             NULL,
    event6e                             NULL,
    event6f                             PrimaryCPICH-Info,
    event6g                             PrimaryCPICH-Info,
```

```
    spare                                   NULL
}

UE-InternalMeasQuantity ::=         SEQUENCE {
    measurementQuantity                     UE-MeasurementQuantity,
    filterCoefficient                       FilterCoefficient                   DEFAULT fc0
}

UE-InternalMeasuredResults ::=      SEQUENCE {
    modeSpecificInfo                        CHOICE {
        fdd                                     SEQUENCE {
            ue-TransmittedPowerFDD                  UE-TransmittedPower         OPTIONAL,
            ue-RX-TX-ReportEntryList                UE-RX-TX-ReportEntryList    OPTIONAL
        },
        tdd                                     SEQUENCE {
            ue-TransmittedPowerTDD-List             UE-TransmittedPowerTDD-List OPTIONAL,
            appliedTA                               UL-TimingAdvance            OPTIONAL
        }
    }
}

UE-InternalMeasuredResults-r7 ::=       SEQUENCE {
    modeSpecificInfo                        CHOICE {
        fdd                                     SEQUENCE {
            ue-TransmittedPowerFDD                  UE-TransmittedPower         OPTIONAL,
            ue-RX-TX-ReportEntryList                UE-RX-TX-ReportEntryList    OPTIONAL
        },
        tdd                                     SEQUENCE {
            ue-TransmittedPowerTDD-List             UE-TransmittedPowerTDD-List OPTIONAL,
            appliedTA                               UL-TimingAdvance-VHCR       OPTIONAL
        }
    }
}

UE-InternalMeasuredResults-LCR-r4 ::=   SEQUENCE {
        ue-TransmittedPowerTDD-List         UE-TransmittedPowerTDD-List     OPTIONAL,
        t-ADVinfo                           T-ADVinfo                       OPTIONAL
}

UE-InternalMeasurement ::=          SEQUENCE {
    ue-InternalMeasQuantity             UE-InternalMeasQuantity             OPTIONAL,
    ue-InternalReportingQuantity        UE-InternalReportingQuantity        OPTIONAL,
    reportCriteria                      UE-InternalReportCriteria
}

UE-InternalMeasurement-r4 ::=       SEQUENCE {
    ue-InternalMeasQuantity             UE-InternalMeasQuantity             OPTIONAL,
    ue-InternalReportingQuantity        UE-InternalReportingQuantity-r4     OPTIONAL,
    reportCriteria                      UE-InternalReportCriteria
}

UE-InternalMeasurementSysInfo ::=   SEQUENCE {
    ue-InternalMeasurementID            MeasurementIdentity         DEFAULT 5,
    ue-InternalMeasQuantity             UE-InternalMeasQuantity
}

UE-InternalReportCriteria ::=       CHOICE {
    ue-InternalReportingCriteria        UE-InternalReportingCriteria,
    periodicalReportingCriteria         PeriodicalReportingCriteria,
    noReporting                         NULL
}

UE-InternalReportingCriteria ::=    SEQUENCE {
    ue-InternalEventParamList           UE-InternalEventParamList           OPTIONAL
}

UE-InternalReportingQuantity ::=    SEQUENCE {
    ue-TransmittedPower                 BOOLEAN,
    modeSpecificInfo                    CHOICE {
        fdd                                 SEQUENCE {
            ue-RX-TX-TimeDifference             BOOLEAN
        },
        tdd                                 SEQUENCE {
            appliedTA                           BOOLEAN
        }
    }
}
```

```
UE-InternalReportingQuantity-r4 ::= SEQUENCE {
    ue-TransmittedPower                 BOOLEAN,
    modeSpecificInfo                    CHOICE {
        fdd                                 SEQUENCE {
            ue-RX-TX-TimeDifference             BOOLEAN
        },
        tdd                                 SEQUENCE {
            tddOption                           CHOICE {
            -- appliedTA applies to both 3.84 Mcps TDD and to 7.68 Mcps TDD.
            -- Therefore, no additional choice of TDD mode is necessary
                tdd384                              SEQUENCE {
                    appliedTA                           BOOLEAN
                },
                tdd128                              SEQUENCE {
                    t-ADVinfo                           BOOLEAN
                }
            }
        }
    }
}

-- TABULAR: UE-MeasurementQuantity, for 3.84 Mcps TDD only the first two values
-- ue-TransmittedPower and utra-Carrier-RSSI are used.
-- For 1.28 Mcps TDD ue-RX-TX-TimeDifference corresponds to T-ADV in the tabular
UE-MeasurementQuantity ::=          ENUMERATED {
                                        ue-TransmittedPower,
                                        utra-Carrier-RSSI,
                                        ue-RX-TX-TimeDifference }

UE-RX-TX-ReportEntry ::=            SEQUENCE {
    primaryCPICH-Info                   PrimaryCPICH-Info,
    ue-RX-TX-TimeDifferenceType1        UE-RX-TX-TimeDifferenceType1
}

UE-RX-TX-ReportEntryList ::=        SEQUENCE (SIZE (1..maxRL)) OF
                                        UE-RX-TX-ReportEntry

-- SPARE: UE-RX-TX-TimeDifferenceType1, Max = 1280
-- Values above Max are spare
UE-RX-TX-TimeDifferenceType1 ::=            INTEGER (768..1791)


UE-RX-TX-TimeDifferenceType2 ::=    INTEGER (0..8191)

UE-RX-TX-TimeDifferenceType2Info ::=    SEQUENCE {
    ue-RX-TX-TimeDifferenceType2            UE-RX-TX-TimeDifferenceType2,
    neighbourQuality                        NeighbourQuality
}

-- In 1.28 Mcps TDD, actual value for
-- T-ADV Threshold = (UE-RX-TX-TimeDifferenceThreshold - 768) * 0.125
UE-RX-TX-TimeDifferenceThreshold ::= INTEGER (768..1280)

UE-TransmittedPower ::=             INTEGER (0..104)

UE-TransmittedPowerTDD-List ::=     SEQUENCE (SIZE (1..maxTS)) OF
                                        UE-TransmittedPower

UL-TrCH-Identity ::=                    CHOICE{
    dch                                 TransportChannelIdentity,
    -- Note: the reference to CPCH in the element name below is incorrect. The name is not changed
    -- to keep it aligned with R99.
    rachorcpch                          NULL,
    usch                                TransportChannelIdentity
}

UE-Positioning-Accuracy ::=                 BIT STRING (SIZE (7))


UE-Positioning-CipherParameters ::=         SEQUENCE {
    cipheringKeyFlag                    BIT STRING (SIZE (1)),
    cipheringSerialNumber               INTEGER (0..65535)
}

UE-Positioning-Error ::=                        SEQUENCE {
    errorReason                         UE-Positioning-ErrorCause,
    ue-positioning-GPS-additionalAssistanceDataRequest          UE-Positioning-GPS-
AdditionalAssistanceDataRequest OPTIONAL
```

```
}

UE-Positioning-ErrorCause ::=                   ENUMERATED {
                                        notEnoughOTDOA-Cells,
                                        notEnoughGPS-Satellites,
                                        assistanceDataMissing,
                                        notAccomplishedGPS-TimingOfCellFrames,
                                        undefinedError,
                                        requestDeniedByUser,
                                        notProcessedAndTimeout,
                                        referenceCellNotServingCell }

UE-Positioning-EventParam ::=                   SEQUENCE {
    reportingAmount                     ReportingAmount,
    reportFirstFix                      BOOLEAN,
    measurementInterval                 UE-Positioning-MeasurementInterval,
    eventSpecificInfo                   UE-Positioning-EventSpecificInfo
}

UE-Positioning-EventParamList ::=               SEQUENCE (SIZE (1..maxMeasEvent)) OF
                                        UE-Positioning-EventParam

UE-Positioning-EventSpecificInfo ::=            CHOICE {
    e7a                                 ThresholdPositionChange,
    e7b                                 ThresholdSFN-SFN-Change,
    e7c                                 ThresholdSFN-GPS-TOW
}

UE-Positioning-GPS-AcquisitionAssistance ::=    SEQUENCE {
    gps-ReferenceTime                   INTEGER (0..604799999),
    utran-GPSReferenceTime              UTRAN-GPSReferenceTime          OPTIONAL,
    satelliteInformationList            AcquisitionSatInfoList
}

UE-Positioning-GPS-AdditionalAssistanceDataRequest ::=      SEQUENCE {
    almanacRequest                      BOOLEAN,
    utcModelRequest                     BOOLEAN,
    ionosphericModelRequest             BOOLEAN,
    navigationModelRequest              BOOLEAN,
    dgpsCorrectionsRequest              BOOLEAN,
    referenceLocationRequest            BOOLEAN,
    referenceTimeRequest                BOOLEAN,
    aquisitionAssistanceRequest         BOOLEAN,
    realTimeIntegrityRequest            BOOLEAN,
    navModelAddDataRequest              UE-Positioning-GPS-NavModelAddDataReq       OPTIONAL
}

UE-Positioning-GPS-Almanac ::=                  SEQUENCE {
    wn-a                                BIT STRING (SIZE (8)),
    almanacSatInfoList                  AlmanacSatInfoList,
    sv-GlobalHealth                     BIT STRING (SIZE (364))             OPTIONAL
}

UE-Positioning-GPS-AssistanceData ::=           SEQUENCE {
    ue-positioning-GPS-ReferenceTime                UE-Positioning-GPS-ReferenceTime
    OPTIONAL,
    ue-positioning-GPS-ReferenceLocation            ReferenceLocation               OPTIONAL,
    ue-positioning-GPS-DGPS-Corrections             UE-Positioning-GPS-DGPS-Corrections
    OPTIONAL,
    ue-positioning-GPS-NavigationModel              UE-Positioning-GPS-NavigationModel
    OPTIONAL,
    ue-positioning-GPS-IonosphericModel             UE-Positioning-GPS-IonosphericModel
    OPTIONAL,
    ue-positioning-GPS-UTC-Model                    UE-Positioning-GPS-UTC-Model
    OPTIONAL,
    ue-positioning-GPS-Almanac                      UE-Positioning-GPS-Almanac
    OPTIONAL,
    ue-positioning-GPS-AcquisitionAssistance        UE-Positioning-GPS-AcquisitionAssistance
    OPTIONAL,
    ue-positioning-GPS-Real-timeIntegrity           BadSatList                              OPTIONAL,
    -- dummy is not used in this version of the specification, it should
    -- not be sent and if received it should be ignored.
    dummy           UE-Positioning-GPS-ReferenceCellInfo        OPTIONAL
}

UE-Positioning-GPS-DGPS-Corrections ::=     SEQUENCE {
    gps-TOW                             INTEGER (0..604799),
    statusHealth                        DiffCorrectionStatus,
```

```
    dgps-CorrectionSatInfoList          DGPS-CorrectionSatInfoList
}

UE-Positioning-GPS-IonosphericModel ::=     SEQUENCE {
    alfa0                               BIT STRING (SIZE (8)),
    alfa1                               BIT STRING (SIZE (8)),
    alfa2                               BIT STRING (SIZE (8)),
    alfa3                               BIT STRING (SIZE (8)),
    beta0                               BIT STRING (SIZE (8)),
    beta1                               BIT STRING (SIZE (8)),
    beta2                               BIT STRING (SIZE (8)),
    beta3                               BIT STRING (SIZE (8))
}

UE-Positioning-GPS-MeasurementResults ::=       SEQUENCE {
    referenceTime                       CHOICE {
        utran-GPSReferenceTimeResult        UTRAN-GPSReferenceTimeResult,
        gps-ReferenceTimeOnly               INTEGER (0..604799999)
    },
    gps-MeasurementParamList            GPS-MeasurementParamList
}

UE-Positioning-GPS-NavigationModel ::=          SEQUENCE {
    navigationModelSatInfoList          NavigationModelSatInfoList
}

UE-Positioning-GPS-NavModelAddDataReq ::=       SEQUENCE {
    gps-Week                            INTEGER (0..1023),
    -- SPARE: gps-Toe, Max = 167
    -- Values above Max are spare
    gps-Toe                             INTEGER (0..255),
    -- SPARE: tToeLimit, Max = 10
    -- Values above Max are spare
    tToeLimit                           INTEGER (0..15),
    satDataList                         SatDataList
}

UE-Positioning-GPS-ReferenceCellInfo ::=        SEQUENCE{
    modeSpecificInfo                CHOICE {
        fdd                             SEQUENCE {
            referenceIdentity               PrimaryCPICH-Info
        },
        tdd                             SEQUENCE {
            referenceIdentity               CellParametersID
        }
    }
}

UE-Positioning-GPS-ReferenceTime ::=            SEQUENCE {
    gps-Week                            INTEGER (0..1023),
    gps-tow-1msec                       GPS-TOW-1msec,  utran-GPSReferenceTime              UTRAN-
GPSReferenceTime                OPTIONAL,
    sfn-tow-Uncertainty                 SFN-TOW-Uncertainty                 OPTIONAL,
    utran-GPS-DriftRate                 UTRAN-GPS-DriftRate                 OPTIONAL,
    gps-TOW-AssistList                  GPS-TOW-AssistList                  OPTIONAL
}

UE-Positioning-GPS-UTC-Model ::=                SEQUENCE {
    a1                                  BIT STRING (SIZE (24)),
    a0                                  BIT STRING (SIZE (32)),
    t-ot                                BIT STRING (SIZE (8)),
    wn-t                                BIT STRING (SIZE (8)),
    delta-t-LS                          BIT STRING (SIZE (8)),
    wn-lsf                              BIT STRING (SIZE (8)),
    dn                                  BIT STRING (SIZE (8)),
    delta-t-LSF                         BIT STRING (SIZE (8))
}

UE-Positioning-IPDL-Parameters ::=              SEQUENCE {
    ip-Spacing                          IP-Spacing,
    ip-Length                           IP-Length,
    ip-Offset                           INTEGER (0..9),
    seed                                INTEGER (0..63),
    burstModeParameters                 BurstModeParameters         OPTIONAL
}

UE-Positioning-IPDL-Parameters-r4 ::=           SEQUENCE {
    modeSpecificInfo                    CHOICE {
```

```
        fdd                                 SEQUENCE {
            ip-Spacing                          IP-Spacing,
            ip-Length                           IP-Length,
            ip-Offset                           INTEGER (0..9),
            seed                                INTEGER (0..63)
        },
        tdd                                 SEQUENCE {
            ip-Spacing-TDD                      IP-Spacing-TDD,
            ip-slot                             INTEGER (0..14),
            ip-Start                            INTEGER (0..4095),
            ip-PCCPCG                           IP-PCCPCH-r4            OPTIONAL
        }
    },
    burstModeParameters                 BurstModeParameters             OPTIONAL
}

UE-Positioning-IPDL-Parameters-TDD-r4-ext ::=   SEQUENCE {
    ip-Spacing                          IP-Spacing-TDD,
    ip-slot                             INTEGER (0..14),
    ip-Start                            INTEGER (0..4095),
    ip-PCCPCG                           IP-PCCPCH-r4                    OPTIONAL,
    burstModeParameters                 BurstModeParameters
}

UE-Positioning-MeasuredResults ::=              SEQUENCE {
    ue-positioning-OTDOA-Measurement                UE-Positioning-OTDOA-Measurement
    OPTIONAL,
    ue-positioning-PositionEstimateInfo             UE-Positioning-PositionEstimateInfo
        OPTIONAL,
    ue-positioning-GPS-Measurement                  UE-Positioning-GPS-MeasurementResults
        OPTIONAL,
    ue-positioning-Error                            UE-Positioning-Error
    OPTIONAL
}

UE-Positioning-MeasuredResults-v390ext ::=      SEQUENCE {
    ue-Positioning-OTDOA-Measurement-v390ext        UE-Positioning-OTDOA-Measurement-v390ext
}

UE-Positioning-Measurement ::=                  SEQUENCE {
    ue-positioning-ReportingQuantity                UE-Positioning-ReportingQuantity,
    reportCriteria                      UE-Positioning-ReportCriteria,
    ue-positioning-OTDOA-AssistanceData         UE-Positioning-OTDOA-AssistanceData
    OPTIONAL,
    ue-positioning-GPS-AssistanceData               UE-Positioning-GPS-AssistanceData
    OPTIONAL
}

UE-Positioning-Measurement-v390ext ::=          SEQUENCE {
    ue-positioning-ReportingQuantity-v390ext        UE-Positioning-ReportingQuantity-v390ext
    OPTIONAL,
    measurementValidity                 MeasurementValidity                 OPTIONAL,
    ue-positioning-OTDOA-AssistanceData-UEB         UE-Positioning-OTDOA-AssistanceData-UEB
    OPTIONAL
}

UE-Positioning-Measurement-r4 ::=               SEQUENCE {
    ue-positioning-ReportingQuantity                UE-Positioning-ReportingQuantity-r4,
    measurementValidity                             MeasurementValidity
    OPTIONAL,
    reportCriteria                                  UE-Positioning-ReportCriteria,
    ue-positioning-OTDOA-AssistanceData             UE-Positioning-OTDOA-AssistanceData-r4
    OPTIONAL,
    ue-positioning-GPS-AssistanceData               UE-Positioning-GPS-AssistanceData
    OPTIONAL
}

UE-Positioning-Measurement-v7xyext ::=          SEQUENCE {
    ue-positioning-ReportingQuantity                UE-Positioning-ReportingQuantity-v7xyext,
    measurementValidity                             MeasurementValidity                 OPTIONAL,
    reportCriteria                                  UE-Positioning-ReportCriteria,
    ue-positioning-OTDOA-AssistanceData             UE-Positioning-OTDOA-AssistanceData-r4
    OPTIONAL,
    ue-positioning-GPS-AssistanceData               UE-Positioning-GPS-AssistanceData       OPTIONAL
}

UE-Positioning-MeasurementEventResults ::=      CHOICE {
    event7a                             UE-Positioning-PositionEstimateInfo,
```

```
    event7b                                 UE-Positioning-OTDOA-Measurement,
    event7c                                 UE-Positioning-GPS-MeasurementResults,
    spare                                   NULL
}

UE-Positioning-MeasurementInterval ::=          ENUMERATED {
                                        e5, e15, e60, e300,
                                        e900, e1800, e3600, e7200 }

UE-Positioning-MethodType ::=                   ENUMERATED {
                                        ue-Assisted,
                                        ue-Based,
                                        ue-BasedPreferred,
                                        ue-AssistedPreferred }

UE-Positioning-OTDOA-AssistanceData ::=     SEQUENCE {
    ue-positioning-OTDOA-ReferenceCellInfo          UE-Positioning-OTDOA-ReferenceCellInfo
    OPTIONAL,
    ue-positioning-OTDOA-NeighbourCellList              UE-Positioning-OTDOA-NeighbourCellList
        OPTIONAL
}

UE-Positioning-OTDOA-AssistanceData-r4 ::=  SEQUENCE {
    ue-positioning-OTDOA-ReferenceCellInfo          UE-Positioning-OTDOA-ReferenceCellInfo-r4
        OPTIONAL,
    ue-positioning-OTDOA-NeighbourCellList          UE-Positioning-OTDOA-NeighbourCellList-r4
        OPTIONAL
}

UE-Positioning-OTDOA-AssistanceData-r4ext ::= SEQUENCE {
    -- In case of TDD these IPDL parameters shall be used for the reference cell instead of
    -- IPDL Parameters in IE UE-Positioning-OTDOA-ReferenceCellInfo
    ue-Positioning-IPDL-Parameters-TDD-r4-ext       UE-Positioning-IPDL-Parameters-TDD-r4-ext
    OPTIONAL,
    -- These IPDL parameters shall be used for the neighbour cells in case of TDD instead of
    -- IPDL Parameters in IE UE-Positioning-OTDOA-NeighbourCellInfoList. The cells shall be
    -- listed in the same order as in IE UE-Positioning-OTDOA-NeighbourCellInfoList
    ue-Positioning-IPDL-Parameters-TDDList-r4-ext   UE-Positioning-IPDL-Parameters-TDDList-r4-ext
    OPTIONAL
}

UE-Positioning-OTDOA-AssistanceData-UEB ::=     SEQUENCE {
    ue-positioning-OTDOA-ReferenceCellInfo-UEB          UE-Positioning-OTDOA-ReferenceCellInfo-UEB
                OPTIONAL,
    ue-positioning-OTDOA-NeighbourCellList-UEB              UE-Positioning-OTDOA-NeighbourCellList-
UEB             OPTIONAL
}

UE-Positioning-IPDL-Parameters-TDDList-r4-ext ::=   SEQUENCE (SIZE (1..maxCellMeas)) OF
                                            UE-Positioning-IPDL-Parameters-TDD-r4-ext

UE-Positioning-OTDOA-Measurement ::=            SEQUENCE {
    sfn                                 INTEGER (0..4095),
    modeSpecificInfo                CHOICE {
        fdd                             SEQUENCE {
            referenceCellIDentity               PrimaryCPICH-Info,
            ue-RX-TX-TimeDifferenceType2Info    UE-RX-TX-TimeDifferenceType2Info
        },
        tdd                                 SEQUENCE {
            referenceCellIdentity           CellParametersID
        }
    },
    neighbourList                       NeighbourList                       OPTIONAL
}

UE-Positioning-OTDOA-Measurement-v390ext ::=            SEQUENCE {
    neighbourList-v390ext                       NeighbourList-v390ext
}

UE-Positioning-OTDOA-NeighbourCellInfo ::= SEQUENCE {
    modeSpecificInfo    CHOICE  {
        fdd                             SEQUENCE {
            primaryCPICH-Info                   PrimaryCPICH-Info
        },
        tdd                             SEQUENCE{
            cellAndChannelIdentity              CellAndChannelIdentity
        }
    },
```

```
    frequencyInfo                       FrequencyInfo                       OPTIONAL,
    ue-positioning-IPDL-Paremeters              UE-Positioning-IPDL-Parameters
    OPTIONAL,
    sfn-SFN-RelTimeDifference           SFN-SFN-RelTimeDifference1,
    sfn-SFN-Drift                       SFN-SFN-Drift                       OPTIONAL,
    searchWindowSize                    OTDOA-SearchWindowSize,
    positioningMode     CHOICE{
        ueBased                                 SEQUENCE {},
        ueAssisted                              SEQUENCE {}
    }
}

UE-Positioning-OTDOA-NeighbourCellInfo-r4 ::= SEQUENCE {
    modeSpecificInfo    CHOICE  {
        fdd                             SEQUENCE {
            primaryCPICH-Info                   PrimaryCPICH-Info
        },
        tdd                             SEQUENCE{
            cellAndChannelIdentity              CellAndChannelIdentity
        }
    },
    frequencyInfo                       FrequencyInfo                       OPTIONAL,
    ue-positioning-IPDL-Paremeters      UE-Positioning-IPDL-Parameters-r4    OPTIONAL,
    sfn-SFN-RelTimeDifference           SFN-SFN-RelTimeDifference1,
    sfn-Offset-Validity                 SFN-Offset-Validity                 OPTIONAL,
    sfn-SFN-Drift                       SFN-SFN-Drift                       OPTIONAL,
    searchWindowSize                    OTDOA-SearchWindowSize,
    positioningMode     CHOICE {
        ueBased                                 SEQUENCE {
            relativeNorth                       INTEGER (-20000..20000)             OPTIONAL,
            relativeEast                        INTEGER (-20000..20000)             OPTIONAL,
            relativeAltitude                    INTEGER (-4000..4000)               OPTIONAL,
            fineSFN-SFN                         FineSFN-SFN                         OPTIONAL,
            -- actual value roundTripTime = (IE value * 0.0625) + 876
            roundTripTime                       INTEGER (0.. 32766)                 OPTIONAL
        },
        ueAssisted                              SEQUENCE {}
    }
}

UE-Positioning-OTDOA-NeighbourCellInfo-UEB ::= SEQUENCE {
    modeSpecificInfo    CHOICE  {
        fdd                             SEQUENCE {
            primaryCPICH-Info                   PrimaryCPICH-Info
        },
        tdd                             SEQUENCE{
            cellAndChannelIdentity              CellAndChannelIdentity
        }
    },
    frequencyInfo                       FrequencyInfo                       OPTIONAL,
    ue-positioning-IPDL-Paremeters      UE-Positioning-IPDL-Parameters      OPTIONAL,
    sfn-SFN-RelTimeDifference           SFN-SFN-RelTimeDifference1,
    sfn-SFN-Drift                       SFN-SFN-Drift                       OPTIONAL,
    searchWindowSize                    OTDOA-SearchWindowSize,
    relativeNorth                       INTEGER (-20000..20000)             OPTIONAL,
    relativeEast                        INTEGER (-20000..20000)             OPTIONAL,
    relativeAltitude                    INTEGER (-4000..4000)               OPTIONAL,
    fineSFN-SFN                         FineSFN-SFN,
    -- actual value roundTripTime = (IE value * 0.0625) + 876
    roundTripTime                       INTEGER (0..32766)                  OPTIONAL
}

UE-Positioning-OTDOA-NeighbourCellList ::= SEQUENCE (SIZE (1..maxCellMeas)) OF
                                        UE-Positioning-OTDOA-NeighbourCellInfo

UE-Positioning-OTDOA-NeighbourCellList-r4 ::= SEQUENCE (SIZE (1..maxCellMeas)) OF
                                        UE-Positioning-OTDOA-NeighbourCellInfo-r4

UE-Positioning-OTDOA-NeighbourCellList-UEB ::= SEQUENCE (SIZE (1..maxCellMeas)) OF
                                        UE-Positioning-OTDOA-NeighbourCellInfo-UEB

UE-Positioning-OTDOA-Quality ::=            SEQUENCE {
    stdResolution                       BIT STRING (SIZE (2)),
    numberOfOTDOA-Measurements          BIT STRING (SIZE (3)),
    stdOfOTDOA-Measurements             BIT STRING (SIZE (5))
}

UE-Positioning-OTDOA-ReferenceCellInfo ::=          SEQUENCE {
```

```
    sfn                                 INTEGER (0..4095)
    OPTIONAL,
    modeSpecificInfo CHOICE {
        fdd                                     SEQUENCE {
            primaryCPICH-Info                   PrimaryCPICH-Info
        },
        tdd                                     SEQUENCE{
            cellAndChannelIdentity              CellAndChannelIdentity
        }
    },
    frequencyInfo                       FrequencyInfo                       OPTIONAL,
    positioningMode CHOICE {
        ueBased                                 SEQUENCE {},
        ueAssisted                              SEQUENCE {}
    },
    ue-positioning-IPDL-Paremeters              UE-Positioning-IPDL-Parameters  OPTIONAL
}

UE-Positioning-OTDOA-ReferenceCellInfo-r4 ::=   SEQUENCE {
    sfn                                 INTEGER (0..4095)
    OPTIONAL,
    modeSpecificInfo CHOICE {
        fdd                                     SEQUENCE {
            primaryCPICH-Info                   PrimaryCPICH-Info
        },
        tdd                                     SEQUENCE{
            cellAndChannelIdentity              CellAndChannelIdentity
        }
    },
    frequencyInfo                       FrequencyInfo                       OPTIONAL,
    positioningMode CHOICE {
        ueBased                                 SEQUENCE {
            cellPosition                                ReferenceCellPosition   OPTIONAL,
            -- actual value roundTripTime = (IE value * 0.0625) + 876
            roundTripTime                       INTEGER (0..32766)              OPTIONAL
        },
        ueAssisted                              SEQUENCE {}
    },
    ue-positioning-IPDL-Paremeters              UE-Positioning-IPDL-Parameters-r4   OPTIONAL
}

UE-Positioning-OTDOA-ReferenceCellInfo-UEB ::=          SEQUENCE {
    sfn                                 INTEGER (0..4095)                   OPTIONAL,
    modeSpecificInfo CHOICE {
        fdd                                     SEQUENCE {
            primaryCPICH-Info                   PrimaryCPICH-Info
        },
        tdd                                     SEQUENCE{
            cellAndChannelIdentity              CellAndChannelIdentity
        }
    },
    frequencyInfo                       FrequencyInfo                       OPTIONAL,
    cellPosition                        ReferenceCellPosition               OPTIONAL,
    -- actual value roundTripTime = (IE value * 0.0625) + 876
    roundTripTime                       INTEGER (0..32766)                  OPTIONAL,
    ue-positioning-IPDL-Paremeters      UE-Positioning-IPDL-Parameters      OPTIONAL
}

UE-Positioning-PositionEstimateInfo ::=                 SEQUENCE {
    referenceTime                   CHOICE {
        utran-GPSReferenceTimeResult        UTRAN-GPSReferenceTimeResult,
        gps-ReferenceTimeOnly               INTEGER (0..604799999),
        cell-Timing                         SEQUENCE {
            sfn                                     INTEGER (0..4095),
            modeSpecificInfo                CHOICE {
                fdd                                 SEQUENCE {
                    primaryCPICH-Info                   PrimaryCPICH-Info
                },
                tdd                                 SEQUENCE{
                    cellAndChannelIdentity              CellAndChannelIdentity
                }
            }
        }
    },
    positionEstimate                    PositionEstimate
}

UE-Positioning-ReportCriteria ::=               CHOICE {
```

```
    ue-positioning-ReportingCriteria              UE-Positioning-EventParamList,
    periodicalReportingCriteria         PeriodicalReportingCriteria,
    noReporting                         NULL
}

UE-Positioning-ReportingQuantity ::=            SEQUENCE {
    methodType                          UE-Positioning-MethodType,
    positioningMethod                   PositioningMethod,
    -- dummy1 is not used in this version of specification and it should
    -- be ignored.
    dummy1                              UE-Positioning-ResponseTime,
    horizontal-Accuracy                 UE-Positioning-Accuracy             OPTIONAL,
    gps-TimingOfCellWanted              BOOLEAN,
    -- dummy2 is not used in this version of specification and it should
    -- be ignored.
    dummy2                              BOOLEAN,
    additionalAssistanceDataRequest     BOOLEAN,
    environmentCharacterisation         EnvironmentCharacterisation         OPTIONAL
}

UE-Positioning-ReportingQuantity-v390ext ::=        SEQUENCE {
    vertical-Accuracy                           UE-Positioning-Accuracy
}

UE-Positioning-ReportingQuantity-r4 ::=         SEQUENCE {
    methodType                          UE-Positioning-MethodType,
    positioningMethod                   PositioningMethod,
    horizontalAccuracy                  UE-Positioning-Accuracy             OPTIONAL,
    verticalAccuracy                    UE-Positioning-Accuracy             OPTIONAL,
    gps-TimingOfCellWanted              BOOLEAN,
    additionalAssistanceDataReq         BOOLEAN,
    environmentCharacterisation         EnvironmentCharacterisation         OPTIONAL
}

UE-Positioning-ReportingQuantity-v7xyext ::=    SEQUENCE {
    methodType                          UE-Positioning-MethodType,
    positioningMethod                   PositioningMethod,
    horizontalAccuracy                  UE-Positioning-Accuracy             OPTIONAL,
    verticalAccuracy                    UE-Positioning-Accuracy             OPTIONAL,
    gps-TimingOfCellWanted              BOOLEAN,
    additionalAssistanceDataReq         BOOLEAN,
    environmentCharacterisation         EnvironmentCharacterisation         OPTIONAL,
    velocityRequested                   ENUMERATED { true }                 OPTIONAL
}

UE-Positioning-ResponseTime ::=             ENUMERATED {
                                    s1, s2, s4, s8, s16,
                                    s32, s64, s128 }

-- SPARE: UTRA-CarrierRSSI, Max = 76
-- Values above Max are spare
UTRA-CarrierRSSI ::=                INTEGER (0..127)

UTRAN-GPS-DriftRate ::=             ENUMERATED {
                                    utran-GPSDrift0, utran-GPSDrift1, utran-GPSDrift2,
                                    utran-GPSDrift5, utran-GPSDrift10, utran-GPSDrift15,
                                    utran-GPSDrift25, utran-GPSDrift50, utran-GPSDrift-1,
                                    utran-GPSDrift-2, utran-GPSDrift-5, utran-GPSDrift-10,
                                    utran-GPSDrift-15, utran-GPSDrift-25, utran-GPSDrift-50}

UTRAN-GPSReferenceTime ::=              SEQUENCE {
    -- For utran-GPSTimingOfCell values above 2322431999999 are not
    -- used in this version of the specification
    -- Actual value utran-GPSTimingOfCell = (ms-part * 4294967296) + ls-part
    utran-GPSTimingOfCell           SEQUENCE {
        ms-part                         INTEGER (0..1023),
        ls-part                         INTEGER (0..4294967295)
    },
    modeSpecificInfo                CHOICE {
        fdd                             SEQUENCE {
            referenceIdentity               PrimaryCPICH-Info
        },
        tdd                             SEQUENCE {
            referenceIdentity               CellParametersID
        }
    }               OPTIONAL,
    sfn                                 INTEGER (0..4095)
}
```

```
UTRAN-GPSReferenceTimeResult ::=                SEQUENCE {
    -- For ue-GPSTimingOfCell values above 37158911999999 are not
    -- used in this version of the specification
    -- Actual value ue-GPSTimingOfCell = (ms-part * 4294967296) + ls-part
    ue-GPSTimingOfCell          SEQUENCE {
        ms-part                         INTEGER (0.. 16383),
        ls-part                         INTEGER (0..4294967295)
    },
    modeSpecificInfo                CHOICE {
        fdd                             SEQUENCE {
            referenceIdentity               PrimaryCPICH-Info
        },
        tdd                             SEQUENCE {
            referenceIdentity               CellParametersID
        }
    },
    sfn                                 INTEGER (0..4095)
}

VarianceOfRLC-BufferPayload ::=     ENUMERATED {
                                        plv0, plv4, plv8, plv16, plv32, plv64,
                                        plv128, plv256, plv512, plv1024,
                                        plv2k, plv4k, plv8k, plv16k, spare2, spare1 }

VelocityEstimate    ::=             CHOICE {
    horizontalVelocity                                  HorizontalVelocity,
    horizontalWithVerticalVelocity                      HorizontalWithVerticalVelocity,
    horizontalVelocityWithUncertainty                   HorizontalVelocityWithUncertainty,
    horizontalWithVerticalVelocityAndUncertainty    HorizontalWithVerticalVelocityAndUncertainty
}

-- Actual value W = IE value * 0.1
W ::=                               INTEGER (0..20)

-- **************************************************
--
--     OTHER INFORMATION ELEMENTS (10.3.8)
--
-- **************************************************

BCC ::=                             INTEGER (0..7)

BCCH-ModificationInfo ::=           SEQUENCE {
    mib-ValueTag                        MIB-ValueTag,
    bcch-ModificationTime               BCCH-ModificationTime               OPTIONAL
}

-- Actual value BCCH-ModificationTime = IE value * 8
BCCH-ModificationTime ::=           INTEGER (0..511)

BSIC ::=                            SEQUENCE {
    ncc                                 NCC,
    bcc                                 BCC
}

CBS-DRX-Level1Information ::=       SEQUENCE {
    ctch-AllocationPeriod               INTEGER (1..256),
    cbs-FrameOffset                     INTEGER (0..255)
}

CBS-DRX-Level1Information-extension-r6 ::=  ENUMERATED {p8, p16, p32, p64, p128, p256}

CDMA2000-Message ::=                SEQUENCE {
    msg-Type                            BIT STRING (SIZE (8)),
    payload                             BIT STRING (SIZE (1..512))
}

CDMA2000-MessageList ::=                SEQUENCE (SIZE (1..maxInterSysMessages)) OF
                                            CDMA2000-Message

CDMA2000-UMTS-Frequency-List ::=        SEQUENCE (SIZE (1..maxNumCDMA2000Freqs)) OF
                                            FrequencyInfoCDMA2000

CellValueTag ::=                        INTEGER (1..4)

--Actual value = 2^(IE value)
ExpirationTimeFactor ::=                INTEGER (1..8)
```

```
FDD-UMTS-Frequency-List ::=             SEQUENCE (SIZE (1..maxNumFDDFreqs)) OF
                                            FrequencyInfoFDD

FrequencyInfoCDMA2000 ::=               SEQUENCE {
                                            band-Class      BIT STRING (SIZE (5)),
                                            cdma-Freq       BIT STRING (SIZE(11))
}

GERAN-SystemInfoBlock ::=               OCTET STRING (SIZE (1..23))

GERAN-SystemInformation ::=             SEQUENCE (SIZE (1..maxGERAN-SI)) OF GERAN-SystemInfoBlock

GSM-BA-Range ::=                        SEQUENCE {
                                            gsmLowRangeUARFCN       UARFCN,
                                            gsmUpRangeUARFCN        UARFCN
}

GSM-BA-Range-List ::=                   SEQUENCE (SIZE (1..maxNumGSMFreqRanges)) OF
                                            GSM-BA-Range


-- This IE is formatted as 'TLV' and is coded in the same way as the Mobile Station Classmark 2
-- information element in [5]. The first octet is the Mobile station classmark 2 IEI and its value
-- shall be set to 33H. The second octet is the Length of mobile station classmark 2 and its value
-- shall be set to 3. The octet 3 contains the first octet of the value part of the Mobile Station
-- Classmark 2 information element, the octet 4 contains the second octet of the value part of the
-- Mobile Station Classmark 2 information element and so on. For each of these octets, the first/
-- leftmost/ most significant bit of the octet contains b8 of the corresponding octet of the Mobile
-- Station Classmark 2.
GSM-Classmark2 ::=                  OCTET STRING (SIZE (5))

-- This IE is formatted as 'V' and is coded in the same way as the value part in the Mobile station
-- classmark 3 information element in [5]
-- The value part is specified by means of CSN.1, which encoding results in a bit string, to which
-- final padding may be appended upto the next octet boundary [5]. The first/ leftmost bit of the
-- CSN.1 bit string is placed in the first/ leftmost/ most significant bit of the first
-- octet. This continues until the last bit of the CSN.1 bit string, which is placed in the last/
-- rightmost/ least significant bit of the last octet.
GSM-Classmark3 ::=                  OCTET STRING (SIZE (1..32))

GSM-MessageList ::=                 SEQUENCE (SIZE (1..maxInterSysMessages)) OF
                                        BIT STRING (SIZE (1..512))

GSM-MS-RadioAccessCapability ::=    OCTET STRING (SIZE (1..64))

GsmSecurityCapability ::=           BIT STRING {
                                        -- For each bit value '0' means false/ not supported
                                        a5-7(0),
                                        a5-6(1),
                                        a5-5(2),
                                        a5-4(3),
                                        a5-3(4),
                                        a5-2(5),
                                        a5-1(6)
                                        }   (SIZE (7))

GSM-TargetCellInfoList ::=      SEQUENCE (SIZE (1..maxGSMTargetCells)) OF
                                        GSM-TargetCellInfo


GSM-TargetCellInfo ::=              SEQUENCE {
    bcch-ARFCN                          BCCH-ARFCN,
    frequency-band                      Frequency-Band,
    bsic                                BSIC            OPTIONAL
}

IdentificationOfReceivedMessage ::= SEQUENCE {
        rrc-TransactionIdentifier       RRC-TransactionIdentifier,
        receivedMessageType             ReceivedMessageType
}

InterRAT-ChangeFailureCause ::=     CHOICE {
    configurationUnacceptable           NULL,
    physicalChannelFailure              NULL,
    protocolError                       ProtocolErrorInformation,
    unspecified                         NULL,
    spare4                              NULL,
```

```
    spare3                              NULL,
    spare2                              NULL,
    spare1                              NULL
}

GERANIu-MessageList ::=             SEQUENCE (SIZE (1..maxInterSysMessages)) OF
                                        BIT STRING (SIZE (1..32768))

GERANIu-RadioAccessCapability ::=   BIT STRING (SIZE (1..170))

InterRAT-UE-RadioAccessCapability ::= CHOICE {
    gsm                                 SEQUENCE {
        gsm-Classmark2                      GSM-Classmark2,
        gsm-Classmark3                      GSM-Classmark3
    },
    cdma2000                            SEQUENCE {
        cdma2000-MessageList                CDMA2000-MessageList
    }
}

InterRAT-UE-RadioAccessCapabilityList ::=   SEQUENCE (SIZE(1..maxInterSysMessages)) OF
                                            InterRAT-UE-RadioAccessCapability

InterRAT-UE-RadioAccessCapability-v590ext ::= SEQUENCE {
    geranIu-RadioAccessCapability       GERANIu-RadioAccessCapability
}

InterRAT-UE-RadioAccessCapability-v690ext ::= SEQUENCE {
    supportOfInter-RAT-PS-Handover      ENUMERATED { doesSupporInter-RAT-PS-Handover }  OPTIONAL,
    gsm-MS-RadioAccessCapability        GSM-MS-RadioAccessCapability
}

InterRAT-UE-SecurityCapability ::= CHOICE {
    gsm                                 SEQUENCE {
        gsmSecurityCapability           GsmSecurityCapability
    }
}

InterRAT-UE-SecurityCapList ::=     SEQUENCE (SIZE(1..maxInterSysMessages)) OF
                                        InterRAT-UE-SecurityCapability

InterRAT-HO-FailureCause ::=        CHOICE {
    configurationUnacceptable           NULL,
    physicalChannelFailure              NULL,
    protocolError                       ProtocolErrorInformation,
    interRAT-ProtocolError              NULL,
    unspecified                         NULL,
    spare11                             NULL,
    spare10                             NULL,
    spare9                              NULL,
    spare8                              NULL,
    spare7                              NULL,
    spare6                              NULL,
    spare5                              NULL,
    spare4                              NULL,
    spare3                              NULL,
    spare2                              NULL,
    spare1                              NULL
}

MasterInformationBlock ::=          SEQUENCE {
        mib-ValueTag                    MIB-ValueTag,
        -- TABULAR: The PLMN identity and ANSI-41 core network information
        -- are included in PLMN-Type.
        plmn-Type                       PLMN-Type,
        sibSb-ReferenceList             SIBSb-ReferenceList,
    -- Extension mechanism for non- release99 information
        v690NonCriticalExtensions           SEQUENCE {
            masterInformationBlock-v690ext      MasterInformationBlock-v690ext,
            nonCriticalExtensions               SEQUENCE {}                         OPTIONAL
        }   OPTIONAL
}

MasterInformationBlock-v690ext ::=  SEQUENCE {
    multiplePLMN-List                   MultiplePLMN-List-r6            OPTIONAL
}

MIB-ValueTag ::=                    INTEGER (1..8)
```

```
NCC ::=                             INTEGER (0..7)

PLMN-ValueTag ::=                   INTEGER (1..256)


PredefinedConfigIdentityAndValueTag ::= SEQUENCE {
    predefinedConfigIdentity            PredefinedConfigIdentity,
    predefinedConfigValueTag            PredefinedConfigValueTag
}

ProtocolErrorInformation ::=        SEQUENCE {
    diagnosticsType                     CHOICE {
        type1                               SEQUENCE {
            protocolErrorCause                  ProtocolErrorCause
        },
        spare                               NULL
    }
}

ReceivedMessageType ::=             ENUMERATED {
                                        activeSetUpdate,
                                        cellChangeOrderFromUTRAN,
                                        cellUpdateConfirm,
                                        counterCheck,
                                        downlinkDirectTransfer,
                                        interRATHandoverCommand,
                                        measurementControl,
                                        pagingType2,
                                        physicalChannelReconfiguration,
                                        physicalSharedChannelAllocation,
                                        radioBearerReconfiguration,
                                        radioBearerRelease,
                                        radioBearerSetup,
                                        rrcConnectionRelease,
                                        rrcConnectionReject,
                                        rrcConnectionSetup,
                                        securityModeCommand,
                                        signallingConnectionRelease,
                                        transportChannelReconfiguration,
                                        transportFormatCombinationControl,
                                        ueCapabilityEnquiry,
                                        ueCapabilityInformationConfirm,
                                        uplinkPhysicalChannelControl,
                                        uraUpdateConfirm,
                                        utranMobilityInformation,
                                        assistanceDataDelivery,
                                        spare6, spare5, spare4, spare3, spare2,
                                        spare1
}

Rplmn-Information ::=                   SEQUENCE {
                                            gsm-BA-Range-List       GSM-BA-Range-List   OPTIONAL,
                                            fdd-UMTS-Frequency-List FDD-UMTS-Frequency-List
    OPTIONAL,
                                            tdd-UMTS-Frequency-List TDD-UMTS-Frequency-List
    OPTIONAL,
                                            cdma2000-UMTS-Frequency-List    CDMA2000-UMTS-Frequency-
List    OPTIONAL
}

Rplmn-Information-r4 ::=        SEQUENCE {
    gsm-BA-Range-List               GSM-BA-Range-List                   OPTIONAL,
    fdd-UMTS-Frequency-List         FDD-UMTS-Frequency-List             OPTIONAL,
    -- the option is the same for 7.68 Mcps TDD as for 3.84 Mcps TDD
    -- i.e. TDD-UMTS-Frequency-List applies
    tdd384-UMTS-Frequency-List      TDD-UMTS-Frequency-List             OPTIONAL,
    tdd128-UMTS-Frequency-List      TDD-UMTS-Frequency-List             OPTIONAL,
    cdma2000-UMTS-Frequency-List    CDMA2000-UMTS-Frequency-List        OPTIONAL
}

SchedulingInformation ::=           SEQUENCE {
    scheduling                          SEQUENCE {
        segCount                            SegCount                        DEFAULT 1,
        sib-Pos                             CHOICE {
            -- The element name indicates the repetition period and the value
            -- (multiplied by two) indicates the position of the first segment.
            rep4                                INTEGER (0..1),
```

```
            rep8                                INTEGER (0..3),
            rep16                               INTEGER (0..7),
            rep32                               INTEGER (0..15),
            rep64                               INTEGER (0..31),
            rep128                              INTEGER (0..63),
            rep256                              INTEGER (0..127),
            rep512                              INTEGER (0..255),
            rep1024                             INTEGER (0..511),
            rep2048                             INTEGER (0..1023),
            rep4096                             INTEGER (0..2047)
        },
        sib-PosOffsetInfo                   SibOFF-List                     OPTIONAL
    }
}

SchedulingInformationSIB ::=            SEQUENCE {
    sib-Type                            SIB-TypeAndTag,
    scheduling                          SchedulingInformation
}

SchedulingInformationSIBSb ::=          SEQUENCE {
    sibSb-Type                          SIBSb-TypeAndTag,
    scheduling                          SchedulingInformation
}

SegCount ::=                        INTEGER (1..16)

SegmentIndex ::=                    INTEGER (1..15)

-- Actual value SFN-Prime = 2 * IE value
SFN-Prime ::=                       INTEGER (0..2047)


SIB-Data-fixed ::=                  BIT STRING (SIZE (222))


SIB-Data-variable ::=               BIT STRING (SIZE (1..214))

SIBOccurIdentity ::=            INTEGER (0..15)

SIBOccurrenceIdentityAndValueTag ::=    SEQUENCE {
    sibOccurIdentity                SIBOccurIdentity,
    sibOccurValueTag                SIBOccurValueTag
}

SIBOccurValueTag ::=            INTEGER (0..15)

SIB-ReferenceList ::=               SEQUENCE (SIZE (1..maxSIB)) OF
                                        SchedulingInformationSIB

SIBSb-ReferenceList ::=             SEQUENCE (SIZE (1..maxSIB)) OF
                                        SchedulingInformationSIBSb

SIB-ReferenceListFACH ::=           SEQUENCE (SIZE (1..maxSIB-FACH)) OF
                                        SchedulingInformationSIB

SIB-Type ::=                        ENUMERATED {
                                        masterInformationBlock,
                                        systemInformationBlockType1,
                                        systemInformationBlockType2,
                                        systemInformationBlockType3,
                                        systemInformationBlockType4,
                                        systemInformationBlockType5,
                                        systemInformationBlockType6,
                                        systemInformationBlockType7,
        -- dummy, dummy2 and dummy3 are not used in this version of the specification,
        -- they should not be sent. If they are received they should be ignored
                                        dummy,
                                        dummy2,
                                        dummy3,
                                        systemInformationBlockType11,
                                        systemInformationBlockType12,
                                        systemInformationBlockType13,
                                        systemInformationBlockType13-1,
                                        systemInformationBlockType13-2,
                                        systemInformationBlockType13-3,
                                        systemInformationBlockType13-4,
                                        systemInformationBlockType14,
```

```
                                    systemInformationBlockType15,
                                    systemInformationBlockType15-1,
                                    systemInformationBlockType15-2,
                                    systemInformationBlockType15-3,
                                    systemInformationBlockType16,
                                    systemInformationBlockType17,
                                    systemInformationBlockType15-4,
                                    systemInformationBlockType18,
                                    schedulingBlock1,
                                    schedulingBlock2,
                                    systemInformationBlockType15-5,
                                    systemInformationBlockType5bis,
                                    spare1 }

SIB-TypeAndTag ::=                  CHOICE {
    sysInfoType1                        PLMN-ValueTag,
    sysInfoType2                        CellValueTag,
    sysInfoType3                        CellValueTag,
    sysInfoType4                        CellValueTag,
    sysInfoType5                        CellValueTag,
    sysInfoType6                        CellValueTag,
    sysInfoType7                        NULL,
    -- dummy, dummy2 and dummy3 are not used in this version of the specification,
    -- they should not be sent. If they are received they should be ignored
    dummy                               CellValueTag,
    dummy2                              NULL,
    dummy3                              NULL,
    sysInfoType11                       CellValueTag,
    sysInfoType12                       CellValueTag,
    sysInfoType13                       CellValueTag,
    sysInfoType13-1                     CellValueTag,
    sysInfoType13-2                     CellValueTag,
    sysInfoType13-3                     CellValueTag,
    sysInfoType13-4                     CellValueTag,
    sysInfoType14                       NULL,
    sysInfoType15                       CellValueTag,
    sysInfoType16                       PredefinedConfigIdentityAndValueTag,
    sysInfoType17                       NULL,
    sysInfoType15-1                     CellValueTag,
    sysInfoType15-2                     SIBOccurrenceIdentityAndValueTag,
    sysInfoType15-3                     SIBOccurrenceIdentityAndValueTag,
    sysInfoType15-4                     CellValueTag,
    sysInfoType18                       CellValueTag,
    sysInfoType15-5                     CellValueTag,
    sysInfoType5bis                     CellValueTag,
    spare4                              NULL,
    spare3                              NULL,
    spare2                              NULL,
    spare1                              NULL
}

SIBSb-TypeAndTag ::=                    CHOICE {
    sysInfoType1                        PLMN-ValueTag,
    sysInfoType2                        CellValueTag,
    sysInfoType3                        CellValueTag,
    sysInfoType4                        CellValueTag,
    sysInfoType5                        CellValueTag,
    sysInfoType6                        CellValueTag,
    sysInfoType7                        NULL,
    -- dummy, dummy2 and dummy3 are not used in this version of the specification,
    -- they should not be sent. If they are received they should be ignored
    dummy                               CellValueTag,
    dummy2                              NULL,
    dummy3                              NULL,
    sysInfoType11                       CellValueTag,
    sysInfoType12                       CellValueTag,
    sysInfoType13                       CellValueTag,
    sysInfoType13-1                     CellValueTag,
    sysInfoType13-2                     CellValueTag,
    sysInfoType13-3                     CellValueTag,
    sysInfoType13-4                     CellValueTag,
    sysInfoType14                       NULL,
    sysInfoType15                       CellValueTag,
    sysInfoType16                       PredefinedConfigIdentityAndValueTag,
    sysInfoType17                       NULL,
    sysInfoTypeSB1                      CellValueTag,
    sysInfoTypeSB2                      CellValueTag,
    sysInfoType15-1                     CellValueTag,
```

```
    sysInfoType15-2                     SIBOccurrenceIdentityAndValueTag,
    sysInfoType15-3                     SIBOccurrenceIdentityAndValueTag,
    sysInfoType15-4                     CellValueTag,
    sysInfoType18                       CellValueTag,
    sysInfoType15-5                     CellValueTag,
    sysInfoType5bis                     CellValueTag,
    spare2                              NULL,
    spare1                              NULL
}

SibOFF ::=                          ENUMERATED {
                                        so2, so4, so6, so8, so10,
                                        so12, so14, so16, so18,
                                        so20, so22, so24, so26,
                                        so28, so30, so32 }

SibOFF-List ::=                     SEQUENCE (SIZE (1..15)) OF
                                        SibOFF

SysInfoType1 ::=                    SEQUENCE {
    -- Core network IEs
        cn-CommonGSM-MAP-NAS-SysInfo    NAS-SystemInformationGSM-MAP,
        cn-DomainSysInfoList            CN-DomainSysInfoList,
    -- User equipment IEs
        ue-ConnTimersAndConstants       UE-ConnTimersAndConstants           OPTIONAL,
        ue-IdleTimersAndConstants       UE-IdleTimersAndConstants           OPTIONAL,
    -- Extension mechanism for non- release99 information
        v3a0NonCriticalExtensions       SEQUENCE {
            sysInfoType1-v3a0ext        SysInfoType1-v3a0ext-IEs,
            nonCriticalExtensions       SEQUENCE {} OPTIONAL
        }                           OPTIONAL
}

SysInfoType1-v3a0ext-IEs ::= SEQUENCE {
    ue-ConnTimersAndConstants-v3a0ext       UE-ConnTimersAndConstants-v3a0ext,
    ue-IdleTimersAndConstants-v3a0ext       UE-IdleTimersAndConstants-v3a0ext
}

SysInfoType2 ::=                    SEQUENCE {
    -- UTRAN mobility IEs
        ura-IdentityList                URA-IdentityList,
    -- Extension mechanism for non- release99 information
        nonCriticalExtensions           SEQUENCE {}                         OPTIONAL
}

SysInfoType3 ::=                    SEQUENCE {
        sib4indicator                   BOOLEAN,
    -- UTRAN mobility IEs
        cellIdentity                    CellIdentity,
        cellSelectReselectInfo          CellSelectReselectInfoSIB-3-4,
        cellAccessRestriction           CellAccessRestriction,
    -- Extension mechanism for non- release99 information
        v4b0NonCriticalExtensions       SEQUENCE {
            sysInfoType3-v4b0ext            SysInfoType3-v4b0ext-IEs,
            v590NonCriticalExtension        SEQUENCE {
                sysInfoType3-v590ext            SysInfoType3-v590ext,
                v5c0NoncriticalExtension        SEQUENCE {
                    sysInfoType3-v5c0ext            SysInfoType3-v5c0ext-IEs,
                    v670NonCriticalExtension            SEQUENCE {
                        sysInfoType3-v670ext                SysInfoType3-v670ext,
                        nonCriticalExtensions           SEQUENCE {}                 OPTIONAL
                    }                               OPTIONAL
                }                               OPTIONAL
            }                               OPTIONAL
        }                               OPTIONAL
}

SysInfoType3-v4b0ext-IEs ::= SEQUENCE {
    mapping-LCR                     Mapping-LCR-r4                          OPTIONAL
}

SysInfoType3-v590ext ::= SEQUENCE {
    cellSelectReselectInfo-v590ext      CellSelectReselectInfo-v590ext      OPTIONAL
}

SysInfoType3-v5c0ext-IEs ::= SEQUENCE {
    cellSelectReselectInfoTreselectionScaling-v5c0ext
                                        CellSelectReselectInfoTreselectionScaling-v5c0ext   OPTIONAL
```

```
}

SysInfoType3-v670ext ::= SEQUENCE {
        domainSpecificAccessRestrictionParametersForPLMNOfMIB
                                    DomainSpecificAccessRestrictionParam-v670ext    OPTIONAL,
        domainSpecificAccessRestictionForSharedNetwork
                                    DomainSpecificAccessRestrictionForSharedNetwork-v670ext OPTIONAL
}

SysInfoType4 ::=                    SEQUENCE {
    -- UTRAN mobility IEs
        cellIdentity                    CellIdentity,
        cellSelectReselectInfo          CellSelectReselectInfoSIB-3-4,
        cellAccessRestriction           CellAccessRestriction,
    -- Extension mechanism for non- release99 information
        v4b0NonCriticalExtensions       SEQUENCE {
            sysInfoType4-v4b0ext            SysInfoType4-v4b0ext-IEs,
            v590NonCriticalExtension        SEQUENCE {
                sysInfoType4-v590ext            SysInfoType4-v590ext,
                v5b0NonCriticalExtension        SEQUENCE {
                    sysInfoType4-v5b0ext            SysInfoType4-v5b0ext-IEs,
                    v5c0NonCriticalExtension            SEQUENCE {
                        sysInfoType4-v5c0ext                SysInfoType4-v5c0ext-IEs,
                        nonCriticalExtensions           SEQUENCE {}                     OPTIONAL
                    }   OPTIONAL
                }   OPTIONAL
            }   OPTIONAL
        }   OPTIONAL
}

SysInfoType4-v4b0ext-IEs ::= SEQUENCE {
    mapping-LCR                     Mapping-LCR-r4                          OPTIONAL
}


SysInfoType4-v590ext ::= SEQUENCE {
    cellSelectReselectInfo-v590ext      CellSelectReselectInfo-v590ext      OPTIONAL
}

SysInfoType4-v5b0ext-IEs ::= SEQUENCE {
    cellSelectReselectInfoPCHFACH-v5b0ext   CellSelectReselectInfoPCHFACH-v5b0ext       OPTIONAL
}

SysInfoType4-v5c0ext-IEs ::= SEQUENCE {
    cellSelectReselectInfoTreselectionScaling-v5c0ext
                                        CellSelectReselectInfoTreselectionScaling-v5c0ext   OPTIONAL
}

SysInfoType5 ::=                    SEQUENCE {
        sib6indicator                   BOOLEAN,
    -- Physical channel IEs
        pich-PowerOffset                PICH-PowerOffset,
        modeSpecificInfo                CHOICE {
            fdd                             SEQUENCE {
                aich-PowerOffset                AICH-PowerOffset
            },
            tdd                             SEQUENCE {
    -- If PDSCH/PUSCH is configured for 1.28Mcps TDD, the following IEs should be absent
    --   and the info included in the tdd128SpecificInfo instead.
    -- If PDSCH/PUSCH is configured for 3.84Mcps TDD in R5, HCR-r5-SpecificInfo should also be
    -- included.
                pusch-SysInfoList-SFN           PUSCH-SysInfoList-SFN       OPTIONAL,
                pdsch-SysInfoList-SFN           PDSCH-SysInfoList-SFN       OPTIONAL,
                openLoopPowerControl-TDD        OpenLoopPowerControl-TDD
            }
        },
        primaryCCPCH-Info               PrimaryCCPCH-Info                   OPTIONAL,
        prach-SystemInformationList     PRACH-SystemInformationList,
        sCCPCH-SystemInformationList    SCCPCH-SystemInformationList,
        -- cbs-DRX-Level1Information is conditional on any of the CTCH indicator IEs in
        -- sCCPCH-SystemInformationList
        cbs-DRX-Level1Information       CBS-DRX-Level1Information           OPTIONAL,
    -- Extension mechanism for non- release99 information
        v4b0NonCriticalExtensions       SEQUENCE {
            sysInfoType5-v4b0ext            SysInfoType5-v4b0ext-IEs        OPTIONAL,
        -- Extension mechanism for non- rel-4 information
            v590NonCriticalExtensions       SEQUENCE {
                sysInfoType5-v590ext            SysInfoType5-v590ext-IEs        OPTIONAL,
```

```
                v650NonCriticalExtensions       SEQUENCE {
                    sysInfoType5-v650ext            SysInfoType5-v650ext-IEs        OPTIONAL,
                    v680NonCriticalExtensions       SEQUENCE {
                        sysInfoType5-v680ext            SysInfoType5-v680ext-IEs        OPTIONAL,
                        v690NonCriticalExtensions       SEQUENCE {
                            sysInfoType5-v690ext            SysInfoType5-v690ext-IEs,
                            v7xyNonCriticalExtensions       SEQUENCE {
                                sysInfoType5-v7xyext            SysInfoType5-v7xyext-IEs,
                                nonCriticalExtensions           SEQUENCE {}             OPTIONAL
                            }       OPTIONAL
                        }       OPTIONAL
                    }       OPTIONAL
                }       OPTIONAL
            }       OPTIONAL
        }       OPTIONAL
}

SysInfoType5-v4b0ext-IEs ::= SEQUENCE {
    --The following IE PNBSCH-Allocation-r4 shall be used for 3.84Mcps TDD only.
    pNBSCH-Allocation-r4            PNBSCH-Allocation-r4            OPTIONAL,
    -- In case of TDD, the following IE is included instead of the
    -- IE up-IPDL-Parameter in up-OTDOA-AssistanceData.
    openLoopPowerControl-IPDL-TDD   OpenLoopPowerControl-IPDL-TDD-r4    OPTIONAL,
-- If SysInfoType5 is sent to describe a 1.28Mcps TDD cell, the IE PRACH-RACH-Info included in
-- PRACH-SystemInformationList shall be ignored, the IE PRACH-Partitioning and the
-- IE rach-TransportFormatSet shall be absent and the corresponding IE in the following
-- PRACH-SystemInformationList-LCR-r4 shall be used
    prach-SystemInformationList-LCR-r4  PRACH-SystemInformationList-LCR-r4  OPTIONAL,
    tdd128SpecificInfo              SEQUENCE {
        pusch-SysInfoList-SFN           PUSCH-SysInfoList-SFN-LCR-r4    OPTIONAL,
        pdsch-SysInfoList-SFN           PDSCH-SysInfoList-SFN-LCR-r4    OPTIONAL,
        pCCPCH-LCR-Extensions           PrimaryCCPCH-Info-LCR-r4-ext    OPTIONAL,
        sCCPCH-LCR-ExtensionsList       SCCPCH-SystemInformationList-LCR-r4-ext
    }                                                                   OPTIONAL,
    frequencyBandIndicator          RadioFrequencyBandFDD           OPTIONAL
}

SysInfoType5-v590ext-IEs ::= SEQUENCE {
    hcr-r5-SpecificInfo             SEQUENCE {
        pusch-SysInfoList-SFN           PUSCH-SysInfoList-SFN-HCR-r5    OPTIONAL,
        pdsch-SysInfoList-SFN           PDSCH-SysInfoList-SFN-HCR-r5    OPTIONAL
    }                                                                   OPTIONAL
}

SysInfoType5-v650ext-IEs ::= SEQUENCE {
    frequencyBandIndicator2         RadioFrequencyBandFDD2
}

SysInfoType5-v680ext-IEs ::= SEQUENCE {
    -- TABULAR: HSDPA Cell Indicator is MD in tabular description
    -- Default value is "HSDPA Capability not indicated"
    hsdpa-CellIndicator     ENUMERATED { hsdpa-CapableCell }            OPTIONAL
}

SysInfoType5-v690ext-IEs ::=        SEQUENCE {
    -- TABULAR: E-DCH Cell Indicator is MD in tabular description
    -- Default value is "E-DCH Capability not indicated"
    edch-CellIndicator                  ENUMERATED { edch-CapableCell }     OPTIONAL,
    sccpch-SystemInformation-MBMS       CHOICE {
        mcchOnSCCPCHusedForNonMBMS          MBMS-MCCH-ConfigurationInfo-r6,
        mcchOnSCCPCHusedOnlyForMBMS         SCCPCH-SystemInformation-MBMS-r6
    }       OPTIONAL,
    additionalPRACH-TF-and-TFCS-CCCH-List   AdditionalPRACH-TF-and-TFCS-CCCH-List   OPTIONAL,
    cBS-DRX-Level1Information-extension     CBS-DRX-Level1Information-extension-r6  OPTIONAL
}

SysInfoType5-v7xyext-IEs ::=        SEQUENCE {
    pusch-SysInfoList-SFN-VHCR          PUSCH-SysInfoList-SFN-VHCR      OPTIONAL,
    prach-SystemInformationList-r7      PRACH-SystemInformationList-r7  OPTIONAL,
    pdsch-SysInfoList-SFN-r7            PDSCH-SysInfoList-r7            OPTIONAL,
    sccpch-SystemInformation-MBMS       CHOICE {
        mcchOnSCCPCHusedForNonMBMS          MBMS-MCCH-ConfigurationInfo-r6,
        mcchOnSCCPCHusedOnlyForMBMS         SCCPCH-SystemInformation-MBMS-r7
    }       OPTIONAL,
    sCCPCH-SystemInformationList-r7     SCCPCH-SystemInformationList-r7 OPTIONAL
}
```

```
-- SysInfoType5bis uses the same structure as SysInfoType5
SysInfoType5bis ::= SysInfoType5

SysInfoType6 ::=                    SEQUENCE {
    -- Physical channel IEs
        pich-PowerOffset                PICH-PowerOffset,
        modeSpecificInfo                CHOICE {
            fdd                             SEQUENCE {
                aich-PowerOffset                AICH-PowerOffset,
                -- dummy is not used in this version of specification, it should
                -- not be sent and if received it should be ignored.
                dummy                           CSICH-PowerOffset           OPTIONAL
            },
            tdd                             SEQUENCE {
                -- If PDSCH/PUSCH is configured for 1.28Mcps TDD, pusch-SysInfoList-SFN,
                -- pdsch-SysInfoList-SFN and openLoopPowerControl-TDD should be absent
                -- and the info included in the tdd128SpecificInfo instead.
                -- If PDSCH/PUSCH is configured for 3.84Mcps TDD in R5, HCR-r5-SpecificInfo should
                -- also be included.
                pusch-SysInfoList-SFN           PUSCH-SysInfoList-SFN       OPTIONAL,
                pdsch-SysInfoList-SFN           PDSCH-SysInfoList-SFN       OPTIONAL,
                openLoopPowerControl-TDD        OpenLoopPowerControl-TDD
            }
        },
        primaryCCPCH-Info               PrimaryCCPCH-Info                   OPTIONAL,
        prach-SystemInformationList     PRACH-SystemInformationList         OPTIONAL,
        sCCPCH-SystemInformationList    SCCPCH-SystemInformationList        OPTIONAL,
        cbs-DRX-Level1Information       CBS-DRX-Level1Information           OPTIONAL,
        -- Conditional on any of the CTCH indicator IEs in
        -- sCCPCH-SystemInformationList
    -- Extension mechanism for non- release99 information
        v4b0NonCriticalExtensions       SEQUENCE {
            sysInfoType6-v4b0ext            SysInfoType6-v4b0ext-IEs        OPTIONAL,
        -- Extension mechanism for non- rel-4 information
            v590NonCriticalExtensions   SEQUENCE {
                sysInfoType6-v590ext            SysInfoType6-v590ext-IEs        OPTIONAL,
                v650nonCriticalExtensions       SEQUENCE {
                    sysInfoType6-v650ext            SysInfoType6-v650ext-IEs        OPTIONAL,
                    v690nonCriticalExtensions       SEQUENCE {
                        sysInfoType6-v690ext            SysInfoType6-v690ext-IEs,
                        v7xyNonCriticalExtensions       SEQUENCE {
                            sysInfoType6-v7xyext            SysInfoType6-v7xyext-IEs,
                            nonCriticalExtensions           SEQUENCE {}                 OPTIONAL
                        }   OPTIONAL
                    }                               OPTIONAL
                }                               OPTIONAL
            }                               OPTIONAL
        }                           OPTIONAL
}

SysInfoType6-v4b0ext-IEs ::= SEQUENCE {
    -- openLoopPowerControl-IPDL-TDD is present only if IPDLs are applied for TDD
    openLoopPowerControl-IPDL-TDD   OpenLoopPowerControl-IPDL-TDD-r4    OPTIONAL,
    -- If SysInfoType6 is sent to describe a 1.28Mcps TDD cell, the IE PRACH-RACH-Info included
    -- in PRACH-SystemInformationList shall be ignored, the IE PRACH-Partitioning and the
    -- IE rach-TransportFormatSet shall be absent and the corresponding IEs in the following
    -- PRACH-SystemInformationList-LCR-r4 shall be used
    prach-SystemInformationList-LCR-r4  PRACH-SystemInformationList-LCR-r4  OPTIONAL,
    tdd128SpecificInfo              SEQUENCE {
        pusch-SysInfoList-SFN           PUSCH-SysInfoList-SFN-LCR-r4    OPTIONAL,
        pdsch-SysInfoList-SFN           PDSCH-SysInfoList-SFN-LCR-r4    OPTIONAL,
        pCCPCH-LCR-Extensions           PrimaryCCPCH-Info-LCR-r4-ext    OPTIONAL,
        sCCPCH-LCR-ExtensionsList       SCCPCH-SystemInformationList-LCR-r4-ext OPTIONAL
    }                                                                   OPTIONAL,
    frequencyBandIndicator          RadioFrequencyBandFDD               OPTIONAL
}

SysInfoType6-v590ext-IEs ::= SEQUENCE {
    hcr-r5-SpecificInfo             SEQUENCE {
        pusch-SysInfoList-SFN           PUSCH-SysInfoList-SFN-HCR-r5    OPTIONAL,
        pdsch-SysInfoList-SFN           PDSCH-SysInfoList-SFN-HCR-r5    OPTIONAL
    }                                                                   OPTIONAL
}

SysInfoType6-v650ext-IEs ::= SEQUENCE {
    frequencyBandIndicator2         RadioFrequencyBandFDD2
}
```

```
SysInfoType6-v690ext-IEs ::= SEQUENCE {
    additionalPRACH-TF-and-TFCS-CCCH-List   AdditionalPRACH-TF-and-TFCS-CCCH-List   OPTIONAL
}

SysInfoType6-v7xyext-IEs ::=        SEQUENCE {
    pusch-SysInfoList-SFN-VHCR          PUSCH-SysInfoList-SFN-VHCR      OPTIONAL,
    pdsch-SysInfoList-SFN-r7            PDSCH-SysInfoList-r7            OPTIONAL,
    prach-SystemInformationList-r7      PRACH-SystemInformationList-r7  OPTIONAL,
    sCCPCH-SystemInformationList-r7     SCCPCH-SystemInformationList-r7 OPTIONAL
}

SysInfoType7 ::=                    SEQUENCE {
    -- Physical channel IEs
        modeSpecificInfo                CHOICE {
            fdd                             SEQUENCE {
                ul-Interference                 UL-Interference
            },
            tdd                             NULL
        },
        prach-Information-SIB5-List     DynamicPersistenceLevelList,
        prach-Information-SIB6-List     DynamicPersistenceLevelList         OPTIONAL,
        expirationTimeFactor            ExpirationTimeFactor                OPTIONAL,
    -- Extension mechanism for non- release99 information
        nonCriticalExtensions           SEQUENCE {}                         OPTIONAL
}

-- This IE is not used in this version of the specification.
-- It was kept only for backwards compatibility reasons
SysInfoType8 ::=                    SEQUENCE {
    -- User equipment IEs
        -- dummy1, dummy2, dummy3 are not used in this version of the specification and
        -- they should be ignored by the receiver.
        dummy1                          CPCH-Parameters,
    -- Physical channel IEs
        dummy2                          CPCH-SetInfoList,
        dummy3                          CSICH-PowerOffset,
    -- Extension mechanism for non- release99 information
        nonCriticalExtensions           SEQUENCE {}                         OPTIONAL
}

-- This IE is not used in this version of the specification.
-- It was kept only for backwards compatibility reasons
SysInfoType9 ::=                    SEQUENCE {
    -- Physical channel IEs
        -- dummy is not used in this version of the specification and
        -- it should be ignored by the receiver.
        dummy                           CPCH-PersistenceLevelsList,
    -- Extension mechanism for non- release99 information
        nonCriticalExtensions           SEQUENCE {}                         OPTIONAL
}

-- This IE is not used in this version of the specification.
-- It was kept only for backwards compatibility reasons
SysInfoType10 ::=                   SEQUENCE {
    -- User equipment IEs
        -- dummy is not used in this version of the specification, it should
        -- not be sent and if received it should be ignored.
        dummy                           DRAC-SysInfoList,
    -- Extension mechanism for non- release99 information
        nonCriticalExtensions           SEQUENCE {}                         OPTIONAL
}

SysInfoType11 ::=                   SEQUENCE {
        sib12indicator                  BOOLEAN,
    -- Measurement IEs
        fach-MeasurementOccasionInfo    FACH-MeasurementOccasionInfo        OPTIONAL,
        measurementControlSysInfo       MeasurementControlSysInfo,
    -- Extension mechanism for non- release99 information
        v4b0NonCriticalExtensions       SEQUENCE {
            sysInfoType11-v4b0ext           SysInfoType11-v4b0ext-IEs       OPTIONAL,
            v590NonCriticalExtension        SEQUENCE {
                sysInfoType11-v590ext           SysInfoType11-v590ext-IEs,
                v690NonCriticalExtensions           SEQUENCE {
                    sysInfoType11-v690ext           SysInfoType11-v690ext-IEs,
                    nonCriticalExtensions           SEQUENCE {}                     OPTIONAL
                }                               OPTIONAL
            }                               OPTIONAL
        }                               OPTIONAL
```

```
}

SysInfoType11-v4b0ext-IEs ::= SEQUENCE {
    fach-MeasurementOccasionInfo-LCR-Ext    FACH-MeasurementOccasionInfo-LCR-r4-ext OPTIONAL,
    measurementControlSysInfo-LCR           MeasurementControlSysInfo-LCR-r4-ext
}

SysInfoType11-v590ext-IEs ::= SEQUENCE {
    --The order of the list corresponds to the order of cell in newIntraFrequencyCellInfoList
    newIntraFrequencyCellInfoList-v590ext   SEQUENCE (SIZE (1..maxCellMeas)) OF
                                                CellSelectReselectInfo-v590ext  OPTIONAL,
    --The order of the list corresponds to the order of cell in newInterFrequencyCellInfoList
    newInterFrequencyCellInfoList-v590ext   SEQUENCE (SIZE (1..maxCellMeas)) OF
                                                CellSelectReselectInfo-v590ext  OPTIONAL,
    --The order of the list corresponds to the order of cell in newInterRATCellInfoList
    newInterRATCellInfoList-v590ext         SEQUENCE (SIZE (1..maxCellMeas)) OF
                                                CellSelectReselectInfo-v590ext  OPTIONAL,
    intraFreqEventCriteriaList-v590ext      Intra-FreqEventCriteriaList-v590ext     OPTIONAL,
    intraFreqReportingCriteria-1b-r5        IntraFreqReportingCriteria-1b-r5    OPTIONAL,
    intraFreqEvent-1d-r5                    IntraFreqEvent-1d-r5                OPTIONAL
}

SysInfoType11-v690ext-IEs ::= SEQUENCE {
    -- Measurement IEs
    interFreqRACHReportingInfo          InterFreqRACHReportingInfo          OPTIONAL
}

SysInfoType12 ::=                   SEQUENCE {
    -- Measurement IEs
        fach-MeasurementOccasionInfo    FACH-MeasurementOccasionInfo        OPTIONAL,
        measurementControlSysInfo       MeasurementControlSysInfo,
    -- Extension mechanism for non- release99 information
        v4b0NonCriticalExtensions       SEQUENCE {
            sysInfoType12-v4b0ext           SysInfoType12-v4b0ext-IEs       OPTIONAL,
            v590NonCriticalExtension        SEQUENCE {
                sysInfoType12-v590ext           SysInfoType12-v590ext-IEs,
                v690NonCriticalExtensions           SEQUENCE {
                    sysInfoType12-v690ext           SysInfoType12-v690ext-IEs,
                    nonCriticalExtensions           SEQUENCE {}                     OPTIONAL
                }                               OPTIONAL
            }                               OPTIONAL
        }                               OPTIONAL
}

SysInfoType12-v4b0ext-IEs ::= SEQUENCE {
    fach-MeasurementOccasionInfo-LCR-Ext    FACH-MeasurementOccasionInfo-LCR-r4-ext OPTIONAL,
    measurementControlSysInfo-LCR           MeasurementControlSysInfo-LCR-r4-ext
}

SysInfoType12-v590ext-IEs ::= SEQUENCE {
    --The order of the list corresponds to the order of cell in newIntraFrequencyCellInfoList
    newIntraFrequencyCellInfoList-v590ext   SEQUENCE (SIZE (1..maxCellMeas)) OF
                                                CellSelectReselectInfo-v590ext  OPTIONAL,
    --The order of the list corresponds to the order of cell in newInterFrequencyCellInfoList
    newInterFrequencyCellInfoList-v590ext   SEQUENCE (SIZE (1..maxCellMeas)) OF
                                                CellSelectReselectInfo-v590ext  OPTIONAL,
    --The order of the list corresponds to the order of cell in newInterRATCellInfoList
    newInterRATCellInfoList-v590ext         SEQUENCE (SIZE (1..maxCellMeas)) OF
                                                CellSelectReselectInfo-v590ext  OPTIONAL,
    intraFreqEventCriteriaList-v590ext      Intra-FreqEventCriteriaList-v590ext     OPTIONAL,
    intraFreqReportingCriteria-1b-r5        IntraFreqReportingCriteria-1b-r5    OPTIONAL,
    intraFreqEvent-1d-r5                    IntraFreqEvent-1d-r5                OPTIONAL
}

SysInfoType12-v690ext-IEs ::= SEQUENCE {
    -- Measurement IEs
    interFreqRACHReportingInfo          InterFreqRACHReportingInfo          OPTIONAL
}

SysInfoType13 ::=                   SEQUENCE {
    -- Core network IEs
        cn-DomainSysInfoList            CN-DomainSysInfoList,
    -- User equipment IEs
        ue-IdleTimersAndConstants       UE-IdleTimersAndConstants           OPTIONAL,
        capabilityUpdateRequirement     CapabilityUpdateRequirement         OPTIONAL,
    -- Extension mechanism for non- release99 information
        v3a0NonCriticalExtensions           SEQUENCE {
            sysInfoType13-v3a0ext           SysInfoType13-v3a0ext-IEs,
```

```
            v4b0NonCriticalExtensions       SEQUENCE {
                sysInfoType13-v4b0ext           SysInfoType13-v4b0ext-IEs,
            -- Extension mechanism for non- release99 information
                v7xyNonCriticalExtensions       SEQUENCE {
                    sysInfoType13-v7xyext           SysInfoType13-v7xyext-IEs,
                    nonCriticalExtensions           SEQUENCE {}                     OPTIONAL
                }                               OPTIONAL
            }                               OPTIONAL
        }                               OPTIONAL
}

SysInfoType13-v3a0ext-IEs ::= SEQUENCE {
    ue-IdleTimersAndConstants-v3a0ext       UE-IdleTimersAndConstants-v3a0ext
}

SysInfoType13-v4b0ext-IEs ::= SEQUENCE {
    capabilityUpdateRequirement-r4Ext   CapabilityUpdateRequirement-r4-ext  OPTIONAL
}

SysInfoType13-v7xyext-IEs ::= SEQUENCE {
    capabilityUpdateRequirement-r7Ext   CapabilityUpdateRequirement-r7-ext  OPTIONAL
}

SysInfoType13-1 ::=                 SEQUENCE {
    -- ANSI-41 IEs
        ansi-41-RAND-Information        ANSI-41-RAND-Information,
    -- Extension mechanism for non- release99 information
        nonCriticalExtensions           SEQUENCE {}                         OPTIONAL
}

SysInfoType13-2 ::=                 SEQUENCE {
    -- ANSI-41 IEs
        ansi-41-UserZoneID-Information  ANSI-41-UserZoneID-Information,
    -- Extension mechanism for non- release99 information
        nonCriticalExtensions           SEQUENCE {}                         OPTIONAL
}

SysInfoType13-3 ::=                 SEQUENCE {
    -- ANSI-41 IEs
        ansi-41-PrivateNeighbourListInfo ANSI-41-PrivateNeighbourListInfo,
    -- Extension mechanism for non- release99 information
        nonCriticalExtensions           SEQUENCE {}                         OPTIONAL
}

SysInfoType13-4 ::=                 SEQUENCE {
    -- ANSI-41 IEs
        ansi-41-GlobalServiceRedirectInfo
                                        ANSI-41-GlobalServiceRedirectInfo,
    -- Extension mechanism for non- release99 information
        nonCriticalExtensions           SEQUENCE {}                         OPTIONAL
}

SysInfoType14 ::=                   SEQUENCE {
    -- Physical channel IEs
        individualTS-InterferenceList   IndividualTS-InterferenceList,
        expirationTimeFactor            ExpirationTimeFactor                OPTIONAL,
    -- Extension mechanism for non- release99 information
        nonCriticalExtensions           SEQUENCE {}                         OPTIONAL
}

SysInfoType15 ::=                   SEQUENCE {
    -- Measurement IEs

        ue-positioning-GPS-CipherParameters     UE-Positioning-CipherParameters     OPTIONAL,
        ue-positioning-GPS-ReferenceLocation    ReferenceLocation,
        ue-positioning-GPS-ReferenceTime        UE-Positioning-GPS-ReferenceTime,

        ue-positioning-GPS-Real-timeIntegrity       BadSatList                          OPTIONAL,
    -- Extension mechanism for non- release99 information
        v4b0NonCriticalExtensions           SEQUENCE {
            sysInfoType15-v4b0ext               SysInfoType15-v4b0ext-IEs,
        -- Extension mechanism for non- release4 information
            nonCriticalExtensions               SEQUENCE {}             OPTIONAL
        }   OPTIONAL
}

SysInfoType15-v4b0ext-IEs ::= SEQUENCE {
    up-Ipdl-Parameters-TDD          UE-Positioning-IPDL-Parameters-TDD-r4-ext   OPTIONAL
```

```
}

SysInfoType15-1 ::=                 SEQUENCE {
    -- DGPS corrections
        ue-positioning-GPS-DGPS-Corrections         UE-Positioning-GPS-DGPS-Corrections,

    -- Extension mechanism for non- release99 information
        nonCriticalExtensions           SEQUENCE {}             OPTIONAL
}

SysInfoType15-2 ::=                 SEQUENCE {
    -- Ephemeris and clock corrections
        transmissionTOW                 INTEGER (0..604799),
        satID                           SatID,
        ephemerisParameter              EphemerisParameter,

    -- Extension mechanism for non- release99 information
        nonCriticalExtensions           SEQUENCE {}         OPTIONAL
}

SysInfoType15-3 ::=                 SEQUENCE {
    -- Almanac and other data
        transmissionTOW                 INTEGER (0.. 604799),
        ue-positioning-GPS-Almanac                  UE-Positioning-GPS-Almanac
    OPTIONAL,
        ue-positioning-GPS-IonosphericModel         UE-Positioning-GPS-IonosphericModel
    OPTIONAL,
        ue-positioning-GPS-UTC-Model                UE-Positioning-GPS-UTC-Model
    OPTIONAL,
        satMask                         BIT STRING (SIZE (1..32))   OPTIONAL,
        lsbTOW                          BIT STRING (SIZE (8))       OPTIONAL,
    -- Extension mechanism for non- release99 information
        nonCriticalExtensions           SEQUENCE {}                 OPTIONAL
}

SysInfoType15-4 ::=                 SEQUENCE {
    -- Measurement IEs
        ue-positioning-OTDOA-CipherParameters   UE-Positioning-CipherParameters         OPTIONAL,
        ue-positioning-OTDOA-AssistanceData     UE-Positioning-OTDOA-AssistanceData,
        v3a0NonCriticalExtensions           SEQUENCE {
            sysInfoType15-4-v3a0ext             SysInfoType15-4-v3a0ext,
        -- Extension mechanism for non- release99 information
            v4b0NonCriticalExtensions           SEQUENCE {
                sysInfoType15-4-v4b0ext             SysInfoType15-4-v4b0ext,
                nonCriticalExtensions               SEQUENCE {}     OPTIONAL
            }   OPTIONAL
        }   OPTIONAL
}

SysInfoType15-4-v3a0ext ::= SEQUENCE {
    sfn-Offset-Validity             SFN-Offset-Validity     OPTIONAL
}

SysInfoType15-4-v4b0ext ::= SEQUENCE {
    ue-Positioning-OTDOA-AssistanceData-r4ext   UE-Positioning-OTDOA-AssistanceData-r4ext   OPTIONAL
}

SysInfoType15-5 ::=                 SEQUENCE {
    -- Measurement IEs
        ue-positioning-OTDOA-AssistanceData-UEB     UE-Positioning-OTDOA-AssistanceData-UEB,
        v3a0NonCriticalExtensions           SEQUENCE {
            sysInfoType15-5-v3a0ext             SysInfoType15-5-v3a0ext,
        -- Extension mechanism for non- release99 information
            nonCriticalExtensions               SEQUENCE {}     OPTIONAL
        }   OPTIONAL
}

SysInfoType15-5-v3a0ext ::= SEQUENCE {
    sfn-Offset-Validity         SFN-Offset-Validity     OPTIONAL
}

SysInfoType16 ::=                   SEQUENCE {
    -- Radio bearer IEs
        preDefinedRadioConfiguration    PreDefRadioConfiguration,
    -- Extension mechanism for non- release99 information
        nonCriticalExtensions           SEQUENCE {}                         OPTIONAL
}
```

```
SysInfoType17 ::=                   SEQUENCE {
    -- Physical channel IEs
        -- If PDSCH/PUSCH is configured for 1.28Mcps TDD, pusch-SysInfoList and
        -- pdsch-SysInfoList should be absent and the info included in the
        -- tdd128SpecificInfo instead.
        -- If PDSCH/PUSCH is configured for 3.84Mcps TDD in R5, HCR-r5-SpecificInfo should also be
        -- included.
        pusch-SysInfoList               PUSCH-SysInfoList               OPTIONAL,
        pdsch-SysInfoList               PDSCH-SysInfoList               OPTIONAL,
    -- Extension mechanism for non- release99 information
        v4b0NonCriticalExtensions       SEQUENCE {
            sysInfoType17-v4b0ext           SysInfoType17-v4b0ext-IEs,
            v590NonCriticalExtensions   SEQUENCE {
                sysInfoType17-v590ext           SysInfoType17-v590ext-IEs       OPTIONAL,
                v7xyNonCriticalExtensions       SEQUENCE {
                    sysInfoType17-v7xyext           SysInfoType17-v7xyext-IEs,
                    nonCriticalExtensions           SEQUENCE {}             OPTIONAL
                }                           OPTIONAL
            }                           OPTIONAL
        }                           OPTIONAL
}

SysInfoType17-v4b0ext-IEs ::= SEQUENCE {
    tdd128SpecificInfo              SEQUENCE {
        pusch-SysInfoList               PUSCH-SysInfoList-LCR-r4        OPTIONAL,
        pdsch-SysInfoList               PDSCH-SysInfoList-LCR-r4        OPTIONAL
    }                                                                   OPTIONAL
}

SysInfoType17-v590ext-IEs ::= SEQUENCE {
    hcr-r5-SpecificInfo             SEQUENCE {
        pusch-SysInfoList           PUSCH-SysInfoList-HCR-r5    OPTIONAL,
        pdsch-SysInfoList           PDSCH-SysInfoList-HCR-r5    OPTIONAL
    }                                                           OPTIONAL
}

SysInfoType17-v7xyext-IEs ::=       SEQUENCE {
    pusch-SysInfoList-SFN-VHCR          PUSCH-SysInfoList-SFN-VHCR      OPTIONAL,
    pdsch-SysInfoList-r7                PDSCH-SysInfoList-r7            OPTIONAL
}

SysInfoType18 ::=                       SEQUENCE {
        idleModePLMNIdentities          PLMNIdentitiesOfNeighbourCells      OPTIONAL,
        connectedModePLMNIdentities PLMNIdentitiesOfNeighbourCells      OPTIONAL,
    -- Extension mechanism for non- release99 information
        nonCriticalExtensions           SEQUENCE {}     OPTIONAL
}

SysInfoTypeSB1 ::=                  SEQUENCE {
    -- Other IEs
        sib-ReferenceList               SIB-ReferenceList,
    -- Extension mechanism for non- release99 information
        nonCriticalExtensions           SEQUENCE {}                         OPTIONAL
}

SysInfoTypeSB2 ::=                  SEQUENCE {
    -- Other IEs
        sib-ReferenceList               SIB-ReferenceList,
    -- Extension mechanism for non- release99 information
        nonCriticalExtensions           SEQUENCE {}                         OPTIONAL
}

TDD-UMTS-Frequency-List ::=             SEQUENCE (SIZE (1..maxNumTDDFreqs)) OF
                                            FrequencyInfoTDD

-- **************************************************
--
--     ANSI-41 INFORMATION ELEMENTS (10.3.9)
--
-- **************************************************

ANSI-41-GlobalServiceRedirectInfo ::=   ANSI-41-NAS-Parameter
ANSI-41-PrivateNeighbourListInfo ::=    ANSI-41-NAS-Parameter
ANSI-41-RAND-Information ::=            ANSI-41-NAS-Parameter
ANSI-41-UserZoneID-Information ::=      ANSI-41-NAS-Parameter
ANSI-41-NAS-Parameter ::=               BIT STRING (SIZE (1..2048))

Min-P-REV ::=                           BIT STRING (SIZE (8))
```

```
NAS-SystemInformationANSI-41 ::=        ANSI-41-NAS-Parameter
NID ::=                                 BIT STRING (SIZE (16))

P-REV ::=                               BIT STRING (SIZE (8))

SID ::=                                 BIT STRING (SIZE (15))

-- **************************************************
--
--     MBMS INFORMATION ELEMENTS (10.3.9a)
--
-- **************************************************

MBMS-AccessProbabilityFactor ::=    ENUMERATED {
                                        apf0, apf32, apf64, apf96, apf128, apf160, apf192,
                                        apf224, apf256, apf288, apf320, apf352, apf384, apf416,
                                        apf448, apf480, apf512, apf544, apf576, apf608, apf640,
                                        apf672, apf704, apf736, apf768, apf800, apf832, apf864,
                                        apf896, apf928, apf960, apf1000 }

MBMS-CellGroupIdentity-r6 ::=       BIT STRING (SIZE (12))

MBMS-CommonCCTrChIdentity ::=       INTEGER (1..32)

MBMS-CommonPhyChIdentity ::=        INTEGER (1..32)

MBMS-CommonRBIdentity ::=           INTEGER (1..32)

MBMS-CommonRBInformation-r6 ::=     SEQUENCE {
    commonRBIdentity                    MBMS-CommonRBIdentity,
    pdcp-Info                           PDCP-Info-r4,
    rlc-Info                            RLC-Info-MTCH-r6
}

MBMS-CommonRBInformationList-r6 ::= SEQUENCE (SIZE (1..maxMBMS-CommonRB)) OF
                                        MBMS-CommonRBInformation-r6

MBMS-CommonTrChIdentity ::=         INTEGER (1..32)

MBMS-ConnectedModeCountingScope ::= SEQUENCE {
    countingForUraPCH                               BOOLEAN,
    countingForCellPCH                              BOOLEAN,
    countingForCellFACH                             BOOLEAN
}

MBMS-CurrentCell-SCCPCH-r6 ::=      SEQUENCE {
    sccpchIdentity                      MBMS-SCCPCHIdentity                 OPTIONAL,
    secondaryCCPCH-Info                 MBMS-CommonPhyChIdentity,
    softComb-TimingOffset               MBMS-SoftComb-TimingOffset          OPTIONAL,
    -- If the IE transpCh-InfoCommonForAllTrCh is absent, the default TFCS as specified
    -- in 14.10.1 applies
    transpCh-InfoCommonForAllTrCh       MBMS-CommonCCTrChIdentity           OPTIONAL,
    transpCHInformation                 MBMS-TrCHInformation-CurrList
}

MBMS-CurrentCell-SCCPCHList-r6 ::=  SEQUENCE (SIZE (1..maxSCCPCH)) OF
                                        MBMS-CurrentCell-SCCPCH-r6

MBMS-FACHCarryingMTCH-List ::=      SEQUENCE (SIZE (1..maxFACHPCH)) OF
                                            TransportFormatSet

MBMS-JoinedInformation-r6 ::=       SEQUENCE {
    p-TMSI                              P-TMSI-GSM-MAP                      OPTIONAL
}

MBMS-L1CombiningSchedule-32 ::=     SEQUENCE {
    -- Actual L1 combining schedule values (offset, start, duration) = IE value * 4
    cycleOffset                         INTEGER (0..7)                      OPTIONAL,
    mtch-L1CombiningPeriodList          SEQUENCE (SIZE (1..maxMBMS-L1CP)) OF SEQUENCE {
        periodStart                         INTEGER (0..7),
        periodDuration                      INTEGER (1..8)
    }
}

MBMS-L1CombiningSchedule-64 ::=     SEQUENCE {
    -- Actual L1 combining schedule values (offset, start, duration) = IE value * 4
    cycleOffset                         INTEGER (0..15)                     OPTIONAL,
```

```
    mtch-L1CombiningPeriodList          SEQUENCE (SIZE (1..maxMBMS-L1CP)) OF SEQUENCE {
        periodStart                         INTEGER (0..15),
        periodDuration                      INTEGER (1..16)
    }
}

MBMS-L1CombiningSchedule-128 ::=    SEQUENCE {
    -- Actual L1 combining schedule values (offset, start, duration) = IE value * 4
    cycleOffset                         INTEGER (0..31)                     OPTIONAL,
    mtch-L1CombiningPeriodList          SEQUENCE (SIZE (1..maxMBMS-L1CP)) OF SEQUENCE {
        periodStart                         INTEGER (0..31),
        periodDuration                      INTEGER (1..32)
    }
}

MBMS-L1CombiningSchedule-256 ::=    SEQUENCE {
    -- Actual L1 combining schedule values (offset, start, duration) = IE value * 4
    cycleOffset                         INTEGER (0..63)                     OPTIONAL,
    mtch-L1CombiningPeriodList          SEQUENCE (SIZE (1..maxMBMS-L1CP)) OF SEQUENCE {
        periodStart                         INTEGER (0..63),
        periodDuration                      INTEGER (1..64)
    }
}

MBMS-L1CombiningSchedule-512 ::=    SEQUENCE {
    -- Actual L1 combining schedule values (offset, start, duration) = IE value * 4
    cycleOffset                         INTEGER (0..127)                        OPTIONAL,
    mtch-L1CombiningPeriodList          SEQUENCE (SIZE (1..maxMBMS-L1CP)) OF SEQUENCE {
        periodStart                         INTEGER (0..127),
        periodDuration                      INTEGER (1..128)
    }
}

MBMS-L1CombiningSchedule-1024 ::=   SEQUENCE {
    -- Actual L1 combining schedule values (offset, start, duration) = IE value * 4
    cycleOffset                         INTEGER (0..255)                        OPTIONAL,
    mtch-L1CombiningPeriodList          SEQUENCE (SIZE (1..maxMBMS-L1CP)) OF SEQUENCE {
        periodStart                         INTEGER (0..255),
        periodDuration                      INTEGER (1..256)
    }
}

MBMS-L1CombiningSchedule ::=        CHOICE {
    cycleLength-32                      MBMS-L1CombiningSchedule-32,
    cycleLength-64                      MBMS-L1CombiningSchedule-64,
    cycleLength-128                     MBMS-L1CombiningSchedule-128,
    cycleLength-256                     MBMS-L1CombiningSchedule-256,
    cycleLength-512                     MBMS-L1CombiningSchedule-512,
    cycleLength-1024                    MBMS-L1CombiningSchedule-1024
}

MBMS-L1CombiningTransmTimeDiff ::=  INTEGER (0..3)

MBMS-L23Configuration ::=           CHOICE {
    sameAsCurrent                       SEQUENCE {
        currentCell-SCCPCH                  MBMS-SCCPCHIdentity,
        msch-ConfigurationInfo              MBMS-MSCH-ConfigurationInfo-r6      OPTIONAL
    },
    different                           SEQUENCE {
        -- If the IE transpCh-InfoCommonForAllTrCh is absent, the default TFCS as specified
        -- in 14.10.1 applies
        transpCh-InfoCommonForAllTrCh       MBMS-CommonCCTrChIdentity           OPTIONAL,
        transpCHInformation                 MBMS-TrCHInformation-NeighbList
    }
}

MBMS-LogicalChIdentity ::=          INTEGER (1..15)

MBMS-MCCH-ConfigurationInfo-r6 ::=  SEQUENCE {
    accessInfoPeriodCoefficient         INTEGER (0..3),
    repetitionPeriodCoefficient         INTEGER (0..3),
    modificationPeriodCoefficient       INTEGER (7..10),
    rlc-Info                            RLC-Info-MCCH-r6,
    tctf-Presence                       MBMS-TCTF-Presence                  OPTIONAL
}

MBMS-MICHConfigurationInfo-r6 ::=   SEQUENCE {
    michPowerOffset                     MBMS-MICHPowerOffset,
```

```
    mode                                CHOICE {
        fdd                                 SEQUENCE {
            channelisationCode256               ChannelisationCode256,
            ni-CountPerFrame                    MBMS-NI-CountPerFrame,
            sttd-Indicator                      BOOLEAN
        },
        tdd384                              SEQUENCE {
            timeslot                            TimeslotNumber,
            midambleShiftAndBurstType           MidambleShiftAndBurstType,
            channelisationCode                  DL-TS-ChannelisationCode,
            repetitionPeriodLengthOffset        RepPerLengthOffset-MICH     OPTIONAL,
            mbmsNotificationIndLength           MBMS-MICHNotificationIndLength  DEFAULT mn4
        },
        tdd128                              SEQUENCE {
            timeslot                            TimeslotNumber-LCR-r4,
            midambleShiftAndBurstType           MidambleShiftAndBurstType-LCR-r4,
            channelisationCodeList              SEQUENCE (SIZE (1..2)) OF
                                                    DL-TS-ChannelisationCode,
            repetitionPeriodLengthOffset        RepPerLengthOffset-MICH     OPTIONAL,
            mbmsNotificationIndLength           MBMS-MICHNotificationIndLength  DEFAULT mn4
        }
    }
}

MBMS-MICHConfigurationInfo-r7 ::=   SEQUENCE {
    michPowerOffset                     MBMS-MICHPowerOffset,
    mode                                CHOICE {
        fdd                                 SEQUENCE {
            channelisationCode256               ChannelisationCode256,
            ni-CountPerFrame                    MBMS-NI-CountPerFrame,
            sttd-Indicator                      BOOLEAN
        },
        tdd384                              SEQUENCE {
            timeslot                            TimeslotNumber,
            midambleShiftAndBurstType           MidambleShiftAndBurstType,
            channelisationCode                  DL-TS-ChannelisationCode,
            repetitionPeriodLengthOffset        RepPerLengthOffset-MICH     OPTIONAL,
            mbmsNotificationIndLength           MBMS-MICHNotificationIndLength  DEFAULT mn4
        },
        tdd768                              SEQUENCE {
            timeslot                            TimeslotNumber,
            midambleShiftAndBurstType           MidambleShiftAndBurstType-VHCR,
            channelisationCode                  DL-TS-ChannelisationCode,
            repetitionPeriodLengthOffset        RepPerLengthOffset-MICH     OPTIONAL,
            mbmsNotificationIndLength           MBMS-MICHNotificationIndLength  DEFAULT mn4
        },
        tdd128                              SEQUENCE {
            timeslot                            TimeslotNumber-LCR-r4,
            midambleShiftAndBurstType           MidambleShiftAndBurstType-LCR-r4,
            channelisationCodeList              SEQUENCE (SIZE (1..2)) OF
                                                    DL-TS-ChannelisationCode,
            repetitionPeriodLengthOffset        RepPerLengthOffset-MICH     OPTIONAL,
            mbmsNotificationIndLength           MBMS-MICHNotificationIndLength  DEFAULT mn4
        }
    }
}

MBMS-MICHNotificationIndLength ::=  ENUMERATED { mn4, mn8, mn16 }

MBMS-MICHPowerOffset ::=            INTEGER (-10..5)

MBMS-ModifedService-r6 ::=          SEQUENCE {
    mbms-TransmissionIdentity           MBMS-TransmissionIdentity,
    mbms-RequiredUEAction               MBMS-RequiredUEAction-Mod,
    mbms-PreferredFrequency             CHOICE {
        mcch                                MBMS-PFLIndex,
        dcch                                MBMS-PFLInfo
    }       OPTIONAL,
    mbms-DispersionIndicator            ENUMERATED { true }                 OPTIONAL,
    continueMCCHReading                 BOOLEAN
}

MBMS-ModifedServiceList-r6 ::=      SEQUENCE (SIZE (1..maxMBMSservModif)) OF
                                        MBMS-ModifedService-r6

MBMS-MSCH-ConfigurationInfo-r6 ::=  SEQUENCE {
    mschShedulingInfo                   MBMS-MSCHSchedulingInfo             OPTIONAL,
    rlc-Info                            RLC-Info-MSCH-r6                    OPTIONAL,
```

```
    tctf-Presence                       MBMS-TCTF-Presence                  OPTIONAL
}

MBMS-MSCHSchedulingInfo ::=         CHOICE {
    schedulingPeriod-32-Offset          INTEGER (0..31),
    schedulingPeriod-64-Offset          INTEGER (0..63),
    schedulingPeriod-128-Offset         INTEGER (0..127),
    schedulingPeriod-256-Offset         INTEGER (0..255),
    schedulingPeriod-512-Offset         INTEGER (0..511),
    schedulingPeriod-1024-Offset        INTEGER (0..1023)
}

MBMS-NeighbouringCellSCCPCH-r6 ::=  SEQUENCE {
    secondaryCCPCH-Info                 MBMS-CommonPhyChIdentity,
    secondaryCCPCHPwrOffsetDiff         MBMS-SCCPCHPwrOffsetDiff            OPTIONAL,
    layer1Combining                     CHOICE {
        fdd                                 SEQUENCE {
            softComb-TimingOffset               MBMS-SoftComb-TimingOffset,
            mbms-L1CombiningTransmTimeDiff      MBMS-L1CombiningTransmTimeDiff,
            mbms-L1CombiningSchedule            MBMS-L1CombiningSchedule    OPTIONAL
        },
        tdd                                 NULL
    }       OPTIONAL,
    mbms-L23Configuration               MBMS-L23Configuration
}

MBMS-NeighbouringCellSCCPCHList-r6 ::= SEQUENCE (SIZE (1..maxSCCPCH)) OF
                                        MBMS-NeighbouringCellSCCPCH-r6

MBMS-NI-CountPerFrame ::=           ENUMERATED { ni18, ni36, ni72, ni144 }

MBMS-NumberOfNeighbourCells-r6 ::=      INTEGER (0..32)

MBMS-PFLIndex ::=                   INTEGER (1..maxMBMS-Freq)

MBMS-PFLInfo ::=                    FrequencyInfo

MBMS-PhyChInformation-r6 ::=        SEQUENCE {
    mbms-CommonPhyChIdentity            MBMS-CommonPhyChIdentity,
    secondaryCCPCHInfo-MBMS             SecondaryCCPCHInfo-MBMS-r6
}

MBMS-PhyChInformationList-r6 ::=    SEQUENCE (SIZE (1..maxMBMS-CommonPhyCh)) OF
                                        MBMS-PhyChInformation-r6

MBMS-PL-ServiceRestrictInfo-r6 ::=  ENUMERATED { true }

MBMS-PreferredFreqRequest-r6 ::=    SEQUENCE {
    preferredFreqRequest                FrequencyInfo
}

MBMS-PreferredFrequencyInfo-r6 ::=  SEQUENCE {
    mbmsPreferredFrequency              INTEGER (1..maxMBMS-Freq)           OPTIONAL,
    layerConvergenceInformation         CHOICE {
        mbms-Qoffset                        MBMS-Qoffset,
        mbms-HCSoffset                      INTEGER (0..7)
    },
    mbms-PL-ServiceRestrictInfo         MBMS-PL-ServiceRestrictInfo-r6      OPTIONAL
}

MBMS-PreferredFrequencyList-r6 ::=  SEQUENCE (SIZE (1..maxMBMS-Freq)) OF
                                        MBMS-PreferredFrequencyInfo-r6

MBMS-PTMActivationTime-r6 ::=       INTEGER (0..2047)

MBMS-PTM-RBInformation-C ::=        SEQUENCE {
    rbInformation                       MBMS-CommonRBIdentity,
    shortTransmissionID                 MBMS-ShortTransmissionID,
    logicalChIdentity                   MBMS-LogicalChIdentity
}

MBMS-PTM-RBInformation-CList ::=    SEQUENCE (SIZE (1..maxRBperTrCh)) OF
                                        MBMS-PTM-RBInformation-C

MBMS-PTM-RBInformation-N ::=        SEQUENCE {
    shortTransmissionID                 MBMS-ShortTransmissionID,
    logicalChIdentity                   MBMS-LogicalChIdentity,
    layer1-CombiningStatus              BOOLEAN}
```

```
MBMS-PTM-RBInformation-NList ::=    SEQUENCE (SIZE (1..maxRBperTrCh)) OF
                                        MBMS-PTM-RBInformation-N

MBMS-Qoffset ::=                    ENUMERATED { q4, q8, q12, q16, q20, q30, q40, qInfinity }

MBMS-RequiredUEAction-Mod ::=       ENUMERATED {
                                        none,
                                        acquireCountingInfo,
                                        acquireCountingInfoPTM-RBsUnmodified,
                                        acquirePTM-RBInfo,
                                        requestPTPRB,
                                        releasePTM-RB }

MBMS-RequiredUEAction-UMod ::=      ENUMERATED {
                                        none,
                                        acquirePTM-RBInfo,
                                        requestPTPRB }

MBMS-SCCPCHIdentity ::=             INTEGER (1..maxSCCPCH)

MBMS-SCCPCHPwrOffsetDiff ::=        ENUMERATED { mcpo-minus6, mcpo-minus3, mcpo-plus3, mcpo-plus6 }

MBMS-ServiceAccessInfo-r6 ::=       SEQUENCE {
    shortTransmissionID                 MBMS-ShortTransmissionID,
    accessprobabilityFactor-Idle        MBMS-AccessProbabilityFactor,
    accessprobabilityFactor-UraPCH      MBMS-AccessProbabilityFactor        OPTIONAL,
    mbms-ConnectedModeCountingScope     MBMS-ConnectedModeCountingScope
}

MBMS-ServiceAccessInfoList-r6 ::=   SEQUENCE (SIZE (1..maxMBMSservCount)) OF
                                        MBMS-ServiceAccessInfo-r6

MBMS-ServiceIdentity-r6 ::=         SEQUENCE {
    serviceIdentity                     OCTET STRING (SIZE (3)),
    plmn-Identity                       CHOICE {
        -- The 'sameAsMIB-PLMN-Id' choice refers to the 'PLMN Identity' (R99) in MIB.
        sameAsMIB-PLMN-Id                   NULL,
        other                               CHOICE {
            -- The 'sameAsMIB-MultiPLMN-Id' choice refers to one of the (1..5) PLMN Identities
            -- provided in the 'Multiple PLMN List' (REL-6) in MIB.
            sameAsMIB-MultiPLMN-Id              INTEGER (1..5),
            explicitPLMN-Id                     PLMN-Identity
        }
    }
}

MBMS-ServiceSchedulingInfo-r6 ::=   SEQUENCE {
    mbms-TransmissionIdentity           MBMS-TransmissionIdentity,
    mbms-ServiceTransmInfoList          MBMS-ServiceTransmInfoList          OPTIONAL,
    nextSchedulingperiod                INTEGER (0..31)
}

MBMS-ServiceSchedulingInfoList-r6 ::= SEQUENCE (SIZE (1..maxMBMSservSched)) OF
                                        MBMS-ServiceSchedulingInfo-r6

MBMS-ServiceTransmInfo ::=          SEQUENCE {
    -- Actual values (start, duration) = IE values * 4
    start                               INTEGER (0..255),
    duration                            INTEGER (1..256)
}

MBMS-ServiceTransmInfoList ::=      SEQUENCE (SIZE (1..maxMBMSTransmis)) OF
                                        MBMS-ServiceTransmInfo

MBMS-SessionIdentity ::=            OCTET STRING (SIZE (1))

MBMS-ShortTransmissionID ::=        INTEGER (1..maxMBMSservUnmodif)

MBMS-SIBType5-SCCPCH-r6 ::=         SEQUENCE {
    sccpchIdentity                      MBMS-SCCPCHIdentity,
    transpCHInformation                 MBMS-TrCHInformation-SIB5List
}

MBMS-SIBType5-SCCPCHList-r6 ::=     SEQUENCE (SIZE (1..maxSCCPCH)) OF
                                        MBMS-SIBType5-SCCPCH-r6

MBMS-SoftComb-TimingOffset ::=      ENUMERATED { ms0, ms10, ms20, ms40 }
```

```
MBMS-TCTF-Presence ::=              ENUMERATED { false }

MBMS-TimersAndCounters-r6 ::=       SEQUENCE {
    t-318                               T-318                               DEFAULT ms1000
}

MBMS-TransmissionIdentity ::=       SEQUENCE {
    mbms-ServiceIdentity                MBMS-ServiceIdentity-r6,
    mbms-SessionIdentity                MBMS-SessionIdentity                OPTIONAL
}

MBMS-TranspChInfoForCCTrCh-r6 ::=   SEQUENCE {
    commonCCTrChIdentity                MBMS-CommonCCTrChIdentity,
    transportFormatCombinationSet       TFCS
}


MBMS-TranspChInfoForEachCCTrCh-r6 ::= SEQUENCE (SIZE (1..maxMBMS-CommonCCTrCh)) OF
                                    MBMS-TranspChInfoForCCTrCh-r6

MBMS-TranspChInfoForEachTrCh-r6 ::= SEQUENCE (SIZE (1..maxMBMS-CommonTrCh)) OF
                                    MBMS-TranspChInfoForTrCh-r6

MBMS-TranspChInfoForTrCh-r6 ::=     SEQUENCE {
    commonTrChIdentity                  MBMS-CommonTrChIdentity,
    transportFormatSet                  TransportFormatSet
}

MBMS-TrCHInformation-Curr ::=       SEQUENCE {
    transpCh-Info                       MBMS-CommonTrChIdentity,
    rbInformation                       MBMS-PTM-RBInformation-CList        OPTIONAL,
    msch-ConfigurationInfo              MBMS-MSCH-ConfigurationInfo-r6      OPTIONAL
}

MBMS-TrCHInformation-CurrList ::=   SEQUENCE (SIZE (1..maxFACHPCH)) OF
                                    MBMS-TrCHInformation-Curr

MBMS-TrCHInformation-Neighb ::=     SEQUENCE {
    transpCh-Info                       MBMS-CommonTrChIdentity,
    transpCh-CombiningStatus            BOOLEAN,
    rbInformation                       MBMS-PTM-RBInformation-NList        OPTIONAL,
    msch-ConfigurationInfo              MBMS-MSCH-ConfigurationInfo-r6      OPTIONAL
}

MBMS-TrCHInformation-NeighbList ::= SEQUENCE (SIZE (1..maxFACHPCH)) OF
                                    MBMS-TrCHInformation-Neighb

MBMS-TrCHInformation-SIB5 ::=       SEQUENCE {
    transpCh-Identity                   INTEGER (1..maxFACHPCH),
    rbInformation                       MBMS-PTM-RBInformation-CList        OPTIONAL,
    msch-ConfigurationInfo              MBMS-MSCH-ConfigurationInfo-r6      OPTIONAL
}

MBMS-TrCHInformation-SIB5List ::=   SEQUENCE (SIZE (1..maxFACHPCH)) OF
                                    MBMS-TrCHInformation-SIB5

MBMS-UnmodifiedService-r6 ::=       SEQUENCE {
    mbms-TransmissionIdentity           MBMS-TransmissionIdentity,
    mbms-RequiredUEAction               MBMS-RequiredUEAction-UMod,
    mbms-PreferredFrequency             MBMS-PFLIndex                       OPTIONAL
}

MBMS-UnmodifiedServiceList-r6 ::=   SEQUENCE (SIZE (1..maxMBMSservUnmodif)) OF
                                    MBMS-UnmodifiedService-r6

END
```

## 11.4 Constant definitions

```
Constant-definitions DEFINITIONS AUTOMATIC TAGS ::=

BEGIN

hiPDSCHidentities           INTEGER ::= 64
hiPUSCHidentities           INTEGER ::= 64
hiRM                        INTEGER ::= 256
```

```
maxAC                          INTEGER ::= 16
maxAdditionalMeas              INTEGER ::= 4
maxASC                         INTEGER ::= 8
maxASCmap                      INTEGER ::= 7
maxASCpersist                  INTEGER ::= 6
maxCCTrCH                      INTEGER ::= 8
maxCellMeas                    INTEGER ::= 32
maxCellMeas-1                  INTEGER ::= 31
maxCNdomains                   INTEGER ::= 4
maxCPCHsets                    INTEGER ::= 16
maxDPCH-DLchan                 INTEGER ::= 8
maxDPDCH-UL                    INTEGER ::= 6
maxDRACclasses                 INTEGER ::= 8
maxE-DCHMACdFlow               INTEGER ::= 8
maxE-DCHMACdFlow-1             INTEGER ::= 7
maxEDCHRL                      INTEGER ::= 4
maxFACHPCH                     INTEGER ::= 8
maxFreq                        INTEGER ::= 8
maxFreqBandsFDD                INTEGER ::= 8
maxFreqBandsFDD-ext            INTEGER ::= 15  -- maxFreqBandsFDD-ext ::= 22 - (maxFreqBandsFDD - 1)
maxFreqBandsTDD                INTEGER ::= 4
maxFreqBandsGSM                INTEGER ::= 16
maxGERAN-SI                    INTEGER ::= 8
maxGSMTargetCells              INTEGER ::= 32
maxHProcesses                  INTEGER ::= 8
maxHSDSCHTBIndex               INTEGER ::= 64
maxHSDSCHTBIndex-tdd384        INTEGER ::= 512
maxHSSCCHs                     INTEGER ::= 4
maxInterSysMessages            INTEGER ::= 4
maxLoCHperRLC                  INTEGER ::= 2
maxMAC-d-PDUsizes              INTEGER ::= 8
maxMBMS-CommonCCTrCh           INTEGER ::= 32
maxMBMS-CommonPhyCh            INTEGER ::= 32
maxMBMS-CommonRB               INTEGER ::= 32
maxMBMS-CommonTrCh             INTEGER ::= 32
maxMBMS-Freq                   INTEGER ::= 4
maxMBMS-L1CP                   INTEGER ::= 4
maxMBMSservCount               INTEGER ::= 8
maxMBMSservModif               INTEGER ::= 32
maxMBMSservSched               INTEGER ::= 16
maxMBMSservUnmodif             INTEGER ::= 64
maxMBMSTransmis                INTEGER ::= 4
maxMeasEvent                   INTEGER ::= 8
maxMeasIntervals               INTEGER ::= 3
maxMeasParEvent                INTEGER ::= 2
maxNumCDMA2000Freqs            INTEGER ::=  8
maxNumGSMFreqRanges            INTEGER ::= 32
maxNumFDDFreqs                 INTEGER ::=  8
maxNumTDDFreqs                 INTEGER ::=  8
maxNoOfMeas                    INTEGER ::= 16
maxOtherRAT                    INTEGER ::= 15
maxOtherRAT-16                 INTEGER ::= 16
maxPage1                       INTEGER ::= 8
maxPCPCH-APsig                 INTEGER ::= 16
maxPCPCH-APsubCh               INTEGER ::= 12
maxPCPCH-CDsig                 INTEGER ::= 16
maxPCPCH-CDsubCh               INTEGER ::= 12
maxPCPCH-SF                    INTEGER ::= 7
maxPCPCHs                      INTEGER ::= 64
maxPDCPAlgoType                INTEGER ::= 8
maxPDSCH                       INTEGER ::= 8
maxPDSCH-TFCIgroups            INTEGER ::= 256
maxPRACH                       INTEGER ::= 16
maxPRACH-FPACH                 INTEGER ::= 8
maxPredefConfig                INTEGER ::= 16
maxPUSCH                       INTEGER ::= 8
maxQueueIDs                    INTEGER ::= 8
maxRABsetup                    INTEGER ::= 16
maxRAT                         INTEGER ::= 16
maxRB                          INTEGER ::= 32
maxRBallRABs                   INTEGER ::= 27
maxRBMuxOptions                INTEGER ::= 8
maxRBperRAB                    INTEGER ::= 8
maxRBperTrCh                   INTEGER ::= 16
maxReportedGSMCells            INTEGER ::= 8
maxRL                          INTEGER ::= 8
maxRL-1                        INTEGER ::= 7
maxRLCPDUsizePerLogChan        INTEGER ::= 32
```

```
maxRFC3095-CID              INTEGER ::= 16384
maxROHC-PacketSizes-r4      INTEGER ::= 16
maxROHC-Profile-r4          INTEGER ::= 8
maxSat                      INTEGER ::= 16
maxSCCPCH                   INTEGER ::= 16
maxSIB                      INTEGER ::= 32
maxSIB-FACH                 INTEGER ::= 8
maxSIBperMsg                INTEGER ::= 16
maxSRBsetup                 INTEGER ::= 8
maxSystemCapability         INTEGER ::= 16
maxTF                       INTEGER ::= 32
maxTF-CPCH                  INTEGER ::= 16
maxTFC                      INTEGER ::= 1024
maxTFCsub                   INTEGER ::= 1024
maxTFCI-2-Combs             INTEGER ::= 512
maxTGPS                     INTEGER ::= 6
maxTrCH                     INTEGER ::= 32
-- maxTrCHpreconf should be 16 but has been set to 32 for compatibility
maxTrCHpreconf              INTEGER ::= 32
maxTS                       INTEGER ::= 14
maxTS-1                     INTEGER ::= 13
maxTS-2                     INTEGER ::= 12
maxTS-LCR                   INTEGER ::= 6
maxTS-LCR-1                 INTEGER ::= 5
maxURA                      INTEGER ::= 8
maxURNTI-Group              INTEGER ::= 8

END
```

## 11.5 RRC information between network nodes

```
Internode-definitions DEFINITIONS AUTOMATIC TAGS ::=

BEGIN

IMPORTS

    HandoverToUTRANCommand,
    MeasurementReport,
    PhysicalChannelReconfiguration,
    RadioBearerReconfiguration,
    RadioBearerRelease,
    RadioBearerSetup,
    RRCConnectionSetupComplete-r3-add-ext-IEs,
    RRC-FailureInfo,
    TransportChannelReconfiguration,
    UECapabilityInformation-r3-add-ext-IEs
FROM PDU-definitions

-- Core Network IEs :
    CN-DomainIdentity,
    CN-DomainInformationList,
    CN-DomainInformationListFull,
    CN-DRX-CycleLengthCoefficient,
    NAS-SystemInformationGSM-MAP,
-- UTRAN Mobility IEs :
    CellIdentity,
    URA-Identity,
-- User Equipment IEs :
    AccessStratumReleaseIndicator,
    C-RNTI,
    ChipRateCapability,
    DL-CapabilityWithSimultaneousHS-DSCHConfig,
    DL-PhysChCapabilityFDD-v380ext,
    DL-PhysChCapabilityTDD,
    DL-PhysChCapabilityTDD-LCR-r4,
    GSM-Measurements,
    HSDSCH-physical-layer-category,
    FailureCauseWithProtErr,
    MaxHcContextSpace,
    MaximumAM-EntityNumberRLC-Cap,
    MaximumRLC-WindowSize,
    MaxNoPhysChBitsReceived,
    MaxNoDPDCH-BitsTransmitted,
    MaxPhysChPerFrame,
    MaxPhysChPerSubFrame-r4,
    MaxPhysChPerTS,
```

```
    MaxROHC-ContextSessions-r4,
    MaxTS-PerFrame,
    MaxTS-PerSubFrame-r4,
    MinimumSF-DL,
    MultiModeCapability,
    MultiRAT-Capability,
    NetworkAssistedGPS-Supported,
    PhysicalChannelCapability-edch-r6,
    RadioFrequencyBandTDDList,
    RLC-Capability,
    RRC-MessageSequenceNumber,
    SecurityCapability,
    SimultaneousSCCPCH-DPCH-Reception,
    STARTList,
    STARTSingle,
    START-Value,
    SupportOfDedicatedPilotsForChEstimation,
    TransportChannelCapability,
    TxRxFrequencySeparation,
    U-RNTI,
    UE-CapabilityContainer-IEs,
    UE-MultiModeRAT-Capability,
    UE-PowerClassExt,
    UE-RadioAccessCapabBandFDDList,
    UE-RadioAccessCapabBandFDDList2,
    UE-RadioAccessCapabBandFDDList-ext,
    UE-RadioAccessCapability,
    UE-RadioAccessCapability-v370ext,
    UE-RadioAccessCapability-v380ext,
    UE-RadioAccessCapability-v3a0ext,
    UE-RadioAccessCapability-v3g0ext,
    UE-RadioAccessCapability-v4b0ext,
    UE-RadioAccessCapability-v590ext,
    UE-RadioAccessCapability-v5c0ext,
    UE-RadioAccessCapability-v7xyext,
    UL-PhysChCapabilityFDD,
    UL-PhysChCapabilityFDD-r6,
    UL-PhysChCapabilityTDD,
    UL-PhysChCapabilityTDD-LCR-r4,
-- Radio Bearer IEs :
    PredefinedConfigStatusList,
    PredefinedConfigValueTag,
    RAB-InformationSetupList,
    RAB-InformationSetupList-r4,
    RAB-InformationSetupList-r5,
    RAB-InformationSetupList-r6-ext,
    RAB-InformationSetupList-r6,
    RB-Identity,
    SRB-InformationSetupList,
    SRB-InformationSetupList-r5,
    SRB-InformationSetupList-r6,
-- Transport Channel IEs :
    CPCH-SetID,
    DL-CommonTransChInfo,
    DL-CommonTransChInfo-r4,
    DL-AddReconfTransChInfoList,
    DL-AddReconfTransChInfoList-r4,
    DL-AddReconfTransChInfoList-r5,
    DRAC-StaticInformationList,
    UL-CommonTransChInfo,
    UL-CommonTransChInfo-r4,
    UL-AddReconfTransChInfoList,
    UL-AddReconfTransChInfoList-r6,
-- Physical Channel IEs :
    PrimaryCPICH-Info,
    TPC-CombinationIndex,
    ScramblingCodeChange,
    TGCFN,
    TGPSI,
    TGPS-ConfigurationParams,
-- Measurement IEs :
    Event1j-r6,
    Hysteresis,
    Inter-FreqEventCriteriaList-v590ext,
    Intra-FreqEventCriteriaList-v590ext,
    IntraFreqEvent-1d-r5,
    IntraFreqReportingCriteria-1b-r5,
    InterRATCellInfoIndication,
```

```
    MeasuredResultsOnRACHinterFreq,
    MeasurementIdentity,
    MeasurementReportingMode,
    MeasurementType,
    MeasurementType-r4,
    MeasurementType-r6,
    AdditionalMeasurementID-List,
    PositionEstimate,
    ReportingCellStatus,
    TimeToTrigger,
-- MBMS IEs :
    MBMS-JoinedInformation-r6,
-- Other IEs :
    GERANIu-RadioAccessCapability,
    GSM-MS-RadioAccessCapability,
    InterRAT-UE-RadioAccessCapabilityList,
    InterRAT-UE-RadioAccessCapability-v590ext,
    InterRAT-UE-RadioAccessCapability-v690ext,
    UESpecificBehaviourInformation1idle,
    UESpecificBehaviourInformation1interRAT

FROM InformationElements

    maxCNdomains,
    maxNoOfMeas,

    maxRB,
    maxRBallRABs,
    maxRFC3095-CID,
    maxSRBsetup,
    maxRL,
    maxTGPS
FROM Constant-definitions
;

-- Part 1: Class definitions similar to what has been defined in 11.1 for RRC messages
-- Information that is tranferred in the same direction and across the same path is grouped

-- **************************************************
--
-- RRC information, to target RNC
--
-- **************************************************
-- RRC Information to target RNC sent either from source RNC or from another RAT

ToTargetRNC-Container ::= CHOICE {
    interRATHandoverInfo                InterRATHandoverInfoWithInterRATCapabilities-r3,
    srncRelocation                      SRNC-RelocationInfo-r3,
    rfc3095-ContextInfo                 RFC3095-ContextInfo-r5,
    extension                           NULL
}

-- **************************************************
--
-- RRC information, target RNC to source RNC
--
-- **************************************************


TargetRNC-ToSourceRNC-Container ::= CHOICE {
    radioBearerSetup                    RadioBearerSetup,
    radioBearerReconfiguration          RadioBearerReconfiguration,
    radioBearerRelease                  RadioBearerRelease,
    transportChannelReconfiguration     TransportChannelReconfiguration,
    physicalChannelReconfiguration      PhysicalChannelReconfiguration,
    rrc-FailureInfo                     RRC-FailureInfo,
    -- IE dl-DCCHmessage consists of an octet string that includes the IE DL-DCCH-Message
    dL-DCCHmessage                      OCTET STRING,
    extension                           NULL
}

-- Part 2: Container definitions, similar to the PDU definitions in 11.2 for RRC messages
-- In alphabetical order


-- **************************************************
--
-- Handover to UTRAN information
```

```
--
-- **************************************************

InterRATHandoverInfoWithInterRATCapabilities-r3 ::= CHOICE {
    r3                              SEQUENCE {
        -- IE InterRATHandoverInfoWithInterRATCapabilities-r3-IEs also
        -- includes non critical extensions
        interRATHandoverInfo-r3         InterRATHandoverInfoWithInterRATCapabilities-r3-IEs,
        v390NonCriticalExtensions       SEQUENCE {
            interRATHandoverInfoWithInterRATCapabilities-v390ext
                                        InterRATHandoverInfoWithInterRATCapabilities-v390ext-IEs,
            -- Reserved for future non critical extension
            v690NonCriticalExtensions       SEQUENCE {
                interRATHandoverInfoWithInterRATCapabilities-v690ext
                                        InterRATHandoverInfoWithInterRATCapabilities-v690ext-IEs,
            nonCriticalExtensions           SEQUENCE {} OPTIONAL
            }       OPTIONAL
        }       OPTIONAL
    },
    criticalExtensions              SEQUENCE {}
}

InterRATHandoverInfoWithInterRATCapabilities-r3-IEs ::=     SEQUENCE {
        -- The order of the IEs may not reflect the tabular format
        --  but has been chosen to simplify the handling of the information in the BSC
    --  Other IEs
        ue-RATSpecificCapability        InterRAT-UE-RadioAccessCapabilityList   OPTIONAL,
        -- interRATHandoverInfo, Octet string is used to obtain 8 bit length field prior to
        -- actual information.  This makes it possible for BSS to transparently handle information
        -- received via GSM air interface even when it includes non critical extensions.
        -- The octet string shall include the InterRATHandoverInfo information
        -- The BSS can re-use the 44.018 length field received from the MS
        interRATHandoverInfo            OCTET STRING (SIZE (0..255))
}

InterRATHandoverInfoWithInterRATCapabilities-v390ext-IEs ::= SEQUENCE {
    -- User equipment IEs
        failureCauseWithProtErr             FailureCauseWithProtErr                 OPTIONAL
}

InterRATHandoverInfoWithInterRATCapabilities-v690ext-IEs ::= SEQUENCE {
    -- Other IEs
        ue-RATSpecificCapability-v690ext    InterRAT-UE-RadioAccessCapability-v690ext   OPTIONAL
}

-- **************************************************
--
-- RFC3095 context, source RNC to target RNC
--
-- **************************************************

RFC3095-ContextInfo-r5 ::= CHOICE {
    r5                              SEQUENCE {
        rFC3095-ContextInfoList-r5      RFC3095-ContextInfoList-r5,
        -- Reserved for future non critical extension
        nonCriticalExtensions           SEQUENCE {} OPTIONAL
    },
    criticalExtensions              SEQUENCE {}
}

RFC3095-ContextInfoList-r5 ::=      SEQUENCE (SIZE (1..maxRBallRABs)) OF
                                        RFC3095-ContextInfo


-- **************************************************
--
-- SRNC Relocation information
--
-- **************************************************

SRNC-RelocationInfo-r3 ::= CHOICE {
    r3                              SEQUENCE {
        sRNC-RelocationInfo-r3          SRNC-RelocationInfo-r3-IEs,
        v380NonCriticalExtensions           SEQUENCE {
            sRNC-RelocationInfo-v380ext SRNC-RelocationInfo-v380ext-IEs,
            -- Reserved for future non critical extension
            v390NonCriticalExtensions           SEQUENCE {
                sRNC-RelocationInfo-v390ext         SRNC-RelocationInfo-v390ext-IEs,
```

```
            v3a0NonCriticalExtensions           SEQUENCE {
                sRNC-RelocationInfo-v3a0ext         SRNC-RelocationInfo-v3a0ext-IEs,
                v3b0NonCriticalExtensions           SEQUENCE {
                    sRNC-RelocationInfo-v3b0ext         SRNC-RelocationInfo-v3b0ext-IEs,
                    v3c0NonCriticalExtensions           SEQUENCE {
                        sRNC-RelocationInfo-v3c0ext         SRNC-RelocationInfo-v3c0ext-IEs,
                        laterNonCriticalExtensions          SEQUENCE {
                            sRNC-RelocationInfo-v3d0ext         SRNC-RelocationInfo-v3d0ext-IEs,
                            -- Container for additional R99 extensions
                            sRNC-RelocationInfo-r3-add-ext      BIT STRING
                                        (CONTAINING SRNC-RelocationInfo-v3h0ext-IEs)     OPTIONAL,
                            v3g0NonCriticalExtensions           SEQUENCE {
                                sRNC-RelocationInfo-v3g0ext         SRNC-RelocationInfo-v3g0ext-IEs,
                                v4b0NonCriticalExtensions           SEQUENCE {
                                    sRNC-RelocationInfo-v4b0ext         SRNC-RelocationInfo-v4b0ext-IEs,
                                    v590NonCriticalExtensions           SEQUENCE {
                                        sRNC-RelocationInfo-v590ext
                                                                            SRNC-RelocationInfo-v590ext-IEs,
                                        v5a0NonCriticalExtensions           SEQUENCE {
                                            sRNC-RelocationInfo-v5a0ext
                                                                            SRNC-RelocationInfo-v5a0ext-IEs,
                                            v5b0NonCriticalExtensions           SEQUENCE {
                                                sRNC-RelocationInfo-v5b0ext
                                                                            SRNC-RelocationInfo-v5b0ext-IEs,
                                                v5c0NonCriticalExtensions           SEQUENCE {
                                                    sRNC-RelocationInfo-v5c0ext
                                                                            SRNC-RelocationInfo-v5c0ext-IEs,
                                                    v690NonCriticalExtensions       SEQUENCE {
                                                        sRNC-RelocationInfo-v690ext
                                                                            SRNC-RelocationInfo-v690ext-IEs,
                                                        v7xyNonCriticalExtensions SEQUENCE {
                                                            sRNC-RelocationInfo-v7xyext
                                                                            SRNC-RelocationInfo-v7xyext-IEs,
                                                            -- Reserved for future non critical extension
                                                            nonCriticalExtensions   SEQUENCE {}  OPTIONAL
                                                        }       OPTIONAL
                                                    }       OPTIONAL
                                                }       OPTIONAL
                                            }       OPTIONAL
                                        }       OPTIONAL
                                    }       OPTIONAL
                                }       OPTIONAL
                            }       OPTIONAL
                        }       OPTIONAL
                    }       OPTIONAL
                }       OPTIONAL
            }       OPTIONAL
        }       OPTIONAL
    },
    later-than-r3                   CHOICE {
        r4                              SEQUENCE {
            sRNC-RelocationInfo-r4          SRNC-RelocationInfo-r4-IEs,
            v4d0NonCriticalExtensions       SEQUENCE {
                sRNC-RelocationInfo-v4d0ext     SRNC-RelocationInfo-v4d0ext-IEs,
                -- Container for adding non critical extensions after freezing REL-5
                sRNC-RelocationInfo-r4-add-ext      BIT STRING      OPTIONAL,
                v590NonCriticalExtensions           SEQUENCE {
                    sRNC-RelocationInfo-v590ext         SRNC-RelocationInfo-v590ext-IEs,
                    v5a0NonCriticalExtensions           SEQUENCE {
                        sRNC-RelocationInfo-v5a0ext         SRNC-RelocationInfo-v5a0ext-IEs,
                        v5b0NonCriticalExtensions           SEQUENCE {
                            sRNC-RelocationInfo-v5b0ext         SRNC-RelocationInfo-v5b0ext-IEs,
                            v5c0NonCriticalExtensions           SEQUENCE {
                                sRNC-RelocationInfo-v5c0ext         SRNC-RelocationInfo-v5c0ext-IEs,
                                v690NonCriticalExtensions           SEQUENCE {
                                    sRNC-RelocationInfo-v690ext
                                                SRNC-RelocationInfo-v690ext-IEs,
                                    nonCriticalExtensions               SEQUENCE {} OPTIONAL
                                }   OPTIONAL
                            }   OPTIONAL
                        }   OPTIONAL
                    }   OPTIONAL
                }   OPTIONAL
            }   OPTIONAL
        },
        criticalExtensions              CHOICE {
            r5                              SEQUENCE {
```

```
                sRNC-RelocationInfo-r5          SRNC-RelocationInfo-r5-IEs,
                sRNC-RelocationInfo-r5-add-ext  BIT STRING      OPTIONAL,
                v5a0NonCriticalExtensions       SEQUENCE {
                    sRNC-RelocationInfo-v5a0ext     SRNC-RelocationInfo-v5a0ext-IEs,
                    v5b0NonCriticalExtensions       SEQUENCE {
                        sRNC-RelocationInfo-v5b0ext     SRNC-RelocationInfo-v5b0ext-IEs,
                        v5c0NonCriticalExtensions           SEQUENCE {
                            sRNC-RelocationInfo-v5c0ext         SRNC-RelocationInfo-v5c0ext-IEs,
                            v690NonCriticalExtensions       SEQUENCE {
                                sRNC-RelocationInfo-v690ext     SRNC-RelocationInfo-v690ext-IEs,
                                nonCriticalExtensions           SEQUENCE {}     OPTIONAL
                            }   OPTIONAL
                        }   OPTIONAL
                    }   OPTIONAL
                },
                criticalExtensions              CHOICE {
                    r6                              SEQUENCE {
                        sRNC-RelocationInfo-r6          SRNC-RelocationInfo-r6-IEs,
                        sRNC-RelocationInfo-r6-add-ext  BIT STRING      OPTIONAL,
                        nonCriticalExtensions           SEQUENCE {}     OPTIONAL
                    },
                    criticalExtensions                  SEQUENCE {}
                }
            }
        }
    }
}

SRNC-RelocationInfo-r3-IEs ::=      SEQUENCE {
    -- Non-RRC IEs
        stateOfRRC                      StateOfRRC,
        stateOfRRC-Procedure            StateOfRRC-Procedure,
    -- Ciphering related information IEs
    -- If the extension v380 is included use the extension for the ciphering status per CN domain
        cipheringStatus                 CipheringStatus,
        -- If ciphering status is started and the IE latestConfiguredCN-Domain should be included,
        -- the IE cn-DomainIdentity (in SRNC-RelocationInfo-v380ext-IEs) shall be used instead.
        calculationTimeForCiphering     CalculationTimeForCiphering         OPTIONAL,
        -- The order of occurrence in the IE cipheringInfoPerRB-List is the
        -- same as the RBs in SRB-InformationSetupList in RAB-InformationSetupList.
        -- The signalling RBs are supposed to be listed
        -- first. Only UM and AM RBs that are ciphered are listed here
        cipheringInfoPerRB-List         CipheringInfoPerRB-List             OPTIONAL,
        count-C-List                    COUNT-C-List                        OPTIONAL,
        integrityProtectionStatus       IntegrityProtectionStatus,
        -- In the IE srb-SpecificIntegrityProtInfo, the first information listed corresponds to
      -- signalling radio bearer RB0 and after the order of occurrence is the same as the SRBs in
     -- SRB-InformationSetupList
        -- The target RNC may ignore the IE srb-SpecificIntegrityProtInfo if the
        -- IE integrityProtectionStatus has the value "not started".
        srb-SpecificIntegrityProtInfo   SRB-SpecificIntegrityProtInfoList,
        implementationSpecificParams    ImplementationSpecificParams        OPTIONAL,
    -- User equipment IEs
        u-RNTI                          U-RNTI,
        c-RNTI                          C-RNTI                              OPTIONAL,
        ue-RadioAccessCapability        UE-RadioAccessCapability,
        ue-Positioning-LastKnownPos     UE-Positioning-LastKnownPos         OPTIONAL,
    -- Other IEs
        ue-RATSpecificCapability        InterRAT-UE-RadioAccessCapabilityList   OPTIONAL,
    -- UTRAN mobility IEs
        ura-Identity                    URA-Identity                        OPTIONAL,
    -- Core network IEs
        cn-CommonGSM-MAP-NAS-SysInfo    NAS-SystemInformationGSM-MAP,
        cn-DomainInformationList        CN-DomainInformationList            OPTIONAL,
    -- Measurement IEs
        ongoingMeasRepList              OngoingMeasRepList                  OPTIONAL,
    -- Radio bearer IEs
        predefinedConfigStatusList      PredefinedConfigStatusList,
        srb-InformationList             SRB-InformationSetupList,
        rab-InformationList             RAB-InformationSetupList            OPTIONAL,
    -- Transport channel IEs
        ul-CommonTransChInfo            UL-CommonTransChInfo                OPTIONAL,
        ul-TransChInfoList              UL-AddReconfTransChInfoList         OPTIONAL,
        modeSpecificInfo                CHOICE {
            fdd                             SEQUENCE {
                -- dummy and dummy2 are not used in this version of the specification, they should
                -- not be sent and if received they should be ignored.
                dummy                           CPCH-SetID                  OPTIONAL,
```

```
                dummy2                          DRAC-StaticInformationList  OPTIONAL
            },
            tdd                             NULL
        },
        dl-CommonTransChInfo            DL-CommonTransChInfo                OPTIONAL,
        dl-TransChInfoList              DL-AddReconfTransChInfoList         OPTIONAL,
    -- Measurement report
        measurementReport               MeasurementReport                   OPTIONAL
}

SRNC-RelocationInfo-v380ext-IEs ::= SEQUENCE {
    -- Ciphering related information IEs
        -- In the SRNC-RelocationInfo-r3-IEs, the IE 'cn-DomainIdentity' is used to represent the
        -- IE 'Latest configured CN domain' in the tabular.
        cn-DomainIdentity                   CN-DomainIdentity,
        cipheringStatusList                 CipheringStatusList
}

SRNC-RelocationInfo-v390ext-IEs ::= SEQUENCE {
        cn-DomainInformationList-v390ext    CN-DomainInformationList-v390ext        OPTIONAL,
        ue-RadioAccessCapability-v370ext    UE-RadioAccessCapability-v370ext        OPTIONAL,
        ue-RadioAccessCapability-v380ext    UE-RadioAccessCapability-v380ext        OPTIONAL,
        dl-PhysChCapabilityFDD-v380ext      DL-PhysChCapabilityFDD-v380ext,
        failureCauseWithProtErr             FailureCauseWithProtErr                 OPTIONAL
}

SRNC-RelocationInfo-v3a0ext-IEs ::= SEQUENCE {
        cipheringInfoForSRB1-v3a0ext        CipheringInfoPerRB-List-v3a0ext,
        ue-RadioAccessCapability-v3a0ext    UE-RadioAccessCapability-v3a0ext        OPTIONAL,
        -- cn-domain identity for IE startValueForCiphering-v3a0ext is specified
        -- in subsequent extension (SRNC-RelocationInfo-v3b0ext-IEs)
        startValueForCiphering-v3a0ext      START-Value
}

SRNC-RelocationInfo-v3b0ext-IEs ::= SEQUENCE {
        -- cn-domain identity for IE startValueForCiphering-v3a0ext included in previous extension
        cn-DomainIdentity               CN-DomainIdentity,
        -- the IE startValueForCiphering-v3b0ext contains the start values for each CN Domain. The
        -- value of start indicated by the IE startValueForCiphering-v3a0ext should be set to the
        -- same value as the start-Value for the corresponding cn-DomainIdentity in the IE
        -- startValueForCiphering-v3b0ext
        startValueForCiphering-v3b0ext      STARTList2                              OPTIONAL
}

SRNC-RelocationInfo-v3c0ext-IEs ::= SEQUENCE {
        -- IE rb-IdentityForHOMessage includes the identity of the RB used by the source SRNC
        -- to send the message contained in the IE 'TargetRNC-ToSourceRNC-Container'.
        -- Only included if type is 'UE involved'
        rb-IdentityForHOMessage             RB-Identity         OPTIONAL
}

SRNC-RelocationInfo-v3d0ext-IEs ::= SEQUENCE {
    -- User equipment IEs
        uESpecificBehaviourInformation1idle     UESpecificBehaviourInformation1idle     OPTIONAL,
        uESpecificBehaviourInformation1interRAT     UESpecificBehaviourInformation1interRAT
    OPTIONAL
}

SRNC-RelocationInfo-v3g0ext-IEs ::= SEQUENCE {
        ue-RadioAccessCapability-v3g0ext    UE-RadioAccessCapability-v3g0ext        OPTIONAL
}

SRNC-RelocationInfo-v3h0ext-IEs ::= SEQUENCE {
        tpc-CombinationInfoList         TPC-CombinationInfoList     OPTIONAL,
        nonCriticalExtension                SEQUENCE {}             OPTIONAL
}

SRNC-RelocationInfo-v4d0ext-IEs ::= SEQUENCE {
        tpc-CombinationInfoList     TPC-CombinationInfoList     OPTIONAL
}

TPC-CombinationInfoList ::= SEQUENCE (SIZE (1..maxRL)) OF
        TPC-Combination-Info

STARTList2 ::=                      SEQUENCE (SIZE (2..maxCNdomains)) OF
                                        STARTSingle

SRNC-RelocationInfo-v4b0ext-IEs ::= SEQUENCE {
```

```
        ue-RadioAccessCapability-v4b0ext    UE-RadioAccessCapability-v4b0ext        OPTIONAL
}

SRNC-RelocationInfo-v590ext-IEs ::= SEQUENCE {
        ue-RadioAccessCapability-v590ext    UE-RadioAccessCapability-v590ext        OPTIONAL,
        ue-RATSpecificCapability-v590ext    InterRAT-UE-RadioAccessCapability-v590ext   OPTIONAL
}

SRNC-RelocationInfo-v5a0ext-IEs ::= SEQUENCE {
        storedCompressedModeInfo        StoredCompressedModeInfo    OPTIONAL
}

SRNC-RelocationInfo-v5b0ext-IEs ::= SEQUENCE {
    interRATCellInfoIndication          InterRATCellInfoIndication          OPTIONAL
}

SRNC-RelocationInfo-v5c0ext-IEs ::= SEQUENCE {
        ue-RadioAccessCapability-v5c0ext    UE-RadioAccessCapability-v5c0ext        OPTIONAL
}

SRNC-RelocationInfo-v7xyext-IEs ::= SEQUENCE {
        ue-RadioAccessCapability-v7xyext    UE-RadioAccessCapability-v7xyext        OPTIONAL
}

CipheringInfoPerRB-List-v3a0ext ::= SEQUENCE {
        dl-UM-SN                        BIT STRING (SIZE (7))
}

CipheringStatusList ::=         SEQUENCE (SIZE (1..maxCNdomains)) OF
                                CipheringStatusCNdomain

CipheringStatusCNdomain ::=             SEQUENCE {
        cn-DomainIdentity               CN-DomainIdentity,
        cipheringStatus                 CipheringStatus
}

CodeChangeStatusList ::= SEQUENCE (SIZE (1..maxRL)) OF
        CodeChangeStatus

CodeChangeStatus ::= SEQUENCE {
        primaryCPICH-Info                   PrimaryCPICH-Info,
        scramblingCodeChange                ScramblingCodeChange
}

StoredCompressedModeInfo ::= SEQUENCE {
        storedTGP-SequenceList      StoredTGP-SequenceList,
        codeChangeStatusList        CodeChangeStatusList    OPTIONAL
}

StoredTGP-SequenceList ::=          SEQUENCE (SIZE (1..maxTGPS)) OF
                                        StoredTGP-Sequence

StoredTGP-Sequence ::=              SEQUENCE {
    tgpsi                               TGPSI,
    current-tgps-Status                 CHOICE {
        active                              SEQUENCE {
            tgcfn                               TGCFN
        },
        inactive                            NULL
    },
    tgps-ConfigurationParams            TGPS-ConfigurationParams            OPTIONAL
}

SRNC-RelocationInfo-r4-IEs ::=          SEQUENCE {
    -- Non-RRC IEs
        -- IE rb-IdentityForHOMessage includes the identity of the RB used by the source SRNC
        -- to send the message contained in the IE 'TargetRNC-ToSourceRNC-Container'.
        -- Only included if type is 'UE involved'
        rb-IdentityForHOMessage         RB-Identity                         OPTIONAL,
        stateOfRRC                      StateOfRRC,
        stateOfRRC-Procedure            StateOfRRC-Procedure,
    -- Ciphering related information IEs
        cipheringStatusList             CipheringStatusList-r4,
        latestConfiguredCN-Domain       CN-DomainIdentity,
        calculationTimeForCiphering     CalculationTimeForCiphering         OPTIONAL,
        count-C-List                    COUNT-C-List                        OPTIONAL,
        cipheringInfoPerRB-List         CipheringInfoPerRB-List-r4          OPTIONAL,
    -- Integrity protection related information IEs
```

```
        integrityProtectionStatus       IntegrityProtectionStatus,
        -- The target RNC may ignore the IE srb-SpecificIntegrityProtInfo if the
        -- IE integrityProtectionStatus has the value "not started".
        srb-SpecificIntegrityProtInfo   SRB-SpecificIntegrityProtInfoList,
        implementationSpecificParams    ImplementationSpecificParams        OPTIONAL,
    -- User equipment IEs
        u-RNTI                          U-RNTI,
        c-RNTI                          C-RNTI                              OPTIONAL,
        ue-RadioAccessCapability        UE-RadioAccessCapability-r4,
        ue-RadioAccessCapability-ext    UE-RadioAccessCapabBandFDDList      OPTIONAL,
        ue-Positioning-LastKnownPos     UE-Positioning-LastKnownPos         OPTIONAL,
        uESpecificBehaviourInformation1idle     UESpecificBehaviourInformation1idle     OPTIONAL,
        uESpecificBehaviourInformation1interRAT     UESpecificBehaviourInformation1interRAT
    OPTIONAL,
    -- Other IEs
        ue-RATSpecificCapability        InterRAT-UE-RadioAccessCapabilityList   OPTIONAL,
    -- UTRAN mobility IEs
        ura-Identity                    URA-Identity                        OPTIONAL,
    -- Core network IEs
        cn-CommonGSM-MAP-NAS-SysInfo    NAS-SystemInformationGSM-MAP,
        cn-DomainInformationList        CN-DomainInformationListFull        OPTIONAL,
    -- Measurement IEs
        ongoingMeasRepList              OngoingMeasRepList-r4               OPTIONAL,
    -- Radio bearer IEs
        predefinedConfigStatusList      PredefinedConfigStatusList,
        srb-InformationList             SRB-InformationSetupList,
        rab-InformationList             RAB-InformationSetupList-r4         OPTIONAL,
    -- Transport channel IEs
        ul-CommonTransChInfo            UL-CommonTransChInfo-r4             OPTIONAL,
        ul-TransChInfoList              UL-AddReconfTransChInfoList         OPTIONAL,
        -- 'dummy', 'dummy1' and 'dummy2' are not used in this version of the specification,
        -- they should not be sent and if received they should be ignored.
        dummy                           CHOICE {
            fdd                             SEQUENCE {
                dummy1                          CPCH-SetID                  OPTIONAL,
                dummy2                          DRAC-StaticInformationList  OPTIONAL
            },
            tdd                             NULL
        }                                                                   OPTIONAL,
        dl-CommonTransChInfo            DL-CommonTransChInfo-r4             OPTIONAL,
        dl-TransChInfoList              DL-AddReconfTransChInfoList-r4      OPTIONAL,
    -- Measurement report
        measurementReport               MeasurementReport                   OPTIONAL,
        failureCause                    FailureCauseWithProtErr             OPTIONAL
}

SRNC-RelocationInfo-r5-IEs ::=          SEQUENCE {
    -- Non-RRC IEs
        -- IE rb-IdentityForHOMessage includes the identity of the RB used by the source SRNC
        -- to send the message contained in the IE 'TargetRNC-ToSourceRNC-Container'.
        -- Only included if type is "UE involved"
        rb-IdentityForHOMessage         RB-Identity                         OPTIONAL,
        stateOfRRC                      StateOfRRC,
        stateOfRRC-Procedure            StateOfRRC-Procedure,
    -- Ciphering related information IEs
        cipheringStatusList             CipheringStatusList-r4,
        latestConfiguredCN-Domain       CN-DomainIdentity,
        calculationTimeForCiphering     CalculationTimeForCiphering         OPTIONAL,
        count-C-List                    COUNT-C-List                        OPTIONAL,
        cipheringInfoPerRB-List         CipheringInfoPerRB-List-r4          OPTIONAL,
    -- Integrity protection related information IEs
        integrityProtectionStatus       IntegrityProtectionStatus,
        srb-SpecificIntegrityProtInfo   SRB-SpecificIntegrityProtInfoList   OPTIONAL,
        implementationSpecificParams    ImplementationSpecificParams        OPTIONAL,
    -- User equipment IEs
        u-RNTI                          U-RNTI,
        c-RNTI                          C-RNTI                              OPTIONAL,
        ue-RadioAccessCapability        UE-RadioAccessCapability-r5,
        ue-RadioAccessCapability-ext    UE-RadioAccessCapabBandFDDList      OPTIONAL,
        ue-Positioning-LastKnownPos     UE-Positioning-LastKnownPos         OPTIONAL,
        uESpecificBehaviourInformation1idle
                                        UESpecificBehaviourInformation1idle     OPTIONAL,
        uESpecificBehaviourInformation1interRAT
                                        UESpecificBehaviourInformation1interRAT     OPTIONAL,
    -- Other IEs
        ue-RATSpecificCapability        InterRAT-UE-RadioAccessCapabilityList-r5    OPTIONAL,
    -- UTRAN mobility IEs
        ura-Identity                    URA-Identity                        OPTIONAL,
```

```
    -- Core network IEs
        cn-CommonGSM-MAP-NAS-SysInfo    NAS-SystemInformationGSM-MAP,
        cn-DomainInformationList        CN-DomainInformationListFull        OPTIONAL,
    -- Measurement IEs
        ongoingMeasRepList              OngoingMeasRepList-r5               OPTIONAL,
    -- Radio bearer IEs
        predefinedConfigStatusList      PredefinedConfigStatusList,
        srb-InformationList             SRB-InformationSetupList-r5,
        rab-InformationList             RAB-InformationSetupList-r5         OPTIONAL,
    -- Transport channel IEs
        ul-CommonTransChInfo            UL-CommonTransChInfo-r4             OPTIONAL,
        ul-TransChInfoList              UL-AddReconfTransChInfoList         OPTIONAL,
        -- 'dummy', 'dummy1' and 'dummy2' are not used in this version of the specification,
        -- they should not be sent and if received they should be ignored.
        dummy                           CHOICE {
            fdd                             SEQUENCE {
                dummy1                          CPCH-SetID                  OPTIONAL,
                dummy2                          DRAC-StaticInformationList  OPTIONAL
            },
            tdd                             NULL
        }                                                                   OPTIONAL,
        dl-CommonTransChInfo            DL-CommonTransChInfo-r4             OPTIONAL,
        dl-TransChInfoList              DL-AddReconfTransChInfoList-r5      OPTIONAL,
    -- PhyCH IEs
        tpc-CombinationInfoList         TPC-CombinationInfoList             OPTIONAL,
    -- Measurement report
        measurementReport               MeasurementReport                   OPTIONAL,
    -- Other IEs
        failureCause                    FailureCauseWithProtErr             OPTIONAL
}

SRNC-RelocationInfo-v690ext-IEs ::= SEQUENCE {
    -- User equipment IEs
        -- IE ueCapabilityContainer is used for the transparent transfer of capability information
        -- received from the UE
        ueCapabilityContainer           BIT STRING
                                            (CONTAINING UE-CapabilityContainer-IEs) OPTIONAL,
        -- IE ueCapabilityContainer-RSC and IE ueCapabilityContainer-UCI are used for the
        -- transparent transfer of capability information received from the UE that was introduced
        -- in a release independent manner, i.e., transferred within a VLEC. These UE capabilities
        -- are included both in the RRC CONNECTION SETUP COMPLETE and the UE CAPABILITY INFORMATION
        -- messages. Only the VLEC of one message needs to be included i.e. the one from these
        -- messages that was last received.
        -- Case 1: If the last received message was a RRC CONNECTION SETUP COMPLETE (RSC)
        ueCapabilityContainer-RSC       BIT STRING
                            (CONTAINING RRCConnectionSetupComplete-r3-add-ext-IEs)  OPTIONAL,
        -- Case 2: If the last received message was a UE CAPABILITY INFORMATION (UCI)
        ueCapabilityContainer-UCI       BIT STRING
                            (CONTAINING UECapabilityInformation-r3-add-ext-IEs)     OPTIONAL,
    -- Radio bearer IEs
        rab-InformationSetupList        RAB-InformationSetupList-r6-ext     OPTIONAL,
    -- Measurement report
        measuredResultsOnRACHinterFreq  MeasuredResultsOnRACHinterFreq      OPTIONAL,
    -- MBMS IEs
        mbms-JoinedInformation          MBMS-JoinedInformation-r6           OPTIONAL,
    -- Measurement IEs
        intraFreqReportingCriteria      IntraFreqReportingCriteria-r6-ext       OPTIONAL
}

SRNC-RelocationInfo-r6-IEs ::=          SEQUENCE {
    -- Non-RRC IEs
        -- IE rb-IdentityForHOMessage includes the identity of the RB used by the source SRNC
        -- to send the message contained in the IE 'TargetRNC-ToSourceRNC-Container'.
        -- Only included if type is "UE involved"
        rb-IdentityForHOMessage         RB-Identity                         OPTIONAL,
        stateOfRRC                      StateOfRRC,
        stateOfRRC-Procedure            StateOfRRC-Procedure,
    -- Ciphering related information IEs
        cipheringStatusList             CipheringStatusList-r4,
        latestConfiguredCN-Domain       CN-DomainIdentity,
        calculationTimeForCiphering     CalculationTimeForCiphering         OPTIONAL,
        count-C-List                    COUNT-C-List                        OPTIONAL,
        cipheringInfoPerRB-List         CipheringInfoPerRB-List-r4          OPTIONAL,
    -- Integrity protection related information IEs
        integrityProtectionStatus       IntegrityProtectionStatus,
        srb-SpecificIntegrityProtInfo   SRB-SpecificIntegrityProtInfoList   OPTIONAL,
        implementationSpecificParams    ImplementationSpecificParams        OPTIONAL,
    -- User equipment IEs
```

```
        u-RNTI                          U-RNTI,
        c-RNTI                          C-RNTI                                  OPTIONAL,
        ue-RadioAccessCapability        UE-RadioAccessCapability-r6,
        ue-RadioAccessCapability-ext    UE-RadioAccessCapabBandFDDList      OPTIONAL,
        ue-Positioning-LastKnownPos     UE-Positioning-LastKnownPos         OPTIONAL,
        uESpecificBehaviourInformation1idle
                                        UESpecificBehaviourInformation1idle     OPTIONAL,
        uESpecificBehaviourInformation1interRAT
                                        UESpecificBehaviourInformation1interRAT     OPTIONAL,
        -- IE ueCapabilityContainer is used for the transparent transfer of capability information
        -- received from the UE
        ueCapabilityContainer           BIT STRING
                                            (CONTAINING UE-CapabilityContainer-IEs) OPTIONAL,
        -- IE ueCapabilityContainer-RSC and IE ueCapabilityContainer-UCI are used for the
        -- transparent transfer of capability information received from the UE that was introduced
        -- in a release independent manner, i.e., transferred within a VLEC. These UE capabilities
        -- are included both in the RRC CONNECTION SETUP COMPLETE and the UE CAPABILITY INFORMATION
        -- messages. Only the VLEC of one message needs to be included i.e. the one from these
        -- messages that was last received.
        -- Case 1: If the last received message was a RRC CONNECTION SETUP COMPLETE (RSC)
        ueCapabilityContainer-RSC       BIT STRING
                            (CONTAINING RRCConnectionSetupComplete-r3-add-ext-IEs)  OPTIONAL,
        -- Case 2: If the last received message was a UE CAPABILITY INFORMATION (UCI)
        ueCapabilityContainer-UCI       BIT STRING
                            (CONTAINING UECapabilityInformation-r3-add-ext-IEs)     OPTIONAL,
    -- Other IEs
        ue-RATSpecificCapability        InterRAT-UE-RadioAccessCapabilityList-r5    OPTIONAL,
    -- UTRAN mobility IEs
        ura-Identity                    URA-Identity                            OPTIONAL,
    -- Core network IEs
        cn-CommonGSM-MAP-NAS-SysInfo    NAS-SystemInformationGSM-MAP,
        cn-DomainInformationList        CN-DomainInformationListFull        OPTIONAL,
    -- Measurement IEs
        ongoingMeasRepList              OngoingMeasRepList-r6               OPTIONAL,
        interRATCellInfoIndication      InterRATCellInfoIndication          OPTIONAL,
    -- Radio bearer IEs
        predefinedConfigStatusList      PredefinedConfigStatusList,
        srb-InformationList             SRB-InformationSetupList-r6,
        rab-InformationList             RAB-InformationSetupList-r6         OPTIONAL,
    -- Transport channel IEs
        ul-CommonTransChInfo            UL-CommonTransChInfo-r4             OPTIONAL,
        ul-TransChInfoList              UL-AddReconfTransChInfoList-r6      OPTIONAL,
        dl-CommonTransChInfo            DL-CommonTransChInfo-r4             OPTIONAL,
        dl-TransChInfoList              DL-AddReconfTransChInfoList-r5      OPTIONAL,
    -- PhyCH IEs
        tpc-CombinationInfoList         TPC-CombinationInfoList             OPTIONAL,
        storedCompressedModeInfo        StoredCompressedModeInfo            OPTIONAL,
    -- Measurement report
        measurementReport               MeasurementReport                   OPTIONAL,
    -- Other IEs
        failureCause                    FailureCauseWithProtErr             OPTIONAL,
    -- MBMS IEs
        mbms-JoinedInformation          MBMS-JoinedInformation-r6           OPTIONAL
}

-- IE definitions

CalculationTimeForCiphering ::=     SEQUENCE {
    cell-Id                             CellIdentity,
    sfn                                 INTEGER (0..4095)
}

CipheringInfoPerRB ::=              SEQUENCE {
    dl-HFN                              BIT STRING (SIZE (20..25)),
    ul-HFN                              BIT STRING (SIZE (20..25))
}

CipheringInfoPerRB-r4 ::=           SEQUENCE {
    rb-Identity                         RB-Identity,
    dl-HFN                              BIT STRING (SIZE (20..25)),
    dl-UM-SN                            BIT STRING (SIZE (7))               OPTIONAL,
    ul-HFN                              BIT STRING (SIZE (20..25))
}

-- TABULAR: CipheringInfoPerRB-List, multiplicity value numberOfRadioBearers
-- has been replaced with maxRB.
CipheringInfoPerRB-List ::=         SEQUENCE (SIZE (1..maxRB)) OF
                                        CipheringInfoPerRB
```

```
CipheringInfoPerRB-List-r4 ::=      SEQUENCE (SIZE (1..maxRB)) OF
                                        CipheringInfoPerRB-r4


CipheringStatus ::=                 ENUMERATED {
                                        started, notStarted }

CipheringStatusList-r4 ::=          SEQUENCE (SIZE (1..maxCNdomains)) OF
                                        CipheringStatusCNdomain-r4

CipheringStatusCNdomain-r4 ::=      SEQUENCE {
        cn-DomainIdentity               CN-DomainIdentity,
        cipheringStatus                 CipheringStatus,
        start-Value                     START-Value
}

CN-DomainInformation-v390ext ::=        SEQUENCE {
    cn-DRX-CycleLengthCoeff             CN-DRX-CycleLengthCoefficient
}

CN-DomainInformationList-v390ext ::=    SEQUENCE (SIZE (1..maxCNdomains)) OF
                                        CN-DomainInformation-v390ext

CompressedModeMeasCapability-r4 ::= SEQUENCE {
    fdd-Measurements                    BOOLEAN,
    -- TABULAR: The IEs tdd-Measurements, gsm-Measurements and multiCarrierMeasurements
    -- are made optional since they are conditional based on another information element.
    -- Their absence corresponds to the case where the condition is not true.
    tdd384-Measurements                 BOOLEAN                             OPTIONAL,
    tdd128-Measurements                 BOOLEAN                             OPTIONAL,
    gsm-Measurements                    GSM-Measurements                    OPTIONAL,
    multiCarrierMeasurements            BOOLEAN                             OPTIONAL
}

COUNT-C-List ::=                        SEQUENCE (SIZE (1..maxCNdomains)) OF
                                        COUNT-CSingle

COUNT-CSingle ::=                       SEQUENCE {
    cn-DomainIdentity                   CN-DomainIdentity,
    count-C                             BIT STRING (SIZE (32))
}

DL-PhysChCapabilityFDD-r4 ::=       SEQUENCE {
    -- The IE 'maxNoDPCH-PDSCH-Codes' only gives information on the maximum number of DPCH Codes.
    maxNoDPCH-PDSCH-Codes               INTEGER (1..8),
    maxNoPhysChBitsReceived             MaxNoPhysChBitsReceived,
    supportForSF-512                    BOOLEAN,
    -- dummy, dummy2 and dummy3 are not used in this version of the specification,
    -- they should not be sent and if received they should be ignored.
    dummy                               BOOLEAN,
    dummy2                              SimultaneousSCCPCH-DPCH-Reception,
    dummy3                              SupportOfDedicatedPilotsForChEstimation     OPTIONAL
}

DL-PhysChCapabilityFDD-r5 ::=       SEQUENCE {
    -- The IE 'maxNoDPCH-PDSCH-Codes' only gives information on the maximum number of DPCH Codes.
    maxNoDPCH-PDSCH-Codes               INTEGER (1..8),
    maxNoPhysChBitsReceived             MaxNoPhysChBitsReceived,
    supportForSF-512                    BOOLEAN,
    -- dummy, dumy2 and dummy3 are not used in this version of the specification,
    -- they should not be sent and if received they should be ignored.
    dummy                               BOOLEAN,
    dummy2                              SimultaneousSCCPCH-DPCH-Reception,
    dummy3                              SupportOfDedicatedPilotsForChEstimation     OPTIONAL,
    fdd-hspdsch                         CHOICE {
        supported                           SEQUENCE {
            hsdsch-physical-layer-category      HSDSCH-physical-layer-category,
            -- dummy and dummy2 are not used in this version of the specification
            -- they should not be sent and if received they should be ignored.
            dummy                               BOOLEAN,
            dummy2                              BOOLEAN
        },
        unsupported                         NULL
    }
}

DL-PhysChCapabilityTDD-r5 ::=       SEQUENCE {
```

```
    maxTS-PerFrame                      MaxTS-PerFrame,
    maxPhysChPerFrame                   MaxPhysChPerFrame,
    minimumSF                           MinimumSF-DL,
    supportOfPDSCH                      BOOLEAN,
    maxPhysChPerTS                      MaxPhysChPerTS,
    tdd384-hspdsch                      CHOICE {
        supported                           HSDSCH-physical-layer-category,
        unsupported                         NULL
    }
}

DL-PhysChCapabilityTDD-LCR-r5 ::=   SEQUENCE {
    maxTS-PerSubFrame                   MaxTS-PerSubFrame-r4,
    maxPhysChPerFrame                   MaxPhysChPerSubFrame-r4,
    minimumSF                           MinimumSF-DL,
    supportOfPDSCH                      BOOLEAN,
    maxPhysChPerTS                      MaxPhysChPerTS,
    supportOf8PSK                       BOOLEAN,
    tdd128-hspdsch                      CHOICE {
        supported                           HSDSCH-physical-layer-category,
        unsupported                         NULL
    }
}

DL-RFC3095-Context ::=              SEQUENCE {
    rfc3095-Context-Identity            INTEGER (0..16383),
    dl-mode                             ENUMERATED {u, o, r},
    dl-ref-ir                           OCTET STRING ( SIZE (1..3000)),
    dl-ref-time                         INTEGER (0..4294967295)     OPTIONAL,
    dl-curr-time                        INTEGER (0..4294967295)     OPTIONAL,
    dl-syn-offset-id                    INTEGER (0..65535)          OPTIONAL,
    dl-syn-slope-ts                     INTEGER (0..4294967295)     OPTIONAL,
    dl-dyn-changed                      BOOLEAN
}

ImplementationSpecificParams ::=    BIT STRING (SIZE (1..512))


IntegrityProtectionStatus ::=       ENUMERATED {
                                        started, notStarted }

InterRAT-UE-RadioAccessCapabilityList-r5 ::=    SEQUENCE {
    interRAT-UE-RadioAccessCapability   InterRAT-UE-RadioAccessCapabilityList,
    geranIu-RadioAccessCapability       GERANIu-RadioAccessCapability               OPTIONAL
}

IntraFreqReportingCriteria-r6-ext ::= SEQUENCE {
    -- The content of the v690 non-critical extension should be
    -- considered as an extension of IE IntraFreqEventCriteriaList
    event                               Event1j-r6,
    hysteresis                          Hysteresis,
    timeToTrigger                       TimeToTrigger,
    reportingCellStatus                 ReportingCellStatus                 OPTIONAL
}

-- dummy is not used in this version of the specification, it should
-- not be sent and if received it should be ignored.
MaxHcContextSpace-r5 ::=            ENUMERATED {
                                        dummy, by1024, by2048, by4096, by8192,
                                        by16384, by32768, by65536, by131072 }

MeasurementCapability-r4 ::=        SEQUENCE {
    downlinkCompressedMode              CompressedModeMeasCapability-r4,
    uplinkCompressedMode                CompressedModeMeasCapability-r4
}

MeasurementCommandWithType ::=      CHOICE {
    setup                               MeasurementType,
    modify                              NULL,
    release                             NULL
}

MeasurementCommandWithType-r4 ::=   CHOICE {
    setup                               MeasurementType-r4,
    modify                              NULL,
    release                             NULL
}
```

```
MeasurementCommandWithType-r6 ::=   CHOICE {
    setup                               MeasurementType-r6,
    modify                              NULL,
    release                             NULL
}

OngoingMeasRep ::=                  SEQUENCE {
    measurementIdentity                 MeasurementIdentity,
    -- TABULAR: The CHOICE Measurement in the tabular description is included
    -- in MeasurementCommandWithType
    measurementCommandWithType          MeasurementCommandWithType,
    measurementReportingMode            MeasurementReportingMode            OPTIONAL,
    additionalMeasurementID-List        AdditionalMeasurementID-List        OPTIONAL
}

OngoingMeasRep-r4 ::=               SEQUENCE {
    measurementIdentity                 MeasurementIdentity,
    -- TABULAR: The CHOICE Measurement in the tabular description is included
    -- in MeasurementCommandWithType-r4.
    measurementCommandWithType          MeasurementCommandWithType-r4,
    measurementReportingMode            MeasurementReportingMode            OPTIONAL,
    additionalMeasurementID-List        AdditionalMeasurementID-List        OPTIONAL
}

OngoingMeasRep-r5 ::=               SEQUENCE {
    measurementIdentity                 MeasurementIdentity,
    -- TABULAR: The CHOICE Measurement in the tabular description is included
    -- in MeasurementCommandWithType-r4.
    measurementCommandWithType          MeasurementCommandWithType-r4,
    measurementReportingMode            MeasurementReportingMode            OPTIONAL,
    additionalMeasurementID-List        AdditionalMeasurementID-List        OPTIONAL,
    measurementCommand-v590ext          CHOICE {
        -- the choice "intra-frequency" shall be used for the case of intra-frequency measurement,
        -- as well as when intra-frequency events are configured for inter-frequency measurement
        intra-frequency                     Intra-FreqEventCriteriaList-v590ext,
        inter-frequency                     Inter-FreqEventCriteriaList-v590ext
    }       OPTIONAL,
    intraFreqReportingCriteria-1b-r5    IntraFreqReportingCriteria-1b-r5    OPTIONAL,
    intraFreqEvent-1d-r5                IntraFreqEvent-1d-r5                OPTIONAL
}

OngoingMeasRep-r6 ::=               SEQUENCE {
    measurementIdentity                 MeasurementIdentity,
    measurementCommandWithType          MeasurementCommandWithType-r6,
    measurementReportingMode            MeasurementReportingMode            OPTIONAL,
    additionalMeasurementID-List        AdditionalMeasurementID-List        OPTIONAL
}

OngoingMeasRepList ::=              SEQUENCE (SIZE (1..maxNoOfMeas)) OF
                                        OngoingMeasRep

OngoingMeasRepList-r4 ::=           SEQUENCE (SIZE (1..maxNoOfMeas)) OF
                                        OngoingMeasRep-r4

OngoingMeasRepList-r5 ::=           SEQUENCE (SIZE (1..maxNoOfMeas)) OF
                                        OngoingMeasRep-r5

OngoingMeasRepList-r6 ::=           SEQUENCE (SIZE (1..maxNoOfMeas)) OF
                                        OngoingMeasRep-r6

PDCP-Capability-r4 ::=              SEQUENCE {
    losslessSRNS-RelocationSupport      BOOLEAN,
    supportForRfc2507                   CHOICE {
        notSupported                        NULL,
        supported                           MaxHcContextSpace
    },
    supportForRfc3095                   CHOICE {
        notSupported                        NULL,
        supported                           SEQUENCE {
            maxROHC-ContextSessions             MaxROHC-ContextSessions-r4  DEFAULT s16,
            reverseCompressionDepth             INTEGER (0..65535)          DEFAULT 0
        }
    }
}

PDCP-Capability-r5 ::=              SEQUENCE {
    losslessSRNS-RelocationSupport      BOOLEAN,
    supportForRfc2507                   CHOICE {
```

```
        notSupported                        NULL,
        supported                           MaxHcContextSpace-r5
    },
    supportForRfc3095                   CHOICE {
        notSupported                        NULL,
        supported                           SEQUENCE {
            maxROHC-ContextSessions             MaxROHC-ContextSessions-r4  DEFAULT s16,
            reverseCompressionDepth             INTEGER (0..65535)          DEFAULT 0,
            supportForRfc3095ContextRelocation  BOOLEAN
        }
    }
}

PDCP-Capability-r6 ::=              SEQUENCE {
    losslessSRNS-RelocationSupport      BOOLEAN,
    losslessDLRLC-PDUSizeChange         ENUMERATED { true }                 OPTIONAL,
    supportForRfc2507                   CHOICE {
        notSupported                        NULL,
        supported                           MaxHcContextSpace-r5
    },
    supportForRfc3095                   CHOICE {
        notSupported                        NULL,
        supported                           SEQUENCE {
            maxROHC-ContextSessions             MaxROHC-ContextSessions-r4  DEFAULT s16,
            reverseCompressionDepth             INTEGER (0..65535)          DEFAULT 0,
            supportForRfc3095ContextRelocation  BOOLEAN
        }
    }
}

PhysicalChannelCapability-r4 ::=        SEQUENCE {
        fddPhysChCapability                 SEQUENCE {
            downlinkPhysChCapability            DL-PhysChCapabilityFDD-r4,
            uplinkPhysChCapability              UL-PhysChCapabilityFDD
        }                                           OPTIONAL,
        tdd384-PhysChCapability             SEQUENCE {
            downlinkPhysChCapability            DL-PhysChCapabilityTDD,
            uplinkPhysChCapability              UL-PhysChCapabilityTDD
        }                                           OPTIONAL,
        tdd128-PhysChCapability             SEQUENCE {
            downlinkPhysChCapability            DL-PhysChCapabilityTDD-LCR-r4,
            uplinkPhysChCapability              UL-PhysChCapabilityTDD-LCR-r4
        }                                           OPTIONAL
}

PhysicalChannelCapability-r5 ::=        SEQUENCE {
        fddPhysChCapability                 SEQUENCE {
            downlinkPhysChCapability            DL-PhysChCapabilityFDD-r5,
            uplinkPhysChCapability              UL-PhysChCapabilityFDD
        }                                           OPTIONAL,
        tdd384-PhysChCapability             SEQUENCE {
            downlinkPhysChCapability            DL-PhysChCapabilityTDD-r5,
            uplinkPhysChCapability              UL-PhysChCapabilityTDD
        }                                           OPTIONAL,
        tdd128-PhysChCapability             SEQUENCE {
            downlinkPhysChCapability            DL-PhysChCapabilityTDD-LCR-r5,
            uplinkPhysChCapability              UL-PhysChCapabilityTDD-LCR-r4
        }                                           OPTIONAL
}

RF-Capability-r4 ::=                SEQUENCE {
        fddRF-Capability                SEQUENCE {
            ue-PowerClass                   UE-PowerClassExt,
            txRxFrequencySeparation         TxRxFrequencySeparation
        }                                                               OPTIONAL,
        tdd384-RF-Capability            SEQUENCE {
            ue-PowerClass                   UE-PowerClassExt,
            radioFrequencyBandTDDList       RadioFrequencyBandTDDList,
            chipRateCapability              ChipRateCapability
        }                                                               OPTIONAL,
        tdd128-RF-Capability            SEQUENCE {
            ue-PowerClass                   UE-PowerClassExt,
            radioFrequencyBandTDDList       RadioFrequencyBandTDDList,
            chipRateCapability              ChipRateCapability
        }                                                               OPTIONAL
}

RFC3095-ContextInfo ::=             SEQUENCE {
```

```
    rb-Identity                         RB-Identity,
    rfc3095-Context-List                RFC3095-Context-List
}

RFC3095-Context-List ::=            SEQUENCE (SIZE (1..maxRFC3095-CID)) OF SEQUENCE {
    dl-RFC3095-Context                  DL-RFC3095-Context      OPTIONAL,
    ul-RFC3095-Context                  UL-RFC3095-Context      OPTIONAL
}

RLC-Capability-r5 ::=               SEQUENCE {
    totalRLC-AM-BufferSize              TotalRLC-AM-BufferSize-r5,
    maximumRLC-WindowSize               MaximumRLC-WindowSize,
    maximumAM-EntityNumber              MaximumAM-EntityNumberRLC-Cap
}


SRB-SpecificIntegrityProtInfo ::=   SEQUENCE {
    ul-RRC-HFN                          BIT STRING (SIZE (28)),
    dl-RRC-HFN                          BIT STRING (SIZE (28)),
    ul-RRC-SequenceNumber               RRC-MessageSequenceNumber,
    dl-RRC-SequenceNumber               RRC-MessageSequenceNumber
}

SRB-SpecificIntegrityProtInfoList ::= SEQUENCE (SIZE (4..maxSRBsetup)) OF
                                        SRB-SpecificIntegrityProtInfo

StateOfRRC ::=                      ENUMERATED {
                                        cell-DCH, cell-FACH,
                                        cell-PCH, ura-PCH }

StateOfRRC-Procedure ::=            ENUMERATED {
                                        awaitNoRRC-Message,
                                        awaitRB-ReleaseComplete,
                                        awaitRB-SetupComplete,
                                        awaitRB-ReconfigurationComplete,
                                        awaitTransportCH-ReconfigurationComplete,
                                        awaitPhysicalCH-ReconfigurationComplete,
                                        awaitActiveSetUpdateComplete,
                                        awaitHandoverComplete,
                                        sendCellUpdateConfirm,
                                        sendUraUpdateConfirm,
                                        -- dummy is not used in this version of specification
                                        -- It should not be sent
                                        dummy,
                                        otherStates
}

TotalRLC-AM-BufferSize-r5 ::=       ENUMERATED {
                                        kb10, kb50, kb100, kb150, kb200,
                                        kb300, kb400, kb500, kb750, kb1000 }

TPC-Combination-Info ::= SEQUENCE {
        primaryCPICH-Info                   PrimaryCPICH-Info,
        tpc-CombinationIndex                TPC-CombinationIndex
}

UE-MultiModeRAT-Capability-r5 ::=   SEQUENCE {
    multiRAT-CapabilityList             MultiRAT-Capability,
    multiModeCapability                 MultiModeCapability,
    supportOfUTRAN-ToGERAN-NACC         BOOLEAN
}

UE-Positioning-Capability-r4 ::=    SEQUENCE {
    standaloneLocMethodsSupported           BOOLEAN,
    ue-BasedOTDOA-Supported                 BOOLEAN,
    networkAssistedGPS-Supported            NetworkAssistedGPS-Supported,
    supportForUE-GPS-TimingOfCellFrames     BOOLEAN,
    supportForIPDL                          BOOLEAN,
    rx-tx-TimeDifferenceType2Capable        BOOLEAN,
    validity-CellPCH-UraPCH                 ENUMERATED { true }     OPTIONAL,
    sfn-sfnType2Capability                  ENUMERATED { true }         OPTIONAL
}

UE-Positioning-LastKnownPos ::=     SEQUENCE {
        sfn                             INTEGER (0..4095),
        cell-id                         CellIdentity,
        positionEstimate                PositionEstimate
}
```

```
UE-RadioAccessCapability-r4 ::=     SEQUENCE {
    accessStratumReleaseIndicator       AccessStratumReleaseIndicator,
    pdcp-Capability                     PDCP-Capability-r4,
    rlc-Capability                      RLC-Capability,
    transportChannelCapability          TransportChannelCapability,
    rf-Capability                       RF-Capability-r4,
    physicalChannelCapability           PhysicalChannelCapability-r4,
    ue-MultiModeRAT-Capability          UE-MultiModeRAT-Capability,
    securityCapability                  SecurityCapability,
    ue-positioning-Capability           UE-Positioning-Capability-r4,
    measurementCapability               MeasurementCapability-r4        OPTIONAL
}

UE-RadioAccessCapability-r5 ::=     SEQUENCE {
    accessStratumReleaseIndicator       AccessStratumReleaseIndicator,
    dl-CapabilityWithSimultaneousHS-DSCHConfig
                                        DL-CapabilityWithSimultaneousHS-DSCHConfig  OPTIONAL,
    pdcp-Capability                     PDCP-Capability-r5,
    rlc-Capability                      RLC-Capability-r5,
    transportChannelCapability          TransportChannelCapability,
    rf-Capability                       RF-Capability-r4,
    physicalChannelCapability           PhysicalChannelCapability-r5,
    ue-MultiModeRAT-Capability          UE-MultiModeRAT-Capability-r5,
    securityCapability                  SecurityCapability,
    ue-positioning-Capability           UE-Positioning-Capability-r4,
    measurementCapability               MeasurementCapability-r4        OPTIONAL
}

UE-RadioAccessCapability-r6 ::=     SEQUENCE {
    accessStratumReleaseIndicator       AccessStratumReleaseIndicator,
    dl-CapabilityWithSimultaneousHS-DSCHConfig
                                        DL-CapabilityWithSimultaneousHS-DSCHConfig  OPTIONAL,
    pdcp-Capability                     PDCP-Capability-r6,
    rlc-Capability                      RLC-Capability-r5,
    transportChannelCapability          TransportChannelCapability,
    rf-Capability                       RF-Capability-r4,
    physicalChannelCapability           PhysicalChannelCapability-r5,
    ue-MultiModeRAT-Capability          UE-MultiModeRAT-Capability-r5,
    securityCapability                  SecurityCapability,
    ue-positioning-Capability           UE-Positioning-Capability-r4,
    measurementCapability               MeasurementCapability-r4        OPTIONAL
}

UL-RFC3095-Context ::=              SEQUENCE {
    rfc3095-Context-Identity            INTEGER (0..16383),
    ul-mode                             ENUMERATED {u, o, r},
    ul-ref-ir                           OCTET STRING ( SIZE (1..3000)),
    ul-ref-time                         INTEGER (0..4294967295)     OPTIONAL,
    ul-curr-time                        INTEGER (0..4294967295)     OPTIONAL,
    ul-syn-offset-id                    INTEGER (0..65535)          OPTIONAL,
    ul-syn-slope-ts                     INTEGER (0..4294967295)     OPTIONAL,
    ul-ref-sn-1                         INTEGER (0..65535)          OPTIONAL
}

END
```

# 12 Message transfer syntax

Transfer syntax for RRC PDUs is derived from their ASN.1 definitions by use of Packed Encoding Rules, unaligned as specified in X.691 [49], and with adapted final padding. If special encoding is used, it is indicated in the ECN module defined for each ASN.1 module. The use of special encoding is defined in [14].

The following encoding rules apply in addition to what has been specified in X.691 [49]:

- When a bit string value is placed in a bit-field as specified in 15.6 to 15.11 in [11], the leading bit of the bit string value shall be placed in the leading bit of the bit-field, and the trailing bit of the bit string value shall be placed in the trailing bit of the bit-field.

NOTE: The terms "leading bit" and "trailing bit" are defined in ITU-T Rec. X.680 | ISO/IEC 8824-1. When using the "bstring" notation, the leading bit of the bit string value is on the left, and the trailing bit of the bit string value is on the right.

# 12.1 Structure of encoded RRC messages

An RRC PDU, which is the bit string that is exchanged between peer entities/ across the radio interface, is the concatenation of a basic production, an extension and padding, in that order.

RRC PDUs shall be mapped to and from RLC SDUs upon transmission and reception as follows:

- when delivering an RRC PDU as an RLC SDU to the RLC layer for transmission, the first bit of the RRC PDU shall be represented as the first bit in the RLC SDU and onwards; and
- upon reception of an RLC SDU from the RLC layer, the first bit of the RLC SDU shall represent the first bit of the RRC PDU and onwards.

## 12.1.1 Basic production

The 'basic production' is obtained by applying UNALIGNED PER to the abstract syntax value (the ASN.1 description) as specified in X.691, except for the 0 to 7 bits added at the end to produce a multiple of 8 bits. The basic production can have any positive number of bits, not necessarily a multiple of 8 bits.

## 12.1.2 Extension

Emitters compliant with this version of the specification of the protocol shall, unless indicated otherwise on a PDU type basis, set the extension part empty. Emitters compliant with a later version might send non-empty extensions.

## 12.1.3 Padding

Emitters compliant with this version of the specification of the protocol shall, unless indicated otherwise on a PDU type basis, pad the basic production with the smallest number of bits required to meet the size constraints of the lower layers. Padding bits shall be set to 0.

Receivers compliant with this version of the specification have no need to distinguish the extension and padding parts, and shall, unless indicated otherwise on a PDU type basis, accept RRC PDUs with any bit string in the extension and padding parts.




**Figure 12.1.3-1: Padding**

When using AM or UM mode, RLC requires that the RRC PDU length is a multiple of 8 bits.

When using Tr mode, RLC does neither impose size requirements nor perform padding. This implies that RRC has to take into account the transport format set defined for the transport channel across which the message is to be sent. RRC shall add the lowest number of padding bits required to fit the size specified for the selected transport format.

For system information blocks, building the PDU involves two steps. The first step is the building of the System Information Blocks, in which step padding is not applied (the rules for extension apply). The second step is the building of the RRC PDUs, involving segmentation and concatenation of System Information Blocks, and then padding as described above for Tr mode. The procedure is shown by means of an example as described in Figure 12.1.3-2. The example includes two System Information Blocks, SIBn and SIBn+1, of which only SIBn includes a protocol extension. The two System Information Blocks used in the example do not require segmentation and are concatenated into one SYSTEM INFORMATION message.




**Figure 12.1.3-2: Padding for System Information**

PCI: Protocol control information at SYSTEM INFORMATION message level

SI: SYSTEM INFORMATION message

For system information blocks, RRC may also add padding information at the end of IE "SIB data fixed", used both within IE "Last segment" and IE "Complete SIB". The IE "SIB data fixed" has a fixed length i.e. no length denominator used. In case the remaining amount of "SIB data" information is insufficient to fill the IE completely, RRC includes padding bits.

Since no length denominator is included, the receiving RRC cannot remove the padding added by the sender. However, since the padding used is the same as the padding added by the PER encoder to achieve octet alignment, the receiver can handle it.

NOTE 1 The mechanism described above implies that the PDU provided to the ASN.1 decoder may have more than 7 padding bits included. For a complete System Information Block of length 215 bits, 11 padding bits are added by RRC. Since the decoder requires an octet aligned input, 6 additional bits need to be added. In this (worst) case, a total of 17 padding bits is included.

NOTE 2 For the above cases, use of padding bits is possible and more efficient than including a length denominator.

When using the RRC padding described above, the segment has a fixed length, which completely fills the transport block. Therefore, in this case no RRC padding is added within the SYSTEM INFORMATION message. This is illustrated by means of the following figure.




**Figure 12.1.3-3: No RRC padding for System Information**

# 12.2 ECN link module for RRC

```
RRC-ECN-Link-Module LINK-DEFINITIONS ::=
BEGIN

IMPORTS
    RRC-encodings               -- Encoding objects for RRC messages
FROM RRC-Encoding-Definitions;

ENCODE Class-definitions
    WITH RRC-encodings
    COMPLETED BY PER-BASIC-UNALIGNED

ENCODE PDU-definitions
    WITH RRC-encodings
    COMPLETED BY PER-BASIC-UNALIGNED

ENCODE InformationElements
    WITH RRC-encodings
    COMPLETED BY PER-BASIC-UNALIGNED
```

```
ENCODE Internode-definitions
    WITH RRC-encodings
    COMPLETED BY PER-BASIC-UNALIGNED

END
```

## 12.3 ECN modules for RRC

The encoding definition module "RRC-Encoding-Definitions" contains definition of the encoding object set "RRC-encodings". The encoding object set contains all the specialized encoding for RRC.

```
RRC-Encoding-Definitions ENCODING-DEFINITIONS ::=

BEGIN

EXPORTS
    RRC-encodings;

RRC-encodings #ENCODINGS ::= {
    -- Trailing bits
    outer-encoding
}

--************************************************************
--
-- The trailing bits in all RRC messages shall be ignored
-- (including unknown message contents & unknown extensions).
-- This overrides the default PER behaviour which pads the last
-- octet with zero bits.
--
--************************************************************

outer-encoding #OUTER ::= {
    ENCODER-DECODER {
    }
    DECODE AS IF {
        POST-PADDING    encoder-option
    }
}

END

Class-definitions-ECN-Module ENCODING-DEFINITIONS ::=
BEGIN
END

PDU-definitions-ECN-Module ENCODING-DEFINITIONS ::=
BEGIN
END

InformationElements-ECN-Module ENCODING-DEFINITIONS ::=
BEGIN
END


Internode-definitions-ECN-Module ENCODING-DEFINITIONS ::=
BEGIN
END
```

## 12.4 RRC messages encoded otherwise

NOTE: The messages included in this section are not specified by means of ASN.1.

### 12.4.1 Messages using tabular encoding specification

The encoding of the message is specified by means of a table listing the information elements known in the message and their order of their appearance in the message.

When a field extends over more than one octet, the order of bit values progressively decreases as the octet number increases. The least significant bit of the field is represented by the lowest numbered bit of the highest numbered octet of the field.

#### 12.4.1.1 TRANSPORT FORMAT COMBINATION CONTROL using transparent DCCH

##### 12.4.1.1.1 TRANSPORT FORMAT COMBINATION CONTROL, 3 bit format

The 3 bit format is as follows:

| **3** | **2** | **1** | Transport Format Combination Set Identity value |
|---|---|---|---|
| 0 | 0 | 0 | 0 |
| 0 | 0 | 1 | 1 |
| 0 | 1 | 0 | 2 |
| | | | |
| 1 | 1 | 1 | 7 |

##### 12.4.1.1.2 Void

##### 12.4.1.1.3 Void

# 13 Protocol timers, counters, other parameters and default configurations

The information provided in subclauses 13.1 and 13.2 shall be treated as informative. The normative text is specified in the relevant subclauses in clause 8 and clause 8 shall prevail.

## 13.1 Timers for UE

| Timer | Start | Stop | At expiry |
|---|---|---|---|
| T300 | Transmission of RRC CONNECTION REQUEST in case of connection establishment for reasons other than MBMS reception | Reception of RRC CONNECTION SETUP | Retransmit RRC CONNECTION REQUEST if V300 =< N300, else go to Idle mode |
| T302 | Transmission of CELL UPDATE/URA UPDATE | Reception of CELL UPDATE CONFIRM/URA UPDATE CONFIRM | Retransmit CELL UPDATE/URA UPDATE if V302 =< N302, else, go to Idle mode |
| T304 | Transmission of UE CAPABILITY INFORMATION | Reception of UE CAPABILITY INFORMATION CONFIRM | Retransmit UE CAPABILITY INFORMATION if V304 =< N304, else initiate a cell update procedure |
| T305 | Entering CELL_FACH or URA_PCH or CELL_PCH state. Reception of CELL UDPATE CONFIRM/URA UPDATE CONFIRM. | Entering another state. | Transmit CELL UPDATE if T307 is not activated and the UE detects "in service area". Otherwise, if T307 is not active, start T307. |
| T307 | When the timer T305 has expired and the UE detects "out of service area". | When the UE detects "in service area". | Transit to idle mode |
| T308 | Transmission of RRC CONNECTION RELEASE COMPLETE | Not stopped | Transmit RRC CONNECTION RELEASE COMPLETE if V308 <=N308, else go to idle mode. |
| T309 | Upon reception of CELL CHANGE ORDER FROM UTRAN message | Successful response to a connection establishment request in the new cell. | Resume the connection to UTRAN |
| T310 | Transmission of PUSCH CAPACITY REQUEST | Reception of PHYSICAL SHARED CHANNEL ALLOCATION | Transmit PUSCH CAPACITY REQUEST if V310 =< N310, else procedure stops. |
| T311 | Reception of PHYSICAL SHARED CHANNEL ALLOCATION message with the CHOICE "*PUSCH allocation*" set to "PUSCH allocation pending". | Reception of PHYSICAL SHARED CHANNEL ALLOCATION message with CHOICE "*PUSCH allocation*" set to "PUSCH allocation assignment". | UE may initiate a PUSCH capacity request procedure. |
| T312 | When the UE starts to establish dedicated CH | When the UE detects N312 "in sync" indication from L1. | The criteria for physical channel establishment failure is fulfilled |
| T313 | When the UE detects consecutive N313 "out of sync" indication from L1. | When the UE detects consecutive N315 "in sync" indication from L1. | The criteria for Radio Link failure is fulfilled. |
| T314 | When the criteria for radio link failure are fulfilled.<br>The timer is started if radio bearer(s) that are associated with T314 exist of if only RRC connection exists. | When the Cell Update procedure has been completed. | See subclause 8.3.1.13. |

| Timer | Start | Stop | At expiry |
|---|---|---|---|
| T315 | When the criteria for radio link failure are fulfilled.<br>The timer is started only if radio bearer(s) that are associated with T315 exist. | When the Cell Update procedure has been completed. | See subclause 8.3.1.14. |
| T316 | When the UE detects "out of service area" in URA_PCH or CELL_PCH state | When the UE detects "in service area". | Initiate cell update procedure if in service area is detected. Otherwise start timer T317, transit to CELL_FACH state and initiate cell update procedure when the UE detects "in service area". |
| T317 | When the T316 expires or when in CELL_FACH state, the UE detects "out of service area". | When the UE detects "in service area". | T317 never expires. |
| T318 | Transmission of RRC CONNECTION REQUEST in case of connection establishment for MBMS reception | Reception of RRC CONNECTION SETUP | Enter idle mode |

## 13.2 Counters for UE

| Counter | Reset | Incremented | When reaching max value |
|---|---|---|---|
| V300 | When initiating the procedure RRC connection establishment | Upon expiry of T300. | When V300 > N300, the UE enters idle mode. |
| V302 | When initiating the procedure Cell update or URA update | Upon expiry of T302 | When V302 > N302 the UE enters idle mode. |
| V304 | When sending the first UE CAPABILITY INFORMATION message. | Upon expiry of T304 | When V304 > N304 the UE initiates the Cell update procedure |
| V308 | When sending the first RRC CONNECTION RELEASE COMPLETE message in a RRC connection release procedure. | Upon expiry of T308 | When V308 > N308 the UE stops re-transmitting the RRC CONNECTION RELEASE COMPLETE message. |
| V310 | When sending the first PUSCH CAPACITY REQUEST message in a PUSCH capacity request procedure | Upon expiry of T310 | When V310 > N310 the UE stops re-transmitting the PUSCH CAPACITY REQUEST message. |

## 13.3 UE constants and parameters

| Constant | Usage |
|---|---|
| N300 | Maximum number of retransmissions of the RRC CONNECTION REQUEST message |
| N302 | Maximum number of retransmissions of the CELL UPDATE / URA UPDATE message |
| N304 | Maximum number of retransmissions of the UE CAPABILITY INFORMATION message |
| N308 | Maximum number of retransmissions of the RRC CONNECTION RELEASE COMPLETE message |
| N310 | Maximum number of retransmission of the PUSCH CAPACITY REQUEST message |
| N312 | Maximum number of "in sync" received from L1. |
| N313 | Maximum number of successive "out of sync" received from L1. |
| N315 | Maximum number of successive "in sync" received from L1 during T313 is activated. |

## 13.4 UE variables

### 13.4.ob AM_RLC_ERROR_PENDING_RB234

This variable indicates whether an AM RLC unrecoverable error has been detected during the current cell update procedure on RB 2, 3, or 4.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| AM RLC error pending | MP | | Boolean | TRUE means an unrecoverable error was detected on AM RLC during the current cell update procedure..<br>Set to FALSE when the cell update procedure is completed. |

### 13.4.oc AM_RLC_ERROR_PENDING_RB5_AND_UP

This variable indicates whether an AM RLC unrecoverable error has been detected during the current cell update procedure on RB 5 or above.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| AM RLC error pending | MP | | Boolean | TRUE means an unrecoverable error was detected on AM RLC during the current cell update procedure..<br>Set to FALSE when the cell update procedure is completed. |

### 13.4.0 CELL_INFO_LIST

This variable contains cell information on intra-frequency, inter-frequency and inter-RAT cells, as received in messages System Information Block Type 11, System Information Block Type 12, and MEASUREMENT CONTROL.

The first position in Intra-frequency cell info list corresponds to Intra-frequency cell id 0, the second to Intra-frequency cell id 1, etc.

The first position in Inter-frequency cell info list corresponds to Inter-frequency cell id 0, the second to Inter-frequency cell id 1, etc.

The first position in Inter-RAT cell info list corresponds to Intra-frequency cell id 0, the second to Inter-RAT cell id 1, etc.

This variable shall be cleared at cell re-selection, when leaving UTRA RRC connected mode, when switched off as well as at selection of a new PLMN.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| Intra-frequency cell info | OP | 1..<maxCellMeas> | | | |
| >CHOICE *position status* | MP | | | | |
| >>Occupied | | | | | |
| >>>Cell info | MP | | Cell info 10.3.7.2 | | |
| >>Vacant | | | | No data | |
| Inter-frequency cell info | OP | 1..<maxCellMeas> | | | |
| >CHOICE *position status* | MP | | | | |
| >>Occupied | | | | | |
| >>>Frequency info | MP | | Frequency info 10.3.6.36 | | |
| >>>Cell info | MP | | Cell info 10.3.7.2 | | |
| >>Vacant | | | | No data | |
| Inter-RAT cell info list | OP | | | | REL-5 |
| >Inter-RAT cell info | OP | 1..<maxCellMeas> | | | |
| >>CHOICE *position status* | MP | | | | |
| >>>Occupied | | | | | |
| >>>>CHOICE *Radio Access Technology* | | | | | |
| >>>>>GSM | | | | | |
| >>>>>>Cell selection and re-selection info | MP | | Cell selection and re-selection info for SIB11/12 10.3.2.4 | | |
| >>>>>>BSIC | MP | | BSIC 10.3.8.2 | | |
| >>>>>>BCCH ARFCN | MP | | Integer (0..1023) | [43] | |
| >>>>>IS-2000 | | | | | |
| >>>>>>System specific measurement info | | | enumerated (frequency, timeslot, colour code, output power, PN offset) | For IS-2000, use fields from TIA/EIA/IS-2000.5, subclause 3. 7.3.3.2.27, *Candidate Frequency Neighbour List Message* | |
| >>>Vacant | | | | No data | |
| >CHOICE *indication status* | MP | | | | REL-5 |
| >>*Present* | | | | | REL-5 |
| >>>Inter-RAT cell info indicator | OP | | Integer (0..3) | | REL-5 |
| >>*Not present* | | | | No data | REL-5 |

## 13.4.00 Void

## 13.4.0a CELL_UPDATE_STARTED

This variable indicates whether a cell update or URA update procedure is in progress.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Cell update started | MP | | Boolean | TRUE means a cell or URA update procedure is in progress.<br>Set to FALSE when entering UTRA RRC connected mode.<br>Set to FALSE when leaving UTRA RRC connected mode. |

## 13.4.1 CIPHERING_STATUS

This variable contains information about the current status of ciphering in the UE.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Status for each CN domain | MP | <1 to maxCNDomains> | | |
| >CN domain identity | MP | | CN domain identity 10.3.1.1 | |
| >Status | MP | | Enumerated( Not started, Started) | Set to "Not started" when entering UTRA RRC connected mode.<br>Set to "Not started" when leaving UTRA RRC connected mode. |
| Reconfiguration | MP | | Boolean | TRUE means an RRC procedure performing reconfiguration of ciphering is ongoing.<br>Set to FALSE when entering UTRA RRC connected mode.<br>Set to FALSE when leaving UTRA RRC connected mode. |

## 13.4.2 Void

## 13.4.2a CONFIGURATION_INCOMPLETE

This variable indicates whether a received measurement control message contains invalid an incomplete measurement configuration.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Configuration incomplete | MP | | Boolean | TRUE: An incomplete configuration has been detected.<br>Set to FALSE when entering UTRA RRC connected mode.<br>Set to FALSE when leaving UTRA RRC connected mode. |

## 13.4.3 C_RNTI

This variable stores the assigned C-RNTI for this UE when in CELL_FACH state.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| C-RNTI | OP | | C-RNTI 10.3.3.8 | Cleared when entering UTRA RRC connected mode when not otherwise stated in the procedure.<br>Cleared when leaving UTRA RRC connected mode. |

## 13.4.3o DSAC_PARAM

This variable contains Domain Specific Access Restriction Parameters during the connected mode.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| CS Domain Specific Access Restriction | MP | | Domain Access Restriction 10.3.1.3b | This IE contains CS Domain Specific Access Restriction Parameters | REL-6 |
| PS Domain Specific Access Restriction | MP | | Domain Access Restriction 10.3.1.3b | This IE contains PS Domain Specific Access Restriction Parameters | REL-6 |

## 13.4.3a DSCH_RNTI

In TDD this variable stores the assigned DSCH-RNTI for this UE when in CELL_DCH state.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| DSCH-RNTI | OP | | DSCH-RNTI 10.3.3.9a | Cleared when entering UTRA RRC connected mode when not otherwise stated in the procedure.<br>Cleared when leaving UTRA RRC connected mode. |

## 13.4.4 Void

## 13.4.4o E_DCH_TRANSMISSION

This variable indicates whether E-DPDCH and E-DPCCH transmission procedures are ongoing. See subclause 8.5.28 for actions related to the setting of this variable.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| E-DCH transmission | MP | | Boolean | TRUE: E-DCH transmission is ongoing.<br>Set to FALSE when entering UTRA RRC connected mode when not otherwise stated in the procedure.<br>Set to FALSE when leaving UTRA RRC connected mode. | REL-6 |

## 13.4.4a E_RNTI

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| Primary E-RNTI | OP | | E-RNTI 10.3.3.10a | Cleared when entering UTRA RRC connected mode when not otherwise stated in the procedure.<br>Cleared when leaving UTRA RRC connected mode. | REL-6 |
| Secondary E-RNTI | OP | | E-RNTI 10.3.3.10a | Cleared when entering UTRA RRC connected mode when not otherwise stated in the procedure.<br>Cleared when leaving UTRA RRC connected mode. | REL-6 |

## 13.4.5 ESTABLISHED_RABS

This variable is used to store information about the established radio access bearers and signalling radio bearers in the UE.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| RAB information | OP | 1 to <maxRABsetup> | | For each RAB established.<br>Cleared when entering UTRA RRC connected mode when not otherwise stated in the procedure.<br>Cleared when leaving UTRA RRC connected mode. |
| >RAB info | MP | | RAB info 10.3.4.8 | |
| >RB information | MP | 1 to <maxRBperRAB> | | For each RB belonging to the RAB |
| >>RB identity | MP | | RB identity 10.3.4.16 | |
| >>Subflow | MP | | Integer(0..< | Reference to the RAB subflow |

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| | | | maxSubflow count>) | implemented by this RB |
| >>RB started | MD | | Enumerated( stopped, started) | Default value is started |
| Signalling radio bearer information | OP | 1 to < maxSRBsetup> | | In the order of RB0 and upwards.<br>Cleared when leaving UTRA RRC connected mode. |
| >RB started | MD | | Enumerated( stopped, started) | Default value is started |

## 13.4.5a ESTABLISHED_SIGNALLING_CONNECTIONS

This variable is used to store information about established signalling connections.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Signalling connection list | OP | 1 to <maxCNdomains> | | For each established signalling connection.<br>Cleared when entering UTRA RRC connected mode when not otherwise stated in the procedure.<br>Cleared when leaving UTRA RRC connected mode. |
| >Signalling connection identity | MP | | CN domain identity 10.3.1.1 | |

## 13.4.6 ESTABLISHMENT_CAUSE

This variable is used to store the cause for establishment of a signalling connection received by upper layers, to be used at RRC connection establishment or Initial Direct Transfer.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Establishment cause | OP | | Establishment cause 10.3.3.11 | Cleared when leaving UTRA RRC connected mode. |

## 13.4.7 FAILURE_CAUSE

This variable contains the cause for failure of a UE initiated procedure, to be reported in a retransmitted message.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Failure cause | OP | | Failure cause 10.3.3.13 | Cleared when entering UTRA RRC connected mode.<br>Cleared when leaving UTRA RRC connected mode. |

## 13.4.8 FAILURE_INDICATOR

This variable indicates whether the procedure has failed for a UE initiated procedure.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Failure indicator | MP | | Boolean | TRUE: Procedure has failed. Set to FALSE when entering UTRA RRC connected mode. Set to FALSE when leaving UTRA RRC connected mode. |

## 13.4.8o H_RNTI

This variable stores the assigned H-RNTI for this UE when in CELL-DCH state and a HS-DSCH transport channel has been allocated.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| H-RNTI | OP | | H-RNTI 10.3.3.14a | Cleared when entering UTRA RRC connected mode when not otherwise stated in the procedure. Cleared when leaving UTRA RRC connected mode. | REL-5 |

## 13.4.8oo HS_DSCH_RECEPTION

This variable indicates whether HS-SCCH and HS-DSCH reception procedures are ongoing. See subclause 8.5.25 for actions related to the setting of this variable.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| HS-DSCH reception | MP | | Boolean | TRUE: HS-DSCH reception is ongoing. Set to FALSE when entering UTRA RRC connected mode when not otherwise stated in the procedure. Set to FALSE when leaving UTRA RRC connected mode. | REL-5 |

## 13.4.8a INCOMPATIBLE_SECURITY_RECONFIGURATION

This variable indicates whether an incompatible simultaneous reconfiguration of a security function has been received.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Incompatible security reconfiguration | MP | | Boolean | TRUE: An incompatible simultaneous security reconfiguration has been detected.<br>Set to FALSE when entering UTRA RRC connected mode.<br>Set to FALSE when leaving UTRA RRC connected mode. |

## 13.4.9 INITIAL_UE_IDENTITY

In this variable the identity used by the UE when establishing an RRC connection is stored.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Initial UE identity | OP | | Initial UE identity 10.3.3.15 | Cleared when leaving UTRA RRC connected mode. |

## 13.4.9a INTEGRITY_PROTECTION_ACTIVATION_INFO

This variable contains information to be sent to UTRAN about when a new integrity protection configuration shall be activated in the uplink for signalling radio bearers in case of modification of integrity protection.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Uplink Integrity protection activation info | OP | | Integrity protection activation info 10.3.3.17 | Cleared when entering UTRA RRC connected mode.<br>Cleared when leaving UTRA RRC connected mode. |

## 13.4.10 INTEGRITY_PROTECTION_INFO

This variable contains information about the current status of the integrity protection in the UE.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Status | MP | | Enumerated( Not started, Started) | Set to "Not started" when entering UTRA RRC connected mode.<br>Set to "Not started" when leaving UTRA RRC connected mode. |
| Reconfiguration | MP | | Boolean | TRUE means a reconfiguration of integrity protection is ongoing.<br>Set to FALSE when entering UTRA RRC connected mode.<br>Set to FALSE when leaving UTRA RRC connected mode. |
| Signalling radio bearer specific integrity protection information | OP | 1 to <maxSRBsetup> | | When integrity protection is started, status information for RB0- RB4 in that order.<br>Cleared when entering UTRA RRC connected mode.<br>Cleared when leaving UTRA RRC connected mode. |
| >Uplink RRC HFN | MP | | Bit string (28) | |

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| >Downlink RRC HFN | MP | | Bit string (28) | |
| >Uplink RRC Message sequence number | MP | | Integer (0.. 15) | |
| >Downlink RRC Message sequence number | OP | | Integer (0.. 15) | |

## 13.4.10a INTER_RAT_HANDOVER_INFO_TRANSFERRED

This variable stores information about the inter RAT handover info that has been transferred to another RAT.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| Predefined configuration status information | OP | | Predefined configuration status information 10.3.4.5a | Cleared upon entering connected mode in another RAT | |
| Predefined configuration status information compressed | OP | | Predefined configuration status information compressed 10.3.4.5b | Cleared upon entering connected mode in another RAT | REL-5 |
| UE security information | OP | | UE security information 10.3.3.42b | Cleared upon entering connected mode in another RAT | |
| UE security information2 | OP | | UE security information2 10.3.3.42c | Cleared upon entering connected mode in another RAT | REL-6 |
| UE radio access capability | OP | | UE radio access capability 10.3.3.42 | Cleared upon entering connected mode in another RAT | |
| UE radio access capability extension | OP | | UE radio access capability extension 10.3.3.42a | Cleared upon entering connected mode in another RAT | |
| UE radio access capability compressed | OP | | UE radio access capability compressed 10.3.3.42o | | REL-5 |
| UE system specific capability | OP | 1 to <maxSystemCapability> | Inter-RAT UE radio access capability 10.3.8.7 | Cleared upon entering connected mode in another RAT | |
| >Inter-RAT UE radio access capability | MP | | Inter-RAT UE radio | | |

| | | | | | |
|---|---|---|---|---|---|
| | | | access capability 10.3.8.7 | | |

## 13.4.11 INVALID_CONFIGURATION

This variable indicates whether a received message contained an invalid configuration, by means of invalid values or invalid combinations of information elements.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Invalid configuration | MP | | Boolean | TRUE: An invalid configuration has been detected.<br>Set to FALSE when entering UTRA RRC connected mode.<br>Set to FALSE when leaving UTRA RRC connected mode. |

## 13.4.11a LATEST_CONFIGURED_CN_DOMAIN

This variable stores the CN-domain that was most recently configured to be used for ciphering and integrity protection.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Latest configured CN domain | OP | | CN domain identity 10.3.1.1 | Cleared when entering UTRA RRC connected mode when not stated otherwise in the procedure.<br>Cleared when leaving UTRA RRC connected mode. |

## 13.4.11b LATEST_CONFIGURED_SRB_DELAY_AND_PC_PREAMBLE

This variable stores the SRB delay and PC preamble to be used for establishing the DPCH after failure of hard handover, inter-RAT handover from UTRAN, or cell change order from UTRAN.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| SRB delay | OP | | Integer (0..7) | Cleared when entering UTRA RRC connected mode when not stated otherwise in the procedure. |
| PC preamble | OP | | Integer (0..7) | Cleared when entering UTRA RRC connected mode when not stated otherwise in the procedure. |

## 13.4.11c MBMS_ACTIVATED_services

This variable stores the MBMS multicast services the UE has joined as well as the MBMS broadcast services the UE is interested to receive. Whenever the list of joined multicast services and/ or interested broadcast services changes, upper layers provide an indication upon which the UE shall update the variable accordingly.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Activated service list | OP | 1 to <maxMBMS-Services> | | |
| >Service Identity | MP | | MBMS Service identity 10.3.9a.8 | |
| >Service type | MP | | Enumerated (Multicast, Broadcast) | |

## 13.4.11d MBMS_PREV_FREQUENCY_INFO

This variable stores the frequency information of the cell the UE is camped on, upon moving to the MBMS preferred layer indicated MBMS FLC preferred frequency information.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| PREV Frequency Information | | | | | |
| CHOICE *mode* | | | | | |
| >FDD cell | | | | | |
| >>UARFCN downlink (Nd) | MP | | Integer(0 .. 16383) | [21] | |
| >3.84 Mcps TDD cell | | | | | |
| >>UARFCN (Nt) | MP | | Integer(0 .. 16383) | [22] | |
| >1.28 Mcps TDD cell list | | | | | |
| >>UARFCN (Nt) | MP | | Integer(0 .. 16383) | [22] | |

## 13.4.12 MEASUREMENT_IDENTITY

This variable stores the measurements configured in the UE. For each configured measurement, the information below shall be stored.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| MEASUREMENT CONTROL | OP | | MEASUREMENT CONTROL 10.2.17, System Information Block type 11 10.2.48.8.12, System Information Block type 12 10.2.48.8.13 | Information as contained in these messages. Cleared when entering UTRA RRC connected mode when not stated otherwise in the procedure (8.4.1.8-8.4.1.9). Cleared when leaving UTRA RRC connected mode when not stated otherwise in the procedure (8.4.1.9a). |

## 13.4.13 Void

## 13.4.14 ORDERED_RECONFIGURATION

This variable stores information about an ongoing Reconfiguration procedure.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Ordered reconfiguration | MP | | Boolean | TRUE means that a Reconfiguration procedure is ongoing.<br>Set to FALSE when entering UTRA RRC connected mode.<br>Set to FALSE when leaving UTRA RRC connected mode. |

## 13.4.14a PDCP_ROHC_TARGET_MODE

This variable contains the ROHC target mode.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| Target Mode | OP | | Enumerated (O-mode, R-mode) | The UE shall only transit to the signalled mode for operation of ROHC as decribed in [36]. | REL-5 |

## 13.4.15 PDCP_SN_INFO

This variable contains PDCP receive sequence numbers for one or several radio bearers to be included in a response message to UTRAN.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| RB with PDCP information list | OP | 1 to <maxRBallRABs> | | Cleared when entering UTRA RRC connected mode.<br>Cleared when leaving UTRA RRC connected mode. |
| >RB with PDCP information | MP | | RB with PDCP information 10.3.4.22 | |

## 13.4.15a PHYSICAL_SHARED_CHANNEL_CONFIGURATION

This variable is used only for TDD to store information about the physical shared channel configuration in the UE.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| PUSCH configuration | OP | | | Cleared when entering and leaving UTRA RRC connected mode. |
| >PUSCH info | MP | | PUSCH info 10.3.6.63 | |
| >PUSCH Identity | OP | | Integer(1.. hiPUSCHIdentities) | |
| >PUSCH power control info | OP | | PUSCH power control info 10.3.6.65 | |
| PDSCH configuration | OP | | | Cleared when entering and leaving UTRA RRC connected mode. |
| >PDSCH Info | MP | | PDSCH Info 10.3.6.44 | |
| >PDSCH Identity | OP | | Integer(1..hiPDSCHidentities) | |
| >PDSCH power control info | OP | | PDSCH power control info 10.3.6.45 | |
| ISCP Timeslot list | OP | 1 to maxTS | | Cleared when entering and leaving UTRA RRC connected mode. |
| >Timeslot number | MP | | Timeslot number 10.3.6.84 | Timeslot numbers, for which the UE shall report the timeslot ISCP in PUSCH CAPACITY REQUEST message |

## 13.4.16 PROTOCOL_ERROR_INDICATOR

This variable indicates whether there exist a protocol error that is to be reported to UTRAN.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Protocol error indicator | MP | | Protocol error indicator 10.3.3.27 | Set to FALSE when entering UTRA RRC connected mode. Set to FALSE when leaving UTRA RRC connected mode. |

## 13.4.17 PROTOCOL_ERROR_INFORMATION

This variable contains diagnostics to be reported to UTRAN for a message that was not completely understood.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Protocol error information | OP | | Protocol error information 10.3.8.12 | Cleared when entering UTRA RRC connected mode. Cleared when leaving UTRA RRC connected mode. |

## 13.4.18 PROTOCOL_ERROR_REJECT

This variable indicates whether there has occurred a severe protocol error causing the ongoing procedure to fail.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Protocol error reject | MP | | Boolean | TRUE: a severe protocol error has occurred.<br>Set to FALSE when entering UTRA RRC connected mode.<br>Set to FALSE when leaving UTRA RRC connected mode. |

## 13.4.19 RB_TIMER_INDICATOR

This variable contains information to be sent to UTRAN if any of the timers T314 or T315 has expired when the UE sends a cell update with cause RL failure.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| RB timer indicator | OP | | RB timer indicator 10.3.3.28 | Cleared when entering UTRA RRC connected mode.<br>Cleared when leaving UTRA RRC connected mode. |

## 13.4.20 RB_UPLINK_CIPHERING_ACTIVATION_TIME_INFO

This variable contains information to be sent to UTRAN about when a new ciphering configuration shall be activated in the uplink for radio bearers using RLC-AM or RLC-UM.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| RB uplink ciphering activation time info | OP | | RB activation time info 10.3.4.13 | Cleared when entering UTRA RRC connected mode.<br>Cleared when leaving UTRA RRC connected mode. |

## 13.4.20a SECURITY_MODIFICATION

This variable contains information on which CN domain is affected by the ongoing security reconfiguration.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Status for each CN domain | MP | <1 to maxCNDomains> | | |
| >CN domain identity | MP | | CN domain identity 10.3.1.1 | |
| >Status | MP | | Enumerated( Affected, Not Affected) | |

## 13.4.21 Void

## 13.4.22 START_THRESHOLD

This variable contains information about the maximum allowed value of the START for a CN domain.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| THRESHOLD | OP | | Integer (0..1048576) | 20 bits.<br>Cleared when entering UTRA RRC connected mode when not stated otherwise in the procedure.<br>Cleared when leaving UTRA RRC connected mode. |

## 13.4.23 START_VALUE_TO_TRANSMIT

This variable contains the value of START for new radio bearer(s) to be transmitted in a response message.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| START | OP | | START 10.3.3.38 | Cleared when entering UTRA RRC connected mode.<br>Cleared when leaving UTRA RRC connected mode. |

## 13.4.24 TFC_SUBSET

This variable contains information about the TFC subset(s) applicable to the UE.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| CHOICE *mode* | MP | | | | |
| >FDD | | | | | |
| >>Current TFC subset | MP | | Transport Format Combination Subset 10.3.5.22 | Set to "Full transport format set" when entering UTRA RRC connected mode when not stated otherwise in the procedure. | |
| >>Duration | OP | | TFC Control duration 10.3.6.80 | Cleared when entering UTRA RRC connected mode. Cleared when leaving UTRA RRC connected mode. | |
| >>Default TFC subset | OP | | Transport Format Combination Subset 10.3.5.22 | The TFC subset to go back to when any temporary limitation is released.<br>Cleared when entering UTRA RRC connected mode. Cleared when leaving UTRA RRC connected mode. | |
| >>TFC subset list | MP | 1 to <maxTFCsub> | | | REL-4 |
| >>>TFC subset | MP | | Transport Format Combination Subset 10.3.5.22 | | REL-4 |
| >TDD | | | | | |
| >>TFCS list | MP | 1 to < maxCCTrCH > | | One TFCS is created when entering UTRA RRC connected mode when not stated otherwise in the procedure. | |

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| >>>TFCS identity | MP | | Transport Format Combination Set Identity 10.3.5.21 | "TFCS ID" is set to 1 when entering UTRA RRC connected mode when not stated otherwise in the procedure. "Shared channel indicator" is set to FALSE when entering UTRA RRC connected mode when not stated otherwise in the procedure. | |
| >>>Current TFC subset | MP | | Transport Format Combination Subset 10.3.5.22 | Set to "Full transport format set" when entering UTRA RRC connected mode when not stated otherwise in the procedure. | |
| >>>>Duration | OP | | TFC Control duration 10.3.6.80 | Cleared when entering UTRA RRC connected mode. Cleared when leaving UTRA RRC connected mode. | |
| >>>>Default TFC subset | OP | | Transport Format Combination Subset 10.3.5.22 | The TFC subset to go back to when any temporary limitation is released. Cleared when entering UTRA RRC connected mode. Cleared when leaving UTRA RRC connected mode. | |
| >>TFC subset list | MP | 1 to <maxTFCsub2> | | | REL-4 |
| >>>TFCS identity | MP | | Transport Format Combination Set Identity 10.3.5.21 | | REL-4 |
| >>>TFC subset | MP | | Transport Format Combination Subset 10.3.5.22 | | REL-4 |

## 13.4.25 TGPS_IDENTITY

This variable contains the configuration parameters of all the configured compressed mode transmission gap pattern sequences.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Transmission gap pattern sequence | OP | 1 to <maxTGPS> | | Cleared when entering UTRA RRC connected mode. Cleared when leaving UTRA RRC connected mode. |
| >TGPSI | MP | | TGPSI 10.3.6.82 | |
| >TGPS Status Flag | MP | | Enumerated( activate, deactivate) | This flag indicates whether the Transmission Gap Pattern Sequence shall be activated or |

| | | | | |
|---|---|---|---|---|
| | | | | deactivated. |
| > Current TGPS Status Flag | MP | | Enumerated( active, inactive) | This flag indicates the current status of the Transmission Gap Pattern Sequence, whether it is active or inactive |
| >TGCFN | CV-*Active* | | Integer (0..255) | Connection Frame Number of the first frame of the first pattern within the Transmission Gap Pattern Sequence. |
| >Transmission gap pattern sequence configuration parameters | MP | | | Information as contained in the IE group "Transmission gap pattern sequence configuration parameters" in IE "DPCH compressed mode info" 10.3.6.33. |

| Condition | Explanation |
|---|---|
| *Active* | This IE is mandatory present when the value of the IE "TGPS Status Flag" is "Activate" and not needed otherwise. |

## 13.4.26 TGSN_REPORTED

This variable specifies whether an IE "Proposed TGSN" was reported to the UTRAN

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Proposed TGSN reported | MP | | Boolean | Set to FALSE when entering UTRA RRC connected mode. Set to FALSE when leaving UTRA RRC connected mode. |

## 13.4.26a TIMERS_AND_CONSTANTS

This variable contains the values for all timers and constants used in connected mode.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| UE Timers and constants in connected mode | MD | | UE Timers and constants in connected mode 10.3.3.43 | Default value means that for all timers and constants<br>- for parameters with need MD, the defaults specified in 10.3.3.43 apply and<br>- for parameters with need OP, the parameters are absent.<br>All parameters are set to the default value when leaving UTRA RRC connected mode to another RAT. |

## 13.4.27 TRANSACTIONS

This variable stores the identifications of the ongoing RRC procedure transactions.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Accepted transactions | OP | 1 to <maxtransactions> | | Cleared when leaving UTRA RRC connected mode. |
| >Message type | MP | | Message Type | |
| >RRC transaction identifier | MP | | RRC transaction identifier 10.3.3.36 | |
| Rejected transactions | OP | 1 to <maxtransactions> | | Cleared when leaving UTRA RRC connected mode. |
| >Message type | MP | | Message Type | |
| >RRC transaction identifier | MP | | RRC transaction identifier 10.3.3.36 | |

## 13.4.27a TRIGGERED_1A_EVENT

This variable contains information about a 1a event that has been triggered in the UE. There is one such variable per 1a event configured in the UE.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Cells triggered | OP | 1 to < maxCellMeas> | | Cleared when entering UTRA RRC connected mode. Cleared when leaving UTRA RRC connected mode. |
| >primary CPICH | MP | | Primary CPICH info 10.3.6.60 | |
| >sent reports | MP | | Integer(1..Infinity) | Number of reports sent to UTRAN in case of event triggered periodical reporting |
| Cells recently triggered | OP | 1 to < maxCellMeas> | | |
| >primary CPICH | MP | | Primary CPICH info 10.3.6.60 | |
| >sent reports | MP | | Integer(1..Infinity) | Number of reports sent to UTRAN in case of event triggered periodical reporting |
| Periodical reporting running | MP | | Boolean | |

## 13.4.27b TRIGGERED_1B_EVENT

This variable contains information about a 1b event that has been triggered in the UE. There is one such variable per 1b event configured in the UE.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| Cells triggered | OP | 1 to < maxCell Meas> | | Cleared when entering UTRA RRC connected mode. Cleared when leaving UTRA RRC connected mode. | |
| >primary CPICH | MP | | Primary CPICH info 10.3.6.60 | | |
| >sent reports | MP | | Integer(1.. Infinity) | Number of reports sent to UTRAN in case of event triggered periodical reporting | REL-5 |
| Cells recently triggered | OP | 1 to < maxCell Meas> | | | REL-5 |
| >primary CPICH | MP | | Primary CPICH info 10.3.6.60 | | REL-5 |
| >sent reports | MP | | Integer(1.. Infinity) | Number of reports sent to UTRAN in case of event triggered periodical reporting. | REL-5 |
| Periodical reporting running | MP | | Boolean | | REL-5 |

## 13.4.27c TRIGGERED_1C_EVENT

This variable contains information about a 1c event that has been triggered in the UE. There is one such variable per 1c event configured in the UE.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Cells triggered | OP | 1 to < maxCellMeas> | | Cleared when entering UTRA RRC connected mode. Cleared when leaving UTRA RRC connected mode. |
| >primary CPICH | MP | | Primary CPICH info 10.3.6.60 | |
| >sent reports | MP | | Integer(1..Infinity) | Number of reports sent to UTRAN in case of event triggered periodical reporting |
| Cells recently triggered | OP | 1 to < maxCellMeas> | | |
| >primary CPICH | MP | | Primary CPICH info 10.3.6.60 | |
| >sent reports | MP | | Integer(1..Infinity) | Number of reports sent to UTRAN in case of event triggered periodical reporting |
| Periodical reporting running | MP | | Boolean | |

## 13.4.27d BEST_CELL_1D_EVENT

This variable contains information about a 1d event that has been triggered in the UE. There is one such variable per 1d event configured in the UE.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Best cell | OP | | Primary CPICH info 10.3.6.60 | Cleared when entering UTRA RRC connected mode. Cleared when leaving UTRA RRC connected mode. |

## 13.4.27e TRIGGERED_1E_EVENT

This variable contains information about a 1e event that has been triggered in the UE. There is one such variable per 1e event configured in the UE.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Cells triggered | OP | 1 to < maxCellMeas> | | Cleared when entering UTRA RRC connected mode. Cleared when leaving UTRA RRC connected mode. |
| >primary CPICH | MP | | Primary CPICH info 10.3.6.60 | |
| Cells recently triggered | OP | 1 to < maxCellMeas> | | |
| >primary CPICH | MP | | Primary CPICH info 10.3.6.60 | |

## 13.4.27f TRIGGERED_1F_EVENT

This variable contains information about a 1f event that has been triggered in the UE. There is one such variable per 1f event configured in the UE.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Cells triggered | OP | 1 to < maxCellMeas> | | Cleared when entering UTRA RRC connected mode. Cleared when leaving UTRA RRC connected mode. |
| >primary CPICH | MP | | Primary CPICH info 10.3.6.60 | |
| Cells recently triggered | OP | 1 to < maxCellMeas> | | |
| >primary CPICH | MP | | Primary CPICH info 10.3.6.60 | |

## 13.4.27f1 TRIGGERED_1G_EVENT

This variable contains information about a 1g event that has been triggered in the UE.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Cells triggered | OP | 1 to < maxCellMeas> | | |
| >Primary CCPCH info | MP | | Primary CCPCH info 10.3.6.57 | |

## 13.4.27f2 TRIGGERED_1H_EVENT

This variable contains information about a 1h event that has been triggered in the UE.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Cells triggered | OP | 1 to < maxCellMeas> | | |
| >Primary CCPCH info | MP | | Primary CCPCH info 10.3.6.57 | |

## 13.4.27f3 TRIGGERED_1I_EVENT

This variable contains information about a 1i event that has been triggered in the UE.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Cells triggered | OP | 1 to < maxCellMeas> | | |
| >Primary CCPCH info | MP | | Primary CCPCH info 10.3.6.57 | |

## 13.4.27f4 BEST_FREQUENCY_2A_EVENT

This variable contains information about a 2a event that has been configured in the UE. There is one such variable per 2a event configured in the UE.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Best frequency | MP | | Frequency info 10.3.6.36 | |

## 13.4.27f5 TRIGGERED_2B_EVENT

This variable contains information about a 2b event that has been configured in the UE. There is one such variable per 2b event configured in the UE.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Frequency triggered | OP | 1 to < maxCellMeas> | | |
| >Frequency | MP | Frequency info 10.3.6.36 | | |

## 13.4.27f6 TRIGGERED_2C_EVENT

This variable contains information about a 2c event that has been configured in the UE. There is one such variable per 2c event configured in the UE.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Frequency triggered | OP | 1 to < maxCellMeas> | | |
| >Frequency | MP | Frequency info 10.3.6.36 | | |

## 13.4.27f7 TRIGGERED_2D_EVENT

This variable contains information about a 2d event that has been configured in the UE. There is one such variable per 2d event configured in the UE.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Event triggered | OP | | Boolean | |

## 13.4.27f8 TRIGGERED_2E_EVENT

This variable contains information about a 2e event that has been configured in the UE. There is one such variable per 2e event configured in the UE.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Frequency triggered | OP | 1 to < maxCellMeas> | | |
| >Frequency | MP | Frequency info 10.3.6.36 | | |

## 13.4.27f9 TRIGGERED_2F_EVENT

This variable contains information about a 2f event that have been configured in the UE. There is one such variable per 2f event configured in the UE.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Event triggered | OP | | Boolean | |

## 13.4.27f10 TRIGGERED_3A_EVENT

This variable contains information about a 3a event that has been configured in the UE. There is one such variable per event 3a configured in the UE.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| CHOICE *system* | OP | | | |
| >GSM | | | | |
| >>CHOICE *BSIC* | MP | | | |
| >>>Verified BSIC | | 0 to <maxCellMeas> | | |
| >>>>Inter-RAT cell id | MP | | Integer(0..<maxCellMeas>-1) | |
| >>>Non verified BSIC | | 0 to <maxCellMeas> | | |
| >>>>BCCH ARFCN | MP | | Integer (0..1023) | |

## 13.4.27f11 TRIGGERED_3B_EVENT

This variable contains information about a 3b event that has been configured in the UE. There is one such variable per event 3b configured in the UE.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| CHOICE *system* | OP | | | |
| >GSM | | | | |
| >>CHOICE *BSIC* | MP | | | |
| >>>Verified BSIC | | 0 to <maxCellMeas> | | |
| >>>>Inter-RAT cell id | MP | | Integer(0..<maxCellMeas>-1) | |
| >>>Non verified BSIC | | 0 to <maxCellMeas> | | |
| >>>>BCCH ARFCN | MP | | Integer (0..1023) | |

## 13.4.27f12 TRIGGERED_3C_EVENT

This variable contains information about a 3c event that has been configured in the UE. There is one such variable per event 3c configured in the UE.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| CHOICE *system* | OP | | | |
| >GSM | | | | |
| >>CHOICE *BSIC* | MP | | | |
| >>>Verified BSIC | | 0 to <maxCellMeas> | | |
| >>>>Inter-RAT cell id | MP | | Integer(0..<maxCellMeas>-1) | |
| >>>Non verified BSIC | | 0 to <maxCellMeas> | | |
| >>>>BCCH ARFCN | MP | | Integer (0..1023) | |

## 13.4.27f13 BEST_CELL_3D_EVENT

This variable contains information about a 3d event that has been configured in the UE. There is one such variable per event 3a configured in the UE.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| CHOICE *system* | | | | |
| >GSM | | | | |
| >>CHOICE *BSIC* | MP | | | |
| >>>Verified BSIC | | | | |
| >>>>Inter-RAT cell id | MP | | Integer(0..< maxCellMeas>-1) | |
| >>>Non verified BSIC | | | | |
| >>>>BCCH ARFCN | MP | | Integer (0..1023) | |

### 13.4.27f14 TRIGGERED_6A_EVENT

This variable contains information about a 6a event that has been configured in the UE. There is one such variable per 6a event configured in the UE.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Event triggered | OP | | Boolean | |

### 13.4.27f15 TRIGGERED_6B_EVENT

This variable contains information about a 6b event that has been configured in the UE. There is one such variable per 6b event configured in the UE.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Event triggered | OP | | Boolean | |

### 13.4.27f16 TRIGGERED_6C_EVENT

This variable contains information about a 6c event that has been configured in the UE. There is one such variable per 6c event configured in the UE.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Event triggered | OP | | Boolean | |

### 13.4.27f17 TRIGGERED_6D_EVENT

This variable contains information about a 6d event that has been configured in the UE. There is one such variable per 6d event configured in the UE.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Event triggered | OP | | Boolean | |

### 13.4.27f18 TRIGGERED_6E_EVENT

This variable contains information about a 6e event that has been configured in the UE. There is one such variable per 6e event configured in the UE.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Event triggered | OP | | Boolean | |

### 13.4.27f19 TRIGGERED_6F_EVENT

This variable contains information about a 6f event that has been configured in the UE. There is one such variable per 6f event configured in the UE.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| CHOICE mode | | | | | |
| >FDD | | | | | |
| Event triggered_RL | OP | <maxRL> | Boolean | | |
| >1.28 Mcps TDD | | | | | REL-4 |
| >>$T_{ADV}$ | MP | | TADV info 10.3.7.112 | | REL-4 |

### 13.4.27f20 TRIGGERED_6G_EVENT

This variable contains information about a 6g event that has been configured in the UE. There is one such variable per 6g event configured in the UE.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Event triggered_RL | OP | <maxRL> | Boolean | |

## 13.4.27f21 TRIGGERED_1J_EVENT

This variable contains information about a 1j event that has been triggered in the UE. There is one such variable per 1j event configured in the UE.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| Cells triggered | OP | 1 to < maxCellMeas> | | Cleared when entering UTRA RRC connected mode. Cleared when leaving UTRA RRC connected mode. | REL-6 |
| >primary CPICH | MP | | Primary CPICH info 10.3.6.60 | | REL-6 |
| >sent reports | MP | | Integer(1..Infinity) | Number of reports sent to UTRAN in case of event triggered periodical reporting | REL-6 |
| Cells recently triggered | OP | 1 to < maxCellMeas> | | | REL-6 |
| >primary CPICH | MP | | Primary CPICH info 10.3.6.60 | | REL-6 |
| >sent reports | MP | | Integer(1..Infinity) | Number of reports sent to UTRAN in case of event triggered periodical reporting | REL-6 |
| Periodical reporting running | MP | | Boolean | | REL-6 |

## 13.4.27g UE_CAPABILITY_REQUESTED

This variable stores information about the UE capabilities that have been requested by UTRAN but that have not yet been transferred to UTRAN.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| UE radio access capability | OP | | UE radio access capability 10.3.3.42 | Cleared when entering UTRA RRC connected mode. Cleared when leaving UTRA RRC connected mode. |
| UE radio access capability extension | OP | | UE radio access capability extension 10.3.3.42a | Cleared when entering UTRA RRC connected mode. Cleared when leaving UTRA RRC connected mode. |
| UE system specific capability | OP | 1 to < maxInterSysMessages > | | |
| >Inter-RAT UE radio access capability | MP | | Inter-RAT UE radio access capability 10.3.8.7 | Includes inter-RAT classmark. Cleared when entering UTRA RRC connected mode. Cleared when leaving UTRA RRC connected mode. |

## 13.4.28 UE_CAPABILITY_TRANSFERRED

This variable stores information about which UE capabilities that have been transferred to UTRAN.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| UE radio access capability | OP | | UE radio access capability 10.3.3.42 | Cleared when entering UTRA RRC connected mode when not stated otherwise in the procedure. Cleared when leaving UTRA RRC connected mode. | |
| UE radio access capability extension | OP | | UE radio access capability extension 10.3.3.42a | Cleared when entering UTRA RRC connected mode when not stated otherwise in the procedure. Cleared when leaving UTRA RRC connected mode. | |
| UE system specific capability | OP | 1 to <maxSystemCapability> | | | |
| >Inter-RAT UE radio access capability | MP | | Inter-RAT UE radio access capability 10.3.8.7 | Includes inter-RAT classmark. Cleared when entering UTRA RRC connected mode when not stated otherwise in the procedure. Cleared when leaving UTRA RRC connected mode. | |
| UE radio access capability compressed | OP | | UE radio access capability compressed 10.3.3.42o | | REL-5 |
| Security capability | OP | | Security capability 10.3.3.37 | | REL-5 |

## 13.4.28a UE_POSITIONING_GPS_DATA

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| GPS Data ciphering info | OP | | UE positioning Ciphering info 10.3.7.86 | |
| GPS Deciphering Keys | OP | | | |
| >Current deciphering key | MP | | Bit string(56) | |
| >Next deciphering key | MP | | Bit string(56) | |
| UE positioning GPS reference time | OP | | UE positioning GPS reference time 10.3.7.96 | |
| UE positioning GPS reference UE position | OP | | Ellipsoid point with altitude and uncertainty ellipsoid 10.3.8.4c | A priori knowledge of UE 3-D position. |
| UE positioning GPS DGPS corrections | OP | | UE positioning GPS DGPS corrections 10.3.7.91 | |
| UE positioning GPS navigation model | OP | 1 to <maxSat> | | |
| >SatID | MP | | Enumerated( 0..63) | Satellite ID |
| >GPS Ephemeris and Clock Correction parameters | MP | | UE positioning GPS Ephemeris and Clock Correction parameters 10.3.7.91a | |
| UE positioning GPS ionospheric model | OP | | UE positioning GPS ionospheric model 10.3.7.92 | |
| UE positioning GPS UTC model | OP | | UE positioning GPS UTC model 10.3.7.97 | |
| UE positioning GPS almanac | OP | | | |
| >SatID | MP | 1 to <maxSatAlmanacStorage> | | |
| >>$WN_a$ | MP | | | Same as IE in 10.3.7.89 |
| >>DataID | MP | | | Same as IE in 10.3.7.89 |
| >>e | MP | | | Same as IE in 10.3.7.89 |
| >>$t_{oa}$ | MP | | | Same as IE in 10.3.7.89 |
| >>$\delta I$ | MP | | | Same as IE in 10.3.7.89 |
| >>OMEGADOT | MP | | | Same as IE in 10.3.7.89 |
| >>SV Health | MP | | | Same as IE in 10.3.7.89 |
| >>$A^{1/2}$ | MP | | | Same as IE in 10.3.7.89 |
| >>$OMEGA_0$ | MP | | | Same as IE in 10.3.7.89 |
| >>$M_0$ | MP | | | Same as IE in 10.3.7.89 |

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| >>$\omega$ | MP | | | Same as IE in 10.3.7.89 |
| >>$af_0$ | MP | | | Same as IE in 10.3.7.89 |
| >>$af_1$ | MP | | | Same as IE in 10.3.7.89 |
| >SV Global Health | OP | | | Same as IE in 10.3.7.89 |
| UE positioning GPS acquisition assistance | OP | | UE positioning GPS acquisition assistance 10.3.7.88 | |
| UE positioning GPS real-time integrity | OP | | UE positioning GPS real-time integrity 10.3.7.95 | |

## 13.4.28b UE_POSITIONING_OTDOA_DATA_UE_ASSISTED

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| UE positioning OTDOA reference cell info for UE-assisted | OP | | UE positioning OTDOA reference cell info 10.3.7.108 | |
| UE positioning OTDOA neighbour cell list for UE-assisted | OP | 1 to <maxCellMeas> | | |
| >UE positioning OTDOA neighbour cell info for UE-assisted | MP | | UE positioning OTDOA neighbour cell info 10.3.7.106 | |

## 13.4.28c UE_POSITIONING_OTDOA_DATA_UE_BASED

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| OTDOA Deciphering Keys | OP | | | |
| >Current deciphering key | MP | | Bit string(56) | |
| >Next deciphering key | MP | | Bit string(56) | |
| OTDOA Data ciphering info | OP | | UE positioning Ciphering info 10.3.7.86 | |
| UE positioning OTDOA reference cell info for UE-based | OP | | UE positioning OTDOA reference cell info for UE-based 10.3.7.108a | |
| UE positioning OTDOA neighbour cell list for UE-based | OP | 1 to <maxCellMeas> | | |
| >UE positioning OTDOA neighbour cell info for UE-based | MP | | UE positioning OTDOA neighbour cell info for UE-based 10.3.7.106 | |

## 13.4.29 UNSUPPORTED_CONFIGURATION

This variable indicates whether a received message contained a configuration that is not supported by the UE.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Unsupported configuration | MP | | Boolean | TRUE: An unsupported configuration has been detected.<br>Set to FALSE when entering UTRA RRC connected mode.<br>Set to FALSE when leaving UTRA RRC connected mode. |

## 13.4.30 URA_IDENTITY

This variable stores the assigned URA identity for this UE when in URA_PCH state.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| URA identity | OP | | URA identity 10.3.2.6 | Cleared when entering UTRA RRC connected mode.<br>Cleared when leaving UTRA RRC connected mode. |

## 13.4.31 U_RNTI

This variable stores the assigned U-RNTI for this UE.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| U-RNTI | OP | | U-RNTI 10.3.3.47 | Cleared when leaving UTRA RRC connected mode. |

## 13.4.32 VALUE_TAG

This variable contains information about the value tag for the last received system information block of a given type, for all system information blocks using value tags. The UE shall maintain one instance of this variable for the current selected cell. The UE may store several instances of this variable, one for each cell, to be used if the UE returns to these cells.

All IEs in this variable shall be cleared when switched off. All IEs in this variable except for the IE "SIB 16 value tag list" shall be cleared at selection of a new cell and this cell broadcasts an IE "PLMN Identity" in the MIB which is different from the IE "PLMN Identity" broadcast in the MIB in the previously selected cell. The IE "SIB 16 value tag list" is cleared when NAS informs AS about a new selected PLMN.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| MIB value tag | OP | | MIB value tag 10.3.8.9 | Value tag for the master information block |
| SB 1 value tag | OP | | Cell value tag 10.3.8.4 | Value tag for the scheduling block type 1 |
| SB 2 value tag | OP | | Cell value tag 10.3.8.4 | Value tag for the scheduling block type 2 |
| SIB 1 value tag | CV-*GSM* | | PLMN value tag 10.3.8.10 | Value tag for the system information block type 1 |
| SIB 2 value tag | OP | | Cell value tag 10.3.8.4 | Value tag for the system information block type 2 |
| SIB 3 value tag | OP | | Cell value tag 10.3.8.4 | Value tag for the system information block type 3 |
| SIB 4 value tag | OP | | Cell value tag 10.3.8.4 | Value tag for the system information block type 4 |
| SIB 5 value tag | OP | | Cell value tag 10.3.8.4 | Value tag for the system information block type 5 |
| SIB 6 value tag | OP | | Cell value tag 10.3.8.4 | Value tag for the system information block type 6 |
| CHOICE *mode* | MP | | | |
| >FDD | | | | |
| >TDD | | | | (no data) |
| SIB 11 value tag | OP | | Cell value tag 10.3.8.4 | Value tag for the system information block type 11 |
| SIB 12 value tag | OP | | Cell value tag 10.3.8.4 | Value tag for the system information block type 12 |
| SIB 13 value tag | CV-*ANSI* | | Cell value tag 10.3.8.4 | Value tag for the system information block type 13 |
| SIB 13.1 value tag | CV-*ANSI* | | Cell value tag 10.3.8.4 | Value tag for the system information block type 13.1 |
| SIB 13.2 value tag | CV-*ANSI* | | Cell value tag 10.3.8.4 | Value tag for the system information block type 13.2 |
| SIB 13.3 value tag | CV-*ANSI* | | Cell value tag 10.3.8.4 | Value tag for the system information block type 13.3 |
| SIB 13.4 value tag | CV-*ANSI* | | Cell value tag 10.3.8.4 | Value tag for the system information block type 13.4 |
| SIB 15 value tag | OP | | Cell value tag 10.3.8.4 | Value tag for the system information block type 15 |
| SIB 15.1 value tag | OP | | Cell value tag 10.3.8.4 | Value tag for the system information block type 15.1 |
| SIB 15.2 value tag list | OP | 1 to <maxSat> | | List of value tags for all stored occurrences of system information block type 15.2 |
| >SIB 15.2 value tag | MP | | Cell value tag 10.3.8.4 | |
| >SIB occurrence identity and value tag | MP | | SIB occurrence | |

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| | | | identity and value tag 10.3.8.20b | |
| SIB 15.3 value tag list | OP | 1 to <maxSat> | | List of value tags for all stored occurrences of system information block type 15.3 |
| >SIB 15.3 value tag | MP | | PLMN value tag 10.3.8.10 | Value tag for the system information block type 15.3 |
| >SIB occurrence identity and value tag | MP | | SIB occurrence identity and value tag 10.3.8.20b | |
| SIB 15.4 value tag | OP | | Cell value tag 10.3.8.4 | Value tag for the system information block type 15.4 |
| SIB 15.5 value tag | OP | | Cell value tag 10.3.8.4 | Value tag for the system information block type 15.5 |
| SIB 16 value tag list | OP | 1 to <maxPredefConfig> | | List of value tags for all stored occurrences of the system information block type 16 |
| >Predefined configuration identity and value tag | MP | | Predefined configuration identity and value tag 10.3.8.11 | |
| SIB 18 value tag | OP | | Cell value tag 10.3.8.4 | Value tag for the system information block type 18 |

| Condition | Explanation |
|---|---|
| *GSM* | This information is optional when the UE is operating in "GSM-MAP mode" and never stored otherwise. |
| *ANSI* | This information is optional when the UE is operating in "ANSI-41 mode" and never stored otherwise. |

## 13.5 UE RRC Procedure Performance

This subclause defines the performance requirements related to RRC procedures in the UE. Where the total delay is impacted by processing of variable length on the physical layer (e.g. physical layer synchronisation), references to appropriate specifications are given.

### 13.5.1 Definitions

The following definitions of N1 and N2 are valid only for this UE RRC Procedure Performance specification.

N1 = upper limit on the time required to execute modifications in UE after the reception of a UTRAN -> UE message has been completed. Where applicable (e.g. the physical layer transmission is impacted), the changes shall be adopted in the beginning of the next TTI starting after N1. N1 is specified as a multiple of 10 ms.

N2 = number of 10 ms radio frames from end of reception of UTRAN -> UE message on UE physical layer before the transmission of the UE -> UTRAN response message must be ready to start on a transport channel with no access delay other than the TTI alignment (e.g. DCH, therefore excluding delays caused by RACH procedure etc). The UE response message transmission from the physical layer shall begin at the latest (N2*10)+TTI ms after completion of the reception of the last TTI carrying the triggering UTRAN -> UE message. When Target State is CELL_DCH, the UE response message transmission from the physical layer may be additionally delayed by the value of IE "SRB delay".

N1 and N2 are independent (e.g. N2-N1 is not restricted to being less than or equal to 10ms).

## 13.5.2 RRC procedure performance values

NOTE: Times indicated in the table do not include cell reselection.

| Procedure title: | UTRAN -> UE | UE -> UTRAN | N1 | N2 | Notes |
|---|---|---|---|---|---|
| **RRC Connection Management Procedures** | | | | | |
| Broadcast of system information | SYSTEM INFORMATION | | | | N2 is not applicable for any system information messages, because there is no response message from the UE. |
| Master Information Block | SYSTEM INFORMATION | | 5 | NA | No system information data shall be lost due to processing of a MIB received with no detectable errors. This means that the UE shall buffer all system information data received after the MIB until the data can be processed according to the information in the MIB, unless the MIB was received erroneously. |
| System Information Block type 1 | SYSTEM INFORMATION | | 10 | NA | |
| System Information Block type 2 | SYSTEM INFORMATION | | 10 | NA | |
| System Information Block type 3 | SYSTEM INFORMATION | | 10 | NA | |
| System Information Block type 4 | SYSTEM INFORMATION | | 10 | NA | |
| System Information Block type 5 | SYSTEM INFORMATION | | 10 | NA | |
| System Information Block type 6 | SYSTEM INFORMATION | | 10 | NA | |
| System Information Block type 7 | SYSTEM INFORMATION | | 5 | NA | |
| System Information Block type 11 | SYSTEM INFORMATION | | 10 | NA | |
| System Information Block type 12 | SYSTEM INFORMATION | | 10 | NA | |
| System Information Block type 13 | SYSTEM INFORMATION | | 10 | NA | |
| System Information Block type 14 | SYSTEM INFORMATION | | 10 | NA | |
| System Information Block type 15 | SYSTEM INFORMATION | | 10 | NA | |
| System Information Block type 16 | SYSTEM INFORMATION | | 10 | NA | |
| System Information Block type 18 | SYSTEM INFORMATION | | 10 | NA | |
| RRC connection establishment<br>*Target state CELL_DCH* | RRC CONNECTION SETUP | RRC CONNECTION SETUP COMPLETE | 10 | NA | N1 measures time to the start of tx / rx on DPCH. N2 cannot be specified, because RRC CONNECTION SETUP COMPLETE message is transmitted only after physical layer synchronisation, which also depends on the Node B.<br><br>The performance of the physical layer synchronisation procedure is specified in [19] and [20] |
| RRC connection establishment<br>*Target state CELL_FACH* | RRC CONNECTION SETUP | RRC CONNECTION SETUP COMPLETE | 10 | 11 | N1 and N2 applicable as defined (N2 can be tested from the initiation of the power ramp on RACH). |

| Procedure title: | UTRAN -> UE | UE -> UTRAN | N1 | N2 | Notes |
|---|---|---|---|---|---|
| RRC connection release<br>*From CELL_DCH state* | RRC CONNECTION RELEASE | RRC CONNECTION RELEASE COMPLETE | 5 | 8 | N1 sets the requirement for the time from the completion of the last repetition of the RRC CONNECTION RELEASE COMPLETE message to the release of the physical channel.<br><br>N2 sets the requirement from the end of successful reception of the RRC CONNECTION RELEASE message to the start of the first transmission of the RRC CONNECTION RELEASE COMPLETE message. |
| RRC connection release<br>*From CELL_FACH state* | RRC CONNECTION RELEASE | RRC CONNECTION RELEASE COMPLETE | NA | 11 | N1 represents UE internal configuration that cannot be externally observed. |
| Paging | PAGING TYPE 1 | CELL UPDATE | 10 | 11+ T | T is the repetition period of SIB7 (applicable for FDD) and SIB14 (applicable for TDD) |
| UE capability enquiry | UE CAPABILITY ENQUIRY | UE CAPABILITY INFORMATION | NA | 8 | N1 is not applicable because the UE configuration does not change. |
| Security mode control | SECURITY MODE COMMAND | SECURITY MODE COMPLETE | 5 | 8 | |
| Signalling connection release procedure | SIGNALLING CONNECTION RELEASE | | 5 | NA | N2 is not applicable because there is no response message. |
| Counter check | COUNTER CHECK | COUNTER CHECK RESPONSE | NA | 8 | N1 is not applicable because the UE configuration does not change. |
| **Radio Bearer control procedures** | | | | | |
| Radio bearer establishment<br><br>*Target state CELL_DCH* | RADIO BEARER SETUP | RADIO BEARER SETUP COMPLETE / FAILURE | 10 | NA | N2 cannot be specified, because the RADIO BEARER SETUP COMPLETE / FAILURE message is transmitted only after physical layer synchronisation, which depends also on Node B. |
| Radio bearer establishment<br><br>*From state CELL_FACH to state CELL_FACH* | RADIO BEARER SETUP | RADIO BEARER SETUP COMPLETE / FAILURE | 10 | 11 | |
| Radio bearer establishment<br><br>*From CELL_DCH to CELL_FACH* | RADIO BEARER SETUP | RADIO BEARER SETUP COMPLETE | NA | NA | N1 and N2 cannot be specified, because UE need to read SIBs on BCH before sending RADIO BEARER SETUP COMPLETE |
| Radio bearer reconfiguration<br><br>*Target state CELL_DCH* | RADIO BEARER RECONFIGURATION | RADIO BEARER RECONFIGURATION COMPLETE / FAILURE | 5 or 10 | NA | N2 cannot be specified, because the RADIO BEARER RECONFIGURATION COMPLETE / FAILURE message is transmitted only after physical layer synchronisation, which depends also on Node B. NOTE 1 |
| Radio bearer reconfiguration<br><br>*From state CELL_FACH to state CELL_FACH* | RADIO BEARER RECONFIGURATION | RADIO BEARER RECONFIGURATION COMPLETE / FAILURE | 10 | 11 | |

| Procedure title: | UTRAN -> UE | UE -> UTRAN | N1 | N2 | Notes |
|---|---|---|---|---|---|
| Radio bearer reconfiguration<br><br>*From state CELL_DCH to state CELL_FACH* | RADIO BEARER RECONFIGURATION | RADIO BEARER RECONFIGURATION COMPLETE | NA | NA | N1 and N2 cannot be specified, because UE need to read SIBs on BCH before sending RADIO BEARER RECONFIGURATION COMPLETE |
| Radio bearer release<br>*Target state CELL_DCH* | RADIO BEARER RELEASE | RADIO BEARER RELEASE COMPLETE / FAILURE | 10 | 11 | |
| Radio bearer release<br>*From state CELL_FACH to state CELL_FACH* | RADIO BEARER RELEASE | RADIO BEARER RELEASE COMPLETE / FAILURE | 10 | 11 | |
| Radio bearer release<br>*From state CELL_DCH to state CELL_FACH* | RADIO BEARER RELEASE | RADIO BEARER RELEASE COMPLETE | NA | NA | N1 and N2 cannot be specified, because UE need to read SIBs on BCH before sending RADIO BEARER RECONFIGURATION COMPLETE |
| Transport channel reconfiguration<br><br>*Target state CELL_DCH* | TRANSPORT CHANNEL RECONFIGURATION | TRANSPORT CHANNEL RECONFIGURATION COMPLETE / FAILURE | 5 or 10 | NA | N2 cannot be specified, because the TRANSPORT CHANNEL RECONFIGURATION COMPLETE / FAILURE message is transmitted only after physical layer synchronisation, which depends also on Node B. NOTE 1 |
| Transport channel reconfiguration<br><br>*From state CELL_FACH to state CELL_FACH* | TRANSPORT CHANNEL RECONFIGURATION | TRANSPORT CHANNEL RECONFIGURATION COMPLETE / FAILURE | 10 | 11 | |
| Transport channel reconfiguration<br><br>*From state CELL_DCH to state CELL_FACH* | TRANSPORT CHANNEL RECONFIGURATION | TRANSPORT CHANNEL RECONFIGURATION COMPLETE | NA | NA | N1 and N2 cannot be specified, because UE need to read SIBs on BCH before sending TRANSPORT CHANNEL RECONFIGURATION COMPLETE |
| Transport format combination control<br><br>*AM or UM RLC mode* | TRANSPORT FORMAT COMBINATION CONTROL | TRANSPORT FORMAT COMBINATION CONTROL FAILURE | 5 | 8 | |
| Transport format combination control<br><br>*Transparent mode* | TRANSPORT FORMAT COMBINATION CONTROL | | 5 | NA | N2 is not applicable because no response message is defined. |
| Physical channel reconfiguration<br><br>*Target state CELL_DCH* | PHYSICAL CHANNEL RECONFIGURATION | PHYSICAL CHANNEL RECONFIGURATION COMPLETE / FAILURE | 5 or 8 | NA | N2 cannot be specified, because the PHYSICAL CHANNEL RECONFIGURATION COMPLETE / FAILURE message is transmitted only after physical layer synchronisation, which depends also on Node B. NOTE 1 |
| Physical channel reconfiguration<br><br>*From state CELL_FACH to state CELL_FACH* | PHYSICAL CHANNEL RECONFIGURATION | PHYSICAL CHANNEL RECONFIGURATION COMPLETE / FAILURE | 8 | 9 | |

| Procedure title: | UTRAN -> UE | UE -> UTRAN | N1 | N2 | Notes |
|---|---|---|---|---|---|
| Physical channel reconfiguration<br><br>*From state CELL_DCH to state CELL_FACH* | PHYSICAL CHANNEL RECONFIGURATION | PHYSICAL CHANNEL RECONFIGURATION COMPLETE | NA | NA | N1 and N2 cannot be specified, because UE need to read SIBs on BCH before sending PHYSICAL CHANNEL RECONFIGURATION COMPLETE |
| Physical Shared Channel Allocation [TDD only] | PHYSICAL SHARED CHANNEL ALLOCATION | | 5 | NA | N2 is not applicable because no response message is defined. |
| Uplink Physical Channel Control [TDD only] | UPLINK PHYSICAL CHANNEL CONTROL | | 8 | NA | Requirements for outer loop and timing advance adjustments are defined in [22] and [20]. N2 is not applicable because there is no response message. |
| **RRC connection mobility procedures** | | | | | |
| Cell update | CELL UPDATE CONFIRM | UTRAN MOBILITY INFORMATION CONFIRM | 5 | 8 | |
| | | PHYSICAL CHANNEL RECONFIGURATION COMPLETE *Target state CELL_FACH* | 8 | 9 | |
| | | PHYSICAL CHANNEL RECONFIGURATION COMPLETE *Target state CELL_DCH* | 8 | NA | N2 cannot be specified, because the PHYSICAL CHANNEL RECONFIGURATION COMPLETE / FAILURE message is transmitted only after physical layer synchronisation, which depends also on Node B. |
| | | TRANSPORT CHANNEL RECONFIGURATION COMPLETE *Target state CELL_FACH* | 10 | 11 | |
| | | TRANSPORT CHANNEL RECONFIGURATION COMPLETE *Target state CELL_DCH* | 10 | NA | N2 cannot be specified, because the PHYSICAL CHANNEL RECONFIGURATION COMPLETE / FAILURE message is transmitted only after physical layer synchronisation, which depends also on Node B. |
| | | RADIO BEARER RECONFIGURATION COMPLETE *Target state CELL_FACH* | 10 | 11 | |
| | | RADIO BEARER RECONFIGURATION COMPLETE *Target state CELL_DCH* | 10 | NA | N2 cannot be specified, because the PHYSICAL CHANNEL RECONFIGURATION COMPLETE / FAILURE message is transmitted only after physical layer synchronisation, which depends also on Node B. |

| Procedure title: | UTRAN -> UE | UE -> UTRAN | N1 | N2 | Notes |
|---|---|---|---|---|---|
| | | RADIO BEARER RELEASE COMPLETE *Target state CELL_DCH* | 10 | 11 | |
| URA update | URA UPDATE CONFIRM | UTRAN MOBILITY INFORMATION CONFIRM | 5 | 8 | |
| UTRAN mobility information | UTRAN MOBILITY INFORMATION | UTRAN MOBILITY INFORMATION CONFIRM / FAILURE | 5 | 8 | |
| Active set update | ACTIVE SET UPDATE | ACTIVE SET UPDATE COMPLETE / FAILURE | NA | 5 | The requirements on UE combining and power control performance for both UL and DL are specified by RAN WG4 in [21] and [19].<br><br>Also in case of branch addition the COMPLETE / FAILURE message is transmitted without waiting for the new branch to stabilise, therefore N2 is specified. |
| Inter-RAT handover to UTRAN | HANDOVER TO UTRAN COMMAND (other system) | HANDOVER TO UTRAN COMPLETE | NA | NA | The performance of this procedure is specified in 05.10. |
| Inter-RAT handover from UTRAN | HANDOVER FROM UTRAN COMMAND | HANDOVER FROM UTRAN FAILURE | NA | NA | The performance of this procedure is specified in [19] and [20]. |
| **Measurement procedures** | | | | | |
| Measurement control | MEASUREMENT CONTROL | MEASUREMENT CONTROL FAILURE | 5 | 8 | Response to measurement inquiry depends on physical layer measurement. Response time is defined in [19] and [20]. N1 and N2 only define the processing of the message. |

NOTE 1: The lower value applies when the UE is ordered to do a serving HS-DSCH cell change, changing no other information than contained in the IE "H-RNTI", the IE "Downlink HS-PDSCH information", the IE "Uplink DPCH power control info" and/or the IE "Serving HS-DSCH radio link indicator".

## 13.6 RB information parameters for signalling radio bearer RB 0

The following Radio Bearer parameter values apply for signalling radio bearer RB0:

| Information element/ Group name | Value | Comment |
|---|---|---|
| RLC info | | |
| >Uplink RLC mode | TM | |
| >>Transmission RLC discard | omitted | Neither discard is used, nor will there be a reset |
| >>Segmentation indication | FALSE | |
| >Downlink RLC mode | UM | |
| RB mapping info | | Single multiplexing option |
| >Uplink mapping info | | |
| >>UL transport channel | RACH | RACH corresponding with selected PRACH |
| >>RLC size list | N/A | If available the size in the IE 'Additional Dynamic Transport Format Information for CCCH' for the transport channel used.<br>Else the first TF defined in the Transport Format Set for the transport channel is used. |
| >>MAC logical channel priority | 1 | |
| >Downlink mapping info | | |
| >>DL transport channel | FACH | |

Procedure descriptions in subclause 8.6.4.8 shall not be applied for the IE "RB mapping info" that is used for signalling radio bearer RB0.

## 13.6a RB information parameters for SHCCH

The following Radio Bearer parameter values apply for SHCCH:

| Information element/ Group name | Value | Comment |
|---|---|---|
| RLC info | | |
| >Uplink RLC mode | TM | |
| >>Transmission RLC discard | omitted | Neither discard is used, nor will there be a reset |
| >>Segmentation indication | FALSE | |
| >Downlink RLC mode | UM | |
| RB mapping info | | |
| >Uplink mapping info | | Option 1 |
| >>UL transport channel | RACH | RACH corresponding with selected PRACH |
| >>RLC size list | N/A | The first TF defined in the Transport Format Set for the transport channel that is used |
| >>MAC logical channel priority | 1 | |
| >Downlink mapping info | | |
| >>DL transport channel | FACH | |
| >Uplink mapping info | | Option 2 |
| >>UL transport channel | USCH | |
| >>UL Transport Channel Identity | 1 | |
| >>MAC logical channel priority | 1 | |
| >>RLC size list | N/A | The first TF defined in the Transport Format Set for the transport channel that is used |
| >Downlink mapping info | | |
| >>DL transport channel | DSCH | |
| >>DL Transport Channel Identity | 1 | |

## 13.6b RB information parameters for BCCH mapped to FACH

The following Radio Bearer parameter values apply for BCCH mapped to FACH:

| Information element/ Group name | Value | Comment |
|---|---|---|
| Downlink RLC mode | TM | |
| Segmentation indication | FALSE | |

## 13.6c RB information parameters for PCCH mapped to PCH

The following Radio Bearer parameter values apply for PCCH mapped to PCH:

| Information element/ Group name | Value | Comment |
|---|---|---|
| Downlink RLC mode | TM | |
| Segmentation indication | FALSE | |

## 13.6d Parameters for BCCH mapped to BCH

The transport format parameters for BCH are specified in [34].

## 13.7 Parameter values for default radio configurations

The UE shall support the use of the default radio configurations that are specified in the following.

NOTE 1: These configurations are based on [41] and cover a number of RAB and signalling connection configurations.

In the table that is used to specify the parameter values for these default configurations, the following principles are used:

- Optional IEs that are not used are omitted;
- In case no parameter value is specified in a column, this means the value given the previous (left side) column applies.

NOTE 2: If needed, signalling radio bearer RB4 is established after the completion of handover.

NOTE 3: For each default configuration, the value of FDD, 3.84 Mcps TDD and 1.28 Mcps TDD parameters are specified. All parameters apply to FDD, 3.84 Mcps TDD and 1.28 Mcps TDD modes, unless explicitly stated otherwise. It should be noted that in this respect default configurations differ from pre-defined configurations, which only include parameter values for one mode.

NOTE 4: The transport format sizes, indicated in the following table, concern the RLC PDU size, since all configurations concern dedicated channels. The transport block sizes indicated in TS 34.108 are different since these include the size of the MAC header.

NOTE 5: The tabular values included in this subclause, represent the actual IE values as in clause 10, and not the ASN.1 representation of these values.

| Configuration | 3.4 kbps signalling | 13.6 kbps signalling | Unused configuration | 12.2 kbps speech + 3.4 kbps signalling |
|---|---|---|---|---|
| Ref 34.108 | 2 | 3 | | 4 |
| Default configuration identity | 0 | 1 | 2 | 3 |
| RB INFORMATION | | | | |
| rb-Identity | RB1: 1, RB2: 2, RB3: 3 | RB1: 1, RB2: 2, RB3: 3 | | RB1: 1, RB2: 2, RB3: 3, RB5: 5, RB6: 6, RB7: 7 |
| rlc-InfoChoice | Rlc-info | Rlc-info | | Rlc-info |
| >ul-RLC-Mode | RB1: UM<br>RB2- RB3: AM | RB1: UM<br>RB2- RB3: AM | | RB1: UM<br>RB2- RB3: AM<br>RB5-RB7: TM |
| >>transmissionRLC-DiscardMode | RB1: N/A<br>RB2- RB3: NoDiscard | RB1: N/A<br>RB2- RB3: NoDiscard | | RB1: N/A<br>RB2- RB3: NoDiscard<br>RB5- RB7: N/A |

| Configuration | 3.4 kbps signalling | 13.6 kbps signalling | Unused configuration | 12.2 kbps speech + 3.4 kbps signalling |
|---|---|---|---|---|
| >>>maxDat | RB1: N/A<br>RB2- RB3: 15 | RB1: N/A<br>RB2- RB3: 15 | | RB1: N/A<br>RB2- RB3: 15<br>RB5- RB7: N/A |
| >>transmissionWindowSize | RB1: N/A<br>RB2- RB3: 128 for UEs with more than 10 kbyte "total RLC AM buffer size" and 32 otherwise | RB1: N/A<br>RB2- RB3: 128 for UEs with more than 10 kbyte "total RLC AM buffer size" and 32 otherwise | | RB1: N/A<br>RB2- RB3: 128 for UEs with more than 10 kbyte "total RLC AM buffer size" and 32 otherwise<br>RB5- RB7: N/A |
| >>timerRST | RB1: N/A<br>RB2- RB3: 300 | RB1: N/A<br>RB2- RB3: 300 | | RB1: N/A<br>RB2- RB3: 300<br>RB5- RB7: N/A |
| >>max-RST | RB1: N/A<br>RB2- RB3: 1 | RB1: N/A<br>RB2- RB3: 1 | | RB1: N/A<br>RB2- RB3: 1<br>RB5- RB7: N/A |
| >>pollingInfo | RB1: N/A<br>RB2- RB3: as below | RB1: N/A<br>RB2- RB3: as below | | RB1: N/A<br>RB2- RB3: as below<br>RB5- RB7: N/A |
| >>>lastTransmissionPDU-Poll | RB2- RB3: FALSE | RB2- RB3: FALSE | | RB2- RB3: FALSE |
| >>>lastRetransmissionPDU-Poll | RB2- RB3: FALSE | RB2- RB3: FALSE | | RB2- RB3: FALSE |
| >>>timerPollPeriodic | RB2- RB3: 300 | RB2- RB3: 100 | | RB2- RB3: 300 |
| >>segmentationIndication | RB1- RB3: N/A | RB1- RB3: N/A | | RB1- RB3: N/A<br>RB5- RB7: FALSE |
| >dl-RLC-Mode | RB1: UM<br>RB2- RB3: AM | RB1: UM<br>RB2- RB3: AM | | RB1: UM<br>RB2- RB3: AM<br>RB5- RB7: TM |
| >>inSequenceDelivery | RB1: N/A<br>RB2- RB3: TRUE | RB1: N/A<br>RB2- RB3: TRUE | | RB1: N/A<br>RB2- RB3: TRUE<br>RB5- RB7: N/A |
| >>receivingWindowSize | RB1: N/A<br>RB2- RB3: 128 for UEs with more than 10 kbyte "total RLC AM buffer size" and 32 otherwise | RB1: N/A<br>RB2- RB3: 128 for UEs with more than 10 kbyte "total RLC AM buffer size" and 32 otherwise | | RB1: N/A<br>RB2- RB3: 128 for UEs with more than 10 kbyte "total RLC AM buffer size" and 32 otherwise<br>RB5- RB7: N/A |
| >>dl-RLC-StatusInfo | RB1: N/A<br>RB2- RB3: as below | RB1: N/A<br>RB2- RB3: as below | | RB1: N/A<br>RB2- RB3: as below<br>RB5- RB7: N/A |
| >>>timerStatusProhibit | RB2- RB3: 100 | RB2- RB3: 100 | | RB2- RB3: 100 |
| >>>missingPDU-Indicator | RB2- RB3: FALSE | RB2- RB3: FALSE | | RB2- RB3: FALSE |
| >>>timerStatusPeriodic | RB2- RB3: 300 | RB2- RB3: 100 | | RB2- RB3: 300 |
| >>segmentationIndication | RB1- RB3: N/A | RB1- RB3: N/A | | RB1- RB3: N/A<br>RB5- RB7: FALSE |
| rb-MappingInfo | | | | |
| >UL-LogicalChannelMappings | OneLogicalChannel | OneLogicalChannel | | OneLogicalChannel |
| >>ul-TransportChannelType | Dch | Dch | | Dch |
| >>>transportChannelIdentity | RB1- RB3: 1 | RB1- RB3: 1 | | RB1- RB3: 4<br>RB5: 1, RB6: 2, RB7: 3 |
| >>logicalChannelIdentity | RB1: 1, RB2: 2, RB3: 3 | RB1: 1, RB2: 2, RB3: 3 | | RB1: 1, RB2: 2, RB3: 3<br>RB5- RB7: N/A |
| >>rlc-SizeList | RB1- RB3: configured | RB1- RB3: configured | | RB1- RB3: configured<br>RB5- RB7: N/A |

| Configuration | 3.4 kbps signalling | 13.6 kbps signalling | Unused configuration | 12.2 kbps speech + 3.4 kbps signalling |
|---|---|---|---|---|
| >>mac-LogicalChannelPriority | RB1: 1, RB2: 2, RB3: 3 | RB1: 1, RB2: 2, RB3: 3 | | RB1: 1, RB2: 2, RB3: 3<br>RB5- RB7: 5 |
| >DL-logicalChannelMappingList | | | | |
| >>Mapping option 1 | One mapping option | One mapping option | | One mapping option |
| >>>dl-TransportChannelType | Dch | Dch | | Dch |
| >>>>transportChannelIdentity | RB1- RB3: 1 | RB1- RB3: 1 | | RB1- RB3: 4<br>RB5: 1, RB6: 2, RB7: 3 |
| >>>logicalChannelIdentity | RB1: 1, RB2: 2, RB3: 3 | RB1: 1, RB2: 2, RB3: 3 | | RB1: 1, RB2: 2, RB3: 3<br>RB5- RB7: N/A |
| TrCH INFORMATION PER TrCH | | | | |
| UL-AddReconfTransChInfoList | | | | |
| >Uplink transport channel type | dch | dch | | dch |
| >transportChannelIdentity | TrCH1: 1 | TrCH1: 1 | | TrCH1: 1, TrCH2: 2, TrCH3: 3, TrCH4: 4 |
| >transportFormatSet | DedicatedTransChTFS | DedicatedTransChTFS | | DedicatedTransChTFS |
| >>dynamicTF-information | | | | |
| >>>tf0/ tf0,1 | TrCH1: (0x144, 1x144) | TrCH1: (0x144, 1x144) | | TrCH1: (0x81)<br>TrCH2: (0x 103, 1x103)<br>TrCH3: (0x 60, 1x60)<br>TrCH4: (0x144, 1x144) |
| >>>>rlcSize | BitMode | BitMode | | BitMode |
| >>>>>sizeType | TrCH1: type 2, part1= 2, part2= 0 (144) | TrCH1: type 2, part1= 2, part2= 0 (144) | | TrCH1: type 1: 81<br>TrCH2: type 1: 103<br>TrCH3: type 1: 60<br>TrCH4: 2: type 2, part1= 2, part2= 0 (144) |
| >>>>numberOfTbSizeList | TrCH1: Zero, one | TrCH1: Zero, one | | TrCH1: Zero<br>TrCH2-4: Zero, one |
| >>>>logicalChannelList | All | All | | All |
| >>>tf 1 | N/A | N/A | | TrCH1: (1x39)<br>TrCH2- TrCH4: N/A |
| >>>>numberOfTransportBlocks | | | | TrCH1: One |
| >>>>rlc-Size | | | | TrCH1: BitMode |
| >>>>>sizeType | | | | TrCH1: 1: 39 |
| >>>>numberOfTbSizeList | | | | TrCH1: One |
| >>>>logicalChannelList | | | | TrCH1: all |
| >>>tf 2 | N/A | N/A | | TrCH1: (1x81)<br>TrCH2- TrCH4: N/A |
| >>>>numberOfTransportBlocks | | | | TrCH1: One |
| >>>>rlc-Size | | | | TrCH1: BitMode |
| >>>>>sizeType | | | | TrCH1: type 1: 81 |
| >>>>numberOfTbSizeList | | | | TrCH1: One |
| >>>>logicalChannelList | | | | TrCH1: all |
| >>semistaticTF-Information | | | | |
| >>>tti | TrCH1: 40 | TrCH1: 10 | | TrCH1- TrCH3: 20<br>TrCH4: 40 |
| >>>channelCodingType | Convolutional | Convolutional | | Convolutional |

| Configuration | 3.4 kbps signalling | 13.6 kbps signalling | Unused configuration | 12.2 kbps speech + 3.4 kbps signalling |
|---|---|---|---|---|
| >>>>codingRate | TrCH1: Third | TrCH1: Third | | TrCH1- TrCH2: Third<br>TrCH3: Half<br>TrCH4: Third |
| >>>rateMatchingAttribute | TrCH1: 160 | TrCH1: 160 | | TrCH1: 200<br>TrCH2: 190<br>TrCH3: 235<br>TrCH4: 160 |
| >>>crc-Size | TrCH1: 16 | TrCH1: 16 | | TrCH1: 12<br>TrCH2- TrCH3: 0<br>TrCH4: 16 |
| DL-AddReconfTransChInfoList | | | | |
| >Downlink transport channel type | dch | dch | | dch |
| >dl-TransportChannelIdentity (should be as for UL) | TrCH1: 1 | TrCH1: 1 | | TrCH1: 1, TrCH2: 2, TrCH3: 3, TrCH4: 4 |
| >tfs-SignallingMode | SameAsUL | SameAsUL | | Explicit<br><Only tf0 on TrCH1 is different and shown below> |
| >>transportFormatSet | | | | DedicatedTransChTFS |
| >>>dynamicTF-information | | | | |
| >>>>tf0/ tf0,1 | | | | TrCH1: (1x0) |
| >>>>rlcSize | | | | bitMode |
| >>>>>sizeType | | | | TrCH1: type 1: 0 |
| >>>>numberOfTbSizeList | | | | TrCH1: One |
| >>>>logicalChannelList | | | | All |
| >>ULTrCH-Id | TrCH1: 1 | TrCH1: 1 | | TrCH1: 1, TrCH2: 2, TrCH3: 3, TrCH4: 4 |
| >dch-QualityTarget | | | | |
| >>bler-QualityValue | TrCH1: $5x10^{-2}$ | TrCH1: $5x10^{-2}$ | | TrCH1: $7x10^{-3}$<br>TrCH2- TrCH4: Absent |
| TrCH INFORMATION, COMMON | | | | |
| ul-CommonTransChInfo | | | | |
| >tfcs-ID (TDD only) | 1 | 1 | | 1 |
| >sharedChannelIndicator (TDD only) | FALSE | FALSE | | FALSE |
| >tfc-Subset | Absent, not required | Absent, not required | | Absent, not required |
| >ul-TFCS | Normal TFCI signalling | Normal TFCI signalling | | Normal TFCI signalling |
| >>explicitTFCS-ConfigurationMode | Complete | Complete | | Complete |
| >>>ctfcSize | Ctfc2Bit | Ctfc2Bit | | Ctfc6Bit |
| >>>>TFCS representation | Addition | Addition | | Addition |
| >>>>>TFCS list | | | | |
| >>>>>>TFCS 1 | (TF0) | (TF0) | | (TF0, TF0, TF0, TF0) |
| >>>>>>>ctfc | 0 | 0 | | 0 |
| >>>>>>>gainFactorInformation | Computed | Computed | | Computed |
| >>>>>>>>referenceTFCId | 0 | 0 | | 0 |
| >>>>>>TFCS 2 | (TF1) | (TF1) | | (TF1, TF0, TF0, TF0) |
| >>>>>>>ctfc | 1 | 1 | | 1 |
| >>>>>>>gainFactorInformation | Signalled | Signalled | | Computed |

| Configuration | 3.4 kbps signalling | 13.6 kbps signalling | Unused configuration | 12.2 kbps speech + 3.4 kbps signalling |
|---|---|---|---|---|
| >>>>>>>>βc (FDD only) | 11 | 11 | | N/A |
| >>>>>>>>βd | 15 | 15 | | N/A |
| >>>>>>>>referenceTFCId | 0 | 0 | | 0 |
| >>>>>>TFCS 3 | | | | (TF2, TF1, TF1, TF0) |
| >>>>>>>ctfc | | | | 11 |
| >>>>>>>gainFactorInformation | | | | Computed |
| >>>>>>>>referenceTFCId | | | | 0 |
| >>>>>>TFCS 4 | | | | (TF0, TF0, TF0, TF1) |
| >>>>>>>ctfc | | | | 12 |
| >>>>>>>gainFactorInformation | | | | Computed |
| >>>>>>>>βc (FDD only) | | | | N/A |
| >>>>>>>>βd | | | | N/A |
| >>>>>>>>referenceTFCId | | | | 0 |
| >>>>>>TFCS 5 | | | | (TF1, TF0, TF0, TF1) |
| >>>>>>>ctfc | | | | 13 |
| >>>>>>>gainFactorInformation | | | | Computed |
| >>>>>>>>referenceTFCId | | | | 0 |
| >>>>>>TFCS 6 | | | | (TF2, TF1, TF1, TF1) |
| >>>>>>>ctfc | | | | 23 |
| >>>>>>>gainFactorInformation | | | | Signalled |
| >>>>>>>>βc (FDD only) | | | | 11 |
| >>>>>>>>βd | | | | 15 |
| >>>>>>>>referenceTFCId | | | | 0 |
| dl-CommonTransChInfo | | | | |
| >tfcs-SignallingMode | Same as UL | Same as UL | | Same as UL |
| PhyCH INFORMATION FDD | | | | |
| UL-DPCH-InfoPredef | | | | |
| >ul-DPCH-PowerControlInfo | | | | |
| >>powerControlAlgorithm | Algorithm 1 | Algorithm 1 | | Algorithm 1 |
| >>>tpcStepSize | 1 dB | 1 dB | | 1 dB |
| >tfci-Existence | TRUE | TRUE | | TRUE |
| >puncturingLimit | 1 | 1 | | 0.88 |
| DL-CommonInformationPredef | | | | |
| >dl-DPCH-InfoCommon | | | | |
| >>spreadingFactor | 256 | 128 | | 128 |
| >>tfci-Existence | FALSE | FALSE | | FALSE |
| >>pilotBits | 4 | 4 | | 4 |
| >>positionFixed | N/A | N/A | | Fixed |
| | | | | |
| PhyCH INFORMATION 3.84 Mcps TDD | | | | |
| UL-DPCH-InfoPredef | | | | |
| >ul-DPCH-PowerControlInfo | | | | |
| >>dpch-ConstantValue | 0 | 0 | | 0 |
| >commonTimeslotInfo | | | | |
| >>secondInterleavingMode | frameRelated | frameRelated | | frameRelated |
| >>tfci-Coding | 4 | 4 | | 16 |
| >>puncturingLimit | 1 | 0.92 | | 0.88 |

| Configuration | 3.4 kbps signalling | 13.6 kbps signalling | Unused configuration | 12.2 kbps speech + 3.4 kbps signalling |
|---|---|---|---|---|
| >>repetitionPeriodAndLength | repetitionPeriod1 | repetitionPeriod1 | | repetitionPeriod1 |
| DL-CommonInformationPredef | | | | |
| >dl-DPCH-InfoCommon | | | | |
| >>commonTimeslotInfo | | | | |
| >>>secondInterleavingMode | frameRelated | frameRelated | | frameRelated |
| >>>tfci-Coding | 4 | 4 | | 16 |
| >>>puncturingLimit | 1 | 0.92 | | 0.92 |
| >>>repetitionPeriodAndLength | repetitionPeriod1 | repetitionPeriod1 | | repetitionPeriod1 |
| PhyCH INFORMATION 1.28 Mcps TDD | | | | |
| UL-DPCH-InfoPredef | | | | |
| >commonTimeslotInfo | | | | |
| >>secondInterleavingMode | frameRelated | frameRelated | | frameRelated |
| >>tfci-Coding | 4 | 4 | | 16 |
| >>puncturingLimit | 1 | 0.64 | | 0.60 |
| >>repetitionPeriodAndLength | repetitionPeriod1 | repetitionPeriod1 | | repetitionPeriod1 |
| DL-CommonInformationPredef | | | | |
| >dl-DPCH-InfoCommon | | | | |
| >>commonTimeslotInfo | | | | |
| >>>secondInterleavingMode | frameRelated | frameRelated | | frameRelated |
| >>>tfci-Coding | 4 | 4 | | 16 |
| >>>puncturingLimit | 1 | 0.64 | | 0.60 |
| >>>repetitionPeriodAndLength | repetitionPeriod1 | repetitionPeriod1 | | repetitionPeriod1 |

| Configuration | 28.8 kbps conv. CS- data + 3.4 kbps signalling | 32 kbps conv. CS-data + 3.4 kbps signalling | 64kbps conv. CS-data + 3.4 kbps signalling | 14.4 kbps streaming CS-data + 3.4 kbps signalling |
|---|---|---|---|---|
| Ref 34.108 | 12 | 14 | 13 | 15 |
| Default configuration identity | 4 | 5 | 6 | 7 |
| RB INFORMATION | | | | |
| rb-Identity | RB1: 1, RB2: 2, RB3: 3, RB5: 5 | RB1: 1, RB2: 2, RB3: 3, RB5: 5 | RB1: 1, RB2: 2, RB3: 3, RB5: 5 | RB1: 1, RB2: 2, RB3: 3, RB5: 5 |
| rlc-InfoChoice | Rlc-info | Rlc-info | Rlc-info | Rlc-info |
| >ul-RLC-Mode | RB1: UM<br>RB2- RB3: AM<br>RB5: TM | RB1: UM<br>RB2- RB3: AM<br>RB5: TM | RB1: UM<br>RB2- RB3: AM<br>RB5: TM | RB1: UM<br>RB2- RB3: AM<br>RB5: TM |
| >>transmissionRLC-DiscardMode | RB1: N/A<br>RB2- RB3: NoDiscard<br>RB5: N/A | RB1: N/A<br>RB2- RB3: NoDiscard<br>RB5: N/A | RB1: N/A<br>RB2- RB3: NoDiscard<br>RB5: N/A | RB1: N/A<br>RB2- RB3: NoDiscard<br>RB5: N/A |
| >>>maxDat | RB1: N/A<br>RB2- RB3: 15<br>RB5: N/A | RB1: N/A<br>RB2- RB3: 15<br>RB5: N/A | RB1: N/A<br>RB2- RB3: 15<br>RB5: N/A | RB1: N/A<br>RB2- RB3: 15<br>RB5: N/A |
| >>transmissionWindowSize | RB1: N/A<br>RB2- RB3: 128 for UEs with more than 10 kbyte "total RLC AM buffer size" and 32 otherwise<br>RB5: N/A | RB1: N/A<br>RB2- RB3: 128 for UEs with more than 10 kbyte "total RLC AM buffer size" and 32 otherwise<br>RB5: N/A | RB1: N/A<br>RB2- RB3: 128 for UEs with more than 10 kbyte "total RLC AM buffer size" and 32 otherwise<br>RB5: N/A | RB1: N/A<br>RB2- RB3: 128 for UEs with more than 10 kbyte "total RLC AM buffer size" and 32 otherwise<br>RB5: N/A |

| Configuration | 28.8 kbps conv. CS- data + 3.4 kbps signalling | 32 kbps conv. CS-data + 3.4 kbps signalling | 64kbps conv. CS-data + 3.4 kbps signalling | 14.4 kbps streaming CS-data + 3.4 kbps signalling |
|---|---|---|---|---|
| >>timerRST | RB1: N/A<br>RB2- RB3: 300<br>RB5: N/A | RB1: N/A<br>RB2- RB3: 300<br>RB5: N/A | RB1: N/A<br>RB2- RB3: 300<br>RB5: N/A | RB1: N/A<br>RB2- RB3: 300<br>RB5: N/A |
| >>max-RST | RB1: N/A<br>RB2- RB3: 1<br>RB5: N/A | RB1: N/A<br>RB2- RB3: 1<br>RB5: N/A | RB1: N/A<br>RB2- RB3: 1<br>RB5: N/A | RB1: N/A<br>RB2- RB3: 1<br>RB5: N/A |
| >>pollingInfo | RB1: N/A<br>RB2- RB3: as below<br>RB5: N/A | RB1: N/A<br>RB2- RB3: as below<br>RB5: N/A | RB1: N/A<br>RB2- RB3: as below<br>RB5: N/A | RB1: N/A<br>RB2- RB3: as below<br>RB5: N/A |
| >>>lastTransmissionPDU-Poll | RB2- RB3: FALSE | RB2- RB3: FALSE | RB2- RB3: FALSE | RB2- RB3: FALSE |
| >>>lastRetransmissionPDU-Poll | RB2- RB3: FALSE | RB2- RB3: FALSE | RB2- RB3: FALSE | RB2- RB3: FALSE |
| >>>timerPollPeriodic | RB2- RB3: 300 | RB2- RB3: 300 | RB2- RB3: 300 | RB2- RB3: 300 |
| >>segmentationIndication | RB1- RB3: N/A<br>RB5: FALSE | RB1- RB3: N/A<br>RB5: FALSE | RB1- RB3: N/A<br>RB5: FALSE | RB1- RB3: N/A<br>RB5: FALSE |
| >dl-RLC-Mode | RB1: UM<br>RB2- RB3: AM<br>RB5: TM | RB1: UM<br>RB2- RB3: AM<br>RB5: TM | RB1: UM<br>RB2- RB3: AM<br>RB5: TM | RB1: UM<br>RB2- RB3: AM<br>RB5: TM |
| >>inSequenceDelivery | RB1: N/A<br>RB2- RB3: TRUE<br>RB5: N/A | RB1: N/A<br>RB2- RB3: TRUE<br>RB5: N/A | RB1: N/A<br>RB2- RB3: TRUE<br>RB5: N/A | RB1: N/A<br>RB2- RB3: TRUE<br>RB5: N/A |
| >>receivingWindowSize | RB1: N/A<br>RB2- RB3: 128 for UEs with more than 10 kbyte "total RLC AM buffer size" and 32 otherwise<br>RB5: N/A | RB1: N/A<br>RB2- RB3: 128 for UEs with more than 10 kbyte "total RLC AM buffer size" and 32 otherwise<br>RB5: N/A | RB1: N/A<br>RB2- RB3: 128 for UEs with more than 10 kbyte "total RLC AM buffer size" and 32 otherwise<br>RB5: N/A | RB1: N/A<br>RB2- RB3: 128 for UEs with more than 10 kbyte "total RLC AM buffer size" and 32 otherwise<br>RB5: N/A |
| >>dl-RLC-StatusInfo | RB1: N/A<br>RB2- RB3: as below<br>RB5: N/A | RB1: N/A<br>RB2- RB3: as below<br>RB5: N/A | RB1: N/A<br>RB2- RB3: as below<br>RB5: N/A | RB1: N/A<br>RB2- RB3: as below<br>RB5: N/A |
| >>>timerStatusProhibit | RB2- RB3: 100 | RB2- RB3: 100 | RB2- RB3: 100 | RB2- RB3: 100 |
| >>>missingPDU-Indicator | RB2- RB3: FALSE | RB2- RB3: FALSE | RB2- RB3: FALSE | RB2- RB3: FALSE |
| >>>timerStatusPeriodic | RB2- RB3: 300 | RB2- RB3: 300 | RB2- RB3: 300 | RB2- RB3: 300 |
| >>segmentationIndication | RB1- RB3: N/A<br>RB5: FALSE | RB1- RB3: N/A<br>RB5: FALSE | RB1- RB3: N/A<br>RB5: FALSE | RB1- RB3: N/A<br>RB5: FALSE |
| rb-MappingInfo | | | | |
| >UL-LogicalChannelMappings | OneLogicalChannel | OneLogicalChannel | OneLogicalChannel | OneLogicalChannel |
| >>ul-TransportChannelType | Dch | Dch | Dch | Dch |
| >>>transportChannelIdentity | RB1- RB3: 2<br>RB5: 1 | RB1- RB3: 2<br>RB5: 1 | RB1- RB3: 2<br>RB5: 1 | RB1- RB3: 2<br>RB5: 1 |
| >>logicalChannelIdentity | RB1: 1, RB2: 2, RB3: 3<br>RB5: N/A | RB1: 1, RB2: 2, RB3: 3<br>RB5: N/A | RB1: 1, RB2: 2, RB3: 3<br>RB5: N/A | RB1: 1, RB2: 2, RB3: 3<br>RB5: N/A |
| >>rlc-SizeList | RB1- RB3: configured<br>RB5: N/A | RB1- RB3: configured<br>RB5: N/A | RB1- RB3: configured<br>RB5: N/A | RB1- RB3: configured<br>RB5: N/A |
| >>mac-LogicalChannelPriority | RB1: 1, RB2: 2, RB3: 3<br>RB5: 5 | RB1: 1, RB2: 2, RB3: 3<br>RB5: 5 | RB1: 1, RB2: 2, RB3: 3<br>RB5: 5 | RB1: 1, RB2: 2, RB3: 3<br>RB5: 5 |
| >DL-logicalChannelMappingList | | | | |
| >>Mapping option 1 | One mapping option | One mapping option | One mapping option | One mapping option |
| >>>dl-TransportChannelType | Dch | Dch | Dch | Dch |
| >>>>transportChannelIdentity | RB1- RB3: 2<br>RB5: 1 | RB1- RB3: 2<br>RB5: 1 | RB1- RB3: 2<br>RB5: 1 | RB1- RB3: 2<br>RB5: 1 |

| Configuration | 28.8 kbps conv. CS- data + 3.4 kbps signalling | 32 kbps conv. CS-data + 3.4 kbps signalling | 64kbps conv. CS-data + 3.4 kbps signalling | 14.4 kbps streaming CS-data + 3.4 kbps signalling |
|---|---|---|---|---|
| >>>logicalChannelIdentity | RB1: 1, RB2: 2, RB3: 3 RB5: N/A | RB1: 1, RB2: 2, RB3: 3 RB5: N/A | RB1: 1, RB2: 2, RB3: 3 RB5: N/A | RB1: 1, RB2: 2, RB3: 3 RB5: N/A |
| TrCH INFORMATION PER TrCH | | | | |
| UL-AddReconfTransChInfoList | | | | |
| >Uplink transport channel type | dch | dch | dch | dch |
| >transportChannelIdentity | TrCH1: 1, TrCH2: 2 | TrCH1: 1, TrCH2: 2 | TrCH1: 1, TrCH2: 2 | TrCH1: 1, TrCH2: 2 |
| >transportFormatSet | DedicatedTransChTFS | DedicatedTransChTFS | DedicatedTransChTFS | DedicatedTransChTFS |
| >>dynamicTF-information | | | | |
| >>>tf0/ tf0,1 | TrCH1: (0x576, 1x576, 2x576) TrCH2: (0x144, 1x144) | TrCH1: (0x640, 1x640) TrCH2: (0x144, 1x144) | TrCH1: (0x640, 2x640) TrCH2: (0x144, 1x144) | TrCH1: (0x576, 1x576) TrCH2: (0x144, 1x144) |
| >>>>rlcSize | TrCH1: OctetMode TrCH2:BitMode | TrCH1: OctetMode TrCH2:BitMode | TrCH1: OctetMode TrCH2:BitMode | TrCH1: OctetMode TrCH2:BitMode |
| >>>>>sizeType | TrCH1: type 2, part1= 9, part2= 2 (576) TrCH2: type 2, part1= 2, part2= 0 (144) | TrCH1: type 2, part1= 11, part2= 2 (640) TrCH2: type 2, part1= 2, part2= 0 (144) | TrCH1: type 2, part1= 11, part2= 2 (640) TrCH2: type 2, part1= 2, part2= 0 (144) | TrCH1: type 2, part1= 9, part2= 2 (576) TrCH2: type 2, part1= 2, part2= 0 (144) |
| >>>>numberOfTbSizeList | TrCH1: Zero,1, 2 TrCH2: Zero, one | TrCH1: Zero, one TrCH2: Zero, one | TrCH1: Zero, 2 TrCH2: Zero, one | TrCH1: Zero, one, TrCH2: Zero, one |
| >>>>logicalChannelList | All | All | All | All |
| >>semiStaticTF-Information | | | | |
| >>>tti | TrCH1: 40 TrCH2: 40 | TrCH1: 20 TrCH2: 40 | TrCH1: 20 TrCH2: 40 | TrCH1: 40 TrCH2: 40 |
| >>>channelCodingType | TrCH1: Turbo TrCH2: Convolutional | TrCH1: Turbo TrCH2: Convolutional | TrCH1: Turbo TrCH2: Convolutional | TrCH1: Turbo TrCH2: Convolutional |
| >>>>codingRate | TrCH1: N/A TrCH2: Third | TrCH1: N/A TrCH2: Third | TrCH1: N/A TrCH2: Third | TrCH1: N/A TrCH2: Third |
| >>>rateMatchingAttribute | TrCH1: 180 TrCH2: 160 | TrCH1: 185 TrCH2: 160 | TrCH1: 170 TrCH2: 160 | TrCH1: 165 TrCH2: 160 |
| >>>crc-Size | TrCH1: 16 TrCH2: 16 | TrCH1: 16 TrCH2: 16 | TrCH1: 16 TrCH2: 16 | TrCH1: 16 TrCH2: 16 |
| DL-AddReconfTransChInfoList | | | | |
| >Downlink transport channel type | dch | dch | dch | dch |
| >dl-TransportChannelIdentity (should be as for UL) | TrCH1: 1, TrCH2: 2 | TrCH1: 1, TrCH2: 2 | TrCH1: 1, TrCH2: 2 | TrCH1: 1, TrCH2: 2 |
| >tfs-SignallingMode | SameAsUL | SameAsUL | SameAsUL | SameAsUL |
| >>transportFormatSet | | | | |
| >>>dynamicTF-information | | | | |
| >>>>tf0/ tf0,1 | | | | |
| >>>>rlcSize | | | | |
| >>>>>sizeType | | | | |
| >>>>numberOfTbSizeList | | | | |
| >>>>logicalChannelList | | | | |
| >>ULTrCH-Id | TrCH1: 1, TrCH2: 2 | TrCH1: 1, TrCH2: 2 | TrCH1: 1, TrCH2: 2 | TrCH1: 1, TrCH2: 2 |
| >dch-QualityTarget | | | | |
| >>bler-QualityValue | TrCH1: $2x10^{-3}$ TrCH2: Absent | TrCH1: $2x10^{-3}$ TrCH2: Absent | TrCH1: $2x10^{-3}$ TrCH2: Absent | TrCH1: $1x10^{-2}$ TrCH2: Absent |

| Configuration | 28.8 kbps conv. CS- data + 3.4 kbps signalling | 32 kbps conv. CS-data + 3.4 kbps signalling | 64kbps conv. CS-data + 3.4 kbps signalling | 14.4 kbps streaming CS-data + 3.4 kbps signalling |
|---|---|---|---|---|
| TrCH INFORMATION, COMMON | | | | |
| ul-CommonTransChInfo | | | | |
| >tfcs-ID (TDD only) | 1 | 1 | 1 | 1 |
| >sharedChannelIndicator (TDD only) | FALSE | FALSE | FALSE | FALSE |
| >tfc-Subset | Absent, not required | Absent, not required | Absent, not required | Absent, not required |
| >ul-TFCS | Normal TFCI signalling | Normal TFCI signalling | Normal TFCI signalling | Normal TFCI signalling |
| >>explicitTFCS-ConfigurationMode | Complete | Complete | Complete | Complete |
| >>>ctfcSize | Ctfc4Bit | Ctfc2Bit | Ctfc2Bit | Ctfc4Bit |
| >>>>TFCS representation | Addition | Addition | Addition | Addition |
| >>>>>TFCS list | | | | |
| >>>>>>TFCS 1 | (TF0, TF0) | (TF0, TF0) | (TF0, TF0) | (TF0, TF0) |
| >>>>>>>ctfc | 0 | 0 | 0 | 0 |
| >>>>>>>gainFactorInformation | Computed | Computed | Computed | Computed |
| >>>>>>>>referenceTFCId | 0 | 0 | 0 | 0 |
| >>>>>>TFCS 2 | (TF1, TF0) | (TF1, TF0) | (TF1, TF0) | (TF1, TF0) |
| >>>>>>>ctfc | 1 | 1 | 1 | 1 |
| >>>>>>>gainFactorInformation | Computed | Computed | Computed | Computed |
| >>>>>>>>βc (FDD only) | N/A | N/A | N/A | N/A |
| >>>>>>>>βd | N/A | N/A | N/A | N/A |
| >>>>>>>>referenceTFCId | 0 | 0 | 0 | 0 |
| >>>>>>TFCS 3 | (TF2, TF0) | (TF0, TF1) | (TF0, TF1) | (TF0, TF1) |
| >>>>>>>ctfc | 2 | 2 | 2 | 2 |
| >>>>>>>gainFactorInformation | Computed | Computed | Computed | Computed |
| >>>>>>>>referenceTFCId | 0 | 0 | 0 | 0 |
| >>>>>>TFCS 4 | (TF0, TF1) | (TF1, TF1) | (TF1, TF1) | (TF1, TF1) |
| >>>>>>>ctfc | 3 | 3 | 3 | 3 |
| >>>>>>>gainFactorInformation | Computed | Signalled | Signalled | Signalled |
| >>>>>>>>βc (FDD only) | N/A | 8 | 8 | 11 |
| >>>>>>>>βd | N/A | 15 | 15 | 15 |
| >>>>>>>>referenceTFCId | 0 | 0 | 0 | 0 |
| >>>>>>TFCS 5 | (TF1, TF1) | N/A | N/A | |
| >>>>>>>ctfc | 4 | | | |
| >>>>>>>gainFactorInformation | Computed | | | |
| >>>>>>>>referenceTFCId | 0 | | | |
| >>>>>>TFCS 6 | (TF2, TF1) | N/A | N/A | |
| >>>>>>>ctfc | 5 | | | |
| >>>>>>>gainFactorInformation | Signalled | | | |
| >>>>>>>>βc (FDD only) | 8 | | | |
| >>>>>>>>βd | 15 | | | |
| >>>>>>>>referenceTFCId | 0 | | | |
| >>>>>>TFCS 7 | | | | |
| >>>>>>>ctfc | | | | |
| >>>>>>>gainFactorInformation | | | | |
| >>>>>>>>referenceTFCId | | | | |
| >>>>>>TFCS 8 | | | | |
| >>>>>>>ctfc | | | | |
| >>>>>>>gainFactorInformation | | | | |
| >>>>>>>>referenceTFCId | | | | |

| Configuration | 28.8 kbps conv. CS- data + 3.4 kbps signalling | 32 kbps conv. CS-data + 3.4 kbps signalling | 64kbps conv. CS-data + 3.4 kbps signalling | 14.4 kbps streaming CS-data + 3.4 kbps signalling |
|---|---|---|---|---|
| >>>>>>TFCS 9 | | | | |
| >>>>>>>ctfc | | | | |
| >>>>>>>gainFactorInformation | | | | |
| >>>>>>>>referenceTFCId | | | | |
| >>>>>>TFCS 10 | | | | |
| >>>>>>>ctfc | | | | |
| >>>>>>>gainFactorInformation | | | | |
| >>>>>>>>βc (FDD only) | | | | |
| >>>>>>>>βd | | | | |
| >>>>>>>>referenceTFCId | | | | |
| dl-CommonTransChInfo | | | | |
| >tfcs-SignallingMode | Same as UL | Same as UL | Same as UL | Same as UL |
| | | | | |
| PhyCH INFORMATION FDD | | | | |
| UL-DPCH-InfoPredef | | | | |
| >ul-DPCH-PowerControlInfo | | | | |
| >>powerControlAlgorithm | Algorithm 1 | Algorithm 1 | Algorithm 1 | Algorithm 1 |
| >>>tpcStepSize | 1 dB | 1 dB | 1 dB | 1 dB |
| >tfci-Existence | TRUE | TRUE | TRUE | TRUE |
| >puncturingLimit | 0.92 | 0.8 | 0.92 | 1 |
| DL-CommonInformationPredef | | | | |
| >dl-DPCH-InfoCommon | | | | |
| >>spreadingFactor | 64 | 64 | 32 | 128 |
| >>tfci-Existence | TRUE | TRUE | TRUE | TRUE |
| >>pilotBits | 8 | 8 | 8 | 8 |
| >>positionFixed | Flexible | Flexible | Flexible | Flexible |
| PhyCH INFORMATION 3.84 Mcps TDD | | | | |
| UL-DPCH-InfoPredef | | | | |
| >ul-DPCH-PowerControlInfo | | | | |
| >>dpch-ConstantValue | 0 | 0 | 0 | 0 |
| >commonTimeslotInfo | | | | |
| >>secondInterleavingMode | frameRelated | frameRelated | frameRelated | frameRelated |
| >>tfci-Coding | 16 | 8 | 8 | 8 |
| >>puncturingLimit | 0.44 | 0.8 | 0.56 | 0.8 |
| >>repetitionPeriodAndLength | repetitionPeriod1 | repetitionPeriod1 | repetitionPeriod1 | repetitionPeriod1 |
| DL-CommonInformationPredef | | | | |
| >dl-DPCH-InfoCommon | | | | |
| >>commonTimeslotInfo | | | | |
| >>>secondInterleavingMode | frameRelated | frameRelated | frameRelated | frameRelated |
| >>>tfci-Coding | 16 | 8 | 8 | 8 |
| >>>puncturingLimit | 0.44 | 0.64 | 0.56 | 0.8 |
| >>>repetitionPeriodAndLength | repetitionPeriod1 | repetitionPeriod1 | repetitionPeriod1 | repetitionPeriod1 |
| PhyCH INFORMATION 1.28 Mcps TDD | | | | |
| UL-DPCH-InfoPredef | | | | |
| >commonTimeslotInfo | | | | |

| Configuration | 28.8 kbps conv. CS- data + 3.4 kbps signalling | 32 kbps conv. CS-data + 3.4 kbps signalling | 64kbps conv. CS-data + 3.4 kbps signalling | 14.4 kbps streaming CS-data + 3.4 kbps signalling |
|---|---|---|---|---|
| >>secondInterleavingMode | frameRelated | frameRelated | frameRelated | frameRelated |
| >>tfci-Coding | 16 | 8 | 8 | 8 |
| >>puncturingLimit | 0.64 | 0.60 | 0.64 | 1 |
| >>repetitionPeriodAndLength | repetitionPeriod1 | repetitionPeriod1 | repetitionPeriod1 | repetitionPeriod1 |
| DL-CommonInformationPredef | | | | |
| >dl-DPCH-InfoCommon | | | | |
| >>commonTimeslotInfo | | | | |
| >>>secondInterleavingMode | frameRelated | frameRelated | frameRelated | frameRelated |
| >>>tfci-Coding | 16 | 8 | 8 | 8 |
| >>>puncturingLimit | 0.64 | 0.60 | 0.64 | 0.88 |
| >>>repetitionPeriodAndLength | repetitionPeriod1 | repetitionPeriod1 | repetitionPeriod1 | repetitionPeriod1 |

| Configuration | 28.8 kbps streaming CS-data + 3.4 kbps signalling | 57.6 kbps streaming CS-data + 3.4 kbps signalling | 12.2/7.95/5.9/4.75 kbps speech + 3.4 kbps signalling |
|---|---|---|---|
| Ref 34.108 | 16 | 17 | 4a |
| Default configuration identity | 8 | 9 | 10 |
| RB INFORMATION | | | |
| rb-Identity | RB1: 1, RB2: 2, RB3: 3, RB5: 5 | RB1: 1, RB2: 2, RB3: 3, RB5: 5 | RB1: 1, RB2: 2, RB3: 3, RB5: 5, RB6: 6, RB7: 7 |
| rlc-InfoChoice | Rlc-info | Rlc-info | Rlc-info |
| >ul-RLC-Mode | RB1: UM<br>RB2- RB3: AM<br>RB5: TM | RB1: UM<br>RB2- RB3: AM<br>RB5: TM | RB1: UM<br>RB2- RB3: AM<br>RB5-RB7: TM |
| >>transmissionRLC-DiscardMode | RB1: N/A<br>RB2- RB3: NoDiscard<br>RB5: N/A | RB1: N/A<br>RB2- RB3: NoDiscard<br>RB5: N/A | RB1: N/A<br>RB2- RB3: NoDiscard<br>RB5- RB7: N/A |
| >>>maxDat | RB1: N/A<br>RB2- RB3: 15<br>RB5: N/A | RB1: N/A<br>RB2- RB3: 15<br>RB5: N/A | RB1: N/A<br>RB2- RB3: 15<br>RB5- RB7: N/A |
| >>transmissionWindowSize | RB1: N/A<br>RB2- RB3: 128 for UEs with more than 10 kbyte "total RLC AM buffer size" and 32 otherwise<br>RB5: N/A | RB1: N/A<br>RB2- RB3: 128 for UEs with more than 10 kbyte "total RLC AM buffer size" and 32 otherwise<br>RB5: N/A | RB1: N/A<br>RB2- RB3: 128 for UEs with more than 10 kbyte "total RLC AM buffer size" and 32 otherwise<br>RB5- RB7: N/A |
| >>timerRST | RB1: N/A<br>RB2- RB3: 300<br>RB5: N/A | RB1: N/A<br>RB2- RB3: 300<br>RB5: N/A | RB1: N/A<br>RB2- RB3: 300<br>RB5- RB7: N/A |
| >>max-RST | RB1: N/A<br>RB2- RB3: 1<br>RB5: N/A | RB1: N/A<br>RB2- RB3: 1<br>RB5: N/A | RB1: N/A<br>RB2- RB3: 1<br>RB5- RB7: N/A |
| >>pollingInfo | RB1: N/A<br>RB2- RB3: as below<br>RB5: N/A | RB1: N/A<br>RB2- RB3: as below<br>RB5: N/A | RB1: N/A<br>RB2- RB3: as below<br>RB5- RB7: N/A |
| >>>lastTransmissionPDU-Poll | RB2- RB3: FALSE | RB2- RB3: FALSE | RB2- RB3: FALSE |
| >>>lastRetransmissionPDU-Poll | RB2- RB3: FALSE | RB2- RB3: FALSE | RB2- RB3: FALSE |
| >>>timerPollPeriodic | RB2- RB3: 300 | RB2- RB3: 300 | RB2- RB3: 300 |

| Configuration | 28.8 kbps streaming CS-data + 3.4 kbps signalling | 57.6 kbps streaming CS-data + 3.4 kbps signalling | 12.2/7.95/5.9/4.75 kbps speech + 3.4 kbps signalling |
|---|---|---|---|
| >>segmentationIndication | RB1- RB3: N/A<br>RB5: FALSE | RB1- RB3: N/A<br>RB5: FALSE | RB1- RB3: N/A<br>RB5- RB7: FALSE |
| >dl-RLC-Mode | RB1: UM<br>RB2- RB3: AM<br>RB5: TM | RB1: UM<br>RB2- RB3: AM<br>RB5: TM | RB1: UM<br>RB2- RB3: AM<br>RB5- RB7: TM |
| >>inSequenceDelivery | RB1: N/A<br>RB2- RB3: TRUE<br>RB5: N/A | RB1: N/A<br>RB2- RB3: TRUE<br>RB5: N/A | RB1: N/A<br>RB2- RB3: TRUE<br>RB5- RB7: N/A |
| >>receivingWindowSize | RB1: N/A<br>RB2- RB3: 128 for UEs with more than 10 kbyte "total RLC AM buffer size" and 32 otherwise<br>RB5: N/A | RB1: N/A<br>RB2- RB3: 128 for UEs with more than 10 kbyte "total RLC AM buffer size" and 32 otherwise<br>RB5: N/A | RB1: N/A<br>RB2- RB3: 128 for UEs with more than 10 kbyte "total RLC AM buffer size" and 32 otherwise<br>RB5- RB7: N/A |
| >>dl-RLC-StatusInfo | RB1: N/A<br>RB2- RB3: as below<br>RB5: N/A | RB1: N/A<br>RB2- RB3: as below<br>RB5: N/A | RB1: N/A<br>RB2- RB3: as below<br>RB5- RB7: N/A |
| >>>timerStatusProhibit | RB2- RB3: 100 | RB2- RB3: 100 | RB2- RB3: 100 |
| >>>missingPDU-Indicator | RB2- RB3: FALSE | RB2- RB3: FALSE | RB2- RB3: FALSE |
| >>>timerStatusPeriodic | RB2- RB3: 300 | RB2- RB3: 300 | RB2- RB3: 300 |
| >>segmentationIndication | RB1- RB3: N/A<br>RB5: FALSE | RB1- RB3: N/A<br>RB5: FALSE | RB1- RB3: N/A<br>RB5- RB7: FALSE |
| rb-MappingInfo | | | |
| >UL-LogicalChannelMappings | OneLogicalChannel | OneLogicalChannel | OneLogicalChannel |
| >>ul-TransportChannelType | Dch | Dch | Dch |
| >>>transportChannelIdentity | RB1- RB3: 2<br>RB5: 1 | RB1- RB3: 2<br>RB5: 1 | RB1- RB3: 4<br>RB5: 1, RB6: 2, RB7: 3 |
| >>logicalChannelIdentity | RB1: 1, RB2: 2, RB3: 3<br>RB5: N/A | RB1: 1, RB2: 2, RB3: 3<br>RB5: N/A | RB1: 1, RB2: 2, RB3: 3<br>RB5- RB7: N/A |
| >>rlc-SizeList | RB1- RB3: configured<br>RB5: N/A | RB1- RB3: configured<br>RB5: N/A | RB1- RB3: configured<br>RB5- RB7: N/A |
| >>mac-LogicalChannelPriority | RB1: 1, RB2: 2, RB3: 3<br>RB5: 5 | RB1: 1, RB2: 2, RB3: 3<br>RB5: 5 | RB1: 1, RB2: 2, RB3: 3<br>RB5- RB7: 5 |
| >DL-logicalChannelMappingList | | | |
| >>Mapping option 1 | One mapping option | One mapping option | One mapping option |
| >>>dl-TransportChannelType | Dch | Dch | Dch |
| >>>>transportChannelIdentity | RB1- RB3: 2<br>RB5: 1 | RB1- RB3: 2<br>RB5: 1 | RB1- RB3: 4<br>RB5: 1, RB6: 2, RB7: 3 |
| >>>logicalChannelIdentity | RB1: 1, RB2: 2, RB3: 3<br>RB5: N/A | RB1: 1, RB2: 2, RB3: 3<br>RB5: N/A | RB1: 1, RB2: 2, RB3: 3<br>RB5- RB7: N/A |
| TrCH INFORMATION PER TrCH | | | |
| UL-AddReconfTransChInfoList | | | |
| >Uplink transport channel type | dch | dch | dch |
| >transportChannelIdentity | TrCH1: 1, TrCH2: 2 | TrCH1: 1, TrCH2: 2 | TrCH1: 1, TrCH2: 2, TrCH3: 3, TrCH4: 4 |
| >transportFormatSet | DedicatedTransChTFS | DedicatedTransChTFS | DedicatedTransChTFS |

| Configuration | 28.8 kbps streaming CS-data + 3.4 kbps signalling | 57.6 kbps streaming CS-data + 3.4 kbps signalling | 12.2/7.95/5.9/4.75 kbps speech + 3.4 kbps signalling |
|---|---|---|---|
| >>dynamicTF-information | | | |
| >>>tf0/ tf0,1 | TrCH1: (0x576, 1x576, 2x576)<br>TrCH2: (0x144, 1x144) | TrCH1: (0x576, 1x576, 2x576, 3x576, 4x576)<br>TrCH2: (0x144, 1x144) | TrCH1: (0x81)<br>TrCH2: (0x 103<br>TrCH3: (0x 60)<br>TrCH4: (0x144) |
| >>>>rlcSize | TrCH1: OctetMode<br>TrCH2:BitMode | TrCH1: OctetMode<br>TrCH2:BitMode | BitMode |
| >>>>>sizeType | TrCH1: type 2, part1= 9, part2= 2 (576)<br>TrCH2: type 2, part1= 2, part2= 0 (144) | TrCH1: type 2, part1= 9, part2= 2 (576)<br>TrCH2: type 2, part1= 2, part2= 0 (144) | TrCH1: type 1: 81<br>TrCH2: type 1: 103<br>TrCH3: type 1: 60<br>TrCH4: 2: type 2, part1= 2, part2= 0 (144) |
| >>>>numberOfTbSizeList | TrCH1: Zero, one, 2<br>TrCH2: Zero, one | TrCH1: Zero, one, 2, 3, 4<br>TrCH2: Zero, one | TrCH1-4: Zero |
| >>>>logicalChannelList | All | All | All |
| >>>tf 1 | | | TrCH1: (1x39)<br>TrCH2: (1x53)<br>TrCH3: (1x60)<br>TrCH4: (1x144) |
| >>>>numberOfTransportBlocks | | | TrCH1-3: One |
| >>>>rlc-Size | | | TrCH1-3: BitMode |
| >>>>>sizeType | | | TrCH1: 1: 39<br>TrCH2: 1: 53<br>TrCH3: 1: 60 |
| >>>>numberOfTbSizeList | | | TrCH1-3: One |
| >>>>logicalChannelList | | | TrCH1-3: all |
| >>>tf 2 | | | TrCH1: (1x42)<br>TrCH2: (1x63)<br>TrCH3- TrCH4: N/A |
| >>>>numberOfTransportBlocks | | | TrCH1-2: One |
| >>>>rlc-Size | | | TrCH1: BitMode |
| >>>>>sizeType | | | TrCH1: type 1: 42<br>TrCH2: type 1: 63 |
| >>>>numberOfTbSizeList | | | TrCH1-2: One |
| >>>>logicalChannelList | | | TrCH1: all |
| >>>tf 3 | | | TrCH1: (1x55)<br>TrCH2: (1x84)<br>TrCH3- TrCH4: N/A |
| >>>>numberOfTransportBlocks | | | TrCH1-2: One |
| >>>>rlc-Size | | | TrCH1: BitMode |
| >>>>>sizeType | | | TrCH1: type 1: 55<br>TrCH2: type 1: 84 |
| >>>>numberOfTbSizeList | | | TrCH1-2: One |
| >>>>logicalChannelList | | | TrCH1: all |
| >>>tf 4 | | | TrCH1: (1x75)<br>TrCH2: (1x103)<br>TrCH3- TrCH4: N/A |
| >>>>numberOfTransportBlocks | | | TrCH1-2: One |
| >>>>rlc-Size | | | TrCH1: BitMode |
| >>>>>sizeType | | | TrCH1: type 1: 75<br>TrCH2: type 1: 103 |
| >>>>numberOfTbSizeList | | | TrCH1-2: One |
| >>>>logicalChannelList | | | TrCH1: all |
| >>>tf 5 | | | TrCH1: (1x81)<br>TrCH2- TrCH4: N/A |

| Configuration | 28.8 kbps streaming CS-data + 3.4 kbps signalling | 57.6 kbps streaming CS-data + 3.4 kbps signalling | 12.2/7.95/5.9/4.75 kbps speech + 3.4 kbps signalling |
|---|---|---|---|
| >>>>numberOfTransportBlocks | | | TrCH1: One |
| >>>>rlc-Size | | | TrCH1: BitMode |
| >>>>>sizeType | | | TrCH1: type 1: 81 |
| >>>>numberOfTbSizeList | | | TrCH1: One |
| >>>>logicalChannelList | | | TrCH1: all |
| >>semiStaticTF-Information | | | |
| >>>tti | TrCH1: 40<br>TrCH2: 40 | TrCH1: 40<br>TrCH2: 40 | TrCH1- TrCH3: 20<br>TrCH4: 40 |
| >>>channelCodingType | TrCH1: Turbo<br>TrCH2: Convolutional | TrCH1: Turbo<br>TrCH2: Convolutional | Convolutional |
| >>>>codingRate | TrCH1: N/A<br>TrCH2: Third | TrCH1: N/A<br>TrCH2: Third | TrCH1- TrCH2: Third<br>TrCH3: Half<br>TrCH4: Third |
| >>>rateMatchingAttribute | TrCH1: 155<br>TrCH2: 160 | TrCH1: 145<br>TrCH2: 160 | TrCH1: 200<br>TrCH2: 190<br>TrCH3: 235<br>TrCH4: 160 |
| >>>crc-Size | TrCH1: 16<br>TrCH2: 16 | TrCH1: 16<br>TrCH2: 16 | TrCH1: 12<br>TrCH2- TrCH3: 0<br>TrCH4: 16 |
| DL-AddReconfTransChInfoList | | | |
| >Downlink transport channel type | dch | dch | dch |
| >dl-TransportChannelIdentity (should be as for UL) | TrCH1: 1, TrCH2: 2 | TrCH1: 1, TrCH2: 2 | TrCH1: 1, TrCH2: 2, TrCH3: 3, TrCH4: 4 |
| >tfs-SignallingMode | SameAsUL | SameAsUL | Independent<br><Only tf0 on TrCH1 is different and shown below> |
| >>transportFormatSet | | | DedicatedTransChTFS |
| >>>dynamicTF-information | | | |
| >>>>tf0/ tf0,1 | | | TrCH1: (1x0) |
| >>>>rlcSize | | | bitMode |
| >>>>>sizeType | | | TrCH1: type 1: 0 |
| >>>>numberOfTbSizeList | | | TrCH1: One |
| >>>>logicalChannelList | | | All |
| >>ULTrCH-Id | TrCH1: 1, TrCH2: 2 | TrCH1: 1, TrCH2: 2 | TrCH1: 1, TrCH2: 2, TrCH3: 3, TrCH4: 4 |
| >dch-QualityTarget | | | |
| >>bler-QualityValue | TrCH1: $1x10^{-2}$<br>TrCH2: Absent | TrCH1: $1x10^{-2}$<br>TrCH2: Absent | TrCH1: $7x10^{-3}$<br>TrCH2- TrCH4: Absent |
| TrCH INFORMATION, COMMON | | | |
| ul-CommonTransChInfo | | | |
| >tfcs-ID (TDD only) | 1 | 1 | 1 |
| >sharedChannelIndicator (TDD only) | FALSE | FALSE | FALSE |
| >tfc-Subset | Absent, not required | Absent, not required | Absent, not required |
| >ul-TFCS | Normal TFCI signalling | Normal TFCI signalling | Normal TFCI signalling |
| >>explicitTFCS-ConfigurationMode | Complete | Complete | Complete |
| >>>ctfcSize | Ctfc4Bit | Ctfc4Bit | Ctfc8Bit |

| Configuration | 28.8 kbps streaming CS-data + 3.4 kbps signalling | 57.6 kbps streaming CS-data + 3.4 kbps signalling | 12.2/7.95/5.9/4.75 kbps speech + 3.4 kbps signalling |
|---|---|---|---|
| >>>>TFCS representation | Addition | Addition | Addition |
| >>>>>TFCS list | | | |
| >>>>>>TFCS 1 | (TF0, TF0) | (TF0, TF0) | (TF0, TF0, TF0, TF0) |
| >>>>>>>ctfc | 0 | 0 | 0 |
| >>>>>>>gainFactorInformation | Computed | Computed | Computed |
| >>>>>>>>referenceTFCId | 0 | 0 | 0 |
| >>>>>>TFCS 2 | (TF1, TF0) | (TF1, TF0) | (TF1, TF0, TF0, TF0) |
| >>>>>>>ctfc | 1 | 1 | 1 |
| >>>>>>>gainFactorInformation | Computed | Computed | Computed |
| >>>>>>>>βc (FDD only) | N/A | N/A | N/A |
| >>>>>>>>βd | N/A | N/A | N/A |
| >>>>>>>>referenceTFCId | 0 | 0 | 0 |
| >>>>>>TFCS 3 | (TF2, TF0) | (TF2, TF0) | (TF2, TF1, TF0, TF0) |
| >>>>>>>ctfc | 2 | 2 | 8 |
| >>>>>>>gainFactorInformation | Computed | Computed | Computed |
| >>>>>>>>referenceTFCId | 0 | 0 | 0 |
| >>>>>>TFCS 4 | (TF0, TF1) | (TF3, TF0) | (TF3, TF2, TF0, TF0) |
| >>>>>>>ctfc | 3 | 3 | 15 |
| >>>>>>>gainFactorInformation | Computed | Computed | Computed |
| >>>>>>>>βc (FDD only) | N/A | N/A | N/A |
| >>>>>>>>βd | N/A | N/A | N/A |
| >>>>>>>>referenceTFCId | 0 | 0 | 0 |
| >>>>>>TFCS 5 | (TF1, TF1) | (TF4, TF0) | (TF4, TF3, TF0, TF0) |
| >>>>>>>ctfc | 4 | 4 | 22 |
| >>>>>>>gainFactorInformation | Computed | Computed | Computed |
| >>>>>>>>referenceTFCId | 0 | 0 | 0 |
| >>>>>>TFCS 6 | (TF2, TF1) | (TF0, TF1) | (TF5, TF4, TF1, TF0) |
| >>>>>>>ctfc | 5 | 5 | 59 |
| >>>>>>>gainFactorInformation | Signalled | Computed | Computed |
| >>>>>>>>βc (FDD only) | 8 | N/A | N/A |
| >>>>>>>>βd | 15 | N/A | N/A |
| >>>>>>>>referenceTFCId | 0 | 0 | 0 |
| >>>>>>TFCS 7 | | (TF1, TF1) | (TF0,TF0,TF0,TF1) |
| >>>>>>>ctfc | | 6 | 60 |
| >>>>>>>gainFactorInformation | | Computed | Computed |
| >>>>>>>>referenceTFCId | | 0 | 0 |
| >>>>>>TFCS 8 | | (TF2, TF1) | (TF1,TF0,TF0,TF1) |
| >>>>>>>ctfc | | 7 | 61 |
| >>>>>>>gainFactorInformation | | Computed | Computed |
| >>>>>>>>referenceTFCId | | 0 | 0 |
| >>>>>>TFCS 9 | | (TF3, TF1) | (TF2,TF1,TF0,TF1) |
| >>>>>>>ctfc | | 8 | 68 |
| >>>>>>>gainFactorInformation | | Computed | Computed |
| >>>>>>>>referenceTFCId | | 0 | 0 |
| >>>>>>TFCS 10 | | (TF4, TF1) | (TF3,TF2,TF0,TF1) |

| Configuration | 28.8 kbps streaming CS-data + 3.4 kbps signalling | 57.6 kbps streaming CS-data + 3.4 kbps signalling | 12.2/7.95/5.9/4.75 kbps speech + 3.4 kbps signalling |
|---|---|---|---|
| >>>>>>>ctfc | | 9 | 75 |
| >>>>>>>gainFactorInformation | | Signalled | Computed |
| >>>>>>>>βc (FDD only) | | 8 | N/A |
| >>>>>>>>βd | | 15 | N/A |
| >>>>>>>>referenceTFCId | | 0 | 0 |
| >>>>>>TFCS 11 | | | (TF4,TF3,TF0,TF1) |
| >>>>>>>ctfc | | | 82 |
| >>>>>>>gainFactorInformation | | | Computed |
| >>>>>>>>referenceTFCId | | | 0 |
| >>>>>>TFCS 12 | | | (TF5,TF4,TF1,TF1) |
| >>>>>>>ctfc | | | 119 |
| >>>>>>>gainFactorInformation | | | Signalled |
| >>>>>>>>βc (FDD only) | | | 11 |
| >>>>>>>>βd | | | 15 |
| >>>>>>>>referenceTFCId | | | 0 |
| dl-CommonTransChInfo | | | |
| >tfcs-SignallingMode | Same as UL | Same as UL | Same as UL |
| PhyCH INFORMATION FDD | | | |
| UL-DPCH-InfoPredef | | | |
| >ul-DPCH-PowerControlInfo | | | |
| >>powerControlAlgorithm | Algorithm 1 | Algorithm 1 | Algorithm 1 |
| >>>tpcStepSize | 1 dB | 1 dB | 1 dB |
| >tfci-Existence | TRUE | TRUE | TRUE |
| >puncturingLimit | 1 | 1 | 0.88 |
| DL-CommonInformationPredef | | | |
| >dl-DPCH-InfoCommon | | | |
| >>spreadingFactor | 64 | 32 | 128 |
| >>tfci-Existence | TRUE | TRUE | FALSE |
| >>pilotBits | 8 | 8 | 4 |
| >>positionFixed | Flexible | Flexible | Fixed |
| PhyCH INFORMATION 3.84 Mcps TDD | | | |
| UL-DPCH-InfoPredef | | | |
| >ul-DPCH-PowerControlInfo | | | |
| >>dpch-ConstantValue | 0 | 0 | 0 |
| >commonTimeslotInfo | | | |
| >>secondInterleavingMode | frameRelated | frameRelated | frameRelated |
| >>tfci-Coding | 16 | 16 | 16 |
| >>puncturingLimit | 0.44 | 0.48 | 0.88 |
| >>repetitionPeriodAndLength | repetitionPeriod1 | repetitionPeriod1 | repetitionPeriod1 |
| DL-CommonInformationPredef | | | |
| >dl-DPCH-InfoCommon | | | |
| >>commonTimeslotInfo | | | |
| >>>secondInterleavingMode | frameRelated | frameRelated | frameRelated |
| >>>tfci-Coding | 16 | 16 | 16 |
| >>>puncturingLimit | 0.44 | 0.48 | 0.92 |

| Configuration | 28.8 kbps streaming CS-data + 3.4 kbps signalling | 57.6 kbps streaming CS-data + 3.4 kbps signalling | 12.2/7.95/5.9/4.75 kbps speech + 3.4 kbps signalling |
|---|---|---|---|
| >>>repetitionPeriodAndLength | repetitionPeriod1 | repetitionPeriod1 | repetitionPeriod1 |
| PhyCH INFORMATION 1.28 Mcps TDD | | | |
| UL-DPCH-InfoPredef | | | |
| >commonTimeslotInfo | | | |
| >>secondInterleavingMode | frameRelated | frameRelated | |
| >>tfci-Coding | 16 | 16 | |
| >>puncturingLimit | 0.64 | 0.72 | |
| >>repetitionPeriodAndLength | repetitionPeriod1 | repetitionPeriod1 | |
| DL-CommonInformationPredef | | | |
| >dl-DPCH-InfoCommon | | | |
| >>commonTimeslotInfo | | | |
| >>>secondInterleavingMode | frameRelated | frameRelated | frameRelated |
| >>>tfci-Coding | 16 | 16 | 16 |
| >>>puncturingLimit | 0.64 | 0.72 | 0.92 |
| >>>repetitionPeriodAndLength | repetitionPeriod1 | repetitionPeriod1 | repetitionPeriod1 |

| Configuration | 10.2/6.7/5.9/4.75 kbps speech + 3.4 kbps signalling + 0.15 kbps SRB#5 | 7.4/6.7/5.9/4.75 kbps speech + 3.4 kbps signalling + 0.15 kbps SRB#5 |
|---|---|---|
| Ref 34.108 | 5a | 7a |
| Default configuration identity | 11 | 12 |
| RB INFORMATION | | |
| rb-Identity | RB1: 1, RB2: 2, RB3: 3, RB5: 5, RB6: 6, RB7: 7, RB8: 8 | RB1: 1, RB2: 2, RB3: 3, RB5: 5, RB6: 6, RB7: 7 |
| rlc-InfoChoice | Rlc-info | Rlc-info |
| >ul-RLC-Mode | RB1: UM<br>RB2- RB3: AM<br>RB5-RB7: TM | RB1: UM<br>RB2- RB3: AM<br>RB5-RB6: TM |
| >>transmissionRLC-DiscardMode | RB1: N/A<br>RB2- RB3: NoDiscard<br>RB5- RB7: N/A | RB1: N/A<br>RB2- RB3: NoDiscard<br>RB5- RB6: N/A |
| >>>maxDat | RB1: N/A<br>RB2- RB3: 15<br>RB5- RB7: N/A | RB1: N/A<br>RB2- RB3: 15<br>RB5- RB6: N/A |
| >>transmissionWindowSize | RB1: N/A<br>RB2- RB3: 128 for UEs with more than 10 kbyte "total RLC AM buffer size" and 32 otherwise<br>RB5- RB7: N/A | RB1: N/A<br>RB2- RB3: 128 for UEs with more than 10 kbyte "total RLC AM buffer size" and 32 otherwise<br>RB5- RB6: N/A |
| >>timerRST | RB1: N/A<br>RB2- RB3: 300<br>RB5- RB7: N/A | RB1: N/A<br>RB2- RB3: 300<br>RB5- RB6: N/A |
| >>max-RST | RB1: N/A<br>RB2- RB3: 1<br>RB5- RB7: N/A | RB1: N/A<br>RB2- RB3: 1<br>RB5- RB6: N/A |
| >>pollingInfo | RB1: N/A<br>RB2- RB3: as below<br>RB5- RB7: N/A | RB1: N/A<br>RB2- RB3: as below<br>RB5- RB6: N/A |
| >>>lastTransmissionPDU-Poll | RB2- RB3: FALSE | RB2- RB3: FALSE |
| >>>lastRetransmissionPDU-Poll | RB2- RB3: FALSE | RB2- RB3: FALSE |
| >>>timerPollPeriodic | RB2- RB3: 300 | RB2- RB3: 300 |
| >>segmentationIndication | RB1- RB3: N/A<br>RB5- RB7: FALSE | RB1- RB3: N/A<br>RB5- RB6: FALSE |
| >dl-RLC-Mode | RB1: UM<br>RB2- RB3: AM<br>RB5- RB7: TM<br>RB8: TM | RB1: UM<br>RB2- RB3: AM<br>RB5- RB6: TM<br>RB7: TM |
| >>inSequenceDelivery | RB1: N/A<br>RB2- RB3: TRUE<br>RB5- RB8: N/A | RB1: N/A<br>RB2- RB3: TRUE<br>RB5- RB7: N/A |
| >>receivingWindowSize | RB1: N/A<br>RB2- RB3: 128 for UEs with more than 10 kbyte "total RLC AM buffer size" and 32 otherwise<br>RB5- RB8: N/A | RB1: N/A<br>RB2- RB3: 128 for UEs with more than 10 kbyte "total RLC AM buffer size" and 32 otherwise<br>RB5- RB7: N/A |
| >>dl-RLC-StatusInfo | RB1: N/A<br>RB2- RB3: as below<br>RB5- RB8: N/A | RB1: N/A<br>RB2- RB3: as below<br>RB5- RB7: N/A |
| >>>timerStatusProhibit | RB2- RB3: 100 | RB2- RB3: 100 |
| >>>missingPDU-Indicator | RB2- RB3: FALSE | RB2- RB3: FALSE |
| >>>timerStatusPeriodic | RB2- RB3: 300 | RB2- RB3: 300 |

| | | |
|---|---|---|
| >>segmentationIndication | RB1- RB3: N/A<br>RB5- RB8: FALSE | RB1- RB3: N/A<br>RB5- RB7: FALSE |
| rb-MappingInfo | | |
| >UL-LogicalChannelMappings | OneLogicalChannel | OneLogicalChannel |
| >>ul-TransportChannelType | Dch | Dch |
| >>>transportChannelIdentity | RB1- RB3: 4<br>RB5: 1, RB6: 2, RB7: 3, | RB1- RB3: 3<br>RB5: 1, RB6: 2 |
| >>logicalChannelIdentity | RB1: 1, RB2: 2, RB3: 3<br>RB5- RB7: N/A | RB1: 1, RB2: 2, RB3: 3<br>RB5- RB6: N/A |
| >>rlc-SizeList | RB1- RB3: configured<br>RB5- RB7: N/A | RB1- RB3: configured<br>RB5- RB6: N/A |
| >>mac-LogicalChannelPriority | RB1: 1, RB2: 2, RB3: 3<br>RB5- RB7: 5 | RB1: 1, RB2: 2, RB3: 3<br>RB5- RB6: 5 |
| >DL-logicalChannelMappingList | | |
| >>Mapping option 1 | One mapping option | One mapping option |
| >>>dl-TransportChannelType | Dch | Dch |
| >>>>transportChannelIdentity | RB1- RB3: 4<br>RB5: 1, RB6: 2, RB7: 3, RB8: 5 | RB1- RB3: 3<br>RB5: 1, RB6: 2, RB7:4 |
| >>>logicalChannelIdentity | RB1: 1, RB2: 2, RB3: 3<br>RB5- RB8: N/A | RB1: 1, RB2: 2, RB3: 3<br>RB5- RB7: N/A |
| TrCH INFORMATION PER TrCH | | |
| UL-AddReconfTransChInfoList | | |
| >Uplink transport channel type | dch | dch |
| >transportChannelIdentity | TrCH1: 1, TrCH2: 2, TrCH3: 3, TrCH4: 4 | TrCH1: 1, TrCH2: 2, TrCH3: 3 |
| >transportFormatSet | DedicatedTransChTFS | DedicatedTransChTFS |
| >>dynamicTF-information | | |
| >>>tf0/ tf0,1 | TrCH1: (0x65)<br>TrCH2: (0x 99)<br>TrCH3: (0x 40, 1x40)<br>TrCH4: (0x144, 1x144) | TrCH1: (0x61)<br>TrCH2: (0x 87)<br>TrCH3: (0x 144, 1x144) |
| >>>>rlcSize | BitMode | BitMode |
| >>>>>sizeType | TrCH1: type 1: 65<br>TrCH2: type 1: 99<br>TrCH3: type 1: 40<br>TrCH4: 2: type 2, part1= 2, part2= 0 (144) | TrCH1: type 1: 61<br>TrCH2: type 1: 87<br>TrCH3: 2: type 2, part1= 2, part2= 0 (144) |
| >>>>numberOfTbSizeList | TrCH1-2: Zero<br>TrCH3-4: Zero, one | TrCH1-2: Zero<br>TrCH3: Zero, one |
| >>>>logicalChannelList | All | All |
| >>>tf 1 | TrCH1: (1x39)<br>TrCH2: (1x 53)<br>TrCH3- TrCH4: N/A | TrCH1: (1x39)<br>TrCH2: (1x53)<br>TrCH3: N/A |
| >>>>numberOfTransportBlocks | TrCH1: One<br>TrCH2: One | TrCH1: One<br>TrCH2: One |
| >>>>rlc-Size | TrCH1-2: BitMode | TrCH1-2: BitMode |
| >>>>>sizeType | TrCH1: 1: 39<br>TrCH2: 1: 53 | TrCH1: 1: 39<br>TrCH1: 1: 53 |
| >>>>numberOfTbSizeList | TrCH1-2: One | TrCH1-2: One |

| | | |
|---|---|---|
| >>>>logicalChannelList | TrCH1: all | TrCH1: all |
| >>>tf 2 | TrCH1: (1x42)<br>TrCH2: (1x63)<br>TrCH3- TrCH4: N/A | TrCH1: (1x42)<br>TrCH2: (1x63)<br>TrCH3: N/A |
| >>>>numberOfTransportBlocks | TrCH1: One<br>TrCh2: One | TrCH1: One<br>TrCh2: One |
| >>>>rlc-Size | TrCH1: BitMode | TrCH1: BitMode |
| >>>>>sizeType | TrCH1: type 1: 42<br>TrCH2: type 1: 63 | TrCH1: type 1: 42<br>TrCH2: type 1: 63 |
| >>>>numberOfTbSizeList | TrCH1: One<br>TrCH2: One | TrCH1: One<br>TrCH2: One |
| >>>>logicalChannelList | TrCH1: all<br>TrCH2: all | TrCH1: all<br>TrCH2: all |
| >>>tf 3 | TrCH1: (1x55)<br>TrCH2: (1x76)<br>TrCH3- TrCH4: N/A | TrCH1: (1x55)<br>TrCH2: (1x76)<br>TrCH3: N/A |
| >>>>numberOfTransportBlocks | TrCH1: One<br>TrCh2: One | TrCH1: One<br>TrCh2: One |
| >>>>rlc-Size | TrCH1: BitMode | TrCH1: BitMode |
| >>>>>sizeType | TrCH1: type 1: 55<br>TrCH2: type 1: 76 | TrCH1: type 1: 55<br>TrCH2: type 1: 76 |
| >>>>numberOfTbSizeList | TrCH1: One<br>TrCH2: One | TrCH1: One<br>TrCH2: One |
| >>>>logicalChannelList | TrCH1: all<br>TrCH2: all | TrCH1: all<br>TrCH2: all |
| >>>tf 4 | TrCH1: (1x58)<br>TrCH2: (1x99)<br>TrCH3- TrCH4: N/A | TrCH1: (1x58)<br>TrCH2: (1x87)<br>TrCH3: N/A |
| >>>>numberOfTransportBlocks | TrCH1: One<br>TrCh2: One | TrCH1: One<br>TrCh2: One |
| >>>>rlc-Size | TrCH1: BitMode | TrCH1: BitMode |
| >>>>>sizeType | TrCH1: type 1: 58<br>TrCH2: type 1: 99 | TrCH1: type 1: 58<br>TrCH2: type 1: 87 |
| >>>>numberOfTbSizeList | TrCH1: One<br>TrCH2: One | TrCH1: One<br>TrCH2: One |
| >>>>logicalChannelList | TrCH1: all<br>TrCH2: all | TrCH1: all<br>TrCH2: all |
| >>>tf 5 | TrCH1: (1x65)<br>TrCH2- TrCH4: N/A | TrCH1: (1x61)<br>TrCH2- TrCH4: N/A |
| >>>>numberOfTransportBlocks | TrCH1: One | TrCH1: One |
| >>>>rlc-Size | TrCH1: BitMode | TrCH1: BitMode |
| >>>>>sizeType | TrCH1: type 1: 65 | TrCH1: type 1: 61 |
| >>>>numberOfTbSizeList | TrCH1: One | TrCH1: One |
| >>>>logicalChannelList | TrCH1: all | TrCH1: all |
| >>semistaticTF-Information | | |
| >>>tti | TrCH1- TrCH3: 20<br>TrCH4: 40 | TrCH1- TrCH2: 20<br>TrCH3: 40 |
| >>>channelCodingType | Convolutional | Convolutional |
| >>>>codingRate | TrCH1- TrCH2:<br>Third<br>TrCH3: Half<br>TrCH4: Third | TrCH1- TrCH2:<br>Third<br>TrCH3: Third |
| >>>rateMatchingAttribute | TrCH1: 200<br>TrCH2: 190<br>TrCH3: 235<br>TrCH4: 160 | TrCH1: 200<br>TrCH2: 190<br>TrCH3: 160 |
| >>>crc-Size | TrCH1: 12<br>TrCH2- TrCH3: 0<br>TrCH4: 16 | TrCH1: 12<br>TrCH2: 0<br>TrCH3: 16 |
| DL-AddReconfTransChInfoList | | |
| >Downlink transport channel type | dch | dch |
| >dl-TransportChannelIdentity | | |

| | | |
|---|---|---|
| >tfs-SignallingMode | Independent<br><Only tf0 on TrCH1 and tf0/tf1 on TrCH5 are different and shown below> | Independent<br><Only tf0 on TrCH1 and tf0/tf1 on TrCH4 are different and shown below> |
| >>transportFormatSet | | |
| >>>dynamicTF-information | | |
| >>>>tf0/ tf0,1 | TrCH1: (1x0)<br>TrCH5: (0x3, 1x3) | TrCH1: (1x0)<br>TrCH4: (0x3, 1x3) |
| >>>>rlcSize | BitMode | bitMode |
| >>>>>sizeType | TrCH1: type 1: 0<br>TrCH5: type 1: 3 | TrCH1: type 1: 0<br>TrCH4: type 1: 3 |
| >>>>numberOfTbSizeList | TrCH1: One<br>TrCH5: Zero, one | TrCH1: One<br>TrCH4: Zero, one |
| >>>>logicalChannelList | All | All |
| >>>semistaticTF-Information | same as UL except for TrCH5 | same as UL except for TrCH4 |
| >>>>tti | TrCH5: 20 | TrCH4: 20 |
| >>>>channelCodingType | Convolutional | Convolutional |
| >>>>>codingRate | TrCH5: Third | TrCH4: Third |
| >>>>rateMatchingAttribute | TrCH5: 200 | TrCH4: 200 |
| >>>>crc-Size | TrCH5: 12 | TrCH4: 12 |
| >>ULTrCH-Id | TrCH1: 1, TrCH2: 2, TrCH3: 3, TrCH4: 4, | TrCH1: 1, TrCH2: 2, TrCH3: 3 |
| >dch-QualityTarget | | |
| >>bler-QualityValue | TrCH1: $7x10^{-3}$<br>TrCH2- TrCH5: Absent | TrCH1: $7x10^{-3}$<br>TrCH2- TrCH4: Absent |
| TrCH INFORMATION, COMMON | | |
| ul-CommonTransChInfo | | |
| >tfcs-ID (TDD only) | 1 | 1 |
| >sharedChannelIndicator (TDD only) | FALSE | FALSE |
| > tfc-Subset | Absent, not required | Absent, not required |
| >ul-TFCS | Normal TFCI signalling | Normal TFCI signalling |
| >>explicitTFCS-ConfigurationMode | Complete | Complete |
| >>>ctfcSize | Ctfc8Bit | Ctfc6Bit |
| >>>>TFCS representation | Addition | Addition |
| >>>>>TFC list | | |
| >>>>>>TFC 1 | (TF0, TF0, TF0, TF0) | (TF0, TF0, TF0) |
| >>>>>>>ctfc | 0 | 0 |
| >>>>>>>gainFactorInformation | Computed | Computed |
| >>>>>>>>referenceTFCId | 0 | 0 |
| >>>>>>TFC 2 | (TF1, TF0, TF0, TF0) | (TF1, TF0, TF0) |
| >>>>>>>ctfc | 1 | 1 |
| >>>>>>>gainFactorInformation | Computed | Computed |
| >>>>>>>>βc (FDD only) | N/A | N/A |
| >>>>>>>>βd | N/A | N/A |
| >>>>>>>>referenceTFCId | 0 | 0 |
| >>>>>>TFC 3 | (TF2, TF1, TF0, TF0) | (TF2, TF1, TF0) |
| >>>>>>>ctfc | 8 | 8 |
| >>>>>>>gainFactorInformation | Computed | Computed |
| >>>>>>>>referenceTFCId | 0 | 0 |
| >>>>>>TFC 4 | (TF3, TF2, TF0, TF0) | (TF3, TF2, TF0) |
| >>>>>>>ctfc | 15 | 15 |

| | | |
|---|---|---|
| >>>>>>>gainFactorInformation | Computed | Computed |
| >>>>>>>>βc (FDD only) | | |
| >>>>>>>>βd | | |
| >>>>>>>>referenceTFCId | 0 | 0 |
| >>>>>>TFC 5 | (TF4, TF3, TF0, TF0) | (TF4, TF3, TF0) |
| >>>>>>>ctfc | 22 | 22 |
| >>>>>>>gainFactorInformation | Computed | Computed |
| >>>>>>>>referenceTFCId | 0 | 0 |
| >>>>>>TFC 6 | (TF5, TF4, TF1, TF0) | (TF5, TF4, TF0) |
| >>>>>>>ctfc | 59 | 29 |
| >>>>>>>gainFactorInformation | Computed | Computed |
| >>>>>>>>βc (FDD only) | | |
| >>>>>>>>βd | | |
| >>>>>>>>referenceTFCId | 0 | 0 |
| >>>>>>TFC 7 | (TF0, TF0, TF0, TF1) | (TF0, TF0, TF1) |
| >>>>>>>ctfc | 60 | 30 |
| >>>>>>>gainFactorInformation | Computed | Computed |
| >>>>>>>>referenceTFCId | 0 | 0 |
| >>>>>>TFC 8 | (TF1, TF0, TF0, TF1) | (TF1, TF0, TF1) |
| >>>>>>>ctfc | 61 | 31 |
| >>>>>>>gainFactorInformation | computed | computed |
| >>>>>>>>βc (FDD only) | | |
| >>>>>>>>βd | | |
| >>>>>>>>referenceTFCId | 0 | 0 |
| >>>>>>TFC 9 | (TF2, TF1, TF0, TF1) | (TF2, TF1, TF1) |
| >>>>>>>ctfc | 68 | 38 |
| >>>>>>>gainFactorInformation | computed | computed |
| >>>>>>>>referenceTFCId | 0 | 0 |
| >>>>>>TFC 10 | (TF3, TF2, TF0, TF1) | (TF3, TF2, TF1) |
| >>>>>>>ctfc | 75 | 45 |
| >>>>>>>gainFactorInformation | computed | computed |
| >>>>>>>>βc (FDD only) | | |
| >>>>>>>>βd | | |
| >>>>>>>>referenceTFCId | 0 | 0 |
| >>>>>>TFC 11 | (TF4, TF3, TF0, TF1) | (TF4, TF3, TF1) |
| >>>>>>>ctfc | 82 | 52 |
| >>>>>>>gainFactorInformation | computed | computed |
| >>>>>>>>referenceTFCId | 0 | 0 |
| >>>>>>TFC 12 | (TF5, TF4, TF1, TF1) | (TF5, TF4, TF1) |
| >>>>>>>ctfc | 119 | 59 |
| >>>>>>>gainFactorInformation | signalled | signalled |
| >>>>>>>>βc (FDD only) | 11 | 11 |
| >>>>>>>>βd | 15 | 15 |
| >>>>>>>>referenceTFCId | 0 | 0 |
| > TFC subset list | | |
| >>TFC subset 1 | (speech rate 10.2) | (speech rate 7.4) |

| | | |
|---|---|---|
| >>> Allowed transport format combination list | (TFC1, TFC2, TFC7, TFC8, TFC6, TFC12) | (TFC1, TFC2, TFC7, TFC8, TFC6, TFC12) |
| >>TFC subset 2 | (speech rate 6.7) | (speech rate 6.7) |
| >>> Allowed transport format combination list | (TFC1, TFC2, TFC7, TFC8, TFC5, TFC11) | (TFC1, TFC2, TFC7, TFC8, TFC5, TFC11) |
| >>TFC subset 3 | (speech rate 5.9) | (speech rate 5.9) |
| >>> Allowed transport format combination list | (TFC1, TFC2, TFC7, TFC8, TFC4, TFC10) | (TFC1, TFC2, TFC7, TFC8, TFC4, TFC10) |
| >>TFC subset 4 | (speech rate 4.75) | (speech rate 4.75) |
| >>> Allowed transport format combination list | (TFC1, TFC2, TFC7, TFC8, TFC3, TFC9) | (TFC1, TFC2, TFC7, TFC8, TFC3, TFC9) |
| dl-CommonTransChInfo | | |
| >tfcs-SignallingMode | Independent | Independent |
| >tfcs-ID (TDD only) | 1 | 1 |
| >sharedChannelIndicator (TDD only) | FALSE | FALSE |
| > tfc-Subset | Absent, not required | Absent, not required |
| >dl-TFCS | Normal TFCI signalling | Normal TFCI signalling |
| >>explicitTFCS-ConfigurationMode | Complete | Complete |
| >>>ctfcSize | Ctfc8Bit | Ctfc8Bit |
| >>>>TFCS representation | Addition | Addition |
| >>>>>TFCS list | | |
| >>>>>>TFC 1 | (TF0, TF0, TF0, TF0, TF0) | (TF0, TF0, TF0, TF0) |
| >>>>>>>ctfc | 0 | 0 |
| >>>>>>TFC 2 | (TF1, TF0, TF0, TF0, TF0) | (TF1, TF0, TF0, TF0) |
| >>>>>>>ctfc | 1 | 1 |
| >>>>>>TFC 3 | (TF2, TF1, TF0, TF0, TF0) | (TF2, TF1, TF0, TF0) |
| >>>>>>>ctfc | 8 | 8 |
| >>>>>>TFC 4 | (TF3, TF2, TF0, TF0, TF0) | (TF3, TF2, TF0, TF0) |
| >>>>>>>ctfc | 15 | 15 |
| >>>>>>TFC 5 | (TF4, TF3, TF0, TF0, TF0) | (TF4, TF3, TF0, TF0) |
| >>>>>>>ctfc | 22 | 22 |
| >>>>>>TFC 6 | (TF5, TF4, TF1, TF0, TF0) | (TF5, TF4, TF0, TF0) |
| >>>>>>>ctfc | 59 | 29 |
| >>>>>>TFC 7 | (TF0, TF0, TF0, TF1, TF0) | (TF0, TF0, TF1, TF0) |
| >>>>>>>ctfc | 60 | 30 |
| >>>>>>TFC 8 | (TF1, TF0, TF0, TF1, TF0) | (TF1, TF0, TF1, TF0) |
| >>>>>>>ctfc | 61 | 31 |
| >>>>>>TFC 9 | (TF2, TF1, TF0, TF1, TF0) | (TF2, TF1, TF1, TF0) |
| >>>>>>>ctfc | 68 | 37 |
| >>>>>>TFC 10 | (TF3, TF2, TF0, TF1, TF0) | (TF3, TF2, TF1, TF0) |
| >>>>>>>ctfc | 75 | 55 |
| >>>>>>TFC 11 | (TF4, TF3, TF0, TF1, TF0) | (TF4, TF3, TF1, TF0) |
| >>>>>>>ctfc | 82 | 52 |
| >>>>>>TFC 12 | (TF5, TF4, TF1, TF1, TF0) | (TF5, TF4, TF1, TF0) |
| >>>>>>>ctfc | 119 | 59 |

| | | |
|---|---|---|
| >>>>>>TFC 13 | (TF0, TF0, TF0, TF0, TF1) | (TF0, TF0, TF0, TF1) |
| >>>>>>>ctfc | 120 | 60 |
| >>>>>>TFC 14 | (TF1, TF0, TF0, TF0, TF1) | (TF1, TF0, TF0, TF1) |
| >>>>>>>ctfc | 121 | 61 |
| >>>>>>TFC 15 | (TF2, TF1, TF0, TF0, TF1) | (TF2, TF1, TF0, TF1) |
| >>>>>>>ctfc | 128 | 68 |
| >>>>>>TFC 16 | (TF3, TF2, TF0, TF0, TF1) | (TF3, TF2, TF0, TF1) |
| >>>>>>>ctfc | 135 | 75 |
| >>>>>>TFC 17 | (TF4, TF3, TF0, TF0, TF1) | (TF4, TF3, TF0, TF1) |
| >>>>>>>ctfc | 142 | 82 |
| >>>>>>TFC 18 | (TF5, TF4, TF1, TF0, TF1) | (TF5, TF4, TF0, TF1) |
| >>>>>>>ctfc | 179 | 89 |
| >>>>>>TFC 19 | (TF0, TF0, TF0, TF1, TF1) | (TF0, TF0, TF1, TF1) |
| >>>>>>>ctfc | 180 | 90 |
| >>>>>>TFC 20 | (TF1, TF0, TF0, TF1, TF1) | (TF1, TF0, TF1, TF1) |
| >>>>>>>ctfc | 181 | 91 |
| >>>>>>TFC 21 | (TF2, TF1, TF0, TF1, TF1) | (TF2, TF1, TF1, TF1) |
| >>>>>>>ctfc | 188 | 98 |
| >>>>>>TFC 22 | (TF3, TF2, TF0, TF1, TF1) | (TF3, TF2, TF1, TF1) |
| >>>>>>>ctfc | 195 | 105 |
| >>>>>>TFC 23 | (TF4, TF3, TF0, TF1, TF1) | (TF4, TF3, TF1, TF1) |
| >>>>>>>ctfc | 202 | 112 |
| >>>>>>TFC 24 | (TF5, TF4, TF1, TF1, TF1) | (TF5, TF4, TF1, TF1) |
| >>>>>>>ctfc | 239 | 119 |
| PhyCH INFORMATION FDD | | |
| UL-DPCH-InfoPredef | | |
| >ul-DPCH-PowerControlInfo | | |
| >>powerControlAlgorithm | Algorithm 1 | Algorithm 1 |
| >>>tpcStepSize | 1 dB | 1 dB |
| >tfci-Existence | TRUE | TRUE |
| >puncturingLimit | 0.88 | 0.88 |
| DL-CommonInformationPredef | | |
| >dl-DPCH-InfoCommon | | |
| >>spreadingFactor | 128 | 128 |
| >>tfci-Existence | FALSE | FALSE |
| >>pilotBits | 4 | 4 |
| >>positionFixed | Fixed | Fixed |
| | | |
| PhyCH INFORMATION 3.84 Mcps TDD | | |
| UL-DPCH-InfoPredef | | |
| >ul-DPCH-PowerControlInfo | | |
| >>dpch-ConstantValue | 0 | 0 |
| >commonTimeslotInfo | | |
| >>secondInterleavingMode | frameRelated | frameRelated |
| >>tfci-Coding | 16 | 16 |
| >>puncturingLimit | 0.60 | 0.60 |
| >>repetitionPeriodAndLength | repetitionPeriod1 | repetitionPeriod1 |

| | | |
|---|---|---|
| DL-CommonInformationPredef | | |
| >dl-DPCH-InfoCommon | | |
| >>commonTimeslotInfo | | |
| >>>secondInterleavingMode | frameRelated | frameRelated |
| >>>tfci-Coding | 16 | 16 |
| >>>puncturingLimit | 0.60 | 0.60 |
| >>>repetitionPeriodAndLength | repetitionPeriod1 | repetitionPeriod1 |
| PhyCH INFORMATION 1.28 Mcps TDD | | |
| UL-DPCH-InfoPredef | | |
| >commonTimeslotInfo | | |
| >>secondInterleavingMode | frame Related | frame Related |
| >>tfci-Coding | 16 | 16 |
| >>puncturingLimit | 0.64 | 0.64 |
| >>repetitionPeriodAndLength | repetitionPeriod1 | repetitionPeriod1 |
| DL-CommonInformationPredef | | |
| >dl-DPCH-InfoCommon | | |
| >>commonTimeslotInfo | | |
| >>>secondInterleavingMode | frame Related | frame Related |
| >>>tfci-Coding | 16 | 16 |
| >>>puncturingLimit | 0.64 | 0.64 |
| >>>repetitionPeriodAndLength | repetitionPeriod1 | repetitionPeriod1 |

NOTE : Default configuration identity 11 can not be used with release 4 UEs.

| Configuration | 12.65/8.85/6.6 kbps speech + 3.4 kbps signalling + 0.15 kbps SRB#5 |
|---|---|
| Ref 34.108 | 62 |
| Default configuration identity | 13 |
| RB INFORMATION | |
| rb-Identity | RB1: 1, RB2: 2, RB3: 3, RB5: 5, RB6: 6, RB7: 7, RB8: 8 |
| rlc-InfoChoice | Rlc-info |
| >ul-RLC-Mode | RB1: UM<br>RB2- RB3: AM<br>RB5-RB7: TM |
| >>transmissionRLC-DiscardMode | RB1: N/A<br>RB2- RB3: NoDiscard<br>RB5- RB7: N/A |
| >>>maxDat | RB1: N/A<br>RB2- RB3: 15<br>RB5- RB7: N/A |
| >>transmissionWindowSize | RB1: N/A<br>RB2- RB3: 128 for UEs with more than 10 kbyte "total RLC AM buffer size" and 32 otherwise<br>RB5- RB7: N/A |
| >>timerRST | RB1: N/A<br>RB2- RB3: 300<br>RB5- RB7: N/A |
| >>max-RST | RB1: N/A<br>RB2- RB3: 1<br>RB5- RB7: N/A |
| >>pollingInfo | RB1: N/A<br>RB2- RB3: as below<br>RB5- RB7: N/A |
| >>>lastTransmissionPDU-Poll | RB2- RB3: FALSE |
| >>>lastRetransmissionPDU-Poll | RB2- RB3: FALSE |
| >>>timerPollPeriodic | RB2- RB3: 300 |
| >>segmentationIndication | RB1- RB3: N/A<br>RB5- RB7: FALSE |
| >dl-RLC-Mode | RB1: UM<br>RB2- RB3: AM<br>RB5- RB7: TM<br>RB8: TM |
| >>inSequenceDelivery | RB1: N/A<br>RB2- RB3: TRUE<br>RB5- RB7: N/A<br>RB8: N/A |
| >>receivingWindowSize | RB1: N/A<br>RB2- RB3: 128 for UEs with more than 10 kbyte "total RLC AM buffer size" and 32 otherwise<br>RB5- RB7: N/A<br>RB8: N/A |
| >>dl-RLC-StatusInfo | RB1: N/A<br>RB2- RB3: as below<br>RB5- RB7: N/A<br>RB8: N/A |

| | |
|---|---|
| >>>timerStatusProhibit | RB2- RB3: 100 |
| >>>missingPDU-Indicator | RB2- RB3: FALSE |
| >>>timerStatusPeriodic | RB2- RB3: 300 |
| >>segmentationIndication | RB1- RB3: N/A<br>RB5- RB7: FALSE<br>RB8: FALSE |
| rb-MappingInfo | |
| >UL-LogicalChannelMappings | OneLogicalChannel |
| >>ul-TransportChannelType | Dch |
| >>>transportChannelIdentity | RB1- RB3: 4<br>RB5: 1, RB6: 2,<br>RB7: 3. |
| >>logicalChannelIdentity | RB1: 1, RB2: 2,<br>RB3: 3<br>RB5- RB7: N/A |
| >>rlc-SizeList | RB1- RB3:<br>configured<br>RB5- RB7: N/A |
| >>mac-LogicalChannelPriority | RB1: 1, RB2: 2,<br>RB3: 3<br>RB5- RB7: 5 |
| >DL-logicalChannelMappingList | |
| >>Mapping option 1 | One mapping option |
| >>>dl-TransportChannelType | Dch |
| >>>>transportChannelIdentity | RB1- RB3: 4<br>RB5: 1, RB6: 2,<br>RB7: 3, RB8: 5 |
| >>>logicalChannelIdentity | RB1: 1, RB2: 2,<br>RB3: 3<br>RB5- RB7: N/A<br>RB8: N/A |
| TrCH INFORMATION PER TrCH | |
| UL-AddReconfTransChInfoList | |
| >Uplink transport channel type | dch |
| >transportChannelIdentity | TrCH1: 1, TrCH2: 2,<br>TrCH3: 3, TrCH4: 4 |
| >transportFormatSet | DedicatedTransChTFS |
| >>dynamicTF-information | |
| >>>tf0/ tf0,1 | TrCH1: (0x72)<br>TrCH2: (0x 181)<br>TrCH3: (0x60)<br>TrCH4: (0x144,<br>1x144) |
| >>>>rlcSize | BitMode |
| >>>>>sizeType | TrCH1: type 1: 72<br>TrCH2: type 2:<br>part1= 6, part2= 5<br>TrCH3: type1: 60<br>TrCH4: 2: type 2,<br>part1= 2, part2= 0<br>(144) |
| >>>>numberOfTbSizeList | TrCH1-3: Zero<br>TrCH4: Zero, one |
| >>>>logicalChannelList | All |
| >>>tf 1 | TrCH1: (1x40)<br>TrCH2: (1x 78)<br>TrCH3: N/A<br>TrCH4: N/A |

| | |
|---|---|
| >>>>numberOfTransportBlocks | TrCH1: One<br>TrCH2: One |
| >>>>rlc-Size | TrCH1-2: BitMode |
| >>>>>sizeType | TrCH1: 1: 40<br>TrCH2: 1: 78 |
| >>>>numberOfTbSizeList | TrCH1-2: One |
| >>>>logicalChannelList | TrCH1: all |
| >>>tf 2 | TrCH1: (1x54)<br>TrCH2: (1x113)<br>TrCH3: N/A<br>TrCH4: N/A |
| >>>>numberOfTransportBlocks | TrCH1: One<br>TrCh2: One |
| >>>>rlc-Size | TrCH1: BitMode |
| >>>>>sizeType | TrCH1: type 1: 54<br>TrCH2: type 1: 113 |
| >>>>numberOfTbSizeList | TrCH1: One<br>TrCH2: One |
| >>>>logicalChannelList | TrCH1: all<br>TrCH2: all |
| >>>tf 3 | TrCH1: (1x64)<br>TrCH2: (1x181)<br>TrCH3: N/A<br>TrCH4: N/A |
| >>>>numberOfTransportBlocks | TrCH1: One<br>TrCh2: One |
| >>>>rlc-Size | TrCH1: BitMode |
| >>>>>sizeType | TrCH1: type 1: 64<br>TrCH2: type 2:<br>part1=6, part2= 5 |
| >>>>numberOfTbSizeList | TrCH1: One<br>TrCH2: One |
| >>>>logicalChannelList | TrCH1: all<br>TrCH2: all |
| >>>tf 4 | TrCH1: (1x72)<br>TrCH2: N/A<br>TrCH3: N/A<br>TrCH4: N/A |
| >>>>numberOfTransportBlocks | TrCH1: One |
| >>>>rlc-Size | TrCH1: BitMode |
| >>>>>sizeType | TrCH1: type 1: 72 |
| >>>>numberOfTbSizeList | TrCH1: One |
| >>>>logicalChannelList | TrCH1: all |
| >>semistaticTF-Information | |
| >>>tti | TrCH1- TrCH2: 20<br>TrCH4: 40 |
| >>>channelCodingType | Convolutional |
| >>>>codingRate | TrCH1- TrCH3:<br>Third<br>TrCH4: Third |
| >>>rateMatchingAttribute | TrCH1: 200<br>TrCH2: 190<br>TrCH3: 256<br>TrCH4: 170 |
| >>>crc-Size | TrCH1: 12<br>TrCH2: 0<br>TrCH3: 0<br>TrCH4: 16 |
| DL-AddReconfTransChInfoList | |
| >Downlink transport channel type | dch |
| >dl-TransportChannelIdentity | |

| | |
|---|---|
| >tfs-SignallingMode | Independent<br><Only tf0 on TrCH1 and tf0/tf1 on TrCH5 are different and shown below> |
| >>transportFormatSet | |
| >>>dynamicTF-information | |
| >>>>tf0/ tf0,1 | TrCH1: (1x0)<br>TrCH5: (0x3, 1x3) |
| >>>>rlcSize | BitMode |
| >>>>>sizeType | TrCH1: type 1: 0<br>TrCH5: type 1: 3 |
| >>>>numberOfTbSizeList | TrCH1: One<br>TrCH5: Zero, one |
| >>>>logicalChannelList | All |
| >>>semistaticTF-Information | same as UL except for TrCH5 |
| >>>>tti | TrCH5: 20 |
| >>>>channelCodingType | Convolutional |
| >>>>>codingRate | TrCH5: Third |
| >>>>rateMatchingAttribute | TrCH5: 205 |
| >>>>crc-Size | TrCH5: 8 |
| >>ULTrCH-Id | TrCH1: 1, TrCH2: 2, TrCH3: 3, TrCH4: 4, |
| >dch-QualityTarget | |
| >>bler-QualityValue | TrCH1: $7x10^{-3}$<br>TrCH2: Absent<br>TrCH3: Absent<br>TrCH4- TrCH5: Absent |
| TrCH INFORMATION, COMMON | |
| ul-CommonTransChInfo | |
| >tfcs-ID (TDD only) | 1 |
| >sharedChannelIndicator (TDD only) | FALSE |
| > tfc-Subset | Absent, not required |
| >ul-TFCS | Normal TFCI signalling |
| >>explicitTFCS-ConfigurationMode | Complete |
| >>>ctfcSize | Ctfc6Bit |
| >>>>TFCS representation | Addition |
| >>>>>TFC list | |
| >>>>>>TFC 1 | (TF0, TF0, TF0, TF0) |
| >>>>>>>ctfc | 0 |
| >>>>>>>gainFactorInformation | Computed |
| >>>>>>>>referenceTFCId | 0 |
| >>>>>>TFC 2 | (TF1, TF0, TF0, TF0) |
| >>>>>>>ctfc | 1 |
| >>>>>>>gainFactorInformation | Computed |
| >>>>>>>>βc (FDD only) | N/A |
| >>>>>>>>βd | N/A |
| >>>>>>>>referenceTFCId | 0 |
| >>>>>>TFC 3 | (TF2, TF1, TF0, TF0) |
| >>>>>>>ctfc | 7 |
| >>>>>>>gainFactorInformation | Computed |
| >>>>>>>>referenceTFCId | 0 |

| | |
|---|---|
| >>>>>>TFC 4 | (TF3, TF2, TF0, TF0) |
| >>>>>>>ctfc | 13 |
| >>>>>>>gainFactorInformation | Computed |
| >>>>>>>>βc (FDD only) | |
| >>>>>>>>βd | |
| >>>>>>>>referenceTFCId | 0 |
| >>>>>>TFC 5 | (TF4, TF3, TF0, TF0) |
| >>>>>>>ctfc | 19 |
| >>>>>>>gainFactorInformation | Computed |
| >>>>>>>>referenceTFCId | 0 |
| >>>>>>TFC 6 | (TF0, TF0, TF0, TF1) |
| >>>>>>>ctfc | 20 |
| >>>>>>>gainFactorInformation | Computed |
| >>>>>>>>βc (FDD only) | |
| >>>>>>>>βd | |
| >>>>>>>>referenceTFCId | 0 |
| >>>>>>TFC 7 | (TF1, TF0, TF0, TF1) |
| >>>>>>>ctfc | 21 |
| >>>>>>>gainFactorInformation | Computed |
| >>>>>>>>referenceTFCId | 0 |
| >>>>>>TFC 8 | (TF2, TF1, TF0, TF1) |
| >>>>>>>ctfc | 27 |
| >>>>>>>gainFactorInformation | computed |
| >>>>>>>>βc (FDD only) | |
| >>>>>>>>βd | |
| >>>>>>>>referenceTFCId | 0 |
| >>>>>>TFC 9 | (TF3, TF2, TF0, TF1) |
| >>>>>>>ctfc | 33 |
| >>>>>>>gainFactorInformation | computed |
| >>>>>>>>referenceTFCId | 0 |
| >>>>>>TFC 10 | (TF4, TF3, TF0, TF1) |
| >>>>>>>ctfc | 39 |
| >>>>>>>gainFactorInformation | signalled |
| >>>>>>>>βc (FDD only) | 11 |
| >>>>>>>>βd | 15 |
| >>>>>>>>referenceTFCId | 0 |
| > TFC subset list | |
| >>TFC subset 1 | (speech rate 6.6) |
| >>> Allowed transport format combination list | (TFC1, TFC2, TFC3, TFC6, TFC7, TFC8) |
| >>TFC subset 2 | (speech rate 8.85) |
| >>> Allowed transport format combination list | (TFC1, TFC2, TFC3, TFC4, TFC6, TFC7, TFC8, TFC9) |
| >>TFC subset 3 | (speech rate 12.65) |
| >>> Allowed transport format combination list | (TFC1, TFC2, TFC3, TFC4, TFC5, TFC6, TFC7, TFC8, TFC9, TFC10) |

| | |
|---|---|
| dl-CommonTransChInfo | |
| >tfcs-SignallingMode | Independent |
| ul-CommonTransChInfo | |
| >tfcs-ID (TDD only) | 1 |
| >sharedChannelIndicator (TDD only) | FALSE |
| > tfc-Subset | Absent, not required |
| >dl-TFCS | Normal TFCI signalling |
| >>explicitTFCS-ConfigurationMode | Complete |
| >>>ctfcSize | Ctfc8Bit |
| >>>>TFCS representation | Addition |
| >>>>>TFCS list | |
| >>>>>>TFC 1 | (TF0, TF0, TF0, TF0, TF0) |
| >>>>>>>ctfc | 0 |
| >>>>>>TFC 2 | (TF1, TF0, TF0, TF0, TF0) |
| >>>>>>>ctfc | 1 |
| >>>>>>TFC 3 | (TF2, TF1, TF0, TF0, TF0) |
| >>>>>>>ctfc | 7 |
| >>>>>>TFC 4 | (TF3, TF2, TF0, TF0, TF0) |
| >>>>>>>ctfc | 13 |
| >>>>>>TFC 5 | (TF4, TF3, TF0, TF0, TF0) |
| >>>>>>>ctfc | 19 |
| >>>>>>TFC 6 | (TF0, TF0, TF0, TF1, TF0) |
| >>>>>>>ctfc | 20 |
| >>>>>>TFC 7 | (TF1, TF0, TF0, TF1, TF0) |
| >>>>>>>ctfc | 21 |
| >>>>>>TFC 8 | (TF2, TF1, TF0, TF1, TF0) |
| >>>>>>>ctfc | 27 |
| >>>>>>TFC 9 | (TF3, TF2, TF0, TF1, TF0) |
| >>>>>>>ctfc | 33 |
| >>>>>>TFC 10 | (TF4, TF3, TF0, TF1, TF0) |
| >>>>>>>ctfc | 39 |
| >>>>>>TFC 11 | (TF0, TF0, TF0, TF0, TF1) |
| >>>>>>>ctfc | 40 |
| >>>>>>TFC 12 | (TF1, TF0, TF0, TF0, TF1) |
| >>>>>>>ctfc | 41 |
| >>>>>>TFC 13 | (TF2, TF1, TF0, TF0, TF1) |
| >>>>>>>ctfc | 47 |
| >>>>>>TFC 14 | (TF3, TF2, TF0, TF0, TF1) |
| >>>>>>>ctfc | 53 |
| >>>>>>TFC 15 | (TF4, TF3, TF0, TF0, TF1) |
| >>>>>>>ctfc | 59 |
| >>>>>>TFC 16 | (TF0, TF0, TF0, TF1, TF1) |
| >>>>>>>ctfc | 60 |
| >>>>>>TFC 17 | (TF1, TF0, TF0, TF1, TF1) |
| >>>>>>>ctfc | 61 |

| | |
|---|---|
| >>>>>>TFC 18 | (TF2, TF1, TF0, TF1, TF1) |
| >>>>>>>ctfc | 67 |
| >>>>>>TFC 19 | (TF3, TF2, TF0, TF1, TF1) |
| >>>>>>>ctfc | 73 |
| >>>>>>TFC 20 | (TF4, TF3, TF0, TF1, TF1) |
| >>>>>>>ctfc | 79 |
| PhyCH INFORMATION FDD | |
| UL-DPCH-InfoPredef | |
| >ul-DPCH-PowerControlInfo | |
| >>powerControlAlgorithm | Algorithm 1 |
| >>>tpcStepSize | 1 dB |
| >tfci-Existence | TRUE |
| >puncturingLimit | 0.84 |
| DL-CommonInformationPredef | |
| >dl-DPCH-InfoCommon | |
| >>spreadingFactor | 128 |
| >>tfci-Existence | FALSE |
| >>pilotBits | 4 |
| >>positionFixed | Fixed |

| **Configuration** | **12.2/7.4/5.9/4.75 kbps speech + 3.4 kbps signalling + 0.15 kbps SRB#5** |
|---|---|
| Ref 34.108 | 4b |
| Default configuration identity | 14 |
| RB INFORMATION | |
| rb-Identity | RB1: 1, RB2: 2, RB3: 3, RB5: 5, RB6: 6, RB7: 7, RB8: 8 |
| rlc-InfoChoice | Rlc-info |
| >ul-RLC-Mode | RB1: UM<br>RB2- RB3: AM<br>RB5-RB7: TM |
| >>transmissionRLC-DiscardMode | RB1: N/A<br>RB2- RB3: NoDiscard<br>RB5- RB7: N/A |
| >>>maxDat | RB1: N/A<br>RB2- RB3: 15<br>RB5- RB7: N/A |
| >>transmissionWindowSize | RB1: N/A<br>RB2- RB3: 128 for UEs with more than 10 kbyte "total RLC AM buffer size" and 32 otherwise<br>RB5- RB7: N/A |
| >>timerRST | RB1: N/A<br>RB2- RB3: 300<br>RB5- RB7: N/A |
| >>max-RST | RB1: N/A<br>RB2- RB3: 1<br>RB5- RB7: N/A |
| >>pollingInfo | RB1: N/A<br>RB2- RB3: as below<br>RB5- RB7: N/A |

| Configuration | 12.2/7.4/5.9/4.75 kbps speech + 3.4 kbps signalling + 0.15 kbps SRB#5 |
|---|---|
| >>>lastTransmissionPDU-Poll | RB2- RB3: FALSE |
| >>>lastRetransmissionPDU-Poll | RB2- RB3: FALSE |
| >>>timerPollPeriodic | RB2- RB3: 300 |
| >>segmentationIndication | RB1- RB3: N/A<br>RB5- RB7: FALSE |
| >dl-RLC-Mode | RB1: UM<br>RB2- RB3: AM<br>RB5- RB7: TM<br>RB8: TM |
| >>inSequenceDelivery | RB1: N/A<br>RB2- RB3: TRUE<br>RB5- RB8: N/A |
| >>receivingWindowSize | RB1: N/A<br>RB2- RB3: 128 for UEs with more than 10 kbyte "total RLC AM buffer size" and 32 otherwise<br>RB5- RB8: N/A |
| >>dl-RLC-StatusInfo | RB1: N/A<br>RB2- RB3: as below<br>RB5- RB8: N/A |
| >>>timerStatusProhibit | RB2- RB3: 100 |
| >>>missingPDU-Indicator | RB2- RB3: FALSE |
| >>>timerStatusPeriodic | RB2- RB3: 300 |
| >>segmentationIndication | RB1- RB3: N/A<br>RB5- RB8: FALSE |
| rb-MappingInfo | |
| >UL-LogicalChannelMappings | OneLogicalChannel |
| >>ul-TransportChannelType | Dch |
| >>>transportChannelIdentity | RB1- RB3: 4<br>RB5: 1, RB6: 2, RB7: 3. |
| >>logicalChannelIdentity | RB1: 1, RB2: 2, RB3: 3<br>RB5- RB7: N/A |
| >>rlc-SizeList | RB1- RB3: configured<br>RB5- RB7: N/A |
| >>mac-LogicalChannelPriority | RB1: 1, RB2: 2, RB3: 3<br>RB5- RB7: 5 |
| >DL-logicalChannelMappingList | |
| >>Mapping option 1 | One mapping option |
| >>>dl-TransportChannelType | Dch |
| >>>>transportChannelIdentity | RB1- RB3: 4<br>RB5: 1, RB6: 2, RB7: 3, RB8: 5 |
| >>>logicalChannelIdentity | RB1: 1, RB2: 2, RB3: 3<br>RB5- RB8: N/A |
| TrCH INFORMATION PER TrCH | |
| UL-AddReconfTransChInfoList | |

| Configuration | 12.2/7.4/5.9/4.75 kbps speech + 3.4 kbps signalling + 0.15 kbps SRB#5 |
|---|---|
| >Uplink transport channel type | dch |
| >transportChannelIdentity | TrCH1: 1, TrCH2: 2, TrCH3: 3, TrCH4: 4 |
| >transportFormatSet | DedicatedTransChTFS |
| >>dynamicTF-information | |
| >>>tf0/ tf0,1 | TrCH1: (0x81)<br>TrCH2: (0x 103)<br>TrCH3: (0x60)<br>TrCH4: (0x144, 1x144) |
| >>>>rlcSize | BitMode |
| >>>>>sizeType | TrCH1: type 1: 81<br>TrCH2: type 1: 103<br>TrCH3: type1: 60<br>TrCH4: 2: type 2, part1= 2, part2= 0 (144) |
| >>>>numberOfTbSizeList | TrCH1-3: Zero<br>TrCH4: Zero, one |
| >>>>logicalChannelList | All |
| >>>tf 1 | TrCH1: (1x39)<br>TrCH2: (1x53)<br>TrCH3: (1x60)<br>TrCH4: (1x144) |
| >>>>numberOfTransportBlocks | TrCH1-3: One |
| >>>>rlc-Size | TrCH1-3: BitMode |
| >>>>>sizeType | TrCH1: 1: 39<br>TrCH2: 1: 53<br>TrCH3: 1: 60 |
| >>>>numberOfTbSizeList | TrCH1-3: One |
| >>>>logicalChannelList | TrCH1-3: all |
| >>>tf 2 | TrCH1: (1x42)<br>TrCH2: (1x63)<br>TrCH3- TrCH4: N/A |
| >>>>numberOfTransportBlocks | TrCH1-2: One |
| >>>>rlc-Size | TrCH1: BitMode |
| >>>>>sizeType | TrCH1: type 1: 42<br>TrCH2: type 1: 63 |
| >>>>numberOfTbSizeList | TrCH1-2: One |
| >>>>logicalChannelList | TrCH1: all |
| >>>tf 3 | TrCH1: (1x55)<br>TrCH2: (1x87)<br>TrCH3- TrCH4: N/A |
| >>>>numberOfTransportBlocks | TrCH1-2: One |
| >>>>rlc-Size | TrCH1: BitMode |
| >>>>>sizeType | TrCH1: type 1: 55<br>TrCH2: type 1: 87 |
| >>>>numberOfTbSizeList | TrCH1-2: One |
| >>>>logicalChannelList | TrCH1: all |
| >>>tf 4 | TrCH1: (1x61)<br>TrCH2: (1x103)<br>TrCH3- TrCH4: N/A |
| >>>>numberOfTransportBlocks | TrCH1-2: One |
| >>>>rlc-Size | TrCH1: BitMode |
| >>>>>sizeType | TrCH1: type 1: 61<br>TrCH2: type 1: 103 |

| Configuration | 12.2/7.4/5.9/4.75 kbps speech + 3.4 kbps signalling + 0.15 kbps SRB#5 |
|---|---|
| >>>>numberOfTbSizeList | TrCH1-2: One |
| >>>>logicalChannelList | TrCH1: all |
| >>>tf 5 | TrCH1: (1x81)<br>TrCH2- TrCH4: N/A |
| >>>>numberOfTransportBlocks | TrCH1: One |
| >>>>rlc-Size | TrCH1: BitMode |
| >>>>>sizeType | TrCH1: type 1: 81 |
| >>>>numberOfTbSizeList | TrCH1: One |
| >>>>logicalChannelList | TrCH1: all |
| >>semiStaticTF-Information | |
| >>>tti | TrCH1- TrCH3: 20<br>TrCH4: 40 |
| >>>channelCodingType | Convolutional |
| >>>>codingRate | TrCH1- TrCH2: Third<br>TrCH3: Half<br>TrCH4: Third |
| >>>rateMatchingAttribute | TrCH1: 200<br>TrCH2: 190<br>TrCH3: 235<br>TrCH4: 160 |
| >>>crc-Size | TrCH1: 12<br>TrCH2- TrCH3: 0<br>TrCH4: 16 |
| DL-AddReconfTransChInfoList | |
| >Downlink transport channel type | |
| >dl-TransportChannelIdentity (should be as for UL) | |
| >tfs-SignallingMode | Independent<br><Only tf0 on TrCH1 and tf0/tf1 on TrCH5 are different and shown below> |
| >>transportFormatSet | |
| >>>dynamicTF-information | |
| >>>>tf0/ tf0,1 | TrCH1: (1x0)<br>TrCH5: (0x3, 1x3) |
| >>>>rlcSize | bitMode |
| >>>>>sizeType | TrCH1: type 1: 0<br>TrCH5: type 1: 3 |
| >>>>numberOfTbSizeList | TrCH1: One<br>TrCH5: Zero, one |
| >>>>logicalChannelList | all |
| >>>semistaticTF-Information | same as UL except for TrCH5 |
| >>>>tti | TrCH5: 20 |
| >>>>channelCodingType | Convolutional |
| >>>>>codingRate | TrCH5: Third |
| >>>>rateMatchingAttribute | TrCH5: 205 |
| >>>>crc-Size | TrCH5: 8 |
| >>ULTrCH-Id | TrCH1: 1, TrCH2: 2, TrCH3: 3, TrCH4: 4 |
| >dch-QualityTarget | |

| Configuration | 12.2/7.4/5.9/4.75 kbps speech + 3.4 kbps signalling + 0.15 kbps SRB#5 |
|---|---|
| >>bler-QualityValue | TrCH1: $7x10^{-3}$<br>TrCH2: Absent<br>TrCH3: Absent<br>TrCH4- TrCH5: Absent |
| TrCH INFORMATION, COMMON | |
| ul-CommonTransChInfo | |
| >tfcs-ID (TDD only) | 1 |
| >sharedChannelIndicator (TDD only) | FALSE |
| >tfc-Subset | Absent, not required |
| >ul-TFCS | Normal TFCI signalling |
| >>explicitTFCS-ConfigurationMode | Complete |
| >>>ctfcSize | Ctfc8Bit |
| >>>>TFCS representation | Addition |
| >>>>>TFCS list | |
| >>>>>>TFCS 1 | (TF0, TF0, TF0, TF0) |
| >>>>>>>ctfc | 0 |
| >>>>>>>gainFactorInformation | Computed |
| >>>>>>>>referenceTFCId | 0 |
| >>>>>>TFCS 2 | (TF1, TF0, TF0, TF0) |
| >>>>>>>ctfc | 1 |
| >>>>>>>gainFactorInformation | Computed |
| >>>>>>>>βc (FDD only) | N/A |
| >>>>>>>>βd | N/A |
| >>>>>>>>referenceTFCId | 0 |
| >>>>>>TFCS 3 | (TF2, TF1, TF0, TF0) |
| >>>>>>>ctfc | 8 |
| >>>>>>>gainFactorInformation | Computed |
| >>>>>>>>referenceTFCId | 0 |
| >>>>>>TFCS 4 | (TF3, TF2, TF0, TF0) |
| >>>>>>>ctfc | 15 |
| >>>>>>>gainFactorInformation | Computed |
| >>>>>>>>βc (FDD only) | N/A |
| >>>>>>>>βd | N/A |
| >>>>>>>>referenceTFCId | 0 |
| >>>>>>TFCS 5 | (TF4, TF3, TF0, TF0) |
| >>>>>>>ctfc | 22 |
| >>>>>>>gainFactorInformation | Computed |
| >>>>>>>>referenceTFCId | 0 |
| >>>>>>TFCS 6 | (TF5, TF4, TF1, TF0) |
| >>>>>>>ctfc | 59 |
| >>>>>>>gainFactorInformation | Computed |
| >>>>>>>>βc (FDD only) | N/A |
| >>>>>>>>βd | N/A |

| Configuration | 12.2/7.4/5.9/4.75 kbps speech + 3.4 kbps signalling + 0.15 kbps SRB#5 |
|---|---|
| >>>>>>>>referenceTFCId | 0 |
| >>>>>>TFCS 7 | (TF0,TF0,TF0,TF1) |
| >>>>>>>ctfc | 60 |
| >>>>>>>gainFactorInformation | Computed |
| >>>>>>>>referenceTFCId | 0 |
| >>>>>>TFCS 8 | (TF1,TF0,TF0,TF1) |
| >>>>>>>ctfc | 61 |
| >>>>>>>gainFactorInformation | Computed |
| >>>>>>>>referenceTFCId | 0 |
| >>>>>>TFCS 9 | (TF2,TF1,TF0,TF1) |
| >>>>>>>ctfc | 68 |
| >>>>>>>gainFactorInformation | Computed |
| >>>>>>>>referenceTFCId | 0 |
| >>>>>>TFCS 10 | (TF3,TF2,TF0,TF1) |
| >>>>>>>ctfc | 75 |
| >>>>>>>gainFactorInformation | Computed |
| >>>>>>>>βc (FDD only) | N/A |
| >>>>>>>>βd | N/A |
| >>>>>>>>referenceTFCId | 0 |
| >>>>>>TFCS 11 | (TF4,TF3,TF0,TF1) |
| >>>>>>>ctfc | 82 |
| >>>>>>>gainFactorInformation | Computed |
| >>>>>>>>referenceTFCId | 0 |
| >>>>>>TFCS 12 | (TF5,TF4,TF1,TF1) |
| >>>>>>>ctfc | 119 |
| >>>>>>>gainFactorInformation | Signalled |
| >>>>>>>>βc (FDD only) | 11 |
| >>>>>>>>βd | 15 |
| >>>>>>>>referenceTFCId | 0 |
| > TFC subset list | |
| >>TFC subset 1 | (speech rate 4.75) |
| >>> Allowed transport format combination list | (TFC1, TFC2, TFC3, TFC7, TFC8, TFC9) |
| >>TFC subset 2 | (speech rate 5.9) |
| >>> Allowed transport format combination list | (TFC1, TFC2, TFC3, TFC4, TFC7, TFC8, TFC9, TFC10) |
| >>TFC subset 3 | (speech rate 7.4) |
| >>> Allowed transport format combination list | (TFC1, TFC2, TFC3, TFC4, TFC5, TFC7, TFC8, TFC9, TFC10, TFC11) |
| >>TFC subset 4 | (speech rate 12.2) |
| >>> Allowed transport format combination list | (TFC1, TFC2, TFC3, TFC4, TFC5, TFC6, TFC7, TFC8, TFC9, TFC10, TFC11, TFC12) |
| dl-CommonTransChInfo | |
| >tfcs-SignallingMode | Independent |
| ul-CommonTransChInfo | |
| >tfcs-ID (TDD only) | 1 |

| Configuration | 12.2/7.4/5.9/4.75 kbps speech + 3.4 kbps signalling + 0.15 kbps SRB#5 |
|---|---|
| >sharedChannelIndicator (TDD only) | FALSE |
| > tfc-Subset | Absent, not required |
| >dl-TFCS | Normal TFCI signalling |
| >>explicitTFCS-ConfigurationMode | Complete |
| >>>ctfcSize | Ctfc8Bit |
| >>>>TFCS representation | Addition |
| >>>>>TFCS list | |
| >>>>>>TFC 1 | (TF0, TF0, TF0, TF0, TF0) |
| >>>>>>>ctfc | 0 |
| >>>>>>TFC 2 | (TF1, TF0, TF0, TF0, TF0) |
| >>>>>>>ctfc | 1 |
| >>>>>>TFC 3 | (TF2, TF1, TF0, TF0, TF0) |
| >>>>>>>ctfc | 8 |
| >>>>>>TFC 4 | (TF3, TF2, TF0, TF0, TF0) |
| >>>>>>>ctfc | 15 |
| >>>>>>TFC 5 | (TF4, TF3, TF0, TF0, TF0) |
| >>>>>>>ctfc | 22 |
| >>>>>>TFC 6 | (TF5,TF4,TF1,TF0, TF0) |
| >>>>>>>ctfc | 59 |
| >>>>>>TFC 7 | (TF0, TF0, TF0, TF1, TF0) |
| >>>>>>>ctfc | 60 |
| >>>>>>TFC 8 | (TF1, TF0, TF0, TF1, TF0) |
| >>>>>>>ctfc | 61 |
| >>>>>>TFC 9 | (TF2, TF1, TF0, TF1, TF0) |
| >>>>>>>ctfc | 68 |
| >>>>>>TFC 10 | (TF3, TF2, TF0, TF1, TF0) |
| >>>>>>>ctfc | 75 |
| >>>>>>TFC 11 | (TF4, TF3, TF0, TF1, TF0) |
| >>>>>>>ctfc | 82 |
| >>>>>>TFC 12 | (TF5,TF4,TF1,TF1, TF0) |
| >>>>>>>ctfc | 119 |
| >>>>>>TFC 13 | (TF0, TF0, TF0, TF0, TF1) |
| >>>>>>>ctfc | 120 |
| >>>>>>TFC 14 | (TF1, TF0, TF0, TF0, TF1) |
| >>>>>>>ctfc | 121 |
| >>>>>>TFC 15 | (TF2, TF1, TF0, TF0, TF1) |
| >>>>>>>ctfc | 128 |
| >>>>>>TFC 16 | (TF3, TF2, TF0, TF0, TF1) |
| >>>>>>>ctfc | 135 |
| >>>>>>TFC 17 | (TF4, TF3, TF0, TF0, TF1) |
| >>>>>>>ctfc | 142 |

| Configuration | 12.2/7.4/5.9/4.75 kbps speech + 3.4 kbps signalling + 0.15 kbps SRB#5 |
|---|---|
| >>>>>>TFC 18 | (TF5,TF4,TF1,TF0, TF1) |
| >>>>>>>ctfc | 179 |
| >>>>>>TFC 19 | (TF0, TF0, TF0, TF1, TF1) |
| >>>>>>>ctfc | 180 |
| >>>>>>TFC 20 | (TF1, TF0, TF0, TF1, TF1) |
| >>>>>>>ctfc | 181 |
| >>>>>>TFC 21 | (TF2, TF1, TF0, TF1, TF1) |
| >>>>>>>ctfc | 187 |
| >>>>>>TFC 22 | (TF3, TF2, TF0, TF1, TF1) |
| >>>>>>>ctfc | 193 |
| >>>>>>TFC 23 | (TF4, TF3, TF0, TF1, TF1) |
| >>>>>>>ctfc | 199 |
| >>>>>>TFC 24 | (TF5,TF4,TF1,TF1, TF1) |
| >>>>>>>ctfc | 239 |
| PhyCH INFORMATION FDD | |
| UL-DPCH-InfoPredef | |
| >ul-DPCH-PowerControlInfo | |
| >>powerControlAlgorithm | Algorithm 1 |
| >>>tpcStepSize | 1 dB |
| >tfci-Existence | TRUE |
| >puncturingLimit | 0.84 |
| DL-CommonInformationPredef | |
| >dl-DPCH-InfoCommon | |
| >>spreadingFactor | 128 |
| >>tfci-Existence | FALSE |
| >>pilotBits | 4 |
| >>positionFixed | Fixed |
| PhyCH INFORMATION 3.84 Mcps TDD | |
| UL-DPCH-InfoPredef | |
| >ul-DPCH-PowerControlInfo | |
| >>dpch-ConstantValue | |
| >commonTimeslotInfo | |
| >>secondInterleavingMode | |
| >>tfci-Coding | |
| >>puncturingLimit | |
| >>repetitionPeriodAndLength | |
| DL-CommonInformationPredef | |
| >dl-DPCH-InfoCommon | |
| >>commonTimeslotInfo | |
| >>>secondInterleavingMode | |
| >>>tfci-Coding | |
| >>>puncturingLimit | |

| Configuration | 12.2/7.4/5.9/4.75 kbps speech + 3.4 kbps signalling + 0.15 kbps SRB#5 |
|---|---|
| >>>repetitionPeriodAndLength | |
| PhyCH INFORMATION 1.28 Mcps TDD | |
| UL-DPCH-InfoPredef | |
| >commonTimeslotInfo | |
| >>secondInterleavingMode | |
| >>tfci-Coding | |
| >>puncturingLimit | |
| >>repetitionPeriodAndLength | |
| DL-CommonInformationPredef | |
| >dl-DPCH-InfoCommon | |
| >>commonTimeslotInfo | |
| >>>secondInterleavingMode | |
| >>>tfci-Coding | |
| >>>puncturingLimit | |
| >>>repetitionPeriodAndLength | |

| Configuration | 7.95 kbps speech + 3.4 kbps signalling |
|---|---|
| Ref 34.108 | 6 |
| Default configuration identity | 15 |
| RB INFORMATION | |
| rb-Identity | RB1: 1, RB2: 2, RB3: 3, RB5: 5, RB6: 6, RB7: 7 |
| rlc-InfoChoice | Rlc-info |
| >ul-RLC-Mode | RB1: UM<br>RB2- RB3: AM<br>RB5-RB7: TM |
| >>transmissionRLC-DiscardMode | RB1: N/A<br>RB2- RB3: NoDiscard<br>RB5- RB7: N/A |
| >>>maxDat | RB1: N/A<br>RB2- RB3: 15<br>RB5- RB7: N/A |
| >>transmissionWindowSize | RB1: N/A<br>RB2- RB3: 128 for UEs with more than 10 kbyte "total RLC AM buffer size" and 32 otherwise<br>RB5- RB7: N/A |
| >>timerRST | RB1: N/A<br>RB2- RB3: 300<br>RB5- RB7: N/A |
| >>max-RST | RB1: N/A<br>RB2- RB3: 1<br>RB5- RB7: N/A |

| Configuration | 7.95 kbps speech<br>+<br>3.4 kbps signalling |
|---|---|
| >>pollingInfo | RB1: N/A<br>RB2- RB3: as below<br>RB5- RB7: N/A |
| >>>lastTransmissionPDU-Poll | RB2- RB3: FALSE |
| >>>lastRetransmissionPDU-Poll | RB2- RB3: FALSE |
| >>>timerPollPeriodic | RB2- RB3: 300 |
| >>segmentationIndication | RB1- RB3: N/A<br>RB5- RB7: FALSE |
| >dl-RLC-Mode | RB1: UM<br>RB2- RB3: AM<br>RB5- RB7: TM |
| >>inSequenceDelivery | RB1: N/A<br>RB2- RB3: TRUE<br>RB5- RB7: N/A |
| >>receivingWindowSize | RB1: N/A<br>RB2- RB3: 128 for UEs with more than 10 kbyte "total RLC AM buffer size" and 32 otherwise<br>RB5- RB7: N/A |
| >>dl-RLC-StatusInfo | RB1: N/A<br>RB2- RB3: as below<br>RB5- RB7: N/A |
| >>>timerStatusProhibit | RB2- RB3: 100 |
| >>>missingPDU-Indicator | RB2- RB3: FALSE |
| >>>timerStatusPeriodic | RB2- RB3: 300 |
| >>segmentationIndication | RB1- RB3: N/A<br>RB5- RB7: FALSE |
| rb-MappingInfo | |
| >UL-LogicalChannelMappings | OneLogicalChannel |
| >>ul-TransportChannelType | Dch |
| >>>transportChannelIdentity | RB1- RB3: 3<br>RB5: 1, RB6: 2, RB7: 3 |
| >>logicalChannelIdentity | RB1: 1, RB2: 2, RB3: 3<br>RB5- RB7: N/A |
| >>rlc-SizeList | RB1- RB3: configured<br>RB5- RB7: N/A |
| >>mac-LogicalChannelPriority | RB1: 1, RB2: 2, RB3: 3<br>RB5- RB7: 5 |
| >DL-logicalChannelMappingList | |
| >>Mapping option 1 | One mapping option |
| >>>dl-TransportChannelType | Dch |
| >>>>transportChannelIdentity | RB1- RB3: 3<br>RB5: 1, RB6: 2, RB7: 3 |
| >>>logicalChannelIdentity | RB1: 1, RB2: 2, RB3: 3<br>RB5- RB7: N/A |
| TrCH INFORMATION PER TrCH | |

| Configuration | 7.95 kbps speech + 3.4 kbps signalling |
|---|---|
| UL-AddReconfTransChInfoList | |
| >Uplink transport channel type | dch |
| >transportChannelIdentity | TrCH1: 1, TrCH2: 2, TrCH3:3, TrCH4: 4 |
| >transportFormatSet | DedicatedTransChTFS |
| >>dynamicTF-information | |
| >>>tf0/ tf0,1 | TrCH1: (0x75)<br>TrCH2: (0x 84<br>1x84)<br>TrCH3: (0x 60)<br>TrCH4: (0x144,<br>1x144) |
| >>>>rlcSize | BitMode |
| >>>>>sizeType | TrCH1: type 1: 75<br>TrCH2: type 1: 84<br>TrCH3: type 1: 60<br>TrCH4: 2: type 2,<br>part1= 2, part2= 0<br>(144) |
| >>>>numberOfTbSizeList | TrCH1: Zero<br>TrCH2-4: Zero, one |
| >>>>logicalChannelList | All |
| >>>tf 1 | TrCH1: (1x39)<br>TrCH2- TrCH4: N/A |
| >>>>numberOfTransportBlocks | TrCH1: One |
| >>>>rlc-Size | TrCH1: BitMode |
| >>>>>sizeType | TrCH1: 1: 39 |
| >>>>numberOfTbSizeList | TrCH1: One |
| >>>>logicalChannelList | TrCH1: all |
| >>>tf 2 | TrCH1: (1x75)<br>TrCH2- TrCH4: N/A |
| >>>>numberOfTransportBlocks | TrCH1: One |
| >>>>rlc-Size | TrCH1: BitMode |
| >>>>>sizeType | TrCH1: type 1: 75 |
| >>>>numberOfTbSizeList | TrCH1: One |
| >>>>logicalChannelList | TrCH1: all |
| >>semistaticTF-Information | |
| >>>tti | TrCH1- TrCH4: 20<br>TrCH3: 40 |
| >>>channelCodingType | Convolutional |
| >>>>codingRate | TrCH1- TrCH2:<br>Third<br>TrCH3: Half<br>TrCH4: Third |
| >>>rateMatchingAttribute | TrCH1: 200<br>TrCH2: 190<br>TrCH3: 235<br>TrCH4: 160 |
| >>>crc-Size | TrCH1: 12<br>TrCH2-TrCH3: 0<br>TrCH4: 16 |
| DL-AddReconfTransChInfoList | |
| >Downlink transport channel type | Dch |

| Configuration | 7.95 kbps speech + 3.4 kbps signalling |
|---|---|
| >dl-TransportChannelIdentity (should be as for UL) | TrCH1: 1, TrCH2: 2, TrCH3: 3, TrCH4: 4 |
| >tfs-SignallingMode | Explicit <Only tf0 on TrCH1 is different and shown below> |
| >>transportFormatSet | DedicatedTransChTFS |
| >>>dynamicTF-information | |
| >>>>tf0/ tf0,1 | TrCH1: (1x0) |
| >>>>rlcSize | BitMode |
| >>>>>sizeType | TrCH1: type 1: 0 |
| >>>>numberOfTbSizeList | TrCH1: One |
| >>>>logicalChannelList | All |
| >>ULTrCH-Id | TrCH1: 1, TrCH2: 2, TrCH3:3, TrCH4: 4 |
| >dch-QualityTarget | |
| >>bler-QualityValue | TrCH1: 7x10-3 TrCH2- TrCH4: Absent |
| TrCH INFORMATION, COMMON | |
| ul-CommonTransChInfo | |
| >tfcs-ID (TDD only) | 1 |
| >sharedChannelIndicator (TDD only) | FALSE |
| >tfc-Subset | Absent, not required |
| >ul-TFCS | Normal TFCI signalling |
| >>explicitTFCS-ConfigurationMode | Complete |
| >>>ctfcSize | Ctfc4Bit |
| >>>>TFCS representation | Addition |
| >>>>>TFCS list | |
| >>>>>>TFCS 1 | (TF0, TF0, TF0, TF0) |
| >>>>>>>ctfc | 0 |
| >>>>>>>gainFactorInformation | Computed |
| >>>>>>>>referenceTFCId | 0 |
| >>>>>>TFCS 2 | (TF1, TF0, TF0, TF0) |
| >>>>>>>ctfc | 1 |
| >>>>>>>gainFactorInformation | Computed |
| >>>>>>>>βc (FDD only) | N/A |
| >>>>>>>>βd | N/A |
| >>>>>>>>referenceTFCId | 0 |
| >>>>>>TFCS 3 | (TF2, TF1, TF0, TF0) |
| >>>>>>>ctfc | 5 |
| >>>>>>>gainFactorInformation | Computed |
| >>>>>>>>referenceTFCId | 0 |
| >>>>>>TFCS 4 | (TF0, TF0, TF0, TF1) |
| >>>>>>>ctfc | 6 |
| >>>>>>>gainFactorInformation | Computed |
| >>>>>>>>βc (FDD only) | N/A |

| Configuration | 7.95 kbps speech + 3.4 kbps signalling |
|---|---|
| >>>>>>>>βd | N/A |
| >>>>>>>>referenceTFCId | 0 |
| >>>>>>TFCS 5 | (TF1, TF0, TF0, TF1) |
| >>>>>>>ctfc | 7 |
| >>>>>>>gainFactorInformation | Computed |
| >>>>>>>>referenceTFCId | 0 |
| >>>>>>TFCS 6 | (TF2, TF1, TF0, TF1) |
| >>>>>>>ctfc | 11 |
| >>>>>>>gainFactorInformation | Signalled |
| >>>>>>>>βc (FDD only) | 11 |
| >>>>>>>>βd | 15 |
| >>>>>>>>referenceTFCId | 0 |
| dl-CommonTransChInfo | |
| >tfcs-SignallingMode | Same as UL |
| PhyCH INFORMATION FDD | |
| UL-DPCH-InfoPredef | |
| >ul-DPCH-PowerControlInfo | |
| >>powerControlAlgorithm | Algorithm 1 |
| >>>tpcStepSize | 1 dB |
| >tfci-Existence | TRUE |
| >puncturingLimit | 1 |
| DL-CommonInformationPredef | |
| >dl-DPCH-InfoCommon | |
| >>spreadingFactor | 128 |
| >>tfci-Existence | FALSE |
| >>pilotBits | 4 |
| >>positionFixed | Fixed |
| | |
| PhyCH INFORMATION 3.84 Mcps TDD | |
| UL-DPCH-InfoPredef | |
| >ul-DPCH-PowerControlInfo | |
| >>dpch-ConstantValue | 0 |
| >commonTimeslotInfo | |
| >>secondInterleavingMode | frameRelated |
| >>tfci-Coding | 16 |
| >>puncturingLimit | 0.52 |
| >>repetitionPeriodAndLength | repetitionPeriod1 |
| DL-CommonInformationPredef | |
| >dl-DPCH-InfoCommon | |
| >>commonTimeslotInfo | |
| >>>secondInterleavingMode | frameRelated |
| >>>tfci-Coding | 16 |
| >>>puncturingLimit | 0.52 |
| >>>repetitionPeriodAndLength | repetitionPeriod1 |
| PhyCH INFORMATION 1.28 Mcps TDD | |
| UL-DPCH-InfoPredef | |

| Configuration | 7.95 kbps speech + 3.4 kbps signalling |
|---|---|
| >commonTimeslotInfo | |
| >>secondInterleavingMode | frameRelated |
| >>tfci-Coding | 16 |
| >>puncturingLimit | 0.80 |
| >>repetitionPeriodAndLength | repetitionPeriod1 |
| DL-CommonInformationPredef | |
| >dl-DPCH-InfoCommon | |
| >>commonTimeslotInfo | |
| >>>secondInterleavingMode | frameRelated |
| >>>tfci-Coding | 16 |
| >>>puncturingLimit | 0.80 |
| >>>repetitionPeriodAndLength | repetitionPeriod1 |

| Configuration | 12.65/8.85/6.6 kbps speech + 3.4 kbps signalling (without SRB#5) |
|---|---|
| Ref 25.993 | 106 |
| Default configuration identity | 16 |
| RB INFORMATION | |
| rb-Identity | RB1: 1, RB2: 2, RB3: 3, RB5: 5, RB6: 6, RB7: 7, |
| rlc-InfoChoice | Rlc-info |
| >ul-RLC-Mode | RB1: UM<br>RB2- RB3: AM<br>RB5-RB7: TM |
| >>transmissionRLC-DiscardMode | RB1: N/A<br>RB2- RB3: NoDiscard<br>RB5- RB7: N/A |
| >>>maxDat | RB1: N/A<br>RB2- RB3: 15<br>RB5- RB7: N/A |
| >>transmissionWindowSize | RB1: N/A<br>RB2- RB3: 128 for UEs with more than 10 kbyte "total RLC AM buffer size" and 32 otherwise<br>RB5- RB7: N/A |
| >>timerRST | RB1: N/A<br>RB2- RB3: 300<br>RB5- RB7: N/A |
| >>max-RST | RB1: N/A<br>RB2- RB3: 1<br>RB5- RB7: N/A |
| >>pollingInfo | RB1: N/A<br>RB2- RB3: as below<br>RB5- RB7: N/A |
| >>>lastTransmissionPDU-Poll | RB2- RB3: FALSE |
| >>>lastRetransmissionPDU-Poll | RB2- RB3: FALSE |
| >>>timerPollPeriodic | RB2- RB3: 300 |
| >>segmentationIndication | RB1- RB3: N/A<br>RB5- RB7: FALSE |
| >dl-RLC-Mode | RB1: UM<br>RB2- RB3: AM<br>RB5- RB7: TM |
| >>inSequenceDelivery | RB1: N/A<br>RB2- RB3: TRUE<br>RB5- RB7: N/A |
| >>receivingWindowSize | RB1: N/A<br>RB2- RB3: 128 for UEs with more than 10 kbyte "total RLC AM buffer size" and 32 otherwise<br>RB5- RB7: N/A |
| >>dl-RLC-StatusInfo | RB1: N/A<br>RB2- RB3: as below<br>RB5- RB7: N/A |
| >>>timerStatusProhibit | RB2- RB3: 100 |
| >>>missingPDU-Indicator | RB2- RB3: FALSE |
| >>>timerStatusPeriodic | RB2- RB3: 300 |
| >>segmentationIndication | RB1- RB3: N/A<br>RB5- RB7: FALSE |
| rb-MappingInfo | |

| | |
|---|---|
| >UL-LogicalChannelMappings | OneLogicalChannel |
| >>ul-TransportChannelType | Dch |
| >>>transportChannelIdentity | RB1- RB3: 4<br>RB5: 1, RB6: 2,<br>RB7: 3. |
| >>logicalChannelIdentity | RB1: 1, RB2: 2,<br>RB3: 3<br>RB5- RB7: N/A |
| >>rlc-SizeList | RB1- RB3:<br>configured<br>RB5- RB7: N/A |
| >>mac-LogicalChannelPriority | RB1: 1, RB2: 2,<br>RB3: 3<br>RB5- RB7: 5 |
| >DL-logicalChannelMappingList | |
| >>Mapping option 1 | One mapping option |
| >>>dl-TransportChannelType | Dch |
| >>>>transportChannelIdentity | RB1- RB3: 4<br>RB5: 1, RB6: 2,<br>RB7: 3, |
| >>>logicalChannelIdentity | RB1: 1, RB2: 2,<br>RB3: 3<br>RB5- RB7: N/A |
| TrCH INFORMATION PER TrCH | |
| UL-AddReconfTransChInfoList | |
| >Uplink transport channel type | Dch |
| >transportChannelIdentity | TrCH1: 1, TrCH2: 2,<br>TrCH3: 3, TrCH4: 4 |
| >transportFormatSet | DedicatedTransChTFS |
| >>dynamicTF-information | |
| >>>tf0/ tf0,1 | TrCH1: (0x72)<br>TrCH2: (0x 181)<br>TrCH3: (0x60)<br>TrCH4: (0x144,<br>1x144) |
| >>>>rlcSize | BitMode |
| >>>>>sizeType | TrCH1: type 1: 72<br>TrCH2: type 2:<br>part1= 6, part2= 5<br>TrCH3: type1: 60<br>TrCH4: 2: type 2,<br>part1= 2, part2= 0<br>(144) |
| >>>>numberOfTbSizeList | TrCH1-3: Zero<br>TrCH4: Zero, one |
| >>>>logicalChannelList | All |
| >>>tf 1 | TrCH1: (1x40)<br>TrCH2: (1x 78)<br>TrCH3: N/A<br>TrCH4: N/A |
| >>>>numberOfTransportBlocks | TrCH1: One<br>TrCH2: One |
| >>>>rlc-Size | TrCH1-2: BitMode |
| >>>>>sizeType | TrCH1: 1: 40<br>TrCH2: 1: 78 |
| >>>>numberOfTbSizeList | TrCH1-2: One |
| >>>>logicalChannelList | TrCH1: all |

| | |
|---|---|
| >>>tf 2 | TrCH1: (1x54)<br>TrCH2: (1x113)<br>TrCH3: N/A<br>TrCH4: N/A |
| >>>>numberOfTransportBlocks | TrCH1: One<br>TrCh2: One |
| >>>>rlc-Size | TrCH1: BitMode |
| >>>>>sizeType | TrCH1: type 1: 54<br>TrCH2: type 1: 113 |
| >>>>numberOfTbSizeList | TrCH1: One<br>TrCH2: One |
| >>>>logicalChannelList | TrCH1: all<br>TrCH2: all |
| >>>tf 3 | TrCH1: (1x64)<br>TrCH2: (1x181)<br>TrCH3: N/A<br>TrCH4: N/A |
| >>>>numberOfTransportBlocks | TrCH1: One<br>TrCh2: One |
| >>>>rlc-Size | TrCH1: BitMode |
| >>>>>sizeType | TrCH1: type 1: 64<br>TrCH2: type 2: part1=6, part2= 5 |
| >>>>numberOfTbSizeList | TrCH1: One<br>TrCH2: One |
| >>>>logicalChannelList | TrCH1: all<br>TrCH2: all |
| >>>tf 4 | TrCH1: (1x72)<br>TrCH2: N/A<br>TrCH3: N/A<br>TrCH4: N/A |
| >>>>numberOfTransportBlocks | TrCH1: One |
| >>>>rlc-Size | TrCH1: BitMode |
| >>>>>sizeType | TrCH1: type 1: 72 |
| >>>>numberOfTbSizeList | TrCH1: One |
| >>>>logicalChannelList | TrCH1: all |
| >>semistaticTF-Information | |
| >>>tti | TrCH1- TrCH2: 20<br>TrCH4: 40 |
| >>>channelCodingType | Convolutional |
| >>>>codingRate | TrCH1- TrCH3: Third<br>TrCH4: Third |
| >>>rateMatchingAttribute | TrCH1: 200<br>TrCH2: 190<br>TrCH3: 256<br>TrCH4: 170 |
| >>>crc-Size | TrCH1: 12<br>TrCH2: 0<br>TrCH3: 0<br>TrCH4: 16 |
| DL-AddReconfTransChInfoList | |
| >Downlink transport channel type | Dch |
| >dl-TransportChannelIdentity | |
| >tfs-SignallingMode | Independent |
| >>transportFormatSet | |
| >>>dynamicTF-information | |
| >>>>tf0/ tf0,1 | TrCH1: (1x0) |
| >>>>rlcSize | BitMode |
| >>>>>sizeType | TrCH1: type 1: 0 |
| >>>>numberOfTbSizeList | TrCH1: One |
| >>>>logicalChannelList | All |

| | |
|---|---|
| >>>semistaticTF-Information | same as UL |
| >>ULTrCH-Id | TrCH1: 1, TrCH2: 2, TrCH3: 3, TrCH4: 4, |
| >dch-QualityTarget | |
| >>bler-QualityValue | TrCH1: $7x10^{-3}$<br>TrCH2: Absent<br>TrCH3: Absent<br>TrCH4: Absent |
| TrCH INFORMATION, COMMON | |
| ul-CommonTransChInfo | |
| >tfcs-ID (TDD only) | 1 |
| >sharedChannelIndicator (TDD only) | FALSE |
| > tfc-Subset | Absent, not required |
| >ul-TFCS | Normal TFCI signalling |
| >>explicitTFCS-ConfigurationMode | Complete |
| >>>ctfcSize | Ctfc6Bit |
| >>>>TFCS representation | Addition |
| >>>>>TFC list | |
| >>>>>>TFC 1 | (TF0, TF0, TF0, TF0) |
| >>>>>>>ctfc | 0 |
| >>>>>>>gainFactorInformation | Computed |
| >>>>>>>>referenceTFCId | 0 |
| >>>>>>TFC 2 | (TF1, TF0, TF0, TF0) |
| >>>>>>>ctfc | 1 |
| >>>>>>>gainFactorInformation | Computed |
| >>>>>>>>βc (FDD only) | N/A |
| >>>>>>>>βd | N/A |
| >>>>>>>>referenceTFCId | 0 |
| >>>>>>TFC 3 | (TF2, TF1, TF0, TF0) |
| >>>>>>>ctfc | 7 |
| >>>>>>>gainFactorInformation | Computed |
| >>>>>>>>referenceTFCId | 0 |
| >>>>>>TFC 4 | (TF3, TF2, TF0, TF0) |
| >>>>>>>ctfc | 13 |
| >>>>>>>gainFactorInformation | Computed |
| >>>>>>>>βc (FDD only) | |
| >>>>>>>>βd | |
| >>>>>>>>referenceTFCId | 0 |
| >>>>>>TFC 5 | (TF4, TF3, TF0, TF0) |
| >>>>>>>ctfc | 19 |
| >>>>>>>gainFactorInformation | Computed |
| >>>>>>>>referenceTFCId | 0 |
| >>>>>>TFC 6 | (TF0, TF0, TF0, TF1) |
| >>>>>>>ctfc | 20 |
| >>>>>>>gainFactorInformation | Computed |
| >>>>>>>>βc (FDD only) | |
| >>>>>>>>βd | |

| | |
|---|---|
| >>>>>>>>referenceTFCId | 0 |
| >>>>>>TFC 7 | (TF1, TF0, TF0, TF1) |
| >>>>>>>ctfc | 21 |
| >>>>>>>gainFactorInformation | Computed |
| >>>>>>>>referenceTFCId | 0 |
| >>>>>>TFC 8 | (TF2, TF1, TF0, TF1) |
| >>>>>>>ctfc | 27 |
| >>>>>>>gainFactorInformation | computed |
| >>>>>>>>βc (FDD only) | |
| >>>>>>>>βd | |
| >>>>>>>>referenceTFCId | 0 |
| >>>>>>TFC 9 | (TF3, TF2, TF0, TF1) |
| >>>>>>>ctfc | 33 |
| >>>>>>>gainFactorInformation | computed |
| >>>>>>>>referenceTFCId | 0 |
| >>>>>>TFC 10 | (TF4, TF3, TF0, TF1) |
| >>>>>>>ctfc | 39 |
| >>>>>>>gainFactorInformation | signalled |
| >>>>>>>>βc (FDD only) | 11 |
| >>>>>>>>βd | 15 |
| >>>>>>>>referenceTFCId | 0 |
| > TFC subset list | |
| >>TFC subset 1 | (speech rate 6.6) |
| >>> Allowed transport format combination list | (TFC1, TFC2, TFC3, TFC6, TFC7, TFC8) |
| >>TFC subset 2 | (speech rate 8.85) |
| >>> Allowed transport format combination list | (TFC1, TFC2, TFC3, TFC4, TFC6, TFC7, TFC8, TFC9) |
| >>TFC subset 3 | (speech rate 12.65) |
| >>> Allowed transport format combination list | (TFC1, TFC2, TFC3, TFC4, TFC5, TFC6, TFC7, TFC8, TFC9, TFC10) |
| dl-CommonTransChInfo | |
| >tfcs-SignallingMode | Independent |
| ul-CommonTransChInfo | |
| >tfcs-ID (TDD only) | 1 |
| >sharedChannelIndicator (TDD only) | FALSE |
| > tfc-Subset | Absent, not required |
| >dl-TFCS | Normal TFCI signalling |
| >>explicitTFCS-ConfigurationMode | Complete |
| >>>ctfcSize | Ctfc8Bit |
| >>>>TFCS representation | Addition |
| >>>>>TFCS list | |
| >>>>>>TFC 1 | (TF0, TF0, TF0, TF0) |
| >>>>>>>ctfc | 0 |
| >>>>>>TFC 2 | (TF1, TF0, TF0, TF0) |
| >>>>>>>ctfc | 1 |
| >>>>>>TFC 3 | (TF2, TF1, TF0, TF0) |

| | |
|---|---|
| >>>>>>>ctfc | 7 |
| >>>>>>TFC 4 | (TF3, TF2, TF0, TF0) |
| >>>>>>>ctfc | 13 |
| >>>>>>TFC 5 | (TF4, TF3, TF0, TF0) |
| >>>>>>>ctfc | 19 |
| >>>>>>TFC 6 | (TF0, TF0, TF0, TF1) |
| >>>>>>>ctfc | 20 |
| >>>>>>TFC 7 | (TF1, TF0, TF0, TF1) |
| >>>>>>>ctfc | 21 |
| >>>>>>TFC 8 | (TF2, TF1, TF0, TF1) |
| >>>>>>>ctfc | 27 |
| >>>>>>TFC 9 | (TF3, TF2, TF0, TF1) |
| >>>>>>>ctfc | 33 |
| >>>>>>TFC 10 | (TF4, TF3, TF0, TF1) |
| >>>>>>>ctfc | 39 |
| >>>>>>TFC 11 | (TF0, TF0, TF0, TF0) |
| >>>>>>>ctfc | 40 |
| >>>>>>TFC 12 | (TF1, TF0, TF0, TF0) |
| >>>>>>>ctfc | 41 |
| >>>>>>TFC 13 | (TF2, TF1, TF0, TF0) |
| >>>>>>>ctfc | 47 |
| >>>>>>TFC 14 | (TF3, TF2, TF0, TF0) |
| >>>>>>>ctfc | 53 |
| >>>>>>TFC 15 | (TF4, TF3, TF0, TF0) |
| >>>>>>>ctfc | 59 |
| >>>>>>TFC 16 | (TF0, TF0, TF0, TF1) |
| >>>>>>>ctfc | 60 |
| >>>>>>TFC 17 | (TF1, TF0, TF0, TF1) |
| >>>>>>>ctfc | 61 |
| >>>>>>TFC 18 | (TF2, TF1, TF0, TF1) |
| >>>>>>>ctfc | 67 |
| >>>>>>TFC 19 | (TF3, TF2, TF0, TF1) |
| >>>>>>>ctfc | 73 |
| >>>>>>TFC 20 | (TF4, TF3, TF0, TF1) |
| >>>>>>>ctfc | 79 |
| PhyCH INFORMATION FDD | |
| UL-DPCH-InfoPredef | |
| >ul-DPCH-PowerControlInfo | |
| >>powerControlAlgorithm | Algorithm 1 |
| >>>tpcStepSize | 1 dB |
| >tfci-Existence | TRUE |
| >puncturingLimit | 0.84 |
| DL-CommonInformationPredef | |
| >dl-DPCH-InfoCommon | |
| >>spreadingFactor | 128 |

| | |
|---|---|
| >>tfci-Existence | FALSE |
| >>pilotBits | 4 |
| >>positionFixed | Fixed |

| Configuration | Signalling on E-DCH on UL depending based on minimum E-DCH UE category + Signalling on HS-DSCH based minimum HS-DSCH UE category |
|---|---|
| Ref 34.108 | FFS |
| Default configuration identity | 17 |
| RB INFORMATION | |
| rb-Identity | RB1: 1, RB2: 2, RB3: 3 |
| rlc-InfoChoice | Rlc-info |
| >ul-RLC-Mode | RB1: UM<br>RB2- RB3: AM |
| >>transmissionRLC-DiscardMode | RB1: N/A<br>RB2- RB3: NoDiscard |
| >>>maxDat | RB1: N/A<br>RB2- RB3: 15 |
| >>transmissionWindowSize | RB1: N/A<br>RB2- RB3: 128 |
| >>timerRST | RB1: N/A<br>RB2- RB3: 300 |
| >>max-RST | RB1: N/A<br>RB2- RB3: 1 |
| >>pollingInfo | RB1: N/A<br>RB2- RB3: as below |
| >>>lastTransmissionPDU-Poll | RB2- RB3: FALSE |
| >>>lastRetransmissionPDU-Poll | RB2- RB3: FALSE |
| >>>timerPollPeriodic | RB2- RB3: 300 |
| >>segmentationIndication | RB1- RB3: N/A |
| >dl-RLC-Mode | RB1: UM<br>RB2- RB3: AM |
| >>DL RLC PDU size | RB1-RB3: 144 |
| >>inSequenceDelivery | RB1: N/A<br>RB2- RB3: TRUE |
| >>receivingWindowSize | RB1: N/A<br>RB2- RB3: 128 |
| >>dl-RLC-StatusInfo | RB1: N/A<br>RB2- RB3: as below |
| >>>timerStatusProhibit | RB2- RB3: 100 |
| >>>missingPDU-Indicator | RB2- RB3: FALSE |
| >>>timerStatusPeriodic | RB2- RB3: 300 |
| >>segmentationIndication | RB1- RB3: N/A |
| >>dl-UM-RLC-LI-size | 7 |
| Rb-MappingInfo | |
| >UL-LogicalChannelMappings | OneLogicalChannel |
| >>UplinkTransport ChannelTypeChoice | |
| >>ul-TransportChannelType | E-DCH |
| >>>logicalChannelIdentity | RB1: 1, RB2: 2, RB3: 3 |
| >>>E-DCH MAC-d flow identity | RB1-RB3:0 |
| >>>DDI | RB1: 1, RB2: 2, RB3: 3 |
| >>>>RLC PDU size | 144 |
| >>mac-LogicalChannelPriority | RB1: 1, RB2: 2, RB3: 3 |

| Configuration | Signalling on E-DCH on UL depending based on minimum E-DCH UE category + Signalling on HS-DSCH based minimum HS-DSCH UE category |
|---|---|
| >DL-logicalChannelMappings | OneLogicalChannel |
| >>Mapping option 1 | One mapping option |
| >>>dl-TransportChannelType | HS-DSCH |
| >>>>Mac-d flow identity | RB1- RB3: 0 |
| >>>logicalChannelIdentity | RB1: 1, RB2: 2, RB3: 3 |
| TrCH INFORMATION PER TrCH | |
| UL-AddReconfTransChInfoList | |
| >Uplink transport channel type | E-DCH |
| >UL Transport channel identity | |
| > UL-ParametersChoice | |
| >> E-DCH Transmission Time Interval | 10 |
| >> HARQ info for E-DCH | |
| >>> HARQ RV Configuration | Rvtable |
| >> Added or reconfigured E-DCH MAC-d flow | One MAC-d flow |
| >>> E-DCH MAC-d flow identity | 0 |
| >>> E-DCH MAC-d flow power offset | 4 |
| >>> E-DCH MAC-d flow maximum number of retransmissions | 5 |
| >>> E-DCH MAC-d flow multiplexing list | 0 |
| >>> transmission grant typeChoice | |
| >>>> Non-scheduled transmission grant info | Non-scheduled |
| >>>>> Max MAC-e PDU contents size | 144 |
| DL-AddReconfTransChInfoList | |
| >Downlink transport channel type | HS-DSCH |
| >DL-ParametersChoice | |
| >>HARQ Info | |
| >>>Number of Processes | 6 |
| >>>Memory PartitioningChoice | |
| >>>>Implicit | |
| >>Added or reconfigured MAC-d flow | |
| >>> MAC-hs queue to add or reconfigure list | |
| >>>>MAC-hs queue Id | 0 |
| >>>>MAC-d Flow Identity | 0 |
| >>>>T1 | 100 |
| >>>>MAC-hs window size | 12 |
| >>>>MAC-d PDU size info | |
| >>>>>MAC-d PDU size | 148 |
| >>>>>MAC-d PDU size index | 0 |

| Configuration | Signalling on E-DCH on UL depending based on minimum E-DCH UE category + Signalling on HS-DSCH based minimum HS-DSCH UE category |
|---|---|
| TrCH INFORMATION, COMMON | *Null* |

# 14 Specific functions

## 14.1 Intra-frequency measurements

### 14.1.1 Intra-frequency measurement quantities

A measurement quantity is used to evaluate whether an intra-frequency event has occurred or not. It can be:

1 Downlink $E_c/N_0$.

2 Downlink path loss.

For FDD:

Pathloss in dB = Primary CPICH Tx power - CPICH RSCP.

For Primary CPICH Tx power the IE "Primary CPICH Tx power" shall be used. The unit is dBm.

CPICH RSCP is the result of the CPICH RSCP measurement. The unit is dBm.

For TDD:

Pathloss in dB = Primary CCPCH TX power - Primary CCPCH RSCP.

For Primary CCPCH TX power the IE "Primary CCPCH TX Power" shall be used. The unit is dBm.

Primary CCPCH RSCP is the result of the Primary CCPCH RSCP measurement. The unit is dBm.

If necessary Pathloss shall be rounded up to the next higher integer.
Results higher than 158 shall be reported as 158.
Results lower than 46 shall be reported as 46.

3 Downlink received signal code power (RSCP) after despreading.

4 ISCP measured on Timeslot basis.

A description of those values can be found in [7] and [8].

### 14.1.2 Intra-frequency reporting events for FDD

Within the measurement reporting criteria field in the Measurement Control message the UTRAN notifies the UE which events should trigger a measurement report. The listed events are the toolbox from which the UTRAN can choose the reporting events that are needed for the implemented handover evaluation function, or other radio network functions.

All the specified events are measured with respect to any of the measurement quantities given in subclause 14.1.1. The measurement quantities are measured on the monitored primary common pilot channels (CPICH) of the cell defined in the measurement object.

Special mechanisms for the events are illustrated in subclause 14.1.4 and 14.1.5.

NOTE: The events below are numbered 1A, 1B, 1C,… since all intra-frequency reporting events would be labelled 1X, inter-frequency reporting events would be labelled 2X, and so on for the other measurement types.

When one intra-frequency measurement identity corresponds to multiple intra-frequency events with identical event identities, the UE behaviour is not specified.

#### 14.1.2.1 Reporting event 1A: A Primary CPICH enters the reporting range

When an intra-frequency measurement configuring event 1a is set up, the UE shall:

1> create a variable TRIGGERED_1A_EVENT related to that measurement, which shall initially be empty;

1> delete this variable when the measurement is released.

When event 1A is configured in the UE, the UE shall:

1> if "Measurement quantity" is "pathloss" and Equation 1 below is fulfilled for one or more primary CPICHs, or if "Measurement quantity" is "CPICH Ec/N0" or "CPICH RSCP", and Equation 2 below is fulfilled for one or more primary CPICHs, for each of these primary CPICHs:

2> if all required reporting quantities are available for that cell; and

2> if the equations have been fulfilled for a time period indicated by "Time to trigger", and if that primary CPICH is part of cells allowed to trigger the event according to "Triggering condition 2", and if that primary CPICH is not included in the "cells triggered" in the variable TRIGGERED_1A_EVENT:

3> include that primary CPICH in the "cells recently triggered" in the variable TRIGGERED_1A_EVENT.

1> if the value of "Reporting deactivations threshold" for this event is greater than or equal to the current number of cells in the active set or equal to 0 and any primary CPICHs are stored in the "cells recently triggered" in the variable TRIGGERED_1A_EVENT:

2> if "Reporting interval" for this event is not equal to 0:

3> if the IE "Periodical reporting running" in the variable TRIGGERED_1A_EVENT is set to FALSE:

4> start a timer with the value of "Reporting interval" for this event and set the IE "Periodical reporting running" in the variable TRIGGERED_1A_EVENT to TRUE;

3> set "sent reports" for the primary CPICHs in "cells recently triggered" in the variable TRIGGERED_1A_EVENT to 1.

2> send a measurement report with IEs set as below:

3> set in "intra-frequency measurement event results": "Intrafrequency event identity" to "1a"; and

3> include in "cell measurement event results" all entries of the "cells recently triggered" in the variable TRIGGERED_1A_EVENT in descending order according to the configured measurement quantity taking into account the cell individual offset for each of those cells;

3> set the IE "measured results" and the IE "additional measured results" according to subclause 8.4.2, not taking into account the cell individual offset for each cell.

2> move all entries from "cells recently triggered" to "cells triggered" in the variable TRIGGERED_1A_EVENT.

1> if the timer for the periodical reporting has expired:

2> if any primary CPICH is included in the "cells triggered" in the variable TRIGGERED_1A_EVENT:

3> if "Reporting interval" for this event is not equal to 0, and if "Amount of reporting" is greater than "sent reports" stored for any of these primary CPICHs, in "cells triggered" in the variable TRIGGERED_1A_EVENT:

4> increment the stored counter "sent reports" for all CPICHs in "cell triggered" in variable TRIGGERED_1A_EVENT;

4> start a timer with the value of "Reporting interval" for this event;

4> send a measurement report with IEs set as below:

5> set in "intra-frequency measurement event results": "Intrafrequency event identity" to "1a"; and

5> include in "cell measurement event results" all entries of the variable TRIGGERED_1A_EVENT with value of IE "sent reports" equal to or smaller than value of "Amount of reporting" in descending order according to the configured measurement quantity taking into account the cell individual offset for each of those cells;

5> set the IE "measured results" and the IE "additional measured results" according to subclause 8.4.2, not taking into account the cell individual offset for each cell.

4> if "sent reports" in variable TRIGGERED_1A_EVENT is equal to "Amount of reporting" for all entries:

5> set the IE "Periodical Reporting running" in the variable TRIGGERED_1A_EVENT to FALSE and disable the timer for the periodical reporting.

1> if "Measurement quantity" is "pathloss" and Equation 3 below is fulfilled for a primary CPICH, or if "Measurement quantity" is "CPICH Ec/N0" or "CPICH RSCP", and Equation 4 below is fulfilled for a primary CPICH; or

1> if a primary CPICH is no longer part of the cells allowed to trigger the event according to the "Triggering condition 2":

2> if that primary CPICH is included in the "cells triggered" or "cells recently triggered" in the variable TRIGGERED_1A_EVENT:

3> remove the entry of that primary CPICH from "cells triggered" or "cells recently triggered" in the variable TRIGGERED_1A_EVENT.

3> if no entry in the variable TRIGGERED_1A_EVENT has a value of "sent reports" smaller than "Amount of reporting"; or

3> if there is no entry in the variable TRIGGERED_1A_EVENT:

4> if the reporting interval timer is running:

5> stop the reporting interval timer;

5> set the IE "Periodical reporting running" in the variable TRIGGERED_1A_EVENT to FALSE.

This event is only applicable to the CELL_DCH state. When the measurement is setup in CELL_DCH or upon transition to CELL_DCH the UE shall:

1> if the "Triggering condition 2" includes active set cells:

2> include the primary CPICH of all cells in the current active set into the "cells triggered" in the variable TRIGGERED_1A_EVENT with the counter "sent reports" set to "Amount of reporting".

Equation 1 (Triggering condition for pathloss)

$$10 \cdot LogM_{New} + CIO_{New} \le W \cdot 10 \cdot Log\left(1/\sum_{i=1}^{N_A}(1/M_i)\right) + (1-W) \cdot 10 \cdot LogM_{Best} + (R_{1a} - H_{1a}/2),$$

Equation 2 (Triggering condition for all the other measurement quantities)

$$10 \cdot LogM_{New} + CIO_{New} \ge W \cdot 10 \cdot Log\left(\sum_{i=1}^{N_A} M_i\right) + (1-W) \cdot 10 \cdot LogM_{Best} - (R_{1a} - H_{1a}/2),$$

Equation 3 (Leaving triggering condition for pathloss)

$$10 \cdot LogM_{New} + CIO_{New} > W \cdot 10 \cdot Log\left(1/\sum_{i=1}^{N_A}(1/M_i)\right) + (1-W) \cdot 10 \cdot LogM_{Best} + (R_{1a} + H_{1a}/2),$$

Equation 4 (Leaving triggering condition for all the other measurement quantities)

$$10 \cdot LogM_{New} + CIO_{New} < W \cdot 10 \cdot Log\left(\sum_{i=1}^{N_A} M_i\right) + (1-W) \cdot 10 \cdot LogM_{Best} - (R_{1a} + H_{1a}/2),$$

The variables in the formula are defined as follows:

***M*$_{New}$** is the measurement result of the cell entering the reporting range.

***CIO*$_{New}$** is the individual cell offset for the cell entering the reporting range if an individual cell offset is stored for that cell. Otherwise it is equal to 0.

***M*$_i$** is a measurement result of a cell not forbidden to affect reporting range in the active set.

***N*$_A$** is the number of cells not forbidden to affect reporting range in the current active set.

For pathloss

***M*$_{Best}$** is the measurement result of the cell not forbidden to affect reporting range in the active set with the lowest measurement result, not taking into account any cell individual offset.

for other measurements quantities.

***M*$_{Best}$** is the measurement result of the cell not forbidden to affect reporting range in the active set with the highest measurement result, not taking into account any cell individual offset.

***W*** is a parameter sent from UTRAN to UE.

***R*$_{1a}$** is the reporting range constant.

***H*$_{1a}$** is the hysteresis parameter for the event 1a.

If the measurement results are pathloss or CPICH-Ec/No then ***M*$_{New}$**, ***M*$_i$** and ***M*$_{Best}$** are expressed as ratios.

If the measurement result is CPICH-RSCP then ***M*$_{New}$**, ***M*$_i$** and ***M*$_{Best}$** are expressed in mW.

### 14.1.2.2 Reporting event 1B: A primary CPICH leaves the reporting range

When an intra-frequency measurement configuring event 1b is set up, the UE shall:

1> create a variable TRIGGERED_1B_EVENT related to that measurement, which shall initially be empty;

1> delete this variable when the measurement is released.

When event 1B is configures in the UE, the UE shall:

1> if "Measurement quantity" is "pathloss" and Equation 1 below is fulfilled for one or more primary CPICHs, or if "Measurement quantity" is "CPICH Ec/N0" or "CPICH RSCP", and Equation 2 below is fulfilled for one or more primary CPICHs, for each of these primary CPICHs:

2> if all required reporting quantities are available for that cell, and if the equations have been fulfilled for a time period indicated by "Time to trigger", and if that primary CPICH is part of cells allowed to trigger the event according to "Triggering condition 1", and if that primary CPICH is not included in the "cells triggered" in the variable TRIGGERED_1B_EVENT:

3> include that primary CPICH in the "cells recently triggered" in the variable TRIGGERED_1B_EVENT.

1> if any primary CPICHs are stored in the "cells recently triggered" in the variable TRIGGERED_1B_EVENT:

2> if "Periodic reporting info-1b" is present, and "Reporting interval" for this event is not equal to 0:

3> if the IE "Periodical reporting running" in the variable TRIGGERED_1B_EVENT is set to FALSE:

4> start a timer with the value of "Reporting interval" for this event and set the IE "Periodical reporting running" in the variable TRIGGERED_1B_EVENT to TRUE;

3> set "sent reports" for the primary CPICHs in "cells recently triggered" in the variable TRIGGERED_1B_EVENT to 1.

2> send a measurement report with IEs set as below:

3> set in "intra-frequency measurement event results": "Intrafrequency event identity" to "1b"; and

3> include in "cell measurement event results" all entries of "cells recently triggered" in the variable TRIGGERED_1B_EVENT in ascending order according to the configured measurement quantity taking into account the cell individual offset for each of those cells;

3> set the IE "measured results" and the IE "additional measured results" according to subclause 8.4.2, not taking into account the cell individual offset for each cell.

2> move all entries from IE "cells recently triggered" to "cells triggered" in the variable TRIGGERED_1B_EVENT.

1> if the timer for the periodical reporting has expired:

2> if any primary CPICH is included in the "cells triggered" in the variable TRIGGERED_1B_EVENT:

3> if "Periodic reporting info-1b" is present:

4> if "Reporting interval" is not equal to 0, and if "Amount of reporting" is greater than "sent reports" stored for any of these primary CPICHs, in "cells triggered" in the variable TRIGGERED_1B_EVENT:

5> increment the stored counter "sent reports" for all CPICHs in "cell triggered" in variable TRIGGERED_1B_EVENT;

5> start a timer with the value of "Reporting interval-1b" for this event;

5> send a measurement report with IEs set as below:

6> set in "intra-frequency measurement event results": "Intrafrequency event identity" to "1b"; and

6> include in "cell measurement event results" all entries of the variable TRIGGERED_1B_EVENT with value of IE "sent reports" equal to or smaller than value of "Amount of reporting" in ascending order according to the configured measurement quantity taking into account the cell individual offset for each of those cells;

6> set the IE "measured results" and the IE "additional measured results" according to subclause 8.4.2, not taking into account the cell individual offset for each cell.

5> if "sent reports" in variable TRIGGERED_1B_EVENT is equal to "Amount of reporting" for all entries:

6> set the IE "Periodical Reporting running" in the variable TRIGGERED_1B_EVENT to FALSE and disable the timer for the periodical reporting.

1> if "Measurement quantity" is "pathloss" and Equation 3 below is fulfilled for a primary CPICH, or if "Measurement quantity" is "CPICH Ec/N0" or "CPICH RSCP", and Equation 4 below is fulfilled for a primary CPICH; or

1> if a primary CPICH is no longer part of the cells allowed to trigger the event according to the "Triggering condition 1":

2> if that primary CPICH is included in the "cells triggered" in the variable TRIGGERED_1B_EVENT:

3> remove the entry of that primary CPICH from "cells triggered" in the variable TRIGGERED_1B_EVENT;

3> if there is no entry in the variable TRIGGERED_1B_EVENT:

4> if the reporting interval timer is running:

5> stop the reporting interval timer;

5> set the IE "Periodical reporting running" in the variable TRIGGERED_1B_EVENT to FALSE.

Equation 1 (Triggering condition for pathloss)

$$10 \cdot LogM_{Old} + CIO_{Old} \geq W \cdot 10 \cdot Log\left(1/\sum_{i=1}^{N_A}(1/M_i)\right) + (1-W) \cdot 10 \cdot LogM_{Best} + (R_{1b} + H_{1b}/2),$$ Equation 2 (Triggering condition for all the other measurement quantities)

$$10 \cdot LogM_{Old} + CIO_{Old} \leq W \cdot 10 \cdot Log\left(\sum_{i=1}^{N_A} M_i\right) + (1-W) \cdot 10 \cdot LogM_{Best} - (R_{1b} + H_{1b}/2),$$ Equation 3 (Leaving triggering condition for pathloss)

$$10 \cdot LogM_{Old} + CIO_{Old} < W \cdot 10 \cdot Log\left(1/\sum_{i=1}^{N_A}(1/M_i)\right) + (1-W) \cdot 10 \cdot LogM_{Best} + (R_{1b} - H_{1b}/2),$$ Equation 4 (Leaving triggering condition for all the other measurement quantities)

$$10 \cdot LogM_{Old} + CIO_{Old} > W \cdot 10 \cdot Log\left(\sum_{i=1}^{N_A} M_i\right) + (1-W) \cdot 10 \cdot LogM_{Best} - (R_{1b} - H_{1b}/2),$$ The variables in the formula are defined as follows:

***$M_{Old}$*** is the measurement result of the cell leaving the reporting range.

***$CIO_{Old}$*** is the individual cell offset for the cell leaving the reporting range if an individual cell offset is stored for that cell. Otherwise it is equal to 0.

***$M_i$*** is a measurement result of a cell not forbidden to affect reporting range in the active set.

***$N_A$*** is the number of cells not forbidden to affect reporting range in the current active set.

For pathloss

***$M_{Best}$*** is the measurement result of the cell not forbidden to affect reporting range in the active set with the lowest measurement result, not taking into account any cell individual offset.

for other measurements quantities.

***$M_{Best}$*** is the measurement result of the cell not forbidden to affect reporting range in the active set with the highest measurement result, not taking into account any cell individual offset.

***$W$*** is a parameter sent from UTRAN to UE.

***$R_{1b}$*** is the reporting range constant.

***$H_{1b}$*** is the hysteresis parameter for the event 1b.

If the measurement results are pathloss or CPICH-Ec/No then ***$M_{Old}$***, ***$M_i$*** and ***$M_{Best}$*** are expressed as ratios.

If the measurement result is CPICH-RSCP then ***$M_{Old}$***, ***$M_i$*** and ***$M_{Best}$*** are expressed in mW.

#### 14.1.2.3 Reporting event 1C: A non-active primary CPICH becomes better than an active primary CPICH

When an intra-frequency measurement configuring event 1c is set up, the UE shall:

1> create a variable TRIGGERED_1C_EVENT related to that measurement, which shall initially be empty;

1> delete this variable when the measurement is released.

When event 1C is configured in the UE, the UE shall:

1> if "Measurement quantity" is "pathloss" and Equation 1 below is fulfilled for one or more primary CPICHs, or if "Measurement quantity" is "CPICH Ec/N0" or "CPICH RSCP", and Equation 2 below is fulfilled for one or more primary CPICHs, for each of these primary CPICHs:

2> if all required reporting quantities are available for that cell; and

2> if the equations have been fulfilled for a time period indicated by "Time to trigger", and if the primary CPICH that is better is not included in the active set but the other primary CPICH is any of the primary CPICHs included in the active set, and if that first primary CPICH is not included in the "cells triggered" in the variable TRIGGERED_1C_EVENT:

3> include that primary CPICH in the "cells recently triggered" in the variable TRIGGERED_1C_EVENT.

1> if the value of "Replacement activation threshold" for this event is less than or equal to the current number of cells in the active set or equal to 0 and if any primary CPICHs are stored in the "cells recently triggered" in the variable TRIGGERED_1C_EVENT:

2> if "Reporting interval" for this event is not equal to 0:

3> if the IE "Periodical reporting running" in the variable TRIGGERED_1C_EVENT is set to FALSE:

4> start a timer for with the value of "Reporting interval" for this event and set the IE "Periodical reporting running" in the variable TRIGGERED_1C_EVENT to TRUE.

3> set "sent reports" for that primary CPICH in the variable TRIGGERED_1C_EVENT to 1.

2> send a measurement report with IEs set as below:

3> set in "intra-frequency measurement event results": "Intrafrequency event identity" to "1c"; and

3> include in "cell measurement event results" all entries of the "cells recently triggered" in the variable TRIGGERED_1C_EVENT not in the active set as well as the "primary CPICH info" of all the primary CPICHs in the active set for which the measured value is worse (i.e. greater for pathloss and less for the other measurement quantities) than the one of the entry in "cell recently triggered" that has the best measured value taking into account their cell individual offset. The "primary CPICH info" for those cells shall be ordered according to their measured value taking into account their cell individual offset, beginning with the best cell to the worst one;

3> set the IE "measured results" and the IE "additional measured results" according to subclause 8.4.2, not taking into account the cell individual offset for each cell.

2> move all entries from "cells recently triggered" to "cells triggered" in the variable TRIGGERED_1C_EVENT.

1> if the timer for the periodical reporting has expired:

2> if any primary CPICH is included in the "cells triggered" in the variable TRIGGERED_1C_EVENT, and not included in the current active set:

3> if "Reporting interval" for this event is not equal to 0, and if "Amount of reporting" is greater than "sent reports" stored for that primary CPICH, in "cells triggered" in the variable TRIGGERED_1C_EVENT:

4> increment the stored counter "sent reports" for all CPICH in "cell triggered" in variable TRIGGERED_1C_EVENT;

4> start a timer with the value of "Reporting interval" for this event;

4> send a measurement report with IEs set as below:

5> set in "intra-frequency measurement event results": "Intrafrequency event identity" to "1c"; and

5> include in "cell measurement event results" all entries of the variable TRIGGERED_1C_EVENT with value of IE "sent report" equal to or smaller than value of "Amount of reporting" and that are not part of the active set as well as the "primary CPICH info" of all the primary CPICHs in the active set for which the measured value is worse (i.e. greater for pathloss and less for the other measurement quantities) than the one of the entry in "cell triggered" that has the best measured value, ordering the "primary CPICH info" according to their measured value beginning with the best cell to the worst one, taking into account the cell individual offset for each cell;

5> set the IE "measured results" and the IE "additional measured results" according to subclause 8.4.2, not taking into account the cell individual offset for each cell.

4> if "sent reports" in variable TRIGGERED_1C_EVENT is equal to "Amount of reporting" for all entries:

5> set the IE "Periodical Reporting running" in the variable TRIGGERED_1C_EVENT to FALSE and disable the timer for the periodical reporting.

1> if "Measurement quantity" is "pathloss" and Equation 3 below is fulfilled for a primary CPICH, or if "Measurement quantity" is "CPICH Ec/N0" or "CPICH RSCP", and Equation 4 below is fulfilled for a primary CPICH or;

1> if a primary CPICH is added to the active set:

2> if that primary CPICH is included in the "cells triggered" or "cells recently triggered" in the variable TRIGGERED_1C_EVENT:

3> remove the entry of that primary CPICH from "cells triggered" or "cells recently triggered" in the variable TRIGGERED_1C_EVENT.

3> if no entry in the variable TRIGGERED_1C_EVENT has a value of "sent reports" smaller than "Amount of reporting" or

3> if there is no entry in the variable TRIGGERED_1C_EVENT:

4> if the reporting interval timer is running:

5> stop the reporting interval timer;

5> set the IE "Periodical reporting running" in the variable TRIGGERED_1C_EVENT to FALSE.

Equation 1 (Triggering condition for pathloss)

$$10 \cdot Log M_{New} + CIO_{New} \leq 10 \cdot Log M_{nAS} + CIO_{nAS} - H_{1c}/2,$$

Equation 2 (Triggering condition for all the other measurement quantities)

$$10 \cdot Log M_{New} + CIO_{New} \geq 10 \cdot Log M_{nAS} + CIO_{nAS} + H_{1c}/2,$$

Equation 3 (Leaving triggering condition for pathloss)

$$10 \cdot Log M_{New} + CIO_{New} > 10 \cdot Log M_{nAS} + CIO_{nAS} + H_{1c}/2,$$

Equation 4 (Leaving triggering condition for all the other measurement quantities)

$$10 \cdot Log M_{New} + CIO_{New} < 10 \cdot Log M_{nAS} + CIO_{nAS} - H_{1c}/2,$$

The variables in the formula are defined as follows:

$M_{New}$ is the measurement result of the cell not included in the active set.

$CIO_{New}$ is the individual cell offset for the cell becoming better than the cell in the active set if an individual cell offset is stored for that cell. Otherwise it is equal to 0.

For pathloss:

$M_{InAS}$ is the measurement result of the cell in the active set with the highest measurement result.

For other measurement quantities:

$M_{InAS}$ is the measurement result of the cell in the active set with the lowest measurement result.

$CIO_{InAS}$ is the individual cell offset for the cell in the active set that is becoming worse than the new cell.

$H_{1c}$ is the hysteresis parameter for the event 1c.

If the measurement results are pathloss or CPICH-Ec/No then $M_{New}$ and $M_{inAS}$ are expressed as ratios.

If the measurement result is CPICH-RSCP then $M_{New}$ and $M_{inAS}$ are expressed in mW.




**Figure 14.1.2.3-1 [Informative]: A primary CPICH that is not included in the active set becomes better than a primary CPICH that is in the active set**

In this figure, the parameters hysteresis and time to trigger, as well as the cell individual offsets for all cells are equal to 0. In this example the cells belonging to primary CPICH 1 and 2 are in the active set, but the cells transmitting primary CPICH 3 and CPICH 4 are not (yet) in the active set.

The first measurement report is sent when primary CPICH 4 becomes better than primary CPICH 2. The "cell measurement event result" of the measurement report contains the information of primary CPICH 4 and CPICH 2.

Assuming that the active set has been updated after the first measurement report (active set is now primary CPICH 1 and primary CPICH 4), the second report is sent when primary CPICH 3 becomes better than primary CPICH 1. The "cell measurement event result" of the second measurement report contains the information of primary CPICH 3 and primary CPICH 1.

### 14.1.2.4 Reporting event 1D: Change of best cell

When an intra-frequency measurement configuring event 1d is set up, the UE shall:

1> create a variable TRIGGERED_1D_EVENT related to that measurement, which shall initially contain the best cell in the active set when the measurement is initiated;

1> delete this variable when the measurement is released.

1> As soon as the best cell in the active set has been evaluated by the UE (and stored in the TRIGGERED_1D_EVENT variable) and provided that there is more than one cell in the active set, trigger an immediate measurement report with IEs set as below:

2> set in "intra-frequency measurement event results"; "Intrafrequency event identity" to "1d" and "cell measurement event results" to the CPICH info of the primary CPICH stored in the TRIGGERED_1D_EVENT variable;

2> set the IE "measured results" and the IE "additional measured results" according to subclause 8.4.2

When event 1D is configured in the UE, the UE shall:

1> if IE "useCIO" is present and its value is TRUE, take into account the Cell Individual Offset for evaluation of the Equation 1 and 2, otherwise do not take it into account.

1> if "Measurement quantity" is "pathloss" and Equation 1 below is fulfilled for a primary CPICH that is not stored in "Best cell" in variable BEST_CELL_1D_EVENT, or if "Measurement quantity" is "CPICH Ec/N0" or "CPICH RSCP", and Equation 2 below is fulfilled for a primary CPICH that is not stored in "Best cell" in variable BEST_CELL_1D_EVENT:

NOTE: If the equations are simultaneously fulfilled for more than one primary CPICH, the UE should report only one event 1D, triggered by the best primary CPICH.

2> if all required reporting quantities are available for that cell, and if the equations have been fulfilled for a time period indicated by "Time to trigger" and if IE "Triggering condition 2" is absent or if it is present and that primary CPICH is part of cells allowed to trigger the event according to "Triggering condition 2":

3> set "best cell" in the variable BEST_CELL_1D_EVENT to that primary CPICH that triggered the event;

3> send a measurement report with IEs set as below:

4> set in "intra-frequency measurement event results"; "Intrafrequency event identity" to "1d" and "cell measurement event results" to the CPICH info of the primary CPICH that triggered the report.

4> set the IE "measured results" and the IE "additional measured results" according to subclause 8.4.2.

This event is only applicable to the CELL_DCH state. Upon transition to CELL_DCH the UE shall:

1> set "best cell" in the variable BEST_CELL_1D_EVENT to the best cell of the primary CPICHs included in the active set.

Equation 1 (Triggering condition for pathloss)

$$10 Log M_{NotBest} + CIO_{NotBest} \leq 10 Log M_{Best} + CIO_{Best} - H_{1d}/2,$$

Equation 2 (Triggering condition for all the other measurement quantities)

$$10 Log M_{NotBest} + CIO_{NotBest} \geq 10 Log M_{Best} + CIO_{Best} + H_{1d}/2,$$

The variables in the formula are defined as follows:

$M_{NotBest}$ is the measurement result of a cell not stored in "best cell" in the variable BEST_CELL_1D_EVENT.

$CIO_{NotBest}$ is the cell individual offset of a cell not stored in "best cell" in the variable BEST_CELL_1D_EVENT.

$M_{Best}$ is the measurement result of the cell stored in "best cell" in variable BEST_CELL_1D_EVENT.

$CIO_{Best}$ is the cell individual offset of a cell stored in "best cell" in the variable BEST_CELL_1D_EVENT.

$H_{1d}$ is the hysteresis parameter for the event 1d.

If the measurement results are pathloss or CPICH-Ec/No then $M_{Not\ Best}$ and $M_{Best}$ are expressed as ratios.

If the measurement result is CPICH-RSCP then $M_{Not\ Best}$ and $M_{Best}$ are expressed in mW.




**Figure 14.1.2.4-1 [Informative]: A primary CPICH becomes better than the previously best primary CPICH**

In this figure, the parameters hysteresis and time to trigger, as well as the cell individual offsets for all cells are equal to 0.

### 14.1.2.5 Reporting event 1E: A Primary CPICH becomes better than an absolute threshold

When an intra-frequency measurement configuring event 1e is set up, the UE shall:

1> create a variable TRIGGERED_1E_EVENT related to that measurement, which shall initially be empty;

1> delete this variable when the measurement is released.

When event 1E is configured in the UE, the UE shall:

1> if "Measurement quantity" is "pathloss" and Equation 1 below is fulfilled for a primary CPICH, or if "Measurement quantity" is "CPICH Ec/N0" or "CPICH RSCP", and Equation 2 below is fulfilled for one or more primary CPICHs, for each of these primary CPICHs:

2> if all required reporting quantities are available for that cell, and if the equations have been fulfilled for a time period indicated by "Time to trigger", and if that primary CPICH is part of cells allowed to trigger the event according to "Triggering condition 2", and that primary CPICH is not included in the "cells triggered" in the variable TRIGGERED_1E_EVENT:

3> include that primary CPICH in the "cells recently triggered" in the variable TRIGGERED_1E_EVENT.

1> if any primary CPICHs are stored in the "cells recently triggered" in the variable TRIGGERED_1E_EVENT:

2> send a measurement report with IEs set as below:

3> set in "intra-frequency measurement event results": "Intrafrequency event identity" to "1e"; and

3> include in "cell measurement event results" all entries of the "cells recently triggered" in the variable TRIGGERED_1E_EVENT in descending order according to the configured measurement quantity taking into account the cell individual offset for each of those cells;

3> set the IE "measured results" and the IE "additional measured results" according to subclause 8.4.2, not taking into account the cell individual offset for each cell.

2> move all entries from "cells recently triggered" to "cells triggered" in the variable TRIGGERED_1E_EVENT.

1> if "Measurement quantity" is "pathloss" and Equation 3 below is fulfilled for a primary CPICH, or if "Measurement quantity" is "CPICH Ec/N0" or "CPICH RSCP", and Equation 4 below is fulfilled for a primary CPICH; or

1> if a primary CPICH is no longer part of the cells allowed to trigger the event according to the "Triggering condition 2":

2> if that primary CPICH is included in the "cells triggered" in the variable TRIGGERED_1E_EVENT:

3> remove that primary CPICH and sent reports from "cells triggered" in the variable TRIGGERED_1E_EVENT.

This event is only applicable to the CELL_DCH state. When the measurement is setup in CELL_DCH or upon transition to CELL_DCH the UE shall:

1> if the "Triggering condition 2" includes active set cells:

2> include the primary CPICH of all cells in the current active set that fulfil the equations 1 or 2 according to the "Measurement quantity" of event 1e into the "cells triggered" in the variable TRIGGERED_1E_EVENT.

Equation 1 (Triggering condition for pathloss)

$$10 Log M_{New} + CIO_{New} \leq T_{1e} - H_{1e} / 2,$$

Equation 2 (Triggering condition for all the other measurement quantities)

$$10 Log M_{New} + CIO_{New} \geq T_{1e} + H_{1e} / 2,$$

Equation 3 (Leaving triggering condition for pathloss)

$$10 Log M_{New} + CIO_{New} > T_{1e} + H_{1e} / 2,$$

Equation 4 (Leaving triggering condition for all the other measurement quantities)

$$10 Log M_{New} + CIO_{New} < T_{1e} - H_{1e} / 2,$$

The variables in the formula are defined as follows:

$M_{New}$ is the measurement result of a cell that becomes better than an absolute threshold.

$CIO_{New}$ is the individual cell offset for the cell becoming better than the absolute threshold. Otherwise it is equal to 0.

$T_{1e}$ is an absolute threshold.

$H_{1e}$ is the hysteresis parameter for the event 1e.

If the measurement results are pathloss or CPICH-Ec/No then $M_{New}$ is expressed as ratios.

If the measurement result is CPICH-RSCP then $M_{New}$ is expressed in mW.




**Figure 14.1.2.5-1 [Informative]: Event-triggered report when a Primary CPICH becomes better than an absolute threshold**

In this figure, the parameters hysteresis and time to trigger, as well as the cell individual offsets for all cells are equal to 0.

### 14.1.2.6 Reporting event 1F: A Primary CPICH becomes worse than an absolute threshold

When an intra-frequency measurement configuring event 1F is set up, the UE shall:

1> create a variable TRIGGERED_1F_EVENT related to that measurement, which shall initially be empty;

1> delete this variable when the measurement is released.

When event 1F is configured in the UE, the UE shall:

1> if "Measurement quantity" is "pathloss" and Equation 1 below is fulfilled for one or more primary CPICHs, or if "Measurement quantity" is "CPICH Ec/N0" or "CPICH RSCP", and Equation 2 below is fulfilled for one or more primary CPICHs, for each of these primary CPICHs:

2> if all required reporting quantities are available for that cell, and if the equations have been fulfilled for a time period indicated by "Time to trigger", and if that primary CPICH is part of cells allowed to trigger the event according to "Triggering condition 1", and that primary CPICH is not included in the "cells triggered" in the variable TRIGGERED_1F_EVENT:

3> include that primary CPICH in the "cells recently triggered" in the variable TRIGGERED_1F_EVENT.

1> if any primary CPICHs are stored in the "cells recently triggered" in the variable TRIGGERED_1F_EVENT:

2> send a measurement report with IEs set as below:

3> set in "intra-frequency event measurement results": "Intrafrequency event identity" to "1f"; and

3> include in "cell measurement event results" all entries of the "cells recently triggered" in the variable TRIGGERED_1F_EVENT in descending order according to the configured measurement quantity taking into account the cell individual offset for each of those cells;

3> set the IE "measured results" and the IE "additional measured results" according to subclause 8.4.2, not taking into account the cell individual offset for each cell;

2> move all entries from "cells recently triggered" to "cells triggered" in the variable TRIGGERED_1F_EVENT.

1> if "Measurement quantity" is "pathloss" and Equation 3 below is fulfilled for a primary CPICH, or if "Measurement quantity" is "CPICH Ec/N0" or "CPICH RSCP", and Equation 4 below is fulfilled for a primary CPICH; or

1> if a primary CPICH is no longer part of the cells allowed to trigger the event according to the "Triggering condition 1":

2> if that primary CPICH is included in the "cells triggered" in the variable TRIGGERED_1F_EVENT:

3> remove that primary CPICH from "cells triggered" in the variable TRIGGERED_1F_EVENT.

Equation 1 (Triggering condition for pathloss)

$$10 Log M_{Old} + CIO_{Old} \geq T_{1f} + H_{1f} / 2,$$

Equation 2 (Triggering condition for all the other measurement quantities)

$$10 Log M_{Old} + CIO_{Old} \leq T_{1f} - H_{1f} / 2,$$

Equation 3 (Leaving triggering condition for pathloss)

$$10 Log M_{Old} + CIO_{Old} < T_{1f} - H_{1f} / 2,$$

Equation 4 (Leaving triggering condition for all the other measurement quantities)

$$10 Log M_{Old} + CIO_{Old} > T_{1f} + H_{1f} / 2,$$

The variables in the formula are defined as follows:

$M_{Old}$ is the measurement result of a cell that becomes worse than an absolute threshold

$CIO_{Old}$ is the individual cell offset for the cell becoming worse than the absolute threshold. Otherwise it is equal to 0.

$T_{1f}$ is an absolute threshold

$H_{1f}$ is the hysteresis parameter for the event 1f.

If the measurement results are pathloss or CPICH-Ec/No then $M_{Old}$ is expressed as ratios.

If the measurement result is CPICH-RSCP then $M_{Old}$ is expressed in mW.




**Figure 14.1.2.6-1 [Informative]: Event-triggered report when a Primary CPICH becomes worse than an absolute threshold**

In this figure, the parameters hysteresis and time to trigger, as well as the cell individual offsets for all cells are equal to 0.

### 14.1.2.7 Reporting event 1J: A non-active E-DCH but active DCH primary CPICH becomes better than an active E-DCH primary CPICH

When an intra-frequency measurement configuring event 1j is set up, the UE shall:

1> create a variable TRIGGERED_1J_EVENT related to that measurement, which shall initially be empty;

1> delete this variable when the measurement is released.

When event 1J is configured in the UE, the UE shall:

1> if "Measurement quantity" is "pathloss" and Equation 1 below is fulfilled for one or more primary CPICHs, or if "Measurement quantity" is "CPICH Ec/N0" or "CPICH RSCP", and Equation 2 below is fulfilled for one or more primary CPICHs, for each of these primary CPICHs:

2> if all required reporting quantities are available for that cell; and

2> if the equations have been fulfilled for a time period indicated by "Time to trigger", and if the primary CPICH that is better is not included in the E-DCH active set but included in DCH active set and the other primary CPICH is any of the primary CPICHs included in the E-DCH active set, and if that first primary CPICH is not included in the "cells triggered" in the variable TRIGGERED_1J_EVENT:

3> include that primary CPICH in the "cells recently triggered" in the variable TRIGGERED_1J_EVENT.

1> if the value of "Replacement activation threshold" for this event is less than or equal to the current number of cells in the E-DCH active set or equal to 0 and if any primary CPICHs are stored in the "cells recently triggered" in the variable TRIGGERED_1J_EVENT:

2> if "Reporting interval" for this event is not equal to 0:

3> if the IE "Periodical reporting running" in the variable TRIGGERED_1J_EVENT is set to FALSE:

4> start a timer for with the value of "Reporting interval" for this event and set the IE "Periodical reporting running" in the variable TRIGGERED_1J_EVENT to TRUE.

3> set "sent reports" for that primary CPICH in the variable TRIGGERED_1J_EVENT to 1.

2> send a measurement report with IEs set as below:

3> set in "intra-frequency measurement event results": "Intrafrequency event identity" to "1J"; and

3> include in "cell measurement event results" all entries of the "cells recently triggered" in the variable TRIGGERED_1J_EVENT not in the E-DCH active set but included in DCH active set as well as the "primary CPICH info" of all the primary CPICHs in the E-DCH active set for which the measured value is worse (i.e. greater for pathloss and less for the other measurement quantities) than the one of the entry in "cell recently triggered" that has the best measured value taking into account their cell individual offset. The "primary CPICH info" for those cells shall be ordered according to their measured value taking into account their cell individual offset, beginning with the best cell to the worst one;

3> set the IE "measured results" and the IE "additional measured results" according to subclause 8.4.2, not taking into account the cell individual offset for each cell.

2> move all entries from "cells recently triggered" to "cells triggered" in the variable TRIGGERED_1J_EVENT.

1> if the timer for the periodical reporting has expired:

2> if any primary CPICH is included in the "cells triggered" in the variable TRIGGERED_1J_EVENT, and not included in the current E-DCH active set but included in DCH active set:

3> if "Reporting interval" for this event is not equal to 0, and if "Amount of reporting" is greater than "sent reports" stored for that primary CPICH, in "cells triggered" in the variable TRIGGERED_1J_EVENT:

4> increment the stored counter "sent reports" for all CPICH in "cell triggered" in variable TRIGGERED_1J_EVENT;

4> start a timer with the value of "Reporting interval" for this event;

4> send a measurement report with IEs set as below:

5> set in "intra-frequency measurement event results": "Intrafrequency event identity" to "1J"; and

5> include in "cell measurement event results" all entries of the variable TRIGGERED_1J_EVENT with value of IE "sent report" equal to or smaller than value of "Amount of reporting" and that are not part of the E-DCH active set but included in DCH active set as well as the "primary CPICH info" of all the primary CPICHs in the E-DCH active set for which the measured value is worse (i.e. greater for pathloss and less for the other measurement quantities) than the one of the entry in "cell triggered" that has the best measured value, ordering the "primary CPICH info" according to their measured value beginning with the best cell to the worst one, taking into account the cell individual offset for each cell;

5> set the IE "measured results" and the IE "additional measured results" according to subclause 8.4.2, not taking into account the cell individual offset for each cell.

4> if "sent reports" in variable TRIGGERED_1J_EVENT is equal to "Amount of reporting" for all entries:

5> set the IE "Periodical Reporting running" in the variable TRIGGERED_1J_EVENT to FALSE and disable the timer for the periodical reporting.

1> if "Measurement quantity" is "pathloss" and Equation 3 below is fulfilled for a primary CPICH, or if "Measurement quantity" is "CPICH Ec/N0" or "CPICH RSCP", and Equation 4 below is fulfilled for a primary CPICH or;

1> if a primary CPICH is added to the E-DCH active set:

2> if that primary CPICH is included in the "cells triggered" or "cells recently triggered" in the variable TRIGGERED_1J_EVENT:

3> remove the entry of that primary CPICH from "cells triggered" or "cells recently triggered" in the variable TRIGGERED_1J_EVENT.

3> if no entry in the variable TRIGGERED_1J_EVENT has a value of "sent reports" smaller than "Amount of reporting" or

3> if there is no entry in the variable TRIGGERED_1J_EVENT:

4> if the reporting interval timer is running:

5> stop the reporting interval timer;

5> set the IE "Periodical reporting running" in the variable TRIGGERED_1J_EVENT to FALSE.

Equation 1 (Triggering condition for pathloss)

$$10 Log M_{New} + CIO_{New} \leq 10 Log M_{inAS} + CIO_{inAS} - H_{1j}/2,$$

Equation 2 (Triggering condition for all the other measurement quantities)

$$10 Log M_{New} + CIO_{New} \geq 10 Log M_{inAS} + CIO_{inAS} + H_{1j}/2,$$

Equation 3 (Leaving triggering condition for pathloss)

$$10 Log M_{New} + CIO_{New} > 10 Log M_{inAS} + CIO_{inAS} + H_{1j}/2,$$

Equation 4 (Leaving triggering condition for all the other measurement quantities)

$$10 Log M_{New} + CIO_{New} < 10 Log M_{inAS} + CIO_{inAS} - H_{1j}/2,$$

The variables in the formula are defined as follows:

$M_{New}$ is the measurement result of the cell not included in the E-DCH active set but included in DCH active set.

$CIO_{New}$ is the individual cell offset for the cell not included in the E-DCH active set but included in DCH active set becoming better than the cell in the E-DCH active set if an individual cell offset is stored for that cell. Otherwise it is equal to 0.

For pathloss:

$M_{InAS}$ is the measurement result of the cell in the E-DCH active set with the highest measurement result.

For other measurement quantities:

$M_{InAS}$ is the measurement result of the cell in the E-DCH active set with the lowest measurement result.

$CIO_{InAS}$ is the individual cell offset for the cell in the E-DCH active set that is becoming worse than the new cell.

$H_{1J}$ is the hysteresis parameter for the event 1J.

If the measurement results are pathloss or CPICH-Ec/No then $M_{New}$ and $M_{inAS}$ are expressed as ratios.

If the measurement result is CPICH-RSCP then $M_{New}$ and $M_{inAS}$ are expressed in mW.




**Figure 14.1.2.7-1 [Informative]: A primary CPICH that is not included in the E-DCH active set but included in DCH active set becomes better than a primary CPICH that is in the E-DCH active set**

In this figure, the parameters hysteresis and time to trigger, as well as the cell individual offsets for all cells are equal to 0 and replacement activation threshold is equal to 0 or 1 or 2. In this example the cells belonging to primary CPICH 1 and 2 are in the E-DCH active set, but the cells transmitting primary CPICH 3 and CPICH 4 are not (yet) in the E-DCH active set but included in DCH active set.

The first measurement report is sent when primary CPICH 4 becomes better than primary CPICH 2. The "cell measurement event result" of the measurement report contains the information of primary CPICH 4 and CPICH 2.

Assuming that the E-DCH active set has been updated after the first measurement report (E-DCH active set is now primary CPICH 1 and primary CPICH 4), the second report is sent when primary CPICH 3 becomes better than primary CPICH 1. The "cell measurement event result" of the second measurement report contains the information of primary CPICH 3 and primary CPICH 1.

## 14.1.3 Intra-frequency reporting events for TDD

### 14.1.3.1 Reporting event 1G: Change of best cell (TDD)

When event 1G is configured in the UE, the UE shall:

1> if the equation 1 is fulfilled for a P-CCPCHs during the time "Time to trigger" and if that P-CCPCH is not included in the "primary CCPCH info" in the variable TRIGGERED_1G_EVENT:

2> include that P-CCPCH in "cells triggered" in the variable TRIGGERED_1G_EVENT;

2> send a measurement report with IEs set as below:

3> set in "intra-frequency measurement event results": "Intrafrequency event identity" to "1g";

3> set the first entry in "cell measurement event results" to the "Cell parameters ID" of the P-CCPCH which was stored in the variable TRIGGERED_1G_EVENT;

3> include all entries in "cells triggered" in variable TRIGGERED_1G_EVENT in "cell measurement event results" in the measurement report in descending order according to:

$$10 \cdot LogM + O$$

where ***M*** is the P-CCPCH RSCP and ***O*** the individual offset of a cell;

3> set the IE "measured results" and the IE "additional measured results" according to subclause 8.4.2, not taking into account the cell individual offset for each cell.

1> if Equation 2 below is fulfilled for a primary CCPCH:

2> if a primary CCPCH is included in the "cells triggered" in the variable TRIGGERED_1G_EVENT:

3> remove the entry of that primary CCPCH from "cells triggered" in the variable TRIGGERED_1G_EVENT;

The UE shall use the equations below for evaluation of reporting event 1g:

Equation 1

$$10 \cdot LogM_i + O_i - H_{1g} > 10 \cdot LogM_{previous_best} + O_{previous_best}$$

The variables in the formula are defined as follows:

$M_{previous_best}$ is the current P-CCPCH RSCP of the previous best cell expressed in mW

$O_{previous_best}$ is the cell individual offset of the previous best cell

$M_i$ is the current P-CCPCH RSCP of the currently evaluated cell ***i*** expressed in mW

$O_i$ is the cell individual offset of the currently evaluated cell ***i***

$H_{1g}$ is the hysteresis parameter for the event 1g.

Equation 2

$$10 \cdot LogM_i + O_i + H_{1g} < 10 \cdot LogM_{previous_best} + O_{previous_best}$$

The variables in the formula are defined as follows:

$M_{previous_best}$ is the current P-CCPCH RSCP of the previous best cell expressed in mW

$O_{previous_best}$ is the cell individual offset of the previous best cell

$M_i$ is the current P-CCPCH RSCP of the currently evaluated cell ***i*** expressed in mW

$O_i$ is the cell individual offset of the currently evaluated cell ***i***

$H_{1g}$ is the hysteresis parameter for the event 1g.




**Figure 14.1.3.1-1: A P-CCPCH RSCP becomes better than the previous best P-CCPCH RSCP**

### 14.1.3.2 Reporting event 1H: Timeslot ISCP below a certain threshold (TDD)

When event 1h is configured in the UE, the UE shall:

1> if equation 1 is fulfilled for a time period indicated by "Time to trigger" and if that P-CCPCH is not included in the IE "cells triggered" in the variable TRIGGERED_1H_EVENT:

2> include that P-CCPCH in the IE "cells triggered" in the variable TRIGGERED_1H_EVENT;

2> send a measurement report with the IEs set as below:

3> set in "intra-frequency measurement event results": "Intrafrequency event identity" to "1h" and in "cell measurement event results" the "Cell parameters ID" of the P-CCPCH that triggered the report;

3> include in "Cell measured results" the "Timeslot ISCP" of those cells that are included in the variable TRIGGERED_1H_EVENT.

1> if a primary CCPCH is included in the "cells triggered" in the variable TRIGGERED_1H_EVENT:

2> send a measurement report with IEs set as below:

3> set in "intra-frequency measurement event results": "Intrafrequency event identity" to "1h" and "cell measurement event results" to the "Cell parameters ID" of the P-CCPCH that triggered the report;

3> set in "measured results " the "Timeslot ISCP" of those cells that are included in the variable TRIGGERED_1H_EVENT and "additional measured results" according to subclause 8.4.2, not taking into account the cell individual offset for each cell.

1> if Equation 2 below is fulfilled for a primary CCPCH:

2> if a primary CCPCH is included in the "cells triggered" in the variable TRIGGERED_1H_EVENT:

3> remove the entry of that primary CCPCH from "cells triggered" in the variable TRIGGERED_1H_EVENT.

The UE shall use the equations below for evaluation of reporting event 1h:

Equation 1

$$10 \cdot LogM_i + H_{1h} + O_i < T_{1h},$$

Equation 2

$$10 \cdot LogM_i - H_{1h} + O_i > T_{1h},$$

The variables in the formula are defined as follows:

$M_i$ is the Timeslot ISCP of the currently evaluated cell ***i*** expressed in mW

$O_i$ is the cell individual offset of the currently evaluated cell ***i***

$T_{1h}$ is the Threshold for event 1h

$H_{1h}$ is the hysteresis parameter for the event 1h.

Before any evaluation is done, the Timeslot ISCP expressed in mW is filtered according to subclause 8.6.7.2.




**Figure 14.1.3.2-1: An ISCP value of a timeslot drops below an absolute threshold**

### 14.1.3.3 Reporting event 1I: Timeslot ISCP above a certain threshold (TDD)

When event 1i is configured in the UE, the UE shall:

1> if equation 1 is fulfilled for a time period indicated by "Time to trigger" and if that P-CCPCH is not included in the IE "cells triggered" in the variable TRIGGERED_1I_EVENT:

2> include that P-CCPCH in the IE "cells triggered" in the variable TRIGGERED_1I_EVENT;

2> send a measurement report with the IEs set as below:

3> set in "intra-frequency measurement event results": "Intrafrequency event identity" to "1i" and in "cell measurement event results" to the "Cell parameters ID" of the P-CCPCH that triggered the report;

3> include in "measured results" the "Timeslot ISCP" of those cells that are included in the variable TRIGGERED_1I_EVENT and "additional measured results" according to 8.4.2, not taking into account the cell individual offset for each cell.

1> if a primary CCPCH is included in the "cells triggered" in the variable TRIGGERED_1I_EVENT:

2> if Equation 2 below is fulfilled for a primary CCPCH:

3> if a primary CCPCH is included in the "cells triggered" in the variable TRIGGERED_1I_EVENT:

4> remove the entry of that primary CCPCH from "cells triggered" in the variable TRIGGERED_1I_EVENT.

The UE shall use the equation below for evaluation of reporting event 1i:

Equation 1

$$10 \cdot Log M_i - H_{1i} + O_i > T_{1h},$$

Equation 2

$10 \cdot Log M_i + H_{1i} + O_i < T_{1h}$,

The variables in the formula are defined as follows:

$M_i$ is the Timeslot ISCP of the currently evaluated cell ***i*** expressed in mW

$O_i$ is the cell individual offset of the currently evaluated cell ***i***

$T_{1i}$ is the Threshold for event 1i

$H_{1i}$ is the hysteresis parameter for the event 1i.

Before any evaluation is done, the Timeslot ISCP expressed in mW is filtered according to subclause 8.6.7.2.




**Figure 14.1.3.3-1: An ISCP value of a timeslot exceeds a certain threshold**

## 14.1.4 Event-triggered periodic intra-frequency measurement reports (informative)

### 14.1.4.1 Cell addition failure (FDD only)




**Figure 14.1.4.1-1: Periodic reporting triggered by event 1A**

When a cell enters the reporting range and triggers event 1A, the UE shall transmit a MEASUREMENT REPORT to the UTRAN and typically this may result in an update of the active set. However, in some situations the UTRAN may be unable to add a strong cell to the active set typically due to capacity shortage for example.

The UE shall continue reporting after the initial report by reverting to periodical measurement reporting if the reported cell is not added to the active set. This is illustrated in Figure 14.1.4.1-1. During periodic reporting the UE shall transmit MEASUREMENT REPORT messages to the UTRAN at predefined intervals. The reports shall include reporting information of the cells in the current active set and of the monitored cell(s) in the reporting range.

Event-triggered periodic measurement reporting shall be terminated if:

1> there are no longer any monitored cell(s) within the reporting range; or

1> the UTRAN has added cells to the active set so that it includes the maximum number of cells (defined by the **reporting deactivation threshold** parameter), which are allowed for event 1A to be triggered; or

1> the UE has sent the maximum number of MEASUREMENT REPORT messages (defined by the **amount of reporting** parameter).

The reporting period is assigned by the UTRAN (with the **Reporting interval** parameter). If the reporting interval is set to zero event-triggered periodic measurement reporting shall not be applied.

### 14.1.4.1a Cell removal failure (FDD only)




**Figure 14.1.4.1a: Periodic reporting triggered by event 1B**

When a cell enters the removal range and triggers event 1B, the UE shall transmit a MEASUREMENT REPORT to the UTRAN and typically this may result in the removal of the weakest active cell. If the UTRAN is unable to receive MEASUREMENT REPORT after the maximum retransmission, it is beneficial to receive continuous reports in this case as well.

The UE shall revert to periodical measurement reporting if the UTRAN does not update the active set after the transmission of the measurement report. This is illustrated in Figure 14.1.4.1a. During periodic reporting the UE shall transmit MEASUREMENT REPORT messages to the UTRAN at predefined intervals.

Event-triggered periodic measurement reporting shall be terminated if:

1> there are no longer any monitored cell(s) within the removal range; or

1> the UTRAN has removed cells from the active set so that there are no longer the minimum amount of active cells for event 1B to be triggered; or

1> the UE has sent the maximum number of MEASUREMENT REPORT messages (defined by the "amount of reporting" parameter).

The reporting period is assigned by the UTRAN (with the "Reporting interval" parameter). If the reporting interval is set to zero, event-triggered periodic measurement reporting shall not be applied.

### 14.1.4.2 Cell replacement failure (FDD only)




**Figure 14.1.4.1-2: Periodic reporting triggered by event 1C**

When a cell enters the replacement range and triggers event 1C, the UE shall transmit a MEASUREMENT REPORT to the UTRAN and typically this may result in the replacement of the weakest active cell. If the UTRAN is unable to replace the cell due to for example capacity shortage, it is beneficial to receive continuous reports in this case as well.

The UE shall revert to periodical measurement reporting if the UTRAN does not update the active set after the transmission of the measurement report. This is illustrated in Figure 14.1.4.1-2. During periodic reporting the UE shall transmit MEASUREMENT REPORT messages to the UTRAN at predefined intervals. The reports shall include reporting information of the cells in the current active set and of the monitored cell(s) in the replacement range.

Event-triggered periodic measurement reporting shall be terminated if:

1> there are no longer any monitored cell(s) within the replacement range; or

1> the UTRAN has removed cells from the active set so that there are no longer the minimum amount of active cells for event 1C to be triggered (as defined by the **replacement activation threshold** parameter); or

1> the UE has sent the maximum number of MEASUREMENT REPORT messages (defined by the **amount of reporting** parameter).

The reporting period is assigned by the UTRAN (with the **Reporting interval** parameter). If the reporting interval is set to zero, event-triggered periodic measurement reporting shall not be applied.

## 14.1.5 Mechanisms available for modifying intra-frequency measurement reporting behaviour (informative)

### 14.1.5.1 Hysteresis

To limit the amount of event-triggered reports, a hysteresis parameter may be connected with each reporting event given above. The value of the hysteresis is given to the UE in the Reporting criteria field of the Measurement Control message.

In the example in Figure 14.1.5.1-1, the hysteresis ensures that the event 1D (FDD) or IG(TDD) (primary CPICH(FDD)/CCPCH(TDD) 2 becomes the best cell) is not reported until the difference is equal to the hysteresis value. The fact that primary CPICH(FDD)/CCPCH(TDD) 1 becomes best afterwards is not reported at all in the example since the primary CPICH(FDD)/CCPCH(TDD) 1 does not become sufficiently better than the primary CPICH(FDD)/CCPCH(TDD) 2.




**Figure 14.1.5.1-1: Hysteresis limits the amount of measurement reports**

### 14.1.5.2 Time-to-trigger

To limit the measurement signalling load, a time-to-trigger parameter could be connected with each reporting event given above. The value of the time-to-trigger is given to the UE in the Reporting criteria field of the Measurement Control message.

The effect of the time-to-trigger is that the report is triggered only after the conditions for the event have existed for the specified time-to-trigger. In the following FDD example in Figure 14.1.5.2-1, the use of time-to-trigger means that the event (primary CPICH 3 enters the reporting range) is not reported until is has been within the range for the time given by the time-to-trigger parameter.




**Figure 14.1.5.2-1: Time-to-trigger limits the amount of measurement reports**

In the following TDD example in Figure 14.1.5.2-2, the use of time-to-trigger means that the event (Timeslot ISCP upon certain threshold) is not reported until it has been upon the threshold for the time given by the time-to trigger parameter.




**Figure 14.1.5.2-2: Time-to-trigger limits the amount of measurement reports**

NOTE: The time-to-trigger could be combined with hysteresis, i.e. a hysteresis value is added to the measurement quantity before evaluating if the time-to-trigger timer should be started.

### 14.1.5.3 Cell individual offsets

For each cell that is monitored, an offset can be assigned with inband signalling. The offset can be either positive or negative. The offset is added to the measurement quantity before the UE evaluates if an event has occurred. The UE receives the cell individual offsets for each primary CPICH(FDD)/CCPCH(TDD) in the IE "Cell individual offset" included in the IE "Cell info" associated with each measurement object included in the MEASUREMENT CONTROL message.

For the FDD example, in Figure 14.1.5.3-1, since an offset is added to primary CPICH 3, it is the dotted curve that is used to evaluate if an event occurs. Hence, this means that measurement reports from UE to UTRAN are triggered when primary CPICH plus the corresponding offset, i.e. the dotted curve, leaves and enters the reporting range and when it gets better than primary CPICH 1 (if these events have been ordered by UTRAN). This offset mechanism provides the network with an efficient tool to change the reporting of an individual primary CPICH.

By applying a positive offset, as in Figure 14.1.5.3-1, the UE will send measurement reports as if the primary CPICH is offset *x* dB better than what it really is. This could be useful if the operator knows that a specific cell is interesting to monitor more carefully, even though it is not so good for the moment. In the example in Figure 14.1.5.3-1, the operator might know by experience that in this area primary CPICH 3 can become good very quickly (e.g. due to street corners) and therefore that it is worth reporting more intensively. Depending on the implemented handover evaluation algorithm, this may result in the cell with primary CPICH 3 being included in the active set earlier than would have been the case without the positive offset.




**Figure 14.1.5.3-1: A positive offset is applied to primary CPICH 3 before event evaluation in the UE**

For the TDD example, in Figure 14.1.5.3-2, an offset is added to primary CCPCH2, it is the dotted curve that is used to evaluate if the primary CCPCH2 becomes better than primary CCPCH1 (ordered by the UTRAN).




**Figure 14.1.5.3-2: A positive offset is applied to primary CCPCH 2**

Correspondingly, the operator can choose to apply a negative offset to a primary CCPCH. Then the reporting on that primary CCPCH is limited and the corresponding cell may be, at least temporarily excluded from the active set or as a target cell for handover.

It is important to note that the offset is added before triggering events, i.e. the offset is added by the UE before evaluating if a measurement report should be sent as opposed to offsets that are applied in the network and used for the actual handover evaluation. It should also be noted that the cell individual offset is not used in all measurement reporting events, and that it is not applied to all events in the same way.

### 14.1.5.4 Forbid a Primary CPICH to affect the reporting range (FDD only)

The reporting range affects the reporting events 1A and 1B presented above. The reporting range is defined as a function of all the Primary CPICHs in the active set (see 14.1.2.1 and 14.1.2.2). If the parameter W is set to 0, the reporting range is defined relative to the best Primary CPICH. However, there could be cases where it is good to forbid a specific Primary CPICH to affect the reporting range. For example in Figure 14.1.5.4-1 the network has requested the UE to not let Primary CPICH 3 affect the reporting range. This mechanism could be effective if the operator knows by experience that the quality of Primary CPICH 3 is very unstable in a specific area and therefore should not affect the reporting of the other Primary CPICHs.

The UE shall ignore that a Primary CPICH is forbidden to affect the reporting range if all of the following conditions are fulfilled:

- the Primary CPICH is included in active set; and
- all cells in active set are defined as Primary CPICHs forbidden to affect the reporting range.




**Figure 14.1.5.4-1: Primary CPICH 3 is forbidden to affect the reporting range**

## 14.1.6 Report quantities in intra-frequency measurements

The quantities that the UE shall report to UTRAN when the event is triggered for an intra-frequency measurement are given by the IE "Intra-frequency reporting quantity" stored for this measurement and can be the following:

1 SFN-SFN observed time difference

2 Cell synchronisation information

3 Cell Identity

4 Downlink $E_c/N_0$ (FDD).

5 Downlink path loss.

For FDD:

Pathloss in dB = Primary CPICH Tx power - CPICH RSCP.

- For Primary CPICH Tx power the IE "Primary CPICH Tx power" shall be used. The unit is dBm.
- CPICH RSCP is the result of the CPICH RSCP measurement. The unit is dBm.

For TDD:

Pathloss in dB = Primary CCPCH TX power - Primary CCPCH RSCP.

- For Primary CCPCH TX power the IE "Primary CCPCH TX Power" shall be used. The unit is dBm.
- Primary CCPCH RSCP is the result of the Primary CCPCH RSCP measurement. The unit is dBm.

If necessary Pathloss shall be rounded up to the next higher integer.
Results higher than 158 shall be reported as 158.
Results lower than 46 shall be reported as 46.

6 Downlink received signal code power (RSCP) after despreading (of a primary CPICH for FDD, and of a primary CCPCH for TDD).

7 ISCP measured on Timeslot basis. (TDD)

8 Proposed TGSN (TDD)

A description of those values can be found in [7] and [8].

# 14.2 Inter-frequency measurements

## 14.2.0a Inter-frequency measurement quantities

The two first measurement quantities listed below are used by the UE to evaluate whether an inter-frequency measurement event has occurred or not, through the computation of a frequency quality estimate. The quantity to use to compute the frequency quality estimate for an inter-frequency measurement is given in the "Inter-frequency measurement quantity" stored for that measurement. In the FDD case, all three measurement quantities can be used for the update of the virtual active set of the non-used frequencies as described in subclause 14.11.

1 Downlink Ec/No (FDD)

2 Downlink received signal code power (RSCP) after despreading.

3 Downlink path loss.

For FDD:

Pathloss in dB = Primary CPICH Tx power - CPICH RSCP.

- For Primary CPICH Tx power the IE "Primary CPICH Tx power" shall be used. The unit is dBm.
- CPICH RSCP is the result of the CPICH RSCP measurement. The unit is dBm.

For TDD:

Pathloss in dB = Primary CCPCH TX power - Primary CCPCH RSCP.

- For Primary CCPCH TX power the IE "Primary CCPCH TX Power" shall be used. The unit is dBm.
- Primary CCPCH RSCP is the result of the Primary CCPCH RSCP measurement. The unit is dBm.

A description of those values can be found in [7] and [8].

## 14.2.0b Frequency quality estimate

### 14.2.0b.1 FDD cells

The frequency quality estimate used in events 2a, 2b 2c, 2d, 2e and 2f is defined as:

$$Q_{frequencyj} = 10 \cdot LogM_{frequency\ j} = W_j \cdot 10 \cdot Log\left(\sum_{i=1}^{N_{A\,j}} M_{i\,j}\right) + (1 - W_j) \cdot 10 \cdot LogM_{Best\ j},$$

The variables in the formula are defined as follows ("the virtual active set on frequency j" should be understood as the active set if frequency j is the used frequency. If frequency j is a non-used frequency, the way the virtual active set is initiated and updated is described in subclause 14.11):

$Q_{frequency\ j}$ is the estimated quality of the virtual active set on frequency j.

$M_{\text{frequency j}}$ is the estimated quality of the virtual active set on frequency j.

$M_{i\,j}$ is a measurement result of cell i in the virtual active set on frequency j.

$N_{A\,j}$ is the number of cells in the virtual active set on frequency j.

$M_{Best\ j}$ is the measurement result of the cell in the virtual active set on frequency j with the highest measurement result.

$W_j$ is a parameter sent from UTRAN to UE and used for frequency j.

If the measurement result is CPICH-Ec/No then $\boldsymbol{M_{Frequency}}$, $\boldsymbol{M_{i\,j}}$ and $\boldsymbol{M_{Best}}$ are expressed as ratios.

If the measurement result is CPICH-RSCP or PCCPCH-RSCP then $\boldsymbol{M_{Frequency}}$, $\boldsymbol{M_{i\,j}}$ and $\boldsymbol{M_{Best}}$ are expressed in mW.

### 14.2.0b.2 TDD cells

$$Q_{i,\,frequency\ \ j} = 10 \cdot LogM_{\ \ i,\,frequency\ \ j} + O_{i,j}$$

$\boldsymbol{Q_{i\,,frequency\,j}}$ is the estimated quality of cell i on frequency j.

$M_{frequency\ j}$ is the measurement result for Primary CCPCH RSCP of cell i on frequency j expressed in mW.

$\boldsymbol{O_{i,j}}$ is the cell individual offset of the currently evaluated cell *i* on frequency j. $\boldsymbol{O_{ij}}$ is set by IE " Cell individual offset"

## 14.2.0c Inter-frequency reporting quantities

The quantities that the UE shall report for each cell to UTRAN when the event is triggered for an inter-frequency measurement is given by the "Inter-frequency reporting quantity" IE stored for this measurement and can be the following, from 1 to 8. The quantity number 9 can be reported for each frequency that triggered the report.

1 Cell identity

2 SFN-SFN observed time difference

3 Cell synchronisation information

4 Downlink Ec/No (FDD)

5 Downlink path loss.

For FDD:

Pathloss in dB = Primary CPICH Tx power - CPICH RSCP.

- For Primary CPICH Tx power the IE "Primary CPICH Tx power" shall be used. The unit is dBm.
- CPICH RSCP is the result of the CPICH RSCP measurement. The unit is dBm.

For TDD:

Pathloss in dB = Primary CCPCH TX power - Primary CCPCH RSCP.

- For Primary CCPCH TX power the IE "Primary CCPCH TX Power" shall be used. The unit is dBm.
- Primary CCPCH RSCP is the result of the Primary CCPCH RSCP measurement. The unit is dBm.

If necessary Pathloss shall be rounded up to the next higher integer.
Results higher than 158 shall be reported as 158.
Results lower than 46 shall be reported as 46.

6 Downlink received signal code power (RSCP) after despreading (of a primary CPICH for FDD, and of a primary CCPCH for TDD).

7 ISCP measured on Timeslot basis. (TDD)

8 Proposed TGSN (TDD)

9 UTRA carrier RSSI

A description of those values can be found in [7] and [8].

## 14.2.1 Inter-frequency reporting events

Within the measurement reporting criteria field in the MEASUREMENT CONTROL message UTRAN notifies the UE which events should trigger the UE to send a MEASUREMENT REPORT message. The listed events are the toolbox from which the UTRAN can choose the reporting events that are needed for the implemented handover evaluation function, or other radio network functions.

All events are evaluated with respect to one of the measurement quantities given in subclause 14.2.0a. The measurement quantities are measured on the monitored primary common pilot channels (CPICH) in FDD mode and the monitored primary common control channels (PCCPCH) in TDD mode of the cell defined in the measurement object. A "non-used frequency" is a frequency that the UE has been ordered to measure upon but is not used for the connection. A "used frequency" is a frequency that the UE has been ordered to measure upon and is also currently used for the connection.

The "monitored set on non-used frequency" consists of cells in "cells for measurement" (or all cells in CELL_INFO_LIST if "cells for measurement" is not present) that are not part of the virtual active set on that non-used frequency.

When one inter-frequency measurement identity corresponds to multiple inter-frequency events with identical event identities, the UE behaviour is not specified.

### 14.2.1.1 Event 2a: Change of best frequency.

When event 2a is configured in the UE within a measurement, the UE shall:

1> when the measurement is initiated or resumed:

2> store the used frequency in the variable BEST_FREQUENCY_2A_EVENT.

1> if equation 1 below has been fulfilled for a time period indicated by "Time to trigger" for a frequency included for that event and which is not stored in the variable BEST_FREQUENCY_2A_EVENT:

2> send a measurement report with IEs set as below:

3> set in "inter-frequency measurement event results":

4> "inter-frequency event identity" to "2a"; and

4> "Frequency info" to the frequency that triggered the event; and

4> "Non frequency related measurement event results" to the "Primary CPICH info" of the best primary CPICH for FDD cells or "Primary CCPCH info" to the "Cells parameters ID" of the best primary CCPCH for TDD cells on that frequency, not taking into account the cell individual offset.

3> if a non-used frequency triggered the measurement report:

4> include in IE "Inter-frequency measured results list" the measured results for the non-used frequency that triggered the event, not taking into account the cell individual offset.

3> if the used frequency triggered the measurement report:

4> do not include the IE "Inter-frequency measured results list" in the measurement report.

3> set the IE "additional measured results" according to subclause 8.4.2, not taking into account the cell individual offset;

2> update the variable BEST_FREQUENCY_2A_EVENT with that frequency.

Equation 1:

$$Q_{NotBest} \geq Q_{Best} + H_{2a}/2$$

The variables in the formula are defined as follows:

$Q_{Not\ Best}$ is the quality estimate of a frequency not stored the "best frequency" in the variable BEST_FREQUENCY_2A_EVENT.

$Q_{Best}$ is the quality estimate of the frequency stored in "best frequency" in the variable BEST_FREQUENCY_2A_EVENT.

$H_{2a}$ is the hysteresis parameter for the event 2a in that measurement.

#### 14.2.1.2 Event 2b: The estimated quality of the currently used frequency is below a certain threshold **and** the estimated quality of a non-used frequency is above a certain threshold.

When an inter-frequency measurement configuring event 2b is set up, the UE shall:

1> create a variable TRIGGERED_2B_EVENT related to that measurement, which shall initially be empty;

1> delete this variable when the measurement is released.

When event 2b is configured in the UE within a measurement, the UE shall:

1> if equations 1 and 2 below have been fulfilled for a time period indicated by "Time to Trigger" from the same instant, respectively for one or several non-used frequencies included for that event and for the used frequency:

2> if any of those non-used frequency is not stored in the variable TRIGGERED_2B_EVENT:

3> store the non-used frequencies that triggered the event and that were not previously stored in the variable TRIGGERED_2B_EVENT into that variable;

3> send a measurement report with IEs set as below:

4> set in "inter-frequency measurement event results":

5> "inter-frequency event identity" to "2b"; and

5> for each non-used frequency that triggered the event, beginning with the best frequency:

6> "Frequency info" to that non-used frequency; and

6> "Non frequency related measurement event results" to the "Primary CPICH info" of the best primary CPICH for FDD cells or "Primary CCPCH info" to the "Cell parameters ID" of the best primary CCPCH for TDD cells on that non-used frequency, not taking into account the cell individual offset.

4> include in IE "Inter-frequency measured results list" the measured results for each non-used frequency that triggered the event, not taking into account the cell individual offset;

4> set the IE "additional measured results" according to subclause 8.4.2, not taking into account the cell individual offset.

1> if equation 3 below is fulfilled for a non-used frequency stored in the variable TRIGGERED_2B_EVENT:

2> remove that non-used frequency from the variable TRIGGERED_2B_EVENT.

1> if equation 4 below is fulfilled for the used frequency:

2> clear the variable TRIGGERED_2B_EVENT.

Triggering conditions:

Equation 1:

$$Q_{Nonused} \geq T_{Nonused2b} + H_{2b}/2$$

The variables in the formula are defined as follows:

$Q_{Non\ used}$ is the quality estimate of a non-used frequency that becomes better than an absolute threshold.

$T_{Non\ used\ 2b}$ is the absolute threshold that applies for this non-used frequency in that measurement.

$H_{2b}$ is the hysteresis parameter for the event 2b.

Equation 2:

$$Q_{Used} \leq T_{Used\ 2b} - H_{2b}/2$$

The variables in the formula are defined as follows:

$Q_{Used}$ is the quality estimate of the used frequency.

$T_{Used\ 2b}$ is the absolute threshold that applies for the used frequency in that measurement.

$H_{2b}$ is the hysteresis parameter for the event 2b.

Leaving triggered state condition:

Equation 3:

$$Q_{Non used} < T_{Non used\ 2b} - H_{2b}/2$$

The variables in the formula are defined as follows:

$Q_{Non\ used}$ is the quality estimate of a non-used frequency that is stored in the variable TRIGGERED_2B_EVENT.

$T_{Non\ used\ 2b}$ is the absolute threshold that applies for this non-used frequency in that measurement.

$H_{2b}$ is the hysteresis parameter for the event 2b.

Equation 4:

$$Q_{Used} > T_{Used\ 2b} + H_{2b}/2$$

The variables in the formula are defined as follows:

$Q_{Used}$ is the quality estimate of the used frequency.

$T_{Used\ 2b}$ is the absolute threshold that applies for the used frequency in that measurement.

$H_{2b}$ is the hysteresis parameter for the event 2b.

#### 14.2.1.3 Event 2c: The estimated quality of a non-used frequency is above a certain threshold

When an inter-frequency measurement configuring event 2c is set up, the UE shall:

1> create a variable TRIGGERED_2C_EVENT related to that measurement, which shall initially be empty;

1> delete this variable when the measurement is released.

When event 2c is configured in the UE within a measurement, the UE shall:

1> if equation 1 below has been fulfilled for one or several non-used frequencies included for that event during the time "Time to trigger":

2> if any of those non-used frequencies is not stored in the variable TRIGGERED_2C_EVENT:

3> store the non-used frequencies that triggered the event and that were not previously stored in the variable TRIGGERED_2C_EVENT into that variable;

3> send a measurement report with IEs set as below:

4> set in "inter-frequency measurement event results":

5> "inter-frequency event identity" to "2c"; and

5> for each non-used frequency that triggered the event, beginning with the best frequency:

6> "Frequency info" to that non-used frequency; and

6> "Non frequency related measurement event results" to the "Primary CPICH info" of the best primary CPICH for FDD cells or "Primary CCPCH info" to the "Cell parameters ID" of the best primary CCPCH for TDD cells on that non-used frequency, not taking into account the cell individual offset.

4> include in IE "Inter-frequency measured results list" the measured results for each non-used frequency that triggered the event, not taking into account the cell individual offset;

4> set the IE "additional measured results" according to subclause 8.4.2 not taking into account the cell individual offset.

1> if equation 2 below is fulfilled for a non-used frequency stored in the variable TRIGGERED_2C_EVENT:

2> remove that non-used frequency from the variable TRIGGERED_2C_EVENT.

Triggering condition:

Equation 1:

$$Q_{Non used} \geq T_{Non used 2c} + H_{2c}/2$$

The variables in the formula are defined as follows:

$Q_{Non\ used}$ is the quality estimate of a non-used frequency that becomes better than an absolute threshold.

$T_{Non\ used\ 2c}$ is the absolute threshold that applies for this non-used frequency in that measurement.

$H_{2c}$ is the hysteresis parameter for the event 2c.

Leaving triggered state condition:

Equation 2:

$$Q_{Non used} < T_{Non used 2c} - H_{2c}/2$$

The variables in the formula are defined as follows:

$Q_{Non\ used}$ is the quality estimate of a non-used frequency stored in the variable TRIGGERED_2C_EVENT.

$T_{Non\ used\ 2c}$ is the absolute threshold that applies for this non-used frequency in that measurement.

$H_{2c}$ is the hysteresis parameter for the event 2c.

#### 14.2.1.4 Event 2d: The estimated quality of the currently used frequency is below a certain threshold

A UE shall be able to perform this measurement and the corresponding event reporting without requiring compressed mode.

When an inter-frequency measurement configuring event 2d is set up, the UE shall:

1> create a variable TRIGGERED_2D_EVENT related to that measurement, which shall initially be set to FALSE;

1> delete this variable when the measurement is released.

When event 2d is configured in the UE within a measurement, the UE shall:

1> if equation 1 below has been fulfilled for the used frequency during the time "Time to trigger":

2> if the variable TRIGGERED_2D_EVENT is set to FALSE:

3> set the variable TRIGGERED_2D_EVENT to TRUE;

3> send a measurement report with IEs set as below:

4> set in "inter-frequency event results": "inter-frequency event identity" to "2d" and no IE "Inter-frequency cells", not taking into account the cell individual offset;

4> include in IE "Inter-frequency measured results list" the measured results for the used frequency, not taking into account the cell individual offset;

4> set the IE "additional measured results" according to subclause 8.4.2, not taking into account the cell individual offset.

1> if the variable TRIGGERED_2D_EVENT is set to TRUE and if equation 2 is fulfilled for the used frequency:

2> set the variable TRIGGERED_2D_EVENT to FALSE.

Triggering condition:

Equation 1:

$$Q_{Used} \leq T_{Used\,2d} - H_{2d}/2$$

The variables in the formula are defined as follows:

$\boldsymbol{Q_{Used}}$ is the quality estimate of the used frequency.

$\boldsymbol{T_{Used\ 2d}}$ is the absolute threshold that applies for the used frequency and event 2d.

$\boldsymbol{H_{2d}}$ is the hysteresis parameter for the event 2d.

Leaving triggered state condition:

Equation 2:

$$Q_{Used} > T_{Used\,2d} + H_{2d}/2$$

The variables in the formula are defined as follows:

$\boldsymbol{Q_{Used}}$ is the quality estimate of the used frequency.

$\boldsymbol{T_{Used\ 2d}}$ is the absolute threshold that applies for the used frequency and event 2d.

$\boldsymbol{H_{2d}}$ is the hysteresis parameter for the event 2d.

#### 14.2.1.5 Event 2e: The estimated quality of a non-used frequency is below a certain threshold

When an inter-frequency measurement configuring event 2e is set up, the UE shall:

1> create a variable TRIGGERED_2E_EVENT related to that measurement, which shall initially be empty;

1> delete this variable when the measurement is released.

When event 2e is configured in the UE within a measurement, the UE shall:

1> if equation 1 below has been fulfilled for one or several non-used frequencies included for that event during the time "Time to trigger":

2> if any of those non-used frequencies is not stored in the variable TRIGGERED_2E_EVENT:

3> store the non-used frequencies that triggered the event and that were not previously stored in the variable TRIGGERED_2E_EVENT into that variable;

3> send a measurement report with IEs set as below:

4> set in "inter-frequency measurement event results":

5> "inter-frequency event identity" to "2e"; and

5> for each non-used frequency that triggered the event, beginning with the best frequency:

6> "Frequency info" to that non-used frequency; and

6> "Non frequency related measurement event results" to the "Primary CPICH info" of the best primary CPICH for FDD cells or "Primary CCPCH info" to the "Cell parameters ID" of the best primary CCPCH for TDD cells on that non-used frequency, not taking into account the cell individual offset.

4> include in the IE "Inter-frequency measured results list" the measured results for each non-used frequency that triggered the event, not taking into account the cell individual offset;

4> set the IE "additional measured results" according to subclause 8.4.2, not taking into account the cell individual offset.

1> if equation 2 below is fulfilled for a non-used frequency stored in the variable TRIGGERED_2E_EVENT:

2> remove that non-used frequency from the variable TRIGGERED_2E_EVENT.

Triggering condition:

Equation 1:

$$Q_{Non used} \leq T_{Non used 2e} - H_{2e}/2$$

The variables in the formula are defined as follows:

$Q_{Non\ used}$ is the quality estimate of a non-used frequency that becomes worse than an absolute threshold.

$T_{Non\ used\ 2e}$ is the absolute threshold that applies for that non-used frequency for that event.

$H_{2e}$ is the hysteresis parameter for the event 2e.

Leaving triggered state condition:

Equation 2:

$$Q_{Non used} > T_{Non used 2e} + H_{2e}/2$$

The variables in the formula are defined as follows:

$Q_{Non\ used}$ is the quality estimate of a non-used frequency stored in the variable TRIGGERED_2E_EVENT.

$T_{Non\ used\ 2e}$ is the absolute threshold that applies for that non-used frequency for that event.

$H_{2e}$ is the hysteresis parameter for the event 2e.

#### 14.2.1.6 Event 2 f: The estimated quality of the currently used frequency is above a certain threshold

A UE shall be able to perform this measurement and the corresponding event reporting without requiring compressed mode.

When an inter-frequency measurement configuring event 2f is set up, the UE shall:

1> create a variable TRIGGERED_2F_EVENT related to that measurement, which shall initially be set to FALSE;

1> delete this variable when the measurement is released.

When event 2f is configured in the UE within a measurement, the UE shall:

1> if equation 1 below has been fulfilled for the used frequency during the time "Time to trigger":

2> if the variable TRIGGERED_2F_EVENT is set to FALSE:

3> set the variable TRIGGERED_2F_EVENT to TRUE;

3> send a measurement report with IEs set as below:

4> set in "inter-frequency event results": "inter-frequency event identity" to "2f", and no IE "Inter-frequency cells";

4> include in IE "Inter-frequency measured results list" the measured results for the used frequency, not taking into account the cell individual offset;

4> set the IE "additional measured results" according to subclause 8.4.2, not taking into account the cell individual offset.

1> if the variable TRIGGERED_2F_EVENT is set to TRUE and if equation 2 is fulfilled for the used frequency:

2> set the variable TRIGGERED_2F_EVENT to FALSE.

Triggering condition:

Equation 1:

$$Q_{Used} \geq T_{Used\,2f} + H_{2f}/2$$

The variables in the formula are defined as follows:

$Q_{Used}$ is the quality estimate of the used frequency.

$T_{Used\ 2f}$ is the absolute threshold that applies for the used frequency and event 2f.

$H_{2f}$ is the hysteresis parameter for the event 2f.

Leaving triggered state condition:

Equation 2:

$$Q_{Used} < T_{Used\,2f} - H_{2f}/2$$

The variables in the formula are defined as follows:

$Q_{Used}$ is the quality estimate of the used frequency.

$T_{Used\ 2f}$ is the absolute threshold that applies for the used frequency and event 2f.

$H_{2f}$ is the hysteresis parameter for the event 2f.

# 14.3 Inter-RAT measurements

## 14.3.0a Inter-RAT measurement quantities

A measurement quantity is used by the UE to evaluate whether an inter-RAT measurement event has occurred or not.

The measurement quantity for UTRAN is used to compute the frequency quality estimate for the active set, as described in the next subclause, and can be:

1 Downlink Ec/No.

2 Downlink received signal code power (RSCP) after despreading.

The measurement quantity for GSM can be:

1 GSM Carrier RSSI

A description of those values can be found in [7] and [8].

## 14.3.0b Frequency quality estimate of the UTRAN frequency

The estimated quality of the active set in UTRAN in event 3a is defined as:

$$Q_{UTRAN} = 10 \cdot LogM_{UTRAN} = W \cdot 10 \cdot Log\left(\sum_{i=1}^{N_A} M_i\right) + (1-W) \cdot 10 \cdot LogM_{Best},$$

The variables in the formula are defined as follows:

$\boldsymbol{Q_{UTRAN}}$ is the estimated quality of the active set on the currently used UTRAN frequency.

$M_{UTRAN}$ is the estimated quality of the active set on currently used UTRAN frequency expressed in another unit.

$M_i$ is the measurement result of cell i in the active set, according to what is indicated in the IE "Measurement quantity for UTRAN quality estimate".

$N_A$ is the number of cells in the active set.

$M_{Best}$ is the measurement result of the cell in the active set with the highest measurement result.

W is a parameter sent from UTRAN to UE.

If the measurement result is CPICH-Ec/No $\boldsymbol{M_{UTRAN}}$, $\boldsymbol{M_i}$ and $\boldsymbol{M_{Best}}$ are expressed as ratios.

If the measurement result is CPICH-RSCP or PCCPCH-RSCP, $\boldsymbol{M_{UTRAN}}$, $\boldsymbol{M_i}$ and $\boldsymbol{M_{Best}}$ are expressed in mW.

## 14.3.0c Inter-RAT reporting quantities

The quantities that the UE shall report to UTRAN when the event is triggered for an inter-RAT measurement are given by the IE "Inter-RAT reporting quantity" stored for that measurement, and can be the following:

In the case the other RAT is GSM:

1 GSM carrier RSSI

A description of those values can be found in [7] and [8].

## 14.3.1 Inter-RAT reporting events

Within the measurement reporting criteria field in the MEASUREMENT CONTROL message the UTRAN notifies the UE which events should trigger the UE to send a MEASUREMENT REPORT message. The listed events are the toolbox from which the UTRAN can choose the reporting events that are needed for the implemented handover evaluation function, or other radio network functions.

All events are measured with respect to one of the measurement quantities given in subclause 14.3.0a, and of the frequency quality estimate given in subclause 14.3.0b. For UTRAN the measurement quantities are measured on the monitored primary common pilot channels (CPICH) in FDD mode and the monitored primary common control channels (PCCPCH) in TDD mode of the cell defined in the measurement object. For other RATs the measurement quantities are system-specific. A "used UTRAN frequency" is a frequency that the UE have been ordered to measure upon and is also currently used for the connection to UTRAN. "Other system" is e.g. GSM.

In the text below describing the events:

- "The BCCH ARFCN and BSIC combinations considered in that inter-RAT measurement" shall be understood as the BCCH ARFCN and BSIC combinations of the inter-RAT cells pointed at in the IE "Cells for measurement" if it has been received for that inter-RAT measurement, or otherwise of the cells included in the "inter-RAT cell info" part of the variable CELL_INFO LIST.
- "The BCCH ARFCNs considered in that inter-RAT measurement" shall be understood as the BCCH ARFCNs of the inter-RAT cells pointed at in the IE "Cells for measurement" if it has been received for that inter-RAT measurement, or otherwise of the cells included in the "inter-RAT cell info" part of the variable CELL_INFO LIST.

When one inter-RAT measurement identity corresponds to multiple inter-RAT events with identical event identities, the UE behaviour is not specified.

#### 14.3.1.1 Event 3a: The estimated quality of the currently used UTRAN frequency is below a certain threshold **and** the estimated quality of the other system is above a certain threshold.

When an inter-RAT measurement configuring event 3a is set up, the UE shall:

1> create a variable TRIGGERED_3A_EVENT related to that measurement, which shall initially be empty;

1> delete this variable when the measurement is released.

When event 3a is configured in the UE within a measurement, the UE shall:

1> if the other RAT is GSM, and if IE "BSIC verification required" is set to "required":

2> if equations 1 and 2 below have both been fulfilled for a time period indicated by "Time to trigger" from the same instant, respectively for the used UTRAN frequency and for one or several GSM cells that match any of the BCCH ARFCN and BSIC combinations considered in that inter-RAT measurement:

3> if the Inter-RAT cell id of any of those GSM cells is not stored in the variable TRIGGERED_3A_EVENT:

4> store the Inter-RAT cell ids of the GSM cells that triggered the event and that were not previously stored in the variable TRIGGERED_3A_EVENT into that variable.

4> send a measurement report with IEs set as below:

5> in "inter-RAT measurement event result": "inter-RAT event identity" to "3a", "CHOICE BSIC" to "verified BSIC" and "Inter-RAT cell id" to the GSM cells that triggered the event (best one first), taking into account the cell individual offset of the GSM cells;

5> "measured results" and possible "additional measured results" according to subclause 8.6.7.5 and 8.4.2, respectively, not taking into account the cell individual offset.

2> if equation 4 is fulfilled for a GSM cell whose inter-RAT cell id is stored in the variable TRIGGERED_3A_EVENT:

3> remove the inter-RAT cell id of that GSM cell from the variable TRIGGERED_3A_EVENT.

2> if equation 3 is fulfilled for the used frequency in UTRAN:

3> clear the variable TRIGGERED_3A_EVENT.

1> if the other RAT is GSM, and if IE "BSIC verification required" is set to "not required":

2> if equations 1 and 2 below have been fulfilled for a time period indicated by "Time to trigger" from the same instant, respectively for the used UTRAN frequency and for one or several BCCH ARFCNs considered in that inter-RAT measurement:

3> if any of those BCCH ARFCNs is not stored into the variable TRIGGERED_3A_EVENT:

4> store the BCCH ARFCNs that triggered the event and that were not previously stored in the variable TRIGGERED_3A_EVENT into that variable;

4> send a measurement report with IEs set as below:

5> in "inter-RAT measurement event result": "inter-RAT event identity" to "3a", "CHOICE BSIC" to "non verified BSIC" and "BCCH ARFCN" to BCCH ARFCNs that triggered the event (best one first), taking into account the cell individual offset of the GSM cells;

5> "measured results" and possible "additional measured results" according to subclause 8.6.7.5 and 8.4.2, respectively, not taking into account the cell individual offset.

2> if equation 4 is fulfilled for a BCCH ARFCN that is stored in the variable TRIGGERED_3A_EVENT:

3> remove that BCCH ARFCN from the variable TRIGGERED_3A_EVENT.

2> if equation 3 is fulfilled for the used frequency in UTRAN:

3> clear the variable TRIGGERED_3A_EVENT.

Triggering conditions:

Equation 1:

$$Q_{Used} \leq T_{Used} - H_{3a}/2$$

The variables in the formula are defined as follows:

$\boldsymbol{Q_{Used}}$ is the quality estimate of the used UTRAN frequency.

$\boldsymbol{T_{Used}}$ is the absolute threshold that applies for the used frequency in that measurement.

$\boldsymbol{H_{3a}}$ is the hysteresis parameter for event 3a.

Equation 2:

$$M_{Other\ RAT} + CIO_{OtheRAT} \geq T_{Other\ RAT} + H_{3a}/2$$

The variables in the formula are defined as follows:

$\boldsymbol{M_{Other\ RAT}}$ is the measurement quantity for the cell of the other system.

$\boldsymbol{CIO_{Other\ RAT}}$ is the cell individual offset for the cell of the other system.

$\boldsymbol{T_{Other\ RAT}}$ is the absolute threshold that applies for the other system in that measurement.

$\boldsymbol{H_{3a}}$ is the hysteresis parameter for event 3a.

Leaving triggered state conditions:

Equation 3:

$$Q_{Used} > T_{Used} + H_{3a}/2$$

The variables in the formula are defined as follows:

$\boldsymbol{Q_{Used}}$ is the quality estimate of the used UTRAN frequency.

$\boldsymbol{T_{Used}}$ is the absolute threshold that applies for the used frequency in that measurement.

$\boldsymbol{H_{3a}}$ is the hysteresis parameter for event 3a.

Equation 4:

$$M_{Other\ RAT} + CIO_{OtheRAT} < T_{Other\ RAT} - H_{3a}/2$$

The variables in the formula are defined as follows:

$\boldsymbol{M_{Other\ RAT}}$ is the measurement quantity for the cell of the other system. $\boldsymbol{M_{Other\ RAT}}$ is expressed in dBm.

$\boldsymbol{CIO_{Other\ RAT}}$ is the cell individual offset for the cell of the other system.

$\boldsymbol{T_{Other\ RAT}}$ is the absolute threshold that applies for the other system in that measurement.

$\boldsymbol{H_{3a}}$ is the hysteresis parameter for event 3a.

#### 14.3.1.2 Event 3b: The estimated quality of other system is below a certain threshold

When an inter-RAT measurement configuring event 3b is set up, the UE shall:

1> create a variable TRIGGERED_3B_EVENT related to that measurement, which shall initially be empty;

1> delete this variable when the measurement is released.

When event 3b is configured in the UE within a measurement, the UE shall:

1> if the other RAT is GSM, and if IE "BSIC verification required" is set to "required":

2> if equation 1 below has been fulfilled for a time period indicated by "time to trigger" for one or several GSM cells that match any of the BCCH ARFCN and BSIC combinations considered in that inter-RAT measurement:

3> if the inter-RAT cell id of any of those GSM cell is not stored in the variable TRIGGERED_3B_EVENT:

4> store the inter-RAT cell ids of the GSM cells that triggered the event and that were not previously stored in the variable TRIGGERED_3B_EVENT into that variable;

4> send a measurement report with IEs set as below:

5> set in "inter-RAT measurement event result": "inter-RAT event identity" to "3b", "CHOICE BSIC" to "verified BSIC" and "Inter-RAT cell id" to the GSM cells that triggered the event (worst one first), taking into account the cell individual offset of the GSM cells;

5> set the IE "measured results" and the IE "additional measured results" according to subclause 8.6.7.5 and 8.4.2, respectively, not taking into account the cell individual offset.

2> if equation 2 below is fulfilled for a GSM cell whose inter-RAT cell id is stored in the variable TRIGGERED_3B_EVENT:

3> remove the inter-RAT cell id of that GSM cell from the variable TRIGGERED_3B_EVENT.

1> if the other RAT is GSM, and if IE "BSIC verification required" is set to "not required":

2> if equation 1 below has been fulfilled for a time period indicated by "time to trigger" for one or several of the BCCH ARFCNs considered in that inter-RAT measurement:

3> if any of those BCCH ARFCN is not stored into the variable TRIGGERED_3B_EVENT:

4> store the BCCH ARFCNs that triggered the event and that were not previously stored in the variable TRIGGERED_3B_EVENT into that variable;

4> send a measurement report with IEs set as below:

5> set in "inter-RAT measurement event result": "inter-RAT event identity" to "3b", "CHOICE BSIC" to "non verified BSIC" and "BCCH ARFCN" to BCCH ARFCNs that triggered the event (worst one first), taking into account the cell individual offset of the GSM cells;

5> set the IE "measured results" and the IE "additional measured results" according to subclause 8.6.7.5 and 8.4.2, respectively, not taking into account the cell individual offset.

2> if equation 2 below is fulfilled for a BCCH ARFCN that is stored in the variable TRIGGERED_3B_EVENT:

3> remove that BCCH ARFCN from the variable TRIGGERED_3B_EVENT.

Triggering condition:

Equation 1:

$$M_{Other\ RAT} + CIO_{Other\ RAT} \leq T_{Other\ RAT} - H_{3b}/2$$

The variables in the formula are defined as follows:

$M_{Other\ RAT}$ is the measurement quantity for the cell of the other system.

$CIO_{Other\ RAT}$ is the cell individual offset for the cell of the other system.

$T_{Other\ RAT}$ is the absolute threshold that applies for the other system in that measurement.

$H_{3b}$ is the hysteresis parameter for event 3b.

Leaving triggered state condition:

Equation 2:

$$M_{Other\ RAT}+CIO_{Other\ RAT}>T_{Other\ RAT}+H_{3b}/2$$

The variables in the formula are defined as follows:

$M_{Other\ RAT}$ is the measurement quantity for the cell of the other system. $M_{Other\ RAT}$ is expressed in dBm.

$CIO_{Other\ RAT}$ is the cell individual offset for the cell of the other system.

$T_{Other\ RAT}$ is the absolute threshold that applies for the other system in that measurement.

$H_{3b}$ is the hysteresis parameter for event 3b.

#### 14.3.1.3 Event 3c: The estimated quality of other system is above a certain threshold

When an inter-RAT measurement configuring event 3c is set up, the UE shall:

1> create a variable TRIGGERED_3C_EVENT related to that measurement, which shall initially be empty;

1> delete this variable when the measurement is released.

When event 3c is configured in the UE within a measurement, the UE shall:

1> if the other RAT is GSM, and if IE "BSIC verification required" is set to "required":

2> if equation 1 below has been fulfilled for a time period indicated by "time to trigger" for one or several GSM cells that match any of the BCCH ARFCN and BSIC combinations considered in that inter-RAT measurement:

3> if the inter-RAT cell id of any of those GSM cell is not stored in the variable TRIGGERED_3C_EVENT:

4> store the Inter-RAT cell ids of the GSM cells that triggered the event and that were not previously stored in the variable TRIGGERED_3C_EVENT into that variable;

4> send a measurement report with IEs set as below:

5> set in "inter-RAT measurement event result": "inter-RAT event identity" to "3c", "CHOICE BSIC" to "verified BSIC" and "Inter-RAT cell id" to the GSM cells that triggered the event (best one first), taking into account the cell individual offset of the GSM cells;

5> set the IE "measured results" and the IE "additional measured results" according to subclause 8.6.7.5 and 8.4.2, respectively, not taking into account the cell individual offset.

2> if equation 2 below is fulfilled for a GSM cell whose inter-RAT cell id is stored in the variable TRIGGERED_3C_EVENT:

3> remove the inter-RAT cell id of that GSM cell from the variable TRIGGERED_3C_EVENT.

1> if the other RAT is GSM, and if IE "BSIC verification required" is set to "not required":

2> if equation 1 below has been fulfilled for a time period indicated by "time to trigger" for one or several of the BCCH ARFCNs considered in that inter-RAT measurement:

3> if any of those BCCH ARFCN is not stored into the variable TRIGGERED_3C_EVENT:

4> store the BCCH ARFCNs that triggered the event and that were not previously stored in the variable TRIGGERED_3C_EVENT into that variable;

4> send a measurement report with IEs set as below:

5> set in "inter-RAT measurement event result": "inter-RAT event identity" to "3c", "CHOICE BSIC" to "non verified BSIC" and "BCCH ARFCN" to BCCH ARFCNs that triggered the event (best one first), taking into account the cell individual offset of the GSM cells;

5> set the IE "measured results" and the IE "additional measured results" according to subclause 8.6.7.5 and 8.4.2, respectively, not taking into account the cell individual offset.

2> if equation 2 is fulfilled for a BCCH ARFCN that is stored in the variable TRIGGERED_3C_EVENT:

3> remove that BCCH ARFCN from the variable TRIGGERED_3C_EVENT.

Triggering condition:

Equation 1:

$$M_{Other\ RAT}+CIO_{Other\ RAT} \geq T_{Other\ RAT}+H_{3c}/2$$

The variables in the formula are defined as follows:

$\boldsymbol{M_{Other\ RAT}}$ is the measurement quantity for the cell of the other system. $\boldsymbol{M_{Other\ RAT}}$ is expressed in dBm.

$\boldsymbol{CIO_{Other\ RAT}}$ is the cell individual offset for the cell of the other system.

$\boldsymbol{T_{Other\ RAT}}$ is the absolute threshold that applies for the other system in that measurement.

$\boldsymbol{H_{3c}}$ is the hysteresis parameter for event 3c.

Leaving triggered state condition:

Equation 2:

$$M_{Other\ RAT}+CIO_{Other\ RAT} < T_{Other\ RAT}-H_{3c}/2$$

The variables in the formula are defined as follows:

$\boldsymbol{M_{Other\ RAT}}$ is the measurement quantity for the cell of the other system. $\boldsymbol{M_{Other\ RAT}}$ is expressed in dBm.

$\boldsymbol{CIO_{Other\ RAT}}$ is the cell individual offset for the cell of the other system.

$\boldsymbol{T_{Other\ RAT}}$ is the absolute threshold that applies for the other system in that measurement.

$\boldsymbol{H_{3c}}$ is the hysteresis parameter for event 3c.

#### 14.3.1.4 Event 3d: Change of best cell in other system

When an inter-RAT measurement configuring event 3d is set up, the UE shall:

1> create a variable BEST_CELL_3D_EVENT related to that measurement;

1> delete this variable when the measurement is released.

When event 3d is configured in the UE within a measurement, the UE shall:

1> if the other RAT is GSM, and if IE "BSIC verification required" is set to "required":

2> when the measurement is initiated or resumed:

3> store in the variable BEST_CELL_3D_EVENT the Inter-RAT cell id of the GSM cell that has the best measured quantity among the GSM cells that match any of the BCCH ARFCN and BSIC combinations considered in that inter-RAT measurement, not taking into account the cell individual offset of the GSM cells;

3> send a measurement report with IE set as below:

4> set in "inter-RAT measurement event result": "inter-RAT event identity" to "3d", "CHOICE BSIC" to "verified BSIC" and "Inter-RAT cell id" to the GSM cell that is stored in the variable BEST_CELL_3D_EVENT;

4> set the IE "measured results" and the IE "additional measured results" according to subclause 8.6.7.5 and 8.4.2, respectively, not taking into account the cell individual offset.

2> if equation 1 has been fulfilled for a time period indicated by "time to trigger" for a GSM cell that is different from the one stored in BEST_CELL_3D_EVENT and that matches any of the BCCH ARFCN and BSIC combinations considered in that inter-RAT measurement:

3> store the Inter-RAT cell id of that GSM cell in the variable BEST_CELL_3D_EVENT;

3> send a measurement report with IEs set as below:

4> set in "inter-RAT measurement event result": "inter-RAT event identity" to "3d", "CHOICE BSIC" to "verified BSIC" and "Inter-RAT cell id" to the GSM cell is now stored in BEST_CELL_3D_EVENT;

4> set the IE "measured results" and the IE "additional measured results" according to subclause 8.6.7.5 and 8.4.2, respectively, not taking into account the cell individual offset.

1> if the other RAT is GSM, and if IE "BSIC verification required" is set to "not required":

2> when the measurement is initiated or resumed:

3> store in the variable BEST_CELL_3D_EVENT the BCCH ARFCN of the GSM cell that has the best measured quantity among the BCCH ARFCNs considered in that inter-RAT measurement;

3> send a measurement report with IE set as below:

4> set in "inter-RAT measurement event result": "inter-RAT event identity" to "3d", "CHOICE BSIC" to "non verified BSIC" and "BCCH ARFCN" to the BCH ARFCN that is stored in the variable BEST_CELL_3D_EVENT;

4> set the IE "measured results" and the IE "additional measured results" according to subclause 8.6.7.5 and 8.4.2, respectively, not taking into account the cell individual offset.

2> if equation 1 below has been fulfilled for a time period indicated by "time to trigger" for one of the BCCH ARFCNs considered in that inter-RAT measurement and different from the one stored in BEST_CELL_3D_EVENT:

3> store the BCCH ARFCN of that GSM cell in the variable BEST_CELL_3D_EVENT;

3> send a measurement report with IEs set as below:

4> set in "inter-RAT measurement event result": "inter-RAT event identity" to "3d", "CHOICE BSIC" to "non verified BSIC" and "BCCH ARFCN" to the BCCH ARFCN that is now stored in the variable BEST_CELL_3D_EVENT;

4> set the IE "measured results" and the IE "additional measured results" according to subclause 8.4.2, not taking into account the cell individual offset.

Equation 1:

$$M_{New} \geq M_{Best} + H_{3d}/2$$

The variables in the formula are defined as follows:

$M_{New}$ is the measurement quantity for a GSM cell that is not stored in the variable BEST_CELL_3D_EVENT.

$M_{Best}$ is the measurement quantity for a GSM cell that is stored in the variable BEST_CELL_3D_EVENT.

$H_{3d}$ is the hysteresis parameter for event 3d.

### 14.3.2 GSM measurements in compressed mode

#### 14.3.2.1 GSM RSSI measurements

The UE shall perform GSM RSSI measurements in the gaps of compressed mode pattern sequence specified for GSM RSSI measurement purpose.

#### 14.3.2.2 Initial BSIC identification

The UE shall perform Initial BSIC identification in compressed mode pattern sequence specified for Initial BSIC identification measurement purpose.

The parameter "N identify abort" in the IE "DPCH compressed mode info" indicates the maximum number of patterns that the UE shall use to attempt to decode the unknown BSIC of the GSM cell in the initial BSIC identification procedure.

The BSIC identification procedure is defined in detail in [19].

#### 14.3.2.3 BSIC re-confirmation

The UE shall perform BSIC re-confirmation in compressed mode pattern sequence specified for BSIC re-confirmation measurement purpose.

The parameter "T reconfirm abort" in the IE "DPCH compressed mode info" indicates the maximum time allowed for the re-confirmation of the BSIC of one GSM cell in the BSIC re-confirmation procedure.

The BSIC re-confirmation procedure is defined in detail in [19].

## 14.4 Traffic Volume Measurements

### 14.4.1 Traffic Volume Measurement Quantity

Traffic volume measurements may be configured by RRC to assist with dynamic radio bearer control. The reported quantities that can be configured are:

1 Buffer Occupancy.

2 Average of Buffer Occupancy.

3 Variance of Buffer Occupancy.

A description of these values can be found in [15].

When a report is triggered, the UE shall provide the requested quantities for the acknowledged and unacknowledged mode RBs mapped onto the transport channels identified.

When the RLC buffer payload, Average of RLC buffer payload or Variance of RLC buffer payload is reported, the measured quantity shall be rounded upwards to the closest higher value possible to report.

### 14.4.2 Traffic Volume reporting triggers

Traffic volume measurement reports can be triggered using two different mechanisms, periodical and event triggered. The reporting criteria are specified in the measurement control message.

All the specified events are evaluated with respect to the Transport Channel Traffic Volume (TCTV). This quantity is equal to the sum of the Buffer Occupancy for all logical channels mapped onto a transport channel. The events on a given transport channel shall be evaluated at least at every TTI (may be more often) as described in [15].

When one traffic volume measurement identity corresponds to multiple traffic volume events with identical event identities for the same transport channel, the UE behaviour is not specified.

When a traffic volume measurement is set up, the UE shall:

1> if the IE "report criteria" is set to "Traffic volume measurement reporting criteria":

2> for each IE "Parameters sent for each transport channel":

3> if the IE "Uplink transport channel type" is not included; or

3> if the IE "Uplink Transport Channel Type" has the value "DCH" or "USCH" and the IE "UL transport channel id" is not included:

4> for each IE "Parameters required for each Event":

5> for each uplink transport channel on which the UE is supposed to report (see below):

6> configure an event trigger defined by the values in the IEs "Measurement Identity", "Traffic volume event identity", "Reporting threshold", "Time to trigger", "Pending time after trigger" and "Tx Interruption after trigger".

3> else:

4> for each IE "Parameters required for each Event":

5> for the uplink transport channel defined by the IEs "Uplink transport channel type" and "UL transport channel id":

6> configure an event trigger defined by the values in the IEs "Measurement Identity", "Traffic volume event identity", "Reporting threshold", "Time to trigger", "Pending time after trigger" and "Tx Interruption after trigger".

1> else:

2> if the IE "report criteria" is set to "Periodical reporting criteria":

2> configure periodical triggers with period equal to the value in the IE "Reporting Interval" and with number of transmissions equal to the value in the IE "Amount of reporting" for the measurement identified by the IE "Measurement Identity".

For each transport channel for which an event trigger has been configured, the UE shall:

1> for each event configured for this transport channel:

2> if the TCTV is larger than the threshold in IE "Reporting threshold" at TVM setup or modify; or

2> if the TCTV becomes larger than the threshold in IE "Reporting threshold" while the event is configured:

3> if the IE "Traffic volume event identity" has value "4a":

4> if the IE "Time to trigger" is not present; and

4> if the Pending-time-after-trigger timer for this event is not active:

5> if the IE "Pending time after trigger" is included:

6> start the Pending-time-after-trigger timer for this event with the value in this IE.

5> trigger a report for the measurement identified by the IE "Measurement Identity".

4> else:

5> start the Time-to-trigger timer for this event with the value in the IE "Time to trigger".

3> if the IE "Traffic volume event identity" has value "4b":

4> if the Time-to-trigger timer for this event is active:

5> stop this timer.

2> if the TCTV is smaller than the threshold in IE "Reporting threshold" at TVM setup or modify; or

2> if the TCTV becomes smaller than the threshold in IE "Reporting threshold" while the event is configured:

3> if the IE "Traffic volume event identity" has value "4a":

4> if the Time-to-trigger timer for this event is active:

5> stop this timer.

3> if the IE "Traffic volume event identity" has value "4b":

4> if the IE "Time to trigger" is not present; and

4> if the Pending-time-after-trigger timer for this event is not active:

5> if the IE "Pending time after trigger" is included:

6> start the Pending-time-after-trigger timer for this event with the value in this IE.

5> trigger a report for the measurement identified by the IE "Measurement Identity".

4> else:

5> start the Time-to-trigger timer for this event with the value in the IE "Time to trigger".

When the Time-to-trigger timer for an event elapses:

1> if the Pending-time-after-trigger timer for this event is not active:

2> trigger a report for the measurement identified by the IE "Measurement Identity" corresponding to this event;

2> if the IE "Pending time after trigger" is included:

3> start the Pending-time-after-trigger timer for this event with the value in this IE.

When the Pending-time-after-trigger for an event elapses:

1> if the IE "Traffic volume event identity" has value "4a":

2> if the TCTV is larger than the threshold in IE "Reporting threshold":

3> if the IE "Time to trigger" is not present:

4> trigger a report for the measurement identified by the IE "Measurement Identity" corresponding to this event;

4> start the Pending-time-after-trigger timer for this event with the value in the IE "Pending time after trigger".

3> else:

4> start the Time-to-trigger timer for this event with the value in the IE "Time to trigger".

1> if the IE "Traffic volume event identity" has value "4b":

2> if the TCTV is smaller than the threshold in IE "Reporting threshold":

3> if the IE "Time to trigger" is not present:

4> trigger a report for the measurement identified by the IE "Measurement Identity" corresponding to this event;

4> start the Pending-time-after-trigger timer for this event with the value in the IE "Pending time after trigger".

3> else:

4> start the Time-to-trigger timer for this event with the value in the IE "Time to trigger".

When a periodical trigger elapses, the UE shall:

1> trigger a report for the measurement identified by the IE "Measurement Identity";

1> if the number of reports triggered by this periodical trigger reaches the value in the IE "Amount of reporting":

2> disable this periodical trigger.

When a report is triggered for a given IE "Measurement Identity", the UE shall:

1> consider the variable MEASUREMENT_IDENTITY corresponding to this measurement identity;

1> if the report is triggered by an event trigger:

2> include the IE "Event results";

2> set the IE "Uplink transport channel type causing the event" to the type of the transport channel which triggered the report;

2> if the transport channel type is "DCH" or "USCH":

3> include the IE "UL Transport Channel identity" and set it to the identity of the transport channel which triggered the report.

2> else:

3> not include the IE "UL Transport Channel identity".

2> set the IE "Traffic volume event identity" to the identity of the event that triggered the report;

2> if the IE "Tx interruption after trigger" for the event that triggered the report is included:

3> if the UE is in CELL_FACH state:

4> prohibit DTCH transmissions on the RACH;

4> if the Tx interruption timer is not running; or

4> if the Tx interruption timer is running and still has a value larger than the IE "Tx interruption after trigger" for the event, i.e. it was started earlier by another event with a larger value in IE "Tx interruption after trigger":

5> start the Tx interruption timer with the value in the IE "Tx interruption after trigger" for this event.

4> when it receives from the UTRAN a message causing the transition to CELL_DCH state; or

4> when the Tx interruption timer elapses:

5> stop the timer;

5> resume these transmissions.

1> if the IE "Traffic volume measurement object" is not included:

2> report on all the uplink transport channels as specified below.

1> if the IE "Traffic volume measurement object" is included:

2> report on the uplink transport channels identified in this IE as specified below.

1> for each UM or AM RB mapped onto a transport channel on which the UE is expected to report:

2> add an element in the IE "Traffic volume measurement results";

2> set the value of the IE "RB Identity" to the identity of the considered radio bearer;

2> if the RB is mapped onto one logical channel:

3> if the IE "RLC Buffer Payload for each RB" is set to TRUE:

4> include the IE "RLC Buffers Payload" and set it to the Buffer Occupancy value for this logical channel, rounded up to the next allowed value.

3> if the IE "Average of RLC Buffer Payload for each RB" is set to TRUE:

4> include and set the IE "Average of RLC Buffer Payload" to the Buffer Occupancy for this logical channel averaged over the interval specified in the IE "Time Interval to take an average or a variance" (see [15]), rounded up to the next allowed value.

3> if the IE "Variance of RLC Buffer Payload for each RB" is set to TRUE:

4> include and set the IE "Variance of RLC Buffer Payload" to the variance of the Buffer Occupancy for this logical channel computed over the interval specified in the IE "Time Interval to take an average or a variance" (see [15]), rounded up to the next allowed value.

2> if the RB is mapped onto two logical channels:

3> if one logical channel is mapped onto transport channels on which the UE is supposed to report:

4> if the IE "RLC Buffer Payload for each RB" is set to TRUE:

5> include and set the IE "RLC Buffers Payload" to the Buffer Occupancy value for this logical channel, rounded up to the next allowed value.

4> if the IE "Average of RLC Buffer Payload for each RB" is set to TRUE:

5> include and set the IE "Average of RLC Buffer Payload" to the Buffer Occupancy for this logical channel averaged over the interval specified in the IE "Time Interval to take an average or a variance" (see [15]), rounded up to the next allowed value.

4> if the IE "Variance of RLC Buffer Payload for each RB" is set to TRUE:

5> include and set the IE "Variance of RLC Buffer Payload" to the variance of the Buffer Occupancy for this logical channel computed over the interval specified in the IE "Time Interval to take an average or a variance" (see [15]), rounded up to the next allowed value.

3> if both logical channels are mapped onto transport channels on which the UE is supposed to report:

4> if the IE "RLC Buffer Payload for each RB" is set to TRUE:

5> include and set the IE "RLC Buffers Payload" to the sum of the Buffer Occupancy values for the two logical channels, rounded up to the next allowed value.

4> if the IE "Average of RLC Buffer Payload for each RB" is set to TRUE:

5> include and set the IE "Average of RLC Buffer Payload" to the sum of the Buffer Occupancy for the two logical channels averaged over the interval specified in the IE "Time Interval to take an average or a variance" (see [15]) and rounded up to the next allowed value.

4> if the IE "Variance of RLC Buffer Payload for each RB" is set to TRUE:

5> include and set the IE "Variance of RLC Buffer Payload" to the variance of the sum of the Buffer Occupancy for the two logical channels, computed over the interval specified in the IE "Time Interval to take an average or a variance" (see [15]) and rounded up to the next allowed value.

### 14.4.2.1 Reporting event 4 A: Transport Channel Traffic Volume becomes larger than an absolute threshold




**Figure 14.4.2.1-1: Event triggered report when Transport Channel Traffic Volume becomes larger than a certain threshold**

If the monitored Transport Channel Traffic Volume (TCTV) [15] is larger than an absolute threshold at TVM setup or modify, or is larger at activation of the monitored transport channel, or becomes larger than an absolute threshold while the event is configured i.e. if TCTV>Reporting threshold, this event could trigger a report. The event could be triggered again only if TCTV becomes smaller than the Reporting threshold and later TCTV>Reporting threshold is verified again.

### 14.4.2.2 Reporting event 4 B: Transport Channel Traffic Volume becomes smaller than an absolute threshold




**Figure 14.4.2.1-2: Event triggered report when Transport Channel Traffic Volume becomes smaller than certain threshold**

If the monitored Transport Channel Traffic Volume (TCTV) [15] is smaller than an absolute threshold at TVM setup or modify, or is smaller at activation of the monitored transport channel, or becomes smaller than an absolute threshold while the event is configured i.e. if TCTV<Reporting threshold, this event could trigger a report. The event could be

triggered again only if TCTV becomes bigger than the Reporting threshold and later TCTV<Reporting threshold is verified again.

## 14.4.3 Traffic volume reporting mechanisms

Traffic volume measurement triggering could be associated with both a *time-to-trigger* and a *pending time after trigger*. The time-to-trigger is used to get time domain hysteresis, i.e. the condition must be fulfilled during the time-to-trigger time before a report is sent. Pending time after trigger is used to limit consecutive reports when one traffic volume measurement report already has been sent and enables periodic reporting while the TCTV remains above(4a) or below(4b) the threshold. This is described in detail below.

### 14.4.3.1 Pending time after trigger

This timer is started in the UE when a measurement report has been triggered by a given event. The UE is then forbidden to send new measurement reports triggered by the same event during this time period. Instead the UE waits until the timer has expired. If the Transport Channel Traffic Volume [15] is still above the threshold for event 4a, or below the threshold for event 4b when the timer expires, the UE sends a new measurement report, and the timer is restarted. Otherwise it waits for a new triggering.




**Figure 14.4.3.1-1: Pending time after trigger limits the amount of consecutive measurement reports**

Figure 14.4.3.1-1 shows that by increasing the pending time after trigger a triggered second event does not result in a measurement report. The figure assumes absence of the IE "Time to trigger".

### 14.4.3.2 Time-to-trigger

The timer is started in the UE when the Transport Channel Traffic Volume triggers the event. If the TCTV crosses the threshold before the timer expires, the timer is stopped. If the timer expires then a report is triggered.




**Figure 14.4.3.1-2: Time-to-trigger is used to achieve time hysteresis**

Figure 14.4.3.1-2 shows that by increasing the time-to-trigger the report is not triggered.

## 14.4.4 Interruption of user data transmission

By including the IE "Tx Interruption after trigger", a UE in CELL_FACH state may be instructed by the UTRAN to prohibit transmission of user data on the RACH temporarily after a measurement report has been triggered.

The UE shall only resume transmission of user data, when:

1> it receives from the UTRAN a message allocating a dedicated physical channel, leading to the transition to CELL_DCH state; or

1> the time period indicated by the IE "Tx Interruption after trigger" elapses.

The transmission on signalling radio bearers shall not be interrupted.

# 14.5 Quality Measurements

## 14.5.1 Quality reporting measurement quantities

For quality measurements, the following measurement quantities are used:

1. Downlink transport channel BLER
2. Timeslot SIR (TDD only)

## 14.5.2 Quality reporting events

When one measurement identity corresponds to multiple quality events for the same transport channel, the UE behaviour is not specified.

### 14.5.2.1 Reporting event 5A: A predefined number of bad CRCs is exceeded

When this event is ordered by UTRAN in a measurement control message, the UE shall send a measurement report when the amount of bad CRCs during a predefined sliding window exceeds a predefined number.

The following three parameters are used in the scheme:

- **Total CRC** = the length of the sliding window over which the number of bad CRCs are counted.

- **Bad CRC** = the number of bad CRC that is required within the latest "Total CRC" received CRCs for the event to be triggered.
- **Pending after trigger** = a new event can not be triggered until "Pending after trigger" CRCs have been received,

When a DCH is established, the UE shall begin to count the number of bad CRCs within the last "Total CRC" received CRCs. No event can be triggered until at least "Total CRC" CRCs have been received. For each new received CRC, the UE shall compare the number of bad CRCs within the latest "Total CRC" received CRCs with the parameter "Bad CRC". An event shall be triggered if the number of bad CRCs is equal or larger than "Bad CRC".

At the time when the event is triggered a pending time after trigger timer is started with the length of "Pending after trigger" CRCs. A new event can not be triggered until Pending after trigger" CRCs have been received. When Pending after trigger" CRCs have been received the event evaluation start again and a new event can be triggered.




**Figure 14.5.2.1-1: Event triggered CRC error reporting**

# 14.6 UE internal measurements

## 14.6.1 UE internal measurement quantities

For UE internal measurements the following measurement quantities exist:

1. UE transmission (Tx) power, for TDD measured on a timeslot basis.
2. UE received signal strength power (RSSI).
3. UE Rx-Tx time difference (FDD only).
4. $T_{ADV}$ (1.28 Mcps TDD).

## 14.6.2 UE internal measurement reporting events

In the Measurement reporting criteria field in the Measurement Control messages, the UTRAN notifies the UE of which events should trigger a measurement report. UE internal measurement reporting events that can trigger a report are given below. The reporting events are marked with vertical arrows in the figures below. All events can be combined with time-to-trigger.

NOTE: The reporting events are numbered 6A, 6B, 6C,.. where 6 denotes that the event belongs to the type UE internal measurements.

When one measurement identity corresponds to multiple internal events with identical event identities, the UE behaviour is not defined.

### 14.6.2.1 Reporting event 6A: The UE Tx power becomes larger than an absolute threshold

When a UE internal measurement configuring event 6a is set up, the UE shall:

1> create a variable TRIGGERED_6A_EVENT related to that measurement, which shall initially be set to FALSE;

1> delete this variable when the measurement is released.

When this event is ordered by UTRAN in a measurement control message, the UE shall:

1> if the UE Tx power (for TDD within a single TS) is greater than the value in IE "UE Transmitted Power Tx power threshold" stored for this event in the variable MEASUREMENT_IDENTITY for a time period indicated by the IE "time_to_trigger":

2> if the variable TRIGGERED_6A_EVENT is set to FALSE:

3> set the variable TRIGGERED_6A_EVENT to TRUE;

3> send a measurement report with IEs set as below:

4> set in "UE internal measurement event results": "UE internal event identity" to "6a";

4> set the IE "measured results" and the IE "additional measured results" according to 8.4.2.

1> if the variable TRIGGERED_6A_EVENT is set to TRUE and if the UE Tx power (for TDD within a single TS) is less or equal the value in IE "UE Transmitted Power Tx power threshold" stored for this event in the variable MEASUREMENT_IDENTITY:

2> set the variable TRIGGERED_6A_EVENT to FALSE.

#### 14.6.2.2 Reporting event 6B: The UE Tx power becomes less than an absolute threshold

When a UE internal measurement configuring event 6b is set up, the UE shall:

1> create a variable TRIGGERED_6B_EVENT related to that measurement, which shall initially be set to FALSE;

1> delete this variable when the measurement is released.

When this event is ordered by UTRAN in a measurement control message, the UE shall:

1> if the UE Tx power (for TDD within a single TS) is less than the value in IE "UE Transmitted Power Tx power threshold" stored for this event in the variable MEASUREMENT_IDENTITY for a time period indicated by the IE "time_to_trigger":

2> if the variable TRIGGERED_6B_EVENT is set to FALSE:

3> set the variable TRIGGERED_6B_EVENT to TRUE;

3> send a measurement report with IEs set as below:

4> set in "UE internal measurement event results": "UE internal event identity" to "6b";

4> set the IE "measured results" and the IE "additional measured results" according to 8.4.2.

1> if the variable TRIGGERED_6B_EVENT is set to TRUE and if the UE Tx power (for TDD within a single TS) is greater or equal the value in IE "UE Transmitted Power Tx power threshold" stored for this event in the variable MEASUREMENT_IDENTITY:

2> set the variable TRIGGERED_6B_EVENT to FALSE.




**Figure 14.6.2.2-1: Event-triggered measurement reports when the UE Tx power becomes larger or less than absolute thresholds**

### 14.6.2.3 Reporting event 6C: The UE Tx power reaches its minimum value

When a UE internal measurement configuring event 6c is set up, the UE shall:

1> create a variable TRIGGERED_6C_EVENT related to that measurement, which shall initially be set to FALSE;

1> delete this variable when the measurement is released.

When this event is ordered by UTRAN in a measurement control message, the UE shall:

1> if the UE Tx power is equal its minimum value (for TDD its minimum value on a single TS) for a time period indicated by the IE "time_to_trigger":

2> if the variable TRIGGERED_6C_EVENT is set to FALSE:

3> set the variable TRIGGERED_6C_EVENT to TRUE;

3> send a measurement report with IEs set as below:

4> set in "UE internal measurement event results": "UE internal event identity" to "6c";

4> set the IE "measured results" and the IE "additional measured results" according to 8.4.2.

1> if the variable TRIGGERED_6C_EVENT is set to TRUE and if the UE Tx power is greater than its minimum value:

2> set the variable TRIGGERED_6C_EVENT to FALSE.




**Figure 14.6.2.3-1: Event-triggered measurement report when the UE Tx power reaches its minimum value**

### 14.6.2.4 Reporting event 6D: The UE Tx power reaches its maximum value

When a UE internal measurement configuring event 6d is set up, the UE shall:

1> create a variable TRIGGERED_6D_EVENT related to that measurement, which shall initially be set to FALSE;

1> delete this variable when the measurement is released.

When this event is ordered by UTRAN in a measurement control message, the UE shall:

1> if the UE Tx power equals the maximum UE TX power (for TDD its maximum value on a single TS) for a time period indicated by the IE "time_to_trigger":

2> if the variable TRIGGERED_6D_EVENT is set to FALSE:

3> set the variable TRIGGERED_6D_EVENT to TRUE;

3> send a measurement report with IEs set as below:

4> set in "UE internal measurement event results": "UE internal event identity" to "6d";

4> set the IE "measured results" and the IE "additional measured results" according to 8.4.2.

1> if the variable TRIGGERED_6D_EVENT is set to TRUE and if the UE Tx power is less than the maximum UE TX power:

2> set the variable TRIGGERED_6D_EVENT to FALSE.

NOTE: The maximum UE TX power is defined in subclause 8.6.6.8.




**Figure 14.6.2.4-1: Event-triggered report when the UE Tx power reaches its maximum value**

### 14.6.2.5 Reporting event 6E: The UE RSSI reaches the UE's dynamic receiver range

When a UE internal measurement configuring event 6e is set up, the UE shall:

1> create a variable TRIGGERED_6E_EVENT related to that measurement, which shall initially be set to FALSE;

1> delete this variable when the measurement is released.

When this event is ordered by UTRAN in a measurement control message, the UE shall:

1> if the UE RSSI is greater or equal the UE's dynamic receiver range for a time period indicated by the IE "time_to_trigger":

2> if the variable TRIGGERED_6E_EVENT is set to FALSE:

3> set the variable TRIGGERED_6E_EVENT to TRUE;

3> send a measurement report with IEs set as below:

4> set in "UE internal measurement event results": "UE internal event identity" to "6e";

4> set the IE "measured results" and the IE "additional measured results" according to subclause 8.4.2.

1> if the variable TRIGGERED_6E_EVENT is set to TRUE and if the UE RSSI is less than the UE's dynamic receiver range:

2> set the variable TRIGGERED_6E_EVENT to FALSE.

### 14.6.2.6 Reporting event 6F (FDD): The UE Rx-Tx time difference for a RL included in the active set becomes larger than an absolute threshold

When a UE internal measurement configuring event 6f is set up, the UE shall:

1> create a variable TRIGGERED_6F_EVENT related to that measurement, which shall initially be set to FALSE for each RL;

1> delete this variable when the measurement is released.

When this event is ordered by UTRAN in a measurement control message, the UE shall:

1> if the UE Rx-Tx time difference for a RL included in the active set is greater than the value in the IE "UE Rx-Tx time difference threshold" stored for this event in the variable MEASUREMENT_IDENTITY for a time period indicated by the IE "time_to_trigger":

2> if the variable TRIGGERED_6F_EVENT is set to FALSE for this RL:

3> set the variable TRIGGERED_6F_EVENT to TRUE for this RL;

3> send a measurement report with IEs set as below:

4> set in "UE internal measurement event results": "UE internal event identity" to "6f";

4> set the IE "measured results" and the IE "additional measured results" according to subclause 8.4.2.

1> if the variable TRIGGERED_6F_EVENT is set to TRUE for a RL and if the UE RX-Tx time difference for this RL included in the active set is less than or equal to the value in the IE "UE Rx-Tx time difference threshold" stored for this event in the variable MEASUREMENT_IDENTITY:

2> set the variable TRIGGERED_6F_EVENT to FALSE for this RL.

### 14.6.2.6a Reporting event 6F (1.28 Mcps TDD): The time difference indicated by $T_{ADV}$ becomes larger than an absolute threshold

When a UE internal measurement configuring event 6f is set up, the UE shall:

1> create a variable TRIGGERED_6F_EVENT related to that measurement, which shall initially be set to the currently measured $T_{ADV}$;

1> delete this variable when the measurement is released.

When this event is ordered by UTRAN in a measurement control message, the UE shall:

1> if the absolute value of the difference between the measured $T_{ADV}$ and the $T_{ADV}$ stored in the variable TRIGGERED_6F_EVENT is greater than the predefined threshold configured with the IE "$T_{ADV}$ Threshold" for this event in the variable MEASUREMENT_IDENTITY for a time period indicated by the IE "time_to_trigger":

2> set the variable TRIGGERED_6F_EVENT to the currently measured $T_{ADV}$;

2> send a measurement report with IEs set as below:

3> set the IE "$T_{ADV}$" to the measured value, and the IE "SFN" to the SFN during which the latest measurement was performed, in the IE "$T_{ADV}$ Info";

3> set the IE "measured results" and the IE "additional measured results" according to subclause 8.4.2.

### 14.6.2.7 Reporting event 6G: The UE Rx-Tx time difference for a RL included in the active set becomes less than an absolute threshold

When a UE internal measurement configuring event 6g is set up, the UE shall:

1> create a variable TRIGGERED_6G_EVENT related to that measurement, which shall initially be set to FALSE for each RL;

1> delete this variable when the measurement is released.

When this event is ordered by UTRAN in a measurement control message, the UE shall:

1> if the UE Rx-Tx time difference for a RL included in the active set is less than the value in IE "UE Rx-Tx time difference threshold" stored for this event in the variable MEASUREMENT_IDENTITY for a time period indicated by the IE "time_to_trigger":

2> if the variable TRIGGERED_6G_EVENT is set to FALSE for this RL:

3> set the variable TRIGGERED_6G_EVENT to TRUE for this RL;

3> send a measurement report with IEs set as below:

4> set in "UE internal measurement event results": "UE internal event identity" to "6g";

4> set the IE "measured results" and the IE "additional measured results" according to subclause 8.4.2.

1> if the variable TRIGGERED_6G_EVENT is set to TRUE for a RL and if the UE RX-Tx time difference for this RL included in the active set is greater or equal the value in IE "UE Rx-Tx time difference threshold" stored for this event in the variable MEASUREMENT_IDENTITY:

2> set the variable TRIGGERED_6G_EVENT to FALSE for this RL.

# 14.7 UE positioning measurements

## 14.7.1 UE positioning measurement quantities

The quantity to measure for UE positioning is dependent on the positioning method and the method type requested in the IE "UE positioning reporting quantity".

1 SFN-SFN observed time difference type 2, optional.

2 Rx-Tx time difference type 2, optional.

3 GPS timing of cell fames, optional.

The definition of other GPS measurements is not within the scope of this specification.

## 14.7.2 Void

## 14.7.3 UE positioning reporting events

In the IE "UE positioning reporting criteria" in the Measurement Control messages, the UTRAN notifies the UE of which events should trigger a measurement report. UE positioning reporting events that can trigger a report are given below. The content of the measurement report is dependant on the positioning method and method type requested in the IE "UE positioning reporting quantity" of the Measurement Control message and is described in detail in [18].

When one measurement identity corresponds to multiple positioning events with identical event identities, the UE behaviour is not defined.

### 14.7.3.1 Reporting Event 7a: The UE position changes more than an absolute threshold

This event is used for UE-based methods only.

When this event is ordered by UTRAN in a measurement control message, the UE shall:

1> if the UE changes its position compared to the last reported position by more than the threshold defined by the IE "Threshold position change"; or

1> if no position has been reported since the event was configured and the UE changes its position compared to the first position estimate obtained after the event was configured by more than the threshold defined by the IE "Threshold position change":

2> send a measurement report as specified in subclause 8.6.7.19.1b;

2> if the value of IE "Amount of Reporting" in variable MEASUREMENT_IDENTITY for this event is greater than zero:

3> decrease IE "Amount of Reporting" in variable MEASUREMENT_IDENTITY for this event by one.

2> if the value of IE "Amount of Reporting" in variable MEASUREMENT_IDENTITY for this event is equal to zero:

3> delete this event from the list of events in variable MEASUREMENT_IDENTITY.

1> if the UE is unable to evaluate the event because a position measurement is not available:

2> not send a report.

#### 14.7.3.2 Reporting Event 7b: SFN-SFN measurement changes more than an absolute threshold

When this event is ordered by UTRAN in a measurement control message, the UE shall:

1> send a measurement report when the SFN-SFN time difference measurement type 2 of any measured cell changes more than the threshold defined by the IE "Threshold SFN-SFN change"; and

1> if UTRAN set IE "Method Type" in "UE positioning reporting quantity" in the MEASUREMENT CONTROL message to "UE-based":

2> act as specified in subclause 8.6.7.19.1b.

1> if UTRAN set IE "Method Type" in "UE positioning reporting quantity" in the MEASUREMENT CONTROL message to "UE-assisted":

2> act as specified in subclause 8.6.7.19.1a.

1> if UTRAN set IE "Method Type" in "UE positioning reporting quantity" in the MEASUREMENT CONTROL message to "UE-assisted preferred but UE-based allowed" or "UE-based preferred but UE-assisted allowed":

2> the UE may choose to act according to either subclause 8.6.7.19.1a or 8.6.7.19.1b.

1> if the value of IE "Amount of Reporting" in variable MEASUREMENT_IDENTITY for this event is greater than zero:

2> decrease IE "Amount of Reporting" in variable MEASUREMENT_IDENTITY for this event by one.

1> if the value of IE "Amount of Reporting" in variable MEASUREMENT_IDENTITY for this event is equal to zero:

2> delete this event from the list of events in variable MEASUREMENT_IDENTITY.

#### 14.7.3.3 Reporting Event 7c: GPS time and SFN time have drifted apart more than an absolute threshold

When this event is ordered by UTRAN in a measurement control message, the UE shall:

1> send a measurement report when the GPS Time Of Week and the SFN timer have drifted apart more than the threshold defined by the IE "Threshold SFN-GPS TOW"; and

1> if UTRAN set IE "Method Type" in "UE positioning reporting quantity" in the MEASUREMENT CONTROL message to "UE based":

2> act as specified in subclause 8.6.7.19.1b.

1> if UTRAN set IE "Method Type" in "UE positioning reporting quantity" in the MEASUREMENT CONTROL message to "UE assisted":

2> act as specified in subclause 8.6.7.19.1a.

1> if UTRAN set IE "Method Type" in "UE positioning reporting quantity" in the MEASUREMENT CONTROL message to "UE assisted preferred but UE based allowed" or "UE based preferred but UE assisted allowed":

2> act as specified in subclause 8.6.7.19.1a or in subclause 8.6.7.19.1b depending on the method type chosen by the UE.

1> if the value of IE "Amount of Reporting" in variable MEASUREMENT_IDENTITY for this event is greater than zero:

2> decrease IE "Amount of Reporting" in variable MEASUREMENT_IDENTITY for this event by one.

1> if the value of IE "Amount of Reporting" in variable MEASUREMENT_IDENTITY for this event is equal to zero:

2> delete this event from the list of events in variable MEASUREMENT_IDENTITY.

# 14.8 Void

# 14.9 Downlink power control

## 14.9.1 Generalities

This function is implemented in the UE in order to set the SIR target value on each CCTrCH used for the downlink power control. This SIR value shall be adjusted according to an autonomous function in the UE in order to achieve the same measured quality as the quality target set by UTRAN. The quality target is set as the transport channel BLER value for each transport channel as signalled by UTRAN.

When transport channel BLER is used the UE shall run a quality target control loop such that the quality requirement is met for each transport channel, which has been assigned a BLER target.

The UE shall set the SIR target when the physical channel has been set up or reconfigured. It shall not increase the SIR target value before the power control has converged on the current value. The UE may estimate whether the power control has converged on the current value, by comparing the averaged measured SIR to the SIR target value.

NOTE: The power control function for F-DPCH is specified in [29].

## 14.9.2 Downlink power control in compressed mode

In compressed mode, the target SIR needs to be changed in several frames compared to normal mode. For this purpose, four values DeltaSIR1, DeltaSIRafter1, DeltaSIR2 and DeltaSIRafter2 are signalled by the UTRAN to the UE (see subclause 10.2.9).

For each frame, the target SIR offset during compressed mode, compared to normal mode is:

$$\Delta SIR = \max(\Delta SIR1_compression, \ldots, \Delta SIRn_compression) + \Delta SIR1_coding + \Delta SIR2_coding$$

where n is the number of TTI lengths for all TrChs of the CCTrCh, $F_i$ is the length in number of frames of the i-th TTI and where ΔSIR_coding fulfils:

- ΔSIR1_coding= DeltaSIR1 if the start of the first transmission gap in the transmission gap pattern is within the current frame.
- ΔSIR1_coding= DeltaSIRafter1 if the current frame just follows a frame containing the start of the first transmission gap in the transmission gap pattern.
- ΔSIR2_coding= DeltaSIR2 if the start of the second transmission gap in the transmission gap pattern is within the current frame.
- ΔSIR2_coding= DeltaSIRafter2 if the current frame just follows a frame containing the start of the second transmission gap in the transmission gap pattern.
- ΔSIR1_coding= 0 and ΔSIR2_coding= 0 otherwise.

and ΔSIRi_compression is defined by :

- ΔSIRi_compression = 3 dB for downlink frames compressed by reducing the spreading factor by 2.
- ΔSIRi_compression = 0 dB in all other cases.

Several compressed mode patterns applying to the same frames should be avoided as much as possible.

In case several compressed mode patterns are used simultaneously, a ΔSIR offset is computed for each compressed mode pattern and the sum of all ΔSIR offsets is applied to the frame.

# 14.10 Calculated Transport Format Combination

The Calculated Transport Format Combination (CTFC) is a tool for efficient signalling of transport format combinations.

Let *I* be the number of transport channels that are included in the transport format combination. For DCHs, all configured DCHs are included in the transport format combination. Each transport channel $TrCH_i$, $i = 1, 2, \ldots, I$, has $L_i$ transport formats, i.e. the transport format indicator $TFI_i$ can take $L_i$ values, $TFI_i \in \{0,1,2,...,L_i - 1\}$.

*Define* $P_i = \prod_{j=0}^{i-1} L_j$ *, where i = 1, 2, ..., I, and* $L_0 = 1$.

Let $TFC(TFI_1, TFI_2, \ldots, TFI_I)$ be the transport format combination for which $TrCH_1$ has transport format $TFI_1$, $TrCH_2$ has transport format $TFI_2$, etc. The corresponding $CTFC(TFI_1, TFI_2, \ldots, TFI_I)$ is then computed as:

$$CTFC(TFI_1, TFI_2, \ldots, TFI_I) = \sum_{i=1}^{I} TFI_i \cdot P_i .$$

For FACH and PCH transport channels, "$TrCH_1$" corresponds to the transport channel listed at the first position in IE "FACH/PCH information" in IE "Secondary CCPCH System Information", "$TrCH_2$" corresponds to the transport channel listed at the second position in IE "FACH/PCH information" and so on.

For all other transport channels in FDD and for all configured transport channels of the same transport channel type (i.e. DCH, DSCH, USCH) in TDD, "$TrCH_1$" corresponds to the transport channel having the lowest transport channel identity in the transport format combination mapped to the TFCI field. "$TrCH_2$" corresponds to the transport channel having the next lowest transport channel identity, and so on.

## 14.10.1 Default TFCS for MBMS

### 14.10.1.1 S-CCPCH configuration including a FACH carrying MSCH

In case the S-CCPCH configuration includes a FACH carrying MSCH, the default TFCS is defined according to the following:

Let TrCH 1 be the FACH carrying MSCH, TrCH 2 be the first TrCH carrying MTCH listed in the IE "TrCh information list", TrCH 3 be the second TrCH carrying MTCH listed in the IE "TrCh information list" etc. and let TrCH I be the last TrCH carrying MTCH listed in the IE "TrCh information list".

Each transport channel $TrCH_i$, $i = 1, 2, \ldots, I$, has $L_i$ transport formats, i.e. the transport format indicator $TFI_i$ can take $L_i$ values.

Each transport format combination set is defined by the transport formats of each transport channel mapped on this S-CCPCH:

$TFC = (TFI_1, TFI_2, \ldots, TFI_I)$.

The "MBMS implicit TFCS" contains then the following set of TFCs:

$$\begin{aligned} TFCS = \{&(0,0,\ldots,0),(0,1,\ldots,0),\ldots,(0,L_2,\ldots,0),(0,0,1,\ldots,0),\ldots,(0,0,L_3,\ldots,0),\ldots,(0,0,0,\ldots,1),\ldots,(0,0,0,\ldots,L_I),\\ &(1,0,\ldots,0),(1,1,\ldots,0),\ldots,(1,L_2,\ldots,0),(1,0,1,\ldots,0),\ldots,(1,0,L_3,\ldots,0),\ldots,(1,0,0,\ldots,1),\ldots,(1,0,0,\ldots,L_I),\\ &(2,0,\ldots,0),\ldots,(L_1,0,\ldots,0)\} \end{aligned}$$

### 14.10.1.2 S-CCPCH configuration not including a FACH carrying MSCH

In case the S-CCPCH configuration does not include a FACH carrying MSCH, the default TFCS is defined according to the following:

Let TrCH 1 be the first TrCH listed in the IE "TrCh information list", TrCH 2 be the second TrCH listed in the IE "TrCh information list" etc. and let TrCH I be the last TrCH listed in the IE "TrCh information list".

Each transport channel $TrCH_i$, $i$ = 1, 2, …, $I$, has $L_i$ transport formats, i.e. the transport format indicator $TFI_i$ can take $L_i$ values.

Each transport format combination set is defined by the transport formats of each transport channel mapped on this S-CCPCH:

$TFC = (TFI_1, TFI_2, …, TFI_I)$.

The "MBMS implicit TFCS" contains then the following set of TFCs:

$$TFCS = \{(0,…,0), (1,…,0),…,(L_1,…,0),(0,1,…,0),…,(0,L_2,…,0),…,(0,0,…,1),…,(0,0,…,L_I)\}$$

# 14.11 UE autonomous update of virtual active set on non-used frequency (FDD only)

In the text that follows:

- a "non-used frequency" is a frequency that the UE has been ordered to measure upon but is not used for the connection. A "used frequency" is a frequency that the UE has been ordered to measure upon and is also currently used for the connection;
- a "non-used frequency (resp. cell) considered in an inter-frequency measurement" shall be understood as a non-used frequency (resp. cell) included in the list of cells pointed at in the IE "cells for measurement" if it was received for that measurement, or otherwise as a non-used frequency (resp. cell) included in the "Inter-frequency cell info" part of the variable CELL_INFO_LIST.

For event-triggered inter frequency measurements it is possible to use intra-frequency measurement reporting events for support of maintenance of an active set associated with a non-used frequency considered in that measurement, a "virtual active set" and used in the evaluation of the frequency quality estimates. The "initial virtual active set" for a frequency is the virtual active set that is associated to that frequency just after a message was received that sets up or modifies the inter-frequency measurement.

The way the virtual active sets are initiated and updated for the non-used frequencies considered in an inter-frequency measurement is described in the two subclauses below.

The UE shall support a single virtual active set per non-used frequency.

The virtual active set is not initialised and maintained for an inter frequency measurement with periodic reporting. A virtual active set initialised and maintained by another inter-frequency measurement does not affect reporting of the periodic inter-frequency measurement.

## 14.11.1 Initial virtual active set

If the UE receives a MEASUREMENT CONTROL message that sets up or modifies an inter-frequency measurement and includes the IE "Inter-frequency set update"; or

If at least one cell can first be measured on a currently empty virtual active set (see subclause 14.11.2) the UE shall:

1> for each non-used frequency $F_i$ considered in the measurement where cells can be measured:

2> if event 1a is configured for the used frequency in an intra-frequency measurement:

3> include in the initial virtual active set the $N_i$ cells that have either the greatest downlink $E_c/N_0$ or the greatest downlink RSCP after despreading or the lowest pathloss (the measurement quantity to be used is determined by the IE "intra-frequency measurement quantity" of the intra-frequency measurement from which the event 1a configuration is taken), among the cells on frequency $F_i$ considered in that inter-frequency measurement, where:

$$N_i = \min(N_{1a} \ , \ N_{Cells\ Fi}) \text{ if } N_{1a} \neq 0 \text{ and } N_i = N_{Cells\ Fi} \text{ otherwise.}$$

where:

$N_{1a}$ is the "Reporting deactivation threshold" included in the intra-frequency measurement for the first event 1a defined in the intra-frequency measurement with the lowest identity at the time the inter-frequency measurement was received with the IE "Inter-frequency set update" present.

$N_{Cells\ Fi}$ is the number of cells on frequency $F_i$ considered in that inter-frequency measurement.

2> else:

$$N_i = N_{Cells\ Fi}$$

where:

$N_{Cells\ Fi}$ is the number of cells on frequency $F_i$ considered in that inter-frequency measurement.

NOTE1: The UE initialises the virtual active set with up to the maximum number of inter-frequency cells supported by the UE as defined in [19].

NOTE2: If the UTRAN configures more than one measurement using events 2A, 2B, 2C or 2E the UE measurement capabilities may be exceeded due to the necessary copying of 1A, 1B, 1C criteria. To avoid this the UTRAN may configure one measurement to apply to multiple frequencies so that the 1A, 1B, and 1C criteria will only be copied once.

NOTE3: After a hard handover (see subclause 8.3.5), if the MEASUREMENT CONTROL message that restarts an inter-frequency measurement using the virtual active set does not include the IE "Inter-frequency set update", the UE behaviour regarding the virtual active set is not specified.

### 14.11.2 Virtual active set update during an inter-frequency measurement

For an inter-frequency measurement, the UE shall:

1> apply the events of type 1a, 1b and 1c that were defined for the used frequency in other stored measurements of type "intra-frequency" at the time the inter-frequency measurement was last received with the IE "Inter-frequency set update" present; and

1> update the virtual active set for the non-used frequencies considered in that measurement according to the following rules:

2> if several events of type 1a (resp. 1b,1c) were defined for the used frequency when the inter-frequency measurement was last received with the IE "Inter-frequency set update" present, only the first 1a event (resp 1b, 1c) that was defined in the measurement with the lowest measurement identity shall apply to the non-used frequencies;

2> all the cells considered in the inter-frequency measurements shall be able to affect the reporting range for event 1a and 1b. (i.e. the IE "Cells forbidden to affect reporting range" possibly stored for the intra-frequency measurements on the used frequency does not apply to the non-used frequencies considered in the inter-frequency measurement);

2> the IEs "amount of reporting" and "reporting interval" that were stored for the intra-frequency measurements on the used frequency shall not be considered if reports of the virtual active set updates are needed.

2> the measurement quantity and filter coefficient to be used is determined by the IE "intra-frequency measurement quantity" of the intra-frequency measurement from which the intra-frequency event configuration configuration is taken.

NOTE: If the measurement quantity and filter coefficients to be used differ for the 1a, 1b, and 1c events applied then the UE behaviour is unspecified.

1> if event 1a is applicable to the non-used frequencies considered in the inter-frequency measurement, always only consider monitored cells that are not in the virtual active set for this event, and:

2> when this event is triggered (according to the criteria described in subclause 14.1.2.1) by a cell for a non-used frequency considered in that measurement:

3> if the "Reporting deactivation threshold" is equal to 0, or if the "Reporting deactivation threshold" is different from 0 and the number of cells included in the virtual active set for that frequency is less than or equal to the "Reporting deactivation threshold":

4> add the primary CPICH that enters the reporting range to the "virtual active set".

2> if event 1b is applicable for the non-used frequencies considered in that inter-frequency measurement, always only consider cells in the virtual active set for this event, and when this event is triggered (according to the criteria described in subclause 14.1.2.2) by a cell for a non-used frequency considered in that measurement:

3> if the number of cells included in the virtual active set is greater than 1:

4> remove the primary CPICH that leaves the reporting range from the "virtual active set".

2> if event 1c is applicable for the non-used frequencies considered in that inter-frequency measurement, always only consider monitored cells for this event, and when this event is triggered (according to the criteria described in subclause 14.1.2.3) by a cell for a non-used frequency considered in that measurement:

3> if the "Reporting activation threshold" is equal to 0, or if the "Reporting activation threshold" is different from 0 and the number of cells included in the virtual active set for that frequency is greater than or equal to the "Reporting activation threshold":

4> rank all active and non-active primary CPICHs and take the *n* best cells to create a new "virtual active set", where *n* is the number of active primary CPICHs in the "virtual active set".

1> if Event 1a is not defined for the used frequency in other stored measurements of type "intra-frequency" at the time the inter-frequency measurement was set up:

2> the UE shall continuously update the virtual active set to consist of all cells on frequency $F_i$ considered in that inter-frequency measurement, without sending any corresponding measurement report.

NOTE: The UE needs to only update the virtual active set with up to the maximum number of interfrequency cells supported by the UE as defined in [19].

If none of the cells that are considered in the measurement on this frequency were measured, the UE may treat the virtual active set as empty and follow the appropriate initialisation procedured in subclause 14.11.1 when any relevant cell can first be measured.

If a cell is a member of the virtual active set and is removed from the variable CELL_INFO_LIST or removed from the list of cells pointed at by the IE "Cells for measurement" for the inter-frequency measurement then the UE shall remove the cell from the virtual active set.

If an inter-frequency measurement that initialised a virtual active set is released, then any virtual active set associated with this measurement shall also be released.

# 14.12 Provision and reception of RRC information between network nodes

## 14.12.0 General

In certain cases, e.g., when performing handover to UTRAN or when performing SRNC relocation, RRC information may need to be transferred between UTRAN nodes, between UTRAN and another RAT, between nodes within another RAT or between the UE and another RAT.

The RRC information exchanged between network nodes or between the UE and another RAT is typically transferred by means of RRC information containers. An RRC information container is a self-contained and extensible RRC information unit that may be used to transfer a number of different RRC messages, one at a time. As stated before, RRC information containers may be used to transfer RRC messages across interfaces other than the Uu interface. The RRC messages that may be included in RRC information containers have similar characteristics as the RRC messages that are transferred across the Uu interface.

The RRC messages that are sent to/ from the UE, e.g., HANDOVER TO UTRAN COMMAND, INTER RAT HANDOVER INFO are covered by (sub)clauses 8, 9, 10, 11.0-11.4 and 12 of this specification. The following subclauses concern RRC messages exchanged between network nodes.

In future versions of this specification, it is possible to extend the RRC messages transferred across interfaces other than Uu. For these RRC messages the same extension mechanism applies as defined for RRC messages transferred across the Uu interface, as is specified in subclause 10.1, i.e., both critical and non-critical extensions may be added.

The transfer syntax for RRC information containers and RRC messages transferred between network nodes is derived from their ASN.1 definitions by use of Packed Encoding Rules, unaligned (X.691). It should be noted that the encoder adds final padding to achieve octet alignment. The resulting octet string is, carried in a container, transferred between the network nodes.

When using a separate RRC information container for each endpoint, the receiving RRC protocol entity is able to interpret the received container; this means that the receiver need not take into account information about the (network interface) message used in transferring the container.

The following encoding rules apply in addition to what has been specified in X.691 [49]:

1> When a bit string value is placed in a bit-field as specified in 15.6 to 15.11 in [11], the leading bit of the bit string value shall be placed in the leading bit of the bit-field, and the trailing bit of the bit string value shall be placed in the trailing bit of the bit-field.

NOTE: The terms "leading bit" and "trailing bit" are defined in ITU-T Rec. X.680 | ISO/IEC 8824-1. When using the "bstring" notation, the leading bit of the bit string value is on the left, and the trailing bit of the bit string value is on the right.

## 14.12.0a General error handling for RRC messages exchanged between network nodes

The error handling for RRC messages that are exchanged between network nodes applies the same principles as defined for other RRC messages.

Although the same principles apply for network nodes receiving unknown, unforeseen and erroneous RRC messages received in RRC information containers, the notification of the error should be done in a different manner, as specified in the following:

The network node receiving an invalid RRC message from another network node should:

1> if the received RRC message was unknown, unforeseen or erroneous:

2> prepare an RRC FAILURE INFO message, including the IE "Failure cause" set to "Protocol error" and the IE "Protocol error information" including an IE "Protocol error cause" which should be set as follows:

3> to "ASN.1 violation or encoding error" upon receiving an RRC message for which the encoded message does not result in any valid abstract syntax value;

3> to "Message type non-existent or not implemented" upon receiving an unknown RRC message type;

3> to "Message extension not comprehended" upon receiving an RRC message including an undefined critical message extension;

3> to "Information element value not comprehended" upon receiving an RRC message including an mandatory IE for which no default value is defined and for which either the value is set to spare or for which the encoded IE does not result in a valid transfer syntax. The same applies for conditional IEs, for which the conditions for presence are met, the IE is present but has a value set to spare or for which the encoded IE does not result in a valid transfer syntax;

3> to "Information element missing" upon receiving an RRC information container with an absent conditional IE for which the conditions for presence are met.

1> if there was another failure to perform the operation requested by the received RRC message:

2> prepare an RRC FAILURE INFO message, including the IE "Failure cause" set to a value that reflects the failure cause.

1> send the RRC FAILURE INFO message to the network node from which the invalid RRC protocol information was received.

NOTE 1: The appropriate (failure) messages used across the network interfaces may not support the inclusion of a RRC information container. In this case, the information contained in the RRC FAILURE INFO message may need to be transferred otherwise e.g. by mapping to a cause value (e.g. a cause value in the RR-HANDOVER FAILURE message when there is a error associated with the RRC-HANDOVER TO UTRAN COMMAND message).

NOTE 2 In case the RRC procedure used to perform SRNS relocation fails e.g. due to non comprehension, the source RNC may notify the target RNC by including the diagnostics information (IEs "Protocol error" and "Protocol error information") in the "RRC message "SRNS Relocation" Info sent in the RRC information container" used for a subsequent relocation request.

## 14.12.1 RRC Information to target RNC

The RRC information container "RRC Information to target RNC" may either be sent from source RNC or from another RAT. In case of handover to UTRAN, this information originates from another RAT, while in case of SRNC relocation the RRC information originates from the source RNC. In case of handover to UTRAN, the RRC information transferred may provide UTRAN specific information, as defined in the INTER RAT HANDOVER INFO WITH INTER RAT CAPABILITIES message, that the target RNC needs when preparing the handover command message. In case of SRNC relocation and handover/cell reselection from GERAN *Iu mode*, the RRC information transferred specifies the configuration of RRC and the lower layers it controls, e.g., including the radio bearer and transport channel configuration. It is used by the target RNC to initialise RRC and the lower layer protocols to facilitate SRNC relocation and handover/cell reselection from GERAN *Iu mode* in a manner transparent to the UE.

RFC 3095 CONTEXT INFO is used to transfer the compressor and decompressor context information of the RFC 3095 protocol from source RNC to target RNC.

| Information Element/Group Name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| CHOICE *case* | MP | | | At least one spare choice, Criticality: Reject, is needed | |
| >Handover to UTRAN | | | INTER RAT HANDOVER INFO WITH INTER RAT CAPABILITIES 14.12.4.1 | | |
| >SRNC relocation | | | SRNS RELOCATION INFO 14.12.4.2 | | |
| >RFC 3095 context info | | | RFC 3095 CONTEXT INFO 14.12.4.4 | | REL-5 |

## 14.12.2 RRC information, target RNC to source RNC

There are 2 possible cases for RNC relocation:

1. The UE is already under control of target RNC; and
2. The SRNC Relocation with Hard Handover (UE still under control of SRNC), but UE is moving to a location controlled by the target RNC (based on measurement information).

In case 1 the relocation is transparent to the UE and there is no "reverse" direction container. The SRNC just assigns the 'serving' function to the target RNC, which then becomes the Serving RNC.

In case 2 the relocation is initiated by SRNC, which also provides the RRC Initialisation Information to the target RNC. Base on this information, the target RNC prepares the Hard Handover Message ( "Physical channel reconfiguration" (subclause 8.2.6), "radio bearer establishment" (subclause 8.2.1), "Radio bearer reconfiguration" (subclause 8.2.2), "Radio bearer release" (subclause 8.2.3) or "Transport channel reconfiguration" (subclause 8.2.4).

In case 2 two possibilities are defined in order to transmit the relocation message from the target RNC to the source RNC which can be chosen by the source RNC by including or not including the IE "RB Id for handover message" in the IE "SRNS Relocation Info".

In case the IE "RB Id for handover message" has been received by the target RNC in the IE "SRNS Relocation Info", the target RNC should choose the IE "DL DCCH message" and include the DL DCCH message that should be transmitted transparently to the UE by the source RNC. In that case, the target RNC is integrity protecting the message if applicable.

If the target RNC did not receive the IE "RB Id for handover message" in the IE "SRNS Relocation Info" the target RNC should use another choice. In that case, the source RNC should integrity protect the message before transmitting it to the UE if applicable.

The source RNC then transmits the Handover Message to the UE, which then performs the handover.

In the successful case, the UE transmits an XXX COMPLETE message, using the new configuration, to the target RNC.

In case of failure, the UE transmits an XXX FAILURE, using the old configuration, to the source RNC and the RRC context remains unchanged (has to be confirmed and checked with the SRNS relocation procedure).

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| CHOICE *RRC message* | MP | | | At least one spare choice, Criticality: Reject, is needed |
| >RADIO BEARER SETUP | | | RADIO BEARER SETUP 10.2.31 | |
| >RADIO BEARER RECONFIGURATION | | | RADIO BEARER RECONFIGURATION 10.2.25 | |
| >RADIO BEARER RELEASE | | | RADIO BEARER RELEASE 10.2.28 | |
| >TRANSPORT CHANNEL RECONFIGURATION | | | TRANSPORT CHANNEL RECONFIGURATION 10.2.51 | |
| >PHYSICAL CHANNEL RECONFIGURATION | | | PHYSICAL CHANNEL RECONFIGURATION 10.2.20 | |
| >RRC FAILURE INFO | | | RRC FAILURE INFO 10.2.41a | |
| >DL DCCH message | | | OCTET STRING | |

## 14.12.3 Void

## 14.12.4 RRC messages exchanged between network nodes

### 14.12.4.0 HANDOVER TO UTRAN COMMAND

This RRC message is sent between network nodes to transfer the actual handover command including the details of the radio configuration to be used upon handover to UTRAN as compiled by the target RNC.

Direction: target RNC →source RAT

The message is exactly the same as the HANDOVER TO UTRAN COMMAND defined in subclause 10.2.16a.

### 14.12.4.0a INTER RAT HANDOVER INFO

This RRC message is sent between network nodes to transfer information relevant for the target RNC when preparing for handover to UTRAN.

Direction: source RNC/RAT→target RAT

The message is exactly the same as the INTER RAT HANDOVER INFO defined in subclause 10.2.16d

### 14.12.4.1 INTER RAT HANDOVER INFO WITH INTER RAT CAPABILITIES

This RRC message is sent between network nodes when preparing for an inter RAT handover to UTRAN.

Direction: source RAT→target RNC

| Information Element/Group Name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| **UE Information elements** | | | | |
| Predefined configuration status information | OP | | Predefined configuration status information 10.3.4.5a | |
| Predefined configuration status information compressed | OP | | Predefined configuration status information compressed 10.3.4.5b | REL-5 |
| UE security information | OP | | UE security information 10.3.3.42b | |
| UE security information2 | OP | | UE security information2 10.3.3.42c | REL-6 |
| UE Specific Behaviour Information 1 interRAT | OP | | UE Specific Behaviour Information 1 interRAT 10.3.3.52 | This IE shall not be included in this version of the protocol |
| UE capability container | OP | | | |
| >UE radio access capability | MP | | UE radio access capability 10.3.3.42 | |
| >UE radio access capability extension | MP | | UE radio access capability extension | Although this IE is not always required, the need has been set to MP to align with the ASN.1 |

| Information Element/Group Name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| | | | 10.3.3.42a | |
| UE radio access capability compressed | OP | | UE radio access capability compressed 10.3.3.42o | REL-5 |
| **Other Information elements** | | | | |
| UE system specific capability | OP | 1 to <maxSystemCapability> | | |
| >Inter-RAT UE radio access capability | MP | | Inter-RAT UE radio access capability 10.3.8.7 | |
| Failure cause | OP | | Failure cause 10.3.3.13 | Diagnostics information related to an earlier handover to UTRAN request |
| Protocol error information | CV-*ProtErr* | | Protocol error information 10.3.8.12 | |

| Condition | Explanation |
|---|---|
| *ProtErr* | This IE is mandatory present if the IE "Protocol error indicator" is included and has the value "TRUE". Otherwise it is not needed. |

NOTE1: To facilitate that network nodes can transparently forward the RRC information received, the INTER RAT HANDOVER INFO WITH INTER RAT CAPABILITIES should include the entire INTER RAT HANDOVER INFO message. The network node, which may not be able to decode the information received, may only append some information to what was received.

NOTE2: The above table does not need to reflect the order of the information elements in the actual encoded message. The order, that is reflected in the ASN.1, should be chosen in a manner that avoids that network nodes need to perform reordering of information elements.

### 14.12.4.2 SRNS RELOCATION INFO

This RRC message is sent between network nodes when preparing for an SRNS relocation or a handover/cell reselection from GERAN *Iu mode*.

With the presence or absence of the IE "RB identity for Hard Handover message" the source RNC indicates to the target SRNC whether the source RNC expects to receive the choice "DL DCCH message" in the IE "RRC information, target RNC to source RNC" in case the SRNS relocation is of type "UE involved". Furthermore the target RNC uses this information for the calculation of the MAC-I.

Direction: source RNC/RAT→target RNC

| Information Element/Group Name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| **Non RRC IEs** | | | | | |
| >RB identity for Handover message | OP | | RB identity 10.3.4.16 | Gives the id of the radio bearer on which the source RNC will transmit the RRC message in the case the relocation is of type "UE involved". In handover from GERAN *Iu mode* this IE is always set to 2. | |
| >State of RRC | MP | | RRC state indicator, | | |

| Information Element/Group Name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| | | | 10.3.3.35a | | |
| >State of RRC procedure | MP | | Enumerated (await no RRC message, await RB Release Complete, await RB Setup Complete, await RB Reconfiguration Complete, await Transport CH Reconfiguration Complete, await Physical CH Reconfiguration Complete, await Active Set Update Complete, await Handover Complete, send Cell Update Confirm, send URA Update Confirm, , others) | | |
| **Ciphering related information** | | | | | |
| >Ciphering status for each CN domain | MP | <1 to maxCNDomains> | | | |
| >>CN domain identity | MP | | CN domain identity 10.3.1.1 | | |
| >>Ciphering status | MP | | Enumerated( Not started, Started) | | |
| >>START | MP | | START 10.3.3.38 | START value to be used in this CN domain. | |
| >Latest configured CN domain | MP | | CN domain identity 10.3.1.1 | Value contained in the variable of the same name. In case this variable is empty, the source RNC can set any CN domain identity. In that case, the Ciphering status and the Integrity protection status should be Not started and the target RNC should not initialise the variable Latest configured CN domain. | |
| >Calculation time for ciphering related information | CV-*Ciphering* | | | Time when the ciphering information of the message were calculated, relative to a cell of the target RNC. In | |

| Information Element/Group Name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| | | | | handover and cell reselection from GERAN *Iu mode* this field is not present. | |
| >>Cell Identity | MP | | Cell Identity 10.3.2.2 | Identity of one of the cells under the target RNC and included in the active set of the current call | |
| >>SFN | MP | | Integer(0..4095) | | |
| >COUNT-C list | OP | 1 to <maxCNdomains> | | COUNT-C values for radio bearers using transparent mode RLC | |
| >>CN domain identity | MP | | CN domain identity 10.3.1.1 | | |
| >>COUNT-C | MP | | Bit string(32) | | |
| >Ciphering info per radio bearer | OP | 1 to <maxRB> | | For signalling radio bearers this IE is mandatory. | |
| >>RB identity | MP | | RB identity 10.3.4.16 | | |
| >>Downlink HFN | MP | | Bit string(20..25) | This IE is either RLC AM HFN (20 bits) or RLC UM HFN (25 bits) | |
| >>Downlink SN | CV-*SRB1* | | Bit String(7) | VT(US) of RLC UM | |
| >>Uplink HFN | MP | | Bit string(20..25) | This IE is either RLC AM HFN (20 bits) or RLC UM HFN (25 bits) | |
| **Integrity protection related information** | | | | | |
| >Integrity protection status | MP | | Enumerated( Not started, Started) | | |
| >Signalling radio bearer specific integrity protection information | CV-*IP* | 4 to <maxSRBsetup> | | | |
| >>Uplink RRC HFN | MP | | Bit string (28) | For each SRB, in the case activation times for the next IP configuration to be applied on this SRB have already been reached this IE corresponds to the last value used. Else this value corresponds to the value the source would have initalized the HFN to at the activation time, not considering any increment of HFN due to RRC SN roll over. Increment of HFN due to RRC SN roll over is taken care of by target based on value sent by the source. | |
| >>Downlink RRC HFN | MP | | Bit string (28) | For each SRB, in the case activation times for the next IP configuration to be applied on this SRB have already been reached this IE corresponds to the last value used. Else this value corresponds to the value the source would have initalized the HFN to at the activation time, not considering any increment of HFN due to RRC SN roll over. Increment of HFN due to RRC SN roll over is taken care of by target based on value sent by the | |

| Information Element/Group Name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| | | | | source. In particular, for SRB2, this IE should not take into account the RRC message that will trigger the relocation. NOTE: In order to have the possibility of sending downlink messages after the construction of the IE "SRNS RELOCATION INFO", the source may choose a value ahead of the last value used. | |
| >>Uplink RRC Message sequence number | MP | | Integer (0..15) | For each SRB, this IE corresponds to the last value received or in the case activation time was not reached for a configuration the value equals (activation time - 1). | |
| >>Downlink RRC Message sequence number | MP | | Integer (0..15) | For each SRB, this IE corresponds to the last value used or in the case activation time was not reached for a configuration the value equals (activation time -1). In particular, for SRB2, this IE should not take into account the RRC message that will trigger the relocation. NOTE: In order to have the possibility of sending downlink messages after the construction of the IE "SRNS RELOCATION INFO", the source may choose a value ahead of the last value used for SRB3 and SRB4. | |
| >Implementation specific parameters | OP | | Bit string (1..512) | | |
| **RRC IEs** | | | | | |
| **UE Information elements** | | | | | |
| >U-RNTI | MP | | U-RNTI 10.3.3.47 | G-RNTI is placed in this field when performing handover or cell reselection from GERAN *Iu mode.* | |
| >C-RNTI | OP | | C-RNTI 10.3.3.8 | | |
| >UE radio access Capability | MP | | UE radio access capability 10.3.3.42 | | |
| >UE radio access capability extension | OP | | UE radio access capability extension 10.3.3.42a | | |
| >Last known UE position | OP | | | | |
| >>SFN | MP | | Integer (0..4095) | Time when position was estimated | |
| >>Cell ID | MP | | Cell identity; 10.3.2.2 | Indicates the cell, the SFN is valid for. | |
| >>CHOICE *Position estimate* | MP | | | | |
| >>>Ellipsoid Point | | | Ellipsoid Point; 10.3.8.4a | | |
| >>>Ellipsoid point with uncertainty circle | | | Ellipsoid point with | | |

| Information Element/Group Name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| | | | uncertainty circle 10.3.8.4d | | |
| >>>Ellipsoid point with uncertainty ellipse | | | Ellipsoid point with uncertainty ellipse 10.3.8.4e | | |
| >>>Ellipsoid point with altitude | | | Ellipsoid point with altitude 10.3.8.4b | | |
| >>>Ellipsoid point with altitude and uncertainty ellipsoid | | | Ellipsoid point with altitude and uncertainty ellipsoid 10.3.8.4c | | |
| **>**UE Specific Behaviour Information 1 idle | OP | | UE Specific Behaviour Information idle 1 10.3.3.51 | This IE should be included if received via the "INTER RAT HANDOVER INFO", the "RRC CONNECTION REQUEST", the IE "SRNS RELOCATION INFO" or the "Inter RAT Handover Info with Inter RAT Capabilities" | |
| **>**UE Specific Behaviour Information 1 interRAT | OP | | UE Specific Behaviour Information 1 interRAT 10.3.3.52 | This IE should be included if received via the "INTER RAT HANDOVER INFO", the "RRC CONNECTION REQUEST", the IE "SRNS RELOCATION INFO" or the "Inter RAT Handover Info with Inter RAT Capabilities" | |
| **Other Information elements** | | | | | |
| >UE system specific capability | OP | 1 to <maxSystemCapability> | | | |
| >>Inter-RAT UE radio access capability | MP | | Inter-RAT UE radio access capability 10.3.8.7 | | |
| **UTRAN Mobility Information elements** | | | | | |
| >URA Identifier | OP | | URA identity 10.3.2.6 | | |
| **CN Information Elements** | | | | | |
| >CN common GSM-MAP NAS system information | MP | | NAS system information (GSM-MAP) 10.3.1.9 | | |
| >CN domain related information | OP | 1 to <MaxCNdomains> | | CN related information to be provided for each CN domain | |
| >>CN domain identity | MP | | | | |
| >>CN domain specific GSM-MAP NAS system info | MP | | NAS system information (GSM-MAP) 10.3.1.9 | | |
| >>CN domain specific DRX cycle length coefficient | MP | | CN domain specific DRX cycle length coefficient, 10.3.3.6 | | |

| Information Element/Group Name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| **Measurement Related Information elements** | | | | | |
| >For each ongoing measurement reporting | OP | 1 to <MaxNoOf Meas> | | The source RNC should include the measurement IEs for each measurement configured and ongoing in the UE. | |
| >>Measurement Identity | MP | | Measurement identity 10.3.7.48 | | |
| >>Measurement Command | MP | | Measurement command 10.3.7.46 | This IE should have the value Setup. | |
| >>Measurement Type | CV-*Setup* | | Measurement type 10.3.7.50 | | |
| >>Measurement Reporting Mode | OP | | Measurement reporting mode 10.3.7.49 | | |
| >>Additional Measurements list | OP | | Additional measurements list 10.3.7.1 | | |
| >>CHOICE *Measurement* | CV-*Setup* | | | | |
| >>>Intra-frequency | | | | | |
| >>>>Intra-frequency cell info | OP | | Intra-frequency cell info list 10.3.7.33 | | |
| >>>>Intra-frequency measurement quantity | OP | | Intra-frequency measurement quantity 10.3.7.38 | | |
| >>>>Intra-frequency reporting quantity | OP | | Intra-frequency reporting quantity 10.3.7.41 | | |
| >>>>Reporting cell status | OP | | Reporting cell status 10.3.7.61 | | |
| >>>>Measurement validity | OP | | Measurement validity 10.3.7.51 | | |
| >>>>CHOICE *report criteria* | OP | | | | |
| >>>>>Intra-frequency measurement reporting criteria | | | Intra-frequency measurement reporting criteria 10.3.7.39 | | |
| >>>>>Periodical reporting | | | Periodical reporting criteria 10.3.7.53 | | |
| >>>>>No reporting | | | NULL | | |
| >>>Inter-frequency | | | | | |
| >>>>Inter-frequency cell info | OP | | Inter-frequency cell info list 10.3.7.13 | | |
| >>>>Inter-frequency measurement | OP | | Inter-frequency | | |

| Information Element/Group Name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| quantity | | | measurement quantity 10.3.7.18 | | |
| >>>>Inter-frequency reporting quantity | OP | | Inter-frequency reporting quantity 10.3.7.21 | | |
| >>>>Reporting cell status | OP | | Reporting cell status 10.3.7.61 | | |
| >>>>Measurement validity | OP | | Measurement validity 10.3.7.51 | | |
| >>>>Inter-frequency set update | OP | | Inter-frequency set update 10.3.7.22 | | |
| >>>>CHOICE *report criteria* | OP | | | | |
| >>>>>Intra-frequency measurement reporting criteria | | | Intra-frequency measurement reporting criteria 10.3.7.39 | | |
| >>>>>Inter-frequency measurement reporting criteria | | | Inter-frequency measurement reporting criteria 10.3.7.19 | | |
| >>>>>Periodical reporting | | | Periodical reporting criteria 10.3.7.53 | | |
| >>>>>No reporting | | | NULL | | |
| >>>Inter-RAT | | | | | |
| >>>>Inter-RAT cell info | OP | | Inter-RAT cell info list 10.3.7.23 | | |
| >>>>Inter-RAT measurement quantity | OP | | Inter-RAT measurement quantity 10.3.7.29 | | |
| >>>>Inter-RAT reporting quantity | OP | | Inter-RAT reporting quantity 10.3.7.32 | | |
| >>>>Reporting cell status | OP | | Reporting cell status 10.3.7.61 | | |
| >>>>Measurement validity | OP | | Measurement validity 10.3.7.51 | | |
| >>>>CHOICE *report criteria* | OP | | | | |
| >>>>>Inter-RAT measurement reporting criteria | | | Inter-RAT measurement reporting criteria 10.3.7.30 | | |
| >>>>>Periodical reporting | | | Periodical reporting criteria 10.3.7.53 | | |
| >>>>>No reporting | | | NULL | | |

| Information Element/Group Name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| >>>Traffic Volume | | | | | |
| >>>>Traffic volume measurement Object | OP | | Traffic volume measurement object 10.3.7.70 | | |
| >>>>Traffic volume measurement quantity | OP | | Traffic volume measurement quantity 10.3.7.71 | | |
| >>>>Traffic volume reporting quantity | OP | | Traffic volume reporting quantity 10.3.7.74 | | |
| >>>>Measurement validity | OP | | Measurement validity 10.3.7.51 | | |
| >>>>CHOICE *report criteria* | OP | | | | |
| >>>>>Traffic volume measurement reporting criteria | | | Traffic volume measurement reporting criteria 10.3.7.72 | | |
| >>>>>Periodical reporting | | | Periodical reporting criteria 10.3.7.53 | | |
| >>>>>No reporting | | | NULL | | |
| >>>Quality | | | | | |
| >>>>Quality measurement quantity | OP | | Quality measurement quantity 10.3.7.59 | | |
| >>>>CHOICE *report criteria* | OP | | | | |
| >>>>>Quality measurement reporting criteria | | | Quality measurement reporting criteria 10.3.7.58 | | |
| >>>>>Periodical reporting | | | Periodical reporting criteria 10.3.7.53 | | |
| >>>>>No reporting | | | NULL | | |
| >>>UE internal | | | | | |
| >>>>UE internal measurement quantity | OP | | UE internal measurement quantity 10.3.7.79 | | |
| >>>>UE internal reporting quantity | OP | | UE internal reporting quantity 10.3.7.82 | | |
| >>>>CHOICE *report criteria* | OP | | | | |
| >>>>>UE internal measurement reporting criteria | | | UE internal measurement reporting criteria 10.3.7.80 | | |
| >>>>>Periodical reporting | | | Periodical reporting criteria | | |

| Information Element/Group Name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| | | | 10.3.7.53 | | |
| >>>>>No reporting | | | NULL | | |
| >>>UE positioning | | | | | |
| >>>>LCS reporting quantity | OP | | LCS reporting quantity 10.3.7.111 | | |
| >>>>CHOICE *report criteria* | OP | | | | |
| >>>>>LCS reporting criteria | | | LCS reporting criteria 10.3.7.110 | | |
| >>>>>Periodical reporting | | | Periodical reporting criteria 10.3.7.53 | | |
| >>>>>No reporting | | | | | |
| **Radio Bearer Information Elements** | | | | | |
| >Predefined configuration status information | OP | | Predefined configuration status information 10.3.4.5a | | |
| >Signalling RB information list | MP | 1 to <maxSRBsetup> | | For each signalling radio bearer | |
| >>Signalling RB information | MP | | Signalling RB information to setup 10.3.4.24 | | |
| >RAB information list | OP | 1 to <maxRABsetup> | | Information for each RAB | |
| >>RAB information | MP | | RAB information to setup 10.3.4.10 | | |
| **Transport Channel Information Elements** | | | | | |
| **Uplink transport channels** | | | | | |
| >UL Transport channel information common for all transport channels | OP | | UL Transport channel information common for all transport channels 10.3.5.24 | | |
| >UL transport channel information list | OP | 1 to <MaxTrCH> | | | |
| >>UL transport channel information | MP | | Added or reconfigured UL TrCH information 10.3.5.2 | | |
| **Downlink transport channels** | | | | | |
| >DL Transport channel information common for all transport channels | OP | | DL Transport channel information common for all transport channels 10.3.5.6 | | |

| Information Element/Group Name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| >DL transport channel information list | OP | 1 to <MaxTrCH> | | | |
| >>DL transport channel information | MP | | Added or reconfigured DL TrCH information 10.3.5.1 | | |

| Information Element/Group Name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| **PhyCH information elements** | | | | | |
| >TPC Combination Info list | OP | 1 to <maxRL> | | | |
| >>Primary CPICH info | MP | | Primary CPICH info 10.3.6.60 | | |
| >>TPC combination index | MP | | TPC combination index 10.3.6.85 | | |
| >Transmission gap pattern sequence | OP | 1 to <maxTGPS> | | | REL-5 |
| >>TGPSI | MP | | TGPSI 10.3.6.82 | | REL-5 |
| >> Current TGPS Status Flag | MP | | Enumerated( active, inactive) | This flag indicates the current status of the Transmission Gap Pattern Sequence, whether it is active or inactive | REL-5 |
| >>TGCFN | CV-*Active* | | Integer (0..255) | Connection Frame Number of the latest past frame of the first pattern within the Transmission Gap Pattern Sequence. | REL-5 |
| >>Transmission gap pattern sequence configuration parameters | OP | | | | REL-5 |
| >>>TGMP | MP | | Enumerated( TDD measurement, FDD measurement, GSM carrier RSSI measurement, GSM Initial BSIC identification, GSM BSIC re-confirmation, Multi-carrier measurement) | Transmission Gap pattern sequence Measurement Purpose. | REL-5 |
| >>>TGPRC | MP | | Integer (1..511, Infinity) | The number of remaining transmission gap patterns within the Transmission Gap Pattern Sequence. | REL-5 |
| >>>TGSN | MP | | Integer (0..14) | Transmission Gap Starting Slot Number<br>The slot number of the first transmission gap slot within the TGCFN. | REL-5 |
| >>>TGL1 | MP | | Integer(1..14 ) | The length of the first Transmission Gap within the transmission gap pattern expressed in number of slots | REL-5 |
| >>>TGL2 | MD | | Integer (1..14) | The length of the second Transmission Gap within the transmission gap pattern. If omitted, then TGL2=TGL1. The value of TGL2 shall be ignored if TGD is set to 'undefined' | REL-5 |
| >>>TGD | MP | | Integer(15..269, | Transmission gap distance indicates the number of slots | REL-5 |

| Information Element/Group Name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| | | | undefined) | between starting slots of two consecutive transmission gaps within a transmission gap pattern. If there is only one transmission gap in the transmission gap pattern, this parameter shall be set to undefined. | |
| >>>TGPL1 | MP | | Integer (1..144) | The duration of transmission gap pattern 1. | REL-5 |
| >>>RPP | MP | | Enumerated (mode 0, mode 1). | Recovery Period Power control mode during the frame after the transmission gap within the compressed frame. Indicates whether normal PC mode or compressed PC mode is applied | REL-5 |
| >>>ITP | MP | | Enumerated (mode 0, mode 1). | Initial Transmit Power is the uplink power control method to be used to compute the initial transmit power after the compressed mode gap. | REL-5 |
| >>>CHOICE *UL/DL mode* | MP | | | | REL-5 |
| >>>>DL only | | | | Compressed mode used in DL only | REL-5 |
| >>>>>Downlink compressed mode method | MP | | Enumerated (SF/2, higher layer scheduling) | Method for generating downlink compressed mode gap | REL-5 |
| >>>>UL only | | | | Compressed mode used in UL only | REL-5 |
| >>>>>Uplink compressed mode method | MP | | Enumerated (SF/2, higher layer scheduling) | Method for generating uplink compressed mode gap | REL-5 |
| >>>>UL and DL | | | | Compressed mode used in UL and DL | REL-5 |
| >>>>>Downlink compressed mode method | MP | | Enumerated (SF/2, higher layer scheduling) | Method for generating downlink compressed mode gap | REL-5 |
| >>>>>Uplink compressed mode method | MP | | Enumerated (SF/2, higher layer scheduling) | Method for generating uplink compressed mode gap | REL-5 |
| >>>Downlink frame type | MP | | Enumerated (A, B) | | REL-5 |
| >>>DeltaSIR1 | MP | | Real(0..3 by step of 0.1) | Delta in DL SIR target value to be set in the UE during the frame containing the start of the first transmission gap in the transmission gap pattern (without including the effect of the bit-rate increase) | REL-5 |
| >>>DeltaSIRafter1 | MP | | Real(0..3 by step of 0.1) | Delta in DL SIR target value to be set in the UE one frame after the frame containing the start of the first transmission gap in the transmission gap pattern. | REL-5 |
| >>>DeltaSIR2 | OP | | Real(0..3 by step of 0.1) | Delta in DL SIR target value to be set in the UE during the frame containing the start of the second transmission gap in the transmission gap pattern | REL-5 |

| Information Element/Group Name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| | | | | (without including the effect of the bit-rate increase)<br>When omitted, DeltaSIR2 = DeltaSIR1. | |
| >>>DeltaSIRafter2 | OP | | Real(0..3 by step of 0.1) | Delta in DL SIR target value to be set in the UE one frame after the frame containing the start of the second transmission gap in the transmission gap pattern.<br>When omitted, DeltaSIRafter2 = DeltaSIRafter1. | REL-5 |
| >>>N Identify abort | CV-*Initial BSIC* | | Integer(1..128) | Indicates the maximum number of repeats of patterns that the UE shall use to attempt to decode the unknown BSIC of the GSM cell in the initial BSIC identification procedure | REL-5 |
| >>>T Reconfirm abort | CV-*Re-confirm BSIC* | | Real(0.5..10.0 by step of 0.5) | Indicates the maximum time allowed for the re-confirmation of the BSIC of one GSM cell in the BSIC re-confirmation procedure. The time is given in steps of 0.5 seconds. | REL-5 |
| >Scrambling Code Change List | CH-*SF/2* | 1 to <maxRL> | | | REL-5 |
| >>Primary CPICH info | MP | | Primary CPICH info 10.3.6.60 | | REL-5 |
| >>Scrambling code change | MP | | Enumerated (code change, no code change) | Indicates whether the alternative scrambling code is used for compressed mode method 'SF/2'. | REL-5 |
| **Other Information elements** | | | | | |
| >Measurement report | OP | | MEASUREMENT REPORT 10.2.19 | The source RNC should include the Measurement report the UE sent that triggered the SRNS relocation. This information could e.g. be used by the target RNC to set initial power when establishing a DCH. | |
| >Failure cause | OP | | Failure cause 10.3.3.13 | Diagnostics information related to an earlier SRNC Relocation request (see NOTE 2 in 14.12.0a) | |
| >Protocol error information | CV-*ProtErr* | | Protocol error information 10.3.8.12 | | |
| MBMS joined information | OP | | | Included if the UE has joined one or more MBMS services | REL-6 |
| >P-TMSI | OP | | P-TMSI (GSM-MAP) 10.3.1.13 | In case the UE is in PMM-Idle | REL-6 |

| Multi Bound | Explanation |
|---|---|
| MaxNoOfMeas | Maximum number of active measurements, upper limit 16 |

| Condition | Explanation |
|---|---|
| *Setup* | The IE is mandatory present when the IE Measurement command has the value "Setup", otherwise the IE is not needed. |
| *Ciphering* | The IE is mandatory present when the IE Ciphering Status has the value "started" and the ciphering counters need not be reinitialised, otherwise the IE is not needed. |
| *IP* | The IE is mandatory present when the IE Integrity protection status has the value "started" and the integrity protection counters need not be reinitialised, otherwise the IE is not needed. |
| *ProtErr* | This IE is mandatory present if the IE "Protocol error indicator" is included and has the value "TRUE". Otherwise it is not needed. |
| *SRB1* | The IE is mandatory present for RB1. Otherwise it is not needed. |
| Active | This IE is mandatory present when the value of the IE "Current TGPS Status Flag" is "Active" and not needed otherwise. |
| Initial BSIC | This IE is mandatory present when the value of the IE "TGMP" is set to "GSM Initial BSIC identification" and not needed otherwise. |
| Re-confirm BSIC | This IE is mandatory present when the value of the IE "TGMP" is set to "GSM BSIC re-confirmation" and not needed otherwise. |
| SF/2 | The IE is mandatory present if the IE 'Transmission Gap Pattern Sequence' is included and has the value 'SF/2' as the compressed mode method, and already sent the UE the IE 'Scrambling Code Change' for each RL in the active set. Otherwise the IE is not needed. |

#### 14.12.4.3 Void

#### 14.12.4.4 RFC 3095 CONTEXT INFO

This RRC message is sent between network nodes in SRNS relocation. It is used to transfer the compressor and decompressor context information of the RFC 3095 protocol.

Direction: source RNC →target RNC

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| RFC 3095 context | MP | 1 to <maxRBallRABs> | | | REL-5 |
| >RB identity | MP | | RB identity 10.3.4.16 | | REL-5 |
| >RFC 3095 context list | MP | 1 to <maxRFC3095-CID> | | | REL-5 |
| >>Downlink RFC 3095 context | OP | | | | REL-5 |
| >>>Downlink RFC 3095 context identity | MP | | Integer (0..16383) | | REL-5 |
| >>>DL_MODE | MP | | Enumerated (u, o, r) | RFC 3095 mode in downlink before SRNS relocation. | REL-5 |
| >>>REF_IR | MP | | Octet string (1..3000) | The RTP IR header (see section 5.7.7 of RFC3095 for detailed format) corresponding to the oldest header in the compressor sliding window. | REL-5 |
| >>>REF_TIME | OP | | Integer (0..4294967295) | Arrival time (at the compressor) of REF_IR in milliseconds. See sections 4.5.4 and 6.5.1 of RFC3095. | REL-5 |
| >>>CURR_TIME | OP | | Integer (0..4294967295) | Current time in milliseconds. See section 6.5.1 of RFC3095. | REL-5 |
| >>>SYN_OFFSET_ID | OP | | Integer (0..65535) | Last synchronized offset of IP-ID. See section 4.5.5 and 6.5.1 of RFC3095 (termed "Offset_I").<br><br>It is related to the compression and decompression of IP-ID and is the synchronized offset between the IP-ID value and the SN value (in the same header) during the last SO state before the relocation procedure. | REL-5 |
| >>>SYN_SLOPE_TS | OP | | Integer (0..4294967295) | Last synchronized slope of TS. See sections 5.5.1.2 and 5.7 of RFC3095.<br><br>In SO state, TS(n) = TS(m) + (n-m) * SYN_SLOPE_TS, where n and m are, the RTP SN of the current and | REL-5 |

| | | | | | |
|---|---|---|---|---|---|
| | | | | the reference packet, respectively. The unit of SYN_SLOPE_TS depends on whether TS is scaled before compression or not. | |
| >>>DYN_CHANGED | MP | | Boolean | Information whether dynamic fields other than RTP SN, RTP TS and IP-ID have changed in the headers that are stored in the sliding window. Set to TRUE if changed and FALSE if not changed. | REL-5 |
| >>Uplink RFC 3095 context | OP | | | | REL-5 |
| >>>Uplink RFC 3095 context identity | MP | | Integer (0..16383) | | REL-5 |
| >>>UL_MODE | MP | | Enumerated (u, o, r) | RFC 3095 mode in uplink | REL-5 |
| >>>REF_IR | MP | | Octet string (1..3000) | The RTP IR header (see section 5.7.7 of IETF RFC3095 for detailed format) corresponding to the last correctly decompressed header. | REL-5 |
| >>>REF_TIME | OP | | Integer (0..4294967 295) | Arrival time (at the decompressor) of REF_IR in milliseconds. See sectionss 4.5.4 and 6.5.1 of RFC3095. | REL-5 |
| >>>CURR_TIME | OP | | Integer (0..4294967 295) | Current time in milliseconds. See section 6.5.1 of RFC3095. | REL-5 |
| >>>SYN_OFFSET_ID | OP | | Integer (0..65535) | Last synchronized offset of IP-ID. See sectionss 4.5.5 and 6.5.1 of RFC3095 (termed"Offset_I") .<br><br>It is related to the compression and decompression of IP-ID and is the synchronized offset between the IP-ID value and the SN value (in the same header) during the last SO state before the relocation | REL-5 |

| | | | | | |
|---|---|---|---|---|---|
| | | | | procedure. | |
| >>>SYN_SLOPE_TS | OP | | Integer (0..4294967295) | Last synchronized slope of TS. See sectionss 5.5.1.2 and 5.7 of RFC3095.<br><br>In SO state, TS(n) = TS(m) + (n-m) * SYN_SLOPE_TS, where n and m are, the RTP SN of the current and the reference packet, respectively. The unit of SYN_SLOPE_TS depends on whether TS is scaled before compression or not. | REL-5 |
| >>>REF_SN_1 | OP | | Integer (0..65535) | Corresponds to the RTP Sequence Number of the predecessor of the latest RTP packet. This could be used to perform local repair of context by decompressor in U or O mode (see 'ref - 1' in section5.3.2.2.5 in IETF RFC3095 for further explanation). | REL-5 |

## 14.13 Void

## 14.14 Void

# Annex A (informative): USIM parameters

## A.1 Introduction

This annex contains recommendations about the RRC parameters to be stored in the USIM.

## A.2 Ciphering information

| Information Element/Group name | Need | Multi | Type and reference | Semantics description |
|---|---|---|---|---|
| Cipher key for each CN domain | MP | <1 to maxCNDomains> | | Cipher key is described in [40]. |
| >CK | MP | | Bit string (128) | |
| Integrity key for each CN domain | MP | <1 to maxCNDomains> | | Integrity key is described in [40]. |
| >IK | MP | | Bit string (128) | |
| THRESHOLD | MP | | Bit string (20) | |
| START value for each CN domain | MP | <1 to maxCNDomains> | | START value is described in [40]. |
| >START | MP | | Bit string (20) | |
| KSI, Key set identifier for each CN domain | MP | <1 to maxCNDomains> | | Key set identifier is described in [40]. |
| >KSI | MP | | Bit string (3) | |

## A.3 Frequency information

Neighbour cell list.

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| FDD cell list | OP | <1 to maxFDDFreqList> | | | |
| >UARFCN downlink (Nd) | MP | | Integer(0 .. 16383) | [21] | |
| >Primary scrambling code | OP | <1 to maxFDDFreqCellList> | Primary CPICH info 10.3.6.60 | | |
| 3.84 Mcps TDD cell list | OP | <1 to maxTDDFreqList> | | | |
| >UARFCN (Nt) | MP | | Integer(0 .. 16383) | [22] | |
| >Cell parameters ID | OP | <1 to maxTDDFreqCellList> | Integer (0..127) | The Cell parameters ID is described in [32]. | |
| 1.28 Mcps TDD cell list | OP | <1 to maxTDDFreqList> | | | REL-4 |
| >UARFCN (Nt) | MP | | Integer(0 .. | [22] | REL-4 |

| Information Element/Group name | Need | Multi | Type and reference | Semantics description | Version |
|---|---|---|---|---|---|
| | | | 16383) | | |
| >Cell parameters ID | OP | <1 to maxTDDFreqCellList> | Integer (0..127) | The Cell parameters ID is described in [32]. | REL-4 |
| GSM Neighbour cell list | OP | | | | |
| >GSM neighbour cell info | MP | <1 to maxGSMCellList> | | | |
| >>BSIC | MP | | | | |
| >>BCCH ARFCN | MP | | | | |

## A.4 Multiplicity values and type constraint values

| Constant | Explanation | Value |
|---|---|---|
| **Ciphering information** | | |
| maxCNDomains | Maximum number of CN domains | 4 |
| **Frequency information** | | |
| maxFDDFreqList | Maximum number of FDD carrier frequencies to be stored in USIM | 4 |
| maxTDDFreqList | Maximum number of TDD carrier frequencies to be stored in USIM | 4 |
| maxFDDFreqCellList | Maximum number of neighbouring FDD cells on one carrier to be stored in USIM | 32 |
| maxTDDFreqCellList | Maximum number of neighbouring TDD cells on one carrier to be stored in USIM | 32 |
| maxGSMCellList | Maximum number of GSM cells to be stored in USIM | 32 |

# Annex B (informative): Description of RRC state transitions

This annex contains Stage 2 description of RRC states and state transitions.

## B.1 RRC states and state transitions including GSM

After power on, the UE stays in Idle Mode until it transmits a request to establish an RRC Connection. In Idle Mode the connection of the UE is closed on all layers of the access stratum. In Idle Mode the UE is identified by non-access stratum identities such as IMSI, TMSI and P-TMSI. In addition, the UTRAN has no own information about the individual Idle Mode UEs, and it can only address e.g. all UEs in a cell or all UEs monitoring a paging occasion. The UE behaviour within this mode is described in [4].

The UTRA RRC Connected Mode is entered when the RRC Connection is established. The UE is assigned a radio network temporary identity (RNTI) to be used as UE identity on common transport channels.

The RRC states within UTRA RRC Connected Mode reflect the level of UE connection and which transport channels that can be used by the UE.

For inactive stationary data users the UE may fall back to PCH on both the Cell and URA levels. That is, upon the need for paging, the UTRAN checks the current level of connection of the given UE, and decides whether the paging message is sent within the URA, or should it be sent via a specific cell.

## B.2 Transition from Idle Mode to UTRA RRC Connected Mode

The transition to the UTRA RRC Connected Mode from the Idle Mode can only be initiated by the UE by transmitting a request for an RRC Connection. The event is triggered either by a paging request from the network or by a request from upper layers in the UE.

When the UE receives a message from the network that confirms the RRC connection establishment, the UE enters the CELL_FACH or CELL_DCH state of UTRA RRC Connected Mode.

In the case of a failure to establish the RRC Connection the UE goes back to Idle Mode. Possible causes are radio link failure, a received reject response from the network or lack of response from the network (timeout).

### B.2.1 Transitions for Emergency Calls

Refer to [4] for all states and procedures referred to in this subclause. When UE leaves idle mode from state *Camped on any cell* in order to make an emergency call, moving to state *Connected mode (emergency calls only),* the UE shall attempt to access the current serving cell. If the access attempt to the serving cell fails the UE shall use the *Cell Reselection* procedure. If no acceptable cell is found, the UE shall use the *Any cell selection*. When returning to idle mode, the UE shall use the procedure *Cell selection when leaving connected mode* in order to find an acceptable cell to camp on, state *Camped on any cell*.

## B.3 UTRA RRC Connected Mode States and Transitions

### B.3.1 CELL_DCH state

The CELL_DCH state is characterised by

- For TDD: A dedicated physical channel is allocated to the UE in uplink and downlink or a dedicated physical channel is allocated to the UE in the uplink and HS_DSCH_RECEPTION is set to TRUE.

- A dedicated physical channel is allocated to the UE in uplink and downlink.
- The UE is known on cell level according to its current active set.
- Dedicated transport channels, downlink and uplink (TDD) shared transport channels, and a combination of these transport channels can be used by the UE.

The CELL_DCH-state is entered from the Idle Mode through the setup of an RRC connection, or by establishing a dedicated physical channel from the CELL_FACH state.

In TDD a PDSCH may be assigned to the UE in this state, to be used for a DSCH. A PUSCH may also be assigned to the UE in this state, to be used for a USCH. If PDSCH or PUSCH are used for TDD, a FACH transport channel may be assigned to the UE for reception of physical shared channel allocation messages.

### B.3.1.1 Transition from CELL_DCH to Idle Mode

Transition to Idle Mode is realised through the release of the RRC connection.

### B.3.1.2 Transition from CELL_DCH to CELL_FACH state

Transition to CELL_FACH state occurs when all dedicated channels have been released, which may be

a) via explicit signalling (e.g. PHYSICAL CHANNEL RECONFIGURATION, RADIO BEARER RECONFIGURATION, RADIO BEARER RELEASE, RADIO BEARER SETUP, TRANSPORT CHANNEL RECONFIGURATION, etc.).

at the end of the time period for which the dedicated channel was allocated (TDD)

### B.3.1.3 Transition from CELL_DCH to CELL_PCH state

Transition to CELL_PCH state occurs via explicit signalling (e.g. PHYSICAL CHANNEL RECONFIGURATION, RADIO BEARER RECONFIGURATION, RADIO BEARER RELEASE, RADIO BEARER SETUP, TRANSPORT CHANNEL RECONFIGURATION, etc.).

### B.3.1.4 Transition from CELL_DCH to URA_PCH state

Transition to URA_PCH state occurs via explicit signalling (e.g. PHYSICAL CHANNEL RECONFIGURATION, RADIO BEARER RECONFIGURATION, RADIO BEARER RELEASE, RADIO BEARER SETUP, TRANSPORT CHANNEL RECONFIGURATION, etc.).

### B.3.1.5 Radio Resource Allocation tasks (CELL_DCH)

For the DCH, several physical channel allocation strategies may be applied. The allocations can be either permanent (needing a DCH release message) or based on time or amount-of-data.

Resource allocation can be done separately for each packet burst with fast signalling on the DCH

For each radio frame the UE and the network indicate the current data rate (in uplink and downlink respectively) using the transport format combination indicator (TFCI). However, in TDD, DCH and DSCH or USCH may be mapped on different CCTrCHs, their TFCI are totally independent. DCH transmission is not modified by the simultaneous existence of DSCH/USCH. If the configured set of combinations (i.e. transport format set for one transport channel) are found to be insufficient to retain the QoS requirements for a transport channel, the network initiates a reconfiguration of the transport format set (TFS) for that transport channel. This reconfiguration can be done during or in between data transmission. Further, the network can reconfigure the physical channel allowing an increase or decrease of the peak data rate.

For the uplink data transmission, the UE reports the observed traffic volume to the network in order for the network to re-evaluate the current allocation of resources. This report contains e.g. the amount of data to be transmitted or the buffer status in the UE.

#### B.3.1.6 RRC Connection mobility tasks (CELL_DCH)

Depending on the amount and frequency of data macrodiversity (soft handover) may or may not be applied.

The RRC Connection mobility is handled by measurement reporting, soft handover and Timing re-initialised or Timing-maintained hard handover procedures.

#### B.3.1.7 UE Measurements (CELL_DCH)

The UE performs measurements and transmit measurement reports according to the measurement control information.

The UE uses the connected mode measurement control information received in other states until new measurement control information has been assigned to the UE.

#### B.3.1.8 Acquisition of system information (CELL_DCH)

FDD UEs with certain capabilities reads system information broadcast on FACH.

TDD UEs reads the BCH to acquire valid system information. For each acquisition, the UE may need different combinations of system information broadcast on BCH. The scheduling on the broadcast channel is done in such way that the UE knows when the requested information can be found.

### B.3.2 CELL_FACH state

The CELL_FACH state is characterised by:

- No dedicated physical channel is allocated to the UE.
- The UE continuously monitors a FACH in the downlink.
- The UE is assigned a default common or shared transport channel in the uplink (e.g. RACH) that it can use anytime according to the access procedure for that transport channel.
- The position of the UE is known by UTRAN on cell level according to the cell where the UE last made a cell update.
- In TDD mode, one or several USCH or DSCH transport channels may have been established.

#### B.3.2.1 Transition from CELL_FACH to CELL_DCH state

A transition occurs, when a dedicated physical channel is established via explicit signalling (e.g. PHYSICAL CHANNEL RECONFIGURATION, RADIO BEARER RECONFIGURATION, RADIO BEARER RELEASE, RADIO BEARER SETUP, TRANSPORT CHANNEL RECONFIGURATION, etc.).

#### B.3.2.2 Transition from CELL_FACH to CELL_PCH state

The transition occurs when UTRAN orders the UE to move to CELL_PCH state, which is done via explicit signalling (e.g. CELL UPDATE CONFIRM, RADIO BEARER RECONFIGURATION, etc.).

#### B.3.2.3 Transition from CELL_FACH to Idle Mode

Upon release of the RRC connection, the UE moves to the idle mode.

#### B.3.2.4 Transition from CELL_FACH to URA_PCH State

The transition occurs when UTRAN orders the UE to move to URA _PCH state, which is done via explicit signalling (e.g. URA UPDATE CONFIRM, RADIO BEARER RECONFIGURATION, etc.).

### B.3.2.5 Radio Resource Allocation Tasks (CELL_FACH)

In the CELL_ FACH state the UE will monitor an FACH. It is enabled to transmit uplink control signals and it may be able to transmit small data packets on the RACH.

The network can assign the UE transport channel parameters (e.g. transport format sets) in advance, to be used when a DCH is used. Upon assignment of the physical channel for DCH, the UE moves to CELL_DCH state and uses the pre-assigned TFS for the DCH.

If no UE dedicated physical channel or transport channel configuration has been assigned, the UE uses the common physical channel and transport channel configuration according to the system information.

For the uplink data transmission, the UE reports the observed traffic volume to the network in order for the network to re-evaluate the current allocation of resources. This report contains e.g. the amount of data to be transmitted or the buffer status in the UE.

When there is either user or control data to transmit, a selection procedure determines whether the data should be transmitted on a common transport channel, or if a transition to CELL_DCH should be executed. The selection is dynamic and depends on e.g. traffic parameters (amount of data, packet burst frequency).

In the TDD mode, the UTRAN can assign USCH / DSCH resources to the UE in CELL_FACH state. When USCH / DSCH resources are assigned, the UE will continue to monitor FACHs, depending on the UE capability. The UE may use the USCH / DSCH to transmit signalling messages or user data in the uplink and / or the downlink using USCH and / or DSCH when resources are allocated to cell and UE is assigned use of those USCH / DSCH.

For the uplink data transmission on USCH the UE reports to the network the traffic volume (current size of RLC data buffers), The UTRAN can use these measurement reports to re-evaluate the current allocation of the USCH / DSCH resources.

### B.3.2.6 RRC Connection mobility tasks (CELL_FACH)

In this state the location of the UE is known on cell level. A cell update procedure is used to report to the UTRAN, when the UE selects a new cell to observe the common downlink channels of a new cell. Downlink data transmission on the FACH can be started without prior paging.

The UE monitors the broadcast channel and system information on BCCH of its own and neighbour cells and from this the need for the updating of cell location is identified.

The UE performs cell reselection and upon selecting a new UTRA cell, it initiates a cell update procedure. Upon selecting a new cell belonging to another radio access system than UTRA, the UE enters idle mode and makes an access to that system according to its specifications.

### B.3.2.7 UE Measurements (CELL_FACH)

The UE performs measurements and transmit measurement reports according to the measurement control information.

By default, the UE uses the measurement control information broadcast within the system information. However, for measurements for which the network also provides measurement control information within a MEASUREMENT CONTROL message, the latter information takes precedence.

### B.3.2.8 Transfer and update of system information (CELL_FACH)

The UE reads the BCH to acquire valid system information. For each acquisition, the UE may need different combinations of system information broadcast on BCH. The scheduling on the broadcast channel is done in such way that the UE knows when the requested information can be found.

When the system information is modified, the scheduling information is updated to reflect the changes in system information transmitted on BCH. The new scheduling information is broadcast on FACH in order to inform UEs about the changes. If the changes are applicable for the UE, the modified system information is read on BCH.

## B.3.3 CELL_PCH state

The CELL_PCH state is characterised by:

- No dedicated physical channel is allocated to the UE.
- The UE selects a PCH with the algorithm specified in subclause 8.5.19, and uses DRX for monitoring the selected PCH via an associated PICH.
- No uplink activity is possible.
- The position of the UE is known by UTRAN on cell level according to the cell where the UE last made a cell update in CELL_FACH state.

The DCCH logical channel cannot be used in this state. If the network wants to initiate any activity, it needs to make a paging request on the PCCH logical channel in the known cell to initiate any downlink activity.

### B.3.3.1 Transition from CELL_PCH to CELL_FACH state

The UE is transferred to CELL_FACH state:

a) by paging from UTRAN (PAGING TYPE1 message)

b) through any uplink access

### B.3.3.2 Radio Resource Allocation Tasks (CELL_PCH)

In CELL_PCH state no resources have been granted for data transmission. For this purpose, a transition to another state has to be executed.

The UE may use Discontinuous Reception (DRX) in order to reduce power consumption. When DRX is used the UE needs only to receive at one paging occasion per DRX cycle. The UE may be instructed to use a specific DRX cycle length by the network. The UE determines its paging occasions in the same way as for Idle Mode, see [4].

### B.3.3.3 RRC Connection mobility tasks (CELL_PCH)

In the CELL_PCH state, the UE mobility is performed through cell reselection procedures, which may differ from the one defined in [4].

The UE performs cell reselection and upon selecting a new UTRA cell, it moves to CELL_FACH state and initiates a cell update procedure in the new cell. After the cell update procedure has been performed, the UE changes its state back to CELL_PCH state if neither the UE nor the network has any more data to transmit.

Upon selecting a new cell belonging to another radio access system than UTRA, the UE enters idle mode and make an access to that system according to its specifications.

In case of low UE activity, UTRAN may want to reduce the cell-updating overhead by ordering the UE to move to the URA_PCH State. This transition is made via the CELL_FACH state. UTRAN may apply an inactivity timer, and optionally, a counter, which counts the number of cell updates e.g. UTRAN orders the UE to move to URA_PCH when the number of cell updates has exceeded certain limits (network parameter).

### B.3.3.4 UE Measurements (CELL_PCH)

The UE performs measurements and transmit measurement reports according to the measurement control information.

The UE uses the measurement control information according to the system information when no UE dedicated measurement control information has been assigned.

### B.3.3.5 Transfer and update of system information (CELL_PCH)

The UE reads the BCH to acquire valid system information. For each acquisition, the UE may need different combinations of system information broadcast on BCH. The scheduling on the broadcast channel is done in such way that the UE knows when the requested information can be found.

## B.3.4 URA_PCH State

The URA_PCH state is characterised by:

- No dedicated channel is allocated to the UE.
- The UE selects a PCH with the algorithm specified in subclause 8.5.19, and uses DRX for monitoring the selected PCH via an associated PICH.
- No uplink activity is possible.
- The location of the UE is known on UTRAN Registration area level according to the URA assigned to the UE during the last URA update in CELL_FACH state.

The DCCH logical channel cannot be used in this state. If the network wants to initiate any activity, it needs to make a paging request on the PCCH logical channel within the URA where the location of the UE is known. If the UE needs to transmit anything to the network, it goes to the CELL_FACH state. The transition to URA_PCH State can be controlled with an inactivity timer, and optionally, with a counter that counts the number of cell updates. When the number of cell updates has exceeded certain limits (a network parameter), then the UE changes to the URA_PCH State.

URA updating is initiated by the UE, which, upon the detection of the Registration area, sends the network the Registration area update information on the RACH of the new cell.

### B.3.4.1 Transition from URA_PCH State to CELL_FACH State (URA_PCH)

Any activity causes the UE to be transferred to CELL_ FACH State.

a) Uplink access is performed by RACH.

b) by paging from UTRAN ( PAGING TYPE1 message ).

NOTE: The release of an RRC connection is not possible in the URA_PCH State. The UE will first move to CELL_FACH State to perform the release signalling.

### B.3.4.2 Radio Resource Allocation Tasks (URA_PCH)

In URA_PCH State no resources have been granted for data transmission. For this purpose, a transition to CELL_FACH State has to be executed.

The UE may use Discontinuous Reception (DRX) in order to reduce power consumption. When DRX is used the UE needs only to receive at one paging occasion per DRX cycle. The UE may be instructed to use a specific DRX cycle length by the network. The UE determines its paging occasions in the same way as for Idle Mode, see [4].

### B.3.4.3 RRC Connection mobility tasks (URA_PCH)

In URA_PCH State the location of a UE is known on UTRAN Registration area level.

In this state, the UE mobility is performed through URA reselection procedures, which may differ from the definitions in [4]. The UE performs cell reselection and upon selecting a new UTRA cell belonging to a URA that does not match the URA used by the UE, the UE moves to CELL_FACH state and initiates a URA update towards the network. After the URA update procedure has been performed, the UE changes its state back to URA_PCH state if neither the UE nor the network has any more data to transmit.

Upon selecting a new cell belonging to another radio access system than UTRA, the UE enters idle mode and makes an access to that system according to its specifications.

### B.3.4.4 UE Measurements (URA_PCH)

The UE performs measurements and transmit measurement reports according to the measurement control information.

The UE uses the measurement control information according to the system information when no UE dedicated measurement control information has been assigned.

### B.3.4.5 Transfer and update of system information (URA_PCH)

The same mechanisms to transfer and update system information as for state CELL_PCH are applicable for UEs in URA_PCH state.

## B.3.5 States and Transitions for Cell Reselection in URA_PCH, CELL_PCH, and CELL_FACH




**Figure B.3.5-1: UTRA RRC Connected mode cell reselection for URA_PCH, CELL_PCH, and CELL_FACH**

In some states the UE performs cell reselection procedures. The UE selects a suitable cell (defined in [4]) and radio access technology based on connected mode radio measurements and cell reselection criteria.

Figure B.3.5-1 shows the states and procedures in the cell reselection process in connected mode.

When a cell reselection is triggered, the UE evaluates the cell reselection criteria based on radio measurements, and if a better cell is found that cell is selected, procedure Cell reselection (see [4]). If the change of cell implies a change of radio access technology, the RRC connection is released, and the UE enters idle mode of the other RAT. If no suitable cell is found in the cell reselection procedure, the UE eventually enters idle mode.

When an Initial cell reselection is triggered, the UE shall use the Initial cell reselection procedure (see [4]) to find a suitable cell. One example where this procedure is triggered is at radio link failure, where the UE may trigger an initial cell reselection in order to request re-establishment of the RRC connection. If the UE is unable to find a suitable cell, the UE eventually enters idle mode.

# B.4 Inter-RAT handover with CS domain services

When using CS domain services, UTRAN is using an Inter-Radio access system Handover Procedure and GSM is using a Handover procedure for the transition from UTRA RRC Connected Mode to GSM Connected Mode.

# B.5 Inter-RAT handover with PS domain services

When using PS domain services, the UE can initiate cell reselection from a GSM/GPRS cell to a UTRAN cell and then uses the RRC Connection Establishment procedure for the transition to UTRA RRC Connected mode. It is also possible for the BSS to initiate a UTRA Inter-RAT Handover to seamlessly relocate the UE to UTRAN. In this latter case there is no need to return the UE to Idle Mode (GPRS Packet Idle Mode) and the UE immediately moves to RRC connected state in the UTRAN.

In the case that cell reselection is used, when the RRC Connection is established from Idle Mode (GPRS Packet Idle Mode) the RRC CONNECTION REQUEST message contains an indication, that UTRAN needs to continue an already established GPRS UE context from the CN. This indication allows UTRAN to e.g. prioritise the RRC CONNECTION REQUEST from the UE.

In UTRA RRC connected mode UTRAN may use UE or network initiated cell reselection to change from a UTRAN cell to a GSM/GPRS cell. If the cell reselection was successful the UE enters Idle Mode (GPRS Packet Idle Mode). The UE sends a packet channel request from Idle Mode (GPRS Packet Idle mode) to establish a Temporary Block flow and enter GPRS Packet Transfer Mode. In the GPRS Packet Transfer Mode the UE sends a RA Update request message. The RA Update Request message sent from the UE contains an indication that GSM/GPRS need to continue an already established UTRAN UE context from the CN. This means that the RA Update request is always sent for the transition from UTRA RRC Connected Mode to GSM/GPRS regardless if the RA is changed or not.

Alternatively, the UTRAN may use an Inter-System Relocation (PS Handover) to relocate a UTRA RRC connected UE directly to GPRS Packet Transfer Mode in GERAN.

NOTE: The reason for using RA update instead of a new message is to reduce the impact on the existing GSM/GPRS specification.

# B.6 Inter-RAT handover with simultaneous PS and CS domain services

## B.6.1 Inter-RAT handover UTRAN to GSM / BSS

For a UE in CELL_DCH state using both CS and PS Domain services the Inter-RAT handover procedure is based on measurement reports from the UE but initiated from UTRAN.

The UE performs the Inter-RAT handover from UTRA RRC Connected Mode to GSM Connected Mode first. When the UE has sent handover complete message to GSM / BSS the UE initiates a temporary block flow towards GPRS and sends a RA update request.

If the Inter-RAT handover from UTRA RRC Connected Mode to GSM Connected Mode was successful the handover is considered as successful regardless if the UE was able to establish a temporary block flow or not towards GPRS.

In case of Inter-RAT handover failure the UE has the possibility to go back to UTRA RRC Connected Mode and re-establish the connection in the state it originated from.

## B.6.2 Inter-RAT handover GSM / BSS to UTRAN

For a UE in GSM Connected Mode using both CS and PS domain services the Inter-RAT handover procedure is based on measurement reports from the UE but initiated from GSM / BSS.

The UE performs the Inter-RAT handover from GSM Connected Mode to UTRA RRC Connected Mode.

In UTRA RRC Connected Mode both services are established in parallel.

If the Inter-RAT handover from GSM Connected mode to UTRA RRC Connected Mode was successful the handover is considered as successful.

In case of Inter-RAT handover failure the UE has the possibility to go back to GSM Connected Mode and re-establish the connection in the state it originated from.

# Annex C (informative): Description for the Compressed Coding of Pre-defined configurations included in the INTER RAT HANDOVER INFO message

This annex contains a description of the compressed coding of the IE "Predefined configuration status information compressed" (see subclause 10.3.4.5b) included in the INTER RAT HANDOVER INFO message.

## C.1 Definitions

**Pre-defined configuration set with different value tags:** This is a set of consecutive positions for which pre-defined configurations are stored with different value tags. The set cannot include positions for which no pre-defined configuration is stored.

**Pre-defined configuration list with variable size:** This is the variable sized list consisting of the value tags corresponding to the remaining positions after the "Pre-defined configuration sets with different value tags" have been formed. This will also indicate not stored pre-defined configurations, either explicitly or implicitly (i.e. in the case that there are no more stored configurations until the end of the variable sized list). This is highlighted in figures C.2-1 and C.2-2.

## C.2 Examples of the methodology

From figure C.2-1 it can be seen that there are two "Pre-defined configuration sets with different value tags".

The start position of Set1 is "1" with a list of 7 pre-defined configurations {1, 2, 3, 4, 5, 6, 7}.

The start position of Set2 is "10" with a list of 6 pre-defined configurations {10, 11, 12, 13, 14, 15}.

The "Pre-defined configurations list with variable size" has a start position of 0, and includes all of the pre-defined configurations not included in the sets {0, 8, 9}. The value tag at position 9 is not stored. This does not need to be explicitly indicated in the coding as "not stored" because there are no stored pre-defined configurations positioned after this in the list.




**Figure C.2-1: Example scenario where non-stored pre-defined configurations do not need to be explicitly indicated**

Figure C.2-2 is similar to Figure C.2-1. However in this case for the "Pre-defined configurations list with variable size", the pre-defined configuration in position 8 is not stored. This needs to be explicitly indicated in the coding as "not stored" because there is a stored pre-defined configuration (position 9) positioned after this in the list.




**Figure C.2-2: Example scenario where non-stored pre-defined configurations need to be explicitly indicated**

# Annex D (Normative): Implementation of Domain Specific Access Control (DSAC) in UEs of 3GPP Release 5

UEs of 3GPP Release 5 implementing the domain specific access class control feature but not implementing the network sharing feature shall act on the domain specific access class restriction indicated by the IE "Domain Specific Access Restriction Parameters For PLMN Of MIB" if present, and otherwise apply the access restrictions indicated by the IE "Cell Access Restriction".

# Annex E (informative): Change history

| Change history | | | | | | | |
|---|---|---|---|---|---|---|---|
| Date | TSG # | TSG Doc. | CR | Rev | Subject/Comment | Old | New |
| 10/1999 | RP-05 | RP-99524 | - | | Approved at TSG-RAN #5 and placed under Change Control | - | 3.0.0 |
| 12/1999 | RP-06 | RP-99650 | 001 | | Modification of RRC procedure specifications | 3.0.0 | 3.1.0 |
| | RP-06 | RP-99654 | 005 | 1 | Introduction of Information Element for Power Control Algorithm | 3.0.0 | 3.1.0 |
| | RP-06 | RP-99654 | 007 | 1 | RRC parameters for SSDT | 3.0.0 | 3.1.0 |
| | RP-06 | RP-99656 | 009 | 1 | Inclusion of information elements for integrity protection | 3.0.0 | 3.1.0 |
| | RP-06 | RP-99656 | 010 | 2 | Security mode control procedure | 3.0.0 | 3.1.0 |
| | RP-06 | RP-99656 | 011 | 3 | Updates of the system information procedure | 3.0.0 | 3.1.0 |
| | RP-06 | RP-99656 | 012 | 2 | Inter-frequency measurements and reporting | 3.0.0 | 3.1.0 |
| | RP-06 | RP-99656 | 013 | 1 | Inter-system measurements and reporting | 3.0.0 | 3.1.0 |
| | RP-06 | RP-99656 | 014 | 1 | Additional measurements in RRC measurement messages | 3.0.0 | 3.1.0 |
| | RP-06 | RP-99656 | 015 | 3 | Value range for Measurement Information Elements | 3.0.0 | 3.1.0 |
| | RP-06 | RP-99656 | 016 | 2 | Message contents for inter system handover to UTRAN | 3.0.0 | 3.1.0 |
| | RP-06 | RP-99652 | 017 | | Inclusion of ciphering information elements | 3.0.0 | 3.1.0 |
| | RP-06 | RP-99651 | 018 | | Corrections and editorial changes | 3.0.0 | 3.1.0 |
| | RP-06 | RP-99654 | 019 | 1 | Algorithm for CTCF Calculation | 3.0.0 | 3.1.0 |
| | RP-06 | RP-99651 | 025 | | Logical CH for RRC Connection Re-establishment (RRC Connection Re-establishment deleted in RAN_10, RP-000715) | 3.0.0 | 3.1.0 |
| | RP-06 | RP-99719 | 026 | 1 | Gain Factors | 3.0.0 | 3.1.0 |
| | RP-06 | RP-99654 | 027 | 1 | Parameters for CELL UPDATE CONFIRM message | 3.0.0 | 3.1.0 |
| | RP-06 | RP-99651 | 028 | | Cell Update Cause | 3.0.0 | 3.1.0 |
| | RP-06 | RP-99654 | 029 | 1 | RRC Initialisation Information | 3.0.0 | 3.1.0 |
| | RP-06 | RP-99656 | 034 | 1 | Open loop power control for PRACH | 3.0.0 | 3.1.0 |
| | RP-06 | RP-99652 | 038 | | Addition of the UE controlled AMR mode adaptation | 3.0.0 | 3.1.0 |
| | RP-06 | RP-99651 | 039 | | Information elements for RLC reset | 3.0.0 | 3.1.0 |
| | RP-06 | RP-99656 | 040 | | Support for DS-41 Initial UE Identity | 3.0.0 | 3.1.0 |
| | RP-06 | RP-99656 | 042 | 2 | Integration of Cell Broadcast Service (CBS) | 3.0.0 | 3.1.0 |
| | RP-06 | RP-99654 | 044 | 1 | Gated transmission of DPCCH | 3.0.0 | 3.1.0 |
| | RP-06 | RP-99656 | 045 | | Modification to the Transport Format Combination Control message | 3.0.0 | 3.1.0 |
| | RP-06 | RP-99656 | 046 | | New Information elements and modifications to messages required in order to support configuration and re-configuration of the DSCH in FDD mode | 3.0.0 | 3.1.0 |
| | RP-06 | RP-99654 | 047 | 1 | Editorial Corrections and Alignments with Layer 1 specifications | 3.0.0 | 3.1.0 |
| | RP-06 | RP-99654 | 048 | 1 | Information elements for TDD shared channel operation | 3.0.0 | 3.1.0 |
| | RP-06 | RP-99656 | 049 | | Description of CN dependent IEs in Master Information Block | 3.0.0 | 3.1.0 |
| | RP-06 | RP-99650 | 050 | | UE capability information elements | 3.0.0 | 3.1.0 |
| | RP-06 | RP-99656 | 051 | 1 | UTRAN response time to uplink feedback commands of TX diversity control | 3.0.0 | 3.1.0 |
| | RP-06 | RP-99654 | 052 | | New and corrected CPCH parameters | 3.0.0 | 3.1.0 |
| | RP-06 | RP-99654 | 053 | 2 | Compressed mode parameters without gating | 3.0.0 | 3.1.0 |
| | RP-06 | RP-99654 | 054 | | Transport format combination set and transport format combination subset | 3.0.0 | 3.1.0 |
| | RP-06 | RP-99656 | 055 | 1 | Information elements for cell selection and reselection | 3.0.0 | 3.1.0 |
| | RP-06 | RP-99654 | 056 | | Corrections and Alignments of the RRC to the L1 for TDD | 3.0.0 | 3.1.0 |
| | RP-06 | RP-99656 | 057 | 1 | Introduction of a SCCH procedure | 3.0.0 | 3.1.0 |
| | RP-06 | RP-99656 | 061 | | Support for DS-41 Paging UE Identity | 3.0.0 | 3.1.0 |
| | RP-06 | RP-99656 | 062 | 2 | Support for cdma2000 Hard Handover | 3.0.0 | 3.1.0 |
| | RP-06 | RP-99656 | 063 | 1 | Provide necessary signalling to support FDD DSCH | 3.0.0 | 3.1.0 |
| | RP-06 | RP-99654 | 064 | | RRC procedure interactions | 3.0.0 | 3.1.0 |
| | RP-06 | RP-99654 | 066 | 1 | Transfer of UE capabilities | 3.0.0 | 3.1.0 |
| | RP-06 | RP-99654 | 067 | | Selection of initial UE identity | 3.0.0 | 3.1.0 |
| | RP-06 | RP-99657 | 069 | | UE capability verification in the security mode control procedure | 3.0.0 | 3.1.0 |
| | RP-06 | RP-99657 | 070 | 1 | DPCH initial power | 3.0.0 | 3.1.0 |
| | RP-06 | RP-99657 | 071 | | Actions when entering idle mode | 3.0.0 | 3.1.0 |
| | RP-06 | RP-99657 | 072 | | Specification of inter-frequency and inter-system reporting events for FDD | 3.0.0 | 3.1.0 |

| Change history | | | | | | | |
|---|---|---|---|---|---|---|---|
| Date | TSG # | TSG Doc. | CR | Rev | Subject/Comment | Old | New |
| | RP-06 | RP-99657 | 073 | 1 | Signalling radio bearers | 3.0.0 | 3.1.0 |
| | RP-06 | RP-99654 | 074 | | CN information elements | 3.0.0 | 3.1.0 |
| | RP-06 | RP-99654 | 076 | | UE information elements | 3.0.0 | 3.1.0 |
| | RP-06 | RP-99657 | 077 | 1 | Radio bearer, transport channel and physical channel information elements | 3.0.0 | 3.1.0 |
| | RP-06 | RP-99654 | 078 | | Other information elements | 3.0.0 | 3.1.0 |
| | RP-06 | RP-99657 | 079 | 2 | RRC signalling for PDCP | 3.0.0 | 3.1.0 |
| | RP-06 | RP-99654 | 080 | | Content of Measurement Control Messages | 3.0.0 | 3.1.0 |
| | RP-06 | RP-99654 | 081 | | RRC Information Elements to support Block STTD transmission diversity in TDD | 3.0.0 | 3.1.0 |
| | RP-06 | RP-99657 | 082 | 1 | Signalling connection release | 3.0.0 | 3.1.0 |
| | RP-06 | RP-99657 | 083 | 1 | Addition of cell access restriction information elements to System Information | 3.0.0 | 3.1.0 |
| | RP-06 | RP-99655 | 085 | 1 | RRC Connection Establishment parameters | 3.0.0 | 3.1.0 |
| | RP-06 | RP-99657 | 092 | 1 | Support of UE autonomous update of a active set on a non-used frequency | 3.0.0 | 3.1.0 |
| | RP-06 | RP-99657 | 095 | 1 | TPC combining for power control | 3.0.0 | 3.1.0 |
| | RP-06 | RP-99653 | 096 | 1 | Editorial Modification of IEs in RRC messages | 3.0.0 | 3.1.0 |
| | RP-06 | RP-99655 | 097 | | Selection of SCCPCH | 3.0.0 | 3.1.0 |
| | RP-06 | RP-99655 | 098 | 1 | RRC Initialisation Information | 3.0.0 | 3.1.0 |
| | RP-06 | RP-99657 | 100 | 1 | Support of physical channel establishment and failure criteria in the UE | 3.0.0 | 3.1.0 |
| | RP-06 | RP-99655 | 102 | 1 | RRC Connection Re-establishment (Message deleted in RAN_10, RP-000715) | 3.0.0 | 3.1.0 |
| | RP-06 | RP-99657 | 106 | 1 | System information on FACH | 3.0.0 | 3.1.0 |
| | RP-06 | RP-99657 | 108 | 1 | SAPs and Primitives for DS-41 mode | 3.0.0 | 3.1.0 |
| | RP-06 | RP-99655 | 109 | 1 | TX Diversity Mode for Dedicated Channel | 3.0.0 | 3.1.0 |
| | RP-06 | RP-99657 | 110 | 1 | RACH message length signalling on System Information | 3.0.0 | 3.1.0 |
| | RP-06 | RP-99657 | 113 | 1 | Routing of NAS messages in UTRAN | 3.0.0 | 3.1.0 |
| | RP-06 | RP-99655 | 116 | 3 | TBS Identification in TFS | 3.0.0 | 3.1.0 |
| | RP-06 | RP-99657 | 117 | 1 | Merging the hard handover and some radio bearer control procedures | 3.0.0 | 3.1.0 |
| | RP-06 | RP-99653 | 120 | 1 | Selected RRC message transfer syntax | 3.0.0 | 3.1.0 |
| | RP-06 | RP-99657 | 121 | | Efficient rate command signalling | 3.0.0 | 3.1.0 |
| 03/2000 | RP-07 | RP-000043 | 122 | | TDD Mode BCH Reception in Cell DCH State | 3.1.0 | 3.2.0 |
| | RP-07 | RP-000043 | 123 | | Uplink Outer Loop Power Control in TDD Mode | 3.1.0 | 3.2.0 |
| | RP-07 | RP-000043 | 124 | 1 | TFS TB Size Calculation with Bit Aligned TDD MAC Headers | 3.1.0 | 3.2.0 |
| | RP-07 | RP-000043 | 125 | | Grouping of DRAC IEs, and detailed definitions of these IEs | 3.1.0 | 3.2.0 |
| | RP-07 | RP-000043 | 126 | | Correction of specifications for the 'Dynamic Resource Allocation Control of Uplink DCH' Procedure | 3.1.0 | 3.2.0 |
| | RP-07 | RP-000043 | 131 | 2 | Clarification of PDCP info and PDCP capability IEs | 3.1.0 | 3.2.0 |
| | RP-07 | RP-000043 | 132 | | Editorial change to "Specification of system information block characteristics" | 3.1.0 | 3.2.0 |
| | RP-07 | RP-000043 | 133 | | Additions of CBS related Information Elements | 3.1.0 | 3.2.0 |
| | RP-07 | RP-000043 | 134 | | Signalling for computed gain factors | 3.1.0 | 3.2.0 |
| | RP-07 | RP-000043 | 137 | 1 | General error handling procedures | 3.1.0 | 3.2.0 |
| | RP-07 | RP-000043 | 138 | 1 | RRC message extensions | 3.1.0 | 3.2.0 |
| | RP-07 | RP-000043 | 139 | | Padding of RRC messages using RLC transparent mode | 3.1.0 | 3.2.0 |
| | RP-07 | RP-000043 | 140 | 2 | UE information elements | 3.1.0 | 3.2.0 |
| | RP-07 | RP-000043 | 141 | | Other information elements | 3.1.0 | 3.2.0 |
| | RP-07 | RP-000043 | 142 | 3 | Integrity protection function | 3.1.0 | 3.2.0 |
| | RP-07 | RP-000043 | 143 | 4 | RAB-RB relations | 3.1.0 | 3.2.0 |
| | RP-07 | RP-000043 | 144 | 1 | Inter-system handover from UTRAN | 3.1.0 | 3.2.0 |
| | RP-07 | RP-000043 | 145 | 3 | Handover to UTRAN including procedure for pre- configuration | 3.1.0 | 3.2.0 |
| | RP-07 | RP-000043 | 146 | 2 | RRC measurement filtering parameters | 3.1.0 | 3.2.0 |
| | RP-07 | RP-000043 | 147 | | New event "RL out of UE Rx window" | 3.1.0 | 3.2.0 |
| | RP-07 | RP-000044 | 148 | 1 | Access control on RACH | 3.1.0 | 3.2.0 |
| | RP-07 | RP-000044 | 149 | 2 | cdma2000 Hard Handover | 3.1.0 | 3.2.0 |
| | RP-07 | RP-000044 | 150 | 1 | CPCH parameters with corrections | 3.1.0 | 3.2.0 |
| | RP-07 | RP-000044 | 152 | | U-plane AM RLC reconfiguration by cell update procedure | 3.1.0 | 3.2.0 |

| Change history | | | | | | | |
|---|---|---|---|---|---|---|---|
| Date | TSG # | TSG Doc. | CR | Rev | Subject/Comment | Old | New |
| | RP-07 | RP-000044 | 154 | 3 | CPCH | 3.1.0 | 3.2.0 |
| | RP-07 | RP-000044 | 155 | 1 | Information elements for ASC in TDD | 3.1.0 | 3.2.0 |
| | RP-07 | RP-000044 | 156 | | Addition of timing advance value in handover related messages | 3.1.0 | 3.2.0 |
| | RP-07 | RP-000044 | 157 | 2 | Physical channel description for TDD | 3.1.0 | 3.2.0 |
| | RP-07 | RP-000044 | 159 | | Message contents for the intersystem command message to UTRAN operating in TDD mode | 3.1.0 | 3.2.0 |
| | RP-07 | RP-000044 | 160 | | Corrections on use of PUSCH power control info and minor corrections | 3.1.0 | 3.2.0 |
| | RP-07 | RP-000044 | 162 | 2 | UE individual DRX cycles in CELL_PCH and URA_PCH states | 3.1.0 | 3.2.0 |
| | RP-07 | RP-000044 | 163 | | Correction to Transport Format Combination Control procedure | 3.1.0 | 3.2.0 |
| | RP-07 | RP-000044 | 164 | 3 | Downlink outer loop power control | 3.1.0 | 3.2.0 |
| | RP-07 | RP-000044 | 165 | 2 | Redirection of RRC connection setup | 3.1.0 | 3.2.0 |
| | RP-07 | RP-000044 | 166 | 2 | Inter-frequency measurements in CELL_FACH state | 3.1.0 | 3.2.0 |
| | RP-07 | RP-000044 | 167 | | List of found editorial mistakes in the Dec99 version of 25.331 (V3.1.0) | 3.1.0 | 3.2.0 |
| | RP-07 | RP-000044 | 168 | 1 | Transport block size | 3.1.0 | 3.2.0 |
| | RP-07 | RP-000044 | 169 | 1 | Cell Access Restriction | 3.1.0 | 3.2.0 |
| | RP-07 | RP-000044 | 170 | | Editorial modification | 3.1.0 | 3.2.0 |
| | RP-07 | RP-000044 | 171 | | Modification of DPCH info | 3.1.0 | 3.2.0 |
| | RP-07 | RP-000045 | 172 | 1 | Measurement control message | 3.1.0 | 3.2.0 |
| | RP-07 | RP-000045 | 173 | 2 | Reporting cell status | 3.1.0 | 3.2.0 |
| | RP-07 | RP-000045 | 174 | | Additional IE for RB release | 3.1.0 | 3.2.0 |
| | RP-07 | RP-000045 | 175 | | Available SF in PRACH info | 3.1.0 | 3.2.0 |
| | RP-07 | RP-000045 | 176 | | Traffic volume measurement event | 3.1.0 | 3.2.0 |
| | RP-07 | RP-000045 | 177 | | Report of multiple cells on an event result | 3.1.0 | 3.2.0 |
| | RP-07 | RP-000045 | 178 | | Editorial modification on Direct Transfer | 3.1.0 | 3.2.0 |
| | RP-07 | RP-000045 | 179 | | Correction of the Security Mode Control procedure | 3.1.0 | 3.2.0 |
| | RP-07 | RP-000045 | 180 | 1 | Maximum calculated Transport Format Combination | 3.1.0 | 3.2.0 |
| | RP-07 | RP-000045 | 183 | | Additional DPCH IEs to align 25.331 with 25.214 | 3.1.0 | 3.2.0 |
| | RP-07 | RP-000045 | 184 | 1 | RB – DCH mapping | 3.1.0 | 3.2.0 |
| | RP-07 | RP-000045 | 188 | 1 | Modifications related to FDD mode DSCH | 3.1.0 | 3.2.0 |
| | RP-07 | RP-000045 | 189 | 1 | Identification of Shared Channel Physical Configuration in TDD Mode | 3.1.0 | 3.2.0 |
| | RP-07 | RP-000045 | 192 | 1 | Uplink Outer Loop Power Control During Hard Handover | 3.1.0 | 3.2.0 |
| | RP-07 | RP-000045 | 193 | | Support of Multiple CCTrCH's in TDD Mode | 3.1.0 | 3.2.0 |
| | RP-07 | RP-000045 | 194 | 1 | Uplink Physical Channel Control in TDD Mode | 3.1.0 | 3.2.0 |
| | RP-07 | RP-000045 | 201 | 1 | Transfer of initial information from UE to target RNC prior to handover to UTRAN | 3.1.0 | 3.2.0 |
| | RP-07 | RP-000045 | 202 | 1 | CN information elements | 3.1.0 | 3.2.0 |
| | RP-07 | RP-000045 | 203 | | UTRAN mobility information elements | 3.1.0 | 3.2.0 |
| | RP-07 | RP-000045 | 204 | 1 | RB information elements | 3.1.0 | 3.2.0 |
| | RP-07 | RP-000046 | 205 | 1 | Physical channel information elements | 3.1.0 | 3.2.0 |
| | RP-07 | RP-000046 | 206 | 1 | UE capability information elements | 3.1.0 | 3.2.0 |
| | RP-07 | RP-000046 | 207 | | UE variables | 3.1.0 | 3.2.0 |
| | RP-07 | RP-000046 | 208 | 1 | Actions when entering idle mode | 3.1.0 | 3.2.0 |
| | RP-07 | RP-000046 | 209 | | Usage of pilot bits | 3.1.0 | 3.2.0 |
| | RP-07 | RP-000046 | 210 | | System information procedure corrections | 3.1.0 | 3.2.0 |
| | RP-07 | RP-000046 | 212 | | Reconfiguration of ciphering | 3.1.0 | 3.2.0 |
| | RP-07 | RP-000046 | 213 | 1 | Enhancements to RRC connection re-establishment procedure (Message subsequently deleted in RAN_!), RP-000715) | 3.1.0 | 3.2.0 |
| | RP-07 | RP-000046 | 215 | | Updates to RRC Initialisation Information transparent container and addition of reverse direction container description | 3.1.0 | 3.2.0 |
| | RP-07 | RP-000046 | 220 | 1 | Changes in RRC messages to support lossless SRNC relocation | 3.1.0 | 3.2.0 |
| | RP-07 | RP-000046 | 229 | 1 | Measurements of unlisted neighbouring cells | 3.1.0 | 3.2.0 |
| | RP-07 | RP-000046 | 234 | 2 | Inclusion of Location Services | 3.1.0 | 3.2.0 |
| | RP-07 | RP-000046 | 236 | 1 | Application of Access Service Classes and relation to Access Classes | 3.1.0 | 3.2.0 |
| | RP-07 | RP-000046 | 252 | 1 | DRX indicator presence and state entering mechanism at the end of a procedure | 3.1.0 | 3.2.0 |
| | RP-07 | RP-000046 | 254 | 1 | Physical shared channel allocation procedure | 3.1.0 | 3.2.0 |

| Change history | | | | | | | |
|---|---|---|---|---|---|---|---|
| Date | TSG # | TSG Doc. | CR | Rev | Subject/Comment | Old | New |
| | RP-07 | RP-000046 | 255 | | Corrections to TDD specific parameters in PICH info | 3.1.0 | 3.2.0 |
| | RP-07 | RP-000046 | 256 | | Editorial modifications | 3.1.0 | 3.2.0 |
| | RP-07 | RP-000046 | 259 | 2 | Introduction of mapping function information in Cell selection and | 3.1.0 | 3.2.0 |
| | RP-07 | RP-000046 | 263 | | Ciphering and integrity HFN | 3.1.0 | 3.2.0 |
| | RP-07 | RP-000046 | 267 | | New SIB for UP | 3.1.0 | 3.2.0 |
| | RP-07 | RP-000047 | 268 | | Removal of synchronization Case 3 | 3.1.0 | 3.2.0 |
| | RP-07 | RP-000047 | 271 | | TX Diversity | 3.1.0 | 3.2.0 |
| | RP-07 | RP-000047 | 272 | | Update of tabular format clause 10 | 3.1.0 | 3.2.0 |
| | RP-07 | RP-000047 | 273 | | ASN.1 description | 3.1.0 | 3.2.0 |
| 06/2000 | RP-08 | RP-000222 | 228 | 5 | Downlink power control in compressed mode | 3.2.0 | 3.3.0 |
| | RP-08 | RP-000222 | 260 | 1 | Clarification on physical channel allocations in TDD | 3.2.0 | 3.3.0 |
| | RP-08 | RP-000222 | 261 | 4 | TDD Measurements and Reporting | 3.2.0 | 3.3.0 |
| | RP-08 | RP-000222 | 262 | 4 | Signalling of IEs related to System Information on FACH | 3.2.0 | 3.3.0 |
| | RP-08 | RP-000222 | 265 | 3 | Transport Format Combination Control | 3.2.0 | 3.3.0 |
| | RP-08 | RP-000222 | 269 | 1 | Signalling of partial failure in radio bearer related procedures | 3.2.0 | 3.3.0 |
| | RP-08 | RP-000222 | 275 | | Clarification on PDCP info | 3.2.0 | 3.3.0 |
| | RP-08 | RP-000222 | 279 | | Editorial modification on Transport Ch capability | 3.2.0 | 3.3.0 |
| | RP-08 | RP-000222 | 280 | | Editorial modification on CN IE | 3.2.0 | 3.3.0 |
| | RP-08 | RP-000222 | 281 | 3 | Editorial modification on Physical CH IE | 3.2.0 | 3.3.0 |
| | RP-08 | RP-000222 | 282 | 1 | Editorial modification on ASN.1 description | 3.2.0 | 3.3.0 |
| | RP-08 | RP-000222 | 283 | 1 | IEs on SIB5/6 | 3.2.0 | 3.3.0 |
| | RP-08 | RP-000222 | 285 | 2 | Re-establishment timer | 3.2.0 | 3.3.0 |
| | RP-08 | RP-000222 | 286 | 1 | CN DRX cycle coefficient | 3.2.0 | 3.3.0 |
| | RP-08 | RP-000222 | 287 | 1 | Cell Access Restriction | 3.2.0 | 3.3.0 |
| | RP-08 | RP-000222 | 288 | 1 | Cell selection and re-selection parameters | 3.2.0 | 3.3.0 |
| | RP-08 | RP-000222 | 289 | 2 | Modification on Measurement IE | 3.2.0 | 3.3.0 |
| | RP-08 | RP-000222 | 291 | 1 | RACH Transmission parameters | 3.2.0 | 3.3.0 |
| | RP-08 | RP-000222 | 292 | 1 | SCCPCH System Info | 3.2.0 | 3.3.0 |
| | RP-08 | RP-000222 | 293 | 1 | Addition of HFN for RRC CONNECTION RE-ESTABLISHMENT COMPLETE | 3.2.0 | 3.3.0 |
| | RP-08 | RP-000223 | 294 | 1 | RLC reconfiguration indicator | 3.2.0 | 3.3.0 |
| | RP-08 | RP-000223 | 296 | 3 | RLC Info | 3.2.0 | 3.3.0 |
| | RP-08 | RP-000223 | 297 | 1 | Usage of Transport CH ID | 3.2.0 | 3.3.0 |
| | RP-08 | RP-000223 | 298 | 2 | Transport format combination set | 3.2.0 | 3.3.0 |
| | RP-08 | RP-000223 | 300 | 1 | Usage of U-RNTI and C-RNTI in DL DCCH message | 3.2.0 | 3.3.0 |
| | RP-08 | RP-000223 | 301 | | Description of Cell Update Procedure | 3.2.0 | 3.3.0 |
| | RP-08 | RP-000223 | 304 | 1 | System information modification procedure | 3.2.0 | 3.3.0 |
| | RP-08 | RP-000223 | 305 | | Functional descriptions of the RRC messages | 3.2.0 | 3.3.0 |
| | RP-08 | RP-000223 | 306 | | Clarification of CTFC calculation | 3.2.0 | 3.3.0 |
| | RP-08 | RP-000223 | 307 | 3 | Compressed mode parameters | 3.2.0 | 3.3.0 |
| | RP-08 | RP-000223 | 309 | 2 | Signalling procedure for periodic local authentication | 3.2.0 | 3.3.0 |
| | RP-08 | RP-000223 | 310 | 5 | Editorial corrections on security | 3.2.0 | 3.3.0 |
| | RP-08 | RP-000223 | 311 | 2 | Security capability | 3.2.0 | 3.3.0 |
| | RP-08 | RP-000223 | 312 | 1 | Corrections on ASN.1 definitions | 3.2.0 | 3.3.0 |
| | RP-08 | RP-000223 | 313 | 2 | DRX cycle lower limit | 3.2.0 | 3.3.0 |
| | RP-08 | RP-000223 | 314 | 1 | Removal of CPICH SIR measurement quantity | 3.2.0 | 3.3.0 |
| | RP-08 | RP-000223 | 315 | 1 | Signalling connection release request | 3.2.0 | 3.3.0 |
| | RP-08 | RP-000223 | 318 | 1 | Change to IMEI coding from BCD to hexadecimal | 3.2.0 | 3.3.0 |
| | RP-08 | RP-000223 | 319 | 1 | Removal of RLC sequence numbers from RRC initialisation information | 3.2.0 | 3.3.0 |
| | RP-08 | RP-000223 | 320 | 3 | Addition of the length of PDCP sequence numbers into PDCP info | 3.2.0 | 3.3.0 |
| | RP-08 | RP-000224 | 323 | 1 | BSIC verification of GSM cells | 3.2.0 | 3.3.0 |
| | RP-08 | RP-000224 | 324 | | Reporting cell status | 3.2.0 | 3.3.0 |
| | RP-08 | RP-000224 | 325 | | RRC measurement filtering parameters | 3.2.0 | 3.3.0 |
| | RP-08 | RP-000224 | 326 | | Cell-reselection parameter signalling | 3.2.0 | 3.3.0 |
| | RP-08 | RP-000224 | 328 | 3 | Multiplicity values | 3.2.0 | 3.3.0 |
| | RP-08 | RP-000224 | 329 | | Quality measurements | 3.2.0 | 3.3.0 |

| Change history | | | | | | | |
|---|---|---|---|---|---|---|---|
| Date | TSG # | TSG Doc. | CR | Rev | Subject/Comment | Old | New |
| | RP-08 | RP-000224 | 330 | 4 | CPCH Status Indication mode correction | 3.2.0 | 3.3.0 |
| | RP-08 | RP-000224 | 331 | 4 | End of CPCH transmission | 3.2.0 | 3.3.0 |
| | RP-08 | RP-000224 | 332 | | Handover to UTRAN procedure | 3.2.0 | 3.3.0 |
| | RP-08 | RP-000224 | 333 | | Harmonization of access service classes in FDD and TDD | 3.2.0 | 3.3.0 |
| | RP-08 | RP-000224 | 334 | 1 | Correction to usage of primary CCPCH info and primary CPICH info | 3.2.0 | 3.3.0 |
| | RP-08 | RP-000224 | 335 | | Corrections and clarifications on system information handling | 3.2.0 | 3.3.0 |
| | RP-08 | RP-000224 | 336 | | Editorial corrections | 3.2.0 | 3.3.0 |
| | RP-08 | RP-000224 | 337 | 1 | Editorial corrections on uplink timing advance | 3.2.0 | 3.3.0 |
| | RP-08 | RP-000224 | 339 | | Correction of Transport Format Combination tabular format and ASN.1 | 3.2.0 | 3.3.0 |
| | RP-08 | RP-000224 | 340 | 1 | UE variables | 3.2.0 | 3.3.0 |
| | RP-08 | RP-000224 | 342 | 1 | General error handling | 3.2.0 | 3.3.0 |
| | RP-08 | RP-000224 | 344 | 1 | System Information extensibility in ASN.1 definitions | 3.2.0 | 3.3.0 |
| | RP-08 | RP-000224 | 345 | | Usage of pilot bits | 3.2.0 | 3.3.0 |
| | RP-08 | RP-000224 | 346 | 3 | RRC connection release procedure | 3.2.0 | 3.3.0 |
| | RP-08 | RP-000225 | 347 | 1 | Alignment of Section 10.3 on methodology defined in 25.921 | 3.2.0 | 3.3.0 |
| | RP-08 | RP-000225 | 348 | | Modifications of cell (re)selection parameters | 3.2.0 | 3.3.0 |
| | RP-08 | RP-000225 | 350 | 1 | GPS time-of-week represented as seconds and fractions of seconds | 3.2.0 | 3.3.0 |
| | RP-08 | RP-000225 | 351 | 2 | CPCH corrections | 3.2.0 | 3.3.0 |
| | RP-08 | RP-000225 | 352 | | PLMN type selection | 3.2.0 | 3.3.0 |
| | RP-08 | RP-000225 | 353 | 3 | Paging and establishment cause values | 3.2.0 | 3.3.0 |
| | RP-08 | RP-000225 | 354 | | Common channel configurations | 3.2.0 | 3.3.0 |
| | RP-08 | RP-000225 | 355 | 2 | Clarification of prioritization of logical channels in UE | 3.2.0 | 3.3.0 |
| | RP-08 | RP-000225 | 357 | 2 | UE capability corrections | 3.2.0 | 3.3.0 |
| | RP-08 | RP-000225 | 358 | 2 | Clarification of HFN | 3.2.0 | 3.3.0 |
| | RP-08 | RP-000225 | 359 | 3 | Clarification of Integrity Protection | 3.2.0 | 3.3.0 |
| | RP-08 | RP-000225 | 360 | 1 | RRC message size optimization regarding TrCH parameters | 3.2.0 | 3.3.0 |
| | RP-08 | RP-000225 | 361 | | Protocol extensions in ASN | 3.2.0 | 3.3.0 |
| | RP-08 | RP-000225 | 362 | 1 | Downloading of pre- defined configurations via SIB 16 | 3.2.0 | 3.3.0 |
| | RP-08 | RP-000225 | 363 | 1 | Optimization of System Information | 3.2.0 | 3.3.0 |
| | RP-08 | RP-000225 | 364 | 1 | CPCH gain factor | 3.2.0 | 3.3.0 |
| | RP-08 | RP-000225 | 368 | 2 | SFN Transmission Rate in TDD Mode | 3.2.0 | 3.3.0 |
| | RP-08 | RP-000225 | 371 | 1 | Integrity Control | 3.2.0 | 3.3.0 |
| | RP-08 | RP-000225 | 372 | | Modification to measurement event evaluation | 3.2.0 | 3.3.0 |
| | RP-08 | RP-000225 | 373 | | System Information related parameters | 3.2.0 | 3.3.0 |
| | RP-08 | RP-000226 | 375 | 1 | Changes in RB mapping info | 3.2.0 | 3.3.0 |
| | RP-08 | RP-000226 | 377 | | Editorial corrections to PRACH system information and Cell info | 3.2.0 | 3.3.0 |
| | RP-08 | RP-000226 | 378 | | Editorial Corrections to 25.331 Procedures and Tabular Format | 3.2.0 | 3.3.0 |
| | RP-08 | RP-000226 | 379 | 1 | Corrections to figures and procedures for the failure cases | 3.2.0 | 3.3.0 |
| | RP-08 | RP-000226 | 380 | | Corrections on use of ORDERED_CONFIG | 3.2.0 | 3.3.0 |
| | RP-08 | RP-000226 | 382 | 1 | Corrections to Transport Channel and RB Reconfiguration procedures | 3.2.0 | 3.3.0 |
| | RP-08 | RP-000226 | 383 | 1 | Corrections to INITIAL DIRECT TRANSFER and UE CAPABILITY INFORMATION CONFIRM procedures | 3.2.0 | 3.3.0 |
| | RP-08 | RP-000226 | 384 | | Corrections to Transparent mode signalling info Tabular format and ASN.1 | 3.2.0 | 3.3.0 |
| | RP-08 | RP-000226 | 385 | | Corrections to Soft Handover messages and procedures | 3.2.0 | 3.3.0 |
| | RP-08 | RP-000226 | 387 | | Corrections to RRC CONNECTION REJECT procedures | 3.2.0 | 3.3.0 |
| | RP-08 | RP-000226 | 388 | 1 | Transport format combination in TDD and Transport channel ID | 3.2.0 | 3.3.0 |
| | RP-08 | RP-000226 | 389 | 1 | Signalling for dynamic TTI in TDD | 3.2.0 | 3.3.0 |
| | RP-08 | RP-000226 | 390 | 1 | Usage of DCCH for Shared Channel Allocation message | 3.2.0 | 3.3.0 |
| | RP-08 | RP-000226 | 391 | 1 | Correction to physical channel IEs in TDD | 3.2.0 | 3.3.0 |
| | RP-08 | RP-000226 | 392 | 1 | TDD preconfiguration for Handover to UTRAN | 3.2.0 | 3.3.0 |
| | RP-08 | RP-000226 | 393 | | Corrections to measurement control descriptions and messages | 3.2.0 | 3.3.0 |
| | RP-08 | RP-000226 | 394 | 1 | Corrections on ASN.1 definitions | 3.2.0 | 3.3.0 |
| | RP-08 | RP-000226 | 395 | | Addition of the Segmentation indication field for transparent mode RLC in the RLC Info | 3.2.0 | 3.3.0 |

| Change history | | | | | | | |
|---|---|---|---|---|---|---|---|
| Date | TSG # | TSG Doc. | CR | Rev | Subject/Comment | Old | New |
| | RP-08 | RP-000226 | 396 | 1 | Radio Bearer identity for CCCH | 3.2.0 | 3.3.0 |
| | RP-08 | RP-000226 | 397 | 1 | ASN.1 definitions for RRC information between network nodes | 3.2.0 | 3.3.0 |
| | RP-08 | RP-000227 | 398 | 1 | NAS Routing | 3.2.0 | 3.3.0 |
| | RP-08 | RP-000227 | 399 | | DPCCH power control preamble | 3.2.0 | 3.3.0 |
| | RP-08 | RP-000227 | 400 | 2 | Modifications of Assisted GPS Messages | 3.2.0 | 3.3.0 |
| | RP-08 | RP-000227 | 401 | | Choice of Initial UE Identity | 3.2.0 | 3.3.0 |
| | RP-08 | RP-000227 | 402 | | ANSI-41 information elements | 3.2.0 | 3.3.0 |
| | RP-08 | RP-000227 | 404 | 1 | RLC value ranges | 3.2.0 | 3.3.0 |
| | RP-08 | RP-000227 | 408 | 1 | HFN Reset | 3.2.0 | 3.3.0 |
| | RP-08 | RP-000227 | 409 | 1 | Clarification on ciphering parameters and integrity protection procedure in case of SRNS relocation | 3.2.0 | 3.3.0 |
| | RP-08 | RP-000227 | 410 | 1 | Clarification of compressed mode activation and configuration failure | 3.2.0 | 3.3.0 |
| | RP-08 | RP-000227 | 412 | 1 | Modification of the RLC Size IE | 3.2.0 | 3.3.0 |
| | RP-08 | RP-000227 | 414 | | CPCH DL Power control | 3.2.0 | 3.3.0 |
| | RP-08 | RP-000227 | 415 | 1 | SFN measurements in TDD | 3.2.0 | 3.3.0 |
| 09/2000 | RP-09 | RP-000361 | 356 | 3 | Clarification on multiplicity of PCH and PICH and S-CCPCH selection | 3.3.0 | 3.4.0 |
| | RP-09 | RP-000361 | 403 | 3 | Parameters to be stored in the USIM | 3.3.0 | 3.4.0 |
| | RP-09 | RP-000361 | 413 | 3 | Optimization of Inter-system handover message | 3.3.0 | 3.4.0 |
| | RP-09 | RP-000361 | 416 | 2 | Timing Advance in Handover Procedures | 3.3.0 | 3.4.0 |
| | RP-09 | RP-000361 | 417 | 2 | Synchronization of Timing Advance and Timing Deviation Measurement | 3.3.0 | 3.4.0 |
| | RP-09 | RP-000361 | 418 | | Downlink Physical Channels Per Timeslot | 3.3.0 | 3.4.0 |
| | RP-09 | RP-000361 | 419 | | TDD Mode DCH Reception in Cell DCH State | 3.3.0 | 3.4.0 |
| | RP-09 | RP-000361 | 420 | 2 | Downlink Power Control During DTX in TDD Mode | 3.3.0 | 3.4.0 |
| | RP-09 | RP-000361 | 421 | 1 | Paging Indicator Length Definition | 3.3.0 | 3.4.0 |
| | RP-09 | RP-000361 | 422 | | Updating & alignment of RRC containers & handover to UTRAN information transfer | 3.3.0 | 3.4.0 |
| | RP-09 | RP-000361 | 424 | | Default values for UE timers and counters | 3.3.0 | 3.4.0 |
| | RP-09 | RP-000361 | 425 | 1 | Security mode control | 3.3.0 | 3.4.0 |
| | RP-09 | RP-000361 | 426 | 1 | Corrections and Editorial updates to chapter 8 | 3.3.0 | 3.4.0 |
| | RP-09 | RP-000361 | 427 | | Corrections and editorial updates to chapter 10 | 3.3.0 | 3.4.0 |
| | RP-09 | RP-000361 | 428 | | Transition from CELL_DCH to CELL_PCH and URA_PCH state | 3.3.0 | 3.4.0 |
| | RP-09 | RP-000361 | 430 | | Assisted GPS Messaging and Procedures | 3.3.0 | 3.4.0 |
| | RP-09 | RP-000361 | 431 | 2 | Corrections to Activation Time use | 3.3.0 | 3.4.0 |
| | RP-09 | RP-000361 | 432 | | Editorial Corrections to measurement reporting range | 3.3.0 | 3.4.0 |
| | RP-09 | RP-000361 | 434 | 4 | Default DPCH offset value and DPCH offset | 3.3.0 | 3.4.0 |
| | RP-09 | RP-000361 | 435 | 3 | RLC info | 3.3.0 | 3.4.0 |
| | RP-09 | RP-000362 | 437 | | Clarification of the description of IE semantics in "RB with PDCP information" | 3.3.0 | 3.4.0 |
| | RP-09 | RP-000362 | 438 | 1 | Editorial corrections on security | 3.3.0 | 3.4.0 |
| | RP-09 | RP-000362 | 439 | | Editorial correction to RB mapping info | 3.3.0 | 3.4.0 |
| | RP-09 | RP-000362 | 440 | 1 | Compressed mode configuration failure | 3.3.0 | 3.4.0 |
| | RP-09 | RP-000362 | 441 | | Gain factors for TDD | 3.3.0 | 3.4.0 |
| | RP-09 | RP-000362 | 442 | | Introduction of Default DPCH Offset Value in TDD | 3.3.0 | 3.4.0 |
| | RP-09 | RP-000362 | 444 | 1 | Optimization of handover to UTRAN command | 3.3.0 | 3.4.0 |
| | RP-09 | RP-000362 | 445 | | Editorial corrections | 3.3.0 | 3.4.0 |
| | RP-09 | RP-000362 | 448 | 1 | Mapping of channelisation code | 3.3.0 | 3.4.0 |
| | RP-09 | RP-000362 | 449 | 2 | DL TFCS Limitation | 3.3.0 | 3.4.0 |
| | RP-09 | RP-000362 | 450 | | SIB offset | 3.3.0 | 3.4.0 |
| | RP-09 | RP-000362 | 451 | | RRC CONNECTION RELEASE cause | 3.3.0 | 3.4.0 |
| | RP-09 | RP-000362 | 452 | | Addition of RACH TFCS | 3.3.0 | 3.4.0 |
| | RP-09 | RP-000362 | 453 | 2 | Cell Identity | 3.3.0 | 3.4.0 |
| | RP-09 | RP-000362 | 454 | | Editorial Modifications | 3.3.0 | 3.4.0 |
| | RP-09 | RP-000362 | 455 | 1 | TDD PRACH Power Control for Spreading Factor 8/16 | 3.3.0 | 3.4.0 |
| | RP-09 | RP-000362 | 456 | | TDD CCTrCH Repetition Length Definition | 3.3.0 | 3.4.0 |
| | RP-09 | RP-000362 | 457 | 1 | Reporting threshold of traffic volume measurements | 3.3.0 | 3.4.0 |
| | RP-09 | RP-000362 | 459 | 2 | UP GPS assistance data for SIB | 3.3.0 | 3.4.0 |

| Change history | | | | | | | |
|---|---|---|---|---|---|---|---|
| Date | TSG # | TSG Doc. | CR | Rev | Subject/Comment | Old | New |
| | RP-09 | RP-000362 | 461 | 1 | Support of cell update confirm on CCCH | 3.3.0 | 3.4.0 |
| | RP-09 | RP-000363 | 462 | 1 | Max Window Size in RLC capabilities | 3.3.0 | 3.4.0 |
| | RP-09 | RP-000363 | 463 | 3 | UE handling of CFN | 3.3.0 | 3.4.0 |
| | RP-09 | RP-000363 | 464 | 1 | Correction of padding description in clause 12 | 3.3.0 | 3.4.0 |
| | RP-09 | RP-000363 | 465 | 1 | Window size in RLC info | 3.3.0 | 3.4.0 |
| | RP-09 | RP-000363 | 466 | 1 | TFC Control Duration | 3.3.0 | 3.4.0 |
| | RP-09 | RP-000363 | 467 | | System Information Block Tabular Information | 3.3.0 | 3.4.0 |
| | RP-09 | RP-000363 | 469 | 1 | Frequency encoding in inter-system handover messages | 3.3.0 | 3.4.0 |
| | RP-09 | RP-000363 | 470 | | RRC message size optimization regarding TFS parameters | 3.3.0 | 3.4.0 |
| | RP-09 | RP-000363 | 471 | 2 | RACH selection | 3.3.0 | 3.4.0 |
| | RP-09 | RP-000363 | 472 | | DRX cycle lower limit | 3.3.0 | 3.4.0 |
| | RP-09 | RP-000363 | 474 | | Rx window size in RLC info | 3.3.0 | 3.4.0 |
| | RP-09 | RP-000363 | 476 | 1 | Corrections & optimizations regarding system information blocks of length 215..221 | 3.3.0 | 3.4.0 |
| | RP-09 | RP-000363 | 477 | 1 | Corrections on 8.1.1 resulting from RRC review at R2#14 | 3.3.0 | 3.4.0 |
| | RP-09 | RP-000363 | 478 | 1 | Corrections to the RRC connection release procedure | 3.3.0 | 3.4.0 |
| | RP-09 | RP-000363 | 479 | 1 | New release cause for signalling connection re-establishment | 3.3.0 | 3.4.0 |
| | RP-09 | RP-000363 | 480 | 1 | Correction to IE midamble shift and burst type | 3.3.0 | 3.4.0 |
| | RP-09 | RP-000363 | 481 | 1 | Correction in RLC info | 3.3.0 | 3.4.0 |
| | RP-09 | RP-000363 | 483 | | Description of CTCH occasions | 3.3.0 | 3.4.0 |
| | RP-09 | RP-000363 | 485 | 1 | TDD CCTrCH UL/DL Pairing for Inner Loop Power Control | 3.3.0 | 3.4.0 |
| | RP-09 | RP-000363 | 486 | 1 | DCCH and BCCH Signalling of TDD UL OL PC Information | 3.3.0 | 3.4.0 |
| | RP-09 | RP-000364 | 487 | 1 | Broadcast SIBs for TDD UL OL PC Information | 3.3.0 | 3.4.0 |
| | RP-09 | RP-000364 | 490 | 1 | CPCH corrections | 3.3.0 | 3.4.0 |
| | RP-09 | RP-000364 | 492 | 3 | Corrections to Security IEs | 3.3.0 | 3.4.0 |
| | RP-09 | RP-000364 | 494 | 1 | Corrections to parameters to be stored in the USIM | 3.3.0 | 3.4.0 |
| | RP-09 | RP-000364 | 496 | | Editorial corrections | 3.3.0 | 3.4.0 |
| | RP-09 | RP-000364 | 497 | 2 | Physical Shared Channel Allocation procedure | 3.3.0 | 3.4.0 |
| | RP-09 | RP-000364 | 498 | | Correction to Transport Format Combination Control Message | 3.3.0 | 3.4.0 |
| | RP-09 | RP-000364 | 499 | 1 | Usage of Cell Parameter ID | 3.3.0 | 3.4.0 |
| | RP-09 | RP-000364 | 500 | | RB description for SHCCH | 3.3.0 | 3.4.0 |
| | RP-09 | RP-000364 | 501 | 1 | Use of LI in UM | 3.3.0 | 3.4.0 |
| | RP-09 | RP-000364 | 502 | 1 | Minor Corrections to RRC Protocol Specification | 3.3.0 | 3.4.0 |
| | RP-09 | RP-000364 | 503 | 1 | Correction to Cell Update Cause | 3.3.0 | 3.4.0 |
| | RP-09 | RP-000364 | 504 | | Correction on T307 definition | 3.3.0 | 3.4.0 |
| | RP-09 | RP-000364 | 505 | | Corrections to relative priorities in RRC Protocol | 3.3.0 | 3.4.0 |
| | RP-09 | RP-000364 | 506 | | Unification of Reconfiguration Procedures | 3.3.0 | 3.4.0 |
| | RP-09 | RP-000364 | 507 | 1 | Changes to section 8.2 proposed at Paris RRC Ad Hoc | 3.3.0 | 3.4.0 |
| | RP-09 | RP-000364 | 508 | | Establishment Cause | 3.3.0 | 3.4.0 |
| | RP-09 | RP-000364 | 509 | 1 | PRACH partitioning | 3.3.0 | 3.4.0 |
| | RP-09 | RP-000364 | 510 | | Editorial Correction on Active Set Update | 3.3.0 | 3.4.0 |
| | RP-09 | RP-000364 | 511 | | Editorial Correction regarding system information | 3.3.0 | 3.4.0 |
| | RP-09 | RP-000365 | 512 | 1 | Clarification on Reporting Cell Status | 3.3.0 | 3.4.0 |
| | RP-09 | RP-000365 | 513 | 1 | Editorial corrections on RRC Connection Establishment and Release procedures<br>NOTE: In subclause 8.1.4.6, the change from "decrease" to "increase" for V308 was decided to be incorrect after discussion on the TSG-RAN WG2 reflector and was not implemented | 3.3.0 | 3.4.0 |
| | RP-09 | RP-000365 | 514 | | Gated Transmission Control Info | 3.3.0 | 3.4.0 |
| | RP-09 | RP-000365 | 515 | 1 | Cell selection/reselection parameters for SIB 3/4 | 3.3.0 | 3.4.0 |
| | RP-09 | RP-000365 | 516 | | Implementation of Ec/N0 parameters and optimization of SIB 11/12 | 3.3.0 | 3.4.0 |
| | RP-09 | RP-000365 | 517 | | PRACH Info | 3.3.0 | 3.4.0 |
| | RP-09 | RP-000365 | 518 | 1 | Uplink DPCH power control info | 3.3.0 | 3.4.0 |
| | RP-09 | RP-000365 | 519 | | AICH power offset value range | 3.3.0 | 3.4.0 |
| | RP-09 | RP-000365 | 520 | | Direct paging of RRC connected UE in CELL_PCH/URA_PCH<br>NOTE: This CR was postponed in TSG-RAN #9 and was wrongly included in v3.4.0. This was corrected in v3.4.1 | 3.3.0 | 3.4.0 |
| | RP-09 | RP-000365 | 521 | | Corrections to Sections 1-7 | 3.3.0 | 3.4.0 |
| | RP-09 | RP-000365 | 522 | | Error handling for Uplink Physical Channel Control procedure | 3.3.0 | 3.4.0 |

| Change history | | | | | | | |
|---|---|---|---|---|---|---|---|
| Date | TSG # | TSG Doc. | CR | Rev | Subject/Comment | Old | New |
| | RP-09 | RP-000365 | 523 | | Corrections to downlink outer loop power control in compressed mode | 3.3.0 | 3.4.0 |
| | RP-09 | RP-000365 | 524 | 1 | Clarification on measurement procedure using compressed mode | 3.3.0 | 3.4.0 |
| | RP-09 | RP-000365 | 525 | 1 | Updates to cell and URA update procedures based on RRC Ad Hoc | 3.3.0 | 3.4.0 |
| | RP-09 | RP-000365 | 526 | 1 | Updates to RNTI allocation procedure based on RRC Ad Hoc | 3.3.0 | 3.4.0 |
| | RP-09 | RP-000365 | 528 | | PRACH constant value | 3.3.0 | 3.4.0 |
| | RP-09 | RP-000365 | 530 | 1 | Corrections to the paging procedure | 3.3.0 | 3.4.0 |
| | RP-09 | RP-000365 | 532 | 1 | Moving of text from 25.304 | 3.3.0 | 3.4.0 |
| | RP-09 | RP-000365 | 533 | 1 | Message extensibility | 3.3.0 | 3.4.0 |
| | RP-09 | RP-000365 | 534 | 1 | Additions to "State of RRC Procedure" in RRC Initialisation information, source RNC to target RNC | 3.3.0 | 3.4.0 |
| | RP-09 | RP-000365 | 535 | 1 | Support of codec negotiation | 3.3.0 | 3.4.0 |
| | - | - | - | | Removal of contents of CR 520 from v3.4.0, because it was postponed at TSG-RAN #9 and by accident included anyway. | 3.4.0 | 3.4.1 |
| 12/2000 | RP-10 | RP-000570 | 536 | | Downlink outer-loop power control in compressed mode | 3.4.1 | 3.5.0 |
| | RP-10 | RP-000570 | 537 | 1 | Correction in the use of "U-RNTI Short" | 3.4.1 | 3.5.0 |
| | RP-10 | RP-000570 | 538 | | Corrections related to UE Timing | 3.4.1 | 3.5.0 |
| | RP-10 | RP-000570 | 539 | | Corrections to SFN-SFN definition | 3.4.1 | 3.5.0 |
| | RP-10 | RP-000570 | 541 | 1 | Corrections to definition and use of Activation Time | 3.4.1 | 3.5.0 |
| | RP-10 | RP-000570 | 542 | | Corrections to logical channel priorities | 3.4.1 | 3.5.0 |
| | RP-10 | RP-000570 | 543 | 1 | Correction to codec negotiation | 3.4.1 | 3.5.0 |
| | RP-10 | RP-000570 | 544 | 1 | CFN-SFN observed time difference measurement | 3.4.1 | 3.5.0 |
| | RP-10 | RP-000570 | 545 | 1 | Correction to timing indication for hard handover | 3.4.1 | 3.5.0 |
| | RP-10 | RP-000570 | 546 | 1 | UE Radio Access Capability Corrections | 3.4.1 | 3.5.0 |
| | RP-10 | RP-000570 | 548 | 1 | RRC establishment and paging causes for NAS signalling | 3.4.1 | 3.5.0 |
| | RP-10 | RP-000570 | 549 | | Corrections to Intra-frequency measurements and Traffic volume measurements | 3.4.1 | 3.5.0 |
| | RP-10 | RP-000570 | 551 | 1 | PRACH/RACH System information | 3.4.1 | 3.5.0 |
| | RP-10 | RP-000570 | 553 | 1 | GSM Measurement reporting | 3.4.1 | 3.5.0 |
| | RP-10 | RP-000570 | 554 | 1 | BLER measurement and quality target | 3.4.1 | 3.5.0 |
| | RP-10 | RP-000570 | 556 | 1 | Clarification of PDCP sequence number window terminology | 3.4.1 | 3.5.0 |
| | RP-10 | RP-000570 | 559 | 1 | Clarification on Error Handling | 3.4.1 | 3.5.0 |
| | RP-10 | RP-000570 | 560 | | Removal of compressed mode measurement purpose "other" | 3.4.1 | 3.5.0 |
| | RP-10 | RP-000570 | 561 | | Clarification of compressed mode measurement purpose "GSM" | 3.4.1 | 3.5.0 |
| | RP-10 | RP-000570 | 564 | 2 | Reporting multiple GSM cells | 3.4.1 | 3.5.0 |
| | RP-10 | RP-000571 | 566 | 1 | Number of RLs that can be removed in Active Set update | 3.4.1 | 3.5.0 |
| | RP-10 | RP-000571 | 568 | 1 | Clarification on Segment Index | 3.4.1 | 3.5.0 |
| | RP-10 | RP-000571 | 571 | 3 | RRC procedure performance requirements | 3.4.1 | 3.5.0 |
| | RP-10 | RP-000571 | 572 | 1 | Correction of newInterSystemCellList and MeasurementControlSysInfo in ASN.1 | 3.4.1 | 3.5.0 |
| | RP-10 | RP-000571 | 573 | 4 | Removal of Flow Id concept while maintaining Iu interface flexibility | 3.4.1 | 3.5.0 |
| | RP-10 | RP-000571 | 574 | 2 | Ciphering and reset | 3.4.1 | 3.5.0 |
| | RP-10 | RP-000571 | 575 | 1 | Corrections and clarifications concerning inter-RAT change procedures | 3.4.1 | 3.5.0 |
| | RP-10 | RP-000571 | 576 | 1 | General Security Clarifications | 3.4.1 | 3.5.0 |
| | RP-10 | RP-000571 | 577 | | Clarification on RB 0 | 3.4.1 | 3.5.0 |
| | RP-10 | RP-000571 | 578 | | Clarification on the transition of RRC state | 3.4.1 | 3.5.0 |
| | RP-10 | RP-000571 | 580 | 1 | UP measurements for RRC information to target RNC | 3.4.1 | 3.5.0 |
| | RP-10 | RP-000571 | 581 | | Correction on LCS reporting criteria | 3.4.1 | 3.5.0 |
| | RP-10 | RP-000574 | 583 | 1 | CSICH Corrections | 3.4.1 | 3.5.0 |
| | RP-10 | RP-000571 | 584 | 1 | Clarification to handling of satellite health issues | 3.4.1 | 3.5.0 |
| | RP-10 | RP-000571 | 585 | | Clarification on activation time | 3.4.1 | 3.5.0 |
| | RP-10 | RP-000571 | 586 | | Clarification on activation time for ciphering in TM | 3.4.1 | 3.5.0 |
| | RP-10 | RP-000571 | 587 | 2 | Measurement procedures and messages | 3.4.1 | 3.5.0 |
| | RP-10 | RP-000571 | 590 | 1 | Inter-RAT UE radio access capability | 3.4.1 | 3.5.0 |
| | RP-10 | RP-000571 | 592 | 1 | Clarification on cell update/URA update procedures | 3.4.1 | 3.5.0 |
| | RP-10 | RP-000571 | 595 | 4 | Protocol States and Process | 3.4.1 | 3.5.0 |
| | RP-10 | RP-000571 | 596 | 1 | System Information | 3.4.1 | 3.5.0 |

| Change history | | | | | | | |
|---|---|---|---|---|---|---|---|
| Date | TSG # | TSG Doc. | CR | Rev | Subject/Comment | Old | New |
| | RP-10 | RP-000715 | 597 | 5 | RRC Connection Management Procedures, Generic procedures and actions | 3.4.1 | 3.5.0 |
| | RP-10 | RP-000572 | 598 | 1 | Paging Procedures | 3.4.1 | 3.5.0 |
| | RP-10 | RP-000572 | 599 | | NAS signalling Procedures | 3.4.1 | 3.5.0 |
| | RP-10 | RP-000572 | 600 | 3 | Radio Bearer Control Procedures | 3.4.1 | 3.5.0 |
| | RP-10 | RP-000572 | 601 | 1 | Corrections to the Counter Check Procedure | 3.4.1 | 3.5.0 |
| | RP-10 | RP-000572 | 602 | | Tabular Information and ASN.1 | 3.4.1 | 3.5.0 |
| | RP-10 | RP-000572 | 604 | 2 | Corrections to Measurement Occasion concept | 3.4.1 | 3.5.0 |
| | RP-10 | RP-000572 | 606 | | Corrections concerning optimisation of RB information | 3.4.1 | 3.5.0 |
| | RP-10 | RP-000572 | 608 | 1 | Corrections to security | 3.4.1 | 3.5.0 |
| | RP-10 | RP-000572 | 609 | 1 | Ciphering activation time for DPCH | 3.4.1 | 3.5.0 |
| | RP-10 | RP-000572 | 610 | | Confirmation of signalling connection establishment | 3.4.1 | 3.5.0 |
| | RP-10 | RP-000572 | 611 | 2 | RACH Sub-channel signalling | 3.4.1 | 3.5.0 |
| | RP-10 | RP-000572 | 613 | 2 | Assistance data delivery for UP | 3.4.1 | 3.5.0 |
| | RP-10 | RP-000572 | 614 | 1 | Clarification of LCS measurements | 3.4.1 | 3.5.0 |
| | RP-10 | RP-000572 | 615 | 2 | Configuration of RLC PDU sizes for logical channels | 3.4.1 | 3.5.0 |
| | RP-10 | RP-000574 | 616 | | PICH power offset for TDD | 3.4.1 | 3.5.0 |
| | RP-10 | RP-000572 | 617 | | Correction for PDSCH power control for TDD | 3.4.1 | 3.5.0 |
| | RP-10 | RP-000574 | 618 | | Usage of dynamic spreading factor in uplink | 3.4.1 | 3.5.0 |
| | RP-10 | RP-000572 | 619 | | Correction of Midamble Shift for Burst Type 3 | 3.4.1 | 3.5.0 |
| | RP-10 | RP-000572 | 621 | | Correction of text concerning Scheduling of System Information | 3.4.1 | 3.5.0 |
| | RP-10 | RP-000572 | 622 | 1 | Alignment of GSM'99 BA Range concept and its inclusion in UTRA | 3.4.1 | 3.5.0 |
| | RP-10 | RP-000572 | 623 | 1 | Clarification of RB mapping info | 3.4.1 | 3.5.0 |
| | RP-10 | RP-000572 | 624 | 1 | Correction to UE multi-RAT capability | 3.4.1 | 3.5.0 |
| | RP-10 | RP-000573 | 625 | | Correction to PDCP sequence number exchange during hard handover | 3.4.1 | 3.5.0 |
| | RP-10 | RP-000573 | 628 | 2 | DCH Quality Target | 3.4.1 | 3.5.0 |
| | RP-10 | RP-000573 | 629 | 1 | Simultaneous release of RBs and signalling connection | 3.4.1 | 3.5.0 |
| | RP-10 | RP-000573 | 630 | | Correction on Transport Channel Reconfiguration | 3.4.1 | 3.5.0 |
| | RP-10 | RP-000573 | 631 | | Limitation of DRX cycle length | 3.4.1 | 3.5.0 |
| | RP-10 | RP-000574 | 632 | | Signalling of the alpha value in TDD for open loop power control | 3.4.1 | 3.5.0 |
| | RP-10 | RP-000573 | 633 | | Support for improved compressed mode handling for TDD measurements | 3.4.1 | 3.5.0 |
| | RP-10 | RP-000573 | 636 | | Usage of secondary CPICH and secondary scrambling code | 3.4.1 | 3.5.0 |
| | RP-10 | RP-000573 | 639 | | Expiration time of SIB type 7, 14 | 3.4.1 | 3.5.0 |
| | RP-10 | RP-000573 | 640 | | Correction to integrity protection | 3.4.1 | 3.5.0 |
| | RP-10 | RP-000684 | 641 | | Downlink Outer Loop Control | 3.4.1 | 3.5.0 |
| 03/2001 | RP-11 | RP-010029 | 642 | 2 | RL Failure in cell update procedure | 3.5.0 | 3.6.0 |
| | RP-11 | RP-010029 | 645 | 1 | Clarification on COUNTER CHECK | 3.5.0 | 3.6.0 |
| | RP-11 | RP-010029 | 646 | 2 | Traffic Volume Measurement corrections | 3.5.0 | 3.6.0 |
| | RP-11 | RP-010029 | 650 | 2 | Reserved TFCI for the TDD Special Burst | 3.5.0 | 3.6.0 |
| | RP-11 | RP-010029 | 653 | | Correction to description of RRC state transitions | 3.5.0 | 3.6.0 |
| | RP-11 | RP-010029 | 657 | | RLC re-establish correction | 3.5.0 | 3.6.0 |
| | RP-11 | RP-010029 | 658 | 1 | Removal of RLC logical channel mapping indicator | 3.5.0 | 3.6.0 |
| | RP-11 | RP-010029 | 659 | | New paging and establishment cause "Unknown" | 3.5.0 | 3.6.0 |
| | RP-11 | RP-010029 | 660 | 1 | Miscellaneous procedure corrections | 3.5.0 | 3.6.0 |
| | RP-11 | RP-010029 | 661 | | Corrections to compressed mode pattern sequence handling | 3.5.0 | 3.6.0 |
| | RP-11 | RP-010029 | 662 | | Inter-system change clarifications | 3.5.0 | 3.6.0 |
| | RP-11 | RP-010029 | 663 | 1 | RLC status transmission in CELL_PCH and URA_PCH | 3.5.0 | 3.6.0 |
| | RP-11 | RP-010029 | 665 | 1 | Clarification of RB information parameter values for SRB0 | 3.5.0 | 3.6.0 |
| | RP-11 | RP-010029 | 666 | | Encoding for RRC- container | 3.5.0 | 3.6.0 |
| | RP-11 | RP-010029 | 667 | 2 | Update of message extension and encoding descriptions | 3.5.0 | 3.6.0 |
| | RP-11 | RP-010032 | 668 | 4 | Introduction of default pre-defined configurations | 3.5.0 | 3.6.0 |
| | RP-11 | RP-010029 | 669 | 2 | Security corrections | 3.5.0 | 3.6.0 |
| | RP-11 | RP-010029 | 670 | | Clarifications on Blind Handover Support | 3.5.0 | 3.6.0 |
| | RP-11 | RP-010029 | 671 | 1 | Missing descriptions of UE actions | 3.5.0 | 3.6.0 |
| | RP-11 | RP-010029 | 672 | 2 | Corrections on UE Positioning information | 3.5.0 | 3.6.0 |
| | RP-11 | RP-010029 | 674 | 1 | Security related corrections to SRNS | 3.5.0 | 3.6.0 |

| Change history | | | | | | | |
|---|---|---|---|---|---|---|---|
| Date | TSG # | TSG Doc. | CR | Rev | Subject/Comment | Old | New |
| | RP-11 | RP-010032 | 675 | 2 | Downlink power offsets | 3.5.0 | 3.6.0 |
| | RP-11 | RP-010274 | 676 | 2 | Checking the integrity of UE security capabilities | 3.5.0 | 3.6.0 |
| | RP-11 | RP-010030 | 678 | 1 | Clarification to Secondary CCPCH info | 3.5.0 | 3.6.0 |
| | RP-11 | RP-010030 | 679 | 1 | Miscellaneous corrections | 3.5.0 | 3.6.0 |
| | RP-11 | RP-010030 | 680 | | Removal of Layer 3 filtering for RACH | 3.5.0 | 3.6.0 |
| | RP-11 | RP-010030 | 681 | 2 | Correction of compressed mode parameters | 3.5.0 | 3.6.0 |
| | RP-11 | RP-010030 | 682 | | Removal of immediate cell evaluation | 3.5.0 | 3.6.0 |
| | RP-11 | RP-010030 | 684 | 2 | Scheduling of SIB 15.2 and SIB 15.3 | 3.5.0 | 3.6.0 |
| | RP-11 | RP-010030 | 685 | 1 | Correction to ECN modules | 3.5.0 | 3.6.0 |
| | RP-11 | RP-010030 | 686 | 1 | Improvement of the description of timing advance for TDD | 3.5.0 | 3.6.0 |
| | RP-11 | RP-010030 | 687 | | Correction on timing advance and allocation for shared channels | 3.5.0 | 3.6.0 |
| | RP-11 | RP-010030 | 688 | 1 | Clarification on SF 1 signalling | 3.5.0 | 3.6.0 |
| | RP-11 | RP-010030 | 689 | 1 | Correction to power control in TDD | 3.5.0 | 3.6.0 |
| | RP-11 | RP-010030 | 690 | | Midamble - Channelisation code association for TDD | 3.5.0 | 3.6.0 |
| | RP-11 | RP-010030 | 691 | | Network requested reporting for physical shared channel allocation | 3.5.0 | 3.6.0 |
| | RP-11 | RP-010030 | 693 | | System Information | 3.5.0 | 3.6.0 |
| | RP-11 | RP-010030 | 694 | 1 | Clarification on Transport Channel Identity | 3.5.0 | 3.6.0 |
| | RP-11 | RP-010030 | 696 | 1 | Editorial Correction | 3.5.0 | 3.6.0 |
| | RP-11 | RP-010030 | 698 | 2 | Correction to add coding of intra domain NAS node selector | 3.5.0 | 3.6.0 |
| | RP-11 | RP-010030 | 700 | 1 | Corrections to system information block characteristics in TDD | 3.5.0 | 3.6.0 |
| | RP-11 | RP-010030 | 701 | 2 | ASN.1 corrections | 3.5.0 | 3.6.0 |
| | RP-11 | RP-010030 | 702 | 2 | Measurement related corrections | 3.5.0 | 3.6.0 |
| | RP-11 | RP-010031 | 703 | 1 | Clarifications on TFC Control procedure | 3.5.0 | 3.6.0 |
| | RP-11 | RP-010031 | 704 | 2 | Association of PLMN ID to neighbour cells | 3.5.0 | 3.6.0 |
| | RP-11 | RP-010031 | 705 | 1 | TFCS Selection Guidelines | 3.5.0 | 3.6.0 |
| | RP-11 | RP-010031 | 710 | | Special Burst Scheduling During DTX in TDD | 3.5.0 | 3.6.0 |
| | RP-11 | RP-010031 | 711 | 1 | Radio Link Failure Criteria in TDD | 3.5.0 | 3.6.0 |
| | RP-11 | RP-010031 | 712 | 1 | Correction & Clarification to TDD RACH Subchannels | 3.5.0 | 3.6.0 |
| | RP-11 | RP-010031 | 713 | 1 | Number of retransmission of RRC CONNECTION REQUEST | 3.5.0 | 3.6.0 |
| | RP-11 | RP-010031 | 714 | | Uplink Frequency Notification | 3.5.0 | 3.6.0 |
| | RP-11 | RP-010031 | 715 | | Clarification of Radio Bearer Mapping for DCH/DSCH Transport Channels | 3.5.0 | 3.6.0 |
| | RP-11 | RP-010031 | 716 | | Correction of mismatches between tabular and ASN.1 | 3.5.0 | 3.6.0 |
| | RP-11 | RP-010031 | 717 | | Correction to discontinuous reception in TDD | 3.5.0 | 3.6.0 |
| | RP-11 | RP-010031 | 718 | | Power control preamble | 3.5.0 | 3.6.0 |
| | RP-11 | RP-010031 | 719 | | Maximum number of AM entity | 3.5.0 | 3.6.0 |
| | RP-11 | RP-010031 | 720 | 1 | Real-time Integrity Broadcast | 3.5.0 | 3.6.0 |
| | RP-11 | RP-010031 | 721 | 3 | Moving Real-time Integrity description to different chapter | 3.5.0 | 3.6.0 |
| | RP-11 | RP-010031 | 723 | 1 | Removal of the payload unit concept | 3.5.0 | 3.6.0 |
| | RP-11 | RP-010031 | 724 | | Security related corrections to SRNS | 3.5.0 | 3.6.0 |
| | RP-11 | RP-010031 | 725 | | Periodic PLMN selection correction | 3.5.0 | 3.6.0 |
| | RP-11 | RP-010042 | 683 | 1 | Modification of "SSDT Information" IE parameters to indicate if SSDT is used in the UL only | 3.6.0 | 4.0.0 |
| | RP-11 | RP-010041 | 692 | 1 | Idle allocation for Node B synchronisation | 3.6.0 | 4.0.0 |
| | RP-11 | RP-010037 | 706 | 1 | Physical channel configuration information elements for 1.28 Mcps TDD | 3.6.0 | 4.0.0 |
| | RP-11 | RP-010037 | 707 | 2 | Changes to Measurement Related Signalling and Introduction of Cell (Re)selection Parameters for 1.28Mcps TDD | 3.6.0 | 4.0.0 |
| | RP-11 | RP-010037 | 708 | 1 | Introduction of RACH Parameters for 1.28 Mcps TDD | 3.6.0 | 4.0.0 |
| | RP-11 | RP-010037 | 709 | | Introduction of UE radio access capability Parameters for 1.28 Mcps TDD | 3.6.0 | 4.0.0 |
| | RP-11 | RP-010040 | 722 | 1 | Introduction of IPDLs for TDD | 3.6.0 | 4.0.0 |
| | RP-11 | RP-010039 | 726 | 1 | ROHC updates to RRC | 3.6.0 | 4.0.0 |
| 06/2001 | RP-12 | RP-010311 | 731 | | Clarification of the IE 'spreading factor' in Uplink DPCH info for FDD mode | 4.0.0 | 4.1.0 |
| | RP-12 | RP-010311 | 733 | | Correction of UE Radio Access Capability depending on UTRAN FDD bands | 4.0.0 | 4.1.0 |
| | RP-12 | RP-010311 | 735 | | Clarification on Security mode control | 4.0.0 | 4.1.0 |
| | RP-12 | RP-010311 | 738 | | Correction of TrCH parameter handling | 4.0.0 | 4.1.0 |

| Change history | | | | | | | |
|---|---|---|---|---|---|---|---|
| Date | TSG # | TSG Doc. | CR | Rev | Subject/Comment | Old | New |
| | RP-12 | RP-010311 | 740 | | TFC Subsets in TDD | 4.0.0 | 4.1.0 |
| | RP-12 | RP-010311 | 746 | | RRC containers | 4.0.0 | 4.1.0 |
| | RP-12 | RP-010311 | 748 | | Various corrections | 4.0.0 | 4.1.0 |
| | RP-12 | RP-010311 | 750 | | General error handling for system information | 4.0.0 | 4.1.0 |
| | RP-12 | RP-010311 | 752 | | Order of elements in strings | 4.0.0 | 4.1.0 |
| | RP-12 | RP-010311 | 754 | | Configuration consistency checks | 4.0.0 | 4.1.0 |
| | RP-12 | RP-010312 | 756 | | Compressed mode corrections | 4.0.0 | 4.1.0 |
| | RP-12 | RP-010312 | 758 | | Correction concerning inter-RAT procedures | 4.0.0 | 4.1.0 |
| | RP-12 | RP-010312 | 762 | | Measurement corrections | 4.0.0 | 4.1.0 |
| | RP-12 | RP-010312 | 764 | | RLC Tr Discard | 4.0.0 | 4.1.0 |
| | RP-12 | RP-010312 | 766 | | Annex B CPCH Correction | 4.0.0 | 4.1.0 |
| | RP-12 | RP-010312 | 768 | | SIB Correction for CSICH Power Offset | 4.0.0 | 4.1.0 |
| | RP-12 | RP-010312 | 770 | | Transfer of Last known position in case of SRNS relocation | 4.0.0 | 4.1.0 |
| | RP-12 | RP-010312 | 772 | | Corrections to UE Positioning measurements | 4.0.0 | 4.1.0 |
| | RP-12 | RP-010312 | 779 | | GSM measurements in compressed mode | 4.0.0 | 4.1.0 |
| | RP-12 | RP-010312 | 781 | | Correction of Activation Time in Inter-Rat HO Commands | 4.0.0 | 4.1.0 |
| | RP-12 | RP-010313 | 785 | | Clarification of FRESH in SRNS relocation | 4.0.0 | 4.1.0 |
| | RP-12 | RP-010313 | 789 | | Correction to UE timers and constants in idle mode | 4.0.0 | 4.1.0 |
| | RP-12 | RP-010313 | 793 | | Clarification on multiframe allocation in TDD | 4.0.0 | 4.1.0 |
| | RP-12 | RP-010313 | 795 | | Predefined parameters for logical channels | 4.0.0 | 4.1.0 |
| | RP-12 | RP-010313 | 797 | | Pathloss calculation | 4.0.0 | 4.1.0 |
| | RP-12 | RP-010313 | 799 | | Clarification on periodic measurement reporting | 4.0.0 | 4.1.0 |
| | RP-12 | RP-010313 | 803 | 1 | Handling of IE PRACH TFCS and Primary CPICH/Primary CCPCH info | 4.0.0 | 4.1.0 |
| | RP-12 | RP-010313 | 805 | | Correction to FACH measurement occasion in TDD | 4.0.0 | 4.1.0 |
| | RP-12 | RP-010313 | 807 | | Clarification of L1 synchronization procedures | 4.0.0 | 4.1.0 |
| | RP-12 | RP-010313 | 809 | | Correction of Activation Time definition | 4.0.0 | 4.1.0 |
| | RP-12 | RP-010314 | 813 | | Corrections to RRC procedure performance | 4.0.0 | 4.1.0 |
| | RP-12 | RP-010314 | 815 | | Removal of mapping function | 4.0.0 | 4.1.0 |
| | RP-12 | RP-010314 | 817 | | Security clarifications | 4.0.0 | 4.1.0 |
| | RP-12 | RP-010314 | 819 | | Corrections to UE Positioning | 4.0.0 | 4.1.0 |
| | RP-12 | RP-010314 | 825 | | Definition of DPCH numbering | 4.0.0 | 4.1.0 |
| | RP-12 | RP-010314 | 827 | | Corrections to System Information Procedure | 4.0.0 | 4.1.0 |
| | RP-12 | RP-010314 | 829 | | Relation between DOFF and DPCH Frame Offset | 4.0.0 | 4.1.0 |
| | RP-12 | RP-010314 | 831 | | Procedures for "same as UL" | 4.0.0 | 4.1.0 |
| | RP-12 | RP-010314 | 837 | | Editorial and minor corrections | 4.0.0 | 4.1.0 |
| | RP-12 | RP-010314 | 839 | | Editorial Correction | 4.0.0 | 4.1.0 |
| | RP-12 | RP-010315 | 843 | | Corrections on OTDOA-IPDL specific burst parameter semantic description | 4.0.0 | 4.1.0 |
| | RP-12 | RP-010315 | 845 | | Error handling for messages sent from another RAT | 4.0.0 | 4.1.0 |
| | RP-12 | RP-010315 | 849 | | Needed TFC in the TFCS for TDD | 4.0.0 | 4.1.0 |
| | RP-12 | RP-010315 | 855 | | Clarification of TFCS selection guidelines | 4.0.0 | 4.1.0 |
| | RP-12 | RP-010315 | 861 | | Clarification of Traffic Volume measurements | 4.0.0 | 4.1.0 |
| | RP-12 | RP-010315 | 863 | | CFN synchronisation problems at timing re-initialised hard handover | 4.0.0 | 4.1.0 |
| | RP-12 | RP-010315 | 866 | | Corrections on UP Assistance Message Descriptions | 4.0.0 | 4.1.0 |
| | RP-12 | RP-010315 | 868 | | Correction on Area Scope of SIB 15.3 | 4.0.0 | 4.1.0 |
| | RP-12 | RP-010315 | 872 | | Correction to AICH power offset | 4.0.0 | 4.1.0 |
| | RP-12 | RP-010316 | 875 | | Clarification on IE 'Downlink rate matching restriction information' | 4.0.0 | 4.1.0 |
| | RP-12 | RP-010316 | 877 | | Corrections on Tabular/ASN.1 | 4.0.0 | 4.1.0 |
| | RP-12 | RP-010316 | 879 | | Corrections on Tabular and ASN.1 inconsistencies | 4.0.0 | 4.1.0 |
| | RP-12 | RP-010316 | 881 | | Editorial corrections on Tabular and ASN.1 inconsistencies | 4.0.0 | 4.1.0 |
| | RP-12 | RP-010316 | 883 | | UE Positioning corrections to ASN.1 and tabular | 4.0.0 | 4.1.0 |
| | RP-12 | RP-010316 | 885 | | Corrections to resolve inconsistencies between Tabular and ASN.1 | 4.0.0 | 4.1.0 |
| | RP-12 | RP-010316 | 887 | | UE positioning OTDOA Neighbour Cell Info | 4.0.0 | 4.1.0 |
| | RP-12 | RP-010316 | 889 | | DRAC corrections | 4.0.0 | 4.1.0 |
| | RP-12 | RP-010316 | 893 | | ASN.1 Correction of IE TFCS ID | 4.0.0 | 4.1.0 |
| | RP-12 | RP-010316 | 895 | | Correction of IE IODE range in AGPS Positioning | 4.0.0 | 4.1.0 |

| Change history | | | | | | | |
|---|---|---|---|---|---|---|---|
| Date | TSG # | TSG Doc. | CR | Rev | Subject/Comment | Old | New |
| | RP-12 | RP-010317 | 897 | | Correction to BurstModeParameters in IPDL | 4.0.0 | 4.1.0 |
| | RP-12 | RP-010317 | 899 | | Corrections on inconsistencies between Tabular and ASN.1 | 4.0.0 | 4.1.0 |
| | RP-12 | RP-010317 | 901 | | Naming of message abstract types in ASN.1 | 4.0.0 | 4.1.0 |
| | RP-12 | RP-010317 | 904 | | Information elements outside the extension container | 4.0.0 | 4.1.0 |
| | RP-12 | RP-010317 | 906 | | Correction concerning DRX cycle upon inter-RAT change towards UTRAN | 4.0.0 | 4.1.0 |
| | RP-12 | RP-010323 | 773 | | Corrections to IPDLs for TDD | 4.0.0 | 4.1.0 |
| | RP-12 | RP-010323 | 850 | 2 | Correction to 1.28Mcps TDD RACH parameters and operation | 4.0.0 | 4.1.0 |
| | RP-12 | RP-010323 | 851 | | TFCI coding in case of 8PSK | 4.0.0 | 4.1.0 |
| | RP-12 | RP-010323 | 902 | 1 | Structure and naming of information elements | 4.0.0 | 4.1.0 |
| 09/2001 | RP-13 | RP-010544 | 0870 | | UL Transport Channel Type Correction | 4.1.0 | 4.2.0 |
| | RP-13 | RP-010544 | 0908 | | Guidelines concerning conditions, spares, defaults and correction of inconsistencies | 4.1.0 | 4.2.0 |
| | RP-13 | RP-010544 | 0910 | | Correction to TDD DL DPCH Common Timeslot Info | 4.1.0 | 4.2.0 |
| | RP-13 | RP-010544 | 0912 | | TDD System Information Update in Cell_DCH | 4.1.0 | 4.2.0 |
| | RP-13 | RP-010544 | 0914 | | Editorial Corrections | 4.1.0 | 4.2.0 |
| | RP-13 | RP-010544 | 0916 | | UL DPCH Power Control Info in TDD | 4.1.0 | 4.2.0 |
| | RP-13 | RP-010544 | 0918 | | CN-originated paging in CELL_PCH and URA_PCH state | 4.1.0 | 4.2.0 |
| | RP-13 | RP-010544 | 0920 | | Corrections to UE variable handling | 4.1.0 | 4.2.0 |
| | RP-13 | RP-010544 | 0922 | | Inter-frequency measurements | 4.1.0 | 4.2.0 |
| | RP-13 | RP-010544 | 0924 | | Inter-RAT measurements | 4.1.0 | 4.2.0 |
| | RP-13 | RP-010671 | 0926 | 1 | Intra-frequency measurements | 4.1.0 | 4.2.0 |
| | RP-13 | RP-010545 | 0928 | | Multiplexing configuration corrections | 4.1.0 | 4.2.0 |
| | RP-13 | RP-010545 | 0930 | | Reception of non-dedicated control channels mapped on FACH in CELL_FACH state | 4.1.0 | 4.2.0 |
| | RP-13 | RP-010545 | 0932 | | Removal of C-RNTI when entering CELL_DCH | 4.1.0 | 4.2.0 |
| | RP-13 | RP-010545 | 0935 | | TF and TFC set definition | 4.1.0 | 4.2.0 |
| | RP-13 | RP-010545 | 0937 | | Correction of remaining ASN.1/Tabular inconsistencies | 4.1.0 | 4.2.0 |
| | RP-13 | RP-010545 | 0939 | | CPICH Ec/N0 Range | 4.1.0 | 4.2.0 |
| | RP-13 | RP-010545 | 0941 | | Priorities for IDNNS coding | 4.1.0 | 4.2.0 |
| | RP-13 | RP-010545 | 0943 | | Dedicated pilots and S-CPICH specification related to UE specific beamforming | 4.1.0 | 4.2.0 |
| | RP-13 | RP-010545 | 0945 | | Security corrections | 4.1.0 | 4.2.0 |
| | RP-13 | RP-010546 | 0953 | | Intra-frequency measurement events for TDD corrections | 4.1.0 | 4.2.0 |
| | RP-13 | RP-010546 | 0955 | | Inconsistencies between ASN.1 and tabular format | 4.1.0 | 4.2.0 |
| | RP-13 | RP-010546 | 0957 | | TDD PICH corrections and clarifications | 4.1.0 | 4.2.0 |
| | RP-13 | RP-010546 | 0959 | | Messages on CCCH | 4.1.0 | 4.2.0 |
| | RP-13 | RP-010546 | 0961 | | Clarification of Parameter Values for Default Radio Configurations | 4.1.0 | 4.2.0 |
| | RP-13 | RP-010546 | 0963 | | Clarification to usage of default values in "Cell Selection and Reselection for SIB11/12Info" | 4.1.0 | 4.2.0 |
| | RP-13 | RP-010546 | 0965 | | Clarification of handling of System information block 14 | 4.1.0 | 4.2.0 |
| | RP-13 | RP-010546 | 0967 | | Description of UE behaviour when receiving UE positioning related information | 4.1.0 | 4.2.0 |
| | RP-13 | RP-010546 | 0982 | | Clarification on periodic measurement reporting | 4.1.0 | 4.2.0 |
| | RP-13 | RP-010546 | 0984 | | Corrections and clarifications on Measurement procedures description | 4.1.0 | 4.2.0 |
| | RP-13 | RP-010547 | 0986 | | Lossless Criteria in PDCP Info | 4.1.0 | 4.2.0 |
| | RP-13 | RP-010547 | 0988 | | Corrections to cell reselection parameter values | 4.1.0 | 4.2.0 |
| | RP-13 | RP-010547 | 0990 | | Correction to signalling connection release | 4.1.0 | 4.2.0 |
| | RP-13 | RP-010547 | 0992 | | Corrections to cell update procedures | 4.1.0 | 4.2.0 |
| | RP-13 | RP-010547 | 0994 | | PDCP configuration and PS domain configuration checks | 4.1.0 | 4.2.0 |
| | RP-13 | RP-010547 | 0996 | | Correction to handling of RRC transaction identifier for Cell Update, URA Update and RRC connection setup | 4.1.0 | 4.2.0 |
| | RP-13 | RP-010547 | 0998 | 1 | Correction of UE capabilities regarding Rx-Tx time difference type 2 measurement | 4.1.0 | 4.2.0 |
| | RP-13 | RP-010547 | 1000 | | Correction to handling of IE 'Downlink info for each radio link' | 4.1.0 | 4.2.0 |
| | RP-13 | RP-010547 | 1004 | | Redundant IE in Traffic volume measurement system information | 4.1.0 | 4.2.0 |
| | RP-13 | RP-010547 | 1006 | | Editorial corrections | 4.1.0 | 4.2.0 |
| | RP-13 | RP-010548 | 1008 | | MAC logical channel priority added to definition of RB0 and SHCCH | 4.1.0 | 4.2.0 |
| | RP-13 | RP-010548 | 1010 | | Control of primary CCPCH RSCP measurement in PUSCH | 4.1.0 | 4.2.0 |

| Change history | | | | | | | |
|---|---|---|---|---|---|---|---|
| Date | TSG # | TSG Doc. | CR | Rev | Subject/Comment | Old | New |
| | | | | | CAPACITY REQUEST message | | |
| | RP-13 | RP-010548 | 1014 | | Various minor corrections | 4.1.0 | 4.2.0 |
| | RP-13 | RP-010548 | 1016 | | Range of T312 | 4.1.0 | 4.2.0 |
| | RP-13 | RP-010548 | 1018 | | Bitstring of channelisationCodeIndices | 4.1.0 | 4.2.0 |
| | RP-13 | RP-010548 | 1020 | | Transmission of UE CAPABILITY INFORMATION message | 4.1.0 | 4.2.0 |
| | RP-13 | RP-010548 | 1022 | | Multiple UE capabilities procedures | 4.1.0 | 4.2.0 |
| | RP-13 | RP-010548 | 1024 | | Corrections to information elements outside the extension container | 4.1.0 | 4.2.0 |
| | RP-13 | RP-010548 | 1026 | | SFN reporting | 4.1.0 | 4.2.0 |
| | RP-13 | RP-010548 | 1028 | | TFCI combining indicator | 4.1.0 | 4.2.0 |
| | RP-13 | RP-010549 | 1030 | | RLC reset on a Signalling Radio Bearer | 4.1.0 | 4.2.0 |
| | RP-13 | RP-010549 | 1034 | | Quality Indication for UE Positioning Parameters | 4.1.0 | 4.2.0 |
| | RP-13 | RP-010549 | 1036 | | Editorial Correction for UE Positioning | 4.1.0 | 4.2.0 |
| | RP-13 | RP-010549 | 1038 | | Clarification on the current status of ciphering | 4.1.0 | 4.2.0 |
| | RP-13 | RP-010549 | 1048 | | Clarification on HFN initialization at SRB and RB setup | 4.1.0 | 4.2.0 |
| | RP-13 | RP-010549 | 1050 | | Clarification on Inter-RAT measurement | 4.1.0 | 4.2.0 |
| | RP-13 | RP-010549 | 1052 | | Clarification on re-assembly of segments | 4.1.0 | 4.2.0 |
| | RP-13 | RP-010549 | 1062 | | Minor Corrections | 4.1.0 | 4.2.0 |
| | RP-13 | RP-010549 | 1066 | | Support of dedicated pilots for channel estimation | 4.1.0 | 4.2.0 |
| | RP-13 | RP-010549 | 1068 | | Correction to SRNS relocation handling | 4.1.0 | 4.2.0 |
| | RP-13 | RP-010550 | 1076 | | Correction to RLC state variables | 4.1.0 | 4.2.0 |
| | RP-13 | RP-010550 | 1082 | | Reading of CN information in SIB 1 inRRC Connected Mode | 4.1.0 | 4.2.0 |
| | RP-13 | RP-010550 | 1086 | | Restricting the maximum amount of preconfigurations in case of equivalent PLMNs | 4.1.0 | 4.2.0 |
| | RP-13 | RP-010554 | 0933 | | Order of bits in bitstrings | 4.1.0 | 4.2.0 |
| | RP-13 | RP-010554 | 0946 | | Selection of the RFC3095 CID transmission | 4.1.0 | 4.2.0 |
| | RP-13 | RP-010554 | 0970 | | Correction of IPDL parameters for TDD enhancements in ASN.1 description | 4.1.0 | 4.2.0 |
| | RP-13 | RP-010554 | 0971 | 1 | 1.28 Mcps TDD PICH, Midamble and UL timing advance control corrections | 4.1.0 | 4.2.0 |
| | RP-13 | RP-010554 | 0972 | | Introduction of 1.28 Mcps TDD Mode in clause 13.7 | 4.1.0 | 4.2.0 |
| | RP-13 | RP-010554 | 0973 | | Tadv in 1.28 Mcps TDD | 4.1.0 | 4.2.0 |
| | RP-13 | RP-010554 | 0974 | | Correction and clarification to PRACH in 1.28 Mcps TDD | 4.1.0 | 4.2.0 |
| 10/2001 | - | - | - | | Replacement of incorrect (R'99) version of ASN.1 by correct (Rel-4) version of ASN.1. | 4.2.0 | 4.2.1 |
| 12/2001 | RP-14 | RP-010763 | 1088 | | Corrections to RRC information containers | 4.2.1 | 4.3.0 |
| | RP-14 | RP-010763 | 1090 | | Removal of Block SSTD | 4.2.1 | 4.3.0 |
| | RP-14 | RP-010763 | 1098 | | COUNT-C-SFN frame difference measurement | 4.2.1 | 4.3.0 |
| | RP-14 | RP-010763 | 1100 | | Trigger for deletion of ciphering and integrity keys | 4.2.1 | 4.3.0 |
| | RP-14 | RP-010763 | 1102 | | Correction to P_compensation calculation for GSM neighbour cells | 4.2.1 | 4.3.0 |
| | RP-14 | RP-010763 | 1104 | | Preconfigurations in case of equivalent PLMNs | 4.2.1 | 4.3.0 |
| | RP-14 | RP-010763 | 1109 | | Handling of DRX cycle and U-RNTI in RRC connection setup and handling of TrCH information | 4.2.1 | 4.3.0 |
| | RP-14 | RP-010763 | 1111 | | Correction to Information Element names | 4.2.1 | 4.3.0 |
| | RP-14 | RP-010763 | 1113 | | Correction of Description of IE "SSDT Information" | 4.2.1 | 4.3.0 |
| | RP-14 | RP-010763 | 1115 | | Clarification on Cell Identity and correction to reference to BAND_INDICATOR | 4.2.1 | 4.3.0 |
| | RP-14 | RP-010764 | 1117 | | Clarification to Measured Results on RACH and Measurement Events | 4.2.1 | 4.3.0 |
| | RP-14 | RP-010764 | 1119 | | Inconsistency between ASN.1 and tabular wrt. RPLMN information | 4.2.1 | 4.3.0 |
| | RP-14 | RP-010764 | 1124 | | General clarification on Establishment of Access Service Classes | 4.2.1 | 4.3.0 |
| | RP-14 | RP-010764 | 1126 | | Clarification on TX diversity indicator IE and STTD indicator IE | 4.2.1 | 4.3.0 |
| | RP-14 | RP-010764 | 1132 | | Different diversity modes used in the same active set | 4.2.1 | 4.3.0 |
| | RP-14 | RP-010764 | 1134 | | Issues regarding signalling connection establishment and RRC connection release | 4.2.1 | 4.3.0 |
| | RP-14 | RP-010764 | 1136 | | Presence of AC to ASC mapping in SIB5 and SIB6 | 4.2.1 | 4.3.0 |
| | RP-14 | RP-010764 | 1138 | | RRC establishment cause at inter-RAT cell change order to UTRAN | 4.2.1 | 4.3.0 |
| | RP-14 | RP-010764 | 1142 | | Start of timers at radio link failure | 4.2.1 | 4.3.0 |
| | RP-14 | RP-010765 | 1144 | | Handling of the number of FBI bits sent in Uplink DPCH info | 4.2.1 | 4.3.0 |
| | RP-14 | RP-010765 | 1146 | | Bit string order when using PER | 4.2.1 | 4.3.0 |

| Change history | | | | | | | |
|---|---|---|---|---|---|---|---|
| Date | TSG # | TSG Doc. | CR | Rev | Subject/Comment | Old | New |
| | RP-14 | RP-010765 | 1148 | | Clarification on DRX cycle length in connected mode | 4.2.1 | 4.3.0 |
| | RP-14 | RP-010765 | 1152 | | Correction to error condition on downlink information for each radio link | 4.2.1 | 4.3.0 |
| | RP-14 | RP-010765 | 1154 | | Correction of inconsistencies between tabular and ASN.1 | 4.2.1 | 4.3.0 |
| | RP-14 | RP-010765 | 1156 | | Measurement related corrections | 4.2.1 | 4.3.0 |
| | RP-14 | RP-010765 | 1158 | | Inconsistency between hard-coded preconfigurations parameters and procedure text | 4.2.1 | 4.3.0 |
| | RP-14 | RP-010765 | 1166 | | PLMN search in CELL_PCH/URA_PCH states with 80ms DRX cycle | 4.2.1 | 4.3.0 |
| | RP-14 | RP-010765 | 1168 | | Correction to CFN calculation for FDD | 4.2.1 | 4.3.0 |
| | RP-14 | RP-010765 | 1170 | | Correction to radio bearer control | 4.2.1 | 4.3.0 |
| | RP-14 | RP-010766 | 1172 | | Handling of IE "frequency info" | 4.2.1 | 4.3.0 |
| | RP-14 | RP-010766 | 1174 | | Correction to Radio Bearer Release | 4.2.1 | 4.3.0 |
| | RP-14 | RP-010940 | 1178 | 1 | Correction to RACH reporting | 4.2.1 | 4.3.0 |
| | RP-14 | RP-010766 | 1180 | | Correction to URA/Cell update and other minor corrections | 4.2.1 | 4.3.0 |
| | RP-14 | RP-010766 | 1182 | | Correction to Active Set Update | 4.2.1 | 4.3.0 |
| | RP-14 | RP-010766 | 1184 | | Correction of Traffic Volume Measurement Criteria | 4.2.1 | 4.3.0 |
| | RP-14 | RP-010941 | 1186 | 1 | Correction of UE Positioning | 4.2.1 | 4.3.0 |
| | RP-14 | RP-010766 | 1203 | | Invalid RRC CONNECTION REJECT | 4.2.1 | 4.3.0 |
| | RP-14 | RP-010766 | 1214 | | Security baseline for corrections | 4.2.1 | 4.3.0 |
| | RP-14 | RP-010766 | 1220 | | Pending integrity protection activation time for UL RB0 | 4.2.1 | 4.3.0 |
| | RP-14 | RP-010767 | 1222 | | Correction of rate matching restriction function | 4.2.1 | 4.3.0 |
| | RP-14 | RP-010773 | 1096 | | Usage of UM RLC Special Length Indicator | 4.2.1 | 4.3.0 |
| | RP-14 | RP-010773 | 1120 | | Corrections to REL-4 LCR Tabular Description and ASN1 Code | 4.2.1 | 4.3.0 |
| | RP-14 | RP-010773 | 1199 | | Correction of FPACH parameter definition for 1.28Mcps TDD | 4.2.1 | 4.3.0 |
| | RP-14 | RP-010773 | 1200 | | Correction of 1.28Mcps TDD | 4.2.1 | 4.3.0 |
| | RP-14 | RP-010773 | 1201 | | Correction and Clarification to Open Loop Power Control in 1.28 Mcps TDD | 4.2.1 | 4.3.0 |
| | RP-14 | RP-010773 | 1206 | | Extensions of IE value ranges in tabular | 4.2.1 | 4.3.0 |
| 03/2002 | RP-15 | RP-020070 | 1229 | | Constant value range correction for DPCH and PUSCH in TDD mode | 4.3.0 | 4.4.0 |
| | RP-15 | RP-020070 | 1231 | | Corrections to open loop power control for TDD and RB information parameters for SHCCH | 4.3.0 | 4.4.0 |
| | RP-15 | RP-020070 | 1233 | | Removal of unnecessary replication of TFCS ID in Physical Shared Channel Allocation message | 4.3.0 | 4.4.0 |
| | RP-15 | RP-020070 | 1237 | | Correction to TF selection when using UL RLC TM | 4.3.0 | 4.4.0 |
| | RP-15 | RP-020070 | 1239 | | Correction to the UE behaviour in case of SRNS relocation | 4.3.0 | 4.4.0 |
| | RP-15 | RP-020070 | 1241 | | Header Compression protocols re-initialisation during SRNS Relocation | 4.3.0 | 4.4.0 |
| | RP-15 | RP-020070 | 1243 | | Misalignments between tabular and ASN.1 related to UE Positioning, tabular correction | 4.3.0 | 4.4.0 |
| | RP-15 | RP-020070 | 1245 | | Corrections to comments in ASN.1 | 4.3.0 | 4.4.0 |
| | RP-15 | RP-020070 | 1247 | | Correction to restarting of T308 | 4.3.0 | 4.4.0 |
| | RP-15 | RP-020070 | 1249 | | Clarification of the use of T309 during inter-RAT cell reselections | 4.3.0 | 4.4.0 |
| | RP-15 | RP-020071 | 1251 | | Measurement Corrections | 4.3.0 | 4.4.0 |
| | RP-15 | RP-020239 | 1253 | 1 | Existence of TFCI bits | 4.3.0 | 4.4.0 |
| | RP-15 | RP-020071 | 1258 | | Corrections of inconsistency between procedural description, tabular and ASN.1 | 4.3.0 | 4.4.0 |
| | RP-15 | RP-020071 | 1260 | | Corrections to Expiration Time Factor and Expiration Time formula for SIB 7 and SIB 14 | 4.3.0 | 4.4.0 |
| | RP-15 | RP-020071 | 1262 | | Corrections to Reporting Cell Status | 4.3.0 | 4.4.0 |
| | RP-15 | RP-020071 | 1268 | | Correction to inter frequency measurements | 4.3.0 | 4.4.0 |
| | RP-15 | RP-020071 | 1271 | | Actions at reception of system information block type 1 | 4.3.0 | 4.4.0 |
| | RP-15 | RP-020071 | 1273 | | Tx diversity and no diversity in the same active set | 4.3.0 | 4.4.0 |
| | RP-15 | RP-020071 | 1275 | | Correction to cell update | 4.3.0 | 4.4.0 |
| | RP-15 | RP-020071 | 1277 | | Successful and unsuccessful procedures | 4.3.0 | 4.4.0 |
| | RP-15 | RP-020072 | 1279 | | Measurement related corrections | 4.3.0 | 4.4.0 |
| | RP-15 | RP-020072 | 1281 | | Clarifications on Event 1D | 4.3.0 | 4.4.0 |
| | RP-15 | RP-020205 | 1283 | 1 | Security corrections | 4.3.0 | 4.4.0 |
| | RP-15 | RP-020072 | 1285 | | Transition from CELL_DCH to CELL_FACH state | 4.3.0 | 4.4.0 |
| | RP-15 | RP-020072 | 1287 | | Corrections and clarifications of Radio link timing | 4.3.0 | 4.4.0 |

| Change history | | | | | | | |
|---|---|---|---|---|---|---|---|
| Date | TSG # | TSG Doc. | CR | Rev | Subject/Comment | Old | New |
| | RP-15 | RP-020072 | 1289 | | Spare values in ASN.1 | 4.3.0 | 4.4.0 |
| | RP-15 | RP-020072 | 1294 | | Actions on reception of measurement related IEs | 4.3.0 | 4.4.0 |
| | RP-15 | RP-020231 | 1296 | 1 | Removal of channel coding option "no coding" for FDD and 3.84 Mcps TDD | 4.3.0 | 4.4.0 |
| | RP-15 | RP-020072 | 1298 | | Timing Indication when moving to CELL_DCH state | 4.3.0 | 4.4.0 |
| | RP-15 | RP-020072 | 1307 | | Correction to processing RB mapping info | 4.3.0 | 4.4.0 |
| | RP-15 | RP-020072 | 1313 | | RRC Connection Release following network authentication failure | 4.3.0 | 4.4.0 |
| | RP-15 | RP-020072 | 1317 | | Clarification on serving cell in SIB11 | 4.3.0 | 4.4.0 |
| | RP-15 | RP-020073 | 1319 | | Treatment of optional elements in RB control messages | 4.3.0 | 4.4.0 |
| | RP-15 | RP-020073 | 1323 | | Procedure Performance for TDD UL physical Channel Control | 4.3.0 | 4.4.0 |
| | RP-15 | RP-020250 | 1331 | 1 | Clarification to physical channel establishment criteria | 4.3.0 | 4.4.0 |
| | RP-15 | RP-020249 | 1333 | 1 | OTDOA Assistance Data | 4.3.0 | 4.4.0 |
| | RP-15 | RP-020073 | 1337 | | Retransmission of uplink direct transfer at RLC re-establishment and inter-RAT change | 4.3.0 | 4.4.0 |
| | RP-15 | RP-020073 | 1339 | | Correction to IE "UL interference" for UTRA TDD | 4.3.0 | 4.4.0 |
| | RP-15 | RP-020074 | 1343 | | Corrections of UE Positioning requirements | 4.3.0 | 4.4.0 |
| | RP-15 | RP-020074 | 1345 | | Multimode speech in default configurations | 4.3.0 | 4.4.0 |
| | RP-15 | RP-020073 | 1347 | | Correction to UE Id for DSCH | 4.3.0 | 4.4.0 |
| | RP-15 | RP-020073 | 1349 | | Corrections to support combined Cell/URA update and SRNS relocation | 4.3.0 | 4.4.0 |
| | RP-15 | RP-020073 | 1351 | | Number of UTRAN and Inter-RAT frequencies | 4.3.0 | 4.4.0 |
| | RP-15 | RP-020073 | 1353 | | Abortion of signalling connection establishment | 4.3.0 | 4.4.0 |
| | RP-15 | RP-020073 | 1358 | | Modification of GPS timing representation to avoid large integers | 4.3.0 | 4.4.0 |
| | RP-15 | RP-020074 | 1360 | | Additional TFCS selection guidelines | 4.3.0 | 4.4.0 |
| | RP-15 | RP-020074 | 1362 | | Clarification of layer 3 filtering of measurements in the UE | 4.3.0 | 4.4.0 |
| | RP-15 | RP-020210 | 1364 | | Improved readability of procedural text | 4.3.0 | 4.4.0 |
| | RP-15 | RP-020228 | 1366 | | Clarification on ICS version within UE radio access capabilities | 4.3.0 | 4.4.0 |
| | RP-15 | RP-020233 | 1368 | | Clarification of Maximum number of TFC in the TFCS | 4.3.0 | 4.4.0 |
| | RP-15 | RP-020238 | 1370 | | Support of UP measurement reporting in CELL_PCH/URA_PCH | 4.3.0 | 4.4.0 |
| | RP-15 | RP-020082 | 1122 | 2 | Correction to include Cell ID for Cell_DCH state | 4.3.0 | 4.4.0 |
| | RP-15 | RP-020082 | 1187 | 2 | Correction of Transparent mode signalling for UL rate control | 4.3.0 | 4.4.0 |
| | RP-15 | RP-020082 | 1188 | 2 | Introduction of default radio configurations for UMTS_AMR2 with four speech modes | 4.3.0 | 4.4.0 |
| | RP-15 | RP-020082 | 1223 | 1 | Acquisition of PLMN identity of neighbour cells via SIB 18 | 4.3.0 | 4.4.0 |
| | RP-15 | RP-020082 | 1254 | | Various ASN.1 Corrections | 4.3.0 | 4.4.0 |
| | RP-15 | RP-020082 | 1290 | | Handover from UTRAN failure | 4.3.0 | 4.4.0 |
| | RP-15 | RP-020082 | 1335 | | Corrections to indicate that SIB 14 is not used by 1.28 TDD | 4.3.0 | 4.4.0 |
| | RP-15 | RP-020084 | 1129 | 2 | Support of flexible hard split mode | 4.4.0 | 5.0.0 |
| | RP-15 | RP-020090 | 1225 | 1 | Introduction of the parameters of OTDOA with IPDL for 1.28 Mcps TDD | 4.4.0 | 5.0.0 |
| | RP-15 | RP-020085 | 1291 | 1 | Radio link timing | 4.4.0 | 5.0.0 |
| | RP-15 | RP-020094 | 1305 | 2 | Introduction of HSDPA | 4.4.0 | 5.0.0 |
| 06/2002 | RP-16 | RP-020330 | 1373 | | ASN.1 Corrections | 5.0.0 | 5.1.0 |
| | RP-16 | RP-020330 | 1376 | | Clarification of unnecessary MP IEs in RADIO BEARER RECONFIGURATION | 5.0.0 | 5.1.0 |
| | RP-16 | RP-020330 | 1379 | | Correction on SIB type | 5.0.0 | 5.1.0 |
| | RP-16 | RP-020330 | 1382 | | Clarification to the handling of IE "Cells for measurement" received in SIB 11/12 | 5.0.0 | 5.1.0 |
| | RP-16 | RP-020330 | 1385 | 1 | Correction to Cell Update procedure | 5.0.0 | 5.1.0 |
| | RP-16 | RP-020330 | 1388 | | Correction to handling of FACH measurement occasion info in SIB12 | 5.0.0 | 5.1.0 |
| | RP-16 | RP-020331 | 1392 | | Actions when optional IE "Maximum allowed UL TX power" is missing | 5.0.0 | 5.1.0 |
| | RP-16 | RP-020331 | 1395 | | Corrections concerning default configurations | 5.0.0 | 5.1.0 |
| | RP-16 | RP-020331 | 1398 | | Correction concerning when hard handover specific handling applies | 5.0.0 | 5.1.0 |
| | RP-16 | RP-020331 | 1401 | | Handling of variables CELL_INFO_LIST and MEASUREMENT_IDENTITY | 5.0.0 | 5.1.0 |
| | RP-16 | RP-020331 | 1404 | | IE "Cell Synchronisation Information" | 5.0.0 | 5.1.0 |
| | RP-16 | RP-020331 | 1407 | | Corrections to Cell Individual Offset | 5.0.0 | 5.1.0 |
| | RP-16 | RP-020332 | 1410 | | Clarification to Compressed Mode Status Info | 5.0.0 | 5.1.0 |

| Change history | | | | | | | |
|---|---|---|---|---|---|---|---|
| Date | TSG # | TSG Doc. | CR | Rev | Subject/Comment | Old | New |
| | RP-16 | RP-020332 | 1413 | | Clarification of OTDOA quality figure | 5.0.0 | 5.1.0 |
| | RP-16 | RP-020332 | 1416 | | Correction to Cell Access Restriction for SIB4 | 5.0.0 | 5.1.0 |
| | RP-16 | RP-020332 | 1419 | | Corrections concerning spare values and comments | 5.0.0 | 5.1.0 |
| | RP-16 | RP-020332 | 1423 | | Variable for shared channel configurations | 5.0.0 | 5.1.0 |
| | RP-16 | RP-020332 | 1426 | 1 | Integrity protection on RB0 | 5.0.0 | 5.1.0 |
| | RP-16 | RP-020333 | 1429 | 1 | Periodic cell update clarifications | 5.0.0 | 5.1.0 |
| | RP-16 | RP-020333 | 1432 | | Multiple cells triggering event 1D | 5.0.0 | 5.1.0 |
| | RP-16 | RP-020333 | 1435 | | Disjoint Active Sets in the Active Set Update procedure | 5.0.0 | 5.1.0 |
| | RP-16 | RP-020333 | 1438 | | Deletion on compressed mode patterns when moving to CELL_FACH state | 5.0.0 | 5.1.0 |
| | RP-16 | RP-020333 | 1441 | | TDD C-RNTI in Cell DCH | 5.0.0 | 5.1.0 |
| | RP-16 | RP-020333 | 1444 | 1 | CCTrCH Release in TDD | 5.0.0 | 5.1.0 |
| | RP-16 | RP-020334 | 1447 | | Layer 3 retransmission of SIGNALLING CONNECTION RELEASE INDICATION | 5.0.0 | 5.1.0 |
| | RP-16 | RP-020334 | 1450 | | Alignment of tabular and ASN.1 for UTRAN GPS timing of cell frames resolution | 5.0.0 | 5.1.0 |
| | RP-16 | RP-020334 | 1453 | | Correction to Default Radio Configuration Timers | 5.0.0 | 5.1.0 |
| | RP-16 | RP-020334 | 1456 | | Clarification to number of L3 filters | 5.0.0 | 5.1.0 |
| | RP-16 | RP-020334 | 1459 | 1 | Correction to 3G to 2G Inter-RAT handover for multi-domain RABs | 5.0.0 | 5.1.0 |
| | RP-16 | RP-020334 | 1462 | | DCH quality target | 5.0.0 | 5.1.0 |
| | RP-16 | RP-020335 | 1465 | | Correction to RB Mapping Info | 5.0.0 | 5.1.0 |
| | RP-16 | RP-020335 | 1468 | 1 | Ciphering activation for TM bearers | 5.0.0 | 5.1.0 |
| | RP-16 | RP-020335 | 1471 | | TFCS selection guideline correction | 5.0.0 | 5.1.0 |
| | RP-16 | RP-020382 | 1480 | 1 | Clarification of Measurement Validity and Valid Measurement Objects | 5.0.0 | 5.1.0 |
| | RP-16 | RP-020363 | 1483 | | Remaining clarification of Measurement Validity and Valid Measurement Objects | 5.0.0 | 5.1.0 |
| | RP-16 | RP-020381 | 1486 | 1 | Traffic Volume Measurement clarifications | 5.0.0 | 5.1.0 |
| | RP-16 | RP-020335 | 1489 | | Correction to handling of IE 'Downlink information for each RL' | 5.0.0 | 5.1.0 |
| | RP-16 | RP-020336 | 1492 | | Corrections to Security procedure on Missing integrity protection reset on relocation and counter check response actions for asymmetric bearer configurations | 5.0.0 | 5.1.0 |
| | RP-16 | RP-020336 | 1495 | | Corrections to cell update interactions with security and SRNS Relocation | 5.0.0 | 5.1.0 |
| | RP-16 | RP-020336 | 1498 | | "Out of service" area definition | 5.0.0 | 5.1.0 |
| | RP-16 | RP-020339 | 1473 | | RRC connection release procedure in CELL_DCH state | 5.0.0 | 5.1.0 |
| | RP-16 | RP-020339 | 1475 | | Correction to DL TM DCCH TF size for Default Configurations | 5.0.0 | 5.1.0 |
| | RP-16 | RP-020339 | 1477 | | Corrections in ASN.1 related to SRNS relocation | 5.0.0 | 5.1.0 |
| | RP-16 | RP-020341 | 1499 | | HS-DSCH related corrections | 5.0.0 | 5.1.0 |
| | RP-16 | RP-020341 | 1500 | | Removal of BLER threshold from IE "Measurement Feedback info" | 5.0.0 | 5.1.0 |
| | RP-16 | RP-020345 | 1501 | | RFC 3095 context relocation | 5.0.0 | 5.1.0 |
| 09/2002 | RP-17 | RP-020541 | 1504 | 1 | UE behaviour when active set cells are not included in CELL_INFO_LIST | 5.1.0 | 5.2.0 |
| | RP-17 | RP-020541 | 1507 | 1 | Corrections to handling of IE "Cells for measurement" | 5.1.0 | 5.2.0 |
| | RP-17 | RP-020541 | 1510 | | Clarification on the use of UE radio access capability extensions within the INTER RAT HANDOVER INFO message | 5.1.0 | 5.2.0 |
| | RP-17 | RP-020541 | 1513 | | Correction to RRC connection procedure | 5.1.0 | 5.2.0 |
| | RP-17 | RP-020541 | 1516 | | Correction to the variable TGPS_IDENTITY | 5.1.0 | 5.2.0 |
| | RP-17 | RP-020541 | 1522 | | Missing IEs in RLC info | 5.1.0 | 5.2.0 |
| | RP-17 | RP-020542 | 1528 | 1 | Corrections of UE internal measurement reporting events | 5.1.0 | 5.2.0 |
| | RP-17 | RP-020542 | 1531 | 2 | UE behaviour upon reception of reconfiguration | 5.1.0 | 5.2.0 |
| | RP-17 | RP-020542 | 1534 | | Application of integrity keys in case of a pending CN domain switch during a SRNS relocation | 5.1.0 | 5.2.0 |
| | RP-17 | RP-020542 | 1537 | 1 | Clarifications on Quality Measurements | 5.1.0 | 5.2.0 |
| | RP-17 | RP-020542 | 1540 | | Correction of DPCH constant value in TDD default radio configurations | 5.1.0 | 5.2.0 |
| | RP-17 | RP-020542 | 1543 | | Handling of UE internal measurement information in broadcast | 5.1.0 | 5.2.0 |
| | RP-17 | RP-020543 | 1546 | | Observed time difference to GSM reporting indicator | 5.1.0 | 5.2.0 |
| | RP-17 | RP-020543 | 1551 | | Corrections on Security relative to ciphering of TM bearers and to SRNS relocation | 5.1.0 | 5.2.0 |
| | RP-17 | RP-020543 | 1554 | | Coding of IE NC mode | 5.1.0 | 5.2.0 |
| | RP-17 | RP-020543 | 1557 | | Clarification to filtered measurement quantities | 5.1.0 | 5.2.0 |

| Change history | | | | | | | |
|---|---|---|---|---|---|---|---|
| Date | TSG # | TSG Doc. | CR | Rev | Subject/Comment | Old | New |
| | RP-17 | RP-020543 | 1560 | | Inconsistencies in triggering and reporting for events 1a, 1b,1c, 1e and 1f | 5.1.0 | 5.2.0 |
| | RP-17 | RP-020543 | 1563 | 1 | Optional and Mandatory fields in Measurement Control | 5.1.0 | 5.2.0 |
| | RP-17 | RP-020544 | 1566 | | Clarifications to Reporting Cell Status | 5.1.0 | 5.2.0 |
| | RP-17 | RP-020544 | 1569 | | Clarification to minimum SF | 5.1.0 | 5.2.0 |
| | RP-17 | RP-020544 | 1572 | | Clarifications to inter-frequency measurements | 5.1.0 | 5.2.0 |
| | RP-17 | RP-020544 | 1578 | 2 | Ciphering when HO to UMTS of signalling only connection | 5.1.0 | 5.2.0 |
| | RP-17 | RP-020544 | 1581 | | Inter RAT handover from UTRAN | 5.1.0 | 5.2.0 |
| | RP-17 | RP-020544 | 1584 | | Correction to Cell Update procedure with cause "Radio link failure" | 5.1.0 | 5.2.0 |
| | RP-17 | RP-020545 | 1587 | | Correction to the handling of IE "UTRAN DRX cycle length coefficient" in CELL/URA UPDATE procedure | 5.1.0 | 5.2.0 |
| | RP-17 | RP-020545 | 1590 | | Correction to RLC unrecoverable error occurs in CELL_DCH state | 5.1.0 | 5.2.0 |
| | RP-17 | RP-020545 | 1593 | | Use of scrambling change when activating CM pattern using SF/2 by MEASUREMENT CONTROL | 5.1.0 | 5.2.0 |
| | RP-17 | RP-020545 | 1596 | | Actions when optional IE "Maximum allowed UL TX power" is missing | 5.1.0 | 5.2.0 |
| | RP-17 | RP-020630 | 1599 | 1 | IP_offset correction | 5.1.0 | 5.2.0 |
| | RP-17 | RP-020545 | 1602 | | Clarification on the IE "Frequency Info" | 5.1.0 | 5.2.0 |
| | RP-17 | RP-020546 | 1605 | | Correction of RNTI used in PUSCH capacity request and physical shared channel allocation | 5.1.0 | 5.2.0 |
| | RP-17 | RP-020546 | 1608 | | Correction to allowed logical channel list choice for RACH transport channels | 5.1.0 | 5.2.0 |
| | RP-17 | RP-020654 | 1611 | 1 | Clarification of SRNS Relocation Info | 5.1.0 | 5.2.0 |
| | RP-17 | RP-020546 | 1614 | | DCH quality target | 5.1.0 | 5.2.0 |
| | RP-17 | RP-020546 | 1617 | | Handling of variables CELL_INFO_LIST and MEASUREMENT_IDENTITY(2) | 5.1.0 | 5.2.0 |
| | RP-17 | RP-020546 | 1620 | 1 | Correction of secondary CCPCH selection and PRACH selection | 5.1.0 | 5.2.0 |
| | RP-17 | RP-020547 | 1623 | | RRC TVM Corrections | 5.1.0 | 5.2.0 |
| | RP-17 | RP-020547 | 1626 | | Correction of Transmission Gap Distance semantics description | 5.1.0 | 5.2.0 |
| | RP-17 | RP-020547 | 1629 | | Corrections to Active Set Update and simultaneous reconfiguration | 5.1.0 | 5.2.0 |
| | RP-17 | RP-020547 | 1632 | | UE behaviour following RLC size change | 5.1.0 | 5.2.0 |
| | RP-17 | RP-020547 | 1635 | | RRC SN in uplink | 5.1.0 | 5.2.0 |
| | RP-17 | RP-020547 | 1638 | | Multiplexing of Tr mode RBs of different CN domains on the same transport channel | 5.1.0 | 5.2.0 |
| | RP-17 | RP-020548 | 1641 | | Security clarifications | 5.1.0 | 5.2.0 |
| | RP-17 | RP-020548 | 1644 | | Correction to the actions of "out of service area" and "in service area" | 5.1.0 | 5.2.0 |
| | RP-17 | RP-020548 | 1647 | | TVM: pending time after trigger and initial conditions | 5.1.0 | 5.2.0 |
| | RP-17 | RP-020548 | 1650 | 1 | Handling of Downlink information for each RL in reconfiguration messages | 5.1.0 | 5.2.0 |
| | RP-17 | RP-020548 | 1655 | | Corrections to Cell Update/URA Update Procedure in case of nested cell updates and simultaneous SRNS relocation | 5.1.0 | 5.2.0 |
| | RP-17 | RP-020548 | 1670 | | Corrections to security | 5.1.0 | 5.2.0 |
| | RP-17 | RP-020631 | 1673 | 1 | SRNS relocation with integrity | 5.1.0 | 5.2.0 |
| | RP-17 | RP-020549 | 1676 | | Reception of MEASUREMENT CONTROL in state CELL_FACH | 5.1.0 | 5.2.0 |
| | RP-17 | RP-020549 | 1679 | | Unsupported configuration | 5.1.0 | 5.2.0 |
| | RP-17 | RP-020549 | 1682 | | Handover corrections | 5.1.0 | 5.2.0 |
| | RP-17 | RP-020558 | 1575 | 1 | Correction of SFN-SFN Measurement | 5.1.0 | 5.2.0 |
| | RP-17 | RP-020559 | 1661 | | Corrections to Synchronisation for 1.28 Mcps TDD | 5.1.0 | 5.2.0 |
| | RP-17 | RP-020553 | 1657 | | Corrections on Power Control for 1.28 Mcps TDD | 5.1.0 | 5.2.0 |
| | RP-17 | RP-020553 | 1659 | | Correction to RLC entity re-establishment during SRNS relocation | 5.1.0 | 5.2.0 |
| | RP-17 | RP-020553 | 1663 | | Reintroduction of IE "SRB delay" in Rel-4 ASN.1 | 5.1.0 | 5.2.0 |
| | RP-17 | RP-020553 | 1665 | | Corrections to ASN.1 for SRNC relocation container | 5.1.0 | 5.2.0 |
| | RP-17 | RP-020553 | 1667 | | Unused elements in ASN.1 | 5.1.0 | 5.2.0 |
| | RP-17 | RP-020557 | 1547 | | Correction on Radio link timing | 5.1.0 | 5.2.0 |
| | RP-17 | RP-020662 | 1651 | 2 | Physical layer IEs for HSDPA | 5.1.0 | 5.2.0 |
| | RP-17 | RP-020557 | 1652 | | Transport channel information elements for HSDPA | 5.1.0 | 5.2.0 |
| | RP-17 | RP-020590 | 1683 | | TX diversity on radio links in the active set | 5.1.0 | 5.2.0 |
| | RP-17 | RP-020557 | 1684 | | Mandatory Support of dedicated pilots for channel estimation | 5.1.0 | 5.2.0 |
| 12/2002 | RP-18 | RP-020721 | 1687 | | Corrections to IEs "Ellipsoid point with Altitude and uncertainty Ellipsoid" and "Ellipsoid point with uncertainty Ellipse" | 5.2.0 | 5.3.0 |

| Change history | | | | | | | |
|---|---|---|---|---|---|---|---|
| Date | TSG # | TSG Doc. | CR | Rev | Subject/Comment | Old | New |
| | RP-18 | RP-020721 | 1690 | 1 | Handling of Ciphering and integrity protection activation times | 5.2.0 | 5.3.0 |
| | RP-18 | RP-020721 | 1693 | | Handling of measurements at state transitions to/from DCH state. | 5.2.0 | 5.3.0 |
| | RP-18 | RP-020721 | 1696 | 2 | Measurement related corrections | 5.2.0 | 5.3.0 |
| | RP-18 | RP-020721 | 1699 | | ASN.1 of the SRNS relocation info | 5.2.0 | 5.3.0 |
| | RP-18 | RP-020721 | 1710 | 1 | Corrections to PRACH selection | 5.2.0 | 5.3.0 |
| | RP-18 | RP-020722 | 1713 | | TDD Downlink Path Loss for interfrequency measurement | 5.2.0 | 5.3.0 |
| | RP-18 | RP-020892 | 1716 | 1 | Correction on coding of GSM Classmark 2 and 3 | 5.2.0 | 5.3.0 |
| | RP-18 | RP-020722 | 1719 | | Correction on Frame Allocation Calculation | 5.2.0 | 5.3.0 |
| | RP-18 | RP-020722 | 1722 | | Inter-frequency measurements | 5.2.0 | 5.3.0 |
| | RP-18 | RP-020722 | 1725 | | Maximum Allowed UL TX Power | 5.2.0 | 5.3.0 |
| | RP-18 | RP-020722 | 1728 | | START values for the initialisation of SRB counters and UTRAN incorrect actions | 5.2.0 | 5.3.0 |
| | RP-18 | RP-020723 | 1731 | | Correction to the RRC transaction table management | 5.2.0 | 5.3.0 |
| | RP-18 | RP-020723 | 1803 | | Use of DCH Quality Target with Blind Transport Format Detection | 5.2.0 | 5.3.0 |
| | RP-18 | RP-020723 | 1742 | | Correction to storing current TFC subset in variable TFC_SUBSET for TDD | 5.2.0 | 5.3.0 |
| | RP-18 | RP-020723 | 1745 | | Security at inter-RAT handover | 5.2.0 | 5.3.0 |
| | RP-18 | RP-020723 | 1748 | | Integrity protection activations times | 5.2.0 | 5.3.0 |
| | RP-18 | RP-020723 | 1751 | | Additional measurements | 5.2.0 | 5.3.0 |
| | RP-18 | RP-020724 | 1754 | | DPCH compressed mode info in Downlink information common for all RLs | 5.2.0 | 5.3.0 |
| | RP-18 | RP-020724 | 1757 | 1 | Handling of RB mapping | 5.2.0 | 5.3.0 |
| | RP-18 | RP-020724 | 1766 | | RLC window size in default configurations | 5.2.0 | 5.3.0 |
| | RP-18 | RP-020724 | 1769 | | Corrections to Activation time | 5.2.0 | 5.3.0 |
| | RP-18 | RP-020724 | 1772 | | Numbering of "ASC Setting" IEs included in "PRACH partitioning" IE | 5.2.0 | 5.3.0 |
| | RP-18 | RP-020724 | 1779 | 2 | Correction on support for compressed mode | 5.2.0 | 5.3.0 |
| | RP-18 | RP-020903 | 1734 | 3 | Introduction of backwards compatible correction mechanism | 5.2.0 | 5.3.0 |
| | RP-18 | RP-020727 | 1776 | | Signalling of the timing adjustment mode for closed loop Tx diversity | 5.2.0 | 5.3.0 |
| | RP-18 | RP-020893 | 1810 | | Handling of hyper frame numbers | 5.2.0 | 5.3.0 |
| | RP-18 | RP-020726 | 1760 | 2 | Early UE Specific Behaviour Information in RRC Connection Request / interRAT info | 5.2.0 | 5.3.0 |
| | RP-18 | RP-020858 | 1701 | | Correction of ASN1 IE "InterFreqCellInfoList-r4" | 5.2.0 | 5.3.0 |
| | RP-18 | RP-020858 | 1703 | | Correction of Special Burst Scheduling for TDD | 5.2.0 | 5.3.0 |
| | RP-18 | RP-020858 | 1705 | | Correction of measurement reporting event 6f for 1.28 Mcps TDD | 5.2.0 | 5.3.0 |
| | RP-18 | RP-020858 | 1781 | | Ciphering during SRNS relocation without reuse of COUNT-C | 5.2.0 | 5.3.0 |
| | RP-18 | RP-020858 | 1783 | | Correction to IE 'Intra Domain NAS Node Selector' | 5.2.0 | 5.3.0 |
| | RP-18 | RP-020858 | 1785 | | Correction to PRACH selection | 5.2.0 | 5.3.0 |
| | RP-18 | RP-020859 | 1787 | | Correction to reporting event 6f for FDD | 5.2.0 | 5.3.0 |
| | RP-18 | RP-020859 | 1802 | | ASN.1 corrections | 5.2.0 | 5.3.0 |
| | RP-18 | RP-020859 | 1805 | | Asymmetric ROHC Configuration | 5.2.0 | 5.3.0 |
| | RP-18 | RP-020859 | 1807 | | Reference Cell for GSM OTD Measurement | 5.2.0 | 5.3.0 |
| | RP-18 | RP-020736 | 1707 | | RRC container for RFC3095 context | 5.2.0 | 5.3.0 |
| | RP-18 | RP-020736 | 1791 | | Correction to IE 'Access stratum release indicator' | 5.2.0 | 5.3.0 |
| | RP-18 | RP-020736 | 1792 | | RLC capability for HSDPA | 5.2.0 | 5.3.0 |
| | RP-18 | RP-020736 | 1794 | | Dedicated pilot bits for HS-DSCH | 5.2.0 | 5.3.0 |
| | RP-18 | RP-020736 | 1795 | | Expansion of CPICH RSCP range | 5.2.0 | 5.3.0 |
| | RP-18 | RP-020736 | 1796 | | L3 Retransmission of event 1b | 5.2.0 | 5.3.0 |
| | RP-18 | RP-020736 | 1797 | | DPC mode change in ACTIVE SET UPDATE message | 5.2.0 | 5.3.0 |
| | RP-18 | RP-020736 | 1798 | | Correction to handling of IE 'Downlink information for each RL' | 5.2.0 | 5.3.0 |
| | RP-18 | RP-020896 | 1793 | 2 | HSDPA parameter value ranges | 5.2.0 | 5.3.0 |
| 03/2003 | RP-19 | RP-030103 | 1813 | | ASN.1 of the SRNS relocation Info | 5.3.0 | 5.4.0 |
| | RP-19 | RP-030103 | 1816 | | Correction to procedural text for Physical Shared Channel Allocation (TDD only) | 5.3.0 | 5.4.0 |
| | RP-19 | RP-030103 | 1819 | 1 | CM and state transition related to measurements, additional measurements, virtual active set and periodic measurements | 5.3.0 | 5.4.0 |
| | RP-19 | RP-030103 | 1822 | | Physical channel failure and radio link re-establishment | 5.3.0 | 5.4.0 |
| | RP-19 | RP-030103 | 1825 | | Correction concerning bit numbering convention | 5.3.0 | 5.4.0 |

| Change history | | | | | | | |
|---|---|---|---|---|---|---|---|
| Date | TSG # | TSG Doc. | CR | Rev | Subject/Comment | Old | New |
| | RP-19 | RP-030104 | 1831 | | Additional Measurement reporting list | 5.3.0 | 5.4.0 |
| | RP-19 | RP-030104 | 1834 | 2 | Correction on RRC integrity protection procedure | 5.3.0 | 5.4.0 |
| | RP-19 | RP-030104 | 1837 | | Reporting Cell Status and Event 2A | 5.3.0 | 5.4.0 |
| | RP-19 | RP-030104 | 1840 | | Correction to the handling of variable TGPS_IDENTITY and IE 'Triggering condition 1/2' | 5.3.0 | 5.4.0 |
| | RP-19 | RP-030104 | 1843 | 1 | Hard handover with pending ciphering activation times | 5.3.0 | 5.4.0 |
| | RP-19 | RP-030105 | 1846 | | Correction of default configurations | 5.3.0 | 5.4.0 |
| | RP-19 | RP-030105 | 1849 | | Correction to UE behaviour on entering RRC Connected mode | 5.3.0 | 5.4.0 |
| | RP-19 | RP-030105 | 1855 | | Update of Start values in USIM on inter-RAT transitions and transitions to idle mode | 5.3.0 | 5.4.0 |
| | RP-19 | RP-030082 | 1858 | | Corrections to Channelisation Code TFCI Mapping for TDD | 5.3.0 | 5.4.0 |
| | RP-19 | RP-030111 | 1860 | | Correction of PNBSCH for 1.28Mcps TDD | 5.3.0 | 5.4.0 |
| | RP-19 | RP-030111 | 1862 | | Correction of SFN-SFN observed time difference for 1.28Mcps TDD | 5.3.0 | 5.4.0 |
| | RP-19 | RP-030111 | 1864 | 3 | ASN.1 corrections concerning missing UE capability extensions | 5.3.0 | 5.4.0 |
| | RP-19 | RP-030111 | 1866 | | Extensions for 1.28 Mcps specific elements in system information | 5.3.0 | 5.4.0 |
| | RP-19 | RP-030111 | 1868 | | Corrections to power control parameter signalling for 1.28 Mcps TDD | 5.3.0 | 5.4.0 |
| | RP-19 | RP-030117 | 1872 | | TDD HS-SICH Power Control | 5.3.0 | 5.4.0 |
| | RP-19 | RP-030117 | 1873 | | Usage of separate scrambling code for HSDPA | 5.3.0 | 5.4.0 |
| | RP-19 | RP-030119 | 1874 | | TDD HS-DSCH midamble shift and burst type | 5.3.0 | 5.4.0 |
| | RP-19 | RP-030117 | 1875 | | Corrections to the IE "Added or Reconfigured MAC-d flow" and the associated table in 10.3.10 | 5.3.0 | 5.4.0 |
| | RP-19 | RP-030117 | 1877 | 1 | Network Assisted Cell Change from UTRAN to GERAN | 5.3.0 | 5.4.0 |
| | RP-19 | RP-030117 | 1878 | 1 | Defining more than one DSCH / USCH transport channel in PDSCH and PUSCH system information (TDD only) | 5.3.0 | 5.4.0 |
| | RP-19 | RP-030117 | 1879 | | Introducing the use of pre-defined configurations within UTRA | 5.3.0 | 5.4.0 |
| | RP-19 | RP-030120 | 1880 | | Group release (without security | 5.3.0 | 5.4.0 |
| | RP-19 | RP-030105 | 1884 | | Correction to Inter-RAT Measurement Report | 5.3.0 | 5.4.0 |
| | RP-19 | RP-030106 | 1887 | | Correction of signalling of transport block size for DSCH | 5.3.0 | 5.4.0 |
| | RP-19 | RP-030106 | 1890 | | PS service continuity when moving between 3G and 2G | 5.3.0 | 5.4.0 |
| | RP-19 | RP-030106 | 1893 | 1 | Multiple activations of the same compressed mode pattern | 5.3.0 | 5.4.0 |
| | RP-19 | RP-030106 | 1896 | | Setting of ciphering activation time for TM bearers | 5.3.0 | 5.4.0 |
| | RP-19 | RP-030117 | 1897 | | Correction of shadow CR implementation | 5.3.0 | 5.4.0 |
| | RP-19 | RP-030111 | 1899 | | Removal of MRRU parameter in PDCP info | 5.3.0 | 5.4.0 |
| | RP-19 | RP-030117 | 1900 | | Measurement event for evaluation of best HS-DSCH cel | 5.3.0 | 5.4.0 |
| | RP-19 | RP-030105 | 1902 | 1 | NAS and Integrity procedure interaction | 5.3.0 | 5.4.0 |
| | RP-19 | RP-030117 | 1903 | | Correction to USBI | 5.3.0 | 5.4.0 |
| | RP-19 | RP-030187 | 1909 | | GPS navigation model update mechanism | 5.3.0 | 5.4.0 |
| | RP-19 | RP-030201 | 1910 | | Layer 3 filtering definition | 5.3.0 | 5.4.0 |
| | RP-20 | RP-030293 | 1913 | | Handling of UP Assistance Data | 5.4.0 | 5.5.0 |
| | RP-20 | RP-030293 | 1916 | 1 | Concerns on Procedures for Cell-ID Positioning Method | 5.4.0 | 5.5.0 |
| | RP-20 | RP-030293 | 1919 | | Inconsistency between Procedural, ASN.1, and Tabular Aspects of UE Positioning Error | 5.4.0 | 5.5.0 |
| | RP-20 | RP-030293 | 1922 | | Removal of FFS (For further Study) and references to other working groups | 5.4.0 | 5.5.0 |
| | RP-20 | RP-030293 | 1926 | | Key handling when entering idle mode and coding of security capabilities | 5.4.0 | 5.5.0 |
| | RP-20 | RP-030293 | 1929 | | Security actions when SIM is present on RRC Connection Request | 5.4.0 | 5.5.0 |
| | RP-20 | RP-030294 | 1932 | | Update of interfrequency measurement cell info list, reading of SIB11/12, inclusion of Measured Results on RACH | 5.4.0 | 5.5.0 |
| | RP-20 | RP-030294 | 1937 | | Additional measurements without measurement validity | 5.4.0 | 5.5.0 |
| | RP-20 | RP-030294 | 1940 | | Handover to UTRAN in macrodiversity | 5.4.0 | 5.5.0 |
| | RP-20 | RP-030294 | 1943 | 1 | TVM Reporting in CELL_PCH state | 5.4.0 | 5.5.0 |
| | RP-20 | RP-030294 | 1946 | 1 | Initialisation of the Virtual Active Set | 5.4.0 | 5.5.0 |
| | RP-20 | RP-030295 | 1949 | | IE 'Tx diversity mode' in ACTIVE SET UPDATE message | 5.4.0 | 5.5.0 |
| | RP-20 | RP-030295 | 1952 | 1 | Correction to transport channel traffic volume measurement events 4a and 4b | 5.4.0 | 5.5.0 |
| | RP-20 | RP-030295 | 1955 | | Maximum Number of GPS Almanac Messages to be Stored in UE_POSITIONING_GPS_DATA | 5.4.0 | 5.5.0 |
| | RP-20 | RP-030374 | 1958 | 2 | Stopping of RLC entities at relocation | 5.4.0 | 5.5.0 |
| | RP-20 | RP-030369 | 1978 | 4 | Ciphering Mode info IE in 2G-3G Handover | 5.4.0 | 5.5.0 |

| Change history | | | | | | | |
|---|---|---|---|---|---|---|---|
| Date | TSG # | TSG Doc. | CR | Rev | Subject/Comment | Old | New |
| | RP-20 | RP-030295 | 1981 | | START values on 2G-3G handover | 5.4.0 | 5.5.0 |
| | RP-20 | RP-030298 | 1983 | | ROHC profile signalling | 5.4.0 | 5.5.0 |
| | RP-20 | RP-030298 | 1959 | 1 | Optimisation of the INTER RAT HANDOVER INFO message | 5.4.0 | 5.5.0 |
| | RP-20 | RP-030350 | 1987 | 2 | Corrections to security procedures in case of pending security configurations at SRNS Relocation | 5.4.0 | 5.5.0 |
| | RP-20 | RP-030371 | 1990 | | Setting of T317 to infinity and out of service behaviour | 5.4.0 | 5.5.0 |
| | RP-20 | RP-030303 | 1960 | | Correction to the IE "HS-DSCH capability class" | 5.4.0 | 5.5.0 |
| | RP-20 | RP-030303 | 1961 | | Correction of 'RB mapping info' in case HS-DSCH + DCH | 5.4.0 | 5.5.0 |
| | RP-20 | RP-030303 | 1963 | | Explanation of CV-UE for the IE MidambleShift in the tabular | 5.4.0 | 5.5.0 |
| 09/2003 | RP-21 | RP-030484 | 1993 | | Handling of key sets at Inter-RAT Handover to UTRAN | 5.5.0 | 5.6.0 |
| | RP-21 | RP-030484 | 1996 | | Correction to UE Positioning privacy procedures | 5.5.0 | 5.6.0 |
| | RP-21 | RP-030520 | 2003 | 2 | START calculation in connected mode | 5.5.0 | 5.6.0 |
| | RP-21 | RP-030506 | 2000 | 1 | Reconfiguration with state transition to an indicated cell on a different frequency | 5.5.0 | 5.6.0 |
| | RP-21 | RP-030484 | 2006 | | PRACH channelisation code list limitation to align with TS 25.221 | 5.5.0 | 5.6.0 |
| | RP-21 | RP-030484 | 2009 | | Handling of transport channel information at radio bearer release | 5.5.0 | 5.6.0 |
| | RP-21 | RP-030485 | 2015 | | Corrections for TDD for the IEs 'Downlink DPCH info common for all radio links' | 5.5.0 | 5.6.0 |
| | RP-21 | RP-030485 | 2018 | | TFCS selection guidelines for TFC Subset | 5.5.0 | 5.6.0 |
| | RP-21 | RP-030485 | 2025 | | Value range of UE Rx-Tx time difference type 2 measurement | 5.5.0 | 5.6.0 |
| | RP-21 | RP-030485 | 2033 | | Activation Time for DSCH | 5.5.0 | 5.6.0 |
| | RP-21 | RP-030485 | 2044 | | Correction of PDCP Configuration for RFC 2507 | 5.5.0 | 5.6.0 |
| | RP-21 | RP-030486 | 2048 | | Corrections to event list handling | 5.5.0 | 5.6.0 |
| | RP-21 | RP-030486 | 2051 | | Corrections to RACH reporting | 5.5.0 | 5.6.0 |
| | RP-21 | RP-030486 | 2054 | | Corrections to modification of Additional Measurement lists | 5.5.0 | 5.6.0 |
| | RP-21 | RP-030486 | 2057 | | UE positioning support in the UE | 5.5.0 | 5.6.0 |
| | RP-21 | RP-030478 | 2064 | | Elimination of EPC mechanism | 5.5.0 | 5.6.0 |
| | RP-21 | RP-030486 | 2069 | | UE behaviour in transition from CELL_DCH to CELL_FACH/ CELL_PCH/URA_PCH and Out of Service is detected | 5.5.0 | 5.6.0 |
| | RP-21 | RP-030505 | 2072 | 1 | Radio link failure during reconfiguration procedure | 5.5.0 | 5.6.0 |
| | RP-21 | RP-030491 | 2020 | | Ciphering of TM SRBs | 5.5.0 | 5.6.0 |
| | RP-21 | RP-030491 | 2022 | 1 | Correction on PDCP Header compression Configuration | 5.5.0 | 5.6.0 |
| | RP-21 | RP-030491 | 2027 | | Corrections for TDD PUSCH | 5.5.0 | 5.6.0 |
| | RP-21 | RP-030495 | 1997 | | Correction to UE behaviour on T317 expiry | 5.5.0 | 5.6.0 |
| | RP-21 | RP-030495 | 2029 | | Correcting value range of MAC-hs buffer ID | 5.5.0 | 5.6.0 |
| | RP-21 | RP-030495 | 2030 | | Correction of handling of IE "MAC-hs reset indicator" in Added or Reconfigured DL TrCH information | 5.5.0 | 5.6.0 |
| | RP-21 | RP-030495 | 2035 | 1 | UE capability signalling for UMTS1800 | 5.5.0 | 5.6.0 |
| | RP-21 | RP-030495 | 2039 | | Handover between UTRAN and GERAN Iu mode | 5.5.0 | 5.6.0 |
| | RP-21 | RP-030495 | 2040 | | Updated references to the RRC State Indicator IE | 5.5.0 | 5.6.0 |
| | RP-21 | RP-030495 | 2041 | | Corrections to Event 1D | 5.5.0 | 5.6.0 |
| | RP-21 | RP-030449 | 2028 | | Reconfiguration of MAC-d flow | 5.5.0 | 5.6.0 |
| | RP-21 | RP-030462 | 2061 | | HS-SCCH transmit diversity mode | 5.5.0 | 5.6.0 |
| | RP-21 | RP-030503 | 2066 | | Scrambling code & phase reference combinations for HS-DSCH (solution 2) | 5.5.0 | 5.6.0 |
| 12/2003 | RP-22 | RP-030617 | 2075 | | Unsuccessful security mode control procedure and Integrity Protection | 5.6.0 | 5.7.0 |
| | RP-22 | RP-030625 | 2076 | | START value calculation for RLC size change | 5.6.0 | 5.7.0 |
| | RP-22 | RP-030617 | 2079 | | UE Positioning UE based assisted GPS | 5.6.0 | 5.7.0 |
| | RP-22 | RP-030617 | 2085 | | Handling of zero-rate TrCHs in TFCS | 5.6.0 | 5.7.0 |
| | RP-22 | RP-030617 | 2091 | 3 | Measurement control for A-GPS | 5.6.0 | 5.7.0 |
| | RP-22 | RP-030621 | 2093 | | Corrections to 1.28 Mcps TDD power control: ASN1/Tabular consistency, correction of omissions | 5.6.0 | 5.7.0 |
| | RP-22 | RP-030621 | 2095 | | UpPCH power control for 1.28Mcps | 5.6.0 | 5.7.0 |
| | RP-22 | RP-030617 | 2102 | 1 | Interaction between compressed mode pattern activation and message activation time | 5.6.0 | 5.7.0 |
| | RP-22 | RP-030625 | 2103 | | Initialisation of virtual active set | 5.6.0 | 5.7.0 |
| | RP-22 | RP-030611 | 2106 | 1 | Correction to Redirection procedure at RRC Connection Setup | 5.6.0 | 5.7.0 |
| | RP-22 | RP-030610 | 2112 | 2 | SFN associated with GPS timing of cell frame | 5.6.0 | 5.7.0 |
| | RP-22 | RP-030618 | 2115 | | Correction to Handling SIB1 | 5.6.0 | 5.7.0 |

| Change history | | | | | | | |
|---|---|---|---|---|---|---|---|
| Date | TSG # | TSG Doc. | CR | Rev | Subject/Comment | Old | New |
| | RP-22 | RP-030618 | 2118 | | Measurement Handling In State Transition for UE Positioning | 5.6.0 | 5.7.0 |
| | RP-22 | RP-030618 | 2124 | | Corrections to UE positioning reporting for UE assisted and UE based methods | 5.6.0 | 5.7.0 |
| | RP-22 | RP-030662 | 2127 | 1 | SIB 7 reading | 5.6.0 | 5.7.0 |
| | RP-22 | RP-030662 | 2130 | | HFN initialisation in case of pending security configurations | 5.6.0 | 5.7.0 |
| | RP-22 | RP-030621 | 2132 | 1 | General protocol error handling failure for DL CCCH messages due to ASN.1 error | 5.6.0 | 5.7.0 |
| | RP-22 | RP-030621 | 2136 | | Corrections relating to 1.28 Mcps TDD | 5.6.0 | 5.7.0 |
| | RP-22 | RP-030621 | 2138 | | Missing CHOICE RLC Info type in the ASN.1 IE "RB-InformationSetup-r4" | 5.6.0 | 5.7.0 |
| | RP-22 | RP-030625 | 2139 | 1 | RRM in PCH/FACH | 5.6.0 | 5.7.0 |
| | RP-22 | RP-030625 | 2140 | | Correction of operating band reference | 5.6.0 | 5.7.0 |
| | RP-22 | RP-030713 | 2141 | 1 | Re-ordering Queue and HARQ Ids | 5.6.0 | 5.7.0 |
| | RP-22 | RP-030625 | 2142 | | Correction to the procedural description: Reconfiguration of MAC-d flow | 5.6.0 | 5.7.0 |
| | RP-22 | RP-030625 | 2143 | 1 | Enhancement of RRC transaction identifier for measurement control message | 5.6.0 | 5.7.0 |
| | RP-22 | RP-030629 | 2144 | | Inclusion of a default configuration identity for AMR-WB | 5.6.0 | 5.7.0 |
| | RP-22 | RP-030625 | 2145 | | TDD C-RNTI in Cell DCH | 5.6.0 | 5.7.0 |
| | RP-22 | RP-030662 | 2148 | | Additional Measurements List Modify | 5.6.0 | 5.7.0 |
| | RP-22 | RP-030625 | 2149 | | IP activation time for RB0 | 5.6.0 | 5.7.0 |
| | RP-22 | RP-030722 | 2152 | 3 | Minimum UE capability class | 5.6.0 | 5.7.0 |
| | RP-22 | RP-030612 | 2158 | 4 | Measured results on RACH | 5.6.0 | 5.7.0 |
| | RP-22 | RP-030625 | 2159 | | COUNT-I reverting in case Security Mode Control procedure failure | 5.6.0 | 5.7.0 |
| | RP-21 | RP-030548 | 2034 | 1 | Maintaining the RRC Connection while Emergency camped on a F-PLMN during OOS (note: it was decided that this CR would not be implemented until the Rel-6 would be created) | 5.5.0 | 6.0.0 |
| | RP-22 | RP-030630 | 2133 | | Introduction of UMTS800 | 5.7.0 | 6.0.0 |
| | RP-22 | RP-030721 | 2134 | 1 | AS capability indication | 5.7.0 | 6.0.0 |
| | RP-22 | RP-030630 | 2160 | | Introduction of new bands | 5.7.0 | 6.0.0 |
| | | Editorial | | | Repair of corrupted figures | 6.0.0 | 6.0.1 |
| 03/2004 | RP-23 | RP-040095 | 2168 | 2 | Response on SRNS Relocation with Cell Update | 6.0.1 | 6.1.0 |
| | RP-23 | RP-040095 | 2172 | | TPC Combination Index in SRNC relocation | 6.0.1 | 6.1.0 |
| | RP-23 | RP-040107 | 2176 | 1 | Correction to "Current TGPS Status Flag" | 6.0.1 | 6.1.0 |
| | RP-23 | RP-040095 | 2180 | 1 | Invalidation of START value in USIM/UE. | 6.0.1 | 6.1.0 |
| | RP-23 | RP-040095 | 2184 | 1 | Uplink Integrity protection handling in case of N302 increment | 6.0.1 | 6.1.0 |
| | RP-23 | RP-040095 | 2188 | 1 | Amount of reporting for UE-based and UE assisted A-GPS | 6.0.1 | 6.1.0 |
| | RP-23 | RP-040101 | 2191 | 1 | Ensuring decoding possibility related to Introduction of new bands | 6.0.1 | 6.1.0 |
| | RP-23 | RP-040101 | 2197 | 2 | Clarification to multimode indication | 6.0.1 | 6.1.0 |
| | RP-23 | RP-040101 | 2200 | | Correction for 1.28 Mcps TDD Power Control | 6.0.1 | 6.1.0 |
| | RP-23 | RP-040101 | 2203 | | Missing "pdcp-SN-info" in ASN.1 IE "RB-InformationReconfig-r4" | 6.0.1 | 6.1.0 |
| | RP-23 | RP-040107 | 2207 | | Correction to HS-SCCH info | 6.0.1 | 6.1.0 |
| | RP-23 | RP-040107 | 2209 | | Correction to HS-SCCH info | 6.0.1 | 6.1.0 |
| | RP-23 | RP-040107 | 2213 | | Correction to activation time for HS-DSCH reconfiguration in TDD | 6.0.1 | 6.1.0 |
| | RP-23 | RP-040131 | 2217 | 3 | Connected mode handling IE 'CN domain system information' in SIB1 | 6.0.1 | 6.1.0 |
| | RP-23 | RP-040096 | 2221 | | Correction to event 6D | 6.0.1 | 6.1.0 |
| | RP-23 | RP-040096 | 2225 | 1 | Correction to UE positioning reporting for GPS standalone operation mode | 6.0.1 | 6.1.0 |
| | RP-23 | RP-040092 | 2229 | | Frequency band alignment with 25.101 | 6.0.1 | 6.1.0 |
| | RP-23 | RP-040096 | 2235 | | UTRAN setting of the activation time for TM bearers in Ciphering Mode info IE | 6.0.1 | 6.1.0 |
| | RP-23 | RP-040096 | 2239 | | Corrections to "Entered parameter" | 6.0.1 | 6.1.0 |
| | RP-23 | RP-040097 | 2243 | | Corrections to TFC Subset Functionality | 6.0.1 | 6.1.0 |
| | RP-23 | RP-040097 | 2247 | 1 | Waiting for RLC-ACK on UMI | 6.0.1 | 6.1.0 |
| | RP-23 | RP-040105 | 2249 | | Invalid Simultaneous Reconfiguration Criteria | 6.0.1 | 6.1.0 |
| | RP-23 | RP-040101 | 2252 | 1 | General correction and alignment of the ASN.1 and tabular | 6.0.1 | 6.1.0 |
| | RP-23 | RP-040121 | 2253 | 1 | Introduction of UMTS1700/2100 (Band IV) | 6.0.1 | 6.1.0 |
| | RP-23 | RP-040091 | 2254 | | Introduction of UMTS850 (Band V) | 6.0.1 | 6.1.0 |
| | RP-23 | RP-040101 | 2257 | | Introduction of VLEC in every message branch | 6.0.1 | 6.1.0 |
| | RP-23 | RP-040107 | 2259 | | Simultaneous Reception of S-CCPCH and HS-DSCH | 6.0.1 | 6.1.0 |

| Change history | | | | | | | |
|---|---|---|---|---|---|---|---|
| Date | TSG # | TSG Doc. | CR | Rev | Subject/Comment | Old | New |
| | RP-23 | RP-040107 | 2261 | | Cell reselection between UTRAN and GERAN Iu mode | 6.0.1 | 6.1.0 |
| | RP-23 | RP-040108 | 2263 | | HSDPA related corrections on buffer flushing on state transitions, RAT transitions, error cases, MAC-hs reconfiguration and readiness to receive HS-PDSCH | 6.0.1 | 6.1.0 |
| | RP-23 | RP-040106 | 2265 | 2 | Signalling of MAC-hs Reset | 6.0.1 | 6.1.0 |
| | RP-23 | RP-040131 | 2267 | 2 | Modification of Inter-frequency CELL_INFO_LIST | 6.0.1 | 6.1.0 |
| | RP-23 | RP-040131 | 2269 | 1 | [VAS] 1B-1C conflicts when 1A is not configured | 6.0.1 | 6.1.0 |
| | RP-23 | RP-040131 | 2271 | 1 | Handling of wait time in RRC connection reject | 6.0.1 | 6.1.0 |
| | RP-23 | RP-040108 | 2274 | | Misalignments between R'99 and Rel-5 procedures | 6.0.1 | 6.1.0 |
| | RP-23 | RP-040097 | 2281 | | Issues related to Inter-RAT and Inter-frequency handovers | 6.0.1 | 6.1.0 |
| | RP-23 | RP-040097 | 2285 | 1 | Corrections to reconfiguration scenarios and ciphering of TM RBs | 6.0.1 | 6.1.0 |
| | RP-23 | RP-040110 | 2286 | 4 | Addition of "cell selection indication" for cell selection at release of RRC connection and RRC connection reject with re-direction | 6.0.1 | 6.1.0 |
| | RP-23 | RP-040129 | 2288 | | HSDPA capability for multimode FDD-TDD terminals | 6.0.1 | 6.1.0 |
| | RP-23 | RP-040095 | 2168 | 2 | Response on SRNS Relocation with Cell Update | 6.0.1 | 6.1.0 |
| 06/2004 | RP-24 | RP-040203 | 2292 | | Empty non-critical extensions | 6.1.0 | 6.2.0 |
| | RP-24 | RP-040211 | 2294 | 1 | Missing 'v3g0' extension in the UE CAPABILITY INFORMATION | 6.1.0 | 6.2.0 |
| | RP-24 | RP-040203 | 2303 | | Correction on System Information in TDD | 6.1.0 | 6.2.0 |
| | RP-24 | RP-040236 | 2305 | | Corrections to Cell Change Order from UTRAN procedure | 6.1.0 | 6.2.0 |
| | RP-24 | RP-040206 | 2308 | | Correction on SFN-SFN time difference misalignment in 1.28 Mcps TDD | 6.1.0 | 6.2.0 |
| | RP-24 | RP-040207 | 2311 | | ASN.1 correction leftovers | 6.1.0 | 6.2.0 |
| | RP-24 | RP-040210 | 2313 | | Closing the REL-5 extensions in the ASN.1 | 6.1.0 | 6.2.0 |
| | RP-24 | RP-040207 | 2316 | | Incorrect presence of UE-RadioAccessCapability extension in RRC CONNECTION SETUP COMPLETE | 6.1.0 | 6.2.0 |
| | RP-24 | RP-040210 | 2318 | | Unnecessary MAC-d flow identity in the IE 'DL-TrCH-Type-r5' | 6.1.0 | 6.2.0 |
| | RP-24 | RP-040211 | 2320 | 1 | UE capability enquiry for GERAN Iu mode | 6.1.0 | 6.2.0 |
| | RP-24 | RP-040207 | 2323 | | Clean up of SRNS Relocation Info REL-4 version | 6.1.0 | 6.2.0 |
| | RP-24 | RP-040210 | 2325 | | Tabular correction for RADIO BEARER RELEASE message | 6.1.0 | 6.2.0 |
| | RP-24 | RP-040210 | 2327 | | Misalignments betwen R"99 and Rel-5 procedures | 6.1.0 | 6.2.0 |
| | RP-24 | RP-040210 | 2329 | | Erroneous setting of Re-establsish Indicator in case of SRNS relocation | 6.1.0 | 6.2.0 |
| | RP-24 | RP-040207 | 2332 | | Correction to IE 'Cell Info' | 6.1.0 | 6.2.0 |
| | RP-24 | RP-040210 | 2334 | | Correction Concerning UE Positioning Measurement | 6.1.0 | 6.2.0 |
| | RP-24 | RP-040236 | 2336 | | Pending compressed mode reconfigurations | 6.1.0 | 6.2.0 |
| | | RP-040236 | 2338 | | Active compressed mode patterns with same measurement purpose | 6.1.0 | 6.2.0 |
| | RP-24 | RP-040211 | 2340 | | Correction to Information Elements for UE Rx-Tx time difference | 6.1.0 | 6.2.0 |
| | RP-24 | RP-040210 | 2342 | | Naming correction in the HS-DSCH IE Measurement Feedback Information | 6.1.0 | 6.2.0 |
| | RP-24 | RP-040206 | 2345 | | Clarification about open loop power control in 1.28Mcps TDD | 6.1.0 | 6.2.0 |
| | RP-24 | RP-040206 | 2348 | | Clarification about measurement control system information in TDD mode | 6.1.0 | 6.2.0 |
| | RP-24 | RP-040211 | 2350 | | Correction to timing-maintained hard handover regarding the UL transmission timing | 6.1.0 | 6.2.0 |
| | RP-24 | RP-040236 | 2354 | 2 | Selection of suitable cell | 6.1.0 | 6.2.0 |
| | RP-24 | RP-040236 | 2356 | | Check of the PLMN identity in the MIB when selecting a new cell | 6.1.0 | 6.2.0 |
| | RP-24 | RP-040211 | 2358 | | Compressed INTER RAT HANDOVER INFO message modifications/corrections | 6.1.0 | 6.2.0 |
| | RP-24 | RP-040215 | 2359 | | The ASN.1 definition of IE 'SysInfoType5bis' | 6.1.0 | 6.2.0 |
| | RP-24 | RP-040224 | 2361 | | RLC size handling and RLC re-establishment | 6.1.0 | 6.2.0 |
| | RP-24 | RP-040212 | 2363 | | Restrict operation of the virtual active set | 6.1.0 | 6.2.0 |
| | RP-24 | RP-040213 | 2365 | | Usage of different RB mapping info | 6.1.0 | 6.2.0 |
| | RP-24 | RP-040256 | 2367 | 1 | Clarification on UE procedure in case of HHO failure | 6.1.0 | 6.2.0 |
| 09/2004 | RP-25 | RP-040327 | 2373 | | TDD misalignment between tabular and ASN.1 definitions of UL Transport channel information common for all transport channels and special burst scheduling | 6.2.0 | 6.3.0 |
| | RP-25 | RP-040327 | 2377 | | Definition of parameters for UE-assisted A-GPS | 6.2.0 | 6.3.0 |
| | RP-25 | RP-040339 | 2378 | 2 | Addition of UMTS850 (Band V) in the tabular | 6.2.0 | 6.3.0 |
| | RP-25 | RP-040360 | 2381 | | Default Configurations for multiple AMR Rate Configurations | 6.2.0 | 6.3.0 |
| | RP-25 | RP-040319 | 2384 | | Correction on PRACH selection in 1.28Mcps TDD | 6.2.0 | 6.3.0 |

| Change history | | | | | | | |
|---|---|---|---|---|---|---|---|
| Date | TSG # | TSG Doc. | CR | Rev | Subject/Comment | Old | New |
| | RP-25 | RP-040334 | 2386 | | Inconsistency in UE action for HFN initialisation | 6.2.0 | 6.3.0 |
| | RP-25 | RP-040334 | 2388 | | Usage of different RB mapping info for TDD | 6.2.0 | 6.3.0 |
| | RP-25 | RP-040334 | 2390 | | TDD HS-DSCH Corrections | 6.2.0 | 6.3.0 |
| | RP-25 | RP-040334 | 2392 | | Alignment of Tabular Definition with ASN.1 for HS-SCCH Info | 6.2.0 | 6.3.0 |
| | RP-25 | RP-040348 | 2394 | 1 | Correction to HS-DSCH reception conditions | 6.2.0 | 6.3.0 |
| | RP-25 | RP-040334 | 2396 | | Correction to RB mapping check | 6.2.0 | 6.3.0 |
| | RP-25 | RP-040334 | 2398 | | Position Timestamp for A-GPS | 6.2.0 | 6.3.0 |
| | RP-25 | RP-040334 | 2400 | | Pending compressed mode reconfigurations | 6.2.0 | 6.3.0 |
| | RP-25 | RP-040335 | 2402 | | Predefined configurations for the RRC connection request | 6.2.0 | 6.3.0 |
| | RP-25 | RP-040335 | 2404 | | Cell update during reconfiguration from CELL_FACH to CELL_PCH | 6.2.0 | 6.3.0 |
| | RP-25 | RP-040335 | 2406 | | UE actions for Delta_ACK/NACK and repetition factor | 6.2.0 | 6.3.0 |
| | RP-25 | RP-040335 | 2408 | | Calculation of UL transmit power for HS-SICH (TDD) | 6.2.0 | 6.3.0 |
| | RP-25 | RP-040335 | 2410 | | Handling of Timer T302 Expiry | 6.2.0 | 6.3.0 |
| | RP-25 | RP-040335 | 2412 | | Correct naming for HS-DSCH with DCH multiplexing option | 6.2.0 | 6.3.0 |
| | RP-25 | RP-040335 | 2414 | | Compressed Pre-defined configurations description in new Annex C | 6.2.0 | 6.3.0 |
| | RP-25 | RP-040335 | 2416 | | Integration between integrity protection and the sending of downlink messages during SRNS relocation | 6.2.0 | 6.3.0 |
| | RP-25 | RP-040328 | 2418 | | Corrections to restrictions of operation of the virtual active set | 6.2.0 | 6.3.0 |
| | RP-25 | RP-040336 | 2420 | | UE actions for received new keys | 6.2.0 | 6.3.0 |
| | RP-25 | RP-040336 | 2422 | 1 | Scrambling Code Change | 6.2.0 | 6.3.0 |
| | RP-25 | RP-040328 | 2428 | | Clarifications to VAS functionality | 6.2.0 | 6.3.0 |
| | RP-25 | RP-040336 | 2430 | | UE security capability in INTER_RAT handover | 6.2.0 | 6.3.0 |
| | RP-25 | RP-040336 | 2432 | | Correction to the Radio Link Failure behaviour | 6.2.0 | 6.3.0 |
| 12/2004 | RP-26 | RP-040481 | 2434 | | Correction to measured results on RACH | 6.3.0 | 6.4.0 |
| | RP-26 | RP-040481 | 2436 | | T305 handling upon a state transition | 6.3.0 | 6.4.0 |
| | RP-26 | RP-040481 | 2438 | | Handling of pending AM RLC unrecoverable errors signalled by cell update | 6.3.0 | 6.4.0 |
| | RP-26 | RP-040476 | 2442 | | Correction to maximum length of CTCH period | 6.3.0 | 6.4.0 |
| | RP-26 | RP-040481 | 2444 | | TPC step size in default configurations | 6.3.0 | 6.4.0 |
| | RP-26 | RP-040474 | 2448 | | References to ITU-T Recommendations on ASN.1 | 6.3.0 | 6.4.0 |
| | RP-26 | RP-040477 | 2451 | | ASN.1 clarification on Measurement Report for 1.28 Mcps TDD | 6.3.0 | 6.4.0 |
| | RP-26 | RP-040481 | 2453 | | Correction to HS-DSCH reception conditions | 6.3.0 | 6.4.0 |
| | RP-26 | RP-040481 | 2455 | 1 | MAC-hs Reset procedure | 6.3.0 | 6.4.0 |
| | RP-26 | RP-040526 | 2457 | 2 | Cell selection and reselection parameters | 6.3.0 | 6.4.0 |
| | RP-26 | RP-040482 | 2459 | 1 | Clarification the PDCP capability- Max HC context space | 6.3.0 | 6.4.0 |
| | RP-26 | RP-040482 | 2461 | | Corrections to IE 'WAIT TIME' = 0 | 6.3.0 | 6.4.0 |
| | RP-26 | RP-040482 | 2463 | 1 | RRC transaction identifier in the MEASUREMENT CONTROL message | 6.3.0 | 6.4.0 |
| | RP-26 | RP-040482 | 2465 | | Correction to intra-frequency measurement handling in SIB11 | 6.3.0 | 6.4.0 |
| | RP-26 | RP-040477 | 2468 | 1 | Missing OTDOA TDD related v4b0 extension in MEASUREMENT CONTROL | 6.3.0 | 6.4.0 |
| | RP-26 | RP-040482 | 2470 | 2 | Clarification of Radio Bearer Downlink Ciphering Activation Time Info | 6.3.0 | 6.4.0 |
| | RP-26 | RP-040520 | 2472 | 2 | TFC Subset Variable Usage and Application of Transport Format Combination Subset | 6.3.0 | 6.4.0 |
| | RP-26 | RP-040505 | 2474 | | Use of preconfiguration in the RADIO BEARER RECONFIGURATION message | 6.3.0 | 6.4.0 |
| | RP-26 | RP-040505 | 2476 | | UTRAN setting of ciphering activation time for SRB2 | 6.3.0 | 6.4.0 |
| | RP-26 | RP-040505 | 2478 | | Correction to ASN1 IE 'srb-SpecificIntegrityProtInfo' | 6.3.0 | 6.4.0 |
| | RP-26 | RP-040522 | 2480 | 2 | Criteria for initiating cell update on receiving 'Frequency info' IE in CELL UPDATE CONFIRM message | 6.3.0 | 6.4.0 |
| | RP-26 | RP-040505 | 2482 | | Traffic volume measurements in PCH states | 6.3.0 | 6.4.0 |
| | RP-26 | RP-040505 | 2484 | | Failure cause indication on Cell Update | 6.3.0 | 6.4.0 |
| | RP-26 | RP-040495 | 2487 | 1 | Network Sharing and multiple PLMN identities | 6.3.0 | 6.4.0 |
| | RP-26 | RP-040505 | 2493 | | Inter-RAT measurement control information used | 6.3.0 | 6.4.0 |
| | RP-26 | RP-040491 | 2494 | | ASN.1 update for the introduction of MBMS | 6.3.0 | 6.4.0 |
| | RP-26 | RP-040491 | 2495 | 1 | Introduction of MBMS | 6.3.0 | 6.4.0 |
| | RP-26 | RP-040543 | 2496 | 2 | Preamble and Postamble to reduce HS-DPCCH transmit power | 6.3.0 | 6.4.0 |

| Change history | | | | | | | |
|---|---|---|---|---|---|---|---|
| Date | TSG # | TSG Doc. | CR | Rev | Subject/Comment | Old | New |
| | RP-26 | RP-040507 | 2497 | | Introduction of E-DCH | 6.3.0 | 6.4.0 |
| 03/2005 | RP-27 | RP-050038 | 2491 | 2 | Removal of TGPL2 | 6.4.0 | 6.5.0 |
| | RP-27 | RP-050069 | 2499 | | Minor HSDPA related corrections | 6.4.0 | 6.5.0 |
| | RP-27 | RP-050169 | 2501 | | Integrity protection related information in the SRNS relocation info | 6.4.0 | 6.5.0 |
| | RP-27 | RP-050069 | 2503 | | Number of timeslots that can be used for HS-PDSCH resource for 3.84 Mcps TDD | 6.4.0 | 6.5.0 |
| | RP-27 | RP-050089 | 2504 | | HS-DSCH operation without a DL DPCH for 3.84 Mcps TDD | 6.4.0 | 6.5.0 |
| | RP-27 | RP-050114 | 2506 | | Removal of unnecessary cell updates on receiving 'Frequency info' IE in CELL UPDATE CONFIRM message | 6.4.0 | 6.5.0 |
| | RP-27 | RP-050069 | 2508 | | ASN.1 clarification on Cell and Channel Identity info for 1.28 Mcps TDD | 6.4.0 | 6.5.0 |
| | RP-27 | RP-050070 | 2510 | | Handling of TM SRB"s at radio link failure | 6.4.0 | 6.5.0 |
| | RP-27 | RP-050070 | 2513 | | Removal of the UARFCN uplink (Nu) in the informative Annex A.3 | 6.4.0 | 6.5.0 |
| | RP-27 | RP-050070 | 2515 | 1 | Correction on PRACH selection | 6.4.0 | 6.5.0 |
| | RP-27 | RP-050067 | 2517 | 3 | Lossless DL RLC PDU size change | 6.4.0 | 6.5.0 |
| | RP-27 | RP-050069 | 2519 | | Clarification of GERAN (P)SI message coding in NACC | 6.4.0 | 6.5.0 |
| | RP-27 | RP-050070 | 2521 | | Unsupported RLC mode reconfigurations | 6.4.0 | 6.5.0 |
| | RP-27 | RP-050070 | 2523 | | Correction to Inter RAT cell info indication | 6.4.0 | 6.5.0 |
| | RP-27 | RP-050086 | 2524 | | Correction to network sharing functionality | 6.4.0 | 6.5.0 |
| | RP-27 | RP-050086 | 2525 | | Network sharing corrections | 6.4.0 | 6.5.0 |
| | RP-27 | RP-050110 | 2526 | 1 | CN domain specific Access Class Barring | 6.4.0 | 6.5.0 |
| | RP-27 | RP-050081 | 2527 | | Corrections to "selected PLMN" in access stratum | 6.4.0 | 6.5.0 |
| | RP-27 | RP-050074 | 2528 | | Introduction of F-DPCH | 6.4.0 | 6.5.0 |
| | RP-27 | RP-050084 | 2529 | | Minor E-DCH related corrections | 6.4.0 | 6.5.0 |
| | RP-27 | RP-050079 | 2530 | 2 | Miscellaneous MBMS corrections | 6.4.0 | 6.5.0 |
| | RP-27 | RP-050087 | 2532 | | Additional Frequency Bands | 6.4.0 | 6.5.0 |
| | RP-27 | RP-050084 | 2534 | | Introduction of E-DCH in the ASN.1 | 6.4.0 | 6.5.0 |
| | RP-27 | RP-050097 | 2535 | | Improvements to uplink closed loop power control for 1.28 Mcps TDD | 6.4.0 | 6.5.0 |
| | RP-27 | RP-050079 | 2536 | 1 | MBMS Corrections to 25.331 ASN.1 | 6.4.0 | 6.5.0 |
| | RP-27 | RP-050128 | 2538 | 1 | Correction to cell selection and reselection parameters to enable enhanced cell reselection | 6.4.0 | 6.5.0 |
| 06/2005 | RP-28 | RP-050253 | 2539 | 3 | Faster L1 DCH synchronization | 6.5.0 | 6.6.0 |
| | RP-28 | RP-050339 | 2540 | 3 | Timing maintained hard handover | 6.5.0 | 6.6.0 |
| | RP-28 | RP-050320 | 2541 | 1 | Removal of unnecessary Start values | 6.5.0 | 6.6.0 |
| | RP-28 | RP-050329 | 2542 | | Merged CR alignement w.r.t. network sharing functionality | 6.5.0 | 6.6.0 |
| | RP-28 | RP-050302 | 2545 | | Timing Reinitialized Handover & Radio Link Timing Adjustmen | 6.5.0 | 6.6.0 |
| | RP-28 | RP-050302 | 2547 | | Addition of omitted IE 'report criteria' in MEASUREMENT CONTROL message 'modify' command | 6.5.0 | 6.6.0 |
| | RP-28 | RP-050316 | 2548 | 2 | Miscellaneous MBMS corrections (set II) | 6.5.0 | 6.6.0 |
| | RP-28 | RP-050316 | 2549 | 1 | Correction to MBMS notification procedure | 6.5.0 | 6.6.0 |
| | RP-28 | RP-050316 | 2550 | 1 | FACH Measurement Occasion when UE receives MBMS | 6.5.0 | 6.6.0 |
| | RP-28 | RP-050316 | 2551 | | Frequency layer dispersion | 6.5.0 | 6.6.0 |
| | RP-28 | RP-050303 | 2553 | 2 | Signalling of target mode for ROHC operation | 6.5.0 | 6.6.0 |
| | RP-28 | RP-050320 | 2554 | 2 | Introduction of inter-frequency RACH measurement reporting | 6.5.0 | 6.6.0 |
| | RP-28 | RP-050324 | 2555 | | Closed-Loop Power Control Improvements for 1.28 Mcps TDD – ASN1 Corrections | 6.5.0 | 6.6.0 |
| | RP-28 | RP-050322 | 2556 | | Release 6 HS-DSCH operation without a DL DPCH for 3.84 Mcps TDD – Setting of Dhs-sync | 6.5.0 | 6.6.0 |
| | RP-28 | RP-050320 | 2557 | 1 | Correction to the Amount of Reporting | 6.5.0 | 6.6.0 |
| | RP-28 | RP-050320 | 2558 | | Measurement report message definition when Inter-RAT cell info indication is used | 6.5.0 | 6.6.0 |
| | RP-28 | RP-050320 | 2559 | | Direct transition to DCH | 6.5.0 | 6.6.0 |
| | RP-28 | RP-050316 | 2560 | 1 | Addition of the number of MBMS Neighbour Cell PTM Information messages to the MBMS Modified Services Information message | 6.5.0 | 6.6.0 |
| | RP-28 | RP-050316 | 2561 | 1 | Addition of MBMS counting for UEs in Cell_PCH and Cell_FACH states and addition of UE requested p-t-p bearer establishmen | 6.5.0 | 6.6.0 |
| | RP-28 | RP-050320 | 2562 | | Introduction of IE 'RB information to reconfigure' in RB SETUP, RB RELEASE messages | 6.5.0 | 6.6.0 |
| | RP-28 | RP-050320 | 2564 | | Including HS-DSCH serving cell change in ASU | 6.5.0 | 6.6.0 |
| | RP-28 | RP-050320 | 2566 | 1 | Detection of Activation CFN wraparound in the UE during HS- | 6.5.0 | 6.6.0 |

| Change history | | | | | | | |
|---|---|---|---|---|---|---|---|
| Date | TSG # | TSG Doc. | CR | Rev | Subject/Comment | Old | New |
| | | | | | DSCH cell change | | |
| | RP-28 | RP-050304 | 2568 | | Correction to handling of keys at inter-RAT handove | 6.5.0 | 6.6.0 |
| | RP-28 | RP-050302 | 2572 | | CTFC calculation for DCH | 6.5.0 | 6.6.0 |
| | RP-28 | RP-050302 | 2574 | | Default RB identity in IE 'Signalling RB information to setup | 6.5.0 | 6.6.0 |
| | RP-28 | RP-050302 | 2576 | | Default configuration 13 | 6.5.0 | 6.6.0 |
| | RP-28 | RP-050320 | 2577 | | UE L3 requirements for HS-DSCH mobility | 6.5.0 | 6.6.0 |
| | RP-28 | RP-050374 | 2579 | 3 | Support for out-of-sequence PDUs in RLC-UM | 6.5.0 | 6.6.0 |
| | RP-28 | RP-050305 | 2581 | | Feature Clean Up: Removal of 80 ms TTI for DCH for all other cases but when the UE supports SF512 | 6.5.0 | 6.6.0 |
| | RP-28 | RP-050306 | 2583 | | Feature Clean Up: Removal of observed time difference to GSM cell | 6.5.0 | 6.6.0 |
| | RP-28 | RP-050307 | 2585 | | Feature Clean Up: Removal of SSDT | 6.5.0 | 6.6.0 |
| | RP-28 | RP-050308 | 2586 | | Feature Clean-up: Removal of DSCH (FDD) | 6.5.0 | 6.6.0 |
| | RP-28 | RP-050309 | 2589 | | Feature Clean Up: Removal of CPCH | 6.5.0 | 6.6.0 |
| | RP-28 | RP-050310 | 2591 | | Feature Clean Up: Removal of dedicated pilot as sole phase reference | 6.5.0 | 6.6.0 |
| | RP-28 | RP-050311 | 2593 | | Feature Clean Up: Removal of DRAC | 6.5.0 | 6.6.0 |
| | RP-28 | RP-050312 | 2595 | | Feature Clean Up: Removal of TX diversity closed loop mode 2 | 6.5.0 | 6.6.0 |
| | RP-28 | RP-050313 | 2597 | | Feature Clean Up: Removal of Compressed mode by puncturing | 6.5.0 | 6.6.0 |
| | RP-28 | RP-050327 | 2598 | 2 | Alignment of EUDCH RRC Stage-3 to Stage-2 status, including handling of 2 E-RNTIs | 6.5.0 | 6.6.0 |
| | RP-28 | RP-050336 | 2599 | | Radio link failure in F-DPCH | 6.5.0 | 6.6.0 |
| | RP-28 | RP-050323 | 2600 | 1 | Setting up F-DPCH and E-DCH in RRC connection setup | 6.5.0 | 6.6.0 |
| | RP-28 | RP-050316 | 2601 | 1 | Validity of PtM configurations | 6.5.0 | 6.6.0 |
| | RP-28 | RP-050392 | 2602 | 1 | CCCH message enhancements | 6.5.0 | 6.6.0 |
| | RP-28 | RP-050320 | 2604 | | Quality measurement corrections | 6.5.0 | 6.6.0 |
| | RP-28 | RP-050328 | 2605 | | Clean-up of R6 ASN.1 leftovers | 6.5.0 | 6.6.0 |
| | RP-28 | RP-050346 | 2607 | 2 | UE behaviour for DCH SIR target setting for Downlink power control | 6.5.0 | 6.6.0 |
| | RP-28 | RP-050317 | 2608 | | RLC LI Optimization for VoiP | 6.5.0 | 6.6.0 |
| | RP-28 | RP-050316 | 2609 | 2 | Introduction of an S-CCPCH power offset difference in order to improve cell selection for soft and selective combining | 6.5.0 | 6.6.0 |
| | RP-28 | RP-050320 | 2610 | | Erroneous implementation of CR#2501 in RRC specification v6.5.0. | 6.5.0 | 6.6.0 |
| | RP-28 | RP-050329 | 2611 | | Correction to network sharing | 6.5.0 | 6.6.0 |
| | RP-28 | RP-050316 | 2613 | | MBMS asn1 issues | 6.5.0 | 6.6.0 |
| | RP-28 | RP-050316 | 2614 | | SCCPCH timing offset information for FDD MBMS soft combining | 6.5.0 | 6.6.0 |
| | RP-28 | RP-050316 | 2615 | | MBMS corrections on signalling optimization | 6.5.0 | 6.6.0 |
| 09/2005 | RP-29 | RP-050486 | 2616 | | Support of Domain Specific Access control in Rel-5 Ues | 6.6.0 | 6.7.0 |
| | RP-29 | RP-050465 | 2619 | | ASN1 update for InterRATReportingQuantity | 6.6.0 | 6.7.0 |
| | RP-29 | RP-050465 | 2621 | 1 | IE 'RB information to reconfigure' for RADIO BEARER RECONFIGURATION message | 6.6.0 | 6.7.0 |
| | RP-29 | RP-050465 | 2623 | | Size of TFC Subset List for Transport Format Combination Control | 6.6.0 | 6.7.0 |
| | RP-29 | RP-050465 | 2626 | | RB mapping rules | 6.6.0 | 6.7.0 |
| | RP-29 | RP-050587 | 2628 | 3 | Rules for triggering hard handover | 6.6.0 | 6.7.0 |
| | RP-29 | RP-050465 | 2630 | | RSCP value range extension | 6.6.0 | 6.7.0 |
| | RP-29 | RP-050465 | 2632 | | H-RNTI validity | 6.6.0 | 6.7.0 |
| | RP-29 | RP-050482 | 2633 | | Removal RLC-SDU alignment capability | 6.6.0 | 6.7.0 |
| | RP-29 | RP-050458 | 2635 | | Feature Clean Up: Removal of DRAC | 6.6.0 | 6.7.0 |
| | RP-29 | RP-050458 | 2637 | | DRAC & Dedicated pilots removal leftovers (asn1) | 6.6.0 | 6.7.0 |
| | RP-29 | RP-050458 | 2639 | | DRAC & CPCH removal leftovers (sib8,9,10) | 6.6.0 | 6.7.0 |
| | RP-29 | RP-050458 | 2641 | 1 | Feature remove (Tabular/asn1 alignment) | 6.6.0 | 6.7.0 |
| | RP-29 | RP-050482 | 2642 | | Correction to UE L3 requirements for HS-DSCH mobility | 6.6.0 | 6.7.0 |
| | RP-29 | RP-050482 | 2643 | | Rate Control Correction | 6.6.0 | 6.7.0 |
| | RP-29 | RP-050482 | 2644 | | Introduction of container to facilitate transparent transfer of UE capabilities | 6.6.0 | 6.7.0 |
| | RP-29 | RP-050482 | 2645 | | Minor ASN.1 correction for TDD IEs Beacon PL Est and DHS-Sync | 6.6.0 | 6.7.0 |
| | RP-29 | RP-050482 | 2646 | | Addition of ongoing reconfiguration indicator in cell update | 6.6.0 | 6.7.0 |
| | RP-29 | RP-050482 | 2648 | | Faster L1 DCH synchronization | 6.6.0 | 6.7.0 |
| | RP-29 | RP-050482 | 2649 | | Direct transition to DCH | 6.6.0 | 6.7.0 |

| Change history | | | | | | | |
|---|---|---|---|---|---|---|---|
| Date | TSG # | TSG Doc. | CR | Rev | Subject/Comment | Old | New |
| | RP-29 | RP-050482 | 2650 | | PSI messages in CELL CHANGE ORDER FROM UTRAN | 6.6.0 | 6.7.0 |
| | RP-29 | RP-050482 | 2651 | | SRNS relocation info | 6.6.0 | 6.7.0 |
| | RP-29 | RP-050482 | 2652 | | Correction to UE-assisted OTDOA support | 6.6.0 | 6.7.0 |
| | RP-29 | RP-050482 | 2653 | | Correction to undefined UE behaviour in case of Cell-ID positioning with method type UE-based | 6.6.0 | 6.7.0 |
| | RP-29 | RP-050482 | 2654 | | Receiving "Frequency info" IE in CELL UPDATE CONFIRM message | 6.6.0 | 6.7.0 |
| | RP-29 | RP-050483 | 2655 | | Re-entry in service in CELL_PCH before T316 expiry | 6.6.0 | 6.7.0 |
| | RP-29 | RP-050483 | 2656 | | ASN.1 alignment to Rel-5 of InterRATCellInfoIndication | 6.6.0 | 6.7.0 |
| | RP-29 | RP-050483 | 2657 | | Addition of Inter-frequency measurements reporting on RACH reporting in the ASN.1 of RRC CONNECTION REQUEST and CELL UPDATE messages | 6.6.0 | 6.7.0 |
| | RP-29 | RP-050483 | 2658 | | Correction to the Amount of Reporting | 6.6.0 | 6.7.0 |
| | RP-29 | RP-050483 | 2659 | | Minor correction of HS-DSCH/ E-DCH capability indication | 6.6.0 | 6.7.0 |
| | RP-29 | RP-050476 | 2660 | | Modification of TPC command error rate granularity and range | 6.6.0 | 6.7.0 |
| | RP-29 | RP-050473 | 2661 | 1 | Introduction of PS handover between UTRAN and GERAN | 6.6.0 | 6.7.0 |
| | RP-29 | RP-050483 | 2662 | | Including HS-DPCCH power offset and HARQ preamble mode in active set update | 6.6.0 | 6.7.0 |
| | RP-29 | RP-050468 | 2663 | | Minor MBMS corrections (set IV) | 6.6.0 | 6.7.0 |
| | RP-29 | RP-050468 | 2664 | | Clarification on MBMS modified services information IE | 6.6.0 | 6.7.0 |
| | RP-29 | RP-050468 | 2665 | | MBMS correction for recounting | 6.6.0 | 6.7.0 |
| | RP-29 | RP-050468 | 2666 | 1 | MBMS asn1 issues | 6.6.0 | 6.7.0 |
| | RP-29 | RP-050471 | 2667 | | E-DCH corrections and additions | 6.6.0 | 6.7.0 |
| | RP-29 | RP-050471 | 2668 | | E-DCH corrections | 6.6.0 | 6.7.0 |
| | RP-29 | RP-050472 | 2669 | 4 | E-DCH additions to active set update | 6.6.0 | 6.7.0 |
| | RP-29 | RP-050471 | 2670 | 1 | UE capabilities for E-DCH in 25.331 | 6.6.0 | 6.7.0 |
| | RP-29 | RP-050468 | 2671 | | Conditional suspension of CELL_FACH measurements to enable reception of MCCH | 6.6.0 | 6.7.0 |
| | RP-29 | RP-050468 | 2672 | | MBMS message order on MCCH | 6.6.0 | 6.7.0 |
| | RP-29 | RP-050468 | 2673 | | MSCH configuration information in case of soft combining Timing Offset | 6.6.0 | 6.7.0 |
| | RP-29 | RP-050469 | 2674 | 1 | Removal of fixed position for S-CCPCHs carrying MBMS channels | 6.6.0 | 6.7.0 |
| | RP-29 | RP-050467 | 2675 | | Introduction of Band VII | 6.6.0 | 6.7.0 |
| | RP-29 | RP-050483 | 2676 | | Introducing pre- configuration upon radio bearer establishment | 6.6.0 | 6.7.0 |
| | RP-29 | RP-050484 | 2677 | 1 | Introduction of the device type indication in UE capability | 6.6.0 | 6.7.0 |
| | RP-29 | RP-050471 | 2680 | | E-DCH TTI Reconfiguration | 6.6.0 | 6.7.0 |
| | RP-29 | RP-050483 | 2681 | | Maximum number of reference ETFCI"s | 6.6.0 | 6.7.0 |
| | RP-29 | RP-050561 | 2682 | | F-DPCH power control | 6.6.0 | 6.7.0 |
| 12/2005 | RP-30 | RP-050801 | 2617 | 2 | Introduction of UMTS1700 | 6.7.0 | 6.8.0 |
| | RP-30 | RP-050787 | 2683 | 4 | Introduction of the HSDPA and E-DCH Capable Cell Indicator | 6.7.0 | 6.8.0 |
| | RP-30 | RP-050785 | 2685 | 1 | PRACH for CCCH in SIB 6 | 6.7.0 | 6.8.0 |
| | RP-30 | RP-050796 | 2686 | 1 | Tx/Rx frequency separation capability (FDD) | 6.7.0 | 6.8.0 |
| | RP-30 | RP-050827 | 2687 | 1 | E-DCH mobility corrections and multi-step handling for E-RGCH | 6.7.0 | 6.8.0 |
| | RP-30 | RP-050797 | 2688 | 1 | L1 synchronisation at HHO | 6.7.0 | 6.8.0 |
| | RP-30 | RP-050786 | 2690 | | Correction to UE positioning measurements in CELL_PCH/URA_PCH state | 6.7.0 | 6.8.0 |
| | RP-30 | RP-050785 | 2692 | | Clarification of Delta in Inter/Intra-frequency measurement reporting criteria | 6.7.0 | 6.8.0 |
| | RP-30 | RP-050785 | 2694 | | Clarification of the usage of "Ack-Nack Power Offset" in HSDPA for TDD | 6.7.0 | 6.8.0 |
| | RP-30 | RP-050785 | 2696 | | Modification of WB-AMR default configuration | 6.7.0 | 6.8.0 |
| | RP-30 | RP-050785 | 2698 | | Serving E-DCH radio link indication | 6.7.0 | 6.8.0 |
| | RP-30 | RP-050800 | 2699 | | Introduction of UMTS 900 (Band VIII) | 6.7.0 | 6.8.0 |
| | RP-30 | RP-050788 | 2700 | | MCCH configuration information | 6.7.0 | 6.8.0 |
| | RP-30 | RP-050788 | 2701 | | Correction of default TFCS for MBMS | 6.7.0 | 6.8.0 |
| | RP-30 | RP-050797 | 2702 | | Unidirectional RLC reconfiguration | 6.7.0 | 6.8.0 |
| | RP-30 | RP-050793 | 2703 | 1 | Misalignments for E-DCH | 6.7.0 | 6.8.0 |
| | RP-30 | RP-050793 | 2704 | | Update for E-DCH Serving Grant IE value range | 6.7.0 | 6.8.0 |
| | RP-30 | RP-050793 | 2705 | | Clarification on MAC-d flow multiplexing list | 6.7.0 | 6.8.0 |
| | RP-30 | RP-050793 | 2706 | | Addition of E-DCH power offsets to active set update | 6.7.0 | 6.8.0 |

| Change history | | | | | | | |
|---|---|---|---|---|---|---|---|
| Date | TSG # | TSG Doc. | CR | Rev | Subject/Comment | Old | New |
| | RP-30 | RP-050793 | 2707 | | E-RNTI validity | 6.7.0 | 6.8.0 |
| | RP-30 | RP-050793 | 2708 | | Clarification of bit strings for EUL | 6.7.0 | 6.8.0 |
| | RP-30 | RP-050793 | 2709 | 1 | Modification of SI periodicity | 6.7.0 | 6.8.0 |
| | RP-30 | RP-050793 | 2710 | | E-DCH PO signalling | 6.7.0 | 6.8.0 |
| | RP-30 | RP-050793 | 2711 | 1 | MAC es/e reset indicator | 6.7.0 | 6.8.0 |
| | RP-30 | RP-050788 | 2714 | 1 | MBMS corrections on default TFCS, service identity and PL Service Information | 6.7.0 | 6.8.0 |
| | RP-30 | RP-050831 | 2717 | 1 | Corrections of inconsistencies in Rel-6 RRC messages (ASN.1 review) | 6.7.0 | 6.8.0 |
| | RP-30 | RP-050861 | 2718 | 1 | Introduction of Support of Handover to GAN | 6.7.0 | 6.8.0 |
| 03/2006 | RP-31 | RP-060087 | 2716 | 5 | E-DCH Measurement Event 1J | 6.8.0 | 6.9.0 |
| | RP-31 | RP-060083 | 2720 | - | Default configuration 11 for multirate AMR with SRB5 | 6.8.0 | 6.9.0 |
| | RP-31 | RP-060081 | 2722 | 1 | Addition of synchronization parameters in RRC for HS-SICH in 1.28Mcps TDD | 6.8.0 | 6.9.0 |
| | RP-31 | RP-060091 | 2723 | - | Integrity Protection check for NAS messages | 6.8.0 | 6.9.0 |
| | RP-31 | RP-060087 | 2724 | - | E-DCH radio link addition using ASU of RL already in DCH active set | 6.8.0 | 6.9.0 |
| | RP-31 | RP-060087 | 2725 | - | Addition of SF128 and SF256 in E-DCH maximum channelisation codes | 6.8.0 | 6.9.0 |
| | RP-31 | RP-060087 | 2726 | 2 | RRC signaling efficiency changes for E-DCH | 6.8.0 | 6.9.0 |
| | RP-31 | RP-060087 | 2727 | - | E-DCH HARQ Info signalling | 6.8.0 | 6.9.0 |
| | RP-31 | RP-060087 | 2728 | - | Secondary Scrambling Code in F-DPCH RL information | 6.8.0 | 6.9.0 |
| | RP-31 | RP-060087 | 2729 | - | Correction to E-DCH IEs | 6.8.0 | 6.9.0 |
| | RP-31 | RP-060087 | 2730 | - | Non-scheduled grant | 6.8.0 | 6.9.0 |
| | RP-31 | RP-060087 | 2731 | - | IE handling for E-DCH | 6.8.0 | 6.9.0 |
| | RP-31 | RP-060087 | 2732 | - | E-RNTI handling in Active Set Update procedure | 6.8.0 | 6.9.0 |
| | RP-31 | RP-060087 | 2733 | - | Editorial correction on 'E-DCH information' | 6.8.0 | 6.9.0 |
| | RP-31 | RP-060120 | 2734 | 1 | Corrections of inconsistencies in Rel-6 RRC messages (ASN.1 review) | 6.8.0 | 6.9.0 |
| | RP-31 | RP-060091 | 2735 | - | Correction to Modifying Integrity Protection Configuration for TM SRB | 6.8.0 | 6.9.0 |
| | RP-31 | RP-060091 | 2736 | - | Correction to Security Mode Control Procedure | 6.8.0 | 6.9.0 |
| | RP-31 | RP-060091 | 2737 | - | Resolving problems from CR implementation | 6.8.0 | 6.9.0 |
| | RP-31 | RP-060093 | 2738 | - | Removal of GPRS encryption algorithm info | 6.8.0 | 6.9.0 |
| | RP-31 | RP-060092 | 2739 | 1 | Default configurations for Multi-mode AMR | 6.8.0 | 6.9.0 |
| | RP-31 | RP-060091 | 2740 | - | Periodic URA Update in OOS | 6.8.0 | 6.9.0 |
| | RP-31 | RP-060091 | 2741 | - | Correction in IE UE positioning capability | 6.8.0 | 6.9.0 |
| | RP-31 | RP-060091 | 2742 | - | F-DPCH, HSDPA and E-DCH in HANDOVER TO UTRAN COMMAND (Rel-6 ASN.1 review issue 013) | 6.8.0 | 6.9.0 |
| | RP-31 | RP-060091 | 2743 | - | Representation of IE "latestConfiguredCN-Domain" in the r3 branch of SRNS Relocation Info | 6.8.0 | 6.9.0 |
| | RP-31 | RP-060083 | 2746 | 1 | 7.95kbps NB AMR Default Configuration removal | 6.8.0 | 6.9.0 |
| | RP-31 | RP-060091 | 2747 | - | Periodic BMC Schedule Message | 6.8.0 | 6.9.0 |
| | RP-31 | RP-060092 | 2748 | 1 | Introduction of additional Default configuration identities | 6.8.0 | 6.9.0 |
| | RP-31 | RP-060095 | 2749 | 1 | PS default configurations | 6.8.0 | 6.9.0 |
| | RP-31 | RP-060091 | 2751 | - | Configuration of DL TFCS as 'Same as UL' | 6.8.0 | 6.9.0 |
| | RP-31 | RP-060091 | 2752 | - | NAS synchronization indicator in RB setup | 6.8.0 | 6.9.0 |
| | RP-31 | RP-060088 | 2753 | - | General error handling in case of ASN.1 violation and for MBMS channels | 6.8.0 | 6.9.0 |
| | RP-31 | RP-060091 | 2754 | - | Clarification of UE action upon receiving the IE RB information to change list | 6.8.0 | 6.9.0 |
| | RP-31 | RP-060091 | 2755 | - | Removal of unnecessary checking for HS-DSCH and E-DCH configuration | 6.8.0 | 6.9.0 |
| | RP-31 | RP-060091 | 2756 | - | Introduction of WB-AMR default configuration without SRB#5 | 6.8.0 | 6.9.0 |
| | RP-31 | RP-060091 | 2757 | - | Initial DPCH frame offset for F-DPCH | 6.8.0 | 6.9.0 |
| | RP-31 | RP-060086 | 2760 | 1 | Support for different E-DCH and HS-DSCH serving cells | 6.8.0 | 6.9.0 |
| | RP-31 | RP-060088 | 2761 | - | Correction to S-CCPCH power offset for MBMS | 6.8.0 | 6.9.0 |
| | RP-31 | RP-060093 | 2764 | - | Inter-RAT PS Handover capability | 6.8.0 | 6.9.0 |
| | RP-31 | RP-060095 | 2765 | - | Indication of HSPA capability and conversation call type for CS | 6.8.0 | 6.9.0 |
| | RP-31 | RP-060097 | 2713 | 3 | Enabling the Providing of Velocity | 6.9.0 | 7.0.0 |

| Change history | | | | | | | |
|---|---|---|---|---|---|---|---|
| Date | TSG # | TSG Doc. | CR | Rev | Subject/Comment | Old | New |
| | RP-31 | RP-060096 | 2758 | | Release 7 HS-DSCH operation without a DL DPCH for 1.28 Mcps TDD – synchronisation and power control of UL DPCH via PLCCH | 6.9.0 | 7.0.0 |
| | RP-31 | RP-060098 | 2759 | | 7.68 Mcps TDD Option (Release 7) | 6.9.0 | 7.0.0 |
| | RP-31 | RP-060099 | 2762 | | Introduction of REL-7 access stratum release indicator | 6.9.0 | 7.0.0 |

# History

| Document history | | |
|---|---|---|
| V7.0.0 | March 2006 | Publication |
| | | |
| | | |
| | | |
| | | |