MOTOROLA E6 USER MANUAL

MOTOMANUAL

MOTOROKR™ E6

GSM

English

motorola.com

REGIONS 1016

MOTOROLA E6 USER MANUAL PAGE 2

MOTOROLA E6 USER MANUAL PAGE 3

HELLOMOTO

Introducing your new **MOTO**ROKR™ E6 GSM wireless phone. Here's a quick anatomy lesson.



Note: The above illustration is for reference only. There may be slight difference between the appearances of handset, keys and contents of display used in this manual and those of your handset. Please refer to your handset for actuality.

MOTOROLA E6 USER MANUAL PAGE 4



Side Up/Down Keys
Adjust volume, navigate menus.

Memory Card Slot
Insert SD memory card, store and retrieve multimedia content (music files, video clips, photos).

Media Player Keys

When the **RealOne media player** is active: Press ▶II to pause or play a file or playlist. Press ⏮ or ⏭ to play the previous or next file in a playlist. Press and hold ⏮ or ⏭ to rewind or fast forward.

When the **FM radio** is active: Press ▶II to mute/unmute the radio. Press ⏮ or ⏭ to select the previous or next channel.

Mini-USB Port
Insert battery charger or phone accessories.

Camera Key
Activate camera and take photos.

Phone Lock Switch
Lock phone to prevent unwanted key presses or touch-screen activation. Slide **down** to lock, slide **up** to unlock.

Note: Your phone may not appear as the phone image above, but all key locations, sequences and functions remained the same.

Note: The above illustration is for reference only. There may be slight difference between the appearances of handset, keys and contents of display used in this manual and those of your handset. Please refer to your handset for actuality.

MOTOROLA E6 USER MANUAL PAGE 5



Camera Key
Activate camera and take photos.

Camera Mode Switch
Slide **up** to set **normal** picture mode, slide **down** to set **macro** mode (for close-up shots of business cards or small objects).

Stylus
Use with touchscreen display.

Speaker
Listen to audio playback of music & video clips.

Camera Lens

Mirror
Aim camera lens for self-portraits.

Note: Your phone may not appear as the phone image above, but all key locations, sequences and functions remained the same.

Note: The above illustration is for reference only. There may be slight difference between the appearances of handset, keys and contents of display used in this manual and those of your handset. Please refer to your handset for actuality.

MOTOROLA E6 USER MANUAL PAGE 6

Motorola, Inc.
Consumer Advocacy Office
1307 East Algonquin Road
Schaumburg, IL 60196

www.hellomoto.com

Certain mobile phone features are dependent on the capabilities and settings of your service provider's network. Additionally, certain features may not be activated by your service provider, and/or the provider's network settings may limit the feature's functionality. Always contact your service provider about feature availability and functionality. All features, functionality, and other product specifications, as well as the information contained in this user's guide are based upon the latest available information and are believed to be accurate at the time of printing. Motorola reserves the right to change or modify any information or specifications without notice or obligation.

MOTOROLA and the Stylized M Logo are registered in the US Patent & Trademark Office. All other product or service names are the property of their respective owners. The Bluetooth trademarks are owned by their proprietor and used by Motorola, Inc. under license. Java and all other Java-based marks are trademarks or registered trademarks of Sun Microsystems, Inc. in the U.S. and other countries. Microsoft, Windows and Windows ME are registered trademarks of Microsoft Corporation; and Windows XP is a trademark of Microsoft Corporation.

© Motorola, Inc., 2006.

Caution: Changes or modifications made in the radio phone, not expressly approved by Motorola, will void the user's authority to operate the equipment.

Software Copyright Notice

The Motorola products described in this manual may include copyrighted Motorola and third-party software stored in semiconductor memories or other media. Laws in the United States and other countries preserve for Motorola and third-party software providers certain exclusive rights for copyrighted software, such as the exclusive rights to distribute or reproduce the copyrighted software. Accordingly, any copyrighted software contained in the Motorola products may not be modified, reverse-engineered, distributed, or reproduced in any manner to the extent allowed by law. Furthermore, the purchase of the Motorola products shall not be deemed to grant either directly or by implication, estoppel, or otherwise, any license under the copyrights, patents, or patent applications of Motorola or any third-party software provider, except for the normal, non-exclusive, royalty-free license to use that arises by operation of law in the sale of a product.

MOTOROLA E6 USER MANUAL PAGE 7

contents

Safety Information 8
Use and Care 13
EU Conformance 14
Recycling Information . 15
essentials 16
about this guide 16
SIM card. 16
battery 18
memory card 21
turn it on & off 22
make a call 23
answer a call. 23
your phone number . . 24
basics. 25
display 25
global navigation bar. . 26
application launcher . . 26
button bar 28
status bar 28
text entry 29
tap & hold 32
volume 32
navigation key. 33
speakerphone. 33
codes & passwords . . 34
lock & unlock phone . . 34
lock touch-screen & phone keys 35
share information 36
customize 38
profiles 38
wallpaper 39
color scheme 39
backlight 40
calls 41
recent calls 41
redial. 42
hold or mute a call . . . 43
call waiting 43
caller ID 43
cancel incoming call . . 44
emergency calls 44
international calls 45
turbo dial. 45
dial extension or voicemail number 46
dial extension number during a call 46

MOTOROLA E6 USER MANUAL PAGE 8

address book 47
view contact list 47
add new contact 48
create group 49
call or send message. . 49
search 50
sort 51
delete contact 51
storage location 51
copy contacts 52
categories 52
check capacity. 54
share contact. 55
synchronize contacts. . 55
owner's information . . 56

messages 57
message center. 57
signature 58
send text message . . . 59
send multimedia message 60
unsent messages 63
tips for sending messages 64
receive message 64
read and reply 66
store message object . 66
sort messages. 66
drafts 67
deleted messages 67
messages on SIM card 67
create folder 67
move messages 68
set up message service. 69
browser messages . . . 72
information service messages 73

office applications 75
email 75
calendar 82
tasks 87
notes 88
viewer 88
calculator 89
alarm clock 90
file manager. 91
business card reader . . 95

media applications 98
browser 98
RealOne media player 103
camera. 105
voice recorder 110
video camera 111
photo editor 111
FM radio 113

extra applications 116
talking phone 116
Bluetooth™ wireless . 116
synchronize phone information 120
modem 121

MOTOROLA E6 USER MANUAL PAGE 9

STK 122
world time 123

other features 124
advanced calling 124
setup 125
call times & costs . . . 128
handsfree 129
security 130

SAR Data 132

WHO Information 133

GNU License 134

index 135

MOTOROLA E6 USER MANUAL PAGE 97

business card reader

The business card reader application lets you use your phone's camera to capture a business card image, then store the card's information as a contact in the phone's electronic address book.

capture business card image

Tap **BCR (Business Card Reader)** in the application launcher screen to open the business card reader application.



Tip: Tap **Help** to see instructions on how to position and frame the business card that you want to capture.

Slide the camera mode switch **down** to put the camera lens in macro mode.



Tap **Capture Business Card** to activate the camera and open the Optical Character Recognition (OCR) viewfinder.

Use the red border in the OCR viewfinder to vertically frame the business card you want to capture. Position the camera so that the card fills the frame without extending beyond the frame borders. The framing border and center indicator turn green when the business card is properly framed.

MOTOROLA E6 USER MANUAL PAGE 98

Your phone automatically captures a business card image when the card is properly framed in the OCR viewfinder. (To activate or deactivate the auto-capture feature, see "business card reader settings" on page 97).

If auto-capture is turned off, press the camera key, tap **Capture**, or press the center key ◆ to capture the business card.

edit business card information

Your phone interprets the text on the captured business card image, and sorts the text into logical categories.

The character recognition software may misinterpret a text string or assign it to the wrong category. On the edit business card screen, tap a category name to change the assigned category. Tap the direct line in a category to edit its contents. If more categories are available, pull down the scroll bar on the right side of the screen to see and edit their contents.

To **add** another category to the list, tap ☰, then tap **Add Items**.

To **delete** one or more categories from the list, tap ☰, then tap **Delete Items**.

To **see the business card** while you edit its details, tap ☰, then tap **Show Card Image**.
To **move** the card image, tap and drag the image in the direction you want to move.
To **zoom in/out** on the card image, tap ☰, then tap **Zoom In** or **Zoom Out**. On the card image, tap the small box to the left of an outlined text string to see its assigned category and content in the upper part of the screen.

When you're finished editing business card details, tap **Save** to save the information as a new contact in your phone's address book.

MOTOROLA E6 USER MANUAL PAGE 99

business card reader settings

Tap ☰, then tap **Setup** to adjust business card reader settings.

Select **Auto Capture** to have your phone automatically capture a business card image when the card is properly framed in the OCR viewfinder.

You can set your phone to automatically **Delete Image** or **Save Image** for a captured business card after you save its contact information in the address book.

Use the **Always Show** list to select information categories that you always want to show in the edit business card screen.

recognize stored business card

To recognize and edit a business card image that you've already captured and stored on your phone, tap **BCR (Business Card Reader)** in the application launcher screen to open the business card reader application, tap ☰, tap **Open Business Card**, then tap the card you want to recognize and add to the contact list.

MOTOROLA E6 USER MANUAL PAGE 144

www.hellomoto.com

MOTOROLA and the Stylized M Logo are registered in the US Patent & Trademark office.
All other products or service names are the property of their respective owners.
The Bluetooth trademarks are owned by their proprietor and used by Motorola, Inc. under license.
© Motorola, Inc. 2006

Specifications are subject to change without notice

Part No: 6802925J30

Printed in India

MPL/18/07